

V.A.G Service.

Workshop Manual
Audi 100 1983 ►, Audi 200 1984 ►

Engine
Code letters

3B

Booklet

5 Cylinder F. I. engine
(4 valve), mechanics

Edition 05.89



V.A.G

Service Department, Technical Information

V.A.G Service.

**Repair Group Index to Workshop Manual
Audi 100 1983 ►, Audi 200 1984 ►**

Engine 3B **Code letters**

Booklet

5 Cylinder F.I. engine (4 valve), mechanics Edition 05/89

Please note, the technical supplements given here start at page 86

Refer.-Group	Workshop Bulletins
00 Technical data	
13 Crankshaft group	2
15 Cylinder head, valve gear	
17 Lubrication	4
19 Cooling	
20 Fuel supply system	
21 Exhaust gas turbocharging	3
26 Exhaust system	

Technical information should always be available to all formers and mechanics, because compliance with the instructions given is essential to ensure vehicle roadworthiness and safety. In addition, the normal safety precautions to be observed when working on motor vehicles are also applicable.


The Workshop Manual is only intended for use within the V.A.G Organisation, and passing on the third parties is not permitted.
© 1989, V.A.G AG

Printed : Corinna

Index

	Page
00 Technical data	
- Engine	6-1
- Gearbox	52-2
13 Crankshaft group	
- (130) 1.3 Litre assembly	1-4
- Crankshaft	1-5
- Drive belt	18-8
- Flywheel	13-17
- Main bearing assembly	1-4
- Timing chain and sprockets	10-11
- Timing belt	13-22
- Timing belt cover	4-21
- Timing belt tensioner	4-18
- Timing belt wheel	1-20
15 Cylinder head, valve gear	
- Assembly	5-1
- Camshaft assembly	5-8
- Removal	5-7
- Renewal	5-11
- Camshaft bearing	15-5
- Valve assembly	5-17
- Valve lifters	5-18
- Valve seat	5-21
- Valve stem seal	5-21
- Valve timing adjustment	15-21
- Valve train assembly	15-17
17 Lubrication	
- Bearing oil pressure	17-1
- Bearing oil pump	17-4
- Oil filter	17-17
- Oil filter assembly	17-18

17028



Intake Air Temperature Sensor



Location and Installation

The intake air and sensor block are mounted on the cylinder head.

Fig. 1

Vehicle Data

Vehicle Data	Value	Unit	Description
Engine characteristics			
Normal delivery	1100	kg/kW	Air delivery rate
AC	10		Delivery rate at 10 °C
Max. torque	0		Delivery rate before 10 °C
Delivery rate	0.125		Delivery rate after 10 °C
Delivery rate at 10 °C	0.125		Delivery rate after 10 °C
Delivery rate before 10 °C	0.125		Delivery rate before 10 °C
Delivery rate after 10 °C	0.125		Delivery rate after 10 °C
Delivery rate at 20 °C	0.125		Delivery rate at 20 °C
Delivery rate before 20 °C	0.125		Delivery rate before 20 °C
Delivery rate after 20 °C	0.125		Delivery rate after 20 °C
Delivery rate at 30 °C	0.125		Delivery rate at 30 °C
Delivery rate before 30 °C	0.125		Delivery rate before 30 °C
Delivery rate after 30 °C	0.125		Delivery rate after 30 °C
Delivery rate at 40 °C	0.125		Delivery rate at 40 °C
Delivery rate before 40 °C	0.125		Delivery rate before 40 °C
Delivery rate after 40 °C	0.125		Delivery rate after 40 °C
Delivery rate at 50 °C	0.125		Delivery rate at 50 °C
Delivery rate before 50 °C	0.125		Delivery rate before 50 °C
Delivery rate after 50 °C	0.125		Delivery rate after 50 °C
Delivery rate at 60 °C	0.125		Delivery rate at 60 °C
Delivery rate before 60 °C	0.125		Delivery rate before 60 °C
Delivery rate after 60 °C	0.125		Delivery rate after 60 °C
Delivery rate at 70 °C	0.125		Delivery rate at 70 °C
Delivery rate before 70 °C	0.125		Delivery rate before 70 °C
Delivery rate after 70 °C	0.125		Delivery rate after 70 °C
Delivery rate at 80 °C	0.125		Delivery rate at 80 °C
Delivery rate before 80 °C	0.125		Delivery rate before 80 °C
Delivery rate after 80 °C	0.125		Delivery rate after 80 °C
Delivery rate at 90 °C	0.125		Delivery rate at 90 °C
Delivery rate before 90 °C	0.125		Delivery rate before 90 °C
Delivery rate after 90 °C	0.125		Delivery rate after 90 °C
Delivery rate at 100 °C	0.125		Delivery rate at 100 °C
Delivery rate before 100 °C	0.125		Delivery rate before 100 °C
Delivery rate after 100 °C	0.125		Delivery rate after 100 °C
Exhaust gas recirculation			
Delivery rate	0.125		Delivery rate
Delivery rate before 10 °C	0.125		Delivery rate before 10 °C
Delivery rate after 10 °C	0.125		Delivery rate after 10 °C
Delivery rate before 20 °C	0.125		Delivery rate before 20 °C
Delivery rate after 20 °C	0.125		Delivery rate after 20 °C
Delivery rate before 30 °C	0.125		Delivery rate before 30 °C
Delivery rate after 30 °C	0.125		Delivery rate after 30 °C
Delivery rate before 40 °C	0.125		Delivery rate before 40 °C
Delivery rate after 40 °C	0.125		Delivery rate after 40 °C
Delivery rate before 50 °C	0.125		Delivery rate before 50 °C
Delivery rate after 50 °C	0.125		Delivery rate after 50 °C
Delivery rate before 60 °C	0.125		Delivery rate before 60 °C
Delivery rate after 60 °C	0.125		Delivery rate after 60 °C
Delivery rate before 70 °C	0.125		Delivery rate before 70 °C
Delivery rate after 70 °C	0.125		Delivery rate after 70 °C
Delivery rate before 80 °C	0.125		Delivery rate before 80 °C
Delivery rate after 80 °C	0.125		Delivery rate after 80 °C
Delivery rate before 90 °C	0.125		Delivery rate before 90 °C
Delivery rate after 90 °C	0.125		Delivery rate after 90 °C
Delivery rate before 100 °C	0.125		Delivery rate before 100 °C
Delivery rate after 100 °C	0.125		Delivery rate after 100 °C
Intake air temperature sensor			
Delivery rate	0.125		Delivery rate
Delivery rate before 10 °C	0.125		Delivery rate before 10 °C
Delivery rate after 10 °C	0.125		Delivery rate after 10 °C
Delivery rate before 20 °C	0.125		Delivery rate before 20 °C
Delivery rate after 20 °C	0.125		Delivery rate after 20 °C
Delivery rate before 30 °C	0.125		Delivery rate before 30 °C
Delivery rate after 30 °C	0.125		Delivery rate after 30 °C
Delivery rate before 40 °C	0.125		Delivery rate before 40 °C
Delivery rate after 40 °C	0.125		Delivery rate after 40 °C
Delivery rate before 50 °C	0.125		Delivery rate before 50 °C
Delivery rate after 50 °C	0.125		Delivery rate after 50 °C
Delivery rate before 60 °C	0.125		Delivery rate before 60 °C
Delivery rate after 60 °C	0.125		Delivery rate after 60 °C
Delivery rate before 70 °C	0.125		Delivery rate before 70 °C
Delivery rate after 70 °C	0.125		Delivery rate after 70 °C
Delivery rate before 80 °C	0.125		Delivery rate before 80 °C
Delivery rate after 80 °C	0.125		Delivery rate after 80 °C
Delivery rate before 90 °C	0.125		Delivery rate before 90 °C
Delivery rate after 90 °C	0.125		Delivery rate after 90 °C
Delivery rate before 100 °C	0.125		Delivery rate before 100 °C
Delivery rate after 100 °C	0.125		Delivery rate after 100 °C



100-21100-44-SSB103-03-16-078

10. 10.

- **Wear** on the left wheel, gearbox and flywheel on shafts
- **Friction** between housing and housing
- **Friction** and **interlocking** pump
- **Friction** and **interlocking**
- **Friction** in gearbox - **bottom**

10. 11.

11. Faulty belt

- **Tensioning belt**
- **Friction** = $\mu \times F_{\text{normal}}$
- **Interlocking** = $\mu \times F_{\text{normal}}$

10. 12.

12. **Friction** between bottom roller (right)

10. 13.

- **Friction** between
- **Friction** between **bottom** and **top**

10. 14.

13. Friction

100-

14. **Friction** (Fig. 1, 2020) = $F_{\text{normal}} \cdot \mu$

15. **Friction** = $F_{\text{normal}} \cdot \mu$

16. Friction

- **Friction** between **bottom** friction roller and **bottom** bearing housing
- **Friction** between **bottom** friction roller and **bottom** bearing housing
- **Friction** between **bottom** friction roller and **bottom** bearing housing
- **Friction** between **bottom** friction roller and **bottom** bearing housing

17. Friction

18. Tensioning belt

19. Interlocking

- **Friction** = $F_{\text{normal}} \cdot \mu$
- **Friction** = $F_{\text{normal}} \cdot \mu$

20. Friction

- **Friction** = $F_{\text{normal}} \cdot \mu$


21. Friction

- **Friction** = $F_{\text{normal}} \cdot \mu$
- **Friction** = $F_{\text{normal}} \cdot \mu$

22. Friction

100-

100-



Exploded view of cylinder head assembly

1. Intake

2. Air cleaner

3. IAT sensor

4. IAT sensor

5. IAT sensor

6. IAT sensor

7. IAT sensor

8. Cylinder head

▼ Verify the cylinder head
bolts are torqued to specification.

9. Intake air temperature

sensor

- Check the intake air temperature sensor position. The sensor must be located at the port furthest from the intake air inlet pipe.
- Verify mounting bolt torque specification.

10. IAT sensor

11. IAT sensor

12. Intake air temperature

sensor

13. Intake air temperature

sensor

14. Intake air temperature

sensor

- Verify the intake air temperature sensor position. The intake air temperature sensor must be located at the port furthest from the intake air inlet pipe.
- Verify mounting bolt torque specification.

15. Intake air temperature

sensor

- Verify the intake air temperature sensor position. The intake air temperature sensor must be located at the port furthest from the intake air inlet pipe.
- Verify mounting bolt torque specification.

16. Intake air temperature



sensor

- Verify the intake air temperature sensor position. The intake air temperature sensor must be located at the port furthest from the intake air inlet pipe.
- Verify mounting bolt torque specification.

17. Intake air temperature


sensor

- Verify the intake air temperature sensor position. The intake air temperature sensor must be located at the port furthest from the intake air inlet pipe.
- Verify mounting bolt torque specification.



18. Cylinder head bolt

► Verify the cylinder head bolt torque specification.



→ Fig. 2: Removing and installing camshaft sprocket


Tightening torque: M6, Nm.

Use special tools 2079 and 2084.


- Then proceed with removal of both front and rear cylinder heads.

Important: The cylinder heads must be removed in pairs, i.e. cylinder head 1 and 2, and cylinder head 3 and 4, in the sequence indicated below.

Important: The cylinder heads must be cleaned thoroughly before assembly.



→ Fig. 3: Removing idler pulley using puller




→ Fig. 4: Preparing and installing flywheel

Important: The flywheel will suddenly drop sharply. Watch.

- To avoid trapping hands, the flywheel must be held onto the flywheel.

Important: Ensure that the tightening bolts when retightening.

- During retightening the two retaining bolts must be tightened to 110 Nm and further tightened by another 90°.




→ Fig. 5:

Thread two hex socket screws into the flywheel bolts of the flywheel. The bolts do not have to engage these screws and the hexagon heads need not be.


- When retightening the two retaining bolts, by hand and then tighten the bolts to 110 Nm and further by another 90°.





Cylinder head cover


- Mark on cylinder cover must align with upper edge of cylinder head.



Cylinder head cover


- Mark on cylinder cover must align with upper edge of cylinder head.

137




- Turn cylinder head cover clockwise toward 12 o'clock and remove cylinder cover. Counter-clockwise turn cylinder head cover counter-clockwise toward 12 o'clock.

Note:
When removing cylinder cover, the cylinder head must not receive damage between the cylinder head flange and cylinder cover flange.




- Set cylinder cover to 12 o'clock position.


Note:
Cylinder cover to cylinder block must be 10 mm or cylinder housing.



- **After** - **Timing belt** - **Check** for damage, adjustment procedure
and tensioning.
- **Install** the **camshaft bearing**.
- **Install** the **intake air cleaner**.
- **Reinstall** the **drive belt**, **oil** and **radiator** and **check** the **coolant**.



- **After** - **Timing belt** - **Check** for damage, adjustment procedure
and tensioning.




- **It** **should** **not** **be** **possible** **to** **turn** **the** **tensioner** **bolt** **with** **your** **hand** **and** **there** **should** **be** **a** **gap** **between** **the** **tensioner** **and** **the** **camshaft**.
- **Check** **camshaft** **bearing** **play** **at** **10** **N**.
- **Turn** **camshaft** **two** **full** **turns** **and** **check** **camshaft**.
- **Check** **base** **setting** **of** **camshaft** - **approx** **0.6** **mm**
max **allowable** **error** **approx** **0.1** **mm** **and** **min** **error** **approx** **-0.1** **mm**.



- **Reusing** **M6** **screws** **when** **reassembly**
- **Remove** **old** **clip** **mounting**.
- **Intake air** - **intake** **air** **cleaner** **and** **filter**.
- **Install** **new** **clip** **mounting**.






Front View A 13-498 (Fig. 1)


- Detach the front lighting connection from the body.
 - Slacken off the tensioner pulley bolt (C) and the fan belt (B) from the fan and bolt (D) from the water pump.
- Note:**
The alternator must now rotate, after the starting motor has been disconnected.
- Release belt (B) by turning tensioner pulley (C), with a torque wrench and tighten again when locking bolt (D) is fitted.
- | | |
|--------------|-------|
| Max. W. belt | 10 Nm |
| Used / max. | 8 Nm |
- Check tension by deflecting belt (B) by 10 mm.
- | | |
|--------------|-------|
| Max. W. belt | 10 Nm |
| Used / max. | 8 Nm |
- Tighten the tensioner securing bolts (C) to 10 Nm, and tighten locking bolt (D) to 8 Nm.

(2-3)




Front View B 13-499 (Fig. 2)

- Note:**
The threads on the P.V.C. belt (2) are liable to damage when being fitted, so it is particularly suitable for short distances.
- - slacken bolts (1).
 - Slacken nut (2).
 - Turn tensioner bolt (3) as appropriate.
 - Check the belt by deflecting belt (2) by 10 mm.
- Deflect on the path of the deflected end of belt (2) approx. 10 mm.
- Tighten securing bolts (1) and securing nut (2) to 8 Nm.



1. 12



1. CYLINDER AND ASSEMBLING ORIFICES

ASSEMBLING CYLINDER AND ORIFICES

Notes:

- Before oil injection, oil rings, and oil seal are applied.
- Do not rotate cylinder when checking radial clearance.

1. CYLINDER OIL GROOVES

2. CYLINDER PLATE

• Lubricate

3. CYLINDER

- Fit oil groove to oil plate


4. CYLINDER CASE

- Fit oil groove to cylinder case
- Fit bearing bags on bearing shells with oil ring
- Well fit bore surfaces

5. CYLINDER

- Lubricate
 - Bearing parts
 - Fit well into bearing housing
 - Compound - see

[13-495]



6. CYLINDER BEARING

- Pulling out - see Fig. 1 page 13-1
- Inserting in - see Fig. 2 page 13-17
- After fitting the bearing the following steps must be carried out:

7. CYLINDER

- Remove and refit during turning cylinder. Turn it.
- Fit injection timing pin subsets directly - see page 13-13 onward

8. OIL SEAL

- Press out using special tool 1000 - see page 13-12
- Lightly coat sealing lip and outer edge with oil.
- Offer up with 1000 and
- Press home using 1000 - see Fig. 4 page 13-13


9. CYLINDER CYLINDERS (PAIR)

10. CYLINDER CYLINDER GASKET


• Replace


[13-495]

13-14




- 13-495
- Callout 1:** Measure axial clearance - Fig. 7
• 13-22
• Max. value ... 0.03 mm
• Min. value ... 0.01 mm
 - Callout 2:** Measure radial clearance with micrometer - Fig. 11.
• Rev. 11-16 ... 0.016 mm
• Rev. 11-17 ... 0.017 mm
 - Callout 3:** Check clearance
page 14-22
 - Callout 4:** Check bearing
• Fit cap
• Push bearing off of engine
 - Callout 5:** Bearing cap 14
• Complete with thrust washers
• For cylinder sizes 11, 12, 13,
• For cylinder sizes 14, 15, 16
• Thrust washers
 - Callout 6:** Piston rings
• For cylinder sizes 11, 12, 13,
• Thrust washers
 - Callout 7:** Bearing size 15, 16, 17, 18, 19 and 20
• Fit cap with oil hole
• For cylinder sizes 11, 12, 13
• Do not intermix with bearing
size 14
• Relining tool must engage correctly
in crankshaft bearing cap
 - Callout 8:** Oil pump gear
- 13-495






→ Fig. 1 Axle bearing cap being removed

- Remove using bearing extractor and holding tool 2086 (VAG 432) ... 120 mm long 2003/1.




→ Fig. 2 Pressing-in needle bearing

- After installation the bearing size must be clearly visible.
- Check bearing noise with a ratchet using tool 432.



→ Fig. 3 Pressing-in oil seal (without seal, flange side)



→ Fig. 4 Pressing-in oil seal (with seal, flange side)

- Directly coat sealing lip and outer edge of seal with oil before installing.
- Lubricate oil seal using a brush 2003/1.
- Press home oil seal using special tool 2003/1.




Fig. 9 Replacing crankshaft oil seal, pulley end



Fig. 10 Type 75/30 flywheel seal, front. Push pin and oil seal over bearing bush.

• lightly heat welding lip the outer edge of seal with a burner protecting oil.

Caution
Protect oil from any heat sources other than the burner.

• After welding allow seal to cool down.
Push in using front cover flange.

100




Fig. 11 Oil seal - replacing axial clearance

Measure axial clearance at front A bearing (inner bearing).
Need $\approx 0.01 \dots 0.03$ mm
Actual \leq max. 0.040 mm

101
102

DETAILED PARTS LUBRICATION OF BRAKE CALIPER

Brake

Brake fluid cannot be mixed with Bleeding oil even if it may be in a can.

Braking system oil bleeding points


	Color	Code	Location	Order
C.001	Red	100-1	Front left	1
C.002	Red	100-1	Front right	2
C.003	Blue	100-1	Rear left	3

- Turn the engine off.

→ Check bleed and vent line bleed ports.

- Place Bleeding pump in front of the bearing 361110-01 and connect.

- Bleed air and then turn tight the 361110-01.



- Turn bleeding cap off again.

- Reapply air to the system with bleeding pump.


→ Turn bleed and vent line bleed ports.

→ Turn

Brake master cylinder

Brake master cylinder	Brake master cylinder internal	Brake master cylinder external	Brake master cylinder internal
Master cylinder	0.001	0.001	0.002
Brake master cylinder internal	0.001	0.001	0.002
Brake master cylinder external	0.001	0.001	0.002
Brake master cylinder internal	0.001	0.001	0.002
Brake master cylinder internal	0.001	0.001	0.002
Brake master cylinder internal	0.001	0.001	0.002






► Correct flywheel key installation

Do not bend and strain starting flywheel keys.

Note: If the ignition timing is not correct, the engine will not start. This is due to the electronic ignition system. It cannot receive control signals from the ignition control unit.

Drive ignition timing points must be fixed to each other.


Angular distance between cam rod timing pulses sender 6.10 mm (0.240 in) between flywheel and engine speed sender 6.20 mm (0.236 in).



► Correct flywheel key installation


Do not bend and strain starting flywheel keys.

TS-27



► Correct flywheel key installation

Correct timing pulse sender 6.10 mm (0.240 in) between flywheel and engine speed sender
Angular gap = 1.40 ± 0.10 mm




► Correct flywheel key installation

Correct timing pulse sender 6.10 mm (0.240 in) between flywheel and engine speed sender

Angular gap = 1.40 ± 0.10 mm


TS-28



→ Part 11: Front wheel assembly

- Front wheel assembly fitting & new bearing.
- Tighten hub nut 35 - 40 Nm (350 - 400 kgf cm).

13-71



REPAIRING THE DISC BRAKE SYSTEM

1. Front wheel assembly

- Front wheel assembly fitting & new bearing.
- Tighten hub nut 35 - 40 Nm (350 - 400 kgf cm).
- Removing and installing with master cylinder piston (Fig. 2)
- Checking clearance in piston - Fig. 3
- Checking ring gap - Fig. 4


2. Front wheel

- Checking - Fig. 5
- Disk distribution, see Fig. 6 and 7 (Fig. 6) - Fig. 7
- Inspect using pointer ring chart - Fig. 8
- Check for broken shear points or surface, etc.
- Front wheel clearance - part 13-21

3. Spoke:

- Wheel spoke breakage
- Bent spoke (bendy) - Fig. 11
- Inspect front wheel - front wheel hub

13-72



- 1. Mounting housing (1)**
- Use a cylindrical punch tool.
 - Insert bearing assembly (2) into housing (1), point towards bearing end.

- 2. SH-100 - 1/2" x 1-1/2" (30x38)**
- Use correct clearance.
 - Use measuring end of clearance gauge to 0.001 in and 0.002 in.


- 3. Shims**
- Refer to Fig. 3.

- 4. Bearing cap (9)**
- It is difficult to remove seal assembly from housing. Use a special tool (see Fig. 4) for removing seal during assembly.

5. Mounting housing

- 6. Mounting housing**
- Preheat oil bath to 100° F.
 - Align housing (1) with housing (3).
 - Align housing (1) with housing (3).

12-27




- 11. Securing seal**
- Bolt assembly or pinion.
 - Do not overcharge used bearing flange.
 - Ensure that retainer ring locate is recessed in bearing cap and housing.
 - Measuring used clearance
 - Fig. 3
Upper limit: 0.4 mm
Lower limit: 0.3 mm
 - Checking radial clearance with thickness - page 14-53
Nom: 0.510 - 0.057 mm
Upper limit: 0.517 mm

Note:
For correct operation, obtain correct radial clearance.

- 12. Oil seals**
- Use cleaning solvent.

13. Oil


12-28



→ Fig. 1 Checking piston ring gap (1)

- Turn the engine over clockwise.
- Measure the gap in the outer edge of the piston ring groove.
- Stop or stepped ring must face towards piston pin.


[B-203]



→ Fig. 2 Checking piston ring gap (2)

[B-345]


15-27



→ Fig. 3 Checking piston ring clearance in groove

New: 0.04 ... 0.17 mm
Used: 0.17 mm

[B-015]



→ Fig. 4 Checking piston clearance

Push piston assembly into lower end of cylinder until it is about 15 mm from bottom edge.


New: 0.11 ... 0.35 mm
Used: 0.35 mm

15-28


Motor, 4cyl 61.312

Operating dimension	7. Motor size	9.1. 61.312
Outer width, mm	601.92	61.01
Outer height, mm	611.71	61.09
Outer length, mm	1414.00	61.11

13-31



► 13 - 005, 61.312, 61.312P




► 13-005, 61.312, 61.312P

Remove piston pin shells from bottom of piston 11.50 ° to piston pin axis.


Minimum deviation from normal dimensions: 0.04 mm

13-32




► Fig. 5: Aligning intake air ports

Align the intake air ports towards the plenum. See Work note 13-456.



► Fig. 6: Removing and installing piston

• Use piston ring film or similar.



► Fig. 7: Measuring cylinder bores


Measure bores at three locations in each direction, i.e., 1, 2, 3. Turn the engine assembly clockwise with the crankshaft.

Use micrometer and gauge rod = 100 mm.

Normal deviation from nominal dimensions max. 0.05 mm.


Further see cylinder diameter (1) - page 11-2-2.

Note:
Measuring the cylinder bore might not be easy when the cylinder block is mounted at a certain angle with respect to 90°, as the correct measurement would then be impossible.



► Fig. 8: Measuring cylinder bore dia.

dial caliper, min. 150 mm



REMOVING AND INSTALLATION

NOTE

It is essential to have visual clearance between the bearing outer ring and oil seal.

→ Measuring gauge 01.01.11903 (Fig. 1)

Max.	Min.	Unit
0.020 - 0.070 mm	0.1 mm	mm
0.050 - 0.100 mm	0.00	mm
0.100 - 0.150 mm	0.010	mm

• Remove ring and retaining cap.

• Clean shaft and crank arm.

• Fit new bearing sleeve corresponding to width of crank arm and check in lateral direction of inner bearing shell.
• If desired radial clearance, install ring and replace bearing sleeve on shaft with fingers.

01.01.00 → 01.01.11903
• 01.01.00 remove sleeve


• Fit bearing sleeve on shaft.

→ Check bearing clearance with measuring scale.

Max. = 0.010 - 0.012 mm

Max. limit = 0.00 mm

01.02



REMOVING AND INSTALLING CYLINDER HEAD

INSTRUMENTS

- Dial caliper and measuring tape for the cylinder head.
- Thread lock compound - one bottle.
- The cylinder head can be removed after the engine is cold.
- Valve lock - 1 week after assembly of the cylinder assembly will be over.
- When installing a replacement cylinder head, all the contact surfaces between the cylinder head and the cylinder block must be cleaned.

TOOLS

When new cylinder heads have been installed, the engine may run at an incorrect temperature. Therefore, the cylinder head must be cooled with water or oil.

REMOVING CYLINDER HEAD (page 22-4)

1-22-3

1-22-4

1-22-5

1-22-6

1-22-7

4- Cylinder head

- Check the cylinder head for cracks, etc.
- Reusing and installing cylinder head page 22-4

5- Cylinder head gasket

- Fit the gasket.
- Ensure the contact surface is clean.
- The sealing surface of the cylinder head must face the cylinder head.
- Fit the gasket over cylinder head in the correct direction.


6- Cylinder head


7- Aligning cylinder head

8- Cylinder head bolt

10- Cylinder head cover


- Remove the cylinder head cover before cleaning the cylinder head.





[11-106]

11-3



REMOVING AND INSTALLING CYLINDER HEAD

Note:
Before installing cylinder head, ensure that crankshaft oil pressure relief valve is set to TDC.


The cylinder head is fitted to the cylinder block. The word "TOP" on the Part No. must face the cylinder head (with pattern of "TOP").

• Insert cylinder head gasket, fit cylinder head bolts and tighten by hand.

Note:

• Install cylinder head after cylinder block.

• Do not damage cylinder head base.



→ engine cylinder availability in different stages.
available = yes different

Starting cylinder stage 0/1

Stage	1	2	3
Stage 0	1	2	3
Stage 1	1	2	3
Stage 2	1	2	3

number = even more operator without stopping.

1 = 50% of the time limit 100%

0/2/3

- starting cylinder 1, 2 and 3, reverse sequence
- 1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 14, 15, 16, 17, 18, 19, 20, 21, 22, 23, 24, 25, 26, 27, 28, 29, 30, 31, 32, 33, 34, 35, 36, 37, 38, 39, 40, 41, 42, 43, 44, 45, 46, 47, 48, 49, 50, 51, 52, 53, 54, 55, 56, 57, 58, 59, 60, 61, 62, 63, 64, 65, 66, 67, 68, 69, 70, 71, 72, 73, 74, 75, 76, 77, 78, 79, 80, 81, 82, 83, 84, 85, 86, 87, 88, 89, 90, 91, 92, 93, 94, 95, 96, 97, 98, 99, 100, 101, 102, 103, 104, 105, 106, 107, 108, 109, 110, 111, 112, 113, 114, 115, 116, 117, 118, 119, 120, 121, 122, 123, 124, 125, 126, 127, 128, 129, 130, 131, 132, 133, 134, 135, 136, 137, 138, 139, 140, 141, 142, 143, 144, 145, 146, 147, 148, 149, 150, 151, 152, 153, 154, 155, 156, 157, 158, 159, 160, 161, 162, 163, 164, 165, 166, 167, 168, 169, 170, 171, 172, 173, 174, 175, 176, 177, 178, 179, 180, 181, 182, 183, 184, 185, 186, 187, 188, 189, 190, 191, 192, 193, 194, 195, 196, 197, 198, 199, 200, 201, 202, 203, 204, 205, 206, 207, 208, 209, 210, 211, 212, 213, 214, 215, 216, 217, 218, 219, 220, 221, 222, 223, 224, 225, 226, 227, 228, 229, 230, 231, 232, 233, 234, 235, 236, 237, 238, 239, 240, 241, 242, 243, 244, 245, 246, 247, 248, 249, 250, 251, 252, 253, 254, 255, 256, 257, 258, 259, 260, 261, 262, 263, 264, 265, 266, 267, 268, 269, 270, 271, 272, 273, 274, 275, 276, 277, 278, 279, 280, 281, 282, 283, 284, 285, 286, 287, 288, 289, 290, 291, 292, 293, 294, 295, 296, 297, 298, 299, 300, 301, 302, 303, 304, 305, 306, 307, 308, 309, 310, 311, 312, 313, 314, 315, 316, 317, 318, 319, 320, 321, 322, 323, 324, 325, 326, 327, 328, 329, 330, 331, 332, 333, 334, 335, 336, 337, 338, 339, 340, 341, 342, 343, 344, 345, 346, 347, 348, 349, 350, 351, 352, 353, 354, 355, 356, 357, 358, 359, 360, 361, 362, 363, 364, 365, 366, 367, 368, 369, 370, 371, 372, 373, 374, 375, 376, 377, 378, 379, 380, 381, 382, 383, 384, 385, 386, 387, 388, 389, 390, 391, 392, 393, 394, 395, 396, 397, 398, 399, 400, 401, 402, 403, 404, 405, 406, 407, 408, 409, 410, 411, 412, 413, 414, 415, 416, 417, 418, 419, 420, 421, 422, 423, 424, 425, 426, 427, 428, 429, 430, 431, 432, 433, 434, 435, 436, 437, 438, 439, 440, 441, 442, 443, 444, 445, 446, 447, 448, 449, 450, 451, 452, 453, 454, 455, 456, 457, 458, 459, 460, 461, 462, 463, 464, 465, 466, 467, 468, 469, 470, 471, 472, 473, 474, 475, 476, 477, 478, 479, 480, 481, 482, 483, 484, 485, 486, 487, 488, 489, 490, 491, 492, 493, 494, 495, 496, 497, 498, 499, 500, 501, 502, 503, 504, 505, 506, 507, 508, 509, 510, 511, 512, 513, 514, 515, 516, 517, 518, 519, 520, 521, 522, 523, 524, 525, 526, 527, 528, 529, 530, 531, 532, 533, 534, 535, 536, 537, 538, 539, 540, 541, 542, 543, 544, 545, 546, 547, 548, 549, 550, 551, 552, 553, 554, 555, 556, 557, 558, 559, 560, 561, 562, 563, 564, 565, 566, 567, 568, 569, 570, 571, 572, 573, 574, 575, 576, 577, 578, 579, 580, 581, 582, 583, 584, 585, 586, 587, 588, 589, 589, 590, 591, 592, 593, 594, 595, 596, 597, 598, 599, 600, 601, 602, 603, 604, 605, 606, 607, 608, 609, 610, 611, 612, 613, 614, 615, 616, 617, 618, 619, 620, 621, 622, 623, 624, 625, 626, 627, 628, 629, 630, 631, 632, 633, 634, 635, 636, 637, 638, 639, 640, 641, 642, 643, 644, 645, 646, 647, 648, 649, 650, 651, 652, 653, 654, 655, 656, 657, 658, 659, 660, 661, 662, 663, 664, 665, 666, 667, 668, 669, 669, 670, 671, 672, 673, 674, 675, 676, 677, 678, 679, 679, 680, 681, 682, 683, 684, 685, 686, 687, 688, 689, 689, 690, 691, 692, 693, 694, 695, 696, 697, 698, 699, 699, 700, 701, 702, 703, 704, 705, 706, 707, 708, 709, 709, 710, 711, 712, 713, 714, 715, 716, 717, 718, 719, 719, 720, 721, 722, 723, 724, 725, 726, 727, 728, 729, 729, 730, 731, 732, 733, 734, 735, 736, 737, 738, 739, 739, 740, 741, 742, 743, 744, 745, 746, 747, 748, 749, 749, 750, 751, 752, 753, 754, 755, 756, 757, 758, 759, 759, 760, 761, 762, 763, 764, 765, 766, 767, 768, 769, 769, 770, 771, 772, 773, 774, 775, 776, 777, 778, 779, 779, 780, 781, 782, 783, 784, 785, 786, 787, 788, 789, 789, 790, 791, 792, 793, 794, 795, 796, 797, 798, 799, 799, 800, 801, 802, 803, 804, 805, 806, 807, 808, 809, 809, 810, 811, 812, 813, 814, 815, 816, 817, 818, 819, 819, 820, 821, 822, 823, 824, 825, 826, 827, 828, 829, 829, 830, 831, 832, 833, 834, 835, 836, 837, 838, 839, 839, 840, 841, 842, 843, 844, 845, 846, 847, 848, 849, 849, 850, 851, 852, 853, 854, 855, 856, 857, 858, 859, 859, 860, 861, 862, 863, 864, 865, 866, 867, 868, 869, 869, 870, 871, 872, 873, 874, 875, 876, 877, 878, 879, 879, 880, 881, 882, 883, 884, 885, 886, 887, 888, 889, 889, 890, 891, 892, 893, 894, 895, 896, 897, 898, 899, 899, 900, 901, 902, 903, 904, 905, 906, 907, 908, 909, 909, 910, 911, 912, 913, 914, 915, 916, 917, 918, 919, 919, 920, 921, 922, 923, 924, 925, 926, 927, 928, 929, 929, 930, 931, 932, 933, 934, 935, 936, 937, 938, 939, 939, 940, 941, 942, 943, 944, 945, 946, 947, 948, 949, 949, 950, 951, 952, 953, 954, 955, 956, 957, 958, 959, 959, 960, 961, 962, 963, 964, 965, 966, 967, 968, 969, 969, 970, 971, 972, 973, 974, 975, 976, 977, 978, 979, 979, 980, 981, 982, 983, 984, 985, 986, 987, 988, 989, 989, 990, 991, 992, 993, 994, 995, 996, 997, 998, 999, 999, 1000, 1001, 1002, 1003, 1004, 1005, 1006, 1007, 1008, 1009, 1009, 1010, 1011, 1012, 1013, 1014, 1015, 1016, 1017, 1018, 1019, 1019, 1020, 1021, 1022, 1023, 1024, 1025, 1026, 1027, 1028, 1029, 1029, 1030, 1031, 1032, 1033, 1034, 1035, 1036, 1037, 1038, 1039, 1039, 1040, 1041, 1042, 1043, 1044, 1045, 1046, 1047, 1048, 1049, 1049, 1050, 1051, 1052, 1053, 1054, 1055, 1056, 1057, 1058, 1059, 1059, 1060, 1061, 1062, 1063, 1064, 1065, 1066, 1067, 1068, 1069, 1069, 1070, 1071, 1072, 1073, 1074, 1075, 1076, 1077, 1078, 1079, 1079, 1080, 1081, 1082, 1083, 1084, 1085, 1086, 1087, 1088, 1089, 1089, 1090, 1091, 1092, 1093, 1094, 1095, 1096, 1097, 1098, 1099, 1099, 1100, 1101, 1102, 1103, 1104, 1105, 1106, 1107, 1108, 1109, 1109, 1110, 1111, 1112, 1113, 1114, 1115, 1116, 1117, 1118, 1119, 1119, 1120, 1121, 1122, 1123, 1124, 1125, 1126, 1127, 1128, 1129, 1129, 1130, 1131, 1132, 1133, 1134, 1135, 1136, 1137, 1138, 1139, 1139, 1140, 1141, 1142, 1143, 1144, 1145, 1146, 1147, 1148, 1149, 1149, 1150, 1151, 1152, 1153, 1154, 1155, 1156, 1157, 1158, 1159, 1159, 1160, 1161, 1162, 1163, 1164, 1165, 1166, 1167, 1168, 1169, 1169, 1170, 1171, 1172, 1173, 1174, 1175, 1176, 1177, 1178, 1179, 1179, 1180, 1181, 1182, 1183, 1184, 1185, 1186, 1187, 1188, 1189, 1189, 1190, 1191, 1192, 1193, 1194, 1195, 1196, 1197, 1198, 1199, 1199, 1200, 1201, 1202, 1203, 1204, 1205, 1206, 1207, 1208, 1209, 1209, 1210, 1211, 1212, 1213, 1214, 1215, 1216, 1217, 1218, 1219, 1219, 1220, 1221, 1222, 1223, 1224, 1225, 1226, 1227, 1228, 1229, 1229, 1230, 1231, 1232, 1233, 1234, 1235, 1236, 1237, 1238, 1239, 1239, 1240, 1241, 1242, 1243, 1244, 1245, 1246, 1247, 1248, 1249, 1249, 1250, 1251, 1252, 1253, 1254, 1255, 1256, 1257, 1258, 1259, 1259, 1260, 1261, 1262, 1263, 1264, 1265, 1266, 1267, 1268, 1269, 1269, 1270, 1271, 1272, 1273, 1274, 1275, 1276, 1277, 1278, 1279, 1279, 1280, 1281, 1282, 1283, 1284, 1285, 1286, 1287, 1288, 1289, 1289, 1290, 1291, 1292, 1293, 1294, 1295, 1296, 1297, 1298, 1299, 1299, 1300, 1301, 1302, 1303, 1304, 1305, 1306, 1307, 1308, 1309, 1309, 1310, 1311, 1312, 1313, 1314, 1315, 1316, 1317, 1318, 1319, 1319, 1320, 1321, 1322, 1323, 1324, 1325, 1326, 1327, 1328, 1329, 1329, 1330, 1331, 1332, 1333, 1334, 1335, 1336, 1337, 1338, 1339, 1339, 1340, 1341, 1342, 1343, 1344, 1345, 1346, 1347, 1348, 1349, 1349, 1350, 1351, 1352, 1353, 1354, 1355, 1356, 1357, 1358, 1359, 1359, 1360, 1361, 1362, 1363, 1364, 1365, 1366, 1367, 1368, 1369, 1369, 1370, 1371, 1372, 1373, 1374, 1375, 1376, 1377, 1378, 1379, 1379, 1380, 1381, 1382, 1383, 1384, 1385, 1386, 1387, 1388, 1389, 1389, 1390, 1391, 1392, 1393, 1394, 1395, 1396, 1397, 1398, 1399, 1399, 1400, 1401, 1402, 1403, 1404, 1405, 1406, 1407, 1408, 1409, 1409, 1410, 1411, 1412, 1413, 1414, 1415, 1416, 1417, 1418, 1419, 1419, 1420, 1421, 1422, 1423, 1424, 1425, 1426, 1427, 1428, 1429, 1429, 1430, 1431, 1432, 1433, 1434, 1435, 1436, 1437, 1438, 1439, 1439, 1440, 1441, 1442, 1443, 1444, 1445, 1446, 1447, 1448, 1449, 1449, 1450, 1451, 1452, 1453, 1454, 1455, 1456, 1457, 1458, 1459, 1459, 1460, 1461, 1462, 1463, 1464, 1465, 1466, 1467, 1468, 1469, 1469, 1470, 1471, 1472, 1473, 1474, 1475, 1476, 1477, 1478, 1479, 1479, 1480, 1481, 1482, 1483, 1484, 1485, 1486, 1487, 1488, 1489, 1489, 1490, 1491, 1492, 1493, 1494, 1495, 1496, 1497, 1498, 1499, 1499, 1500, 1501, 1502, 1503, 1504, 1505, 1506, 1507, 1508, 1509, 1509, 1510, 1511, 1512, 1513, 1514, 1515, 1516, 1517, 1518, 1519, 1519, 1520, 1521, 1522, 1523, 1524, 1525, 1526, 1527, 1528, 1529, 1529, 1530, 1531, 1532, 1533, 1534, 1535, 1536, 1537, 1538, 1539, 1539, 1540, 1541, 1542, 1543, 1544, 1545, 1546, 1547, 1548, 1549, 1549, 1550, 1551, 1552, 1553, 1554, 1555, 1556, 1557, 1558, 1559, 1559, 1560, 1561, 1562, 1563, 1564, 1565, 1566, 1567, 1568, 1569, 1569, 1570, 1571, 1572, 1573, 1574, 1575, 1576, 1577, 1578, 1579, 1579, 1580, 1581, 1582, 1583, 1584, 1585, 1586, 1587, 1588, 1589, 1589, 1590, 1591, 1592, 1593, 1594, 1595, 1596, 1597, 1598, 1599, 1599, 1600, 1601, 1602, 1603, 1604, 1605, 1606, 1607, 1608, 1609, 1609, 1610, 1611, 1612, 1613, 1614, 1615, 1616, 1617, 1618, 1619, 1619, 1620, 1621, 1622, 1623, 1624, 1625, 1626, 1627, 1628, 1629, 1629, 1630, 1631, 1632, 1633, 1634, 1635, 1636, 1637, 1638, 1639, 1639, 1640, 1641, 1642, 1643, 1644, 1645, 1646, 1647, 1648, 1649, 1649, 1650, 1651, 1652, 1653, 1654, 1655, 1656, 1657, 1658, 1659, 1659, 1660, 1661, 1662, 1663, 1664, 1665, 1666, 1667, 1668, 1669, 1669, 1670, 1671, 1672, 1673, 1674, 1675, 1676, 1677, 1678, 1679, 1679, 1680, 1681, 1682, 1683, 1684, 1685, 1686, 1687, 1688, 1689, 1689, 1690, 1691, 1692, 1693, 1694, 1695, 1696, 1697, 1698, 1699, 1699, 1700, 1701, 1702, 1703, 1704, 1705, 1706, 1707, 1708, 1709, 1709, 1710, 1711, 1712, 1713, 1714, 1715, 1716, 1717, 1718, 1719, 1719, 1720, 1721, 1722, 1723, 1724, 1725, 1726, 1727, 1728, 1729, 1729, 1730, 1731, 1732, 1733, 1734, 1735, 1736, 1737, 1738, 1739, 1739, 1740, 1741, 1742, 1743, 1744, 1745, 1746, 1747, 1748, 1749, 1749, 1750, 1751, 1752, 1753, 1754, 1755, 1756, 1757, 1758, 1759, 1759, 1760, 1761, 1762, 1763, 1764, 1765, 1766, 1767, 1768, 1769, 1769, 1770, 1771, 1772, 1773, 1774, 1775, 1776, 1777, 1778, 1779, 1779, 1780, 1781, 1782, 1783, 1784, 1785, 1786, 1787, 1788, 17

REPAIRING VALVE SPRINGS

1. Valve head

Note:
Valve heads which have wear between the valve seats and the spark plug threads can be used further if their working diameter remains constant and the wear does not exceed a maximum of 0.06 mm in either of the two cases the spark plug thread is checked.

2. Head lip seal

- Check piston position - Fig. 1
page 10-2
- Installation see note - see
"Installing Camshaft" - page
10-20

3-12. Seal

- Removal
- Dry cleaning - fit the outer edge of O.D. side
- Fitting and installing
page 10-10

13-15. Valve seat

- Outer valve seating
- Remove and install with valve seat
lapping tool 0001, valve lever
W 54, and adapter W 501, 5

1.1

1. Upper valve spring

- Remove upper valve spring with tool 0001, valve lever
W 54, and adapter W 501, 5

2. Lower valve spring

- Remove lower valve spring with tool 0001, 4

3. Valve stem seal


- Cleaning - page 10-10
- over cylinder head removed
page 10-10

4. Valve seat


- Cleaning outer and removing -
see 10-22
- When cleaning and repairing, use
valve parts with caution
- Use support 0001

5. Cylinder head


- Reworking valve seats - page
10-10
- Working dimension - page
10-10
- Reworking dimensions for cylinder
head:
Valve stems or 0.06 mm per 100
mm through a cylinder head
to 100 kg/cm²



15-758




15-758




- 11- Valve
 - After grinding, valve must remain parallel to cylinder axis
 - Valve clearance = Fig. 1
 - Minimum valve clearance after grinding = 0.1 mm
- 12- Valve cap
 - Cleaning, see Fig. 1, page 1-3
 - Grinding and straightening
Ra<15-18
 - Valve seat/valve clearance with flat flame
Ra<15-18, 0.2 mm
 - Valve研磨, 0.04 mm with bearing cap in front of valve end 150°
bearing cap surfaces
- 13- Valve cap
 - Valve hydraulic system must be depressurized
 - Check retarding, mark cylinder number
 - Check valve - valve length
 - Check valve seating surface with valve seat/valve clearance 0.04 mm
 - Before installation, check axial clearance of camshaft - Fig. 1
at the camshaft surface
- 14- Valve cap
 - Grinding - page 1-36
- 15- Upper valve spring seat

15-258



→ Fig. 1 Installation position of bearing cap


The threaded component on the bearing cap must point towards the intake side of the cylinder head (arrow).



→ Fig. 2

Assembly sequence. Before installing camshaft, fit bearing cap and determine installation position.






► Fig. 3: Measuring camshaft axial play.

Valve lift: 2.0 mm

With cylinder block bolts torqued, chain tensioner first and last bearing caps fitted.



► Fig. 4: Valve clearance

Intake valve	Exhaust valve
—	—
a = dia. 30.00 mm	0.00 mm
b = dia. 6.00 mm	0.94 mm
c = 50.00 mm	50.00 mm
d = 45.00 mm	11 mmq.

Caution:
Valves must not be reversed. They can only
be reused.

Notes:


At normal cold un-filled exhaust valves cannot just 2.70°, so measured using a dial gauge, the valves should be set in two areas one inside and the other, during valve operation. Check that the cone does not contact with walls. During a maximum of 10 valves measured, with this ring into a bucket of water and steep back quickly to cool it down faster than the engine block; because during which the bearing will move, the points created by this may then be obscured of the bearing's edge.



REGRINDING VALVE SEAT
[IS-355]

16.2


Grind away the valve seat enough to produce a present contact surface. Before grinding commences, calculate the maximum permissible regrinding distance. If this value (or) is exceeded, correct functioning of the hydraulic system can no longer be guaranteed and the cylinder head must be renewed.



REGRINDING MAXIMUM POSSIBLE GRINDING DISTANCE:


- Insert $\phi 10$ mm and $\phi 12$ mm slightly against the valve seat.
- Measure the distance between the end of the valve stem, upper edge and upper edge of cylinder head.
Regrind valves on areas which are 1mm below or above 10-12 mm permissible working distance.
- Minimum dimension
Initial value = 36.0 mm
Smallest value = 36.1 mm

[IS-356]



→ Regrinding 10mm, 12mm steps

- a = 36.0 mm
- b = max. permissible P regrinding distance
- c = 1.5 - 1.8 mm
- d = 1.5 mm, 0.5 mm, 0.25 mm with 30° measuring tool
- e = Upper edge of cylinder head
- f = Upper connection angle
- g = Valve seat angle



→ Regrinding exhaust valve (20)

- a = 37.5 mm
- b = max. permissible regrinding distance = 0
- c = approx. 1.0 mm
- d = upper edge of cylinder head
- e = upper connection angle
- f = Valve seat angle

* Max. permissible grinding distance = page 16-12



CHART 9. CRANKSHAFT POSITION

VALVE

- Valve clearance equal with the contact surface (top side cutting diamonds on a clean surface).
- Valve clearance complete cannot be adjusted or repaired.
- Intake valve closed when starting engine and service interval.


Start engine and when ready, indicator has to be switched on once.

Intake air flow should be approx. 2000 rpm for 2 minutes.
If the怠速 (idle) air flow is not defined, the speed is 1000 rpm.

- Remove cylinder head cover.

Right intake port of cylinder head has to be checked for mounting covers.

15-1.




- Check intake port with a wooden or plastic wedge, if there is no air flow after 1000 rpm of cylinder head before the valve opened, valve damage.

Caution:
After new valves have been installed, the engine must idle for about 10 minutes, followed by a short run.



15-2.



3.3.1.206 GEARBOX - See also:

stripping:

- Press upper bearing housing.

→ Refer to cross-section drawing below for details.


- Release lock on oil filter drain bolt and remove.

Remove oil filter bracket.

- Remove oil shaft support retaining bolt with a Allen key and pull out oil shaft from the main part from base in position with handle.

Unscrew inner nuts of oil seal extractor clip and pull apart, and pull out oil seal part from base in position with handle.

- - Lubricate threaded ends of oil seal extractor, place it in position and press it into oil seal slot until firmly seated while rotating probe.



14-

- Loosen handle screw and take inner part of extraction rod from handle until oil seal is extracted.
- Using extraction handle turn rod and remove oil seal with jaws.


stripping:

lightly oil sealing lip and outer edge of oil seal.

- Press oil seal locating sleeve (16-001).
- Press oil seal into base using oil seal locating sleeve (16-001) and oil seal sleeve (16-001).

Caution:

X - Oil press oil seal over the first shoulder otherwise the oil return drilling will be covered.



REMOVING AND INSTALLING CYLINDER HEAD

Removal

- Remove cover, thermal oiling guard, intake air take-off field.
- Remove cylinder head ... shown.
- Detach cylinder head from cylinder block TDI.
- Detach cylinder head from cylinder block TDI and remove.
- Remove cylinder head cover.

Extraction sequence

- ► Remove starting cap in front of camshaft 2a until screws 7 and 4, sleeves bearing caps 1, 3 and 5, alternately in staggered sequence.
- Intake manifold:
 - Remove bearing cap in front of camshaft as well as caps 2 and 6.
 - Remove bearing caps 6, 8 and 10 also evenly in staggered sequence.

1-15

Installing

- Fit cylinder head with drain hole that surrounds intake spacers (Fig. 54).

Note:
When installing the bearing caps, ensure that the recessed corners of the caps face towards the "front side" of the cylinder head - (Fig. 54).
Remove distributor before installing cylinder head.
Fitting distributor = torque: screw 22
Distributor housing unit (1) - torque: Group 22
torque: 10 Nm

Final assembly

- Tighten bearing caps 2 and 10 alternately and in staggered sequence
tightening torque: 15 Nm
- Fit bearing cap in front of 2a caps
tightening torque: 15 Nm



Fig. 54

卷之三

- Fighter, operating near 1.5 g and is ultimately one of the most powerful fighters.

三


Other new happenings have been reported and the engine is about to be started for about 20 minutes, starting with strikes of 1000.

• 5 •

2023 RELEASE UNDER E.O. 14176


What is a standard deviation?

each of which suggests with varying degrees of intensity that soft, 186⁴ or somewhat rough, the value added should be also. It is also reasonable to think the value added for some parts of the business, for instance when interest is charged with capital funds,



- Insert new value from given position of value stored in `list` and `list` is updated. Due to the difference in size of pointers, `newNode` will be later also be used as the next node. Hence `list` is first of all the released again.

- reference work
et al. (1991);
third-order cyclic - 1.3 nm
hydrogen bond - 1.0 nm




Replacing valve guides

► Open heads in which the valve seats can no longer be reused, or if valve seats which have already been machined by the service, the guide should no longer be re-used.

- Press out valve guides and from the cylinder head with using 3121. If guide is sprung, see section 20-23 during this operation.

24-21



- Guide with shoulder with a shoulder must be removed from the side with head or by cutting shoulder below shoulder.

Note:
Use support 3123 for pressing out valve guides.

Caution:
With the shoulder or guide taken out, the pressure must not exceed 1.0 bar! Otherwise there may be break off.

Then guides out with hand reamer 3120, max. weight of cutting fl. is.

Remove valve seats.

Note:
After removing valve seats, read further description page 21-23.

24-24

Caution: Risk of carbon monoxide (CO) gas.

Carbon monoxide is highly toxic.


• Remove component and handle carefully.

• Remove valve springs.

• Set the camshaft positioner (Cylinder No. 1 at TDC).

• Lower compressed air line (W 670/1) until spring tension and torque is released from the valve.


VALVE SPRINGS



VALVE SPRINGS


- Insert the lifting tool (rod) into the gap between the height of guides. Remove valve springs with valve lever (W 670/1) and adapter (W 670/2).

VALVE



Opposite side:

- Right cylinder can be lowered by adapting (W 670/1) or (W 670/2) to the rod (W 670/1).



► Release valve stem seals with (W 670/2).

- Install valve stem seals.
Fit a new O-ring seal (W 670/2) to valve stem seal. Squeeze it in fitting tool (W 670) and push it down over valve into the valve guide.


CAUTION:

To prevent damage to the valve (part 949), always use the indicated sleeve.

REMOVING VALVE STEM OIL SEAL

(Cylinder head removed)

- Remove camshaft end bucket bearing.
- Remove spark plug.




[Intake side]

Note:

Lower front valve covers by slightly tapping the assembly (over by 541/1 with a mallet).

- → Install fitting apertures 2036 and adjust the height of studs.
- Remove valve springs using valve lever (K 541/1) and adapter (K 541/2).

14-17




→ [Exhaust side]

Remove valve springs using 2037.


- Remove valve stem seals using 3129.

- → Install valve stem seals.
Fit plastic sleeve to open valve stem. Coat valve stem seal lip with oil, place in fitting tool 3127 and carefully slide over valve guide.

Caution!
Always use the plastic sleeve when fitting valve stem seals to prevent damage.



14-18



REMOVING AND INSTALLING LUBRICATION SYSTEM COMPONENTS

REMOVING AND INSTALLING LUBRICATION SYSTEM COMPONENTS

NOTICE:

Components shown in the following section have been removed and disassembled with engine cold.

1- 26 mm

2- Upper toothed belt guard

3- Tensioner belt

- **NOTICE:** Refer to Repair Group 13.

4- 23 mm

5- Pre-tensioner assembly (either front or rear)

6- Spacer bushes

- **NOTICE:** Remove bushings from cylinder block.
- **NOTICE:** Remove bushings from cylinder head.

7- 24 mm

8- Camshaft assembly

- **NOTICE:** Remove cylinder heads.
- **NOTICE:** Remove cylinder heads.

9- Gear (Lubricated gear) and oil

100

10- 26 mm

- **NOTICE:** Remove cylinder block after using special tools 2018 and 2020 - repair group 13.
- **NOTICE:** Threading and seating surface of cylinder head with sealing compound AWI 398 (K 02).
- **NOTICE:** After tightening - repair group 13.

11- Vibrator carrier

- **NOTICE:** Remove and install ring - Repair group 13.

12- Lower toothed belt guard

13- Oil pan jacking

- Removal - page 17-11

14- Oil seal

- Removal - page 17-11

- Inserting - page 17-11

15- Oil jet

16- Oil temperature sender (oil and oil temperature relief valve) (K 02)


- **NOTICE:** Remove


- **NOTICE:** Turn back sender tube

17- Oil pipe coupling

18- Oil pump gears


- **NOTICE:** Turn back gears around the cover plate





19. **2.7 lPG**
 • Refer to 04.01.1.1.1. Complete with
 • cylinder head gasket 04011104 with
 • fitting paste.
20. **Cylinder base**
21. **Oil pump assembly**
 • Refer to

[7-3]




17. During assembly, the engine must be
 turned 180° counter-clockwise by
 hand to align the cylinder base
 bearing housing with the cylinder head
 bearing housing to prevent damage.

Engines with cylinder base bearing
 04011104:

1. Gasket
 • Refer to 04.01.1.1.1
2. Main bearing cap assembly
 • Bearing and bushings are pre-tempered
 • multi-purpose grease 04011104
 • Apply to bearing and main bearing
 • fitting
3. Adapter 04011104
4. Gasket
 • 04011104
 • Multi-purpose grease
5. Oil base
6. Cylinder base
7. Oil pump assembly
 • Refer to
8. Oil pump assembly
 • Refer to


[7-382] [7-383]


17-4



- 1-
2-
3- Oil pressure switch (SHR-1) [E-7](#)
• 1/8 NPT
• Checking - page 17-40
4- Oil pressure switch, 25 bar
• Checking - [17-40](#)
5- [Inlet, E-26](#)
• Service 17-01 (see 17-01)
6- [Oil](#)
7- Baffle plate
8- Bush
• [Replacing and installing:](#)
Remove front bumper security
• 10 - 14 Nm
• Clean working surface before
install 1-08
9- Seal
• Service
10- [Oil](#)


17-5






- 11- Flow line (Lubricating)
 12- Oil filter
 * number
 13- Oil cooler bracket
 14- Self-tapping screw
 * for securing air line
 15- Air line
 16- Barb collet 70 Km
 17- Oil filter 17 Km
 * Reference 65° C static wrench, clockwise to remove
 * Ensure installation fluid contains
 cleaned oil filter
 18- Oil filter housing
 19- Flow line gasket (O-ring) 0.00075 in.
 * number
 20- Washer
 * number
 21- Nut
 22- Nut

17-2



- 22- Return line - lubricating
 23- Containment system (lubricating)
 * number
 24- Containment system (lubricating)
 * number

17-3




→ Removal (cont.)

Release lock safety cable from the bolt to the cluster and the cover (left side). If alternator, a "drive belt" and "drive" are cut off, take off the pulley.

- Remove pump belt hydraulic fluid and move to the other (bottom) mounting bracket.

Shift lever position depends on the shift lever. (Refer to Fig. 11-11.)

Remove front wheel.



→ Replacing (cont.)

Front

The subframe will suddenly drop by about 100 mm.

→ Remove both front subframe bolts.


Rear

Then the subframe angle must be measured.

- During refitting, the rear subframe bolts should be tensioned to 30 N·m plus a specified value.


→ Refer to Fig. 11-11.

Front centre C →




- There are two subframes. In "Front C" and in the body (sub frame), the bolt is secured to the subframe support ring with hexagon recess head screws.

- When fitting the new ones, these bolts should first be tensioned to 30 N·m plus a specified value. (Front left and right: 10.4 N·m; Front C: 12.7 N·m; Rear C: 11.8 N·m)




→ Removing (cont.)



- Release tensioner belt and remove T-100001. Tensioner belt must be held in direction of arrow (otherwise).

Important:
Vane pump must not be rotated further.

- Remove vibration damper with toothed belt pulley.



- Remove vane pulley with 3034.
 - It is only necessary to remove the vane pulley when removing the oil seals and the vane pulley bearing, e.g. during fly-by-wire according to 15 "95 to be enabled to have out the oil seals.

Sensor plug.

17-11



- Remove crankshaft oil seal, pulley end.



- Press, 16.000000000, 10.000000000, 59.5700, 15.157103.
- Use a suitable adapter and film bolt for pressing oil seal into oil.
- Before installing, slightly oil the sealing lip and the edge of the seal.

Caution:
The oil seal must show signs of sealing. Press oil seal into oil until it is seated. If not, repeat.

- Tighten up sealing ring with a torque wrench.
- Press-in seal using thrust sleeve (part no. 2080-2).


17-12

CHECKING OIL PRESSURE SWITCH AND OIL PRESSURE

(Audible noise and pressure reduction)

Test conditions:


- Oil level 2/3,
- Oil pressure indicator (red) must glow when ignition is switched on.
- On vehicles with auto check system the indication must be O.K. (call up symbols).
- Minimum engine oil temperature: 50 deg. C. (radiation fan must have cut in area).



Oil pressure switch 1.3 bar

- Remove cables from oil pressure switch and oil pressure sensor.
- Unhook oil pressure sensor and screw into oil pressure sender test unit VAG 1342.
- - Screw VAG 1342 into the crimpette to side of the oil pressure sender.
- Connect wire -2- (brown) to earth (-),
- Connect wire +1- (blue) to 1.3 bar oil pressure switch (white insulation).

17-13



- - Connect direct test lead VAG 1527 to wire -1- and positive battery terminal

- Start engine.
- Slowly increase engine speed.
The test lamp should illuminate at 1.0 ... 2.0 bar. If this is not the case the oil pressure switch must be renewed.
- Increase engine speed further.
At 2000 rpm and an oil temperature of 80 deg. C the oil pressure must be at least 2.0 bar.
- Increase engine speed further.
Pressure relief valve working pressure:
5.0 ... 8.0 bar.
This pressure should not be exceeded except by a minimal amount.

NOTE:
If the oil pressure is excessive (pressure relief valve sticking or incorrectly mounted) the hydraulic system will be subjected to excessive pressure. As a result the engine will run away after starting and will even not slowly stop during subsequent starting because of lack of compression.

- If the wires are incorrectly connected to the oil pressure switch the auto check system will cause the engine oil pressure warning symbol to illuminate (e.g. car)

17-14


DIAGNOSIS CH-27: OIL PRESSURE (O.P.)

Test conditions:

- 210 °C oil temp.
- Oil pressure switch (O.P.) by front glow plug ignition is activated by:
 - Vehicles with auto check system the interval 09 min - 20 min is possible.
- Minimum engine oil temperature is dep. 1 °C (factory) to just above oil filter.
- Tachometer is functioning, instrument panel assembly D.R.


Note:

- Check auto check system oil pressure sensor (O.P.) if the oil pressure reference light (OPL) does not illuminate.
- For "Oil pressure sensor (O.P.)" mounting position see page "Chassis" (1).



- → Connect test lead 1520 (1520) between oil pressure sender contact (O.P.) and auxiliary cable from O.P.A. (1520).
- Switch ECU off and on the ECU oil pressure:
 - Specified reading: 0.1 ... 0.6 bar.
- Start engine and run at idling speed:
 - Specified reading: 0 ... 1% rev.
- Increase engine speed to 1000 rpm:
 - Specified reading: 0.9 ... 1.0 bar.

17-13




- → Connect V.P.A. (1520) test lead between oil pressure sensor contact (O.P.) and engine earth using the auxiliary cable from O.P.A. (1520).
- Start engine and run at idling speed:
 - Specified readings: 0.1 ... 0.6 bar.
- Switch off engine:
 - Specified reading: 0 ... 0.6 bar.
- If these values are not obtained the oil pressure sensor (O.P.) should be replaced.

Note:

Incorrect wiring of the oil pressure sensor will cause the auto check system to display the engine oil pressure warning symbol (OPL) lamp.



17-14



Digitized by srujanika@gmail.com

2000-01-01 00:00:00

• 1986.112

• • •

Training and evaluation details

• २०८ - ५-१

Reporting ... by [John](#), [Sam](#), [Bob](#), [John](#) ...

$\frac{1}{2} \cdot \dots$

• 10 •

1000-PIRAN, SUDHAKAR AND AGARWAL

2000-2001 Yearbook

$\tau = \frac{100 \cdot \text{start_time}}{\text{maximum_duration} + \text{start_duration}}$ and $\tau \in [0, 1]$

J. Neurosci. Methods 1998, 75: 147-157

scatter Σ scattering length

23

$\vdash \vdash \vdash \vdash \vdash \vdash$

2nd stage $\frac{1}{16} \text{ sec}$ 21 approx


• 10 •

• 103 •

100 V. M. T.

... 1.75 1.76

7. Secular rate



$\hat{c} = \tilde{c}_\text{min}$

• WEDDING INVITATIONS


[View Details](#)

• 100 •

See page 12-13

220 L. A. LEVINE

- running and installing
- Survey Outlines and the art
based and extreme culture
vertically.



1- 26-100-100-00-0000000000

2- 26-100-200-00-0000000000
• 26-100-200-00-0000000000

3- 26-100-100-00-0000000000

4- Intake air cleaner

5- 26-100-100-00-0000000000

6- Turbocharger coolant pipe
• Checkring, inner 0.13

7- 10 mm

8- Coolant temperature sensor
• 26-100-100-00-0000000000

9- Coolant thermostat


- 26-100-100-00-0000000000
- Open at ~140°F
- 1/2 open at 110°F
- Opening stroke 7mm

10- Water bypass valve - water bypass

11- 22 mm

12- 20 mm

10-2



14- 20 mm

15- Water bypass valve
• 26-100-100-00-0000000000

16- Water bypass valve 21-3
• Temperature control valve required
• Working condition depends on
• the high switching temperatures

17- Turbocharger coolant pipe
• Checkring, outer 0.13
• Checkring, inner 0.10

18- Front plate 20-20


19- 22 mm

20- 20 mm

[19-33]

17

10-2




► Fig. 3: Checking cooling system pressure

The test gauge must be connected when engine is at normal operating temperature.

For more info see Inspection section.

Pressure testing is done at 1 bar approx. using the test port head pins. If pressure drops, check leak and repair.




► Fig. 4: Checking test pressure, relief valve

For info see Test section.

Depressurize by opening the test port head pins.

The pressure relief valve must open at 0.5 ... 1.0 bar.

[6.2]




► Fig. 5: Thermostat, installation position

Starts opening: 80° C approx.

Fully opened: 90° C approx.

Working pressure: 8 cm Hg,



PRIMING AND FILLING COOLING SYSTEM


Caution:

Coolant heater controls can not function.


► Check expansion tank cap.



[6.3]



- Drain coolant by opening coolant hose to bottom of heater coil lower coolant hole for service.



- Lower coolant hole at lower coolant pipe.

19-2

Filling cooling system.

Note:

The cooling system is filled all the year round with a mixture of water and anti-freeze. All the coolant additives approved by VW in accordance with VW-AZ-AP prevent freezing, corrosion damage and early overheating and raise the cool-off boiling point. For these reasons the cooling system cannot be filled all the year round with semi-concentrated anti-freeze additive. Due to the high boiling point the coolant is forced to operate more effectively when the engine is operating in full load, particularly in tropical climates.

Recommended mixture ratio:

Front radiator	Water + 10% G13	Volume of water
1 : 20	1.4 l	2.8 l
1 : 30	1.05 l	4.05 l


* For radiators with cold climates.

- Set heater control to hot.

- Fill with coolant until the expansion tank is full.

- Start and run engine...

Keep topping up expansion tank with coolant until the coolant level stops rising and is slightly above the level mark.



- Repeat until the fuel level is:
 - Allow engine to run until the water minister fuel level is.
 - Then refuel tank again at top up 10 minutes.
- After the engine has stopped, turn back the coolant tank and should be enough above the minimum level mark. When the engine is cold, the level should at least reach the middle of the gauge.

2-2

COOLANT, COOLING AIR AND COOLANT PUMP

• On request to our service the mechanic indicates the time to:

• Turn off engine.

• Under a small opening, the placement and remove and refit the fuel tank switch on.

• Electrical circuit pump and resistor. The one not to 0.040 ohm (0.040 ohm) to 0.050.

• Disconnect wires from thermoswitch and connect wires to meet other.

• The electrical contact pump and fuel should now be:

• Coolant pump and fuel pump.

• Remove thermoswitch.


• In reverse order, the procedure should not need:

• Update and review faults using current fault diagnosis

7

8

9



Exploded view fuel system components


NOTICE

Flushing
Always observe the safety rules when working on the fuel system.

Notes:

- Always observe safety, gestures and noise rules when working on the fuel system.
- All hoses can become brittle when stored in temperatures below 0°C (-32°F).
- Always observe rules of cleanliness – page 21-04.
- Connecting remote control – page 21-05.
- Checking fuel tank relief – page 21-06.
- When removing or installing fuel gauge sender unit make sure the tank is not damaged.

20-1



Exploded view fuel system components

NOTICE

Flushing

1. Fuel Sender Unit

2. Fuel Filter Unit

3. Fuel Gauge Sender

4. Tank Filler neck

5. Fuel Filter area

6. Tank Filter pipe

7. Tank Filter pipe support

8. Tank hose clip

9. Tank Filler pipe hose


10. Support pipe

11. Piping

12. Fuel vent tube/vent valve

13. Support pipe

20-2



- 14- Surge control - page 20-10
 - 15- Desuperheating stage
 - 16- Desuperheating stage to activate the low filter
 - 17- Surge
 - * Review
 - 18- Reheat
 - 19- Surge
 - * Review
 - 20- Gravity valve
 - 21- Fug' jump
 - * Removal and installation - page 20-4
 - * Inspection and assembly - page 20-13
 - * Cleaning - page 20-12
 - 22- Surge tank
 - * Review


- 1 -

60-125-124 1-3-H-10233 4-24 XJHR:1G 24
THE TEL. S. STAN


15

When working on the fire system the following five rules should be observed:


- > Thoroughly clean all unions etc. and the solvent areas before disassembling.
 - > Place parts removed from the fuel system on a clean surface and cover against contamination.
 - > Components that have been opened or dismantled must be carefully covered or sealed if the repair cannot be completed immediately..
 - > Only install clean components.
 - * Do not remove replacement parts from the packaging bag until ready for reinstallation.
 - * Do not use parts that have been stored without their packaging (i.e. in seal-jackets etc.).
 - > When the fuel system is open:
 - * Do not use compressed air.
 - * Do not move the vehicle unless absolutely necessary.



- Fig. 1: Connecting cables for rear window defroster (see also [Fig. 2](#))
- > Remove rear window defroster from body shell.
- > Connect both relays from body shell (see [Fig. 1](#)).
- > Insert rear window defroster (see [Fig. 2](#)) into body shell. Turn on ignition switch. Defroster should now work.




- [Fig. 2: Rear window defroster unit](#)
- > Insert rear window defroster unit into body shell.



REMOVING AND INSTALLING REAR WINDOW DEFROSTER

1. **DETACH:**

- > Remove rear window defroster from body shell (see [Fig. 1](#)).
- > Pull off connector for front parking light bulb.




- > Remove front parking light bulb from body shell (see [Fig. 1](#)).

CAUTION:
Do not pull on cable! Unit should not come loose from body shell.

2. **DETACH:**


3. **DETACH:**




- Release the retaining screw located at 1007 and withdraw the fuel gauge sender from the fuel tank.
- Note:
- When removing and installing the fuel gauge sender unit ensure that the connecting cable is not damaged.

- Disconnect supply and return lines from the filter at the sender housing.
- Disconnect the pump electrical connections.
- Detach gravity valve.

20-6




- Remove fuel gauge and fuel pump assembly.**
- Note:
- Remove fuel gauge sender unit cover (screws located at 1007).
 - Pull out connector for fuel gauge and fuel pump.



- Release fuel supply line (A), return line (B) and vent line (C).

Information:
The fuel tank should be no more than 275 liters.




- Release the retaining bolts, fuel rail, and any other hardware required to remove the tank.

Note:

When removing and installing the fuel gauge sender unit, ensure that the mounting cables are not damaged.


- Disconnect the fuel and return lines before the removal of the sender unit.

Component fuel line connection assembly.



- Position the assembly and the tank connection locknut assembly, part No. 102-371-00.

Assembly part sequence:




Installing Gauge

Installation of Fuel Gauge Assembly

The fuel gauge should be installed at 10° from the vertical.

- Fit fuel pipe to the fuel gauge and connect it to the return line.
- Fit return pipe to the fuel pump.
- Re-fit fuel tank cap and tighten until the tank is 2/3 full.



11:59 AM 10/10/2014

should replace kerosene and gasoline. The difference is added to the fuel requirement by a factor of one-half.

- Sider 15 -


- 3. Sample:
■ $\frac{1}{n} \sum_{i=1}^n y_i$
 - 4. Est.:
■ $\hat{\theta}_0 = \bar{y}$
 - 5. Test: $H_0: \theta = \theta_0$ vs $H_1: \theta < \theta_0$, $\alpha = 0.05$
 - 6. Decision:
■ If $\hat{\theta}_0 < \theta_0$, then H_0 is rejected
■ If $\hat{\theta}_0 \geq \theta_0$, then H_0 is not rejected
 - 7. Confidence interval:
■ $\hat{\theta}_0 \pm t_{\alpha/2} s_{\hat{\theta}_0}$
 - 8. Large sample:
■ $\hat{\theta}_0 \sim N(\theta, \frac{1}{n})$
 - 9. Large sample:
■ $\hat{\theta}_0 \sim N(\theta, \frac{1}{n})$
 - 10. Final:

• • •


WUOL 571 2013

Spiral and Vortex

- Case 01: New car being charged with solar energy
 - Case 02: Solar 0%
 - Additional 20% consumption costs
 - Case 03: New car 20% charged from solar and completes with electric vehicle (EV) - 100% solar



- **Teorema fundamental da álgebra**: todo polinômio de grau maior que zero tem pelo menos uma raiz.




- Check voltage at fuse connection. If voltage is 0 V, ground or a component does not have current drawn during the fault.

The reading should be approximately equal to the battery voltage.

If the specified voltage is not available, turn over switch (using the current flow diagram).

If the specified voltage is not available, disconnect connector.

Reconnect control system. If the fault has not cleared, continue to next paragraph.




- Check if resistance between connection 5 and 1 is approximately 0.05 to 0.1 ohm.

Specified resistance = 0.05 ohm.

If specified reading is not obtained, replace connecting cable.

- If a low value reading is obtained, replace fuel pump.



1.1.1.3.6. Fuel pump control fault


1.1.1.3.6.1.1.1.1

- Test for open circuit voltage with "Fuel pump"
- Test, function
- Battery (0.01) charged (100%)


1.1.1.3.6.1.1.1.2. Corrective action: Control 0.01 to 1346/3A using adapter with code 1346/3-2

- Fit diodes from coil relay to coil relay (location 16 in relay 0.01).

- Connect negative terminal of the 1346/3-2 to coil terminal 16 of relay 0.01.




- Shut off the engine. Turn the "power fuel" valve (Fig. 4-70).



- Connect a hose to the fuel supply pipe and the other end of the hose to a graduated measuring vessel.

00-11



- Shut off the power, turn the "power fuel" valve (Fig. 4-70) on for 15 sec.
- The fuel flow or fuel delivery rate can be read from the diagram.
- Measure voltage delivered by the fuel pump to the fuel return line.
- Check fuel pump voltage with engine stopped off load and running. (With voltage should be approx. 1.5 V less than the battery voltage.)

TESTING FUEL PUMP INTEGRITY (Fig. 4-77)


Notes:

For this test fuel pressure regulator, fuel pump and connectors must be working correctly and there must be no leak in the fuel system.


Procedure:

The pressure gauge lever must remain closed during the test.


00-11



→ Incorrect fuel return line from pressure regulator.




→ Incorrect connecting line between fuel line left side pressure regulator from the fuel rail line.




→ Incorrect position regulator and assembly in intake flow induction manifold complete with connecting line.


→ Incorrect connecting line from pressure regulator




- Connect and tighten line to fuel rail and after installing through the segments.



- Connect fuel return line to pressure regulator.




- Connect pressure gauge VAG 1318 between controller and pressure regulator, set pressure gauge value to 'Initial' pressure.
- Turned service control switch VAG 1318/11 - page 10-14
Press service control switch for approx. 30 sec...
 - Off pressure gauge (turn to closed position)
 - Press service control switch for a short time until the reading is a deviation of +/- 0.5 bar
 - With P.S. service control gauge, monitor pressure drop after 10 min: 0.5 bar.
 - pressure test must meet this value when pressure gauge and fuel supply have completed the break-in of 10 min. and before performing the return value.



Detaching the pressure regulator is universal or central.

- Note that the connector is fitted to the pressure regulator and is tightened with the pressure regulator wrench.

20-720



Replacing the relay

Number part: 0000-0000-0000-0000-0000

- Detach the return valve and seal it according to the seal.
- Tightening torque: 20 Nm

Notes

- Detach the electric fuel pump wires.

20-639

Checking the 12V fuse (20, 21, 22, 23, 24, 25, 26, 27)

Checking the 12V fuse (20)

Remove fuses 12, 20 and 21.

- Connect a diode test lamp (A = 5 mA) between earth and the left-hand contact of fuse 20.

Connect a diode test lamp.

- Connect a diode test lamp (A = 5 mA) between earth and the left-hand contact of fuse 20.

Connect a diode test lamp.


If the diode test lamp illuminates as soon as the ignition is switched on connect a diode test lamp (A = 5 mA) to the right-hand contact of fuse 20.

- Connect a diode test lamp (A = 5 mA) between earth and the left-hand contact of fuse 20.

- Connect a diode test lamp (A = 5 mA) between earth and the left-hand contact of fuse 20.

The diode test lamp must illuminate during all three circuits and the relay must operate suddenly if either current or fuse is missing (check the fuse or relay housing to check the contacts).

20-639




- If the code test lamp does not illuminate, the fuel pump relay should be withdrawn from relay location 61 on the relay plate.
- Check connecting cable between fuse 16 and contact 10 of relay location 61 for continuity using an ohmmeter.
- Check connecting cable between fuse 16 and contact 19 of relay location 61 for continuity using an ohmmeter.
- Check connecting cable between fuse 16 and contact 18 of relay location 61 for continuity using an ohmmeter.
- If necessary, replace the open connection.
- If the relay does not operate, check the fuel pump relay, control circuit.
- If the control circuit is OK, replace the fuel pump relay.

Checking fuel pump relay control circuit

- Withdraw fuel pump relay 61, from relay location 61 on the relay board.
- Switch on ignition.
- Connect voltmeter input to contacts 16 and 51 and then to contacts 18 and 19 of the relay (61/60).
- The voltmeter should read approx. 12V.


→ If the voltage is not present, the control circuit is faulty.




- If the indicator markings are not clearly visible, clean contacts using current flow diagram.
- Inspect diode test lamp (marked 10) to contacts 46 and 47, and the indicator is switched on, the diode test lamp must be clearly visible and become slightly brighter as soon as the indicator lamp is illuminated.
- If the indicator lamp does not become brighter, clean the contacts as follows:

 - Connect test lamp 10/38 to the electronic control unit harness, unit identifier code 153P/5 - (see section 00-31, Control unit connector J1 is disconnected).

- Check connecting cable between contact 47 of relay location 61 and test lamp socket 3 for continuity and if necessary, replace open connection between contacts 47 of relay socket and contact 3 of control unit connector J1.
- If there is no open contact, replace control unit.
- Replace fuses 16, 24 and 27.





2. If necessary, remove the float valve assembly. Refer to page 20-20 for instructions.

3. Remove the喉管 (throat).

4. Remove the喉管 (throat) adjustment screw.

5. Remove the喉管 (throat) stopper.


6. Remove the喉管 (throat) stopper adjustment screw.

7. If necessary, remove the喉管 (throat) adjustment screw.
• Proceeding - page 20-20
• Check the control circuit. Refer to Group 4.

8. Remove the喉管 (throat) stopper adjustment screw. Proceed to "Carburetor throat adjustment" on page 20-20.

9. Reassemble the carburetor.

10. Reinstall the engine.



REMOVING THROAT ADJUSTMENT SCREW

1. Remove the喉管 (throat) adjustment screw.

2. Remove the喉管 (throat) stopper.

3. Remove the喉管 (throat) stopper adjustment screw.

4. Remove the喉管 (throat) adjustment screw.

5. Remove the喉管 (throat) adjustment screw.

6. Remove the喉管 (throat) adjustment screw.

7. Remove the喉管 (throat) adjustment screw.

8. Remove the喉管 (throat) adjustment screw.


9. Remove the喉管 (throat) adjustment screw.

10. Remove the喉管 (throat) adjustment screw.

11. Remove the喉管 (throat) adjustment screw.

12. Remove the喉管 (throat) adjustment screw.

13. Reinstall the engine.



- 1. Body
 - 2. Seal
 - 3. Housing (45101)
 - 4. Seal
 - 5. Seal
 - 6. Seal
 - 7. Seal
 - 8. Seal
 - 9. Seal
 - 10. Seal
 - 11. Seal
 - 12. Seal
 - 13. Seal
 - 14. Seal
 - 15. Seal
 - 16. Seal
 - 17. Seal
 - 18. Seal
 - 19. Seal
- 25-776

46-17-86 Tech 7-1982


ASSEMBLY

The following sequence is intended to minimize time around the assembly. It is recommended that each assembly be completed in its entirety before proceeding to the next.

ASSEMBLY OF PARTS

After fitting a new seal on the body, coat the body with a liberal amount of grease, lubricant and/or sealant and fit the following parts:







After
The accelerator cable is fixed on the accelerator pedal, and the accelerator cable can be adjusted. If the accelerator cable is loose, please refer to the following.

• Fully depress the accelerator pedal.


- If the accelerator cable is loose, please refer to the following section.
• After the adjustment, please adjust the cable lead wire.




- Fix the accelerator cable using the clip.
• Please refer to the following.



- After**
The cable is fixed on the accelerator pedal, and the cable lead wire is fixed by hand without binding.




- Fully depress the accelerator pedal.
• The accelerator cable must be fixed firmly against the cable lead wire.



CONNECT THE OXYGEN SENSOR SIGNAL CABLE

- Connect the cable.
 - Make sure the twist lock connector between the cable and the valve cover (see arrow).




- The throttle sensor should just start turning and the throttle valve fully open, if this is not the case check the cable for damage and replace throttle sensor until it no longer exceeds the tolerance.

→ Reinstall the oxygen sensor.

1. 2

3
2



14-0-01

2001/01/01

16/01
Spare parts catalog and general.

1: Intake air pipe

2: Exhaust pipe

• The side of the intake and side
of the exhaust pipe facing the front
towards the left side.

3: Exhaust pipe

4: Exhaust pipe

5: Exhaust pipe

6: Exhaust pipe

7: Turbocharger

• 040100 = 1698 cc-1
• Increasing and decreasing = 1698 cc-1

8: Exhaust pipe

9: Exhaust pipe

10: Exhaust pipe

11: Exhaust pipe

12: Exhaust pipe

13: Exhaust pipe

14: Exhaust pipe

15: Exhaust pipe

16: Exhaust pipe


17: Exhaust pipe

18: Exhaust pipe

19: Exhaust pipe

20: Exhaust pipe

17-



14-0-01

2001/01/01

1: Intake air pipe

• Increasing = 1698 cc-1

2: Exhaust pipe

3: Intake air pipe


4: Exhaust pipe

5: Intake air pipe

6: Exhaust pipe


• Increasing = 1698 cc-1

18-



- REMOVING AND INSTALLING CARBURETOR**
- DISASSEMBLING AND ASSEMBLING**
- REMOVING AND INSTALLING CARBURETOR**
- 1- Carburetor
- 2- Base
- 3- O-Ring
- 4- Base
- 5- Base
- 6- Base
- 7- Base
- 8- Base
- 9- Base
- 10- Base
- 11- Base
- 12- Base
- 13- Base
- 14- Base
- 15- Base


21-2



- 16- Exhaust ventilation pipe
connected to base
- 17- Pressure reducing valve
- 18- Flare nuts
- 19- Air cleaner ventilation pipe

21-3

21-4



REMOVING AND INSTALLING AIR CLEANER

1.1.1. Remove intake air pipe and air cleaner top cover.


- Disconnect air pipe.

REMOVING AIR FILTER

- Pull off air filter in filter box with filter valve lever.


- Release hood latch.

- Pull off hood. Push out with left hand to open.




- Disconnect air cleaner upper pipe from air cleaner box.

1.1.2.




- Release locking pins from side flaps and bottom base. Lift up to remove.

- Remove air cleaner upper section from engine compartment.




- Remove air cleaner lower section.

1.1.3.




- Remove connecting tube between charge air cooler and induction air pipe.




- Remove intake air ducts.
 - Disconnect intake air pipe from air cleaner.
 - Turn lock nut clockwise and remove.
 - Turn lock nut counter-clockwise and remove pipe.
 - Open intake air gate to maximum position.


21-7




- Remove hoses between hot water pipe, intake water pipe and intake air pipe from intake air pipe. Shut off water and disconnect by disconnecting the two nuts (arrow).



- Remove connecting tube between supercharger and boost pressure limiting valve and intake air pipe (arrow).




21-8




→ Disconnect the pipe from the air cleaner.

→ Remove the air cleaner from the engine compartment.




→ Release base clip securing the air cleaner base pipe to the intake pipe. →




→ Disconnect intake pipe from the air cleaner.

→ Remove intake pipe from the engine compartment.



→ Disconnect base between air cleaner and intake pipe at intake pipe.






→ Remove air cleaner (10 mm hex head screw).

Note:


The connection tube should be clamped immediately after disconnecting.

→ Disconnect coolant return line from supercharger.

21-11




→ Remove heat shield from the right-hand side of the supercharger.



→ Disconnect supercharger exhaust manifold and remove.

→ To install the supercharger, reverse procedure.

21-12




F1-373: AIR INLET DUCT AND AIR FILTER

Remove and install in the order indicated in Group 01.


Install and tighten according to the values in Group 02.

- Remove the air cleaner assembly, air duct and induction pipe from the cylinder head.




- Remove the intake pipe from the cylinder head.

F1-38




- Remove the air cleaner duct and air duct.




- Detach hose between turbocharger and boost air inlet duct pipe.

F1-39




→ Front air cleaner assembly.




→ Remove intake air charge air cooler by releasing two clips on flexible mounting strap.

21-17




→ Intake air charge air cooler assembly. Turn the intake air cooler assembly with the exhaust air cooler intake charge air filter.




→ Remove intake air charge air cooler assembly.

21-18




- With charge air cooler mounted completely.

→ Secure the hood to the body.



- Push screwdriver blade to the left out of the mounting flange.

→ Remove charge air cooler housing from engine compartment.
In "normal" change air flow or interval removal sequence.




Procedure 1: VAG 1397 probe and probe fitting

- Engine oil temperature 27 deg. C.A.
- No testing resistor connected.
- Power electronic control unit cover turned to "open" position.
- Oxygen sensor disconnected from electronic control unit.

- Connect turbocharger test instrument VAG 1397 between exhaust pipe and catalyst control unit.


Note:

When checking the boost pressure the vehicle should be taken for a fast run over 30 seconds of at least 1 km/h (no traffic lights etc.). The boost and rpm measured while the vehicle is being driven, for safety reasons in second gear, should be prefered to take the readings from the turbocharger test instrument.



- Open turbocharger test instrument valve.

→ Fully depressed accelerator in fourth gear when the road speed is approx. 100 km/h.



- Diagnostic connection.
- Boost test (injection system with engine speed switch = 1000 rpm)

Specified readings:

1 bar	1000 rpm
0.00 - 0.05	Sea level
0.05 - 0.10	500
0.10 - 0.15	1000
0.15 - 0.20	1000
0.20 - 0.25	1000


- If the readings are obtained move on to test of the **Parkronic fuel injection and ignition system or intercooler fan motor**.
- See, **Wiring diagram**.
- If the above readings are not obtained check boost pressure limiting potentiometer control circuit (fuel control cylinder).
- Repair or replace valve and check.
- If the above readings are not obtained check bypass valve - **page 21-11**.

11-2

- If the specified reading is not obtained turn off the engine, wait one minute and check.
- If after a repeated boost pressure check the appropriate reading is still not obtained the turbocharger should be replaced.

5
6

11-2




DETONATION PROTECTION SYSTEM (DPS) CHECKING

The detonation protection system is located in front of the turbocharger. It opens in the event of detonation, thus reducing the air/fuel mixture entering the engine front of the throttle valve to prevent lean mixture overacceleration.

If the pressure relief valve does not open during lean mixture, the detonation protection valve should be checked.

- For optimum results a short time is required to activate the DPS valve:
 - pressurize the pipe
 - The bypass valve must open (arrow).
 - operate the valve until the valve after 30 seconds opens.
 - The bypass valve should close (arrow).
- If the bypass bypass valve does not open or closes off if the valve is fully open, replace valve.
Replace bypass valve if bypass valve fails.



EXHAUST AND FUEL/OIL LINE EXHAUST SYSTEM

(COMPONENTS)

1: Exhaust pipe
Exhaust system assembly, not including
muffler.

2: Exhaust pipe

3: Exhaust pipe

4: Exhaust pipe
Exhaust pipe, not including flange
and clamp.

5: Exhaust pipe

6: Exhaust pipe

7: Exhaust pipe
Exhaust pipe, not including flange
and clamp. The end of the uncoated pipe
with a pre-coated pipe must be
toward the exhaust side.

8: Exhaust pipe

9: Exhaust pipe
Exhaust pipe, not including flange
and clamp. The end of the uncoated pipe
with a pre-coated pipe must be
toward the exhaust side.

10: Exhaust pipe

11: Exhaust pipe
Exhaust pipe, not including flange
and clamp. The end of the uncoated pipe
with a pre-coated pipe must be
toward the exhaust side.

12: Exhaust pipe


13: Exhaust pipe


14: Exhaust pipe

15: Exhaust pipe

16: Exhaust pipe

Steps 1-16: Join parts between main and rear
extremes. → Fig. 1 page 29-3






REMOVING AND INSTALLING AIR CLEANER ASSEMBLY

- Remove the upper body and the lower body of the air cleaner assembly.

Upper body : $\phi 124.7 \text{ mm}$
Lower body : $\phi 140.5 \text{ mm}$




REMOVING AND INSTALLING AIR CLEANER BASE

Before disassembling the air cleaner base, ensure sufficient exhaust air flow from the body and exhaust pipe.

- Disassembly sequence of parts in the following steps:
- Disconnect the upper body from the base.
 - Disconnect the lower body from the base.
 - Disconnect the base from the exhaust pipe.
 - Disconnect the base from the upper body.

[20-2]



REMOVING AND INSTALLING AIR CLEANER BASE

Type:
Knee position gas cut and quick-acting type.

Driver side only.


Exhaust pipe / base

- Disconnect connector of quick-acting type knee gas cut.


② ■ Disconnect pipe.

③ ■ Pull off base from exhaust pipe (flow direction).


- Release air cleaner upper body from the base.




[20-3]




→ Undo the three screws holding the front air cleaner top cover.
Remove the top cover. Other tools required from the tool kit:
1 screwdriver



→ Undo the three screws holding the front air cleaner top cover.




→ Remove the central air cleaner filter from the front air cleaner and install the new one.




Replacing waste gas:

- Undo the bolts holding the front waste gas pipe.
- Remove the front waste gas pipe.
- Undo the mounting bolts for the exhaust pipe.
- Undo the waste gas pipe from the exhaust manifold.




- Remove hose between left air cleaner assembly and carburetor (the carburetor ventilation pipe and carburetor must remain in the left side of the engine).





- Remove hose between supercharger and electrical sensor housing (the air cleaner is removed from supercharger).

Step 2




- Remove exhaust pipe from connection.

Note: Retaining torque for hex socket head screws 10 mm access flange.




- Remove right exhaust pipe from connection. (This step is for vehicles with a 2.0L engine.)


Step 3



→ Remove intake air cleaner base and cleaner.
→ Disconnect and remove the intake air duct.



→ Remove base between the intake air cleaner and intake air duct. → Intake air cleaner




→ Remove intake air cleaner base and cleaner. → Intake air duct.


Note: When removing, the intake air cleaner base should be stopped "vertically" after being pulled.

→ Remove intake air cleaner base and cleaner.






→ - Oxygen sensor from exhaust manifold removed.



→ - Catalytic converter from exhaust manifold removed.



- Remove exhaust manifold gaskets from cylinder heads.

To install exhaust manifold follow "reverse" procedure.

Note:

The joint between exhaust manifold and cylinder head should be fitted in such a way that the gases feed into the exhaust muffler.

Defining a MIST System

Define iteration in the system's system definition of the specific problem domain.

- Iterating variables
- A value for each var
- Iteration timing
- Iteration count (e.g., 10)
- Loop progression

Define built-in logic as defined out on the host system.
Example: [Host OS](#) or [Linux](#) system. [Report](#) Oct 2003

The host system should be specified for fields as follows:

- If you want to use a file or command-line
• Then the should be specified as:
 - If you want to use a file, then the subject system's filename
and path, with a copy.
 - Set the action to the file with a string.
 - Set the command and system operating environment to the
file's path.
 - Or simply enter them (path).









16.12.1

• Check manifest and artifacts to determine what

files, settings and connection, etc. are necessary for
communication. Note: with Java reflection, many files may be
needed.

• Report any issues found.

✓
✓
✓



V.A.G Service.

Workshop Bulletin to Workshop Manual

Audi 100 1983 ► , Audi 200 1984 ►

Engine
Code letters

3B

Booklet

5-cylinder fuel injection engine, (4-valve),
mechanics

Edition 05.89

Mark Repair Group Index Column 13

with Bulletin No. 2

Models affected: all vehicles

Subject

Bulletin
page : Booklet
from page

Flywheel mounting bolts - 13-13
Different tightening method

From now on the flywheel mounting bolts must be tightened
as follows:

30 Nm and then turn another 1/4 turn (90°)

Notes:

- The additional 1/4 turn can also be done in two stages of 45° if it is not possible to turn the bolts through 90° in one movement.
- Always install new bolts, and coat with locking compound before installing.

440/404/-

V.A.G Service.

Workshop Bulletin to Workshop Manual

Audi 100 1983 ► , Audi 200 1984 ►

Engine
Code letters

SB

5-cyl. F.I. engine (4-valve), mechanics

Booklet

Edition 05.89

Mark Repair Group Index Column 21

with Bulletin No. 3

Models affected: All vehicles


Subject	Bulletin page	Booklet from page
<u>CHECKING TURBOCHARGER AND WASTEGATE</u>	1	21-18

Due to the introduction of turbocharger tester V.A.G 1397/A boost pressure is no longer measured as relative pressure but as absolute pressure. The checking procedure has changed as follows:

440/444/-

CHECKING TURBOCHARGER AND WASTEGATE

- Engine oil temperature 20° C min.
- No negative vacuum connections.
- Remove Manometer adapter unit cover or -4-blade in front passenger footwell).
- Remove vacuum hose from Manometer adapter unit.
- Connect manometer adapter V.A.G 1397/4 between disconnected vacuum hose and No. 1409/1 (0.05-1 bar).
- Connect plug connector on vacuum hose to connection 1 on turbocharger tester.
- Set selector switch to position 1 (vacuum measurement range).
- Switch on Turbocharger tester.



Notes:

- When Manovac button 4 on Turbocharger tester is pressed the last reading is stored until Manovac button 1 is pressed again or the tester is switched off.
- A flickering dotted point in the display indicates that a reading has been stored.
- If the battery voltage of the turbocharger tester drops below the permissible limit an arrow appears in the upper left corner of the display.
- Before testing the vehicle should be taken for a fast run over a distance of at least 3 km (no stops at traffic lights, etc.).
- As the boost pressure is limited during driving for safety reasons a second person should be present to operate the turbocharger tester.

2
27-086

- Run the engine until it is approx. 80 km/h (accelerate in fourth gear) and observe the rev. counter.

- At 3,000 rev press button 4 on turbocharger tester


- Specified readings:

Altitude (ft)	bar
Sea level up to 2,000 ft	1.013
2,000 ft	1.005
2,000 ft	1.000
2,000 ft	0.995
2,500 ft	0.985

- If the specified reading is obtained but there is reduced performance below 2,000 rev, check for wrong fuel (e.g. less than 90% RON) and check overrun by-pass valve - Repair Group 21.

- If the specified reading is not obtained interrogate fault memory and carry out fault directed diagnosis - see Workshop Manual, Electronic fuel injection and ignition system. Temporarily replace wastegate and repeat check.

- If the specified reading is still not obtained replace turbocharger.



Service.

Technical Bulletin to Workshop Manual
Audi 100 1983 ► , Audi 200 1984 ►

**Engine
code** 3B

Booklet 5-cylinder fuel injection engine (4-valve), mechanics

Edition 05.89

Enter in Repair Group list

Repair Group 17

Bulletin No. 4

Affected: All vehicles

Subject

REMOVING AND INSTALLING G1: SUMP

Contents	Bulletin page	Booklet from page
Removing and installing oil sump	1	17-20

Removing and installing oil pump

17-20

AMENDMENT

REMOVING AND INSTALLING OIL SUMP

When installing the oil sump, tighten the $\frac{1}{8}$ screws to 20 Nm first, and then tighten the $\frac{1}{8}$ screws to 50 Nm.