

## Workshop Manual

***Avant RS2 1994*** ▶

Edition 03.1994



All the assemblies of the RS2 are listed in the repair group index.

The current flow diagrams and repair procedures of the relevant assemblies and repair groups which differ are all described in this manual → Contents.

Where the repair procedures are identical reference is made to the relevant assembly of the Audi 80 1992 ► and Audi 100 1991 ► respectively.

This binder is issued as a loose leaf system.

Updating

Revisions and additions appear as supplements; in this case, the relevant pages should then be replaced.

Assembly		⇒ Workshop Manual
Electrical System	Audi 80	1992 ► Electrical System
Heating, Air Conditioning	Audi 80	1992 ► Heating, Air Conditioning
General Body Work	Audi 80	1992 ► General Body Work
Body Repairs		Body Repairs
6-speed Manual Transmission 01E 4WD	Audi 100	1991 ► 5- and 6-speed Manual Transmission 01E 4WD

Assembly		
Current Flow Diagrams Avant RS2		→ Contents
Running Gear 4WD	Audi 80	1992 Running Gear 4WD
Repair Group		Repair Group ►
01 Self-diagnosis	01	Self-diagnosis
48 Steering	48	Steering
All Other Repair Groups		⇒ Contents
5 Cyl. Engine (4-valve Turbo) Mechanics		⇒ Contents
Motronic		⇒ Contents
Injection and Ignition System (5-Cylinder)		⇒ Contents
Repair Group		Repair Group
	01	Self-diagnosis
	24	Mixture Preparation, Injection
28 Ignition System		→ Workshop Manual
	Audi 80	1992 ► Motronic
		Injection and Ignition System (5-Cylinder)
	28	Ignition System

Technical information should always be available to all foremen and mechanics because compliance with the instructions given is essential to ensure vehicle road worthiness and safety. In addition, the normal safety precautions to be observed when working on motor vehicles are also applicable.

The Workshop Manual is intended for use only within the Volkswagen and Audi Organization; passing on to third parties is not permitted.

## Supplement Index to Workshop Manual

### Avant RS2 1994 ▶

Please enter the date of issue of the Supplement. This enables you to see whether all the Supplements have been filed and that the Workshop Manual is thus up-to date.

Supplement	Edition	Article Number
1		000.5463.31.20
2		000.5463.32.20
3		000.5463.33.20
4		000.5463.34.20
5		000.5463.35.20
6		000.5463.36.20
7		000.5463.37.20
8		000.5463.38.20
9		000.5463.39.20
10		000.5463.40.20
11		000.5463.41.20
12		000.5463.42.20
13		000.5463.43.20
14		000.5463.44.20
15		000.5463.45.20
16		000.5463.46.20
17		000.5463.47.20
18		000.5463.48.20
19		000.5463.49.20
20		000.5463.50.20

Contents - next page

The Workshop Manual is intended for use only within the Volkswagen and Audi Organization; passing on to third parties is not permitted.  
© 1994 Audi AG

Printed in Germany  
000.5463.50.20

.....

3

## Contents

<b>Current Flow Diagrams Avant RS2</b>	<b>Page</b>
Relay position assignment .....	1
Immobilizer .....	2
- Motronic control and heater (cigarette) .....	3
Motronic control unit, heater, rear window .....	4
Film signal and hazard warning flasher system, liner (cigarette) .....	5
Bulb monitoring device, trailer coupling .....	6
Trailer coupling, rear fog lamp .....	7
Electrically adjustable driver and front passenger mirror .....	8
- All other non-Avant RS2 specific current flow diagrams : Workshop Manual Audi 80 Current Flow Diagrams, Electrical Fault Finding and Fitting Locations binder 1992 ▶	
 <b>00 Technical Data</b>	<b>Page</b>
Technical data .....	00- 1
Engine number .....	00- 1
Engine features .....	00- 2
 <b>01 Self-diagnosis</b>	<b>Page</b>
Motronic self diagnosis .....	01- 1
Fault table .....	01- 1
- Basic setting of engine with V.A.G. 1551 .....	01- 2
Coding variants of Motronic control unit J220 .....	01- 5
- For repair procedures below : Audi 80 1992 ▶ Motronic Fuel Injection and Ignition System (5-Cylinder)	
Integrating and erasing fault memory with fault reader V.A.G. 1551	
- Final control diagnosis with fault reader V.A.G. 1551	
- Testing cable connection of diagnostic sockets	
Removing and installing Motronic control unit	
Connecting test box V.A.G. 1596	
- Reading measured value block	
Interrogating control unit version with V.A.G. 1551	
 <b>10 Removing and Installing Engine</b>	<b>Page</b>
Removing and installing engine .....	10- 1
 <b>13 Crankshaft Group</b>	<b>Page</b>
Crankshaft group .....	13- 1
 <b>15 Cylinder Head, Valve Gear</b>	<b>Page</b>
Cylinder head, Valve gear .....	15- 1
 <b>17 Lubrication</b>	<b>Page</b>
Lubrication .....	17- 1
 <b>19 Cooling System</b>	<b>Page</b>
Cooling system .....	19- 1

<b>20 Fuel Supply System</b>	<b>Page</b>
<b>Fuel supply system</b> .....	<b>20- 1</b>
- Dismantling and assembling fuel pump .....	20- 1
- Testing delivery of fuel pump .....	20- 2
<b>21 Charging</b>	<b>Page</b>
<b>Charging</b> .....	<b>21- 1</b>
- Removing and installing parts of charge air cooler .....	21- 2
- Testing exhaust gas turbocharger and blow-off valve .....	21- 3
<b>24 Mixture Preparation, Injection</b>	<b>Page</b>
<b>Motronic components</b> .....	<b>24- 1</b>
- Technical data .....	24- 1
- <b>For repair procedures below → Audi 80 1992 ▶ Motronic Fuel Injection and Ignition System (5-Cylinder)</b>	
- Rules for cleanliness	
- Safety precautions	
<b>Repairing Motronic injection system</b> .....	<b>24- 2</b>
- Testing system pressure and holding pressure .....	24- 2
- Testing injectors .....	24- 3
- Testing altitude sensor -F96 .....	24- 4
- Reduction in engine output when towing a trailer .....	24-10
- <b>For repair procedures below → Audi 80 1992 ▶ Motronic Fuel Injection and Ignition System (5-Cylinder)</b>	
- Testing fuel pump relay and actuation	
- Testing idle speed and CO content	
- Testing idle speed stabilization	
- Testing Lambda probe and lambda control	
- Removing and installing lambda probe	
- Testing solenoid valve for activated charcoal filter	
- Testing solenoid valve for boost pressure limiter	
- Testing and adjusting idle speed switch	
- Testing and adjusting throttle valve potentiometer	
- Testing air mass meter	
- Testing auxiliary signal of air conditioner and compressor control	
- Testing auxiliary signal of air conditioner for increasing engine speed	
- Testing actuation of on-board computer for fuel consumption display	
- Testing fuel speed signal	
- Testing actuation of revolution counter	
- Testing output signal for throttle valve position	
- Testing auxiliary signal for reducing boost pressure when engine not	
- Pressure connections	
<b>26 Exhaust System</b>	<b>Page</b>
<b>Removing and installing exhaust system</b> .....	<b>26- 1</b>
<b>Aligning exhaust system free of tension</b> .....	<b>26- 7</b>
<b>Checking exhaust system for leaks</b> .....	<b>26-11</b>
<b>28 Ignition System</b>	<b>Page</b>
<b>For repair procedures below → Audi 80 1992 ▶ Motronic Fuel Injection and Ignition System (5-Cylinder)</b>	
<b>Motronic components</b>	

40	Front Suspension	Page
	Replacing wheel bearing housing .....	40- 1
	Removing and installing suspension strut and drive shaft .....	40- 6
	- For repair procedures below => Audi 80 1992 ▶ Running Gear 4WD	
	Servicing suspension strut	
	Servicing drive shaft	
	Servicing front suspension	
42	Rear Suspension	Page
	Replacing wheel bearing housing .....	42- 1
	Removing and installing drive shaft .....	42- 7
	- For repair procedures below => Audi 50 1992 ▶ Running Gear 4WD	
	Servicing subframe	
	Servicing drive shaft	
	Servicing rear axle	
	Servicing suspension strut	
44	Wheels, Tyres, Wheel Alignment	Page
	Filling tyres .....	44- 1
	Wheels and tyres .....	44- 5
	- Winter tyres .....	44- 5
	- For repair procedure below => Audi 80 1992 ▶ Running Gear 4WD	
	Wheel alignment	
45	Anti-locking Brake System	Page
	Removing and installing ABS components on front axle .....	45- 1
	Removing and installing ABS components on rear axle .....	45- 5
	- For repair procedures below => Audi 80 1992 ▶ Running Gear 4WD	
	Anti-locking brake system	
	Removing and installing hydraulic unit	
	Removing and installing components of electronic control	
46	Brakes, Brake Mechanics	Page
	Servicing front brakes .....	46- 1
	- Inspecting brake pad thickness .....	46- 3
	- Replacing brake pads .....	46- 3
	- Installing .....	46- 6
	- Running in brake pads .....	46- 6
	Servicing rear brakes .....	46- 9
	Servicing handbrake .....	46-12
	Removing and installing handbrake cables .....	46-16
	Adjusting handbrake .....	46-18
	- For repair procedure below => Audi 80 1992 ▶ Running Gear 4WD	
	Removing and installing pedal group, servicing pedal group	
47	Brakes, Brake Hydraulics	Page
	Servicing four-piston fixed-caliper brake system .....	47- 1
	- For repair procedures below => Audi 80 1992 ▶ Running Gear 4WD	
	Removing and installing brake master cylinder/brake servo unit	
	Bleeding brake system and changing brake fluid	
	Location of brake pressure regulator	










Relay position assignment:  
= Section "Fitting Locations"


Relay position with fuse holder:



Relay position assignment:

- 5 Relay II for sunroof
- 10 Relay I for sunroof


Front auxiliary relay carrier  
(below dash panel on left)



Relay position assignment:

- 15 Half-axle sensor device
- 16 Control unit for trailer recognition

Rear auxiliary relay carrier  
(below rear seat on left)



Relay position assignment:


- 19 Relay for switching off rear fog lamp for towing trailers

Colours of fuses

- 30 A green
- 25 A white
- 20 A yellow
- 15 A blue
- 10 A red
- 5 A black



Immobilizer




- bl = blue
- br = brown
- gy = yellow
- gr = green
- gr = grey
- ll = lilac
- ro = red
- sw = black
- ws = white

27-16245

- B - Starter
- D - Ignition starter switch
- H6 - Horn for anti-theft warning system
- J226 - Relay for starter inhibitor and reversing light
- J341 - Relay I for immobilizer
- J342 - Relay II for immobilizer
- S17 - Fuse for engine management (and ignition coil electric) cut-off valve or auxiliary fuse (odd)
- S111 - Fuse for anti-theft warning system and immobilizer
- T17 - Plug connector, 1-pin, black, below engine near spark
- T56m - Plug connector, 2-pin, violet, below door panel on left
- V94 - Motor for central locking system with cruise control for engine temp time delay and anti-theft warning system
- (39) - Earth connection (engine bay) for anti-theft warning system
- (111) - Universal ignition protection unit (in front right wing beam)
- (112) - Positive earth (90 pin) for immobilizer control for engine system and 2-point contact switch wiring loom
- (39) - Earth connection (engine bay) for anti-theft warning system
- (111) - Universal ignition protection unit (in front right wing beam)
- (112) - Positive earth (90 pin) for immobilizer control for engine system and 2-point contact switch wiring loom



Motoric control unit, trailer recognition



- bl = blue
- br = brown
- ge = grey
- gn = green
- gr = gray
- li = lilac
- m = red
- sw = black
- ws = white


- F56 All-lead cable
- J256 Control panel coolant pump exhaust gas boiler charge
- J220 Motoric control unit
- J240 Control unit for trailer recognition
- S27 Fuse for engine management (on auxiliary fuse holder)
- S28 Plug-in connector, 2-pin, white (in pre-ignition chamber) used to relay pulse (diagnosis, sensor water)
- S29 1x 11 connector, 2-pin, red (in front right wiring loom)
- S30 1x 11 connector, 2-pin, white (in front right wiring loom)
- S31 1x 11 connector, 2-pin, white (in front right wiring loom)

- (D) - Plug-in connector, 2-pin, red (in front right wiring loom)
- (E) - Plug-in connector, 2-pin, white (in front right wiring loom)
- (F) - Plug-in connector, 2-pin, white (in front right wiring loom)
- (G) - Plug-in connector, 2-pin, white (in front right wiring loom)
- (H) - Plug-in connector, 2-pin, white (in front right wiring loom)
- (I) - Plug-in connector, 2-pin, white (in front right wiring loom)
- (J) - Plug-in connector, 2-pin, white (in front right wiring loom)
- (K) - Plug-in connector, 2-pin, white (in front right wiring loom)
- (L) - Plug-in connector, 2-pin, white (in front right wiring loom)
- (M) - Plug-in connector, 2-pin, white (in front right wiring loom)
- (N) - Plug-in connector, 2-pin, white (in front right wiring loom)
- (O) - Plug-in connector, 2-pin, white (in front right wiring loom)
- (P) - Plug-in connector, 2-pin, white (in front right wiring loom)
- (Q) - Plug-in connector, 2-pin, white (in front right wiring loom)
- (R) - Plug-in connector, 2-pin, white (in front right wiring loom)
- (S) - Plug-in connector, 2-pin, white (in front right wiring loom)
- (T) - Plug-in connector, 2-pin, white (in front right wiring loom)
- (U) - Plug-in connector, 2-pin, white (in front right wiring loom)
- (V) - Plug-in connector, 2-pin, white (in front right wiring loom)
- (W) - Plug-in connector, 2-pin, white (in front right wiring loom)
- (X) - Plug-in connector, 2-pin, white (in front right wiring loom)
- (Y) - Plug-in connector, 2-pin, white (in front right wiring loom)
- (Z) - Plug-in connector, 2-pin, white (in front right wiring loom)

Note: Cable glands are located in the front right relay chamber on plug-in chamber.



Motoric control unit, heated rear window




- 30 - Switch for heated rear window
- G1 - Ignition timing sender
- G20 - Engine speed sender
- J220 - Motoric control unit
- T10n - Plug connector, 3-pin, black, for ignition timing sender
- T10r - Plug connector, 3-pin, white, for oil level
- T10b - Plug connector, 3-pin, black, for engine panel auxiliary relay control
- Z1 - Heated rear window

- (117) - Earth connection, in exterior lamp wiring loom
- (128) - Earth connection (ground point), in Motoric wiring loom
- (219) - Earth connection, 2 - in daylight wiring loom
- 108 - Switch only on vehicles without air conditioner
- 110 - Switch on vehicles with air conditioner - Current flow diagram No. 69, model year 1993

- (32) - Earth connection (last panel on left)
- (3) - Earth connection (1-), in cash pans wiring loom




## Turn signal and hazard warning flasher system, licence plate light





Bulb monitoring device, trailer coupling




- F1 - Light switch
- J123 - Front bulb monitoring device
- J124 - Rear bulb monitoring device
- J169 - Auto Check system
- M1 - Bulb for left side light
- M2 - Bulb for right side light
- M3 - Bulb for rear light turn signal light
- M4 - Bulb for right side light
- T102 - Plug connection, 10-pin, yellow, connector base in auxiliary relay carrier
- T103 - Plug connection, 10-pin, brown, connector panel in auxiliary relay carrier
- U10 - Socket for trailer operator

- (86) - Connected to (+) front wing lamp
- (87) - Connected to (-) front wing lamp
- (A20) - Connected (15F) in dash panel wiring loom
- (W7) - Connected (right turn signal) in rear wing loom



Trailer coupling, rear fog light



- bl .. blue
- br .. brown
- ge .. yellow
- gn .. green
- gr .. grey
- li .. lilac
- ru .. red
- sw .. black
- ws .. white


- F10 .. Switch for rear fog light
- F14 .. Switch for rear wing lights
- F24 .. Fuses for thermostat
- 2259 .. Rear fog light control relay (trailer operation)
- K84 .. Indicator lamp for hazard warning system and ignition signal
- K85 .. Indicator lamp for left turn signal
- L46 .. Bulb for left rear fog light
- L47 .. Bulb for right rear fog light
- M1 .. Bulb for left reversing lamp
- M2 .. Bulb for right reversing lamp
- T1 .. Plug connection for rear fog light
- T2 .. Plug connection 1 pin black, behind dash panel
- T3 .. Plug connection 3 pin behind dash panel on left
- T4 .. Plug connection 6 pin black, front of head
- T5 .. Plug connection 8 pin in right of engine compartment
- T6 .. Plug connection 8 pin in right of engine compartment
- T7 .. Plug connection 10 pin brown, in front panel of auxiliary battery
- T8 .. Plug connection 20 pin, with top dash panel insert
- T9 .. Plug connection 28 pin, below dash panel insert
- T10 .. Socket for trailer junction

- (50) .. Leftpoint - left of car
- (91) .. Earth connection - 1 - in dash panel wiring loom
- (98) .. Earth connection - 1 - in rear wing loom
- (213) .. Earth connection - 1 - in tailgate wiring loom
- (213) .. Earth connection - 2 - in tailgate wiring loom

97-18370



Electrically adjustable driver and front passenger mirror



- b/ = blue
- br = brown
- ge = yellow
- gn = green
- gr = grey
- l = lead
- rd = red
- sw = black
- ws = white

- E43 - Switch for adjusting mirror
- T10 - Plug connector, 1-pin, green, behind dash (left side) on left
- T50 - Plug connector, 6-pin, at bottom, right of 4-pin for
- T56 - Plug connector, 6-pin, at bottom, left of 4-pin for
- T69 - Plug connector, 6-pin, in left (rear-view mirror)
- T69g - Plug connector, 6-pin, in right (rear-view mirror)
- V17 - Motor for adjusting mirror (driver side)
- V25 - Motor for adjusting mirror (front passenger side)
- Z4 - Heated rear-view mirror (driver side)
- Z5 - Heated rear-view mirror (front passenger side)
- Z6 - Heated rear-view mirror (left passenger side)
- Z7 - Earth connection in rear-view mirror wiring loom
- Z1 - Connector 1 in mirror adjustment (heated wiring loom)
- Z2 - Connector 2 in mirror adjustment (heated wiring loom)

97 1857E



## Technical data

### Engine number

- The engine number ('engine code letters' and 'serial number') is stamped on the front right of the cylinder head.

In addition, a sticker with 'engine code letters' and 'serial number' is affixed to the toothed belt guard.

The engine code letters are additionally listed on the vehicle data plate.



100-1

### Engine features

Code letters	ADU	Code letters	ADU
Manufactured from	01.94 ➤		
Displacement	2 226	Valve timing	
Engine output	232/6500	at 1 mm valve lift and 0 mm valve clearance	
Torque	400/2400	Inlet opens ATDC	13°
Bore dia	81	Inlet closes ABDC	35°
Stroke	86,4	Exhaust opens BBDC	24°
Compression	9,3	Exhaust closes ATDC	1°
RON/MON 50-80 recommended min. RON	91		
Injection system	Mechanic		
Ignition system	Mechanic		
Knock control	yes		
Self-diagnosis	yes		
Lambda control	yes		
Catalytic converter	yes		
Charging	yes		

100-2

.....

h

## Motronic self-diagnosis

### Fault table

- The differences from engine code ABY are described below; all other faults → Audi B0 1992 Motronic Fuel Injection and Ignition System (5-Cylinder)

Output on printer of V.A.G 1551	Possible cause of fault	Possible effects	Rectifying fault
X0013 Maximum engine speed exceeded  - Signal too large	- Engine overrevs as a result of incorrect gear shift (engine speed greater than 7440 rpm)	- Possible engine damage	- Rectify mechanical damage

! This fault type is displayed in addition to the component.

C1-1

### Basic setting of the engine with V.A.G 1551

- The differences from engine code ABY are described below; the remaining procedure for the basic setting → Audi B0 1992 Motronic Fuel Injection and Ignition System (5-Cylinder).

#### Explanation of readouts in display fields 1 to 10

Display field	Specified readout	Corresponds to measured value	Designation	Remarks
1	94-216	85-105°C	Coolant temperature	Requirement for all other readouts, specifications
2	15-24		Engine load	With air conditioner off, without ancillaries
3	76-84	760-840 rpm	Engine speed	With air conditioner off, without ancillaries
4	121-135		Idle speed stabilization operating range	Change in air flow caused by +N71
5	70-125		Idle speed stabilization map zero point	Internal computed value
6	123-137		Idle speed stabilization load adaptation	Change in air flow caused by +N71
7	41-61		Idle speed stabilization map correction	Internal computed value
8	123-133		Lambda control	After about 1.5 minutes
9	100-150		Programmed value for lambda control	If readout is high, perform road test again
10	35-37	8-12° BTDC	Ignition angle when idling	Ignition angle computed by J220

C1-2

Display group number 03

Display field	Readout on V.A.G 1551	Cause of fault	Rectifying fault
1	760 - 840 rpm	→ Display group number 01, display field 1	
2	95 - 35 %	ok	
	greater than 35 %	<ul style="list-style-type: none"> <li>· Air conditioner on</li> <li>· Electrical components on</li> <li>· AC compressor running, although air conditioner off</li> <li>· Air mass meter -G70 faulty</li> <li>· Central hydraulic pump faulty</li> <li>· Unmetered air between turbocharger and throttle valve</li> </ul>	<ul style="list-style-type: none"> <li>- Switch off air conditioner</li> <li>- Switch off ancillaries</li> <li>- Test air conditioner → Repair Group 87</li> <li>- Test -G70 → Repair Group 24</li> <li>- Test central hydraulic pump → Repair Group 48</li> <li>- Rectify cause of fault</li> </ul>
	less than 25 %	<ul style="list-style-type: none"> <li>· Unmetered air between air mass meter -G70 and turbocharger or downstream of throttle valve</li> <li>· Vacuum hose dropped off</li> <li>· Crankcase ventilation leaking</li> <li>· Fuel tank ventilation</li> <li>· Solenoid valve 1 for activated charcoal filter jamming</li> <li>· Air mass meter -G70</li> </ul>	<ul style="list-style-type: none"> <li>- Rectify cause of fault</li> <li>- Check vacuum system</li> <li>- Check crankcase ventilation</li> <li>- Check fuel tank ventilation system</li> <li>- Perform final control diagnosis → Repair Group 31</li> <li>- Test -G70 → Repair Group 24</li> </ul>

01-3

Display field	Readout on V.A.G 1551	Cause of fault	Rectifying fault
3	5 - 10 s <sup>-1</sup>	ok	
3	greater than 10 s <sup>-1</sup>	<ul style="list-style-type: none"> <li>· Throttle valve potentiometer -G69 faulty or incorrectly set</li> <li>· Throttle cable incorrectly set</li> <li>· Throttle valve jamming</li> </ul>	<ul style="list-style-type: none"> <li>- Test throttle valve potentiometer -G69 → Repair Group 24</li> <li>- Adjust throttle cable → Repair Group 22</li> <li>- Test throttle valve</li> </ul>
	less than 5 s <sup>-1</sup>	<ul style="list-style-type: none"> <li>· Throttle valve potentiometer -G69 faulty or incorrectly set</li> </ul>	<ul style="list-style-type: none"> <li>- Test throttle valve potentiometer -G69 → Repair Group 24</li> </ul>
4	°C	<ul style="list-style-type: none"> <li>· Dependent on ambient temperature: no specification</li> </ul>	

## Display group number 04

Display field	Readout on V.A.G 1551	Cause of fault	Rectifying fault
1	760 240 rpm	-> Display group number 01, display field 1	
2	25.35 %	-> Display group number 03, display field 2	
3	4 km/h	o.k. (if speed less than 4 km/h, a constant 4 km/h is displayed)	
4	0000	o.k. (only when idling)	
	0000	ice speed switch - HSC faulty	Test -> Repair Group 24

01-5

## Coding variants of Motronic control unit -J220

The control unit identification and the coding are displayed when the fault memory is interrogated.

The coding is performed through the wiring loom.

Only coding 4 is permissible.

### Coding 4:

- Road speed limited to 270 km/h
- Contact 38 of Motronic control unit is permanently connected to earth

If coding 1 is displayed for the control unit identification, service cable connection between contact 38 and earth

### *Important!*

*If the earth connection is removed, the road speed limit is cancelled. It is not permitted to perform such a modification.*

01-6

.....

6.

## Removing and installing engine

• Workshop Manual  
Audi 100 1991 ►  
Engine code AAN  
5-Cyl. Injection Engine (4 Valve Turbo),  
Mechanics Edition 07/91  
Bulletin No. 4  
Printed 09/93  
as of page 15-1

Modifications

**Note, information:**

*Coolant pipe to expansion tank needed.*



.....

3



## Crankshaft group

-- Workshop Manual  
Aut. 100 1991 ►  
Engine code AAN  
5-Cyl. Injection Engine (4-Valve, turbo).  
Mechanics Edition 02/91  
Bulletin No. 4  
Edition 09/93

### Modifications

-- Page 13-14

### Note, information.

- Filled main bearings on crankshaft
- Crankshaft main bearing shells with 40° groove

13-1



13-2



## Cylinder head, valve gear

→ Workshop Manual  
Audi 100 '99: ►  
Engine code AAA  
5-Cyl. Injection Engine (4-Valve, Turbo)  
Mechanics

Modifications

-- Page 15-1

**Note, Information:**

- \* "Metal" cylinder head gasket, installation as before





## Lubrication system

↳ Workshop Manual  
Audi 80 1987 ▶, Audi 90 1987 ▶  
Engine code 3B  
5-Cyl. Injection Engine  
(4-Valve, Turbo) Mechanics

### Note, information:

- *If considerable quantities of metal swarf or abrasion - caused by seizure damage such as crankshaft and conrod bearing damage - are found in the engine oil when performing repairs to the engine, it is necessary not only to carefully clean the oil passages but also to replace the oil cooler in order to avoid consequential damage.*
- *The oil level must not exceed the max. marking - risk of damage to catalytic converter.*

### Modifications:

- None

17-1



17-2



## Cooling system

← Workshop Manual  
Audi 60 1987 ▶, Audi 90 1987 ▶  
Engine code JB  
5-Cyl. Injection Engine  
(4-Valve, Turbo), Mechanics  
Édition 01.91

### Modifications

Page 19-1

### Note, information:

- Modified coolant pipe connection Fig. 19-349) from coolant thermostat housing to heat exchanger, additional outlet for coolant expansion tank.
- Modified part (seal) below coolant thermostat
- Drive gear for coolant pump, No. of teeth was 29 is now 26.

19-1







## Fuel supply system


→ Workshop Manual  
Audi 100 1991 →  
Engine code AAN  
5 Cy Injection Engine (4-Valve, Turbo).  
Mechanics Edition: 07/91  
Technical Bulletin No. 4  
Edition 08/93

### Modifications

- Page 20-16

### Dismantling and assembling fuel pump

- - Bolt feed pipe - 1 - tight to the fuel pump, as shown in the plan view (top part of Fig.;  $\delta = 50^\circ$ )
- Attach electrical wiring to the fuel feed pipe, as shown in the Fig.
- After tightening the cable ties - 2 -, cut off excess length.




20-1

Page 20-21

### Testing delivery of fuel pump

Test delivery by switching on switch of remote control V.A.G 1346/3A for 15 seconds (press button and hold)

- - Refer to the diagram for the specifications for testing minimum delivery
- Minimum delivery measured in cm<sup>3</sup>/5 seconds at the return pipe.
- \*\*Voltage at fuel pump when engine switched off and pump running about 2 volts less than battery voltage



20-2



## Charging

→ Workshop Manual  
Audi 100 1991 →  
Engine code AAN  
5-Cyl. Injection Engine (4-Valve, Turbo),  
Mechanics Edition 07 91  
Technical Bulletin No. 4  
Edition 09.03


### Modifications

→ Page 21-13

Hexagon nut Fig. 21-100/12

→ The hexagon nuts (arrows) can only be slackened with a 12 mm ring wrench which has been ground flat at both sides of the ring

- Remove coolant pipe in the turbocharger and bracket for oil filter in order to improve access
- It may be necessary in certain instances to use an open-end wrench




21-13

→ Page 21-14

### Removing and installing parts of charge air cooler


- 1 - Charge air cooler
- 2 - Hexagon bolt, 22 Nm
- 3 - Pressure pipe
- 4 - Hexagon bolt, 22 Nm
- 5 - Hexagon nut, 22 Nm
- 6 - Shield
- 7 - Shield
- 8 - Pressure pipe
- 9 - Hexagon nut, 22 Nm
- 10 - Pressure hose
- 11 - Pressure pipe
- 12 - Pressure hose
- 13 - O-ring seal  
• Replace



Audi RS2 1994 →  
001.046.134.20

Edition 03-94

21-14



### Testing exhaust gas turbocharger and blow-off valve

- Connect turbocharger tester V.A.G 1397/A between the vacuum hose (arrow) and the intake manifold.
- Fit ball end coupling of vacuum hose to connection -B- of the turbocharger tester.  
Run test hose along the rear edge of the bonnet and through the opening of the right window into the interior of the car.
- Switch on turbocharger tester. Set range switch to position -I- (I) test hose on to connection fitting -I-.
- Accelerate car in 4th gear from about 50 km/h and full throttle and keep a check on rev counter.
- At 3000 rpm, press memory button M on turbocharger tester V.A.G 1397/A.

Charge air temperature in °C	10	25	45	55
Height above MSL	Boost pressure in bar at full load			
0 to 1600 m	2300 up to 2400 mbar			
at 2300 m	2200 up to 2300 mbar			

21-3

#### Note:

- The hose pipes must be absolutely free of leaks otherwise incorrect measurements may occur.
- Ensure that the test hose is not jammed at the bonnet and side window.
- When the memory button M on the turbocharger tester is pressed, the last reading is stored and retained until the memory button M is again pressed or until the tester is switched off.
- Storage of the reading is indicated by the contents in the display panel flashing.
- If the battery voltage of the turbocharger tester drops below the specified level, an arrow appears in the top left corner of the display. An incorrect reading may be shown.
- Before testing the car, drive at a brisk speed for at least 2 km (without stopping at traffic lights or similar).
- As the boost pressure is measured when driving, a second person is required for operating the turbocharger tester for safety reasons.
- Perform at least three measurements and calculate an average figure.

## Motronic components

### Technical data

System pressure (gauge pressure in bar) with engine running (idling)	
without vacuum: 3.8 - 4.0 with vacuum: 3.2 - 3.7	
Holding pressure for 10 minutes (minimum pressure in bar)	
when engine cold: 3.1 when engine hot: 3.6	
Injectors	
Quantity injected in ml/20 s: 130 - 140	
Idle speed test	Engine speed: 770 - 800 rpm
	CO content upstream of CAT: 0.5...0.9 % vol

24-3

## Servicing Motronic Injection system


### Testing system pressure and holding pressure

Specified pressures for pressure test:

- 3.8...4.0 bar when pump running
- 3.3...3.5 bar immediately after switching off fuel pump


For procedures as well as connection of pressure measuring device see Aud. 80 1992 Motronic Fuel Injection and Ignition System (5-Cylinder).





### Testing injectors

- ➔ Resistance of injector.
- 13.5 .. 15.5 Ω.



- ➔ Quantity injected per injector in 20 sec.

- 130 .. 140 ml.

Procedures → Audi 20 1992: Electronic Fuel Injection and Ignition System (5-Cylinder).

24 3


### Testing altitude sender –F96

(Models without trailer coupling or not towing a trailer)


#### Notes:

- On models with a trailer coupling, the altitude sender signal passes through the trailer recognition control unit –J345 to the Motronic control unit –J220.
  - If vehicle is not fitted with trailer coupling a bridge is provided at the relay position for –J345 which passes the signal of the altitude sender to the Motronic control unit –J220 instead of through the control unit for trailer detection.
  - The trailer recognition control unit is located in the auxiliary relay carrier below the dash panel on the left, relay position 16 (→ Current Flow Diagram).
- ➔ Testing trailer recognition control unit –J345 → Reducing engine output when towing a trailer, page 24 - 10

The altitude sender is located in the front passenger footwell below the turn panel in a recess of pillar A.



24 4



- Read measured value block and select display group 02 → Repeat Group 01

➔ Readout in display

- Check readout in display field 4

The current atmospheric pressure in mbar is displayed

**Notes:**

- The current atmospheric pressure is dependent on the altitude and pressure fluctuations resulting from meteorological conditions
- The atmosphere pressure at sea level is about 1013 mbar when meteorological conditions are normal and decreases by about 100 mbar for each 1000 m altitude.
- The weather-related pressure fluctuations (ignoring extreme weather conditions and tropical countries) are generally less than ± 50 mbar.
- If a constant 998 mbar is displayed instead of the current atmospheric pressure (fault 00528 in fault memory), in the figure displayed 0000, greatly from the figure which would be normal, as a result of a failure and weather conditions → testing voltage supply of altitude sender and cable connections

24-5

**Notes:**


- if the altitude sender fails, the control unit assumes a substitute altitude of about 3000 m and a constant 998 mbar.
- After rectifying the cause, the fault is classified as a sporadic fault and normal control is resumed

**Testing voltage supply of altitude sender**

- Unplug connector from altitude sender
- Switch on ignition
- ➔ - Connect hand-held multimeter V.A.G 1596 with auxiliary cables from V.A.G 1594 for voltage measurement in turn between contacts 1 and 3 as well as 2 and 3.

Specification in each case: 4.5, 5.5 V

! One of the specifications is not achieved, test cable connections to the Motronic control unit!




### Testing cable connection of altitude sender

Switch off ignition.

Connect test box V.A.G 1598 with adapter cable V.A.G 1598/5 only to the wiring loom in the Malronic control unit → Repair Group 01.

– Remove bridge or unplug control unit for trailer recognition → J345 at the auxiliary relay carrier, relay position 16.



– Test the following cables for open circuit or short circuit on the basis of the current flow diagram.

• From contact 1 at connector for -F96 to contact 2 at relay base for -J345.


• From contact 5 at relay base for -J345 to socket 9 of the test box.

• From contact 2 at connector for -F96 to socket 12 of the test box.


• From contact 3 at connector for -F96 to socket 30 of the test box.

Specification: max. 1.0 Ω

24-7



– Rectify any open circuit or short circuit in wiring.



– If vehicle fitted with trailer coupling, test control unit for trailer recognition contact 2 to contact 5 for continuity.

Specification: approx. 1 Ω

– Re-insert bridge or plug in trailer recognition control unit → J345 at auxiliary relay carrier, relay position 16.

24-8



Connect adapter cable V.A.G 15985 to the Motronic control unit.

- Switch on ignition.
- Connect hand-held multimeter V.A.G 1526 in turn between sockets 12 and 30 as well as 9 and 30.

Specification for socket 12 and 30: 4.5 - 5.5 V.

Specification for socket 9 and 30: 0.5 - 5.0 V.

- If one of the specifications is not achieved, replace Motronic control unit.
- After rectifying all the faults, interrogate and erase fault memory.

24-9

## Reduction in engine output when towing a trailer

(Models with trailer coupling when towing a trailer)

### Notes:

- When towing a trailer, the engine output is reduced to about 169 kW (230 HP). This is done by the trailer recognition control unit -J345- intercepting the signal of the altitude sensor -F36- and supplying a fixed value of about 0.5 V in its place to the Motronic control unit -J220-.
- The fixed value of 0.5 V corresponds to a pressure level of 600 mbar (about 4200 m above MSL).
- The trailer recognition control unit -J345- is located in the auxiliary relay carrier below the dash panel on the left, relay position 16 (→ current flow diagram).
- Either a trailer or a separate light unit (e.g. test facility for trailer socket) must be used for the test.

Read measured value block			
1	2	3	4

#### Test requirements:

- *Altitude sensor: F06 OK (no fault in fault memory)*
- *Trailer lighting operates*

Unplug trailer connector.

- Read measured value block and select display group 02 = Repair Group 01

#### ➤ Readout in display.


- Check readout in display field 4.

The current atmospheric pressure is displayed in mbar.

- Plug in trailer lighting.

The fixed value of 600 mbar supplied by F06 is displayed.

- If no change occurs from the current reading to the fixed value for trailer operation when the trailer lighting is plugged in, or if the constant value of 600 mbar is displayed instead of the current value (and fault 00570 is thus stored), replace trailer recognition control unit.



## Removing and installing exhaust system

### Notes:

- \* Aligning exhaust system front at terrain → page 26-7
- \* Checking exhaust system for leaks → page 26-11
- \* Separation point between centre silencer and fan silencer → page 26-5 Fig. 1
- \* Always fit new gaskets and hexagon nuts


1 - Blow-off valve

2 - Gasket

3 - Turbocharger

- \* Removing and installing
- Workshop Manual Audi 100 1991 →
- Engine Code AAN
- 5-Cyl. Injection Engine (4-Valve)
- Engine, Edition 07.91
- Technical Bulletin No. 4
- Edition 08.85

26-1



4 - Corrugated tube

- \* Fitting location → page 26-6 Fig. 2

5 - Hexagon nuts, 25 Nm

6 - Gasket

7 - Screw plug, 27 Nm

8 - Lambda probe, 50 Nm

- \* Testing
- Repair Group 24
- \* Grease thread with G5: grease must not get into the air area of probe body

9 - Gasket

10 - Hexagon nut, 30 Nm


11 - Hexagon nut, 30 Nm

- \* Width across flats = 5

12 - Front exhaust pipe


- \* Clearance to heat shield of left drive shaft about 16 mm

26-2



- 13 - Intermediate pipes
  - Lock nut, CO sampling 25 Nm
  - Aligning → page 26-10
- 14 - Hexagon bolt, 25 Nm
- 15 - Double clips
  - Fitting location → page 26-10
  - Tighten evenly 40 Nm
  - Replace each time after clanking the screw union
- 16 Bracket
  - Align → page 26-8
- 17 - Hexagon bolt, 25 Nm
- 18 - Tail silencer
  - Align tail pipes → page 26-9
  - Adjust extension of exhaust system → page 26-8
- 19 - Suspension loop
- 20 - Centre allencer
  - Align when performing repairs → page 26-9


26-3



- 21 - Seals
- 22 - Catalytic converter
  - Frs. in adequate clearance between catalytic converter input pipe and heat shield for transmission bearing → page 26-7
- 23 - Seal
- 24 - Hexagon bolt, 25 Nm
- 25 - Catalytic converter suspension
  - Location of parts → page 26-6 Fig. 3
- 25 - Hexagon nuts
  - Welded in place, replace if damaged
- 27 - Hexagon nut, 60 Nm
- 28 - Gasket for exhaust manifold
- 29 - Exhaust manifold
- 30 - Hexagon nut, 25 Nm

26-4


**Fig. 1 Separation point between centre silencer and tail silencer**



- A separation point is provided for replacing the centre silencer or tail silencer, respectively.
- Separate exhaust pipe between centre silencer and tail silencer at the point marked by a groove
- ➔ Size --a-- about 300 mm.
- A short double clip is provided for connecting centre silencer and tail silencer when performing repairs. 40 Nm
- Align centre silencer when performing repairs → page 26-9.
- The double clip should be installed horizontally
- The screw union of the double clip must be sealed on the right side of the exhaust pipe.


26-5

**Fig. 2 Installation position of corrugated tube**



- ➔ - Flow direction: arrow-- from exhaust manifold to exhaust system

**Fig. 3 Suspension of catalytic converter**




- ➔ Location of parts
- 1 Hexagon nut 25 Nm
- 2 Catalytic converter

## Aligning exhaust system free of tension

The exhaust system should be aligned free of tension as described below in order to avoid noises and stresses in the exhaust system.

### Notes:

- Slacken all the bolted joints of the exhaust system including the suspension of the catalytic converter
- The dimensions stated in the Fig. are a guide
- The exhaust system is aligned when cold
- The procedure described below must be performed in the order stated



The clearance between front exhaust pipe and heat shield of the left drive shaft must be at least 10 mm.

- Align catalytic converter. It is important to ensure that an adequate clearance of at least 10 mm exists between catalytic converter input pipe and heat shield for transmission bearing (arrow)

26 7



- The catalytic converters -A- must be positioned at least 2 mm higher than the catalytic converter collision guard, as shown in the figure (size -a-)

### Notes:

- The catalytic converters are shown from the rear viewed in direction of travel
- The size -a- must be measured from the centre -b- of the catalytic converter collision guard
- Tighten flanged joint between front exhaust pipe and catalytic converter on left and right. The screwed joints of the flanges of front exhaust pipe, catalytic converter must be tightened in such a way that the flanges have the same clearance to each other at round: 25 Nm

Tighten suspension of catalytic converter free of tension, 25 Nm.


- Adjust pretension of the left mounting bracket of the wheel sensor. Size -a- at least 15mm should be obtained by moving in the double clip



26 8

**Notes:**

- After tightening the bracket, the opening *b* must not be blocked.
- Brackets which are permanently deformed or damaged must be repaired.
- Align tail pipes so that sufficient clearance to the pump exists in all directions.
- Align center silencer when performing repairs.




**Note:**

The illustration shows the front baffle of the center silencer.

- The pre-tension *a* of 7 mm should be obtained by moving it in the double clip.
- The clearance *b* between the flap and the securing straps must be at least 2 mm at both hangers.


26-9



- Align intermediate pipes as shown in the Fig. Size *a* about 20°.

**Note:**

The intermediate pipes are shown from behind, viewed in direction of travel.



- Align screw unions of the double clips as shown in the Fig., and tighten 40 Nm.

**Notes:**

- Double clips are shown from the rear, viewed in direction of travel.
- After slackening the screw union, the double clip must be replaced.
- Tighten bolted connection of flanges joint of catalytic converter intermediate pipes. The bolted connection of the flanges of the catalytic converter intermediate pipes must be tightened in such a way that the flanges have the same clearance to each other all round, 25 Nm.

26-10


**The exhaust system should be checked for leaks by adopting the following procedure:**

- Run engine
- Seal fan pipes for the duration of the leak test e.g with rags or plugs.
- Check the following joints by listening for leaks: Cylinder head/ manifold, manifold- front exhaust pipe etc.
- Rectify any leaks found

76-11







## Replacing wheel bearing housing

- 1 - Wheel bearing housing**
- With  $\varnothing$  62 mm bearing bore
  - Do not grease bearing seat in wheel bearing housing before pressing in wheel bearing
  - In order to press out the pivot journal, on no account widen slot in wheel bearing housing / seat for pivot journal
  - After installing and removing or replacing, check front side alignment

- 2 - Plug**
- On vehicles fitted with anti locking brake system, a spring sleeve for mounting the speed sensor is in socket instead of the plug

- 3 - Hexagon bolt, 10 Nm**

- 4 - Splash guard**

- 5 - Wheel bearing**

### Important!


*Pay attention to installation position. Large inner diameter of wheel bearing faces wheel hub.*


- Is destroyed when pressing out
- Pressing out  $\Rightarrow$  Fig. 2
- Inserting  $\rightarrow$  Fig. 3

- 6 - Wheel hub**
- Pressing out  $\rightarrow$  Fig. 1
  - Inserting  $\rightarrow$  Fig. 4
  - Pressing off bearing inner race  $\rightarrow$  Figs. 5 and 6

- 7 - Hexagon bolt, 65 Nm**

- 8 - Adapter for brake caliper**
- For attaching the four-piston brake caliper







→ Fig. 1 Pressing wheel hub out of wheel bearing housing

*Note:*

Use a  $\varnothing 200 \times 180 \times 4$  inch ring which is closed at one end for pressing out the wheel hub




→ Fig. 2 Pressing out wheel bearing



→ Fig. 3 Pressing wheel bearing - A- in until fully home


– Large inner diameter of wheel bearing faces wheel hub.



→ Fig. 4 Pressing wheel hub into wheel bearing

*Notes:*

- When pressing in, the tool VW 544 must be supported only at the leading inner race
- Tool 3144 with angled side facing up




→ Fig. 5 Inserting separating device


Insert separating device into the annular groove of the bearing inner race and pre-tension appropriately with spindle.

**Note:**

Use commercially available separating device, e.g. KUKKO 15-17.




→ Fig. 5 Pressing bearing inner race off wheel hub



**Removing and installing suspension strut and drive shaft**

- 1 - Plastic nut
- 2 - Cap
  - Screw into wheelhouse
- 3 - Self-locking nut, 60 Nm
  - Always replace
  - Tighten with torque wrench → page 40-14 Fig. 2
- 4 - Dished stop plate
- 5 - Suspension strut
  - Do not unbolt from wheel bearing housing in order to replace shock absorber, coil spring and wheel bearing, but remove complete and install (camber setting)
- 6 - Gasket
  - Rip out put off protective strip and stick into the joint



**7 - Drive shaft**


- To remove, unbolt coupling rods at both sides of suspension strut and push into ball bar up until from the flanged shaft and also remove hexagon bolt - washer

**Important!**

*If it is necessary to remove vehicles on which the drive shaft has been removed, an outer joint must be installed first of all in place of the drive shaft otherwise the wheel bearing will be damaged.*

- Pay attention to different lengths on left and right
- When removing the drive shaft, push back ABS speed sensor slightly first of all, press in until fully home when installing

40-7



**8 - Backing plate**

**9 - Cylindrical bolt, 80 Nm**

**10 - Hexagon bolt**

- Always replace

**11 - Track rod**

- Prise off steering arm with two-leg gear puller → page 40-11 Fig. 7


**12 - Wheel bearing housing with wheel hub**

- To press off the pivot journal, on no account widen slot in wheel bearing housing (see for correct parallel)
- After installing, check front axle alignment

**13 - Hexagon bolt**


- Always replace
- Bolt head faces in direction of travel

40-8




- 14 - Axle link with axle joint**
- When removing from wheel bearing housing, do not widen slot in wheel bearing housing
  - Limit journal diameter 19.0 mm
  - Only as forged version
- 15 - Self-locking nut, 30 Nm**
- Always replace
- 16 - Self-locking nut**
- Always replace
  - Tighten to 110 Nm and then tighten a further 90°
- 17 - Washer**
- 18 - Self-locking nut, 50 Nm**
- Always replace
- 19 - Spacer**

40-9




- 20 - Hexagon collar bolt**
- Always replace
  - Tighten M16 x 1.5 bolt to 200 Nm and then tighten a further 90°
  - Slacken and tighten only when vehicle standing on its wheels (risk of injury)
- 21 - Self-locking nut, 40 Nm**
- Always replace
- 22 - Coupling rod**

40-10




→ Fig. 1 Pressing off track rod joint



→ Fig. 2 Tightening nut with torque wrench

- Counter-hold coupling rod with hexagon socket wrench.

40 1\*




## Replacing wheel bearing housing

### Note:

Before removing the wheel bearing housing, remove rear wheel parking brake → Servicing rear wheel parking brake, page 42-3


- 1 - **Wheel bearing housing**
  - Do not grease quarry seal in wheel bearing housing before pressing in wheel bearing
  - After replacing the wheel bearing housing, check rear axle alignment
  - Is supplied as replacement part with hole for mounting the clamping sleeve or the speed sensor
- 2 - **Clamping sleeve**
  - Grease all round with brake cylinder paste before inserting into wheel bearing housing
  - Press into wheel bearing housing until fully home

42-1



- 3 - **Speed sensor**
  - Pull out to remove
  - To install press it by hand until fully home
- 4 - **Bonded rubber bush**
  - Removing and installing → Work shop Manual
- 5 - **Self-locking nut, 46 Nm**
  - Always replace
- 6 - **Brake mounting plate**
  - Mounting plate of parking brake and of brake caliper
- 7 - **Hexagon bolt**
- 8 - **Hexagon bolt, 46 Nm**
- 9 - **Hexagon bolt, 50 Nm**


42-2



- 10 - Wheel bearing**
- Inner diameter as stepped design
  - Pay attention to installation position on large inner diameter of wheel bearing faces wheel hub
  - Is destroyed when pressing out
  - Pressing out → Fig. 2
  - Inserting → Fig. 4

- 11 - Wheel hub**
- Pressing out → Fig. 1
  - Inserting → Fig. 3
  - Pressing off bearing inner race → Fig. 5 and Fig. 6


42-3



→ Fig. 1 Pressing out wheel hub


*Note:*

Use a  $\varnothing 200 \times 180 \times 4$  mm ring -A- which is closed at one end for pressing out the wheel hub



→ Fig. 2 Pressing out wheel bearing






→ Fig. 3 Pressing in wheel hub

**Note:**


When pressing in, the tool VW 554 must be supported only at the bearing inner race



→ Fig. 4 Pressing in wheel bearing - A- until fully home

- \* Large inner diameter of wheel bearing faces wheel hub

42-5



→ Fig. 5 Inserting separating device


**Important!**

When pressing off bearing inner race, ensure that the spacer shim -A- is not also pressed off.

- \* Insert separating device into the annular groove of the bearing inner race and pre-tension appropriately with spindle


**Note:**

Use commercially available separating device e.g. KUKKO 15-17.



→ Fig. 6 Pressing bearing inner race off wheel hub

42-6



## Removing and installing drive shaft


- 1 - Differential
- 2 - Gasket
  - Pull off protective sheet and stick into the joint
- 3 - Drive shaft
  - Service → Workshop Manual


### Important!

Should it be necessary to move the vehicle on which the drive shaft has been removed, an outer joint should be installed first of all in place of the drive shaft otherwise the wheel bearing will be damaged.

- 4 - Backing plate
- 5 - Cylindrical bolt, 80 Nm

- 6 - Subframe
- 7 - Spacer
- 8 - Hexagon bolt + washer
  - Always renew
  - Tighten M16 bolt to 200 Nm and then tighten a further 90°
  - Slacken and tighten only when vehicle standing on its wheels (risk of injury)






## Fitting on tyres

The tyre fitting and removal instructions relate to 17" cup-design wheels with asymmetric hump.

### Note:

Avoid damaging the paintwork of the wheel.

- - Use a Matra presser V-180 for removing and fitting on the tyres



- - In addition, the assembly lever should be flattened at its face end and then rounded (arrow)


Fit on the first tyre bead in the usual manner

### Note:

The asymmetrical hump allows its shape over the circumference of the tyre.

For this reason, pay strict attention to the following points when fitting on and removing the tyres


44-1



- Clamp on wheel and coat inside of wheel as well as both tyre beads with assembly paste

Replace the valve each time before fitting on the tyre


- Adjust assembly tool to the correct distance.
- a = 4 - 5 mm
- b = 8 - 10 mm




- When starting to fit on the second bead, the assembly arm should be positioned opposite the valve. Then fit the second tyre bead onto the wheel as flat as possible, guide over the assembly head and hold down offset about 90° - 120° using special tool H039

- - When turning the wheel and fitting on the second bead, the bead of the tyre must be held in the deep bed of the wheel with a second assembly lever and a special tool Matra V-180.

44-2




- To make it easier to fit on the tyre, the additional assembly lever should be positioned below the hump
- When inflating the tyre, the beads must jump across the pump – no later than a pressure of 4.5 bar
- When inflating the tyre, therefore, the head which is still in the deep bed must be positioned opposite the valve (after pump profile). It may be necessary to turn the tyre accordingly and to coat with assembly paste.




#### Removing tyres

- Set assembly tool to the correct distance
  - a = 4 – 5 mm
  - b > 6 – 10 mm
- Begin pushing off the tyre at the valve as the force required here is slightly less. Then press off the tyre on both sides, coating the rim flange with assembly paste when doing this.



- - Lift the first side of the tyre over the assembly head
- Place a rag or a chamois leather between wheel and assembly lever as an aid when performing this step.



- - In addition, ensure that the tyre is held in the deep bed opposite the removal head.
- Use the special tool Matra V-180 for this purpose
- Remove the second side of the tyre in the usual manner.

44-11

## Wheels and tyres

Engine output / kW	Tyre size	Wheel size	Wheel offset and hole circle Ø mm
232	245 / 40 ZR 17	7.5 x 17	55 / 130

- Spare wheel with regular tyre
- Only Dunlop SP Sport 8000 tyres may be fitted as spare tyre

## Winter tyres


Engine output / kW	Tyre size	Wheel size	Wheel offset and hole circle Ø mm
232	205 / 60 R 16 89 T / H	6.5 x 16	51.3 / 130

- It is a regulation (in Germany) that a wheel sticker is affixed in the driver's field of view on vehicles which have a top speed in excess of the maximum permissible speed for winter tyres. This sticker is available from the tyre trade.



.....

6.




## Removing and installing ABS components on front axle

- 1 - Drive shaft with rotor
  - Or outer CV joint, is supplied as replacement part with rotor
  - Before removing, pull back speed sensor slightly
  - After installing, press in speed sensor by hand until fully home
- 2 - Speed sensor
  - Identical part on left and right
  - Pull out of wheel bearing housing in order to remove
  - To install, press in by hand until fully home
  - Plug (plug orientation for speed sensor, front left → Fig. 1, front right → Fig. 2)
  - Routing of wiring for speed sensor → Fig. 3 and Fig. 4

45-071


45-1




- 3 - Clamping sleeve
  - Grease & lubricate with brake cylinder paste before inserting into wheel bearing housing
  - Press into wheel bearing housing until fully home
- 4 - Wheel bearing housing
  - Is supplied as replacement part with bolt 6 for mounting the clamping sleeve or the speed sensor
- 5 - Spacer
- 6 - Hexagon collar bolt
  - Always renew
  - Tighten M 8 x 1.5 bolt to 200 Nm and then tighten a further 50
  - Slacken and tighten only when vehicle standing on its wheels (risk of injury)

45-071


45-2




- Fig. 1 Plug connection of front left speed sensor
- Extend coolant expansion tank and place to the side.
  - Release plug connection from holder and then separate.



- Fig. 2 Plug connection of front right speed sensor
- Release plug connection from holder and then separate.




- Fig. 3 Routing of wiring for speed sensor at suspension strut
- Insert cable with the grommet into the angle bracket at the suspension strut.
  - Insert cable into the cup.



- Fig. 4 Routing of wiring for speed sensor at wheelhouse
- Insert cable with grommet into angle bracket.
  - Insert cable into the clips along the brake pipe.

45-3






## Removing and installing ABS components at rear axle


- 1 - Drive shaft with rotor**
  - Circlifer CV joint is supplied with rotor as replacement part
  - Pull back speed sensor slightly before removing
  - After installing, press in speed sensor by hand until fully home
- 2 - Speed sensor**
  - Identical part on left and right
  - Pull out in order to remove
  - To install, press in by hand until fully home
  - Routing of wiring = Fig. 1 and 2

45 5




- 3 - Clamping sleeve**
  - Grease all round with brake cylinder paste before inserting into wheel bearing housing
  - Press into wheel bearing housing until fully home
- 4 - Wheel bearing housing**
  - Is supplied as replacement part with hole for mounting the clamping sleeve or the speed sensor
  - Grease hole all round with brake cylinder paste before inserting the clamping sleeve - 3-
- 5 - Spacer**
- 6 - Hexagon collar bolt**
  - Always reuse
  - Tighten M 16 x 1.5 bolt to 220 Nm and then tighten a further 90°
  - Slacken or tighten only when vehicle is standing on its wheels

45 6



➔ Fig. 1 Routing of wiring for speed sensor

- Insert cable with rubber grommet into the holder provided at the subframe as well as at the floor assembly



➔ Fig. 2 Routing of wiring for speed sensor at the subframe

- Bolt cable tight with retaining plate to subframe

**Note:**

The wiring connections for the rear speed sensors are located below the rear seat.

45-1



## Servicing front brakes


### Brembo four-piston brake calipers

#### Important!

- *Install all the parts of the repair kit.*
- *The brakes can be tested on all commercially available brake testers provided the driving speed of the two driving rollers of the tester is not greater than 5.5 km/h.*

#### 1 - Brake disc

- Always replace left and right discs
- To remove, unbolt brake caliper first etc. a
- Turn disc to size evenly, on both sides, starting from the thickness when new
- Diameter of brake disc 304 mm
- Wear limit 30 mm



46-913

46-1

#### 2 - Brake pads

- Always replace on both sides → page 46-3
- Thickness of brake pads when new 17,5 mm
- Checking brake pad thickness → page 46-2
- If pad thickness including backing plate is 8 mm, the brake pads have reached their wear limit and should be replaced

#### 3 - Brake caliper housing


- Do not unbolt brake hose and brake caliper for changing brake pads

#### 4 - Washers

#### 5 - Cylinder bolts, 85 Nm

#### Note:

Each time when replacing or removing the brake pads, the damper plates must also be replaced



46-913

46-2

## Checking thickness of brake pads


- Take off the rear wheels to check the rear brake pads
  - The front brake pads can be inspected with the wheels fitted
- Check the brake pads visually for signs of wear.
- If the pad thickness (including backing plate) is 8 mm, the brake pads have reached their wear limit and should be replaced

## Replacing brake pads

Take off wheels

Mark brake pads which have to be re-used when removing. It is not permitted to switch the pads from the outside to the inside or vice versa or also from the right to the left wheel as this may result in the car being pulled to one side when braked

40-3



- Compress expanding spring in the middle and release from its mount

### Note:


At the same time or before starting to compress the spring, press the spring toward the brake disc in the area of the retaining plate (release tension). This prevents damage to the retaining plate.

### Important!


Before turning back the pistons, extract part of the brake fluid from the brake fluid reservoir. If this is not done, brake fluid may flow out and cause damage - especially if it has been topped up in the meantime. Extract the brake fluid only with a bleeder bottle or a plastic bottle which is used for brake fluid. Brake fluid is poisonous and must on no account be extracted by sucking out through a hose.

- Push out the brake pads with the brake pad impact extactor. Pay attention to the following points in the case of brake pads with damping plates or vibration dampers with an adhesive layer:






- Pull out brake pads together with the damping plates or vibration dampers. Should this not be possible (depending on state of wear of brake pads): detach the damping plates/vibration dampers from the brake mounting plate with a spatula before removing the pads. In both cases turn back the brake pads as far as possible with the piston resetting device.
- The spatula must be positioned exactly between brake pad and damping plate/vibration damper, in order to avoid damage to the brake piston seats.



- As the damping plates (1) are provided with an adhesive coating, the damping plates must be replaced each time the brake pads are removed or renewed.




### Installing

- Turn back pistons into starting position with resetting device if necessary.
- Clean seat and guide surface of the brake cards in the brake caliper with methanated sprays, a cylinder or special brush to ensure that the brake pads operate freely in the channel. It is essential to ensure that the brake piston seats (fluid caps) are not damaged when performing this operation.
- Check that the brake calipers are correctly installed. The small pistons must face the brake disc (leading side). This can also be recognized by the arrow on the front Prestolite logo which indicates the direction of rotation of the brake disc.

46-5



46-6




- ➔ Insert new damping plates (—) or vibration dampers into the pistons. As the damping plates or vibration dampers are provided with an adhesive and protective sheeting, the protective sheeting must be pulled off before installing.

- Insert brake pads. Check that the brake pads are of the correct grade.

**Notes:**


- The brake mounting plates (rear of brake pads) must not be greased.
- Coat the seal and guide surfaces with a thin film of grease, however, to prevent the brake pads sticking in the brake caliper as a result of corrosion.
- Use *Optimoly HT (Cu paste)* or *Plastilump (Schilling, 73407 Aalen)* for this operation.



- ➔ Ensure that the expanding spring engages properly (arrow). Do not use force to engage spring (risk of damage to mounting plate).

Install new expanding spring, if necessary; ensure that the flat side is facing the brake disc.





## Servicing rear brakes


### Important!

The brakes can be tested on all commercially available brake testers provided the driving speed of the two driving rollers of the tester is not greater than 5.5 km/h.

#### 1 - Brake disc

- Replace on both sides → Replacing front brake pads, page 46-1
- To remove, unbolt brake caliper first of B1 and also turn back brake shoes for handbrake
- Turn disc to size evenly, on both sides, starting from the thickest when new
- Ensure that an adequate wear limit remains

46-9




- Diameter of brake discs 269 mm
- Thickness of brake discs 24 mm
- Wear limit 22 mm
- Adjusting handbrake → page 46-19

#### 2 - Brake pads

- Replace on both sides → Replacing front brake pads, page 46-3
- Thickness of brake pads when new 17.5 mm
- Wear limit of brake pads 8 mm
- Checking thickness of brake pads → page 46-3

46-10



- If the pad thickness including backing plate is 6 mm, the brake pads have reached their wear limit and should be replaced.

**Note:**

Replace the damping plates each time the brake pads are renewed or removed.

**3 – Brake caliper housing**

- Do not unbolt brake hose and brake caliper.

**4 – Hexagon bolt, 85 Nm**

46-11







## Servicing handbrake

### Removing:

Fasten vehicle and take off wheels


Release handbrake

- Unbolt brake caliper (arrow) and attach at a suitable point (do not detach brake hose or brake pipe).



- Remove counter-sunk screws (arrow).
- Insert a screwdriver through the hole of the brake disc and adjust the position of the adjusting device until the brake disc can be taken off.
- Take off brake disc.

46-13





- Remove compression spring -1- (locking for vehicle), adjusting device -2- and bottom return spring.
- Take out handbrake shoes.

### Installing:


Apply a light coating of grease to adjusting device pin or expanding lever and contact surfaces of handbrake shoes.

- Fit together expanding lever






- Install top long return spring onto handbrake shoes, fit on handbrake shoes and insert into the expanding lever.



- Install compression springs with screwdriver.



- Pull apart handbrake shoes - 1 - and insert assembled adjusting device - 2 -

Attach bottom return spring.

- Centre handbrake shoes.

- Install brake disc.

Insert counter-sink screws

- Install brake caliper

- Adjust handbrake -> page 46-19

46-16

## Removing and installing handbrake cables



### Removing:

#### Note:

To remove the handbrake cables, first of all remove handbrake shoes → page 46-13 Servicing handbrake

- ➔ Remove expanding lever 1
- ➔ Push handbrake cable to the rear and pull out of the guide sleeve 2


Unbuck rear shield for the exhaust system.



- ➔ Detach handbrake cables from the compensating bracket 2
- ➔ Pull out securing clips 1

Detach mounting plate for handbrake cable at the floor assembly

Take out handbrake cable to the rear through plate at bottom axle link



- ➔ The retaining strap (arrow) must be fitted as shown in the figure.

#### Note:

If performing partial repair work on bottom axle link, make hole for mounting the strap of the handbrake cable → fig. 46-929 (pay attention to corrosion protection)

### Installing:

Installation of the handbrake cables is performed in the reverse order

#### Important:

After installing the handbrake cables, adjust handbrake → page 46-19.


46-17

46-18

## Adjusting handbrake


### Note:

The handbrake must be adjusted if the handbrake lever can be pulled up more than 2 clicks with moderate force without the brakes being applied.




- 1 Raise vehicle and take off rear wheels.
- Release handbrake and press back disc brake pads of rear axle until the brake disc rotates freely.
- Remove rear shield for the exhaust system (figure is shown with drive shaft removed to simplify the illustration).
- Slacken adjusting nut of handbrake cable (a) far enough (if necessary) until the handbrake cables are slackened.

46 10



- – Insert a screwdriver through the hole of the brake disc and turn the adjusting device until the wheel can no longer be turned. Then turn back adjusting device again until the wheel rotates freely, then turn back a further 2 clicks (slacken).
- Apply handbrake 4 or 2 clicks and turn adjusting nut sufficiently until both wheels can no longer be rotated easily by hand (when handbrake lever applied 4 clicks, wheels must be locked).
- Slacken handbrake lever sufficiently and check whether both wheels now rotate freely.



## Servicing four-piston fixed caliper brake system

**Important!**

**The brake caliper halves must not be separated.**


- On no account open or tighten the bolts marked with an arrow

The piston ring seats, dust caps and damping plates can be replaced with the fixed caliper assembled.

- 1 - Dust cap
- 2 - Damping plate
- 3 - Rubber seal (rectangular ring)
- 4 - Piston
- 5 - Brake Caliper housing

**Note:**

Proceed as described in the Workshop Manual for servicing



47-1

00

6

