

2007 Hummer H3 L5-3.7L

Vehicle > ALL Diagnostic Trouble Codes (DTC) > Testing and Inspection > P Code Charts

P2101

DTC P2101

Circuit Description

The commanded throttle position (TP) is compared to the actual TP based on accelerator pedal position (APP) and possibly other limiting factors. Both values should be within a calibrated range of each other. The powertrain control module (PCM) continuously monitors the commanded and actual TPs. This DTC sets if the values are greater than the calibrated range.

DTC Descriptor

This diagnostic procedure supports the following DTC:

DTC P2101 Throttle Actuator Position Performance

Conditions for Running the DTC

- * The ignition is ON.
- * The ignition voltage is **greater than 8 volts**.
- * The system is not in Battery Saver mode.
- * The engine is running.
- * DTC P0068 is not set.
- * DTC P2101 runs continuously when the above conditions are met.

Conditions for Setting the DTC

- * The difference between the predicted and the actual throttle position is more than a calibrated amount.
- * The above condition is present for **more than 0.6 second**.

Action Taken When the DTC Sets

- * The control module illuminates the malfunction indicator lamp (MIL) when the diagnostic runs and fails.
- * The control module records the operating conditions at the time the diagnostic fails. The control module stores this information in the Freeze Frame and/or the Failure Records.
- * The control module commands the TAC system to operate in the Reduced Engine Power mode.
- * A message center or an indicator displays Reduced Engine Power.
- * Under certain conditions the control module commands the engine OFF.

Conditions for Clearing the MIL/DTC

- * The PCM turns OFF the MIL after 3 consecutive drive trips that the diagnostic runs and passes.
- * A History DTC clears after 40 consecutive warm-up cycles in which there are no failures reported of this diagnostic or any other emission related diagnostic.

- * The scan tool clears the MIL/DTC.

Diagnostic Aids

The throttle valve is spring loaded to a slightly open position. The throttle valve should be open **approximately 20 percent**. This is referred to as the rest position. The throttle valve should not be completely closed nor should they be open any more than the specified amount. The throttle valve should move open and to the closed position without binding under the normal spring pressure. The throttle should NOT be free to move open or closed WITHOUT spring pressure. Replace the throttle body if any of these conditions are found.

Important: Operating the throttle blade with the Throttle Blade Control function of the scan tool may cause additional DTCs to set. DO NOT attempt to diagnose DTCs set during this function.

The scan tool has the ability to operate the throttle control system using Special Functions. Actuate the throttle valve using the throttle blade control function located in the throttle actuator control (TAC) System menu. This function will operate the throttle valve through the entire range in order to determine if the throttle body and system operate correctly.

Inspect for the following conditions:

- * Use the J 35616 Connector Test Adapter Kit for any test that requires probing the PCM harness connector or a component harness connector.
- * Poor connections at the PCM or at the component-Inspect the harness connectors for a poor terminal to wire connection. Refer to Testing for Intermittent Conditions and Poor Connections in Diagnostic Aids for the proper procedure. See: Vehicle > Component Tests and General Diagnostics
- * For intermittents, Refer to Intermittent Conditions. See: Computers and Control Systems > Initial Inspection and Diagnostic Overview > Intermittent Conditions

Test Description

Step 1 - Step 8

Step	Action	Yes	No
1	Did you perform the Diagnostic System Check - Vehicle?	Go to Step 2	Go to Diagnostic System Check - Vehicle
2	Are DTCs P0120, P0220, P2120, P2125, P2135, P2138 also set?	Go to Diagnostic Trouble Code (DTC) List - Vehicle	Go to Step 3
3	<p>Important: The throttle angle and pedal angle may not correspond during this procedure.</p> <p>Turn ON the ignition, with the engine OFF. Observe the throttle position (TP) sensor 1 and 2 angle parameters. Apply and release the accelerator pedal several times.</p> <p>Does the TP sensor 1 and 2 angle parameters increase as the pedal is applied and decrease as the pedal is released?</p>	Go to Step 4	Go to Step 5
4	<p>Observe the Freeze Frame/Failure Records for this DTC. Start the engine. Operate the vehicle within the Conditions for Running the DTC. You may also operate the vehicle within the conditions that you observed from the Freeze Frame/Failure Records.</p> <p>Did the DTC fail this ignition?</p>	Go to Step 5	Go to Diagnostic Aids
5	<p>Turn ON the ignition, with the engine OFF. Probe both sides of the ETC fuse with a test lamp.</p> <p>Does the test lamp illuminate on both sides of the fuse?</p>	Go to Step 6	Go to Step 16
6	<p>Turn OFF the ignition. Probe both sides of the ETC fuse with a test lamp.</p> <p>Does the test lamp illuminate on both sides of the fuse?</p>	Go to Step 22	Go to Step 7
7	<p>Turn OFF the ignition. Disconnect the powertrain control module (PCM) connector containing the ETC ignition 1 voltage circuit. Connect a fused jumper from the powertrain relay coil control circuit, at the PCM connector, to a good ground. Probe the ETC ignition 1 voltage circuit with a test lamp connected to a good ground.</p> <p>Does the test lamp illuminate?</p>	Go to Step 8	Go to Step 23
8	<p>Turn OFF the ignition. Inspect the throttle body for the following conditions: A throttle valve that is NOT in the rest position A throttle valve that is binding open or closed A throttle valve that is free to move open or closed WITHOUT spring pressure. Refer to Diagnostic Aids.</p> <p>Did you find any of these conditions with the throttle body?</p>	Go to Step 24	Go to Step 9

Step 9 - Step 16

Step	Action	Yes	No
9	<p>Important: The test lamp may momentarily flash when testing these circuits. This is considered normal.</p> <p>Disconnect the throttle body harness (4 wires). Turn ON the ignition with the engine OFF. Place the throttle actuator control (TAC) motor control 1 and 2 circuits with the test lamp connected to ground.</p> <p>Does the test lamp illuminate and remain illuminated on either circuit?</p>	Go to Step 10	Go to Step 10
10	<p>Important: The test lamp may momentarily flash when testing these circuits. This is considered normal.</p> <p>Place the TAC motor control 1 and 2 circuits with the test lamp connected to battery positive.</p> <p>Does the test lamp illuminate and remain illuminated on either circuit?</p>	Go to Step 11	Go to Step 11
11	<p>Turn OFF the ignition. Connect the test lamp between the TAC motor control 1 and safety ground. Observe the test lamp as you try to ON the ignition.</p> <p>Does the test lamp flash ON and then turn OFF?</p>	Go to Step 12	Go to Step 16
12	<p>Turn OFF the ignition. Connect a test lamp between the TAC motor control 1 motor and battery ground. Observe the test lamp as you try to ON the ignition.</p> <p>Does the test lamp flash ON and then OFF?</p>	Go to Step 18	Go to Step 16
13	<p>Turn OFF the ignition. Disconnect the PCM connector that contains the TAC motor control circuits. Turn ON the ignition with the engine OFF. Place the TAC motor control 1 and 2 circuits with the test lamp connected to ground.</p> <p>Does the test lamp illuminate?</p>	Go to Step 20	Go to Step 16
14	<p>Turn OFF the ignition. Disconnect the PCM connector that contains the TAC motor control circuits. Place the TAC motor control 1 and 2 circuits with the test lamp connected to battery positive.</p> <p>Does the test lamp illuminate?</p>	Go to Step 21	Go to Step 16
15	<p>Turn OFF the ignition. Disconnect the PCM connector that contains the TAC motor control circuits. Test the TAC motor control 1 and 2 circuits for an open or high resistance. Repair the circuit as necessary.</p> <p>Did you find and correct the condition?</p>	Go to Step 25	Go to Step 16
16	<p>Test the PTC ignition coil step 1 and 2 as starting the engine.</p> <p>Did you find and correct the condition?</p>	Go to Step 26	Go to Step 17

Step 17 - Step 27

Step	Action	Yes	No
17	Test the motor control 1 circuit for a short to ground. Did you find and correct the condition?	Go to Step 26	Go to Step 24
18	Test for a poor connection or terminal tension at the throttle body connector. Did you find and correct the condition?	Go to Step 26	Go to Step 24
19	Test for a poor connection or terminal tension at the PCM. Did you find and correct the condition?	Go to Step 26	Go to Step 25
20	Repair the short to voltage on the circuit where the test lamp remained illuminated. Did you complete the repair?	Go to Step 26	-
21	Repair the short to ground on the circuit where the test lamp remained illuminated. Did you complete the repair?	Go to Step 26	-
22	Repair the short to voltage on the ETC ignition 1 voltage circuit. Did you complete the repair?	Go to Step 26	-
23	Repair the open or high resistance in the ETC ignition 1 voltage circuit. Did you complete the repair?	Go to Step 26	-
24	Replace the throttle body assembly. Did you complete the replacement?	Go to Step 26	-
25	Replace the PCM. Did you complete the replacement?	Go to Step 26	-
26	Clear the DTCs with a scan tool. Turn OFF the ignition for 30 seconds. Start the engine. Operate the vehicle within the Conditions for Running the DTC. You may also operate the vehicle within the conditions that you observed from the Freeze Frame/Failure Records. Did the DTC fail this ignition?	Go to Step 2	Go to Step 27
27	Observe the Capture Info with a scan tool. Are there any DTCs that have not been diagnosed?	Go to Diagnostic Trouble Code (DTC) List - Vehicle	System OK

The numbers below refer to the step numbers on the diagnostic table.

8. The throttle valve is spring loaded in a slightly open position and should move in either direction without binding. The throttle valve should always be under spring pressure.

11. When the ignition is turned ON, the PCM operates the throttle control motor to verify the integrity of the system prior to start-up. This can be seen by the momentary flash of the test lamp as the ignition is turned ON.