



MASERATI

Levante

OWNER'S MANUAL



MASERATI

Levante

Owner's Manual



Dear Customer,

thank you for choosing a Maserati.

This vehicle represents the result of Maserati's great experience in the design and production of sports, touring and racing vehicles.

The purpose of this manual is to provide you with an understanding of the equipment, systems and controls of the vehicle and to explain how they work.

Consulting this manual you will acquaint yourself with the equipment and optional properties of your Maserati in order to take best advantage of all its potential.

Before driving your vehicle for the first time, we suggest reading the printed Quick Guide carefully in order to quickly acquaint with commands and functions of your vehicle. You can consult this Owner's Manual and the Maserati Touch Control Plus guide directly from the dashboard touch screen display of your vehicle.

The updated version of the on-board documentation can be consulted by accessing the section "SERVICES" on the website www.maserati.com or by using the specific apps developed for the more common Tablet and Smartphone.

In a dedicated section of this manual you will also find instructions for basic maintenance procedures, in order to ensure steady levels of performance, quality and safe driving.

In addition, keep in mind that proper maintenance is an essential factor to help preserve the value of the vehicle over time and protect the environment.

For "Scheduled Maintenance" or any other operations, we recommend to contact the **Maserati Service Network**: you can trust our trained technical staff, who is constantly updated and provided with the required equipment in order to ensure that all service operations are performed properly and reliably.

The Quick guide and other documents contained in on-board documentation Kit are integral part of the vehicle and should always be kept on board.

You can purchase a printed copy of the documents visible on dashboard touch screen display at your dealer of the **Service Network**.

Maserati is committed to protect the environment and natural resources; this is why we chose to develop Owner's documentation in digital format instead of printing paper, thus reducing consumption of materials deriving from wood.







Introduction

1

Before Starting

2

Understanding the Vehicle

3

Dashboard Instruments and Controls

4

Driving

5

In an Emergency

6

Maintenance and Care

7

Features and Specifications

8

Index

9





1 – Introduction

Consulting the Manual	8
Abbreviations	8
Updating	9
Service and Warranty	10
Spare Parts Service	10
Symbols	11
Warnings when Driving	12
Vehicle Identification Data	13



Consulting the Manual

This Owner's Manual illustrates maintenance and use information related to gasoline motorization models, indicated as "Gasoline", and diesel motorization model, indicated as "Diesel". If not otherwise specified, the information is valid for all models. For an easy identification of the topics, this Manual is divided into sections and chapters: each chapter can have more paragraphs. Within the text, important warnings and notes are also easily identifiable through icons.



WARNING!

Failure to comply with the instructions could cause **HAZARDOUS SITUATIONS** involving personal and vehicle safety.



ENVIRONMENTAL!

This note indicates the correct behaviour when using the vehicle to protect the environment.



CAUTION!

Aimed at preventing any damage to the vehicle and thus hazards involving the safety of persons.

NOTE:

Additional information regarding the subject and/or the operation described.

- "Left" and "right" in this manual, always refer to the driving direction.
- All indications and images in this Manual refer to a vehicle with left-hand drive. On right-hand drive vehicles, some controls are ordered differently than shown in the illustrations.
- If not otherwise specified, the instrument cluster shown in the images belongs to the gasoline motorization model – however the indications given are also valid for the diesel motorization model.

Abbreviations

Some descriptions and terms with particular meanings are found in this manual in abbreviated form.

- A/C** Air-Conditioning system.
- ABA** Advanced Brake Assist.
- ABS** Anti-Lock Braking System.
- ACC** Adaptive Cruise Control.
- AFS** Advanced Frontlighting System.
- ALR** Automatic Locking Retractor.
- AQS** Air Quality Sensor.
- ATC** Automatic Temperature Control.
- AWD** All-Wheel Drive.
- BAS** Brake Assist System.
- BSA** Blind Spot Alert.
- CAN** Controller Area Network.
- CC** Cruise Control.
- CRS** Child Restraint System.
- DPF** Diesel Particulate Filter.
- DRL** Daytime Running Lights.
- EBD** Electronic Brake-force Distribution.
- ECU** Electronic Control Unit.
- EPB** Electric Parking Brake.



ESC	Electronic Stability Control.	TPMS	Tire Pressure Monitoring System.
FCW	Forward Collision Warning.	TSM	Trailer Sway Mitigation.
HDC	Hill Descent Control.	VIN	Vehicle Identification Number.
HSA	Hill Start Assist.		
HBA	Hydraulic Brake Assistance.		
I.C.E.	Increased Control and Efficiency.		
LDW	Lane Departure Warning (LaneSense).		
MIL	Malfunction Indicator Light.		
MTC+	Maserati Touch Control Plus.		
ORC	Occupant Restraint Controller.		
RAB	Ready Alert Braking.		
RCP	Rear Cross Path.		
RHD	Right-Hand Drive.		
RKE	Remote Keyless Entry.		
ROM	Roll-Over Mitigation.		
SAB	Side Air Bag.		
SABIC	Supplemental Side Air Bag Inflatable Curtains.		
SBR	Seat Belt Reminder.		
SRS	Supplemental Restraint System.		
TCS	Traction Control System.		
TFT	Thin Film Transistor.		

Updating

The vehicle's high quality level is guaranteed by constant improvements. Therefore, there may prove to be differences between this manual and your vehicle.

Maserati reserves the right to carry out design and functional changes and to achieve additions or improvements without incurring any obligation to update previously manufactured vehicles.

The Owner's Manual illustrates and describes all versions of the current vehicle model. Therefore, some of the equipment and accessories in this publication may not appear on your vehicle; please only consider the information related to your vehicle. All specifications and illustrations contained in this manual refer to the Manual publishing date.

NOTE:

The updated version of the on-board documentation can be consulted by accessing the section "SERVICES" on the website www.maserati.com or by using the specific apps developed for the more common Tablets and Smartphones.



1 Service and Warranty

The information provided in this manual is limited to instructions and indications that are strictly required for vehicle use and proper maintenance.

By following these instructions carefully the vehicle will certainly meet the owner's satisfaction and the best results.

We also advise you to have all the maintenance services and inspections carried at the **Service Network**. Please be advised that Maserati recommends to address to the **Official Service Network**, which is available in the official Maserati website (www.maserati.com).

All features and accessories installed on the vehicle have been designed by Maserati engineers and have successfully passed rigorous tests, submitted in all conditions of use.

Installing aftermarket accessories not approved by Maserati may interfere with the vehicle electronics and compromise driving safety.

For details and information about the warranty, please refer to the "Warranty Card".

The **Maserati Service Network** is at your complete disposal for any information and suggestions.

Spare Parts Service

With genuine parts you keep the reliability, comfort and performance features of your new car unchanged in time.

For service and scheduled maintenance Maserati suggests you to ask for genuine parts since they are the result of constant research and development, reliability test and new technologies, as well as they are specifically designed for this vehicle.

Genuine Accessories

The Maserati Genuine Accessories are the perfect combination of design and functionality. Each detail and characteristic of the items are tailor-made with the highest quality represented by the Maserati Trident. Severe Technical and Quality Tests are performed to approve each product. To fully exploit the vehicle's performance and versatility, discover the wide range of approved accessories that can be added to the car.

The **Maserati Service Network** is at your complete disposal for any information about this "Genuine Accessories" product range.



Symbols

There are specific colored plates on or near some of the components on your Maserati designed to attract user's attention. Important warnings concerning all specific devices that the user must consider are reported on the internal lid cover central label (see "Vehicle Identification Data" in this section).

All symbols reported on the plate and inside the vehicle, as well as the component for which the symbols stand, are summarized in the following list. These symbols are divided into categories according to their meaning.

Danger Symbols



Battery
Corrosive liquid.



Battery
Explosion.



Blower
May start automatically even with engine off.



Coolant expansion tank
Do not open cap with engine warm.



Coil - headlights
High voltage.



Belts and pulleys
Moving parts, keep body and clothing clear.



Air-conditioning lines
High pressure gas, do not open.

Symbols of Prohibitions and Compulsory Measures



Battery
Keep away from flames.



Battery
Keep out of children's reach.



Heat guards - belts - pulleys - fans
Do not touch.



Battery
Wear eye protection.



Battery - jack
Refer to the owner manual.

Warning Symbols



Engine - Engine Oil Refilling Plug
Engine oil. We recommend you use oil with the characteristics indicated in chapter "Refillings" in section "Features and Specifications".



Hydraulic steering tank
Power steering fluid. Do not exceed max. level. We recommend you use liquid with the characteristics indicated in chapter "Refillings" in section "Features and Specifications".



Brake fluid tank
Brake fluid type DOT 4. Do not exceed max. level. We recommend you use fluid with the characteristics indicated in chapter "Refillings" in section "Features and Specifications".



Radiator coolant expansion tank

Use antifreeze liquid for radiators with the characteristics indicated in chapter "Refillings" in section "Features and Specifications".



Windshield washer tank

Windshield washer. We recommend you use liquid with the characteristics indicated in chapter "Refillings" in section "Features and Specifications".

Warnings when Driving

Your driving skills will improve with experience, but be especially careful at the beginning. Always comply with local traffic regulations wherever you drive.

This vehicle is also suitable for off-road use, using the dedicated controls and functions to obtain the optimum balance to safely face the situations that this kind of route may pose.

We recommend you to start gradually in order to acquire the necessary expertise and the perfect control of the vehicle. Follow the indications contained in chapter "Off-road Drive" in section "Driving" for information concerning the off-road use of the vehicle.

Failure to operate this vehicle correctly may result in loss of control or a collision.

Operating this vehicle at excessive speed or in an altered state or while intoxicated may result in loss of control, going off the road, or overturning. In all these situations a collision with other vehicles or objects is more likely to happen with the risk to cause an accident that may lead to serious injury.

In case of an accident, failure to use seat belts causes the driver and passengers a greater risk of injury or death.

This Owner's Manual contains warnings against operating procedures that could result in a collision or injury or damage to the environment. It also contains cautions against procedures that could damage the vehicle. If you do not entirely read this manual, you may miss important information. Consider carefully all warnings and cautions.



WARNING!

- **It is the driver's responsibility to operate the vehicle in a safe way: if you are distracted while driving you can lose control and cause serious accidents.**
- **Maserati strongly recommends to use particular care when operating the features and tools that may take the attention off the road.**
- **Mobile phones, PCs, portable audio devices or other features operated improperly while the vehicle is moving can be very dangerous and can cause serious accidents.**



- It is very dangerous to send text messages while driving, do so only when the vehicle is not moving.
- In some Countries the use of mobile phone when driving is forbidden: it is the driver's sole responsibility to respect local regulations.

ROLL-OVER WARNING

In normal conditions, this vehicle is characterised by a greater ground clearance than the vehicles designed for road use only. This characteristic allows to deal with off-road routes as well, by maintaining all the driveability features and the performance of a sports car, but it makes it more prone to roll-over in case of loss of control.

It is important, for the safety of the occupants and the integrity of the vehicle, to face driving situations on road and off-road avoiding severe turns or leaning over and abrupt manoeuvres carried out at high speed that might cause the loss of control of the vehicle and the possible roll-over.

The use of seat belts is essential in any driving situation. In case of roll-over, the driver and the passengers that do not wear the seat belts are more likely to be

injured than those who wear them correctly.



CAUTION!

If battery charge is too low, proper function of some electric/electronic components may not be guaranteed. It is necessary to recharge the battery in order to allow all vehicle's components and systems to function correctly.

Vehicle Identification Data

Vehicle Identification Number

The vehicle's identification number (VIN) is punched on the foot platform, in front of the right passenger rear seat.



To read the number, lift the mat and rotate the guard.





1

The VIN Number is also visible from the outside through the windshield on the front left corner of the dashboard.



NOTE:

When ordering spare parts or making inquiries, always quote the vehicle identification number.

Warning and Identification Labels

Overview Label with Cautions and Warning Notes


On this label attached centrally on the internal side of the hood cover, you can identify all cautions, warning notes and symbols that are also reported on some parts/components of the vehicle.

For further information refer to "Symbols" in this section.



Passenger Air Bag Labels

The labels are applied on the external side of passenger's sun visor and below it, on the dome.



Danger Restart Engine with Hood Open Label

The label is applied on the lower right side of the hood.



Vehicle Identification Label

The label is fitted on the rear driver door's ledge and it shows the following details.

- Manufacturer's name.
- Homologation number.
- Serial Number (V.I.N.).
- Maximum admissible weight.
- Maximum admissible weight on first (front) axle.
- Maximum admissible weight on second (rear) axle.
- Engine type.
- Vehicle version code.
- Assembly number.



Paint Identification Label

The label is applied on the lower left side of the hood.



Fuel Warning Label - Gasoline Engines


The label is applied inside the fuel filler door.



Gasoline

Fuel Warning Label - Diesel Engine

The labels are applied inside the fuel filler door.



Diesel





2 – Before Starting

Keys	18
Sentry Key Immobilizer System	20
Vehicle Security Alarm	21
Illuminated Entry/Exit	24
Unlock the Vehicle with Key fob	27
Requiring and Setting Additional Key fobs	28
Remote Start System (optional)	30
Doors Locking	32
Passive Entry System	35
Power Windows	38
Power Sunshades on Rear Door Windows (optional)	41
Open and Close the Liftgate	43
Open and Close the Hood	49
Occupants Restraint Systems	50
Supplemental Restraint System (SRS) — Air Bags	57
Child Restraint Systems	67
Transporting Pets	77
Park Assist (optional)	78
Rear Parking Camera (optional)	83
Surround View Camera System (optional)	85
Safety Tips	87



Keys

The vehicle is equipped with a Remote Keyless Entry transmitter and a Keyless Ignition Node, to enter, start and protect the vehicle.



Keyless Ignition Device

This device allows the driver to operate the ignition switch with the push of a button, as long as the Remote Keyless Entry (RKE) transmitter is inside the vehicle.



The Keyless Ignition Node (KIN) has three operating setups indicated on the outer ring. Pressing and releasing the middle button, you can switch from one setup to the next without starting the engine, the switched on indication will turn amber. The engine will start by pushing the centre button **START/STOP** with the brake pedal pressed and the device set in any of the three operating setups.



In case the ignition switch does not change by pushing a button, the RKE transmitter (key fob) may have a low or discharged battery. If this occurs it is necessary to replace the battery in order to operate the ignition switch (see "Requiring and Setting Additional Key fobs" in this section). It is still possible to operate the ignition device using the key fob RKE transmitter with discharged battery by pressing the nose side (side opposite of the emergency key) of the key fob on the **START/STOP** button.



Key fob

The vehicle is provided with two programmed key fobs.

The key fob also contains the Remote Keyless Entry (RKE) transmitter and an emergency key.

The emergency key allows to open the vehicle by inserting into the lock of the opening handle on the driver's door, in case the battery of the vehicle or the key fob are discharged.



You can keep the emergency key with you when using valet parking. To remove the emergency key:

- hold the mechanical latch on the back of the key fob sideways;
- simultaneously remove the emergency key by sliding laterally towards the end of the key fob.



NOTE:

You can insert either side of the emergency key into the lock cylinder.

Shift Ignition Device to OFF Alert

Opening the driver's door to exit the vehicle when the ignition device is set in **ACC** or **RUN** (engine not running), a beep will remind you to cycle the ignition to **OFF**.

In addition to the acoustic signal a dedicated message is displayed on the instrument cluster.

If the ignition device is left in the **ACC** or **RUN** position, when vehicle is locked the system will turn off the instrument cluster and automatically set ignition device to **OFF**.

With the MTC+ System, the power window switches, radio, power sunroof (optional), and power outlets will remain active for up to 10 minutes after the ignition switch is cycled to the **OFF** position. Opening either front door will cancel this feature, it is possible to set the timing of this feature.

NOTE:

Refer to "MTC+ Settings" in Section "Dashboard Instruments and Controls" for further information.



WARNING!

- When leaving the vehicle, always remove the key fob and lock your vehicle.
- Never leave children alone in a vehicle, or with access to an unlocked vehicle.

(Continued)



(Continued)

- Do not allow children to be in a vehicle unattended. A child or others could be seriously or fatally injured. Do not allow children to touch the parking brake switch.
- Do not leave the key fob in or near the vehicle, and do not leave the ignition switch in the ACC or RUN mode. A child could operate power windows, other controls, or move the vehicle.
- Do not leave children or animals inside parked vehicles in hot weather. Interior heat build-up may cause serious injury or death.
- An unlocked car is an invitation to thieves. Always remove the key fob from vehicle, cycle the ignition switch to OFF and lock all doors when leaving the vehicle unattended.

Sentry Key® Immobilizer System

The Sentry Key® Immobilizer System prevents unauthorised vehicle operation by disabling the engine. The system does not need to be armed or activated. Operation is automatic, regardless of whether the vehicle is locked or unlocked.

The system uses a key fob with Remote Keyless Entry (RKE) transmitter, an ignition switch and a RF (Radio Frequency) receiver to prevent unauthorised vehicle operation. Therefore, only key fobs expressly programmed can be used to start and operate the vehicle.

After placing the ignition switch in the RUN position, the Vehicle Security Light (see picture) will light up for a three seconds bulb check.



If the light remains on after the bulb check, it indicates that there is a problem with the electronics: this condition will result in the engine being shut off after two seconds. If the Vehicle Security Light turns on during normal vehicle operation (engine running for longer than 10 seconds), an electronic fault is detected. Should this occur, ask as soon as possible the **Service Network** for assistance.



CAUTION!

The Sentry Key® Immobilizer system is not compatible with some remote starting systems that can be installed in aftermarket.

Use of these systems may result in vehicle starting problems and loss of security protection.

All key fobs provided with the new vehicle have been updated with the vehicle electronics and are therefore able to guarantee correct functioning and protection.

General Information

The Sentry Key® Immobilizer system operates on a carrier frequency of 433.92 MHz. and is used in the



following European Countries, which apply Directive 1999/5/EC: Austria, Belgium, Czech Republic, Denmark, Finland, France, Germany, Greece, Hungary, Ireland, Italy, Luxembourg, The Netherlands, Norway, Poland, Portugal, Romania, Russian Federation, Slovenia, Spain, Sweden, Switzerland, former Yugoslavia Countries, and United Kingdom. Operation is subject to the following conditions:

- This device may not cause harmful interference.
- This device must accept any interference that may be received, including interference that may cause undesired operation.

Replacement Key fobs

NOTE:

Only key fobs that are updated with the vehicle electronics can be used to start and operate the vehicle.



WARNING!

- **Always remove the key fobs from the vehicle and lock all doors when leaving the vehicle unattended.**

- **Always remember to cycle the ignition switch to OFF.**

Duplication of key fobs may be performed by the **Service Network** only.

This procedure consists of programming a key fob that has never been programmed to the vehicle's electronics.

NOTE:

- *When having the Sentry Key® Immobilizer System serviced, bring all key fobs provided with the vehicle with you to the **Maserati Service Centre**.*
- *When selling the vehicle, it is necessary to provide the new owner with all key fobs.*

Vehicle Security Alarm

The vehicle security alarm monitors the vehicle doors and liftgate for unauthorised entry and the **START/STOP** button for unauthorised operations.

The system includes a dual function anti-intrusion sensor and vehicle anti-lift sensor. The anti-intrusion sensor monitors the vehicle interior for motion.

The vehicle anti-lift sensor monitors the vehicle for any lifting or tilting actions (tow away, tire removal, ferry transport, etc). A siren (for versions/markets, where provided) with battery backup which senses interruptions of power and communications is also included. While the vehicle security alarm is enabled, interior door locks switches, liftgate and fuel filler door release are disabled. If something triggers the alarm, the vehicle security alarm will provide the following audible and visible signals: intermittent buzzer, position lights and/or turn signals and the vehicle security light on the dashboard will flash.

This light will fast flash for approximately 15 seconds, when the vehicle security alarm is being armed,



Before Starting

and will then flash slowly until the vehicle is disarmed.




Rearming the System

If something triggers the security alarm, and no quick action is taken to disarm it, the vehicle security alarm will turn off the beeper after 29 seconds, and turn off all of the visual signals after 31 more seconds; the vehicle security alarm will then rearm itself.

Arming the System

Follow these steps to arm the vehicle security alarm.

- Make sure the vehicle ignition switch is **OFF**.
- Perform one of the following methods to lock the vehicle:
 - Press the  lock button on the interior power door lock switch


located on the driver door trim panel with the driver and/or passenger door open.




- Press the button on the exterior "Passive Entry" door handle having a valid key fob RKE transmitter in the same exterior zone (see "Passive Entry System" in this section for further information).



- Press the  lock button on the key fob RKE transmitter.




- If any door is open, close it. In any of these situations, if one or more windows are open, they will remain open. To close the windows press again the  lock button and hold it until their closure. If vehicle is equipped with power liftgate/Hands free, when arming the alarm system in any of the described ways, the liftgate will remain open if it




was left open. In this condition, it will be necessary to first close the liftgate as described under "Open and Close the Liftgate" in this section, and repeat the arming operation, to be able to arm the alarm system.

Vehicles equipped with power liftgate/Hand free option a button - located on the outer edge of the left boot compartment lining and indicated in the figure - that can be used to completely close and lock the liftgate and arm the alarm system if all the doors are closed.

See chapter "Open and Close the Liftgate" in this section for further information.




Each time the vehicle security alarm is armed, the anti-intrusion and anti-lift sensors actively monitor the vehicle. When arming the security alarm, it is possible to disable these sensors by


pressing the  button on the key fob three times within 5 seconds from the moment the system has been armed (meanwhile the security alarm light flashes rapidly).

To disarm the System

Use any of the following steps to disarm the vehicle security alarm.

- Press the  button on key fob RKE transmitter.
- Grasp the "Passive Entry" unlock door handle (see "Passive Entry System" in this section for further information).
- Press the **START/STOP** button so as to release the **OFF** position.

NOTE:

- *When the vehicle security alarm is armed, the interior power door lock switch will not allow to unlock the doors.*
- *The use of the emergency key into the driver door lock and the use of the button  on the key fob cannot arm or disarm the security alarm of the vehicle.*
- *The vehicle security alarm remains engaged while accessing the power liftgate/Hands free. Pressing the button between the licence plate*


lights will not disarm the vehicle security alarm. If anyone enters the vehicle through the liftgate and opens a door, the alarm will trigger.


The vehicle security alarm is designed to protect your vehicle; however, you can create conditions where the system will give you a false alarm. If one of the previously described arming sequences has occurred, the vehicle security alarm will arm regardless of whether you are in the vehicle or not. If you remain in the vehicle and open a door, the alarm will activate. If this occurs, disarm the vehicle security alarm. If the vehicle security alarm is armed and the battery becomes disconnected, the vehicle security alarm will remain armed when the battery is reconnected; the exterior lights will flash, the buzzer will activate. If this occurs, disarm the vehicle security alarm.




Illuminated Entry/Exit

Lights will turn on and off when you enter/exit the vehicle and operate the buttons on the key fob RKE transmitter and/or on the "Passive Entry" system as follows:

- If the lock command is enabled by pressing the specific  button on the key fob RKE transmitter or by the "Passive Entry" system, the "illuminated entry" mode will activate. Courtesy & dimmable internal lighting, night front seats lighting, and approach lighting will stay on for 27 seconds.






- If the lock command of the car is enabled by pressing the specific  button on the key fob RKE transmitter or by the "Passive Entry" system, when the key fob RKE transmitter is moved out of range, all the lights will turn off within 3 seconds, if they were previously on.





- After activating the liftgate opening command in the possible modes (see “Open and Close the Liftgate” in this section), the inner boot and liftgate lights will turn on and will stay on for 10 minutes before turning off. The lights will immediately turn off if you lock the liftgate before 10 minutes.



- If the  light button is pressed on the key fob RKE transmitter, the courtesy & dimmable lights and the approach lights will turn on; doors will stay locked.



Vehicle Lighting with Open/Closed Doors


- If one or more doors are open, the central light, front/rear domelights (main and spot light), the instrument cluster, the MTC+ display, the night front seats lighting and the ignition switch backlighting will turn on and will light up for 27 seconds.
- If the doors are closed, all lights will turn off (within 3 seconds) with the exception of the console display and the ignition switch backlighting, which will turn off after 27 seconds.

Vehicle Headlight Switch Function



Vehicle lighting can be operated from the key fob RKE transmitter, the "Passive Entry" system and from the headlight switch on the left side of the

dashboard (refer to "Lights" in section "Understanding the Vehicle" for further information).



- If the headlight switch is in the "0" (OFF) mode all the switches backlighting and the front seats lighting will turn off.
- If the headlight switch is in the  position and the ignition switch is in **OFF** or **ACC** position, the front low intensity LEDs of the external

headlight and rear position light guide LED will turn on.

- If the headlight switch is in  position and the ignition switch is in **RUN** position, no lighting feature will be available.
- If the headlight switch is in  position (Low beam mode) the front domelight LED (if enabled), the switches backlighting, the instrument cluster's display, the night front seats lighting will turn on. The front domelight LED and the night lighting of the front seats will light up with the intensity set by the buttons on the right side of the steering wheel, entering the menu "Vehicle Settings" and skip to "Interior Lighting". If the interior lighting is in "0" (OFF) position, the night lighting will turn off.
- If the headlight is switched to "AUTO" position (on/off AUTO mode) and the ignition is switched to **RUN** position, as in "low beam mode" all lights turn on either in "DAY" or "NIGHT" mode according to the twilight sensor. In "DAY" mode the switches backlighting will be at 100% intensity, in "NIGHT" mode they will be as set by the





buttons on the right side of the steering wheel.

NOTE:

In "DAY" mode, the switches are not backlighted, except the windows and steering switches.

Unlock the Vehicle with Key fob


The RKE system allows you to lock or unlock the doors and the fuel filler door, open the liftgate and turn the approach/courtesy lights on from a distance up to approximately 10 m (33 ft). The key fob RKE transmitter does not need to be pointed at the vehicle to activate the system. See "Illuminated Entry/Exit" in this section for further information.




NOTE:

Driving at speeds of 8 km/h (5 mph) and above disables the system from responding to all key fobs RKE transmitter buttons.

Unlock the Doors, Fuel Filler Door and Liftgate

Press and release the unlock button  on the key fob RKE transmitter once to unlock the driver's door or twice within five seconds to unlock all doors, the fuel filler door and the liftgate. The turn signal lights will flash for the unlock signal recognition. The illuminated entry/exit system will also turn on. See "Passive Entry System" in this section for further information.

Unlock Driver Door/All Doors with Key fob 1st Press

This feature allows you to programme the system to unlock either the driver's door or all doors, the fuel filler door and the power liftgate/Hands free, if equipped, by the first press of the unlock button  on the key fob RKE transmitter. To change the current setting, see "MTC+ Settings" in section "Dashboard Instruments and Controls".




Lock/Unlock Doors Flash Lights

This feature will cause the flash of the turn signal lights when the doors are locked or unlocked with the key fob RKE transmitter. This feature can be turned on or turned off. To change the current setting, see “MTC+ Settings” in section “Dashboard Instruments and Controls”.

Turn Headlights On with Key fob

This feature activates the headlights for up to 90 seconds when the doors are unlocked with the key fob RKE transmitter. The duration can be set as desired. To change the current setting, see “MTC+ Settings” in section “Dashboard Instruments and Controls”.

Unlatch the Liftgate

Press the button  on the key fob RKE transmitter two times within five seconds to unlatch the manual liftgate. If the vehicle is equipped with power liftgate/Hands free, besides unlocking the liftgate, the control will fully open it.

See chapters “Passive Entry System” and “Open and Close the Liftgate” in this section for further information.

Requiring and Setting Additional Key fobs

In order to purchase additional key fob RKE transmitters you need to bring with you at the **Service Network**:

- all key fobs RKE transmitters in your possession;
- a personal ID;
- the identification and registration documents proving ownership of the vehicle.

Setting new key fobs RKE transmitters or re-setting the original ones may only be performed at the **Service Network**.

NOTE:

The codes of any key fob RKE transmitter that are not available when the new setting procedure is carried out will be deleted from the memory to prevent any lost or stolen key fob RKE transmitter being used to disarm the electronic alarm system.

Key fob Battery Replacement

NOTE:

A low charge level of the key fob battery will be indicated on the instrument cluster display.

The recommended replaced battery type is a: CR2032.

To replace the battery proceed as follows:

- Remove the emergency key as indicated in “Keys” chapter of the current section.
- Loosen the lateral screw that connects the two side covers with a torx T6 screwdriver.



- Separate the two lateral covers from the key fob case.



- Separate both parts of the key fob case.



- Remove the card with PCB (Printed Circuit Board).



- Remove the battery from its seat and replace with a new recommended type of battery.



ENVIRONMENTAL!

Batteries contain dangerous materials that could harm the environment. Please dispose of them according to local regulations or at the Service Network.

NOTE:

Avoid touching the new battery with your fingers. Skin oils may cause battery deterioration. If you touch a battery, clean with alcohol.

- Match the + sign on the battery to the + sign on the inside of the battery clip, located on the back cover.
- Replace the printed circuit board by using the indicated pin for the sealing of the two covers.



- Assemble the key fob case and reassemble the two lateral covers: a click will ensure the succeeded sealing.
- Combine the disassembled parts with clamping screw and reassemble the emergency key.

Radio Frequency RKE Transmitter - General Information

Transmitters and receivers used inside the vehicle operate on a carrier frequency of 433.92 MHz as required by EEC regulations. These devices must be certified to conform to specific regulations in each individual country. Two sets of regulations are involved: ETS (European Telecommunication Standard) 300–220, which most countries use, and German BZT federal regulation 225Z125, which is based on ETC 300–220 but has additional unique requirements. Other defined requirements are noted in ANNEX VI of COMMISSION DIRECTIVE 95/56/ EC. The current device feature is subject to following conditions:

- This device may not cause harmful interference.

- This device must accept any interference received, including interference that may cause undesired operation.

If your key fob RKE transmitter fails to operate from a normal distance, check for these two conditions:

- A weak battery in the key fob RKE transmitter. The expected life of the battery in normal use is a minimum of three years.
- Closeness to a radio transmitter such as a radio station tower, airport transmitter, and some mobile or CB radios.

Remote Start System (optional)

This system enables the key fob RKE transmitter to start the engine conveniently from outside the vehicle while still maintaining security. The system has a range of approximately 91 m (300 ft). Obstructions between the vehicle and the key fob may reduce this range.

How to use Remote Start

All of the following conditions must be met before the engine will remote start:

- System not disabled from previous remote start event.
- Vehicle theft alarm not active.
- Doors closed.
- Hood closed.
- Liftgate closed.
- Hazard lights switched off.
- Brake pedal not pressed by any passenger remained in the vehicle.
- Battery at an acceptable charge level.
- The shift lever is in P (Park) position.
- The vehicle transmission is in automatic mode.



- The remote start has not been activated yet two consecutive times.

**WARNING!**

- Do not start or run an engine in a closed garage or confined area. Exhaust gas contains Carbon Monoxide (CO) which is odourless and colourless
- Keep key fobs RKE transmitter away from children. Operation of the Remote Start System, windows, door locks or other controls could cause serious injury or death.

Engine Remote Start Abort Message on Instrument Cluster

The following messages will display on the instrument cluster if the vehicle fails to remote start or exits remote start prematurely:


- “Remote Start Cancelled Door Open”.
- “Remote Start Cancelled Liftgate Open”.
- “Remote Start Cancelled Fuel Low”.
- “Remote Start Cancelled Time Expired”.
- “Remote Start Disabled Start Vehicle to Reset”.

The message on the instrument cluster stays active as long as the ignition switch is in **RUN** position.

To enter Remote Start Mode

NOTE:

On the key fob RKE transmitter of vehicles with this feature, the external lights button  is replaced by the remote start button .

Press and release the button  on the key fob RKE transmitter twice within five seconds. The vehicle doors will lock, position lights will flash and the horn will ring twice (if this function is set using the MTC+ System, refer to “MTC+ Settings” in section “Dashboard Instruments and Controls”). Then, the engine will start and the vehicle will remain in the “Remote Start” mode for a 15-minute cycle.




NOTE:


- In case of an engine fault or low fuel level, the vehicle will start and then shut down in 10 seconds.
- The park lights will turn on and remain lighted up during “Remote Start” mode.
- For security reasons, power window and power sunroof operation (if equipped) are disabled when the vehicle is in the “Remote Start” mode.
- The engine can be started two consecutive times (two 15-minute cycles) with the key fob RKE transmitter. However, the ignition must be cycled to the **RUN** position before you can repeat the start sequence for a third cycle.




To exit Remote Start Mode without Driving the Vehicle

Press and release the button  one time or allow the engine to run for the entire 15-minute cycle.

NOTE:

To avoid unintentional shutdowns, the system will disable the one time press of the button  for two seconds after receiving a valid "Remote Start" request.

To exit Remote Start Mode and Drive the Vehicle

Before the end of the 15-minute cycle, press and release the button  on the key fob RKE transmitter to unlock the doors and disarm the vehicle security alarm. Then, prior to the end of the 15-minute cycle, press and release the **START/STOP** button.

NOTE:

*The message "Remote Start Active Push Start Button" will display in the instrument cluster until you push the **START/STOP** button.*

Auto-On Comfort with Remote Start

The driver's heated and ventilated seat and the heated steering wheel (if foreseen) can be programmed to come on during a remote start. Refer to "Auto-On Comfort & Remote Start" function in chapter "MTC+ Settings", section "Dashboard Instruments and Controls", for further information.

Doors Locking



WARNING!

- For personal security and safety in the event of an accident or robbery, lock the vehicle doors before you drive as well as when parking and leaving the vehicle unattended.
- When leaving the vehicle, always remove the key fob RKE transmitter and lock your vehicle.
- Never leave children alone in a vehicle, or with access to an unlocked vehicle.
- Do not allow children to be in a vehicle unattended. A child or others could be seriously or fatally injured. Children must not touch the parking brake trigger, brake pedal or the shift lever.
- Do not leave the key fob in or near the vehicle, and do not leave ignition switch in the ACC or RUN mode. A child could operate power windows, other controls, or start the engine and the vehicle.



Doors Manual Lock

To lock each door, push the door lock knob on each door trim panel downward.



To unlock the front doors, pull the inside door handle to the first detent.





To unlock the rear doors, pull the door lock knob on the door trim panel upward.

If the door lock knob is down when you shut the door, the door will lock.


Therefore, make sure the key fob RKE transmitter is not inside the vehicle before closing the door.

Power Doors Locking/Unlocking

A power door lock switch  and a power door unlock switch  are positioned on the front door trim panel. Use these switches to lock or unlock the doors.



If the vehicle has been locked from inside with the above-figured switches, the fuel filler flap remains unlocked.

If power liftgate/Hands free (option) has been left open, it will stay open when you press lock button , and the locking feature will only occur after the closing of the power liftgate.

The doors can also be locked and unlocked with the "Passive Entry" system. For further information, see "Passive Entry System" in this section.

If you press the power door lock switch while the ignition switch is in the **ACC** or **RUN** position, and any front door is open, the power locks will not operate. This prevents you from accidentally locking the key fob RKE transmitter in the vehicle.

Cycling the ignition to the **OFF** position or closing the door will allow the locks of the doors and fuel filler door to operate. If a door is open with the key fob RKE transmitter inside the cabin and the ignition is in the **ACC** or **RUN** position, a beep will draw the driver's attention.



Automatic Door Lock

The auto door lock feature default condition is disabled. When enabled, the door locks will lock automatically when the vehicle's speed exceeds 24 km/h (15 mph). The auto door lock feature can be enabled or disabled by a **Maserati Service Centre** only which can also service the vehicle.

Automatic Door Unlock on Exit

The doors will unlock automatically on vehicles with power door locks if:

- The automatic door unlock on exit feature is enabled.
- The transmission is in gear and the vehicle speed is 0 km/h.
- The transmission is in N (Neutral) or P (Park).
- The driver door is open.
- The doors were not previously unlocked.
- The vehicle speed is 0 km/h.

Set Automatic Door Unlock on Exit

To change the current setting, see "MTC+ Settings" in section "Dashboard Instruments and Controls".



NOTE:

Use the automatic door unlock on exit feature in accordance with local regulations.

Child-Protection Door Lock System — Rear Doors

To provide a safer environment for small children sitting in the rear seats, the rear doors are equipped with a child-protection door lock system.

Engage or Disengage the Child-Protection Door Lock

- Open the rear door.
- Insert the tip of the emergency key into the lock and rotate to the lock  or  unlock position.
- Repeat the first two steps on the opposite rear door.



WARNING!

Avoid trapping anyone in a vehicle in a collision. Remember that the rear doors can only be opened from the outside when the child-protection locks are engaged (locked).

NOTE:

For emergency exit from the rear seats when the child-protection door lock system is engaged, manually raise the door lock knob to the unlocked position, roll down the window, and open the door using the outside door handle.



Passive Entry System

The “Passive Entry” system is an enhancement to the vehicle’s Remote Keyless Entry (RKE) system. This feature allows you to lock and unlock the vehicle’s door(s) without having to press the key fob RKE transmitter lock or unlock buttons.

NOTE:

- “Passive Entry” may be programmed to on/off; see “MTC+ Settings” in section “Dashboard Instruments and Controls” for further information.
- If wearing gloves, or if it has been raining on the “Passive Entry” door handle, the unlock sensitivity can be affected, resulting in a slower response time.
- Access to the vehicle using “Passive Entry” system may not work properly in case of interference caused by external sources such as metal objects, mobile phones, overhead power lines, antennas, etc. In these cases, use the buttons of the key fob RKE transmitter to open and close the vehicle or the emergency key, inserting it into the driver side door lock.
- The “Passive Entry” system does not lock and unlock the doors directly

and immediately but with a slight delay (about 2 seconds).

Unlock Door from the Driver Side

With a valid key fob RKE transmitter within 1 m (3.3 ft) of the driver’s door handle, grip the driver’s door external handle to unlock the door automatically. The interior door panel lock knob will raise when the door is unlocked.



NOTE:

If “Unlock All Doors 1st Press” is programmed on all doors will unlock when you grip the front driver’s door handle. To select between “Unlock Driver Door 1st Press” and “Unlock All Doors 1st Press”, see “MTC+ Settings” in section “Dashboard Instruments and Controls”.

Unlock Door from the Passenger Side

With a valid key fob RKE transmitter within 1 m (3.3 ft) of the passenger door handle, grip the front passenger external door handle to unlock all four doors automatically. The interior door panel lock knob will raise when the door is unlocked.





NOTE:

All doors will unlock when you grip the front passenger door handle regardless of the driver's door unlock preference setting ("Unlock Driver Door 1st Press" or "Unlock All Doors 1st Press").

Preventing Inadvertent Locking of the Key fob RKE Transmitter inside the Vehicle

To minimize the possibility of unintentionally locking a key fob RKE transmitter inside your vehicle, the "Passive Entry" system is equipped with an automatic door unlock feature which will function if the ignition switch is in the **OFF** position.

If one of the vehicle doors is open and the door panel switch  is used to lock the vehicle, once all open doors have been closed, the system checks the inside and outside of the vehicle for any valid key fobs RKE transmitter. If one of the vehicle's key fobs RKE transmitters is detected inside the vehicle, and no other valid key fobs RKE transmitters are detected outside the vehicle, the "Passive Entry" system automatically unlocks all vehicle doors and chirps the horn fourteen times (on the fifteenth attempt ALL doors will lock and the key fob RKE transmitter will be locked in the vehicle). This will happen even on vehicles equipped with power liftgate/Hands free, pressing the lower  button on the outer edge of the left boot compartment lining to close and lock the liftgate.

NOTE:

The vehicle unlocks the doors under any of the following conditions:

- the doors are manually locked using the door lock knob positioned on the door panel;



- there is a valid key fob RKE transmitter inside the vehicle;
- there is not a valid key fob RKE transmitter outside the vehicle.


NOTE:

The vehicle will not unlock the doors under any of the following conditions:

- the doors are locked using the key fob RKE transmitter;
- the doors are locked using the button on the "Passive Entry" door handles;



Optional equipment

- there is a valid key fob RKE transmitter outside the vehicle and within 1 m (3.3 ft) of either "Passive Entry" door handle;
- fifteen attempts are made to lock the doors using the door panel switch and/or the lower  button (on the outer edge of the left boot compartment of vehicles equipped

with power liftgate/Hands free) and then close the doors.

Release the Liftgate and Enter the Boot

For vehicles equipped with manual liftgate: with the key fob within 1 m (3.3 ft) of the liftgate, press the button located between the licence plate lights and lift it manually.

For vehicles equipped with power liftgate/Hands free (optional): with the key fob within 1 m (3.3 ft) of the liftgate, press the button located between the licence plate lights, the liftgate will automatically open until fully home; if the same button is not pressed again to stop it (for more information, see chapter "Open and Close the Liftgate" in this section).

If the vehicle had already been unlocked through key fob or "Passive Entry", the presence of the key fob is not required; simply use the button located between the licence plate lights to open the liftgate manually or automatically.

Manual Door Lock from Outside

With one of the vehicle's key fobs RKE transmitters within 1 m (3.3 ft) of the


driver or passenger front door handles, press the external door handle button to lock all four doors.

NOTE:

- After pressing the external door handle button, you must wait two seconds before you can lock or unlock the doors using this door handle. By pulling the external door handle, you can check if the car remains locked, without "Passive Entry" system reacting and unlocking the doors.
- The "Passive Entry" system will not operate if the key fob RKE transmitter battery is dead.
- If power liftgate/Hand free (option) has been left open, it will stay open when you press the button on door external handle, and the locking feature will only occur after the closing of the power liftgate.



2



Optional equipment

The vehicle doors can also be locked by using the key fob RKE transmitter lock button or the lock button located on the vehicle's inner door panel.



Power Windows

The window controls on the driver's door panel govern all the door windows.



There are single window controls on each passenger door trim panel, which operate the corresponding window. The window controls will operate only when the ignition switch is in the **ACC** or **RUN** position.



NOTE:

- The power window switches will remain active for up to 10 minutes after the ignition switch is turned to the OFF position. Opening either front door will cancel this feature. The time lapse can be set. See "MTC+ Settings" in section "Dashboard Instruments and Controls" for further information.
- Frequent activations of the power windows could result in a temporary lock of their starters. In this case, wait a moment before a new activation.



WARNING!

Improper use of the power windows and the sunroof (if equipped) can however be dangerous, even with the anti-pinch prevention system. Before and during activation of the power window, always check that the passengers are not exposed to the risk of injury both by the moving window and by personal objects that could be dragged or hit by it. Do not leave unattended children in a vehicle with a key fob RKE transmitter inside. When getting out the vehicle, always remove the key fob RKE transmitter to

prevent the windows being accidentally activated, posing a risk to passengers remaining onboard.

Auto-Down Feature

The driver door power window switch and some model passenger door power window switches have an auto-down feature. Press the window switch to the second detent, release, and the window will go completely down automatically. To open the window part way, press the window switch to the first detent and release it when you want the window to stop. To stop the window from going all the way down during the auto-down operation, pull up on the switch briefly.

Auto-Up Feature with Anti-Pinch Protection

Lift the window switch to the second detent, release, and the window will go all the way up automatically. To stop the window from going all the way up during the auto-up operation, push down on the switch briefly. To close the window part way, lift the window switch to the first detent and

release it when you want the window to stop.

NOTE:

- If the window runs into any obstacle during auto-closure, it will reverse direction and then go back down. Remove the obstacle and use the window switch again to close the window.
- Any impact due to rough road conditions may trigger the auto reverse function unexpectedly during auto-closure. If this happens, pull the switch lightly to the first detent and hold to close the window manually.
- Frequent activations of the anti-pinch function could disable the auto-down and auto-up function of the windows. In order to re-activate this function proceed with a reset cycle as described in the next paragraph.



WARNING!

There is no anti-pinch protection when the window is almost closed. Be sure to clear all objects from the area before closing the window.



Reset Auto-Up/Down



Should the auto-up/down feature stop working, the window probably needs to be reset.

To reset auto-up/down, pull the window switch up to close the window completely and push the window switch down to open the window completely.



Open and Close the Windows and Sunroof with RKE Transmitter and Ignition Off

When the ignition switch is in **OFF** position, windows and sunroof (if equipped) can be opened or closed by pressing the buttons on the RKE transmitter.

Opening:

- press the  button and release it;
- press a second time the  button and keep it pressed until complete opening of the window and sunroof, if they were closed.

Closing:

- press the  button and release it;
- press a second time the  button and keep it pressed until complete closure of the window and sunroof, if they were open.

Rear Window and Sunshade Lockout Button

The window lockout button on the driver's door trim panel allows to disable the window and sunshade control on the rear doors by pressing the window lockout button (setting it in the down position).



To enable the controls previously described, press the window lockout button again (setting it in the up position).

Wind Buffeting

Wind buffeting can be described as the perception of pressure or a helicopter-type sound. Your vehicle may exhibit wind buffeting with the windows down, or the sunroof (optional) in open or partially open positions. This is a normal occurrence and can be minimized. If the buffeting

occurs with the rear windows open, open the front and rear windows together to minimize the buffeting. If the buffeting occurs with the sunroof open, then adjust the sunroof opening to minimize the buffeting.




Power Sunshades on Rear Door Windows (optional)

NOTE:

- On vehicles provided with power sunshades on the rear windows, the window switches also operate the sunshades.
- The rear windows lock button operates as well the rear power sunshades.
- The window and sunshades controls will operate only if the ignition switch is in **ACC** or **RUN** position.

Operation of the rear windows and related sunshades is done by pressing or pulling the window switch and depends on the position of the windows prior to the command operation.

As described for the opening and closing functions of the power windows (see chapter "Power Windows" in this section), the windows switch has two functioning modes: press and release the switch to the first detent to partially move the window; press and release the switch to the second detent to move the window all the way up or down.



Operations




WARNING!

Rear seat passengers must be careful when operating the sunshades, since there is the risk of being pinched between the top of the sunshade and the head lining, during raising, and between the top edge of the sunshade and the door panel, during lowering.



CAUTION!

Before activating the sunshade, make sure that no objects can interfere with its travel.

The following images and the subsequent text show the possible starting positions ("A", "B", "C" and "UP", "DOWN") and function of the window and the sunshade, to be independently activated by pressing or lifting the control switch  to the first (1) or second (2) detent.



A. Sunshade fully unrolled ("UP" position) and Window closed ("UP" position)

- Pulling the control up to 1 or 2 detent: no action ("NOP").



- 1.1 Pressing the control to 1 detent: the sunshade rolls down completely and the window stays closed.
- 1.2 Pressing the control again to 1 detent: the window opens partially until the control is released and the sunshade stays down (pressing the control to 2 detent: the window opens completely).
- 2.1 Pressing the control to 2 detent: the sunshade rolls down completely while the window stays closed.
- 2.2 Pressing the control again to 2 detent: the window opens completely.

B. Sunshade fully rolled down ("DOWN" position) and Window closed ("UP" position)

- Pulling the control up to 1 or 2 detent: the sunshade unrolls completely and the window stays closed.
- Pressing the control to 1 or 2 detent: the window opens partially or completely and the sunshade remains rolled.



C. Sunshade fully rolled down (“DOWN” position) and Window completely open (“DOWN” position)

- Pulling the control to 1 or 2 detent: the window closes partially or completely and the sunshade remains rolled.
- Pressing the control to 1 or 2 detent: no action (“NOP”).


Open and Close the Liftgate

The manual liftgate can be unlocked from inside the vehicle by pressing the button on the front dome console. This command will fully open or fully close the power liftgate/Hands free (optional). Pressing this button in sequence, if the power liftgate stops in intermediate position, it resumes and reverse the stroke direction.


NOTE:


The shift lever must be in P (Park) before the button can operate.



The manual liftgate can be released from outside the vehicle by pressing the  button on the key fob with RKE transmitter twice within five seconds or by using the external

release button located on the lower side of the liftgate ledge, between the licence plate lights, when the vehicle has been unlocked using the key fob or the “Passive Entry” system.





When the button  on the key fob is pressed twice within five seconds, the direction indicators flash twice to indicate the opening or closing of the liftgate, if the light flashing function at closing is activated on MTC+ (for



more information, see the chapter "MTC+ Settings" in section "Dashboard Instruments and Controls").
To manually close the liftgate, use the handles indicated in the picture.





With the ignition switch in **RUN** position, the red symbol  will be displayed on the instrument cluster. If the vehicle is in motion, in addition to the symbol  will also appear a message indicating that the liftgate is open. Once the liftgate is closed the symbol or the symbol and message will disappear from the display.



With the ignition device in the **OFF** position, only the liftgate open symbol will display until closure. See "Passive Entry System" in this section for more information on liftgate operation with the "Passive Entry" feature.

Power Liftgate/Hands Free (optional)

Automatic opening and closing movement of the liftgate is driven by electric actuators and a motorised latch ensuring lid locking upon closing. Liftgate can be opened using button  on the key fob RKE transmitter and the button on front dome console used also for non-power version. The  button on key fob and button on front dome console not only allow user to completely open the power liftgate/Hands free, but also to stop it

at any intermediate position by pressing the button again whenever you wish to stop and resume the opening process.


In addition to these commands, it is possible open and close the power liftgate/Hands free, or stop its movement, by simply moving your foot under the rear bumper. In this latter case, the liftgate will be opened and closed only if the "Passive Entry" system acknowledges the presence of the key fob RKE transmitter within 1 m (3.3 ft) of the liftgate.

Power liftgate/Hands free uses the button in between the licence plate lights, indicated in figure, to activate the opening once the car has been unlocked by the key fob or by the "Passive Entry" function.

By pressing this button when the power liftgate/Hands free is closed, you can open it completely, or by pressing the button again stop the opening process, or by pressing the button again invert the movement and close it completely.



When the power liftgate/Hands free is open, to move it there are two buttons positioned on the outer edge of the left boot compartment lining as indicated in figure.



When the liftgate is completely open if you press and release the upper button ↶, the power liftgate/Hands free will be completely closed unless it is stopped;

- if instead the power liftgate/Hands free is in an intermediate position

and you press and release the upper button ↶ during the closing or opening stroke, it will be stopped;

- if instead the power liftgate/Hands free is stopped in an intermediate position and you press and release the upper button ↶, it will reverse its previous movement and it will be completely opened or closed unless it is stopped again.

In any case, when you press the upper button ↶, the doors will not be locked and the alarm system will not be armed.

When the liftgate is completely open if you press and release the lower button ↵, the power liftgate/Hands free will be completely closed unless it is stopped;

- if instead the power liftgate/Hands free is in an intermediate position and you press and release the lower button ↵ during the closing or opening stroke, it will be stopped;
- if instead the power liftgate/Hands free is stopped in an intermediate position and you press and release the lower button ↵, it will reverse its previous movement and it will be completely opened or closed unless it is stopped again.

In any case, when you press the lower button ↵, the doors will not be locked and the alarm system will not be armed immediately, but only when the liftgate will have reached the totally closed position as effect of every movement commands received from every other available inputs.

NOTE:

- *The order of the functions shown does not represent the sequence in which they can be performed.*
- *The buttons of the power liftgate/Hands free do not work if a gear is engaged or if the vehicle speed is higher than 0 km/h (0 mph).*
- *The power liftgate/Hands free does not work with temperatures lower than $-30\text{ }^{\circ}\text{C}$ ($-22\text{ }^{\circ}\text{F}$) or higher than $65\text{ }^{\circ}\text{C}$ ($150\text{ }^{\circ}\text{F}$).*
- *If the opening buttons or the handles are operated while the power liftgate/Hands free is closing, the stroke of liftgate stops. Pressing another time the same command it reverses movement and fully open.*
- *If the opening buttons or the handles are operated while the power liftgate/Hands free is*

(Continued)



(Continued)

opening, the motor of the liftgate is disabled to allow manual operation.

- *If the power liftgate/Hands free finds several obstacles during the same operating cycle, it will stop automatically and must be opened or closed manually.*
- *If the power liftgate/Hands free is closing and a gear is engaged, the liftgate will continue closing. In this condition, it is possible that, during the closing stroke, it may find an obstacle and stop.*



WARNING!

If, for any reason, the liftgate must remain open while driving, close all the windows and activate the fan of the air conditioning control at the maximum speed. Do not activate recirculation.

Since when the doors are locked, the “Passive Entry” system waits for about 16 seconds before verifying if a key fob RKE transmitter is present inside the vehicle.

- If during this time you press the lower button to close the liftgate and activate the alarm, if a key fob

RKE transmitter is left in the trunk, the system will close the liftgate and will activate the alarm system. This option is recommended when you want to leave the other key fob RKE transmitter inside the vehicle.

- By pressing the same button after 16 seconds, if a key fob RKE transmitter is left in the trunk, the liftgate will close and will partially reopen. If the “Passive Entry” system detects no key fob RKE transmitter inside the trunk, close the liftgate and will activate the alarm system.

Set the Position of Maximum Power Liftgate Opening

The maximum opening position of the liftgate can be modified using the previously described buttons on the outer left edge of the boot compartment.

1. Activate the liftgate and stop it in the new maximum opening position to be set, by pressing the upper button.
2. Press the upper or lower buttons and keep it pressed for 3 seconds.
3. Release the button (pressed in the previous point). Upon the following

opening controls, the liftgate will stop in the stored position.


If you want to reset the maximum possible opening position of the liftgate, proceed as described below starting from the previously set opening position.

1. Manually push the liftgate to the maximum possible opening position.
2. Repeat the previously performed steps 2 and 3.

Power Liftgate/Hands Free Automatic Safe Movement

Power liftgate/Hands free safe opening and closing is ensured by a protection system able to stop its movement when an obstacle is detected along the path: when opening or closing, it stops automatically and then slightly moves back.

Along the upper outer edges, the vehicle is equipped with anti-pinch protection sensors. These sensors stop the automatic closing stroke and partly open the liftgate when a pressure is carried out, also slight, within their range shown in the figure.



After the closing command, when power liftgate/Hands free starts closing, all the indicators will blink to warn anyone within range. Apart from activating indicators blinking when liftgate is operated, it is also possible to activate a sound warning by selecting the relevant function within MTC+ user settings (see “MTC+ Settings” in section “Dashboard Instruments and Controls”).

When power liftgate/Hands free edge reaches the car body, the motor locking the latch is activated automatically.

If necessary, the power liftgate/Hands free can also be opened or closed manually. This operation could be required when the liftgate remains open for a long period of time.

NOTE:

Frequent activations of the anti-pinch protection function may disable the automatic movement of the liftgate. To reactivate this function, perform a reset cycle by carrying out a complete opening/closing sequence, after manually closing the liftgate.



WARNING!

- **Activate power liftgate/Hand free only when vehicle is at a standstill.**
- **Always pay utmost attention when opening and closing the tailgate. If for any reason the protection system might fail to respond, it could cause injury to anyone within the operating area.**
- **After the closing command, always make sure that power liftgate/Hand free is completely closed.**



CAUTION!

- **Under extreme weather conditions, liftgate seal could freeze and compromise power liftgate/Hand free automatic opening and closing.**

- **Before opening power liftgate/Hand free, make sure that no objects or snow are set on liftgate or might jam or prevent its opening.**

Hands Free Power Liftgate Release and Closing

This mode is controlled by the “Passive Entry” system (see paragraph “Passive Entry System” in this section), which automatically releases and closes the power liftgate/Hands free when you place your foot in the area under the rear bumper.

The system will only operate if the system acknowledges the presence of the key fob RKE transmitter within 1 m (3.3 ft) of the power liftgate/Hands free.

The range of the sensors that detect your foot movement extends along and underneath the central portion of the rear bumper.

To activate the power liftgate/Hands free, stand behind the vehicle, near the liftgate, and move your foot under the bumper as if to kick something. Do not place your foot too close to the bumper or touch the underbody.



WARNING!

- Pay careful attention to the exhaust tailpipes as they can reach high temperatures and, in case of contact, they can cause severe burns.
- When it is not necessary to open the Power Boot Lid with the “Hands Free” mode, make sure the key fob is outside the range of use (1 m/3.3 ft). Otherwise, the Power Boot Lid/Hand Free can be opened accidentally by an unintentional movement of the foot.



In order for the sensors to detect your foot movement, move your foot towards the vehicle rather than sideways and immediately pull it back: from this moment, the power

liftgate/Hands free will activate within two seconds.

If closed, with the foot movement the power liftgate/Hands free will:

- unlock and completely open;
- after another kick, will stop;
- after another kick, will reverse its movement and completely close unless stopped again.

If open, with the foot movement the power liftgate/Hands free will:

- completely close but not lock;
- another kick before the completed closing can stop the movement;
- if the movement was stopped another kick operation will invert a complete opening.

NOTE:

- If your foot movement fails to activate the power liftgate/Hands free movement, wiggling your foot under the bumper will not help. Repeat the whole kick movement.
- In particular situations, external factors affecting the sensor area may trigger the Hands free power liftgate release feature. For example, when washing the vehicle, a water jet aimed at the sensor area may trigger the Hands free power liftgate release

feature. Keep the key fob RKE transmitter away from the sensing range of the sensors (3 m/10 ft) or disable the Hands free feature from the MTC+ menu (see “MTC+ Settings” in section “Dashboard Instruments and Controls”). A key fob RKE transmitter located in the front seat passenger area is considered out of range of the Hands free liftgate release sensor.

- If somebody or something knocks against the power liftgate/Hands free while it is moving, the safety system might stop lid opening or closing movement.

Liftgate Emergency Release

If the power release control operated by pressing the button on the dome console fails, the battery could be in a low condition. In this case, it is possible to temporarily power the system by using the battery remote poles located inside the engine compartment (see “Auxiliary Jump-Start Procedure” in section “In an Emergency”). Then it is possible to normally open the liftgate by using the key fob RKE transmitter. Have the vehicle subsequently serviced by a **Service Network** centre in order to solve the failure.



Open and Close the Hood

Opening

Two latches must be released to open the lid.

- From inside the vehicle, pull the hood release lever located under the left lower side of the dashboard.




- Move to the outside and stand in front of the vehicle front grille.



- Slightly lift the hood and push the safety catch as indicated by the arrow. The safety catch is located in the centre of the hood.



- Lift the hood completely: this operation is facilitated by two gas struts keeping the fully open position.

With the ignition switch in **RUN** position, the red symbol  will display on the instrument cluster with the message indicating that the hood is open.

Closing

Lower the hood and then gently drop it. This should secure the inclusion of both latches.



CAUTION!

To prevent possible damage, do not slam the hood to close it.



WARNING!

- Be sure the hood is fully latched before driving your vehicle. If the lid is not fully latched, it could open when the vehicle is in motion and block your vision. Failure to follow this warning could result in serious injury or death.
- Gear shifting is always active and may be performed even when one or more doors, the hood or the liftgate are open. Therefore, in these conditions, take great care to avoid moving the gearshift lever and so accidentally engage gears.



Occupants Restraint Systems

The listed occupants restraint systems are some of the most important safety features in your vehicle:

- Three-point seat belts (also called lap shoulder belts) for the driver and all passengers.
- Advanced front air bags for driver and passenger.
- Supplemental Side Air Bag Inflatable Curtains (SABIC) for the driver and passengers seated next to a window.
- Supplemental seat-mounted side air bags.
- An energy-absorbing steering column and steering wheel.
- Front seat belts incorporate dual pretensioners that may enhance occupant protection by managing the energy created during an impact.
- All passengers seat belts include Automatic Locking Retractors (ALR), which lock the seat belt webbing into position by extending the belt all the way out and then adjusting the belt to the desired length to restrain a child seat or secure a large item in a seat.

To carry children up to 12 years old or under 1.5 m (5 ft) in height, you must use adequate child restraint systems that can be fixed with the three point seat belts or the Isofix anchorages.

NOTE:

The advanced front air bags have a multistage inflator design. This allows the air bag to have different rates of inflation based on the severity and type of collision.

Please pay close attention to the information in this section. It tells you how to use your restraint system properly, to keep you and your passengers as safe as possible.



WARNING!

In an accident, all occupants can suffer much greater injuries if not properly buckled up. You can strike the interior of your vehicle or other occupants or you can be thrown out of the vehicle. Always be sure you and others in your vehicle are buckled up properly. Buckle up even though you are an excellent driver, even on short trips. Someone on the road may be a poor driver and cause an accident that includes you. This can happen far

away from home or on your own street.

Statistics report that seat belts save lives and reduce the seriousness of injuries in an accident. Some of the worst injuries happen when people are thrown from the vehicle. Seat belts reduce the possibility of ejection and the risk of injury caused by striking the inside of the vehicle. Everyone in a motor vehicle should be belted at all times.

Three-Point Seat Belts

All seating positions in your vehicle are equipped with combination lap-shoulder belts.

The belt retractor is designed to lock during very sudden stops or impacts. This feature allows the shoulder part of the belt to move freely with you under normal conditions, conforming perfectly to the body of the occupants. However, in an accident, the belt will lock and reduce your risk of striking the inside of the vehicle or being thrown out.

The driver is responsible for respecting, and ensuring that all the other occupants of the car also observe the local regulations concerning the use of



seat belts. Always fasten the seat belts before starting the vehicle.

WARNING!

- It is forbidden and dangerous to ride in a cargo area. In an accident, people riding in these areas are more likely to be seriously injured or killed.
- Do not allow any person to ride in any area of your vehicle that is not equipped with seats and seat belts.
- Be sure all passengers are in a seat and using a seat belt properly.
- Wearing a seat belt improperly is dangerous. Seat belts are designed to go around the large bones of your body. These are the strongest parts of your body and can best absorb the impact of an accident.
- Wearing your belt in the wrong place could make your injuries in an accident much worse. You might suffer internal injuries, or you could even slide out of part of the belt. Follow these instructions to wear your seat belt safely and to keep your passengers safe, too.
- Two people should never be belted into a single seat belt. People belted

together can crash into one another in an accident, hurting one another severely. Never use a lap/shoulder belt for more than one person, no matter what their size.

- Remember that, in the event of an accident, the rear seat passengers not wearing the seat belts are not only subject to personal injuries but also represent a serious danger for the front seat occupants.

Three-Point Seat Belts Use Instructions

- Enter the vehicle and close the door. Sit back and adjust the seat.
- The seat belt latch plate is above your seat on the external side.
- Hold the latch plate and pull the belt across you, make the belt go around your body and when the belt is long enough to fit, insert the latch plate into the buckle until you hear a "click."



WARNING!

- A belt that is buckled up into the wrong buckle will not protect you properly. The lap portion of the belt could ride too high on your body, possibly causing internal injuries. Always buckle up your belt into the corresponding buckle.
- A belt that is too loose will not protect you properly. In a sudden stop, you could move too far forward, increasing the possibility of injury. Wear your seat belt comfortably.
- A belt that is worn under your arm is dangerous. Your body could strike the inside surfaces of the vehicle in an accident, increasing head and neck injury. A belt worn under the

(Continued)



(Continued)
arm can also cause internal injuries. Ribs are not as strong as shoulder bones. Wear the belt over your shoulder so that your strongest bones will take the impact of a collision.

- The lower part must adhere to the pelvis rather than the abdomen of the occupant. To fasten the lap belt pull slightly up the diagonal portion of the shoulder belt. To loosen the lap belt if too tight, tilt the latch plate and pull on the lap belt. A snug belt reduces the risk of sliding under the belt in an accident.



WARNING!

- A lap belt worn too high can increase the risk of internal injury in an accident. The belt forces won't impact on the strong hip and pelvic bones, but across your abdomen. Always wear the lap belt as low as possible and keep it comfortable.
- A twisted belt will not protect you properly. In a collision, it could even cut into you. Be sure the belt is straight. If you can't straighten a belt in your vehicle, take it to a Service Centre immediately.

- Do not use devices (clips, fastenings etc.) that prevent the seat belts from laying close to the occupants bodies.
- Do not carry children on a passenger's lap using only one seat belt for protecting both.
- Position the shoulder belt on your chest so that it is comfortable and not resting on your neck. The retractor will withdraw any slack in the belt.
- To release the belt, push the red button on the buckle. The belt will automatically retract to its stowed position. If necessary, guide the seat belt with your hand while it is rewinding, to prevent it from twisting.



WARNING!

A frayed or torn belt could break in an accident and leave you with no protection. Inspect the belt system periodically, checking for cuts, frays, or loose parts. Damaged parts must be replaced immediately. Do not disassemble or modify the system. Seat belt/retractor assemblies must be replaced by the Service Network after an accident if they have

been damaged (bent retractor, torn belt, etc.).

Three-Point Seat Belt Height Adjustment



WARNING!

The seat belts height must only be adjusted when the vehicle is stationary.

The vehicle has a shoulder belt height adjuster for the driver and front passenger seating positions. Adjust the guide so that the shoulder portion of the belt is on the shoulder and not falling off of it. The belt should be close to, but not contacting, the neck.

Push downward the upper part of the indicated slider above the shoulder belt guide to release the anchorage, then move the belt slider up or down to the fixed position that fits you best.



WARNING!

After the adjustment, always check that the slider to which the oscillating ring is fixed, is locked into one of the positions provided. With the handgrip



released, push again downward to allow the anchoring device to click into place, in the event that it has not been released in one of the positions provided.



When you release the anchorage try to move the belt slider up and down to make sure that it is locked in position.

Three-Point Seat Belt Untwisting Procedure

Use the following procedure to untwist a twisted three-point belt.

- Position the latch plate as close as possible to the anchor point.
- At about 15 to 30 cm (0.5 to 1 ft) above the latch plate, grasp and twist the belt by 180 degrees to create a fold that begins immediately above the latch plate.

- Slide the latch plate upward over the folded belt. The folded belt must enter the slot at the top of the latch plate.
- Continue to slide the latch plate up until it clears the folded belt.

Passengers Seat Belts

All passengers seat belts are equipped with Automatic Locking Retractors (ALR) and can be used to secure a child restraint system. For additional information, see "Installing Child Restraint Systems using the Vehicle Seat Belt equipped with ALR" under "Child Restraint Systems" in this section.

If the passenger seat position should not be used to accommodate a child restraint system, only pull the belt out far enough to comfortably wrap around the occupant so as to not activate the ALR. If the ALR is activated, you will hear a ratcheting sound as the belt retracts. In this case, allow the belt to retract completely and then carefully pull out only the amount of belt necessary to comfortably wrap around the seat occupant.

Slide the latch plate into the buckle until you hear a "click".



WARNING!


- Remember that, in the event of a violent impact, the passengers on the rear seats who are not wearing the seat belts are not only subject to personal injury but also represent a danger for passengers sitting in the front seats.
- Always fasten the seat belts.
- Travelling without the seat belts fastened significantly increases the risk of serious injury in the event of a collision, even with the air bags.
- In the event of a collision, the seat belts help reduce the possibility of the vehicle's occupants being thrown against the structures of the passenger compartment or out of the vehicle.
- The air bags are designed to work together with the seat belts, not to substitute them. The front air bags only deploy in the event of certain head-on collisions of sufficient intensity. They may not be activated if the vehicle rolls over, or in the event of rear bumps or minor frontal collisions, or non-frontal collisions.



Seat Belt for Rear Central Seat

Unlike all other seat belts, this one has two buckles and two metal latch plates; in this way it is possible to release it from the seat.

- Press the red button located on the front of the buckle using the free latch plate (step 1) and unlatch the plate from the left-side buckle (step 2).




- Allow the belt to retract completely into the retractor seat behind the seatback.

To buckle the seat belt proceed as follows:

- Take place in the central seat and pull out the belt (A) from the upper retractor in a normal manner, without twisting it;

- Insert the first latch plate located at the end of the shoulder portion of the belt (A) inside the left buckle (B);



- Pull out completely the tape part with the right buckle (C);



- Insert the latch plate located at the end of the lap portion of the belt (A) inside the right buckle (C).



WARNING!

The restraining action of the central belt is only possible with the tape part with the left and right buckle extracted from the seat cushion.

To unlatch the seat belt, release the right plate of the lap portion by clicking on the red button.

Using Seat Belt in Automatic Locking Retractor Mode (ALR)

Use the seat belt automatic locking mode anytime a child safety seat is installed in a seating position that has a belt with this feature.

Children up to 12 years old or under 1.5 m (5 ft) in height, should be properly buckled up in a child restraint system.

Automatic Locking Mode Setting

- Buckle the lap and shoulder belt.
- Grasp the shoulder portion and pull downward until the entire belt is extracted.
- Allow the belt to retract. As the belt retracts, you will hear a clicking sound. This indicates the safety belt is now in the automatic locking mode.



Automatic Locking Mode Unsetting

Unbuckle the three-point seat belt and allow it to retract completely to disengage the automatic locking mode and activate the vehicle emergency locking mode.



WARNING!

- The belt and retractor assembly must be checked by the Service Network and must be replaced if the Automatic Locking Retractor (ALR) feature or any other seat belt function is not working properly.
- Failure to replace the belt and retractor assembly could increase the risk of injury in collisions.

Seat Belt Pretensioners

The car is equipped with front seat belt pretensioners, that reduce slack in the belts in the event of a severe frontal impact. This guarantees the perfect adherence of the seat belts to the occupants bodies before the restraining action begins.

This car is also equipped with a second pretensioner in the kick plate area. Its activation is signalled by the

shortening of the metal cable and from its protective sheath curled.



Pretensioners work for all size occupant restraint systems, including the child restraint systems.

NOTE:

To obtain the highest degree of protection from the action of the pretensioning device, wear the seat belt tight to the chest and pelvis.

Pretensioners are triggered by the Occupant Restraint Controller (ORC). A pretensioner may be used only once. Pretensioners do not require any maintenance or lubrication: any changes to their original conditions will invalidate their efficiency. If, due to unusual natural events (floods, sea storms, etc.), the device has been affected by water and mud, it must be replaced.



WARNING!

It is strictly forbidden to remove or tamper with the pretensioner components. Any intervention must be carried out only by qualified and authorised personnel. Always contact the Service Network.




CAUTION!

Operations which lead to impacts, vibrations or localized heating (over 100°C/212°F for a maximum of 6 hours) in the area around the pretensioners may damage or deploy them erroneously. These devices are not affected by vibrations caused by uneven road surfaces or low obstacles. Contact the Service Network for any intervention that may be required.





Enhanced Seat Belt Use Reminder System (BeltAlert®)

BeltAlert® is a feature intended to remind the driver and front passenger to fasten their seat belts.

The feature activates with engine running. If the driver or front seat passenger is unbelted, the seat belt reminder light  will turn on in the instrument cluster.



The BeltAlert® warning sequence begins after the vehicle speed is over 8 km/h (5 mph) for more than 19 seconds, by blinking the seat belt reminder light  and by sounding an intermittent chime.

Once the sequence starts, it will continue for the entire duration. After the sequence completes, the seat belt reminder light  remain illuminated until the respective seat belts are fastened.

If the opened front door on the driver or passenger side is closed and the occupant presence sensor detects a status change from occupant not present to occupant present the system will repeat the warning sequence.

The driver should instruct all other occupants to fasten their seat belts. If a front seat belt is unbuckled while travelling at speeds greater than 8 km/h (5 mph), BeltAlert® will provide both audio and visual notification on the instrument cluster.

The front passenger seat BeltAlert® is not active when the front passenger seat is not occupied. BeltAlert® may be triggered when an animal or heavy object is on the front passenger seat. It is recommended to restrain pets in the rear seat, in pet harnesses or pet carriers that are secured by seat belts, and properly stow cargo.

Seat Belts and Pregnant Women

Seat belts should also be worn by pregnant women: the risk of injury in the event of an accident is greatly reduced for them and the unborn child if they are wearing a seat belt. The best way to protect the foetus is to protect the mother.

Pregnant women must position the lower part of the belt very low down so that it passes over the pelvis and under the abdomen (see figure).



When a safety belt is worn properly, it is more likely that baby will not be hurt in a crash. For pregnant women, as for anyone, the key to making safety belts effective is wearing them properly.



WARNING!

Pregnant women must scrupulously observe the above indications, as well as local regulation concerning the use of seat belts.



Supplemental Restraint System (SRS) — Air Bags


This vehicle has advanced front air bags for both the driver and front passenger as a supplement to the seat belt restraint systems.

The driver's advanced front air bag is mounted in the centre of the steering wheel in the area shown in the picture. On this area is embossed the word "SRS AIRBAG" for easier recognition.

The passenger's advanced front air bag is mounted in the dashboard, above the glove compartment in the area shown in the picture. On this area is embossed the word "AIRBAG" for easier recognition.

NOTE:

These air bags are certified to regulations for advanced air bags.



The advanced front air bags have a multistage inflator design. This allows the air bag to have different rates of inflation based on the severity and type of collision.

This vehicle may be equipped with a driver and/or front passenger seat belt buckle sensor that detects whether the driver or front passenger seat belt is fastened. The seat belt buckle sensor may adjust the inflation rate of the advanced front air bags.

This vehicle is equipped with Supplemental Side Air Bag Inflatable Curtains (SABIC) to protect the heads of front and rear outer occupants. The SABIC air bags are located above the side windows and their covers are also labeled "AIR bag".

This vehicle is also equipped with Supplemental Seat-Mounted Side Air Bags (SAB) for driver and passenger pelvis-chest-shoulder protection

during a side impact. The Supplemental Seat-Mounted Side Air Bags are mounted on front seats and are located in the outboard side of the front seats.

NOTE:

*After any accident, the vehicle should be taken to the **Service Network** immediately.*

Air Bag System Components

Your vehicle may be equipped with the following air bag system components:

- Occupant Restraint Controller (ORC);
- Air bag warning light on the instrument cluster;
- Steering wheel and column;
- Instrument cluster;
- Driver advanced front air bag;
- Passenger advanced front air bag;
- Supplemental Seat-Mounted Side Air Bags (SAB);
- Supplemental Side Air Bag Inflatable Curtains (SABIC);
- Front and side impact sensors;
- Front seat belt pretensioners and seat belt buckle switch;



- Pyrotechnical charge to cut power from the battery; it is located on the positive battery terminal.

Advanced Front Air Bags Properties

The advanced front air bag system has multistage driver and front passenger air bags. This system provides output appropriate to the severity and type of collision as determined by the Occupant Restraint Controller (ORC), which may receive information from the front impact sensors.

The first stage inflator is triggered immediately during an impact that requires air bag deployment. This low output is used in less severe collisions. A higher energy output is used for more severe collisions.



CAUTION!

- The electronic control unit provides for the activation of the pretensioners, front air bags or side air bags (front and rear) based on different criteria, according to the type of impact. Failure of one or more systems to activate is not indicative of a system malfunction.

- The front and/or lateral air bags may inflate if the vehicle suffers a violent impact involving the underbody area, for example in case of violent impacts against steps, sidewalks, speed bumps, or when the vehicle falls into potholes, or similar.



WARNING!

- **EXTREME HAZARD!**

Do not use a rearward facing child restraint on a seat protected by an air bag in front of it! Deployment of the air bag in an accident could cause fatal injuries to the baby regardless of the severity of the collision. Therefore, always release the passenger air bag when a rearward facing child restraint is installed on the passenger front seat. The front passenger seat must also be positioned back as far as possible in order to avoid the child restraint from coming into contact with the dashboard. Immediately reactivate the passenger air bag as soon as the child restraint system has been removed.

- Never put objects (e.g. mobile phones, toys, folders, tablets, etc..) on the passenger side of the dashboard since they could interfere

with correct inflation of the passenger air bag and also cause serious injury to the occupants.

- Do not put anything on or around the air bag covers or attempt to open them manually. You may damage the air bags and you could be injured because the air bags may no longer be functional. The protective covers for the air bag are designed to open only when the air bags are inflating.
- Always drive with your hands on the steering wheel rim, so that the air bag can inflate freely if required. During the drive your back must be as upright as comfort allows and be against the seat back with the seat belt properly fastened.
- Do not apply stickers or other objects on the steering wheel, on the dashboard in the passenger's side air bag area, on roof side trims or on the seats.
- Do not travel with objects in your lap, in front of your chest or especially with a pipe, pencil or other objects in your mouth. In the event of a collision, the intervention of the air bag could result in serious injury.



Passenger seat's front air bag and child restraint systems

Rearward-facing child seats must NEVER be used in the front seat of a vehicle with the front passenger air bag activated.

Deployment of the air bag in an accident could cause fatal injuries to the infant regardless of the severity of the collision.

NOTE:

ALWAYS refer to the instructions written on the label located on the passenger side sunshade and behind it.





1	REGIÃO INFANTE GRAVO MORTAL. I suggerito bambini del 11 massimo nel caso opposto a quello di morte non vanno considerati nel walk-around la presenza di un bag passeggero attivo.
00	DEATH OR SERIOUS INJURY CAN OCCUR. NEVER use a restraint being DMN present on a seat prepared by an ACTIVE AIRBAG in face of a DEATH or SERIOUS INJURY to the CHILD can occur
9	RISQUE DE MORT OU DE BLESSURES GRAVES NE PAS présenter le siège pour enfant devant une fenêtre, en cas d'un bag passager actif.
01	Fährbarnböring kann TOD oder SCHWERE VERLETZUNGEN zur Folge haben. Kleinere gebaute Kindersitzbelegungen (Babykinder) dürfen nicht in Verbindung mit aktivem Fährbarnböring auf dem Fährbereich verwendet werden
04	DITANAN DOOBUN ZÏN OF GRISTIGE ONVLUKKEKEN KEROCCAZIEN. Plaas het kindersitje niet vóór het raam op de voorste passagier of een airbag aanwezig is.
05	TRUCCO OCCAZIONALE MURTE O HERIDAS GRAVES, NO utilizar el sistema para niños en sentido inverso a la marcha en el asiento delantero o behind an bag active full passenger.
06	PODRIE GROSZE SZERCIALNE LUB CIĘZKIE OBRAZOWANIA NIE WOLNO umieszczać fotelika dziecięcego tyłem do kierunku jazdy na przednim siedzeniu w przegubie sterowanym aktywnie podczas prowadzenia pojazdu
08	OLUK WVA ADR BIKKZE TANALANPAID ZSEPP OLAKLIK. Nincs utólagi üvöltésű kocsik kocsijára amsz, gilyk székere nem felel meg a gyermekülésnek.
0C	NARE FOR DODUOLIE KVIESTELUM DIO LAVTILUENDE BRADUR. Pluss, siting en bagdramm berennet på passagerenses, her passager settesen en iokkelt et en nero akter setet.
0E	TALGJÁRÁSOK VÁRAJÓ DARA TÖRÖKÖI KÉPVAGYALUJÓI VÖI ÖLMEI. Turistákú utasoknál kényel legy utólagi üvöltésű kocsijára nem szabad ültetni a gyerekeket.
0F	KUOLEHMANNARA TAI VAKAVEN VAKPHEJEN LAKKA. Äls barna bane varvörstilla nån, ett bag en aktiv motorstyrning kan medföra ett stort risk för dödsfall
0	RISCO DE MORTE OU FERIMENTOS GRAVES. Não posicione o banco para criança para frente dentro do sentido de marcha do veículo quando o sistema de passageiros estiver ativo.
0T	GAJI ŠTAKI HIRTS MIBA GALTE RINTASUŠIŠTĪ. Niekāds bērns nedrīkst sēdēt uz priekšu (pretīmi) automaībā aktīvajā režīmā, kur ir redzams kārtava drošības
0	KAN VARA UNVHOFANDE ELLEN LEM TEL ALVAREIGA BRADOR. Plussu siting en bakværd berennet i ferntatid di passagerenses brokkeltid i styt
0	HMAJON WAGY MGYVA MALEST NÖHETKÉZNET BE. Ne helyezze a gyermekülést a motorvezérlés alatt, ha az aktív oldalon ültetést előltek
0Y	VAR IZBAŠTĪ HĀVI VAI NĀPĒTĪNAS TRĀPMAS. Niekāds bērns nedrīkst sēdēt priekšējos sēdekus, ja pasākums ir aktīvs, un ir atzīmēta gājē spēks
0Z	PROZÍ NEEZÉKCI VÁZŃHO VILÉJENŃVA. ZPRAVÍ NEDO KOKONCE ŠMŤI. Nemzetileg öltözött utasok is utólagi üvöltésű kocsikba is ültethetők, ha a kocsiban aktív oldalon ültetést előltek.
0A	LAHKO PRIDE DO ŠTITAJI HJŠTĚR PÖRÖČE. Dovoljeno umestiti dijete na prednja + strana sjedala u slučaju aktivnog sistema za zaštitu od sudara.
0B	SI POGAT PRODUCE OCESELA SAU LEZVANI GRAVE. Ne apstāt avarid di maģid jektu bērnēg, ir jāpārē nerēvēti ātrēst di mar unēdi idēi atēgali pasēgēni ner aktīvi.
0C	TRIGERI NA VPOK-ONVOSTA NĀKATZĒ H ZORANA TRĀVNĀTA. Ne nosēdēt uz priekšu (pretīmi) automaībā aktīvajā režīmā, kur ir redzams kārtava drošības
0D	IMBI OLAONDOT OF OMLPT H OPRVONH NĀFANPĀNĀNE. Ne nosēdēt uz priekšu (pretīmi) automaībā aktīvajā režīmā, kur ir redzams kārtava drošības
0E	PODRIE TRĀSTĀT ŠMŤI ALBO VÁZNE ZHĀVĚNĀ. Niekāds bērns nedrīkst sēdēt priekšējos sēdekus, ja pasākums ir aktīvs, un ir atzīmēta gājē spēks
0F	TRĀPMAS H VĚTĚVĀNĀJ OČOVĚJ. Dovoljeno umestiti dijete na prednja + strana sjedala u slučaju aktivnog sistema za zaštitu od sudara.
0H	OPĀNĀST OD ŠTĚRĀ H VĀTŤOVONH OČOVĚJ. Niekāds bērns nedrīkst sēdēt priekšējos sēdekus, ja pasākums ir aktīvs, un ir atzīmēta gājē spēks



Supplemental Air bags

Supplemental Seat-Mounted Side Air Bags (SAB)

Supplemental Seat-Mounted Side Air Bags (SAB) protect the pelvis, chest and shoulder area of the occupants in the event of a side impact of medium/high severity. The SAB is marked with "AIRBAG" label sewn into the outboard side of the front seats.



When the air bag deploys, it opens the seam between the front and side of the seat's trim cover. Each air bag deploys independently; a left side impact deploys the left air bag only and a right side impact deploys the right air bag only.

Supplemental Side Air Bag Inflatable Curtain (SABIC)

SABIC air bags are designed to protect the head of front and rear occupants in the event of a side impact, thanks to the wide cushion inflation surface. Each air bag features inflated chambers placed adjacent to the head of each outboard occupant that reduce the potential for side-impact head injuries. The SABICS deploy downward, covering both windows on the impact side.



WARNING!

- Side air bags also need room to inflate. Do not rest your head, arms or elbows on the door, windows or the area in which the window bag is located to avoid possible injury during air bag inflation. Sit upright in the centre of the seating area.
- Do not cover the front seatbacks with clothes or covers. Do not use accessory seat covers or place objects between you and the side air bags; the performance could be adversely affected and/or objects could cause serious injury.
- Do not add roof racks that require permanent attachments (bolts or

screws) for installation on the vehicle roof. Do not drill into the roof of the vehicle for any reason.

Air Bag Deployment Sensors and Controls

Occupant Restraint Controller (ORC)

The Occupant Restraint Controller (ORC) determines if deployment of the front air bags and/or side air bags in a frontal or side collision or rollover event is required. Based on the impact sensor's signals, a central electronic ORC deploys the advanced front air bags, SABIC and SAB air bags, and front seat belt pretensioners, as required, depending on the severity and type of impact. On top of what previously described, the characteristics of the collision registered by the sensors and sent to the control unit of the ORC can also cause a sudden cut of the power from the battery, "blowing" the pyrotechnical charge located on the positive battery terminal.



CAUTION!

After a collision that has caused the blowing up of the pyrotechnical


(Continued)



(Continued)
charge, this must be replaced at a Service Network.

Advanced front air bags are designed to provide additional protection by supplementing the seat belts in certain frontal collisions depending on the severity and type of collision. Advanced front air bags are not expected to reduce the risk of injury in rear, side, or rollover collisions. The advanced front air bags will not deploy in all frontal collisions, including those that may produce substantial vehicle damage, for example, some pole collisions, truck under rides, and corner impacts. On the other hand, depending on the type and location of impact, advanced front air bags may deploy in crashes with little vehicle front-end damage but that produce a severe initial deceleration. The side air bags will not deploy in all side collisions. Side air bag deployment will depend on the severity and type of collision. Because air bag sensors measure vehicle deceleration over time, vehicle speed and damage merely are not good indicators of whether or not an air bag should have deployed.

Seat belts are necessary for your protection in all accidents, and also are needed to help keep you in position, away from an inflating air bag. The ORC monitors the readiness of the electronic parts of the air bag system whenever the ignition switch is in the **RUN** position. If the ignition switch is in the **OFF** position, in the **ACC** position, or not active, the air bag system is not activated and the air bags will not inflate.

The ORC contains a backup power supply system that may deploy the air bags even if the battery has low power or it becomes disconnected prior to deployment. When starting the vehicle, ORC turns on the air bag warning light  on the instrument cluster for approximately 4 to 8 seconds for a test.

After the test, the air bag warning light will turn off. If the ORC, during the diagnosis phase detects a malfunction that could affect the air bag system, it turns on the air bag warning light and the "Service Airbag System" message either momentarily or continuously. The diagnostics also record the nature of the malfunction. A beep will sound if the light illuminates again after initial startup.



The air bag warning light monitors the internal circuits and interconnecting wiring associated with air bag system electrical components.



WARNING!

- The air bags may also be deployed when the car is not moving, if the ignition switch is in RUN position and the engine is off, if the car is hit by another moving vehicle. Therefore, even if the car is stationary, when an active passenger air bag is fitted, DO NOT install on the passenger seat child restraint systems to be fitted rearward facing on the front seat. Deployment of the air bag following an impact could cause fatal injuries to the child. Therefore, always deactivate the passenger air bag (see "Passenger's



Air bag Deactivation (if foreseen)" in this section) when a rearward facing child restraint is installed on the passenger front seat. The front passenger seat must also be positioned back as far as possible in order to avoid the child restraint from coming into contact with the dashboard. Immediately reactivate the passenger air bag as soon as the child restraint system has been removed. Also remember that, if the ignition switch is in OFF, ACC position or off, none of the safety devices (air bags or pretensioners) will be deployed in the event of collision. Non-deployment of these devices does not indicate a system malfunction.

- **Ignoring the air bag warning light and message in your instrument cluster could mean you won't have the air bags to protect you in a collision. If the light does not come on as a bulb check when the ignition is first turned on, stays on after you start the engine, or if it comes on as you drive, have an authorised Maserati Service Centre service the air bag system immediately.**

Front Air Bag Inflator Units

When the ORC detects a collision requiring the advanced front air bags, it signals the inflator units. A large quantity of non-toxic gas is generated to inflate the advanced front air bags. The steering wheel hub trim cover and the upper right side of the dashboard separate and fold out of the way as the air bags inflate to their full size. The air bags then quickly deflate while helping to restrain the driver and front passenger. The advanced front air bag gas is vented through the vent holes in the sides of the air bag. In this way, the air bags do not interfere with your control of the vehicle.

Supplemental Seat-Mounted Side Air Bag (SAB) Inflator Units

The ORC unit determines if a side collision requires the side air bags to inflate, based on the severity and type of collision. Based on the severity and type of collision, the side air bag inflator on the crash side of the vehicle may be triggered, releasing a quantity of non-toxic gas. The inflating SAB exits through the seat seam into the space between the occupant and the door. The side air bag moves at a very high speed and with such a high force that it could

injure you if you are not seated properly, or if items are positioned in the area where the side air bag inflates. This especially applies to children.

Supplemental Side Air Bag Inflatable Curtain (SABIC) Inflator Units

During collisions where the impact is confined to a particular area of the side of the vehicle, the ORC may deploy the SABIC air bags, depending on the severity and type of collision. In these events, the ORC will deploy the SABIC only on the impact side of the vehicle. A quantity of non-toxic gas is generated to inflate the side curtain air bag.

The inflating side curtain air bag pushes the head/s of the occupant/s seating in the outside seats from the edge of the headliner out of the way and covers the window. The air bag inflates with enough force to possibly injure you if you are not belted and seated properly, or if items are positioned in the area where the side curtain air bag inflates. This especially applies to children.

The SABICs may also help reduce the risk of partial or complete ejection of vehicle occupants through side windows in certain rollover events



(because equipped with rollover sensing).

Front and Side Impact Sensors

In front and side impacts, impact sensors can aid the ORC in determining appropriate response to impact events.

Enhanced Accident Response System

In the event of an impact causing air bag deployment, if the communication network and the power remains intact, depending on the nature of the event, the ORC will determine whether the enhanced accident response system will have to perform the following functions:

- cut off fuel to the engine;
- turn hazard lights and interior lights on as long as the battery has power or until the ignition switch is turned off;
- unlock the doors automatically;
- disconnect the battery with a pyrotechnic charge.

Air Bag Deployment Result

The advanced front air bags are designed to deflate immediately after deployment.

If you do have a collision which deploys the air bags, any or all of the following may occur:

- The nylon air bag material may sometimes cause abrasions and/or skin reddening to the driver and front passenger as the air bags deploy and unfold. They are not caused by contact with chemicals. They are not permanent and normally heal quickly. However, if you haven't healed significantly within a few days, or if you have any blistering, see your doctor immediately.
- As the air bags deflate, you may see some smoke-like particles. The particles are a normal by-product of the process that generates the non-toxic gas used for air bag inflation. These airborne particles may irritate the skin, eyes, nose, or throat. If you have skin or eye irritation, rinse the area with cool water. For nose or throat irritation, move to fresh air. If the irritation continues, see your doctor. If these particles settle on your clothing, follow the garment manufacturer's instructions for cleaning. Do not drive your vehicle after an air bag has deployed. If you are involved in another collision, the air bags will not be in place to protect you.



ENVIRONMENTAL!

Air bag inflation releases a small amount of powder. This powder is not harmful for the environment.



WARNING!

- Deployed air bags and seat belt pretensioners cannot protect you in another collision. Have the air bags, seat belt pretensioners, and the front seat belt retractor assemblies replaced by a Maserati Service Centre. Also, have the Occupant Restraint Controller (ORC) system serviced as well.
- Have the air bag checked, serviced and replaced only by the Service Network.

Air Bag System Maintenance



WARNING!

- Modifications to any part of the air bag system could cause it to fail when you need it; thus you could be injured if the air bag system is not there to protect you. Do not modify



the components or wiring. Do not modify the front bumper, vehicle body structure, or add aftermarket side steps or running boards.

- It is dangerous to try to repair any part of the air bag system without the necessary know-how.
- Do not attempt to modify any part of your air bag system. The air bag may inflate accidentally or may not function properly if modifications are made. Take your vehicle to the Service Network for any air bag system service. If your seat including your trim cover and cushion needs to be serviced in any way (including removal or loosening/tightening of seat attachment bolts), take the vehicle to the Service Network.
- Only Maserati manufacturer approved seat accessories may be used. If it is necessary to modify the air bag system for persons with disabilities, contact the Service Network.
- If the speedometer, tachometer, or any engine related gauges are not working, the Occupant Restraint Controller (ORC) may also be disabled. The air bags may not be ready to inflate for your protection. Promptly check the fuse block for

blown fuses. To identify the air bag fuse see "Fuse Replacement" in section "Maintenance and Care". See the Service Network if the fuse does not fix the problem.

Passenger's Air bag Deactivation (if foreseen)


If you have to carry a child on the front passenger seat, always deactivate the air bag on the passenger's side before installing a rearward-facing child seat. To deactivate the air bag, open the menu "Vehicle Settings" and skip to "Passenger Airbag" (see "Instrument Cluster" in section "Dashboard Instruments and Controls"). The passenger air bag is normally activated (ON).



With the switch pressed in the ▼ arrow direction select option "OFF"

and confirm by pressing the switch (▶).




Confirm the selection by pressing the switch (▶): a confirmation box will prompt user to select "Yes" or "No". Select "No" to go back to previous selection screen. Select "Yes" to confirm deactivation: the  symbol will display for 2 seconds with the corresponding message.





Before Starting


The air bag light  will illuminate on the instrument cluster display and on the overhead console.



The display will then return to the "Vehicle Settings" menu. In order to activate the passenger air bag follow the same procedure by selecting "ON" option on menu.



CAUTION!

Should the warning light  (passenger's air bag off) malfunction, its failure will be shown on the display. Deactivation of the front passenger air bag does not deactivate the other air bags and the seat belt.



WARNING!

We recommend you to always fit any child seats on the rear seat, as this is the safest position in the event of a collision.

When the passenger side air bag is deactivated the passenger seated on the front seat will not have the additional protection of the air bag in the event of a collision.

Only deactivate the air bag when you are carrying a person considered at risk, and always reactivate it at the end of transportation.

Transport of persons with disability

If it is necessary to modify the advanced air bag system of your vehicle to accommodate a person with disabilities, contact the **Service Network**.



WARNING!

- The advanced air bag system of your vehicle is not designed to protect adults with disabilities that require deactivation of the passenger or driver air bag.



- If you or another occupant is an adult with a medical condition that requires air bag deactivation, please contact the Service Network.
- Persons with disabilities are advised not to travel in the front seat in order to avoid the risk of serious injuries or death, even in minor crashes.

Child Restraint Systems

Everyone in your vehicle needs to be buckled up all the time, including babies and children. This prescription is compulsory in all EC countries according to EC Directive 2003/20/EC. Children up to 12 years old or under 1.5 m (5 ft) in height, must be properly buckled up in a child restraint system. According to crash statistics, children are safer when properly restrained in the rear seats rather than in the front.

NOTE:

All states have legislation governing how and where children should be carried in a vehicle. Please check the regulations existing in your state.



WARNING!

- **EXTREME HAZARD!**
Do not use a rearward facing child restraint on a seat protected by an air bag in front of it! Deployment of the air bag in an accident could cause fatal injuries to the baby regardless of the severity of the collision.
- If the passenger's air bag is deactivated always check the

warning light on the instrument cluster to make sure that it has actually been deactivated.

- **Never carry children on your lap, not even newborns. No one can restrain a child in the event of an accident.**
- **Every child has to use one child restraint system; never carry two children using only one child seat.**
- **In case of accident, replace the child seat with a new one.**

The choice of the most suitable child restraint system depends on the weight of the child. There are different types of child restraint systems. Always refer to the manual provided with child seat to ensure it is the proper type according to the travelling child.

In Europe the child restraint systems prescriptions are defined by European Standard ECE-R44.

Child restraint systems are classified into five weight groups:

- Group 0: up to 10 kg (up to 22 lb) weight;
- Group 0 +: up to 13 kg (up to 29 lb) weight;
- Group 1: 9 - 18 kg (20 - 40 lb) weight;



- Group 2: 15 - 25 kg (33 - 55 lb) weight;
- Group 3: 22 - 36 kg (49 - 79 lb) weight.

All restraint devices must bear the approval data, with the control mark on a label firmly secured to the child seat which must never be removed. Over 1.5 m (5 ft) in height, from the point of view of restraint systems, children are considered as adults and wear the seat belts normally.

Group 0 and 0+ Child Restraint Systems

Babies up to 13 kg (29 lb) must be carried with rearward-facing seats, which, supporting the head, do not induce stress on the neck in the event of sharp decelerations.

These child restraint systems are fixed to the car by the three-point seat belt or by the Isofix anchorages. Check "Installing Child Restraint Systems using the Vehicle Seat Belt equipped with ALR" or "Isofix Universal Child Restraint System" in this chapter for further information.

NOTE:

For Group 0/0+ Semi Universal Isofix child restraint system are available, always check the manual to ensure the car seat is approved for your specific vehicle.



WARNING!

Rearward-facing child seats must never be used in the front seat of a vehicle with the front passenger air bag activated. An air bag deployment could cause severe injury or death to infants in this position.

Group 1 Child Restraint Systems

Children with weight between 9 kg to 18 kg (20 lb to 40 lb) may use forward facing seats.

These child restraint systems are fixed to the car by the three-point seat belt or by the Isofix anchorages. Check "Installing Child Restraint Systems using the Vehicle Seat Belt equipped with ALR" or "Isofix Universal Child Restraint System" in this chapter for further information.

NOTE:

Regardless of the type of child restraint, always check that the seat belt is well fastened by pulling on it.





Group 2 Child Restraint Systems

Children from 15 kg to 25 kg (33 lb to 55 lb) may use the car seat belts directly. These child restraint systems are fixed to the car by the by the three-point seat belt or by the Isofix anchorages. Refer to "Installing Child Restraint Systems using the Vehicle Seat Belt equipped with ALR" or "Isofix Universal Child Restraint System" in this chapter for further information.

This type of child seat is featured to position the child correctly towards the belts so that the diagonal section crosses the child's chest and not its neck, and the lower part is snug on the pelvis and not on the abdomen. Always check that the seat belts do not restrain the child's throat.



Group 3 Child Restraint Systems

For children with weight between 22 kg to 36 kg (49 lb to 79 lb) devices are available to position the seat belt correctly.

- Make sure that the child is upright in the seat.
- The lap portion must adhere to the pelvis and as snug as possible.
- Check belt fit periodically. A child's squirming or slouching can move the belt out of position.
- Always check that the seat belts do not restrain the child's throat.
- Never allow a child to put the shoulder belt under an arm or behind their back.

Over 1.50 m (5 ft) in height children can wear seat belts like adults.



WARNING!

Improper installation leads to failure of an infant or child restraint. It could come loose in a collision. The child could be badly injured or killed. Follow the child restraint manufacturer's directions exactly when installing a child restraint system.

Some Tips on getting the most out of your Child Restraint

- Before buying any child restraint system, make sure that it has a label certifying that it meets all applicable Safety Standards. Maserati recommends that you make sure that you can install the child restraint system in the vehicle where you will use it before you buy it.
- The child restraint systems choice must be appropriate for your child's weight.
- Carefully follow the instructions that come with the child restraint system. If you install the child restraint system improperly, it may not work when you need it.
- Fit the child into the seat according to the child restraint manufacturer's directions.



WARNING!

When your child restraint system is not used, secure it in the vehicle with the seat belt or remove it from the vehicle. Do not leave it loose in the vehicle. In a sudden stop or accident, it could strike the occupants or seatbacks and cause serious personal injury.

Suitability of Passenger Seats for Universal Child Restraint System Use

According to the European Directive 2003/20/EC the suitability of each passenger seat position for the fixing of universal child restraint systems is shown in the following table:

Group	Front passenger seat	Outer rear seats	Central rear seat
0 Up to 10 kg / 22 lb	U (*)	U	X
0+ Up to 13 kg / 29 lb	U (*)	U	X
1 9–18 kg / 20–40 lb	U (*)	U	X
2 15–25 kg / 33–55 lb	U (*)	U	X
3 22–36 kg / 49–79 lb	U (*)	U	X

U = Child seat category "Universal". A child seat designed for fastening on the seat with the seat belt.

(*) = The seat should be adjusted.


X = Central rear seat isn't suitable to fix any type of Universal Child restraint system.



Summary of Children Safety Transporting Regulations:

Children up to 12 years old or under 1.50 m (5 ft) may only travel if secured, using adequate child restraint systems. We recommend to always fit any child restraint system on the rear seats outer, as this is the safest position in the event of a collision. Do not fit any CRS on rear centre seating position.

If the vehicle is equipped with active passenger air bags, do not place rearward-facing infant seats on front seat.

When deactivating the passenger-side air bag, always check the illumination of the warning light  in the TFT display of the instrument cluster and on the overhead console, indicating the air bag has been deactivated (see “Supplemental Restraint System (SRS) — Air bags” in this section).

Strictly follow the instructions which the manufacturer is obliged to provide with the child restraint system.

Keep the instructions in the vehicle together with the documents and this owner’s manual. Do not use a child restraint system which does not comprehend any instructions for use.

Installing Child Restraint Systems using the Vehicle Seat Belt equipped with ALR

The passenger seat belts are equipped with an Automatic Locking Retractor (ALR) to secure child protection through a Child Restraint System (CRS). These types of seat belts are designed to keep the lap portion of the seat belt tight around the child restraint seat avoiding to use a locking clip.

The ALR will make a ratcheting noise if the entire belt is pulled out of the retractor in order to enable the belt retracting subsequently. For additional information on ALR, see “Using Seat Belt in Automatic Locking Retractor Mode (ALR)” in “Occupants Restraint Systems” in this section.

To install a Child Restraint System with ALR, pull enough of the belt out of the retractor leading it through the belt path of the protection device. Slide the latch into the buckle until it clicks. Remove then the entire safety belt from the retractor in order to rewind. While rewinding a click will indicate the safety belt is now in Automatic Locking mode. Exert then a traction on the exceeded lap section of the belt in order to

tighten it around the child restraint seat. All seat belts will loosen over time, it is therefore necessary to check them periodically and set them properly.

Isofix Universal Child Restraint System


Your vehicle's side rear seats are all equipped with Isofix anchorages. The Isofix Universal system allows the child restraint systems to be fixed without using the vehicle's seat belts, instead fixing the child restraint system to the vehicle structure, using lower anchorages **A** and upper tether strap **B**.





NOTE:

Remember that when using a Isofix Universal child seat, you can only use approved child seats with the marking ECE R44 "Isofix Universal" (03 release or post) (see the example in the figure).



Isofix Universal child restraint systems are now available. You should never install Isofix Universal child seats so that two seats share a common lower anchorage.

If your child restraints are not Isofix Universal, install the restraints using the vehicle's seat belts.

Installing an Isofix Universal Child Restraint System

Follow the child restraint manufacturer's instructions provided with the child restraint system.


The lower Isofix anchorages are "U" metal rings located on the rear seat where the cushion meets the seatback and are located just below the symbol shown in the picture, but are not visible. You will easily feel them if you run your finger along the intersection of the seatback and seat cushion surfaces.



NOTE:

- To correctly install a child restraint system on the rear seats, position the seat back in the less tilted position (see chapter "Rear seats" in section "Understanding the Vehicle").
- On the vehicles of Australian market the top tether strap anchorage behind the central rear seat should be used to secure a child restraint system with the vehicle's seat belts.

Top tether strap anchorages are placed behind the backrest of the rear seats.



Such anchorages can be reached pushing down or lifting the foldable end of the boot compartment cover.



To fix an Isofix Universal Child seat for weight group 1 proceed as follows.

- Secure the child seat to the "U" lower metal rings positioned on the rear seat.



Fix the end of the upper belt, also called Top Tether (provided with the child seat), to the attachment located behind the backrest.

- Lift the headrest.
- Route the top tether to provide the most direct path between the anchorage behind the backrest and the child restraint system passing it between the slide rods of the headrest.



- Tighten upper strap until you reach the tension level recommended by the restraint system manufacturer.
- Fully lower the headrest.

NOTE:

- The other weight groups are covered by specific Isofix child seats, which can be used only if specifically tested for this car (see list of cars provided with the child seat).

- For any further details on installation and/or use, refer to the instructions provided with the child seat.



WARNING!

- Fit the child seat when the car is stationary. The child seat is correctly fixed to the anchorages when hearing a click. Follow the instructions for assembly, disassembly and positioning that the manufacturer must supply with the child restraint system.
- An incorrectly anchored tether strap could lead to increased head motion and possible injury to the child. Use only the anchor position directly behind the child seat to secure a child restraint top tether strap.

NOTE:

- Ensure that the tether strap does not slip into the opening between the seatbacks as you remove slack in the strap.
- When using an Isofix child restraint system, please ensure that all seat belts not being used for occupant

restraints are stowed and out of reach of children.



WARNING!

- Improper installation of a child restraint system to the Isofix anchorages can lead to failure of an infant or child restraint. The child could be badly injured or killed. Follow the child restraint manufacturer's directions exactly when installing an infant or child restraint system.
- Child restraint anchorages are designed to withstand only those loads imposed by correctly fitted child restraints. Under no circumstances are they to be used for adult seat belts, harnesses, or for attaching other items or equipment to the vehicle.



Suitability of Passenger Seats for Isofix Child Restraint System Use

The table below shows the various installation possibilities for Isofix child restraint systems on seats fitted with Isofix anchorages in accordance with European standard ECE 16.

2

Group	Size category of the child seat (*)	Front passenger seat	Outer rear seats	Central rear seat
0 Up to 10 kg / 22 lb	E	X	IL	X
0+ Up to 13 kg / 29 lb	E	X	IL	X
	D	X	IL	X
	C	X	IL (**)	X
1 9–18 kg / 20–40 lb	D	X	IL	X
	C	X	IL (**)	X
	B	X	IUF, IL	X
	B1	X	IUF, IL	X
	A	X	IUF, IL	X

(*) = The size category is shown on the label attached to the child seat.

(**) = It is necessary to make adjustments on the corresponding front seat.

IL = The seat is suited for installation of an Isofix child seat with the "Semi Universal" approval. The Category "Semi Universal" means that the child seat with the Isofix system is approved for your vehicle. Observe the information in the list of vehicles which comes with the child seat.

IUF = The seat is suitable for the installation of an Isofix child seat with the approval "Universal" and attachment with the Top Tether belt.

X = The seat is not fitted with Isofix systems.



Maserati Recommended Child Restraint Systems for this Vehicle

NOTE:
Please check the availability of the Child Seats for your Country.

“Maserati Genuine Accessories” makes available a complete range of child restraint systems that can be fixed using the vehicle seat belts or through the Isofix anchorages.

<p>Group: 0+ (Up to 13 kg / 29 lb)</p>	 <p>Maserati Peg Pèrego Primo viaggio SL</p>	 <p>Maserati Peg Pèrego Isofix K Base</p>	 <p>Maserati Peg Pèrego Primo viaggio SL</p>
	<p>Approval Number with Isofix Basement: E24 040089 Isofix/Semi-Universal child seat. This seat can only be installed in rear-facing position using the related Isofix basement (to be purchased separately) and the Isofix anchorages on rear outboard seat. Maserati recommends this seat for this weight group.</p>		<p>Approval Number: E24 040088 Universal child seat. This seat can only be installed in rear-facing position using the vehicle seat belts (it can also be used together with the “Maserati Peg Pèrego Pushchair”).</p>



2

Group: 1
(9 – 18 kg / 20
– 40 lb)



Maserati Peg Pèrego Viaggio 1 Duo-Fix



Maserati Peg Pèrego Isofix K Base



Maserati Peg Pèrego Viaggio 1 Duo-Fix

Approval Number with Isofix Basement: E24 040058
Isofix child seat.
To be installed in forward-facing position using the related basement Isofix K (to be purchased separately) and the Isofix anchorages on rear outboard seat.

Approval Number: E24 040057
Universal child seat.
To be installed in forward-facing position using the vehicle seat belts.

Group: 2, 3
(15 – 36 kg / 33
– 79 lb)




Maserati Peg Pèrego Viaggio 2-3 Surefix

Universal Approval Number: E24 040070
Semi-Universal Approval Number: E24 040071
This seat can only be installed in forward-facing position using the vehicle seat belts and, optionally, the Isofix anchorages on rear outboard seat.

**WARNING!**

Maserati recommends to install the child seat according to the manufacturer's directions that must be supplied with it.

Important Safety Notice for Transporting Children

- Install the child seat on the rear seat as this is the safest position in case of collisions.
 - Use the seat in the rear-facing position as long as possible, if possible until the child is 3-4 years old.
 - When deactivating the front passenger air bag (for versions/markets, where provided), make sure that the  light stays On on the TFT display and on the overhead console to indicate the correct deactivation.
 - Keep the instructions in the vehicle together with the documents and this owner's manual. Do not use a child restraint system which does not provide any instructions for use.
 - Every child has to use one child restraint system; never carry two children using only one child seat.
- If using the vehicle seat belt, always check that the belt does not restrain the child's throat.
 - Firmly pull the seat belt to check that it is correctly buckled.
 - Never allow a child to seat improperly or to unbuckle the seat belt while driving.
 - Never allow a child to wear the shoulder portion of the belt under the arms or behind the back.
 - Never carry children on your lap, not even newborns. No one can restrain a child in the event of an accident.
 - In case of accident, replace the child seat with a new one.

Transporting Pets

Air bags deploying in the front seat could harm your pet. An unrestrained pet will be thrown about and possibly injured, or injure a passenger during panic braking or in an accident. Pets should be restrained in the rear seat in pet harnesses or pet carriers that are secured by vehicle seat belts.



Park Assist (optional)

The Park Assist (also called "ParkSense") system provides visual and audible indications of the distance between the rear and/or front bumper and a detected obstacle when backing up or moving forward, e.g. during a parking manoeuvre.

Besides the use of the sensors available on the bumpers and of the rear parking camera, the vehicle may be equipped with surround view cameras (optional) to assist the driver during manoeuvres on dead-ends/roads and on intersections. For more details on this option, see chapter "Surround View Camera System (optional)" in this section.

Refer to "Park Assist System Usage Precautions" for limitations of this system and recommendations.

Park Assist system will retain the last system state (enabled or disabled) from the last ignition cycle when the ignition is changed to the **RUN** position.

Park Assist system can be active only when the shift lever is in R (Reverse) or D (Drive).

If Park Assist is enabled at one of these shift lever positions, the system will remain active until the vehicle speed is

increased to approximately 12 km/h (7.5 mph) or above. The system will become active again if the vehicle speed is decreased to speeds less than approximately 10 km/h (6.2 mph).

Park Assist Sensors

The four Park Assist sensors, located in the rear bumper, monitor the area behind the vehicle that is within the sensor's field of view. The sensors can detect obstacles up to approximately 200 cm (78 in) from the rear bumper in the horizontal direction, depending on the location, type and orientation of the obstacle.



The six Park Assist sensors, located in the front bumper, monitor the area in front of the vehicle that is within the sensor's field of view.

The sensors can detect obstacles up to a distance of approximately 120 cm (50

in) from the front bumper in the horizontal direction, depending on the location, type and orientation of the obstacle.



Park Assist Warning Messages Display

The Park Assist Warning screen will only be displayed if "Sound + Display" is selected from the MTC+ System. Refer to "MTC+ Settings" in section "Dashboard Instruments and Controls" for further information.

The Park Assist Warning screen is located on the instrument cluster display.

It provides visual warnings to indicate the distance between the rear bumper and/or front bumper and the detected obstacle.

The warning display will turn on indicating the system status (ready or off) when the vehicle is in R (Reverse)



or in D (Drive) and an obstacle has been detected.

The detection area in front of the vehicle is divided into two parts with four arcs while the two detection areas behind the car into five arcs. The system will indicate a detected obstacle by displaying arcs with fixed or flashing light and a characteristic sound according to the obstacle distance. The colour indicates the distance and the arc indicates the position of the detected obstacle. The green colour of the outer arc indicates the maximum distance, the amber colour of the middle arcs indicates the medium distance, while the red colour of the nearest arc indicates the minimum distance.



As the vehicle moves closer to the object the instrument cluster will display the arc moving towards the vehicle and the sound tone will change from single to slow, to fast and to continuous.

The vehicle is close to the obstacle when the instrument cluster displays one flashing red arc only, combined with a continuous sound.



The following charts show the warning alert visualization when the system is detecting an obstacle.

2

Front Sensors - Warning Alerts					
Front distance	More than 120 cm (50 in)	120-101 cm (50-40 in)	100-61 cm (40-24 in)	60-31 cm (23.6-12.2 in)	Less than 30 cm (12 in)
Audible Alert	None	None	Slow	Fast	Continuous
Arc in left and right areas	None	4 th	3 rd	2 nd	1 st (inner most)
Type light	None	Solid	Solid	Flash	Flash
Arc colour	-	Green	Amber	Amber	Red
Radio sound	Active	Active	Mute	Mute	Mute

Rear Sensors - Warning Alerts						
Rear distance	More than 200 cm (78 in)	200-151 cm (78-59.4 in)	150-101 cm (60-40 in)	100-61 cm (40-24 in)	60-31 cm (23.6-12.2 in)	Less than 30 cm (12 in)
Audible Alert	None	Single	Slow	Slow	Fast	Continuous
Arc in left and right areas	None	5 th	4 th	3 rd	2 nd	1 st (inner most)
Type light	None	Solid	Solid	Solid	Flash	Flash
Arc colour	-	Green	Amber	Amber	Amber	Red
Radio sound	Active	Mute	Mute	Mute	Mute	Mute



NOTE:

Park Assist will turn off the front park assist audible alert (chime) after approximately 4 seconds when an obstacle has been detected, the vehicle is stationary, and brake pedal is applied.

Enabling and Disabling Park Assist

By accessing the submenu "Safety & Driving Assistant" from MTC+ System, the "Park Assist" can be disabled (option "Off"). The available options regarding the warning alerts are: "Sound" or "Sound + Display". Refer to "MTC+ Settings" in section "Dashboard Instruments and Controls" for further information. The front sensors can be enabled or disabled at any time by pressing the button on the front dome console.



After pressing the button the instrument cluster will display the state of front parking sensors for approximately five seconds. The button LED will be on when the front sensors are disabled. The button LED will be off when the front sensors are enabled. If the button is pressed and the system requires service, the LED will blink momentarily, and then the LED will be on.

When the shift lever is moved to R (Reverse) or to D (Drive) at a speed of 11 km/h (7 mph) or below and the system is disabled, the instrument cluster will display the "PARK ASSIST Off" message for 5 seconds until the shift lever remains in R (Reverse) or when the shift lever is moved in D (Drive).

Service the Park Assist System

In case of malfunction of the Park Assist system, the instrument cluster will actuate a single sound, once per ignition cycle. The instrument cluster will display a message when any of the rear or front sensor(s) are blocked by snow, mud, or ice and the vehicle is shifted into R (Reverse) or D (Drive). The instrument cluster will display a message when any of the rear or front sensors are damaged and require service.

When the shift lever is moved to R (Reverse) or D (Drive) and the system has detected a faulted condition, the instrument cluster will display the corresponding message for the time lapse the vehicle is in R (Reverse) or D (Drive) at speeds less than 11 km/h (7 mph). Under this condition Park Assist will not operate. See "Instrument Cluster" in section "Dashboard Instruments and Controls" for further information. If the instrument cluster displays a message prompting you to clean the sensors, make sure the outer surface and the underside of the rear bumper and/or front bumper is clean and clear of snow, ice, mud, dirt or other obstruction and then cycle the ignition



switch. If the message continues to appear contact the **Service Network**.



If a failure message is displayed on the instrument cluster, contact the **Service Network**.

Cleaning the Park Assist Sensors

When cleaning the sensors, take special care not to scratch or damage them; therefore, do not use dry, rough or hard cloths.

The sensors must be washed with clean water, possibly adding car shampoo. Should you need to repaint the bumper or in case of paint touch-ups in the sensor area, please contact exclusively the **Service Network**. Incorrect paint application could affect the parking sensors operation.

Park Assist System Usage Precautions

NOTE:

- Jackhammers, large trucks, and other vibrations could affect the performance of Park Assist.
- Objects such as bicycle carriers, trailer hitches, etc., must not be placed within 30 cm (12 in) from the rear bumper while driving the vehicle. Failure to do so can result in the system misinterpreting a close object as a sensor problem, causing the service Park Assist message to be displayed in the instrument cluster.



CAUTION!

- Park Assist is only a parking aid and it is unable to recognise every obstacle, including small obstacles. Parking curbs might only be temporarily detected or not detected at all. Obstacles located above or below the sensors will not be detected when they are in close proximity.
- The vehicle must be driven slowly when using Park Assist in order to be able to stop in time when an obstacle is detected. When backing

up, it is recommended that the driver looks over his/her shoulder when using Park Assist.



WARNING!

Drivers must be careful when backing up even when using the Park Assist system. Always check carefully behind your vehicle, look behind you, and be sure to check for pedestrians, animals, other vehicles, obstructions, and blind spots before backing up. You are responsible for safety and must continue to pay attention to your surroundings. Failure to do so can result in serious injury or death.

Park Assist Volume

The volume of the acoustic signal emitted by the front and rear parking sensors is set to the medium level. Three different level of volume can be selected the submenu "Safety & Driving Assistant" from the MTC+ System.

Low level is useful in certain conditions when the parking sensor acoustic signal keeps coming on although there is no actual collision hazard. This may typically occur when driving in a queue



or when the vehicle is overtaken by motorcycles or other vehicles on one or both sides in a queue of traffic. When you set the volume, only the parking sensor acoustic signal will be affected. The radio or any other devices connected to the vehicle sound system will not be affected. Refer to chapter "MTC+ Settings" in section "Dashboard Instruments and Controls" for further information.

Operation with a Trailer

The operation of the rear sensors is automatically deactivated when the trailer's electric plug is inserted in the vehicle's tow hook socket, while the front sensors stay active and can provide acoustic and visual warnings. The rear sensors are automatically reactivated when the trailer's cable plug is removed.

Rear Parking Camera (optional)

Your vehicle can be equipped with a rear parking camera that allows you to see an image on the MTC+ screen of the rear surroundings of your vehicle whenever the shift lever is put into R (Reverse).

When "Parkview Backup Camera Delay" mode is enabled, the rear view image shall be displayed for up to 10 seconds after shifting out of R (Reverse).

To assist the driver during manoeuvres on dead-ends/roads and on intersections, the vehicle may be equipped with an optional surround view camera system. For more details on this option, see chapter "Surround View Camera System (optional)" in this section.

The image will be displayed along with a caution note to "Check Entire Surroundings" across the top of the screen. After five seconds this note will disappear.

The rear parking camera is located on the rear of the vehicle above the rear licence plate.




When the shift lever is shifted out of R (Reverse), the rear camera mode is exited and the navigation or audio screen appears again.

When displayed, dynamic grid lines (if the function is set to "MTC+ Settings") will illustrate the width of the vehicle while a dashed centre-line will indicate the centre of the vehicle to assist with parking or aligning to a hitch/receiver. The dynamic grid lines will show separate zones in different colour that will help indicate the distance to the rear of the vehicle.



The following table shows the approximate distances for each zone and colour:

Zone	Distance to the rear of the vehicle
Red	28 - 30 cm (11 - 12 in)
Yellow	30 cm - 2 m (12 - 78 in)
Green	2 - 4 m (78 - 157 in)



WARNING!

Drivers must be careful when reversing even when using the rear view camera. Always check carefully behind your vehicle, and be sure to check for pedestrians, animals, other vehicles, obstructions, or blind spots before reversing. You are responsible for the safety of your surroundings and must continue to be careful while reversing. Failure to do so can result in serious injury or death.



CAUTION!

- To avoid vehicle damage, the rear camera should only be used as a parking aid, as the rear camera is unable to view every obstacle or object in your drive path.
- To avoid vehicle damage, the vehicle must be driven slowly when using the rear camera to be able to stop in time when an obstacle is seen. It is recommended that the driver looks frequently over his/her shoulder when using the rear camera.


**NOTE:**

If snow, ice, mud, or any other substance builds up on the camera lens, clean the lens, rinse with water, and dry with a soft cloth. Do not cover the lens.

Surround View Camera System (optional)

System components

The system uses four cameras to monitor the area around the vehicle, placed on the front grid, under the side rear-view mirrors and on the liftgate, between the number plate lights.



When the shift lever is shifted to R (Reverse) position, camera images will be automatically displayed on MTC+ display.

Instead, when the shift lever is shifted to P (Park), N (Neutral), D (Drive) or R (Reverse) position, it is possible to activate/deactivate the system by pressing "Surround View" soft-key in "Controls" screen of MTC+ display.



Once the "Surround View" screen is displayed, it is possible to choose



Before Starting

which images to display according to 4 possible settings.



Rear view and top view



Rear cross path view



Front cross path view



Front view and top view

In any shift lever condition, when "Surround View" screen is displayed, a pop-up message will appear in the upper part for 5 seconds.

With gear in P (Park), N (Neutral) or D (Drive) or R (Reverse), the upper right corner of the screen will show the "X" key: touch it to go back to the previous screen of MTC+ display, before entering in "Controls".

Choose the most suitable setting for the situation and the manoeuvre you are performing or going to perform, by touching the relevant button present under the images. The button will highlight and the type of selected view will appear on each image.



In the top view, the vehicle is represented as it is during the manoeuvre, therefore any open doors will be visible in the image (see example in the figure).

To display also the dynamic lines of the trajectory you are setting, it is necessary to set this function by accessing the "Settings" menu on MTC+, at "Safety & Driving Assistant" item. Once this menu is displayed, it is also possible to set the function that delays the exit from this screen in special situations when the gear lever is in D (Drive) position. For further information, see "MTC+ Settings" in section "Dashboard Instruments and Controls".



WARNING!

Failure to follow the precautions below might result in serious injury or even death.

- Drivers must be careful during manoeuvres also when using the camera system with surround view.
- Always check carefully the areas around your vehicle, before proceeding forward or backward.
- Be sure to always check for any pedestrians, animals, other vehicles, obstructions, or blind spots.
- The driver must use the utmost caution while using the system to avoid damage to property or personal injury.



- The camera system with surround view is designed for use during the day or under good lighting conditions. Do not use the system under poor lighting conditions.
- Distance lines and trajectory lines must be used only as a reference and only when vehicle is on a flat ground. The distance shown on MTC+ display must be interpreted as a reference and might be different from the distance actually present between the vehicle and any displayed objects.
- Any obstacles present above the cameras cannot be detected.

**CAUTION!**

- To avoid vehicle damage, the camera system with surround view should only be used as a parking aid, as the cameras are unable to view every obstacle or object in your drive path.
- To avoid vehicle damage, the vehicle must be driven slowly when using the camera system with surround view, to be able to stop in time when an obstacle is seen. It is recommended that the driver looks

frequently over his/her shoulder when using this system.

NOTE:

If snow, ice, mud, or any other substance builds up on the camera lens, clean the lens, rinse with water, and dry with a soft cloth. Do not cover the lens.

Safety Tips

Transporting Passengers

**WARNING!**

- Do not leave children or animals inside parked vehicles in hot weather. Interior heat build-up may cause serious injury.
- It is extremely dangerous to ride in a cargo area, inside of a vehicle. In a collision, people riding in these areas are more likely to be seriously injured.
- Do not allow people to ride in any area of your vehicle that is not equipped with seats and seat belts.
- Be sure everyone in your vehicle is in a seat and using a seat belt properly.



Exhaust Gas



WARNING!

Exhaust gases can injure. They contain carbon monoxide (CO), which is colourless and odourless. Breathing it can make you unconscious and can eventually poison you. To avoid breathing (CO), follow these safety tips:

- Do not run the engine in a closed garage or in confined areas any longer than needed to move your vehicle in or out of the area.
- If it is necessary to sit in a parked vehicle with the engine running, adjust your heating or cooling controls to force outside air into the vehicle. Set the blower at high speed.
- If you are required to drive with the liftgate open, make sure that all windows are closed and the climate control blowers switch is set at high speed. **DO NOT** use the recirculation mode.

The best protection against carbon monoxide entry into the passenger compartment is a properly maintained engine exhaust system.

Whenever detecting a change in the sound of the exhaust system or eventual exhaust fumes inside the vehicle have the **Service Network** inspect the complete exhaust system and adjacent body areas for broken, damaged, deteriorated, or mispositioned parts.


Open seams or loose connections could permit exhaust fumes to seep into the passenger compartment.


Vehicle Safety Checks

Seat Belts

- Inspect the belt system periodically, checking for cuts, frays, and loose parts. Damaged parts must be replaced immediately.
- Do not disassemble or modify the system.
- If the belt has been sharply pulled, for example as the result of an accident, the safety belt, together with the anchoring devices, the anchoring device mounting screws and the pretensioner must be completely replaced. Even if the belt does not present any exterior signs of wear or damage, it may have lost its restraining properties.

Air Bag Warning Light

The  light should illuminate and remain lit for a few seconds bulb checking when the ignition switch is pushed in **RUN** position (see “Supplemental Restraint System (SRS) — Air Bags” chapter in this section).

- If the light  does not illuminate while starting, contact the **Service Network**.
- If the light stays on, flickers, or comes on while driving, have the system checked by the **Service Network**.

Defroster

Check operation by selecting the defrost mode and place the fan system on high speed (see “Air Conditioning Controls” chapter in section “Dashboard Instruments and Controls”).

You should be able to feel the air directed against the windshield and front side windows. Contact **Service Network** for service if your defroster is inoperable.

Floor Mat

Always use floor mats designed to fit the footwell of your vehicle. Use only floor mats that leave the pedal area unobstructed and that are firmly secured so that they cannot slip out of



position and interfere with the pedals or impair safe operation of your vehicle in other ways.

NOTE:

The **Maserati Service Network** can provide you with any information about the available Maserati floor mats included in the “Genuine Accessories” range.



WARNING!

Pedals that cannot move freely can cause loss of vehicle control and increase the risk of serious personal injury.

- Always make sure that floor mats are properly attached to the proper fasteners.
- Never place or install floor mats or other floor coverings in the vehicle that cannot be properly secured to prevent them from moving and interfering with the pedals or the ability to control the vehicle.
- Never put floor mats or other floor coverings on top of already installed floor mats. Additional floor mats and other coverings will reduce the size of the pedal area and interfere

with the pedals.

- Check mounting of mats on a regular basis. Always properly reinstall and secure floor mats that have been removed for cleaning.
- Always make sure that objects cannot fall into the driver footwell while the vehicle is moving. Objects can become trapped under the brake pedal and accelerator pedal causing a loss of vehicle control.
- Mounting posts must be properly installed, if not equipped from the factory. Failure to properly follow floor mat installation or mounting can cause interference with the brake pedal and accelerator pedal operation causing loss of control of the vehicle.

Tires

- Examine tires for excessive tread wear and uneven wear patterns.
- Check for stones, nails, glass, or other objects lodged in the tread or sidewall.
- Inspect the tread for cuts and cracks.
- Inspect sidewalls for cuts, cracks and bulges.
- Check the wheel nuts for tightness.

- Check the tires (see “Tire Inflation Pressure” chapter in section “Features and Specifications”) for proper cold inflation pressure.

Lights and Indicator Lights

- Have someone observe the operation of exterior lights while you operate the controls (see “Lights” chapter in section “Understanding the Vehicle”).
- Check turn signal and high beam indicator lights on the instrument cluster (see “Instrument Cluster” chapter in section “Dashboard Instruments and Controls”).

Door Latches

- Check for positive closing, latching, and locking of doors and liftgate (see “Unlock the Vehicle with Key fob” chapter in this section).

Fluid Leaks

- Check area under vehicle after overnight parking for recent fluid leaks (oil, fuel, etc.).
- If gasoline fumes are detected or fluid leaks are suspected, contact the **Service Network**.





3 – Understanding the Vehicle


Interior Components	92
Front Seats	95
Driver Memory Seat (for versions/markets, where provided)	100
Rear Seats	103
Steering Wheel Adjustment	106
Adjustable Pedals (for versions/markets, where provided)	107
Rear-View Mirrors	108
Lights	111
Wipers and Washers	123
Interior Features	126
Cargo Area	133
Front to Back Roof Rails (optional)	140
Power Sunroof with Sunshade (optional)	141
HomeLink (for versions/markets, where provided)	143
Air Conditioning Distribution	147



Interior Components

Dashboard Components

3






- 1 Adjustable side air outlets.
- 2 Engine **START/STOP** button.
- 3 Headlight switch.
- 4 Anti-theft system indicator.
- 5 Steering wheel controls.
- 6 Instrument cluster.
- 7* Right shift paddle +.
- 8* Left shift paddle -.
- 9 Multifunction lever (windshield wipers, headlight washer and headlight selection, turn signals).
- 10 Adjustable central air outlets.
- 11 Analogue clock.
- 12 MTC+ display.
- 13 Climate controls.
- 14 Dashboard glove box handle.
- 15 Dashboard storage compartment with two USB ports for charging of connected source.
- 16 Steering wheel adjustment control.

(* If foreseen

Central Console Components

- 1 Automatic transmission shift lever.
- 2 Drive mode switches.
- 3 Electric Parking Brake lever.
- 4 Cover for compartment with AUX, USB and SD memory card port.
- 5 Cover for cup holder and cigarette lighter/power socket compartment.
- 6 Rotary selectors and buttons for the multimedia navigation.
- 7 Hazard lights switch.
- 8 Drive height selector.





- 9 Unlock button for central console compartment with cup holder and power outlet.
- 10 Central console covers with armrest function.
- 11 Adjustable air outlets.
- 12 Cover for power outlet and USB slots compartment.
- 13 Four-zone climate controls for rear passengers (optional).

Front Dome Console Components




- 1 Reading lights control button.
- 2 Central light control button.
- 3 Reading lights.
- 4 Central light.

- 5 Passenger airbag deactivation warning light (for versions/markets, where provided).
- 6 Button to switch off passenger compartment lights.
- 7 Button to release the manual liftgate or to open fully/partially the power liftgate (optional).
- 8 Button to enable/disable front sensors of the Park Assist system (optional).
- 9 Sunroof controls (optional).
- 10 HomeLink controls (optional).

Front Doors Components



Driver door




Passenger door

- 1 Internal door handle.
- 2 Driver's seat and rear mirrors memory switch (if equipped).
- 3 External rear view mirrors switches.
- 4 Power window switches.
- 5 Power door unlocks/locks.
- 6 Rear windows and sunshade lockout button.
- 7 Loudspeakers.
- 8 Storage compartment.
- 9 Internal door lock/unlock knob.
- 10 Door panel grip.
- 11 Reflex reflector.
- 12 External door handle.



- 13 Door lock button with “Passive Entry” function.
- 14 Door outboard opening lock.

Rear Doors Components



- 1 Internal rear door handle.
- 2 Grip.
- 3 Loudspeaker.
- 4 Door storage pockets.
- 5 Power window and sunshade (optional) button.
- 6 Power doors lock/unlock buttons.
- 7 “Child protection” door lock system.
- 8 Inside door lock/unlock knob.
- 9 Reflex reflector.

- 10 External door handle.
- 11 Heated switch for right rear seat (optional). The heated switch for the left rear seat is on the left rear door.
- 12 Door lock button with “Passive Entry” function (optional).

Front Seats

Seats and seat belts are parts of the Occupant Restraint System of the vehicle.

For further information, see chapter “Occupant Restraint System” in Section “Before Starting”.

Depending on the different markets and versions, the front seats may have different controls for adjustment and optional features. The configurations shown below may differ from the ones in your vehicle.

The front passenger seat is equipped with a sensor that informs the SBR system about the presence of an occupant on the seat.



WARNING!

Be sure everyone in your vehicle is in a seat and using a seat belt properly.

Front Power Seats

The power seats switches are located on the outboard side of the seat cushion.

Use the front switch **1** to move the seat up or down, forward or rearward or to recline the seat cushion.



Use the switch **2** to recline the seatback.
Use the rear switch **3** to adjust the lumbar support.



Seat Forward/Rearward Adjustment

The seat can be adjusted both forward and rearward.
Push the seat switch **1** forward or rearward, the seat will move in the direction of the switch.

Release the switch **1** when the desired position is reached.

Seat Up/Down Adjustment

The height of the seat can be adjusted up- or downward.
Grip switch **1** from the back side and push it down or up.
Release the switch **1** when the desired position is reached.



CAUTION!

If the seat's movement does not work, make sure that the corresponding fuse is not tripped (see chapter "Fuse Replacement" in section "Maintenance and Care").

Head Restraints Adjustment

To manually lift or lower the head restraints press the indicated lateral button.



WARNING!

Remember that the headrests must be positioned so that their upper edge is aligned with the top of the occupant's head. In fact, only in this position can they provide the support required in the event of a bumper-to-tail collision.

Seat Tilt Control (Up/Down)

The angle of the seat cushion can be adjusted in four directions.
Pull upward or push the front of the switch **1**, to move the front cushion seat in the direction of the switch.
Release the switch **1** when the desired position is reached.

Seat Back Tilt Control

The angle of the seatback can be adjusted forward or rearward.
Push the seatback switch **2** forward or rearward, the upper seatback will move in the direction of the switch.
Release the switch **2** when the desired position is reached.

Power Lumbar

Push the switch **3** forward or rearward to increase or decrease the lumbar support.



Push the switch **3** upward or downward to raise or lower the lumbar support.



WARNING!

- **Never adjust the seat while driving. You could lose control of the vehicle. Moving the seat could distract you or make you press a pedal unintentionally.**
- **Seats should be adjusted before fastening the seat belts and while the vehicle is parked.**
- **Do not ride with the seatback reclined so that the shoulder belt is no longer resting against your chest. In a collision you could slide under the seat belt, which could result in serious injury or death.**



CAUTION!

Do not place any object under a power seat or obstruct its movement as it may cause damage to the seat controls. Seat movement may become limited if there is an obstruction in the way.

Front Power/Manual Seats

On these seats, the power switch **1** and the manual reclining lever **2** are located on the outboard side of the seat cushion.

Use the power switch **1** to move the seat up or down, forward or rearward or to recline the seat cushion.



CAUTION!

If the seat's movement does not work, make sure that the corresponding fuse is not tripped (see chapter "Fuse Replacement" in section "Maintenance and Care").

Use the manual lever **2** to recline the seatback.



Seat Forward/Rearward Adjustment

The seat can be adjusted both forward and rearward.

Push the seat switch **1** forward or rearward, the seat will move in the direction of the switch.

Release the switch **1** when the desired position is reached.

On some versions, the passenger seat can be adjusted front- and rearward manually.

In order to adjust the seat forward or rearward, push the lever **3** located below the seat cushion and manually move the seat forward or rearward. Release the lever once you have reached the desired position.



3



Seat Up/Down Adjustment

The height of the seat can be adjusted up- or downward.

Grip switch **1** from the back side and push it down or up.

Release the switch **1** when the desired position is reached.

Head Restraints Adjustment

To manually lift or lower the head restraints press the indicated lateral button.



WARNING!

Remember that the headrests must be positioned so that their upper edge is aligned with the top of the occupant's head. In fact, only in this position can they provide the support required in the event of a bumper-to-tail collision.



Seat Tilt Control (Up/Down)

The angle of the seat cushion can be adjusted in four directions.

Pull upward or push the front of the seat in the direction of the switch **1**.

Release the switch **1** when the desired position is reached.

Seat Back Manual Control

The angle of the seatback can be adjusted forward or rearward.

To recline, lean forward slightly, lift the lever **2**, then push back to the desired position and release the lever. Lean forward and lift the lever **2** to return the seatback to its normal position. Using body pressure, lean forward and rearward on the seat to be sure the seatback has latched.

Power Lumbar (optional)

Push the switch **4** forward or rearward to increase or decrease the lumbar support.

Push the switch **4** upward or downward to raise or lower the lumbar support.



WARNING!

- **Never adjust the seat while driving. You could lose control of the vehicle. Moving the seat could distract you or make you press a pedal unintentionally.**
- **Seats should be adjusted before fastening the seat belts and while the vehicle is parked.**
- **Do not ride with the seatback reclined so that the shoulder belt is**



no longer resting against your chest. In a collision you could slide under the seat belt, which could result in serious injury or death.



CAUTION!

Do not place any object under a power seat or obstruct its movement as it may cause damage to the seat controls. Seat movement may become limited if there is an obstruction in the way.

Front Heated Seats (optional)

The front seats can be equipped with heaters in both seat cushions and seatbacks.

The front seats heating is operated by the MTC+ System.



WARNING!

• Persons with low skin sensitivity because of advanced age, chronic illness, diabetes, spinal cord injury, medication, alcohol use, exhaustion or other physical conditions must be careful when using the seat heater. It may cause burns even at low temperatures, especially if used for long periods of time.

• Do not place anything on the seat that insulates against heat, such as a blanket or cushion. This may cause the seat heater to overheat. Sitting in a seat that has been overheated could cause serious burns due to the increased surface temperature of the seat.

Front Seats Heat Function

NOTE:

The engine must be running for the heated seats to operate.

• Touch the “Controls” soft-key on the lower part of the MTC+ display.



• Within 15 seconds, touch the “Driver” or “Passenger” seat soft-key once to select HI-level heating.



- Within 15 seconds, touch the same soft-key a second time to select LO-level heating.
- Within 15 seconds, touch the same soft-key a third time to shut the heating elements OFF.

NOTE:

Once a heat setting is selected, heat will be felt within 2 to 5 minutes.

When the HI-level setting is selected, the heater will provide a boosted heat level during the first 4 minutes of operation.

Then, the heat output will drop to the normal HI-level.

If the HI-level setting is selected, the system will automatically switch to LO-level after a maximum of 60 minutes of continuous operation. At that time, the display will indicate the change from HI to LO.



The LO-level setting will turn OFF automatically after a maximum of approximately 45 minutes.

Front Ventilated Seats (optional)

NOTE:

The engine must be running for the ventilated seats to operate.

To enhance occupants comfort by high external temperatures, both the driver and passenger seats, on request, can be ventilated.

Small fans are located in the seat cushion and seatback, they draw air from the seat surface through fine perforations in the seat cover to help keep the driver and front passenger cooler when the temperature is high. The ventilated seats are operated with the MTC+ System.

Front Ventilated Seats Function

- Touch the “Controls” soft-key on the lower part of the MTC+ display.



- Within 15 seconds, touch the “Driver” or “Passenger” seat soft-key once to select HI-level ventilation.



- Within 15 seconds, touch the same soft-key a second time to select LO-level ventilation.
- Within 15 seconds, touch the same soft-key a third time to shut off the seat ventilation.

Driver Memory Seat (for versions/markets, where provided)

This feature allows the driver to store up to two different memory profiles for easy recall through a memory switch. Each memory profile contains desired position settings for the driver seat, external side mirrors, adjustable pedals (optional), and power tilt and telescopic steering column and a set of programmed radio stations. Your key fob RKE transmitter can also be set to recall the same positions by pressing the button.

NOTE:

- Only one key fob RKE transmitter can be linked to each of the memory positions.
- “Passive Entry” door handles cannot be linked to the memory function. Use either the memory recall switch or the key fob RKE transmitter (if linked to the memory feature) to recall memory positions 1 or 2.

The memory seat switch is located on the driver's door trim panel. The switch consists of three buttons:



- The “S” (SET) button, which is used to activate the memory save function.
- The “1” and “2” buttons which are used to recall either of two programmed memory profiles.



Memory Profiles Setting

NOTE:

Saving a new memory profile will erase an existing profile from memory.

To create a new memory profile, perform the following:

- Cycle the ignition device to the **ACC** or **RUN** position.
- Adjust all memory profile settings to desired preferences (i.e., seat, side mirrors, adjustable pedals (optional), power tilt and telescopic steering column, and radio station presets).


- Press and release the “S” button on the memory switch.
- Within 5 seconds, press and release the memory button “1” or “2”.
- Check on the instrument cluster for the positive response of the actions “Memory 1 (or 2) profile set”.

After these steps, the profile set will be memorized in the selected position.

NOTE:

Memory profiles can be set without the vehicle in P (Park), but the vehicle must be in P (Park) to recall a memory profile.



Pairing Remote Keyless Entry Transmitter to Seats Memory


Your key fob with RKE transmitters can be programmed to recall one of two programmed memory profiles by pressing the  button on the RKE transmitter.

NOTE:

This feature can be enabled or disabled using the MTC+ System, refer to “MTC+ Settings” in section “Dashboard Instruments and Controls” for further information.


To programme your key fobs RKE transmitter, perform the following actions:

- Cycle the ignition device to the **ACC** or **RUN** position.
- Move the seat and/or the other adjustable devices in the position that you wish to memorize, or recall a previously memorized profile, pressing the corresponding memory button “1” or “2”.
- Cycle the ignition device to the **OFF** position.
- Press and release the “S” button.
- Within 5 seconds, press and release the memory button “1” or “2”.
- Press and release the  button on key fob RKE transmitter.
- Within 3 seconds, press and release the  button on the key fob RKE transmitter.

To check if the system has memorized the correct profile, you can move the seat and press the  button: the seat will move to the memorized position.




NOTE:

Your key fobs RKE transmitter can be unlinked to your memory settings by pressing the "S" button followed by the  button on the key fob RKE transmitter.

Memory Position Recall

NOTE:

The vehicle must be in P (Park) to recall memory positions. If a recall is attempted when the vehicle is not in P (Park), a message will display in the instrument cluster.

To recall the memory settings for driver, press memory button number "1" or "2" on the driver's door trim panel or the  button on the RKE transmitter linked to memory position "1" or "2" with ignition device in the **RUN** position.

A recall can be cancelled by pressing any of the buttons ("S", "1", or "2") during a recall. When a recall is cancelled, the driver seat, external side mirrors, adjustable pedals (optional), and power tilt and telescopic steering column stop moving.

A delay of at least one second will occur before selecting a new recall.

Easy Entry/Exit Driver Seat (optional)

This feature provides automatic driver seat positioning to enhance driver mobility when entering and exiting the vehicle.

The distance the driver seat moves depends on where you have the driver seat positioned when you place the ignition device to the **OFF** position.

- When you cycle the ignition device to the **OFF** position the driver seat:
 - will move about 60 mm (2.36 in) rearward if the driver seat position is greater than or equal to ca. 140 mm (5.51 in) forward of the rear stop;
 - will move to a position of ca. 80 mm (3.15 in) rearward of the rear stop if the driver seat position is between 140 mm (5.51 in) and 80 mm (3.15 in) forward of the rear stop.
- The seat will return to its previously set position when you place the ignition device into the **ACC** or **RUN** position.
- The Easy Entry/Exit feature is disabled when the driver seat position is less than 80 mm (3.15 in) forward of the rear stop. In this

position, there would be no benefit to the driver by moving the seat for Easy Exit or Easy Entry.

Each stored memory setting will have an associated easy entry/exit position.

NOTE:

The Easy Entry/Exit feature can be enabled or disabled using the MTC+ System, refer to "MTC+ Settings" in section "Dashboard Instruments and Controls" for further information.



Rear Seats

Rear seats can fit three passengers. Seats and seat belts are parts of the occupant restraint system of the vehicle.



WARNING!

Be sure everyone in your vehicle is in a seat and using a seat belt properly.

NOTE:

See chapter "Occupants Restraint Systems" in section "Before Starting" for seat belt positioning.

Rear Seat Folding Seatback

The 60/40 split-folding seatback of the rear seat provides for a recliner feature with three available fixed positions that can be set using the lever on seat external side. The LH lever tilts the long part (60), while the RH lever tilts the shorter one (40). The less tilted position (90°) is the one most suitable when a child seat must be installed; the other positions tilt the seatback toward the liftgate up to 23°.

To tilt the seatback, lift the lever from its rest position 0 to position 1 while

pushing the seatback to the back until reaching the required position. When releasing the lever, the fixed positions will be acknowledged by lever control cable clicking in place to lock.

Ensure that seatback is fastened to the position by trying to move it back and forth. Lever control cable locks also when fully folding the seatback down on the seat.

To move the seatback in another position, lift lever in position 1 and hold it up until bringing seatback to the new fixed position, which is acknowledged by the cable locking in place when releasing the lever.



WARNING!

- Ensure the seatback is always locked in one of the fixed positions before fastening the rear seat belts. An

unlocked seatback cannot ensure the necessary stability for passengers and/or for child seats. An unlocked seatback could cause severe injuries in case of accident.

- When fastening a child seat on external rear seats, ensure that the corresponding seatback is duly locked in the less tilted position.

NOTE:

Rear seat backrest can be fully folded to increase luggage space. See "Cargo Area" in this section for further details.

Rear Head Restraints

The seat head restraints are adjustable in height.

NOTE:

When there are no occupants in the seat, lowered the head restraint in order to provide the driver for maximum visibility. See label on each side of the central head restraint (if foreseen) or on the fixed side restraints, shown in the pictures.





3



- To raise the head restraint, pull upward on the head restraint.



- To lower the head restraint, press the push button, located at the foot of the head restraint on the left side, and push downward on the head restraint.



Rear Armrest

The rear armrest is mobile and can be folded up into the seatback.

- To lower it, pull the stripe as indicated.



- To close it, pull it upwards then push it back into its seat.

On the front part of the armrest there are two cup holders (see "Interior Features" in this section).



CAUTION!

The armrest is not designed to support the weight of an adult or a child: please use it only to store beverages or small objects.

NOTE:

Seatback panel behind armrest features an opening allowing you to carry long objects or ski bags with no need to fold the seatback. See "Cargo Area" in this section for further details.



Rear Side Heated Seats (optional)

The side rear seats can be equipped with heaters both in seat cushion and seatback.

Rear seats heating can be adjusted by operating control devices on the trim panel of each rear door.



WARNING!

- Persons with low skin sensitivity because of advanced age, chronic illness, diabetes, spinal cord injury, medication, alcohol use, exhaustion or other physical conditions must be careful when using the seat heater. It may cause burns even at low temperatures, especially if used for long periods of time.
- Do not place anything on the seat that insulates against heat, such as a blanket or cushion. This may cause the seat heater to overheat. Sitting in a seat that has been overheated could cause serious burns due to the increased surface temperature of the seat.

The switch on the trim panel with the resistance icon activates the heating on the corresponding seat.

- Push the switch once to select the highest heating level. The two upper LEDs on the switch will illuminate.
- Push the same switch a second time to select the lowest level. Only one LED will illuminate.
- Push the same switch a third time to shut the heating elements off. The LED will turn off.



NOTE:

- Once a heat setting is selected, heat will be felt within two to five minutes.
- The engine must be running for the heated seats to operate.

By selecting the HI-level setting, the heater will provide a boosted heat level during the first four minutes of operation. Then, the heat output will drop to the normal HI-level.

By setting the HI-level, the system will automatically switch to LO-level after a maximum of 60 minutes of continuous operation. The LO-level setting will turn off automatically after a maximum of approximately 45 minutes.





Steering Wheel Adjustment


This feature allows you to tilt the steering column upward or downward or to lengthen or shorten it in order to adjust the steering wheel to an optimised position. Steering wheel adjustment can be manual or electric.

Manual Adjustment

The tilt/telescoping control handle is located below the steering wheel at the end of the steering column.

To unlock the steering column, push the control handle downward . To tilt the steering column, move the steering wheel upward or downward as desired. To lengthen or shorten the steering column, pull the steering wheel outward or push it inward as desired.

To lock the steering column in position , pull the control handle upward until fully engaged.



Power Adjustment

The power tilt/telescoping steering column/wheel switch is located on the lower left side of the steering column. To adjust the tilt of the steering column/wheel, move the switch up or down as desired.



To lengthen or shorten the steering column/wheel, pull the switch toward you or push the switch away from you as desired.

NOTE:

You can use your key fob with RKE transmitter or the memory buttons on the driver's door trim panel to return the tilt/telescopic steering column/wheel to programmed positions. See "Driver Memory Seat (for versions/markets, where provided)" in this section.



WARNING!

Do not adjust the steering column/wheel while driving. Adjusting the steering column/wheel while driving could cause the driver to lose control of the vehicle. Be sure the steering column/wheel is adjusted before driving your vehicle. Failure to follow this warning may result in serious injury or death.

Heated Steering Wheel (optional)

NOTE:

The engine must be running for the heated steering wheel to operate.

The steering wheel contains a heating element inside the rim that helps warm driver's hands by cold weather.



The heated steering wheel has only one temperature setting. Once turned on, this function will operate for approximately 58 to 70 minutes before automatically shutting off. The heated steering wheel can shut off early or may not turn on when the steering wheel is already warm. The heated steering wheel can be turned on and off using the MTC+ System.

- Touch the “Controls” soft-key located on the lower part of the MTC+ display.



- Within 15 seconds, touch the “Heated wheel” soft-key to turn on the function.



- Within 15 seconds, touch the “Heated wheel” soft-key a second time to turn it off.



WARNING!

- **Persons who are unable to feel pain to the skin because of advanced age, chronic illness, diabetes, spinal cord injury, medication, alcohol use, exhaustion, or other physical conditions must exercise care when using the steering wheel heater. It may cause burns even at low temperatures, especially if used for long periods.**
- **Do not place anything on the steering wheel that insulates against heat, such as a blanket or steering wheel covers of any type and material. This may cause the steering wheel heater to overheat.**

Adjustable Pedals (for versions/markets, where provided)

The adjustable pedals system is designed to allow greater range of pedals positions enabling driver comfort with regard to the steering wheel tilt and the seat position. This feature allows the brake and accelerator pedals to move toward or away from the driver's feet. The switch is located on the front side of the driver's seat cushion side shield.



Press the switch downward to move the pedals forward (toward the front of the vehicle). Lift the switch upward to move the pedals rearward (toward the driver).



WARNING!

Do not adjust the pedals position while the vehicle is moving. You could lose control and have an accident. Always adjust the pedals position while the vehicle is parked.

The following messages will be displayed if the driver is attempting to adjust the pedals when the system is locked out:

- “Adjustable Pedals Unavailable While Reversing”;
- or “Adjustable Pedals Unavailable While Cruise Engaged”.

NOTE:

For vehicles equipped with driver memory seat, use your key fob (RKE) transmitter or the memory buttons on the driver's door trim panel to return the adjustable pedals to programmed positions. See “Driver Memory Seat (for versions/markets, where provided)” in section “Understanding the Vehicle” for further information.



CAUTION!

Do not place any object under the adjustable pedals or obstruct their movements as it may cause damage to the pedal controls. Pedal movement may become limited if there is an obstruction in the adjustable pedal's.

Rear-View Mirrors

External Mirrors

External mirrors can be adjusted electrically and are equipped with anti-mist resistors operated by the air conditioning system (see “Air Conditioning Controls” in section “Dashboard Instruments and Controls”).

The mirrors can be closed electrically and will yield in both directions in case of a collision.

The external mirrors are electrochromic (for versions/markets where provided), which means, they automatically operate an anti-dazzle function by gradually shading as the light hitting the mirrors increases.

The external rearview electrochromic mirrors work in conjunction with the internal rearview electrochromic mirror.

NOTE:

- *The mirrors can be adjusted electrically only with the ignition device in **ACC** and **RUN** position.*
- *When the vehicle is started, the warning light shown in the picture will momentarily illuminate in both outside rear-view mirrors to let the*



driver know that the BSA system (optional) is operational. For more details see chapter “Blind Spot Alert - BSA (optional)” in section “Driving”.



The external of the rear-view mirror support is equipped with LEDs, lighting up when the turn signals and vehicle entry/exit lights are activated. When the surround view camera system is installed, at the external bottom side of the rear-view mirror is the side view camera (refer to “Surround View Camera System (optional)” in section “Before Starting”).

Mirrors Positioning

The power mirror controls are located on the driver's door trim panel.

The power mirror controls consist of mirror select buttons and a four-way mirror control switch.



To adjust a rear-view mirror, press either the L (left) or R (right) button to select the mirror that you want to adjust. The spin button will illuminate indicating the rear-view mirror is activated and can be adjusted. Press the mirror control switch corresponding to the arrow indicating

the direction of the desired movement.

For optimal vision orientate the outside(s) mirror(s) in order to frame the adjacent lane and get a partial overlap with the visible image on the inside rear-view mirror.

Power mirror preselected positions can be reset by operating the optional Memory Driver Seat device. Check “Driver Memory Seat” in section “Understanding the Vehicle” for further information.



WARNING!

Vehicles and other objects seen in the external side convex mirror will look smaller and farther away than they really are. Use the inside mirror to judge the size or distance of a vehicle seen in the external side convex mirror.

Tilt Side Mirrors In Reverse

This feature provides automatic external rear-view mirrors positioning, allowing the driver to view the ground area behind the front doors. The external mirrors will move slightly downward from the current position when the shift lever is shifted into



reverse. The external mirrors will then return to the original position when the lever is shifted out of the reverse position. Each memory set of the driver's seat (see "Driver Memory Seat (for versions/markets, where provided)" chapter in section "Understanding the Vehicle") corresponds to a mirror tilt position in reverse.

NOTE:

The mirrors tilt in reverse can be turned on and off using the MTC+ System, refer to "MTC+ Settings" in section "Dashboard Instruments and Controls".

Folding Mirrors

The switch for the power folding mirrors is located between the power mirror switches.



Press the switch once and the mirrors will fold in; press the switch a second time to reset the mirrors to the standard position.

There is a way to make external mirrors automatically fold/unfold.

- If the function is available, it needs to be activated by MTC+ (refer to "MTC+ Settings" in section "Dashboard Instruments and Controls").
- If the mirrors are automatically folded after the last lock action, then they will automatically unfold when the ignition device is set on **ACC** or **RUN** position.
- If the mirrors were manually folded by the switch on the driver's door panel, before a lock action, they will need to be manually unfolded to reactivate the automatic function.




CAUTION!

Never retract or open the mirrors manually: it could damage the power mechanism.

Internal Rear-View Mirror

The position of internal rear-view mirror can be manually adjusted, and is endowed with an accident-prevention release system operating in the event of a collision.

Internal rear-view mirror is electrochromic (for versions/markets where provided): this glare function is automatically deactivated in reverse to ensure maximum visibility of obstacles.



**CAUTION!**

To avoid damage to the mirror during cleaning, never spray any cleaning solution directly onto the mirror. Apply the solution onto a clean cloth and wipe the mirror clean.

Auto-dimming On/Off Button


By pressing the on/off button to the mirror base the user can disable/enable the auto-dimming function. Typical case is at night when the auto-dimming can be excessive (low reflectance). Pressing the button will increase the reflectance of the mirror, increasing visibility.

Lights

Light Switch

The headlight switch located on the left side of the dashboard is used for the position lights, headlights, front and rear fog lights operation.

**NOTE:**

- In certain European countries, the position lights will only operate with the ignition switch in **OFF** position, or with front fog lights and headlights on. Regardless of ignition switch position, the position lights will remain on as long as the lights switch is in this first detent .
- If the headlights or position lights are on after the ignition switch is placed in **OFF** position, a buzzer will alert the driver while opening the driver's door.



Lighting Up External Lights according to the Position of the Headlights Switch, Ignition Device and Transmission and according to the Engine Status

Ignition device position	Engine status	Transmission position	Lights switch position		
			0		
OFF	-	-	All lights off	Position lights (1), side marker and licence plate lights on	Low beams, position (1), side marker and licence plate lights on
ACC	Off	P (Park)	All lights off	Position lights (1), side marker and licence plate lights on (2)	Low beams, position (1), side marker and licence plate lights on (2)
RUN	Off	P (Park)	All lights off	All lights off	Low beams, position (1), side marker and licence plate lights on (2)
RUN	On	P (Park)	All lights off	All lights off	Low beams, position (1), side marker and licence plate lights on
RUN	On	Any position other than P (Park)	DRL (1) on	DRL (1) on	Low beams, position (1), side marker and licence plate lights on


(1) The lighting system uses the same LED with two different levels of intensity: high for DRL and low for position lights.

(2) The lights are powered up for 30 minutes to preserve the charge of the battery.

3



Lighting Up Internal Lights according to the Headlights Switch and Ignition Device Position

- When lights switch is in  mode and ignition switch in **RUN**, besides the outdoor lights, the rear side dome lights LED, the front dome light (if enabled), the control backlighting, the lighting of the instrument cluster and front seats night lighting will light up.
- Besides the external lights, the same interior lights indicated in the previous step based on the DAY or NIGHT mode established by the Ambient light detecting sensor will light up (see "Interior Lights" of this chapter).
- When the light switch position is "0" and the ignition device is in **RUN** mode, the control back light and night lighting will turn off.

NOTE:

During DAY mode, the control switches are not backlit except the windows and steering switches.

Automatic Headlights

This system automatically turns the headlights on or off according to ambient light intensity detected by

the twilight sensor. To turn the system on, rotate the lights switch clockwise to "AUTO" position.

When the automatic system is activated, the headlight time delay feature is activated as well. This means the headlights will stay on for up to 90 seconds after you place the ignition device into **OFF** position.

To turn the automatic system off, move the lights switch out of "AUTO" position.

NOTE:

The engine must be running before the headlights turn on in automatic mode.



WARNING!

- **The responsibility for turning on the lights, depending on the daylight and regulations in force in the country of use, always lies with the driver. The automatic system for switching on and off the external lights is to be considered as an aid for the driver. If necessary, switch the lights on and off manually.**
- **In case of fog during the day, the position lights and low beams will turn on automatically. The driver**

must always be ready to turn the lights on manually, including the front and rear fog lights.

Headlights On with Wipers

When this feature is active, the headlights will turn on in "adverse weather beam" mode approximately 10 seconds after activation of the wipers, if the lights switch is placed in the "AUTO" position. The headlights will additionally turn off by deactivation of the wipers if previously activated with this function.

NOTE:

The Headlights ignition feature with wipers may be turned on and off using the MTC+ System, refer to "MTC+ Settings" in section "Dashboard Instruments and Controls".

Headlights Time Delay

This safety feature provides headlight illumination for up to 90 seconds (programmable) when leaving your vehicle in an unlit area. To activate the delay feature, place the ignition switch in the **OFF** or **ACC** position while the headlights are still on. Then turn off the headlights within 45 seconds.



The delay interval begins when the lights switch is turned off (position “0”). If you turn the headlights or position lights on, or place the ignition switch in **RUN**, the system will cancel the delay.

If you turn the headlights off (“0” position) before the ignition, they will turn off in the normal mode.

NOTE:

- *To activate this feature the lights must be turned off (“0” position) within 45 seconds of placing the ignition switch in the **OFF** or **ACC** position.*
- *The headlight delay time is programmable using the MTC+ System, see “MTC+ Settings” in section “Dashboard Instruments and Controls”.*

SmartBeam™ System (for versions/markets, where provided)

The SmartBeam™ system provides increased forward lighting at night by automating high beam control (“Auto Dim High Beams” function) through the use of a digital camera fitted behind the rear-view mirror.

This camera detects vehicle specific light and automatically switches from high beams to low beams until the approaching vehicle or the front vehicle is out of view.

NOTE:

- *This function can be turned on or off using the MTC+ System, refer to “MTC+ Settings” in section “Dashboard Instruments and Controls” for further information.*
- *If the headlights and rear position lights of the vehicle in the visual field of the camera are broken, covered in mud or obstructed, main-beam headlights will remain lit for longer, up to a closer position of the oncoming or foregoing vehicle. Dirt, impurities and other obstructions on the windshield or camera lens can cause the system to function improperly.*
- *By replacing the windshield or SmartBeam™ mirror, the SmartBeam™ mirror must be re-aimed to ensure proper performance. Please contact exclusively the **Service Network** for replacement.*

Daytime Running Lights (DRL)

The lighting system uses the same high or low intensity Headlamps LED, respectively, for the DRL lights and position lights.

DRL lights will turn on when the engine is running and the shift lever is moved out of the P (Park) position. If a turn signal is activated, the DRL lamp on the same side of the vehicle will turn off for the duration of the turn signal activation. Once the turn signal is deactivated, the DRL lamp will light up again.

NOTE:

Depending on your Country’s regulations, DRL lights may be turned on and off.

Adaptive Bi-Xenon Headlights

The gas-discharge (xenon) headlights operate with an electric arc saturated with Xenon gas under pressure, instead of the incandescent filament. The light produced is assuredly higher compared to traditional light bulbs, in terms of quality (brighter light) as well as of the span and positioning of the illuminated area.

The adaptive headlight system combines the light beam with the



steering angle to assure better visibility of the road surface when driving in a curve, steering or in the event of road deviations.

AFS Adaptive Feature (for versions/markets, where provided)


These projectors combine the “xeno” Technology to the AFS (Advanced Front lighting System) adaptive feature, using the vehicle dynamics parameters, in particular acceleration, pitching angle and steering angle. The System is able to process signals from dynamics other onboard systems and subsequently start up five strategic steps in the following situations:

- “highway beam”;
- “country beam”;
- “town beam”;
- “adverse weather beam”;
- “tourist beam” (for example in countries with circulation on the opposite side). In this case this function must be activated via the menu of MTC+ (refer to “MTC+ Settings” in section “Dashboard Instruments and Controls”).

The advantages offered by the AFS system are perceived especially in case of bad weather, fog and/or insufficient

road indications providing broader illumination of the side zones, which are normally left in the dark, and for motorway driving (see comparison rendered below).

This surely increases driving safety as it offers less eye strain and increased orientation for the driver and better detection of other persons on the road sides (pedestrians, bicycle riders and motorcycle drivers). Furthermore, the projectors are suitable to prevent glare, providing optimal lighting when driving the car in a country with circulation on the opposite side. The table shows the light values (lux) and the light flux (lumen) of AFS headlights.



AFS headlight system combines the light beam with the steering angle and the vehicle speed to assure better visibility of the road surface when driving in a curve, steering or in the event of road deviations.

	Lighting	Light flux
(A) Low beam	75 lux	1200 lm
High beam	130 lux	1600 lm
(B) Motorway	120 lux (Driver Side) 140 lux (Passenger Side)	1200 lm



NOTE:

- Each time the adaptive headlight system is turned on, the headlights will perform a self-regulation cycle.
- The adaptive headlight system is active only when the vehicle is moving forward.
- “Steering Directed Headlights” function can be turned on or off using the MTC+ System, refer to “MTC+ Settings” in section “Dashboard Instruments and Controls” for further information.




WARNING!

If xenon headlamp replacement is necessary, contact the Service Network only: DANGER - RISK OF ELECTRICAL SHOCK.

Fog Lights

The front and rear fog lights switch is built into the light switch.


To activate the front and rear fog lights, turn the headlight switch to the low beam light  or “AUTO” position.

The front and rear fog lights turn on and off in the following order:


- press the lights switch once to turn on the front fog lights;
- press the light switch a second time to turn on the rear fog lights (front fog lights will stay on);
- from this condition, press the light switch again to turn off the rear fog lights (front fog lights will stay on);
- press the light switch again to turn off the front fog lights.



Turning the lights switch off (position “0”) will also deactivate the front and rear fog lights.


The green warning light  in the instrument cluster display illuminates when the front fog lights are turned on.



The amber warning light  inside the tachometer of the instrument cluster illuminates when the rear fog lights are turned on.



**NOTE:**

The front and rear fog lights will NOT activate automatically when turning on the low beam  or "AUTO" headlights if previously deactivated by turning the lights switch off. The front and rear fog lights will only turn on by operating the switch as previously described.

Multifunction Lever

The multifunction lever controls the operation of the turn signals, headlight beam selection, overtaking lights and wipers and washers acting on the windshield and on the liftgate. The multifunction lever is fitted on the left side of the steering column.

Turn Signals

Move the multifunction lever all the way up or down until the stop triggers.



The left or right arrow on the speedometer and tachometer instrument cluster respectively, flashes to show proper operation of the front and rear turn signal lights.





To activate lane change function, tap the lever up or down once, without moving beyond the detent. The turn signals (right or left) will flash three times then automatically turn off. This function is useful when overtaking or changing lanes.

NOTE:

- If either light remains on and does not flash, or flashes at a fast rate, check for a defective outside light bulb. If an indicator on the instrument cluster fails while moving the lever, then the indicator bulb is probably defective.
- A "Turn Signal On" message will appear in the instrument cluster and a continuous chime will sound if the vehicle is driven more than 1.6 km (1 mile) with either turn signal on.



High Beams and Flashing

To switch on the high beams with the light switch in headlamp  or "AUTO" position, shift the multifunction lever onward. The blue telltale  will illuminate on the tachometer.



By pulling the lever backward (toward the steering wheel) you switch off the high beams and switch on the low beams.



You can signal another vehicle with your headlights by lightly pulling the multifunction lever toward you. This will turn on the high beams headlights until the lever is released.



Flashing occurs also with lights off (lights switch in position "0") if the ignition switch is **RUN** position.



CAUTION!

The high beams can only be switched on manually by pushing the multifunction lever forward.



WARNING!

If the high beams have been switched on, they will turn on automatically every time the low beams are switched on either manually or

automatically. We recommend therefore that you switch them off when they are no longer necessary and every time the twilight sensor deactivates the external lights.

Automatic High Beams (if equipped)

The Automatic High Beam headlight control system provides increased forward lighting at night by automating high beam control through the use of a digital camera mounted behind the rearview mirror, which is the same one used also by the Lane Departure Warning (LDW) system. This camera detects vehicle specific light and automatically switches from high beams to low beams until the approaching vehicle is out of view. Furthermore, the digital camera is able to detect the urban areas and the inhabited centers and to turn off the high beams when driving near of one of them.

The high beam can be turned back on if there are all the necessary conditions and if the vehicle speed exceed 35 km/h (21.7 mph).


The Automatic High Beam function can be turned on or off using the MTC+ System. Refer to "MTC+ Settings" in section "Dashboard



Instruments and Controls" for further information.

The function is ability only if the brightness sensor detects the right lighting conditions.

To activate this function:

- Shift the multifunction lever onward .
- Put the headlight switch in "AUTO" position.
- Enable the "Automatic High Beam" function on MTC+.

After these steps, the green indicator on the upper left side of the TFT display comes on.



NOTE:


Broken, muddy, or obstructed headlights and taillights of vehicles in the field of view will cause headlights to remain on longer (closer to the vehicle). Also, dirt, film, and other obstructions on the windshield or camera lens will cause the system to function improperly.


If the windshield or Automatic High Beam headlight control mirror is replaced, the mirror must be re-aimed to ensure proper performance. See the **Service Network**.

Interior Lights




The interior and external approach lights turn on and off when entering/exiting the vehicle (see "Illuminated Entry/Exit" in section "Before Starting" for further information).

To protect the battery, the interior lights will turn off automatically 10 minutes after the ignition switch has been shifted to **OFF**. This occurs if the interior lights were turned on manually or by opening a door. The glove box light, on the dashboard, shares the same characteristics excepting the boot and liftgate lights.

The backlight brightness of controls and instruments can be adjusted by means of the buttons on steering wheel right-hand side, enter "Vehicle settings" menu and select "Interior Lights" sub-menu. To adjust the backlighting, the vehicle must be running and the light switch must be in  position.

Press and release the switch () to display "Backlighting".



Use arrow  or  to scroll the list of parameters that can be adjusted and confirm selection by pressing and releasing switch (): available options will be shown on the display. A check mark will remain next to the previously-selected item until a new selection is made.



3



Press and release the switch (▶) to select the option. A selection notice pops up for 2 seconds and then the display reverts to the last modified parameter.



The dimmable lights are the following:

- instrument cluster dials and display;
- dome light (front/rear);
- LED in correspondence of the internal door handle;

- doors and steering wheel backlight controls LED;
- front footrest light;
- front seats night lighting.

Automatic Headlights Levelling

A correct headlights levelling is crucial for the safety of the vehicle's occupants and of people in the street. Moreover it is included in the road regulation law.

In order to obtain the best visibility conditions while driving with headlights on, the headlight beam must be properly levelled, under any vehicle load condition. The vehicle is equipped with a system that automatically adjusts headlight levelling according to ground clearance and vehicle load conditions.

Dome Lights

The dome lights integrated into the front dome console, include a central and two reading lights.

The central light automatically turns on when one of the doors is opened and turns off when the door is closed (timed switching off). The light may be switched on manually by pressing the central button.

The reading lights are controlled by the respective side buttons.

If they are turned on by pressing the button, both central and reading lights will stay on for about 10 minutes after turning the engine off, and will then turn off gradually.

When the exterior lights are switched on, the two night LEDs fitted on the side of the power buttons on the overhead console will light up to







facilitate the use of the transmission lever and the central console.



If one or more doors are opened, the front and rear dome lights will turn on for 27 seconds. If the door is closed before this time, the lights will dim and subsequently switch off after about 3 seconds.

NOTE:

The dome lights will also turn on by pressing the  or  button for centralized doors unlock and lock on the key fob RKE transmitter. See “Illuminated Entry/Exit” section “Before Starting” for further information.

In the event of a collision causing automatic interruption of fuel supply, the dome lights switch on automatically and remain lit for approx. 15 minutes.

NOTE:

The controls of the sunroof and the HomeLink and the button to switch off Park Assist system can be found on the front dome console.

A light is available on the roof, under the sun visors; it turns on when user moves the courtesy mirror cover, which is built in the back of sun visor.



Apart the lights on the front dome console, there is a light with relevant on/off switch located next to the passenger handholds next to the external rear seats. These lights will operate only when the ignition device is in the ACC or RUN position.



Button to Switch off Passenger Compartment Lights



In addition to specific switches to turn on and off the dome lights as previously described, on the front console there is a button that allows to turn off all these lights.





Cargo Lights

To illuminate the cargo area there are two lights on liftgate and two more inside the boot. These lights turn on when liftgate is opened and turn off when it is closed.



If liftgate is left open for a long time, lights will turn off after 30 minutes to save battery charge.

Hazard Warning Lights

Press the indicated button on the centre of the central console to turn on the hazard warning lights. The operation is independent of the ignition device position.


Press the button again to turn them off.

When these lights are on, the direction indicators, the related warning lights on the instrument cluster and the button itself will flash.



Integrated External Rear-View Mirror Lights

External mirrors are supplied with LED turn signals integrated on the support.




The LED turn signal indicators flash simultaneously with the corresponding turn signal lights in the front and rear of the vehicle. Turning on the hazard warning lights will also activate these LEDs.

The external mirrors can be equipped also with approach and courtesy LEDs (optional), lighting up when the vehicle entry/exit lights are activated.



Wipers and Washers

The multifunction lever operates the wipers and washers acting on the windshield and on the window of the liftgate when the ignition switch is placed in **RUN** or **ACC** position. The multifunction lever is located on the left side of the steering column. The windshield washer and headlight washer (if foreseen) share the same fluid reservoir, and a low fluid level is indicated by the same warning light  and by the message on the instrument cluster.



To refill the fluid, see “Maintenance Procedures” in section “Maintenance and Care”.




CAUTION!

- Turn the washer acting on the windshield and on the window of the liftgate wipers off when driving through an automatic car wash. The windshield wipers may be damaged if the wiper control is left in any position other than “OFF”.
- In cold weather, always turn off the wiper switch and allow the wipers to return to the park position before turning off the engine. If the wiper switch is left on and the wipers freeze to the windshield and/or to the window of the liftgate, the wiper motor may be damaged when the vehicle is restarted.
- Always remove any buildup of snow that prevents the wiper blades from returning to the off position. If the wiper control is turned off and the blades cannot return to the off position, the wiper motor may be damaged.

Windshield Wipers

- Rotate the end of the multifunction lever to one of the four settings to activate the automatic intermittent setting (see “Rain Sensing Wipers” paragraph in this chapter).
- For low speed wiper operation (stable position “LO”): rotate the end of the multifunction control lever forward to the first trigger after the intermittent setting.
- Rotate to the second trigger after the intermittent setting for high-speed (stable position HI) wiper operation.
- Rotate the end of the lever backward to the “MIST” position to activate a single wipe cycle. The wipers will continue to operate until you release the multifunction lever.
- To turn the wipers off rotate the lever to “OFF”.





Rain Sensing Windshield Wipers (for versions/markets, where provided)

This feature detects moisture on the windshield through an internal rear-view mirror integrated sensor, which automatically activates the relative wipers.

Rotate forward the end of the multifunction lever to one of four settings to adjust the detection system. First wiper delay position is the least sensitive, and fourth wiper delay position is the most sensitive. Third position should be used for normal rain conditions.

The rain sense wipers will automatically change between an intermittent wipe, slow wipe and a fast wipe depending on the amount of detected moisture sensed by a particular area of the windshield. Place the wiper switch in the "OFF" position when you do not want to use the automatic intermittent system. The rain sensing feature can be turned on and off using the MTC+ System, see "MTC+ Settings" in section "Dashboard Instruments and Controls" for further information.



- The rain sensing feature may not function properly by ice or dried salt water on the windshield.
- Use on the windshield of RainX® or products containing wax or silicone may reduce rain sensor performance.

The rain sensing system has protective features for the wiper blades and arms. It will not operate under the following conditions:

- **Low Temperature Wipe Inhibit:** the rain sensing feature will not operate when the ignition is in **RUN** position, the vehicle is stationary and the outside temperature is below 0°C. To resume, set the automatic feature on the multifunction lever, start the engine and drive or wait until the outside temperature rises above freezing.
- **Wipe Inhibit with Transmission in Neutral Position:** the rain sensing feature will not operate when the ignition is placed in the **RUN** position, the transmission shift lever is in the N (Neutral) position and the vehicle speed is less than 8 km/h (5 mph). To resume, set the

multifunction lever to the automatic function or move the shift lever out of N (Neutral).

Headlights On with Windshield Wipers

When activating this function, the headlights will light up approximately 10 seconds after the wipers acting on the windshield are turned on if the headlight switch is placed in "AUTO" position. In addition, the headlights switch off when the wipers are turned off (position "OFF") if they were previously turned by using this function. Powering on Headlights with wipers can be activated and deactivated with the MTC+ System, see "MTC+ Settings" in section "Dashboard Instruments and Controls" for further information.

Wipers Blades Maintenance

When the wiper arms acting on the windshield are in the rest position it is not possible to check or replace the blades (Service position) as they are folded under the hood. To service the blades (see paragraph "Wiper Maintenance and Blades Replacement" in chapter "Maintenance Procedures" of section "Maintenance and Care") it is



necessary to shift the multifunction lever to “OFF” and the ignition switch to **OFF** position.

Shift the control lever within 15 seconds to the “MIST” position (forward rotation of the end of the multifunction control lever) and release. The blades are brought in a position enabling to open the wiper arms and change the blades.



It is possible to use the “MIST” position for a maximum of 3 times within two minutes, corresponding to different three blades positions on the windshield. When completed, bring the ignition switch in **RUN**: the arms will reposition. If necessary move the multifunction lever to other required operating positions.

To change the wiper blade on rear window of liftgate, simply lift the wiper arm to detach it from window

(see paragraph “Wiper Maintenance and Blades Replacement” in chapter “Maintenance Procedures” of section “Maintenance and Care”).



WARNING!


Operate or service the windshield wiper blades without deactivating the wipers (“OFF” position), leaving the ignition switch in RUN can be dangerous for the operator since the rain sensor may suddenly activate the wipers. Always use “Service” position for any intervention on the windshield wiper blades.

Windshield Washers and Headlight Washers

To use the washer on the windshield, push the end of the multifunction lever inward (toward the steering column) and hold it as long as washer spray is desired.

If you activate the washer while the windshield wiper control is in the automatic intermittent range, the wipers will operate for two wipe cycles after releasing the lever and then resume the previously-selected intermittent interval.

If you activate the washer while the windshield wiper is turned off (“OFF” position) the wipers will operate for three wipe cycles and then turn off.



WARNING!

- **Do not start the windshield washer during the cold months until the windshield has warmed up. If it has not warmed up, the liquid could freeze on the glass and block your view.**
- **Sudden loss of visibility through the windshield could lead to a collision. You might not see other vehicles or other obstacles. To avoid sudden icing of the windshield during freezing weather, warm the windshield with the defroster before and during windshield**



**(Continued)
washer use.**

Headlight Washers (if foreseen)

The multifunction lever also operates the headlight washers when the ignition switch is in **RUN** position and the headlights are turned on.

The headlight washers will spray a timed high-pressure spray of washer fluid onto each headlight lens every 11 windshield wipers cycles.

Head Windshield Washer Nozzles (optional)

To avoid fluid freezing inside at low external temperatures, the fluid supply nozzles can be heated by internal resistors.

Rear Window Wiper/Washer

Use the switch on multifunction lever as follows to turn on the rear window wiper and/or washer:

- From the "OFF" position, turn control forward to the first detent to activate wiper intermittently;
- Turn control forward to the second detent to activate wiper continuous action;
- A further rotation forward (unstable position) will trigger the rear window washer until control is

released. After control release, the rear window wiper will resume continuous operation;

- From the "OFF" position, turn control backward (unstable position) to trigger rear window washer until control is released: the rear window wiper will perform several cycles. Once released, control will go back to "OFF" position.



As a precaution, rear window washer pump stops if control is held in active position for over 20 seconds. When control is released, pump will resume normal operation.

If rear window wiper is still on, the wiper arm will automatically go back to rest position when the ignition device is turned **OFF**.

Interior Features

Electric Power Outlets

The vehicle is equipped with three or four 12 Volt (13 Amp) electric power outlets, one or two (if you use as power outlet the socket of the cigarette lighter) available for each front seat, one for rear seat passengers and one fitted in the boot.

In vehicles equipped with "Smoking Kit" the electric power outlet inside the cup holder is replaced with a cigarette lighter.

All power outlets are supplied only when the engine is started or the ignition device set to **ACC** or **RUN**.

Power outlets are protected by a fuse. Insert a cigar lighter or accessory plug into the power outlets to ensure proper operation. Otherwise, check the matching fuse integrity, see "Fuse Replacement" in section "Maintenance and Care" for further information.



CAUTION!

- Do not plug in accessories that exceed the maximum power of 160 Watts (13 Amps) at 12 Volts.



- Power outlets are designed for accessory plugs only. Do not insert any other object in the power outlets as this will damage the outlet and blow the fuse. Damages caused by improper use of the power outlet are not covered by the New Vehicle Limited Warranty.

**WARNING!**

To avoid serious injury or death:

- Only devices designed for use in this type of outlet should be inserted into any 12 Volt outlet.
- Replacing the fuses that protect power outlets with others of higher amperage, there is the risk of fire.
- Do not touch with wet hands.
- Close the lids when the plug is not used and while driving the vehicle.
- If this outlet is mishandled, it may cause an electric shock and failure.

Power Outlet inside the Cup Holder

To access the power outlet inside the cup holder beside the shift lever, press the cover as indicated to open it completely. Remove the cigarette

lighter and use its socket as power outlet.

**WARNING!**

High power consumption items plugged into this outlet for long periods may discharge the battery and/or prevent the engine from starting.

**Power Outlets inside the Central Console**

To access the power outlet located inside the glove box of the central console you need to open the half-lids as indicated in the following paragraph.

**Rear Power Outlets**

A 12 V power outlet in the compartment at the rear end of the central console, is available upon request for rear seat passengers. To access the power outlet, push the lid as indicated: it will open completely.




3



Power Outlet inside the Boot

The power outlet is positioned on the right side of the boot compartment.



Cup Holders

The vehicle is equipped with several cup holders.



- Use light and shatterproof containers.
- Do not forcefully push unsuitable containers into the cup holders to prevent damage to the containers.
- Do not store hot drinks.

Cup Holders for Front Passengers

The front cup holders are located beside the transmission lever and within the central console. To access the cup holder, push the cover as shown in the picture and it will open completely.



By pressing the indicated button on the central console, the half-lids will rise completely enabling access to the inner compartment where the two cup holders are located.



The storage and passenger compartment share the same air conditioning even though you may exclude the air conditioning of the cup holder compartment by moving the indicated button.



To close one or both of the half-lids, push them down to the locking position.


Cup Holders for Rear Passengers

Two cup holders are available in the front side of the rear seats central armrest.




AUX, USB and SD Memory Card Inputs

The inputs are located inside the compartment at the front end of the central console. To access the inputs, push the lid as indicated: it will open completely.



The AUX auxiliary port features:

- typical input impedance between AUX-IN and AUX_REF: 13 Kohm;
 - max. applicable voltage: 0.75 Vrms at 1 kHz;
 - input compatible only with 3.5 mm jack connectors (not included).
- Any player with these characteristics and analogue audio output (headset output type) can be served by the MTC+ System. The system can recognise the connection to a player outlet autonomously, by enabling access to the audio functions connected to this source.
- This USB input  can be used for data exchange (refer to the MTC+ guide for further details).
- Two other USB inputs for charging of connected source (CHARGE ONLY label) are present inside the glove box compartment of the dashboard.



3



In the compartment of the central console there is also a SD memory card input. Once inserted into the slot, to extract it, press lightly on the card. For rear seat passengers, there are two USB inputs inside the compartment located on the rear end of the central console, above the air vents. To access the USB inputs open the outside cover.



This USB ports allow charging (CHARGE ONLY label) the connected source.

iPod® Connection



An iPod® can be connected to the system via USB and AUX ports by means of a special cable (optional). The MTC+ will then control the following functions: play, pause, fast forward, rewind, next track, previous track, random or repeat mode, selection and navigation of playlist/genre/singer/album/Podcast.




Do not leave your USB device, iPod® or an external audio source in the vehicle for extended periods of time: extreme temperatures and humidity can occur in the vehicle.

Sun Visors

Sun visors can be folded to the front and to the side of the vehicle. To move the visor laterally, lower and release it from its catch as indicated. In this condition, the visor can be extended by sliding the visor end backward.



By lowering the visor you can access the courtesy mirror and, by sliding the mirror protective cover, the light on the dome will automatically light up (with the ignition switch in RUN). Before raising the visor, close the mirror cover: the light will turn off. A business card holder is fitted inside each sun visor.



Smoking Kit (optional)

The kit includes a lighter and a removable ashtray with cover. The Smoking kit for front seats passengers is located inside the box beside the transmission lever and can be accessed by pressing the cover as indicated.



The rear seat passengers can use the removable ashtray by inserting it into the rear doors pocket, while the lighter can be inserted into the power outlet at the end of the central console.

Press the central button to activate the cigarette lighter. After about 20 seconds the button returns automatically to the initial position and stops the heating: from this time the cigarette lighter is ready for use.



CAUTION!

After use, always make sure that the cigarette lighter is switched off.



WARNING!

- The cigarette lighter reaches high temperatures. Handle it carefully

and do not allow children to use it so as to avoid risk of fire and injury!

- The cigarette lighter may not be used as a power outlet.

Handholds and Cloth Hooks

Handholds are fitted above the passenger doors. Once grabbed, they will lower until the block position. When released, a return spring will bring them back to the original position.



Behind the rear handholds there is a light with relevant on/off switch (refer to chapter "Lights" in this section). Cloth hooks are present on rear handholds and on pillars between doors.



3



On the side walls of the boot compartment there is a shopping hook that can withstand a maximum load of 10 kg (22 lb).



Mesh Pockets

Front seats are fitted with mesh pockets, on the rear of the seatbacks, and accessible by rear passengers.



On the back of the boot compartment cover there is another mesh pocket that can withstand a maximum load of 5 kg (11 lb).



The mesh pockets can hold small items, maps and magazines.



CAUTION!

Do not put heavy or sharp objects in the mesh pockets.

iPad Holder (Genuine Accessories)

The Maserati Service Network can provide you with all information about the "Maserati iPad Holder" to be fixed to the slide rods of the front head restraints, available in the "Genuine Accessories" range.





Cargo Area



WARNING!

To help protect against personal injury, passengers should not be seated in the rear cargo area. The rear cargo space is intended for load carrying purposes only, not for passengers, who should sit in seats and use seat belts.

Vehicle Load Carrying Capacity

The load carrying capacity of your vehicle is shown on the vehicle identification label positioned on the rear driver door's ledge.



The information indicated on the label concerns passengers and luggage loading operations.

Do not exceed the specified Gross Vehicle Weight Rating (GVWR) or the Gross Axle Weight Rating (GAWR), both front and rear.

The GVWR is the total allowable weight of your vehicle. This includes driver, passengers, and cargo.

The total load must be limited so that you do not exceed the GVWR indicated on the label.



WARNING!

- **Improper weight distribution can have an adverse effect on the way the vehicle steers, handles and the way the brakes operate.**
- **Never drive with the liftgate open. Exhaust gases can enter the passenger compartment.**
- **Do not arrange any luggage on cargo area cover. In said position luggage could not only impair driver's view but also, in case of collision or unexpected stop, it could cause injury to all occupants.**

The boot is the most suitable place to load bulky and heavy objects onboard the vehicle. The maximum allowable load on the floor of the boot is 200 kg (440 lb).

To load your vehicle properly, store heavier items below and be sure you distribute their weight as evenly as possible.

Stow all loose items securely before start driving as they could move during the trip.

To separate boot from passenger compartment, the vehicle is equipped with a rigid horizontal panel, fitted behind the rear seat backrest. When vehicle is at a standstill, cargo area cover can withstand a maximum static load of 120 kg (260 lb).

Apart from cargo area cover, the vehicle can be also equipped with a vertical rolling Cargo Net, to be used to separate the cargo area from the passenger area.

The **Maserati Service Network** can provide you with any information about the items dedicated to the usage of the boot (luggage compartment mat, net, foldable box,..), available in the "Genuine Accessories" range.



Luggage Fasteners and Retainers

Vehicle can be equipped with fixed and mobile anchorages on boot floor allowing to fasten and retain any luggage in a convenient and safe manner. Using a special and approved net with hooks available in the "Genuine Accessories" range, also large and heavy objects can be fastened to boot floor.

Eyelets to secure the luggage net are provided on the four corners of boot floor.



Longitudinal rails on boot floor provide safe anchorage for luggage of different size, thanks to the special hooks with locking button. To position the hook, slide it along the rails until reaching the required position, holding down the central button. Release the button and slightly move

the hook to secure its position in the notches of the guide.



By using the Railing Fastening Bar, available in the "Genuine Accessories" range, fastened by means of sliding blocks along the floor rails, you can fasten heavy luggage in the innermost area of the boot.



CAUTION!

To avoid luggage inadvertent movement, in case of sudden braking or collision, always check correct fastening of the retainers onto floor rails before anchoring any luggage.

NOTE:

The **Maserati Service Network** can provide you with information about the available "Genuine Accessories" for the boot compartment.

Loading with Rear Seatbacks Folded Down

The 60/40 split-folding seatback of the rear seat provides cargo-carrying versatility.

The seatback folded down provides a continuous nearly-flat extension of the



load floor able to accommodate bulky luggage, large-sized equipment and objects that may not fit with the normal dimensions of the boot.

NOTE:

Both seat backs can be folded down independently.



WARNING!

To prevent the other luggage in the boot from getting into the passenger compartment and create a potential danger for the passengers, keep boot cover installed when folding down one of the two seatbacks.

When the seatbacks are unfolded to the upright position, make sure they are latched in one of the fixed positions (see "Rear Seats" in this section).



WARNING!

• Make sure that the seatback is securely locked into position. If the seatback is not securely locked into position, the seat will not provide the proper stability for child seats and/or rear passengers. An improperly latched seat could cause serious injury.

• The cargo area in the rear of the vehicle with the rear seatbacks in the folded down position should not be used as a play area by children when the vehicle is in motion. They could be seriously injured in a collision. Children should be seated and use proper restraint systems.

Ski and Snowboard Bag Compartment

To stow and safely fasten a ski and snowboard bag, with no need to fold down the seatback, use the opening available at the back of the longer seatback (60), at the level of the armrest between the rear seats. To reach this compartment and properly arrange the bag, proceed as follows.

- From inside the passenger compartment, lower the armrest between the rear seats.
- From the boot compartment, open the flap at the back of the long seatback.



- Insert the bag end without anchor hook into seatback opening.
- Fasten the hook to one of the eyelets available on boot floor.
- From the passenger compartment, route bag strap under armrest and fasten it.



If you follow these instructions, the bag will be securely fastened to vehicle structure and will thus remain in place also in case of collision or unexpected braking.



The Maserati approved Ski and Snowboard Bag available in the "Genuine Accessories" range, can be fastened also by folding down the seatback.

Accessories Compartment

In order to hold any accessories to be kept on the vehicle, the car is equipped with a storage box with carrying handles, at the rear end of the boot compartment.

To reach this box, lift or remove the boot floor panel.

NOTE:

The Maserati Service Network can provide you with information about the available "Genuine Accessories" for the boot compartment.




Boot Compartment Cover

Boot compartment cover is made of two parts, the most outward one lifts when liftgate is opened.

The cover can be removed to obtain a larger cargo area, as follows:

- slide the top end of side linkages out of the shafts on rear pillars;



- lift the cover rear end and slide it towards the liftgate: this will result in sliding the four lower ends of the cover inner part out of their guides on boot panel;



- remove boot cover from the vehicle. The two parts of boot cover can be folded one onto the other for a more compact unit.



WARNING!

Driving with no boot cover could be dangerous. Any unfastened luggage or objects could move into the passenger compartment in case of sudden stop or collision and seriously injure the occupants. You can try to prevent this by using the Cargo Net in the boot compartment.

When refitting the boot cover, perform the same operations in reverse order.

**WARNING!**

After refitting the boot cover, make sure that the lower ends of the inner part have properly engaged in their guides. If cover is not properly positioned and fastened, in case of unexpected stop or collision it could move and seriously injure the passengers in the rear seats.

Cargo Area Extension

The following procedure is aimed at obtaining the maximum possible extension of the cargo area, and it can be only a partial extension if you carry out only a few of the listed operations.

- Remove the boot cover as indicated under “Boot compartment cover” in this chapter.
- Completely lower the headrests of rear seats.
- Completely fold down the rear seats backrests by lifting the lever to position **1** and hold it up.
- Release the lever when seatback is against the seat: the control cable will click into place and lock.

Now that seatbacks are folded down, boot floor and the back panels of seatbacks will form a larger flat floor.


**CAUTION!**

Seatback rear panel is not suitable to support heavy loads and metal objects with protruding elements that might scratch its surface. If necessary, protect the seatback rear panel surface using rigid panels.


Installing the Cargo Net for Cargo Area

The Cargo Net can be installed to two positions depending on the current extension of the cargo area. When only the boot cover is removed (see previous paragraph), while backrests are still vertical, the Cargo Net must

be installed immediately behind them (position **A**).



While, in case also backrests were folded down, the Cargo Net must be installed in a more forward position behind the front seats (position **B**).

**WARNING!**



- The Cargo Net must be properly installed following the instructions

(Continued)



(Continued)
in this paragraph.


- The Cargo Net will not properly hold objects in case of sudden vehicle braking or collision depending on cargo weight. Heavy loads not sufficiently fastened could exceed net capacity and hit the vehicle occupants, with the ensuing risk of injury.
- Before leaving for a trip, fasten all objects that might move to boot floor, using the devices provided by Maserati for this purpose.
- When using the Cargo Net, do not load any heavy object on top of the other objects which are laid on the boot floor (see example in the figures).



The Cargo Net is housed in the accessories compartment under the boot floor.

The Cargo Net is supplied folded, inside a bag that is part of the net itself.



To install it, open the bag zip, unfold the two parts until hearing the jointing elements clicking in place. To close it, press the button indicated in the figure, at the two jointing elements.



To install the Cargo Net in position A, proceed as follows.

- Turn downwards the upper part of the protection cover on roof brackets.





- Insert the net top ends in the slot on roof brackets (position )
- Pull net down to ensure it is properly engaged (position ) .



- Fully unfold Cargo Net down and engage the ends of side tethers, with



hook, in the fixed or mobile retainers available on boot floor.

- Pull down the free ends of the tethers to tension the Cargo Net: once released, the tether will remain in taut position . To disengage and release tether from retainer position , lift the tether free end as indicated in the figure.



Should it be necessary to position the Cargo Net in position **B** - more forward, i.e., behind the front seats - use the top retainers next to external rear passenger handholds.


- Lower handhold and lift upward the retainer cover on the roof.



- Engage the net top ends in the slot on roof, as already described for the rear retainers.



- Fasten the lower tethers of Cargo Net to external retainers, also used to fasten the top safety belt for children seat, available on rear seat backrests (see chapter "Child Restraint Systems" in section "Before Starting").



When Cargo Net is no longer necessary, remove it from its fastening points, fold it and close the bag zip. Store bag under boot floor, then restore vehicle original conditions by repositioning all moved or removed parts.



Front to Back Roof Rails (optional)

The front to back roof rails that can be installed to this vehicle have been designed to carry luggage or equipment suitable for transport outside of the vehicle.



Weight of luggage/equipment carried on the rails must not exceed 80 kg (176 lb) and must be evenly distributed. This weight must be added to the load carried inside of the vehicle as well as the passengers' weight, and total must not exceed the maximum allowed weight (see "Features and Specifications" in section "Features and Specifications").

When arranging load on rails, make sure that it will not interfere with liftgate and sunroof opening (if equipped).

Securely fasten load to rails using the suitable retainers that can hold the original anchorage points throughout the trip.

When installing to rails any bicycle, surfboard or other types of carriers requiring cross bars, please comply with the equipment manufacturer's instructions to ensure proper installation.

The **Maserati Service Network** can provide you with any information about the Maserati approved Carrying Items, available in the "Genuine Accessories" range.



WARNING!

- **During the trip, it is recommended to periodically check the proper fastening of luggage or equipment carried on the roof rails. This is to avoid that any parts that may have accidentally unfastened could damage vehicle bodywork and fall out, thereby becoming a danger for all vehicles behind yours.**
- **When driving with a bulky load on roof rails, take additional precautions and drive at lower speed, keeping a wider safety distance from vehicles ahead.**

Indeed, a bulky and/or heavy load carried on the roof will affect driving behaviour and steering response since it shifts the vehicle centre of gravity to a higher position compared to normal conditions.

- **All objects/equipment carried on the roof and protruding beyond the windshield, e.g. surfboard, must be fastened to both sides of the vehicle. Any wind blow might suddenly increase load lift possibly resulting in breakage and loss of part of the carried equipment.**



Power Sunroof with Sunshade (optional)

The sunroof and the sunshade are power-controlled and can only be operated with the ignition switch in **RUN** position.

The sunroof is made of two glass panels: the front one can be moved whereas the rear one is fixed. The right switch controls the sunroof movement, whereas the left one controls the sunshade.

Lifting of the sunroof front panel for venting is controlled by the button, behind the two switches.

By opening the sunroof a front flap rises automatically in order to deviate the air flow.



WARNING!

- **Improper use of the sunroof can be dangerous, even if it features a finger-trap prevention system. Before and during the sunroof operation, always make sure that passengers are not exposed to the risk of injuries caused by the moving sunroof or by personal objects dragged or hit by the moving sunroof.**
- **Never leave children in a vehicle with the key fob RKE transmitter in the passenger compartment.**
- **In a collision, there is a greater risk of being thrown from the vehicle if the sunroof is open. Always fasten your seat belt properly and make sure all passengers are properly secured too.**

- **Do not allow small children to operate the sunroof. Never insert fingers, other body parts, or any object through the roof opening.**



CAUTION!

- **In the event of rain, always close the sunroof to prevent water infiltrations from staining the fabric/leather upholstery.**
- **Do not open the sunroof if there is ice on it: risk of damage.**
- **Do not open the sunroof in case of presence of any object (bicycle, surfboard or other type of carriers fixed to cross bars) that might interfere with sunroof.**

Sunroof

Press backwards and release the right switch: the front panel will open completely.

From the completely open position, press onwards and release the right switch: the front panel will close completely.

The automatic movement can be interrupted in any position by pressing backward and onward the right switch again.



Venting Sunroof

Press and release the rear button; the sunroof front panel will open to the vent position. Where this function is available, this type of opening can be activated regardless of the sunroof position. During this opening operation, any movement of the button will stop the sunroof.

By pressing the rear button when the sunroof is completely closed, the latter will open to the venting position.

Sunshade

Press backwards and release the left switch: the sunshade will move to the vehicle rear side until completely open. From this position, press onwards and release the left switch to move the sunshade to the vehicle front side until completely closed.

During the opening and closing operations, work on backward and onward the left switch to interrupt the sunshade movement in any position.

Pinch Protect Feature

This feature will detect an obstruction in the roof opening during the automatic closure or a constant obstruction of the sunroof front panel. If an obstruction is detected by the

safety system during the closing movement, the sunroof front panel will automatically retract. If this occurs, remove the obstruction then press onwards and release the right switch to reactivate the sunroof automatic closure.

NOTE:

- *If three consecutive attempts to close the sunroof result in pinch protect reversals, the fourth attempt will be manual, with pinch protect feature disabled.*
- *Pinch protection is disabled while pressing the switches.*

Initialization Procedure


In case of a fault in the automatic opening/closing movements or in case of battery removal, it is necessary to initialize the automatic operation of the sunroof.



Proceed as follows:

- bring the sunroof in the completely closed position;
- push the ignition switch to **OFF** position and keep this condition for 10 seconds;
- push the ignition switch to **RUN** position;


- press the right switch onwards and keep it pressed for at least 10 seconds after which you should hear the sunroof electric motor mechanic stop;
- within 5 seconds, press the right switch onwards again and keep it pressed: the sunroof performs an automatic complete opening and closing cycle. Should this not happen, repeat the procedure from the beginning;
- press the right switch onwards and keep it pressed until the sunroof is completely closed: the initialization procedure is then completed.

Closing and Opening the Power Sunroof with RKE Transmitter and Ignition Off

When the ignition switch is in **OFF** position, if the sunroof is open, it can be closed together with the windows by pressing the  button on the RKE transmitter (refer to “Power Windows” in section “Before Starting”).

- Press and release the  button.
- Press a second time the  button and keep it pressed until the sunroof is completely closed.



To open completely the sunroof from the outside, press in the same way the  button on the RKE transmitter.

Wind Buffeting

Wind buffeting can be described as the perception of pressure or a helicopter-type sound. Your vehicle may exhibit wind buffeting with the windows down, or the sunroof in certain open or partially open positions. This is a normal occurrence and can be minimised. If the buffeting occurs with the rear windows open, then open the front and rear windows together to minimise the buffeting. If the buffeting occurs with the sunroof open, then adjust the sunroof opening to minimise the buffeting.

Ignition Off Operation

The power sunroof controls will remain active for up to approximately ten minutes after the ignition switch is in **OFF** position. Opening either front door will cancel this feature. The ignition system timing can be set using the MTC+ System (see “MTC+ Settings” in section “Dashboard Instruments and Controls”).

Sunroof Maintenance

Use only a nonabrasive cleaner and a soft cloth to clean the glass panel.

HomeLink® (for versions/markets, where provided)

HomeLink® replaces up to three hand-held transmitters operating the automatic devices that open garage doors and gates, enable/disable the lighting or security systems. The HomeLink® unit is powered by your vehicle's 12 Volt battery. The HomeLink® buttons that are located in the overhead console designate the three different HomeLink® channels. The HomeLink® warning light is located in front of the buttons.



NOTE:

HomeLink® is disabled when the vehicle security alarm is active (see “Vehicle security alarm” in section “Before Starting”).



WARNING!

- Your motorized door or gate will open and close while you are programming the universal transceiver. Do not program the transceiver if people, pets or other objects are in the path of the door or gate. Only use this transceiver with a garage door opener that has a “stop and reverse” feature. Do not use a garage door opener without these safety features. Call toll-free 1-800-355-3515 or, on the Internet at www.HomeLink.com for safety information or assistance.
- Vehicle exhaust contains carbon monoxide, a dangerous gas. Do not run your vehicle in the garage while programming the transceiver. Exhaust gas can cause serious injury or death.

Before You Start Programming HomeLink®

Be sure that your vehicle is parked outside of the garage before you begin programming.

For more efficient programming and accurate transmission of the radio-frequency signal it is

recommended that a new battery be placed in the hand-held transmitter of the device that is being programmed to the HomeLink® system.

Before starting programming it is necessary to erase the standard codes memorized on the HomeLink® device during the production phase. To erase such codes:

- place the ignition device in the **RUN** position without starting the engine;
- press and hold the two outside HomeLink® buttons (I and III) until the warning light starts flashing (after approximately 20 seconds);
- release the buttons.

NOTE:

- *Erasing the standard codes should only be performed when programming HomeLink® for the first time. Do not perform this operation to program additional buttons.*
- *If you have any problems, or require assistance, please call toll-free 1-800-355-3515 or, on the Internet at www.HomeLink.com for information or assistance.*



System with Devices Provided with Rolling Codes

Programming the Hand-held Transmitters Manufactured after 1995

These devices can be identified by the “LEARN” or “TRAIN” setting button located where the hanging antenna is attached to the garage door/gate opener. It is NOT the button that is normally used to open and close the door.

The name and color of the button may vary by manufacturer.

- Place the ignition device to the **RUN** position without starting the engine.
- Place the hand-held transmitter 5 - 30 cm (1 to 3 inches) away from the HomeLink® button you wish to program.



- Simultaneously press the Homelink[®] button you want to program and the hand-held transmitter button.
- Release immediately the Homelink[®] button you want to program.
- Continue holding the hand-held transmitter button until the warning light starts flashing quickly; then release the button.

The quick flashing light indicates that the channel with the new frequency has been acquired and programmed correctly by the HomeLink[®] system.

NOTE:

The distance necessary between the portable hand-held transmitter and the HomeLink[®] in the vehicle depends on the system you wish to program. Probably it will be necessary to try several times. Upon every attempt, keep the setting position for at least 15 seconds before trying again.

Synchronising the Rolling Codes

At the end of the previously-described programming, if the HomeLink[®] has been programmed for a rolling code system, it will be necessary to synchronise it to ensure its correct operation.

- Locate the “LEARN” or “TRAINING” setting button of the opening motor. Firmly press it and then release it. On some garage door openers/devices there may be a light that blinks when the garage door opener/device is in the LEARN/TRAIN mode.

NOTE:

You have 30 seconds to initiate the next step after the setting button has been pressed.

- Return to the vehicle and press the programmed HomeLink[®] button for two seconds and then release it.
- Repeat this operation a second time. If the garage door opening device activates, the programming/synchronization phase is complete.

NOTE:

If the garage door opening device does not activate, press the button a third time for two seconds and then release it to complete the programming/synchronization phase.

- To program the remaining two HomeLink[®] buttons, repeat the same step for the same remaining button. **DO NOT erase the channels.**

Reprogramming a Single HomeLink[®] Button

To reprogramme a channel that has been previously trained, follow these steps:

- Place the ignition device to the **RUN** position without starting the engine.
- Press and hold the desired HomeLink[®] button.
- **Without releasing the button** proceed with “Programming the hand-held transmitters” from second step and follow all remaining steps.

System with Devices Without Rolling Code

Programming the Hand-held Transmitters Manufactured before 1995

- Turn the ignition device to the **RUN** position without starting the engine.
- Place the hand-held transmitter 5 to 30 cm (1 to 3 inches) away from the HomeLink[®] button you wish to program.
- Simultaneously press and hold both buttons until the warning light starts flashing quickly; then release both buttons.

The quick flashing light indicates that the channel with the new frequency



has been acquired and programmed correctly by the HomeLink® system.

NOTE:

The distance necessary between the portable hand-held transmitter and the HomeLink® in the vehicle depends on the system you wish to program. Probably it will be necessary to try several times. Upon every attempt, keep the setting position for at least 15 seconds before trying again.

- Press and hold the programmed HomeLink® button.

If the garage door opener/device activates, programming is complete. To program the remaining two HomeLink® buttons, repeat each step for each remaining button. **Do not erase the channels.**

Reprogramming a Single HomeLink® Button

To reprogram a channel that has been previously trained, follow these steps:

- Place the ignition device to the **RUN** position without starting the engine.
- Press and hold the desired HomeLink® button.
- **Without releasing the button** proceed with “Programming the

hand-held transmitters” from second step and follow all remaining steps.

Using HomeLink®

To operate, press and release the programmed HomeLink® button. Activation will now occur for the programmed device (i.e., garage door opener, gate operator, security system, entry door lock, home/office lighting, etc.). The hand-held transmitter of the device may also be used at any time.

Security

It is advisable to erase all channels before you sell or turn in your vehicle. To erase the channels press and hold the two outside HomeLink® buttons (I and III) until the warning light starts flashing (after approximately 20 seconds).

The HomeLink® Universal Transceiver is disabled when the vehicle security alarm is active (see “Vehicle security alarm” in section “Before Starting”).

Troubleshooting Tips

If you are having trouble while programming HomeLink®, here are some of the most common solutions:


- Replace the battery in the original hand-held transmitter.

- Press the LEARN button on the garage door opener to complete the training for a rolling code.
- Did you unplug the device for programming and forgot to plug it back in?

If you have any problems, or require assistance, please call toll-free 1-800-355-3515 or, on the Internet at www.HomeLink.com for information or assistance.




Air Conditioning Distribution



A/C Dual-zone



3



A/C Four-zone



Adjustable and fixed air vents allow passengers to achieve the optimal comfort conditions.

Fixed Air Vents

- The fixed vents, positioned on the upper part of the dashboard, beneath the windshield and on the windshield side pillars are meant to guarantee the demisting and defrosting of the windshield and the side windows.



- The fixed vents under the dashboard and below the front seats (for dual-zone air conditioning system only) are used to ventilate the lower part of the passenger compartment.



A/C Dual-zone

- When a four-zone air conditioning system is installed, there is a fixed air vent on each side of the rear end of the central console to guide air

conditioning flow towards the bottom of the external rear seats.





A/C Four-zone



Adjustable Air Vents

The adjustable vents are located at the center of the dashboard, on both sides of the MTC+ display and on the upper surface, and at the side ends of the dashboard. They have the purpose of ventilating the upper part of the passenger compartment. There are also adjustable vents placed at the rear end of the central console. The rotor 1, located near each vent, allows to control the quantity of the air flow from fully closed to fully open, and vice versa.

Excluding the adjustable vents on the upper surface of the dashboard, the grill of these vents can be oriented by operating on the central handle 2.



NOTE:

In order not to obstruct the air conditioning inlet, the defrosting or the demisting function of the glass surfaces, avoid covering vents with clothing or other items.



4 – Dashboard Instruments and Controls

Instrument Cluster	152
Infotematic System	180
Audio Controls	187
Audio System	188
MTC+ Settings.	190
Dashboard Compartment	203
Analog Clock	206
Air Conditioning Controls	206
Phone and Voice Controls on Steering Wheel (if foreseen)	214

Instrument Cluster

The instrument cluster is divided into three main areas displaying information, signs and text and/or icon messages.

- A. Analogue speedometer. It indicates the vehicle speed.
- B. Analogic tachometer.
- C. TFT display. In this area the odometer display shows the total distance covered by the vehicle.

Speedometer and tachometer display the main warning lights (see “Warning and Indicator Lights on Analog Instruments” in this chapter). The other warning and indicator lights are displayed on the TFT display together with mode and drive function indicators (see “TFT Display: Warning/Indicator Lights of Set Modes/Functions” in this chapter).

NOTE:

The image shows the instrument cluster before starting the engine.



Gasoline



Diesel



Warning and Indicator Lights on Analog Instruments

Telltails on Speedometer

The following telltales are displayed on the speedometer, and related messages are visible for 5 seconds on the central sector of the display, unless otherwise indicated (see "TFT Display: Warning/Indicator Lights of Set Modes/Functions" paragraph in this chapter).



Gasoline



Diesel

Malfunction Indicator Light (MIL)



The Malfunction Indicator Light (MIL) is part of an onboard diagnostic system that monitors engine and automatic transmission control systems. Under normal conditions, this indicator light should switch on when the ignition switch is in **RUN** position and switch off as soon as the engine is started. This is a sign of the indicator light working properly. If the indicator remains lighted up or switches on while driving, there is a failure in the fuel supply/ignition and emission control systems. The failure could cause high exhaust emissions, loss of performance, poor

vehicle handling and high consumption levels. Under these conditions you can proceed slowly without forcing the engine or driving at high speeds. The indicator light will switch off if the problem is solved. The error will be registered by the system in any case.



CAUTION!

- When the ignition switch is in the **RUN** position and the indicator light does not switch on or it switches on while driving, contact the **Service Network** as soon as possible.
- Prolonged driving with the MIL on could cause damage to the engine control system. It also could affect fuel economy and driveability. If the MIL is flashing, severe catalytic converter damage and power loss will soon occur. Immediate service is required.

Left Turn Signal Indicator Light



The indicator lights up when the left direction indicators or the hazard lights are turned on.



The indicator light will flash at the same frequency of the turn indicators and is controlled by the multifunction lever behind the steering wheel. If the vehicle electronics sense that the vehicle drives for more than 1.6 km (1 mile) with either turn signal on, a continuous sound will alert the driver to turn the signal off. If the indicator flashes at a rapid rate, check for a defective exterior light bulb.

Tire Pressure Monitoring Light



This warning light is connected to the Tire Pressure Monitoring System (TPMS).

Under normal conditions, the warning light should illuminate when the ignition switch is in **RUN** and should go off as soon as the engine is started.

If the warning light remains lit or illuminates while driving, the pressure of one or more tires is too low and a message will be displayed.

The TPMS malfunction warning light is connected to the low tire pressure monitoring light.

When the system detects a malfunction, the monitoring light and the related message will flash for

approximately one minute and then remain lit.

This sequence will continue upon subsequent vehicle start-ups as long as the malfunction lasts.


When the malfunction warning light lights up, the system may not be able to detect or signal low tire pressure correctly.

Please refer to "Tire Pressure Monitoring System (TPMS)" in section "Driving" for further information.

Anti-Lock Braking System (ABS) Light



This light, and its related message, indicate possible malfunctions of the Anti-Lock Braking System (ABS).

The light will turn on when the ignition switch is in **RUN** position and may stay on for 4 seconds. If the ABS light remains lit or turns on while driving, the Anti-Lock portion of the brake system is not functioning and requires service. However, the conventional brake system will continue to operate normally if the  warning light is switched off. If the ABS light turns on while driving, or if it does not switch on when the ignition switch is in **RUN** position, please visit as soon as possible a

Service Centre in order to restore the Anti-Lock brakes functions.

Electronic Stability Control (ESC) Activation/Malfunction Indicator Light



The ESC activation/malfunction indicator light on the instrument cluster will display when the ignition switch is in

RUN position.

It should switch off by starting the engine.

If the light stays on with the engine running, there is a malfunction in the ESC system.

If the light still stays on after several ignition cycles, and the vehicle has been driven for several kilometers at more than 48 km/h (30 mph) visit the **Service Network** as soon as possible to have the problem diagnosed and restored.

NOTE:

*Each time the ignition switch is in **RUN**:*

- *The ESC OFF indicator light and the ESC activation/malfunction indicator light illuminates temporarily.*
- *The ESC system will be on, even if it was turned off previously. The ESC system will make buzzing or clicking sounds when active. This is normal; the sounds will stop when ESC*



becomes inactive by solving the problem that caused the ESC activation.

Electronic Stability Control (ESC) OFF Indicator Light



This indicator notifies that the Electronic Stability Control (ESC) is disabled (OFF); the linked message will be displayed.

displayed.

Telltales on Tachometer

Following telltales and linked messages are displayed on the tachometer on central sector of the display (see “TFT Display: Warning/Indicator Lights of Set Modes/Functions” in this chapter).



Gasoline



Diesel

Start&Stop Active Indicator



This telltale indicates that the engine has been switched off automatically by the Start&Stop system.

When the engine starts again, the telltale will switch off.

If the telltale during an automatic engine shutdown (AutoStop) phase starts flashing, it will be necessary to restart the engine normally with the ignition device while holding down the brake pedal.

See chapter “Normal Starting of the Engine” in section “Driving” for further information.

Rear Fog Light Indicator



This indicator lights up when the rear fog lights are switched on.

High Beam Indicator



This indicator lights up when the high beams are switched on or when blinking.

Brake Indicator Light



This light monitors various brake functions, including brake fluid level and parking brake engagement.

If the brake light illuminates the parking brake may be engaged, the brake fluid level may be low or a problem with the anti-lock brake system (ABS) reservoir may have occurred.

In all the above situations, a related message will be displayed.

If the light still illuminates when the parking brake has been disengaged, and the fluid level is at the full mark on the master cylinder reservoir, there could be a brake hydraulic system malfunction or a problem with the brake booster detected by the ABS/ESC system. If this occurs, the light will remain lit until the problem has been solved.

If the problem concerns the brake booster, the ABS master cylinder will run when engaging the brake and a brake pedal pulsation may be felt during each stop of the vehicle.



4

Inefficiency of one of the dual brake system cycles is indicated by the brake warning light, which will turn on when the brake fluid level in the master cylinder has dropped below a certain level.

The light will remain lit until the problem has been solved. If a brake failure occurs, visit the **Service Network** as soon as possible in order to check up the brake system.

In the event of an Electronic Brake Force Distribution (EBD) failure, both the brake indicator light and the ABS light illuminate.

Immediate repair of the ABS system is required.

Functioning of the brake warning light can be checked by turning the ignition switch from **OFF** to **RUN** position.

The light should illuminate for approximately 2 seconds.

The light should switch off unless the parking brake is engaged or a brake fault is detected. If the light does not illuminate, have the light system repaired by the **Service Network**.

The light will also switch on when the parking brake is engaged with the ignition switch in **RUN** position.

This light only indicates the brake is engaged but not the clamping force of the parking brake to the wheels.



WARNING!
Driving a vehicle with the red brake light on can be very dangerous. Part of the brake system may have failed, resulting in increased braking distances and the risk of an accident. Have the braking system checked as soon as possible at the **Service Network**.

Air Bag Indicator Light



This light will illuminate for a few seconds for a bulb check when the ignition switch is in **RUN**. If the light does not

illuminate while starting the engine, stays lit, or switches on while driving, have the system checked at the **Service Network** as soon as possible.

In the latter case, the message will remain displayed: to hide it, press the button ◀ on the steering wheel right side.



See “Supplemental Restraint System (SRS) – Air bags” in section “Before Starting” for further information.



WARNING!
If the warning light remains **ON** or if it does not illuminate or illuminates while driving, contact your **Service Network** as soon as possible.

Right Turn Signal Indicator



This indicator lights up when the right direction indicators or the hazard lights are switched on.

The indicator will flash at the same frequency of the turn indicators and is controlled by the turn signal lever. If the vehicle electronics sense that the vehicle drives for more than 1.6 km (1 mile) with either turn signal on, a



continuous sound will advise the driver to turn the signal off. If the indicator flashes at a fast rate, check for a defective outside indicator light bulb.

Seat Belt Reminder Light



When the ignition switch is in **RUN**, the seat belt reminder light will light up for a few seconds as a bulb check.

During the bulb check, you will hear an acoustic signal if one or both front seat belts are unbuckled.

After the bulb check or while driving, if a seat belt is unbuckled, together with the acoustic signal the seat belt reminder light will light up.



WARNING!

Maserati urges you to use the seat belts correctly fastened and adjusted at all times. Correct use of the seat belts can help reduce the risk of serious injury in the event of an accident. Do not pass seat belts over sharp edges: they could tear. Do not pin anything to the seat belts. This could reduce their initial strength and cause them to tear in the event of a crash.

Refer to “Occupants Restraint Systems” in section “Before Starting” for further information.

TFT Display: Menus and Settings


When operating, the TFT Display is divided into sectors including menus and submenus, running data, warning/indicator lights and messages. The different sectors of the display layout are rendered in the following picture.



- 1 Main area.
- 2 Selectable information (data, time, outside temperature, compass, etc.). When setting the “Automatic High Beam” feature (if equipped), in the left side of this area is displayed the respective indicator.
- 3 Main menu titles with scroll arrows (the number and the main menu title is always visible while scrolling the menu, and for the next five seconds).
- 4 Submenu Titles.
- 5 Position within the submenu and scroll arrows (example: 1 of 5). There can be maximum 9 displayable submenu positions. When the number of submenu points exceeds 9, the points are replaced by a numerical value within the scroll arrows.
- 6 Menu Instruction (hideable).
- 7 Shift lever positions (P, R, N, D, M, 1, 2, 3...).
- 8 Gear shift indicator light and paddles (if equipped).
- 9 Hard/Soft suspension indicator light.

- 10 Complete Odometer.
 - 11 Fuel Gauge.
 - 12 Engine Temperature Gauge.
 - 13* Reconfigurable quadrant for red telltales.
 - 14* Reconfigurable quadrant for amber telltales.
 - 15 Front fog indicator light.
 - 16 Low beam headlights/position lights.
 - 17 NORMAL, SPORT, I.C.E. and OFF ROAD modes indicator light.
 - 18* Combined ACC, LDW telltale: ACC gap, ACC car engaged and LDW status: LDW on (gray lines), LDW enabled (white lines) and LDW intervention (yellow flashing lines).
 - 19* CC, ACC, HDC status function.
 - 20 Ride height indicator.
 - 21 Electric Parking Brake failure warning light.
 - 22 Speed Warning indicator (dynamic text).
- (*) See "TFT Display: Warning/ Indicator Lights of Set Modes/ Functions" in this chapter.


The display background may change according to the type of message displayed.



- Blue color: normal conditions.
- Yellow color: low-critical warning.
- Red color: high-critical warning.

Main and Submenu


Operate the controls on the right side of the steering wheel to scroll, modify and program the Main and Sub-menu.



Press and release the multifunction switch in the ▲ and ▼ arrow directions to scroll upwards and downwards the main menu titles. The screen area in sector 1 (Main Area) will be updated and the selected title will be shown in sector 3 (Main Menu Title).

Press and release the multifunction switch (▶) to enter the information screens or a submenu. Keep the switch (▶) depressed for 2 seconds to restore the selected/visualized functions. The selected sub-menu title selected will be displayed in sector 4 (Submenu Title).

Within a submenu, press and release the switch in the ▲ and ▼ arrow directions to scroll the menu. Press the ◀ button to return to the main menu from an item of interest or from an information screen.





Main Menu & Submenu Content Overview

1. MAIN MENU

- View speed in km/h or mph

2. VEHICLE INFO

- Tire Pressure
- Transmission Temperature
- Oil Temperature
- Oil Pressure (Gasoline only)
- Battery Voltage
- AdBlue Level (Diesel only)
- Maintenance

3. DRIVE MODE

- Drive Mode - Ride Height - Torque Distribution - Powertrain status - ESC status - Suspension stiffness status

4. DRIVER ASSIST

- Shows the status of any active driver assist systems: CC, ACC, LDW and HDC. Graphics in the main area of TFT display only refer to ACC and LDW systems
- LDW (LaneSense) status

5. FUEL ECONOMY

- Average, Range, Current gauge

6. TRIP

- Trip A: Average, Avg. speed, Elapsed time, Distance

- Trip B: Average, Avg. speed, Elapsed time, Distance

7. START&STOP

- Messages relating to the Start&Stop function

8. AUDIO

- Information concerning audio status according to current media source, track and station.
- Information on phone incoming call.

9. STORED MESSAGES

10. VEHICLE SETTINGS

- Speed Warning: enables, disables or sets the speed limit represented in the dynamic icon on the TFT display
- Auto apply Off/On of the Electric Parking Brake
- Passenger Air bag enable/disable
- Interior Lighting
 - Backlighting
- SCREEN SETUP
 - Upper Left
 - Upper Right
 - Main Menu: Line 1
 - Main Menu: Line 2
 - Main Menu: Line 3
 - MPH km/h Display On/Off
 - Main Menu Navigation
 - Outline Colouring
 - Key-On Display

- Key-Off Display
- Defaults

Messages on Main Display Area

The main display area also displays "pop up" messages. These pop up messages fall into several categories:

• Five-Second Stored Messages

When the appropriate conditions occur, this type of message appears on the main display area for five seconds and then returns to the previous screen. Most of the messages of this type are then stored (as long as the condition that activated them remains active) and can be reviewed from the "Stored Messages" main menu item. Example of this message type is the one shown in the picture.



• Unstored Messages

This message type is displayed until

the condition that activated the message is cleared (see example in picture).



• Unstored Messages with Ignition Switch in RUN

This message type is displayed until the ignition switch is in **RUN** position. An example of this message type is the one shown in picture.



• Five-Second Unstored Messages

When appropriate conditions occur, this type of message appears on the main display area for five seconds then returns to the previous screen.

• Navigation Messages

When the navigation menu is enabled on the MTC+, information pop-ups will be displayed while changing direction or approaching a turning point until the navigation system requires its displaying, or until a command is given via the buttons on the steering wheel.

On highway, the first pop up will be displayed at 3.2 km (2 miles) from the turn, on roadway, at 1.6 km (1 mile).

While approaching the turn, further pop ups will be displayed starting at 400 m (0.25 miles) from the turning point and the countdown to 0 meters.



While getting closer to a turn, the sections referred to the distance already travelled will switch off while the ones referred to the distance yet to be travelled will remain on.

NOTE:

- *Popup boxes might take up the space normally used to display main menu items and relevant submenus.*
- *The distance indicated under the road name is expressed in the unit of measure set by the user.*

1. MAIN MENU

Press and release the multifunction switch in the ▲ or ▼ arrow directions until this menu item is displayed. Pressing and releasing the switch (▶) will toggle the unit of measure between km/h or mph.



Further to speed, the main area can indicate three lines that can be set to the same options and in the top right or top left area. When these three lines are present and turn-by-turn navigation is on, main menu area will automatically show navigation information. For further details, please refer to MTC+ guide.

2. VEHICLE INFO

Press and release the switch in the ▲ or ▼ arrow directions until this menu item is displayed.

Press and release the switch (▶) to access the submenus.

Press and release the switch in the ▲ or ▼ arrow directions to scroll through the following information displays pressing and releasing the switch (▶) to display the selected information.

• Tire Pressure

Indicates the pressure of each single tire (see example below). Please refer to “Tire Pressure Monitoring System (TPMS)” in section “Driving” for further information.



• Transmission Temperature

Displays the current transmission temperature level.

• Oil Temperature

Displays the current engine oil temperature level.



The gauge fill and telltale (if applicable) are highlighted in red to emphasise that the parameter is at a critical level.



NOTE:

This strategy is also applicable in the Transmission Temperature and Oil Pressure information screen.

• Oil Pressure (Gasoline only)

Displays the current motor oil pressure level.



• Battery Voltage

Displays the current battery voltage.

• AdBlue Level (Diesel only)

Displays both the level of reducing agent AdBlue® contained in the tank located in the luggage compartment and, if there is the need to refuel, the remaining range. For details on refilling or top-up, see chapter "Adding reducing agent AdBlue® (Diesel only)" in section "Driving".



Diesel

• Maintenance (service)

Displays mileage or days remaining to the execution of scheduled maintenance service.



Press and release the ◀ button to return to the main menu.

3. DRIVE MODE

Press and release the switch in the ▲ or ▼ arrow directions until this menu item is displayed. The screen graphically shows the Drive Mode (NORMAL, SPORT, I.C.E., and OFF ROAD) set by the user through the relevant controls.


The display main area will show vehicle image with parameters and color-coded components affected by the selected drive mode.

The image will show the following parameters:

- current ground clearance indicated in front of vehicle and on a specific indicator on top right corner;

- torque distribution percentage indicated under the arrow in front of the wheels;
- selected drive mode (in the example shown: I.C.E.).

For any color-coded components, color depends on settings of:

- ESC: identified by wheel color.
- PowerTrain: identified by engine + transmission unit color.
- Suspension  : identified by the color of the four shock absorbers.



For every drive mode, function (ESC, PowerTrain and Suspension) and color of the components shown are matched as follows:



Drive Mode	ESC	PT	
NORMAL			
Sport			
L.C.E.			
Off Road			

NOTE:

To set drive parameters according to own needs and path, refer to chapter "Drive Mode" and "Off-road Drive" in section "Driving".

Press and release the ◀ button to return to the main menu.

4. DRIVER ASSIST

Press and release the switch in the ▲ or ▼ arrow directions until this menu item is displayed.

- **Active Driver Assist System**

The screen graphically shows current status of driver assist systems: the figure shows an example with ACC set and LDW armed.



- **LDW (LaneSense) Status**

Vehicle is delivered with LDW in "Off" state set on MTC+ system.

You can enable LDW in the "Sound + Display" mode or disable it permanently (it means that maintains this condition even after a key-off/key-on cycle) by holding down the switch (▶) on the right side of the steering wheel (condition shown in picture). If LDW is enabled or disabled via MTC + system, after each key-off/key-on cycle the system returns to the previous state before turning off the vehicle.

**NOTE:**

To set these systems, see chapters "Adaptive Cruise Control - ACC (optional)" and "Lane Departure Warning - LDW (optional)" in section "Driving".

Press and release the ◀ button to return to the main menu.

5. FUEL ECONOMY

Press and release the switch in the ▲ or ▼ arrow directions until this menu item is displayed.

The screen will display the following:

- **Current Fuel Economy in l/100km or mpg**

Shows the current fuel economy. During AutoStop stage performed by the Start&Stop system (see "Normal Starting of the Engine" in section "Driving"), a dash will be displayed instead of the value.



• Range in km or miles

Shows the range since the last fuel average reset.

When the fuel economy is reset, the display will read "Reset" or show dashes for two seconds.

Then, the history information will be erased, and the averaging will continue from the last fuel average reading before the reset.

• Fuel Economy Average in l/100km or mpg

Shows the average fuel economy since the last reset.

Press the multifunction switch (▶) for 1 second and release it to reset the fuel economy average.

When the fuel economy is reset, the display will read "Reset" or show dashes for two seconds.

Then, the history information will be erased, and the averaging will continue from the last fuel average reading before the reset.



Press and release the ◀ button to return to the main menu.

6. TRIP

Press and release the switch in the ▲ or ▼ arrow directions until this menu item is displayed.

For each of the "Trip A" and "Trip B" sub-menus the screen will display the following:



• "Distance" traveled in km or miles.

Shows the total covered distance since the last reset.

• "Average" consumption in l/100km or mpg.

Shows the average fuel consumption since the last reset.

• "Average" speed in km/h or mph.

Shows the average speed since the last reset.

• "Elapsed Time"

Shows the total time of travel since the last reset in "hours:minutes:seconds." Elapsed Time will increment when the ignition switch is in the **RUN** or **START** position.

Press the multifunction switch (▶) for 1 second and release to reset "Trip A" or "Trip B".

"Trip B" is reset after each key on/key off cycle.

Press and release the ◀ button to return to the main menu.

7. START & STOP

Press and release the switch in the ▲ or ▼ arrow directions until this menu item is displayed.

With the ignition device in **RUN** position, the screen will display the statuses of the function (see example in picture). To change the status of the



function, please see paragraph “Automatic Start&Stop System” in “Normal Starting of the Engine” of section “Driving”.



8. AUDIO

Press and release the switch in the ▲ or ▼ arrow directions until this menu item is displayed. The screen will display the following:

- Audio Status



The display will show the audio status (source and current audio track) as set on the MTC+. It is possible to display 5 lines of 15 alphanumeric characters. Displays Audio Statuses are:





- **AM:** Station Number, provided with one line of info (frequency);
- **FM:** Frequency, provided with 2 info lines;
- **SAT** (Satellite radio), where available: number and station name, artist, song;
- **BTSA** Bluetooth: folder, album, artist, song;
- **USB** (Audio): USB, album, artist, current track or, if available, previous track, current track and next track;
- **USB:** folder, previous track, current track and next track;
- **SD Card** (Audio): album, artist, previous track, current track and next track;
- **SD Card:** folder, previous track, current track and next track;
- **AUX:** name of source, “Device Connected” text;
- **No Signal:** “No Signal Available” text;

- **Mute:** symbol “Mute”, the lines remain those displayed before the command “Mute”.

The different reception modes are identified by symbols, shown on the display above the info lines. The chart indicates their meaning.

	AM
	FM
	AUX
	SD
	SAT Radio (where available)
	DAB (where available)



	USB
	<ul style="list-style-type: none"> • Many signals • Signal not available
	BTSA
	Audio mute

• Phone Call Details

The display will show the information on incoming call if this feature is checkmarked on MTC+ (see "MTC+ Settings" in this section). On display, said details shall temporarily replace the ones on media source in use.

Press and release the ◀ button to return to the main menu.

9. STORED MESSAGES

Press and release the central switch in the ▲ or ▼ arrow directions until this menu item is displayed.

The system will either display the number of the stored messages (if any available) or "No Stored Messages" as shown in picture.



Press and release the switch in the ▲ or ▼ arrow directions to scroll the stored messages.

When the number of messages exceeds 9, the submenu points will be replaced by a numerical value indicating the message number. Press and release the switch (▶) to view the selected message (see example in the picture).



Press and release the ◀ button to return to the main menu.

10. VEHICLE SETTINGS

With ignition switch in RUN position and vehicle stopped, press and release the switch in the ▲ or ▼ arrow directions until this menu item is displayed.

Press and release the switch (▶) to access the submenus.

Scroll with the switch in the ▲ or ▼ arrow directions to view the selectable items:

- Speed Warning
- Electric Parking Brake
- Passenger Air bag (if foreseen)
- Interior Lighting
- Screen Setup

**NOTE:**

- In order to modify the status of electric parking brake, please see chapter “Parking Brake” in section “Driving”.
- In order to modify the status of passenger air bag, please see paragraph “Passenger’s Air bag Deactivation (if foreseen)” in “Supplemental Restraint Systems – Air bag” in section “Before Starting”.
- Adjust interior lighting brightness or/and ambient lighting as described in paragraph “Interior Lights” under “Lights” in section “Understanding the Vehicle”.

Example: How to modify the “Speed Warning” status**NOTE:**

When the vehicle is in motion (above 8 km/h – 5 mph) this function is available and displayed in the list of “Vehicle Settings” menu.

Scroll with the switch in the ▲ or ▼ arrow directions to view the selectable items.

Press and release the switch (▶) to select “Speed Warning”.



Press and release the switch (▶) once again to view the related options: “Off” is the default status.



Scroll with the switch in the ▲ or ▼ arrow directions to view the selectable options.

Speed values are in loop, keeping the switch pressed in the ▲ or ▼ arrow directions will increase scroll speed. Press and release the switch (▶) to select the option. A check mark will

remain next to the previously-selected item until a new selection is made.



A setting saved notification appears as a popup for 2 seconds and a white telltale indicating the set speed limit will appear on display.



Then the display will show the last modified item.

When the set speed is exceeded, the driver is alerted by an acoustic signal and the telltale indicating the speed limit becomes amber.



A pop-up message indicating that the limit has been exceeded will appear on display.



The pop-up message and the telltale will be displayed for 5 seconds then system will return to the previous screen.

SCREEN SETUP

After having entered the "Vehicle Settings" menu, press and release the switch in the ▲ or ▼ arrow directions until this menu item is displayed. Press and release the switch (▶) to access the available items for this submenu.

If the vehicle exceeds 8 km/h (5 mph), this feature is unavailable and the main screen shows possible options in grey (not activable).

Operate this function with the vehicle stopped and transmission in P (Park) position.

In order to enter a function, press the switch (▶).

The following directory shows the items available in the "Screen Setup" submenu:

Upper Left

- None
- Compass (only with navigation system)
- Outside Temperature (default: Upper Right)
- Date
- Time
- Time/Date (default: Upper Left)
- Range to Empty
- Average l/100km (or MPG)
- Current l/100km (or MPG)
- Trip A Distance
- Trip B Distance

Upper Right (example in picture)

- None
- Compass (only with navigation system)
- Outside Temperature (default: Upper Right)
- Date
- Time
- Time/Date (default: Upper Left)

- Range to Empty
- Average L/100km (or MPG)
- Current L/100km (or MPG)
- Trip A Distance
- Trip B Distance



Main Menu: Line 1

(only displays in Main Menu)

- None (default status)
- Compass (only with navigation system)
- Outside Temp.
- Date
- Time
- Time/Date
- Range to Empty
- Average L/100km (or MPG or km/L)
- Current L/100km (or MPG or km/L)
- Trip A Distance
- Trip B Distance



- Audio

Main Menu: Line 2

(only displays in Main Menu)

- Same configurable options as Line 1

Main Menu: Line 3

(only displays in Main Menu)

- Same configurable options as Line 1

MPH km/h Display

(instruction line)

- On
- Off

Main Menu Navigation

- On
- Off

Outline Colouring

- On
- Off

Key-On Display

- On
- Off

Key-Off Display

- On
- Off

Defaults

- Restore
- Cancel

Scroll with the switch in the ▲ or ▼ arrow directions to view the selectable items (in the example “Time” is

selected). A check mark will remain next to the previously-selected item until a new selection is made.



Press and release the switch (▶) to select an item. The notification of setting saved appears as a popup for 2 seconds, then the display will show the last-modified item.



Press and release the ◀ button to return to the “Screen Setup” submenu.

“Screen Setup” submenu parameters set by the user as the ones to be displayed are also indicated in the top part of the MTC+ (see example in the figures).



As for the instruction line “MPH km/h Display”, you can either select to display it in sector 6 or not (“Off” option). In the latter case, the function of changing units remains in any case active.



If the "Main Navigation Menu" is set to "On", navigation information will be displayed in the main area of the display only if a destination has been set on the navigator of the MTC+. If function is set to "Off", the navigation information will not be displayed.

If the "Outline Colouring" is set to "On", the TFT side edge of engine temperature and fuel gauge indicators will change color depending on the selected Drive Mode:

- Sport: green (example shown in picture);
- I.C.E.: light blue;
- Off Road: brown.

If it is set to "Off", the color/Drive Mode combination is not active and the edges will remain "Normal" Drive Mode color.



"Key-On Display" and "Key-Off Display" items allow user to set display during vehicle key-on and off.

"Key-On Display" is normally set to "On". When entering the vehicle, after the welcome screen, the display will show the information concerning engine starting sequence. While if it is set to "Off" (example shown in figure), the display will show the information displayed before last vehicle key-off.



When engine is started and ignition device is pressed to stop it, it is possible to set "Key-Off Display" to obtain the following display settings:

- On: "Trip Summary" screen is displayed before engine off and key-off (Trip B is reset after each key-on/key-off cycle);
- Off: no screen is displayed before engine off and key-off.

The "Defaults" item of "Screen Setup" submenu allows restoring Maserati factory settings.

TFT Display: Warning/Indicator Lights of Set Modes/Functions

Display sections indicated in the figure show warning/indicator lights concerning all selected driving functions and all set functions/systems. The relevant messages will be indicated within the main area for five seconds, unless otherwise specified. Fault messages will be stored under "Stored messages".

Charging System Warning Light



This warning light shows the status of the electrical charging system. If the warning light stays on or comes on while driving, turn off some of the vehicle's non-essential electrical devices or increase engine speed (if at idle). If the charging system warning light remains on, it means that the vehicle is experiencing a problem with the charging system. Require IMMEDIATE service at the **Service Network**.



If jump starting is required, refer to “Jump Start Procedures” in section “In an Emergency”.

Transmission Temperature Warning Light



This warning light and the related message indicate that the transmission fluid temperature is rising.

If this warning light turns on, safely pull over and stop the vehicle. Then, shift the transmission into P (Park) and run the engine at idle or faster until the temperature drops and the light switches off. If the problem persists, contact the **Service Network**.



CAUTION!

Continuous driving with the

transmission temperature warning light illuminated will eventually cause severe transmission damage or failure.



WARNING!

If the transmission temperature warning light is illuminated and you continue operating the vehicle, in some circumstances you could cause the fluid to boil over, come in contact with hot engine or exhaust components and cause a fire.



Gasoline

Engine Temperature Warning Light



This warning light notifies when the engine is overheated. If the temperature reaches critical levels and the gauge displayed in sector 12 turns red, this warning light under the engine temperature gauge indicator will illuminate in red color combined with the related message on display. When the temperature is reaching the set threshold an acoustic signal will be heard.

If the warning light switches on while driving, safely pull over and stop the vehicle. If the A/C system is on, turn it off. Also, shift the transmission into N (Neutral) and idle the vehicle. If the

temperature does not return to normal, immediately turn the engine off and contact the **Service Network**. Check “Engine Overheating” in section “In an Emergency” for more information.

Low Oil Pressure Warning Light



Under normal conditions, the warning light illuminates when the ignition device is

turned to **RUN** and goes off as soon as the engine is started. If the warning light stays or turns on while driving, the engine oil pressure is too low. The warning light is combined with a displayed message and an acoustic signal that will last 4 minutes. In this case, turn the engine off immediately and carry out the necessary checks.

Do not operate the vehicle until the problem has been corrected. This light does not indicate the oil level. The engine oil level must be checked with the dipstick located under the hood (see “Maintenance Procedures” in section “Maintenance and Care”). If the problem persists, contact the **Service Network**.

Engine Oil Temperature Warning Light



This light indicates that the engine oil is overheated. The warning light is combined with the related displayed message. In this case, drive carefully until the temperature drops back to normal level and the warning light indicator turns off. If the problem persists, contact the **Service Network**.

Low Engine Oil Level Warning Light



This warning light and the related displayed message, indicate a low engine oil level. The engine oil level must be checked with the dipstick fitted under the hood (see “Maintenance Procedures” in section “Maintenance and Care”).



Diesel



Power Steering Failure Warning Light



This warning light, and the related message, illuminate when the power steering is not operating and needs

service.

If the problem persists, contact the **Service Network**.

Catalyst Over Temperature Warning Light



This warning light, and the related message, light up if the engine runs irregularly with consequent high

temperature in the exhaust system.



WARNING!

- If the warning light is accompanied by the message “Catalyst Temp Getting Hot Reduce Speed”: the temperature of the catalytic converters is too high. The driver must slow down immediately until the warning light turns off.
- If the message “Catalyst Temp Hot Stop Safely Wait To Cool” appears after decelerating: the temperature in the catalytic converters has reached a dangerous level and the catalytic converters could be

damaged. Drive slowly to the nearest workshop.

- Maserati declines all responsibility for whatever damage deriving from non-compliance with the above mentioned warnings.

Door Ajar Indicator



This indicator illuminates when one or more doors are ajar. The indicator will show which door is ajar. When one or more doors are open, a related message will be displayed if the vehicle is running at a speed of 8 km/h (5 mph) or faster.

Liftgate and Hood Ajar Indicators



These light indicators will illuminate to indicate that the liftgate and/or the hood are ajar.



When the liftgate or the hood is open, a related message will be displayed besides the light

if the vehicle is running at a speed of 8 km/h (5 mph) or faster.

Low Fuel Indicator



When the fuel level reaches approximately 16.0 litres (3.5 UK gal) this light under the fuel gauge indicator will turn

on, and remain on until fuel is added together with the related message. In this condition the color indicating the quantity of fuel in the tank, inside the indicator on display, will go from white to amber.

Refer to “Refuelling” in section “Driving” for fuel filling.

Windshield and Headlights Washer Low Fluid Indicator



This indicator will illuminate for 5 seconds to indicate a low level of the windshield and headlights washer fluid. A related message will be displayed. See “Maintenance Procedures” in section “Maintenance and Care” for fluid filling.

Adaptive Light Control System Failure Warning Light



This warning light, and the related message, indicate a failure of the automatic headlight aiming system.

Please contact the **Service Network** to check the system.

Suspensions Failure Warning Light



This warning light and the related message turn on while driving if there is a failure of the suspension system.

Please contact the **Service Network** to check the system.

Ice Hazard Indicator



When the external temperature falls below 3°C (38°F), the temperature value blinks for a few seconds, the indicator light turns on, a message is displayed and an acoustic signal is triggered to warn the driver of the risk of icy roadbed.

Under such conditions, we recommend using the I.C.E. drive mode (see “Automatic Transmission” in section “Driving”) drive carefully and slow down as the grip of the tires may be significantly reduced.

The indicator light flashes for 5 seconds and switches off when the temperature reaches 6°C (43°F) or higher.

Brake Pads Wear Warning Light



This warning light and the related message indicate that the brake pads have reached their wear limit.

Please contact the **Service Network** to have them replaced.

Electric Parking Brake Failure Warning Light



This warning light and related message illuminate when there is an EPB system failure.

The failure could also completely or partially block the vehicle because the parking brake could remain on even after it has been automatically or manually disengaged though its controls.

If it is still possible to use the vehicle (parking brake not engaged) drive to the nearest **Service Network** and remember to perform each operation/command during which the electric parking brake does not work.

Start&Stop Disable Indicator



This indicator illuminates when Start&Stop is turned off through the controls located

on the right side of the steering wheel. See paragraph “Automatic Start&Stop System” in chapter “Normal Starting of the Engine” of section “Driving” for further information.

Start&Stop Failure Warning Light



This warning light illuminates when there is a failure in the Start&Stop system. Switch the

engine on or off using the normal procedure with the ignition device **START/STOP** and have the vehicle checked at a **Service Network**.

Scheduled Maintenance (Service) Indicator



This indicator illuminates and a message flashes on the display for approximately 5 seconds after an acoustic signal to indicate that the next scheduled maintenance is due or has already overdue.

Unless reset, the message will continue to display each time you cycle the ignition to the **RUN** position.

To turn off the message temporarily, press and release the ◀ button on the steering wheel. To reset the service indicator system, please visit a **Service Centre**.

Passenger's Air bag Deactivated Indicator (if equipped)



This warning light switches on when the passenger's airbag is deactivated. See

“Supplemental Restraint System (SRS) — Airbags” in section “Before Starting” for further details.



Wait to Start Indicator (Diesel only)



This indicator will turn on when the ignition device is first turned to the **RUN** position.

Wait until the Wait to Start indicator turns off to start the engine. Refer to “Normal Starting of the Engine” in section “Driving” for further details.

Water in Fuel Indicator (Diesel only)





It indicates there is water detected in the fuel filter. If this light remains on, **DO NOT** start the vehicle before you drain the water from the fuel filter to prevent engine damage.

Contact the **Service Network** for inspection and draining of the fuel filter.



CAUTION!

The presence of water inside the fuel system can damage the injection system and cause engine's malfunction. If the  warning light turns on, you shall contact the **Service Network** as soon as possible to have the fuel filter cleaned. If, after a refueling, the  warning light turns on, some water could have entered the fuel tank: in this case, turn off the

engine immediately and contact the **Service Network**.

Low AdBlue® Indicator (Diesel only)



This indicator will turn on to indicate the AdBlue® is low (for more details see paragraph “Messages

Concerning the AdBlue® Injection System (Diesel only)” in this chapter.

Adaptive Cruise Control (ACC) and Lane Departure Warning (LDW) Status Indicators



The indicators at top left-hand side of the display indicate status of individual system (see examples) or the combination of both.



For further details, refer to “Adaptive Cruise Control - ACC (optional)” and “Lane Departure Warning - LDW (optional)” in section “Driving”.

Forward Collision Warning (FCW) Off



This warning light informs the driver that Forward Collision Warning (FCW) is disabled.

This might occur when front sensor and/or the ACC/FCW system sensors are malfunctioning and need cleaning or servicing and when ACC/FCW system is not available due

to a system error (for further details, refer to “Adaptive Cruise Control - ACC (optional)” in section “Driving”). This warning light will light even when the activation of another driver assistance feature or drive mode (such as “Off Road”) disables the FCW.

Forward Collision Warning (FCW) Fault



If the Forward Collision Warning (FCW) system turns off and this warning light is displayed together with the

specific message, there could have been a system fault requiring servicing at the **Service Network**. It is nevertheless possible to drive the vehicle without using this function (for further details, refer to “Forward Collision Warning - FCW with Braking Action (optional)” in section “Driving”).

General Fault for Driving with a Trailer



The warning light and the relevant message are displayed to indicate a fault or failure of the connection

between vehicle and trailer. In these cases please contact the **Service Network** as soon as possible, and avoid using the vehicle with a trailer.

AWD Failure Warning Light



This warning light turns on to indicate a fault of the AWD system. Contact the **Service Network** as soon as possible, and avoid using the vehicle in heavy duty conditions.

Set Passive Speed Limit



This warning light indicates the passive speed limit set via the controls on the RH side of the steering wheel (for further details, refer to "TFT Display: Menus and Settings" in this chapter).

Passive Speed Limit Exceeded



This warning light informs the driver that the speed limit that was set has been exceeded.

Suspension Setting Indicator



This indicator indicates the damping level of suspension set by the user through the button on central console, next to shift lever: Soft or Hard. For further details, refer to "Drive Mode" in section "Driving".

Set Drive Mode Indicator



Drive mode set by the driver through the controls on central console is displayed above the transmission lever indicator.



For further details, refer to "Drive Mode" in section "Driving".



Ride Height Indicator for Vehicle Setup



Ride height set through the control on central console is always displayed in the specific area on the RH side of the TFT display. From the "Normal" level (shown in picture) ride height can be lowered at "Aero 1" or "Aero 2" levels when using vehicle on the road. When using the vehicle off road, ride height can be set to a higher position thanks to "Off Road 1" or "Off Road 2" levels. For further details, refer to "Drive Mode" and "Off-road Drive" in section "Driving".



The lowest position "Entry/Exit" shown in picture is used for entering and exiting the vehicle.

Cruise Control (CC) Ready



This white light will illuminate when the CC is ready to be set and, once it sets, to turn it off temporarily. For further information, check "Electronic Cruise Control" in section "Driving".

Cruise Control (CC) Set



This green light will illuminate when the CC is set. For further information, check "Electronic Cruise Control" in section "Driving".

Lane Departure Warning (LDW) Fault



This warning light on indicates that the LDW system is in fault. If the warning light and the relevant message do not go off after a few manoeuvres, contact the **Service Network**.



Adaptive Cruise Control (ACC) Ready



This white light indicates that the ACC is ready to be set and, once it sets, turn it off temporarily. For further details, refer to “Adaptive Cruise Control - ACC (optional)” in section “Driving”.

Adaptive Cruise Control (ACC) Set



This green light with below the set speed turns on when the ACC is set (for further details, refer to “Adaptive Cruise Control - ACC (optional)” in section “Driving”) and vehicle will keep set speed.

Adaptive Cruise Control (ACC) Fault



This warning light turns on when ACC is not operating or needs servicing. For further details, refer to “Adaptive Cruise Control - ACC (optional)” in section “Driving”.

Hill Descent Control (HDC) Ready



This white light turns on to indicate that HDC is ready to be set and, once it sets, to turn it off temporarily. For further details, refer to “Brake and Stability Control System” in section “Driving”.

Hill Descent Control (HDC) Set



This green light with below the set speed turns on when the HDC is set. For further details, refer to “Brake and Stability Control System” in section “Driving”.

Park/Headlight On Indicator



This indicator will illuminate when the park lights or headlights are turned on. For further details, see “Lights” in section “Understanding the Vehicle”.

Front Fog lights On Indicator



This indicator turns on when the fog lights are on.

Automatic High Beam On Indicator



This indicator turn on when the “Automatic High Beam” feature is set on MTC+ (see “MTC+ Settings” in this section).

Gear Shift Indicator Light



This indicator lights up to indicate gear shift change in order to optimise fuel consumption. See “Drive Mode” in section “Driving” for further information.

Service AWD System Message

The message on the TFT display will illuminate when all-wheel drive feature requires service. For further information refer to “All-Wheel Drive” in section “Driving”.



DPF System Messages (Diesel only)

Under conditions of exclusive short duration and low speed driving cycles, the engine and exhaust after-treatment system may never reach the conditions required to remove the trapped Particulate Matter (PM). If this



occurs a message will be displayed on the TFT display first time when driving for 10 seconds and are repeated each time the vehicle is started, accompanied by a single acoustic signal. By driving your vehicle at highway speeds for as little as 30 minutes, you can remedy the condition in the particulate filter system by allowing the trapped PM to be removed to restore the system to normal operating condition. Carefully follow the indications shown on the display until regeneration is completed (see examples).

4




Diesel



Diesel



Diesel

If the exhaust after-treatment system requires service intervention, a message and the Malfunction Indicator Light (MIL)  will be displayed to alert the driver.



CAUTION!

- Prolonged driving with the MIL on inhibits the regeneration process with possible DPF clogged.
- Maserati is not responsible for defects occurring due to not performed DPF regeneration process.



Diesel


In this condition the engine will be derated to prevent permanent damage to the after-treatment system. If this condition occurs, it is necessary to have your vehicle serviced by your local **Service Network**.

Messages Concerning the AdBlue® Injection System (Diesel only)

Suitable messages displayed on the TFT display indicate when the system



needs servicing, or AdBlue® needs to be added to the tank in the boot compartment.

When the system requires servicing, in addition to the message the Malfunction Indicator Light  is also displayed. In these cases, as indicated on the message reported in figure, contact the **Service Network**.




Diesel



Diesel

When AdBlue® needs to be added to the tank, its messages are displayed first time when driving for 10 seconds and are repeated each time the vehicle is started, accompanied by a single acoustic signal.

The mileage reported on some of these messages indicates the remaining range of AdBlue® which is continuously updated and made visible at each next start up. This mileage is the result of an estimated consumption that depends on the type of use of the vehicle. Therefore it is appropriate to refuel as soon as possible.

When the estimated range of AdBlue® is less than 2400 km (1500 mi) on the instrument cluster display an early warning about AdBlue® level low appears: it is suggested to refuel AdBlue® as soon as possible. When the estimated range is less than 1500 km (932 mi), the  warning light comes on.

When the mileage displayed reaches 600 km (360 mi), the messages will be displayed continuously unless other warnings come up (i.e. safety related messages).

When the indicated range is less than 1 km (0.6 mi), if the engine is switched off the car can no longer be started: in

this case we suggest you not to switch off the engine and to refuel preventively AdBlue®

NOTE:

In case of exhaustion of AdBlue® the vehicle, once the engine has been turned off, will not restart: refuel AdBlue® regularly (see chapter "Adding reducing agent AdBlue® (Diesel only)" in section "Driving").

It is important that you follow the displayed instructions closely otherwise the engine may not restart after it stops. A few example messages are reported in the figure. Messages are stored in "Stored Messages".



Diesel



Diesel

Infotelematic System

The vehicle is equipped with the infotelematic Maserati Touch Control Plus (MTC+) System, an advanced user interface which combines innovative and exclusive technical features integrating entertainment, user settings, air conditioning, navigation, communication and information features within a single system. The MTC+ System features an audio system which is acoustically optimised for this specific vehicle.



The vehicle is provided with a specific add to the owner's manual, describing the MTC+ System features and listing all warnings and precautions, which are essential for a safe use of the system. Maserati advises you to read this add carefully and thoroughly. The MTC+ display is positioned in the central part of the dashboard and the manual controls and devices for connecting external sources are positioned on the central console.



WARNING!

The navigation system assists the driver while driving, providing advice and suggestions, by voice guidance and graphic information, for the best route to reach the set destination. The suggestions provided by the navigation system do not relieve the driver from full responsibility for the manoeuvres made through traffic while driving, or from compliance with road regulations and other provisions regarding road traffic. The person driving the vehicle is always and in any case responsible for safe driving on the road.



1. MTC+ touch display.
2. Ports for SD card, AUX and USB (for further details, refer to “Interior features” in section “Understanding the Vehicle”).
3. “Browse” button .
4. “Back” button .
5. “Enter” button.
6. Volume control.
7. Tune/scroll control.



Manual Controls and Devices

SD, AUX and USB Ports

When an SD card is inserted into its housing, the MTC+ is able to read it and select multimedia files (music and images) from the device.

By using the AUX and USB ports it is possible to connect external devices to the MTC+ (see chapter “Interior features” in section “Understanding the Vehicle”).

After connecting the device, by using the MTC+ display soft-keys, knobs on the central console and controls at the steering wheel, user can navigate through the content of the connected device and set its playing mode.


Multimedia Navigation Controls on Central Console

The manual controls located on the central console are a further interface for the driver and nearby passenger, that adds to the MTC+ display soft-keys. Using the manual controls, the MTC+ display will work as a graphic display of the inputs from the controls.

Volume Control

By working this knob in “Radio” or “Media” mode, user can adjust the volume of the radio or audio files,

from minimum to maximum and vice versa. Turn knob clockwise to increase the volume, counter-clockwise to decrease it. The volume status will be indicated in the top part of the MTC+ display.



Tune/Scroll Control

By working this knob in “Radio” or “Media” mode, user can go through the radio stations or scroll the tracks inside connected external devices and confirm the selection by pressing enter button.

In any other mode of the MTC+, use this knob to scroll the list of available options or to manage the cursor movement in the lower bar of the main menus. Then press enter button to confirm the function or setting highlighted on MTC+ display.



Browse button

After selecting a function, using the tune/scroll knob or soft-keys on MTC+ display, press this button to see the detail of the items/options of the selected function. This button is also used as short cut to display the phone book, when the "Phone" menu is selected, or the favourites when the "Nav (Navigation)" menu is selected.

Back button

Press this button to go back to previous menu or previous screen. Press this button to shift the navigation one level backwards on MTC+ screen. If it is pressed and held for at least 2 seconds, it brings the cursor back in the lower bar of the main menus.

Enter Button

To confirm the function or setting highlighted on MTC+ display.

Main Menu Bar on MTC+ Display

The soft keys located on the lower part of the MTC+ display represent the main menu modes/functions, which are briefly indicated below.



MTC+ with Navigation System



MTC+ without Navigation System

Main menu bar is set up by Maserati: it can be customised according to personal requirements, as explained in "Customising the Main Menu Bar" in this chapter.

For further information refer to the dedicated booklet included in the owner documentation.

1. "Radio" soft-key

Touch this soft-key to enter the Radio mode. The different tuner modes: FM, AM, MW, LW, SW, DAB, DAB+, DMB and "Aha" App (for countries where it is supported) can be selected by touching the related soft-keys in the Radio mode.

2. "Media" soft-key

Touch this soft-key to access media sources such as: USB Device, AUX, Bluetooth and SD card as long as the requested media is present.

3. "Controls" soft-key

Touch this soft-key to access the controls that can be set up. Controls such as: Heated Seats, Heated Steering Wheel, Ventilated Seats, etc. can be selected and adjusted or turned on/off by touching the related soft-key.

4. (Apps) soft-key

Touch this soft-key to access connected phone connection options and user functions settings.

5. "Climate" soft-key

Touch this soft-key to access the air conditioning settings. See "Air Conditioning Controls" in this section for further details.



6. "Nav" soft-key (if equipped)

Touch this soft-key to access the Navigation feature. Refer to the MTC+ instruction manual for further details.

7. "Phone" soft-key

Touch this soft-key to access the MTC+ Phone feature that can be set or monitored via MTC+.

8. "Screen Off" soft-key (default position only for MTC+ without navigator).

Touch these soft-keys to access the list of functions that the user can set.

Touch screen Display Warnings



CAUTION!

- Do NOT attach any object to the touch screen, doing so can result in damage to the touch screen.
- Do not press the screen with any hard or sharp objects (pen, USB stick, jewelry, etc.) which could scratch the touch screen surface.
- Do not spray any liquid or caustic chemicals directly on the screen. Use a clean and dry micro fiber lens cleaning cloth in order to clean the touch screen.

- If necessary, use a lint-free cloth dampened with a cleaning solution, such as isopropyl alcohol, or an isopropyl alcohol and water solution ratio of 50:50. Be sure to follow the solvent manufacturer's precautions and directions.

Switch OFF Touch screen Backlight

If the screen backlight becomes annoying when driving, it is possible to switch it off.

Switch off the screen backlight by touching "Screen OFF" soft-key in the main menu bar or in "Controls" screen (shown in picture) of MTC+ display.



Customising the Main Menu Bar

The soft-keys for the main functions of the MTC+ system, indicated at the bottom of the MTC+ display, can be

easily customised to suit user's requirements, as follows:

- press Ψ button to open applications/settings screen;
- hold depressed and drag the icon corresponding to the selected function until it overlaps the one to be replaced on the bottom bar.



Once it is set in the menu bar, the new connection will be immediately operational.



Use the MTC+ Display as Projection Device

If your smartphone is properly connected to the vehicle via the USB port, in the Ψ (Apps) screen in place of "Phone" soft-key and in the source list of "Media" screen you can find the "Apple CarPlay" (example shown in picture) or the "Android Auto" app soft-key (according to the MTC+



System installed). “Android Auto” app needs to be downloaded on your mobile device.



Play Music. It also offers the possibility to make phone calls or send and receive messages without taking your hands off the steering wheel. You can also request Google to make any type of research. Android Auto will give an easier access to applications and content from the MTC+ system display. The following tables show the “Screen” and “Audio” source (of projection device  or of MTC+ System ) when a smartphone is connected, a session is established and the device (Table A) or the MTC+ System (Table B) is performing an action.

These applications use the MTC+ display as projector of the functions available on the connected device. “Apple CarPlay” allows the best use of your iPhone® in the car and perfect integration with the MTC + display and with the controls of the car, including Siri voice control. You can make phone calls, access music, send and receive messages, get real-time directions on traffic conditions, all while staying focused on the road. The “Android Auto” app lets you share information while driving and make it easier to access Google. The interface is equipped with Google Maps with voice guided navigation, traffic information in real time, on-demand access to millions of songs in Google

4























































Table A: device is performing an action

Action	MTC+ System : Active Mode				
	 Radio	 Media	 Navigation	 Phone	 Voice Rec.
No App active	Screen: Audio:	Screen: Audio:	Screen: Audio:	Screen: Audio:	Screen: Audio:
Start Media Player	Screen: Audio:	Screen: Audio:	Screen: Audio: +		Screen: Audio:
Start Navigation	Screen: Audio: + Audio priority	Screen: Audio: + Audio priority	Popup to ask which Nav to use		Screen: Audio: + Audio priority
Start Phone Call	Screen: Audio:				
Start Voice Rec.	Screen: Audio:	Screen: Audio:	Screen: Audio:	Screen: Audio:	Screen: Audio:



Table B: MTC+ is performing an action

Action 	Device  : Active Mode				
	No App active	Media	Navigation	Phone Call	Voice Rec.
Start Radio	Screen:  Audio: 	Screen:  Audio: 	Screen:  Main Audio:  + mix  prompt nav	Screen:  Audio: 	Screen:  Audio: 
Start Media Player	Screen:  Audio: 	Screen:  Audio: 	Screen:  Main Audio:  + Audio priority	Screen:  Audio: 	Screen:  Audio: 
Start Navigation	Screen:  Audio: 	Screen:  Main Audio:  + Audio priority	Popup to ask which Nav to use	Screen:  Audio:  + Audio priority	Screen:  Audio:  + Audio priority
Start Phone Call	Screen:  Audio: 				
Start VR 	Screen:  Audio: 	Screen:  Audio:  + Audio priority	Screen:  Audio:  + Audio priority	Cannot start VR during Call	Screen:  Audio: 
Start Rearview Camera	Screen:  Audio: 	Screen:  Audio: 	Screen:  Audio: 	Screen:  Audio: 	Screen:  Audio: 

4



Audio Controls

The vehicle is equipped with audio controls that allow both driver and front passenger to operate the audio system. These controls can be used to adjust audio volume, change radio station or mode (FM, AM, USB, etc).

Steering Wheel Audio Controls

These audio controls are rocker-type switches with a button in the center and are located on the rear side of the steering wheel, right behind the front switches.



Press any button to display information on the radio station or track being listened to inside a pop-up for 2 seconds on instrument cluster. The right-hand control manages the volume.

By pressing the top of the rocker switch you can increase the volume and by pressing the bottom of the rocker switch you can lower it. Press the center button to mute the volume. The left-hand control functions depend on the current source. To change source, press the center button.

When in “Radio” mode, pressing the top of the switch will “Seek” up for the previous listenable station and pressing the bottom of the switch will “Seek” down for the previous listenable station.

When an external source is connected to MTC+, a light press on the top of the switch will play the next track on the device connected.


Press the bottom of the switch once to go to the beginning of the current track, or to the beginning of the previous track if it is within one second after the current track begins to play.

If you press the switch up or down twice, it plays the second track; three times, it will play the third one, etc.

Audio Controls on Central Console

In “Radio” mode, turn the volume upper knob to set the audio volume, or turn the tune/scroll bottom knob to tune station.



For further details, refer to “Infotelematic System” in this section. When in App/Settings mode, the tune/scroll bottom knob and the browse  and enter buttons allow you to scroll through the menus and change the user’s settings (see “MTC+ Settings” in section “Dashboard Instruments and Controls”).

Audio System

The vehicle is equipped with an audio system that offers superior sound quality, higher sound pressure levels and reduced energy consumption. The system maximises the amplifier and speaker technology delivering substantially higher components and system efficiency.

Basic System

The basic sound system features 8 speakers and can develop a sound output of 280 W.

The basic system includes:

- Four 165 mm (6.5 in) diameter Woofers, one on each door.
- Four 25 mm (1 in) diameter Tweeters, one at the base of the windshield side pillars and one on each rear door.



Basic System

Premium System

The vehicle can be equipped with a "Premium" sound system which features 14 speakers and can develop a sound output of 900 W.

This system includes:

- Four 160 mm (6.3 in) diameter Woofers, one on each door.

- Five 80 mm (3.1 in) diameter Midrange: one on the top of the dashboard, one on each front door panel and one on each side wall of the boot, above the cover level.
- Four 25 mm (1 in) diameter Tweeters: one at the base of the windshield side pillars and one on each rear door.
- One bass box in the boot, under the front part of the floor.
- 12-channel amplifier positioned in the wall of the boot left side.



Premium System

High Premium System

The vehicle can be equipped with a “High Premium” audio system including 17 speakers and 1280 W of sound power, available upon request.

The “High Premium” system includes:

- Four 165 mm (6.5 in) Woofers: one on each door.
- Five 100 mm (4 in) Midranges: one on center dashboard, one on each

front door and one on each side wall of the boot, above the cover level.

- Seven 25 mm (1 in) Tweeters: one on center dashboard, one at the base of the windshield side pillars, one on each rear door and one on each side wall of the boot, above the cover level.
- One bass box in the boot, under the front part of the floor.
- 16-channel amplifier positioned in the wall of the boot left side.



High Premium System

The “High Premium” sound system is supplied with a 12-channel high-efficiency amplifier and is operated by a high-voltage tracking power supply and drives a 7.5-channel playback architecture. This audio system offers the ability to choose Logic 7[®] surround-sound for any audio source. The high-efficiency speaker design ensures higher Sound Pressure



Level (SPL) and exceptional dynamic sound quality.

The speakers are tuned for maximum efficiency and compatible with the amplifier output stage ensuring best updated surround sound processing. Logic 7® multichannel surround sound technology delivers an immersive, accurate sound stage throughout the passenger compartment.

This surround effect is available from any audio source - AM/FM/Satellite Radio or AUX and USB input; and is activated through the MTC+ System controls. By selecting "Audio Surround", you can activate the Logic 7® multichannel surround-sound technology in your vehicle. All information on the current operational mode can be found in the specific booklet visible on the MTC+ screen.

When in "Audio Surround" mode, balance is set automatically. Fader control is available in surround mode but it should be set to the center position for optimal surround performance.

MTC+ Settings

Customer Programmable Features

The MTC+ System uses a combination of keys able to access and change the customer programmable features. Access programmable features using touch screen keys positioned on the lower part of the MTC+ display, centrally of the dashboard, or manual controls on central console (refer to "Infotelematic System" in this section). Turn the tune/scroll knob to scroll through menus and change settings on MTC+ display, press the enter upper button to confirm the selection.



NOTE:

- For further details refer to the "Maserati Touch Control Plus (MTC+)" guide.

- All settings must be edited with ignition device set to **RUN** position.

To display the programmable features menu on MTC+:

- touch the "Settings" soft-key, if available, on main menu toolbar;



- or touch Ψ to view all available applications and then select "Settings";





- or touch “Controls” on main menu toolbar and select “Settings”.



In this mode the MTC+ System allows you to access the following programmable features (some of them are optional and may not be available on your vehicle): Display, Units, Voice Commands, Clock, Safety & Driving Assistant, Lights, Doors & Locks, Auto-On Comfort & Remote Start, Engine Off Options, Suspension, Audio, Phone/Bluetooth, Radio Setup, Restore Settings and Clear Personal Data.

NOTE:

- Only one touch screen area/soft-key may be selected at a time.
- Menu navigation indications refer to the use of soft-keys on MTC+ display: the same operations can be performed using the manual

controls on central console.

To make a selection, and enter the desired function, touch the corresponding soft-key on the menu (the picture shown is “Engine Off Options”).



To scroll through the functions, move the cursor up or down, or touch the arrow ▼ or ▲. Once the desired mode is entered, press and release the touch screen area of the setting that you wish to modify. The new setting will be highlighted with one or more boxes to indicate status or possible variants of the function status. A check mark in a box indicates the current status of the function. Touch the check mark to cancel, or the empty box to insert the check mark, and change the status of the function.



Once the procedure is completed (for example, Display mode) touch the ← back arrow soft-key to return to the previous menu or touch the upper right “X” soft-key, to close the settings screen. Touching the ▲ or ▼ soft keys and the cursor on the right side of the screen will allow you to scroll up or down through the available settings.





Display

After pressing the “Display” soft-key the following mode settings will be available.

- **Display mode**

When in this display you can select one of the auto display settings. To change mode status, touch and release the “Manual” or “Auto” soft-key.

- **Display Brightness with Headlights On**

When in this display, you can select the brightness with the headlights on. Adjust the brightness from level 0 to 10 with the “+” and “-” setting soft-keys or by selecting any point on the scale between the “+” and “-” soft-keys.

- **Display Brightness with Headlights Off**

When in this display, you can select the brightness with the headlights off. Adjust the brightness as previously explained.

- **Set Language**

When in this display, you can select one language for all display descriptions, including the trip functions and the navigation system

(if equipped). The available languages are specific to the target markets.

- **Touchscreen Beep**

When in this display, you can turn on or shut off the sound activated by pressure of a touchscreen soft-key.

- **Controls Screen Time-Out**

When this mode is selected, the “Controls” screen will remain displayed for 5 seconds. If this mode is not selected, the screen will remain displayed until closed manually.



- **Nav Next Turn Pop-ups in Cluster**

By selecting this feature, the next turn direction will appear on the instrument cluster along a programmed route until the desired destination is reached (see picture).



- **AutoShow Smartphone Display Upon Connection**

This feature allows to use the MTC+ display as a projection device connected via USB port in order to browse the Apple CarPlay and Android Auto apps. By setting this feature, automatic switch from native screen to projection device will happen every time you connect your smartphone. For further details refer to the “Maserati Touch Control Plus (MTC+)” guide.

Units

After pressing the “Units” and then “Custom” soft-key on the touchscreen you may select between Metric and Imperial units of measure. Each unit of measure can be independently displayed in the TFT Display and in the navigation system (if equipped). The



following selectable units of measure are listed below:

- **Distance unit:**
select from: "km" or "mi".
- **Speed unit:**
select from: "km/h" or "mph".
- **Consumption unit:**
select from: "L/100km", "km/L", "MPG" (UK).
- **Capacity unit:**
select from: "L/100km", "L" or "gal".
- **Pressure unit:**
select from: "kPa", "bar" or "psi".
- **Temperature unit:**
select from: "°C" or "°F".
- **Power unit:**
select from: "kW" or "HP".
- **Torque unit:**
select from: "Nm" or "lb-ft".

Voice Commands

After pressing "Voice" soft-key the following modes will be available.

• Voice Response Length

When in this display, you can change the voice response length settings. To change the voice response length, touch the "Brief" or "Detailed" soft-key.

• Show Command List

When this feature is selected, it is possible to select options during a voice control session. Options for available controls are: "Always", "w/Help" or "Never".

Clock

Time is always visible on the dashboard analog clock (see "Analog Clock" in this section) and in digital format on the instrument cluster and on the MTC+ display.



With this feature it is possible to view and set the following modes.

• Sync Time with GPS

Time is normally automatically synchronised with the radio signal. It is also possible to set automatic synchronisation mode using GPS signal instead.



• Set Time Hours

With “Sync Time with GPS” feature unchecked and this mode selected, you can set the hours manually from 1 to 24. To select, touch the “+” or “-” soft-keys to adjust the hours.

• Set Time Minutes

With “Sync Time with GPS” feature unchecked and this mode selected, you can set the minutes manually from 0 to 59. To select, touch the “+” or “-” soft-keys as done for the hours.

• Time Format

When in this mode, you can select the time format display. To change the current setting, touch and release the “12 Hrs” or “24 Hrs” soft-key.

• Show Time In Status Bar

This feature will allow you to turn on or shut off the digital clock in the status bar (main menu bar).

• Set Date in Cluster (DD/MM/YY)

When in this mode, you can set the date manually in the main menu bar of the MTC+ and on the instrument cluster display. Touch the “+” or “-” soft-keys to adjust “Day”, “Month” and “Year”.

Safety & Driving Assistant

Touch this soft-key to set the following modes.

• Forward Collision Warning

The Forward Collision Warning (FCW) feature provides an audible and/or visual warning in case of potential forward collisions. The feature can be set to “On” or “Off”.

For further details, refer to “Front Collision Warning - FCW with Braking Action (optional)” in section “Driving”.

• Forward Collision Sensitivity

This feature can be set to “Near”, to “Medium” or to “Far”. The default status of FCW is the “Medium” setting. This means the system will warn you of a possible collision with the vehicle in front of you when you are farther away. This gives you the best reaction time.

To change the setting for more dynamic driving, select the “Near” setting. This warns you of a possible collision when you are much closer to the vehicle in front of you. For further details, refer to “Front Collision Warning - FCW with Braking Action (optional)” in section “Driving”.

• Forward Collision Warning Active Braking

The FCW system includes many automatic braking functions such as Low Speed Collision Mitigation (LSCM) and Collision Mitigation System (CMS), brake jerk and Advanced Brake Assist (ABA). With FCW on, all these function are enabled. When “FCW Active Braking” is selected and the speed is within limits activation, the ABA applies additional brake pressure when the driver applies an insufficient brake pressure to avoid a potential frontal collision, but at the same time enough to trigger the feature. The feature can be set to “On” or “Off”. The ABA system becomes active at 1.8 km/h (1.12 mph) and up to 250 km/h (155 mph).

For further details, refer to “Front Collision Warning - FCW with Braking Action (optional)” in section “Driving”.

• LaneSense

This feature sets the activation mode of the Lane Departure Warning (LDW). The feature can be set to “Off” (state in which the vehicle is delivered), “Display” or



“Sound+Display”.

For further details, refer to “Lane Departure Warning - LDW” in section “Driving”.



• ParkSense (Park Assist)

The park assist system will scan for objects behind and in front of the vehicle when the transmission shift lever is in R (Reverse) and the vehicle speed is less than 12 km/h (7.5 mph). The system can be enabled with “Sound” only, “Sound+Display”, or turned “Off”. See “Park Assist (optional)” in section “Before Starting” for further information.

• Front Sensors Active in Drive

If this feature is active, when driver takes shift lever from P (Park) or N (Neutral) to D (Drive), front parking sensors are activated. If this feature is not active, when driver takes shift

lever from P (park) or N (Neutral) to D (Driver), front parking sensors are NOT activated.

• Front ParkSense Volume

When this feature is selected, the chime volume of front park assist sensors can be set to “Low”, “Medium” or “High” level. “Medium” is the default setting. The system will retain its last known configuration state through ignition cycles.

• Rear ParkSense Volume

When this feature is selected, the chime volume of rear park assist sensors can be set to “Low”, “Medium” or “High” level. “Medium” is the default setting. The system will retain its last known configuration state through ignition cycles.

• Tilt Side Mirrors In Reverse

By selecting this feature the outside side-view mirrors will tilt downward when the ignition is in RUN position and the transmission shift lever is in R (Reverse) position. The mirrors will move back to their previous position when the transmission is shifted out of R (Reverse). The feature can be set to “On” or “Off”.

• Auto Folding Side Mirrors

By selecting this feature the power external mirrors will automatically fold after a lock door request, performed by key fob RKE transmitter or by the “Passive Entry” system.

Power external mirrors will automatically unfold once the ignition device is in ACC or RUN position, only if the last fold movement has been automatic.

If the mirrors were manually folded by the switch on the driver's door panel, before a lock action, they will need to be manually unfold to reactivate the automatic behave.

• Blind Spot Alert

When this feature is selected, the Blind Spot Alert (BSA) feature can be set to “Off”, “Lights” or “Lights + Chime” (default mode). When this feature is activated in “Lights” mode, the system will only show a warning light in the outside mirrors. When “Lights + Chime” mode is activated, the system will show a warning light in the outside mirrors as well as give an audible alert when the turn signal is on. When “Off” is selected, the system is deactivated. For description of this



4

system, see chapter “Blind Spot Alert - BSA (optional)” in section “Driving”.

• Surround View Camera Delay

When activation occurs by pressing the “Surround View” button in the “Controls” screen or moving the shift lever in R (Reverse) position, the initial view will be the default view (associated with current gear state). Image will be displayed while in that gear as long as vehicle speed remains lower than 12 km/h (8 mph). When vehicle is shifted into a different gear, the image will remain displayed for 10 seconds, or vehicle is shifted in P (Park), or until vehicle speed exceeds 12 km/h (8 mph), at which point it will immediately cancel and return to the last-viewed screen. The feature can be set to “On” or “Off”. See “Surround View Camera System (optional)” in section “Understanding the Vehicle” for further details.

• Surround View Camera Guidelines

When this feature is selected, by moving the shift lever in R (Reverse) position or pressing “Surround View” soft-key on MTC+ display, active guidelines will appear over

the surround view camera display. The feature can be set to “On” or “Off”.

• ParkView Backup Camera Delay

By selecting this feature, when the shift lever is moved out of R (Reverse), the rear view image with dynamic grid lines will be displayed for up to 10 seconds after shifting unless the forward vehicle speed exceeds 12 km/h (8 mph), or the transmission is shifted into P (Park) or the ignition device is switched to the OFF position. The feature can be set to “On” or “Off”.

• Rain Sensing Auto Wipers

By selecting this feature, the system will automatically activate the windshield wipers if the rain sensor senses moisture on the windshield. The feature can be set to “On” or “Off”.

• Hill Start Assist

This feature allows you to disable the HSA system. The feature can be set to “On” or “Off”. See “Brake and Stability Control System” in section “Driving” for further details.

Lights

Press the “Lights” soft-key to set the following modes.

• Headlight Off Delay

By selecting this feature, the driver can choose to have the headlight off or lit for 30, 60, or 90 seconds when the engine is shut off. To change the current headlight off delay status, touch and release the “0”, “30”, “60” or “90” soft-key to select the desired time range.



• Headlight Illumination on Approach

By selecting this feature, the driver can choose to have the headlight off or lit for 30, 60, or 90 seconds when the doors are unlocked with the key fob RKE transmitter.

• Headlights with Wipers

By selecting this feature, while the



headlight lever is in "AUTO" position, the headlight will turn on approximately 10 seconds after the wipers are activated. The headlight will also turn off when the wipers deactivate if they were activated in the current mode. The feature can be set to "On" or "Off".

- **Auto Dim High Beams**

By selecting this feature, the high beam headlight will deactivate automatically under certain conditions. The feature can be set "On" or "Off". See "Lights" in section "Understanding the Vehicle" for further information.

- **Headlight Dip (Traffic Changeover)**

By selecting this feature, the headlights will change their light distribution when a left-hand-drive vehicle enter a Country with right-hand-drive system and vice versa. The feature can be set to "On" or "Off".

- **Steering Directed Headlights**

By selecting this feature, the headlights rotate following the steering wheel direction change and change their flux distribution at high speeds, when the vehicle enters an town area and when it's

raining. The feature can be set to "On" or "Off". See "Lights" in section "Understanding the Vehicle" for further details.

Doors & Locks

Press the "Doors & Locks" soft-key to set the following modes.

- **Auto Door Locks**

When this feature is selected, all doors will automatically lock when the vehicle is in motion. The feature can be set to "On" or "Off".



- **Auto Unlock on Exit**

By selecting this feature, all doors will unlock when the vehicle is stopped, the transmission is in P (Park) or N (Neutral) position and the driver's door is open. The feature can be set to "On" or "Off".

- **Flash Lights with Lock**

By selecting this feature, the headlights will flash when the doors are locked or unlocked with the key fob RKE transmitter or when using the Passive Entry feature. The feature can be set to "On" or "Off".

- **Sound Horn with Lock (where available)**




When this feature is selected, the horn will sound when the doors are locked with the key fob RKE transmitter. You can choose from the following options: "Off" (no sound), "1st Press" (sound on the first press of the button) and "2nd Press" (sound on the second press of the button).

- **Sound Horn with Remote Start**

When this feature is selected, the horn will sound when you use the key fob RKE transmitter to start the engine. The feature can be set to "On" or "Off". See "Remote Start System (for version/markets, where provided)" in section "Before Starting" for further details.

- **Remote Unlock Sequence**



By selecting this feature you may set up only the driver's door or all doors mode will unlock on the first

press of the key fob RKE transmitter  button. When "Driver Door" is selected, you must press the key fob RKE transmitter  button twice to unlock also the passenger's doors. When unlocking "All Doors" by first press selection mode, all doors will unlock on the first press of the key fob RKE transmitter  button. If the vehicle is programmed on "1st Press of Key Fob Unlocks":

- all doors will unlock no matter which "Passive Entry" equipped door handle is grasped;
- only the driver's door will unlock when the driver's door is grasped;
- with "Passive Entry", touching the handle more than once will only result in the driver's door opening.


If driver door first is selected, once the driver door is opened, the interior door lock/unlock switch can be used to unlock all doors (or use key fob RKE transmitter).

• **Passive Entry**

This feature allows you to lock and unlock the vehicle door(s) without having to push the key fob RKE transmitter  or  buttons. By selecting this feature, "Passive Entry" may be set to "On" or "Off". The default status is "On". With

"Passive Entry" deactivated, also the "Pre-Short Drop" function is disabled (for further information, refer to "Bodywork Maintenance and Care" in section "Maintenance and Care").

• **Personal Settings Linked to Key Fob**

This selected mode enables to combine the key fob to personal driver's position settings. These settings will be implemented when pressing the  button on the key fob RKE transmitter with ignition device in **RUN** position.

• **Power Liftgate Alert**

When this feature is available, if it selected, further to turn indicators flashing, an acoustic warning will also be triggered when opening and closing the liftgate and also when the fully open position of the liftgate is set by the user. The feature can be set to "On" or "Off".

• **Hands Free Power Liftgate**

To prevent the accidental opening of the power liftgate/Hand free (optional) with the movement of the foot, it is possible to disable the "Hand Free" function. The feature can be set to "On" or "Off". This operation is recommended when

you have to wash the car (for further information, refer to "Open and Close the Liftgate" in section "Before Starting").

Auto-On Comfort & Remote Start

• **Auto-on Driver Comfort System**

This feature allows to activate the comfort of the driving seat when starting the engine.

If equipped, the driver's heated/vented seat and/or heated steering wheel will automatically activate by temperatures below 4°C (40°F). When temperatures are above 26°C (80°F) the driver vented seat will turn on.



• **Remote Start**

If the vehicle is equipped with the remote start system, you can choose



from the following options: “Off”, “Remote Start” (activation of this function when you use the key fob RKE transmitter to start the engine) and “All Starts” (activation of this function when you start the engine in all modes).

Engine Off Options

This feature allows you to set some functions after turning off the engine.

• Easy Exit Seat

When this feature is selected, the driver's seat will automatically move rearward once the engine is shut off for easy exit of the vehicle. The feature can be set to “On” or “Off”.



• Engine Off Power Delay (Power duration after engine shutdown)

By selecting this feature, the power window switches, radio, MTC+

Phone System, power sunroof (if equipped), and power outlets will remain active for up to 10 minutes after turning off the engine. Opening of one front doors will cancel this feature.

The switch-off delay can be cancelled (0 seconds) you can choose from 45 seconds, 5 minutes or 10 minutes.

• Headlight Off Delay

By selecting this feature the headlight will stay lit for up to 90 seconds after turning off the engine.

The switch-off delay can be cancelled (0 seconds) or reduced to 60 or 30 seconds.

• Auto Entry/Exit Suspension

Select this mode to automatically lower vehicle to minimum ground clearance when driver takes transmission to P (Park) to help entry into and exit from the vehicle and unloading of cargo from the boot compartment. The feature can be set to “On” or “Off”.

Suspension

This feature allows displaying and setting the following modes of the pneumatic suspension system.

• Auto Entry/Exit Suspension

Select this mode to automatically lower vehicle to minimum ground clearance when driver takes transmission to P (Park) to help entry into and exit from the vehicle and unloading of cargo from the boot compartment. The feature can be set to “On” or “Off”.

• Warning/Suspension Warning Messages Only

Select this mode to choose whether to display only warnings (option “On”). The feature can be set to “On” or “Off”.

• Tire Change Mode/Stationary Auto Leveling

Select this mode to disable the pneumatic suspension to avoid automatic levelling, when vehicle must be lifted for changing a wheel or tire. The feature can be set to “On” or “Off”.

• Transport To Mode

Select this mode to lower the pneumatic suspension to minimum



ride height and disable system operation to help vehicle loading and transport, for instance on the platform of a tow truck. The feature can be set to "On" or "Off".

• Wheel Alignment Mode

Select this mode to prevent automatic pneumatic suspension alignment when servicing suspension and/or steering parts. The feature can be set to "On" or "Off".



• Equalizer

Use this screen is used to adjust the "Bass", "Mid" and "Treble" settings. Adjust the settings with the "+" and "-" setting soft-keys or scroll and touch the slider in any point on the scale between the "+" and "-" soft-keys.



• Speed Adjusted Volume

This feature increases or decreases volume combined to vehicle speed.

To change the speed adjusted volume touch the "Off", "1", "2" or "3" soft-key.



• Surround Sound

This feature provides simulated surround sound mode. Available settings: "On" and "Off".



• Clari-Fi

This function improves the audio quality by enhancing digitally compressed source files such as MP3

Audio

This feature enables to view and set the available audio modes depending on the type of audio system supplied on the car.

The following modes refer to the "High Premium" audio system.

• Balance/Fade

Use this screen to adjust the balance and fade settings. Touch and drag the speaker icon, use the arrows to adjust, or tap the "C" icon to readjust to the centre.



and AAC files and certain music tracks played by radio stations. In case of high-definition source files like the ones on a CD, Clari-Fi shall apply no enhancement. Clari-Fi intervention is completely automatic. The feature can be set "On" or "Off".

• Auto Play

When a portable device is connected to MTC+ system, it plays automatically the songs if this feature is set to "On".



Phone/Bluetooth

Press this soft-key to select and connect phones and audio sources.

• Do Not Disturb

Settings available for this feature:

– Auto Reply

To change the mode status, touch

the "Text", "Call" or "Both" soft-key.

– Auto Reply Message

To change the mode status, touch the "Custom" or "Default" soft-key.

– Customise Auto Reply Message

This feature allows you to customise the "Auto Reply Message". Text messages are limited to 160 characters (key pad is not available while vehicle is in motion).

• Paired Phones

By selecting this feature you will be notified which phones are combined to the Phone/Bluetooth system.

For each option, you can also add a device and change the PIN code of the device you wish to connect. For further information, see the MTC+ guide.



• Paired Audio Sources

By selecting this feature you will be notified which audio source are combined to the Phone/Bluetooth system.

For each option, you can also add a device and change the PIN code of the device you wish to connect. For further information, see the MTC+ guide.

• Phone Pop-ups Displayed in Cluster

When this mode is selected a pop-up message will appear in case of incoming call. Information associated to call in progress are available by entering to the “Audio” menu using the buttons on the steering wheel RH side.

NOTE:

On the Maserati website, at www.maserati.com, or through the **Maserati Service Network** you may consult the list of telephones that are compatible with the MTC+, and their level of compatibility.

Radio Setup

Press the “Radio Setup” soft-key to set some listening options.

• Traffic Announcements

By Selecting the FM type of frequency you may listen to traffic announcement information.



• DAB Announcements (if supported)

By selecting the frequency of digital broadcasting you may listen to traffic announcements.

• DAB Announcements Categories (if supported)

Selecting the frequency of digital broadcasting you can tune on an alternative frequency and the regional mode. These two features can be set to “On” or “Off”. Digital radio extends the selection of stations, adding also numerous specialty channels. It features the most modern reception technology and it is DAB+ compatible. Additional information are also shown in the display, such as the song title and the artist.



Restore Settings

When this feature is selected, it will reset the “Display”, “Clock”, “Audio”, and “Radio Settings” to their default settings.

Run this feature and a pop-up will appear asking user to confirm default settings resetting. Select “Yes” to restore, or “Cancel” to exit. Once the settings are restored, a pop-up appears confirming that settings have been reset to default.

Clear Personal Data

When this feature is selected, it will remove personal data concerning settings and/or options that have been modified compared to factory settings and will also remove from system memory Bluetooth devices and presets. To remove personal information, select this feature and a pop-up will appear



asking confirmation to delete all personal data. Select "OK" to clear, or "Cancel" to exit. Once the data have been cleared, a pop up appears confirming that personal data have been cleared.

Dashboard Compartment

There is a glove box compartment on the passenger side of the dashboard to store small items or documents.



WARNING!

Do not operate the vehicle with the lid of glove box or compartment in the open position. Store objects or devices in dashboard compartment or in any other vehicle compartments, to ensure they will not move during the trip and prevent them from hitting any person on board.




CAUTION!

Do not place objects weighing over 10 kg (22 lb) in the glove box compartment.

To open the glove box, pull the handle as shown in the picture.



In the compartment there is a location to hold the Owner's documentation. Inside the door there are compartments for storing glasses and small items.




The compartment is illuminated by a courtesy light when open (the light will automatically switch off when the compartment is closed) moreover, the compartment is also air-conditioned like the rest of the interior.



Under the courtesy light there are two USB inputs for charging the connected source (see "Interior Features" in section "Understanding the Vehicle" for further details).

The air outlet inside the compartment is located on the right side: it can be opened/closed by turning counterclockwise a ring nut placed in correspondence.



Glove Box Lock Feature

The glove box is equipped with an opening/closing electric actuator that can be locked and unlocked via a feature of the MTC+, by entering a 4-digit PIN code. It is important to memorise and take note of the PIN since if it is lost, you must contact the **Maserati Service Network** that will reset this feature.

NOTE:

"Glove Box" lock feature must be activated when the glove box is already closed. If you activated the "Glove Box" lock feature when the glove box is opened, the glove box will not close properly and will not lock

Glove Box Lock

- Open "Controls" screen and touch "Glove Box" soft-key.



- To open the screen required to enter the PIN, answer "Yes" to the prompt.



- Using the keypad, enter the four digits of the PIN and press "OK". The system prompts you re-enter the PIN code to confirm it.



NOTE:

- *If you do not enter all PIN digits, a prompt will indicate that you should do so.*
- *In case of incoming call while entering the PIN, the MTC+ system will temporarily stop the release*



function. As soon as the call is over, the keypad screen will be displayed again so that you can enter the PIN.

- When the next page shown in figure appears, touch "OK".



Glove box is now locked and the MTC+ will go back to "Controls" page.

Glove Box Unlock

If the glove box is locked, when you enter in the vehicle, the MTC+ screen will display the page already shown during the locking procedure, on which a message will indicate that system operation is reduced and that only "Climate", "Controls" and "Settings" features are active. Unlock glove box by entering the lock code as previously specified.

Glove Box Manual Unlock

If battery is flat, it is necessary to manually work the actuator on the LH side of the glove box to unlock the glove box that has been locked using the PIN code.

- Proceed carefully and start with the central part, indicated by the arrows in the figure, and remove the dashboard moulding beneath and on the sides of the climate control panel. This moulding is fastened by means of 10 pins (indicated in the figure) press-fitted onto clips present in dashboard structure.



- After removing the moulding, take the screwdriver from the tool kit under boot mat (see "Tool kit" in section "In an Emergency").
- Insert screwdriver tip inside the hole on LH side of glove box structure:

push until home against actuator pin.

- Push down screwdriver tip to release actuator pin and manually unlock the glove box. The actuator will remain in this condition until battery feed is restored.



Inner Section

- Reinstall the moulding ensuring that pins match with the clips of dashboard structure.

- Press on the moulding, always starting from the central part until all 10 pins are engaged in their clips and “click” in place.

After releasing the glove box by means of this procedure, do not lock glove box using the PIN code and contact the **Maserati Service Network** to have unlock feature via PIN code checked.

Analog Clock

To adjust the analog clock located on the center of the dashboard between the air outlets, use the MTC+ System (see “MTC+ Settings” in this section).



The time can be displayed also on the MTC+ main menu bar and on the instrument cluster display (see “MTC+ Settings” in this section).

Clock lighting works in the same way as instrument and controls backlighting (refer to “Lights” in section “Understanding the Vehicle”).

Air Conditioning Controls

The vehicle is equipped with an automatic dual-zone air conditioning system that allows to adjust separately the air temperature in the left and in the right zone of the passenger compartment, according to the requests of the driver and the front passenger.

A humidity sensor, positioned on the inner surface of the windshield, over the rear view mirror, allows the A/C system to prevent/eliminate fogging of the windshield and side windows.

The best efficacy in preventing fogging is obtained by selecting the AUTO function, described later.

A dual zone solar sensor, positioned on the center of the dashboard upper surface, helps to achieve the best comfort in presence of solar radiation. Upon request, the vehicle can be equipped with an additional automatic dual-zone air conditioning system installed in the central console, between the front seats. The additional dual-zone module, can be operated by the rear passengers (see “Four-zone Climate Control (optional)” in this chapter), by means of the control panel at the end of central console, but also by the front



passengers using the soft-keys on MTC+ display.



CAUTION!

To ensure proper functioning of the solar sensor, do not apply adhesive parking stickers, etc. in the checking area between the sensor and the windshield. Therefore, keep the windshield and the solar sensor clean to prevent accumulation of dust or other impurities.

Dual Zone Climate Controls

This system can be operated by using the controls of the automatic climate control panel on the dashboard, or the soft-keys on the MTC+ display when "Climate" mode is selected. When the MTC+ System is in any mode other than "Climate" ("Radio", "Media", "Controls", etc.) the driver and passenger temperature settings will be indicated at the opposite sides of the upper part of the display, while the blower speed and the air distribution are shown in the climate icon, in the lower part of the MTC+ display.



Description of Controls

All described functions can be set and modified using the climate control panel or the MTC+ display. To adjust driver and passenger side temperature and fan speed, climate control panel features two-function controls that can be pushed up to increase temperature/speed, or down to decrease them.

1. Climate control on/off

Once you enter the screen "Climate", press the "ON" soft-key to switch the climate control on/off. The "OFF" soft-key will appear when the A/C is on.

NOTE:

For vehicles equipped with Remote Start, the Air Conditioning System will not function during Remote Start operation if the climate control is left in "OFF".

2. A/C

Press to change the current air conditioning (A/C) setting; the indicator illuminates when the "A/C" is on. Operating this function will cause the automatic feature to switch into manual mode and the "AUTO" LED on the button/MTC+ soft-key will turn off.

3. Driver temperature control

Provides the driver with independent temperature control. Push the blue ▼ soft-key for cooler temperature. Push the red ▲ soft-key for warmer temperature. The driver's temperature setting will be displayed on the MTC+ between the soft-key ▲ and ▼. The MTC+ display can also be used to adjust the temperature by pressing



and sliding the bar towards soft-key ▲, to increase temperature, or towards soft-keys ▼ to decrease it.

NOTE:

In “SYNC” mode, this button will also automatically and simultaneously adjust the passenger temperature.

4. Passenger temperature control

Provides the passenger with independent temperature control. Push the ▼ soft-key for cooler temperature. Push the ▲ soft-key for warmer temperature. The passenger's temperature setting will be displayed on the MTC+ screen between the soft-keys ▲ and ▼.

NOTE:

Pressing the 4 button while in “SYNC” mode will automatically exit “SYNC”.

5. Recirculation

Press to change the current setting, the LED indicator on the button/the relevant soft-key illuminates to indicate which recirculation function is activated. For further details, see paragraph “Dual zone Climate Control Functions” in this chapter.

6. Blower control

Blower control is used to regulate the amount of air forced through the climate system. There are seven blower speeds available. Adjusting the blower will cause automatic mode to switch to manual.

On the climate control panel, push the rocker switch up to increase fan speed. Push the rocker switch down to decrease fan speed. Pushing down the rocker switch when set blower is at the first speed, causes the A/C system shutdown (OFF condition).

On the MTC+ display, touch the small icon of the blower to decrease the speed, or the big icon to increase it. Between the two icons, bars will appear to show the number of the corresponding selected speed.



The blower can also be activated/regulated by touching the bars between the two blower icons.

7. AUTO



This function automatically controls the interior temperature by adjusting the air flow rate and the air distribution. Press “AUTO” to switch the ATC between manual and automatic mode. The LED on the button/the “AUTO” soft-key illuminates when the “AUTO” function is activated. See “Automatic

Temperature Control (ATC)” in this chapter for more information.

8. FAST defrosting/demisting

Press the  button/the  soft-key to switch the airflow setting to the windshield and the front side windows to get a quick defrosting/defogging. The LED on the button/the soft-key illuminates when this feature is activated. Operating this function will cause the ATC to switch into manual mode: so the “AUTO” LED/MTC+ soft-key will turn off; the fifth blower speed will be automatically selected, unless the blower is not already set to a higher speed. If this function is turned off the climate system will return to the previous setting.

9. REAR defrosting/demisting

Press the  button/the  soft-key to turn on the rear window defroster and the heated outside mirrors. A LED indicator/MTC+ soft-key will illuminate when the rear window defroster and the heated external mirrors are on. The rear window defroster and the heated external mirrors automatically turn off after 10 minutes.


**CAUTION!**

Failure to observe the following cautions may cause damage to the rear windows defroster:

- Use care when washing the inside of the rear window. Do not use abrasive window cleaners on the interior surface of the window. Use a soft cloth and a mild washing solution, wiping parallel to the heating elements. Labels can be peeled off after soaking with warm water.
- Do not use scrapers, sharp instruments, or abrasive window cleaners on the interior surface of the window.
- Keep all objects inside the vehicle at a safe distance from the window.


10. Air flow distribution modes


The airflow distribution mode can be adjusted so air comes from the dashboard vents, floor vents, demist/defrost vents.

The display contains the relevant soft-keys used to set these modes. The climate control panel features a button  : press it several times to

select and set the required airflow distribution mode.

Available settings are as follows:


- **“Dashboard” mode** 

Air flows in from the six adjustable vents of the dashboard and the two positioned at the rear of the central console. Each of these vents can be singly adjusted. The air grids or vanes of the vents can be moved to adjust air flow direction. A setting wheel, placed near each vent, allows to regulate or close the air flow.
- **“Bi-Level” mode** 

Air comes from the dashboard vents, the central console adjustable vents and the fixed floor vents. A small portion of the airflow is directed through the defrost/demist vents.


NOTE:

Bi-Level mode is designed to let cooler air come in the dashboard and rear part of the central console vents and warmer air from the floor vents.

- **“Floor” mode** 

Air comes from the floor vents. A small portion of the airflow is

directed through the defrost/demist vents.

- **“Mix” mode** 

Air comes from the defrost/demist vents and from floor vents. This mode is recommended for cold climates, to improve comfort and prevent fogging.

11. “SYNC” mode

Press the “SYNC” soft-key on the MTC+ to switch the Sync feature on/off. The “SYNC” indicator illuminates when this feature is selected. This function is used to synchronise the passenger temperature setting with the driver temperature setting. Changing the passenger temperature setting while in “SYNC” will automatically exit this feature.

12. MAX A/C

By pressing the “MAX A/C” button/soft-key, the system automatically switches to get the maximum cold air flow.

Dual Zone Climate Control Functions**Air Conditioning (A/C)**

The “A/C” button allows to manually activate or deactivate the air conditioning system. When the air



conditioning system is turned on, cool dehumidified air will flow through the vents into the cabin. For improved fuel economy, press the "A/C" button to turn off the air conditioning and manually adjust the blower and airflow mode settings.

When the "A/C" and "AUTO" are switched off it is not possible to have air at a lower temperature than the outside.

Recirculation and Air Quality Sensor (AQS)

When outside air contains smoke, odours, or high humidity, or if rapid cooling is desired, you may wish to recirculate interior air by pressing the recirculation control button to activate the two different functionalities.

The recirculation function, that allows to open/close the A/C air inlet by operating the relevant button on the climate control panel/MTC+ softkey, is integrated with the Air Quality Sensor. This sensor, positioned upstream of the A/C filter, in front of the air intake of the A/C system, detects the presence of polluting substances and submits an electric signal to the A/C control unit, that closes the intake of the external air by activating the air recirculation.


The recirculation button/MTC+ softkey can therefore enable three operating modes, switchable in sequence. Starting from the outside air condition, in which the external air is aspirated by the A/C system and treated to be introduced into the passenger compartment, subsequent actuations of the button/MTC+ softkey change the state as follows.

- First press: the A/C system activates the recirculation, the LED on the button/MTC+ softkey lights up. The A/C system will stay this way up to a new actuation, or until the increased humidity could lead to windshield fogging: in this case the recirculation automatically switches to external air.
- Second press: the A/C system activates the automatic recirculation control by using the signal transmitted from the AQS. The symbol "A" on the recirculation button/MTC+ softkey lights up.
- Third press: the A/C system switches back to external air.


The next press of the recirculation button/MTC+ softkey restarts the operating cycle just described.

NOTE:

To avoid the risk of fogging, the AQS is disabled when the external temperature falls below 2 °C (35 °F).





NOTE:

In cold weather, use of recirculation mode may lead to window fogging. Select the MIX mode  and increase the blower speed to prevent fogging.



MAX A/C

Activating this function, the system switches to exit "AUTO", enter "A/C" and recirculation. The minimum temperature (LO) in both zones, the maximum blower speed and the air distribution  are also selected. The blower speed can be adjusted and the air distribution can be modified without exiting "MAX A/C". To exit "MAX A/C" press the relevant MTC+ soft-key or exit A/C or recirculation. Selecting , "AUTO", or "OFF", will also exit "MAX A/C".

Automatic Temperature Control (ATC)

Automatic operation

- Press the "AUTO" soft-key on the A/C panel or the soft-key button on the MTC+ screen.
- Set the desired temperature adjusting the driver and/or passenger temperature hard or soft control buttons. Once the desired temperature is displayed, the system will achieve and automatically maintain that comfort level.
- When the system is set up for your comfort level, it is not necessary to change the settings anymore, simply

allow the system to function automatically.



- To provide you with maximum comfort in the Automatic mode, during cold start-ups the blower speed will remain low until the engine warms up.

Manual operation

The system allows manual selection of blower speed, air distribution mode, A/C status and recirculation control.

The blower fan speed can be set to any fixed speed by using the blower control. In this case the blower will operate at a fixed speed until additional speeds are selected. This allows the front occupants to control the volume of air circulated in the vehicle and cancel the "AUTO" mode. The user can also select the direction of the airflow by selecting one of the available mode settings. A/C operation and recirculation control can also be manually selected.

Four-Zone Climate Controls (optional)


Air conditioning controls that allow rear passengers to adjust the temperature in the left and right rear part of the passenger compartment are located at the rear end of the central console underneath the adjustable air outlets.




Description of Controls

The following functions can be operated/adjusted by using the rear climate control panel.

1. Rear climate control on/off



Press the button  to switch the rear climate control on/off. The LED on the button turns on when the rear A/C is on.





2. A/C

Press to change the current air conditioning (A/C) setting, the "A/C" symbol on the button illuminates when the A/C is on. This will cause the automatic operation to switch into manual mode and the "AUTO" indicator will turn off.

3. Left side temperature control

Provides the rear passengers with independent temperature control. Push the  button for cooler temperature settings or the  button for warmer temperature. The set temperature value will be displayed in the area above the buttons.

4. Right side temperature control

Provides the rear seats passengers with independent temperature control. Push the  button for cooler temperature settings or the  button for warmer temperature. The set temperature value will be displayed in the area above the buttons.

5. Blower control

Blower control is used to regulate the airflow of the rear climate system. There are seven blower speeds available. Adjusting the blower will cause the automatic mode to switch to manual.

Press the "+" button to increase blower speed.
Press the "-" button for lower speed.

Airflow distribution modes

The airflow distribution can be adjusted to let air come in from the adjustable and fixed central console vents and floor vents. The set mode is recognisable through the lighting of the soft-key or the LED on the button of the climate control panel.

6. "Bi-Level" mode

Air comes from the adjustable vents on the rear central console and from the fixed ones directed to the floor.

NOTE:

The Bi-Level mode is designed to provide comfort by sending cooler air out of the central console vents and warmer air from the floor vents.

7. "Floor" mode

Air comes from the floor vents.

8. "Torso" mode

Air comes from the adjustable vents on the central console. Each of these vents can be singly adjusted. The air grids of the vents can be moved up and down or right and left to adjust air flow direction. A setting wheel, placed near each vent, allows to

4



regulate the airflow or to close the vent.

9. AUTO

This function automatically controls the interior temperature by adjusting the air flow rate and the air distribution.

- Press the “AUTO” button: the automatic rear climate control switches from manual to automatic mode and vice-versa. The “AUTO” symbol on the button illuminates when this function is activated.
- Adjust then the temperature you wish to maintain by regulating the left and/or right side temperature control buttons. Once the desired temperature is set, the system will achieve and automatically maintain that comfort level.
- When the system is set up for your comfort level, it is not necessary to change the settings anymore: simply allow the system to function automatically.

To provide you with maximum comfort in the Automatic mode, during cold start-ups the blower speed will remain low until the engine warms up.

Four-Zone Climate Control by the Driver

By operating the MTC+ display controls the driver can adjust the settings of the rear climate zones controlled by rear passengers. By touching the following MTC+ screen keys, the driver is able to:

1. View and change the settings of the rear climate.
2. Block the settings of the rear climate.
3. Synchronise the temperature of the front passenger side and the one set by the rear passengers with the driver's side.
4. Return to the front climate control display.



Operating Tips

- Continuous use of the air recirculation in winter, in rainy weather or humid climate is not recommended because it may cause window fogging.
- Interior fogging on the windshield can be quickly removed by fast defrosting/demisting. The “Mix” mode can be used to maintain a clear windshield and provide sufficient heating. If side window fogging becomes a problem increase blower speed.

NOTE:

- Recirculation mode without A/C should not be used for long periods of time, as fogging may occur.
- If inside the passenger compartment there are conditions of high

(Continued)



(Continued)

temperature and humidity, when the A/C compressor is switched on (A/C soft-key illuminated on MTC+ display or LED on climate control panel A/C button ON) there may be some cold steam at ventilation port outlet: this situation is normal and does not indicate air conditioning system malfunction.

- *Automatic Temperature Controls (ATC) will automatically adjust the climate control settings to reduce or eliminate window fogging on the front windshield.*
- Make sure the external air intake, located directly in front of the windshield, is free of obstructions such as leaves or other objects. Leaves collected in the air intake may reduce airflow, and if they enter the plenum, they could plug the water drains. In winter make sure the air intake is clear of ice, slush, and snow.
- The temperature can be displayed in Metric or Imperial units by selecting the M/Imperial customer programmable feature. See “MTC+ Settings” in this section.
- Any time you store your vehicle or keep it stationary (i.e., during vacation) for two weeks or more, run

the air conditioning system at idle for about five minutes in the fresh air by high blower setting. This will ensure adequate system lubrication and minimize the possibility of compressor damage when the system is started again.

A/C Filter

The climate control system filters outside air containing dust, pollen and some odours. Strong odours cannot be totally removed from by A/C filter at the entrance of the air climate system. See “Maintenance Procedures” in section “Maintenance and Care” for filter replacement instructions.

Phone and Voice Controls on Steering Wheel (if foreseen)

The commands on the right side of the steering wheel activate/deactivate the phone mode and the voice controls functions.



These functions are only available when one or more Bluetooth® compatible mobile phones are paired with the MTC+ System connection: to pair a phone and to learn all available functions refer to the MTC+ guide.

**NOTE:**

On the Maserati website, at www.maserati.com, or through the **Maserati Service Network** you may consult the list of telephones that are compatible with the MTC+, and their level of compatibility.

The voice command communication system is fully integrated with the vehicle's audio system.

The volume can be adjusted from the upper knob on the central console (see "Infotelematic System" in this section) or from the steering wheel radio controls (see "Audio Controls" in this section).

The system will automatically mute the radio when using the phone mode.


When activating the phone mode using voice commands with speakerphone, you should talk quietly in a normal conversational tone by keeping the driving position and turning to the microphone of the voice command system located inside the internal rearview mirror.

The ability of the system voice control to recognise the user's voice commands can be invalidated when speaking too quickly or too loudly.


**WARNING!**

Any voice-controlled system should be used only in safe driving conditions following all applicable regulations. Full attention should be kept on driving. Failure to do so may result in a collision causing serious injury or death.

Phone Mode

By using the Phone button  it is possible to: activate the phone mode, start a call, show recent incoming and outgoing calls, show contacts list, etc. All these functions can also be reached by using the touch screen commands on the MTC+ display in "Phone" mode.



When pressing the button  an audible sound will invite you to impart a command.


Information on incoming call is indicated in a pop-up on instrument panel display main area if this feature is checkmarked on MTC+ (see "MTC+ Settings" in this section). Said information will stay displayed until a control is executed (e.g.: answer, reject, etc.) for the incoming call.



The screen will only display the phone number or name of caller (if available) as long as this complies with system specifications in terms of font and number of characters.

Call details can be displayed at any time through "Audio" submenu item, then "Phone: call details" using the buttons on steering wheel RH side. On display, said details shall temporarily replace the ones on media source in use.


Siri Smart Personal Assistant


When a compatible iPhone or iPad that supports Siri voice recognition is paired to the vehicle, the  button also activates the Siri Smart Personal Assistant.

Siri requires mobile internet access and its functionality might change depending on the geographical area. Through simple voice commands, without taking your eyes off the road, it may be possible to send messages, make phone calls, create notes and reminders, etc.

4

Voice Commands

By using voice commands, after pressing the  button, it is possible to control the AM and FM radio, the satellite radio and all devices connected and managed by the "Media" mode (i.e SD card, USB/iPod player).

When pressing the button  an acoustic signal will invite to give a voice command.

NOTE:

For further details refer to the Maserati Touch Control Plus (MTC+) guide.



5 – Driving

Normal Starting of the Engine	218
Automatic Transmission	223
All-Wheel Drive	229
Drive Mode	230
Off-Road Drive	246
Parking Brake	249
Parking	252
Brake and Stability Control System	255
Using the Brakes	261
Use of the Engine	262
Electronic Cruise Control	264
Lane Departure Warning - LDW (optional)	267
Adaptive Cruise Control - ACC (optional)	269
Forward Collision Warning - FCW with Braking Action (optional)	279
Tires - General Information	282
Tire Pressure Monitoring System (TPMS)	286
Fuel Requirements	291
Refuelling	293
Driving Conditions	297
Blind Spot Alert - BSA (optional)	300
Adding Reducing Agent AdBlue (Diesel only)	304
Trailer Towing	308




Normal Starting of the Engine



WARNING!

It is dangerous to run the engine in an enclosed area. The engine consumes oxygen and discharges carbon dioxide, carbon monoxide and other toxic gases in the atmosphere.

When doors are opened, the instrument cluster displays the Maserati Logo in the center and the complete odometer plus the open doors indicator  in the lower part of the cluster.



Before starting the engine, close the doors, adjust your seat, the inside and outside mirrors, fasten your seat belt

and instruct all other occupants to buckle their seat belts. The shift lever must be in P (Park) or N (Neutral) position before you can start the engine. Apply the brakes before shifting into any driving gear (see "Automatic Transmission" in this section).



CAUTION!

- Before starting the engine, switch off the electrical devices with a high power consumption (air-conditioning and heating system, heated rear window, headlights, etc.).
- Do not start the engine if the fuel level in the tank is low.

The keyless ignition allows the driver to operate the ignition switch by pushing the center button, as long as the key fob RKE transmitter is within the passenger compartment (check "Keys" in section "Before Starting" for further information).

By pressing the brake pedal and pushing the **START/STOP** button the engine starts. Instrument panel displays the initial sequence with warning light and analog instruments test routine and switch-on of the engine temperature indicators and

fuel level. This happens if option "On" was set in screen settings for display cluster" in section "Dashboard Instruments and Controls").



The current display subsequently sets up with the latest screenshot.



If the engine fails to start, the starter will disengage automatically after 10 seconds. If you wish to stop the



cranking of the engine prior to starting it, press the button again.

NOTE:

Normal starting of either a cold or a warm engine is obtained without pumping or pressing the accelerator pedal.

If the driver only pushes the **START/STOP** button but does not press the brake pedal, the ignition switch cycles to the **ACC** position (see “Keys” in section “Before Starting”) and the instrument cluster displays the latest screenshot.

At the second press of the **START/STOP** button, the ignition device switches to **RUN** position (see “Keys” in section “Before Starting”) and the instrument cluster displays the latest screenshot.

At the third press of the **START/STOP** button the ignition switch returns to **OFF** position and the display powers down.


At the fourth press of the **START/STOP** button the screen will display the message that invites you to press the brake pedal and push the **START/STOP** button to start the engine.

NOTE:

*If the ignition switch is left in the **ACC** or **RUN** (engine not running) position and the transmission is in P (Park), the system will automatically time out after 30 minutes of inactivity and the ignition will switch to the **OFF** position.*

After starting the engine, the idle speed is controlled automatically and will decrease as the engine warms up.

Notes for the Diesel Engine Starting (Diesel only)

With cold engine and external temperature below 0°C, ignition may be delayed a few seconds in order to allow the spark plugs to pre-heat. In this case the amber light  will illuminate on the TFT display and will stay on for a few seconds after the engine has started.

Cold Weather Precautions (Diesel only)

If the outside temperature is very low, the diesel fuel thickens due to the formation of paraffin clots and could clog the diesel filter. In order to avoid these problems, different types of diesel fuel are distributed according to the season: summer type, winter type

and arctic type (very cold, mountainous areas).
If refueling with diesel fuel whose specifications are not suitable for the too cold outside temperature, it is advisable to mix TUTELA DIESEL ART additive in the proportions shown on the container with the fuel. Pour the additive into the tank before the fuel using the funnel provided.

Engine Start Failure



CAUTION!

- Do not attempt to push or tow your vehicle to get it started. Vehicles equipped with an automatic transmission cannot be started this way. Moreover, unburned fuel could enter the catalytic converter and once the engine has started, ignite and damage the converter and vehicle.
- If the vehicle has a discharged battery, booster cables may be used to obtain a start from a booster battery or the battery in another vehicle. This type of start can be dangerous if done improperly. See “Auxiliary Jump Start Procedure” in



(Continued)
section "In an Emergency" for further information.

Flooded Engine Clearing

If the engine fails to start after you have followed the described procedures, it may be flooded. To clear any excess fuel, move the shift lever in P (Park) position. Press and hold the brake pedal, push the accelerator all the way to the floor and hold it, then press and release the **START/STOP** button once. The starter will engage automatically, run for 10 seconds, and then disengage. Once this occurs, release the accelerator pedal and the brake pedal, wait 10 to 15 seconds, then repeat the "Normal starting of the engine" procedure.

Driving with a Cold Engine

Start-off slowly, avoiding sudden acceleration and rev the engine up at low medium speeds. High-performance driving should be avoided until the engine temperature reaches 65-70°C (149-158°F).

Engine Turn Off

- Place the shift lever in P (Park) (see "Automatic Transmission" in this section).

- With the engine at idle, press and release the **START/STOP** button. The ignition switch will return to the **OFF** position. A burst on the accelerator pedal before turning off the engine has no purpose and increases fuel consumption.
- If the shift lever is not in P (Park), the **START/STOP** button must be held for two seconds and vehicle speed must be above 8 km/h (5 mph) before the engine will shut off. The ignition switch will remain in the **ACC** position until the shift lever is in P (Park) and the button is pressed twice from the **OFF** position.
- If the shift lever is not in P (Park) and the **START/STOP** button is pressed once, the instrument cluster will display a "Vehicle Not in Park" message and the engine will remain running.



WARNING!
Never leave a vehicle out of the P (Park) position, as it could move.

NOTE:

If the ignition switch is left in the ACC or RUN (engine not running) position and the transmission is in P (Park), the system will automatically time out after 30 minutes of inactivity and the ignition will switch to OFF position.

"Panic Stop" Strategy

In panic conditions, if driver stops engine in any non-standard manner while driving at a speed over 3 km/h (2 mph), the "Panic Stop" strategy can manage the situation by checking gearchange condition upon engine cutting, driver's action on brakes, road condition (flat or slope) so as to set gearchange to the most suitable condition. The "Panic Stop" strategy considers that the driver should stop the engine by pressing the ignition switch at least 3 times or holding it depressed for at least 5 seconds.

Automatic Start&Stop System

The Maserati Start&Stop system allows the engine to automatically switch off when the vehicle stops and to restart when the driver intends to drive. This feature helps reduce fuel consumption. During the "Stop



(AutoStop)“ phase the ignition is still on and all security features are available.

In order for the Start&Stop to activate, the vehicle must be stationary and the brake pedal adequately pressed.

NOTE:

If the brake pedal is not sufficiently pressed the Start&Stop may not function even if the vehicle is stopped.

When the Start&Stop switches off the engine, the related light

 illuminates on the instrument cluster.

As soon as the brake pedal is released, the engine turns on.


While the vehicle is stopped, the shift lever can be placed in P (Park).

In this case it is possible to release the brake pedal and the vehicle will remain in “AutoStop” with engine off. Pressing the brake pedal and shifting gear into D (Drive) or R (Reverse) will deactivate the “AutoStop” condition and restart the engine.



Start&Stop Deactivated

Start&Stop function is deactivated under the following conditions:

- When SPORT drive mode is activated.
- When  drive mode is activated.
- When ride height is set to Off Road 1 or Off Road 2.
- If it has been disabled through the main menu voice “Vehicle Settings” (see chapter “Instrument cluster” in section “Dashboard Instruments and Controls”).

Start&Stop Not Active

For keeping driving safety, interior comfort and a correct functioning of engine and vehicle, the Start&Stop function does not activate under the following conditions:

- When the driver’s seat belt is unbuckled.

- When the driver door is open.
- When the fuel level is too low.
- When the vehicle is stopped on a very steep road.
- When the vehicle is stopped with steered wheels.
- When the vehicle is manoeuvring: shift lever in R (Reverse).
- When the temperature conditions inside the vehicle do not correspond to the air conditioning setting.
- When the front and rear “defroster” function is activated.
- When the engine coolant and the engine oil temperature is not on proper functioning level.
- When the external temperature is too cold.
- When the battery charge is below safety value (see example).






- When the previous stop had just happened (few seconds) and the minimum speed has not yet been achieved.
- Shortly after R (Reverse) has been set or when driving under a certain speed level.
- When the hood is open.
- The sensors managing the Start&Stop have been damaged.
- Start&Stop system faults are present.
- During DPF regeneration process (Diesel only).

Automatic Restarting of the Engine

The engine may automatically restart, before the brake pedal has been released, when one of the following conditions occurs:


- The SPORT drive mode or  drive mode is being activated.
- If the Start&Stop function has been disabled through the main menu voice "Vehicle Settings" (see chapter "Instrument cluster" in section "Dashboard Instruments and Controls").
- If shift lever is moved to R (Reverse).
- If the steering wheel is moved to steer the wheels.

- When the temperature conditions inside the vehicle do not correspond to the air conditioning setting.
- When changing the temperature setting on the air conditioning.
- When the defroster function is being activated.
- When the battery charge is below safety value.
- When the accelerator pedal is being pressed (together with the brake pedal).
- If a long time has passed since the last automatic stop of the engine.

Occupants Safety Function

To enhance occupants safety, the Start&Stop system monitors if the driver is present and does not allow automatic restarting of the engine if one of the following manoeuvres is being performed while in "AutoStop" condition:

- The driver unbuckles his/her seat belt and releases the brake pedal.
- The driver opens the door and releases the brake pedal.
- The driver unbuckles the seat belt and opens the door.
- The driver opens the hood.

All the above-mentioned conditions deactivate the Start&Stop function (the "AutoStart" is deactivated and the engine remains off) and the shift lever moves automatically in P (Park). The  telltale will flash to indicate the Start&Stop function disabling. To restart the engine it is necessary to press the brake pedal and push the **START/STOP** button. Move the shift lever to D (Drive) to drive away.



WARNING!

- **Even when the vehicle is stopped in the "Stop (AutoStop)" phase, the driver is responsible for the vehicle and the occupants and shall take care of what happens inside and outside the vehicle.**
- **Even when the vehicle is stopped within the "Stop (AutoStop)" phase, the vehicle driver is responsible for the vehicle, the vehicle's occupants and the vehicle's surrounding area. Never leave the vehicle unattended with the engine running; doing so poses a risk of danger. It is a good practice to always ensure to set the parking brake and place the transmission gear selector lever into**



the P (Park) position, thereby ensuring the vehicle will not move, when performing any vehicle checks, maintenance and/or service procedures on the vehicle.

Start&Stop Function Disabling

Under certain driving conditions, when frequent stops and restarts of the engine may become annoying, it is possible to turn off the Start&Stop function.

Use the controls located on the right side of the steering wheel (see instructions in chapter "Instrument Cluster" in section "Dashboard Instruments and Controls") and select "Start & Stop" main menu item which displays the status of the function: Start & Stop enabled is the default status.

Hold the switch (▶) to change the status of the function.

When the Start&Stop function is turn off, in addition to the related message the amber indicator ⚠ indicated in the picture will turn on.



Start&Stop System Failure

When the ⚠ warning light and the related message illuminate on the TFT display (see chapter "Instrument Cluster" in section "Dashboard Instruments and Controls") there is a malfunction in the Start&Stop system and the engine cannot be switched off and restarted automatically. To switch off or restart the engine it is necessary to push the **START/STOP**. Have the vehicle checked at the **Service Network**.

Automatic Transmission

The electronic shift lever replaces the conventional mechanical lever and has no mechanical connection to the transmission. The transmission is operated by electrical actuators on the hydraulic system and all commands to the control system are transmitted by the CAN network. The lever itself represents a mere user interface. Gear positions are simulated by solenoids inside the lever body, which are computer-controlled and enable or disable certain positions of the lever. The solenoids inside the shift lever prevent the movement of the lever towards invalid positions. The electronically-controlled transmission provides a precise shift schedule. The transmission electronics are self-calibrating, therefore the gearshift behaviour could become perfect as expected after few hundreds of km.



CAUTION!

In order to properly use the automatic transmission, it is essential that you read through the whole chapter, so that you can understand right from

(Continued)



(Continued)
the start what the correct and granted operations are.

Damage to the transmission may occur if the following precautions are not observed:

- Shift into P (Park) only after the vehicle has come to a complete stop. This is the default position of the lever and should be used every time the ignition switch is cycled to **OFF**.
- Shift into or out of R (Reverse) only after the vehicle has come to a complete stop and the engine is at idle speed.
- Do not shift between P (Park), R (Reverse), N (Neutral) or D (Drive) when the engine is above idle speed
- To effect any change from vehicle stop to R (Reverse), D (Drive), 1st or 2nd gear, it is necessary to keep the brake pedal fully depressed.



WARNING!

- It is dangerous to move the shift lever out of P (Park) or N (Neutral) if the engine speed is higher than idle speed. If your foot is not firmly pressing on the brake pedal, the vehicle could accelerate quickly

forward or in reverse. You could lose control of the vehicle and hit someone or something. Only shift into gear when the engine is idling normally and when your foot is firmly pressing on the brake pedal.

- Unintended movement of a vehicle could injure those in or near the vehicle. As with all vehicles, you should never exit a vehicle while the engine is running. Before exiting a vehicle, always apply the electronic parking brake, shift the transmission into P (Park), and turn the engine off. The shift lever will consequently lock in P (Park) position for a few seconds, then eases, handling the change to prevent the motion of the car.
- Never leave children alone in a vehicle, or with access to an unlocked vehicle. Allowing children to be in a vehicle unattended is dangerous for a number of reasons. A child or others could be seriously or fatally injured. Children should be warned not to touch the parking brake, brake pedal or the shift lever.
- When leaving the vehicle, always remove the key fob and lock your vehicle.
- Do not leave the key fob in or near

the vehicle. A child could operate power windows, other controls, or move the vehicle.

This vehicle is equipped with a feature which requires the shift lever to be placed in P (Park) before the engine can be turned off. This prevents the driver from inadvertently leaving the vehicle without having placed the transmission in P (Park). This system also locks the shift lever in P (Park) whenever the ignition switch is in the OFF position.

Automatic Transmission Lever

Automatic transmission is operated by a selection lever with lock button located on the central console. By using the selection lever it is possible to select following positions, indicated on the top of the lever: the selected position will illuminate in amber light.

- P (Park);
- R (Reverse);
- N (Neutral);
- D (Drive) automatic forward speed (8 speeds);
- -/+ to downshift or upshift when manual mode in D (Drive) status, or set M (Manual) mode.



Transmission status is visible on the lever and on the lower part of the Instrument cluster display.



By pressing the release button on the lever, the gear change positions field is displayed: if you release the button without moving the lever, the field disappears after 2 seconds. By operating instead the lever, the new range will be indicated in the field and in the lower part of the display.



If the vehicle is temporarily in the manual drive mode, D (Drive) status, or in M (Manual) drive mode, the gear position is indicated beside the lever status, on the lower part of the display.



In normal conditions, the shift lever is always unlocked. When in D (Drive) mode it is possible to upshift or downshift the changing gears by automatically temporarily setting in M (Manual) mode.

You must also press the brake pedal to shift the transmission out of P (Park) position.

Shifting from D (Drive) to P (Park) or R (Reverse) should be done only after the accelerator pedal is released and



the vehicle is stopped. Be sure to keep your foot pressed on the brake pedal when moving the shift lever between these gears.

DO NOT race the engine when shifting from P (Park) or N (Neutral) into another gear range.

Automatic Transmission Range

P (Park)

Use this position to park the vehicle. The gears can be shifted from P (Park) position only with the brake pedal pressed. To move the shift lever from P (Park) position to any other position, the engine must be switched on. The engine can be regularly started in P (Park) range. Never attempt to use P (Park) while the vehicle is in motion. When parking on a level surface, you may place the shift lever in the P (Park) position first, and then apply the electronic parking brake by pulling the trigger upwards.



The Instrument cluster will display the related light indicator (ⓘ) and the message for 5 seconds.



When parking on a hill, apply the parking brake before placing the shift lever in P (Park).

For enhanced security, turn the front wheels toward the curb on a downhill and away from the curb on an uphill grade.



WARNING!

- Never use the P (Park) position as a substitute for the electronic parking brake. Always apply the parking brake fully when parked to prevent vehicle movement and possible injury or damage.
- Make sure the transmission is in P (Park) before leaving the vehicle.



CAUTION!

- DO NOT race the engine when shifting from P (Park) or N (Neutral) into another gear range, as this can damage the drivetrain.
- The following indicators should be used to ensure that you have engaged the shift lever into the P (Park) position:
 - when shifting into P (Park), press the lock button on the shift lever and push the lever all the way forward until it stops. When released, the lever will return to its standard position;
 - with the brake pedal released, verify that P (Park) position is illuminated on the shift lever.



When moving the shift lever in P (Park) position, to facilitate the entry and exit from the vehicle and the loading/unloading of baggage, the system automatically lowers the height from the floor. Automatic lowering of the vehicle into “Entry/Exit” mode can be disabled through the MTC+ (refer to “MTC+ Settings” in section “Dashboard Instruments and Controls”).

R (Reverse)

This range is used to move the vehicle backward.

We recommend to shift into R (Reverse) only after the vehicle has come to a complete stop.

- Vehicle halted: switching between P (Park), R (Reverse) and D (Drive) requires pressing the unlock button on the lever and brake pedal: N (Neutral) is reached only by pressing the unlock button on the lever.
- Vehicle moving: the driver can switch from R (Reverse) to N (Neutral), or vice versa, by pressing the lock button on the shift lever.

N (Neutral)

- Vehicle halted and engine started: switching from N (Neutral) to R (Reverse), P (Park) and/or D (Drive)

requires brake pedal and unlock button pressed.

- Vehicle moving: switching from N (Neutral) to R (Reverse) and/or D (Drive) requires pressing the unlock button. Switching to R (Reverse) starting from N (Neutral) is only possible if the vehicle is moving backwards, while switching to D (Drive) starting from N (Neutral) is only possible if the vehicle is moving forwards.

Set the parking brake and shift the transmission into P (Park) if you must leave the vehicle.

NOTE:

To move the car into tunnel washers, or to generally move with engine off, if foreseen use the “Car Wash” mode (see “Bodywork Maintenance and Cure” chapter in section “Maintenance and Care”).



WARNING!

Do not switch to N (Neutral) and/or never turn off the ignition to coast downhill. These are unsafe practices that limit driver’s response to changing traffic or road conditions. It

is possible to lose control of the vehicle and have a collision.



CAUTION!

Towing the vehicle, coasting, or driving for any other reason with the transmission in N (Neutral) can result in transmission damage. See “Towing a Disabled Vehicle” in section “In an Emergency” for further information.

D (Drive)

This range should be used for most city and highway driving. It provides the smoothest upshifts and downshifts and the best fuel economy. The transmission automatically shifts up and down through all gears. The D (Drive) position provides optimum driving characteristics under all normal operating conditions of the vehicle.

- Vehicle stationary: to switch from D (Drive) to R (Reverse) and/or to P (Park) requires brake pedal and unlock button pressed: to reach N (Neutral) starting from D (Drive) is allowed by only pressing the unlock button on the shift lever.
- To enable special operations while the car is moving at a low speed, such as getting out of marsh or



snow, it is possible to run quickly from D (Drive) to R (Reverse), and vice versa, by pressing the reset button on the gear shift lever.


- Vehicle moving: switching to N (Neutral) from D (Drive) requires the unlock button on the shift lever pressed.
- From D (Drive) selected mode it is always possible to switch to M (Manual), by pressing the M (Manual) button: the Led indicator beside the button will light up; to return to D (Drive) position, the same action should be performed as the LED will turn off.
- When in D (Drive) mode, moving the shift lever forward or backwards to the next step without pressing the unlock button on the lever will cause the system to enter a temporary function and enable the manual shift mode. This range is indicated with the symbols “-/+” on the left and right sides of the “D” letter on the gear range field of the display. The system will then switch back to automatic mode according to time elapsed in “temporary” mode and driving conditions.

At extremely cold temperatures (-30°C/-23°F or below), transmission

may be affected by the low temperature of the engine and transmission. Normal operation will resume once the transmission temperature has risen to a normal level.


Transmission Malfunction and Overheating Conditions

Transmission Emergency Control

Transmission function is electronically monitored to detect abnormal conditions. If a condition that could result in transmission damage is detected, Transmission Limp Home Mode will be activated. In this situation, the transmission may operate only in certain gears, or may not shift at all. Vehicle performance may be severely degraded and the engine may stall. In some situations, the transmission system may not re-engage if the engine is turned off and restarted. The automatic transmission failure indicator light  may illuminate.



A message in the instrument cluster will inform the driver about the more serious transmission conditions, and indicate what actions may be necessary.

Transmission Oil Over Temperature

If the transmission oil temperature exceeds the operating limit, the  amber light illuminates on the instrument cluster.



In this case, slow down until temperature returns to normal level (the light will turn off).

If this is not sufficient, we recommend to stop the vehicle, shift the lever to position P (Park) or N (Neutral) and keep the engine idle until the temperature warning light  turns off and the message disappears from the display. Resume driving without demanding high engine performance. If the warning light  and the related message turns on again, it is advisable to stop the vehicle, turn off the engine and wait for the engine/transmission assembly to fully cool down.



If the instrument cluster message indicates that the transmission may not re-engage after engine shutdown, perform the following procedure preferably at a **Service Center**.

In the event of a momentary problem, the transmission can be reset to regain all forward gears by performing the following steps.

- Stop the vehicle.
- Shift the transmission into P (Park), if possible.
- Turn the engine off.
- Wait approximately 30 seconds.
- Restart the engine.
- Shift the transmission into D (Drive) and then into the desired gear range. If the problem is no longer detected, the transmission will return to normal operation.

NOTE:

*Even if the transmission can be reset, we recommend that you visit the **Service Network** at your earliest possible convenience, which has diagnostic equipment to determine if the problem could recur.*

Transmission Manual Release of P (Park) Position

See chapter “Transmission Manual Release of P (Park) Position” in section “In an Emergency”.

All-Wheel Drive

The active on-demand All-Wheel Drive (AWD) system provides available optimum traction for a wide variety of road and off-road surface and driving conditions. The system minimizes wheel slip by automatically redirecting torque to the front and rear wheels as necessary.

To maximise fuel economy, the AWD system automatically disengages torque distribution on front axle when road and environmental conditions are such that wheel slip is unlikely to occur. When specific road and environmental conditions require increased levels of road traction, the AWD system automatically distributes the torque between front and rear axle in order to grant the best driving experience. Torque distribution is displayed on the TFT in the “Drive Mode” main menu. Refer to paragraph “TFT Display: Menus and Settings” in chapter “Instrument Cluster” of section “Dashboard Instruments and Controls” for further information.



WARNING!

There may be a slight delay for AWD engagement after a wheel slip condition occurs.



NOTE:

If the AWD system service warning message appears after engine start up, or during driving, it means that the AWD system is not functioning properly. If the warning message is often activated, it is recommended to have the vehicle serviced at the **Service Network**.



Drive Mode

Controls Preview

Drive modes and ride heights to use the vehicle on and off road can be set using the buttons and vehicle height selector on central console.



CAUTION!

"NORMAL" is the default drive mode, optimised for the best balance between performances, fuel consumptions and emissions in the standard conditions use of the car.





Buttons on the central console have the following functions:

- (ESC OFF): to exclude/reactivate the ESC system.
- M (Manual): to switch from automatic to manual drive mode.
- I.C.E: to activate/deactivate the drive mode to ensure increased control on slippery surfaces as well as higher energy efficiency.
- SPORT and (Suspension): to activate/deactivate a sportier drive mode and to switch between the two suspensions setting modes (Soft, Hard). In this mode, the vehicle has a faster throttle response and ESC sport calibration (not recommended on wet/slippery surfaces).
- OFF ROAD: to activate/deactivate the specific driving mode for off road conditions (uphill/downhill, cobblestone, mud, grass and sand). In this mode, the vehicle has a specific ESC/ASR calibration and shock absorbers skyhook damping curve.

By selecting one of these drive modes, the LED beside the button illuminates and the vehicle configuration obtained is graphically displayed on instrument panel. The same screen is also obtained when selecting the

“Drive mode” menu using the buttons on steering wheel.

When changing drive mode between NORMAL, I.C.E., SPORT and OFF ROAD, engine temperature and fuel level indicators inner edge will change color if “Outline Coloring” of submenu “Screen Setup” is set to “On” (see example in the figure). Refer to chapter “Instrument Cluster” in section “Dashboard Instruments and Controls” for further information.



Setting the Drive Mode

Drive modes can be set using the buttons on central console.

Keys (buttons) only have two statuses: OFF and ON. The OFF status (button released) is the standard function mode. The ON status is activated by pressing the button, the dedicated LED will illuminate. It is necessary to

press the (ESC OFF) button for at least 3 seconds.



The table shows the different drive modes according to the status of the buttons.

Button	OFF – Button released	ON – Button pressed (LED ON)
	Electronic Stability Control ESC activated.	Electronic Stability Control ESC partially deactivated.
M	Autoshift Mode (Auto).	Manual shift mode (Manual) ON.
I.C.E.	Increased Control and Efficiency mode OFF.	Increased Control and Efficiency mode ON (*).
	Normal drive mode (NORMAL) ON and Soft suspensions setting (S).	<ul style="list-style-type: none"> • Button pressed first time (first LED ON): sportier drive mode (SPORT) ON and Soft suspension setting. • Button pressed second time (first and second LED ON): sportier drive mode (SPORT) ON and Hard suspension setting (H). • When button is pressed third time, it returns to OFF-button released.
OFF ROAD	OFF ROAD drive mode OFF.	OFF ROAD drive mode ON.
(*) I.C.E. (Increased Control and Efficiency) operates on engine supply in order to reduce fuel consumption, exhausts, noisiness (efficiency) by dampening vehicle reactions (control). The current mode is also useful for low-grip surfaces.		

The tables below summarise the adjustment of transmission and engine parameters according to set drive mode/s. (ESC OFF) is the only mode that does not depend on the activation or deactivation of the other modes. The tables show the two configurations with:

- (ESC OFF) button NOT pressed;
- (ESC OFF) button pressed.



(ESC OFF) Button NOT pressed

<p> Button pressed: LED ON Button not pressed: LED OFF</p>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
	<input type="radio"/> M	<input checked="" type="radio"/> M	<input type="radio"/> M	<input type="radio"/> M	<input type="radio"/> M	<input type="radio"/> M	<input type="radio"/> M
	<input type="radio"/> I.C.E.	<input type="radio"/> I.C.E.	<input checked="" type="radio"/> I.C.E.	<input type="radio"/> I.C.E.	<input type="radio"/> I.C.E.	<input type="radio"/> I.C.E.	<input type="radio"/> I.C.E.
	<input type="radio"/> SPORT	<input type="radio"/> SPORT	<input type="radio"/> SPORT	<input type="radio"/> SPORT	<input checked="" type="radio"/> SPORT	<input checked="" type="radio"/> SPORT	<input type="radio"/> SPORT
	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>
	<input type="radio"/> OFF ROAD	<input type="radio"/> OFF ROAD	<input type="radio"/> OFF ROAD	<input type="radio"/> OFF ROAD	<input type="radio"/> OFF ROAD	<input type="radio"/> OFF ROAD	<input checked="" type="radio"/> OFF ROAD
	<i>Setup</i>	Normal + Auto + Soft suspensions	Normal + Manual + Soft suspensions	I.C.E. + Auto + Soft suspensions	Sport + Auto + Soft suspensions	Sport + Auto + Hard suspensions	Off Road + Auto + Off Road suspension
Stability control	Active	Active	Active	Active-Sport (*)	Active-Sport (*)	Active with specific tuning	
Suspensions setup	Normal	Normal	Normal	Normal	Hard	Off Road	
Engine control	Normal	Normal	Comfort	Performance	Performance	Normal	
Engine boost	Normal boost	Overboost	Low boost	Overboost	Overboost	Overboost	
Exhaust sound	Low (Rev. Threshold)	Low (Rev. Threshold)	Close to 5000 rpm	Always High	Always High	Normal	
Gear shifting point	Normal	-	Comfort	Performance	Performance	Off Road	
Kick down	Yes	Yes	Yes - Soft	Yes - Strong	Yes - Strong	Yes	
Upshift rev. limiter	Yes	Yes	Yes	Yes (No, when in M)	Yes (No, when in M)	Yes	



<input checked="" type="radio"/> Button pressed: LED ON <input type="radio"/> Button not pressed: LED OFF	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
	<input type="radio"/> M	<input checked="" type="radio"/> M	<input type="radio"/> M	<input type="radio"/> M	<input type="radio"/> M	<input type="radio"/> M	<input type="radio"/> M
	<input type="radio"/> I.C.E.	<input type="radio"/> I.C.E.	<input checked="" type="radio"/> I.C.E.	<input type="radio"/> I.C.E.	<input type="radio"/> I.C.E.	<input type="radio"/> I.C.E.	<input type="radio"/> I.C.E.
	<input type="radio"/> SPORT	<input type="radio"/> SPORT	<input type="radio"/> SPORT	<input checked="" type="radio"/> SPORT	<input type="radio"/> SPORT	<input checked="" type="radio"/> SPORT	<input type="radio"/> SPORT
	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>
	<input type="radio"/> OFF ROAD	<input type="radio"/> OFF ROAD	<input type="radio"/> OFF ROAD	<input type="radio"/> OFF ROAD	<input type="radio"/> OFF ROAD	<input type="radio"/> OFF ROAD	<input checked="" type="radio"/> OFF ROAD
Automatic downshift	Normal	Anti - Stall	Normal	Performance (Anti - Stall, when in M)	Performance (Anti - Stall, when in M)	Normal (Anti - Stall, when in M)	
Shifting timing	Normal	Quick - Normal	Comfort	Sport (Quick - Sport, when in M)	Sport (Quick - Sport, when in M)	Normal	

(*) In low- and medium-grip conditions (e.g., rain, snow, ice, sand, etc.) it is advisable not to activate Sport mode, even with the ESC system active (button not pressed).



(ESC OFF) Button pressed

<p> Button pressed: LED ON Button not pressed: LED OFF</p>	<p> M I.C.E. SPORT OFF ROAD</p>	<p> M I.C.E. SPORT OFF ROAD</p>	<p> M I.C.E. SPORT OFF ROAD</p>	<p> M I.C.E. SPORT OFF ROAD</p>	<p> M I.C.E. SPORT OFF ROAD</p>	<p> M I.C.E. SPORT OFF ROAD</p>
Setup	Normal + Auto + Soft suspensions	Normal + Manual + Soft suspensions	I.C.E. + Auto + Soft suspensions	Sport + Auto + Soft suspensions	Sport + Auto + Hard suspensions	Off Road + Auto + Off Road suspension
Stability control	OFF	OFF	OFF	OFF	OFF	OFF
Suspensions setup	Normal	Normal	Normal	Normal	Hard	Off Road
Engine control	Normal	Normal	Comfort	Performance	Performance	Normal
Engine boost	Normal boost	Overboost	Low boost	Overboost	Overboost	Overboost
Exhaust sound	Low (Rev. Threshold)	Low (Rev. Threshold)	Close to 5000 rpm	Always High	Always High	Normal
Gear shifting point	Normal	-	Comfort	Performance	Performance	Off Road
Kick down	Yes	Yes	Yes - Soft	Yes - Strong	Yes - Strong	Yes
Upshift rev. limiter	Yes	Yes	Yes	Yes (No, when in M)	Yes (No, when in M)	Yes



<input checked="" type="radio"/> Button pressed: LED ON <input type="radio"/> Button not pressed: LED OFF	<input checked="" type="radio"/> M <input type="radio"/> I.C.E. <input type="radio"/> SPORT <input type="radio"/> OFF ROAD <input type="radio"/> OFF ROAD	<input checked="" type="radio"/> M <input type="radio"/> I.C.E. <input type="radio"/> SPORT <input type="radio"/> OFF ROAD <input type="radio"/> OFF ROAD	<input checked="" type="radio"/> M <input type="radio"/> I.C.E. <input type="radio"/> SPORT <input type="radio"/> OFF ROAD <input type="radio"/> OFF ROAD	<input checked="" type="radio"/> M <input type="radio"/> I.C.E. <input checked="" type="radio"/> SPORT <input type="radio"/> OFF ROAD <input type="radio"/> OFF ROAD	<input checked="" type="radio"/> M <input type="radio"/> I.C.E. <input type="radio"/> SPORT <input checked="" type="radio"/> OFF ROAD <input type="radio"/> OFF ROAD	<input checked="" type="radio"/> M <input type="radio"/> I.C.E. <input type="radio"/> SPORT <input type="radio"/> OFF ROAD <input checked="" type="radio"/> OFF ROAD
Automatic downshift	Normal	Anti - Stall	Normal	Performance (Anti - Stall, when in M)	Performance (Anti - Stall, when in M)	Normal (Anti - Stall, when in M)
Shifting timing	Normal	Quick - Normal	Comfort	Sport (Quick - Sport, when in M)	Sport (Quick - Sport, when in M)	Normal

NOTE:


A different drive mode can be set even with engine running and vehicle in motion.

To activate a drive mode, press briefly the corresponding button. The LED beside the button will light up and set drive mode screen will be displayed (example in the figure: I.C.E.) for 5 seconds.






Activate/Deactivate (ESC OFF) Drive Mode


To activate  drive mode press the corresponding button for at least 3 seconds.



To deactivate the drive mode, press the same button again: the display will show the message indicating that  drive mode is off and ESC system is active.

Activate/Deactivate SPORT / Drive Mode

To activate SPORT drive mode, press the corresponding button once: the LED beside the symbol "SPORT" will turn on. Remaining in SPORT mode,

Hard suspension setting can be activated by pressing again the same button: also the LED beside the symbol  will turn on.



To disable the SPORT mode, press the same button once again: the two LED will turn off.

Monitoring Settings on Display

By gaining access to "Drive mode" menu through the buttons on steering wheel right-hand side, it is possible to monitor the settings for driving on and off road.

The list and figure show vehicle parameters referred to each drive mode. Driving mode and its










parameters are identified by a different color (example in the figure: I.C.E.).

- A Ride height
- B Powertrain
- C ESC
- D Torque distribution
- E Suspension stiffness









The table below specifies the default, ride height and relevant commands that can be set, for each drive mode.



Drive Mode	Default Condition		Possible Ride Height / Command
	ESC	Normal	<ul style="list-style-type: none"> • Normal / Via dedicated drive height selector according to current speed. • Aero 1 / Via dedicated drive height selector according to current speed. • Aero 2 / Only speed dependent. • Entry/Exit / Via dedicated drive height selector according to current speed.
		Normal	
		Normal	
	ESC	I.C.E.	<ul style="list-style-type: none"> • Normal / Via dedicated drive height selector according to current speed. • Aero 1 / Via dedicated drive height selector according to current speed. • Aero 2 / Only speed dependent. • Entry/Exit / Via dedicated drive height selector according to current speed.
		Normal	
		Normal	
	ESC	Sport	<ul style="list-style-type: none"> • Normal / Via dedicated drive height selector according to current speed. • Aero 1 / Via dedicated drive height selector according to current speed. • Aero 2 / Only speed dependent. • Entry/Exit / Via dedicated drive height selector according to current speed.
		Normal	
		Normal	



Drive Mode	Default Condition		Possible Ride Height / Command
	ESC	Sport	<ul style="list-style-type: none"> • Normal / Via dedicated drive height selector according to current speed. • Aero 1 / Via dedicated drive height selector according to current speed. • Aero 2 / Only speed dependent. • Entry/Exit / Via dedicated drive height selector according to current speed.
		Sport	
		Aero 1	
	ESC	Off Road	<ul style="list-style-type: none"> • Off Road 1 / Via dedicated drive height selector according to current speed. • Off Road 2 / Via dedicated drive height selector according to current speed.
		Off Road	
		Off Road 1	

Automatic Selection of Drive Mode upon Ignition

If ride height was set to “Off Road 1” or “Off Road 2” before switching off the vehicle, this setting will be applied upon the following activation of the ignition device.

While if any other ride height/drive mode is set, “NORMAL” ride height/drive mode will be set automatically upon re-ignition.



M (Manual) Drive Mode

In this mode, the transmission interacts with the driver in order to allow manual shift and increase driver interaction. The current mode allows the gear system to optimise the engine brake action, remove undesired shifting into higher and lower gears and improve the overall performance of the vehicle.

This mode allows you to move the shift lever step by step forward (-) or backward (+) without pressing the lock button. The current transmission gear is displayed on the instrument cluster beside "M".

5



Using the shift paddles behind the steering wheel (if foreseen), the corresponding icon will display beside the "M" indication and current shifted gear.

Pull the right shift paddle (+) towards the steering wheel and release it to enter the higher gear; do the same operation with the left shift paddle (-) to enter the lower gear.



Manual mode can be activated at any time, with no need to release the brake pedal.

Even if the release button is pressed and gear is shifted in R (Reverse), P (Park) or N (Neutral), the selected manual mode will be maintained.

In Manual mode, the transmission will shift up or down (+/-) if manually selected by the driver by using the shift lever, or shift paddles on the steering wheel (if present). The transmission remains in the engaged gear until the driver shifts into another higher or lower gear, except in the following cases.

- Lack of accelerator pedal activity will cause the transmission to revert to automatic operation. The transmission will also upshift automatically once maximum engine speed is reached.



- If in SPORT mode, the transmission will remain in the selected gear even when maximum engine speed is reached. The transmission will upshift only if enabled by the driver. Manual upshift or downshift will be maintained as long as SPORT mode is selected, even by full stroke pedal press.
- If in M (Manual) or in SPORT mode, the transmission will automatically downshift as the vehicle slows to halt (to prevent engine lugging) and the current gear will display on the instrument cluster. Shifting the shift lever backward (+) or moving the right shift paddle (+) towards the steering wheel when stationary, will cause the vehicle to start in second gear. If the vehicle speed is too low, the system will ignore further upshifts. Avoid using speed control when the M (Manual) mode is engaged.

Note for diesel version

If the transmission is in SPORT mode, the system will change gear automatically when the set rpm limit (limiter) is reached.

Gear Shift Indicator Light

In order to improve fuel economy, we recommend that you shift gears when the system prompts you to do so. This will help reduce fuel consumption without significantly affecting vehicle performance.

The indicator beside the displayed gear will light up just before reaching the required speed to change downshift ▼ or upshift ▲ (example in the figure).




When the new gear is engaged, the indicator turns off. If the shift runs late or is not performed at all, the indicator remains lit for a few seconds then turns off. As soon as new conditions requiring further gear change occur, the indicator light will illuminate again.

NOTE:

The gearshift indicator will only work when the transmission is set in M (Manual) mode.





I.C.E. Mode excluding ESC

To release the vehicle in low grip conditions (e.g.: heaps of snow, mud, sand, etc), it is possible to shift the transmission feature in the specific driving mode as required for these situations, by pressing the I.C.E. button and to exclude completely the yaw and spinning control system, by pressing the button for two seconds  (ESC OFF).

Setting Ride Height

The pneumatic suspension system ensures vehicle continuous automatic levelling and allows setting ground clearance by simply moving the ride height selector.

The selector can be moved forward () and backward () by one position at a time in order to set six different heights. Every position is identified by the switch-on of the corresponding LED at the left side of the selector and in the dedicated area at top right of the display.

The table below shows the possible selector positions and the relevant symbols.

	Off Road 2
	Off Road 1
	Normal
	Aero 1
	Aero 2
	Entry/Exit



During transition from one position to another, the instrument panel display will show a pop-up indicator (above the coolant temperature indicator) which reproduces the ride height symbols. On this indicator, the LED for the new position, set by means of the selector on central console, will flash while the LEDs of intermediate positions will turn on when set position is reached. The new position will be displayed on the dedicated area at top right of the display and the indicator will turn off after approximately 2 seconds.



The system requires that the engine be running for all changes. When lowering the vehicle, all of the doors, including the liftgate, must be closed. If a door is opened at any time while the vehicle is lowering, the change will not be completed until the open door/s is/are closed.

The pneumatic suspension system of this vehicle uses a lifting and lowering pattern preventing the headlights from incorrectly shining into oncoming traffic.

When raising the vehicle, the rear of the vehicle will move up first and then the front.

When lowering the vehicle, the front will move down first and then the rear.

After the engine is turned off, it may be noticed that the pneumatic suspension system operates briefly, this is normal. The system is correcting

the position of the vehicle with little suspension movements to ensure a proper appearance.

Display Messages

After shifting selector to change position, a pop-up message will indicate for 5 seconds when set position has been reached (after pneumatic suspension system intervention that might last up to 30 seconds).

This type of message will be displayed only if the option to view all pneumatic suspension system messages was set (For further details, refer to "MTC+ Settings" in section "Dashboard Instruments and Controls").



Set ride height and drive mode can be monitored on instrument panel display via "Drive mode" menu, using buttons on the right-hand side of the

steering wheel (see chapter "Instrument Cluster" in section "Dashboard Instruments and Controls").

The change from one position to another can occur only if the following requirements are met.

- Lifting: engine running, speed lower than preset limit, etc.
- Lowering: engine running, speed lower than preset limit, doors closed, etc.

Ride height change can be temporarily suspended or disabled under the following conditions, as indicated in the pop-up messages on instrument panel display.

- High speed: decrease speed to set new height.
- Pneumatic suspension system overheat: wait for the system to cool down before changing height.
- Door(s) and/or liftgate open: close door(s) and liftgate to lower the vehicle.
- Pneumatic suspension system temporarily disabled or in fault: wait a few minutes and repeat the operation or contact the **Service Network**.



- Low battery: start the engine to recharge battery and change ride height.
- Entry/Exit position not available: check the cause preventing this control.

Using the Ride Height Positions and speed Thresholds

The different ride heights that can be set with the selector allow user to drive the vehicle on and off road, using the available drive modes and functions.

NOTE:

The indications below explain as a general rule which selector position has to be used in certain situations and which are the speed thresholds at which it is possible to set the available ride height and when system automatically switches to a different height. In any case, the driver must always assess and set the ride height and drive mode most suitable to the conditions of the current driving path on a case by case basis.

- **Normal:** normal ground clearance. This is the standard height position of the pneumatic suspension and is meant for normal road conditions.

In this ride height position driver can set the "NORMAL" and "I.C.E. drive modes.

- **Off Road 1:** raises the vehicle by approx. 25 mm (1 in). This is the height suitable for most off road driving conditions until the other "OFF ROAD" option is needed. This ride height can set only in "OFF ROAD" drive mode. Select this height while the vehicle speed is below 80 km/h (50 mph). When in the "Off Road 1" height, if the vehicle speed remains between 80 km/h (50 mph) and 90 km/h (56 mph) for over 30 seconds or if vehicle speed exceeds 90 km/h (56 mph), the vehicle will be automatically lowered to "NORMAL" height. For further details, refer to "Off-road Drive" in this section.
- **Off Road 2:** raises the vehicle by approx. 40 mm (1.5 in). This height is intended for off-road use only where maximum ground clearance is required. This ride height can be set only in "OFF ROAD" drive mode. Select this height while the vehicle speed is below 30 km/h (18.6 mph). When in the "Off Road 2" height, if the vehicle speed remains between 30 km/h (18.6 mph) and 40 km/h (25 mph) for over 30 seconds or if

vehicle speed exceeds 40 km/h (25 mph), the vehicle will be automatically lowered to "Off Road 1" height. For further details, refer to "Off-road drive" in this section.

- **Aero 1:** lowers the vehicle by approx. 20 mm (0.8 in). This height provides improved aerodynamics by lowering the vehicle. This ride height is available in "NORMAL", "SPORT ⚡" or "I.C.E." drive mode. System automatically lowers the vehicle when speed remains between 120 km/h (74.5 mph) and 130 km/h (80 mph) for over 15 seconds or if the vehicle speed exceeds 130 km/h (80 mph). The system will return to "NORMAL" height when the vehicle speed remains between 100 km/h (62 mph) and 90 km/h (56 mph) for over 15 seconds or if the vehicle speed falls below 90 km/h (56 mph). The vehicle will enter "Aero 1" height, regardless of vehicle speed if the "SPORT" mode is set.
- **Aero 2:** lowers the vehicle by approx. 35 mm (1.4 in). It is the height ensuring excellent aerodynamics for top performance further lowering the vehicle. This ride height is available in "NORMAL", "SPORT ⚡" or "I.C.E."



drive mode.

System automatically lowers the vehicle when speed exceeds 170 km/h (105.6 mph) or when it remains between 170 km/h (105.6 mph) and 185 km/h (115 mph) for over 15 seconds. The system will return to Aero 1 height when the vehicle speed remains between 155 km/h (96.3 mph) and 140 km/h (87 mph) for over 15 seconds or if the vehicle speed falls below 140 km/h (87 mph).

- **Easy/Entry:** lowers the vehicle by approx. 45 mm (1.8 in). This mode lowers the vehicle for easier passenger entry and exit as well as lowering the rear of the vehicle for easier loading and unloading of cargo from the boot compartment. This ride height can be set only in "NORMAL", "SPORT" or "I.C.E." After selecting this height, once the vehicle speed goes below 24 km/h (15 mph), the vehicle height will begin to lower. To exit "Entry/Exit" mode, move selector to another position or drive the vehicle over 24 km/h (15 mph). Automatic lowering of the vehicle into "Entry/Exit" mode can be enabled through the MTC+ (refer to "MTC+ Settings" in section "Dashboard

Instruments and Controls"). If this feature is enabled, the vehicle will only lower if the gearshift lever is in P (Park), the engine is running, doors and liftgate are closed and the pneumatic suspension system should be either in "NORMAL" or "Aero". The Vehicle will not automatically lower if the pneumatic suspension system is in "Off Road 2" or "Off Road 1" mode. The lowering will be suppressed when the ignition is switched off and a door is opened to prevent setting the alarm off.

Lowering Vehicle Height for Inactivity

Lowering of vehicle ground clearance after a long period of inactivity should be considered normal since it is due to a drop of pressure in the pneumatic suspension system.

Approximately, after one week of inactivity, vehicle ground clearance will lower by 10 mm (0.4 in). To set off the drop of pressure due to inactivity, it is necessary to start the engine and allow some time until system reaches operating pressure and lifts the vehicle to set ride height. A message on instrument cluster display will warn driver when set ride height is reached.



Driving vehicle before the set riding height is reached is not safe and could damage suspension components.



WARNING!

After a long period of inactivity, drive the vehicle only when reaches set ride height to prevent any problems of the pneumatic suspension system from limiting occupants' safety.



Off-Road Drive

This vehicle is equipped with a specific "Off Road" driving mode which allows to drive through various terrain conditions (rock, mud, sand), also in uphill and downhill, eventually in condition of lateral inclination.

To set the "OFF-ROAD" drive mode, please see paragraphs "Setting the Drive Mode" and "Setting Ride Height" of chapter "Drive Mode" in this section.

In order to enhance this specific performance, the "OFF-ROAD" drive mode modifies the setting of:

- Ride height;
- Engine, transmission calibration;
- Suspensions.

When "OFF ROAD" is selected, ride height is set to "Off Road 1" (vehicle is higher by approx. 25 mm / 1 in).

It is possible to select ride height "Off Road 2" (vehicle is raised by approx. 40 mm / 1.5 in) using the ride height selector.

"OFF ROAD" drive mode is limited up to a max speed of 90 km/h (56 mph). In case the vehicle speed should exceed this limit, the drive mode will be de-selected automatically and the driving mode will return to normal.

"Off Road 2" ride height is limited instead up to a max speed of 40 km/h (25 mph). In case the vehicle speed should exceed this limit, ride height will be put automatically to "Off Road 1" while driving mode will remain "OFF ROAD".

An advantage of the higher ground clearance is a better view of the road, allowing you to anticipate problems. A higher clearance and the longer travel of the suspension might allow the vehicle to overcome some obstacles.

A higher ground clearance means a higher center of gravity. If at all possible, avoid sharp turns or abrupt manoeuvres. **Failure to operate this vehicle correctly may result in loss of control or vehicle rollover.**

Although the pneumatic suspension system contributes to limiting these risks by setting precautionary speed thresholds, the driver must always pay utmost attention and drive carefully.



WARNING!

"Off Road 2" ride height must always be selected in case of water fording. Please remember water fording limits: max depth of the water must be lower

than 50 cm (18 in) and crossing speed lower than 8 km/h (5 mph).

In "OFF ROAD" drive mode, also engine, transmission settings are changed in order to provide the most suitable level of torque and selected gear to improve traction on low-adherence condition and uphill climbing.



WARNING!

In case of downhill, the use of the Hill Descent Control (HDC) is recommended, especially for relevant slope and in case of low-adherence conditions.

Also suspensions (Skyhook Continuous Damping Control) are set to a specific calibration in "OFF ROAD" driving mode, in order to obtain the right damping force provided by the shock absorbers, combined with the increased ride heights "Off Road 1" and "Off Road 2".

Driving Through Water

Set maximum ride height "Off Road 2" before driving through water. Although your vehicle is capable of driving through water, there are a



number of precautions that must be considered before entering the water.

NOTE:

Your vehicle is capable of water fording to a maximum of 50 cm (18 in) of water. To maintain optimal performance of your vehicle's heating and ventilation system it is recommended to switch the system into recirculation mode during water fording.



CAUTION!

When driving through water, do not exceed 8 km/h (5 mph). Always check water depth before entering, as a precaution. Check all fluids afterwards: driving through water may cause damage to engine and driveline that may not be covered by the new vehicle limited warranty

Driving through water more than a few inches/centimeters deep will require extra caution to ensure safety and prevent damage to your vehicle. If you must drive through water, try to determine the depth and the bottom condition (and location of any obstacles) prior to entering. Proceed with caution and maintain a steady

controlled speed lower than 8 km/h (5 mph) while in water to minimize wave effects that might cause serious damage to all components, especially engine.



WARNING!

Avoid driving through flowing or standing water. Doing so can be highly dangerous and can be very difficult to determine the depth of the water you are driving through. If driving through water cannot be avoided, and after driving through it, apply the brakes lightly to ensure the brakes are operating correctly.

Flowing Water

If the water is swift flowing and rising (as in storm run-off), avoid crossing until the water level recedes and/or the flow rate is reduced. If you must cross flowing water avoid depths in excess of 25 cm (9 in). The flowing water can erode the streambed, causing your vehicle to sink into deeper water and create waves that could cause serious damage to mechanical and electric components. Determine exit point(s) that are

downstream of your entry point to allow for drifting.

Standing Water

Do not drive in standing water deeper than 50 cm (18 in), and reduce speed appropriately to minimize wave effects.

Maintenance

After driving through water, have your vehicle fluids and lubricants inspected at the **Service Network** to assure the fluids have not been contaminated.

Driving in Snow and Wet Grass

In heavy snow, when pulling a load, or for additional control at slower speeds, set "I.C.E." drive mode with transmission in M (Manual) and shift the transmission to a low gear. See "Drive Mode" in this section for further details. Do not shift to a lower gear than necessary to maintain forward motion. Over-revving the engine can spin the wheels and traction will be lost. Avoid abrupt downshifts on icy or slippery roads, because engine braking may cause skidding and loss of control.



Follow these instructions even when driving through a path section covered with wet grass.

Driving in Mud and Sand

In general, when driving in mud and sand, if your wheels spin, always reduce the throttle in order to slow the tires and regain traction.

- When driving in mud, avoid using low gear that could cause wheel spin. Follow the tyre and vehicle manufacturer's advice on tire pressure.
- When driving in sand, adopt lowest gear possible. Tire pressure set at the lower limits may help to increase the vehicle capability. If you are driving through sand dunes, avoid climbing over them while try to go round them.

Hill Climbing

Before climbing a hill, determine the conditions at the crest and/or on the other side and shift the transmission to a lower gear.

The vehicle is equipped with Hill Start Assist (HSA) that helps the driver to manage the brake intervention in acceleration when driving uphill (for further details, refer to "Brake and

Stability Control System" in this section).

If you stall or begin to lose forward motion while climbing a steep hill, allow your vehicle to come to a stop and immediately apply the brakes. If stalled, restart the engine, and shift into R (Reverse). Back slowly down the hill, allowing the compression braking of the engine to help regulate your speed. If the brakes are required to control vehicle speed, apply them lightly and avoid locking or skidding the tires.



WARNING!

If you lose forward motion, or cannot make it to the top of a hill or grade, never attempt to turn around. To do so may result in tipping and rolling the vehicle. Always back carefully straight down a hill in R (Reverse) gear. Never back down a hill in N (Neutral) using only the brake

Remember, never drive diagonally across a hill; always drive straight up or down.

If the wheels start to slip as you approach the crest of a hill, ease off the accelerator and maintain forward motion by turning the front wheels

slowly. This may provide a fresh "bite" into the surface and will usually provide traction to complete the climb.

Traction Downhill

When descending mountains or hills, use Hill Descent Control (HDC) to avoid repeated heavy braking (for further details, refer to "Brake and Stability Control System" in this section).

When descending mountains or hills, repeated braking can cause brake fade with loss of braking power. Avoid repeated heavy braking and downshift the transmission whenever possible in order to cool down the brakes.

Warnings and Tips for Off-road Driving

When driving off-road, using the "OFF ROAD" drive mode which is specific for this use, it is necessary to pay utmost attention when tackling potentially dangerous paths.

Before moving off, always make sure that the vehicle reached the ride height set through the selector.

When driving, always:

- limit driving speed as much as possible to tackle bends, bumpy sections and slopes;



- increase visual control in front and on the sides of the vehicle to quickly spot any obstacles on your path (potholes, branches, etc.);
- if possible, avoid going up steep ramps without being aware of the level of difficulty of the path beyond the ramp peak;
- consider that weather conditions may suddenly change and increase the level of difficulty of the paths to be driven through.

Always consider these tips further to your experience gained in off-road driving.

After Driving Off-road

Off-road operation puts more stress on your vehicle than does most on-road driving. After going off-road, it is always a good idea to check for damage. That way you can get any problems taken care of right away and have your vehicle ready when you need it.

- Completely inspect the underbody of your vehicle. Check tires, body structure, steering, suspension, and exhaust system for damage.
- Inspect the radiator for mud and debris that might decrease sinking effect and clean as required.

- Check for accumulations of plants or brush in underbody. These things could be a fire hazard if they get in contact with the exhaust system.
- After extended operation in mud, sand, water, or similar dirty conditions, have all parts that got in contact with mud, sand and water inspected and cleaned as soon as possible.



WARNING!


Abrasive material in any part of the brakes may cause excessive wear or unpredictable braking operation. You might not have full braking power when you need it to prevent a collision. Do not drive if braking system is not perfectly efficient: get your brakes checked and cleaned as necessary by the Service Network.

- If you experience unusual vibration after driving in mud, slush or similar conditions, check the wheels and suspension linkages for impacted material. Impacted material can cause wheel imbalance and affect suspension response. Removing it will correct the situation.


Parking Brake

The vehicle is equipped with an electric automatic parking brake, also called EPB (Electric Parking Brake). The braking action is ensured by a power actuator directly working on the brake pad inside each calliper of the rear brake system.

It can be automatically engaged when the engine is turned off and disengaged with engine running, driver seatbelt latched and driver door closed, while pressing the brake pedal and operating the shift lever.


When the parking brake is applied, the warning light  lights up on the rev. counter display and the related message is displayed on the instrument cluster for 5 seconds (see “Instrument Cluster” in section “Dashboard Instruments and Controls”).



During engagement and disengagement procedures, the warning light  flashes until the parking brake has reached its maximum activation force and is respectively fully released. In the above-mentioned conditions, the automatic engagement function can be deactivated/activated by selecting the menu item "Vehicle settings" on the main menu (refer to paragraph "Deactivating Automatic Operation" in this chapter).

Manual Engagement/Disengagement

The parking brake can also be manually engaged or disengaged when the engine is running or the ignition switch is in the **RUN** position, by pressing the brake pedal and

raising the lever located behind the shift lever. When the parking brake is applied, the warning light  lights up on the rev. counter and the related message will be displayed for 5 seconds on the instrument cluster.

If you attempt to engage/disengage the parking brake without having pressed the brake pedal, a message will be displayed, warning you to press the brake pedal.

If the engine was turned off when the automatic engagement device was deactivated (see "Deactivating Automatic Operation" in this chapter) it is possible to shift the parking brake simply by pulling the lever upward within 3 minutes after turning off.



CAUTION!

The main function of the EPB is to allow safe parking of the vehicle, therefore it must only be applied when the vehicle is already stationary. If the EPB is used while the vehicle is moving and decelerating until a speed lower of 5 km/h (3 mph) and, in particular, until complete stop (typically in a sudden brake), it is necessary to have the EPB system checked by the **Service Network**.



WARNING!

- Always hold the brake pedal pressed during engagement or disengagement of the parking brake.
- The EPB command activation while running generates a deceleration of the vehicle with strong deceleration (Dynamic Braking). It is therefore recommended to use this feature only in case of emergency. The stability of the car is guaranteed by the action of the activated ESC system.



Deactivating Automatic Operation

The automatic engagement function can be deactivated/reactivated by selecting the menu item “Vehicle settings” through the switch on the right-side of the steering wheel (refer to “Instrument Cluster” in section “Dashboard Instruments and Controls”).

Press and release the switch toward the arrow (▶) to select “Electric Park Brake”.



Press and release the switch once again toward the arrow (▶) to visualize the options connected to this function.

- Auto Apply On;
- Auto Apply Off (default setting).



Scroll with the switch toward the arrow ▲ or ▼ through the programmable options. Press and release the switch toward the arrow (▶) to set the selected option. A check mark will remain next to the previously-selected item until a new selection is made.



“Setting Saved” Selection notification appears as a popup for 2 seconds then the display will show again the modified function.



In order to disable the automatic operation follow the same procedures and select the other option.




CAUTION!

- Under certain conditions when the battery voltage is low, the electric automatic parking brake system may temporarily be deactivated for safety reasons. Therefore, typically upon starting the engine, when the battery voltage drops, a message may temporarily be displayed, indicating that automatic operation is temporarily disabled.
- In case of repetitive requests to reset the EPB through the messages shown on the TFT display, please contact the **Service Network**.



Failure Indication

In the event of electric parking brake system failure, the warning light  on the display will light up and the related message will show for 5 seconds.



WARNING!

In the event of an EPB failure, take your vehicle to the nearest Service Network Center as soon as possible.



Emergency Disengagement

In case of brake lock with complete electrical system failure, it is necessary to force the electric actuator on the rear calipers (see "Emergency Release of the Parking Brake" chapter in section "In an Emergency").

EPB Operation with Overheated Brakes

Driving on mountain roads with steep slopes or a sports use of the vehicle could overheat the brake system components. In these conditions, parking brake must not be used since the push of the power actuator might not be sufficient to ensure vehicle braking, especially on a slope. Drive normally without braking to allow the brakes to cool down a few minutes before stopping. In this way, the automatic or manual activation of the parking brake will ensure vehicle braking.

Parking

Before leaving the vehicle, make sure that the parking brake is fully applied and place the shift lever in the P (Park) position.



WARNING!

- Always check that the vehicle is locked before leaving it.
- Never leave children unattended in the vehicle.
- Do not park the vehicle on paper, grass, dry leaves or other flammable materials. They could catch fire if they come into contact with hot parts of the exhaust system.
- Do not leave the engine running while the vehicle is unattended.



CAUTION!

- When you need to park the vehicle on a steep slope, both with the engine on and off, it is recommended not only to engage the parking brake, but also to shift the gearshift lever to P (Park) before leaving the vehicle.



- When parking on uneven surfaces (rocks, sidewalks, etc.) do not activate the Entry/Exit ride height to avoid any contact of the bottom of the car with the protrusions of the ground.

When parking on hill roads, it is important to turn the front wheels toward the curb on a downhill grade and away from the curb on an uphill grade.

Apply the parking brake before placing the shift lever in P (Park), otherwise the load on the transmission locking mechanism may make it difficult to move the shift lever out of P (Park).

In certain conditions, it is however advisable to disengage the parking brake manually and slightly apply the service brake for starting off. This is advisable when there are obstacles very close to the vehicle in the direction in which you intend to move.



“Drive Away Inhibit” strategy

In order to avoid a dangerous condition resulting from leaving the vehicle not “braked” with running

engine and without driver on board, “Drive Away Inhibit” strategy alerts the driver with messages on the instrument cluster display and sounding chimes, then puts the

transmission in P (Park) and applies the parking brake. The table shows the vehicle condition and the action that the system runs to exit the dangerous condition.

Vehicle condition	Action of the driver	
<ul style="list-style-type: none"> • Engine running and speed lower than 3 km/h (1.8 mph). • Transmission in any position other P (Park). • Driver safety belt unlocked. • Driver door opened. • Brake pedal pressed. 	<p>The driver releases the brake pedal to get out of the vehicle.</p>	<p>The system puts the transmission in P (Park) position and applies the parking brake</p>
<p>Warnings</p>	<p>Warnings</p>	
<ul style="list-style-type: none"> • Slow continuous chime. • The condition of the vehicle not in P (Park) position will be signalled by a message on the display. 	<ul style="list-style-type: none"> • Fast chime. • A message which invites to engage the parking brake to prevent vehicle movement will be displayed on the display. 	



Brake and Stability Control System

The vehicle is endowed with an Electronic Stability Control System (ESC), which helps to maintain directional control in the event of loss of grip of the tires. The system is able to detect potentially dangerous situations for the stability of the vehicle and automatically sets the brakes on all four wheels in a differentiated manner, in order to provide a torque settlement of the vehicle.

ESC includes the following subsystems:

- ABS (Anti-lock Braking System);
- EBD (Electronic Brake-force Distribution);
- TCS (Traction Control System);
- BAS (Brake Assist System);
- HSA (Hill Start Assist).
- ROM (Roll-Over Mitigation);
- TSM (Trailer Sway Mitigation);
- HDC (Hill Descent Control).



WARNING!

- **These systems cannot prevent the natural laws of physics from affecting the vehicle, nor can they**

increase traction, braking or steering efficiency beyond that afforded by the condition of the vehicle brakes and tires.

- **These systems cannot prevent collisions, including those resulting from excessive speed in turns, following another vehicle too closely, or hydroplaning.**
- **The capabilities of a vehicle equipped with these systems must never be exploited in a reckless or dangerous manner that could jeopardise the driver's and the passenger's safety or the safety of others.**

Electronic Stability Control (ESC)

This system enhances directional control and stability of the vehicle under various driving conditions. The ESC corrects over steering and under steering of the vehicle by applying the brake to the appropriate wheel.

Engine power may also be reduced to assist in counteracting the conditions of instability and maintain the right direction. The system is also able to reduce the engine power.

Through sensors fitted on the vehicle, the ESC system detects the driver's

chosen direction comparing it to the one maintained while running. In case of discrepancy between the required trajectory and the current one, the ESC system brakes the appropriate wheel to counteract over or under steering.

- Oversteer - when the vehicle is turning more than appropriate for the steering wheel position.
- Understeer - when the vehicle is turning less than appropriate for the steering wheel position.

The ESC system has two available operating modes:


ESC on

This is the normal ESC operating mode. At each start-up of the vehicle, the ESC system is set in this mode and should be used for most driving conditions. The ESC should only be turned off for specific reasons as pointed out in the following paragraphs.

ESC off


The "ESC off" mode is aimed for a more spirited driving experience but also purposeful for driving in deep snow, sand, or gravel. The current mode disables the TCS portion of the ESC and raises the threshold for ESC activation, allowing higher wheel spin




than normally granted by the ESC system. The  switch is fitted beside the gear shift lever: to deactivate the system see "Drive mode" in "Automatic Transmission" in this section.




WARNING!

In SPORT mode the ESC control thresholds are higher for maximum performance on dry road surface. To ensure maximum security of the ESC is recommended not to activate SPORT mode on surfaces with medium- and low-grip (e.g., wet, snow, dirt, etc..) with ESC system active (button  not pressed).

NOTE:

- When in "ESC off" mode, the TCS functionality of ESC is deactivated (except for the limited slip feature described in the TCS paragraph of this chapter). All other stability features of ESC function regularly.
- To improve the vehicle's traction when driving with snow chains, or when starting off in deep snow, sand, or gravel, it may be desirable to switch to the "ESC off" mode by pressing the  switch and remain in this operational mode no longer

than needed. Once the situation requiring "ESC off" mode is overcome, turn the ESC on again by pressing the  switch. This may also be performed while in motion.

Anti-Lock Brake System (ABS) and Electronic Brake-force Distribution (EBD)

The Anti-Lock Brake System (ABS) provides increased vehicle stability and brake performance under most braking conditions. The system automatically "pumps" the brakes during severe braking to prevent wheel lock-up.

The Electronic Brake-force Distribution (EBD) prevents the rear wheels from over-braking and provides greater control of available braking forces applied to the rear axle.



WARNING!

The ABS helps prevent the wheels from locking, but it does not increase the physical grip limits between the tires and the road. Therefore, always keep a safe distance from the vehicle in front of yours and reduce your speed when entering a curve.

NOTE:

- When the vehicle's speed is higher than 11 km/h (7 mph), you may hear a slight clicking sound as well as other motor noises. The system is performing a self-check cycle to ensure that the ABS is working properly.
- This self-check occurs each time the vehicle is started and accelerated past 11 km/h (7 mph).

ABS is activated during braking under certain road or stopping conditions. ABS-inducing conditions can include ice, snow, gravel, bumps, railroad tracks, loose debris.

You may also experience the following when the brake system goes into Anti-Lock:

- The ABS motor running (it may continue to run for a short time after the vehicle stops).
- The clicking sound of solenoid valves.
- Brake pedal pulsations.
- A slight drop or fall away of the brake pedal at the end of the stop. These are all normal characteristics of ABS functioning.

**WARNING!**

- The ABS contains sophisticated electronic equipment that may be susceptible to interference caused by improperly-installed or high-output radio transmitting equipment. This interference can cause possible loss of anti-lock braking capability. Installation of such equipment should be performed by qualified Maserati personnel.
- Pumping the Anti-Lock Brakes will diminish their effectiveness and may lead to a collision. Pumping brakes makes the stopping distance longer. Just press firmly on your brake pedal when you need to slow down or stop
- The ABS installed to this vehicle does not control trailer braking system. Pay utmost attention when driving on slippery ground since the trailer traction might get poorer and driver might lose control of the vehicle.
- Do not modify the vehicle braking system to control the trailer brakes. The hydraulic system controlling vehicle braking must remain

independent from trailer braking system.

Traction Control System (TCS)

The current device is an integral part of the ESC system. It operates automatically by reducing the power transmitted by the engine in case of slipping, loss of grip on wet floor (aquaplaning), acceleration on slippery snow-covered or frozen surfaces, etc.

Activating under slip conditions different control systems:

- if slippage affects both drive wheels, it reduces the power transmitted by the engine;
- if slippage only affects one drive wheel, it brakes the slipping wheel automatically.

Brake Assist System (BAS)

This system completes the ABS system by optimising the vehicle braking capacity during emergency brake manoeuvres. The system detects an emergency braking situation by sensing the rate and amount of brake application and then applies optimum pressure to the brakes in order to help reduce braking distances.

The quick brake coupling is optimal for BAS performances. In order to fully exploit the system, apply continuous brake pedal pressure during the entire vehicle stop sequence. Do not reduce brake pedal pressure earlier than required. Once the brake pedal is released, the BAS is deactivated.

Hill Start Assist (HSA)

The HSA system is designed to assist the driver when starting a vehicle uphill. HSA will maintain the level of brake pressure applied for a short period of time also after releasing the brake pedal.

If the driver does not apply the throttle during this short period of time, the system will release brake pressure and the vehicle will start sloping down. The system will release brake pressure proportionally to the amount of throttle/torque applied as the vehicle starts to move in the chosen direction.

By scrolling MTC+ user settings and selecting "Safety & Driving Assistant", the driver can disable the HSA system.

HSA Activation Criteria

The following criteria must be met in order for HSA to activate:

- vehicle is stationary.



- gear selection matches vehicle uphill direction (i.e., vehicle facing uphill is in forward gear; vehicle backing uphill is in reverse gear).

HSA will work in R (Reverse) and all forward gears when the activation criteria have been met.

The system will not activate if the gear is placed in N (Neutral) or P (Park).

Roll-Over Mitigation (ROM)

This system anticipates the potential for wheel lift by monitoring the driver's steering wheel input and the speed of the vehicle. When ROM determines that the rate of change of the steering wheel angle and vehicle's speed are sufficient to potentially cause wheel lift, it then applies the appropriate brake and may also reduce engine power to lessen the chance that wheel lift will occur. ROM will only intervene during very severe or evasive driving maneuvers. ROM can only reduce the chance of wheel lift occurring during severe or evasive driving maneuvers. It cannot prevent wheel lift due to other factors, such as road and off-road conditions, leaving the roadway, or striking objects or other vehicles.




WARNING!

Many factors, such as vehicle loading, road and off-road conditions, and driving conditions, influence the chance that wheel lift or rollover may occur. ROM cannot prevent all wheel lift or roll-overs, especially those that involve leaving the roadway or striking objects or other vehicles. The capabilities of a ROM-equipped vehicle must never be exploited in a reckless or dangerous manner, which could jeopardize the user's safety or the safety of others.

Trailer Sway Mitigation (TSM)

TSM uses sensors in the vehicle to recognize an excessively swaying trailer and will take the appropriate actions to attempt to stop the sway. The system may reduce engine power and apply the brake of the appropriate wheel(s) to counteract the sway of the trailer. TSM will become active automatically once an excessively swaying trailer is recognized.

TSM cannot stop all trailers from swaying. Always use caution when towing a trailer and follow the trailer

tongue weight recommendations. Refer to "Trailer Towing" in this section for further information. When TSM is functioning, the "ESC Activation/Malfunction Indicator Light" will flash (see "Instrument Cluster" in section "Dashboard Instruments and Controls"), the engine power may be reduced and you may feel the brakes being applied to individual wheels to attempt to stop the trailer from swaying. TSM is disabled when the ESC system is partially deactivated (button  pressed, LED on).



WARNING!

If TSM activates while driving, slow the vehicle down, stop at the nearest safe location, and adjust the trailer load to eliminate trailer sway.

Hill Descent Control (HDC)

HDC maintains vehicle speed while descending hills during various driving situations, by actively controlling the brakes.

HDC is part of the ESC system and has three possible states:

- Off: feature is not enabled and will not activate.




- **Enabled:** feature is enabled and ready but activation conditions are not met, or driver is actively overriding with brake or throttle application.
- **Active:** feature is enabled and actively controlling vehicle speed.


Enabling and Activating the HDC

HDC is enabled by pressing the HDC switch on LH side of steering wheel, but the following conditions must also be met to enable HDC:

- Maximum activation speed: 30 km/h (18 mph).
- Parking brake is released.
- Driver door is closed.

HDC enabling is indicated by the white light  on instrument panel display coming steady on. The light remains white while the driver operates the pedal unit to change the speed, or when driving on a flat stretch of road between two descents, or when the descent is over. Failed enabling is indicated by a message on display.




Once enabled, when driving the system automatically activates HDC. When the vehicle exceeds 4 km/h (2.5 mph), the light  turns green and the current speed appears below it until the default speed value set to 8 km/h (5 mph). Therefore, the vehicle speed is increased or decreased until it reaches the default value.




The set speed for HDC is selectable by the driver, and can be adjusted by using the pedal unit or the


multifunction control on steering wheel, which is the same used to set the Cruise Control (see “Electronic Speed Limiter and Cruise Control” or “Adaptive Cruise Control - ACC (optional)” in this section).

- If the driver brakes, the speed goes below the default value: when s/he releases the brake pedal, the speed goes back to 8 km/h (5 mph).
- If the driver accelerates without exceeding the maximum limit value of 30 km/h (18 mph), when s/he releases the accelerator pedal HDC will set to the speed reached by vehicle in that moment. The set value appears under the green light  on the display.

Or:


- Push down (SET -) multifunction switch to decrease the speed up to 3 km/h (1.8 mph) : pressing the brake pedal up to default speed of 8 km/h (5 mph). The set value appears under the green light  on the display.




- Push up (RES +) multifunction switch to increase speed until the required value is displayed below the green light  on display.




Driver Override

- HDC will be deactivated but remain available when driver pushes the accelerator steadily, without exceeding 30 km/h (18 mph). A message will indicate that the limit has been exceeded while the green light  will stay on.



- If vehicle reaches 30 km/h (18 mph) the light  turns flashing white and a pop-up message on display will warn driver that maximum speed limit was set for the HDC feature.



- While, if speed exceeds 50 km/h (31 mph), or when driving beyond 30 km/h (18 mph) for over 70 seconds, system will immediately disable the feature and the light  will turn off.

Brake Overheating with HDC

The icon on instrument panel display and the LED on steering wheel button will flash when HDC deactivates due to overheated brakes. The flashing will stop and HDC will activate again once the brakes have cooled sufficiently.


**WARNING!**

- HDC is only intended to assist the driver in controlling vehicle speed when descending hills. The driver must remain attentive to the driving conditions and is responsible for maintaining a safe vehicle speed.
- Prolonged use of the system might overheat the brakes. In case of brake overheating, the HDC, if active, will be progressively deactivated after warning the driver (switch-off of LED on button); feature can be reactivated only after brake temperature has decreased sufficiently. Distance that can be traveled depends on brake temperature, load and vehicle speed.
- The performance of a vehicle equipped with HDC must never be exploited in a reckless or dangerous manner that could jeopardise the driver's safety or the safety of others.

Using the Brakes

**CAUTION!**

To obtain a good performance by brake pads and discs, avoid sudden braking during the first 300 km (190 mi).

The pad wear limit is indicated by the illumination of the warning light , on the instrument cluster. In this event, please contact the **Service Network**.

**WARNING!**

Riding the brakes can lead to brake failure and possibly an accident. Driving with your foot resting or riding on the brake pedal can result in abnormally high brake temperatures,

excessive lining wear, and possible brake damage. In an emergency full braking capacity may be impaired.

Brake Pads and Brake Discs

Wear on the brake pads and brake discs depends to a great extent on the driving style and the conditions of use and therefore cannot be expressed in actual kilometres/miles driven on the road.

The high-performance brake system is designed for optimal braking effect at all speeds and temperatures.

Certain speeds, braking forces and ambient conditions (e.g. temperature, humidity and long outdoor stopping periods) can therefore cause the brakes to "squeal". This is normal and will cease after a few brakings.

New Brake Pads and/or Brake Discs

New brake pads have to be "broken in", and therefore only attain optimal friction to the brake disc when the vehicle has covered several hundred km/miles.

During this first period, the slightly reduced braking ability must be compensated for by pressing the brake pedal harder. This applies



whenever the brake pads and/or brake discs are replaced.

Brake Overheating

Driving on mountain roads with steep slopes or a sports use of the vehicle could overheat the brake system components. In these conditions, parking brake must not be used since the push of the power actuator might not be sufficient to ensure vehicle braking, especially on a slope. Drive normally without braking to allow the brakes to cool down a few minutes before stopping. In this way, the automatic or manual activation of the parking brake will ensure vehicle braking.

Use of the Engine

Breaking-In

Today's most modern production methods are designed to provide extremely precise construction and assembly of components. However, moving parts do undergo a settling process, basically in the first hours of vehicle operation.

Do not drive keeping at a constant high speed rate for a prolonged time. While cruising, brief full-throttle acceleration within the limits of local traffic laws contributes to a good break-in. Wide-open throttle acceleration in low gear can be detrimental and should be avoided. The engine oil installed in the engine at the factory is a high-quality energy conserving type lubricant. Oil changes should be consistent with anticipated climate conditions under which vehicle operations will occur. For the recommended viscosity and quality grades, see "Maintenance Procedures" in section "Maintenance and Care". A new engine may consume some oil during its first few thousand kilometers/miles of operation. This should be considered as a normal part

of the break-in and not interpreted as an indication of malfunction.

Specific Requirements for Gasoline Engines

Avoid exceeding 5000 rpm for the first 1000 trip km (620 mi).

After starting the vehicle, do not exceed 4000 rpm until the engine has warmed up sufficiently (coolant temperature: 65-70°C /149-158°F).

Specific Requirements for Diesel Engine

During the first 1500 km (900 mi) avoid heavy loads, e.g. driving at full throttle. Do not exceed 2/3 of the maximum permissible engine speed for each gear. In M (Manual) drive mode, change gear in good time. Do not shift down a gear manually in order to brake.

Trailer Towing

During the first 1000 km (620 mi) of a new vehicle it is advisable not to tow a trailer. This allows to limit the load on the engine and on the other parts of the vehicle.

While Driving

Never travel with the rev. counter indicator approaching the peak rpm, not even downhill. When the rev.



counter indicator is approaching the peak rpm (red colored zone), take precautions to avoid exceeding that limit.



Gasoline



Diesel

Ensure proper operation of different devices checking their respective control telltales.



CAUTION!

- Under normal conditions, all red warning lights on the instrument cluster display should be off. When they come on, they indicate a malfunction. Refer to “Instrument Cluster” in section “Dashboard Instruments and Controls”.
- Continuing to drive when a red warning light is on could cause serious damage to the vehicle and affect its performance.




WARNING!

Do not travel downhill with the engine off, as the servo brake will no longer function due to the vacuum decrease and thus after a few braking attempts, the system becomes totally inefficient. The power steering will also lose its efficiency under these conditions.

On-Board Diagnostic System



Your vehicle is equipped with a sophisticated onboard diagnostic system. This system monitors the performance of the emissions, engine,

and automatic transmission control systems. When these systems are operating properly, your vehicle will provide excellent performance and fuel economy, as well as engine emissions well within current local regulations of various countries. If any of these systems require service, the system will turn on the  malfunction indicator light (MIL). It will also store diagnostic codes and other information to assist which your **Service Center** will use to service your vehicle. Although the vehicle will still be driveable and not need towing, contact the **Service Network** for service as soon as possible.





CAUTION!

- Prolonged driving with the  Malfunction Indicator Light (MIL) on could cause further damage to the emissions control system. It could also affect fuel economy and driveability. The vehicle must be serviced before any emissions tests can be performed.
- If the  Malfunction Indicator Light (MIL) is flashing while the engine is running, severe catalytic converter damage and power loss will soon occur. Immediate service is required at the **Service Network**.
- After the problem has been solved, the **Service Network** personnel will perform specific tests on the test bench for a complete check of the system and, if necessary, also road tests, even on long distances.

Regenerate the Diesel Particulate Filter (DPF)

Under conditions of exclusive short duration and low speed driving cycles, the engine and exhaust aftertreatment system may never reach the conditions required to remove the trapped Particulate Matter (PM). This

conditions is reported by the messages on TFT display. To restore the exhaust aftertreatment system to normal operating condition it is necessary to regenerate the DPF by following the indications reported in the paragraph "TFT Display: Warning/Indicator Lights of Set Modes/Functions" of the chapter "Instrument Cluster" in section "Dashboard Instruments and Controls".



CAUTION!

- Prolonged driving with the MIL on inhibits the regeneration process with possible DPF clogged.
- Maserati is not responsible for defects occurring due to not performed DPF regeneration process.

Electronic Cruise Control

The electronic Cruise Control (CC) enables the driver to maintain the desired vehicle speed without pressing the accelerator pedal, reducing driving fatigue on highways, especially long trips, as the set speed is automatically maintained.



CAUTION!

Cruise Control can only be switched on at speeds exceeding 30 km/h (19 mph) and it switches off automatically when the brake pedal is pressed.



WARNING!


The Cruise Control function must only be activated when traffic and the route allow to safely maintain a constant speed for a sufficiently long distance.

Controls

The electronic Cruise Control controls are located on the left side of the steering wheel. Control configuration depends on which driver assist systems are installed to the vehicle.




In the standard configuration there is a specific button to enable and disable the CC.



Standard Configuration

In the optional configuration, there is no specific button to enable and disable the CC, since driver uses the ACC control buttons.



Optional Configuration

Control buttons have the following functions:

Standard Configuration



ON/OFF button: CC activation/deactivation.

Optional Configuration



Press ACC Gap button and hold it down for 2 seconds to enable the CC system.



Press ACC button to disable the CC system.

Shared by All Configurations



Multifunction switch:


- pushed up (indication RES +): resume set speed/higher speed;
- pressed (indication CANC): cancel set speed;
- pushed down (indication SET -): setting speed/lower speed.

NOTE:


- *The figures only show the Standard Configuration.*
- *In order to ensure proper operation, the CC system has been designed to shut down if multiple systems are operated at the same time (example:*

ACC and FCW). When conditions so allow, the CC system can be reactivated by pushing the CC "ON/OFF" button or the ACC Gap button (in the Optional Configuration) and resetting the desired vehicle set speed.

Activation

To turn the system on, push the "ON/OFF" button or the ACC Gap button for 2 seconds (in the Optional Configuration). The white light  on the instrument cluster display will illuminate.



To turn the system off, push the "ON/OFF" button a second time or the ACC button (in the Optional Configuration). The white light  will turn off.



NOTE:

The CC system must be turned off when not in use.




WARNING!

Never leave the electronic Cruise Control system on when not in use. You could accidentally set the system or cause it to go faster than you want. Always leave the system off when you are not using it.

Setting Desired Speed

Turn on the CC function. When the vehicle has reached the desired speed (in the example: 100 km/h), push downward the multifunction switch (SET -) and release.

The green light  with below the desired speed will illuminate on the instrument cluster display.



Release the accelerator and the vehicle will operate at the selected speed.

NOTE:

The vehicle should be traveling at a steady speed and on level ground before pushing the switch downward.

Pressing the "ON/OFF" button or the ACC Gap button for 2 seconds (in the Optional Configuration) or moving the ignition switch in OFF position erases the set speed memory.


Changing Speed Setting

When the CC is set, you can increase cruise speed by pushing upward the multifunction switch (RES +). Keeping the switch pressed, the set speed will continue to increase by 5 unit per time

(5 km/h or 5 mph) until the switch is released. The new set speed will be visualized below the green light. To decrease speed, push downward the multifunction switch (SET -). Keeping the switch pushed in the downward position, the set speed will continue to decrease by 5 unit per time (5 km/h or 5 mph) until the switch is released. Release the switch when the desired speed is reached, and the new set speed will be visualized below the green light.

Pushing the multifunction switch upward (RES +) or downward (SET -) once will enable to increase or decrease the set speed by one unit (1 km/h or 1 mph). Each subsequent tap of the multifunction switch will increase or decrease the speed by 1 km/h or 1 mph.

Temporary Deactivation

A soft tap on the brake pedal, pressing the multifunction switch (CANC), or normal brake pressure while slowing the vehicle will temporarily deactivate the CC without erasing the set speed memory. The white light  will appear on the display.




Driver Override


If the driver presses the accelerator pedal while the CC is on, such as to overtake another vehicle, and exceeds the set speed limit, the system will temporarily deactivate the CC. If the vehicle is equipped with ACC, a pop up message will illuminate on the instrument cluster display.



When the accelerator pedal is released, the vehicle will return to the

set speed and the green light  with below the set speed will be displayed.

Resume Speed

To resume a previously set speed, push upward the multifunction switch (RES +) and release. The green light  with below the set speed will illuminate on the instrument cluster. Resume can be used at any speed above 30 km/h (19 mph).

Using Electronic Cruise Control on Hill

The transmission may be downshifted on hills to maintain the vehicle set speed. The CC system maintains set speed up and down hills. A slight speed change on moderate hills is normal. On steep slopes it is recommend to drive without CC.



WARNING!

Electronic Cruise Control can be dangerous where the system cannot maintain a constant speed. Your vehicle could go too fast for the conditions, and you could lose control and have an accident. Do not use electronic Cruise Control in heavy traffic or on winding, icy, snow-covered or slippery roads.

Lane Departure Warning - LDW (optional)

This system, named "LaneSense" in the messages on instrument cluster display, was designed especially for highway or freeway driving, to reduce the risk that the vehicle, under particular circumstances, accidentally departing from the lane in use. When this happens, graphic instructions on instrument panel display, together with an acoustic warning (if set) warn the driver that the vehicle is going out of the lane.

To detect lane lines, the system uses the camera in front of the rear-view mirror, which is the same one used by the lighting system to manage automatic high beam.

LDW system remembers the condition it was in before turning off the vehicle.

LDW can be permanently enabled in "Sound+Display" state or disabled with the button (▶) on the steering wheel entering the submenu "Driver Assist" (see "Instrument Cluster" in section "Dashboard Instruments and Controls"). This state remains even after a key-off/key-on cycle. Refer to "MTC+ Settings" in section



“Dashboard Instruments and Controls” for further information.

Customised Settings

By scrolling MTC+ user settings and selecting “Safety & Driving Assistant” and then “LaneSense”, the driver can change the setting or disable the system (option “Off”).



System Limits

The system cannot trigger the above-specified warnings when vehicle is departing from the lane in the following instances:

- Turn indicator activation for overtaking or turning.
- Driver suddenly braking or accelerating
- When the road is too steep (both uphill and downhill).
- ESC, ABS or FCW interventions.

- Driver swiftly moving the steering wheel or fast bends that make vehicle slide.
- System is only available at speeds from 60 km/h (37.3 mph) to 180 km/h (112 mph).
- When after a lane crossing the warning is provided and the vehicle is not yet aligned to center line of the destination lane.

Operation and Symbols

The LDW, CC, ACC and FCW systems help the driver while driving. These systems can be set and monitored simultaneously on the display, after opening “Driver Assist” menu (see paragraph “TFT Display: Menus and Settings” under “Instrument Cluster” in section “Dashboard Instruments and Controls”).

If the LDW system is enabled (option “Sound+Display” or “Display set on MTC+”) but not active, the lane lines will be displayed in grey since they are not detected by the system. When system detects them and there are no conditions which prevent the LDW operation (example: vehicle speed out of range, lane too narrow, sharp turn, Hazard warning light on, turn indicator on, etc.), they will be white. If only one lane line is detected and

there are the activation condition, only one line will be shown white and the other one will be shown gray. When vehicle is moving toward one of the lane lines but did not cross it yet, system expects possible lane departure and warns the driver as follows:

- lines change color from white to yellow and flashes;
- a buzzer is triggered, if the “Sound+Display” option was selected.

Apart from the screen at the center of the display, in the area at top left are the icons indicating status of LDW (lines) and ACC (the horizontal bars and the vehicle, if ahead).

- Grey lines: system enabled (option “Sound+Display” or “Display set on MTC+”).
 - White lines: there are the activation condition and at least one line of the lane detected.
 - Yellow lines: system active with detection of possible lane departure.
- An example of this screen, with only LDW system activated and with LDW and ACC systems activated, can be found in the following figures.



System in Fault

When the LDW cannot properly operate due to a fault of its components or because the windshield in front of the camera is dirty, the amber light and/or the corresponding message will be displayed.

If message suggestion does not allow fixing the fault, avoid using the system and have the vehicle inspected at the **Service Network**.

Adaptive Cruise Control - ACC (optional)

The Adaptive Cruise Control (ACC) further increases the drive comfort ensured by the Cruise Control when driving on highways and freeways. Always consider that ACC is not a safety system and is not designed to prevent accidents.

The ACC allows driver to keep Cruise Control active in limited or moderate traffic conditions with no need to constantly restore the Cruise Control. The ACC uses a radar sensor, located on the front grille behind the trident, and the camera behind the internal rear-view mirror to detect the presence of a vehicle ahead at a close distance and moving in the same direction.





This vehicle, in this chapter, will be indicated as "target vehicle" or "vehicle ahead".

NOTE:

- If the sensor detects no vehicle ahead, the ACC system will maintain set steady speed.
- If the ACC sensor detects a vehicle ahead, the ACC system automatically kicks in by slightly accelerating or braking (to avoid exceeding the initially set speed) so that the vehicle keeps present distance, trying to adapt to the speed of the detected vehicle ahead.



WARNING!

- The Adaptive Cruise Control (ACC) is designed to increase vehicle driving comfort. It must not be considered as a means replacing the required attention of the driver. The driver is always required to drive carefully. The driver is always required to pay utmost attention to driving conditions (road, traffic, weather) and style (speed, distance from sensed vehicle ahead, brake use). Driver has the full responsibility of the vehicle therefore his attention is

crucial to keeping vehicle control in particular when approaching curves, rounds and situations with heavy traffic. Failure to follow these warnings can result in a collision and death or serious personal injury.

- In some driving scenarios, the ACC could have detection problems. In such cases, the ACC could kick in late or unexpectedly. The driver must be careful since his/her intervention could be necessary.
- It is always driver responsibility to obey to speed limits and to keep minimum legal distance to the preceding vehicle foreseen for the specific country.
- ACC system can decelerate only with limited braking, it cannot execute emergency braking.

The ACC system:

- Does not activate/react in the presence of pedestrians, bicycle and not licensable vehicle in general, incoming traffic from opposite direction and steady objects such as a vehicle stuck in a traffic jam or for a fault.
- Is meant for the use on highways and well-build roads, not for city traffic or mountain roads.

- May not have enough time to react and/or decelerate sufficiently on vehicles when lane is changed too fast or the relative speed is too high. In such cases the driver has to react appropriately also without any acoustic/visual warning.
- Cannot consider road, traffic and weather conditions and might prove limited when visibility is poor.
- Does not always fully recognise complex driving conditions and this could cause wrong assessment of the required safety distance.

It is recommended to disable the ACC system in the following instances:

- When driving in the fog, heavy rain, heavy snow, slush, heavy traffic and similar complex situations such as for instance highway sections where there are men at work.
- When entering a junction lane or a slip road to leave the highway; when driving on narrow, icy, snowy, slippery roads, or on steep up and downhill roads.
- The system is designed and calibrate for car with no trailer.
- When circumstances do not allow to drive safely at constant speed.



Displayed information


Adaptive Cruise Control (ACC) condition, as well as the LDW status, is displayed on instrument panel after selecting "Driver Assist" menu (see paragraph "TFT Display: Menus and Settings" under "Instrument Cluster" in section "Dashboard Instruments and Controls").

Displayed information depends on system status: ready, disabled, cancelled or set.

Apart from the image at the center of the display, CC, ACC, HDC and LDW systems status is represented by icons at the top left. The vehicle(s) and horizontal bars represent the ACC status as ready (white) or with sensed vehicle ahead (green); the white, green or yellow lines represent the LDW. The ACC screen can be displayed any time driver changes system status or settings. After 5 seconds of ACC inactivity, the display goes back to last screen.

ACC Controls and Activation Conditions

The buttons on steering wheel L/H side control ACC operation and the other functions/driver assist systems installed to this vehicle.



- 1 ACC ON/OFF button. If enabled, pressing this button will disable CC.
- 2 Multifunction control shared by all driver assist functions/systems:
 - Press up (indication "RES +"): increase speed, set current speed or resume previously set speed when system is in "cancelled" status.
 - Pushed (indication "CANC"): cancel the function if it was in "set" status, going in a ready condition but remembering the previous set speed.
 - Press down (indication "SET -"): set speed/decrease speed.

- 3 Two functions button with ACC activated:
 - ACC Gap: pressed and released; set the distance to sensed vehicle ahead as horizontal bars (setting cycle starts to 3 bars).
 - CC On: pressed for 2 seconds activates the CC system.
 - Press it to switch from CC to ACC.
- 4 Hill Descent Control (HDC) ON/OFF button.

NOTE:

Any change made to tire dimensions affects performance of Adaptive Cruise Control and Front Collision Warning (FCW), if equipped.

The ACC system can be activated only if vehicle speed is over 0 km/h – mph and lower than 210 km/h (130 mph). Minimum set speed for ACC is 30 km/h (18 mph): maximum set speed is 210 km/h (130 mph). The ACC is not activated in the following conditions:

- When braking.
- When parking brake is activated.
- When automatic transmission is in P (Park), R (Reverse) or N (Neutral).



- When vehicle speed is out of preset speed range
- When brakes are too hot.
- When driver door is open.
- When the driver's seat belt is unbuckled.
- When the road is particularly steep (both uphill and downhill) at low speed.
- When ride height is "Off Road 1" or "Off Road 2", or drive mode is "OFF ROAD".
- When drive mode (ESC OFF) is selected.
- When the door is opened at low speed.
- When there has been an ESC event in the last 5 seconds, or is still active.
- When there is an object too close in front of the vehicle.

It is possible that more than one system is active at the same time. The table below shows the "Possible" and "Impossible" combinations.

Possible	Impossible
ACC and LDW	ACC and CC
CC and LDW	ACC and HDC
HDC and LDW	CC and HDC

Activation/Deactivation

NOTE:

Pictures show status of ACC and LDW systems.

Press and release ON/OFF button to activate the ACC. The display will show a pop-up message for 2 seconds and the white symbol will illuminate indicating that system is ready to be set.



If a vehicle is detected as being too close, the display will show a message for 5 seconds and trigger a buzzer to warn the driver that current conditions do not allow enabling of the ACC. At any rate, system will remain in the ready status.



Push the ON/OFF button a second time and release to turn the system off. A pop-up message is displayed for 2 seconds to indicate that ACC was disabled.




WARNING!

Leaving the Adaptive Cruise Control (ACC) system on when not in use is dangerous. You could accidentally



activate the system or cause it to go faster than you want. Always leave the system off when you are not using it.

Setting the Speed

When vehicle reaches required speed, press down and release the multifunction control (SET -). The display will show set speed corresponding to vehicle current one. Speed value will be indicated below the green symbol  and above the distance bars, in the center of the display.



Remove foot from accelerator pedal and vehicle will continue at set speed.

Driver Override

If driver accelerates beyond the set speed or faster than the car would do autonomously, the display will show a

message indicating that system was temporarily disabled by driver override but it is still set. In this condition, system cannot control the distance between vehicle and sensed vehicle ahead. Vehicle speed will be determined only by the accelerator pedal position.

Changing Speed Setting

Once speed is set, driver can increase or decrease it by respectively pressing multifunction control up (RES +) or down (SET -). Speed can be increased or decreased in two ways:

- Pressing control once, set speed will increase or decrease by one unit corresponding to 1 km/h (1 mph).
- Hold the control to increase or decrease set speed by 10 km/h (5 mph) at a time.

NOTE:


- When pressing the multifunction control up (RES +) or down (SET -), the new set speed will be the current speed of the vehicle.
- When using (SET -) control to decelerate, if the engine braking power does not slow down the vehicle sufficiently to reach the set speed, the brake system will automatically slow down the vehicle.

- The ACC system applies the brake down to a full stop when following a target vehicle. If an ACC host vehicle follows a target vehicle to a standstill, after two-three seconds the system will not be able to resume driving the car autonomously. As this point it is necessary the intervention of the driver on the multifunction control (press SET- or RES+) or press the accelerator pedal (see “ACC Operation Before and During Stop” in this chapter).
- The ACC system maintains set speed when driving up hill and down hill. However, a slight speed change on moderate hills is normal. In addition, downshifting may occur while climbing uphill or descending downhill. This is normal operation and necessary to maintain set speed. When driving uphill and downhill, the ACC system will cancel if the braking temperature exceeds normal range.

Temporary Deactivation


A soft tap on the brake pedal, pushing the multifunction control (CANC), or normal brake pressure while slowing the vehicle will temporarily deactivate



the ACC without erasing the set speed memory. The white light  will appear on the display.

Conditions for Disabling and Deactivation

Besides the cases specified in the previous paragraph, the following conditions will disable the system:

- Anti-Lock Brake (ABS) kicks in.
- Transmission lever is not in D (Drive).
- Ride height is set to "Off Road 1" or "Off Road 2".
- The Electronic Stability Control and the Traction Control System (ESC/TCS) activate.
- Vehicle parking brake is operated.
- The driver safety belt is unbuckled at low speed.
- The driver door is ajar at low speed.
- The driver disabled the ESC using the button  on central console.
- The road is too steep both uphill and downhill at low speed.

The system is deactivated and set speed is deleted from system memory, if the ACC ON/OFF button is pressed or if ignition device is turned to **OFF**.

Resuming Speed

If a speed setting is stored in system memory, press the multifunction control (RES +) up and take foot off the accelerator pedal. The last set speed will be displayed.



WARNING!

The resume function should be used only when road and traffic conditions allow it. Resuming too a high or too a low speed for current traffic and road conditions could cause a harsh vehicle acceleration or deceleration which could jeopardise driving safety and risk to cause severe accidents.

Setting the ACC Gap

The specified ACC gap can be set by varying the distance setting among the four possible options identified by the number of horizontal bars:

- Maximum (longest) distance: 4 bars.
- Long distance: 3 bars (default distance).
- Medium distance: 2 bars.
- Short distance: 1 bar.

Using this distance setting and the vehicle speed, ACC calculates and sets the gap to the vehicle ahead.

If system does not detect the presence of any vehicles ahead, only the bars referred to set distance will be displayed.

When system detects the presence of a vehicle ahead, it is displayed in front of the bars (see example in the figure).



To increase or decrease the number of bars, corresponding to the gap from vehicle ahead, press and release the distance setting button. Each press and release of the button changes the gap starting from 3 bars (default distance) and moving in a sequential way towards the minimum distance: 3→2→1→4→3→2→1→4 and so on.

If there is no vehicle ahead, the vehicle will maintain the set speed. If a slower moving vehicle is detected in the same lane, the system displays the target vehicle icon before the bars. From that moment, the system adjusts vehicle



speed automatically to maintain the distance setting, regardless of the set speed.

The vehicle will then maintain the set distance until:

- The vehicle ahead accelerates to a speed above the set speed.
- The vehicle ahead moves out of your lane or view of the sensor.
- The distance setting is changed.
- The driver disables the system.

The maximum braking applied by ACC is limited; however, the driver can always apply the brakes manually, if necessary. Any time the ACC system automatically operates the brakes, the stop lights will turn on as if the driver was braking.

A Proximity Warning on display will alert the driver if ACC predicts that its maximum braking level is not sufficient to maintain the set distance. If this occurs, a visual alert will flash on the display and a chime will sound while ACC continues to apply its maximum braking capacity.



NOTE:

The displayed warning is a warning for the driver to take action and does not necessarily mean that the Forward Collision Warning (FCW) system is applying the brakes autonomously.

Overtake Aid

When driving with ACC engaged and following a target vehicle, the system will provide an additional acceleration to assist in passing vehicles in front. This additional acceleration is triggered when the driver utilises the left turn signal to start overtaking. In locations with left hand drive traffic, overtake aid is active only when passing on the left hand side of the target vehicle.

When a vehicle goes from a location with left hand drive traffic to a location with right hand drive traffic,

the ACC system will automatically detect traffic direction. In this condition, overtake aid is active only when passing on the right side of the target vehicle. This additional acceleration is triggered when the driver utilises the right turn signal to start overtaking. In this condition the ACC system will no longer provide Overtake Aid on the left side until it determines that the vehicle has moved back to a location with left hand drive.

ACC Operation Before and During Stop

If an ACC host vehicle follows a target vehicle to a standstill, after two-three seconds the system will not be able to resume driving the car autonomously. In this condition, TFT displays an instruction message pop up for 5 seconds.

When the ACC system brings your vehicle to a standstill while following a target vehicle, the brakes are released after 180 seconds after the stop and at the same time the system inserts the parking brake. When parking brake engages the ACC deactivates going to ready state. At this point the driver must act on the multifunction control (RES + or



SET -) or alternatively on the accelerator pedal. While ACC with Stop is holding your vehicle at a standstill, if the driver unbuckles the seatbelt or opens the door, the ESC system will activate the EPB. During standstill, ACC system monitors the occupant detection signals: if the driver's seatbelt becomes unbuckled, the ACC system shall be cancelled when the EPB is applied.



WARNING!

- **When the ACC system is resumed, the driver must ensure that there are no pedestrians, vehicles or objects in the path of the vehicle. Failure to follow these warnings can result in a collision and death or serious personal injury.**
- **During the automatic stopping behind a vehicle in some rare cases it may happen that the system does not recognize the rearmost point of the vehicle ahead but a target under the vehicle ahead (e.g. the back axis of a truck with a high loading edge or a bumper of a vehicle although overhanging load is hanging over the vehicle's rear). In these cases the system cannot guarantee the**

appropriate stopping distance leading to collision in the worst case. For this reason the driver has to be attentive and ready to brake during automatic stops.

Display Warnings and Maintenance of ACC and FCW Systems

Wipe Front Radar Sensor Warning

This warning will display and also a chime will indicate when conditions temporarily limit system performance due to sensor poor or failed signal reception. This most often occurs at times of poor visibility, such as in snow or heavy rain. The ACC and FCW systems may also become temporarily blinded due to obstructions, such as mud, dirt or ice on the radar sensor. In these cases, the system will be disabled.

This message can sometimes be displayed while driving in highly reflective areas (i.e. tunnels with reflective tiles, or ice and snow). The ACC and FCW systems will recover operation after the vehicle has left these areas. Under rare conditions, when the radar is not tracking any vehicles or objects in its path this warning may temporarily occur.

If weather conditions are not a factor, the driver should examine the sensor. It may require cleaning or removal of an obstruction. The sensor is located in the center of the vehicle behind the Maserati trident in the front grille. To keep the ACC System operating properly, it is important to note the following maintenance items:

- Always keep the sensor clean. Carefully wipe the sensor lens with a soft cloth. Be cautious not to damage it.
- Do not remove any screws from the sensor. Doing so could cause an ACC system malfunction or failure and require a sensor realignment.
- If the sensor or front end of the vehicle is damaged due to a collision, see your authorised dealer for service.
- Do not attach or install any accessories near the sensor, including transparent material or aftermarket grilles. Doing so could cause an ACC system failure or malfunction. When the condition that deactivated the system is no longer present, the system will return to the "Adaptive Cruise Control Off" state and will resume function by simply reactivating it.

**NOTE:**

If the radar sensor wipe warning message occurs frequently (e.g. more than once on every trip) without any snow, rain, mud, or other obstruction, have the radar sensor realigned at the **Service Network**.

Clean Front Windshield Warning

This warning will display and also a chime will indicate when conditions temporarily limit system performance due to camera poor or failed signal reception. This most often occurs at times of poor visibility, such as in snow or heavy rain and fog. The ACC and FCW systems may also become temporarily blinded due to obstructions, such as mud, dirt, or ice on windshield and fog on the inside of glass or when driving in bad weather. In these cases, the system will have degraded performance.

The ACC and FCW systems will recover operation after the vehicle has left these areas. Under rare conditions, when the camera is not tracking any vehicles or objects in its path this warning may temporarily occur. If weather conditions are not a factor, the driver should examine the windshield and the camera. They may

require cleaning or removal of an obstruction.

When the condition that created limited functionality is no longer present, the ACC and FCW systems will return to full functionality.

NOTE:

If the windshield wiper warning message occurs frequently (e.g. more than once on every trip) without any snow, rain, mud, or other obstruction, have the windshield and front camera inspected at the **Service Network**.

Service ACC/FCW Warning


If the ACC and FCW systems turn off, and the system displays a service warning, there may be an internal system fault or a temporary malfunction that limits functionality. Although the vehicle is still driveable under normal conditions, ACC and FCW will be temporarily unavailable. If this occurs, try activating ACC and FCW again later, following a key cycle. If the problem persists, contact the **Service Network**.

**Precautions while Driving with ACC****Towing a Trailer****WARNING!**

Towing a trailer when using ACC can lead to serious system failures which can cause severe accidents.


Offset Driving

ACC may not detect a vehicle in the same lane that is offset from your direct line of travel, or a vehicle merging in from a side lane. There may not be sufficient distance to the vehicle ahead. The offset vehicle may move in and out of the line of travel, which can cause your vehicle to brake or accelerate unexpectedly.



Turns and Bends

When driving on a curve with ACC engaged, the system may decrease the vehicle speed and acceleration for stability reasons, with no target vehicle detected. Once the vehicle is out of the curve the system will resume your original Set Speed. This is a part of normal ACC system functionality. Moreover, the radar sensor might detect a vehicle on a nearby lane or no longer detect the target vehicle.



Using ACC on Hills

When driving on steep hills, ACC may not detect a vehicle in your lane when vehicle reaches the crest. Depending on the speed, vehicle load, traffic conditions, and the steepness of the hills, ACC performance may be limited.




Lane Changing

ACC may not detect a vehicle until it is completely in the lane in which you are traveling.


In the illustration shown, ACC has not yet detected the vehicle changing lane and it may not detect the vehicle until it is too late for the driver to take action. ACC may not detect a vehicle until it is completely in the lane. There may not be sufficient distance to the lane changing vehicle.

Always be attentive and ready to apply the brakes if necessary.



Narrow Vehicles

Some narrow vehicles (like motorcycles) traveling near the outer edges of the lane or edging into the lane are not detected until they have moved fully into the lane. There may not be sufficient distance to the vehicle ahead.




Stationary Objects and Vehicles

ACC does not react to stationary objects and stationary vehicles. For example, ACC will not react in



situations where the vehicle you are following exits your lane and the vehicle ahead is stopped in your lane. Always be attentive and ready to apply the brakes if necessary.



Forward Collision Warning - FCW with Braking Action (optional)

Operation

The Forward Collision Warning (FCW) system with braking action interacts with the Adaptive Cruise Control (ACC), uses the same parts for sensing vehicle ahead (hereinafter “target vehicle”) as well as part of the warnings/messages on system condition and activation status. For further details, refer to “Adaptive Cruise Control - ACC (optional)” in this section.

Full performance can be reached only when both the sensing parts have detected the object, the difference between full and reduced performance is not visible for the driver.

The FCW feature may apply a brake jerk to warn the driver when it detects a potential frontal collision. The audible and visual warnings and limited braking are intended to provide the driver with enough time to react, avoid or mitigate the potential collision.

NOTE:

FCW system is not intended for towing: this could lead the system to malfunctions and/or to late reaction.




FCW monitors the information from the forward looking radar sensor as well as the Electronic Brake Controller (EBC), to calculate the probability of a forward collision. When the system determines that a forward collision is probable, the driver will be provided with audible and visual warnings and may provide a brake jerk warning. If the driver does not take action based upon these progressive warnings, then the system will provide a limited level of active braking to help slow down the vehicle and mitigate the potential forward collision. If the driver reacts to the warnings by braking and the system determines that the driver intends to avoid the collision by



braking but has not applied sufficient brake force, the system will compensate and provide additional brake force as required. When the system determines a collision with the vehicle in front of you is no longer probable, the warning messages will be deactivated.

NOTE:

- *Bad weather conditions, like strong rain, snow, etc., can lead to reduced system performance. Under these conditions relevant objects will not be detected or detected late by the system.*
- *FCW is designed to react in specific situations in typical traffic scenarios with objects in the same lane driving in the same direction, but under certain conditions it can also react on stationary objects in the same lane. It is not designed to react on oncoming traffic or crossing traffic.*
- *The minimum speed for FCW activation is 1,8 km/h (1.12 mph). The maximum speed for FCW activation is 250 km/h (155 mph). When the speed is outside the specified limits, the system automatically disabled FCW without turning on the corresponding warning light on the instrument cluster.*

- *The FCW alerts may be triggered on objects other than vehicles such as guard rails or sign posts based on the course prediction. This is expected and is a part of normal FCW activation and functionality.*
- *It is unsafe to test the FCW system. To prevent such misuse of the system, after four Active Braking events within a key cycle, the Active Braking portion of FCW will be deactivated until the next key cycle. The limit of four events applies to the brake jerk too.*
- *The FCW system is intended for on-road use only. If the vehicle is taken off-road, the FCW system should be deactivated to prevent unnecessary warnings. If the vehicle ride height is set to "Off Road 1" or "Off Road 2", the FCW system will be automatically deactivated.*
- *FCW will automatically deactivated when  (ESC OFF) button is pressed (LED light up) and when HDC is active.*



WARNING!

- **Forward Collision Warning (FCW) is not intended to avoid a collision on**

its own, nor can FCW detect every type of potential collision. The driver has the responsibility to avoid a collision by controlling the vehicle via braking and steering. Failure to follow this warning could lead to serious injury or death. The driver is always in charge to safely drive and to avoid critical situations not relying on the support of the system. Driver has to keep in mind that the system and therefore its intervention is always subject to the prevailing physical limits.

- **Forward Collision Warning (FCW) is not intended either to warn or to apply any brake aid/brake intervention in case of collisions with pedestrians, bicycles and not licensable vehicles in general.**

Turning FCW "On" or "Off"

The default status of FCW is "On". By scrolling MTC+ user settings and selecting "Safety & Driving Assistant", the driver can turn FCW off, adjust its sensitivity or enable/disable the brake jerk with the other emergency brakings ("Forward Collision Warning Active Braking" function). When FCW status is turned off, the corresponding



amber warning light on instrument cluster light on.



Changing the status to “Off” prevents the system from providing any braking aid if the driver is not braking adequately in the event of a potential collision.

When “Off”, all the functionality is switched off. Both the warnings and the brakings (including braking aids) will not be performed.

NOTE:

The default FCW system status is kept in memory from one key cycle to the next. If the system is turned off, it will return on when the vehicle is restarted: in this case, the corresponding warning light light off.

Changing FCW Sensitivity and Active Braking

The default status of FCW Sensitivity is the “Medium” setting. When also the “Forward Collision Warning Active Braking” function setting is “On”, the system warns you of a possible collision with the vehicle in front of you when you are farther away and it applies limited braking. This gives you the most reaction time to avoid a possible collision.

Changing the status to the “Near” setting, allows the system to warn you of a possible collision with the vehicle in front of you when you are much closer. This setting provides less reaction time than the “Far” setting, which allows for a more dynamic driving experience. “Medium” is the intermediate status between the two described above.

NOTE:

- *The default values shall appear at every new ignition cycle: FCW = on, Sensitivity = “Medium” and Active Braking = on.*
- *FCW may not react to irrelevant objects such as objects not in the path of the car, stationary objects that are far away, oncoming traffic, on cross traffic vehicles, or leading*

vehicles with the same or higher rate of speed.

- *The active braking (autonomous braking/braking aid) will not engage in case of potential collision with static object such as guard rails, walls, etc..*
- *FCW will be disabled like ACC (refer to chapter “Adaptive Cruise Control - ACC (optional)” in this section.*

Changing the active braking status to “Off” prevents the system from providing limited autonomous braking or additional brake support if the driver is not braking adequately in the event of a potential frontal collision. In this state the system disables the brake jerk.

Limited Operation and Service Warning

The messages indicating on display the limited functionality or service at **Service Network** required are the same as for the ACC system. For further details, refer to “Adaptive Cruise Control (ACC) (optional)” in this section.



NOTE:

- *The adjustment of the sensor could be affected by strong shocks or light collisions. This could affect the system by reducing the systems performance or could increase the false positive rate. The adjustment of the radar system has to be proved or a new adjustment has to be performed by a **Service Network**.*
- *The radar system requires specific feature to detect objects. The detection could be disturbed/reduced by environment influences, for example by electrical field or the object itself. Object with smal radar reflection proprieties could not be detected or detected late.*

Tires - General Information

Tire Pressure

Proper tire inflation pressure is essential for safety and best performance of your vehicle. The tire pressure monitoring system "TPMS" setup on the vehicle (see "Tire Pressure Monitoring System" in this section) may alert the driver about insufficient tire pressure even though the driver is responsible for checking regularly the tire pressure.

Radial tires fitted on the vehicle may look properly inflated even when they actually are under inflated. Do not make a visual judgment when determining proper inflation.

Three primary driving aspects are affected by improper tire pressure:

Safety



WARNING!

- **Improperly inflated tires are dangerous and can cause collisions.**
- **Under-inflation increases tire flexing and can result in tire overheating and failure.**
- **Over-inflation reduces a tire's ability to cushion shock. Objects on the**

road and potholes can cause damage that result in tire failure.

- **Over-inflated or under-inflated tires can affect vehicle handling and can fail suddenly, resulting in loss of vehicle control.**
- **Unequal tire pressures can cause steering problems. You could lose control of your vehicle.**
- **Unequal tire pressures from one side of the vehicle to the other can cause the vehicle to drift to the right or left.**
- **Always drive with each tire inflated to the recommended cold tire inflation pressure.**

Economy

Improper inflation pressures may cause uneven wear patterns to develop across the tire tread. These abnormal wear patterns will reduce tread life resulting in a need for earlier tire replacement. Under-inflation also increases tire rolling resistance resulting in higher fuel consumption.

Ride comfort and vehicle stability

Proper tire inflation contributes to a comfortable ride. Over-inflation produces a jarring and uncomfortable ride.



Tire Pressure Checkup

The proper cold tire inflation pressure is indicated on the table "Tire Inflation Pressure" in section "Features and Specifications".

Inflation pressure specified on the table always refers to "cold tire inflation pressure". Cold tire inflation pressure is defined as the tire pressure after the vehicle has not been driven for at least three hours, or driven less than 1.6 km (1 mi) after a three hour period.

Check tire pressures more often in case of significant outside temperature changes, as tire pressure varies according to temperature changes.

The pressure should be checked and if necessary adjusted; tire wear and overall conditions should also be checked monthly. Tire pressures change by approximately 0.07 bar per 7°C of air temperature change. Keep this in mind when checking tire pressure inside a garage, especially in winter.

Example: If garage temperature = 20°C and the outside temperature = 0°C then the cold tire inflation pressure should be increased by 0.21

bar for every 7°C for this outside temperature condition.

Tire pressure may increase from 0.13 to 0.4 bar during operation. DO NOT reduce this normal pressure build-up or your tire pressure will be too low. After inspecting or adjusting the tire pressure, always reinstall the valve stem cap. This will prevent moisture and dirt from entering the valve stem, which could damage the valve stem and the TPMS sensor connected to it.

Tread Wear Indicators

Tread wear indicators are in the original equipment tires to help you determine when your tires should be replaced.

These indicators are moulded into the bottom of the tread grooves. They will appear as bands when the tread depth becomes 1,6 mm (0.06 in) or 4 mm (0.16 in) for winter or all-season tires. When the tread is worn to one of the tread wear indicators, the tire should be replaced.



WARNING!

The wet performance (aquaplaning resistance) will decrease proportionally to the thickness of the tread.

Tires Durability

The service life of a tire depends on various factors including, but not limited to:

- driving style;
- tire pressure;
- distance driven.



WARNING!

Tires and the spare tire (if equipped) should be replaced after six years, regardless of the remaining tread. Failure to follow this warning can result in tire failure. You could lose control and have a collision resulting in serious injury or death.



Replacement Tires

NOTE:

In order to maintain high performance and safety level under all driving conditions, Maserati strongly recommends to use tires equivalent to the originals in size, quality and performance when replacement is needed.

For the size designation of your tire see table “Wheels” in section “Features and Specifications”. The Load Index and Speed Symbol for your tire will be found on the original equipment tire sidewall.

NOTE:

Maserati recommends Maserati Genuine Tires marked with “MGT” logo specifically designed for its models.

It is recommended to replace the two front tires or two rear tires as a pair. Replacing just one tire can seriously affect your vehicle’s handling. If you ever replace a wheel assembly, make sure that the wheel’s specifications (valve, TPMS sensor and tire) match those of the original wheels. Failure to use equivalent replacement tires may adversely affect

the safety, handling, and ride of your vehicle.

The **Service Network** is available to provide suggestions as to the types of tires most suited to the use foreseen by the Customer.



WARNING!

- Do not use a tire, wheel size or rating other than that specified for your vehicle. Some combinations of unapproved tires and wheels may change suspension dimensions and performance characteristics, resulting in altered steering, handling, and braking operations of the vehicle. This can cause unpredictable handling and stress to steering and suspension components. You could lose control and have a collision resulting in serious injury or death. Use only the tire and wheel sizes with load ratings appointed for your vehicle.
- Never use a tire with a smaller load index or capacity, other than what was originally equipped on your vehicle. Using a tire with a smaller load index could result in tire overloading and failure. You could lose control and have a collision.

- Always check the maximum speed rating on the tire sidewall on any tire on the vehicle.
- Never exceed the maximum speed rating of the tires. Risk of accident and serious personal injury due to excessive speed.
- Failure to equip your vehicle with tires having adequate speed capability can result in tire failure and loss of vehicle control.



CAUTION!

Replacing original tires with tires of a different size may result in false speedometer and odometer readings.

Winter Tires

These tires are specially designed for driving on snow and ice and are fitted to replace the ones supplied with the vehicle. Winter or all-season tires can be identified by the M+S (Mud & Snow) designation on the tire sidewall. Before mounting winter tires, contact the **Service Network** to receive the technical information necessary to advise you on wheel and tire compatibility.



As to the type of tires to use, inflation pressures and winter tires specifications, carefully follow the indications as reported in the “Technical Data” and “Tire Inflation Pressure” chapters in section “Features and Specifications”.

The features of these tires are markedly reduced in winter when tread depth is less than 4 mm (0.16 in). In this case, they should be replaced. The specific features of winter tires lead to lower performance (even in terms of braking) under normal weather conditions or on long motorway trips, compared to the standard tires. Therefore, their use should be limited to the conditions for which they have been type-approved.



WARNING!

The standard tires profile and rubber mixture are optimised for wet and dry driving conditions. Standard tires may not prove favourable for snow conditions: install snow tires before driving in such conditions to avoid risk of loss of control and damage to the vehicle as well as serious personal injury.

NOTE:

Snow tires should have the same load capacity as original equipment tires and should be mounted on all four wheels.

Snow Chains

Maserati approved traction devices may be used to improve traction on compacted snow in heavy snow conditions.

They should not be used in off-road conditions where there is no compacted snow.

Maserati tested and recommends to use traction devices with air suspension system in “Off Road 1” or “Off Road 2” ride height in order to increase wheel clearance. In any case do not exceed 50 km/h (30 mph).

Maserati tested, approved and recommends traction devices “Thule XG-12 tg 265” (for rear 265/50 ZR19 tires) and “Thule K-SUMMIT XXL tg K67” (for rear 295/45 ZR 19 tires). Please, contact your Service for further information.

The chains may be fitted only on rear wheel tires.

Check the chain tension after driving for a distance of about 50 m (55 yd) with the chains fitted. With the chains fitted, it is advisable to deactivate the ESC system (see chapter “Automatic Transmission” in this section).



CAUTION!

- The use of non-recommended snow chains may damage the vehicle.
- Broken chains can cause serious damage. Stop the vehicle immediately if noise occurs that could indicate chain breakage. Remove the damaged parts of the chain before further use.
- Do not exceed 50 km/h (30 mph).
- Drive cautiously and avoid severe turns and large bumps, especially with a loaded vehicle.
- Avoid holes in the road, do not drive over steps or sidewalks and do not drive on long stretches without snow. This will prevent damage to the vehicle and the roadbed.



NOTE:

The **Maserati Service Network** can provide you with all information about the **Maserati Snow Chains**, available in the "Genuine Accessories" range.

Pneumatic Suspension Mode for Wheel Change

The pneumatic suspension system is equipped with a specific mode to be used when vehicle must be lifted to change one or several wheels/tires. This mode temporarily disables pneumatic suspension automatic levelling.

To activate this mode, scroll user settings on MTC+ and select "Wheel Replacement Mode" in submenu "Suspension". The tick next to selected item will indicate that this mode is active and system is disabled (for further details, refer to chapter "MTC+ Settings" in section "Dashboard Instruments and Controls").

After servicing, restore original conditions and eliminate the tick next to selected mode: in this way the pneumatic suspension system will go back to normal operation.

Compact Spare Tire (if provided)

The limited-use spare tire, or compact spare tire, is for temporary emergency use only.

This tire is identified by a label indicating the driving speed limitations to comply with when using the spare tire.

Inflate the spare tire to the cold inflation pressure listed on the table "Tire Inflation Pressure" in section "Features and Specifications".

Mounting the spare tire affects vehicle handling. Replace (or repair) as soon as possible the original equipment tire and reinstall it on the vehicle. Do not install more than one compact spare tire and wheel on the vehicle at a time.



WARNING!

With these compact spare tires, do not drive more than 80 km/h (50 mph). Temporary use spares have limited tread life.

Tire Pressure Monitoring System (TPMS)

The Tire Pressure Monitoring System (TPMS) will warn the driver of a low tire pressure according to the vehicle recommended cold pressure indicated on the table "Tire Inflation Pressure" in section "Features and Specifications" and on the label applied on the driver's side rear door pillar (for versions/markets, where provided).

Tire pressure should always be set based on cold inflation tire pressure. The cold tire inflation pressure must not exceed the maximum inflation pressure moulded into the tire sidewall. Check "Tires – General Information" in section "Driving" for information on how to properly inflate the tires.

The tire pressure will also increase as the vehicle is driven - this is normal and there is no adjustment required when this occurs.

The TPMS will warn the driver of a low tire pressure if the tire pressure falls below the low-pressure warning limit for any reason, including low temperature effects and natural pressure loss of the tire.



The TPMS will continue to warn the driver of low tire pressure as long as the condition persists and will not turn off until the tire pressure is equal or above the recommended cold inflation pressure. Once the low tire pressure warning light (⚠) illuminates, you must increase the tire pressure to the recommended cold inflation pressure in order for the TPMS light (⚠) to turn off. The system will automatically update and the TPMS light (⚠) will turn off once the system acquires the correct tire pressure. The vehicle may need to be driven for up to 20 minutes above 24 km/h (15 mph) in order for the TPMS to acquire and process the updated setting.



WARNING!

The TPMS warns the driver that the tire pressure has decreased. This warning does not exempt the driver from periodically checking the tires and from complying with the prescribed tire pressure levels.



CAUTION!

The TPMS has been optimised for the original equipment tires and wheels. TPMS pressures and warning have been established for the tire size equipped on your vehicle. Undesirable system operation or sensor damage may occur when using replacement equipment that is not of the same size, type, and/or style. Aftermarket wheels can cause

sensor damage. Do not use aftermarket tire sealants or balance beads if your vehicle is equipped with a TPMS, as damage to the sensors may result.

- The system can temporarily experience radio-electric interference emitted by devices using similar frequencies.
- After inspecting or adjusting the tire pressure, always reinstall the valve stem cap. This will prevent moisture and dirt from entering the valve stem and damage the TPMS internal sensor.

NOTE:

- Driving on a significantly underinflated tire causes the tire to overheat and may lead to tire failure. Under-inflation also reduces fuel efficiency and tire tread life, and may affect the vehicle's handling and stopping ability.
- The TPMS is not a substitute for proper tire maintenance, and it is the driver's responsibility to maintain correct tire pressure using an accurate tire pressure gauge, even if under-inflation has not reached the

(Continued)



(Continued)

level to trigger illumination of the TPMS light (⚠).

- Seasonal temperature changes will affect tire pressure, and the TPMS will monitor the actual tire pressure in the tire.

Premium System

The TPMS system uses wireless technology with wheel rim mounted electronic sensors to monitor tire pressure levels. Sensors mounted to each wheel as part of the valve stem transmit tire pressure readings to the receiver module.

The TPMS consists of the following components:

- receiver module;
- four TPMS sensors;
- various TPMS messages, which display on the instrument cluster;
- warning light (⚠).

Tire Pressure Low Warning

The TPMS light (⚠) will illuminate in the instrument cluster and an acoustic signal will notify that tire pressure is low in one or more of the four tires.



The instrument cluster will also display a screenshot reporting the pressure values of each tire with flashing low pressure value.



Should this occur, you should stop as soon as possible and inflate the tire/s with the low pressure (the one/s flashing in the instrument cluster graphic) to the recommended cold pressure inflation value. Once the system receives the updated tire pressure value, the system will

automatically update, the graphic display in the instrument cluster will stop flashing, and the TPMS light (⚠) will turn off. The vehicle may need to be driven for up to 20 minutes above 24 km/h (15 mph) in order for the TPMS to acquire and process the updated information.

Tire Pressure System Fault

If a system fault is detected, the TPMS light (⚠) will flash for 75 seconds and then remain lit followed by a beeping sound. Therewith, the instrument cluster will display a "Service Tire Pressure System" message for a minimum of five seconds and then display dashes (--) in place of the pressure value to indicate which sensor is ineffective.

If the ignition switch is cycled, the sequence will repeat, in case the system fault still persists. If the system fault no longer exists, the TPMS light (⚠) will no longer flash, and the "Service Tire Pressure System" message will no longer display, and a pressure value will display in place of the dashes.

A system fault can occur due to any of the following:

- Signal interference due to electronic devices or driving next to facilities



emitting the same radio frequencies as the TPMS sensors.

- Installing aftermarket window tinting that contains materials that may block radio wave signals.
- Accumulation of snow or ice around the wheels or wheel housings.
- Using tire chains on the vehicle.
- Using wheels/tires not endowed with TPMS sensors.

The instrument cluster will also display a "Service Tire Pressure System" message for a minimum of five seconds when a system fault related to an incorrect sensor location fault is detected. In this case, the "Service Tire Pressure System" message is then followed by a graphic display with pressure values still shown. This indicates that the pressure values are still being received from the TPMS sensors but they may not be located in the correct vehicle position. The system still needs to be serviced as long as the "Service Tire Pressure System" message is displayed.



Vehicles with Compact Spare Tire

- The compact spare tire does not have a TPMS sensor. Therefore, the TPMS will not monitor the pressure of the compact spare tire.
- If you replace a pneumatic having pressure below the low-pressure warning limit, with the compact spare tire, on the next ignition switch cycle, the TPMS light (⚠) will illuminate followed by a beeping

sound. In addition, the graphic in the instrument cluster will still display a flashing pressure value corresponding to the compact tire position.



- After driving the vehicle for up to 20 minutes above 24 km/h (15 mph), the TPMS light (⚠) will flash for 75 seconds and then remain lit. The instrument cluster will then display a "Service Tire Pressure System" message for a minimum of five seconds and then display dashes (--) in place of the pressure value.
- Each subsequent ignition switch cycle will be followed by a beeping sound, the TPMS light (⚠) will flash for 75 seconds and then remain lit. The instrument cluster will then display a "Service Tire Pressure System" message for a minimum of five seconds and subsequently



displays dashes (--) in place of the pressure value.



- Once you repair, replace or reinstall a tire with the compact spare tire, the TPMS will update automatically. The TPMS light (⚠) will turn OFF and the graphic in the instrument cluster will display a new pressure value instead of dashes (--), as long as no tire pressure is below the low-pressure warning limit in any of the four tires. The vehicle may need to be driven for up to 20 minutes above 24 km/h (15 mph) in order for the TPMS to acquire and process the updated information.

TPMS Deactivation

The TPMS can be deactivated if replacing all four tire rims with wheel and tire assemblies not using of TPMS sensors, such as winter wheel and tire

assemblies. After replacing all four wheel and tire assemblies (road tires) with tires not endowed with Tire Pressure Monitoring System sensors, drive the vehicle for 20 minutes above 24 km/h (15 mph). The TPMS will chime, the TPMS light (⚠) will flash on and off for 75 seconds and then remain on and the instrument cluster will display the "Service Tire Pressure System" message and then display dashes (--) in place of the pressure values. Beginning with the next ignition switch cycle, the TPMS will no longer chime or display the "Service Tire Pressure System" message in the instrument cluster but dashes (--) will remain in place of the pressure values.



To reactivate the TPMS, replace all four wheel and tire assemblies (road tires) with tires endowed with TPMS sensors. Then, drive the vehicle for up to 20

minutes above 24 km/h (15 mph). The TPMS will chime, the TPMS light (⚠) will flash for 75 seconds and then turn off. The instrument cluster will then display the "Service Tire Pressure System" message.



The instrument cluster will also display pressure values in place of the dashes (--). On the next ignition switch cycle the "Service Tire Pressure System" message will no longer be displayed as long as no system fault exists.



Fuel Requirements

Requirements of Gasoline

The engines are designed to meet all environmental regulations and provide excellent fuel economy and performance when using high-quality unleaded gasoline with a minimum octane rating of 95.

For vehicle top performance, use unleaded gasoline with no less than 98 minimum octane rating.

Light spark knock at low engine speeds is not harmful to your engine. However, continued heavy spark knock at high speeds can cause damage, and immediate service is required.

Poor quality gasoline can cause problems such as hard starting, stalling, and hesitations. If you experience these symptoms, try another brand of gasoline before considering service for the vehicle at the **Service Network**.


Over 40 auto manufacturers worldwide have issued and endorsed consistent gasoline specifications (the World Wide Fuel Charter, WWFC) which define fuel properties necessary to deliver enhanced emissions,

performance, and durability for your vehicle.

Maserati recommends the use of gasoline that meets the WWFC specifications if they are available. Besides using unleaded gasoline with the proper octane rating, gasoline that contain detergents, anti-corrosion and stability additives are recommended. Using gasoline that have these additives may help improve fuel economy, reduce emissions, and maintain vehicle performance.



CAUTION!

- Maserati strongly recommends the use of Premium unleaded fuel **ONLY**. Use of lesser grade fuel (other than Premium) will lead to reduced engine performance, and poor fuel economy and can lead to the **Malfunction Indicator Light**  illuminating on the instrument cluster. Continued use of lesser grade fuel (other than Premium fuel) can lead to engine misfire problems and possible catalytic converter damage.
- The anti-pollution devices of the vehicle require unleaded fuel to be used at all times. Under no circumstance, not even in an emergency, should leaded fuel be

supplied to the fuel tank, not even a minimum quantity. This would irreparably damage the catalytic converters. An inefficient catalytic converter results in noxious exhaust emissions which damage the environment.

Gasoline Containing Alcohol & Ethers (Oxygenated Fuels)

Some fuels in some geographical areas, contain "oxygenates" which are usually alcohols or ethers. The fuel station service pumps with oxygenated fuels must be clearly marked indicating use of alcohols or ethers.

Please be aware that in some geographic areas fuel stations may have fuelling pumps that are unmarked. If you are not sure if the fuel you will be dispensing into your vehicle contains alcohol or ethers, ask the fuel service station operator or change station.



CAUTION!

Some geographic areas, require the use of “oxygenated” fuels to meet seasonal air quality standards.

- Alcohol - Ethanol: Fuels containing **ONLY** up to 10% ethanol by volume may be used (ethanol may also be referred to as Ethyl alcohol, or “Gasohol”).
- Ethers - MTBE: Fuel containing **ONLY** up to 15% MTBE may be used. Do not use any gasoline that contains lead as a knock inhibitor, and **DO NOT** use lead additives.

The use of detergent gasoline is effective in minimising fuel injector and intake valve deposits.

The use of external fuel injector cleaning systems/fluids is **NOT** recommended.

MMT in Gasoline

MMT (Methylcyclopentadienyl Manganese Tricarbonyl) is a manganese containing metallic additive that is blended into some gasoline to increase octane. Gasoline blended with MMT provides no performance advantage beyond gasoline of the same octane number

without MMT. Maserati recommends that gasoline **without** MMT to be used in your vehicle.

The MMT content of gasoline may not be indicated on the gasoline pump; therefore, you should ask the gasoline station operator whether or not the gasoline contains MMT.

Requirements of Diesel Fuel


Use good quality diesel fuel from a reputable supplier. If the vehicle is exposed to extreme cold (below $-7^{\circ}\text{C}/20^{\circ}\text{F}$), or is required to operate at colder than normal conditions for prolonged periods, use climatized No. 2 diesel fuel or dilute the No. 2 diesel fuel with 50% No. 1 diesel fuel. This will provide better protection from fuel gelling or wax-plugging of the fuel filters.

This vehicle must only use “Premium Diesel” fuel that meets the requirements of EN 590 (as reported on the label applied inside the fuel filler door). Biodiesel blends that meet EN 590 may also be used.



CAUTION!

- Maserati strongly recommends the use of **Premium diesel fuel ONLY**. Use of lesser grade fuel (other than

Premium) will lead to reduced engine performance, and poor fuel economy and can lead to the Malfunction Indicator Light  illuminating on the instrument cluster. Continued use of lesser grade fuel (other than Premium diesel fuel) can lead to fuel injection system damages and engine operating problems.

- The manufacturer requires that you must fuel this vehicle with Ultra Low Sulphur Highway Diesel fuel (15 ppm Sulphur maximum) and prohibits the use of Low Sulphur Highway Diesel fuel (500 ppm Sulfur maximum) to avoid damage to the emissions control system.



WARNING!

Do not use alcohol or gasoline as a fuel blending agent. They can be unstable under certain conditions and hazardous or explosive when mixed with diesel fuel.



Diesel fuel is seldom completely free of water. To prevent fuel system trouble, drain the accumulated water from the fuel/water separator using the fuel/water separator drain provided. If you buy good quality fuel and follow the cold weather advice above, fuel



conditioners should not be required in your vehicle. If available in your area, a high cetane “Premium Diesel” fuel may offer improved cold-starting and warm-up performance.

Refuelling

Fuel Filler Neck Access

To access the fuel filler neck, the filler door must be unlocked. From outside the vehicle, this can only be done by pressing the unlock  or the lock  button on the key fob RKE transmitter, in the same way as if opening or closing the doors. If any of the door lock controls is pressed from inside the vehicle, the filler door will still remain open to allow refueling.

- Press the indicated area on the filler door, which is located on the rear left side of the vehicle: the filler door will open completely.





Fuel Compatible Labels - Gasoline Engines

To help to user in the choice of fuel compatible for the car, inside the fuel

filler door is present a label show in the picture.



The label includes two graphic symbols that identifies the type of fuel to be used compliant to **EN16942** and reported in the following table.

	Unleaded fuel containing up to 2,7% (m/m) oxygen and a maximum ethanol content of 5,0% (V/V) EN228 compliant fuel
	Unleaded fuel containing up to 3,7% (m/m) oxygen and a maximum ethanol content of 10,0% (V/V) EN228 compliant fuel

Fuel Compatible Label - Diesel Engines

To help to user in the choice of fuel compatible for the car, inside the fuel



filler door is present a label show in the picture.



The label includes a graphic symbol that identifies the type of fuel to be used compliant to EN16942 and reported in the following table.

B7	Diesel fuel containing up to 7% (V/V) Fatty Acid Methyl Esters (FAME) EN590 compliant fuel
-----------	--

Refill the Tank (Gasoline Only)

The fuel filler neck is provided with external cap.

- Rotate counterclockwise and remove the fuel filler cap. The cap hermetic seal may result in a slight pressure increase inside the tank. Any hissing noise while the cap is being opened is therefore completely normal. The

cap is linked to the filler neck with a strap, to prevent it from being lost while refuelling.



- When refuelling, place the cap in the proper seat on the filler door hinge.




- Insert the fuel nozzle fully into the filler.



WARNING!

- To avoid the risk of fire, do not

approach the filler with open flames or cigarettes!

- To avoid the risk of inhaling noxious fumes, do not breathe close to the fuel filler door, when opened.
- Never have any smoking materials lit in or near the vehicle when the fuel filler door is open or the tank is being filled.
- Never add fuel when the engine is running. This violates most fire-prevention regulations and may cause the Malfunction Indicator Light  to turn on (see "Instrument Cluster" in section "Dashboard Instruments and Controls").
- Fill the vehicle with fuel. Fuel tank capacity is indicated in the "Refillings" table in section "Features and Specifications". When the fuel nozzle "clicks" or shuts off, the fuel tank is basically full: it is possible to further ensure refueling by enabling the fuel nozzle additional fuel supply until twofold clicks. After the two additional clicks, the amount of fuel allowed by the system is very low, we recommend therefore not to persist further.
- Wait approximately 10 seconds before removing the fuel nozzle in



order to ensure completed supply of residual fuel and restrict the risk of fouling the fuel filler door area.

- Remove the fuel nozzle.
- Insert the cap on the fuel filler neck.
- Tighten the cap, turning it clockwise until it stops.
- Close the fuel filler door.




CAUTION!


To avoid fuel spillage and overfilling, do not "top off" the fuel tank after filling.

Emergency Refueling Funnel

A funnel is provided (in the boot in the tool box container) for emergency refueling with a gas can.



Tire Kit Configuration



Spare Wheel Configuration



WARNING!

A fire may result if fuel is pumped into a portable container that is inside of a vehicle. You could be burned. Always place gas containers outside the vehicle while filling.

Refill the Tank (Diesel Only)

The fuel filler is sealed by an internal closing tab, which is opened by the fuel nozzle of the service station when refueling.

Only a nozzle of the suitable size can open the closing tab.

- Insert the fuel nozzle fully into the filler.

NOTE:

Only with a correct size nozzle you can refuel.




WARNING!

- To avoid the risk of fire, do not approach the filler with open flames or cigarettes!
- To avoid the risk of inhaling noxious fumes, do not breathe close to the fuel filler door, when opened.
- Never have any smoking materials lit in or near the vehicle when the fuel filler door is open or the tank is being filled.
- Never add fuel when the engine is running. This violates most fire-prevention regulations and may

(Continued)





(Continued)
 cause the Malfunction Indicator Light  to turn on (see “Instrument Cluster” in section “Dashboard Instruments and Controls”).

- Fill the vehicle with fuel. Fuel tank capacity is indicated in the “Refillings” table in section “Features and Specifications”. When the fuel nozzle “clicks” or shuts off, the fuel tank is basically full: it is possible to further ensure refueling by enabling the fuel nozzle additional fuel supply until twofold clicks. After the two additional clicks, the amount of fuel allowed by the system is very low, we recommend therefore not to persist further.
- Wait approximately 10 seconds before removing the fuel nozzle in order to ensure completed supply of residual fuel and restrict the risk of fouling the fuel filler door area.
- Remove the fuel nozzle.
- Close the fuel filler door.




CAUTION!

- To avoid fuel spillage and overfilling, do not “top off” the fuel tank after filling.

- The presence of water inside the fuel system can damage the injection system and cause engine’s malfunction. If the  warning light turns on, you shall contact the **Service Network** as soon as possible to have the fuel filter cleaned. If, after a refueling, the  warning light turns on, it may be that some water has entered the fuel tank: in this case, turn off the engine immediately and contact the **Service Network**.

Emergency Refueling Funnel

A funnel is provided (in the boot in the tool box container) for emergency refueling with a gas can.



Tire Kit Configuration



Spare Wheel Configuration



WARNING!


A fire may result if fuel is pumped into a portable container that is inside of a vehicle. You could be burned. Always place gas containers outside the vehicle while filling.




Emergency Fuel Filler Door Release

If you are unable to unlock the fuel filler door using the key fob RKE transmitter, then use the fuel filler door emergency release located in the boot.

- Open the liftgate (see “Open and Close the Liftgate” in section “Before Starting”).
- Lift the access cover on the left side of the boot compartment.



- Pull the release cable moderately to avoid its possible break. It's not possible to feel or hear the unlocking of the fuel filler door actuator.



- Then open normally the fuel filler door.

Driving Conditions

Before the Trip

Check the following at regular intervals and always before long trips:

- tire pressure and condition;
- levels of fluids and lubricants;
- conditions of the windshield wiper blades;
- clean the glass on the external light and all other glass surfaces;
- proper operation of the warning lights and of the external lights.



CAUTION!

It is however advisable to perform these checks at least every 1000 km (600 mi) and always following the maintenance schedule reported in section “Maintenance and Care”.

Before you drive:

- adjust seat position, steering wheel, adjustable pedals (if equipped with) and rear-view mirrors in order to have the best driving position;
- ensure that nothing (mat covers, etc.) is obstructing the pedals movement;



- carefully arrange and secure any objects in the boot, to prevent them from moving forward in case of sudden stops;
- avoid heavy meals before a trip. A light snack helps keep your reflexes sharp. In particular, avoid drinking alcohol.



WARNING!

Beyond being prohibited by law, it is extremely dangerous to ride inside the boot or on the hood. In the event of an accident, passengers sitting here are more exposed to the risk of serious injury. Passengers must only travel seated in the vehicle seats, with the seat belts fastened. Always check that the driver and all passengers have the seat belts correctly fastened.

Safe Driving

Although the vehicle is equipped with active and passive safety devices, the driver's conduct is always a decisive factor for road safety. Some simple rules for travelling safely in different conditions are listed below. Some of them will probably already sound familiar but, in any case,

it would be useful to read them carefully.

Driving at Night

The main guidelines to follow when driving at night are set out below.

- Drive carefully. Night conditions demand more focus and attention.
- Reduce your speed, especially on roads with no streetlights.
- Stop at early signs of drowsiness. Continuing to drive would be a risk for yourself and for others. Have a rest before continuing your trip.
- Keep the vehicle at a greater distance from vehicles in front of you than you would during the day: it is difficult to assess the speed of other vehicles when you only see the lights.
- Use the high beams only outside of densely-populated areas and when you are sure that they will not disturb other drivers.
- When another vehicle is approaching, switch from high beams (if on) to low beams.
- Keep lights and headlights clean.
- Outside of densely-populated areas, beware of animals crossing the road.

Driving in the Rain

Rain and wet roads are dangerous. On a wet road all manoeuvres are more difficult since wheel grip on the road is significantly reduced. This means that the braking distances increase considerably and the road grip decreases.

Some advices for driving in the rain are listed below.

- Reduce your speed and keep a greater safety distance from the vehicles in front of you. High speed may result in a loss of vehicle control.
- When driving on wet or slushy roads, it is possible for a wedge of water to build up between the tire and road surface. This is known as aquaplaning and may cause partial or complete loss of vehicle control and stopping ability. To reduce this possibility: slow down if the road has standing water or puddles.
- Heavy rain substantially reduces visibility. In these circumstances, even during the day, turn on the low beams, to be more visible to other drivers.
- Set the air conditioning and heating system controls on the demisting function, in order to avoid any visibility problem.



- Periodically check the conditions of the windshield wiper blades.
- In low grip conditions use “I.C.E.” driving mode (see chapters “Drive Mode” and “Off-road Drive” in this section).

Driving in Fog

If the fog is dense, avoid travelling if possible.

When driving in mist, blanket fog or when there is the possibility of banks of fog, please consider some advices listed below.

- Keep a moderate speed.
- Even in daytime, turn on the low beams and front and rear fog lights. Do not use the high beams.
- Remember that fog creates dampness on the asphalt and thus any type of manoeuvre is more difficult and braking distances are extended.
- Keep a safe distance from the vehicle in front of you.
- Avoid sudden changes in speed as much as possible.
- Whenever possible, avoid overtaking.
- If you are forced to stop the vehicle (breakdowns, impossibility of proceeding due to poor visibility,

etc.), first of all, try to stop off of the travel lane. Then turn on the hazard warning lights and, if possible, the low beams.

- Sound the horn rhythmically if you hear another vehicle approaching.



CAUTION!

Be aware that rear fog lights can bother the drivers following your vehicle: when visibility is back to normal, turn off these lights.

Driving in the Mountains

Mountain roads usually have many narrow turns and curves, tunnels and steep uphill or downhill slopes: please consider some advices listed below.

- Drive at a moderate speed, avoid “cutting” corners.
- When driving inside a tunnel in daylight turn on the low beams in advance; avoid high beams and be aware of the rapid brightness change. Avoid abrupt manoeuvres that could be dangerous for the following vehicle.
- Never coast downhill with the engine off or in neutral.
- Remember that passing other vehicles when driving uphill is slower

and thus requires more free distance on the road. If you are being overtaken on a hill, slow down and allow the other vehicle to pass.

Driving on Snow or Ice

Please consider some general advice for driving in these conditions, listed below.

- Maintain a very moderate speed.
- Fit snow chains or specific tires if the road is covered with snow: see the paragraphs “Tires – General Information” in this section.
- We recommend you to activate the “I.C.E.” mode (see chapters “Drive Mode” and “Off-road Drive” in this section).
- During the winter season, even apparently dry roads can have icy sections. Be careful when crossing bridges, viaducts and roads that have little exposure to the sun and are bordered by trees and rocks. They may be icy.
- Keep an ample safe distance from the vehicles in front of you.
- Avoid sharp braking, sharp changes in direction and rapid acceleration. Rapid acceleration on snow covered or icy surfaces may cause the driving wheels to pull erratically to the right



or left. This phenomenon occurs when there is a difference in the surface traction under the rear (driving) wheels.



WARNING!

Rapid acceleration on slippery surfaces is dangerous. Unequal traction can cause sudden pulling of the rear driving wheels. You could lose control of the vehicle and possibly have a collision. Accelerate slowly and carefully whenever there is likely to be poor traction (ice, snow, wet mud, loose sand, etc.).

5

Driving through Flooded Sections


Driving through water sections will require extra caution to ensure passenger safety and prevent damage to your vehicle. For more details, see "Off-road Drive" in this section.

Blind Spot Alert - BSA (optional)

BSA System

The Blind Spot Alert (BSA) system uses two radar-based sensors, located inside the rear bumper fascia, to detect highway licensable vehicles (cars, lorries, motorbikes, etc.) that enter the blind spot zones from the rear/front/side of the vehicle.

The example shown in the figure highlights the blind spots on either side of the vehicle when oncoming traffic is approaching from behind.



When the vehicle is started, the BSA warning light will momentarily illuminate in both outside rear view mirrors to let the driver know that the system is operational. The BSA system sensors operate when the vehicle is in

any forward gear or REVERSE and enters standby mode when the transmission is in (P) Park.



The BSA detection zone covers approximately one lane on both sides of the vehicle (approximately 3.3 m or 11 ft). The blind spot area extends from 4 m (13 ft) behind the rear bumper and 1 m (3.3 ft) in front of it. The BSA system monitors the detection zones on both sides of the vehicle when the vehicle speed reaches approximately 10 km/h (6 mph) or higher and will alert the driver of vehicles in these areas.



WARNING!

The BSA system does NOT alert the driver about rapidly approaching



vehicles that are outside the detection zones.

NOTE:

*If your vehicle has experienced any damage in the area where the sensor is located, even if the fascia is not damaged, the sensor may have become misaligned. Take your vehicle at the **Service Network** to verify sensor alignment. Having a sensor that is misaligned will result in the BSA not operating to specification.*

The area on the rear bumper fascia where the radar sensors are located must remain free of snow, ice, and dirt/road contamination so that the BSA system can function properly. Do not cover or block the area of the rear bumper fascia where the radar sensors are located with foreign objects (bumper stickers, spoilers, bicycle racks, etc.).

The BSA system notifies the driver of vehicles or objects in the detection zones by illuminating the BSA warning light located in the outside mirrors in addition to sounding an audible (chime) alert and reducing the radio volume (if the radio is on). Refer to "Modes of Operation of BSA and RCP" in this chapter for further information.

The BSA system monitors the detection zone from three different entry points (side, rear, overtaking traffic) while driving to see if an alert is necessary. The BSA system will issue an alert whenever a vehicle enters any one detection zone as outlined below.


Entering from the Side

Vehicles that move into your adjacent lanes from either side of the vehicle.





Entering from the Rear

The alert will turn on when the vehicles that come up from behind your vehicle on either side and enter the rear detection zone with a relative speed of less than 48 km/h (30 mph).



Overtaking Traffic

The figures show the vehicle approaching (A) and passing (O) another vehicle in the overtaking lane. If you pass another vehicle slowly (with a relative speed of less than 16 km/h (10 mph) and the vehicle remains in the blind spot for approximately 1.5 seconds, the BSA warning light in the outside mirror will illuminate. If the difference in speed between the two vehicles is greater than 16 km/h (10 mph), the warning light will not illuminate.




The BSA system will not alert you of objects that are traveling in the opposite direction of the vehicle in adjacent lanes.



Other Cases

The BSA system is not designed to issue an alert on stationary objects such as guardrails, posts, walls, foliage heaps, berms, etc. However, occasionally the system may alert on such objects. This is normal operation and your vehicle does not require service.



WARNING!

- The BSA system is only an aid to help detect vehicles in the blind spot zones.

- The BSA system is not designed to detect pedestrians, cyclists, or animals.
- Even if your vehicle is equipped with the BSA system, always check your vehicle's outside and rear-view mirrors for any vehicles approaching from behind or overtaking.
- Use your turn signal before changing lanes.

RCP - Rear Cross Path (optional)


The Rear Cross Path (RCP) feature is intended to aid the drivers when backing out of parking spaces where their vision of oncoming vehicles may be blocked.

The RCP system monitors the rear detection zones on both sides of the vehicle. Using sensors located on either side of the rear bumper, it detects any vehicles or objects that are moving toward the side of the vehicle with a minimum speed of approximately 1 to 3 km/h (1 to 2 mph) to a maximum of approximately 16 km/h (10 mph), such as in parking lot situations.

**NOTE:**

In a parking lot situation, oncoming vehicles can be obscured by vehicles parked on either side. If the sensors are blocked by other structures or vehicles, the system will not be able to alert the driver.

Proceed slowly and cautiously out of the parking space until the rear end of the vehicle is moderately exposed. The RCP system will then have a clear view of the cross traffic. If an oncoming vehicle is detected, the RCP system will alert the driver using both the visual and audible alarms. If the radio is on, it will also reduce the radio volume.

**WARNING!**

RCP is not a Back Up Aid system. More specifically, it is intended to be used to help a driver detect an oncoming vehicle in a parking lot situation. Drivers must be careful when backing up, even when using RCP. Always check carefully behind your vehicle, look behind you, and be sure to check for pedestrians, animals, other vehicles, obstructions, and blind spots before backing up. Failure to do so can result in serious injury or death.

Modes of Operation of BSA and RCP

Three modes of operation can be selected from the MTC+ System. Refer to chapter “MTC+ Settings” in section “Dashboard Instruments and Controls” for further information.

Blind Spot Alert

When operating in Blind Spot Alert mode, the BSA system will provide a visual alert in the appropriate side view mirror when it detects a vehicle or an object in the detection areas monitored by its sensors. However, when the system is operating in RCP mode, it will respond with both visual

and audible alerts when an oncoming vehicle or an object approaching the rear end side of the vehicle is detected.

Whenever an audible alert is requested, the radio is muted (if the radio is on).

Blind Spot Alert “Lights + Chime” Mode

When operating in Blind Spot Alert “Lights + Chime” mode, the BSA system will provide a visual alert in the appropriate side view mirror based on a detected vehicle or object.

If the turn signal is then activated, and it corresponds to an alert present on that side of the vehicle, an audible chime will also be sounded.

Whenever a turn signal and detected vehicle or object are present on the same side at the same time, both the visual and audio alerts will be issued. In addition to the audible alert, the radio volume will be reduced (if the radio is on).

NOTE:

If the hazard flashers are on, the BSA system will issue the appropriate visual alert only.

When the system is in RCP mode, the system shall respond with both visual



and audible alerts when a detected vehicle or object is present. Whenever an audible alert is requested, the radio (if on) is also muted.

Right/left turn/hazard signal status is ignored; the RCP status always requests the chime.

Blind Spot Alert Off

When this function is turned off from the MTC+, there will be no visual or audible alerts from either the BSA or RCP subsystems.

NOTE:

The BSA system will store the current operating mode when the vehicle is shut off. Each time the vehicle is started, the previously-stored mode will be recalled and used.

System Temporarily Unavailable

When the vehicle enters in particular zones, the blind spot system may become temporarily unavailable and the instrument cluster display will show the message "Blind Spot Alert Temporarily Unavailable". The warning lights in the side mirrors will be lit up and stay lit until the vehicle exits the zone.

Adding Reducing Agent AdBlue® (Diesel only)

Specifications of Reducing Agent AdBlue®

AdBlue® is a registered trademark of VDA (Verband der Automobilindustrie), the German vehicle manufacturers' association. Reducing agent AdBlue® must meet the quality requirements of ISO 22241-1.



CAUTION!

- AdBlue® is a non-toxic, colourless solution of pure synthetic urea and de-mineralised water. In the event AdBlue® becomes contaminated due to improper handling or storage, it may lead to the exhaust gas after-treatment system malfunctioning.
- In its sealed container, AdBlue® has a shelf life of at least a year if stored at temperatures between 30°C (86°F) and -11°C (12°F) away from direct sunlight.

Have the AdBlue® tank filled or topped up by the **Service Network**. They have the necessary equipment


and skills to perform this operation safely, and avoiding damage to the vehicle or the environment. Suitable messages on the TFT display indicate when the AdBlue® tank needs filling (see chapter "Instrument Cluster" in section "Dashboard Instruments and Controls"). You can check any time the filling status of the reservoir containing AdBlue® by entering the submenu "Vehicle Info" with the buttons on the right side of the steering wheel (see chapter "Instrument Cluster" in section "Dashboard Instruments and Controls"). Under normal use there will be no need to top up AdBlue® level between services. Under severe operating conditions, sporty use or at temperatures below -5°C (23°F), it may be necessary to top up AdBlue® between two consecutive scheduled maintenance services. Before travelling in countries where it might be difficult to find AdBlue®, check that the reductant level in the tank is sufficient to cover the distance to be travelled. If this is not the case, top up with AdBlue® by yourself or have it done by the **Service Network**.

**CAUTION!**

- AdBlue® freezes at outer temperatures of approximately -11 °C (12 °F) but the vehicle can be used also at lower temperatures since it is equipped with an AdBlue® pre-heating system.
- At temperatures below -11°C (12°F), the AdBlue® level sensor may no longer ensure an accurate indication for the instrument cluster. Allow the vehicle to reach regular operating conditions before checking level by means of the “AdBlue Level” function in the VEHICLE INFO menu (see chapter “Instrument Cluster” in section “Dashboard Instruments and Controls”).

Owners may top up reducing agent AdBlue® to proper level after purchasing AdBlue® at service stations that stock it. It is available in canisters of varying sizes and in single-use bottles (this is the option recommended by Maserati).



If a wrong fluid is filled into the AdBlue® tank (for instance Diesel fuel, coolant, etc...), the Malfunction Indicator Light  comes on and the message shown in the figure appears on the instrument cluster first time when driving for 10 seconds, accompanied by a single acoustic signal. If so, have the vehicle serviced by the **Service Network** as soon as possible.



Important Warnings if You Top Up AdBlue® Level Yourself

A top-up is not a difficult operation provided that you follow the instructions given in the following paragraph and standard safety precautions to avoid direct contact with AdBlue® fluid or prevent possible spills from being released into the environment or damaging vehicle bodywork or covers.

Wear protective gloves and goggles and carry out this operation outdoors or in well-ventilated area, as unpleasant smelling vapour may develop.

**WARNING!**

- **Keep AdBlue® away from skin or eyes: in the event of accidental contact, wash the affected area with water and flush eyes with running water, keeping eyelids wide open. In the event product is swallowed, rinse mouth and drink abundant water.**
- **Keep AdBlue® containers out of the reach of children.**



CAUTION!

If AdBlue® is spilled on luggage compartment lining or on paint-finished vehicle body parts, wash the affected area with abundant soapy water, if possible before the fluid begins to crystallise. After removing any residue of AdBlue®, let the area dry or blow with compressed air.


How To Top Up AdBlue® Level Yourself

When the low level indication is displayed, the quantity of AdBlue® left in the tank gives a range of about 2000 km (1200 mi) under normal driving conditions.


Maserati recommends using single-use bottles to top up AdBlue® level. These bottles contain 2 litres of product approximately, which is enough to extend range by another 2000 km (1200 mi) at least. These bottles are generally available at service stations that sell these products.

The AdBlue® tank has a chamber with a filler cap and is located on the bottom of the luggage compartment.

- To gain access to the tank, raise the ground coverage (see chapter “Tool Kit” in section “In an Emergency”).
- Unscrew the locking knob and remove the container with tool and first-aid kit.



Tire Kit Configuration




Spare Wheel Configuration

- Remove the compact spare wheel (if fitted).



- Slide the external rubber cap off the tank.



- Turn the blue inner cap counter clockwise until releasing it.




- Insert the single-use bottle into the filler neck and turn it clockwise until hearing a detent click.
- Press down on the bottom of the bottle to release its seal so the fluid will pour into the tank.



- If you are using an AdBlue® canister instead of a bottle, please note that canisters normally come with an extension spout with the same shape as the bottle tip to engage the filler neck. Apply the extension spout to

the tank filler neck following the same instructions as for the bottle, then screw the other end onto the canister and pour the content into the tank.



To avoid contamination, use AdBlue® from sealed containers or canisters and always clean the extension spout before fitting it to the filler neck.

- Turn the bottle or the extension spout of the canister counter clockwise (after detaching the canister) to release it from the tank filler neck.
- Insert the inner cap into the filler neck and turn it clockwise until locking it in place.

- Fit the outer press-on cap to the tank.
- Refit the compact spare wheel (if present) and the tool and first-aid kit container and secure it using the centre knob. Lower the ground coverage of the luggage compartment.



ENVIRONMENTAL!

Empty bottles or containers may be disposed of at the Service Network or into household waste bins where this is allowed by local environmental protection regulations.

When the engine is started next after a top-up, the low level message on the display should disappear after a few seconds. If less than 2 litres of AdBlue® have been added upon top-up, the message may appear again with a longer range before engine start inhibition.



Trailer Towing

In this section you will find safety tips and information on limits to the type of towing you can reasonably do with your vehicle.

NOTE:

- *Using original Maserati equipment offers an advantage, compared to aftermarket one, in terms of driving safety and utilizing the vehicle potential under all conditions, especially considering that ESC and AWD systems feature specific settings for trailer towing. Further to this, if vehicle use conditions so allow, the original trailer tongue allows use of the driver assist systems present on-board.*
- *To maintain the new vehicle limited warranty coverage, follow the requirements and recommendations in this chapter.*

Trailer Tongue Weight

Maximum load of tow vehicle is reduced by the trailer tongue weight and the load on the same due to the trailer. Trailer tongue weight increases vehicle weight.

Do not exceed the maximum GVWR of the tow vehicle, the one for each axle

(GAWR) and the mass that the vehicle is rated to tow (GTW) specified on the nameplate located on the rear driver door's ledge.



WARNING!

It is important that you do not exceed the maximum allowed overall GVWR and GTW. A dangerous driving condition can result if either rating is exceeded. You could lose control of the vehicle and have an accident.

Arranging Load on Trailer

Arrange load at the bottom and as close as possible to trailer wheel axle. In this way the trailer center of gravity will be lower, thereby increasing the driving safety of the vehicle-trailer assembly.

Always load a trailer with 60% of the weight in the front of the trailer. Loads bearing more on wheel axle, or heavier in the rear of the trailer, can cause the trailer to sway severely side-to-side which could cause loss of control of vehicle and trailer.



WARNING!

Failure to load trailers heavier in front is the cause of many trailer accidents. Never exceed the maximum tongue weight stamped on your trailer hitch.

Tire Pressure Adjustment

Proper tire inflation pressures of your vehicle and trailer are essential to the safe and satisfactory operation of your vehicle while driving and in manoeuvres. Check for signs of tire wear or visible tire damage on trailer and vehicle before towing a trailer.

For more information on vehicle tires, see "Tires – General Information" in this section.

When a trailer must be towed, inflate vehicle tires to full load recommended pressure (FLC) indicated in chapter "Tire pressure" in section "Features and Specifications".

For pressure of trailer tires, follow the instructions given by the trailer manufacturer.

After adjusting vehicle tire pressure and connecting and disconnecting the trailer, initialise the Tire Pressure Monitoring System (TPMS) following the instructions under chapter "Tire



Pressure Monitoring System (TPMS)" in this section.

Field of Vision of External Rear View Mirrors

Law provisions require the field of vision of external rear-view mirrors to include the rear trailer corners.

If vehicle external rear-view mirrors cannot cover the required field of vision, it is possible to install additional rear-view mirrors sticking further out at the sides.

The **Service Network** can provide you with information about towing a trailer and about the approved components available in the "Genuine Accessories" range.

Trailer Lights

Law provisions require trailers to be equipped with an electrical lighting system that must include the following lights:

- Turn signals;
- Position lights;
- Stop lights;
- Rear fog lights;
- Reverse lights;
- Number plate lights;

- Side marker lights (for trailer width over 2.1 m/6.8 ft).

The power input of the trailer lights must not exceed the values in the following list.

- Position lights, side marker lights and number plate lights: 6 x 5W per side.
- Rear fog lights: 2 x 21W
- Turn indicators: 2 x 21W
- Stop lights: 4 x 21W
- Reverse lights: 2 x 21W

Trailer Wiring Harness

Vehicle trailer tongue includes a 13-pin sealed connector powered at 12VDC (CUNA/UNI and ISO/DIN standards) for connection of the corresponding trailer wiring connector.

In addition to the electrical branches, the vehicle electrical system can only be connected to the supply cable for an electric brake and to the cable for an internal light for the trailer, not exceeding 15W.



CAUTION!

Do not cut or splice wiring into the vehicle wiring harness. Do not change cable connections on connectors. Under certain conditions some lights

may not operate and trailer may be not sufficiently visible. The table below indicates the function and color of cable corresponding to every connector pin as shown in the figure.



5

Pin N.	Function	Wire color
1	Left turn signal	Black-White
2	Rear fog light	White
3	Lights ground (Lights GND)	Brown
4	Right turn signal	Black-Green
5	Left unit, including position light, side marker lights, and licence plate light (*)	Green-Red
6	Stop lights	Black-Red
7	Right unit, including position light, side marker lights, and licence plate light (*)	Green-Black
8	Reverse light	Blue-Red
9	Permanent power supply (+Batt)	Red
10	Power supply controlled by ignition switch (+Key)	Yellow
11	+Ignition Switch (+Key GND)	Yellow-Brown
12	Reserved (trailer connected)	-
13	+Battery (+Batt GND)	Red-Brown

(*) The assembly including position light, side marker and licence plate light shall be connected such that no light of the assembly has a common connection with both pins 5 and 7.



If the hooking and/or the electrical connection between vehicle and trailer is faulty, the warning light and the relevant message are displayed on instrument cluster display (see example in the figure).



In these cases please contact the **Service Network** and avoid using the vehicle with a trailer.

Installing the Trailer Tongue

Removing the Access Cover

Before fitting the trailer tongue, the access cover on the bottom part of the rear bumper must be removed

The cover is engaged in the bumper.

- Release cover inner side from bumper, using the tip of a tool or screwdriver at the points indicated by the arrows.



- Slide cover downward to disengage the two projecting elements indicated in the figure from bumper.




- Store cover in the luggage compartment.


Install the Trailer Tongue

- Remove the protective plug from the trailer tongue seat on the cross member of the car.





- Lift the rear side of boot floor panel and hold it up in one of the available positions (see "Tool Kit" in section "In an Emergency").
- Remove the storage box.

On cars equipped with Tire Kit, the trailer tongue is installed in the preformed tool box, while it can be found next to the spare wheel on cars equipped with this equipment. The trailer tongue is usually in the released position  when taken out from the luggage compartment. This can be observed by the knob spaced of approximately 5 mm (0.2 in) from the bar of trailer tongue (shown in the side view of figure) and by the red mark on the knob directed to the green mark on the bar. The trailer tongue can be installed only when in these conditions.




If the locking mechanism of the trailer tongue is NOT preloaded before the installation, or in the locked position, it must be preloaded.

The locked position  can be identified by the green mark of the knob coinciding with the green mark on the bar of the trailer tongue and by the knob resting on the bar.



Should it be necessary to preload the locking mechanism, proceed as follows:

- remove the cap from the lock and insert the supplied key;
- turn key clockwise until it stops, until it stops;
- extract the knob following the direction of arrow (1);
- turn the knob clockwise (2), until it stops. The locking mechanism remains preloaded even when the knob is released.



At this point the trailer tongue with locking mechanism preloaded is ready to be inserted in the seat on the cross member of the car.

- Aim trailer tongue so that delta-shaped inserts on tongue parallel side are aligned with the corresponding slots on seat bottom edge, on cross member.

- Push the trailer tongue upwards: the preloaded mechanism locks it automatically in place.




WARNING!

To prevent injury to limbs, keep hands away from the knob when inserting the trailer tongue in the seat on the cross member of the car.

Using the supplied key, lock the mechanism .

- Turn key counter clockwise until it stops and remove it.
- Fit the protection cap on the lock.



NOTE:

- The key can be removed only when the locking mechanism is locked.
- To avoid losing the key while towing, do NOT leave it in the lock.

Remove ball protection from trailer tongue and hook the vehicle to be trailed.

Connect the Electrical System of the Trailer

- For connection, turn down the mounting bracket of connector, which is found on the left-hand side of trailer tongue seat.



- After lowering protection cover, engage the trailer male connector into the car female connector. To ensure that connectors properly match, make sure that protruding tab on trailer side connector is aligned with the recess on car side connector.
- Push trailer connector fully home and engage the safety lock, if any.




Remove the Trailer Tongue

When trailer tongue is no longer necessary, disconnect electrical connections and remove it from its seat as described below.

- Remove the protection cap and insert the key in the lock.
- Open the lock by turning the key clockwise until it stops.



- Grip the trailer tongue firmly and pull out the knob following the direction of the arrow (1).
- Rotate knob clockwise (2) until it stops, in order to release it in unlocked position .



- Then remove the trailer tongue from its seat.
- Install the protective cap in the trailer tongue seat on the cross member of the car.



- Clean the trailer tongue and remove all residues, especially on the ends.
- Install the ball protection and cap on the key.
- Set trailer tongue in its seat inside the luggage compartment.

- Turn connector mounting bracket upwards.
- Refit the access cover making sure to engage the two projecting elements indicated by the arrow fully home into the bumper.



- Push cover lower end toward bumper until the two retainers click in place.



Towing Tips

- Before setting out on a trip, check operation of trailer rear lights and stop lights to ensure you do not jeopardise other road users' safety.
- Make certain that the load is secured in the trailer and will not shift during travel. When trailering cargo that is not fully secured, dynamic load shifts can occur that may be difficult for the driver to control. You could lose control of your vehicle and have a collision.
- When hauling cargo or towing a trailer, do not overload your vehicle or trailer. Overloading can cause a loss of control, damage to brakes, driveline, steering, suspension or tires.
- Safety metal wire must always be used between your vehicle and trailer. Always connect the wire to the hook retainers of the trailer and vehicle hitch. Cross the wire under the trailer tongue and allow enough slack for turning corners.
- Comply with local applicable speed limits.
- Towing any trailer will increase your stopping distance. When towing, you should allow for additional space



between your vehicle and the vehicle in front of you. Failure to do so could result in an accident.

- For towing use ride height "Normal".
- Adjust speed when towing a trailer. Depending on towed load and weather conditions, trailer might sway at a speed above 80 km/h (50 mph).
- If trailer sways, driver can restore vehicle-trailer stability by immediately braking in a firm manner.
- When towing a trailer, never exceed 100 km/h (62 mph). The high axial load developed under these conditions might damage tires.
- Do not exceed maximum specified pressure for vehicle and trailer tires.
- Considering the large dimensions of the vehicle-trailer assembly, any indispensable correction of trajectory must be performed with great care to avoid any damage to other road users.
- To ensure other vehicles' safety and avoid hindering smooth traffic flow, towing a trailer is allowed on roads with a maximum grade of 12%.

- In case of hill start, the Hill Start Assist system (HSA, see "Brake and Stability Control Systems" in this section) can manage brake system intervention at best.
- Vehicles with trailers should not be parked on a steep grade. When parking, put the tow vehicle transmission in P (Park) and apply the parking brake on the tow vehicle. Always, block or "chock" the trailer wheels.
- On steep downhill roads, the vehicle-trailer assembly will tend to sway more easily. Before driving downhill, manually engage lower gear and drive slowly.
- Do not use electronic Cruise Control (CC and/or ACC) when driving on slopes or when carrying heavy loads.
- The D (Drive) gear must be selected when towing. The transmission controls include a drive strategy to avoid frequent shifting when towing. However, if frequent shifting does occur while in D (Drive), if foreseen, you can use the paddle shift switches to manually select a lower gear.
- Using a lower gear while operating the vehicle under heavy loading conditions, will improve

performance and extend transmission life by reducing excessive shifting and heat buildup. This action will also provide better engine braking.

Trailer Tongue Maintenance

To ensure correct operation of the system, periodically remove all deposits of dirt which may have accumulated on the ball head bar and from the mounting pipe.

The possible key locking must only be treated with graphite.

Periodically lubricate the joints, the sliding surfaces and the ball with grease without resin or oil. Lubrication is also a further corrosion protection. If the vehicle is washed with high pressure jets, the ball head bar must be removed and the dedicated plug fitted.

The ball head bar must never be treated with high-pressure jets.

The **Maserati Service Network** can provide you with any information about the Maserati approved Towing Items, available in the "Genuine Accessories" range.







6 – *In an Emergency*

Tool Kit	318
Hazard Warning Flashers	320
In the Event of an Accident	320
Engine Overheating	322
In case of a Punctured Tire	322
Emergency Release of the Parking Brake	328
Transmission Manual Release of P (Park) Position	329
Freeing the Stuck Vehicle	329
Auxiliary Jump-Start Procedure	330
Towing a Disabled Vehicle	334



Tool Kit

The tools and other first-aid equipment are located in the boot inside a preformed container. To access the tools, lift the rear part of the boot cargo floor, by acting on the handle.



Remove the storage box.



The tools layout in the container depends on the boot configuration of the vehicle, depending on the destination markets and customer requirements.

- A Tire Kit Configuration.
- B Spare Wheel Configuration.

6

It is possible to maintain the cargo floor in the lifted position when boot cover is not hooked to liftgate (figure 1), is hooked to liftgate (figure 2) or is removed (figure 3).

The straps for fastening the cargo floor can be found at the ends and along the strap fastened by means of Velcro inserts on the floor back side. Once cargo floor is lifted, release the strap and fasten it at the positions shown in the figures below.




The tools inserted in the boot container are the following:

Ref.	Description	Layout
1	Double torx + cross-head screwdriver	A, B
2	Emergency tow hook	A, B
3	Funnel for emergency supply	A, B
4	Tire repair kit	A
5	Extended spanner with rubber-coated handle for unscrewing/tightening the wheel nuts	B
6	Adapter for wheel extended spanner	B
7	Jack set	B
8	Electric compressor complete with pressure gauge for inflating the compact spare wheel	B
9	Hook for trailer (optional)	A, B (*)

(*) In configuration with spare wheel the hook for trailer is positioned below the container with tools.

Once these operations are completed, stretch band and fasten it at the back of cargo floor, making sure to match the Velcro inserts. Lower the cargo floor.



Tire Kit Configuration



Spare Wheel Configuration



Hazard Warning Flashers

The hazard warning flasher switch is located in the center of the central console, behind the multimedia navigation controls.



Press the switch to turn on the hazard warning flashers to warn oncoming traffic of an emergency. When these lights illuminate, the direction indicators, the related indicator lights on the instrument cluster and the button start flashing.

Press the switch a second time to turn off the hazard warning flashers.

This is an emergency warning system and it should not be used when the vehicle is in motion. Use it when your vehicle is disabled and it is creating a safety hazard for other motorists.

When you must leave the vehicle to seek assistance, the hazard warning

flashers will continue to operate even though the ignition is placed in the OFF position.



CAUTION!

- When the hazard warning lights are activated, the direction indicators control is disabled.
- The extended use of the hazard warning flashers may wear down your battery.

In the Event of an Accident

It is important always to keep calm.

- If not directly involved, stop at a safe distance of at least ten meters away from the accident area.
- If on a motorway, stop without obstructing the emergency lane and be especially careful if you need to exit the vehicle.
- Turn off the engine and switch on the hazard lights.
- At night, illuminate the accident area with the headlights.
- Always act with caution to avoid the risk of being crashed into by other drivers.
- Indicate that an accident has occurred by placing the emergency triangle (if equipped) in a well visible position and at the prescribed distance.
- Call the emergency services, providing as much information as possible. On the motor way, use the special call boxes.
- Remove the ignition key (if present) from the vehicles involved.
- If fuel or other chemical products can be smelled, do not smoke and ask



people around you to put their cigarettes out.

- To extinguish fires, even small ones, use a fire extinguisher, blankets, sand or earth. Never use water.
- In multiple accidents occurred on motorways, particularly where visibility is poor, there is a high risk of being involved in other collisions. Leave the vehicle immediately and move away from the area.

In case of Injured Persons

- Never leave the injured person alone. Persons not directly involved in the accident are also required to give assistance.
- Do not crowd around injured persons.
- Reassure the injured person that help is on the way and stay close to them to assist them to avoid possible panic attacks.
- Release or cut the seat belts restraining the injured persons.
- Do not give the injured persons anything to drink.
- Never move an injured person.
- Remove the injured person from the vehicle only in emergency situation, e.g. if there is a risk of fire, sinking in water or falling down into a pit.

- When removing an injured person, do not pull his/her limbs, never bend his/her head and, as far as possible, keep his/her body in a horizontal position.

Emergency Kit (for versions/markets where provided)

The Emergency Kit provides first aid in case of a car breakdown or any other situation. The kit comes in a case on the left side of the boot compartment. The kit includes the following elements:

- emergency triangle;
- reflective emergency vest;
- luminescent pipes providing chemical lights;
- dynamo torch;
- first-aid kit;
- gloves;
- ice scraper;
- box with spare lamps and fuses.

NOTE:

- *The items inside the kit could change according to different countries' regulations.*
- *Upon request, a potassium-based fire suppressor same size and weight*

as a standard electric torch can be included. It ensures an higher effectiveness compared with conventional 10-kilo fire extinguishers and preventing damage to hides and rugs.

First-Aid Kit (for versions/markets where provided)

The First-Aid Kit is available in the boot compartment inside the Emergency Kit case (if foreseen) or in the following positions:

- on the vehicles with tire repair kit configuration (see "Tool Kit" in this section) this kit is placed in the tools container;
- on the vehicles with compact spare wheel this kit is placed in the right side of the boot compartment.

This kit contains following:

- sterile gauze to cover and clean the wounds;
- bandages of various sizes;
- treated adhesive bandages of various sizes;
- an adhesive bandage strip;
- a pair of rounded-end scissors;
- gloves;
- rescue blanket.



Engine Overheating

To reduce potential overheating of the engine in city traffic, while stationary, place the transmission in N (Neutral), but do not increase the engine idle speed.

NOTE:

There are steps that you can take to slow down an impending overheating condition:

- If your air conditioner (A/C) is on, turn it off. The A/C system adds heat to the engine cooling system and turning the A/C off can help remove this heat.
- You can also turn the temperature control to maximum heat, the mode control to floor and the blower control to high. This allows the heater core to act as a supplement to the radiator and aids in removing heat from the engine cooling system.



CAUTION!

Driving with a hot cooling system could damage the engine. If the temperature gauge reads "H" (refer to "Instrument Cluster" in section "Dashboard Instruments and

Controls"), pull over and stop the vehicle. Idle the vehicle with the air conditioner turned off until the temperature gauge drops back into the normal range. If the temperature gauge remains on the "H," turn the engine off immediately and contact the Service Network.



WARNING!

You or others can be badly burned by hot engine coolant (antifreeze) or steam from your radiator. If you see or hear steam coming from under the hood, do not open it until the radiator has had time to cool.

Never try to open a coolant bottle pressure cap (refer to "Maintenance Procedures" in section "Maintenance and Care") when the radiator is overheated.

In case of a Punctured Tire


The vehicle can be equipped with a tire repair kit or with a compact spare wheel, depending on the destination markets and on customer requirements.

Using Tire Repair Kit

Small punctures up to 6 mm (1/4") in the tire tread can be sealed using the tire repair kit, fitted beneath the ground coverage of the boot compartment (see chapter "Tool Kit" in this section).

The kit consists of two parts:

- an electric compressor with pressure gauge and power cable;
- a gas cylinder containing sealant with hose to be connected to the punctured tire.



**NOTE:**

For the tire repair procedures with tire repair kit see instructions included in the kit.

This kit will provide a temporary tire seal, allowing you to drive your vehicle up to 10 km (6 miles) with a maximum speed of 80 km/h (50 mph).

**CAUTION!**

- Intruding objects (e.g., screws or nails) should not be removed from the tire, which could compromise the repair with the tire repair kit.
- Do not use the tire repair kit if the tire shows lateral damages and/or the rim is damaged by driving with flat tire.
- Tire repair kit can be used in outside temperatures down to approximately -20°C (-4°F).
- Replace the tire repair kit sealant gas cylinder prior to the expiration date (printed on the gas cylinder label) to assure optimum operation of the system.

NOTE:

- The compressor power plug can be inserted either in the 12 V power outlet housed in the boot or inside the passenger compartment (see “Interior Features” in section “Understanding the Vehicle”).
- When having the tire serviced to the **Service Network** or to a tires service centre, advise who performs the operation that the tire has been sealed using the tire repair kit.

Using the Compact Spare Wheel

The automatic levelling of pneumatic suspensions might create problems when it is necessary to lift the vehicle to replace the wheel featuring punctured tire with the emergency wheel supplied or with another wheel.

**CAUTION!**

Before mounting the compact spare wheel it is necessary to disable the suspension system by scrolling the user settings on MTC+ and selecting “Wheel Replacement Mode” in “Suspensions” submenu. The tick next to selected item will indicate that this mode is active and pneumatic

suspension system is disabled (for further details, refer to “MTC+ Settings” chapter in section “Dashboard Instruments and Controls”). After servicing, restore original conditions and eliminate the tick next to selected mode: in this way the pneumatic suspension system will go back to normal operation.

NOTE:

The compact spare wheel is supplied in aluminium or steel: the pictures show the one in aluminium.

The compact spare wheel is stored in the boot and is supplied deflated in order to limit the amount of space occupied. An electric compressor is also provided for inflating. In the event of a tire puncture, proceed as follows.

- Stop the vehicle in a place that does not constitute a danger to traffic and where the wheel can be changed safely. The vehicle must be level and on firm ground.
- Select the P (Park) mode and then engage manually the electric parking brake and move the ignition switch to **OFF** position.



- If necessary, turn the hazard warning lights on and place the warning triangle (if equipped) at the required distance.



WARNING!

- The jack should be used on level firm ground wherever possible.
- It is recommended that the wheels of the vehicle be chocked, and that no person should remain in a vehicle that is being jacked.
- If the vehicle has been stopped on a slope or an uneven surface, place chocks or other suitable items in front of or behind the wheels to stop the vehicle from moving.
- Never start or run the engine with the vehicle on a jack.
- No person should place any portion of their body under a vehicle that is supported by a jack.
- Lift the ground coverage of the boot compartment (see chapter "Tool Kit" in this section).
- Take the tools (indicated in picture) for changing the wheel from the container.



- Unscrew and pull out the locking wheel knob.
- Take the container, the compressor and the compact spare wheel out of the boot.



- Remove from the compressor case the inflation hose and the cable with a plug for the power outlet.
- Unscrew the valve cap of the compact spare wheel and screw the

fitting of the inflation hose onto the valve.

- Insert the plug in one of the available power outlets fitted in the boot compartment or cabin.
- Turn the compressor on by pressing the switch.
- Stop the compressor pressing switch again, when the pressure indicated by the gauge reaches the recommended level (see "Tire Inflation Pressure" in section "Features and Specifications") and screw the cap on the compact spare wheel valve.



**CAUTION!**

- In order to obtain a more accurate reading, the compressor should be switched off when checking the tire pressure of the compact spare wheel on the pressure gauge.
- Do not run the compressor for more than 20 minutes: there is a risk it could overheat. Also, prolonged power absorption may discharge the battery, subsequently preventing the engine from starting.
- The compressor has been designed exclusively to inflate compact spare wheels; do not use it to inflate air mattresses, dinghies etc.

- Remove the center cover of the wheel rim (if foreseen) levering into the provided groove on the outer edge of the cover.
- Fit the adapter on the spanner. Extend the spanner as shown, then loosen by approximately one turn, the five bolts on the wheel to be changed.



- Place the jack near the wheel to be changed as illustrated.
- Make sure that the head of the jack is correctly inserted in one of the slots beneath the rocket bar.

**WARNING!**

- **Never position yourself under a jacked vehicle.**

- **The lifted vehicle may fall and damage the vehicle's body if the jack is not positioned correctly.**
- **Never use the jack to carry out maintenance or repairs under the vehicle.**

- Insert the extension levers in the jack.
- Turn clockwise the extension lever of the jack until the wheel is raised a few centimeters off the ground.



- Completely unscrew the five bolts and remove the wheel. In case a wheel security stud bolt is installed, it can only be removed by using the specific fitting wrench provided with the "Wheel Security Stud Bolt Kit", available in the "Genuine Accessories" range.



In an Emergency

- Fit the compact spare wheel with the valve stem facing outward, securing it with the five bolts previously removed.
- Turn counterclockwise the extension lever of the jack to lower the vehicle and remove the jack.
- Fully tighten the bolts, alternately tightening diametrically opposite.




WARNING!

- To avoid the risk of forcing the vehicle off the jack, do not tighten the wheel bolts fully until the vehicle has been lowered. Failure to follow this warning may result in personal injury.
- **FOR ALUMINIUM SPARE WHEEL**
Observe the tightening torque for

the bolts securing the spare wheel ($98 \pm 10 \text{ Nm} / 72 \pm 7 \text{ lbf}\cdot\text{ft}$). This is equivalent to a load of approximately 20 kg (44 lb) being placed on the handle of the spanner supplied when extended for use.

- **FOR STEEL SPARE WHEEL**
Observe the tightening torque for the bolts securing the spare wheel ($86 \pm 10 \text{ Nm} / 63 \pm 7 \text{ lbf}\cdot\text{ft}$). This is equivalent to a load of approximately 18 kg (40 lb) being placed on the handle of the spanner supplied when extended for use.



WARNING!

- The spare wheel is narrower than standard wheels and must only be used to travel the distance required



to reach a service station, where the punctured tire can be repaired or replaced.

- Do not exceed a maximum speed of 80 km/h (50 mph) when using the compact spare wheel; when this limit is exceeded, the stability, road holding and braking of the vehicle will be compromised. Avoid accelerating to full speed, heavy braking and fast cornering.
- The compact spare wheel must be inflated to the recommended tire pressure (see "Tire Inflation Pressure" in section "Features and Specifications").
- For safety reasons, it is absolutely forbidden to drive with more than one compact spare wheel fitted on the vehicle.
- Snow chains cannot be fitted on the compact spare wheel.
- The spare wheel can travel a maximum of 3000 km (1800 mi).

To Refit the Standard Wheel with Repaired or Replaced Tire

- Following the procedure and the caution described above, raise the vehicle and remove the compact spare wheel reusing the supplied

- spanner with adapter, suitably extended.
- Fit the standard wheel with repaired or replaced tire.
- Tighten the original bolts on the wheel.
- Lower the vehicle and remove the jack.
- Fully tighten the bolts, alternately tightening diametrically opposite.



WARNING!

Observe the tightening torque for the bolts securing the wheels (98 ± 10 Nm / 72 ± 7 lbf-ft). This is equivalent to a load of approximately 20 kg (44 lb) being placed on the handle of the spanner supplied when extended for use.

- Reassemble the center cover (if foreseen) on the wheel rim.

Once finished:

- completely deflate the compact spare wheel by pressing on the valve with the overhang of the valve cap;
- wrap the power cable and the inflation hose inside the compressor case and place it in the boot seat;
- place the compact spare wheel and tool container in the boot;
- fix everything in place with the locking knob;



- place the extension levers, the jack, the spanner and the adapter in the container inside the compact spare wheel;



- reposition the other tools and the accessories storage box;
- lower the ground coverage at the bottom of the boot compartment.

Emergency Release of the Parking Brake

In the event the electric parking brake locks due to a system failure (see "Parking Brake" in section "Driving"), it is not possible to move the vehicle, since the thrust action of the actuator that operates on the brake pad inside each rear caliper will lock the rear wheels.

After verifying that the battery is sufficiently charged (otherwise use an external power source connected to the vehicle electric system to operate the EPB control lever and try to unlock the parking brake), for moving the vehicle it is necessary to force the actuator to release the rear brake discs. Contact the **Service Network** to carry out this operation.



CAUTION!

If the parking brake has been activated in manual or automatic mode and it is not possible to release it by operating on the lever of the central console, do not move the vehicle since rear brake calipers might be damaged. To move the vehicle, load it on a rescue vehicle, avoiding to move it if only the rear axle is lifted,

since the torque converter of AWD system might be seriously damaged. For more information on vehicle towing, see "Towing a Disabled Vehicle" chapter in this section.



Transmission Manual Release of P (Park) Position

The manual disengagement of the shift from P (Park) has the purpose to allow towing the vehicle if not normally possible using the shift lever (such as inability to start the engine).

NOTE:

This procedure is exclusively intended for emergency situations only!



WARNING!


Always secure your vehicle by fully applying the parking brake, before activating the manual park release. Activating the manual park release could allow your vehicle to roll away if it is not secured by the parking brake. Activating the manual park release on an unsecured vehicle could lead to serious injury or death for those in or around the vehicle.

The cover that allows the emergency manual park release is located on the left part of the driver's foot well.

- Lift the mat on the driver side to access the cover.



- Slip the cover from its seat.
- With the tip of a screwdriver press the clip shown in the picture box and lift the strap up to release the transmission from the P (Park) position. The new position will allow vehicle moving and towing.
- Release the parking brake only when the vehicle is securely connected to a tow vehicle.




Freeing the Stuck Vehicle

If your vehicle is stuck in mud, sand, or snow, it can probably be moved backward and forward by a simple rocking motion.

Steer the wheel right and left to clear the area around the front wheels. Shift then between D (Drive) or M (Manual) and R (Reverse) (see chapter "Automatic Transmission" in section "Driving"). Shifting to M (Manual), try to free the car starting in second gear. At low speed motion of the vehicle, you can switch quickly from D (Drive) to R (Reverse), and vice versa, just by pressing the release button on the shift lever.

For more effectiveness press lightly on the accelerator pedal in order to avoid wheel slippage.

If unable to release the vehicle in one of the previously described ways, enter the low-grip driving mode, by pressing the "I.C.E." button, and completely exclude the yaw and slip control system, by pressing the  button for at least 3 seconds. Moving the shift lever between D (Drive) and R (Reverse) to start.



CAUTION!

Racing the engine or spinning the drive wheels may lead to transmission overheating and failure. Allow the engine to idle with the shift lever in N (Neutral) for at least one minute after every five rocking-motion cycles. This will minimize overheating and reduce the risk of transmission failure during prolonged efforts to free a stuck vehicle.



WARNING!

Fast spinning tires can be dangerous. Forces generated by excessive drive wheel speeds may cause damage, or even failure, of the drivetrain and tires. A tire could explode and injure someone. Do not spin your vehicle's wheels continuously without stopping when you are stuck and do not let anyone near a spinning wheel, no matter what the speed.

Auxiliary Jump-Start Procedure

If your vehicle has a discharged battery it can be jump-started using a set of jumper cables and a battery of another vehicle or by using a portable battery booster. It is necessary to have proper jumper cables in order to connect the booster battery to the remote posts of the discharged battery. Booster cables have positive and negative terminal clamps and are identified by the sheath color (red = positive, black = negative). Maserati provides on request jumper cables created for its models in a practical case.

NOTE:

The Maserati Service Network can provide you with information about the "Maserati Jumper Cables Kit", available in the "Genuine Accessories" range.

Jump-starting can be dangerous if done improperly so please follow the procedures in this section carefully.

NOTE:

When using a portable battery booster pack, follow the battery manufacturer's operating instructions and precautions.



CAUTION!

- To jump start a vehicle do not use a portable battery, a booster pack or any other booster source with a system voltage greater than 14 Volts or damage to the battery, starter motor, alternator or electrical system of the vehicle with the discharged battery may occur.
- Do not use a battery charger for emergency starting under any circumstances. You could damage the electronic systems, particularly the control units managing the ignition and fuel supply functions.
- If the battery is completely discharged when the windows are fully raised, open the door with the utmost care; do not close the door again until it is possible to lower the window.



WARNING!

- Using booster packs that have not



been checked, which could therefore release a too high charging voltage (higher than 14 V), in extreme environmental conditions (for example: closed areas or without proper ventilation and temperatures higher than 50°C/122°F or lower than -20°C/-4°F) create the right conditions for ignition which could then cause the battery to explode. Therefore you shall always perform jump-starting operations using the adequate tools and in the best environmental conditions, taking all necessary precautions.


- Do not attempt jump-starting if the discharged battery is frozen. It could break or explode during jump start and cause personal injury.
- Do not carry out this procedure if you have not done it before: incorrect manoeuvres can originate high electrical discharges and even cause the battery to explode.
- To avoid the risk of explosion or fire, do not approach the battery with open flames or cigarettes that could generate sparks.

NOTE:

If you need to disconnect the battery from the vehicle electrical system, see "Maintenance — Free Battery" in section "Maintenance and Care".

Battery Remote Posts Position - Gasoline Engines

For easier operation, remote battery posts for jump starting are located in the engine compartment while the battery is stored in the boot. After lifting the hood (see "Open and Close the Hood" in section "Before Starting") the positive remote post (+) and the negative remote post (-) are shown in the picture and are easily recognizable by the icons labeled on the integrated power module.



Gasoline

Battery Remote Posts Position - Diesel Engine

For easier operation, remote battery posts for jump starting are located in the engine compartment while the battery is stored in the boot. After lifting the hood (see "Open and Close the Hood" in section "Before Starting") the positive remote post (+) and the negative remote post (-) are shown in the picture and are easily recognizable by the icons labeled on the integrated power module.



Diesel




Jump-Start Procedure - Gasoline Engines



WARNING!

- Stay clear of the radiator cooling fan whenever the hood is raised. It can start anytime the ignition switch is on. You could be injured by the moving fan blades.
- Remove any metal jewelry such as watch bands or bracelets that might make an inadvertent electrical contact. You could be seriously injured.
- Do not allow the vehicles involved in the jumpstarting operation to touch each other as this could establish a ground connection and cause personal injury.
- Turn off the heater, radio, and all unnecessary electrical accessories.
- Set the parking brake, shift the automatic transmission into P (Park) and turn the ignition to **OFF**.
- If using another vehicle to jumpstart the battery, park the vehicle within the jumper cables reach and set the parking brake and make sure the ignition is **OFF**.

- Connect one terminal clamp of the positive (+) remote post of the discharged vehicle after lifting the protection cap of the cable indicated on the external side of the integrated power module.
- Connect the other terminal clamp of the positive (+) jumper cable to the positive (+) post of the booster battery.
- Connect one terminal clamp of the negative (-) jumper cable to the negative (-) post of the booster battery.
- Connect the other terminal clamp of the negative (-) jumper cable to the remote negative (-) post of the vehicle with the discharged battery as rendered.



Gasoline

- Start the engine in the vehicle that has the booster battery, let the engine idle a few minutes, and then start the engine in the vehicle with the discharged battery. If using a portable battery booster, wait a few seconds after connecting the cables, before starting the booster vehicle. Once the engine is started, remove the jumper cables in the reverse sequence.
- Disconnect one terminal clamp of the negative (-) jumper cable from the remote negative (-) post of the vehicle with the discharged battery.
- Disconnect the other terminal clamp of the negative jumper cable from the negative (-) post of the booster battery.
- Disconnect one terminal clamp of the positive (+) jumper cable from the positive (+) post of the booster battery.
- Disconnect the terminal clamp of the positive jumper cable from the remote positive (+) post of the discharged vehicle.

**NOTE:**

If frequent jump-starting is required to start your vehicle you should have the battery and charging system inspected at a **Service Network** center.

Jump-Start Procedure - Diesel Engine

**WARNING!**

- Stay clear of the radiator cooling fan whenever the hood is raised. It can start anytime the ignition switch is on. You could be injured by the moving fan blades.
- Remove any metal jewelry such as watch bands or bracelets that might make an inadvertent electrical contact. You could be seriously injured.
- Do not allow the vehicles involved in the jumpstarting operation to touch each other as this could establish a ground connection and cause personal injury.
- Turn off the heater, radio, and all unnecessary electrical accessories.

- Set the parking brake, shift the automatic transmission into P (Park) and turn the ignition to **OFF**.
- If using another vehicle to jumpstart the battery, park the vehicle within the jumper cables reach and set the parking brake and make sure the ignition is **OFF**.
- Connect one terminal clamp of the positive jumper cable to the positive (+) remote post of the discharged vehicle after lifting the protection cap of the cable indicated on the external side of the integrated power module.
- Connect the other terminal clamp of the positive (+) jumper cable to the positive (+) post of the booster battery.
- Connect one terminal clamp of the negative jumper cable to the negative (-) post of the booster battery.
- Connect the other terminal clamp of the negative (-) jumper cable to the remote negative (-) post of the vehicle with the discharged battery as rendered.

**Diesel**

- Start the engine in the vehicle that has the booster battery, let the engine idle a few minutes, and then start the engine in the vehicle with the discharged battery. If using a portable battery booster, wait a few seconds after connecting the cables, before starting the booster vehicle. Once the engine is started, remove the jumper cables in the reverse sequence.
- Disconnect one terminal clamp of the negative (-) jumper cable from the remote negative (-) post of the vehicle with the discharged battery.
- Disconnect the other terminal clamp of the negative jumper cable from the negative (-) post of the booster battery.
- Disconnect one terminal clamp of the positive (+) jumper cable from



the positive (+) post of the booster battery.

- Disconnect the terminal clamp of the positive jumper cable from the remote positive (+) post of the discharged vehicle.

NOTE:

*If frequent jump-starting is required to start your vehicle you should have the battery and charging system inspected at a **Service Network** center.*

Towing a Disabled Vehicle

Proper towing or lifting equipment is required to prevent damage to your vehicle. Use only towing bars and other equipment designed for the purpose, following equipment manufacturer's instructions. Safety chains are mandatory. Except for the front and rear threaded seats to fix the supplied hook (see "Tool Kit" chapter in this section), the vehicles are not equipped with other connection points for towing operations with tow truck.



CAUTION!

Any improper manoeuvre and use of unsuitable equipment for recovering vehicle in an emergency from off road location could seriously damage the vehicle. Contact the **Service Network** or anyone having suitable equipment and the required expertise to safely and properly carry out any required operations.

Make sure you comply with local towing regulations.

- **If the vehicle's battery is discharged,** refer to the following paragraph on how to shift the automatic

transmission out of the P (Park) position and release the parking brake.

- **If the vehicle battery is still charged,** turn off the engine and disengage the parking brake manually (if automatically engaged) by using the command behind the shift lever (see "Parking Brake" chapter in section "Driving"). Shift then manually the transmission out of P (Park) as described in "Transmission Manual Release of P (Park) Position" chapter of this section. If you need to use the accessories (wipers, defrosters, etc.) while being towed, the ignition must be in **RUN** position, do not use the **ACC** position.

Manual Release of Transmission with Low Battery

In order to push or tow the vehicle if unable to shift the transmission out of P (Park) (such as a discharged battery), a manual park release is available. In this case it is necessary to manually release the shift lever and release the parking brake if inserted (see "Emergency Release of the Parking Brake" in this section). Follow the steps as indicated in "Transmission Manual Release of P



(Park) Position” in this section to manually disengage the transmission.



Vehicle Towing Conditions

Maserati only allows vehicle towing with all four wheels off the ground.



WARNING!

- Single axle towing or use of a tow dolly is not allowed since it will severely damage vehicle components.
- Use of a tow dolly on front wheels is strictly forbidden since front wheels may still receive a residual amount of torque and disengage the vehicle from the tow dolly and affect safety of both rescuers and other road users.



Use the Tow Hook Included in the Tool Kit



CAUTION!

The tow hook should only be used for towing the car on flat roads. Do not use the tow hook to remove the car that is stuck on off road stretches.

The tow hook is also used to tow the vehicle on the platform of a tow truck. Before carrying out this operation, if the battery of the vehicle still works, set "Transport Mode" on MTC+ in "Suspensions" submenu (see "MTC+ Settings" chapter in section "Dashboard Instruments and Controls"). With this mode activated, the ride height will be lowered to the minimum value and the pneumatic suspension system will be disabled to help vehicle loading on the tow truck.

It is necessary to inform the operators of the rescue vehicle about the vehicle minimum height to avoid, during its loading, any contact of the lower ends of the front or rear bumper with the tow truck loading ramp.

The tow hook is contained in the tool kit (see "Tool Kit" chapter in this section) and must be screwed in the seat located on the front and rear bumper.


- To access the front tow hook seat on the front bumper, remove the cover on the right side of the bumper lower grid.




- To access the rear tow hook seat, remove the external cap on the right side of the rear bumper.



- Carefully clean the threaded seat before screwing the hook.
- Screw the tow hook into its seat for at least 11 turns.



NOTE:
Maximum work angle of towing cable or bar: 15°.





7 – Maintenance and Care

Scheduled Maintenance Service	338
Scheduled Service Plan	339
Maintenance Procedures	346
Maintenance-Free Battery	359
Fuse Replacement	362
Bulb Replacement	369
A/C System Maintenance	371
Wheels Maintenance	372
Bodywork Maintenance and Care	373
Interior Maintenance and Care	377
Vehicle Stored for Long Periods	377
Restarting the Vehicle	378
Battery Statement.	379



Scheduled Maintenance Service

Correct maintenance is clearly the best way to guarantee vehicle performance and safety features, ensure respect for the environment and low operating costs.

NOTE:

Also remember that the observance of the maintenance procedures is essential for keeping your vehicle operating properly. Not adhering to the Maintenance Schedule can impact your vehicle's warranty.

Interval Running Coupons

Maserati has therefore provided for a series of checks and maintenance operations involving the 1st service and subsequent when the vehicle reaches mileage/years reported on the "Scheduled Service Plan" in this section.

After the last service, maintenance must be restarted with the operations scheduled for the 1st, 2nd and 3rd service.



CAUTION!

The Scheduled Maintenance services are prescribed by the Manufacturer. Failure to have the services carried out can affect your warranty.

The Scheduled Maintenance service is provided by the whole **Service Network**. In the event that, when a service is performed, further replacements or repairs are found to be necessary in addition to the scheduled operations, these can be carried out only with the specific consent of the Customer.



CAUTION!

You are advised to notify the **Service Network** of any minor operating problem, without waiting for the next scheduled service.

NOTE:

- *Change your engine oil more often if you drive your vehicle off-road for an extended period of time or short trips without reaching operating temperature.*
- *Under no circumstances should oil change intervals exceed*


mileage/years reported on the "Scheduled Service Plan" in this section.



CAUTION!

Failure to perform the required maintenance items may result in damage to the vehicle.

Scheduled Maintenance (Service) Indicator

The service indicator system will remind you the deadline for the maintenance program. The indicator light  on the instrument cluster flashes for approx. 5 seconds displaying the message backed by a beeping sound, indicating that the next scheduled maintenance is due or has already overdue (see paragraph "TFT Display: Warning/Indicator Lights of Set Modes/Functions" in chapter "Instrument Cluster" of section "Dashboard Instruments and Controls" for more details).



The service indicator and message will illuminate approximately from 1000 km (620 mi) or 30 days to the next scheduled maintenance. Have your vehicle serviced as soon as possible.

NOTE:

The service indicator will not monitor the time elapsed from the last scheduled maintenance.

The **Service Network** will reset the service indicator message after completing the scheduled maintenance operations.

Scheduled Service Plan

The Scheduled Maintenance services listed in this manual must be done within the times or mileages specified to protect your vehicle warranty and ensure the best vehicle performance and reliability.

More frequent maintenance may be needed for vehicles in operating conditions, such as dusty areas and very short trip driving.

Inspection and service should also be done anytime a malfunction is suspected.

Maserati recommends that these maintenance intervals be performed at the **Service Network**. The technicians at your dealership know your vehicle best, and have access to factory-approved information, genuine Maserati parts, and specially designed electronic and mechanical tools that can help prevent future costly repairs.



Main Operations/Service Coupons - Gasoline Engines

Service coupons	1°	2°	3°	4°	5°	6°
Main operations	Interval running coupons: every 20000 km (12500 mi) or 2 years (*)					
Vehicle road test		I		I		I
Check with Maserati Diagnosi	I	I	I	I	I	I
Engine oil and filter	R	R	R	R	R	R
Engine coolant level	I	I	I	I	I	I
Engine check for leaks	I	I	I	I	I	I
Cooling system connections and lines (check for leaks)		I		I		I
Air filter		R		R		R
Belt for alternator (1)	I	I	I	R	I	I
	Replace every time the part is removed					
Belt for water pump, air conditioning compressor and hydraulic steering pump	I	I	I	R	I	I
	Replace every time the part is removed					
Spark plugs			R			R
Intercooler check for leaks	I	I	I	I	I	I
Brake fluid	I	I	I	I	I	I
	Replace every 2 years					
Brake system (lines, calipers, connections) - Instrument cluster warning light efficiency - Parking brake operation	I	I	I	I	I	I
Hydraulic steering fluid level	I	I	I	I	I	I
Tire wear, tire and spare tire (if equipped) pressure check	I	I	I	I	I	I
Joints, rods for front and rear suspensions, front and rear under-chassis		I		I		I
Correct operation and reliability of the seats and seat belts	I	I	I	I	I	I



Service coupons	1°	2°	3°	4°	5°	6°
Main operations	Interval running coupons: every 20000 km (12500 mi) or 2 years (*)					
Pollen filter	R	R	R	R	R	R
Windshield fluid level - Windshield washer and headlight cleaner	I	I	I	I	I	I
Headlight leveling	I	I	I	I	I	I
Controls and adjustment systems in general, hinges, doors, engine compartment lid and luggage compartment	I		I		I	
Condition of the leather interiors	I		I		I	
<p>(*) Interval running coupons for Morocco, Lebanon, South Africa and Jordania markets are every 20000 km (12500 mi) or 1 year.</p> <p>(1) In case of heavy-duty use of the vehicle, highlighted by the presence of mud and dust in the engine compartment, proceed to the preventive replacement of the alternator belt.</p> <p>I = Inspect and carry out any other necessary operation</p> <p>R = Replace</p>						



Main Operations/Service Coupons - Diesel Engine

Service coupons	1°	2°	3°	4°	5°	6°
Main operations	Interval running coupons: every 20000 km (12500 mi) or 1 year (*)					
Vehicle road test		I		I		I
Check with Maserati Diagnosi	I	I	I	I	I	I
Emission control	I	I	I	I	I	I
Engine oil and filter	R	R	R	R	R	R
AdBlue® level	I	I	I	I	I	I
Engine coolant level	I	I	I	I	I	I
Engine check for leaks	I	I	I	I	I	I
Cooling system connections and lines (check for leaks)		I		I		I
Belt for alternator, water pump, air conditioning compressor and hydraulic steering pump	I	I	I	I	R	I
	Replace every time the part is removed					
Air filter	R	R	R	R	R	R
Fuel filter		R		R		R
Brake fluid	I	I	I	I	I	I
	Replace every 2 years					
Brake system (lines, calipers, connections) - Instrument cluster warning light efficiency - Parking brake operation	I	I	I	I	I	I
Hydraulic steering fluid level	I	I	I	I	I	I
Tire wear, tire and spare tire (if equipped) pressure check	I	I	I	I	I	I
Joints, rods for front and rear suspensions, front and rear under-chassis		I		I		I
Correct operation and reliability of the seats and seat belts	I	I	I	I	I	I
Pollen filter		R		R		R



Service coupons	1°	2°	3°	4°	5°	6°
Main operations	Interval running coupons: every 20000 km (12500 mi) or 1 year (*)					
Windshield fluid level — Windshield washer and headlight cleaner	I	I	I	I	I	I
Headlight leveling	I	I	I	I	I	I
Controls and adjustment systems in general, hinges, doors, engine compartment lid and luggage compartment	I		I		I	
Condition of the leather interiors	I		I		I	
<p>(*) Interval running coupons for India, Morocco, Lebanon, South Africa and Jordania markets are every 10000 km (6200 mi) or 1 year. I = Inspect and carry out any other necessary operation R = Replace</p>						



Periodic Maintenance

Every 1000 km (600 mi) or before long journeys

Check:

- engine coolant;
- brake fluid;
- windshield washer fluid level;
- tire inflation pressure and condition;
- operation of lighting system (headlights, direction indicators, hazard warning lights, etc.);
- operation of windshield washer/wiper system and wear of windshield wiper blades.

Every 3000 km (1900 mi)

Check and top up, if required, the engine oil level.

Heavy-Duty Vehicle Use

If the car is mainly used under one of the following conditions:

- towing a trailer;
- off-road;
- short, repeated journeys (less than 7-8 km /4-5 mi) at sub-zero outside temperatures;
- engine often idling or driving long distances at low speeds or long periods of idleness;

you should perform the following inspections more frequently than recommended on the “Scheduled Service Plan”:

- check front disc brake pad conditions and wear;
- check cleanliness of hood and trunk locks, cleanliness and lubrication of linkage;
- visually inspect conditions of: engine, transmission, pipes and hoses (exhaust - fuel system - brakes) and rubber elements (boots - sleeves - bushes - etc.);
- check battery charge;
- visually inspect condition of the accessory drive belts;
- check and, if necessary, change engine oil and replace oil filter;
- check and, if necessary, replace pollen filter of the A/C system;
- check and, if necessary, replace air cleaner filter.




CAUTION!

All maintenance operations for the vehicle must be carried out by the **Service Network**. For routine and minor maintenance operations which you can carry out yourself, make sure

that you have the necessary experience and always use suitable equipment, original **Maserati** spare parts (or equivalent) and the prescribed fluids. **Shall this not be the case, do not carry any operation on your own and contact a Service Center.**

On Board Diagnostic System

Your vehicle is equipped with a sophisticated on board diagnostic system. This system monitors the performance of the emissions, engine, and automatic transmission control systems. When these systems are operating properly, your vehicle will provide excellent performance and fuel economy, as well as engine emissions suited to current government regulations.



If any of these systems require service, the system will turn on the Malfunction Indicator Light  on the instrument cluster display (refer to “Instrument Cluster” in section “Dashboard Instruments and Controls”). The system stores as well diagnostic codes and other information to assist your service technician by performing repairs. Although the vehicle will be driveable and will not need towing, contact the



Service Network for service as soon as possible.



CAUTION!

- Prolonged driving with the  MIL on could cause further damage to the emissions control system. It could also affect fuel economy and driveability. The vehicle must be serviced before any emissions tests can be performed.
- If the  MIL is flashing while the engine is running, severe catalytic converter damage and power loss will soon occur. Immediate service at the **Service Network** is required.

Exhaust Gas After-treatment System Strategies (Diesel only)

This vehicle is equipped with a state-of-the-art engine and exhaust system containing a Diesel Particulate Filter (DPF) and an SCR (Selective Catalytic Reduction) catalytic converter integrated into a system which injects a harmless urea solution (reducing agent AdBlue®) into the exhaust gases. When vaporised, it converts smog forming nitrogen oxides (NOx) into harmless nitrogen (N₂) and water

vapour (H₂O), two natural components of the air we breathe. This system consists of the following components:

- AdBlue® tank with pump;
- injector with electronically-heated lines;
- NOx sensors;
- temperature sensors;
- SCR catalyst.

The engine and exhaust after-treatment system work together to meet the Emission standards. The system manages engine combustion to allow the exhaust system's catalytic converter to trap and burn Particulate Matter (PM) pollutants. The AdBlue® injection system reduces nitrogen oxide (NOx) emissions to a minimum so as to meet Euro VI requirements. The injection of AdBlue® and SCR catalyst as well as help to reduce pollution, do not have effect on consumption, performance and driveability.

NOTE:

- *The AdBlue® injection system may sometimes produce a ticking sound, audible when the vehicle stops. This is normal operation.*

- *The pump will run for a period of time after engine shutdown to purge the AdBlue® injection system. This is normal operation and may be audible from the rear of the vehicle.*

The control system visualizes messages on the TFT display to alert the driver when regeneration treatment and /or AdBlue® refilling is necessary or when the vehicle shall be taken to the **Service Network**. Refer to chapter "Instrument Cluster" in section "Dashboard Instruments and Controls" for further information.

Spare Parts

Use of genuine Maserati parts for normal or scheduled maintenance and repairs is highly recommended to ensure excellent performance. Damage or failures caused by non-genuine spare parts used for maintenance and repairs will not be covered by the manufacturer's warranty.



Maintenance Procedures

The following pages contain the “required” maintenance standards determined by Maserati engineers. Besides those maintenance items specified in the “Scheduled Service Plan”, there are other components which may require service or replacement in the future.

To perform most of the services, it is necessary to open the hood (see “Open and Close the Hood” in section “Before Starting”).

The following images show the position of the components involved in the maintenance service.



CAUTION!


- Failure to properly maintain your vehicle or perform repairs and service when necessary could result in more costly repairs, damage to other components or negatively impact vehicle performance. Immediately have potential malfunctions address to the **Service Network**: please be advised that Maserati recommends to address to the **Official Service Network**.
- Your vehicle has been equipped with improved fluids that protect the

performance and durability of your vehicle and also allow extended maintenance intervals. Do not use chemical flushes for washing as the chemicals can damage your engine, transmission, power steering or air conditioning. Such damages are not covered by the New Vehicle Limited Warranty. If a flush is needed because of component malfunction, use only a specific product for the flushing procedure.



Maintenance Service Components - Gasoline Engines

- 1 Engine oil dipstick.
- 2 Engine oil filler neck.
- 3 Power steering fluid reservoir cap.
- 4 Engine coolant expansion reservoir cap.
- 5 Coolant reservoir cap for transmission and hydraulic steering system.
- 6 Windshield/headlight washer fluid reservoir cap.
- 7 Brake fluid reservoir access cover.
- 8 A/C pollen filter access cover.
- 9 Integrated power module (fuses).
- 10 Air cleaner filters.




Gasoline



Maintenance Service Components - Diesel Engine

- | | | | | | |
|---|---|---|--|----|----------------------------------|
| 1 | Engine oil dipstick. | 4 | Engine coolant expansion reservoir cap. | 8 | Integrated power module (fuses). |
| 2 | Engine oil filler neck inspection door. | 5 | Windshield/headlight washer fluid reservoir cap. | 9 | Air cleaner filter. |
| 3 | Power steering fluid reservoir cap. | 6 | Brake fluid reservoir access cover. | 10 | Fuel filter. |
| | | 7 | A/C pollen filter access cover. | | |



Diesel

Level Checks



ENVIRONMENTAL!

- The engine oils and fluids used contain substances that are dangerous for the environment. For replacement you are advised to contact the Service Network, where all the necessary equipment is available to dispose of the used oil and fluids in compliance with the regulations in force and in an environmentally-friendly manner.
- All equipment used for fluids replacement (gloves, cloths, containers, etc) must be disposed of in compliance with the regulations in force.



Engine Coolant Level Check - Gasoline Engines

Your vehicle has been equipped with an improved engine coolant (antifreeze) that offers high protection against corrosion, freezing and allows extended maintenance intervals. To prevent reducing extended maintenance periods, it is important to use original engine coolant (antifreeze) when adding coolant throughout the life of your vehicle.

When adding engine coolant (antifreeze) use pure water only, such as distilled or deionized water when mixing the water/engine coolant (antifreeze) solution. The use of impure water will reduce the amount of corrosion protection in the engine cooling system.

- Mix a minimum solution of 50% engine coolant (antifreeze) and distilled water. Use higher concentrations (do not exceed 70%) if temperatures below -37°C (-35°F) are forecasted.

Please note that it is the owner's responsibility to maintain the proper level of protection against freezing according to the temperatures

occurring in the circulation area of the vehicle.

The coolant bottle provides a quick visual method to determine that the coolant level is adequate. As long as the engine operating temperature is satisfactory, the coolant bottle only needs to be checked once a month. With the engine off and cold, the level of the coolant in the bottle on the left side of the engine compartment should be between the ranges indicated on the bottle and inside the filler neck.



Gasoline



Gasoline

- When additional engine coolant (antifreeze) is needed to maintain the proper level, it should be added to the coolant bottle after removing the cap. Do not overfill.
- Once the desired level is reached, reassemble and firmly close cap of the bottle.
- If frequent engine coolant (antifreeze) additions are required, or if the level in the coolant recovery bottle does not drop when the engine cools, the cooling system should be tested by a **Service Network** centre.
- Keep the front of the radiator and the condenser clean.



WARNING!

- Never add engine coolant (antifreeze) when the engine is hot. Do not loosen or remove the cap of the engine coolant bottle to cool a hot engine. Heat causes pressure to build up in the cooling system. To prevent scalding or injury, do not remove the pressure cap while the system is hot or under pressure.
- When adding coolant do not use a pressure cap other than the one specified for your vehicle. Personal injury or engine damage may result.

Engine Coolant Level Check - Diesel Engine

Your vehicle has been equipped with an improved engine coolant (antifreeze) that offers high protection against corrosion, freezing and allows extended maintenance intervals. To prevent reducing extended maintenance periods, it is important to use original engine coolant (antifreeze) when adding coolant throughout the life of your vehicle. When adding engine coolant (antifreeze) use pure water only, such as distilled or deionized water when mixing the water/engine coolant

(antifreeze) solution. The use of impure water will reduce the amount of corrosion protection in the engine cooling system.

- Mix a minimum solution of 50% engine coolant (antifreeze) and distilled water. Use higher concentrations (do not exceed 70%) if temperatures below -37°C (-35°F) are forecasted.

Please note that it is the owner's responsibility to maintain the proper level of protection against freezing according to the temperatures occurring in the circulation area of the vehicle.

The coolant bottle provides a quick visual method to determine that the coolant level is adequate. As long as the engine operating temperature is satisfactory, the coolant bottle only needs to be checked once a month. With the engine off and cold, the level of the coolant in the bottle on the left side of the engine compartment should be between the ranges indicated on the bottle and inside the filler neck.



Diesel



Diesel

- When additional engine coolant (antifreeze) is needed to maintain the proper level, it should be added to the coolant bottle after removing the cap. Do not overfill.
- Once the desired level is reached, reassemble and firmly close cap of the bottle.




- If frequent engine coolant (antifreeze) additions are required, or if the level in the coolant recovery bottle does not drop when the engine cools, the cooling system should be pressure-tested for leaks by a **Service Centre**.
- Keep the front of the radiator and the condenser clean.

**WARNING!**

- **Never add engine coolant (antifreeze) when the engine is hot. Do not loosen or remove the cap of the engine coolant bottle to cool a hot engine. Heat causes pressure to build up in the cooling system. To prevent scalding or injury, do not remove the pressure cap while the system is hot or under pressure.**
- **When adding coolant do not use a pressure cap other than the one specified for your vehicle. Personal injury or engine damage may result.**


Brake Fluid Level Check

Check the fluid level immediately if the brake system warning light  and the related message turn on indicating a low level of brake fluid.

- Remove the brakes fluid reservoir access cover.




- Clean the top of the master cylinder reservoir before removing the cap.
- Add fluid to bring the level up to the “MAX” mark on the side of the master cylinder reservoir. Use only manufacturer's recommended brake fluid (see “Refillings” in section “Features and Specifications”).
- Add enough fluid to bring it to the “MAX” level marked on the brake fluid reservoir.
- Once the correct level is reached, firmly close the cap.



Normal brake pad wear could cause the fluid level to fall. However, low fluid level may be caused by a leak too, and requires accurate checkup of the braking system.

**CAUTION!**

The symbol  on the tank cap identifies the synthetic type of brake fluid, distinguishing it from the mineral type. Using mineral fluids damages the special rubber linings of the brake system irreparably.

**WARNING!**

- **To avoid contamination from foreign materials or moisture, use only new brake fluid or fluid that has been in a tightly closed container. Keep the**

(Continued)




(Continued)
master cylinder reservoir cap secured at all times. Brake fluid in an open container absorbs moisture from the air resulting in a lower boiling point. This may cause it to boil unexpectedly during hard or prolonged braking, resulting in sudden brake failure. This could result in an accident.

- **Overfilling the brake fluid reservoir can result in spilling brake fluid on hot engine parts, causing the brake fluid to catch fire. Brake fluid can also damage painted and vinyl surfaces, make sure it does not spill over these surfaces.**
- **Do not allow petroleum based fluid to contaminate the brake fluid. Brake seal components could be damaged, causing partial or complete brake failure. This could result in an accident.**

Adding Washer/Headlight Washer Fluid

The reservoir on the left side of the engine compartment contains the fluid to wash the windshield, the window liftgate and headlights (if foreseen). During scheduled services or when the message of low level of the washer

fluid appears together with the related telltale  add more fluid as soon as possible.

Depending on the system installed in the vehicle, the fluid reservoir may contain nearly 4 litres of washer/headlight washer fluid or nearly 3 litres of washer fluid.

- Remove the reservoir cap in the engine compartment and lift the filler neck.



- Fill the reservoir with windshield washer solvent (refer to “Refillings” in section “Features and Specifications”) and operate the system for a few seconds to flush out the residual water.
- When refilling the washer fluid reservoir, apply some washer fluid to a cloth or towel and wipe the wiper blades clean. This will help blade performance.

To prevent freeze-up of your windshield/headlight washer system in cold weather, select a solution or mixture that meets or exceeds the temperature range of your climate. This rating information can be found on most washer fluid containers.

NOTE:

*The **Maserati Service Network** can provide you with information about the Maserati recommended “Windshield Washer Fluid” with antifreeze, available in the “Genuine Accessories” catalog.*



WARNING!


- **Commercially available windshield washer solvents are flammable. They could ignite and burn you. Care must**



be exercised when filling or when working around the windshield/headlight washer system.

- Do not drive with the windshield/headlight washer reservoir empty: the action of the washer is essential for improving visibility when driving.

Engine Oil Level Check - Gasoline Engines

To assure proper lubrication of your vehicle's engine, the engine oil must be maintained at the correct level. If the  warning light illuminates and the related message of low oil level displays, or during scheduled services (see "Scheduled Maintenance Service" in this section) it is necessary to check the engine oil level. The best time to check the engine oil level is about five minutes after a fully warmed up engine is shut off or before starting the engine after it has sat overnight. In both cases the vehicle should be parked on level ground to improve the accuracy of the oil level readings.



CAUTION!

- Do not top up with oil with different characteristics than the engine one (refer to "Refillings" in section "Features and Specifications").
- Overfilling or underfilling the sump will cause aeration or loss of oil pressure. This could damage your engine.
- Do not add any supplemental materials to the engine oil, other than leak detection dyes. Engine oil is an engineered product, and its performance may be impaired by supplemental additives.
- Remove the dipstick and clean it with a dry and clean cloth.



Gasoline

- Re-insert the dipstick completely and remove: the oil level should maintain between the "MIN" and "MAX" reference ranges (SAFE range).



Gasoline

- If a refilling is necessary: unscrew the filler neck cap.



Gasoline

- Adding 1 litre (0.22 UK gal) of oil when the level is at the bottom of the SAFE range will result in the




level being at the top of the SAFE range.

- Return the cap and dipstick to their position and wait for a few minutes to allow the oil to reach the sump.
- Check the level again.

Engine Oil Level Check - Diesel Engine

To assure proper lubrication of your vehicle's engine, the engine oil must be maintained at the correct level.

If the  warning light illuminates and the related message of low oil level displays, or during scheduled services (see "Scheduled Maintenance Service" in this section) it is necessary to check the engine oil level.

The best time to check the engine oil level is about five minutes after a fully warmed up engine is shut off or before starting the engine after it has sat overnight. In both cases the vehicle should be parked on level ground to improve the accuracy of the oil level readings.



CAUTION!

- Do not top up with oil with different characteristics than the engine one (refer to "Refillings" in section "Features and Specifications").

- Overfilling or underfilling the sump will cause aeration or loss of oil pressure. This could damage your engine.
- Do not add any supplemental materials to the engine oil, other than leak detection dyes. Engine oil is an engineered product, and its performance may be impaired by supplemental additives.

- Remove the dipstick and clean it with a dry and clean cloth.



Diesel

- Re-insert the dipstick completely and remove: the oil level should maintain between the "MIN" and "MAX" reference ranges (SAFE range).



Diesel

- If a refilling is necessary: open the inspection door and unscrew the filler neck cap.



Diesel

- Adding 1 litre (0.22 UK gal) of oil when the level is at the bottom of the SAFE range will result in the level being at the top of the SAFE range.



- Return the cap and dipstick to their position and wait for a few minutes to allow the oil to reach the sump.
- Check the level again.
- Close the inspection door.

Engine Oil Filter Replacement

The engine oil filter should be replaced with a new filter at every oil change.

Contact the **Service Network** to perform this service.

Fuel Filter Service (Diesel only)

Contact the **Service Network** to perform this service.

DPF Filter Replacement (Diesel only)

Contact the **Service Network** to perform this service.

Automatic Transmission Oil Check

Contact the **Service Network** for the oil level check.


Power Steering Fluid Level Check

With the vehicle on a level ground and the engine cold, check the fluid level of the power steering reservoir.

- To carry out the check, unscrew the cap, clean the dipstick with a dry and clean cloth.



- Retighten the cap then unscrew it again and check the level: it should match the "MAX" notch marked on the dipstick. In hot oil conditions, the level may even exceed the "MAX" notch.



- If necessary, top up with fluid making sure that it has the same characteristics as the one already used in the system (refer to "Refillings" in section "Features and Specifications").



CAUTION!

- Make sure that the power steering fluid does not come in touch with the engine hot parts as it is flammable.
- When the engine is running, do not keep the steering wheel completely turned for longer than 8 seconds, unless absolutely necessary. This will cause a noise and also the overheating of the hydraulic steering fluid and could damage the hydraulic steering system.

Coolant Transmission and Hydraulic Steering System Fluid Level Check (Gasoline only)

The coolant contained in the bottle of this system is the same as the one used for the cooling system of the engine. For the preparation of the mixture of water and antifreeze and for the control of the level, proceed as shown in the "Engine Coolant Level Check" of this chapter.



Gasoline Engine Air Filters Replacement

Contact the **Service Network** to have the air filters replaced.

A/C Air Filter Replacement

This filter performs mechanic/ electrostatic air filtering, provided that windows and doors are closed.


The filter is located under the hood in the external A/C system air inlet, on the passenger side of the vehicle, next to the windshield wipers.

To replace the filter during the scheduled maintenance services or after the vehicle has been heavily used on dusty roads, proceed as follows:

- Remove the access door in the cowl screen by pressing the retaining clips indicated.




- Unsnap both ends and lift the filter retaining cover.



- Remove the used filter slipping it off from within the air intake.



- Install the new filter with arrows pointing in the direction of airflow, which is toward the rear of the vehicle (text and arrows on the filter will indicate this).



- Close the filter retaining cover and reinstall the access door.



CAUTION!

Failure to replace the filter may considerably reduce the air



conditioning and heating system efficiency.

Wiper Maintenance and Blades Replacement

Windshield Wiper Arms Lifting

When the windshield wiper arms are in rest position it is not possible to check or replace the blades as they remain under the engine hood.

To service the blades it is necessary to move the wiper arms in "Service" position (see chapter "Wipers and Washers" in section "Understanding the Vehicle"). In this way it is possible to lift the arms for cleaning or replacing the wiper blades.



WARNING!

It is dangerous to operate or service the wiper blades with the windshield wipers in an active position (any position different from "OFF") and with the ignition switch in the RUN position. The rain sensors may suddenly activate the wipers. Always use the "Service" position for any intervention on the windshield wiper blades.

Windshield Wiper Maintenance

Life expectancy of wiper blades varies depending on the geographical area's weather conditions where the car is used and frequency of use. Poor performance of blades may be present with chattering, marks on the glass, water lines or wet spots. If any of these conditions are present, clean the wiper blades or replace if necessary. Clean the rubber edges of the wiper blades and the windshield/rear window glasses periodically with a sponge or soft cloth and a mild nonabrasive cleaner. This will remove accumulations of salt or road film. Operation of the wipers on dry glass for long periods may cause deterioration of the wiper blades. Always use washer fluid when using the wipers to remove salt or dirt from a dry windshield.

Avoid using the wiper blades to remove frost or ice from the windshield. Keep the blade rubber out of contact with petroleum products such as engine oil, gasoline, etc.

Spray nozzles

If the jet does not work, first check that there is fluid in the tank (see paragraph "Level checks" in this

section) then check that the nozzles are not clogged.

Windshield Wiper Blades Replacement

- Move the wiper arms into "Service" position, (see chapter "Windshield Wipers and Washers" in section "Understanding the Vehicle") and lift them.
- Press the indicated button, slip off the blade support from the arm and replace it.



- Return the blade to its original position on the windshield.
- Turn the multifunction lever to one of the automatic settings (see chapter "Windshield Wipers and Washers" in section "Understanding the Vehicle") and move the ignition switch to the **RUN** position: the wiper arms will return to the resting position.



NOTE:

Due to the difficulty of this operation, we recommend that you contact the **Service Network** for replacement of the blades.

Rear Window Blade Replacement


- To replace the rear window wiper blade on the liftgate, lift the wiper arm with blade up to the stop position.



- Turn the blade to the position indicated in the figure.
- Hold the arm steady and pull the blade, by holding it from the central support, until it is removed.



- Replace the blade.
- Insert the pivot, present inside the blade central support, in the fork-shaped end of the arm until hearing the click indicating that it is engaged.



Stretch the arm and put the blade back in contact with the liftgate window.

Body Lubrication

Locks and all body pivot points, including such items as seat tracks, door hinge pivot points and rollers, liftgate, sliding parts of power sunroof (if foreseen) and hood hinges, should be lubricated periodically with a lithium-based grease. This action is essential to preserve the original operation of these components and to protect them against rust and wear. Prior to the application of any lubricant, the parts concerned should be wiped clean to remove dust and grit; after lubricating excess oil and grease should be removed. Particular attention should also be given to hood latching components to ensure proper function. When performing maintenance in the engine compartment, the hood latch, release mechanism and safety catch should be cleaned and lubricated. The coupling pin of the lock on the rear driver door pillar must be lubricated at least twice a year, preferably in the Fall and Spring. Apply a small amount of high quality lubricant directly on the bolt.



Maintenance-Free Battery

This vehicle is equipped with a sealed type maintenance-free battery. You will never have to add water, nor is periodic maintenance required.



WARNING!

- Battery fluid is a corrosive acid solution and can burn or damage the eyes. Do not allow battery fluid to contact your eyes, skin, or clothing. Do not lean with the face over a battery. If acid splashes in eyes or on skin, flush the area immediately with large amounts of water.
- Battery gas is flammable and explosive. Keep flame or sparks away from the battery. Do not use a booster battery or any other booster source with an output greater than 12 Volts. Do not allow cable clamps to touch each other.
- Battery posts, terminals, and related accessories contain lead and lead compounds. Wash hands after handling the battery.
- The battery in this vehicle has a vent hose that should not be disconnected and should only be

replaced with a component of the same type (vented).

NOTE:

Remote battery terminals for start are located in the engine compartment for jump starting to be used with an auxiliary battery or a battery from another vehicle (see "Auxiliary Jump-Start Procedure" chapter in section "In an Emergency").


To Disconnect the Battery

The battery is located on the inner right side of the boot compartment. To access the battery it is necessary to lift the ground coverage of the boot compartment (see chapter "Tool Kit" in section "In an Emergency") and remove the storage box.



CAUTION!

- Before disconnecting the battery, open the liftgate and lower the windows a few centimetres, to avoid damaging the seal when opening and closing the door. When the battery is connected, the lowering of the window is performed automatically when the door is opened and closed. The windows must remain lowered until the charged battery is reconnected.
- Never disconnect the battery from the electrical system when the engine is running.
- To temporarily disconnect the vehicle electrical system from the battery, simply remove the cable end with quick coupling from the negative post (-) of the battery.
- If the battery needs to be removed from its compartment, you must first detach the terminal clamp to the negative post (-) and then the other terminal clamp to the positive post (+), after removing the protective cover. Battery posts are marked positive (+) and negative (-) and are identified on the battery case.



To Reconnect the Battery



- It is essential when replacing the cables on the battery that the positive cable is precisely attached to the positive post (+) and the negative cable is attached to the negative post (-).

- Cable clamps should be tight on the terminal posts and free of corrosion.

After the battery has been disconnected and re-connected and before starting the engine it is necessary to proceed as follows:

- Unlock and lock the doors using the Key fob RKE Transmitter.
- Unlock the boot lid with the key fob RKE transmitter and then lock it manually. If the vehicle is equipped with power liftgate, manually perform the complete closure. Then move the lid automatically, using the buttons on the outer edge of the left boot compartment, performing a complete cycle of opening and closing.
- Initialise the climate control system by activating the system and pressing the "AUTO" control as described in chapter "Air Conditioning Controls" in section "Dashboard Instruments and Controls".
- Turn on the MTC+ and set the date and time following the MTC+ instructions manual.
- Lift, release and lift again the lever on the central console to initialise the electric parking brake. Following this operation the warning light

on the instrument cluster will turn off.

- For correct activation of the approach lights on the external mirrors, press at least once the tilt button on the driver's door panel so that the door mode recognizes the mirrors position.



- Every time the battery is reconnected, wait at least 30 seconds with the ignition switch turned to **RUN** before starting the engine, in order to allow the electronic system that manages the motor-driven throttles to run a self-learning cycle. At the same time, you can run the date and time set up procedure for the MTC+.
- Every time the battery is reconnected the warning lights and flash for about 10 seconds and then go off.



Useful Advice to Extend Battery Life

When parking the vehicle, make sure that the doors, hood, liftgate and flaps are properly closed. All interior lights should be off.

When the engine is turned off, do not keep the connected devices switched on for a long time (such as radio, hazard warning lights, fan, etc.).



CAUTION!

If the battery charge remains below 50% for a long period of time, it will be damaged due to sulphation; its performance and starting power will be reduced and it will be more subject to freezing (this can happen even at $-10^{\circ}\text{C}/14^{\circ}\text{F}$).

We recommend you to have the battery charge condition checked, preferably at the beginning of the cold season, to prevent the electrolyte from freezing.

This check should be carried out more frequently if the vehicle is used mainly for short trips or if it is equipped with power-absorbing devices that remain permanently on even when the ignition switch is off. This applies

above all if these devices have been retrofitted ("Aftermarket" services). If the vehicle is not used for long periods of time, please see "Vehicle Stored for Long Periods" in this section.

Battery Recharge



WARNING!


The process of charging or recharging the battery produces hydrogen, a flammable gas that can explode and cause serious injuries. When charging or recharging the battery, follow the recommended precautions at all times.

- Before using a charger device always check that this tool is suitable for the installed battery, with constant voltage (lower than 14.0 V) and low amperage (maximum limit 15 A).
- Recharge the battery in a well-ventilated environment.
- Never charge or recharge a frozen battery: it can explode due to hydrogen trapped inside the ice crystals.
- Ensure that any sparks or open flames are kept well away from the battery while it is charging.


- Before using a charger to charge or maintain the battery charge status, carefully follow the instructions provided to ensure the charger is connected to the battery safely and correctly.

Is possible to recharge the battery without disconnecting the cables of the vehicle electrical system.

- To access the battery lift the ground coverage of the boot compartment (see chapter "Tool Kit" section "In an Emergency") and remove the storage box.
- Remove the protection cover and connect the terminal clamp of the charger positive cable (typically in red) to the positive post (+) of the battery.
- Connect the terminal clamp of the charger negative cable (typically in black) to the nut located by the negative post (-) on the battery, indicated in the picture.



The vehicle is equipped with a IBS (Intelligent Battery Sensor) sensor able to measure charging and discharging currents and to calculate the state of charge and state of health of the battery. This sensor is located in at the negative post (-) of the battery. For a successful charge/recharge operation, the charging current must flow through the IBS sensor as shown in the picture.



- Turn the charger on and follow the instructions on its user manual to completely recharge the battery.
- When the battery is recharged, turn off the battery charger before disconnecting it from the battery.
- Disconnect first the terminal clamp of the charger black cable from the battery and then the terminal clamp of the red cable.
- Reassemble the protection cover on the battery positive post and the other parts removed for this operation.

Fuse Replacement


Used Fuses Characteristics

When an electrical device is not functioning, check that the corresponding fuse is in proper working order (intact).

- A Fuse intact
- B Fuse blown



Replace the faulty fuse with a new one featuring the same rating, by using appropriate forceps added in the integrated power module and inside the cover of the rear power distribution center.



The color identifies the value of the fuses in amperes which is also reported on them.

The vehicle is powered with mini-and maxi-fuses.

The table shows the match between color and amperage of mini and maxi fuses.

Type	Color / Ampere						
Mini Fuse	Beige - 5	Brown - 7,5	Red - 10	Blue - 15	Yellow - 20	White - 25	Green - 30
Maxi Fuse	Yellow - 20	Green - 30	Orange - 40	Red - 50	Blue - 60		



CAUTION!

- Never replace a blown fuse with anything other than a new and suitable fuse (same rating).
- After replacing a fuse, if the fault recurs, contact the **Service Network**.



Position of Fuses

The fuses are located in three parts of the vehicle, namely:

- inside the integrated power module, on the right hand side of the engine compartment (figures show a gasoline engine);




- inside the rear power distribution center, behind the battery, on the right hand side of the boot compartment;



- on the fuse and relay box located in a covered area, under the dashboard left side.

Integrated Power Module

- To access the module it is necessary to lift the hood (see "Open and Close the Hood" in section "Before Starting").
- To access the fuses remove the module cover unhooking the lateral locks as shown in the picture.



The table points out the position as featured in the figure, the type and function of the fuses included in the integrated power module.



CAUTION!

- After replacement, refit the protective cover of the module.
- If you need to wash the engine compartment, do not direct the water for too long directly on the module.




Ref.	Type	Function
11	Mini – 20A	Horn relay input
12	Mini – 10A	AC compressor relay input
14	Mini – 7,5A	Alarm siren
19	Maxi – 30A	HDLP Headlights washer relay input

Ref.	Type	Function
20	Maxi – 30A	Wiper motor relay output
21	Maxi – 20A	LH low beam relay input
22	Maxi – 20A	RH low beam relay input
28	Mini – 7,5A	IPC Instrument Panel Control

Ref.	Type	Function
33	Mini – 10A	HDLP Headlights

Rear Power Distribution Center

- To access the center it is necessary to lift the ground coverage of the boot compartment (see chapter “Tool Kit” in section “In an Emergency”) and remove the storage box.
- To access the fuses, release the cover latch shown in picture.




- Press the release latch and lift the lid from this side.
- Push the lid toward the right side to release the indicated latches on the unit.



The table points out the position as featured in the figure, the type and function of the fuses on the rear area distribution control unit.

Ref.	Type	Function
7	Maxi – 30A	Driver door module
8	Maxi – 30A	Passenger door module
11	Maxi – 40A	High Premium stereo amplifier unit

7





Ref.	Type	Function
15	Maxi – 40A	HVAC front blower relay coil
17	Maxi – 30A	Rear LH door module
18	Maxi – 30A	Rear RH door module
20	Maxi – 20A	Premium stereo amplifier unit
31	Mini – 25A	LH front seat movement
35	Mini – 20A	Rear doors sunshade
38	Mini – 25A	RH front seat movement


Ref.	Type	Function
45	Mini – 10A	Sunroof
46	Mini – 5A	Rear camera
49	Mini – 10A	Internal mirror, Rain Light Sensor (RLS), humidity sensor and internal temperature sensor
52	Mini – 20A	Power outlet in boot compartment
61	Mini – 15A	Rear window wiper
68	Mini – 20A	Power outlet in rear side of central console
69	Mini – 25A	Power outlet in central console and cigar lighter



Fuse Box under the Dashboard

This box is located in an internal area under the dashboard left side. Considering the complexity of this operation, we recommend having the fuses replaced by the **Service Network**. The table points out the position as featured in the figure, the type and function of the fuses in the box under the dashboard.

Ref.	Type	Function
1	Mini – 7.5A	USB charger on dashboard glove box
6	Mini – 25A	Radio





Bulb Replacement

The signal failure of an external light (turn signal, low beam and high beam, number plate light, reverse light and brake light) is communicated to the instrument cluster that displays on the TFT screen in a graphical form and with a text message which light is faulty (see example in the figure).



Lights Cluster


The lights of the front clusters are arranged as follows:

- 1 Bi-Xenon low-beam/high-beam bulb (25W-No AFS, 35W-With AFS).
- 2 Position and DRL LED lights.
- 3 Direction indicator LED.
- 4 Side-marker LED light.
- 5 Side reflex-reflector.
- 6 Front fog light LED.



The lights of the rear clusters are arranged as follows:

- 1 Position light guide LED.
- 2 Stop light LED.
- 3 Direction indicator LED.
- 4 Reverse light LED.
- 5 Rear fog light LED.
- 6 Side reflex-reflector.



CAUTION!

Due to the complexity of the operation, for the replacement of the headlight clusters light bulbs, we recommend that you contact the **Service Network**.



WARNING!

The headlamps are a type of high voltage discharge tube. High voltage can remain in the circuit even with the headlamp switch and the ignition switch off. Because of this, you should not attempt to replace a headlamp bulb yourself, but take the vehicle to a center of the Service Network for service.

Besides the light clusters, a third LED stop light is present on the rear side of the liftgate.



Light Clusters Bulbs Replacement

Most of the lamps of the front light clusters, all those of the rear light clusters, those integrated in the exterior mirrors and those of the stop light on the liftgate are LED powered and cannot be replaced individually. The only exceptions are the front fog light bulbs.

Contact the **Service Network** to locate the correct parts and replace them.

7 Front Light Bulb Replacement

Contact the **Service Network** to replace them.

Number Plate Lights

Number plate light are LED powered: contact the **Service Network** to replace them.

Passenger Compartment Interior Lights



CAUTION!

Before replacing a bulb, ensure that the matching fuse is intact. For replacement, use only original new light bulbs having the same rating as the old one.

Lamps inside the glove box compartment of the dashboard, lamps under the sun visors and those located next to the passenger handholds for the external rear seats are LED powered and cannot be replaced by the owner. Contact the **Service Network** to replace them.

Courtesy Lights (below Door)

To replace the bulb (W5W):

- use a screwdriver positioned at the indicated point to lever out the light fixing frame;



- remove the light from its seat and open the two parts to access the bulb;



- replace the pressure-fitted bulb;
- refit the light inserting first the electrical connector side and then pressing on the other side to hook up the clip.



Boot Compartment Light

The lights inside the boot compartment and on the liftgate are LED powered: contact the **Service Network** to replace them.

A/C System Maintenance

For best performances, the air conditioning system should be checked and serviced by the **Service Network** at the beginning of the warm season.

This service should include cleaning of the condenser check of the drive belt tension and a performance test.

During the winter, the air conditioning system should be operated at least once a month for about 10 minutes.



CAUTION!

Do not use chemical flushes in your air conditioning system as the chemicals can damage your air conditioning components. Such damage is not covered by the New Vehicle Limited Warranty.



WARNING!

- Use only refrigerants and compressor lubricants approved by the manufacturer for your air conditioning system. Some refrigerants are flammable and can explode, causing injuries. Other unapproved refrigerants or

lubricants can cause the system to fail, requiring costly repairs.

- The air conditioning system contains refrigerant under high pressure. To avoid risk of personal injury or damage to the system, adding refrigerant or any repair requiring lines to be disconnected should be done by an experienced technician.

Periodically remove any leaves and insects that may build up and obstruct the inlet of external air in the air conditioning system through the grille present underneath the rear part of the hood.

To access the grille, lift the hood as described in “Open and Close the Hood” in section “Before Starting”.



Wheels Maintenance

Tires Maintenance



CAUTION!

To obtain the best performances and the longest mileage from the tires, take following precautions during the first 500 km (310 mi):

- do not drive at the vehicle's maximum speed;
- drive at low speed on curves;
- avoid sudden steering;
- avoid sudden braking;
- avoid sudden acceleration;
- do not drive at high speeds for too long.

The tires inflation pressure must correspond to the prescribed values (see the chapter "Tire Inflation Pressure" in section "Features and Specifications") and should be checked only when the tires have cooled down. In fact, the pressure increases as the tire temperature progressively increases.

Never reduce the pressure if tires are hot (see "Tires – General Information" chapter in section "Driving").

Insufficient tire inflating pressure can cause tire overheating and possible internal damage, which may even lead to the tire destruction.



CAUTION!

After inspecting or adjusting the tire pressure, always reinstall the valve stem cap. This will prevent moisture and dirt from entering the valve stem, which could damage it.

Impacts with curbs, holes, and obstacles in the road, and prolonged trips on rough roads or off-road trails can cause tire damage which may not be visible to the naked eye.

Check your tires regularly for any signs of damage (e.g. scratches, cuts, cracks, bulges, etc.). If sharp objects penetrate the tires, they can cause structural damage which is only visible when the tire is removed.

In any case, any possible damage must be inspected by an experienced technician, as it may seriously reduce the tire life.

Remember that tires deteriorate with time, even if used little or not at all. Cracks in the tire tread and sides, alongside possible bulging, are a sign of deterioration.



WARNING!

- Check the inflating pressure of the tires when cold, at least every two weeks and before long trips.
- Have the old tires inspected by an experienced technician, to make sure they can still be used safely. If the same tire has been on your vehicle for 4 or 5 years, have it inspected anyway by an experienced technician.
- Never fit tires of uncertain origin.
- "Directional" tires have an arrow on their side showing the rolling direction. To keep the best performance when replacing a tire, make sure that the rolling direction corresponds to the one shown by the arrow.
- During the tire life, the rolling direction used for the first fitting shall always be observed, also in case of "nondirectional" tires.
- Check the depth of the tire tread at regular intervals. The minimum allowed value is 1,6 mm (0.06 in) at that point the wear indicators on the tire will be visible (see "Tires – General Information" in section



“Driving”). The thinner is the tread, the greater is the risk of skidding.

- Drive carefully on wet roads to decrease the risk of aquaplaning.

Winter Tires

These tires are specially designed for driving on snow and ice and are fitted to replace the ones supplied with the vehicle.

The winter features of these tires are significantly reduced when tread depth is less than 4 mm (0.16 in). In this case, they should be replaced. The specific features of the winter tires lead to lower performance under normal environmental conditions or on long highway trips, compared to the standard tires.

Therefore, their use should be limited to the situations and performance for which they have been type-approved. The **Service Network** can provide all necessary information about fitting winter tires on the vehicle.

Wheel Trims Maintenance

All wheel trims should be cleaned regularly with a mild soap and water. To remove heavy soil and/or excessive brake dust, use a nonabrasive, non-acidic cleaner.

Do not use scouring pads, steel wool, a bristle brush, or metal polishes.

Do not use oven cleaner that may involve and damage the brake calipers.

Avoid automatic car washes that use acidic solutions or harsh brushes that may damage the wheel trim protective finish.

Bodywork Maintenance and Care

Protection from Atmospheric Agents

The main causes of corrosion are:

- atmospheric pollution;
- salinity and humidity in the atmosphere (marine areas or a damp climate);
- seasonal environmental conditions;
- salt scattered on the roadbed to melt ice and snow.

The abrasive action of wind-carried atmospheric dust and sand, mud and stones should not be underestimated. On this vehicle, Maserati has adopted the best technological solutions to protect the bodywork from corrosion. The main measures are:

- paint products and systems that give the vehicle particular resistance to corrosion and abrasion;
- use of galvanized (or pre-treated) metal sheets which are highly resistant to corrosion in the most exposed parts;
- spraying of the underbody, engine compartment, insides of wheel housings, and other structures with



wax products having high protective power;

- spraying of plastic materials, with a protective function, in the most exposed points: underneath the doors, inside part of the mud guards, edges, etc.;
- use of ventilated box sections, coated with protective wax products, to avoid condensation and trapped water which could encourage the formation of internal rust.

Useful Advice to Keep the Bodywork in Good Condition

Paint

The paintwork does not only have an aesthetic function but also protects the underlying metal sheets. In the event of abrasions or deep scratches, we recommend to have the necessary touch-ups made immediately, to avoid any rust formation. Touch-ups do not feature particular difficulties, even on metallic finishes.

For all paint touch-ups, use only original products indicated on the plate applied on the lower left side of the hood.



Normal paint maintenance consists in washing, the frequency of which depends on the conditions of use and of the environment. For example, if driving the vehicle in areas where there is high atmospheric pollution or the roads are spread with anti-freeze salt, it is advisable to wash the vehicle more frequently.



ENVIRONMENTAL!
Detergents pollute water. Therefore the vehicle should be washed in areas equipped for the collection and purification of the fluids used for washing.

NOTE:

The use of alcohol-based products for cleaning the metal surfaces in the engine compartment and/or the boot may deteriorate the protective paint. It is recommended to use water-based products and neutral surfactants.

Car Wash

For correct washing:

- wet the bodywork with a low pressure water jet;
- pass a sponge with a light detergent solution over the bodywork, frequently rinsing the sponge;
- rinse well with water and dry with an air jet or chamois leather.

When drying, take particular care with the parts that are less visible, such as the door, liftgate and lid bays, headlight edges, in which water can be trapped more easily.

You are recommended not to take the vehicle immediately into an enclosed environment, but leave it in the open air so as to allow the water to evaporate.

Do not wash the vehicle after it has been left in the sun or when the hood is hot: the paint gloss could be affected.



External plastic parts must be cleaned with the same procedure followed for the normal washing of the vehicle. Avoid, as far as possible, parking the vehicle under trees; the resinous substances that very often drop from the trees give the paint a dull appearance and increase the possibility of originating corrosive processes.

It is important that the drain holes in the lower sides of the doors, rocker panels, and trunk bottom be kept clear and open.



CAUTION!

- Bird droppings must be washed off immediately and thoroughly, since their acidity is particularly corrosive.
- To provide better protection for the paint, polish the vehicle at intervals with a suitable product leaving a protective film on the paint.
- If the vehicle is washed using high-pressure water jets or cleaners, it is important that the nozzle of the jet be kept at a distance of at least 40 cm (16 in) from the bodywork to avoid damaging it.

Glass Surfaces

All glass surfaces should be cleaned on a regular basis with any commercial household-type glass cleaner.

Never use an abrasive type cleaner.

Use caution when cleaning the inside rear window on the liftgate equipped with electric defrosters. Do not use scrapers or other sharp instrument that may scratch the elements.

When cleaning the rear view mirror, spray cleaner on the towel or rag that you are using. Do not spray cleaner directly on the mirror.

Labels can be peeled off after soaking with warm water.

When cleaning is performed, keep all metal objects at a safe distance from the window.

Cleaning Headlights

Your vehicle has plastic headlights that are lighter and less susceptible to stone breakage than glass headlights. Plastic is not as scratch-resistant as glass and therefore different lens cleaning procedures must be followed. To minimize the possibility of scratching the lenses and reducing light output, avoid wiping with a dry cloth. To remove road dirt, wash with a mild soap solution followed by rinsing.

Do not use abrasive cleaning components, solvents, steel wool or other aggressive material to clean the lenses.

Mouldings and Aluminium Trim

- For cleaning mouldings and aluminium trim, avoid the use of acidic or alkaline cleaning agents that can destroy the protecting surface treatment.
- After washing aluminium trim with warm water, apply the cleaning agent with a clean tissue or a soft sponge on the surface. Do not use any other equipment such as brushes, steel wool, abrasives or any other equipment for cleaning.
- After cleaning, please rinse the aluminium trim with a lot of clear water.
- While cleaning in the car wash please make sure that the mouldings and aluminium trim only gets contact with soft brushes or textiles.

Engine Compartment

At the end of each winter season, carefully wash the engine compartment, remembering to avoid directing the jet of water for too long on the electric parts.



To perform this operation, you must contact the **Service Network**.

“Car Wash” Mode (if foreseen)

To move the vehicle in tunnel washers, or generally move with engine off, you can use the following modes.

- Vehicle must be on level ground, stationary or moving up to 8 km/h (5 mph).
- If enabled, disable the automatic engagement function of electric parking brake (see “Parking Brake” in section “Driving”).
- Shift the gearshift lever to N (Neutral).
- The brake pedal can be pressed or not pressed.
- Turn the engine off by pressing the **START/STOP** button for 5 seconds.

Through these steps, the driver's door must be closed. This condition will persist for about 25 minutes, the shift lever will switch to P (Park) once time has expired.

In case of low-battery voltage the shift lever can be placed in P (Park) before this time has expired.

NOTE:

It is also appropriate to disable the “Passive Entry” function from the MTC+ system so that the “Pre-Short Drop” function will not be activated. This prevents water from entering in the passenger compartment during car washing.



WARNING!

- **Performed this procedure the vehicle will stay in N (Neutral), rather without any brake. To avoid accidental movement, always check that the movement of the vehicle take place only on a flat surface.**
- **DO NOT USE this function to haul the vehicle because after a period of time the shift lever will be placed automatically in P (Park) position. If this occurs when the vehicle is moving the transmission can be damaged. To haul the vehicle use the emergency manual park release (see “Transmission Manual Release of P (Park) Position” in section “In an Emergency”).**

Pre-Short Drop Function

When in a car washing, if the driver keeps the RKE Transmitter in his/her pocket, or in any place outside the vehicle within 1 m (3.3 ft) distance, the front windows will perform a pre-short drop. This is a shorter drop compared to the normal short drop performed by the “Passive Entry” function when you grab the door handle to enter the vehicle.

In order to prevent water from entering the vehicle between the upper edge of the glass window and the door outline on the bodywork, while the car is being washed, it is advisable to disable the “Passive Entry” from the MTC+ System, for further information refer to chapter “MTC+ Settings” in section “Dashboard Instruments and controls”. When deactivating the “passive entry”, also the “Pre-Short Drop” function will be disabled.



Interior Maintenance and Care

Interior trim should be cleaned starting with a damp cloth. Do not use harsh cleaners.

The leather upholstery can be best preserved by regular cleaning with a damp soft cloth. Small particles of dirt can act as an abrasive and damage the leather upholstery and should be removed promptly with a damp cloth. Stubborn soils stains can be removed easily with a soft cloth and appropriate products. Avoid soaking the leather upholstery with any liquid. Please do not use polishes, oils, cleaning fluids, solvents, detergents, or ammonia-based cleaners to clean your leather upholstery.

Application of a leather conditioner is not required to maintain the original condition.

Check at regular intervals that there is no water trapped under the mats (due to drips off shoes, umbrellas etc.) which may cause the metal parts to oxidize.



CAUTION!

Do not use alcohol, petrol or solvents to clean the instrument cluster's transparent dome, the MTC+ display, the analog clock and the leather upholstery. We recommended the use of "Car Care" products approved by Maserati for the maintenance and care of the interior.

Leather Upholstery Treatment

Have the leather upholstery only treated, as provided in the Scheduled Service Plan, by the **Service Network** which has the required specific products.

Parts in Premium Quality Wood

Remove any dirt with a buckskin leather or damp cloth.

NOTE:

The Maserati Service Network can provide you with any information about the Maserati approved "Car Care" products, available in the "Genuine Accessories" range.

Vehicle Stored for Long Periods

If the vehicle is going to be stored for long periods of time, follow the below precautions:

- Wash and dry the vehicle thoroughly.
- Store the vehicle on a level surface in a covered, dry and, if possible, ventilated area.
- Select P (Park) and turn off the engine.
- Disconnect the battery (refer "Maintenance-Free Battery" in this section) or connect a battery charger (refer to paragraph "Maintaining Battery Load" in this section).
- Check the battery charge status. During parking, this check must be carried out every three weeks. Recharge the battery if the open circuit voltage is lower than 12.2 V.
- Check that the parking brake is NOT engaged.
- Do not empty the engine cooling system.
- Clean and protect the painted parts applying protective wax.



- Clean and protect polished metal parts with special products available on the market.
- Talc the wiper blades and raise them from the windshield and rear windows.
- Cover the vehicle with a long cloth in breathable fabric (available from the **Maserati Service Network**). Do not use thick plastic sheets, which do not allow the humidity on the vehicle surface to evaporate.
- Inflate the tires up to a pressure which must be 1 bar (14.5 psi) higher than the normally prescribed one, and check it at regular intervals.

NOTE:

The **Maserati Service Network** can provide you with any information about the available "Indoor and Outdoor Car Covers", available in the "Genuine Accessories" range.



WARNING!

The tire pressure must be brought back to the prescribed value before reusing the vehicle (see "Tire Inflation Pressure" in section "Features and Specifications").

Restarting the Vehicle

Before restarting the vehicle after a long period of inactivity, we recommend that you carry out the following operations.

- Check the tires for pressure and for any damages, cuts or cracks. If this is the case, have them replaced.
- Do not dry-rub the external surface of the vehicle: use a damp cloth.
- Visually inspect if there are any fluid leaks (oil, brake and clutch fluid, engine coolant etc.).
- Have the engine oil and filter replaced.
- Check the fluid levels in the brake system, as well as the engine coolant level.
- Check the air filters and have them replaced if necessary.
- Reconnect the battery after checking the charge status (refer to "Maintenance-Free Battery" in this section) and perform the initialising procedure if applicable.
- With the gearshift in N (Neutral), let the engine idle for several minutes. In this way, the pneumatic suspension system will be able to reach the operating pressure and lift the car to

the Entry/Exit height (for further details, see "Drive Modes" in section "Driving").




WARNING!

The engine idle must be performed outdoors. Exhaust gases contain carbon monoxide which is strongly toxic and potentially lethal.



Battery Statement

Battery Statement Status of Charge

To avoid problems with ignition and/or the electrical system in general when you are driving, the battery charge status is constantly maintained and guaranteed by the vehicle's recharge circuit; the main component of which is the alternator. This circuit is only able to supply voltage to the battery when the vehicle is travelling. The warning light  on the instrument cluster, will indicate any malfunctions in the recharge circuit or an insufficient battery charge status (example in figure).



The vehicle contains advanced electronic systems, such as, for example, the alarm system and various electronic control modules, which

consume power even when the ignition switch is in the **OFF** position and the vehicle is not being used. Therefore, it is fundamental that the battery is properly charged to ensure that the engine starts properly and that all the electrical/electronic systems in the vehicle work efficiently.

Maintaining Battery Charge

If you perform short daily trips (approximately 16 km/10 miles), which correspond to an annual total of 6000 km/4000 miles, or when the vehicle is not going to be used for one week or more, Maserati recommends connecting the vehicle to a battery charger, to save you the trouble of having to recharge the battery. The battery charger will keep the battery charged properly and at the correct voltage levels required by the systems and devices in the vehicle.

Before using the battery charger, carefully follow the instructions provided.

If you do not use a battery charger to prevent the battery from going flat when you are not going to use the vehicle for long periods of time, you need to check and recharge the battery at least once every three weeks. Make this check if you perform

short daily trips (approximately 16 km/10 mi) which correspond to an annual total of 6000 km/4000 miles. Please note that allowing the battery to go flat repeatedly can cause premature wear on the internal cells and greatly reduce their life, leading to problems with the ignition system and other electrical/electronic systems. The **Service Network** is available to advise you on how to recharge your battery correctly and give you useful information on battery care and maintenance.

NOTE:

*The **Maserati Service Network** can provide you with any information about the Maserati approved "Battery Charger and Conditioner", available in the "Genuine Accessories" range.*



WARNING!

The process of charging or recharging the battery produces hydrogen, a dangerous gas that can explode and cause serious injuries. When charging or recharging the battery, follow the recommended precautions at all times:

(Continued)



(Continued)

- always charge or recharge the battery in a well-ventilated environment;
- never charge or recharge a battery that has frozen: it can explode due to hydrogen trapped inside the ice crystals;
- ensure that any sparks or open flames are nowhere near the battery while it is charging;
- before using a charger to charge or maintain the battery charge status, carefully follow the instructions provided to ensure the charger is connected to the battery safely and correctly.



8 – Features and Specifications

Refillings	382
Fuel Consumption	386
Exhaust Emissions	388
Technical Data	389
Tire Inflation Pressure	398



Refillings

NOTE:

Maserati reserves the right to change or revise specifications without prior notification.




CAUTION!

To guarantee vehicle's integrity and maintain performance level Maserati recommends to use Maserati genuine products.

Refillings and Recommended Products – Gasoline Engines

Parts to be refilled	Quantity	Product specifications
Fuel tank	80 litres/17.5 UK gal (including 16 litres/3.5 UK gal of reserve)	Premium unleaded fuel with no less than 95 RON/85 MON (91 CLC or AKI).
Engine	8,3 litres/1.82 UK gal (max) (MIN – MAX difference: 1 litre/0.22 UK gal)	Synthetic multigrade lubricants SAE 5W/40 that meet API SL/CF and ACEA A3, B3, B4 specifications. Recommended oil: SHELL Helix Ultra 5W-40.
Windshield and headlight washer fluid tank	5 litres/1.1 UK gal	Mix of water and detergent fluid, in the proportions indicated on the product package. If the temperature is below -20°C (-4°F), use pure detergent fluid. Detergent fluid: Mix of CUNA NC 956-II surfactants and alcohols. Recommended fluid: WUERTH Windshield Washer Fluid with antifreeze or AREXONS DP1.
Windshield washer fluid tank	3,5 litres/0.77 UK gal	




Parts to be refilled	Quantity	Product specifications
Engine cooling circuit	9,2 litres/2.03 UK gal (for dual-zone air conditioning system) 10 litres/2.2 UK gal (for four-zone air conditioning system)	Mixture of water and coolant, proportionally 50/50%. Coolant: protective, antifreeze action and ethylene glycol-based with organic inhibitors compatible with regulations: <ul style="list-style-type: none"> • ASTM D 3306, ASTM D 2570 • ASTM D 4340, ASTM D 2809 • SAE J 1034 • CUNA NC 956/16. Recommended fluid: PETRONAS Paraflu UP or SHELL Long Life OAT.
Hydraulic power steering and automatic transmission cooling circuit	2,5 litres/0.55 UK gal	Recommended fluid: PETRONAS Paraflu UP or SHELL Long Life OAT.
Hydraulic power steering	1,35 litres/0.29 UK gal +/-4%	Oil: ATF Type A - MB 236.2. Recommended oil: SHELL Spirax S1 ATF TASA.
(*) Automatic transmission	7,6 litres/1.67 UK gal	First equipment oil: SHELL ATF L- 12108 or ZF Lifeguard 8.
(*) Differential	0,9 litres/0.19 UK gal	Synthetic Axle Lubricant SAE 75W-85 – FE Hypoid Gear Lubricant.
(*) Front differential	0,45 litres/0.10 UK gal	First equipment oil: SHELL TF 0951B.
(*) Transfer case	0,62 litres/0.14 UK gal	First equipment oil: SHELL TF 0870.
Braking system	0,8 litres/0.17 UK gal +/-4%	Synthetic fluid: FMVSS 116 DOT 4, ISO 4925 Class 4, ENSAYOS INTA-UNE 26-109-88, SAE J1703, SAE J1704, CUNA NC 956-01. Recommended fluid: PETRONAS Tutela TOP 4/S.
 CAUTION! For each oil refilling and/or replacement, please contact the Service Network .		
Air conditioning system	dual-zone: 620 g +/-20 g 1.366 lb +/-0.044 lb four-zone: 760 g +/-20 g 1.675 lb +/-0.044 lb	Coolant: r1234yf.
(*) No change and/or topping up expected in scheduled maintenance.		



Refillings and Recommended Products – Diesel Engine

Parts to be refilled	Quantity	Product specifications
Fuel tank	80 litres/17.5 UK gal (including 16 litres/3.5 UK gal of reserve)	Premium diesel fuel that meets the requirements of EN590. Biodiesel blends that meet EN590 may also be used.
Tank of reducing agent AdBlue®	20,5 litres/4.5 UK gal	Solution of pure urea (32.5%) in de-mineralised water (67.5%) meeting DIN 70070 and ISO 22241 specifications, obtained by synthesis. Recommended fluid: AdBlue®.
Engine	8,8 litres/1.93 UK gal (max) (MIN – MAX difference: 1 litre/0.22 UK gal)	Synthetic multigrade lubricants SAE 5W/40 that meet API SL/CF and ACEA A3, B3, B4 specifications. Recommended oil: SHELL Helix Ultra 5W-40.
Windshield and headlight washer fluid tank	5 litres/1.1 UK gal	Mix of water and detergent fluid, in the proportions indicated on the product package. If the temperature is below –20°C (–4°F), use pure detergent fluid.
Windshield washer fluid tank	3,5 litres/0.77 UK gal	Detergent fluid: Mix of CUNA NC 956-II surfactants and alcohols. Recommended fluid: WUERTH Windshield Washer Fluid with antifreeze or AREXONS DP1.
Engine cooling circuit	13 litres/2.86 UK gal (for dual-zone air conditioning system) 13,8 litres/3.03 UK gal (for four-zone air conditioning system)	Mixture of water and coolant, proportionally 50/50%. Coolant: protective, antifreeze action and ethylene glycol-based with organic inhibitors compatible with regulations: <ul style="list-style-type: none"> • ASTM D 3306, ASTM D 2570 • ASTM D 4340, ASTM D 2809 • SAE J 1034 • CUNA NC 956/16. Recommended fluid: PETRONAS Paraflu UP or SHELL Long Life OAT.



Parts to be refilled	Quantity	Product specifications
Hydraulic power steering	1,35 litres/0.29 UK gal +/-4%	Oil: ATF Type A - MB 236.2. Recommended oil: SHELL Spirax S1 ATF TASA.
(*) Automatic transmission	7,7 litres/1.69 UK gal	First equipment oil: SHELL ATF L- 12108 or ZF Lifeguard 8.
(*) Differential	0,9 litres/0.19 UK gal	Synthetic Axle Lubricant SAE 75W-85 – FE Hypoid Gear Lubricant.
(*) Front differential	0,45 litres/0.10 UK gal	First equipment oil: SHELL TF 0951B.
(*) Transfer case	0,62 litres/0.14 UK gal	First equipment oil: SHELL TF 0870.
Braking system	0,8 litres/0.17 UK gal +/-4%	Synthetic fluid: FMVSS 116 DOT 4, ISO 4925 Class 4, ENSAYOS INTA-UNE 26-109-88, SAE J1703, SAE J1704, CUNA NC 956-01. Recommended fluid: PETRONAS Tutela TOP 4/S.
 CAUTION! For each oil refilling and/or replacement, please contact the Service Network .		
Air conditioning system	dual-zone: 620 g +/-20 g 1.366 lb +/-0.044 lb four-zone: 760 g +/-20 g 1.675 lb +/-0.044 lb	Coolant: r1234yf.
(*) No change and/or topping up expected in scheduled maintenance.		



Fuel Consumption

NOTE:

The technical data, values and specifications in this Owner's Manual are provided as guidance only. The vehicle specific data can deviate from the information provided, for example, as a result of optional or special equipment ordered with the vehicle, vehicle loads, and country specific measurement methods.

The test procedures adopted for fuel consumption measuring are the following.

- **Urban cycle:** this test begins with a cold start, followed by a simulation of an urban route.
- **Extra-urban cycle:** this test involves frequent accelerations in all gears, simulating use of the vehicle on routes outside urban areas; the speed varies between 0 and 120 km/h (75 mph).
- **Combined cycle:** this is calculated by considering a route consisting of about 37% urban cycle and 63% extra-urban cycle.



CAUTION!

The type of route, traffic and weather conditions, driving style, general condition of the vehicle, equipment/accessories in the vehicle, use of the air conditioning system, vehicle load and other items or situations which may negatively affect the vehicle aerodynamics or wind resistance lead to consumption ratios differing from the indicated ones.

Fuel Consumption Data - Gasoline Models

The fuel consumption values shown (litres per 100 km) were established based on homologation tests prescribed by following European Directives: Directives EC 715/2007 and EC 692/2008.

	Levante S	Levante
Urban cycle	15 l/100 km	14.8 l/100 km
Extra urban cycle	8.5 l/100 km	8.3 l/100 km
Combined cycle	10.9 l/100 km	10.7 l/100 km



Fuel Consumption Data - Diesel Model

The fuel consumption values shown (litres per 100 km) were established based on homologation tests prescribed by following European Directives: Directives EC 715/2007 and EC 692/2008.

Urban cycle	8.2 l/100 km
Extra urban cycle	6.6 l/100 km
Combined cycle	7.2 l/100 km



Exhaust Emissions

NOTE:

The technical data, values and specifications in this Owner's Manual are provided as guidance only. The vehicle specific data can deviate from the information provided, for example, as a result of optional or special equipment ordered with the vehicle, vehicle loads, and country specific measurement methods.

Exhaust Emission Data - Gasoline Models

The CO₂ exhaust emission ratings shown (grams per km) were established based on homologation tests prescribed by following European Directives: Directives EC 715/2007 and EC 692/2008.

	Levante S	Levante
Urban cycle	348 g/km	343 g/km
Extra urban cycle	199 g/km	194 g/km
Combined cycle	253 g/km	249 g/km

Exhaust Emission Data - Diesel Model

The CO₂ exhaust emission ratings shown (grams per km) were established based on homologation tests prescribed by following European Directives: Directives EC 715/2007 and EC 692/2008.

Urban cycle	216 g/km
Extra urban cycle	174 g/km
Combined cycle	189 g/km



Technical Data

NOTE:

The technical data, values and specifications in this Owner's Manual are provided as guidance only. The vehicle specific data can vary from the information provided, for example, as a result of optional or special equipment ordered with the vehicle, vehicle loads, and country specific measurement methods.

Engine Data - Gasoline Models

Data	Levante S	Levante
Cylinder number and position	6 - 60° V	6 - 60° V
Number of valves per cylinder	4	4
Bore x stroke	86.5 x 84.5 mm	86.5 x 84.5 mm
Total displacement	2979 cu.cm	2979 cu.cm
Compression ratio	9.7 : 1	9.7 : 1
Maximum power output (EC)	316 kW – 430 CV (*)	257 kW – 350 CV
- corresponding RPM	5750 g/min	5750 g/min
Peak and overboost torque (EC)	580 Nm – 59 kgm	500 Nm – 51 kgm
- corresponding RPM	2000 – 4750 g/min	1750 – 4750 g/min
(*) Values obtained in SPORT mode with 98 RON unleaded gasoline.		

Engine Properties

Timing	The timing system uses two overhead camshafts with timing variator.
Timing system control	Timing chain.
Supply	Over-supplied with turbocompressor and related intercooler for each bank.
Injection – Ignition	High-pressure (200 bar) direct fuel injection system. Static ignition with digital electronic control system included and controlled by a single microprocessor ECU.



Engine Data - Diesel Model

Data	Levante Diesel
Cylinder number and position	6 - 60° V
Number of valves per cylinder	4
Bore x stroke	83 x 92 mm
Total displacement	2987 cu.cm
Compression ratio	16.5 : 1
Maximum power output (EC) - corresponding RPM	202 kW – 275 CV (**) 4000 g/min
Peak torque (EC) - corresponding RPM	600 Nm – 61.2 kgm 2000 – 2600 g/min
(**) 184 kW – 250 CV for Italian market only.	

Engine Properties

Timing	The timing system uses two overhead camshafts.
Timing system control	Timing chain.
Supply	Over-supplied with turbocompressor and related intercooler for each bank.
Injection – Ignition	Common-Rail direct-injection with reduced dwell time-injectors. It features sequential multiple injections with pilot and post injection to deliver highly responsive performance as well as clean raw emissions, assisted by a sophisticated exhaust gas recirculation system. The max injection pressure of the common rail system is 2000 bar.



Brakes

Self-ventilating disc brakes on the four wheels. The Electric Parking Brake (EPB) acts on the rear wheels.

Brakes Discs Diameter - Gasoline Models

	Levante S	Levante
Front disc diameter	Drilled disc: 380 mm (15 in)	345 mm (13.6 in)
Rear disc diameter	Drilled disc: 330 mm (13 in)	330 mm (13 in)

Brakes Discs Diameter - Diesel Model

Front disc diameter	345 mm (13.6 in)
Rear disc diameter	330 mm (13 in)

Transmission

Automatic transmission with 8 gears, torque converter, lock-up clutch and anti-slip function.

Sequential and traditional control type.

TRANSAXLE-type transmission.

Traction system equipped with rear self-locking differential.

Suspension

Front suspensions with double wishbone independent wheels.

Multilink system rear suspensions on independent wheels.

The air suspension system features air spring units at both axles and a closed air supply unit.

Steering

Hydraulic speed-sensitive steering with cooling exchanger system.

Steering diameter = 12,1 m (13.2 yd).

No. of steering wheel turns = 1.41 (to the left and right).



Wheels

NOTE:

- Maserati recommends Maserati Genuine Tires marked with “MGT” logo specifically designed for its models.
- In order to maintain high performance and safety level, Maserati recommends to use tires equivalent to the original size.
- Optionally tires may have “ZR” in the size description combined with speed index (e.g. 265/45 ZR20 104Y).

Only for front and rear mounting with the same tire:

- Front and rear rims are different and cannot be swapped.
- Both front and rear tires can be swapped.



WARNING!

- The maximum speed reachable with the tires is indicated by the tire manufacturer. Always comply with the regulations in force in the Country you are driving in.
- Never exceed the maximum speed indicated for the tires: failure to respect the max. speed may damage these tires.
Danger: risk of accident!

Standard Wheel Dimension - Gasoline Models

Allowed tires size	Levante S	Levante
Light alloy rims	19" x 8,5J (front) 19" x 10,5J (rear)	18" x 8J (front and rear)
- Front tires	265/50 R19 110Y	255/60 R18 108W
- Rear tires	295/45 R19 113Y (1)	255/60 R18 108W (3)
- Front all season tires (M+S)	265/50 R19 110W	255/60 R18 108W
- Rear all season tires (M+S)	295/45 R19 113W (1)	255/60 R18 108W (3)
Light alloy spare rim	18" x 6J	18" x 6J



- Spare tire	195/75 R18	195/75 R18
(1) It can equipped only with special chain with front anchorage (2) It can be equipped only with special chain with maximum 12 mm (0.47 in) link thickness (3) Snow chains CANNOT BE USED		

Optional Wheel Dimension - Gasoline Models

Allowed tires size	Levante S	Levante
Light alloy rims	-	19" x 8,5J (front and rear)
- Front tires	-	265/50 R19 110Y
- Rear tires	-	265/50 R19 110Y (2)
- Front all season tires (M+S)	-	265/50 R19 110W
- Rear all season tires (M+S)	-	265/50 R19 110W (2)
Light alloy rims	20" x 9J (front) 20" x 10,5J (rear)	20" x 9J (front and rear)
- Front tires	265/45 R20 104Y	265/45 R20 104Y
- Rear tires	295/40 R20 106Y (3)	265/45 R20 104Y (3)
- Front all season tires (M+S)	265/45 R20 104W	265/45 R20 104W
- Rear all season tires (M+S)	295/40 R20 106W (3)	265/45 R20 104W (3)
Light alloy rims	21" x 9J (front) 21" x 10,5J (rear)	21" x 9J (front and rear)
- Front tires	265/40 R21 101Y	265/40 R21 101Y
- Rear tires	295/35 R21 103Y (3)	265/40 R21 101Y (3)
(1) It can equipped only with special chain with front anchorage (2) It can be equipped only with special chain with maximum 12 mm (0.47 in) link thickness (3) Snow chains CANNOT BE USED		



Standard Wheel Dimension - Diesel Model

Allowed tires size	Levante Diesel
Light alloy rims	18" x 8J (front and rear)
- Front tires	255/60 R18 108W
- Rear tires	255/60 R18 108W (3)
- Front all season tires (M+S)	255/60 R18 108W
- Rear all season tires (M+S)	255/60 R18 108W (3)
Light alloy spare rim	18" x 6J
- Spare tire	195/75 R18
(1) It can equipped only with special chain with front anchorage (2) It can be equipped only with special chain with maximum 12 mm (0.47 in) link thickness (3) Snow chains CANNOT BE USED	

Optional Wheel Dimension - Diesel Model

Allowed tires size	Levante Diesel
Light alloy rims	19" x 8,5J (front and rear)
- Front tires	265/50 R19 110Y
- Rear tires	265/50 R19 110Y (2)
- Front all season tires (M+S)	265/50 R19 110W
- Rear all season tires (M+S)	265/50 R19 110W (2)
Light alloy rims	20" x 9J (front and rear)
- Front tires	265/45 R20 104Y
- Rear tires	265/45 R20 104Y (3)
- Front all season tires (M+S)	265/45 R20 104W
- Rear all season tires (M+S)	265/45 R20 104W (3)
Light alloy rims	21" x 9J (front and rear)



Allowed tires size	Levante Diesel
- Front tires	265/40 R21 101Y
- Rear tires	265/40 R21 101Y (3)
(1) It can be equipped only with special chain with front anchorage (2) It can be equipped only with special chain with maximum 12 mm (0.47 in) link thickness (3) Snow chains CANNOT BE USED	

Performance

Performance Data - Gasoline Models

NOTE:

The specifications described can change without prior notification.

	Levante S	Levante
Maximum speed	(*) 264 km/h (164 mph)	251 km/h (156 mph)
Accelerations from 0 to 100 km/h	5.2 seconds	6.0 seconds
(*) Values obtained in SPORT mode with 98 RON unleaded gasoline.		

Performance Data - Diesel Model

NOTE:

The specifications described can change without prior notification.

Maximum speed	230 km/h (143 mph)
	(**) 225 km/h (140 mph)
Accelerations from 0 to 100 km/h	6.9 seconds
	(**) 7.3 seconds
(**) For Italian market only.	



Weights

Weight Data - Gasoline Models

NOTE:

The specifications described can change without prior notification.

	Levante S	Levante
Unladen vehicle weight (with tanks filled, tools and accessories)	2109 kg / 4650 lb (*)	2109 kg / 4650 lb (*)
Approved Gross Vehicle Weight Rating (GVWR)	2780 kg / 6129 lb (1285 kg / 2833 lb front axle – 1495 kg / 3296 lb rear axle)	2780 kg / 6129 lb (1285 kg / 2833 lb front axle – 1495 kg / 3296 lb rear axle)
Maximum load on the roof rails	80 kg (176 lb)	
(*) Base configuration without optionals.		

Weight Data - Diesel Models

NOTE:

The specifications described can change without prior notification.

Unladen vehicle weight (with tanks filled, tools and accessories)	2205 kg / 4861 lb (*)
Approved Gross Vehicle Weight Rating (GVWR)	2900 kg / 6393 lb (1350 kg / 2976 lb front axle – 1550 kg / 3417 lb rear axle)
Maximum load on the roof rails	80 kg (176 lb)
(*) Base configuration without optionals.	



Trailer Towing Weights

NOTE:

- The specifications described can change without prior notification.
- Follow trailer manufacturer recommendations, never exceed trailer tow weights provided.

Towable loads: trailer with brakes	2700 kg (5952 lb)
Towable loads: trailer without brakes	750 kg (1653 lb)
Maximum load on tow hitch (trailer with brakes)	108 kg (238 lb)

Dimensions

Wheel base	3004 mm (118.2 in)
Overall length	5003 mm (197 in)
Overall width without mirrors	1968 mm (77.5 in)
Overall width with mirrors	2158 mm (85 in)
Front track	1624 mm (63.9 in)
Rear track	1676 mm (65.9 in)
Front overhang	966 mm (38 in)
Rear overhang	1033 mm (40.6 in)
Overall height (*)	1679 mm (66.1 in)
Ground clearance (*)	205 mm (8 in)
Boot compartment volume	422 l (93 UK gal)
Cargo area length	1040 mm (41 in)
Cargo area length with rear seatbacks folded down	2027-1803 mm (79.8-71 in)
Cargo area width	1186-1002 mm (46.7-39.5 in)
(*) In "Normal" ride height and with standard rims and tires.	



Tire Inflation Pressure

Cold tire inflation pressure value under the following loading conditions listed in the table below:

- PLC (Partial Loading Condition): considering 2 passengers + luggage.
- FLC (Full Loading Condition): considering 4 or 5 passengers + luggage.
- CC (Comfort Condition) : not more than 130 km/h (80 mph).

Wheel		Pressure					
Tire Type	Rim	PLC		CC		FLC/High speed	
		Front	Rear	Front	Rear	Front	Rear
Summer	18" - 19" - 20"	230 kPa - 2,3 bar - 33 psi	250 kPa - 2,5 bar - 36 psi	200 kPa - 2,0 bar - 29 psi	220 kPa - 2,2 bar - 32 psi	250 kPa - 2,5 bar - 36 psi	270 kPa - 2,7 bar - 39 psi
	21"					270 kPa - 2,7 bar - 39 psi	310 kPa - 3,1 bar - 45 psi
All Season	18"					250 kPa - 2,5 bar - 36 psi	290 kPa - 2,9 bar - 42 psi
	19"					250 kPa - 2,5 bar - 36 psi	(265/50) 290 kPa - 2,9 bar - 42 psi
						250 kPa - 2,5 bar - 36 psi	(295/45) 270 kPa - 2,7 bar - 39 psi
	20"					270 kPa - 2,7 bar - 39 psi	(265/45) 310 kPa - 3,1 bar - 45 psi
270 kPa - 2,7 bar - 39 psi		(295/40) 290 kPa - 2,9 bar - 42 psi					

**NOTE:**

- For more information about the pressure check methods, see “Tires – General Information” in section “Driving”.
- On vehicles of some markets the tire inflation pressure values are also indicated on the driver's side rear door pillar.

**WARNING!**

- Improperly inflated tires are dangerous and can cause collisions.
- Under-inflation increases tire flexing and can result in tire overheating and failure.
- Over-inflation reduces a tire's ability to cushion shock. Objects on the road and potholes can cause damage that result in tire failure.
- Over-inflated or under-inflated tires can affect vehicle handling and can fail suddenly, resulting in loss of vehicle control.
- Unequal tire pressures can cause steering problems. You could lose control of your vehicle.
- Unequal tire pressures from one side of the vehicle to the other can cause the vehicle to drift to the right or left.
- Always drive with each tire inflated to the recommended cold tire inflation pressure.





9 – Index





Abbreviations	8	Supplemental Side Air Bag Inflatable Curtain (SABIC)61	Maintaining Battery Charge379
Accident, in the event of320	Air Conditioning (A/C) System206	Maintenance - Free Battery359
Adaptive Cruise Control (ACC)269	A/C Distribution147	To Disconnect the Battery359
Activation/Deactivation272	A/C System Maintenance371	To Reconnect the Battery360
Display Warnings and Maintenance276	Dual-zone Climate Controls207	Blind Spot Alert - BSA300
Precautions while Driving with ACC277	Filter Replacement356	BSA System300
Setting the Following Distance274	Four-zone Climate Controls211	Modes of Operation of BSA and RCP303
Setting the Speed273	Alarm, Vehicle Security21	RCP - Rear Cross Path302
AdBlue, adding (Diesel only)304	ALR (Automatic Locking Retractor)54	Bluetooth, Customer settings201
AdBlue Injection System Messages178	Anti-Lock Brake System (ABS) and Electronic Brake-force Distribution (EBD)256	Bodywork Maintenance and Care373
Low AdBlue Indicator175	ATC (Automatic Temperature Control)211	Pre-Short Drop Function376
Air bag57	Audio Controls187	Protection from Atmospheric Agents373
Advanced Front Air bag Properties58	Audio Controls on Central Console187	Useful Advice to Keep the Bodywork in Good Condition374
Air bag Deployment Result64	Steering Wheel Audio Controls187	Brakes	
Air bag Deployment Sensors and Controls11	Audio, setting200	Brake and Stability Control System (ESC)255
Air bag System Components57	Audio System188	Brake Fluid Level Check351
Air bag System Maintenance64	Automatic Transmission Manual Release of Transmission334	Brake Overheating262
Air bag Warning Light88	AUX, USB and SD Memory Card Ports129	Brake System255
Front Air bag Inflator Units63	AWD, All-Wheel Drive229	Manual Release of Parking Brake328
Passenger Air bag Labels14	BAS (Brake Assist System)257	Parking Brake249
Passenger's Air bag Deactivated Indicator174	Battery359	Using the Brakes261
Passenger's Air bag Deactivation65	Battery Recharge361	Bulb Replacement369
Supplemental Restraint System (SRS)57	Battery Remote Posts Position331	Cargo Area133
Supplemental Seat-mounted Side Air Bags (SAB)61	Jump Start Procedure330	Accessories Compartment136



- Loading with Rear Seatbacks
 - Folded Down 134
 - Luggage Fasteners and Retainers. 134
 - Ski and Snowboard Bag Compartment 135
 - Vehicle Load Carrying Capacity. . 133
- Child Restraint Systems
 - Installing an Isofix Universal Child Restraint System 72
 - Installing Child Restraint Systems using the Vehicle Seat Belt equipped with ALR. 71
 - Isofix Universal Child Restraint System 71
 - Maserati Recommended Child Restraint Systems for this Vehicle 75
 - Suitability of Passenger Seats for Isofix Child Restraint System Use 74
 - Suitability of Passenger Seats for Universal Child Restraint System Use 70
- Climate Control 207
- Clock, analog 193
- Console
 - Central Console Components. . . 93
 - Front Dome Console Components 94
 - Power Outlet Inside the Central Console. 127
- Cruise Control
 - Cruise Control Adaptive (ACC) . . 269
 - Electronic Cruise Control (CC) . . 264
- Cup Holders 128
 - Front Passengers Cup Holders. . . 128
 - Rear Passengers Cup Holders . . . 129
- Dashboard Compartment 203
- Dashboard Components 92
- Data, Technical 389
- Defroster 88
- Doors
 - Automatic Locking Doors 34
 - Child Protection Door Lock System 34
 - Doors Locking 32
 - Doors Manual Lock. 33
 - Front Doors Components 94
 - Lock/Unlok Door Flashlight 28
 - Power Doors Locking/Unlocking . . 33
 - Rear Doors Components 95
 - Unlock Driver Door/All Doors with Key fob 1st Press 27
 - Unlock the Doors, Fuel Filler Door and Liftgate 27
 - Unlock the Vehicle with Key Fob 27
- DPF System
 - DPF Filter Replacement 353
 - DPF System Messages 177
 - “Drive Away Inhibit” strategy . . . 254
- Drive Mode, controls 230
 - Setting Ride Height 242
- Setting the Drive Mode 231
- Driving Conditions 297
 - Before the Trip. 297
 - Driving at Night 298
 - Driving in Fog 299
 - Driving in the Mountains. 299
 - Driving in the Rain 298
 - Driving on Snow or Ice 299
 - Driving through Flooded Sections 300
 - Safe Driving. 298
- DRL (Daytime Running Light) 114
- Electronic Cruise Control. 264
- Emergency 5
 - Emergency Fuel Filler Door Release 297
 - Emergency Kit 321
 - First Aid Kit 321
 - Hazard Warning Lights 122
 - In the Event of an Accident . . . 320
 - Jump Starting 330
 - Tool Kit. 318
 - Use the Vehicle Tow Hook 335
- Emissions, Exhaust 388
- Engine
 - Engine Air Filter Replacement . . 356
 - Engine Coolant Level Check . . . 349
 - Engine Oil Level Check 353
 - Engine Overheating 322
 - Engine Start Failure 219
 - Hood 49
 - Normal Starting of the Engine . . 218



Use of the Engine262

Entry/Exit, lights on24

EPB (Electric Parking Brake)249

ESC (Electronic Stability Control) . . .255

Exhaust Gas After-treatment345

Filters

 A/C System Air Filter Replacement356

 Engine Air Filter Replacement . . .356

First aid kit321

Forward Collision Warning (FCW) .279

Fuel

 Emergency Fuel Filler Door Release297

 Fuel Consumption386

 Fuel Filter Service353

 Fuel Requirements291

 Low Fuel Indicator173

Fuses362

 Fuses Position364

 Fuses Replacement362

Glove Box Lock Feature204

 Handholds and Cloth Hooks . . .131

Hazard Warning Flashers320

Head Restraints96

Hill Descend Control (HDC)258

HomeLink143

 Security146

 Troubleshooting Tips146

 Using HomeLink146

Hood

 Liftgate and Hood Ajar Indicators173

 Open and Close the Hood49

HSA (Hill Start Assist)257

Identification Labels14

Illuminated Entry/Exit24

Immobilizer (Sentry Key)20

Indicator Lights/Warning Lights

 Air Bag Warning Light88

 TFT Display: Menus and Settings157

 TFT Display: Warning/Indicator Lights of Set Modes/Functions . .170

 Warning and Indicator Lights on Analog Instrument153

Infotelematic System180

 Main Menu Bar on MTC+ Display182

 Manual Controls and Devices . .181

 Personalized the Main Menu Bar183

Instrument Cluster152

Interior Components92

Interior Maintenance and Care . . .377

Interiors Features126

iPad Holder132

iPod Connection130

Isofix

 Installing an Isofix Universal Child Restraint System72

 Isofix Universal Child Restraint System71

 Vehicle Isofix Positions Chart on Passenger Seats74

Jump Start Procedure332

Key Fob19

 Key Fob Battery Replacement . . .28

 Preventing Inadvertent Locking of key fob RKE Transmitter Inside the Vehicle36

 Replacement21

 Requiring and setting Additional Key Fobs28

 Unlock the Vehicle with Key Fob .27

Keyless Ignition Device18

Keys18

Lane Departure Warning (LDW) . .267

Level Checks348

 Brake Fluid Level Check351

 Coolant and Hydraulic Steering System Fluid Level Check355

 Engine Coolant Level Check . . .349

 Engine Oil Level Check349

 Steering Fluid Level Check355

 Transmission Oil Check355

 Washer/Headlight Fluid, adding352

Liftgate

 Liftgate and Hood Ajar Indicators173



Liftgate Emergency Release	48	Bodywork Maintenance and Care	373	Lights	196
Open and Close the Liftgate	43	Interior Maintenance and Care	377	Phone/Bluetooth	201
Power Liftgate/Hands free	44	Maintenance Procedures	346	Pneumatic Suspension	199
Unlatch the Liftgate	28	Periodic Maintenance	344	Radio Setup	202
Lights	111	Scheduled Maintenance Service	338	Restore Settings	202
Adaptive Bi-Xenon Headlights	114	Scheduled Service Plan	339	Safety and Driving Assistance	194
Automatic Headlights	113	Sunroof Maintenance	143	Voice Commands	193
Automatic Headlights Leveling	120	Wheels Maintenance	372	MTC+ System (Maserati Touch Control Plus)	180
Bulb Replacement	369	Mesh Pockets	132	Occupant Restraint System	50
Cargo Lamps	122	Messages on Main Display Area	157	Off-road Drive	246
Dome Lights	120	MIL (Malfunction Indicator Light)	153	After Driving Off-road	249
DRL, Daytime Running Lights	114	Mirrors	108	Driving in Snow and Wet Grass	247
Fog Lights	116	Blind Spot Monitoring Warning Light	300	Driving Throught Water	246
Hazard Warning Lights	122	External Mirrors	108	Traction Downhill	248
Headlights On With Wipers	124	Folding Mirrors	110	On Board Diagnostics	263
Headlight Time Delay	113	Integrated External Rear View Mirror Lights	122	ORC (Occupant Restraint Controller)	61
High Beam and Flashing	118	Internal Rear View Mirror	110	Park Assist	78
Integrated External Rear View Mirror Lights	122	Mirrors Positioning	109	Enabling and Disabling Park Assist	81
Interior Lights	119	Rear View Mirrors	108	Parking	252
Light Switch	111	Tilt Mirrors in Reverse	109	Parking Brake	249
Multifunction Lever	117	MTC+ Settings - Customer Programmable Features	190	Emergency Release of Parking Brake	328
SmartBeam System	114	Auto-On Comfort & Remote Start	198	Passive Entry System	35
Turn Signals	117	Clear Personal Data	202	Pedals, adjustable	107
Loading the Vehicle		Clock & Date	193	Pets, transporting	77
Loading with Rear Seatbacks		Display	192	Phone and Voice Controls on Steering Wheel	214
Down	134	Doors & Locks	197	Phone Mode	215
Vehicle Load Carrying Capacity	133	Engine Off Options	199		
Main- and Submenu	158				
Maintenance	5				
A/C System Maintenance	371				
Air bag System Maintenance	64				



Voice Commands	216	Safety Tips	50	Rear Seat Folding Seatback	103
Phone/Bluetooth, Customer settings.	201	Scheduled Maintenance Service	338	Rear Seats	103
Power Outlets	126	Scheduled Service Plan	339	Rear Side Heated Seats	105
Power Outlet Inside the Boot	128	Scheduled Maintenance Indicator	338	Seat Adjustment.	96
Power Outlet Inside the Central Console	127	Seat Belt	50	Service	10
Power Outlet Inside the Cup Holder.	127	Automatic Locking Retractor (ALR) Mode	54	Siri Smart Personal Assistant	216
Rear Power Outlets	127	Enhanced Seat Belt Use Reminder System (SBR)	56	SmartBeam system	114
Power Sunshades on Rear Door Windows	41	Passenger Seat Belts	53	Smoking Kit.	131
Power Windows.	38	Seat Belt Reminder Light	157	Snow Chains	285
Rear Parking Camera	83	Seat Belts and Pregnant Women.	56	Spare parts service Genuine Parts	10
Reducing Agent, adding (Diesel only).	304	Seat Belts Pretensioners.	55	Scheduled Maintenance	10
Refillings.	382	Three-Point Seat Belts	50	Spare Parts Service	10
Refueling	293	Three-Point Seat Belts Height Adjustment	52	SRS (Supplemental Restraint System).	57
Fuel Filler Neck Access	293	Three-Point Seat Belts Untwisting Procedure	53	Start&Stop System	220
Remote Start System	30	Three-Point Seat Belts Use Instructions	51	Occupant Safety Function	222
Restarting the Vehicle.	378	Using the Seat Belt in Automatic Locking Retractor Mode (ALR)	54	Start&Stop Active Indicator	155
Restraint System	57	Seats	95	Start&Stop Disable Indicator.	174
Child Restraint Systems	67	Driver Memory Seat	100	Start&Stop Failure Warning Light.	174
RKE (Remote Keyless Entry) Transmitter	18	Easy Entry/Exit Seats	102	Start&Stop Function Disabling Indicator	223
Roll-Over Warning	12	Front Heated Seats	99	Start&Stop Menu	164
ROM (Roll-Over Mitigation).	258	Front Power/Manual Seats	97	Start&Stop System Failure	223
Roof Rails	140	Front Power Seats.	95	Start the Engine Engine Start Failure.	219
Safety Child Restraint Systems	67	Front Ventilated Seats	100	Engine Turn Off	220
Safety Net for Cargo Area	137	Power Lumbar Seats	96	Normal Starting of the Engine	218
		Rear Armrest	104	Steering Wheel	106
		Rear Head Restraints	103	Heated Steering Wheel	106
				Manual Adjustment	106



- Phone and Voice Controls on Steering Wheel214
- Power Adjustment106
- Stuck Vehicle, freeing.329
- Sunroof
 - Close and Open Sunroof with RKE Transmitter and Ignition Off . . .142
 - Closing Sunroof141
 - Initialization Procedure.142
 - Pinch Protect Feature142
 - Power Sunroof with Sunshade . .141
 - Slide Opening Sunroof141
 - Sunroof Maintenance143
 - Venting Sunroof.142
- Sunshades41
- Sun Visors.130
- Surround View Camera System . . .85
- Symbols11
 - Danger Symbols.11
 - Symbols of Prohibitions and Compulsory Measures.11
 - Warning Symbol11
- Tank, fuel refill295
- TCS (Traction Control System) . . .257
- Technical Data.389
- Telltails
 - Telltails on Speedometer.153
 - Telltails on Tachometer.155
 - Warning/Indicator Lights of Set Modes/Functions on Display. . .170
- TFT Display: Menus and Settings . .157
- Tires
 - Change a Tire.322
 - Compact spare tire286
 - General Information282
 - Inflation Pressure398
 - Pneumatic Suspension Mode for Wheel Change286
 - Punctured Tire, use322
 - Replacement Tires284
 - Snow Chains285
 - Tire Pressure282
 - Tire Pressure Low Warning. . . .288
 - Tire repair kit.322
 - Tire repair kit, use.322
 - TPMS - Tire Pressure Monitoring System286
 - Winter Tires.284
- Tool Kit318
- Towing
 - Towing a Disabled Vehicle334
 - Towing the Vehicle334
 - Use the Vehicle Tow Hook335
 - Vehicle Towing Conditions. . . .335
- TPMS System286
 - Tire Pressure Low Warning. . . .288
 - TPMS Deactivation290
- Trailer Towing308
 - Arranging Load on Trailer308
 - Tire Pressure Adjustment. . . .308
 - Towing Tips314
 - Trailer Light309
 - Trailer Torque Maintenance. . . .315
 - Trailer Towing Weight.308
- Transmission, Automatic223
 - Automatic Transmission Lever . .224
 - Automatic Transmission Range. .226
 - Malfunction and Overheating Conditions.228
 - Transmission Manual Release of P (Park) Position.329
- Transmitter, Key fob RKE
 - Preventing Inadvertent Locking of Key fob RKE Transmitter Inside the Vehicle36
 - Radio Frequency RKE Transmitter30
- TSM (Trailer Sway Mitigation) . . .258
- Unlock the Vehicle with Key fob . .27
- Updating9
- Vehicle Identification Number (VIN)13
- Vehicle Stored for Long Periods . .377
- Voice Commands216
- Wait to Start Indicator175
- Warning icons.8
- Warning Lights/Indicator Lights
 - Air Bag Warning Light88
 - TFT Display: Menus and Settings.157
 - TFT Display: Warning/Indicator Lights of Set Modes/Functions . .170
 - Warning and Indicator Lights on Analog Instrument153



- Warnings when Driving12
- Warranty10
 - Accessories10
- Water in Fuel Indicator175
- Wheels372
 - Wheels Maintenance372
- Windows38
 - Auto Down/Auto Up Feature39
 - Open and Close the Windows and Sunroof with RKE Transmitter and Ignition Off40
 - Reset Auto-Up/Down40
 - Window and Sunshade Lockout Button40
- Wipers and Washers123
 - Headlight On with Windshield Wipers.124
 - Rain Sensing Windshield Wipers.124
 - Rear Window Wiper/Washer. . . .126
 - Windshield Washer and Headlight Washers.125
 - Windshield Wipers123
 - Wipers Blades Maintenance124

Because of the evolutions of the MASERATI products, which are continually developed and perfected, MASERATI S.p.A. reserves the right to make modifications to this manual as well as to the technical contents, functions and equipment of the vehicles delivered.

Therefore, the user is not entitled to any claims based on the contents (texts, data, illustrations, explanations and regulations) in this manual, which are based on the data known at the time of going to print.

This document may not be reproduced, printed or translated, even partially, without the written consent of MASERATI S.p.A.



WWW.MASERATI.COM
MASERATI SPA · VIALE CIRO MENOTTI, 322 · I-41121 MODENA