




SERVICE NOTES

ELAN

1990 Model Year Onwards



LOTUS CARS LTD

Notwich, Northwich, England NR14 6EZ. Telephone (0945) 809000
Telex (0945) 806384 Telex 93401

This publication has been designed for use by Lotus Dealers familiar with general workshop safety procedures and practices. Take all appropriate action to guard against injury to persons or damage to property.

Lotus (s) Ltd. is one of continuous product improvement, and the right is reserved to alter specifications at any time without notice.

Whilst every care has been taken to ensure correctness of information, it is impossible to guarantee complete freedom from errors or omissions, or to accept liability arising there with errors or omissions, but nothing herein contained shall affect your statutory rights.

FLUOROELASTOMERS - Cautionary Note - Issued by the Society of Motor Manufacturers and Traders (SMMT) December 1990.

Fluoroelastomers are synthetic rubbers often used in engines, engine test rigs and other equipment such as 'O' rings and engine gasket seals. When used within design and operating conditions fluoroelastomers are safe and do not present a hazard to health.

If heated beyond normal operating conditions, for example during attempts to remove a tight coupling flange or in a fire, they can break down to give a highly corrosive acid (Hydrofluoric acid) - this can cause serious burns on contact with skin. Avoid skin contact with fire damaged members.

NOTE: Further information and advice is contained in SMMT 'All Members' Circular December 1990 entitled "SMMT Guidance on Fluoroelastomers".



CONTENTS

REAR SERVICE NOTES MANUAL R10070263

	<u>Section</u>
Technical Data - Engine	TRG
- Vehicle	TRH
Chassis	20
Body - Panel Procedures	24
- Body Repair	24
- Body Fittings	28
Front Suspension	34
Rear Suspension	34
Exhaust	30
Engine Maintenance - 2000cc Turbo	TRG*
- New (not light duty)	TRH*
- Refurbishing (repaired)	TRC*
* See separate manual: 2000cc TURBO (NEW), 2000cc TURBO (REPAIRED) (TRM*)	
Transmission	38
Driveline System	40
Clutching	40
Brake	46
Wipers	40
Power Windows	42
Electrical	44
* See separate manual: ELECTRICAL (Technical Sections)	
Registration & Licensing	48
Painting, Body Work & Refinishing	48
Crutch	44
Exhaust	40
Interior Trim	46
Supplementary Information (Illustrated Parts Lists) etc.	48**
** See separate manual: F10070263	



1.1.6. VIN

- Only one serial number sequence is listed for all variations of model and trim level, but the numerical sequence restarts each model year.
- 2002 Model Year Five-Character Sequence is assigned as VIN serial number 4100.
- All subsequent model year serial number sequences start at 6000.
- VIN serial numbers above 9999 never re-appear. Except upon the entire seven-digit character sequence the serial number with the model year (and four character) sequence 9999.
- Any change in the identification of service books, parts lists and service bulletins, does not affect the VIN serial number which is being sequenced.


Jacking Points

- 1) Jack only jacking points are positioned in the rear one just ahead of each rear wheel, and one just behind each front wheel. Each jacking point is fitted with a minimum weight of 10 kN to engage the hole in the vehicle's chassis rails. Other permissible jacking points are:
 - 1) beneath the tail section, the rear end of the front suspension rails for 4x4 drive components;
 - 2) beneath the rearward pivot points of the rear suspension wishbones, bearing in the inner edge of the chassis section using a suitable approved plate.

CAUTION: Do NOT use a jack beneath any other part of the vehicle, especially:

- Do NOT jack beneath the engine bay inducers;
- Do NOT jack beneath the rear suspension lower wishbones, control arms or/and

It is crucial that the correct location of these components has to be observed, as lifting



Body Structural Integrity

- When assessing accident damage/repair, it is most important to use the comparison of the following safety systems:
 - ABS (Anti-locking system) - (see section 4, 10/6 7-13)
 - Electronic stability control system - (see section 10/11)
 - Supplemental inflatable restraint systems - (see section 10/12/13)
 - Seat belt system (impact absorption technology) - (see section 10/12)

TERMINAL DATA - ENGINESECTION 1106 - PISTON, RINGS, & TAPPING

	Page
General Specification	1
Cylinder Head	2
Valves	3
Valve Guides	4
Valve Seats	4
Valve Springs	5
Valve Lifters	5
Camshaft	6
Cylinder Block	6
Pistons & Rings	6
Crosshead Bolt	7
Crankshaft	7
Flywheel & Ring Gear	8
Oil Pump	8
Water Pump	8

GENERAL

See General Notes

- Naturally Aspirated 4/30
- Turbocharged

Engine order for 4-cylinder

5-cylinder engines

Capacity

2000

220000

Compression ratio 8:1

10:1

Maximum recommended 4000 rpm - 4000

Maximum recommended 2000

Maximum

Maximum 2000

Maximum 2000

Maximum recommended engine speed 4000

Maximum 2000

- 10000 10000 rpm - 4000

- alternator
4000 compressor 4000

Maximum engine speed

Maximum engine speed 4000

Maximum engine speed 4000

Maximum engine speed 4000

Maximum engine speed 4000

- Turbo - turbocharged
- 4000 - 4000 rpm
- 4000 - 4000 rpm
- 4000 - 4000 rpm

Maximum engine speed 4000

Maximum engine speed 4000

Maximum engine speed 4000

Maximum engine speed 4000

CYLINDER HEAD

Material

Maximum engine speed 4000

- 4000
- 4000
- 4000
- 4000
- 4000

Maximum engine speed 4000

- 4000

4000

4000

Maximum engine speed 4000

Maximum engine speed 4000

Maximum engine speed 4000

Maximum engine speed 4000

Maximum engine speed 4000

4000

4000

Maximum engine speed 4000

Maximum engine speed 4000

Maximum engine speed 4000

4000

Maximum engine speed 4000

Maximum engine speed 4000

Maximum engine speed 4000

Maximum engine speed 4000

Maximum engine speed 4000

Maximum engine speed 4000

Maximum engine speed 4000

Maximum engine speed 4000

Maximum engine speed 4000

Maximum engine speed 4000

Maximum engine speed 4000

Maximum engine speed 4000

Maximum engine speed 4000

Maximum engine speed 4000

Maximum engine speed 4000

Maximum engine speed 4000

Maximum engine speed 4000

Maximum engine speed 4000

Maximum engine speed 4000

Maximum engine speed 4000

Maximum engine speed 4000

Maximum engine speed 4000

Maximum engine speed 4000

Maximum engine speed 4000

Maximum engine speed 4000

Maximum engine speed 4000

Maximum engine speed 4000

Maximum engine speed 4000

Maximum engine speed 4000

Maximum engine speed 4000

Maximum engine speed 4000

Maximum engine speed 4000

Maximum engine speed 4000

Maximum engine speed 4000

Maximum engine speed 4000

Maximum engine speed 4000

VALVES

valve clearance	see (reference and y dimension)
height of valve seats & faces	25"
rod diameter - inlet	31.00 mm (1.220 in)
rod diameter - exhaust	25.00 mm (0.984 in)
rod diameter - inlet - new	31.00 mm (1.220 in) (1.214) + 0.005 in
rod diameter - inlet - service limit	31.00 mm (1.220 in)
rod diameter - exhaust - new	25.00 mm (0.984 in) (0.979) + 0.005 in
rod diameter - exhaust - service limit	25.00 mm (0.984 in)
valve lead edge thickness	0.200 mm (0.0079 in) maximum

VALVE SPRINGS

valve spring clearance	
- inlet - new	0.101 + 0.004 mm (0.0039 + 0.0016 in)
- inlet - service limit	0.100 mm (0.0039 in)
- exhaust - new	0.100 + 0.004 mm (0.0039 + 0.0016 in)
- exhaust - service limit	0.100 mm (0.0039 in)
valve guide clearance above head - inlet	0.040 mm (0.0016 in)
- exhaust	0.030 mm (0.0012 in)

VALVE SEALS

valve seal cut-in - maximum of 80% valve above combustion chamber surface - new	1.70 mm (0.067 in) maximum
- service limit	0.65 mm (0.026 in)
valve guide - inlet - new	1.10 mm (0.043 in)
- exhaust - new	1.10 mm (0.043 in)
- inlet - service limit	1.10 mm (0.043 in)
- exhaust - service limit	1.10 mm (0.043 in)
to be removed at	0.08 + 0.05 mm (0.0031 + 0.0020 in)

VALVE SPRINGS

free height - new	22.7 mm (0.894 in)
- service limit	21.5 mm (0.847 in)
spring force - service limit	1.70 mm (0.067 in)
pressure at specified height - 2.000	12.0 + 0.144 (1.250)

VALVE GUIDES

valve guide diameter - new	30.70 mm (1.209 in) (1.204)
- service limit	31.00 mm (1.220 in)
valve guide diameter - new	25.00 mm (0.984 in) (0.979) + 0.005 in
- service limit	25.00 mm (0.984 in)

CRANKSHAFT

valve lift - inlet & exhaust	0.4 mm (0.016 in)
maximum cam lobe height - inlet & exhaust	19.00 mm (0.748 in)
lobe crown wear limit	0.00 mm (0.000 in)
journal diameter - new	26.94 - 26.96 mm (1.061 - 1.062 in)
- service limit	26.80 mm (1.055 in)
journal crown wear limit	0.00 mm (0.000 in)
maximum run out	0.10 mm (0.004 in)



Normal rate of charge (all materials here provided)

- saw = 1st compression	0.20 = 0.15 per 15' cut = 0.016 per
- 2nd compression	0.25 = 0.15 per 15' cut = 0.015 per
- all other	0.15 = 0.10 per 15' cut = 0.015 per
Normal rate of clearance	
- 1st compression = 1st	0.025 = 0.020 per 10' cut = 0.0025 per
- 2nd compression = 1st	0.15 = 0.020 per 10' cut = 0.0025 per
- 3rd compression = 1st	0.02 = 0.020 per 10' cut = 0.0025 per
- 4th compression = 1st	0.02 = 0.020 per 10' cut = 0.0025 per
- 5th compression = 1st	0.02 = 0.020 per 10' cut = 0.0025 per
- 6th compression = 1st	0.02 = 0.020 per 10' cut = 0.0025 per
- 7th compression = 1st	0.02 = 0.020 per 10' cut = 0.0025 per
- 8th compression = 1st	0.02 = 0.020 per 10' cut = 0.0025 per
- 9th compression = 1st	0.02 = 0.020 per 10' cut = 0.0025 per
- 10th compression = 1st	0.02 = 0.020 per 10' cut = 0.0025 per
- 11th compression = 1st	0.02 = 0.020 per 10' cut = 0.0025 per
- 12th compression = 1st	0.02 = 0.020 per 10' cut = 0.0025 per
- 13th compression = 1st	0.02 = 0.020 per 10' cut = 0.0025 per
- 14th compression = 1st	0.02 = 0.020 per 10' cut = 0.0025 per
- 15th compression = 1st	0.02 = 0.020 per 10' cut = 0.0025 per
- 16th compression = 1st	0.02 = 0.020 per 10' cut = 0.0025 per
- 17th compression = 1st	0.02 = 0.020 per 10' cut = 0.0025 per
- 18th compression = 1st	0.02 = 0.020 per 10' cut = 0.0025 per
- 19th compression = 1st	0.02 = 0.020 per 10' cut = 0.0025 per
- 20th compression = 1st	0.02 = 0.020 per 10' cut = 0.0025 per

CONCRETE WORK

Normal rate per 100 sq. ft. for all	0.15 per sq. ft. per day
Normal rate per 100 cu. yd. for all	0.15 per cu. yd. per day
- 1st compression	
- 1st compression	0.02 = 0.020 per 10' cut = 0.0025 per
- 2nd compression = 1st	0.02 = 0.020 per 10' cut = 0.0025 per
- 3rd compression = 1st	0.02 = 0.020 per 10' cut = 0.0025 per
- 4th compression = 1st	0.02 = 0.020 per 10' cut = 0.0025 per
- 5th compression = 1st	0.02 = 0.020 per 10' cut = 0.0025 per
- 6th compression = 1st	0.02 = 0.020 per 10' cut = 0.0025 per
- 7th compression = 1st	0.02 = 0.020 per 10' cut = 0.0025 per
- 8th compression = 1st	0.02 = 0.020 per 10' cut = 0.0025 per
- 9th compression = 1st	0.02 = 0.020 per 10' cut = 0.0025 per
- 10th compression = 1st	0.02 = 0.020 per 10' cut = 0.0025 per
- 11th compression = 1st	0.02 = 0.020 per 10' cut = 0.0025 per
- 12th compression = 1st	0.02 = 0.020 per 10' cut = 0.0025 per
- 13th compression = 1st	0.02 = 0.020 per 10' cut = 0.0025 per
- 14th compression = 1st	0.02 = 0.020 per 10' cut = 0.0025 per
- 15th compression = 1st	0.02 = 0.020 per 10' cut = 0.0025 per
- 16th compression = 1st	0.02 = 0.020 per 10' cut = 0.0025 per
- 17th compression = 1st	0.02 = 0.020 per 10' cut = 0.0025 per
- 18th compression = 1st	0.02 = 0.020 per 10' cut = 0.0025 per
- 19th compression = 1st	0.02 = 0.020 per 10' cut = 0.0025 per
- 20th compression = 1st	0.02 = 0.020 per 10' cut = 0.0025 per

FORMWORK

City of Clearing work selection: full dimensions on all

Material in to specify sqd	Quantity of city and material in specifying job	Formwork frame	Material material type	Quantity of material to specify sqd
1	40,000 = 40,000	10,000 = 10,000	Base	1.00 = 1.00
11	40,000 = 40,000		Lock	1.00 = 1.00
11	40,000 = 40,000		Edge	1.00 = 1.00

City Clearing work selection: Full dimensions on all

- 1st	0.02 = 0.020 per 10' cut = 0.0025 per
- 2nd	0.02 = 0.020 per 10' cut = 0.0025 per
- 3rd	0.02 = 0.020 per 10' cut = 0.0025 per
- 4th	0.02 = 0.020 per 10' cut = 0.0025 per
- 5th	0.02 = 0.020 per 10' cut = 0.0025 per
- 6th	0.02 = 0.020 per 10' cut = 0.0025 per
- 7th	0.02 = 0.020 per 10' cut = 0.0025 per
- 8th	0.02 = 0.020 per 10' cut = 0.0025 per
- 9th	0.02 = 0.020 per 10' cut = 0.0025 per
- 10th	0.02 = 0.020 per 10' cut = 0.0025 per
- 11th	0.02 = 0.020 per 10' cut = 0.0025 per
- 12th	0.02 = 0.020 per 10' cut = 0.0025 per
- 13th	0.02 = 0.020 per 10' cut = 0.0025 per
- 14th	0.02 = 0.020 per 10' cut = 0.0025 per
- 15th	0.02 = 0.020 per 10' cut = 0.0025 per
- 16th	0.02 = 0.020 per 10' cut = 0.0025 per
- 17th	0.02 = 0.020 per 10' cut = 0.0025 per
- 18th	0.02 = 0.020 per 10' cut = 0.0025 per
- 19th	0.02 = 0.020 per 10' cut = 0.0025 per
- 20th	0.02 = 0.020 per 10' cut = 0.0025 per

TECHNICAL DATA - VEHICLESECTION 1303 - EGAR (H H 5 Turbo)

	<u>Page</u>
Classification	1
Classification	1
Front Suspension	2
Rear Suspension	1
Steering	2
Wheels	1
Tires	1
Brakes	2
Transmission	2
Clutch	2
Engine Cooling	1
Electrical Equipment	2
Fuel Consumption	6
Torque and Fuel	6

CONTOURS

Overall length - Tow/Exp	1561 mm (149.1 in)
- 25A	1573 mm (152.4 in)
Overall width - excel. minimum	1334 mm (103.3 in)
- 10% minimum	1375 mm (107.3 in)
Overall height (with top raised)	1230 mm (48.4 in)
max. base	2350 mm (92.5 in)
to top - front	1450 mm (57.1 in)
- rear	1406 mm (55.3 in)
Overall clearance	110 mm (4.3 in)
from top - 10% to - between keels	10.50 m (34.1 ft)
base - 25A - N.A.	10.2 m (33.78 ft) (exc. tall base) base
	total
	front axle (10%)
	rear axle (10%)
Table - Tow/Exp	total
	front axle (10%)
	rear axle (10%)
25A	total
	front axle (10%)
	rear axle (10%)
gross weight - 25A	total
	front axle (10%)
	rear axle (10%)
Table - Tow/Exp	total
	front axle (10%)
	rear axle (10%)
- 25A	total
	front axle (10%)
	rear axle (10%)
step height (with) - excel. raised	150 mm (5.9 in)
- excel. conv.	57 mm (2.25 in)

AXLE SPAC.

excels. - 25A - 10% factor	1.1 times (1.2 kg pt. 2.7 lbs qt)
- without factor	1.1 times (1.8 kg pt. 3.9 lbs qt)
by	1.2 times (2.4 kg pt. 5.3 lbs qt)
distance - 25 between main flow supports	
25A	1.1 times (1.2 kg pt. 2.7 lbs qt)
25B	1.2 times (1.8 kg pt. 3.9 lbs qt)
25C	1.2 times (1.8 kg pt. 3.9 lbs qt)
25D	1.2 times (1.8 kg pt. 3.9 lbs qt)
25E	1.2 times (1.8 kg pt. 3.9 lbs qt)
25F	1.2 times (1.8 kg pt. 3.9 lbs qt)
25G	1.2 times (1.8 kg pt. 3.9 lbs qt)
25H	1.2 times (1.8 kg pt. 3.9 lbs qt)
25I	1.2 times (1.8 kg pt. 3.9 lbs qt)
25J	1.2 times (1.8 kg pt. 3.9 lbs qt)
25K	1.2 times (1.8 kg pt. 3.9 lbs qt)
25L	1.2 times (1.8 kg pt. 3.9 lbs qt)
25M	1.2 times (1.8 kg pt. 3.9 lbs qt)
25N	1.2 times (1.8 kg pt. 3.9 lbs qt)
25O	1.2 times (1.8 kg pt. 3.9 lbs qt)
25P	1.2 times (1.8 kg pt. 3.9 lbs qt)
25Q	1.2 times (1.8 kg pt. 3.9 lbs qt)
25R	1.2 times (1.8 kg pt. 3.9 lbs qt)
25S	1.2 times (1.8 kg pt. 3.9 lbs qt)
25T	1.2 times (1.8 kg pt. 3.9 lbs qt)
25U	1.2 times (1.8 kg pt. 3.9 lbs qt)
25V	1.2 times (1.8 kg pt. 3.9 lbs qt)
25W	1.2 times (1.8 kg pt. 3.9 lbs qt)
25X	1.2 times (1.8 kg pt. 3.9 lbs qt)
25Y	1.2 times (1.8 kg pt. 3.9 lbs qt)
25Z	1.2 times (1.8 kg pt. 3.9 lbs qt)

FRONT SUBFRAME

Type

Independent, torsion bar front upper & lower wishbones, coaxial coil springs and dampers with top on lower wishbone, tubular steel roll bar. Separate alignment adjust subframes.



- temporary speed
- size - standard - 8.75
 - Turbo - 10.7
 - 14.7
- wheel type
- temporary space
- Pressures (front & rear)
 - standard - 8.5 bar
 - Turbo - 15.0
 - 16.0
- wheel type
- temporary space
- Full continuous speed over 100 mph (160 km/h) maximum pressure is 2.0 bar (29.5 lb/in²)

SPRINGS

- Type Ventilated front discs, solid rear discs with single piston steering calipers
- Specifications 22.2 sq. inch tandem master cylinder with direct acting 200 wt. vector valve (logical split). Pressure proportioning valve at each rear circuit
- Steering Servo operation of rear calipers
- Parking Brake Brake discs
 - diameter: - front 256 mm
 - rear 246 mm
 - thickness - front 24.0 mm
 - rear 12.65 mm
 - minimum - front 22.0 mm
 - rear 10.9 mm
 - maximum allowed - Lotted 0.10 mm
 - 0.008
- Brake pads - material standard thickness - front 17.0 mm (16.65 mm)
- rear 14.1 mm (13.75 mm)
- minimum thickness - front 7.0 mm (10.25 mm)
- rear 1.0 mm (1.65 mm)
- Braking application values see section 12.1

TRANSMISSION

Type Manual, 5 speed + reverse

Gear	Internal Ratio	Final Drive		mph/1000 rpm			km/h/1000 rpm		
		R.A.	Turbo	R.A.	Turbo 15.0	16.0	R.A.	Turbo 15.0	16.0
1st	3.117:1	4.117	3.809	4.00	5.29	5.27	7.78	8.55	8.43
2nd	1.916:1	"	"	6.21	7.82	7.80	11.5	12.5	12.5
3rd	1.33:1	"	"	12.1	15.9	15.9	19.0	20.9	20.9
4th	1.00:1	"	"	19.7	25.9	25.9	29.5	31.2	31.2
5th	0.809:1	"	"	19.4	26.9	26.9	31.5	33.8	33.5
Rev	3.59:1	"	"	4.50	4.95	4.95	7.04	7.78	7.78



crank shafts
 - 1000 hours - inspect
 - overhaul

Final length with exhaust & oilhead
 constant velocity joints
 Flaring forged type
 - Ball, hardened type

CRANK

Type
 - 1000 hrs
 Crank plate aft - H.A.
 - Turbo
 Reverse plate clamp load - H.A.
 Turbo

1000 - dry plate, rollerless free
 end; reverse: ball type release bearing
 715 mm
 125 mm
 440 kg
 500 kg

ENGINE COOLING

Type
 water tank pressure cap
 radiator fan speed control

closed water circuit, engine driven
 centrifugal pump, thermostat, cooling fan
 radiator circuit, 2 electric fans with
 thermal switch, auxiliary electric pump
 on Turbo models with ign. off thermal
 control
 110 kPa (10.137 bar)
 recommended 10% concentration
 coolant 70 year point
 radiator 10% or reserve dilution

ELECTRICAL EQUIPMENT

Voltage polarity
 battery - type
 - 1000 hrs
 - cold start performance (CEN)
 - 1000 standard test code
 Alternator - max.
 rated output
 regulated voltage
 - drive belt tension

12V negative earth
 Delco Freedom maintenance free
 model 642
 10 amp hr @ 20 hr rating
 25A
 22
 Supplemental
 60 A
 14.2 to 14.8 V
 41 ± 10 amp (90 - 100 Hz)
 2500 & 3000000's series
 Recommended or engaged
 1.2 hr
 10
 Recommended 1000 hrs, 2 x 500 mm blades

Generator motor - type
 - rated output
 Fuel oil switch
 dump system



Torque settings cont'd.

	Nm	lbf·ft
Indicator Screw (2) front, bottom	22	16
Indicator Screw (2) rear (bottom screw top)	13	7.7
Pressure Screw (2) front (bottom screw bottom)	22	16
Pressure Screw (2) indicator	22	16
11A.		
Transmission Case to Frame	22 - 25	16 - 18
Crash nut on bracket to transmission gear	67 - 70	50 - 52
Body		
Tyre bumper to body	16 - 20	12 - 15
Body to chassis	15	11
Front Suspension		
Upper top plate nut	27 - 30	21 - 22
Top wishbone inboard nut**	7 - 10	4.7 - 6.1
Top wishbone inboard bolt	7 - 10	5.6 - 6.9
Wishbone plate to diff	17 - 20	12 - 14
Top wishbone to coil spring	7 - 10	5.6 - 6.9
Lower wishbone inboard pivot nut	6.5 - 7	5.0 - 5.2
Lower wishbone inboard pivot cap plate	22 - 25	16 - 18
Lower wishbone steel to tyre member	41 - 45	30 - 33
Upper steel shock axle to lower wishbone	175 - 190	130 - 140
Ball joint to wishbone hub	7 - 10	5.6 - 6.9
Coil to suspension unit	25 - 28	18 - 21
Shock absorber to hub carrier	61 - 67	45 - 49
Oil seal to hub to hub carrier	11 - 13	8 - 9.5
Hub to tyre and tyre mounting bolts	28 - 33	21 - 24
Spooling top nut to chassis	21 - 25	16 - 19
Drive shaft end to steering arm	58 - 64	43 - 47
Ball joint to frame hub	225 - 245	165 - 180
Rear Suspension		
Upper top plate nut	26 - 30	19 - 22
Spooling top nut to chassis	22 - 25	16 - 18
Upper to lower wishbone*	68 - 72	50 - 53
Top link, inboard** and 1 Lozenge*	75 - 81	55 - 59
Top link inboard adjustment bolt	12 - 15	9 - 11
Lower wishbone inboard pivot (110 Lozenge)**	15 - 20	11 - 15
Lower wishbone inboard pivot (110 TCB carrier)**	12 - 15.5	9 - 11.5
Oil seal to hub to wishbone hub to hub	7 - 10	5.6 - 6.9
Anti-roll bar ball joint to lower wishbone	9 - 11	7 - 8
Anti-roll bar to diff	9 - 11	7 - 8
Oil seal	9 - 11	7 - 8
Hub to hub carrier**	50 - 55	37 - 41
Drive shaft to wheel to hub carrier**	75 - 79	55 - 59
Drive shaft to steering arm**	100 - 110	74 - 81

* Tighten only at 90° angle.

** Apply thread locking compound unless running bolts (non-applied).

Transmission

Down to floor set screw plate

10

20

Down to floor set screw plate

25

25



Tractor with 12000 COMBO

	Qty	Int. Pk.
Over-center roll over bracket screws	22-5	21
Pinion housing to cylinder block	80	66
Shaft-hub assembly bracket to block	20	20
Bearing retainer plate	20	14
Intermediate pinion mounting plate	16	14
Shaft-hub housing to clutch housing	21	21
Reverse idler shaft retaining bolt	21	21
Selector shaft pin	20	18
1st speed drive & driver gear 100%	1-1	10
Over selector housing	20	12
End cover	20	12
Over wheel to shaft pin	112	81

Wheels

Wheel bolt	57 - 50	50	50
------------	---------	----	----

Steering

Link housing to frame	170	90
Dist. pressure pipe from pump to housing	19 - 21	14 - 11
Low pressure pipe from pump to housing	19 - 21	14 - 11
Frame connections, pin and bush to axle tube	12	7
Center pin to pedal box	10	7-5
Column to control lever	14	11
Upper pin to intermediate shaft	40	30
Lower pin to pinion shaft	40	30
Steering wheel to column	40	30
Track rod end to control	80	50
Track rod end to steering arm	80 - 81	42 - 47
Track rod ball joint to steering arm	10-5	54
Ball joint to A-Frame ball	10	41

Brakes

Front caliper to axle tube	95 - 110	1 - 11
Rear caliper to axle tube	90 - 110	65 - 11
Turner hose to caliper	40	20
Line nipple	9 - 10	7 - 17
Pressure hose to axle assembly to caliper	11 - 52	12 - 10
Line to pedal box	16 - 20	12 - 15
Brake line to wheelhead	22	16
Brake line to axle tube	41	20
Master cylinder to axle	14 - 18	11 - 11
Brake pipe to wheel head pin	15	1

Coaling System

Oil water pump motor	11	21
----------------------	----	----

Fuel System

Fuel pump bolt	12	7
Fuel filter connections	21	14

Air Conditioning

High pressure inlet connection	11 - 16	8 - 12
High pressure inlet connection	18 - 23	13 - 11




Tongue settings cont'd

		Min	Max
independent hose connections:	5/8"-10	11 - 16	9 - 12
	3/4"-16	20 - 27	15 - 20
	7/8"-16	24 - 30	17 - 22
	1-1/2"-16/20	30 - 34	25 - 27
Clutch			
operational arm pinch bolt		30	30
oil pan cover		15	15


CHANGESSECTION AD - ELAP

	<u>Sub-Section</u>	<u>Page</u>
General Description	AD.1	4
Change of Anti-Dive Angle	AD.2	5
Dimensional Check	AD.3	6
Landing Gear & Strut Frame	AD.4	9
Crew Structure	AD.5	12
Body/Chassis Mounting Points	AD.6	16
Chassis External Point Repair	AD.7	17

Non-USA Three-Chairlift Assembly



1044 Type Channel Front End



**AD-1 - GENERAL DESCRIPTION**

The chassis front is fabricated principally from "Aluflex" electroplated zinc precoated steel sheet, and in certain critical areas, "Tenflex" high strength steel. Various welding processes are used in the construction of a central square box section "chassis", with a crossmember at the front and two tapering box section outriggers at the rear. These outriggers form the top abutments for the rear suspension units, and carry the top link anchorage points. An extension of the central chassis to the rear of the outriggers, carries the rearward pivots for the wide based lower wishbones.

The chassis structure ahead of the front crossmember is bolted together for ease of removal and repair, and carries the engine and transmission, front suspension, cooling radiators and front bodywork. This bolt-on structure differs in detail between HBA and non-HBA specifications, but the pertaining crash performance regulations, but the main components are similar:

- The chassis front crossmember provides mounting points for the two bolt on longitudinal, which extend forwards alongside the engine bay, and carry the front suspension and top struts, and the left top bushes (see section 02). Each longitudinal is secured to the chassis front crossmember with six high tensile bolts, some of which are taper seat bolts for accurate location.
- A front frame is bolted between the front ends of the longitudinal, and provides the mounting points for the front bumper.
- A separate radiator support frame hangs from this front frame to form a mounting structure for the engine radiator and air conditioning evaporator.
- An engine bay underframe (subchassis) bolts to the bottom of the chassis front crossmember, carries the front suspension shaft lower bushes, and extends forwards to bolt to the bottom of the radiator support frame.

On non-HBA cars, a "crash structure" is bonded to the top surface of the front frame, and consists of a composite box containing a series of composite tubes with longitudinal axes. The usual characteristics of the assembly are designed to provide a progressive collapse in the event of a frontal collision, and reduce the decelerative forces transmitted to the cabin and its occupants. In USA cars, a similar result is achieved by the use of an energy absorbing expanded aluminium honeycomb, bonded to the front frame and filling the space between the frame and front bumper.

Sixteen body to chassis mounting points take the form of caged nuts, and are widely distributed about the chassis, mating with plain hole aluminium bobbins incorporated in the body structure. Four of the body/chassis fixings also serve as inward seal mounting tags.

The complete chassis frame is painted by an electrophoretic process before being coated with a grey polyester based anti-rust surface to protect the treatment from erosion. Further corrosion protection is provided by a "Dinitrol" wax based coating, applied to the inner steel surfaces. The wax treatment process is manufactured, and the corrosion warranty administered by Dinitrol (GB) Ltd., with re-treatment inspections required after two years, and at two year intervals thereafter. For details of this warranty and re-treatment/inspection, refer to the separate literature supplied by Dinitrol (GB) Ltd., Marlboro Road, Bernard Castle, Co. Durham, DL16 9ES.

Collision damage to the vehicle can subject parts of the chassis to abnormally high loads and initiate defects which may not be readily apparent. Consequently, if the vehicle's suspension or steering is damaged, then consideration must be given to secondary, or shock damage. For example, all springs and mechanical attachments should be carefully examined for both mis-alignment and stress cracks. If any suspension pivot shafts or suspension links are bent through collision impact, pay particular attention to the above points.



If any visible damage is found, such as panel warping, broken welds, cracks etc., or if a dimensional check reveals any distortion, a **NEW CHASSIS** should be fitted. It is not recommended to perform any repairs to the chassis involving welding, heating, attaching or patching. The application of high temperatures to the chassis may cause internal stressing or weakening of the structure and subsequent failure. In all cases, safety considerations must be regarded as paramount.


RD-2 - CHANGE OF ASSE 1.177 ANGLE

The rear suspension geometry incorporates a feature designed to reduce the tendency of the rear of the vehicle to lift under braking. The angle between the rear lower wishbone inboard pivot axis and the horizontal when viewed from the side, is referred to as the anti-lift angle. This was changed from 5° to 21° for all USA models, and as a running change on other vehicles from V26, W 6441, excluding 6646, 6646, 6611, 6715, 6715, 6716, 6719, 6721, 6721, 6721, 6716, 6746, 6760, 6788.

It is most important to establish the type of chassis fitted before carrying out a dimensional check. If a chassis type is in doubt (e.g. genuine replacement chassis) examine the rear wishbone anchorage channel at the extreme rear of the chassis, and refer to the diagram below.

Straight channel - early type 5°

Angled channel - later type 21°



Note that the following rear suspension components differ between the two chassis variants:

- rear wishbone;
- top link inboard pivot stiffening struts;
- top link outboard pivot fixings;

For service replacement, only the later type 21° chassis is available. If replacing the chassis on an earlier 5° car, the 21° chassis must be fitted together with a rear suspension conversion kit 610000955, which consists of 2 rear wishbones, 2 top link struts, 2 top link outboard pivot spread sleeves, 2 top link outboard pivot spacers, 2 top link outboard pivot bolts, and 2 nylon nuts. Refer to rear suspension sub sections BU.4 and BU.5 for the correct assembly sequence.


AD.3. - DIMENSIONAL CHECK

In general terms, when examining accident damage, if after any suspension rebuild (if necessary) the specified suspension geometry can be achieved using such adjustment procedures as are specified in sections 2E and 3D, and a thorough visual inspection of the chassis reveals no signs of secondary damage, the chassis may be deemed serviceable.

In order to help assess chassis distortion without disassembly of the suspension or body, a pair of chassis deflection pointers may be mounted at the rear of the longaron, and measurements made from the datum points thus provided. Two types of datum pointer tool have been produced; machined aluminium and fabricated steel.

Tools required: Datum pointer, LH T000T1079 (aluminium) or T000T1201 (steel)
Datum pointer, RH T000T1200 (aluminium) or T000T1232 (steel)
4 off M12x1.75x70 bolts H100M7099 - use only with steel pointers
16 steel Cape nuts

1. With the car raised on a wheel from lift, remove the front wheels and shock absorber liners.
2. Fit the datum pointers:
Machined aluminium type: Position one of the datum pointers against the top heads of the longaron fixing bolts, and fit the clamping hook through the pointer into the chassis hole. Pull the hook back to engage against the chassis, and tighten the lock nut securely.





- Fabricated steel type: Remove the top heat and bottom wear temper to chassis bolts. Bolt the fabricated pointers the longevon/chassis using the M12x70 bolts.
- Measure from the inside corner of an alloy pointer, or the tip of a steel pointer to one datum point at the rear of the channel section forming the chassis pick-up for the rear pivot at the rear lower wishbone (dimension A). Repeat for the opposite side.
 - Repeat (4), but measuring diagonally to the pick up point on the opposite side of the car (dimension B).
 - Measure across the car from one datum pointer to the other (dimension C).
 - Measure between the front and rear pick ups for the rear wishbone pivots on each side, as shown in the diagram (dimension D).
 - From inside the boot, measure between the centreline of the tops of the rear-most shock shafts, securing the top spring mounts to the chassis (dimension E).
 - Compare the measurements obtained above with those in the table below, and if any dimension is outside tolerance, a chassis distortion is indicated, necessitating chassis replacement.
 - To check the longevon and front cross, it is necessary to strip down the front of the car to enable measurements to be taken between the datum pointers and front bumper lower fixing holes. Alternatively, comparative measurements can be taken between the steering rack mounting boxes on the chassis front crossmember and the bumper lower fixing holes.

Dimension	Tolerance (mm)		Maximum Deviation mm/100
	Alloy Pointers	Steel Pointers	
A 5° anti-lift angle*	2100 - 2120	2090 - 2110	0.5
21° anti-lift angle*	2208 - 2220	2207 - 2210	0.5
B 5° anti-lift angle*	2388 - 2400	2381 - 2401	0.5
21° anti-lift angle*	2482 - 2492	2484 - 2493	0.5
* See sub-section AP.2			
C	1035 - 1047	1080 - 1092	
D	418.5 - 420.5	419.5 - 420.5	
E	806 - 810	886 - 890	
F non-USA type	1379 - 1386	1430 - 1419	0.5
USA type	1349 - 1367	1372 - 1390	0.5
G non-USA type	906 - 916	922 - 931	0.0
USA type	929 - 939	951 - 951	0.0

If no datum pointers are available, a drop check may be taken from datum points such as suspension pivots, longevon mountings etc., and the 0.5/10 deviation tolerance applied.





Inside corner
of alloy
datum pointer



Rear side of channel section
below centerline of pivot bolt


Chassis
Mount
Dimensions



Inside surfaces of channel sections



Checking
longerons
alignment




RE.4 - LONGERONS & FRONT FRAME

The longerons and front frame differ between USA and non-USA models. On non-USA models, the longerons extend forward as far as the left hand engine mounting, before bolting to the front frame which continues forwards before traversing across ahead of the power unit. On USA cars, the longerons extend all the way to the bumper mounting points before picking up the ends of the front frame.

**Non USA Item**



Each longeron is fitted to the end of the chassis front crossmember using six high tensile bolts, two of which are provided with conical seats for accurate location.



If necessary, shim washers are used at the joint between a longeron and the chassis to ensure optimum transverse alignment of the front end of the longeron. If a longeron is removed and is to be refitted on the same chassis, note a careful note of the location and number of shim washers on disassembly, and refer to the same specification. Similarly, note any shims fitted at the joint between the longerons and front frame and refit in the same manner. All longeron fixing bolts should be fitted finger tight before torque tightening (use the conical seat bolts, and then the cap head bolts, all to 120 Nm (89 lbf-ft)).

If a new longeron or chassis is to be fitted, or if the original shimming build configuration is lost, the set up procedure detailed below must be followed to ensure optimum alignment of the longerons and front frame.

1. Fit the longerons to the chassis without any shims and **do not** tighten the bolts.
2. Offer up the front frame and check the alignment of the longeron/front frame fixing holes. If the longerons are too far apart or close together to allow the bolts to be fitted, it will be necessary to fit shims between the longerons) and chassis.
3. Two thicknesses of shim washer are available:
0.25 mm 01000000
0.50 mm 010000910
If the ends of the longerons are too close together, shim washers should be fitted at the inboard three longeron/chassis fixing points) and if too far apart, at the gearhead three fixing points. A 0.25 mm shim will produce approx. 1.2% movement at the front end of the longeron. Initially, the total shim pack required should be equally divided between the two longerons. If each longeron however, there must be an equal shim thickness at each of the three fixing points.



4. When alignment of the front frame/longeron fixing holes has been achieved, or it is necessary to check the 'backwards' or sideways alignment of the longérons. Fit the front frame.

Measure the diagonal distances between the steering rack mounting lugs of the chassis front crossmember and the two innermost front bumper fixing holes in the front frame (i.e. 34 holes to 24 bumper frame hole, and 20 holes to 16 bumper fixing hole (see AD.3)). If necessary, transfer longeron arms from one side to the other to move the front frame sideways and equalise the two diagonals. Transference of 0.25 mm in shim thickness will result in a 2 mm (approx) movement of the front frame.

5. Torque tighten the longeron to chassis fixings, beginning with the central seat bolts, to 120 Nm (89 lbf.ft).
Note that it is not necessary or practicable or advisable to slack the longeron to front frame joints. Tighten the longeron to front frame fixings to 22 Nm (16 lbf.ft).


USA cars

On USA cars, the six fixings securing each longeron to the chassis allow only one vertical adjustment to be made to the front frame at the production stage. This adjustment is neither necessary nor practicable in service, and if the longeron fixings are slackened, they should be tightened with the vehicle (or chassis) weight supported by the longeron. Tighten the central seat bolt first, followed by the top head bolts, all to 120 Nm (89 lbf.ft). Note that some of the top head bolts use flat washers beneath their heads.

If necessary, shim washers are used at the joint between the longeron and chassis to achieve optimum transverse alignment of the front frame, in the same way as on non-USA cars. See the procedure above to set up the longeron shimming relative to the front frame and steering rack bushes.

Torque tighten the front frame to longeron fixings to 10 - 15 Nm (50 - 55 lbf.ft).


Each bridge gap filled on all cars between the inboard rear sides of each longeron, and the chassis front crossmember, with a shockproof washer between the braid eyelet and the chassis member to ensure good electrical contact. In



In addition, an earth bond is fitted across the joint between the left hand suspension and the front frame.

REAR CRASH STRUCTURE


In many JSA cars, a 'crash structure' is bonded to the top surface of the front frame, and consists of a composite box containing a series of composite tubes with longitudinal slots. The crash characteristics of the assembly are designed to provide a progressive collapse in the event of a frontal collision, and reduce the deceleration forces transmitted to the cabin and its occupants.





The structure is bonded to the top surface of the chassis front frame with polyurethane adhesive, and incorporating mounting points in the form of cupped aluminum bobbin, for the attachment of the electrical water pump and front topshell.

On USA kits, the required progressive crush characteristics is achieved by the use of an energy absorbing expanded aluminum honeycomb, bonded into the front channel section of the front frame, and filling the space between the frame and front bumper structure.




Neither type of crush structure is repairable, and if damaged should be cut from the front frame and a new structure fitted as detailed below.

Replacement of pre-USA Type 4 crush structure

Materials Required: Matesant kit (see below)


1. The bonding surface on the top of the chassis front frame is not painted with the gray polyester surface, so that the adhesive can bond directly to the electrophoretic coat. Dry fit the box into the frame and check that the three locating pop rivet holes are aligned.
2. Clean the white of the bonding area on the chassis frame and crush box with the wipe cleaner in the Matesant kit. Wipe off the excess cleaner and allow to dry.



3. Shake the Behrman primer container for at least 30 seconds before opening. Use a brush to apply the primer to the front frame as shown in the diagram, and also to the whole of the bonding area on the crash structure. Allow to dry for a minimum of ten minutes.



4. Cut the Behrman nozzle at 45° so that the width of the nozzle tip is about 5 mm. Remove the sealant from the RV's outledge, fit into the application gun, and extrude a bead of sealant onto the front frame as shown in the diagram.




5. Fit the box into position, and align the rivet holes. Press down using firm hand pressure to spread the adhesive, and fit the three pop rivets AD1066/990 to secure the structure until the adhesive has cured. Puddle any extruded Betaseal back into the joint using a spatula.

Precautions: Avoid skin or eye contact with the Betaseal, adhesive, and inhalation of the vapour from the cleaner or primer. High concentrations of the vapours are noxious - use in conditions of good ventilation. Flash point 12 - 15°C.


Replacement of USA type crash structure

Materials required: Permatbond 9501 adhesive

1. Use Betaclean 1900, acetone, or a similar solvent to thoroughly degrease the recess in the front frame into which the honeycomb is to be fitted.
2. Cut three pieces of backing foil out of A06P960084 to the dimensions shown, and face each piece around the back of the honeycomb sections.



3. Stick each foil section to the honeycomb by applying a bead of Permatbond 9501 epoxy adhesive to the rear face, and rear edges of the top and bottom surfaces of each honeycomb section before pressing the foil into position.




4. On each of the three sections, apply a bead of adhesive to adhere the chassis or foil to each of the three mating surfaces, and press into position. Retain until tape lifts, the adhesive has cured sufficiently (approx 2 hrs). Full strength is achieved after 24 hrs.

AD.6 - BODY/CHASSIS MOUNTING POINTS

There are 10 rear mounting points securing the body to the chassis, each using a two piece aluminum bobbin crimped together and bonded to the body, and an M10 bolt picking up on a caged nut on the chassis. The mounting points are symmetrical about the car centreline, and are located as follows:

- 2 at the front of each bodyside, into the rear of the chassis front crossmember.
- 2 alongside the bottom of each side of the centre tunnel, also serving as seat mountings, and picking up short outriggers from the side of the chassis centre crossbar.
- 1 in each side on the rear bulkhead, adjacent to the centre tunnel, picking up a bracket at the rear of the chassis bed/dome.
- 1 at each side of the seat, inboard of the rear wheel arch, into the chassis rear suspension top platform.
- 2 in the spare wheel well, into the chassis rear extension.

See section WK.1 for body/chassis removal procedure.

Body/Chassis FixingsAD.1 - CHASSIS EXTERNAL PAINT REPAIRS

In order to preserve the corrosion protection of the chassis, the polyester surface and electrophoretic coating ('E' coat), should be inspected for damage at the specified service intervals. Stone chips and scratches should be repaired and protected using Dinal products as follows:

1. Remove all loose paint, dirt and surface rust from the affected area, and thoroughly degrease using Dinal thinner. Using 800 grade wet/dry paper, rub down any stone chips and scratches, and mildly key the surrounding good paint to accept the wax repair. Wipe over again with Dinal thinner.
2. Spray, at low pressure, a single coat of Dinal 215 thixotropic rust-preventative fluid to the area, followed by a single coat of Tertacote 205 thixotropic wax coating, wet on wet. Allow approx. one hour air drying time.

Both these products (Dinal 215 & Tertacote 205) are available from Dinal at Montalbo Road, Barnard Castle, Co. Durham, DL12 5EE, England., and may be applied using the same equipment as is used for the anti-corrosion guarantee wax re-treatment.

PAINT PROCEDURESSECTION B1E - ELAP

	<u>Sub-Section</u>	<u>Page</u>
Paint Codes	PH 1	1
Commercial Dyeing Practices	PH 2	
Preparation for Painting	PH 3	1
Application of Primers	PH 4	1
Preparation for Surface Coatings	PH 5	1
Application of Marine Coatings and Finishes	PH 6	6
Application of Molecular Sieves, Resins and Chemicals	PH 7	6
Paint Packaging Operations	PH 8	8
Paint Removal (See 38M-Subpart 20)	PH 9	9
Reclamation of the Paint Procedure	PH 10	10
Paint Retention	PH 11	11
Paint Retention and Procedures	PH 12	11

The procedures detailed in this section are based on those used in the manual release of labor, parts, and staff with the paint composite subsystem. The section is included only for general guidance in repair work, and does not constitute a complete service repair procedure. Note that different oven temperatures and times may be necessary dependent on the level of thermal exposure, type of oven etc.

**BU.2 - ESSENTIAL WORKING PRACTICE****1. Working**

Ammonium Oxide based P110-115 fumes with all ECI one pack acrylic polyurethane systems. In some suitable occasions, a small portion of spray is suitable. Spray should not be allowed to accumulate in a confined or badly ventilated space. The spray must be harmful by inhalation and contact with skin and eyes.

Ammonium Oxide should only be used in a well-ventilated area, preferably in suitable spray booth with sufficient exhaust ventilation. Spray operators should wear an eye breathing apparatus to BS1067 part 3. Estimated ammonia to BS4130. People entering the spraying area for short periods up to 15 minutes should wear a respirator to BS2091 with type CC canister.

Before spraying Ammonium Oxide operators should refer to HSE Health and Safety Information Sheet HSE 10000. Store Ammonium Oxide in accordance with the Petroleum (Consolidation) Act 1928 and the Petroleum (Hazardous Order) 1989; and in a well-ventilated store with the Ammonium Oxide in accordance with the highly flammable, oxidising and irritating Petroleum Gas Remanufacture 1972. It is only a non-flammable gas and may form all sources of ignition. Take precautions against spillage of this substance. In case of fire, use foam or dry agent extinguishers. Do not use spillage will send to earth. Do not allow to enter a drain or water course.

All equipment for spraying or use of Ammonium Oxide should be fitted across use.

- All precautions should be taken to ensure there is no oil or water contamination in the paint containers and air supply lines.
- A high standard of cleanliness must be maintained with all spray equipment. Frequent cleaning of guns and the corresponding area and booth is necessary.
- Room temperatures and temperatures in the spray booth, let dry booth and work working areas should be checked daily, and periodic measurements of paint temperatures carried out.
- It is also very essential that any surface to be sprayed is absolutely clean, dry and free from dust or sludge.
- After any and each surface covering treatment including oil filled, cellulose, epoxy, polyurethane primer, primer/finisher, colour paint and clear lacquer, an interval of 24 hours be allowed before using a bank of ammonia liquid giving a full panel preparation for the duration specified for the material. Ammonium Oxide must be allowed to dry good before further work.

BU.1 - BODY AND COMPONENT PREPARATION FOR PRIMER

- (i) Check panels for holes, gel cracks
- (ii) Holes and gel cracks should be sealed out.
- (iii) Using 120 grit paper, 60; last edges of cut where routing has been carried out.
- (iv) Blow out dust.



2. Fill with Fabrication:

1. Flat off excess P59 with 60 grit Ore followed by 120 grit dry. Leaving a very fine film of filler over edges of repairs to avoid more silt through.

3. Lay flat the panels and equipment surfaces down, using 120 grade paper (8 1/2x11) to ensure that there is no trace of wax or oil on.

The operation is a finishing process in order to provide a suitable surface for painting and must present a completely uncolored surface to key the primer.

Slurries should be kept on job with an orbital sander or flat orbital sander on flat surfaces and 6 1/4" belt sand block, as more restricted areas.

Extra care is necessary to avoid get sand job through on sharp corners. Edges and recessed shapes may be flattened using a Scotch pad.

1. Thoroughly sand or clean the panels to be painted & the surrounding area and remove all foreign bodies.
2. Solvent wash panels and components using Isopropyl alcohol with deionized water and squeegee off. Visual check for gel cracks etc. Fill as required, as above.
3. Blow off panels/components to remove dust, water etc. Test surfaces and recesses.
4. Check the area to be masked up and cover with solvent if necessary.
5. Mask up and the body excluding the area to be painted.

6.4 APPLICATION OF PRIMER

1. Enter the spraybooth and thoroughly solvent wipe all surfaces using Isopropyl alcohol with deionized water.

Ensure that new cloths of a woven material are used and that they are changed frequently during use, so as to maintain surface cleanliness.

2. Thoroughly sand and all surfaces to be painted.
3. Prime Preparation Form J11 or Issue Mem.

4. Gun: Epoxy Primer	121 855 695	4	Parts	410086027
4.1 2010F	121 849 179	1	Part	410086027W
4.1 41	121 855 1276	0.5	Part	410086026V

Materiality: 10 32 30000 054 Sup 2 21 000000 01 Material Topcoat etc

1. Spray Gun and Settings

Gun

Grainite System 100
 Air Cap 100-100
 Nozzle 010
 Needle 3/16-11

Settings

Air Pressure 60 PSI at the gun

2. Application

a) Spray 1st and 2nd pass.

b) Wash off 10 minutes from start of spraying.

c) Spray 3rd and 4th pass (same as a).

d) Wash off 10 minutes from start of spraying.

e) Apply 5th and 6th pass. Each dry run build 100-150 um (4-6 thou).
 Apply a 7th coat of 20 Black as a guide coat for later blasting
 using a pot gun spraying from about 3 feet distance. Trigger fully
 open.

f) Wash off 20 minutes from start of job.

3. Test take at 65 degrees C for 30 minutes.

4. Test cover, take to test, inspect and retest if required.

70 Jc Test Mat	100 20 stone	2 Stone	40008010
	90 2000 Red Oxid	2 Stone	41008020
	70000 6500 100	2 Stone	41008020

DI.5 - PREPARATION FOR COLOUR COATING

1) Wet 1st of the panels surface using hand brush and 400 grit paper
 180 or 240 with 120 grit paper wet.

Do not get to close to avoid running through the primer film,
 particularly at sharp corners. These areas may be flattened with a
 Scotch pad.

2) Top thoroughly to seal voids using (sag-proof) mixed 1:1 with
 200000 water and inspect.

3) Scrub any surface defects as required using P40 and stopper.

4) All prepared areas with 120, 400 unit.



solvent wipe painted areas with Isopropanol, as above. Replace damaged masking as necessary.

- Remove any job through or specified areas with 50 Mic primer.

1. Put box 200g 001 4 parts Four 200 ml Pink 300
 2. Put box 200g 001 1 part
 3. Put box 200g 001 1 part

Apply 20 Mic Primer.

Latvian Service Navy Intermediate Repair Gun Settings

02

Spindle System 100
 Air Flow 60 PSI
 Nozzle 021
 Needle 10.01.01

Setting 03

Air Pressure 50 PSI on the gun

400 Mic using 100 Mic paper

- Thoroughly wash the panels and component surfaces to be painted, using hose and brush. The final wash should be with de-ionized water ensuring full removal of all blasting sludge.
- Remove all masking.
- Dry thoroughly inside and out of the gun and components. Remove masking and wire pins remove all foreign bodies.
- Mask entire body excluding area to be painted.

B8.6 - APPLICATION OF PRIMER COLOUR COAT AND CLEARCOAT

- Ensure that body and components are fully surface cleaned.

Prime the unsued area and thoroughly solvent wipe the panels and component surfaces to be painted using Isopropanol mixed 1:1 with de-ionized water. Ensure that new sticks of a given material are used and that they are changed frequently during use, so as to maintain surface cleanliness.

Mask any bonding areas.

- Thoroughly take up all surfaces to be painted to remove all traces of dust.



1. Paint Formulation Follow all the below items.

EPDM Lead Based Colours	101 28	4 Parts	
Acrylates	101 13-276	2 Parts	300000079
Titanium	101 P950-1275	1 Part	310000079
or	101 P950-1130		300000079

Viscosity level 10 to 18 seconds 254 Cup @ 20 Degree C, Maximal Temperature

1. Coloured Manufacture

Chromes	101 P100-407	4 Parts	300000079
Acrylates	101 13-276	2 Parts	300000079
Titanium	101 P950-1275	1 Part	300000079
or	101 0650-1100		300000079

1. Spray Gun and Settings

GUN

Spray System	400
Air Cup	60-800
Nozzle	501
Nozzle	10,91-1)

Settings

Air pressure 65 to 70 psi

1. Application

- i) Blow down internal surfaces with filtered air
 - ii) Take rag to remove all traces of surface dirt
 - iii) Blow down external surfaces with filtered air.
 - iv) Spray 1 double pass of colour.
 - i) Flush out 10 minutes once start of spraying
 - ii) Spray 2nd double pass to the top. Dry film build level 2 to 3 coats.
 - iii) Flush off 10 minutes once start of spraying
 - iv) Spray 1 double header colour. only 100g 1000 to 2000 coats required.
- After priming area, allow to dry 40 minutes @ 40 degree C to 50 degree C.
- a) Enter oven & bake @ 65 degree C for a minimum of 30 minutes.

**PH 2 - APPLICATION OF METALLIC COLOUR COAT AND CLEAR COAT**

1. Ensure task body and components are fully visually cleaned. Enter the task area area with thoroughly solvent wipe the entire car and component surfaces to be painted using facemasked gloves (1) with de-ionized water. Ensure that new linings of a cover material are used and that they are changed frequently during use, so as to maintain surface cleanliness.

2. Thoroughly tack rag all surfaces to be painted to remove all traces of dust. Mask any bonding needs.

3. Paint Formulation - From 101 or 102 or 500:

Primer	Primer Metallic Colour	101 2B	4 parts	
Hardener		101 P010-170	3 parts	410086028V
Thinner		101 P550-1096	2 parts	601606078V
Drying time up to 14 seconds @ 140°C up to 20 degrees C. Material Temperature.				

4. Clearcoat Formulation

Clearcoat	101 P100-405	4 parts	410086001+
Hardener	101 P010-170	2 parts	410086013V
Thinner	101 P550-1096	1 part	601606078V
	1096		601606078V

5. Apply to Bellows**1st**

Primer	101
Hardener	101 P010-170
Thinner	101 P550-1096
Brush	101 P101-21

SPRAYING

At Pressure 10 to 30 PSI.

6. Preparation

(1) Blow down entire area with filtered air.

(2) Tack rag to remove all traces of surface dust.

(3) Blow down external surfaces with filtered air.

(4) Spray 1 single pass of colour.

(5) Finish off 10 minutes from start of spraying.

(6) Spray 2nd single pass of colour.

(7) Finish off 10 minutes from start of spraying.



- x11) Spray double coat rest of exterior, minimum fair finish 30-50 sq ft (11'-2" diam).
 - x2) Flash off 45 minutes from end of spraying.
 - x3) Spray 1 single coat of exterior.
 - x4) Flash off 20 minutes from end of spraying.
 - x12) Spray 1 concrete dry film surface (20-30 sq ft) (1'-1" diam) of exterior. 60 flash off required.
7. Exter. priming area, allow to dwell 45 minutes @ 40 degrees C (100 degrees F).
 8. Exter. oven, bake at 60 degrees C for a maximum of 90 minutes.

III.8 - FINAL POLISHING OPERATION

1. Remove masking from part including all surfaces without paint.
2. Compound formulation
Rubbing compound fine OR 1562-02
3. All painted surfaces to be lightly compressed with a machine rag.
4. Wipe down with solvent material, and blow dry, surface contacts.
5. Remove masking rag.
6. Clean up and wax.

III.9 - PAINT PROCEDURE FOR RAIN COMPONENTS

The front and rear bumpers are formulated reaction injection moulded (RIM) which may be distinguished by their more flexible flange area compared with glass fibre reinforced plastic (GRP) composite mouldings. They are supplied only in primer. Col fill using 100 cc colour required.

1. Preparation
Use 24 gsm nonwoven paper to wet flat the panel and remove all surface irregularities. Do not rub through the primer (R592B429W, 100 P601500).
2. Painting

Primer	R592B429W	R592	5 parts by volume
Flex aid	R592B429W	R592/2301	1 part by volume
Hardener	R592B429W	R592/770	3 parts by volume
Thinner	R592B429W	R592/1274	10 spraying viscosity



See also: Primer

Primer	ADDP01215	P900	2 parts by volume
Flex Aid	ADDP01215	P1000/200	1 part by volume
Hardener	ADDP01215	P200/100	1 part by volume
Thinner	ADDP01215	P900/1217	On spraying viscosity

For other system, spray the single coat. Allow 10 minutes to flash off and spray on second coat. Allow 30 minutes flash off before moving at 100°C for 90 minutes. Slightly sanded/brushed with cellulose stopper and prepare for spraying and second coat.

Spray second coat as above, and if necessary, with metallic colours, a fast over is minimum shading. For other colours, allow 30 minutes flash off before moving at 100°C for 90 minutes.

Clear Coat Application

Clear Coat	ADDP01220	P1000/200	2 parts by volume
Flex Aid	ADDP01215	P1000/200	1 part by volume
Hardener	ADDP01215	P200/100	1 part by volume
Thinner	ADDP01215	P900/1217	On spraying viscosity

Spray one single coat of clear coat. Allow 10 minutes to flash off, and spray one double coat. No flash off is necessary before moving. Spray at 100°C for 90 minutes.

NOTE

BBN components may only be stored if the suggested are used to prevent deterioration. Where pigments are available, the paint may be used dried at room temperature for 10 to 12 hours maximum. Parts should not be fitted for 24 hours.

BB.10 PEARLESCENT WHITE PAINT PROCEDURE

Paint finished in 'pearlescent white' with pearl effect face should be painted as follows:

1. Follow procedures BB.7, BB.8, BB.4 and BB.5 to apply Hi-Die primer and to prepare the substrate coat.
2. Follow procedure BB.6 stages 1, 2 and 3 to apply Horden White, 50% P420 2017.

and allow 24 hrs flash off before applying the pearlescent coat

3. Pearlescent Primer: Adhesive 121 P421-1000

Mixing Ratio:	Basecoat	2 parts by volume	
	Hi-Jet	P200/100	1 part by volume
	Thinner	P900/1215	1 part by volume

Spray rate: viscosity is 16-19 sec/100, 254 cup at 100°C material temperature. Pressure at the gun 57 psi.

Spray 1/4 inch passed to obtain a film thickness of 1.0mil, approx. 5 mil flash off between coats.

Flash off 30-40 min. before clearcoat application.

4. Follow procedure BB.6 stages 4 to 7 to apply clearcoat and to polish.

**557F Components in Reattachment Blanks**

1. Follow procedure 557F to apply a colour coat of Porcel White 100 440-0114.

2. Apply clear epoxy finish:

809986184V	100	142-1665
Clearcoat		
Hardener	100	100
Hardener	100	100
Thinner	100	100

Spray a viscosity of 10-15 cP at 25°C material temperature.

Spray a single pass to obtain a film thickness of 1.0mm.

Apply a thin flash off between coats.

Flash off 30-45 mins before subsequent application.

3. Follow procedure 557F to apply a clear coat of 100 440-015.

557G - PAINT REMOVAL

Under no circumstances must "Paint Stripper" be used to remove paint from G.F.R.F. components or hardware as this will attack the substrate, ablate such items as rivets.

The recommended procedure for painting is as follows:

1. Wash off with a 5:20 thinner: 20
2. Wet film with an an appropriate grade of wax depending on the amount of paint to be removed.

557H - PAINT REPLICATION PROCEDURES**1. Large Fuel or Structure Damaged by Corrosion**

These defects should be removed using 100 all running compound. Use a vacuum bag keeping the bag tight and secure parallel around the bag in a 1/2" and 3/4" direction.

Continue with polishing using 1200 and a fresh polishing rag until reaching the bag tight and moving it a top and all around it. Finally sand patch the area using 1000 grits and Microglass 5000.

2. Small or Sinkages

These problems these defects should be removed by wetting the affected area with 1:10 grade sand 400-500, rubbing compound and polish. Break the sand as taken out to run through the 1:10:1000.

If the problem is with fuel it should be removed by flattening then the area should be prepared as follows:

- a. If necessary, remove adjacent rib and fittings.
- b. Wash the area with clean water.
- c. Clean with water mixed 1:1 with Isopropanol.



- a. Dry off and blow wet surface with filtered air.
- b. If necessary, mask off surrounding areas.
- c. Feather edge the faulty area by wet flattening using hand held blocks and 120 grade paper (acetylene).
- d. Wash with clean running water and dry off using filtered air.
- e. If necessary, scrub PMS to the fault and cure using infra red lights to give a panel temperature of 60°C for 10 minutes. Then dry using 120 and 150 paper (1218).
- f. Spot prime the area using 1000 primer mixed and applied as in Section 2. Cure the primer using infra red lights to give a panel temperature of 60°C for 10 minutes.
- g. When cool, apply wet flat using 120 grade paper (281) and hand held blocks. Wash with clean running water and dry using filtered air.
- h. Take fair the upper and surrounding masked off areas and apply primer 1218 and 1000 coat wet to wet as described in Section 6 using a feathered technique.
- i. After the primer has completely elapsed cure the paint using infra red lights to give a panel temperature of 60°C for 10 minutes.
- j. When cool, 1218 wet flat, compound and polish the repaired area. Remove mask and refill trim.

1. Wet Cracks

Remove the paint, primer and red coat over the cracked area feathering back the original paint surface. Apply PMS and refinish as in 14, above.

4. Blisters

Remove the blister just deep enough to expose the blister cavity and feather the surface.

6. Chips and Scuffing

Remove the fault using 120 paper progressively and refinish as in 14, above.



BODY REPAIR

SECTION B1 - ELAB

	<u>Subcontract</u>	<u>Page</u>
Large Composite Body Features	B1.1	1
Body Shape	B1.2	1
Body Structures	B1.3	4
Nonlinear Damage Assessment	B1.4	3
Repair and/or New	B1.5	2
Repair and/or New	B1.5	3
Superficial Detail Repairs	B1.7	3
Replacement, Integration, Details and Details	B1.8	4
Repair Details	B1.9	10
Integrating Nonlinear Damage Assessment	B1.10	15
Repair of Water Tanks and/or Tanks	B1.11	15
Repair of Water Surface Reinforcement, Damage	B1.12	19
Initial Stage and Sequence of Bonded Panel Repair	B1.13	20
Repair and Replacement of Full Section	B1.14	22
Repair and Replacement of Full Section	B1.15	25
Repair and Replacement of Full Section	B1.16	25
Repair and Replacement of Full Section	B1.17	25
Repair and Replacement of Full Section	B1.18	27
Repair and Replacement of Full Section	B1.19	27
Repair and Replacement of Full Section	B1.20	27
Repair and Replacement of Full Section	B1.21	27
Repair and Replacement of Full Section	B1.22	27
Repair and Replacement of Full Section	B1.23	27
Repair and Replacement of Full Section	B1.24	27
Repair and Replacement of Full Section	B1.25	27
Repair and Replacement of Full Section	B1.26	27
Repair and Replacement of Full Section	B1.27	27
Repair and Replacement of Full Section	B1.28	27
Repair and Replacement of Full Section	B1.29	27
Repair and Replacement of Full Section	B1.30	27
Repair and Replacement of Full Section	B1.31	27
Repair and Replacement of Full Section	B1.32	27
Repair and Replacement of Full Section	B1.33	27
Repair and Replacement of Full Section	B1.34	27
Repair and Replacement of Full Section	B1.35	27
Repair and Replacement of Full Section	B1.36	27
Repair and Replacement of Full Section	B1.37	27
Repair and Replacement of Full Section	B1.38	27
Repair and Replacement of Full Section	B1.39	27
Repair and Replacement of Full Section	B1.40	27
Repair and Replacement of Full Section	B1.41	27
Repair and Replacement of Full Section	B1.42	27
Repair and Replacement of Full Section	B1.43	27
Repair and Replacement of Full Section	B1.44	27
Repair and Replacement of Full Section	B1.45	27
Repair and Replacement of Full Section	B1.46	27
Repair and Replacement of Full Section	B1.47	27
Repair and Replacement of Full Section	B1.48	27
Repair and Replacement of Full Section	B1.49	27
Repair and Replacement of Full Section	B1.50	27
Repair and Replacement of Full Section	B1.51	27
Repair and Replacement of Full Section	B1.52	27
Repair and Replacement of Full Section	B1.53	27

**13.1 - LOTUS COMPOSITE BODY FEATURES**

(General's Handbook Extract)

Body Features

The body structure comprises a moulded composite floorpan reinforced with steel. It begins to form from the box section. The floor pan is bolted at various points to the top section steel members chassis, with further rigidity and load, and protection provided by a high strength aluminium alloy chassis frame, a tubular steel double beam, and steel beams in the doors and the rear cladding. Most composite exterior panels are bonded to the chassis using a flexible polyurethane adhesive, but the front panels are secured by threaded fasteners for ease of service access and collision repair. The front bumper grille and bumper covers are flexible reinforced polyurethane mouldings resistant to damage from minor cracks.

Composite structures have the ability to absorb high impact loads by progressive collapse, with impact damage being localized. In accident situations this feature prevents the occupants from injurious shock loads and greatly reduces the danger of entrapment by deformation of body panels. This ability to absorb localized impact by either realising the damaged section as bonded panels, and by integrating replacement cladding sections with the undamaged areas, allows personalized approval methods which restore the underlay to its original condition without visible signs of deterioration.

At the point of impact beyond the limits of flexibility the gel mat will be overstressed and may well result in through the panel will return to its original shape. A steel panel localized, treated weld become permanent to restore.

The marking may be confined to the surface gel coat with no reduction in panel strength, but if the damage is severe then the composite structure below the gel coat may be weakened. Localized repairs can be made in other cases. The marks may not appear immediately after overstressing because the effect can be masked by the flexibility of the panel which would cover the gel coat. In some situations gel cracks may have as long as three months to appear. Gel coats may be repaired by the following:

1. Apply gel to restore heavily on the panel or on other parts.

2. Use the double system. Start repairs with opening.

3. Apply a strip of heavy gel to a panel.

4. Apply gel to seal joints, joints and on the front of panel.

5. Apply bonded gel to the front of the body projecting vehicles with damage on side.

6. Reinforce the gel mat, as shown by force. Panels

7. Apply to panels with severe damage. Localized

8. Apply gel to the front of the body

9. Reinforce the gel mat.

10. Reinforce the gel mat.

11. Reinforce with heavy metal sheet.

Some light box systems are available, however, which by absorbing 20% shock loads, protect the body from damage, keeping the bumper design loads. However, they do not protect the body panels.

**B1.2 - BODYCARE****[Owner's Handbook Extract]**

The purpose of your toilet is extremely resistant to all normal forms of weathering attacks. Provided the proper maintenance procedure (detailed below) is followed, it will retain its gloss, colour and protective properties throughout the life of the vehicle. However, our finishes are not totally "invisibly" impervious. Severe local contamination of an acid or alkali nature can occur. If it is left in contact with the paint film for any length of time, it may cause etching and colour change.

Washing

All contaminants that will attack a paint film are water soluble. They will be removed from a car's body panels by the tough washing with plenty of water. It will be advised for types of liquid detergent. Frequent washing is the best safeguard against insect contamination as all the water film removes the required amount of dirt, dirt and traffic film.

If weather will not wash, a hot solution, warm water and detergent will remove the quality deposits caused by some insects in the warmer months. Rainfall or water applied will remove stains of the rust, oil and grease type.

Polishing

Occasionally some loss of gloss and an accumulation of traffic film will occur. As soon as possible after the most washing, a polish with a good quality liquid polish will restore the original lustre of the paint film.

Higher gloss of the paint film, and added protection against contamination, can be obtained by wax treatment. It is vital to be advised that wax polish can only be used immediately on a clean surface, and that the previous application of a film be removed with water spray or a liquid polish cleaner before waxing.

Ventilation

Water applied to the paint surface for lengthy periods will penetrate the paint film. Although the effects will not be visible immediately, they will in fact cause a deterioration in the protective properties of the paint film.

If a car is garaged, good ventilation must be provided. Likewise storage outside on a hard standing or under a canopy of permanent.

Summary

- Wash frequently, using mild water with a few drops of liquid detergent added.
- Inspect after a normal washing, and remove any build-up of dirt with warm water, petrol, or white spirit as applicable.
- Use a good quality liquid polish infrequently - say, twice a year - to restore high gloss and to remove accumulated traffic film and grime.
- Park on a hard standing, and under conditions of good ventilation if a covered area is used.



Windscreen

Wash with the windscreen, the wiper area may be pivoted forward to clean the wipers from the glass and provide concentrated access to the windscreen. Wash the wiper blade with clean water.

Alloy Wheels

It is recommended that these are washed with the preparation as advised to wash the bodywork. Use a wire or heavy nylon brushes only. During the winter months, do not usually clean as it has been used on the roads for the disposal of salt and ice. Remove any dirt, and wash thoroughly to remove all accumulated mud. It is then washed and dried.

Upholstery

Remove excessive moisture of an occasional light wipe over with a cloth dampened in a mild soap and water solution. It is important that the cloth is only dampened, not soaked.

Leather Upholstery

The leather should be wiped over occasionally with a cloth dampened in soap and water.

Repeat the treatment using a fresh cloth and water only - avoid flooding the leather. It is best to dry the garments with a mild, dry cloth.

It is important to use a mild, non-caustic leather soap for 'lux' soap classes and to avoid the use of petrol or detergents, furniture polish and polishes.

An occasional use of shoe polish is recommended after the leather has been dried for a week or two.

Seat Belts cleaning

The most suitable solution for seat belts is a mild soap and water solution. Check regularly that the water is not too hot and therefore will dry quite quickly.

Do not wash seat belts in liquid soaps, those containing mineral acids and those not allowed.

11.3 BODY STRUCTURE

The chassis of the vehicle comprises of a non-pneumatic tray and boxed panels made of cast iron, which together with steel castings, straddles a fabricated steel bulk head chassis and bolt together via integral alloy bolsters at several mounting points.

A main structure, which consists of longitudinal, a transverse and a front beam is bolted to the front of the chassis.

The engine is designed to carry all the major structural loads and is made of high tensile steel.

The main structure which bolt to the front of the chassis is designed to take the suspension loads in excess of 1000 lbs the weight of the engine and provide a safe margin of impact.

The composite underbody, subframe and 'D' post structure are designed to carry structural loads and when available will contribute to the strength and functional stability of the whole assembly.



The composite body structure comprises of a one piece moulded undertray into which alloy boltholes are bonded and drilled. The metal substructure are bonded into the undertray, lattice section steel tubes are fitted across the 'B' posts and 'A' posts to form an additional protective cage around the passenger compartment. The rear and front bulk heads are bonded into place before the 'B' and 'A' post work, side and rear panels are bonded into their respective positions.

The front panels, which are also made of GFR/GRP, are bolted to the main assembly.

The undertray is made from low modulus polyester (R.F.R.P.). All other panels are of low profile R.F.R.P. construction.

All panels are produced to the new Labor War Building Process.

B1.4 - ACCEPTED DAMAGE ASSESSMENT

All damage to the body is assessed in the following categories:-

- (i) Highly stressed
- (ii) Moderately stressed
- (iii) Lightly stressed

and as that detection depends on the original construction and therefore the repair method to be employed.

As a general rule there should be a bonded joint wherever two panels touch, or wherever they cross or support each other. It is usually possible to check these bonds with a scalpel and physically test fractures or breaks. Ascertain the cause of damage and the direction of impact and examine all panels to bonds which may have been affected.

In front end impact, for example, one easily cracks the bonds at the bulkhead to hull without the defect being easily visible.

In handling a major assessment, it may be necessary to remove parts and components to determine the extent of the damage. When determining the replacement undertray sections and panels to be ordered, make sure the new undertray section and panels, when repaired will be attached to firm composite material, avoid badly cracked areas and badly built joints.

Fire damage is the most difficult to assess but generally only the obviousity level of charred sections will need to be replaced or sea forced.

After a replacement of severe accident elements should also be carried out on the 'A' and 'B' post distribution points, massing, suspension and boltholes, fibreglass areas.

Note - Impact of damage only with around boards may necessitate body removal from chassis.

Accident Repairs

For repair purposes, accidents may be defined as either:-

- (i) Front section
- (ii) Centre section
- (iii) Rear section

and that detection determines the original construction and therefore the repair method employed.



- a) **Front Section**
The front section has been designed for ease of panel replacement. Each panel may be removed by unfastening and its replacement bolted into position. A series of repair notes in this manual cover replacement of front section panels.
- b) **Centre Section**
If serious damage occurs to the centre or whole body side - underbody and all rear panels may have to be replaced. However, in occasions it will be possible to replace sections of the underbody and outboard. This may be achieved using conventional glass fibre repair techniques. A series of repair notes in this manual cover replacement of sections of the underbody.
- c) **Rear Section**
The rear portion of the car is composed of the rear end of the underbody and body panels bonded into position using flexible polyurethane adhesive. Replacement of sections of the rear underbody may be achieved using conventional glass fibre repair techniques. The rear panels may be replaced by cutting the adhesive and removing the panels. When replacing bonded panels, adhesive must be applied and the panel primed and sanded while the adhesive cures. A series of repair notes in this manual cover the removal and replacement of rear body panels and replacement of rear sections of the underbody.

B.5 - RESIN AND GEL COAT

The following general information appearing in the resin and gel coat notes which must be used when carrying out a repair.

The panels to be repaired are manufactured using two types of material. The details are:

1. **Isophthalic polyester 617 A/B**
2. **urea urethane**
When carrying out a repair, the type of materials used will depend on the original material used in manufacture. The table below shows what materials must be used with each process.

MATERIALS	ISOPHTHALIC POLYESTER RESIN (Underbody)	UREA URETHANE RESIN (All other panels)
Resin	5566/6005	206 and 6206/1 50437
Resin Catalyst	61149 & 50-1300 per 100	61160/6X LFT-1000 per 100
Filler	411	611100/6-40 per 100 parts by weight
Gel	61100/6/6206/1 50167/6005	
Gel Catalyst	61100/6/6206/1 50-1300 per 100	

**Notes:**

1. The Millbrook Filtrine can be mixed thoroughly with the Kantanal Kropol 50431.
2. Kantanal Kropol 50431 has a 220% life of 30 days from the date of despatch by the manufacturer.
3. Broom 555620202 may be obtained from:
International Paint
514 Station
London
UK
Tel: 01-476-3222
4. Kantanal Kropol 50431 may be obtained in small quantities from:
Kantanal
Case 2 09147 41 1010
F33001202
Worcester Park
W. Yorks
UK
Tel: 01924-714120
5. Most of the Kantanal Catalysts may be obtained in small quantities from:
Aqua Chemie
123 Gabels Road
Berkhamstead
Hertfordshire
UK
Tel: 0438-217500
6. Mulsol may be obtained in small quantities from:
Mulsol Ltd
10000000 Road
Malden
Surrey
UK
Tel: 0447-25125
7. The new bonding clear 5670P60 may be obtained from:
International Paint
514 Station
London
UK
Tel: 01-476-3222

Notes should always be read at least once before use.

- a) Stirrers - Test resin on inside surfaces
- b) Use plastic fill when pouring into on inside surfaces



B1.6 BASIC JOINTS AND JOINTS

This section applies to the repair of an interlay.

1. Cut the damaged portion after making for repositioning of the new panel. Clean and prepare both existing and new panels, removing all loose earth, debris, and paint from existing panel. Cut new panel to fit existing leaving a gap of 1/8" to 1/4" between joints up with the previously marked joint center line. Saw the two parts to be joined, leaving a gap of 1/8" to 1/4" between and using polyurethane sealant to achieve a perfect match. Joining plates (if needed) sections should be attached to the exterior of the panel with the aid of self tapping screws or pop rivets. Using chopped-strand glass fabric mat of the size to cover the 45 degree (45°) angle, together with resin and hardener, lay up to half inch to the underside of the joint, making an overlap of 8-inch (2-1/4") least in length in a perpendicular direction from joint.

2. After the repair has fully cured (see below), and set before, remove the joining plates from the exterior surface and all the top exposure and, hammering outward from the joint area, remove any air points in the process. Fill the 1/8" to 1/4" gap with sand using brush mixing and resin, and wash steel wool over the layer of sand. Chopped strand glass fabric mat together with resin and hardener, lay over the top of the lower glass cloth. Fill grain and resin coated together with brush and steel wool. Lay over one layer of fiber chopped strand glass mat together with resin and hardener. Allow resin to dry and lay over it a second coat not less than 1/8".

B1.7 - SUPERFICIAL DEFECT REPAIRS

Pin Holes or Air Voids

The only solution is to pack resin and fill the holes with a polyurethane repair filler. The two commonly used methods of filling these voids being one, cut the resin in advance and avoid to leave a larger hole with resin scattered voids, or cut the resin by dipping or "backing off".

SURFACE CRACKING

There are various degrees of surface cracking, but practically all can be sealed by epoxy resin or other seal damage. During an accident zone panels may flex.

If it is only to secure the surface to create a smooth non-slip immediate apparent damage to the resin surface. The cracking may not work the way through the panel surface but may be so deep that it is necessary when assessing accident damage to carefully examine all panels, particularly near cracks or spill bands and to canvas of resin. It may be possible to promote the appearance of the cracking by applying gentle heat.



Surface crazing itself generally stops at the first layer of glass fibre and is consequently not as structurally serious, but the extensive crazing near damaged areas should be taken as an indication of over stressing and the panel should be reinforced or replaced. It is not possible to merely craze by simply resurfacing with a further layer of resin.

Wrinkling or Distortion

This phenomenon is usually caused by exposure to severe heat. This can cause the resin to soften or glow and in doing so give way to any other more insulating material.

11.1.8 - REPLACEMENT SECTIONS AND PANELS

When the repair of a damaged vehicle calls for replacement sections and parts, they may be obtained direct from the manufacturer (see Section 11.1).

When access damage has been sustained, the damaged section of the underbody may be cut away, and a replacement section ordered or

- a) fabricated away any damaged underbody sections or before erecting replacement by the patched method of repair, positioning of bolts, lines etc. should be ascertained. Determine a method of correct positioning of replacement sections, such as the "RF" post strikers, "RF" post up or, rear bolt bolting, or any permanent features from which measurements can be made, and describe these clearly on the section which is to be used. Use a marker to follow the lines or which is a prepared to cut the section and study these lines thoroughly to see that:-

- a) any damaged section removed will, when correctly 'pick up' points on the replacement section to ensure it can be separately pick used.
- b) The prepared cutline dimensions (longitudinal, lateral and horizontal) definition points to ensure close fitting up of the new section at all three planes.

Underbody sections are available as follows:-

1. **Front half** - This section includes the bow section, front bulkhead, front of the underbody including the front seat belt bolting, the front section of both sidebars, both "RF" posts and both jacking points.
2. **Front quarter** - This section includes the front of underbody as far as the front of the tunnel, the front seat belt bolting, the front section of the underbody, 4 "RF" post jacking points, and part of the bulkhead.
3. **Centre** - This section includes part of the bulkhead, the front of the underbody as far as the front of the tunnel, all four rear seat bolting, the boundary of the underbody, both sidebars and part of the rear wheel arch including the "RF" post tie down points. The outrigger will be supplied separately.
4. **Mid section** - This section includes the middle of the underbody as far as the front of the tunnel, the rear seat bolting, the beginning of the petrol tank (over a part of the rear wheel arch including the "RF" post tie down bolting, the rear half of the underbody and jacking point.
5. **Rear half** - This includes the rear section of the underbody. The two rear wheel arches and half of both wheel arches. It will cover the whole width of the seat.



4. **Rear quarter** - This includes the rear section of the identity, the rear quarter labels and all of the sheet arch. It will cover half the width of the hull.

The front area of the hull, or bow of the LULAS, has been designed to provide "bite" of panel replacement. The rear of the hull has been designed with bumper panels.

The entire 18' port cover is 18' port covers are welded.

The 48" can be replaced in the conventional manner.

BOLTS - BOWBINS (METAL INSERTS)

Metal inserts are used at fastening points in the underbody to fasten secure and accurately located attachment points where high loads are involved. These inserts are used to fasten bolts of the following type:

As indicated by a red line number of Yale and certain pieces and are limited to the underbody after installation. The Yale bolt has a special spiral groove through the hole in the body and into the female half before being crimped over the hole. This is the hole in the underbody. These type of bolts have a diameter of 1/2" or 3/4" diameter, with different diameters applied to different parts of the hull.

Bolts Replacement

All bolts have been supplied complete with bolting, but if a bolt is to be replaced, for example after accident damage, follow the bolting procedure as indicated.

When the same area where the bolt is fitted has been fully repaired, you will require a new bolt for the bolting system. Select a new bolt with

11. The spiral length to provide enough protrusion through the female half of the bolt and hence protrusion of the spiral end to locate and fix the assembly.

Select a bolt of the bolting equipment the area around the hole or bolt hole in the body, and apply a hot wet epoxy adhesive as specified. Put the bolting on a bolt crimping tool. Complete the crimping operation, and allow the epoxy to cure.



BUNZON Legend

SN#	PART DESCRIPTION	REMARKS
A	10000 Lined - LH/RH	Banded Tapecover
B	10000 Lined - LH/RH	
C	Bound quarter bound RH, LH	
D	15000 Lined cover	Banded Tapecover Cover
E	15000 Lined cover	
F	Bound Tapecover	Banded Tapecover
G	Bound bound structure cover	Banded Tapecover
H	Book cover LH/RH	
I	Book spacer	
J	Book number - cover	
K	Book number - cover	
L	Book number and title	Banded Cover Cover
M	cover	
N	Book cover, front cover & back cover	Banded
O	Book cover cover	Banded Cover
P	Book cover cover	
Q	Book cover cover	
R	Book cover LH/RH	
S	Book backboard	
T	Book frame	




Upping Ms. 818-1 Panel



**METAL STRUCTURE BURNING LISTING**

REF.	PART DESCRIPTION	REMARKS
A	Outrigger x 2 Lx18x4	J
B	1/2" post cross beam	J Part of
C	1/2" post Lx18 x 2 Lx18x4	J Lx18 body
D	1/2" post cross beam	J Assembly
E	Track beam custom support	F

Drawing No. BJ-2 Steelwork





DL10 - INTERTRAY ASSEMBLY DAMAGE ASSESSMENTS

Check Critical Points for Body Damage

Special Tools

J. J. #0 - TRUCK110

Op. No.	Notes
1.	Open and close both doors.
2.	Remove driver's side front door 'H' post(s).
3.	Remove the trimmer trim from the underneath of the door frame 'H' in the inner leg.
4.	Put J. J. #0 underneath of the four locking bars, two 'A' post holes, and two 'H' post striker holes.
5.	If the jig fits all the above points, the center of the underline and the strings are correctly positioned as seen above.
6.	If the jig does not fit all the above points it will be necessary to carry out repairs.

Check Movement of Body and Robbin Security

In the event of an accident the following checks should be carried out on body and chassis:

1. Body Movement Visual Check

Check that the front edge of the front bulk head is not in permanent contact with the rear face of the front section of the chassis.

2. Robbin Security

Check that the composite material around each robbin remains undamaged.

This is particularly important in the:

- a) 'H' post fit tracks/rear wheel arch rubbing
- b) Rear suspension/beam rubbing
- c) Toe and heel beam rubbing
- d) Seat belt hold up
- e) Fuel tank security rubbing

**BJ.11 - REPAIR OF MINOR CRACKS AND GR. CHALKS**

The Logis of "A" or "B" and "C" cracks may be carried out in the same way.

- a) Repair of minor damage to the underneath of a panel.
- b) Repair of minor damage to the top coating of the top surface of a panel.
- c) Fixing of minor damage of the top surface of a panel.

d) Repair of a minor damage to the underneath of a panel.

Materials

- Resin
- 100% of chopped strand mat
- Acetone

Special Tools

- Chalk paper

If the cracks have gone through the panel it will be necessary to repair the damaged underneath of the panel as follows:-

Op. No.	Notes
1.	Thorough sand the underneath of panel around the cracks.
2.	Ensure area to be laminated is free from dust.
3.	Brush area with acetone.
4.	Apply 1st coat of resin to panel.
5.	Apply two layers of resin impregnated 100% chopped strand mat.
6.	Roll and tamp down.
7.	Apply 2nd coat of resin to chopped strand mat.
8.	Leave excess to cure in a temperature of not less than 15°C.



- b) Repair of minor damage to the gel coating of the top surface of a panel.

Materials

60 Grit paper

Black Gel Coat - Code 76270001

Code 61330 13300 10 grams per square

Special Tools

60 Grit paper

Seq. No.	Notes
1.	Sand panel to remove some cracks at all cost.
2.	These areas to be repaired as per para 2(a)
3.	Brush sanded area with acetone.
4.	Apply 1st coat of gel to sanded area
5.	Flame 2 layers of fibre glass tissue 10 grams per sq ft required on damaged areas.
6.	Roll and keep down.
7.	Apply 2nd coat of gel to fibre glass tissue 10 grams per sq ft required
8.	Leave gel coat to cure at a temperature of not less than 150C.

- c) Filling of minor damage of the top surface of a panel.

Materials

P35

Acetone

Special Tools

60 Grit paper

60 Grit paper

60 Grit paper

60 Grit paper



Step No.	Notes
1.	Sand outside of panel with 36 grit paper to remove surplus wax.
2.	Sand outside of panel with 50 grit paper to provide a key.
3.	Remove wax to be repaired as free of dust.
4.	Clean wax with acetone
5.	Apply filler to wax to be repaired ensuring surface is filled to slightly above surface of panel.
6.	Allow filler to harden at a temperature of not less than 150°.
7.	Using a 60 grit paper remove excess filler and ensure that contours of the repaired area follow those of the run.
8.	Sand sand with 80 grit paper to provide a better finish to the repaired area.
9.	Sand sand with 90 grit paper to provide a better finish to the repaired area.
10.	Sand sand with 120 grit paper to provide a better finish to the repaired area.
11.	Place the prepared area deep into red heater lamp for two hours. (HT65280) - Ensure the area does not overheat.
12.	Check for distortion or shrinkage.
13.	If distortion or shrinkage has occurred refill as necessary following the above procedure.

10.12 REPAIR OF MINOR SURFACE NON STRUCTURAL DAMAGE TO SILL.**Materials**

- 600
- 150
- Acetone

Special Tools

- 60 grit paper
- 80 grit paper
- 100 grit paper
- 120 grit paper

Step #	Notes
1.	Clean damaged area of sill and its surface with 60 grit paper to remove paint.
2.	Ensure that area to be repaired is free from dirt.
3.	Clean area with acetone.
4.	Apply 600 filler and leave for 30 minutes to harden.
5.	Sand 600 filling with 80 grit paper to fit contours of sill.
6.	Ensure that area to be repaired is free from dirt.
7.	Wipe area with acetone.
8.	Skip over 600 with 80 to fit contours of sill.
9.	Leave for 30 minutes under infra red lamp to harden. IMPORTANT - Ensure area does not overheat.
10.	Sand 600 with 80 grit and then 120 grit paper.

**61.13 INTRODUCTION TO BONDED PANEL REMOVAL**

The notes within this section describe removal procedures for the upper rear panels.

These panels are bonded in position with a flexible, self-healing adhesive.

When removing these panels it will be necessary to use the following special tools:

1. Pry Bar Tool See drawing no. B013-1
2. Wire Saw See drawing no. B013-1

It may be desirable to remove unbonded panels if they are removed carefully.

Before using any of the procedures to remove all traces of this adhesive and finish out the full re-finishing procedure (ie. Treat, Prime and Apply finish 12022).


Procedure of Dismantling Rear Bodywork

The following is the general sequence of dismantling the rear bodywork.

1. Remove hood trim.
2. Rear bumper.
3. Rear light covers.
4. Rear lights.
5. Disconnect and remove rear brake cable or box.
6. Remove hood storage lid.
7. Remove petal filler bezel.
8. Remove top shell.
9. Remove brackets.
10. Remove lower quarter mounts.
11. Remove 'H' post covers.
12. Remove 'G' post covers.
13. Remove skirts.
14. Remove 'E' post discharges.
15. Remove rear fenderhead.



drawing no. B113-1 Tools



Latus pencil Tool.



ALTM 50P.



BJ 14 - REMOVAL AND REPLACEMENT OF SKEL SECTION

Components and Materials

- 2" x 12" Ply or Skel
- 1/2" x 1/2" x 1/2" (shaped) urethane foam
- Resin
- Continuous Strand Matting
- Fiberglass
- 1/2" x 1/2" x 1/2" urethane foam square
- Jel
- Jet Primer

Adhesives

- Epoxy Bond 5100
- Boh's Wipe-On
- Kwik-Bond 5100
- Boh's Sealant

Special Tools

- Saw
- Utility Knife (with No. 100000)
- Planer, Rasp, Surfer and Buzze
- Measuring Tape
- Router
- 70 Grain Sandpaper
- 150 Grain Sandpaper
- 220 Grain Sandpaper
- 60 Grain Sandpaper (for Gun and Kettle)

Step	Notes
1.	Using the Long Panel, Port out, as necessary, and locate (marked) skel. Prime 70 gr. sandpaper and mechanical sander clean and adhesive from rotted and underlying.
2.	Using shaped section of skel mark out lines on new skel. To make backing pieces:
3.	Apply tape to cover a side area up to 1/2" either side of both cut lines on new skel and secure area around tape is free from cuts.
4.	Apply one coat of jet to tape and allow to dry.
5.	Apply two layers of resin impregnated flex. chopped strand mat to tape - roll & tamp down.
6.	Allow resin to cure at a temperature of not less than 120°.
7.	Remove the backing pieces and tape from skel. Finish making backing pieces:
8.	Using saw cut along both cut lines on new skel to create new skel sections.




Op. No.	Notes
9	Clean and repair bonding surfaces of old wall sections, use wall sections and backing strips - ensure all bonding surfaces are free from dust.
10	Apply Perma Bond 400 to old wall bonding surfaces of backing strips as per manufacturer's instructions.
11	Attach backing strips to old wall sections leaving at least 2" (50mm) protrusion from old wall section and secure with self tapping screws.
12	Clean new wall section backing strip bonding surfaces and ensure that it is free from dust.
13	Apply Beta Tape 200 to clean bonding surfaces of new wall sections, cut length and width to show a drawing no. B114-1.
14	Apply Beta Tape 200 to bonding surfaces of new wall section, subpages and order tray, as shown in drawing No. B114-1.
15	Apply Beta Seal 165 to bonding surfaces of new wall as shown in drawing No. B114-1.
16	Apply Perma Bond 400 to new wall bonding surface of backing strip as per manufacturer's instructions.
17	Fit new wall to subpages, order tray and backing strip ensuring 1/8" to 1/4" (3mm to 6mm) gap at each end and a Beta Seal bonding of new section with self tapping screws.
18	Mix Beta Seal 165 ready to cure.
19	When Perma Bond 400 has cured remove self tapping screws.
20	Apply 1/2" thick sand paper over both sides of subpages to be attached and feather to boards from the joint.
21	Grind both ends which are to be joined and free from dust.
22	Wipe both bonded areas with acetone.
23	Apply 2 layers of resin impregnated 1/2" chopped strand mat to each joint - roll ramp down.
24	Apply two layers of fibre glass tissue 30 grams per roll applied to each joint and staple down.
25	Staple lower end joint with 3 layers of gel.
26	Leave resin to cure at a temperature of not less than 75°C



Op. No.	Notes
17.	Bring 1/2 lb. of newspaper and back gate.
18.	Apply P-15 filler as necessary.
19.	Use down P-15 to seal crevices of sill.
20.	Put 1/2 lb. of newspaper and down filler.
21.	Bring 1/2 lb. of newspaper and down filler.

Drawing No. 0114-1, Replacement of Sill Section





EL-15 - REMOVAL AND REPLACEMENT OF BELL WITHOUT REMOVING 'A' AND 'B' POST COVERS

Components and Materials

- Bill with seal
- 1/2oz. USK (clipped strand) talc
- Sealant
- Outboard length cutting
- Amfloc
- Talcum
- Oil
- Oil

Adhesives

- Arma Bond 9515
- Seal Tape 1900
- Seal Tape 9410
- Seal Seal 8V13

Special Tools

- Oil
- Force Head (Flat) (Ductal)
- Seal Seal Dispenser and Nozzle
- Tube
- Wicket
- 100 grit sand paper
- 60 grit sand paper
- 120 grit sand paper
- Seal cartridge Manual cut and Nozzle

Op. No.	Notes
1.	Using wire cut through the seal to release bill from 'A' post cover.
2.	Using wire cut bill at rear end approximately 1/2" from 'B' post cover and remove the post.
3.	Using labor gear, foot pressure and remove bill from cut (1900)
4.	Using removed section of 2 1/2" make a fit the lines on new seal. To make backing piece.
5.	Apply tape to cover inside heel up to 1" either side of rear cut end of the bill.
6.	Ensure area around tape is free from dust.
7.	Apply one coat of 9410 to tape and allow to dry.
8.	Apply two layers of fresh (preprepared) 1/2oz. clipped strand talc to tape + seal and fair lead.




Op. No.	Notes
9.	Allow joint to cure in a temperature of not less than 15°C.
10.	Remove backing paper and tape from new skill. Pinch marking backing piece.
11.	Apply Beta Seal 4503 to joint line in new skill to create new skill section.
12.	Remove old skill under lapping section from underneath 'A' post.
13.	Clean and abrade joining surface of old skill, new skill and wearing surface and ensure all bonding surfaces are free from dust.
14.	Clean bonding surfaces of new skill and 'A' post.
15.	Expose area of skill and hardware area as free from dust.
16.	Apply Beta Band 4503 to old skill bonding surface of marking strip as per manufacturers instructions.
17.	Fit backing paper to old skill section leaving at least 2" (50mm) protrusion from old skill section and secure with self tapping screws.
18.	Apply Beta Wipe 4503 to clean bonding surfaces of new skill section, underside, 'B' post lower and fiber tray as shown in Drawing No. B115-1.
19.	Apply Beta Prime 4503 to bonding surfaces of new skill section, outtrigger, 'B' post lower and under tray as shown in Drawing No. B115-1.
20.	Apply Beta Seal II 4503 to bonding surface of new skill section as shown in Drawing No. B115-1.
21.	Apply Beta Band 4503 to new skill bonding surface of marking strip as per manufacturers instruction.
22.	Fit new skill to outtrigger, under tray and backing strips ensuring 1/2" to 1" (13mm to 25mm) gap at each end and 3 Beta Seal bond gap of 2mm - secure with self tapping screws.
23.	Allow Beta Seal II to cure.
24.	Once Beta Band 4503 has cured remove self tapping screws.
25.	Apply 80 grit sand paper over areas to be laminated.
26.	Seal the bulk edges of both joint to be laminated.



Op. No.	Notes
17.	Remove areas to be laminated as free from dust.
18.	Wipe sandblasted areas with acetone.
19.	Apply two layers of resin impregnated fiber chopped strand mat to both joints - roll and tamp down.
20.	Apply two layers of fiber glass tissue 30 grams per square foot to both joints and staple down.
21.	Cover both joints with a layer of gel.
22.	Leave resin to cure at a temperature of not less than 15°C
23.	Using a 26 grit sand paper rub down gel.
24.	Apply P39 filler as necessary.
25.	Rub down P39 to suit contours of hull.
26.	Using a 50 grit sand paper rub down filler.
27.	Using a 120 grit sand paper rub down filler.

Drawing No. D315-1 Replacement of Bilge without Removing 'A' & 'B' Post
Outform





W3.16 - REMOVE REAR TOP SHELL

Component

Rear Top Shell

Special Tools

Lotus Panel Tool 100071011

Hex Set

36 grit paper and mechanical sander

Note: Provided this panel is initially undamaged it may be re-used if removed successfully.

Before removing the rear top shell it will be necessary to remove the foot lid.

Op. No.	Notes
1.	Using the Lotus panel tool separate the rear top shell from the U.M. lower quarter, transition and L.M. lower quarter panels.
2.	Using the wiring nut separate the rear top shell from the rear bulkhead.
3.	Using the Lotus panel tool separate the rear top shell from the 'B' post and 'B' post cover.
4.	Using a 36 grit paper and mechanical sander remove all old adhesive from the above joining surfaces.

W3.17 - REMOVE TRANSOM

Component

TRANSOM

Special Tools

Hex Set

Lotus Panel Tool 100071002

36 grit paper and mechanical sander

Note: Provided this panel is initially undamaged it may be re-used if carefully removed.

Before removing the rear transom it will be necessary to remove the foot lid and rear top shell.

Op. No.	Notes
1.	Using the wiring nut separate the transom from the undertray.
2.	Using the Lotus panel tool separate the transom from the left hand and right hand lower quarter panels.
3.	Using a 36 grit paper and mechanical sander remove all old adhesive from the above joining surfaces.



BJ.18 - REMOVE LOWER QUARTER PANELS

Components

L.H. and R.H. Lower Quarter Panels

Special Tools

Router
 Lotus Panel Tool - 10000011
 36 grid paper and mechanical bander

Before starting removing the lower quarter panel it will be necessary to remove the boot lid, rear top shell & rear fender.

Op. No.	Notes
1.	Make a router cut through the rear of the lower quarter panel just above the undertray.
2.	Carefully cut along a line 1" above the undertray and following the rear wheel arch to the 'U' post cover.
3.	Using the Lotus panel tool separate the lower quarter panel from the 'U' post cover and discard.
4.	Using the Lotus panel tool separate the remaining section of the lower quarter panel from the undertray.
5.	Using a 36 grid paper and mechanical bander remove all old adhesive from the undertray and 'U' post cover.

Drawing No. BJ18-1 Lower Quarter Panels - Root Lines





BJ.19 - REMOVE 'B' POST COVER

Component:

'B' Post Cover

Special Tools:

Latex Panel Tool T00011077

36 qt Paper and Mechanical Sander

Note: Provided this panel is initially undamaged it may be re-used if carefully removed.

Before removing the 'B' post cover it will be necessary to remove the seat pad, rear top shell, rear transfer & rear lower quarter panel.

Op. No.	Notes
1.	Using the latex panel tool separate the 'B' post cover from the wall, cutligger and 'B' post diaphragm
2.	Using a 36 qt paper and mechanical sander remove all old adhesive from the above joining surfaces

BJ.20 - 'B' POST COVER

Component:

'B' Post Cover

Special Tools:

Router

Latex Panel Tool T00011077

36 qt paper & Mechanical sander

Op. No.	Notes
1.	Using router split the 'B' post cover down the middle.
2.	Using the latex panel tool separate the 'B' post cover from the 'B' post and discard.
3.	Using a 36 qt paper and mechanical sander remove all old adhesive from the 'B' post and front bulkhead etc.

**BJ 21 - REMOVE RTIG****Components**

RTIG

Special Tools

Letter Panel Tool No. 100071077
 36 Grit Paper and Mechanical Sander

Notes: Provided this panel is initially undamaged it may be removed if carefully removed.

Before removing the RTIG it will be necessary to remove the RTIG top shell, rear transition, rear lower quarter panel, 'B' post cover and 'A' post cover.

Op. No.	Notes
1.	Using letter panel tool remove the RTIG from the underbody and outriggers.
2.	Using a 36 grit paper and mechanical sander remove all old adhesive from the underbody and outriggers.

BJ 22 - REMOVE 'B' POST DIAPHRAGM**Components**

'B' post diaphragm

Special Tools

Letter Panel Tool No. 100071077
 36 Grit paper and Mechanical Sander

Notes: Provided this panel is initially undamaged it may be removed if carefully removed.

Before removing the 'B' post diaphragm it will be necessary to remove the front 'A' post top shell, rear transition, rear lower quarter panels and 'B' post covers.

Op. No.	Notes
1.	Cut in the fabric panels, then, cut separate the 'B' post diaphragm from the 'B' post covers, rear transition, underbody and outriggers.
2.	Using a 36 grit paper and mechanical sander remove all old adhesive from the above mentioned surfaces.

**B3.23 - REMOVE REAR BULKHEAD****Component**

Rear Bulkhead

Special Tools

Hex Set

Lotus Panel Tool 000010077

60 Grit Paper and Mechanical Sander

Note: If needed this panel is initially undraged it may be removed if carefully removed.

Before removing the rear bulkhead it will be necessary to remove the front lid, head top shell, rear upper and rear lower quarter panels.

Step No.	Notes
1.	Using wire cut and lotus panel tool set as necessary separate the rear bulkhead from the interior.
2.	Using 60 grit paper and mechanical sander remove all old sealant from the above identified surfaces.



BJ 24 INTRODUCTION AND SEQUENCE OF BONDED PANEL FITMENT

After refitting hood panels to this model care should be taken to ensure bonded surfaces are free of all old adhesive and the full rebonding procedure is carried out i.e. cleaning, bonding and applying fresh adhesive.

Where necessary jigs must be used to ensure the correct positioning of panels.

All face gaps are to be 2mm wide unless otherwise stated.

Self Seal 1-2 J requires 16 hours to cure and 24 hours to reach half strength.

The first page of this section offers a logical sequence of assembly for the major panels

These notes are written for each individual panel.

Fitment of Sealant Bonded Panels

Terminals	Sequence of Assembly
Introduction	
Developers to Undertray	1
'B' Foot Cross Brace and Tie Braces to 'B' Post	2
Console Base to 'A' Post	3
'B' Foot Diaphragm to 'B' Foot Cross Brace and 'B' Posts	4
Rear Bulkhead to Undertray	5
Front Bulkhead to Undertray	6
Wheel Drive Assembly to Front Bulkhead	7
'B' Bulkhead Floor Plates to Front Bulkhead	8
Steering Column Infill to Front Bulkhead	9
Roll Infill and Roll to Undertray and Outriggers	10
'A' Post Cover to 'A' Post	11
'B' Post Cover to 'B' Post	12
Rear Quarter Lower to 'B' Post Cover and Undertray	13
Rear Traps to Undertray and Rear Quarter Lower	14
Rear Top Shell to Rear Bulkhead, Rear Lower Quarter and Trusses	15
Roll Filler Before	16
Access Tray to Undertray	17
Rear Strip Mounting Strengthening Brackets to Undertray	18
Console Console Mounting Brackets to Undertray	19



sealants

There are three systems of adhesives used in repair

System 1

For joining fibreglass to fibreglass or both metal surfaces.

- Self Primer 1000
- Self Primer 5002
- Self Seal 1000.

System 2

For joining untreated metal to fibre glass

- Self Seal 1000
- Self Primer 5002 (50% MEK) the part primer
- Self Primer 5002 (50%)
- Mix two part primer in 1:1 proportions -
- Mix and apply for 20 mins - apply and leave for 1 hour - sand surface to surface.
- IMPORTANT: USE SOME MANUFACTURER'S HEALTH AND SAFETY REGULATIONS**

System 3

For joining treated glass to metal

- Self Primer 1000
- Self Primer 1001
- Self Seal 1001

Use the special 'special nozzle' Self Seal from manufacturers usually supplied.

1. Clean the sand inside of nozzle.
2. Apply 1000 to hole - 4mm from end of 1/2" of hole.
3. Apply 1001 at 45° to tangent of hole.

Note: Must not be used in conjunction with Manchester lat operated gun.

See drawing on page 10.

Always Self Seal 1001 to be used to cure before handling
 Self Seal 1001 coats the metal strands in the nozzle.
 Leave a thin bond gap between joints
 Self Seal has a 40 hour open life
 Self Seal applicator M1000001 Self Seal at 1000 K.O. One of Newbury.
 Contact: 0253 611111. 5pm - 6pm and 9am - 5pm on all bonded joints

Self Products may be obtained from -

Conal - Trade Tools Ltd.,
 17 Greenham Road, Burnley Industrial Estate,
 Burnley, Lancashire, BB10 7PP
 Telephone No. 0781 - 37037.



There are two systems of glue used in repair:

System 1

For joining the backing strips to the soil:
Beta Bond 900 (two part system in one tube)

System 2

Any of the following:
Analytix 2000 (2 parts)

Commercial products may be obtained from:-
Permasend Adhesives Ltd.,
Woodside Road,
Eastleigh,
Hants. SO5 4EN.
Telephone: 0-03 617121

Analytix Products may be obtained from:-
Brown Brothers Ltd.,
20-21 Flaggway,
City Trading Estate,
Berkel,
Norfolk, NR2 4HP.
Telephone: 0803 419232

Thickening wax 0.250" Part No. AD01434 may be obtained from
K. A. J. Mouldings (England) Ltd.,
Spa House,
Shelkanger,
Epsom, Norfolk. Telephone No. 0359 64260

Drawing No B/24-1 Beta Seal nozzle Design



**RF25 - FIT FRONT BULKHEAD****Components**

Front Bulkhead

Adhesives

Beta Mgt 1000

Beta Epox 5400

Beta Seal H V 1

Special Tools

Height Gauge

File Tip Marker

10oz Beals

10oz Abnco


1/2 Lbs 2000 Dry Gravel

Beta Seal Dispenser and Nozzle

Op. No.	Notes
1.	Position front bulkhead to undertray and ensure toe plate follows tie line up undertray toe plate supports.
2.	Check height from underneath of undertray to underside of front bulkhead top flange is 614mm.
3.	Move around front bulkhead so as to mark the correct position of the front bulkhead on the undertray using a file tip marker.
4.	Remove front bulkhead from undertray.
5.	Apply Beta Mgt 1000 to clean bonding surfaces of front bulkhead and undertray as shown in drawing no. B225-1.
6.	Apply Beta Epox 5400 to bonding surfaces of front bulkhead and undertray as shown in drawing no. B225-1.
7.	Apply Beta Seal H V 1 to bonding surfaces of undertray and on front bulkhead as shown in drawing no. B225-1.
8.	Refit front bulkhead to undertray and re-check height from underneath of undertray to underside of front bulkhead top flange is 614mm - ensure head gap is 2mm.
9.	Fit 4 bolts, washers and nuts to toe board and secure.
10.	Fit 4 x 1/2" self tapping screws through front bulkhead and toe board.
11.	Fit 2 x 1/2" self tapping screws through front bulkhead and toe board.
12.	Fit 4 x 1/2" self tapping screws through front bulkhead and tunnel.



Step No.	Notes
22.	Unblock height from underneath of underbody to underneath of front bulkhead top flange in 157mm.
24.	Remove excess Beta Seal from all joints.
25.	Wait 16 hours for Beta Seal to cure.
26.	Remove 4 bolts, washer and nut from top support.

Drawing No. W325-1 Front Bulkhead Bonding

13.76 - FIT DENTIST DUCT ASSEMBLY TO FRONT BULKHEADComponents

Dentist Duct Assembly

AdhesiveBata Nipe 2900
Bata Seal 5400
Bata Seal, H.V.S.Special Tool

Bata Seal Dispenser and Waffle


Op. No.	Notes
1.	Apply Bata Nipe 2900 to inner bonding surfaces of Dentist Duct Assembly and front bulkhead as shown in drawing no. B326-1.
2.	Apply Bata Seal 5400 to bonding surfaces of Dentist Duct Assembly and front bulkhead as shown in drawing no. B326-1.
3.	Apply Bata Seal H.V.S. to dentist duct assembly as shown drawing no. B326-1.
4.	Position duct assembly to front bulkhead and fit posts - ensure snug bond gap and distance from underside of undercut to the top of the forward edge of the dentist duct is 190mm.
5.	Remove excess Bata Seal from joints.
6.	Allow to harden for Bata Seal product.

Drawing No. B326-1 Dentist Duct Bonding

G01

ATTACHMENT

INTERNAL



**BJ-27 VLT HEATER VENTILATION AIR CONDITIONING DUCT PLINER TO FRONT MILKHEAD****Components**

H.V.A.C. Duct Pliner

Adhesive

Beta Kipe 1900

Beta Prime 5002

Beta Seal H.V.A.C.

Special Tools

Beta Seal Dispenser & Nozzle

2 Nuts & Bolts

Sp. No.	Notes
1.	Apply Beta Kipe 1900 to clean bonding surfaces of H.V.A.C. duct pliner & front milkhead as shown in drawing no. BJ27-1.
2.	Apply Beta Prime 5002 to bonding surfaces of H.V.A.C. duct pliner and front milkhead as shown in drawing no. BJ27-1.
3.	Apply Beta Seal H.V.A.C. to bonding surfaces of H.V.A.C. duct pliner and front milkhead as shown in drawing no. BJ27-1.
4.	Position H.V.A.C. duct pliner to front milkhead ensuring a 2mm bond gap.
5.	Fit 2 nuts and bolts and secure.
6.	Remove excess Beta Seal from joints.
7.	Leave 16 hours for Beta Seal to cure.
8.	Buzzle bolts and nuts.

Drawing No. BJ27-1 H Vac. Duct Bonding

BY

 DATE





84.28 - FEE SHEETING COLUMN INFILL TO FRONT BULKHEAD

Components

- Sheeting Column Infill
- Stud Plate
- Sheeting Column Infill Gasket
- Beta Seal

Adhesives

- Beta Wipe 1000
- Beta Prime 5602
- Beta Prime 2 part cyano/epoxy (PC1000)
- Beta Seal H.V.C.

Special Tools

- Beta Seal Dispenser and Brushes

Op. No.	Notes
1	Apply Beta Wipe 1000 to priming bonding surfaces of stud plate and front of front bulkhead as shown in drawing no. 8428-1
2	Apply Beta Prime 5602 to stud surface of front bulkhead as shown in drawing no. 8428-1.
3	Apply Beta Prime (2 part) to bonding surface of stud plate as shown in drawing no. 8428-1.
4	Apply Beta Seal H.V.C. to bonding surface of stud plate as shown in drawing no. 8428-1
5	Fit stud plate to front surface of front bulkhead and ensure a tight gap fit.
6	Remove excess Beta Seal.
7	Leave for 10 hours to allow Beta seal to cure.
8	Fit sheeting column infill gasket to stud plate studs from side of front bulkhead.
9	Fit sheeting column infill to sheeting column infill gasket and stud plate studs.
10	Secure sheeting column infill and gasket to studs with 4 nuts.

Note: Beta Seal cure may be faster after intermediate sheeting column is connected to rack.




Drawing No. 8328-1, Steering Column Infill Bushing

— 1/2" in diam
— 1/4" in diam



Drawing No. 8329-1, Rear Bulkhead Banding

— 1/2" in diam
— 1/4" in diam





12.25 - FIT REAR BULKHEAD

Components

Rear Bulkhead

Adhesives

Beta Wipe 1977

Beta Primer 1461

Beta Seal 4-3

Special Tools

Jig (1000071)

Urethane Bolt

Urethane Washers

Frame Top Marker

Beta Seal Applicator and Nozzle

Op. No.	Name
1.	Position jig to both 'B' ports and secure with 4 bolts.
2.	Position rear bulkhead to jig and undertray.
3.	Using frame top marker draw position of rear bulkhead on undertray.
4.	Remove undertray.
5.	Apply Beta Wipe 1977 to clear bonding surfaces of rear bulkhead and undertray as shown in drawing no. B029-1.
6.	Apply Beta Primer 1461 to bonding surfaces of undertray as shown in drawing no. B029-1.
7.	Apply Beta Seal 4-3 to bonding surfaces of bulkhead as shown in drawing no. B029-1.
8.	Refit rear bulkhead to undertray and secure with urethane bolts and washers. Ensure a bond gap of 1mm.
9.	Remove excess beta seal from all joints.
10.	Leave jig attached to assembly for 16 hours to allow Beta Seal to cure.
11.	Remove urethane bolts and washers.
12.	Secure bolts into jig.
13.	Remove jig.

**B3.30 - FIT THE POST DISAPPEAR****Components**

- 15" Post Dispenser
- 2 x 1mm Rivets
- 2 x 1mm Balls
- 2 x 1mm Washers
- Ball A - Male 1mm A475626165
- Ball B - Female 1mm A475622242

Indicators

- Ball 1/2mm 1X0
- Ball Prime 1402
- Ball 2/2mm 4 X 1
- Ball 1/2mm 17 1mm

Special Tools

- Ball A Comp. Tool 10000076
- Female Male
- 1/2mm
- Ball 2/2mm 1mm and 1mm


Step No.	Notes
1.	Place 2 post Dispenser across male & female parts of Ball A using Analytic handle.
2.	Place male part of hobbit through appropriate hole in 'B' post Dispenser making flat top of correctly positioned to act as bearing surface.
3.	Put 1mm & part of Ball B to male part and hang end of male part from hanging part.
4.	Rotate across Analytic from joints.
5.	Allow 15 second for glue to cure.
6.	Apply ball 1/2mm 3900 to bonding surfaces of 'B' post Dispenser, washers, 'B' posts, 'B' post cross brace and underlay as shown in drawing no. B330-1.
7.	Apply Ball Prime 1402 to bonding surfaces of 'B' post Dispenser, washers, 'B' posts, 'B' post cross brace and underlay as shown in drawing no. B330-1.
8.	Apply ball 2/2mm 4 X 1 to bonding surfaces of 'B' post Dispenser as shown in drawing no. B330-1.
9.	Position 2 post Dispenser to underlay, 'B' posts cross brace and washers (shown) and gap in line and Dispenser according holes close up.
10.	Fit 1/2mm 17mm along top edge & secure.



Op. No.	Notes
11	Remove excess Beta Seal from all joints.
12	Leave for 16 hours to allow Beta Seal to cure.
13	Remove C clamps.

Drawing No. NF 90-1 "21" Post, Blimpbrane Sealing

21
Blimpbrane Sealing
21





B1.31 - FIT STILL, INFILL AND STILL

Components

Beta Seal 1907 1/2 lb. 4 H / 2 L
 Beta Seal 1907 2 lb. 8 H / 4 L

Adhesives

Beta Wipe 4907
 Beta Primer 5402
 Beta Seal H.V.O. 1

Special Tools


Beta Seal Dispenser and Nozzle
 1/2" TORX bit

Op. No.	Notes
1.	Apply Beta Wipe 4907 to clean bonding surfaces of still infill and underlay as shown in Drawing no. B31-1.
2.	Apply Beta Primer 5402 to bonding surfaces of still infill and underlay as shown in Drawing no. B31-1.
3.	Apply Beta Seal 1907 to bond top surface of still infill as shown in Drawing no. B31-1.
4.	Fit still into the underlay.
5.	Apply Beta Wipe 4907 to clean bonding surfaces of still, still infill, underlay and surtigger as shown in Drawing no. B31-1.
6.	Apply Beta Primer 5402 to bonding surfaces of still, still infill, underlay and surtigger as shown in Drawing no. B31-1.
7.	Apply Beta Seal H.V.O. 1 bonding surface of still as shown in Drawing no. B31-1.
8.	Fit still to still infill, underlay and surtigger and ensure bond gap is 2mm and fill holes with Beta Seal H.V.O. 1 as shown in Drawing no. B31-1.
9.	Fit jig to secure still and still infill.
10.	Remove excess Beta Seal from joints.
11.	Leave for 24 hours to allow Beta Seal to cure.
12.	Remove jig.



Drawing No. B11-1 Sill and sill Infill Bonding

100
1000
10000



Drawing No. B11-2 Sill and Sill Infill Bonding

100
1000
10000



**RI.12 - PIT 'A' DOOR COVER****Component**

16' Door Cover (1 x 25 L)

Adhesives

Beta Wipe 3500


Beta Seal 5402



Beta Seal H.V.S.

Special Tool

beta seal dispenser and nozzle

Seq. No.	Notes
1.	Apply beta wipe 3500 to clean bonding surfaces of 16' post cover, 16' post, front bulkhead and sill as shown in drawing no. B112-1.
2.	Apply beta wipe beta to bonding surface of 16' post cover, 16' post, front bulkhead and sill as shown in drawing no. B112-1.
3.	Apply beta seal H.V.S. to bonding surface of 16' post cover as shown in drawing no. B112-1.
4.	Position 16' post cover to 16' post, front bulkhead and sill and ensure bond gap is 3mm.
5.	Remove excess beta seal from joints.
6.	Leave for 16 hours to allow beta seal to cure.

Drawing No. B112-1 'A' Post Cover Bonding

 16' Bulkhead
 Sill



SO 11 - P17 - 'B' Post Cover

Components

'B' Post Cover K/M/L/H

Adhesives

Beta Migs 3900

Beta Prime 5400

Beta Seal H.V.1.

Special Tools

Beta Seal Dispenser and Nozzle

Op. No.	Notes
1.	Apply Beta Migs 3900 to clean bonding surfaces of 'B' post cover, 'B' post, base/leg, outrigger and mill as shown in drawing no. 6333-1.
2.	Apply Beta Prime 5400 to leading surfaces of 'B' post cover, 'B' post diaphragm, valve/leg and mill as shown in drawing no. 6333-1.
3.	Apply Beta Seal H.V.1. to bonding surfaces of 'B' post cover as shown in drawing no. 6333-1.
4.	Install 'B' post cover to 'B' post, 'B' post diaphragm, valve/leg and mill employing hand app. as req.
5.	Remove excess Beta Seal from joints.
6.	Leave for 24 hours to allow Beta seal to cure.

Figuring No. 6333-1 'B' Post Cover Bonding



U.S. Army Corps of Engineers
Logis Service Notes

**BE.14 - REAR LOWER QUARTER LOWER R.H./L.H****Components**

Rear Lower Quarter

Adhesives

Beta Glue 1900

Beta Glue 5400

Beta Seal H.V.S.

Special Tools

Tig 100000114


Beta Seal Dispenser and Nozzle

Op. No.	Notes
1	Apply Beta Glue 1900 to clean bonding surfaces of rear lower quarter panel, 'B' post cover, undertray, rear bulkhead and sill as shown in drawing no. B734-1
2	Apply Beta Glue 5400 to bonding surfaces of rear lower quarter panel, 'B' post cover, undertray, rear bulkhead and sill as shown in drawing no. B734-1
3	Apply Beta Seal H.V.S. to bonding surfaces of rear lower quarter panel as shown in drawing no. B734-1
4	Position rear lower quarter panel to 'B' post cover, undertray, and sill, ensure bond gap in area and sill holes with Beta Seal H.V.S. as shown in drawing no. B734-1
5	Fit Tig 100000114 to secure lower quarter panel.
6	Remove excess Beta Seal.
7	Leave for 16 hours to allow Beta Seal to cure
8	Remove jig.




Drawing No. HJ34-1 Rear Lower Quarter Bending

— 1/2" Scale
— 1/4" Scale



Drawing No. HJ34-2 Rear Lower Quarter Bending

— 1/2" Scale
— 1/4" Scale



Full Size



REAR - REAR TRANSAXLE

Components

Rear Gear Set

Adhesives

Beta Prime 1970

Beta Seal 102

Beta Seal 103

Special Tools


Beta Seal Dispenser and Nozzle

Step No.	Action
1.	Apply Beta Prime 1970 to clean bonding surfaces of rear transaxle, lower quarter panels and undertray as shown in drawing no. 8J-35-1.
2.	Apply Beta Prime 1970 to clean bonding surfaces of rear transaxle, lower quarter panels and undertray as shown in drawing no. 8J-35-1.
3.	Apply Beta Seal 102 to bonding surfaces of rear transaxle as shown in drawing no. 8J-35-1.
4.	Position rear transaxle to undertray and lower quarter panels, and secure a bond gap of .001.
5.	Remove excess Beta Seal from all joints.
6.	Leave 24 hours to allow Beta Seal to cure.

Drawing No. 8J-35-1 Rear Transaxle Bonding

GM

 1970



VI. TO FIT REAR TOP SHELL**Components**

Rear Top Shell

Adhesives

Beta Mipr 3907

Beta Prime 3402

Beta Seal 3402

Special Tools

see 34020-12

Beta Seal Dispenser & Blade

Op. No.	Notes
1.	Apply Beta Mipr 3907 to upper leading surfaces of rear top shell, 10" post cover, 10" post diaphragm, lower quarter case panels and rear section as shown in drawing no. 8036-1.
2.	Apply Beta Prime 3402 to bearing surfaces of rear top shell, 10" post covers, 10" post diaphragm, lower quarter panels and rear section as shown in drawing no. 8036-1.
3.	Apply Beta Seal 3402 to bearing surfaces of rear top shell as shown in drawing no. 8036-1.
4.	Position rear top shell to 10" post cover, 10" post diaphragm, lower quarter panels and rear section - scrape 2mm bond gap.
5.	Fit top to ensure case panels are correctly conditioned.
6.	Remove excess Beta Seal from all joints.
7.	Leave 16 hours to allow 16 hours for Beta Seal to cure.
8.	Remove top.




Drawing No. KJ16-1 Rear Top Shell Bonding

BY

REVISIONS

REVISIONS





BJ 13 - FUEL PILLAR REBATE BRINDING

Components

Fuel Pillar Rebate

Adhesives

Beta Hipe 500
Beta Prime 5402
Beta Seal R V.

Special Tools

Beta Seal dispenser and 102219
Tape

No.	Notes
1.	Apply Beta Hipe 500 to clean bonding surfaces of fuel pillar rebate and rear top shell as shown in drawing no. BJ13-1.
2.	Apply Beta Prime 5402 to bonding surfaces of fuel pillar rebate and rear top shell as shown in drawing no. BJ13-1.
3.	Apply Beta Seal R V. to bonding surface of fuel pillar rebate as shown in drawing no. BJ13-1.
4.	Position fuel pillar rebate to top shell and ensure a bond gap of .001.
5.	Secure fuel pillar rebate to rear top shell using tape.
6.	Remove excess Beta Seal from joints.
7.	Leave for 16 hours to allow Beta Seal to cure.
8.	Remove tape.

Drawing No. BJ13-1 Fuel Pillar Rebate Brinding

BY: [Signature]
DATE: [Date]



**BJ-311 - FIT BATTERY TRAY TO UNDERTRAY****Components**

Battery Tray

Adhesives

Beta Mipc 3900

Beta Prime 5402

Beta Seal H.V.1.

Special Tools

Weights

Beta Seal Dispenser & Nozzle

Step No.	Notes
1.	Apply Beta Mipc 3900 to clean bonding surfaces of battery tray recess in undertray and battery tray as shown in drawing no. BJ38-1.
2.	Apply Beta Prime 5402 to bonding surfaces of battery tray recess in undertray and battery tray as shown in drawing no. BJ38-1.
3.	Apply Beta Seal H.V.1. to bonding surface of battery tray as shown in drawing no. BJ38-1.
4.	Position battery tray in battery tray recess ensuring bond gap is 2w & 2o2 and side upright surfaces of battery tray are in contact with battery tray recess in undertray.
5.	Place weights on battery tray to secure.
6.	Remove excess Beta Seal from joints.
7.	Leave for 10 hours to allow Beta Seal to cure.
8.	Remove weights.

Drawing No. BJ38-1 Battery Tray Recess

1 of 1
 1 of 1
 1 of 1



43.39 - FUEL STRAP MOUNTING STRENGTHENING BRACKET

Components

Fuel strap mounting strengthening bracket

Adhesives

Beta Kipe 1900

Beta Prime 5600

Beta Seal H.V.O.

Special Tools


Brush

Beta Seal Dispenser & Nozzle

Weights

Fiber Tip Marker

Op. No.	Notes
1.	Ensure pump cover is fitted to undertray.
2.	Locate fuel strap mounting strengthening bracket so that pump the cover may be removed and access obtained to the bobbin at rear of fuel strap mounting strengthening bracket.
3.	Trace fibre tip marker lines from around fuel strap mounting strengthening bracket to ascertain its correct position.
4.	Remove fuel strap mounting strengthening bracket.
5.	Apply beta kipe 1900 to clean bonding surfaces of fuel strap mounting strengthening bracket and undertray as shown in drawing no. B179-1.
6.	Apply beta prime 5600 to bonding surfaces of fuel strap mounting strengthening bracket and undertray as shown in drawing no. B179-1.
7.	Apply Beta Seal H.V.O. to bonding surfaces of fuel strap mounting strengthening bracket as shown in drawing no. B179-1.
8.	Reattach fuel strap mounting strengthening bracket to undertray - ensure top hard gap and freedom of access to lubber and fuel pump cover.
9.	Place weights on fuel strap mounting strengthening bracket to secure.
10.	Remove excess Beta Seal from joints.
11.	Allow 16 hours for Beta Seal to cure.
12.	Remove weights.

Drawing No. AI-29-1 Fuel Strap Mounting Bracket BondingDrawing No. AI40-1 Centre Console Mounting Brackets Bonding



NO. 60 - P19 T CONCRETE CONE/CL. FORMING BRACKETS

Components:

- Brackets: Casted Qty: 6,000,000/yr.
- Brackets: Purch Qty: 6,000,000/yr.

Adhesives:

- Beta Hapt 3905
- Beta Prime 3100 1500, 1000 and 2500 (10-85)
- Beta Seal 4100
- Beta Seal 4100

Special Tools:

- Brush
- Roller, Dispenser and Bottle
- Lot 700050112

Qty. No.	Notes
1.	Lubricate over wear areas with grease on assembly tunnel.
2.	Back position of brackets using fabric tag markers.
3.	Remove dirt.
4.	Apply Beta Hapt 3905 to clean bonding surfaces of brackets and tunnel as shown in drawing no. 6140-1.
5.	Apply Beta Prime 3100 to bonding surfaces of metal brackets as shown in drawing no. 6140-1.
6.	Apply Beta Seal 4100 to bonding surfaces of tunnel as shown in drawing no. 6140-1.
7.	Apply Beta Seal 4100 to brackets as shown in drawing no. 6140-1.
8.	1) Single brackets in front position - 1st pair of brackets in rear position.
9.	Ensure bond gap is 2mm.
10.	Remove excess Beta Seal from joints.
11.	Leave 16 hours to allow Beta Seal to cure.

**BJ 48 - INTRODUCTION TO UNDERTRAY REPAIRS**

The following is an introduction to the undertray repairs.

The repair of the undertray provides the largest, most detailed and time consuming work carried out by the G.F.P.P. and for safety reasons it is also the most important.

Each of the following sections contains detailed repair procedures plus list of components, materials, adhesives and special tools which will be required to replace the tank.

It is recommended that a careful study be made of the procedures, components, materials, adhesives, tools and drawings before commencing any repairs.


In many instances it will be necessary to remove panels and chassis from the tray before repairing the undertray.

When removing and replacing half an outrigger it is important to position the cut in exactly the correct position (see sub-tray drawing).

The outrigger strengthening plate will be provided as a spare part.

Drawing No. 3342-1 Undertray - Front Quarter - Cut Line

Undertray Front
Quarter Sections



**B3.42 - REMOVE FRONT QUARTER SECTION OF UNDERTRAY****Component**

Front quarter section of undertray - comprising of:-

- a) Front quarter section of Undertray.
- b) Front section of subchassis including '6' post.
- c) Side section of front bulkhead.
- d) Front parking beam.

Special Tools

See

Crusher

Wrench Set

Lobby Panel Tool (K021011)

Socket

Pliers


Welding Set


Op. No.	Notes
1.	Remove the seats and floor coverings.
2.	Remove the floor board.
3.	Remove the four bolts from the 'A' posts which secure the windscreen frame.
4.	On the adhesive between the windscreen and windscreen framing using the wrench set.
5.	Remove the windscreen and trim-off plane area.
6.	Remove the '6' post cover - using the crusher - the centre of the '6' post being and remove the pliers using the lobby panel tool.
7.	Mark the undertray as shown in drawing no. B342-1 and 2.
8.	Remove the two bolts which secure the tow bar to the chassis.
9.	Ensure that the scuttle box is disconnected from the relevant '6' post.
10.	Cut the undertray along the marked line using a cutter and saw as necessary.
11.	Cut the adhesive on the top of the 'A' post and underneath of the windscreen frame.
12.	Cut the adhesive on the '6' post and bulk head.




No.	Notes
15.	Using a section of the cartigger as shown in drawing No. BU42-4
16.	Remove and discard services from sections of student tray, on a road and cartigger.

Drawing No. BU42-2 Eynns Bulldozer - Front Quarter - Outlines



Drawing No. D147-1 Outrigger Strengthening SectionDrawing No. D142-4 Outriggers - Cut Line and Strengthening Section

Outrigger



REAR QUARTER FRONT SECTION OF UNDERTRAY**Components**

Four sections of undertray comprising of:-

- a) Front quarter sections of undertray.
- b) Front section of undertray including 1st part.
- c) Side section of bulkhead.
- d) Front jacking point.

Notes:- All the above supplied as per section.

Additional strengthening section

1st Top Rivets

1st Top Pop Rivets

Washers

Materials

1000 C S W (chopped strand mat)

8001R

Continuous length sewing

Never glass cloth 100 grams per metre squared

Acetone

Two Part Epoxy (Bona Epoxy 9901/III A and B)

Hex Spray

Adhesives

Bona glue 2001

Bona Paste 2402

Bona Seal H.V.3.

Special Tools

Fig. 100000010

Welder

Saw

Drill Press and Mechanical Bender

Plastic

Hex Bond Equipment

Hex Riveter

Bona Seal Dispenser and Nozzle

Welder


Op. No.	NOTES
1.	Get new sections of undertray, outrigger and front bulkhead to this job to be prepared.
2.	Position 1st to 2nd.
3.	Position new front section to side and undertray.
4.	Fit new front section into undertray, outrigger, front bulkhead and top accurately i.e. a gap of 1/8" to 1/4" (1mm to 3mm) should be maintained between both parts at the bulkhead and undertray while ensuring that the 1st fits comfortably in the 1st and 2nd points.




Op. No.	Notes
5.	Remove the new front section from the jig and using a 16 grit paper and mechanical sander, clean a "6" strip on both surfaces of both panel edges to be laminated. Feathering outwards from the joint line.
6.	Using a 36 grit paper and mechanical sander remove all old Beta Seal from the undertray, front bulkhead and underneath corner of windscreen assembly.
7.	Ensure that area to be bonded is free from dust.
8.	Wipe bonding surfaces of bulkhead, 'A' post and underneath corner of windscreen landing with Beta Hipe 3999 as shown in drawing no. 8102-5 & 6.
9.	Apply Beta Seals 5402 to bonding surfaces of bulkhead, 'A' post and underneath corner of windscreen landing as shown in drawing no. 8102-5 & 6.
10.	Apply Beta Seal H 971 to bonding surfaces of 'A' post front and top as shown in drawing no. 8102-5 & 6.
11.	Ensure the front section fits under tray, 'B' trigger, front bulkhead and jig accurately i.e. a gap of 1.5" to 1/8" (3mm to 6mm) should be maintained between both parts of the undertray, bulkhead and outtrigger while ensuring that the jig fits perfectly in the "pick up" and down points.
12.	Mark and drill and pin rivet the plates to the new front section and the undertray as necessary.
13.	Ensure that the area to be laminated is free from dust.
14.	Wipe sanded area with acetone.
15.	Brush resin onto underneath of joint.
16.	Apply two layers of resin impregnated fibre chopped strand mat to underside of joint - roll and tamp out.
17.	Allow resin to cure at a temperature of not less than 20°C.
18.	When joint on underneath has fully cured, drill out pop rivets and remove plates from top.
19.	Ensure area to be laminated is free from dust.
20.	Wipe sanded area with acetone.



Drawing No. H342-5 Outrigger Bonding



Drawing No. D342-b Front Hullhead Bonding





Step No.	Notes
1.	Apply resin to the remaining length screws and insert into joint.
22.	Brush resin onto top of joint.
23.	Apply one layer of resin impregnated flux, chopped strand mat to the top of the joint - roll and tamp down.
24.	Apply one layer of resin impregnated woven glass cloth (to cross pultruse aligned to the top of the joint) - roll and tamp down.
25.	Apply one layer of resin impregnated flux, chopped strand mat to top of the joint - roll and tamp down.
26.	Allow resin to cure at a temperature of not less than 15°C.
27.	Cut a small section of the fibreglass underlayment away from the outrigger to be covered as shown in drawing no. 3242-1.
28.	Knives & edge of 1/8" to 3/4" (1mm to 6mm) is maintained between both sections of the outrigger, while the "pick up" and "down" points fit comfortably on the jig. Secure the two sections of the outrigger together.
29.	Using a 16 grit paper and mechanical sander clean an area up to 3' (1m) either side of the joint on the outriggers and the strengthening section.
30.	Position and secure the strengthening section to the underside of the outrigger ensuring it fits centrally across the joint and the two sections of the outrigger align correctly with each other.
31.	Ensure that the outer edge of the outrigger remains at an angle of 17° to axis.
32.	Notes: For safety reasons, where all flammable materials (i.e. resin, acetone etc.) are removed from the work area. Ensure that the area is free from dust and well ventilated. Ensure that the dust extraction equipment is cleaned regularly.
33.	Juggle and stitch weld the strengthening section to the outrigger then measure the 'B' post cross brace and tie to the 'B' post.
34.	Using a 16 grit paper and mechanical sander clean all inside and surrounding area.
35.	Ensure that the area to be zinc primed is dust free.
36.	Cover all sanded, welded and strengthening plate areas on both sides of the outrigger by painting with a two part zinc rich primer as per the manufacturer's instructions to provide anti corrosion protection for the outrigger.




Step No.	Notes
27.	Using 60 grit paper and mechanical sander remove all old Beta Seal from the outtrigger and small section of the undertray.
28.	Using 60 grit paper and mechanical sander stain both surfaces of both edges to be laminated, feathering outward from the joint 2' away.
29.	Ensure that the area to be bonded is free from dust.
30.	Apply Beta Wipe 2000 to clean bonding surfaces on small section of undertray as shown in drawing no. B06275.
31.	Apply Beta Prime 8010 to bonding surfaces of small section undertray and outtrigger as shown in drawing no. B06275.
32.	Apply Beta Seal 8100 to bonding surface of small section of undertray as shown in drawing no. B06275.
33.	Fit small section of undertray to outtrigger and undertray and maintain a gap of 1/8" to 1/4" (min) to keep between small section and undertray.
34.	Fit large 2' long gap of gap between small section of undertray and outtrigger.
35.	Attach small and pop plates to the small section of the undertray and undertray.
36.	Ensure area to be laminated is free from dust.
37.	Wipe sanded area with acetone.
38.	Brush resin into underneath of the joints.
39.	Apply two layers of resin impregnated cloth, chopped strand mat to the underneath of the joint - roll and tamp down.
40.	Allow resin to cure at a temperature of not less than 150C.
41.	When the joint has cured, drill out the pop rivets and remove the plates.
42.	Ensure area to be laminated is free from dust.
43.	Wipe sanded area with acetone.
44.	Apply resin to continuous length - mixing and brush into joints.
45.	Brush resin onto top of joint.



Sp. No.	Notes
56.	Apply one layer of resin impregnated glass chopped strand mat to top of joint - roll & tamp down.
57.	Apply one layer of resin impregnated woven glass cloth 300 grams per meter squared to top of joint - roll and tamp down.
58.	Apply one layer of resin impregnated glass chopped strand mat to top of joint - roll & tamp down.
59.	Allow resin to cure at a temperature of not less than 15°C.
60.	Drill and install 1/4" pop rivets and washers to outside edge of undertray and nutrunner.
61.	Drill and install 1/4" hex pop rivets and washers to inside edge of undertray and nutrunner.
62.	Apply wax file to all surfaces of nutrunner both <u>inside</u> and <u>outside</u> as per wax file manufacturer instructions.

Drawing No. W411-2 Undertray - Front Half - Cut Line

Undertray Half Section



**BJ.47 - REMOVE FRONT HALF SECTION****Components**

Front half section comprising of:

- a) Front Half of Underlay
- b) Front Half of Both Outriggers including 'A' Posts
- c) Front Bulk Head
- d) Seatbelts
- e) Both Front Latching Points

Special Tools

File
 Router
 Hammer
 Wire Set
 Latex Panel Tool (ELECTRIC)

Op. No.	Notes
1.	Remove the body from the chassis.
2.	Remove all components from the front bulk head.
3.	Remove the four bolts from the 'A' posts which set up the windscreen frame.
4.	Cut the adhesive between the windscreen and windscreen leading using the wire set.
5.	Remove the windscreen frame and glass slide.
6.	Remove the front bulk head.
7.	Remove the seats, floor covering and all components attached to the floor section of the underlay.
8.	Remove the 'A' post cover - first strip the centre of the 'A' post covers and remove the pieces using the latex panel tool.
9.	Mark the underlay and cutriggers as shown in drawing no. BJ.47 and 3.
10.	Cut the cutriggers and underlay along the marked cut line using a saw and router as necessary.
11.	Remove the forward mounted front section.

REPAIR FRONT HALF SECTION OF UNDERTRAY**Components**

Front half section of undertray comprising of:

- a. Front Half Section of Undertray
 - b. Bolt Head
 - c. Washer Bolt
 - d. Bolt Front Sections of Substructure
 - e. Bolt Front Section Panels
- Note: (f). The above supplied as one section.

Substrate Strengthening Sections

1/4" Pop Rivets

1/4" Hex Pop Rivets

Adhesive

Materials

Resin

1100g. 0.3.4 (Chopped Strand Mat)

4000 grams 1000 100 grams per meter squared

Continuous length matting

Scissors

2 Part Epoxy (Beta Prime VP1700A and B)

dot Spray

Adhesives

Beta Prime 100

Beta Prime 500

Beta Seal 1000

Special Tools

Saw

Router

14 Grit Paper and Mechanical Tander

Jig 00007710

Snips/Cl

Rolling Set

Dot Spray 0001 0001007

Wire Set

Beta Seal Dispenser and Bottle

dot Spray Equipment

Op. No.	Notes
1.	Cut new section of undertray and substructure to suit area to be repaired as shown in drawing no. B264-1 & 2.
2.	Position jig to mat.
3.	Position new section to jig and undertray.



Sp. No.	Notes
4.	Remove new section into undertray, outrigger and jig accurately, i.e. a gap of 1/8" to 1/4" (.5mm to 6mm) should be maintained between both parts of the undertray and outriggers, while ensuring that the jig fits comfortably in the "pack up" and datum points.
5.	Remove the new section into the jig and using a 36 grit paper and mechanical sander, clean a 16" strip on both surfaces of both panel edges to be laminated, feathering outward from the joint line.
6.	Set the new section in the undertray, outrigger and jig accurately, i.e. a gap of 1/8" to 1/4" (.5mm to 6mm) should be maintained between both parts of the undertray and outriggers, while ensuring that the jig fits comfortably in the "pack up" and datum points.
7.	Sanding, drill and pop rivet brackets in the new section and undertray as necessary.
8.	Ensure that the area to be laminated is free from dust.
9.	Wipe sanded area with acetone.
10.	Brush resin into underneath of joint.
11.	Apply two layers of resin impregnated 15oz. chopped strand mat to underneath of joint - roll and tamp down.
12.	Allow resin to cure at a temperature of not less than 10°C.
13.	When the joint underneath has fully cured drill out pop rivets and remove plates from top.
14.	Ensure area to be laminated is free from dust.
15.	Wipe sanded area with acetone.
16.	Apply resin to continuous length fiberglass and insert into joint.
17.	Brush resin onto top of joint.
18.	Apply one layer of resin impregnated 15oz. chopped strand mat to top of joint - roll and tamp down.
19.	Apply one layer of resin impregnated woven glass cloth 300 mesh per meter square to top of joint - roll and tamp down.
20.	Apply one layer of resin impregnated 15oz. chopped strand mat to top of joint - roll and tamp down.



Step No.	Notes
20.	Allow joint to cure at a temperature of not less than 150C.
21.	Cut small sections of industry away from the area to be welded as shown in drawing no. 11.4.1.1.
22.	Prepare a gap of 1/8" to 1/4" (see to draw) as mentioned between both sections of the outliner, while the "pink" and other points fit correctly on the gap. Join the two sections of the outliner together.
23.	Using a 36 grit paper and mechanical sander clean an area up to 2 1/2" (635mm) either side of the joint on the outliner.
24.	Using a 36 grit paper and mechanical sander clean the outliner strengthening section.
25.	Position and secure the strengthened section to the underneath of the outliner ensuring it fits correctly across the joint and the two sections of the outliner align correctly with each other.
26.	Ensure that the side edge of the outliner remains at an angle of 12° as seen.
27.	Notes: For safety reasons ensure all flammable materials (e.g. resin, acetone etc.) are removed from the work area. Ensure that the area is free from dust and well ventilated. Ensure that the dust extraction equipment is maintained regularly.
28.	Bottle and match weld the strengthening section to the outliner.
29.	Using a 36 grit paper and mechanical sander clean all welds and surrounding areas.
30.	Ensure that the area to be zinc primed is free from dust.
31.	Cover all bonded, welded and strengthening plate areas on both sides of the outliner by painting with a two part zinc rich primer, as per manufacturer's instructions, to provide anti-corrosion protection for the outliner.
32.	Using 36 grit paper and mechanical sander remove all old Beta Seal from the outliner and small sections of the underlay.
33.	Using 36 grit paper and mechanical sander clean both surfaces of both edges to be laminated, feathering outwards from the joint line.
34.	Ensure that the area to be laminated is free from dust.
35.	Apply Beta Tape (see 11.4.4.2) bonding sections of new section of underlay and outliner as shown in drawing no. 11.4.1.




Op. No.	Notes
17.	Apply Beta Prime 5402 to bonding surfaces of small section undertray and subtrique as shown on drawing no. B343-6.
18.	Apply Beta Seal E.V.S. to bonding surface of small section of undertray as shown on drawing no. B343-6.
19.	Fit small section of undertray to subtrigger and undertray and maintain a gap of 1/32" to 1/4" (low to low) between small section and undertray.
20.	Spray a bond gap of 1mm between small section of undertray and subtrigger.
21.	Position, drill and pop rivet the plates to the small section of the undertray and undertray.
22.	Expose area to be finished to free from dust.
23.	Wipe bonded area with acetone.
24.	Brush resin into underarea of the joint.
25.	Apply two layers of resin impregnated 15oz. chopped strand mat to the underneath of the joint. Roll and Tamp down.
26.	Allow resin to cure at a temperature of not less than 15°C.
27.	When the joint has cured, drill out the pop rivets and remove the plates.
28.	Expose area to be finished to free from dust.
29.	Wipe bonded area with acetone.
30.	Seal resin to continuous length string and insert it to joint.
31.	Brush resin onto top of joint.
32.	Apply one layer of resin impregnated 15oz. chopped strand mat to top of joint - roll & tamp down.
33.	Apply one layer of resin impregnated woven glass cloth 300 grams per metre square to top of joint - roll & tamp down.
34.	Apply one layer of resin impregnated 15oz. chopped strand mat to top of joint - roll & tamp down.
35.	Allow resin to cure at a temperature of not less than 15°C.
36.	Drill and fit 1/4" pop rivets and washers to outside edge of undertray and subtrique.



No. No.	Notes
5.	Drill and fit 1/4" thick pop rivets and washers to inside edge of undertray and outrigger.
6b.	Apply wax film to all surfaces of outriggers both <u>inside</u> and <u>outside</u> as per wax film manufacturer's instructions.
19.	Note: Operations 22 to 58 must be carried out on both outriggers.

By using Sk. 0111-1 Outrigger Bracing

...
...
...





13.44 - REMOVE UNDERTRAY AND CENTRE SECTION OF UNDERTRAY

Components

- Centre section of Undertray consisting of -
 - 60110061
 - Front and rear jacking points
 - Centre section of undertray
 - Part of front bulkhead
- Note:** All the above supplied as one section

Special Tools

- Saw
- Utility knife
- Wire cut
- Latex Panel Tool (30001077)
- Roller
- Marker

Important: Ensure that the petrol tank has been removed before cutting this section of the undertray.


Op. No.	Notes
1.	Remove screws, floor and 'B' post dashboard covers
2.	Remove dash board
3.	Remove the floor bolts from the 'B' posts where securing the windscreen.
4.	Cut the adhesive between the windscreen and windscreen landing using the wire cut.
5.	Remove the windscreen and frame and place aside.
6.	Remove the rear panels, 'B' post cover, 'A' post cover and wire using the latex panel tool.
7.	Disconnect the 'B' post cross brace and cut close the base of 'B' post.
8.	Ensure scuttle beam is disconnected from base of 'A' post
9.	Mark the undertray as shown in drawings no. B044-L 6 & 7.
10.	Remove the 4 bolts securing the toe and heel boards to the chassis.
11.	Cut the undertray along the marked line using a router and saw as necessary.
12.	Cut the adhesive from the heel board using the latex panel tool.
13.	Cut the adhesive from the 'A' post/bulkhead



Sp. No.	Notes
14.	Cut the Sealant from top of 'A' post/underneath of screen landing.
15.	Remove and discard jagged section of undertray and outrigger.

Drawing No. B344-1 Undertray - Centre Section - Cut Line


undertray Centre Section



————— Cut Line



Drawing No. B444 2 Front Bulkhead - Centre Section - Cut Lines



**REFIT UNDERTRAY CENTER SECTION****Components**

Center Section of Undertray

Materials

Flow 2000W, chopped strand mat
 Transmuc Tough Resin
 Seal
 Kevlar glass cloth (to underlay over resin bonded sections)

Special Tools

1/4" TPOOP/10
 Masked
 Saw
 16 Grain Paper and Mechanical Sander
 Files

Op. No.	Notes
1.	Cut new center section of undertray to suit Undertray
2.	Position jig to mark
3.	Position new center section to jig and undertray.
4.	Remove new center section fits undertray and jig satisfactorily (i.e. a gap of 1/8" to 1/4" can be hand knived as required between both parts of the undertray while ensuring that the jig fits comfortably in the "pick up" and down points.
5.	Remove the new center section from the jig and using a 60 grit paper and mechanical sander, clean a "U" strip on both surfaces of both panel edges to be laminated, feathering outwards from the joint line.
6.	Using a 16 grain paper and mechanical sander remove all 700 grit from seal from inboard, underwash corner of windscreen landing and under tray.
7.	Refit the new section and ensure it fits the undertray and jig accurately i.e. a gap of 1/8" to 1/4" should be maintained between the new section and the undertray while the jig fits comfortably in the "pick up" and down points.
8.	Transducer, drill and tap (if not the plates) in the new section and the undertray as necessary
9.	Ensure the area to be laminated is free from dust
10.	Wipe sanded area with acetone.
11.	Brush resin into the underwash of the joint
12.	Apply two layers of resin impregnated chopped strand mat to the underwash of the joint - both end cap areas.



Op. No.	Notes
13.	Allow resin to cure at a temperature of not less than 25°C.
14.	When joint underneath has fully cured, drill out pop rivets and remove plates from the top.
15.	Ensure area to be laminated is free from dust.
16.	Wipe sanded area with acetone.
17.	Apply resin to continuous length covering and insert into joint.
18.	Brush resin onto top of joint.
19.	Apply one layer of resin impregnated woven glass cloth (300 grams per metre square) to the top of the joint - roll and tamp down.
20.	Apply one layer of resin impregnated woven glass cloth (300 grams per metre square) to the top of the joint - roll and tamp down.
21.	Apply one layer of resin impregnated woven glass cloth (300 grams per metre square) to the top of the joint - roll and tamp down.
22.	Allow resin to cure at a temperature of not less than 25°C.
23.	Drill out rivets and pop rivets (See B.4.17).
24.	Wax spray as per manufacturer's instructions.

**83.45 - REMOVE MID-SECTION OF UNDERTRAY****Component**

Mid section of Undertray - comprising of:-

- a) Mid Section of Undertray
- b) Rear Section of Outriggers Including 'B' Feet
- c) Floor Jacking Points.

Special Tools

SAW

Screw Driver (Flat Tip TORX10??)

Screw

Washer


Welding Set

Note: Ensure that the petrol tank has been removed before commencing with this repair.

Op. No.	Notes
1	Remove seats and floor covering
2	Remove 'B' foot assemblies.
3	Disconnect 'B' foot cross brace and tie brace.
4	Remove the bolts which secure the heel board to the chassis.
5	Mark the undertray and outrigger as shown in drawing nos. 83B-1 & 2.
6	Cut off/strip down floor section at heel board using Lotus power tool.
7	Cut the undertray and outrigger along the marked line using a chisel and saw as necessary.
8	Remove and discard damaged mid section of undertray and outrigger.



Drawing No. 1245.1 - Underbody - Mid-Section Cut-Inwards





REPAIR MID SECTION OF UNDERTRAY

COMPONENTS

Mid section of undertray comprising of:-

- a) Mid Section of Undertray
 - b) Rear Section of Outrigger including 10' Post
 - c) Rear Jacking Point
- Note: All the above supplied as one section.

Other required strengthening sections
 1 1/2" Pop Rivets
 1 1/2" Tank Pop Rivets
 Washers

Materials

- 1) 2x 2x4 (chopped strand mat)
- Resin
- Construction grade screws
- Green glass fibre 400 grams per mat square
- Resin
- Taxi Coat Primer (Fibra Primer 990109) & 2:1
- Rux Spray

Adhesives

- Resin 3900
- Resin 5400
- Resin 990109

Special Tools

- 1)ig JACKING POINT
- Knacker
- 40 Grit Paper and Mechanical Sander
- Files
- Rux Spray Equipment
- Resin 5400 Dispenser and Nozzle
- Roller

Op. No.	Notes
1.	Cut new mid section of undertray and outrigger to suit area to be repaired.
2.	Position rig to suit.
3.	Position new mid section.
4.	Secure new mid section into undertray, outrigger and rig securely, i.e. a gap of 1/16" to 1/8" (Max to min) should be maintained between the mid section and the undertray while ensuring that the rig fits snugly in the pick up and set down points.



Op. No.	Notes
7.	Remove the new mid-section from the jig and using a 36 grit paper and mechanical sander smear a 6" strip on both surfaces of both panel edges to be laminated feathering outwards from the joint line.
8.	Using a 36 grit paper and mechanical sander remove all old Beta Seal from the substrate.
9.	Ensure that area to be bonded is free from dust.
10.	Wipe bonding surfaces of the undertray and cuttrigger with Beta Wipe 2500 as shown in drawing no. B345-2.
11.	Apply Beta Prime 5400 to bonding surfaces of the undertray and cuttrigger as shown in drawing no. B345-2.
12.	Apply Beta Seal H.V.3 to bonding surface of undertray as shown in drawing no. B345-2.
13.	Replace the new mid-section and ensure it fits the undertray, cuttrigger and jig accurately i.e. a gap of 1/8" to 1/4" (3mm to 6mm) should be maintained between both parts of the undertray, cuttrigger and mid-section while ensuring that the jig fits comfortably in the "pick up" and datum points.
14.	Drill, file and prep rivet the plates to the new mid section and undertray as necessary.
15.	Ensure that the area to be laminated is free from dust.
16.	Wipe sanded area with acetone.
17.	Brush resin onto underside of joint.
18.	Apply two layers of resin wetted (for chopped strand mat) on underside of joint - roll and comp down.
19.	Place resin in cure at a temperature of not less than 150°
20.	When joint on underside has fully cured, drill out prep rivets and remove plates from top.
21.	Ensure area to be laminated is free from dust.
22.	Wipe sanded area with acetone.




Step No.	Notes
11.	Apply resin to the reinforcement length having and insert into joint.
12.	Brush resin onto top of joint.
13.	Apply one layer of resin impregnated glass chopped strand mat to the top of the joint - roll and tamp down.
14.	Apply one layer of resin impregnated woven glass cloth 100 grams per metric square to the top of the joint - roll and tamp down.
15.	Apply one layer of resin impregnated glass chopped strand mat to top of the joint - roll and tamp down.
16.	Allow resin to cure at a temperature of not less than 150°
17.	Cut a small section of the fiberglass underlayment away from the outrigger to be welded as shown in drawing no. 21437.
18.	Ensure a gap of 1/8" to 1/4" from the bond is maintained between both sections of the outrigger, while the "gap" will be a detail point for conformity on the job - Secure the two sections of the customer together.
19.	Using a 36 grit paper and mechanical sander clean all welds up to 2 1/2" (each) either side of the joint on the outrigger and the strengthening section.
20.	Position and secure the strengthened section to the underneath of the outrigger ensuring it fits centrally across the joint and the two sections of the outrigger align correctly with each other.
21.	Ensure that the outer edge of the outrigger remains at an angle of 12° or more.
22.	NOTE: For safety reasons ensure all flammable materials (oil, grease, acetone etc.) are removed from the work area. Ensure that the area is free from dust, and well ventilated. Ensure that the dust extraction equipment is cleaned regularly.
23.	Fiddle and stitch weld the strengthened section to the outrigger.
24.	Using a 36 grit paper and mechanical sander clean all welds and surrounding areas.
25.	Ensure that the area to be zinc primed is dust free.
26.	Cover all sanded, welded and strengthening plate areas on both sides of the outrigger by painting with a two part zinc rich primer as per the manufacturer's instructions to provide anti corrosion protection for the outrigger.



Drawing No. 6112-1-101-101-101

1/2" = 1'-0"





Step No.	Notes
33	Lay 30 gsm paper and vacuum in tank. Allow shell and seal form the underlayer and shell sections of the underlayer.
34	Lay 30 gsm paper and vacuum in tank. Allow both sections of both edges to be laminated, feathers are removed from the shell form.
35	Verify that the area to be bonded is free from dust.
36	Apply Beta Bond 100 to smooth bonding surfaces of shell and underlayer as shown in drawing no. B4472.
37	Apply Beta Bond 100 to bonding surfaces of shell sections of underlayer and underlayer as shown in drawing no. B4472.
38	Apply Beta Bond 100 to bonding surface of shell sections of underlayer as shown in drawing no. B4472.
39	Fit shell sections of underlayer to outer pipe and underlayer and maintain a gap of 1/8" to 1/4" (3 to 6mm) between shell sections and underlayer.
40	Remove a 1/2" edge of the between shell sections of underlayer and outer pipe.
41	Install an drive and use level the shell to the shell section of the underlayer and underlayer.
42	Remove area to be laminated is free from dust.
43	Wipe bonded area with acetone.
44	Brush excess into crevices of the pipe.
45	Apply two layers of resin impregnated 100 gsm paper to the crevices of the shell and underlayer.
46	Allow resin to cure at a temperature of not less than 100°.
47	When the pipe has cured, drill out the paper resin and remove the plates.
48	Verify area to be laminated is free from dust.
49	Wipe bonded area with acetone.
50	Apply resin to non-stress length mixing and inner pipe shell.
51	Brush excess into crevices of the pipe.



Q. No.	Answer
56.	Apply one layer of resin on prepared fibre impregnated strand and to top of part in 15 min. lay-up done.
57.	Apply one layer of resin impregnated strand glass cloth 150 gms/m ² fibre weight on top of the part in full and lay-up done.
58.	Apply one layer of resin on prepared fibre chopped strand and to top of part in 15 min. lay-up done.
59.	Keep the temperature of the tank than 15°C.
60.	Apply one layer of glass cloth and adhere to inside edge of mandrel in 15 min.
61.	Apply one layer of glass cloth and adhere to inside edge of mandrel in 15 min.
62.	Apply one layer of all members of techniques both <u>inside</u> and <u>outside</u> as per the lay-up procedure instructions.

**DL-66 - REPAIR BEAR OF UNDERTRAY****Components**

- 2/2 Quarter Undertray Bolt (as Bilt.) if necessary
- Span Bolt Undertray

Materials

- 1/2" Chopped strand mat
- 1/2" epoxy resin (with hardener)
- Resin
- Resin
- Woven Glass Cloth 50 grams per sq. meter required

Special Tools

- 1/2" Hex Bolt
- Marker
- 2/2 Undertray Bolt
- Span Bolt
- Big End Bolt
- Blade
- Utility
- 60 Grain Sand Paper and Mechanical Abrasive

Step	Action
1.	Mark out repair area as necessary around the damaged area of undertray to be replaced.
2.	Mark out repair area on rear cross member section of undertray as necessary using cut line on damaged undertray as a guide.
3.	Cut damaged undertray along cut line and remove.
4.	Cut rear section of undertray along cut line.
5.	Remove outer paper and systems of boards used. Use 60 grain sand paper on all joint edges of undertray and use undertray section fastening to secure from the joint lines.
6.	Remove the portion of undertray subject to undertray (leave a margin of 1/8" to 1/4" from the end).
7.	Install 2/2 and paper over holding plates across top of joints as necessary.
8.	Ensure area to be repaired is free from dirt.
9.	Prime damaged area with resin.
10.	Brush resin to underside of mat.
11.	Apply 2 layers of resin impregnated flex chopped strand mat to underside of joint.



I - 01	Notes
56.	Apply one layer of resin impregnation fabric (chopped strand mat) to top of joint (see 3J.5.4) top down.
57.	Apply one layer of resin impregnated woven glass cloth (50 g/area) to the inside of top of the joint. (mark and tarp down)
58.	Apply one layer of resin impregnated fabric (chopped strand mat) to top of joint (see 3J.5.4) top down.
59.	A. Use resin to fill gaps at temperature of not less than 180°
60.	B. 11" x 14" 14# polyimide and washers on outside edge of assembly (see 3J.5.4)
61.	B. 11" x 14" 14# polyimide washers and washers on inside edge of assembly (see 3J.5.4)
62.	Apply one layer of 4" wide resin impregnated fabric (chopped strand mat) to top of joint (see 3J.5.4) top down.



Drawing No. B146-1 Rear Junction Section - Cut Lane

SEE PLAN SHEET



Drawing No. B146-2 Rear Jct. Section - Cut Lane

SEE PLAN SHEET





1. No.	Notes
12.	Roll and hang down.
13.	Allow seal to cure in a temperature of not less than 32°F.
14.	When the joint underneath has fully cured, peel out the top pop rivet and remove the rivet from the top.
15.	Rivets are to be replaced in three rows (1-3).
16.	Apply sanding area with acetone.
17.	Apply sealant to rivet in row length 1/2 way and end of row rivets.
18.	Brush sealant into top of joint.
19.	Apply one layer of resin impregnated glass chopped strand mat to the top of the joint - roll and hang down.
20.	Apply one layer of resin impregnated woven glass cloth to inside joint with overlap on the top of the joint - roll and hang down.
21.	Brush the cover of resin impregnated glass chopped strand mat to the top of the joint - roll and hang down.
22.	Allow seal to cure in a temperature of not less than 32°F.

**93.47 - FIT OUTERWHEEL TO UNDERTRAY****Components**

- 1/2" dia. H.C.L.
- 1/4" dia. pins
- 1/4" dia. top pins
- Washer
- Wax spray

Adjusted

- Pin in hole
- Pin in place
- Wax Seal dry

Special Tools

- Dr. 10000113
- Pin
- Washer
- Key
- FILE 10-10000113
- Pin in hole
- Pin in place
- Wax Seal
- Pin in place
- Wax spray equipment

Job No.	Notes
1.	Function outerwheel to assembly and temporarily secure by inserting the end hole boards to undertray.
2.	Fit key and ensure 1/4" hole datum and a pin stacked holes are correctly positioned.
3.	Apply file to ensure hole and board outer edge is 90° to hole in position in the undertray.
4.	Remove the key and data pins from the undertray.
5.	Apply file steps 501 to 504 to bonding surfaces of undertray, undertray, 1/4" pin, bushing and a top hole of undertray bonding as shown in drawing no. 9310-1 & 2.
6.	Apply Beta Prime 501 to bonding surfaces of undertray, undertray, 1/4" pin, bushing and underneath of undertray bonding as shown in drawing no. 9310-1 & 2.
7.	Apply Beta Seal H.C.L. to bonding surfaces of undertray as shown in drawing no. 9310-1 & 2.
8.	Refit the pin to undertray and secure by bolting the top and hole boards to the undertray.
9.	Refit file and check positions of 1/4" hole datum and stacked pins to be in correctly positioned.



Sp. No.	Notes
10.	Use the range of air velocity needed to carry light dusts along with 75% velocity to carry a tracked pipe.
11.	Remove dusts - Note that force of air always
12.	Use 100 ft. of 1 1/2" pop rivets and washers to suspend beam of mid length. Use 100 ft. pop.
13.	Install and fit 1 1/2" wash pipe rivets and washers for 100 lb. concrete underneath and in pipe.
14.	Put 100 wash rivets into 100 ft. pipe - 100 rivets to leave 100 ft. pipe.
15.	Remove the wash rivets should be to size
16.	Remove the rivets
17.	Remove the rivets from the 100 ft. pipe
18.	Remove the
19.	Apply wash rivets to all rivets of 100 ft. pipe from <u>inside</u> and <u>outside</u> of pipe. See drawing for dimensions.

ILLUSTRATION - FIT SCUTTLE BEAM**Components**

- Scuttle beam
- Rivets
- Wash
- Washers
- Pipe

Sp. No.	Notes
1.	Fit the scuttle beam between the 100 ft. pipe. Use 100 ft. of 1 1/2" pop.
2.	Remove rivets of scuttle beam.
3.	Install rivets to 100 ft. pipe. Use 100 ft. of 1 1/2" pop. rivets and washers.
4.	Fit the scuttle beam and washers between 100 ft. pipe.
5.	Remove rivets of scuttle beam and apply to 100 ft. pipe. Use 100 ft. of 1 1/2" pop. rivets and washers. See drawing for dimensions.



Op. No.	Notes
12.	Apply new layer of resin impregnated (yarn) chopped strand mat - roll and carry down.
13.	Leave resin to cure in a temperature of not less than 100°.
14.	Remove thicknessing wax.
15.	Using straight edge and true line runner re-join lines of glass to find centre point of bobbin.
16.	Drill hole for bobbin along the centre of cross.
17.	See cut bobbin to under tray.

3.50 - FIT BOBBINS TO UNDERTRAY**Components**

R100 under tray

Bobbins

TYPE	POSITION ON TRAY	PART NO.	QTY
Male	Four wheel arms	AC0280486	4
Male	Body	AC75E2266	21
Male	The board	AC0280308	4
Female	Four wheel arms	AC0280485	2
Female	All other positions	AC0280309	26

Adhesive

Kwik-Bond 907

17 parts

Special Tools

Ratchet crimping tool and six screws

Kwik-Bond nozzle

Op. No.	Notes
1.	Slide 2 part adhesive around male and female parts of bobbin, using Kwik-Bond nozzle.
2.	Slide male part on bobbin through appropriate hole in undertray, ensuring that male is correctly positioned on and not wearing surface.
3.	Fit female part of bobbin to same part. Using end of male part as guide using crimping tool and six screws.
4.	Apply and remove excess Kwik-Bond from joint to produce smooth finish as shown in drawing no. B050-0. Allow 15 mins for cure to take.




Drawing No. W350-1 Boltin Positions in Undertray



Drawing No. W350-2 Boltin Positions in Undertray



Drawing No. W350-3 Asalidite - Smooth Finish



Asalidite - Smooth Finish



BLISA - KIT 'B' PORT TIE TRACK

NOTE: Kit includes 1 year warranty & detailed manual

Drawing No. BLISA-1 'B' Four Cross Beam and Two Bar Assembly



Kit Components

- Kit 1: 1x Top Cross Beam (Part No. 1001)
- Kit 1: 2x Side Bars (Part No. 1002)
- Kit 1: 2x Bottom Cross Beams (Part No. 1003)
- Kit 2: 4x Washers (Part No. 1004)
- Kit 2: 4x Nuts (Part No. 1005)
- Kit 2: 2x Brackets (Part No. 1006)
- Kit 2: 2x Pins (Part No. 1007)


Assembly Sequence

Step No.	Notes
1	Insert Washers 1 & 2 into Beam 1 & align with bottom holes
2	Insert & tighten 2 Pins (1) through 2 Side Bars
3	Put Top Bar over top track & insert pins (2) through the 2 top holes
4	Insert where it fits up gap between bar & bottom washers & tighten hole (1) with washer & nut to 10Nm
5	Tighten both (2) & remove top 2 Pins - insert & tighten both (2) into top of 2 Bars
6	Remove both Pins

Note: Torque Wrenches 15-121 (400-850Nm) for bolts (2), (3) & (4).




DA, SA, JIGS, ETC.




Exploded view of the
pump assembly.

FIG. 10



Exploded view of the
pump assembly.

FIG. 11





Body repair trolley

7250F01h



TRUCK GROUP J/C

- (A) 2ND A/B WINGS J/C
- (B) LHD A/B PERS J/C
- (C) RHQ QUARTER PANEL J/C
- (D) ONE QUARTER PANEL J/C
- (E) REAR TOP PANEL J/C
- (F) REAR F ANCH J/C
- (G) FLOORTRAY TOLLING POLE J/C



TRUCK GROUP



Rear balljoint (A)



000777

WARRANTY REGISTRATION

IMPORTANT: Before installing, use of vehicle, airbags and , are approved by agency. Also, to make an engine, use force with all relevant regulations relating to working design and overall and safety at work. All you are advised of, we do enough year, deal, less to and safety insurance as a local. All other things regarding any work, work done and, can accept no liability for any arrangement of such regulations by any third party repairs.


BOY FITTINGSSECTION Bk - 1700

	<u>Sub-Section</u>	<u>Page</u>
Door Assemblies	BR.1	3
Door Latch Mechanism	BR.2	4
Door Window Glass	BR.3	6
Door Window Lift Mechanism	BR.4	14
Door Mirrors	BR.5	14
1st Row Seats	BR.6	21
Front Trunklid	BR.7	21
Front Bumper/Splatter	BR.8	26
Rear Bumper	BR.9	26
Wheels/Tyres	BR.10	32
Shock Abs	BR.11	32
Seat Storage Lid	BR.12	34
Seat Top Rest	BR.13	34
Headlamp Mechanism	BR.14	36
Accessories & Miscellaneous	BR.15	40
Maintenance / Use Instructions	BR.16	45
Maintenance Data	BR.17	45
Seat General	BR.18	51
Appendix 1: Water Leaks, Area of Attention	APPENDIX 1	56
Appendix 2: Replacement of 1993 back headlamp by single probe type	APPENDIX 2	74



NA.3 - DOOR ASSEMBLY

Each door assembly comprises of an inner composite building, to which is bonded by polyurethane adhesive, a steel treated steel reinforcing beam carrying the door latch mechanism at the rear end, and the integral hinge arms at the front end. A composite outer skin panel is then bonded to this assembly with polyurethane adhesive. For some packages, including the USA, a door interlock locator sprig fitted near the bottom of the 'A' post, engages with an interlock eye on the door to help stabilize the door beam in the event of a side impact.



INSTALL

The two door hinge arms, integral with the door beam, are fitted with self-lubricating Glacier 'GU' bushes and pivot on steel hinge pins. The pins connect the hinge arms to hinge brackets bolted to structure which are themselves bolted to the 'A' post. One end of the hinge pins is tapered to aid assembly, and the other end is provided with a collar and head to aid removal. The pins are retained in the hinge brackets by the interference fit of a straight knurled section on the pins just beneath the head, whilst a chamfer at the tapered end of the pin provides a safety back-up.

Hinge Adjustment

When correctly adjusted, the shutline around the door edge should be approximately 2 mm, with the door maximum aligned with the front and rear wings.

To adjust the door sections:

1. On cars fitted with an interlock locator near the bottom of the door sill track, first remove the door latch panel and loosen the fixings securing the interlock eye to the door beam.



3. Hinge adjustment is achieved in the same way, but, if more is required, door pivots may be fitted (or removed from) between each hinge bracket and carrier.
4. Hinge adjustment is made by slackening the two bolts securing each hinge (except on the carrier (detached fixing bolt)). If this is insufficient, door pivots may be fitted (or removed from) between the hinge carrier and the post. When refitting a hinge carrier, seal around each fixing bolt of the hinge post with Astrofil. Completely seal one sealant hole just above the lower hinge carrier from fixing hole. When adjustment is complete, remove a nut on the hinge carrier hole in turn, and apply a small amount of Astrofil to each hole before sealant being and tightening the bolts.
5. When all nuts are satisfactory, or nuts are equipped, adjust the roller lock (roller eye on the rear end of the door body to align with the interlock square on the bar post). Tighten the fixings, and seal the gap between roller lock eye and door shell with Astrofil (use on a wash brush).

5. Remove door assembly

To remove an element when a door assembly is to be removed, the hinge pins should be withdrawn (either first removing the hinge brackets or carriers).

1. Remove the "K" post pins (see section BK-1).
2. From inside each end of the body, release the two door aspect connectors, and feed up through the body hole with the pinset.
3. Press out the spring pin securing the check strap to the "K" post.
4. Remove the spring clip from the tapered end of each hinge pin, and draw out each pin, the top pin downwards, and the bottom pin upwards. The pins have a straight neck, just beneath the head, which is an interference fit into the hinge bracket hole. Do NOT attempt to loosen a pin by turning, as the interference fit will be lost. A straight pull is required.

Slide the door in the reverse order to removal, noting that the hinge pins may not be lubricated, and that the upper pin must be fitted from below, and the lower pin from above, in a "T" format (after removal with the front lip set to zero).

The door assembly is retained by pins in gullies at each end, and an "A" system (flexi-rod) fasteners in addition to the front top end of the seal structure. A sealant between weatherstrips and door with Skaflex, and a strip of weatherstrips adhesive as shown, secures the rear end of the seal around the top rear edge of the door. If resealing the door, use a scalpel, block to carefully cut the adhesive and mark the weatherstrips to the seal.

7B-1 DOOR LOCK OPERATION


Each door lock mechanism consists of:

- a lock assembly with integral electrically operated central locking actuator, door ajar switch and interior lamps switch;
- an exterior key locking handle;
- an exterior release handle on the door rear end face;
- an interior release handle;
- an interior lock button at the top rear of the door;



A lock sensing switch mounted by a bracket to the bottom of the latch mechanism.

The doors are opened from outside by a locking with the key and turning the interior handle. When it does, cause the Hill Nation to unlink the outside release handle.



The external locking will operate from both the external key lock and internal lock button, but the doors can only be locked when both doors are closed. If a door is locked when either door is open, as caused only by the front latch is set, the central locking system will first operate to lock the doors, but after a two second delay, will unlock the doors again. This feature guards against inadvertently locking the car while the car is in the event of a flat battery. The driver will not operate, and both doors will be locked or unlocked manually. In an accident scenario, such as a bumper, the safety inertia switch will, in addition to the fuel pump feed being switched off, the ABS system will operate to unlock both doors.

For full electrical details of the above system, see section B1.


Adjustment

Before carrying out the adjustment, to the lock mechanism, first ensure that the door is closed and the battery, and if necessary adjust the battery level subsequent to B1.

The striker plate is located on the door, held by two Torx socket head screws, and should sit in a square fitting plate in the steel of the door. It is necessary to use a square fitting plate to allow the striker plate to be moved up/down to align with the latch mechanism, and its adjustment to adjust the door pull in and open lock compression, by the addition or subtraction of the plate between the striker and the door plate. Adjustment of the striker loop may be achieved with the latch mechanism.



If the striker is removed, ensure that the components are assembled in the reverse order - the seal plate fits with its fork well against the body, followed by the striker shank, then the striker plate.





Control Rod

The 'W' post and lock rod(s) are all to be aligned with the tapping plate assembly. The direction of part of the control rods to the tap base (1) is indicated by mark handle and extension screw. It is to be aligned to avoid stress which arises with pressure.

(2) The lock rod is inserted into the tapping mechanism with the seal as the end. The lock rod clip at the end of the rod is attached to the tapping mechanism to avoid the rod slipping out of the end of the tapping mechanism.

The tapping lock button is set out to the bottom and by a retaining pin in the lock rod. The retaining pin is removed for the tapping with seal will usually require removal.

When fitting the button, ensure the end of the button is in the bottom so that the bottom edge of the clip is 100 to 120 mm from the tapping mechanism and press on the end of clip.





Adjustment of Latch & Lock Components

Latch Adjustment:

1. Remove the door glass and the glass seal gasket from the door (see section 10.1).
2. Connect with the universal code lock the latch mechanism.
3. Apply the two universal components, first the motor arm and the secondary to the lock handle pattern.
4. Apply the frame to lock mechanism the return mechanism to PIN Outer, and adjust the handle lock.
5. With the latch retractor in the retracted position, ensure that the cover is released handle is not tilted.

Exterior Release Handle Assembly:

1. The exterior release handle is retained by a hexagonal screw, and the cover handle assembly is retained by three M3 nuts and hexagonal screws.



If the handle assembly is dismantled, check that its lower end is fitted to a metal support plate. This assembly is achieved by using the universal support bolt. The door plate and gasket were tested only in early runs and may be omitted.



The cover of lock barrel is retained in the door by a spring steel clip which has a hole to aid its removal.






55.1 - DOOR WINDOW GLASS

The door window glass is electrically operated, and is fitted with two nylon leveling blocks fixed to its front edge, and two nylon bobbins at the rear edge. These sliders operate vertical channels fixed inside the door shell, which move the glass as it travels up and down. The top portion of the glass is centered on nylon nylon "bobbin" fixed to the lower edge of the glass, which sits against "U" shaped wedge brackets bolted to the inside top of the door shell.

Door shown with outer glass & inner beam removed for clarity




Adjustment of the Glass

Before any adjustment to the door glass position is attempted, first ensure that the roof top rail is correctly adjusted (see later). The fit of the raised front glass to the roof rail and upper roller assembly may be improved by the removal of wedge adjustments. The raised height of the glass should be adjusted so that the top edge of the glass fits snugly into the raised weatherstripping. The bottom edge of the glass should rest on the roller. To adjust the upper edge, lower the glass, remove the glass from the roller (see section 55) and door speaker. Slacken the nylon wedge bracket mounting bolts at front and rear. The front bracket fixings

Rear wedge
uptop fixings

Front wedge
uptop fixings





and adjustment behind the door releases handle. Make sure the movement of the latch is unimpeded by the seal and that the glass is exactly the fit.

• **Remove lock adjustment.** The insert clip on the glass should be adjusted to the correct level of the periphery of the window glass, makes light contact with the weatherstripping on the door, gully and seal and within 10 mm. The clip may be adjusted by adjusting the lower, elevated, springs, securing the bottom end of the front and rear guide through a hole in the door shell. Use screws inside an exterior to be installed. Also adjust the window lift channel mounting bracket to give correct alignment and allow the lift channel to ride in the guide channels. Tighten all mounting after adjustment.

Removal of Glass Panels


- Remove the door trim panel, door lock, door speaker, and the seal where needed, with the window handle.
- Remove both upper and lower trim from the inner edge of the glass by releasing the angle clips, starting with location of the relay capping plate.
- Release the lifting strap from the glass by pulling off the plastic trim from the top edge and off the strap anchor, and slacken by the lower end of the lift channel to allow the strap spring to be withdrawn into the glass.



- Withdraw the glass upwards and out of the door.

Reassembly of Door Glass

- Check ensure that the following parts are fitted into the door:
 - weatherstripping seal;
 - inner and outer glass support rails;
 - weatherstripping channel assembly;
 - front and rear door channels;
 - front and rear top window brackets.
- Assembly of glass blocks:
 - Check that the weatherstripping is correctly seated to the door edge (lower edge of the glass) if necessary, reseat using Wetcoat adhesive. Primer the edge use to seal for the weatherstripping. The channel should be parallel with the glass top edge. Insert the channel to the glass with a plastic beam, weatherstripping, the weather and nylon nuts.
 - Apply Wetcoat 400 to the top edge in the plastic bushes and glass recess.
 - Apply Wetcoat 400 to the top edge in the plastic bushes and glass recess.
 - Apply a drop of Wetcoat F20 (600000400) to the lower edge of the weatherstripping, between the top window bracket and the glass block.





inserting bobbin. Position the tape using guide. In the same way, fit another bobbin to the top end, but do not use a special washer.

2. Fit a slider block to each of the winding rollers and adjust with a flat screw and M screw with a edge of Parbond filed applied to the thread. Tighten the screw. Be certain that the slider will slide about 10 mm.

3. To reach the slider winding rollers to the front edge of the glass container with a guide. First, set on the side of the lifted bobbin the support to thread roller and set top roller and adjust the bobbin on the track. Note that an M screw is fitted at the top position, and a turn bobbin at the lower front position. To the top of the thread roller to the upper thread roller. Refer to reference.

4. Fit a slider block to each of the front winding bobbin and adjust with a flat screw and M screw with a edge of Parbond applied to the thread.


Note that the top slider block is slanted at its upper end. Tighten the upper M screw. Check bobbin that the rollers are still able to turn.

5. Fit rollers into each of the slider blocks:

- Upper front sliding roller in lower cavity;
- Lower front sliding roller in both upper and lower cavities;
- Upper rear sliding roller in lower cavity;
- Lower rear sliding roller in upper cavity.

6. Lubricate the slider blocks with petroleum jelly.

7. Fit the glass into the top with the upper blocks engaged in the guide channels. Fit the two spring bobbins to the lower edge of the glass, with double sided tape or a piece of paper fitted between the glass tapping plate and the glass.



8. Fit the spring of the lifting clamp on top of the glass, and secure with the plastic clip. Adjust the lower end of the lift channel to be in alignment with the guide channels.


9. Set up the glass position of the cavity, as detailed above.

Four Glass Internal Tape Seal

A brush type seal is attached to a carrier which is clamped to the top of the box shell inner panel. A rubber bumper strip is fixed over the seal carrier, and fits over the top of the box top panel.

**By worker:**

- Remove the door trim panel.
- Remove the 4 screws securing the finisher strip clamping plate, and remove plate. Carefully peel finisher strip from its double-sided tape.
- Remove the screws securing the disintegrated rear end of the brush seal carrier. Drill out the 5 screws securing the brush seal carrier to the door. Use case the carrier from the door, using a blade if necessary to release the sealant in the joint between carrier and door.


**By helper:**

1. Clean any sealant from the top edge of the door shell, and underside of the seal carrier. Apply primer (000206199) to the underside of the seal carrier and top of the door shell. Allow to dry.
2. Apply a 3/8-in. length of double strip (000996109) to the underside of the seal carrier, aligning with the edge and ends.
3. Fit the carrier into the door and push fully forwards with the carrier rear end held hard against the rear face of the door shell. Secure the seal carrier against the door with 5 pop rivets. Secure the rear end tag with 4 screws, corner and replace nut.
4. Apply primer (000206199) to the top surface of the brush seal carrier, and to the underside of the finisher strip. Allow to dry.
5. Fit a length of double-sided tape (010006009) to the top of the brush seal carrier, with the edges and ends aligned. Fit the finisher strip onto the tape with the edges and ends aligned, and press down firmly.
6. Fit the clamp plate into the finisher strip, with the edge turned upwards, and the cut-out inboard. Use a screwdriver to locate the fitting holes in the brush seal carrier, position the finisher strip accordingly, and secure the clamp plate and finisher strip with 4 screws.
7. Refit the door trim panel.



External Wipe Seal


The door glass external wipe seal is secured inside the door outer panel top edge by 20 screws. The screws are shown above only with the door to a panel and that window glass removed. See notes on the inner door panel.



Glass Support Pads

Two outer support pads and two inner pads are fixed inside the top of the door shell to provide additional support to the door glass.

Each of the outer two pads are secured to the outer door shell with two screws and washers screws fit only with the door glass removed. The position of the inner pads, which are fixed to the inside of the inner door shell with a single screw and washer, should be adjusted so that the pads rest flush the door glass in the lowered position.



**BE-1 - DOOR WINDOW LIFT MECHANISM**

The door windows are controlled by two switches on the center tunnel, one on each side of the parking brake lever. The windows operate only with the ignition switched on, when a white dot marker on each switch is illuminated to help locate the controls. Pressing the front, closed end of the rocker switch lowers the window, and pressing the rear, pulled out end, raises the glass.

An electrical motor and cable mechanism within each door, uses a lift cable to guide a plastic clamp which is slipped through the glass. The top and bottom of the lift channel are fitted with pulley sheaves to guide the lift cable, and spring loaded outer cable terminals maintain tension on the cable to take up any slack. The complete assembly of motor/lift cable/lift channel, is serviced only as one unit.


Removal of Motor/Cable/Channel Assembly

1. Release the door glass from supports, and motor dripshields.
2. Release the angle fitting the securing the top of the lift channel to the door, and the angle nut securing the bottom of the lift channel to the mounting bracket.
3. Release the blow out seal, securing the motor in the door, disconnect the wiring harness, and withdraw the complete assembly through the door access hole.

See 1 for reverse order.

SE-1 - DOOR MIRRORS

The door mirrors are mounted to the doors via a spring pivot which enables the mirrors to move forwards or backwards on accidental contact, and then return to their fixed position.





To remove a loose assembly, remove the door trim panel, disconnect the mirror harness, and remove the three brass nuts of the mirror assembly to the door shell.

1. Install a door mirror.

Check that the door is fitted over the mirror flange so the door shell nut is feeding the mirror harness connector plug through the flange and into the door shell. Insert the flange in door trim. The hole in the flange

2. Retain the mirror using the three BA screws and washers, and tighten to an 110 in/lb in.


Slide in the mirror harness connector to the door harness, and insert the harness clip in the door shell hole.

3. Retain the door trim panel.

MP1 - DOOR TRIM PANEL

The exterior body panel between the door and front wheel arch, is secured by three screws, and must be removed prior to reaching the front chassis.

To remove a MP1 trim panel, mark the two screws securing the lower edge to the shell, and remove the top and bottom of the trim at the top rear edge of the panel, lifting the panel to the top shell bracket. Tilt on the lower edge, and then pull downwards. All fixing points are open slots. Disconnect the side repeater lamp harness, at the same time, as shown.



MP2 - FRONT WHEEL ARCH


The front wheel arch is a composite retaining comprising of mesh upper front wheel and the lower landing platform. A fault can make dust or debris penetrate to both sides of the topshell, but is limited only for right or left hand drive. The topshell is secured by 19mm threaded fasteners, and may be removed for approved access (air filter, coolant etc).

Topic: Removal

1. Disconnect battery



1. Remove the front bumper/petlet (see 3B.9).
2. Disconnect the suspension washer tubing, about 1/2" to 1" from the hinges, and remove the fender panel.
3. Remove the lower fender panels by loosening the two screws securing the upper edge to the sill, and removing the rod from the slot at the top rear edge of the panel, fixing the panel to the topshell bracket. Pull out the lower edge, and then pull down-side. All fixing points are open slots. Loosen the wide repeated large harness (note 3B section 2) and pull the harness with its bracket through the bulkhead.
4. Remove the front shielded line(s), and remove the shielded cutler pipe between transducer and plunger intake base. Disconnect the rear intake duct from the bulkhead adapter on the passenger side.
5. At each headlamp motor, disconnect the electrical cable, plus the ground connection, and remove the bolt securing the front bulkhead to the top of the motor. Via the access holes in the shield(s), remove the two bolts securing the motor to its mounting bracket, and remove the motor. Remove the three bolts securing each headlamp motor, see 3C bracket to the chassis.
6. At the right hand side, disconnect the speed gauge transducer base. At the left hand side, label and disconnect the vacuum hoses to the vacuum solenoid valve (1) in 3B and separate the pressure hose (2) wire.
7. Release the hornet (1) in 3B, disconnect the top shell (2).
8. Release the plunger (3) in 3B, disconnect:
 - a. all harness (1) in 3B, plus all other wires (2) in 3B
 - b. earth leads from the ground harness, but save the leads to go on the hornet to earth lead (3) in 3B, plus the hornet (4) in 3B
 - c. outline the harness connection (behind left hand bed shell), remove standard cable connections (about at left hand side), for connection to the pressure down pressure valve.
 - d. the three cables on the reverse light switch harness.
9. Access the topshell (1) in 3B:
 - a. Two screws, one at each rear end, securing the topshell to the front bulkhead. Note any pressure fittings.
 - b. Two screws at each side, securing the top shell edge to the body near the base of the wind posts.
 - c. One screw, one at each end, the top of the suspension (1) in 3B.
 - d. One screw, one at each end of the suspension (2) in 3B.
 - e. One screw, one at each end of the headlamp (1) in 3B.
 - f. One screw, one at each end, one on each side, just inboard of the headlamp (2) in 3B.
 - g. One screw, one behind the hornet (1) in 3B.
 - h. One screw, one above the front of the shield (1) in 3B, and release the cable valve harness, securing the topshell to the cabinet (1) in 3B.
 - i. One screw, one below the suspension, but and upper bearing, securing the front of the topshell to the chassis, but not through the top of the suspension (1) in 3B, plus the cable through the front bulkhead of the chassis (1) in 3B, situated inboard of the chassis frame (1) in 3B, one on each side of the front left side.



- 1) Lay the top shell on the prepared adhesive along the inside inner edge of the base of the bulkhead. With the aid of an assistant, lift the topshell up and off the base, taking care not to allow the panel to twist or to slide. Make sure to note the position and number of spacer washers fitted at any of the fixing points.

Special Notes:

Follow the general procedure, but use the following points:

Check that the anti-static self-adhesive foam strips are fitted to the interior of the topshell (see table, if necessary fit new foam, not foam J&R 6067), as shown in the drawing.

- ensure that the topshell bulkhead is fitted correctly to the underside of the topshell;
- Check that the bronze release cable is fitted into position and connected to the launch mechanism;
- Align the rear edge of the topshell to align with the front edge of the base;
- At each fixing point, measure the gap between topshell and structure, and fit spacer washers, as necessary to avoid any stressing of the composite panels, which could result in the projection of gel marking;
- Apply a correct torque command to the topshell fixing screws.



Check that there is sufficient clearance between the cut out at the back of the 20 pin unit and the 200 rivet. Scuff-ride if necessary.



Fitment of foam STRIPS to underside of topshell



The final operation is to seat each (L) and (R) side of the topshell to the car shell:


- (1) At each side of the car, pass off the lower edge of the windscreen and the outside face of the topshell adjacent to the windscreen base.
- (2) Apply a bead of Sikaflex (AUSPHEL 47) between the screen and topshell as shown in the diagram, and use a spatula to push the sealant down into the gap. This is not a new task. The only change is that if sealed, any subsequent topshell removal will be made difficult.





BK.2 FRONT BUMPER, SPOLLER

The front bumper/spoiler consists of a low front location (positioning) mounting (PRM) which is bonded to a stiffening and shock absorbing composite structure. The structure is bolted with mounting brackets, which locate in the fixing holes on each front corner of the chassis front frame, see 486 specification card, to energy absorbing polyurethane elastomer (EAP) which is bonded to the front frame, see 111. In the space between the chassis and bumper structure, 140 models also include energy absorbing foam polyurethane (EAP) located in 591P space. The bottom of the spoiler is made underneath the oil cooler and compressor units and is joined together with a steel spring the inner ends. The rear ends at the corners are fixed to the side radiator frame, and provision is made, via adjustable brackets, for vertical and fore and aft between the bumper rear ends and the top of the mesh grille are fitted in each of the three air intake apertures in the spoiler, and are secured using Red Boss® self-retaining rollers. The front side trim lips, and side mirror lip, on 456 series, are fitted into recesses in the bumper.



1. Procedure

1. Remove the fittings securing the lower edge of the spoiler to the front subframe and radiator frame.
2. Remove the front of the wheel arch liners to provide access to the upper end of 111.011. In each arch, remove the two M6 screws, securing depth stops in the ends of the bumper armature, to the rear ends of the radiator



2. After the tie-rod ends, release the height adjustment bracket from the top edge of the bumper with 2025.

3. For access to the two lowermost bumper rear fixing nuts, pull out the screws, appear from the underside of the spoiler at each side, and reach up to the RH fixing nut behind the flange of the bumper from inside.
4. The two top bumper fixings are accessible at the front of the heading receiver, with the frontage raised.
5. Adjust the bumper assembly sufficiently to disconnect the zinc-titan lamp and side marker lamp harnesses.

Fig. 6011:

After adjusting a bumper assembly, fit spacer plates or body washers into the rear main fixing studs as required in order to achieve correct alignment. Run up with the coachmen from edge. Reverse the process, proceeding using an initial adjusted spacer at each rear end to control the gap between the bumper and chassis before tightening the nuts to lock the bushes.

**Illustrative/Export type shown
(USA type similar)**




Fig. 4 - Body 2025

The rear bumper is a Reinforced Resin fibre (GFR) with Weibull (RRFR) resin. It is a stiffening and shock absorbing composite structure. The structure is fitted to the rear of the body underbody with four bolts. On USA specifications cars, a shock absorber is used, and the space between the exterior and bumper is filled with energy absorbing foam. The weight penalty on these cars are lifted with roller bushes on the inside of the body to provide more compliance and allow the absorber to flex or move.

**1. Prepare**


1. On BSX lamp, at each side, disassemble the side burner lamp harness and remove the burner from the body aperture.

Remove the two screws securing the lamp rear edge of the burner attached to the body.

2. From inside the body, remove the lamp fixing nuts with power wrench and, on BSX lamp, rubber bumper, and substitute the bumper assembly.

General Use/
upward
Type

BSX
Type

**2. Mount**

1. Check that the lamp rear end bolts are securely fixed in the burner structure.
2. Operate a bipolar class B pusher without coil, each LED and fit the lamp in the body. Then insert the spacer washers and spacer washers on the inside of the body and burner apertures. See Fig. 1 for details.
3. BSX Special cases: Check that the two spacer washers are securely fixed in the apertures. Then insert spacer washers on each tube and fit the lamp in the body, treating with a no-rubber lamp harness through the body. Fit a foam sealing washer and spacer washer on the inside of the body, followed by a 2" washer, the rubber bumper, the washer and the rear lamp harness.
4. Check the alignment of the lamp seat in the lamp body and adjust it, and if necessary remove the bumper and the other spacer washers from the side to distance, or to be normal, but retain a total of 1" tolerance a repeat on a BSX special cases spacer washers on the body.



- After alignment is satisfactory, torque fasten the four nuts to 100-110 N·m (72-81 lbf·ft).
- Insert the washers and washers, forcing the lower edge of the bumper to the body.
- Take special care to engage the side marker lens elements in the body openings, and contact the harnesses.

Step 10 - FRONT PANEL

The bumper panel consists of a center and outer segments, both being hinged, with the assembly hinged at each rear corner to the front frame rail. A center pin is located at the front of the center, and may be inserted into a special bracket on the front rail of the front of the vehicle body. The center pin is held in place centrally at the front edge, and is operated by a special device which is mounted on the chassis, some time after the vehicle is brought to its destination. The underside of the bumper panel and the center pin are fastened, and are attached to each wire via the special hanger and its connecting device to the chassis.

Alignment

The bumper alignment may be adjusted by the insertion or removal of shims placed at the bumper hinges.

The hinge to bumper panel mounting holes are drilled to allow adjustment of alignment.

Three shims are attached to the brackets behind each headlight, and will be removed during the final alignment, and may be adjusted for alignment.

The bumper latch roller may be re-adjusted to draw the bumper to the bumper front edge.


Vehicle Cable

The vehicle vehicle cable may be made into the vehicle from the vehicle's bumper hinge post, through the lockhead, along the underside of the front frame rail to the bumper frame, where it is carried to a connection with the vehicle cable from the cable plate. The plate should be released from the vehicle, and a cable run through the vehicle cable through the vehicle.

Step 11 - FRONT LID


The front lid consists of inner and outer composite mouldings, a hinge bracket assembly, and a separate, hinged operation of a front lid. The hinge is attached to the inner moulding, and is hinged at each side. The front lid is hinged at the hinged edge, and uses two special, forwardly angled, hinged, hinged, and hinged brackets to the inner moulding. A hinge assembly is attached to each of the hinge brackets, and engages with the upper hinge pin to provide hinged operation, and supports the lid to the fully open position. The hinge is attached to the hinge, and is attached to the hinge, and is attached to the hinge.

The hinge is attached to each rear hinge lid hinge bracket through the front hinged, and is attached to the hinge, and is attached to the hinge. The hinge is attached to the hinge, and is attached to the hinge, and is attached to the hinge. The hinge is attached to the hinge, and is attached to the hinge, and is attached to the hinge.



It follows that the weatherstrips in boot, carried onto the body flange also, will be partly at the opposite end.

When the weather strip is torn, it is pulled up by the interlock lever and the weatherstrips in the rear bulkhead large reduced, and the boot ventilation of the foot is achieved by dusting air through the boot lid sealant elements to adjust near the rear main plate. Care should be taken not to obstruct the ventilation system with baggage or material.



Adjustments

The height of the front edge, and the lateral position of the lock lid, is adjusted by moving the hinge brackets up or down, or inwards or outwards on the bulkhead.

The amount of and the forward position of the lid is adjustable by slackening the bolts securing the slotted hinge arms to the lid. The lagging plates are pop riveted inside the front lip double skin. If the lid is too far forward, fitting of the operator front edge may result.

Rubber buffers are bolted on the rear (opener) of each side, across the rear lip, and may be adjusted for height to match the rear edge condition.

Lock lid latch

A single, centrally located, lid is fitted to the front lip, and is operated using the door key. Insert the key into the lock (smooth side to the right), and turn clockwise to lock, counterclockwise to unlock.

The latch mechanism is fitted to the inner panel with two screws and a brass tapping plate. The lock barrel is protruded on the outer panel with a spring clip fitted to a slot in the inner panel rear edge. The spring plate is fixed to the body by a single screw using positive adjustment side to side and up/down. Key fit to achieve positive latching after the adjustments detailed above have been completed.

UPPER DOOR STRONGBOX LID

The roof storage lid consists of an inner and outer composite panel bonded together and hinged at the rear edge via the staple, unassisted hinges to the door frame. From the rear edge each hinge bracket to the bulkhead using long lagging plates in the bulk. These plates are bolted to the lid by two M6 x 16 x 1/2 lagging plates pop riveted inside the inner skin.

The pivot pin of each roof storage lid hinge passes through the side of the lid, and an internal beam mounted onto the panel duct against the lock lid hinge arm when either the storage lid is open and up/down. This feature prevents the possibility of lid lid of twist, by ensuring that only one of the lids may be fully opened at any one time (see drawing in section 36 III).

To release a storage lid manual bracket, release the hinge arm from the lid, and then to use the door, release the spring clip from the internal beam to the door shaft extension. Pull the interlock lever out the pin, slide out the hinge arm, and install the hinge bracket onto the bulkhead.

Adjustments


The height of the rear edge of the lid, and the lateral position, is adjustable via the hinge bracket to bulkhead fixings. 'Squareness' and forward position is adjusted at the lid to hinge arm fixings.

Latches

Two types of latch mechanism have been fitted:

Double latch

A double pivoted latch is fitted to each side of the lid aperture, with the release handle mounted on the right hand door panel. The double pins from the handle on the right hand door release lever, to which is fitted a second cable which runs to the left hand door, operating against the release lever, release from attached to the latch bracket. Pulling the release handle releases both latches, and allows the lid to be raised by hand. When closing the lid, press firmly once each side to fully engage both latches.




Each latch is mounted on a bracket fixed to the seat with two factory bolts and to the edge of the body opening. The spring plates are fixed to the linkage rod by two screws and captive tapping nuts. The spring plates may be adjusted freefloat via slotted linkage rod, and the plates must be kept adjusted by making or duplicating a fit between the slitters and link. Screws may be removed from both cables via adjusters provided at their mounts on the right hand latch.

The handle assembly may be removed by releasing the nut and clamp plate behind the 2 posts.

**LEADS PART:**

Leads part use two latches mounted on pinch brackets bolted to the top of the rear storage compartment (rear seat). The two latches are operated by a long cable with a handle provided at the right hand seat pan. The cable connects with a ballcrank lever at the base of the right hand pinch, before extending across to the left hand pinch. At each pinch, a ballcrank lever maintains the tension of the cable up to the latch via a short link rod. To adjust the cabin, remove the fair panels from the large pinches, and adjust at the ballcrank lever solderless nipples.




At the handle end of the release cable, early cars used a separate plastic piece, sometimes stamped into the 'B' post as shown in the illustration, but some cars have the piece sculpted as part of the body panel.

Weatherstripping

A closed cell molded foam weatherstrip seal is fitted around the body openings. To remove the seal, pry out the buttons securing each end of the seal, and carefully peel back each end from the body strip securing the seal to the body. Use a scalpel to cut the 90 degree adhesive tape along the remainder of the seal, and withdraw each of the seal fixing trim (seat fasteners) carrier either the seal.

To fit a new seal, clean the flange on the body before applying a bead of adhesive and squeeze the seal by the high using the seal path, from the front



with the top of one side to the front side of the other side. The lead should not overlap the outside of each of the weatherstrips. Fit a length of Butyl strip (30007) to the end of the seal mounting path to the first push-pin hole. Fit the weatherstrip seal into position, pushing the retaining pins fully into the holes, and fit the bulb to — or by each end of the seal.

There shall a 300mm length of 'any strip 30007' be fitted to the seal path in the drainage lid between the hinges.

2.2.3. REAR DOOR


2.2.3.1. PANEL

- Transfer any faulty items from the rear door to the next, and raise the two feet above the door (30007).
- Remove the two rear window louvers at the side-swing handle, first by pulling down the latch handles, and releasing the rods from their handle ends.






- (ii) Buck the front of the soft top to release the latching mechanism.



- (i) Lift up the rear edge of the soft top whilst adjusting the rear window to fold down into one smooth fold.



- v. Release the roof storage lid by pulling the release handle in the right hand door lock and raise the lid fully.
 vi. Fold the soft top down into the storage compartment by pushing back on the front edge. Secure the soft top by buckling the retaining strap (if fitted).



- (ii) Close the storage lid, pressing firmly over each catch to ensure their full engagement.

To Remove:

- (i) Close the boot lid and lower the door windows.
 (ii) Release the roof storage lid by pulling the release handle in the right hand door lock.
 (iii) Raise the lid fully, unbuckle the retaining strap (if fitted), and pull out the soft top in its folded state, from the storage compartment.
 (iv) Raise the rear edge of the soft top and close the storage lid, pressing firmly over each catch to ensure their full engagement.
 (v) Push down the back edge of the soft top, and pull the front edge to the windscreen header rail.



- At each end of the header rail, engage the inner end of the roller with the roller end of the header rail bracket, and pull the roller end's fully upwards and back.

It is not recommended that the roller be allowed for long periods when wet, as degradation of the fabric will be accelerated. Before storing a wet roll top, wipe down with a soft cloth or sponge to remove most of the water, and raise the roll after the padding is allowed to become almost dry.


CAUTION: Roller does not recommend that the fabric is subjected to a mechanical treatment, or that it was applied to heated used or flame treated new clothes. The edge of the fabric's top window, and unadorned opening of the roof fabric, the front top and rear window should be secured using only warm soap water. Do not use any form of proprietary detergent, or rub with a dry cloth. Wash with clean water and wipe with a soft cloth whenever to remove the surface water. Allow to dry and restore stitching.

Figure 5: Assembly of roof Assembly

The only adjustments that may be made to the roll top roof assembly, are the relative position of the roof sections in the HV posts, and the position of the roller relative to the window header rail. The roof mechanism should, in addition, be set at the manual lateral adjuster. No attempt should be made to alter the setting of any part of the mechanism.

The roof assembly is clamped into each HV post by two through bolts. Before fitting or adjusting the position of the roof mechanism, first check that the doors are fully accepted and correctly adjusted, and that the window header rail and roller are fitted.

- Fit the roof assembly mechanism into the HV posts, and fit the two retaining through bolts and nut/washer to fit at each side. Put two lock washers on the bolts horizontally into the wind rail at the front of each roof post, insert a lock washer into each HV post vertically into the side panel at the base of each roof bracket.





5. Bend the shaft, and using the long roller, position the mechanism in the 18° position as shown.
 - Roll one 1/2" of the stop frame into, along the header rail; this roll must be controlled, with the seal fitting snugly into the angle of the header rail.
 - Adjust the height of the 18° seal so that the top rear corner of the door fits snugly under the rear roller.
 - A 1/2" gap between the front rear edge seal and the sludge rail from the point to the post.
6. Tighten the door door reclining mounting bolts, and remove the long adjuster bolts. Be sure to check for fit.
7. Adjust the position of the two latch plates on the header rail, for optimum alignment with the door latches, and tighten the locking bolts.

Reel Weatherstripping Preparation

Weatherstripping seal with the the rear seal web shown. See Service Parts for the details.

FIELD HEADLAMP MECHANISM


Two types of headlamp mechanism have been used. First prior to 1978 (1979) were John Deere "Field Work" (or "open glass") headlamps, where the headlamp pod was pivoted at its front lower edge and used a separate cover flap to protect the illuminated headlamps. Later units use a "single pivot" mechanism with a top rear edge pivot for the lamp body, whose top surface forms the body pivot, when the headlamps are retracted.

Field Work Type Headlamp Mechanism

The retracting headlamp mechanism consists of a pair of headlamps at each side of the lamp recessed on a pivoting frame which, when the headlamps are retracted, causes the lamps to fold over backwards, under the control of an electric solenoid, and be concealed by cover flaps.

The system comprises the following principle components at each side of the lamp:

- **Headlamp Body Assembly:** This pivoting carrying a pair of headlamps and pivoted to the pod rearwardly frame. Operated by the headlamp motor actuating cable, and raised the cover flap at lamp. In very early years, the headlamp pod was a separate pivoting head to an auxiliary alloy brace bar by three screws.
- **Headlamp Frame:** A castable alloy casting, bolted to the base of the lamp recessed pod with three bolt head studs. Carries the pivot ball for the headlamp pod.
- **Headlamp Cover Flaps:** Cast aluminum alloy covers, and composite outer shell panel painted body covers. Pivoted on the ball joints to the headlamp frame. Operated by an adjustable cable from the outward side of the headlamp pod to raise or reposition with the pod. Incorporated a corded interlock pin at the centre of the front edge, to engage with a hole in the top front of the headlamp pod when raised. This feature adds rigidity to the assembly when in the raised position, and reduces chatter.
- **Top Hinge Brackets:** Steel bracket bolted to top-hill. A stop for cover flap hinges. Improves cover flap stability.
- **Top Link:** Steel link rod with ball socket at each end. Connects the cover flap to rearward side of the headlamp pod.





headlamp flap and adjusting link; the assembly details shown in lines 1 and 2 in this view are mounting brackets, which are used by three bolts through the pod shell to the chassis structure. The rotor adjusting link is controlled by an electric solenoid in the steering bracket, and is connected by an adjustable length adjustment link, fitted with a ball joint at each of its ends, to the headlamp pod. The 1st connecting bracket also carries a non-rotation stop, which is limited by the 1st link only in the pod fully raised position. This permits the headlamp to operate only in that position, and prevents damage to the pod as it returns.

Various adjustments to the headlamp mechanism are required to ensure consistent star shape.

(1) See technical manual specification under air drawing instructions.

Adjustment Procedure:

1. Before adjusting the headlamp mechanism, disconnect or remove the following:
 - pod adjusting link;
 - cover flap outer panels;
 - cover flap operating 1st link;
 - raised operating arm at rear edge of flap shell;
 - safety screws down the pod upstops to the flap hinge bracket.


Headlamp Mechanism in Lowered PositionHeadlamp Mechanism in Raised Position



the flap frame. The post pivot (Fig. 2) is fixed to the base of the hoisting post hole by three washers. The post can be moved vertically with the hoisting cable, vertically, and if necessary, adjust the three fixings and reposition the frame to align the front edge of the post with the top edge.



The clear gap between the post and topshell (see Fig. 1) should not be filled. Some centers may be substituted or modified as each frame is used. Be sure to align the center of the hole in the post with the center of the hole in the topshell.



1. **Hoisting cable.** Wind the hoisting cable to the fully up position with the cable lock against the hoisting cable bracket. Adjust and adjust the cable hoisting cable so that the free end of the cable hangs forward 1" to 2".


2. **Flap hinge assembly.** Wind down the end, and adjust the tension. Fix the upper flap to the post in the fully up position and secure the air lines around the flap. The flap is fixed to the topshell and hoisting post. If necessary, adjust the two hinge brackets, tension, and move the bracket as indicated in the work order to adjust. The flap assembly is adjusted below.

3. **Control hoisting cable.** Wind the cable fully up. Fix the hoisting cable to the flap with a cable lock in the post hole. If necessary, move the flap cable bracket assembly so that it is properly adjusted. Be sure the flap cable is fixed to the hoisting cable through with the cable lock engaged in the post hole, and the pin bracket, pushing against the post.


4. **Hoisting cable.** Push the post against the flap, lower the post partially and reduce the post hoisting cable length by 4.5 cm.



- Check that the necessary handle link is fitted or worn down by reference to the diagram. The flap end of the link should be set to 10mm to allow for adjustment of the pod end of the link. Wind up the pod until just short of the locking pin and adjust the length of the 10' link at the pin end, so that when the link is connected, the centreline of the locking pin is level with the top of the pod. Push on the link, then press the front of the wheel front hub 1/2 way up the rim up of the pod and screw up all four upstops (in flap handle sockets) evenly, the lower flap.




- As a down stop, apply the 10' from downstop (maximize) to the 10' upstop (maximize) and a 10' from downstop (maximize) to the innermost upstop (maximize).




- Wind up the pod and check that the central locating pin enters the hole in the vehicle plate correctly. The pin should enter the hole below the suspension, and engage fully when the wheel is fully raised. At the pin in the hole to enter the hole, turn all four upstops down to engage and to be level. Repeat if necessary. The adjustment is complete.



11. To order to have correct operation of front edge to spring, it is necessary to test for locating pin engagement with an imposed load (load band structure applied to the cover flap) over the non-sufficiency for the total no pin no movement and after a quieting motion of the flap system in the locating pin. Apply a step by step load of 100 N (22.5 lbf) to the pin and note the use fully.
 - a. The pin does not enter the hole of the hole hole, and engage fully when the pin is fully seated.
 - b. If the pin does not engage, adjust the locating pin up to engage the hole of the hole hole. Adjust the pin up to engage the hole of the hole hole. Backlash generally occurs in the application.



12. Apply the cover flap over the hole, and secure with the four screws. Select the position to obtain 100 N (22.5 lbf) around the closed pin below flap being.
13. Check around the flap front edge density to achieve a separate panel applied to the hole. Check that the left hand side density link has not lost the alignment with pins (if fitted).



14. Check headlamp adjuster (if fitted) is correct.

Headlamp eye points

Each headlamp pot uses two head lamp adjusting (L and R) pots. Screws, provided in the headlamp adjusting (L and R) pots, passing through the bushes into tapped holes in pot. The pots have a spring on the top and when the top is in a straight line in the pot (happens), it provides a means of adjusting the pots in position. The reaction force straddles the headlamp pot





to provide lateral position and no manual adjustment or lubrication of the pivot mechanism is required.



Installation procedure Part 2

To install, adjust to level the headlamp harness at correct and correct assembly is required. Do not use neither electrical nor slacker beams at any time of mounting operation. Refer to the following diagrams for the correct installation.







Single Pivot Headlamp Mechanism

The single pivot headlamp mechanism was introduced at M85 6500, and has replaced the previous headlamp pivot assembly in concept to allow use on Excav and Export models.

Headlamp Pod Lowered



Headlamp Pod Raised





The system comprises the following principal components at each side of the car:

- Mainstay Bolt: Located one inch from shoulder; 1 1/2 inches and one 1/2 inch mainstay (mainstay) - 3/8" diameter plate located 11" from shoulder carrying two pivot bolts (2,000).
- Hinge Bracket: Bolted to top rail - 1/2 inch pin and plate.
- Mainstay Nut: Secured with a bracket to the chassis (spring) bracket incorporating two tracks, 1/2 inch steps for the mainstay link. A non-informing bracket at rear plate's base the rod about 1/2 inch on the opposite to the side of body.
- Upper Main Linkage: Comprises two main rods and a relay lever. The main link rods are identical and are adjustable in 1/4" points at each end. The relay lever plate is 1/2 inch in 1/4" points at its base. The link points are placed up by an upper bearing roller to the outer ends of the rod feet in the upright.

OPERATION

When the footstep is depressed the relay lever action operates and the mainstay link moves through the mainstay nut to the upright, when the roller plate and axle are up. In the up position, the rod link and the relay lever take an angle, upwards, toward the pivot on the pedestal.

The mainstay rod is attached to the previous said link and frame system except that:

- 1) The main support (see 1,000,000)
- 2) The main link attached to the mainstay and the spring plate.
- 3) The headlight upright and the relay lever are adjusted so, rather than only when the plate are fully raised. There is no means of being raised just prior to with the mainstay system.


ADJUSTMENT

- 1) Three basic adjustments of the rod mechanism are required.
 - a) rod should be raised - the rod link height and mainstay roller. The roller should be raised the hinge bracket to the upright, and adjustment of the roller to the upright to achieve correct rod height and alignment, relative to the rod to achieve a 90 degree angle between the rod and upright in the upright.
 - b) relay lever - Adjust the length of the link between roller and relay lever to 1/2 inch between roller and upright, with an equal amount of thread remaining at each end of the link. Tighten the locknuts, ensuring that the mainstay link are parallel to upright. This distance will ensure that the link is perpendicular to the upright in the upright, to give a 90 degree angle.
 - c) with the operating frame adjusted, and the mainstay roller link (with the roller) legs raised, the height of the rod from edge of the upright, ensure the height of the link between roller and upright is 1/2 inch, perpendicular to the upright. Tighten the mainstay roller to the upright, and parallel to each other.
- 2) With the rod link raised, ensure that there is adequate clearance between the mainstay rod and roller (4) and the roller standing just above the top of the rod wheel. It is necessary to raise the edge of the pedestal upwards to ensure 2) is not a free wheel and roller policy. This does not mean the adjustment will be a 1/2 inch from 1/2 inch.
- 3) The roller of rod link adjustment with a head roller.

Headlamp harness Positioning

It is most important that the headlamp harness is routed and secured correctly to ensure that it is neither strained nor chafed/trapped at any stage of headlamp operation. Refer to the following diagram for the correct operation.

All pins shown
(1/8" max. diameter)




1/8" clip A075N6000
along back of pod unit

1/8" driven stop
obstacles

Headlamp Motion

Each head lamp uses the vehicle nose lamp system. As the lamp is tilted, it is braked by two thin rods accessible from within the pod. The rods are attached to the top of the lamp unit by brackets. The rods play a role both in the end of the lamp's body.

The rods are braked as required through the "lenses" to ensure the correct operation of the lamp. For the electrical function of the lamp, see next page.







1. Make a small hole through the windscreen edge finisher and Retaxal head, and insert a length of piano wire or similar (supplied in Retaxal Kit) approx. 1 metre long, through the hole. With the aid of an assistant inside the car, use a sawing action to cut through the Retaxal and free the screen from the car. Alternatively, use wire cutting tool 007594169 or a proprietary hot wire cutting tool. Take great care not to damage the interior trim or paintwork during this operation. If using a melting wire, beware of smudging the wire in the joints between headlamp and screen pillar.
2. Remove excess Retaxal from the screen aperture with a sharp blade. Note that it is not necessary to remove all traces of the Retaxal, but a flat surface must be available for bonding the new screen. Do not abrade the leading surface of the alloy windscreen frame or body.

3. Mirror Mounting Plinth:

The interior rear view mirror is secured to a new plinth, which is itself bonded to the windscreen glass. The plinth is not removed from the glass and must be removed if the windscreen is replaced. Use plinth, which is not readily found before the screen is fitted, is supplied as part of a kit (A100062398) which includes adhesive (Bondo 661), and is applied as follows.

WARNING: Contains triethylamine and acrylate acid derivatives. Refer to instructions on product packaging.

- 1) Remove a clean bearing face of mirror plinth and corresponding area on inside surface of windscreen using a sharp razor or steel wool.
- 2) Sand the BOND661 in order to brace the interior glass container. This will allow the primer material to saturate the felt tip. Remove the cardboard cylinder protecting the felt tip and apply primer on wax to coat the bearing surface of both plinth and windscreen. Allow five minutes for the primer to dry.
- 3) Apply a thin coat of adhesive to the bearing surface of the mirror plinth. Position the plinth on the windscreen with the bonded end towards the top and hold in place for 2 to 3 minutes. Allow at least 10 minutes curing time before fitting the mirror to the plinth.





7. If a windscrew pillar or header rail has been replaced or refitted, check that the joint gaps between pillar and header rail, or pillar and body have been sealed with Sikaflex adhesive-sealant, and the screen landing posts are filled.
8. Cut the special paper provided in the Beranost kit into two. With one half, use the wire squeegee fitted to clear the peripheral edge of the glass, and the whole of the evacuation band on the inside surface of the screens. Also clear the whole of the bonding area on the body flange, screen pillars and header rail. Clean the underside of the two screen top corner finishers, and the lower half of the outside surface of the screen pillars. With the other half of the paper, wipe dry the areas cleaned.

9. Shake the Beranost primer container for at least 30 seconds before opening and pouring into the plastic bottle. Cut off the guide portion of the applicator head and fit in the bottle with the sponge pad inserted. Apply a band of primer around the outside edge of the inside surface of the glass, on top of the pre-applied evacuation band. Stop with your applicator head; along the head and sides, and bump with a wire along the top edge. If the evacuation band has a gap in it, drop a ceramic identification plate which is not used, use masking tape to produce a straight edge, and black out the gap with primer.


Also apply primer:

- around the peripheral edge of the glass to help prevent heatline increases;
- to the underside of the screen top corner finishers;
- to the lower half of the outside edge of the screen pillars (after wash);
- to the outside surface of each top corner, for the future flange.

Cut off guide section




Evacuation band



10. When the primer has fully dried (16 to 20 minutes, max. 45 min), fit the finisher to the top edge of the screen, with the lip towards the inside (the finisher channel has pre-applied adhesive), and press firmly into position. Offer up the two side finishers, and press the bottom ends on the shape of the screen lower edge, but do not fit at this stage.


11. Cut the Beranost application nozzle to produce the correct head shape:

- 1) Cut off the end of the nozzle to achieve an inside diameter of 5mm.





- 1.1 Make the patching patch, then apply to top of 6 and 12 inch glass.




Finished nozzle shape



- 1.2 Run the top edge of glass 6 and 12 and run the patch of nozzle to face the final patch.



- 1.3 To fit in the notch of the Retaxal cartridge and remove the distance of 1/2 inch the notch in the cartridge toward, move on the Retaxal's nozzle, and insert in the cartridge gap. Holding the gun vertically, the Retaxal nozzle 1/2 inch 1/2 inch, produce a continuous bead of Retaxal carbide/ceramic around the perimeter of the glass.





The head should be positioned:
 - adjacent to each side edge;


- flush up to the bottom edge of the screen;

- adjacent to the edge of the top finisher;

Make sure the correct orientation of the handle is maintained throughout the transition. Neutralize the two ends of the head to ensure they are completely flush and horizontal.

10. Put the pointer spacers evenly spaced in the Betaseal kit to make sure 5 mm spacers, and insert them, evenly spaced, into the inside edge of the detached head using the inner edge of the glass.

Screen condition
going to fitment



11. Fit the screen onto the body and position so that the screen is centered and flush to edges of the glass (aligning in line as far as possible with the top and sides of the window frame). Fit plastic or wooden blocks at the base of the screen to support the glass in this position. Fit the two size splitters, matching lines onto the glass edge and into the Betaseal head. This step is vital to get the edge of the glass to end in adequate joint suspension and perfect positioning. Balance the whole length of the joint, not just adjusting the 5 mm spacers to provide extra constant, into any localized area.
12. Wipe off any Betaseal extruded from the joint or from the side finisiers, and apply sealant to each top corner of the screen, pushing it 1/4 inch towards the ends of the edge finisiers. Fit the corner finisiers, wipe off any extruded Betaseal and top sealant.
13. Extrude a tapered bead of betaseal along the base of the screen to fill the gap between screen and top-sill moulding. From the extruded wiper plants to the bottom corner of the screen on each side, use only the minimum amount of sealant, starting, or subsequent removal, of the topsill will be needed.



- Do not disturb the screen and if the Betadrol has fully cured, which will take approximately 4 hours dependent on atmospheric conditions, taking longer in a dry atmosphere.
- Relax the screen pillar dual channels and weatherstrips (see below), and water test thoroughly before falling into orbit.
- Relax antenna from panels and water used.

Spillage of materials

- Any residue of 8 type of anti-sepined glue can be readily peeled off after it has cured.
- Any spillage onto the body can be removed with either Mop Cleaner No. 6, or white alcohol.

Shield Test

- Perched over a shell (left) at near 5 months of unaided temperature in the original impound 04, 0577.
- Re-examine primer for a second life of only about 21 hrs after it has been exposed to the air, after which it starts to become spongy. If the material is spongy DO NOT USE. Always use glass primer (water-tight) on openings, and replace lid after use.

Contents of Betadrol Kit 047066, 067.

- One (1) inch adhesive channel Betadrol 1401 in a 4.00 cm cartridge, 26, 0305
- Cartridge applicator nozzle.
- Water primer application bottle.
- Glass primer application head.
- Glass water applicator spray head.
- Glass primer tube.
- Mop Cleaner.
- 100.000 µm 100 mesh diameter x 100 µm hole.
- Special cleaning paper.
- 1/2 inch rubber spatula blades, approximately 1.2 x 11 x 20 mm. (10 to use)

NOTE - WINDSCREEN PILLAR WEATHERSTRIP

The seal between the two tubes and windscreen pillar takes the form of a shielded channel four weatherstrip, mounted in a steel carrier channel itself screwed to the alloy screen pillar.

to remove


As a polyethylene dielectric sealant is used to seal the weatherstrip into the carrier, and to the windscreen framework, it is likely to be damaged on removal.

- Prize out the cartridge keeping the top and bottom ends on the weatherstrip, and peel from the body, carrier channel and windscreen frame. Clean off the old adhesive.
- If necessary, remove the weatherstrip carrier channel from the screen pillar after releasing the remaining screws. Clean off the old adhesive from the carrier and screen pillar.




To Refit

1. Apply two strips of the same film, AGSHP6637, one on top of the other, to the back of the weatherstrip - driver's summit.
2. Fit the carrier to the screw pillar using the screws and washers. Apply a one lead of Sikaflex 221 (Kasabond) to the inside of the carrier channel, around the top of the pillar to the end of the header rail, and down the top post for the length of the seal.
3. Fit the weatherstrip into the carrier and position it that the top end of main cutting may be placed around the top of the seal. The bottom end of the seal may be fitted, and the ends of the weatherstrip strips to meet away from the joint where the main runner flange will bend the weatherstrip. At the base of the weatherstrip beneath the flange of the carrier, and insert the remaining cuttings, pushing fully home.



4. Press the sealant into the weatherstrip top end, and to seal between the top of carrier and screw pillar. A one top and bottom bead, as shown in the illustration. The weatherstrip should not be sealant for a neat finish.




**Fig. 27 - WINDSCREEN FRAME**

The inside of each top strength aluminium alloy windscreen pillar is fitted to the top of each door hinge post using three bolts. One of these bolts is split to fit the oval hole in the hinge post, with the third bolt using a nylon nut. The top of each pillar is spigoted into the hinge post on a 19mm diameter header rail which is secured by two bolts threaded into the pillar itself.


To locate

1. Remove the door top bolt (see section BK.1).
2. Locate the windscreen (see section BK.11).
3. Locate the sun visors, roof latches and trim panel (see 27 - windscreen header rail). Be sure the trim panel from the windscreen holder is located the exterior door harness over the pillar (if applicable).
4. Fit over the buttons securing the top and bottom ends of the moulded rubber screen pillar weatherstrips and press over the top and bottom ends of the windscreen frame. Remove the weatherstrips carrier from the pillar after releasing the retaining arrows.
5. Insert the top pins securing each end of the header rail to the door's pillar.
6. To fit on, withdraw the roll pin locating the pillar to the outside side of the door post. Insert the three bolts securing the bottom of each pillar to the door hinge post, noting that the lower front bolt uses a nylon nut to the inside of the door hinge post. Use a sharp blade to cut the adhesive deposited around the base of the pillar, and slide the pillar out from the hinge post, if necessary releasing the fascia panel end fittings to provide clearance. Note the position of the areas fitted between the pillar and hinge post.



**By Part**

1. Cut an eye-bolt diameter shaft from the base of the screen pillar, and fix to the inside of the top of the door hinge post.
2. Fit one screen pillar into the hinge post, and select sufficient shim plates to take up any oil clearance. Distribute the shim plates equally on both sides of the pillar and fit the three fixing bolts with thread locks, a minimum applied to the threads of the upper front, and the rear bolts, and place washers under the head. Fit the nylon nut to the lower front fixing bolt, not leave all the fixings larger right.
3. Fit the base line as follows: fit second pillar in the bumper rail into position, and return board, then fit the bolts in same way. Slide the second pillar in the same manner to the left.




4. Remove both seats, and pull back the carpet to reveal the tooling hole (approx 20mm diameter) in the cover at each side, ahead of the speaker window. Remove the panels.
5. Measure between the top rear corner of each screen pillar and the lowest edge of the fixing holes in the floor as shown in the illustration, and slide over the pillar in the slot. Adjust the pillar determined with the table below, and adjust the position of the pillar if necessary to bring within tolerance. Shims may be manufactured from the side of the pillar to the slot, and the pillar in the pillar allow a certain amount of clearance till adjustment.

Dimension	Tolerance
A	1000 - 1017 mm
B	1092 - 1096 mm
C	1007 - 2001 mm
D	1479 - 1484 mm
E	1479 - 1484 mm


Adjust the screen pillar bolts and recheck these dimensions.



Screen pillar
check dimensions




1. Seal the gaps between the screen pillar and fixed bulkhead using a bead of RTV adhesive/sealant (ASTM D 995). Pressure them together with a smooth beam (see also) of the waterproof banding. Between the pillar and bulkhead.
2. Use a caulk to seal the gaps between each side of the pillar and the door hinge body and between the top of the pillar and the bracket cap. Notice that there is a smooth transition for the header cap, sealant, and for the screen banding.
3. Fit the water shield gutter to the bottom of the pillar using the two main fasteners.






Verify the alignment of the XCR seal path between the bottom of the screen pillar and the wedge. If the gap is less than 1.0mm, check that the seal wire is fully seated with 2.5N force, and apply film tape 000904255F (Lotus P150904255 (R0)) across the width of the gap in the diagram.




If the wedge is greater than 1.0mm, fit a seal path wedge 400706075 to create the seal. Check that the seal wire is seated flush with 2.5N force, and fit the wedge according to the chart below.

Gap (X)	Wedge (B)	Wedge (C)
0.5 to 1.0	30%	2.0%

Fit the wedge to the body using transfer tape 400706100, and seal between the top of the wedge and the screen pillar using 2.5N force. Prime the surface of the wedge with primer 400706100 before applying film tape as above, but do not overlap to seal the width of the wedge.





10. Refer the windowing (JK.12), screen pillar (JK.13), windshield (JK.14), front upramp (JK.15), and the associated parts in reverse order to disassembly.

JK 16 - BODY REMOVAL PROCEDURE

There are 12 main mounting points securing the body to the chassis, each using a bolt with a locking nut, framed together and bonded to the body, and an NIP or a plastic nut is used for the chassis. The body may be removed from the chassis using a steel cone type front panel puller, leaving the engine in place, by the following procedure:

1. Depressurize the fuel system by trapping the engine section (JK.1) in battery compartment, and bleed all fuel system from panel, to stabilize the fuel pump, and start the engine. After the engine stops, then fuel starvation, crank for several seconds to draw into the remaining fuel, pressure. Disconnect the battery.
2. Disconnect the fuel feed to the engine (see page 41 of the engine log).
3. Remove the front upramp (see section JK 15).
4. Remove or de-pressurize the air conditioning system (see section JK 15) and disconnect the two electrical connections at the rear of the engine bay.
5. Drain the cooling system, and disconnect the two heater hoses (connected at the rear of the engine bay).




5. Disconnect the shoulder and clutch cables.
6. Disconnect the brake pipes from the master cylinder, and plug the cylinder hoses to stop the pipe from leaking.
7. Disconnect the vacuum hose to the brake servo.
Disconnect the vacuum hose to the water valve.
8. Disconnect the splash cable from the transmission.
9. Disconnect the following electrical connections at the engine top:
 - 20-amp wiring cable and starter earth lead at 50% of chassis front crossmember, just inside water feed marks, and release from the plastic bracket.
 - 25-amp fuse terminal frame, starter motor electrical connection, brake fluid level sensor lead, and pressure sensor under seat/door from side of battery, at or near N/A area, the ignition coil (type 1) and distributor. Release the harness from the chassis.
 - 20-amp wiring cable from front end of engine position, and release cable from chassis.
 - Plug up the engine harness connection area on the front of the leaded box, and on both sides the mounting bracket connection, and on both sides the boost line connection at the rear of the leaded box. Plug in the engine water pump fan cable to both battery terminals. Release the harness from the chassis.
10. Remove the plastic between the power seat, battery and the fuel pump.
11. To get inside the car, remove the plastic covering the upper steering column, and the bulkhead between the upper engine assembly to the pedal box. Break the steering column clips loose to raise the fixings covering the top of the column to the plastic bulkhead, and withdraw the column from the car. Remove temporarily as follows: the 12-amp fuse, and 20-amp fuse, marked with 21R, and separate plastic cover, located 50% from power seats to be taken.
12. Remove the fuel tank from petrol, gear, lower front and gear lever position (see section 21). Knock the suspended fuel pipes behind the seats. All of the petrol hoses were found to be removed from the fuel tank top.
13. Remove the parking brake cable, and the 20V, and remove the two bolts securing the cable to the rear cross member to the fuel tank top.
14. Plug beneath the rear of the car, to allow the parking brake cables from the front supports, and tie up the cables from the top links.
15. Remove the rear linkbars.
16. Remove the battery, with earth, and from the front of the hull channel leg.
17. Remove the 16-amp battery, occupying the body of the chassis:
 - at the front of each footwell, into the back of the chassis floor, crossmembers.
 - 2 channels in the ceiling of each side of the engine tunnel, also securing to seat crossmembers, and picking up their connections from the side of the chassis engine position.
 - To get each side of the rear bulkhead, adjacent to the engine tunnel, picking up a bracket at the rear of the chassis bulkhead.



1. At each end of the body, insert the rear wheelends, into the chassis rear suspension tie plate hole.
Push the spare wheel end into the frame a rear extension.
2. Reattach a four point 3.11 pinning for body latching points, and raise the rear end of the chassis.

Body/Chassis Fixings



Preparation - Before Body Latching

- Before installing the body, check that the following details are fitted first:
 - Self-cleaning floor plates around the loading bridle mounting on the chassis.
 - Self-cleaning floor plates around the spare wheel wells.
 - Self-cleaning floor plates around each rear suspension. Gauge top point.
 - Rubber support on each of the two raised beams for the loading bridle at the front of the chassis, centre section.

Body Latching Procedure


1. It is important when latching the body to the chassis, that the loading suspension bolts do not slip, to ensure that the body is correctly pinned when latched. See procedure.

1. Push the body into the chassis, ensuring that the fitting between the rearward hook rollers are not trapped between the body and chassis.



11. With the beam set fairly on the clevis, wind the points, turn 100 Nm (75 ft.lb) bolts and washers at the top of each feather into the chassis front crossmembers. Torque tighten to 49 Nm (36 ft.lb).
12. Fit the two bolts and washers on each side of the rear of the vehicle casting, and torque tighten to 49 Nm (36 ft.lb).
13. Fit the axle nut and washer into the top of your rear suspension hub and fit the nuts and torque tighten to 49 Nm (36 ft.lb).
14. Reinstall the spare wheel bracket in the beam, and fit the two track bolts and washers. Torque tighten to 49 Nm (36 ft.lb).
15. Fit the rear wheel mounting bolts, and torque tighten to 49 Nm (36 ft.lb).
16. Lucas recommends the vehicle to be driven to check assembly.

Changed Seat/Body/Chassis Mounting




**ANNEXURE 1 - WATER DRAINAGE: Areas of attention****APPLICATION OF BEAD SEALANT TO LID APERTURE**

A strip of 4.5mm rubber bead sealant, 4.5mm dia, is run first beneath the forward end of the roof structure lid seal, down the 'B' post beneath the water edge of the trim panel, and along the top of the body sill, beneath the side trim plate, linking with the fascia end seal. In this way, any water passing the front primary seal, or running down the 'A' or 'B' posts inboard of the primary seal, is directed towards two drainage tracks in the primary seal on the outside of the door.

With the 'B' post trim panel and door sill thread plate removed, and the forward end of the seal drainage 'A' post released:

1. Apply a 100mm length of 4.5mm bead sealant to the body, starting at the end of the lid seal platform and overlapping the lid seal bead. Position the seal as shown in the diagram taking care not to encroach into the mounting depression of the seal. Run the seal down the 'B' post, as far as the lower edge of the depression at the base of the 'B' post.


Apply a 100mm length of 4.5mm seal from the upper edge of the 'B' post depression along the top outer edge of the body sill, overlapping forwards at the front end to meet the base of the fascia end seal.




4.5 mm bead #1008620RV
3.0 mm bead #1008620V



View looking down
on top of 'B' post



- Drill six 5mm drain holes in the underside of the body sill as shown in the drawing.
- Carefully cut the surface of the new primary seal on the underside of the door, and seal the cut surface by wiping over with Glasfloc.






SEALING OF FUELLER REBATE

There are three aspects of water sealing of the fuel filler rebate: sealing of the filler neck to the rebate; sealing of the rebate to the body; and ensuring that the rebate drain tube is not blocked.


1. Filler neck to rebate: Release the two screws securing the clamp plate, and remove the plate and top gasket. Put the filler neck up against the underside of the rebate whilst sealing between the neck and rebate with black silicone. Push the sealant down into the gap, paying particular attention to the three indentations around the neck. Also apply a spot of sealant into each of the two fixing holes before refitting the top gasket and clamp plate and tightening the two screws.
2. Rebate to body: Check the integrity of the joint between filler rebate and the body by using a thin tin wrap or similar to poke around the joint line and search for any gaps in the adhesive. If any gaps are found, or if water ingress from this area is established, use a spatula to remove the sealant into the area uncovered, taking care to leave a neat appearance.
3. Rebate drain tube: The purpose of the fuel filler rebate drain tube is to drain any spilled fuel or rain water from the rebate onto the ground beneath the vehicle. Check that the tube is not blocked by blowing through with an inflation.



DOOR SEALING

Work to be considered include the mirror flange seal and dam, adjustment of the door glass inward tilt, and sealing of the fixings and panels attached to the inner door panel. The door shell is provided with drain holes in the underside in order to drain away any water collecting in the gutter of the door, but to prevent water ingress to the interior, the inner panel of the door shell must be sealed.


- 1 Mirror flange seal: Check that the mirror flange seal includes a vertical extension to contact the front edge of the glass, and a labyrinth seal at the apex. If necessary, renew the seal to fit the latest apex fixings.
- 2 Mirror flange dam: In order to divert any water in the mirror flange apex into the inside of the door shell via the mirror harness hole and grommet, a dam is glued (Plybond) along the inside edge of the door shell between the door slider channel and the top of the door primary seal.
- 3 Adjustment of door glass inward tilt: See Service Notes section BK.3.
- 4 Sealing of fixings and panels: Check that there are rubber gaskets fitted between the window lift channels, lower mounting bracket and door shell, and between the key guide channel lower fixing bracket (or shim plate) and door shell. Other adjustment of the door glass has been considered, seal around all screw heads on the inner door panel with Sylastic. Similarly seal all screw slip holes, sliding clips, grommets etc. Check that the speaker is protected by polythene sheet sandwiched between the P.O.D. panel rear seals. Seal all door access panels with Duralastic.




ROOF BENCH

It is essential that the owner understands the importance of leveling the door windows before erecting or lowering the soft top roof. Otherwise damage to the roof seals may be caused. In the interests of optimum sealing and freedom from wind noise, the owner should also be advised to re-adjust the points on the roof cant roll seals at each side, after erecting the roof.

The only adjustments that may be made to the soft top roof assembly, are the fitting position of the roof mechanism in the "H" beam, and the position of the latch plates on the windscreen header rail. The roof mechanism itself is adjusted and set at the manufacturer's, and it is essential that no attempt is made to re-adjust the settings or linkage. Any such attempt will render the roof warranty void. The mounting position of the roof should be set using the procedure detailed in Service Notes section Bk.12, but the use of a pair of specially made wedge plinths will enable the roof height setting to be achieved more easily. These wedges are produced against the base on the rear belt manufacturing stands, and form a horizontal plinth against which the lowest adjustment bolts can bear. These wedges should be fabricated from any sufficiently hard material e.g. steel, aluminum, plastic, wood.





After assembling the roof sealant (see optional I/O at the base of the falling panel seal), it may be necessary to adjust the header seal carrier level(s) position to optimize sealing at the header roll. Insert the left top header seal pins, top access to the two screws at each side which secure the header seal carrier to the roof. Place these screws, A & B from the seal carrier to achieve a snug fit of the header seal along the whole length of the screen header roll. Tighten the screws and retighten the trim panel.

Each of the roof seals (i.e. header seal, intermediate trim roll), falling outer trim posts, and rear deck, etc. available at service replacement kits.

**Falling Pillar Seal Replacement**

With the hood at position 2 (Fig.1) locate the screws that secure the falling pillar seal/carrier. A cut out should be visible along the forward edge of the carrier. The seal should be prised out of the abutment channel at this point to reveal screw.

The seal will also be secured to the hood at the top, by means of adhesion, and at the bottom by a button fastener. A scraper or knife should be used to separate top of seal from hood frame.

Clean all traces of seal and adhesive from top of pillar. Touching up any areas where paint has been chipped.

position 1



position 2

**Parts Required**

Component	Part No
for Falling Pillar Seal Kit.....	A100861676
for Falling Pillar Seal Kit.....	A100861683
between Adhesive Kit.....	A0756c.86J
Lotus 100 (Emergency)	


each seal kit comprises:

- 1 of Seal, falling pillar
- 1 of Thruster, seal
- 2 of Screws, M5x10 pan head
- 1 of Button fastener

position 1

**Figure 1****Ignition**

Using a brush and 'Metabolan 3000' or 'wipe clean' from Betaseal kit, clean seal abutment face of carrier and retaining faces of the falling pillar seal. Allow a minimum of 5 minutes 'flash off' period, after which these same areas should be primed using 'Betaprime 40' or primer from Betaseal kit, this time allowing a minimum of 1 minute, and a maximum of 1 hour 'flash off' period. should this period be exceeded re-apply primer.

Seal/Carrier Preparation

Clean & prime



Fit seal using spatula

Fit carrier to hood frame/pillar using screws provided. Thread lock may if be used on the screws which must be torqued to 7-8Nm. Assemble seal to carrier feeding top/rear edge of seal abutment face into the channel first, using a blunt edged spatula, ease lower/front edge into place.




Breat hood to position 1 (fig 1) The seal can now be adjusted to give the correct alignment via intermediate seal to ensure a weatherproof joint is produced. Using thumb/finger pressure only the seal may be eased towards or away from the adjacent seal to comply with the illustration below.



Seals Not Touching

Lift hood to position 2 (fig 2) and fit bottom fastener to the lower edge of the seal to securing it to the hood at the base of the falling pillar



Have hood to position 2 (fig 2), using Isobond 300 glue top edge of seal to the hood frame/pillar, ensuring the position relative to the intermediate seal remains unchanged. Leave for 7 minutes to allow adhesive to cure.

Seal should now be pulled out of bottom channel, care must be taken not to damage its 'skin'. With the seal out apply a new bead of 'Metaseal 1504' along the carrier abutment channel. The seal can now be fed back into the carrier as before.

Breat hood to position 1 (fig 1) and leave it in that position for no less than 48 hours, this will ensure adhesive is fully cured.

**Intermediate Seal Replacement**

With the hood at position 2 (Fig. 1) locate and remove the two screws retaining the intermediate seal carrier, ensure the associated nuts located between the seal and seal carrier are retained 1/2" away the seal and spacer from contact.

Parts Required

Equipment	Part No
LH Intermediate Seal Kit.....	A100361898
RH Intermediate Seal Kit.....	A100361902
Betaseal Adhesive Kit.....	A07591004


Article 280 (Superium):

Each seal kit comprises:

- 1 of Seal, Intermediate
- 1 of Carrier, seal
- 2 of Screws, Hex Hd, C&K
- 1 of Washer, flat, C&K
- 1 of Plastic spacer
- 1 of adhesive strip

Specialize

Using a brush and 'Betaseal 900' or 'seal primer' from Betaseal kit, clean seal abutment face of carrier and the retaining faces of the intermediate seal. Allow a minimum of 5 minutes 'Lean off' period, after which these same areas should be primed using 'Primerium 1400' or primer from Betaseal kit, this time allow a minimum of 1 minute, maximum of 12 hours 'Lean off' period. Should this period be exceeded re-apply primer.

Seal/Carrier Preparation

Seal backing and one side of adhesive strip and trace it to the top of the seal carrier (see illustration above). Fit carrier to hood contact using screws and nuts provided ensuring plastic spacer is positioned between them. Thread lock should be used on screw threads and screws should be torqued to 7-8lb.

Fit seal to carrier by feeding the top edge of the seal abutment face into the abutment channel first, the lower edge can then be eased into position using a blunt, round edged spatula.

With the seal in place hood to position 2 (Fig. 1). The seal can now be adjusted to give the correct alignment with the header seal at the front, and the falling gully seal at the rear. To ensure a weathertight joint is produced move the seal to comply with the following illustration, under hood 'open' position.

position 1




position 2




position 3





Seals Not Touching

Note the root of seal must be as appropriate fit is achieved. Lift the top edge at each end of the seal and form into the 90 degree into position, ensuring its related position of the other seals remains unaffected. Allow adhesive to cure.



Ease seal out of blister (shown), being care not to tear seal skin particularly at the corners (if space). Apply a small bead of the new adhesive to the abutment channel and refer seal to position. The backing of the adhesive strip can now be removed.

Press back to position, slightly and leave at an exact position for at least 48 hours allowing adhesive to fully cure.

Header Seal Replacement

With the hood at position 1 (Fig. 1) locate and remove 4 screws securing seal carrier to panel. Ensure the associated bolt located between the seal and the seal carrier are retained and away from seal carrier and gasket.

Peel header seal out of the channel at the front of the hood. Clean any traces of adhesive on seal. Before reassembly act to remove, inspect.

Parts Required

Component	Part No.
Header Seal Panel	1210008, 679
Between Adhesive Sealant	1215901, 501
Insert the BR Imperfect	

Part Seal Kit contents:

- 1 1/2" Seal, inner header
- 1 1/2" Carrier seal kit
- 1 1/2" Seal, outer header
- 4 1/2" Multi-use grease
- 1 1/2" Seal, washers set
- 1 1/2" Adhesive strip
- 1 1/2" Adhesive strip

position 1




position 2



position 3

operation


Turn the hood and Retainer. With the hood down, clean sealant traces of LH and RH seal carriers. Remove seal (including support) and a. Using sealant on lower of seal. Allow a minimum of 5 minutes. Seal off joint.

Seal/Carrier Preparation

Clean & prime



Bead of Adhesive

Header Seal in Position

Bead of Adhesive

Spatula

Using a brush and Retainer with an primer seal between seal. Apply header seal. Mount Header of LH and RH carriers. Header seal should seal and maintain surfaces of header seal. Allow a minimum of 5 minutes. Minimum of 75 mm (3 1/8 in) wet period. Should this period be exceeded carefully protect.

Seal. Lacking off one side of adhesive strip and fit to LH and RH seal carrier and position as shown.

FIG LH and RH carriers to front of cabinet using Grease Applied. Grease kit should be used or screw with should be continued to 1-800. For use of the header seal to each of the two carriers by because the two ways of the seal about face into the adjacent channel. The inner when can that be used with



position using a blunt, broad edged spatula.

With the seal in place move head to position 1 (Fig 1). The seal can now be adjusted to give the correct alignment with the intermediate seal. To ensure a weatherproof joint is made, adjust the seal to comply with the illustration below. Adjustment is made by easing the seal along using thumb/finger pressure only.




Seals Not Touching

When an acceptable joint has been produced move head to position 2 (Fig 2). Using spatula 380, glue rear edges of seal to top of IH and III carriers, taking care not to displace seals relative position to the intermediate seal. Check that by moving head to position 1 (Fig 1) while adhesive is wet.

Now head to position 2 and ease seal out of carrier's apertures. Care must be taken not to tear seal at the point just glued. Using 'Beckweld' 2900 adhesive apply a continuous bead 1/8" in dia. along header seal retaining channel from the IH to III seal sections and along the seal abutment channel of both sections.

Slide seal back into IH and III carriers and fit under seal by working from joint centre towards the head centre line. Remove seal remnants with a header cutter where adjustment necessary.

Header Seal in Position




Apply 'Beckweld' 2900 adhesive to header seal support face contact area in IH and III frame carrier positions. Seal backing of adhesive 1/2" up seal carrier.

Now head to position 1 and check alignment to make header seal in position. Clean any excess adhesive from joint surfaces of seal using acetone 2900. Carry out a final inspection for correct alignment of frame weldings. Adjust where necessary with level referenced. Leave load jacks for a minimum of 48 hours to allow adhesives to fully cure.



Modification to 'B' post trim panel: In order to avoid the possibility of the root seal being damaged when skewed by the top rear edge of the 'B' post trim panel, it is recommended to carry out the following modification to the trim panel:

1. Remove the rubber edge finisher, and cut 2 mm off the rear edge of the trim panel, tapering off to a point 10 mm down.
2. Thoroughly heat the triangular root edge with a heat gun, and bend outward sufficiently to avoid contact with the root seal when skewed, and ensure the 'B' post remains cup to fit correctly over the top of the panel (with edging strip fitted).
3. Re-fit or re-apply the rubber edge finisher, positioning flush with the top edge of the panel.






ROOF STORAGE LID SEAL


The roof storage lid seal has a rounded lip at each end which is known as the 'bead' seal, and is designed to fill the space between the roof mechanism or storage lid and the body. The shape of the bucket seal should be checked with the diagram to ensure that the correct version is fitted.


Identification of latest version of bucket seal




Mount of the roof storage lid seal is detailed in Technical Note section 9K.12. It also notes the following points:

1. Do not fit the ends of the seal until the 'B' post has passed in place.
2. Do not fit the bevel tape at the ends of the seal as detailed in BR.11, but apply the bead sealant strip to the end of the roof lid seal platform as detailed in the diagram.






- Ensure that the ends of the seal are positioned as shown in the diagram before fitting the post-fit retaining fasteners (1) (at each end) and taping in position with the sealant/tape (see above).





4. Use Sikaflex to create a dam behind the 'B' post trim panel and divert any water on the inboard side of the seal away from the cabin.


Sikaflex dam behind
'B' post trim panel



VENTILATION DUCT CONNECTOR

The ventilation duct is inserted into the underside of the front topshell, to feed with a duct adaptor on the front bulkhead via a rear rubber sleeve joint located at the top rear of the passenger side front wheelarch.

1. For access to the joint, remove the wheelarch liner.
2. The sleeve joint is made from skinned rear rubber, which is waterproof provided the outside skin remains intact. If the skin is broken, the foam will absorb water which can be drawn into the vehicle's interior via the heater/air conditioning system. Check the sleeve for water absorption and replace if necessary.
3. Check the security of the sleeve which is retained at each end by a long tie wrap which should be tightened securely. In order to provide the sleeve with a gripper mating surface, the spigot on both the bulkhead adaptor and topshell duct is wrapped with a length of self adhesive foam tape:
Bulkhead spigot tape (4.5 met) = K380J5788
Topshell spigot tape (3 met) = A.8.06.67F
4. Also check the joint between bulkhead adaptor and bulkhead, and if necessary seal with Sikaflex.






REAR QUARTER SEALING

When checking the body joints for sealing, pay particular attention to the area at the front of the rear wheel arches. Remove the two side trim panels from the rear storage area and use a torch to check for water ingress when applying a hose pipe to the outside of the vehicle.

1. Check the front end of the joint line between rear topshell and rear quarter panel, and re-seal if necessary using Sikaflex.
2. Check the two sealing grommets inside the bottom front edge of the rear wheelarch, and the joint between rear quarter panel and hull inside the wheelarch. Also check around the lip of the rear wheelarch.

Forward view
Inside R/R
wheelarch




3. In order to reduce the quantity of water shed by the 40 degree waters into the floor hinge joint area, it is recommended to seal both outer rear edges of the front topshell to the base of the hinge using Sikaflex. The only subsequent sealant to complete the bead, or subsequent repairs, removal will be needed.

REAR BRACKET

A bracket is provided at each side of the boat to provide access to the rear suspension top link inner pivot ball. Check that this bracket is securely sealed using Sikaflex.

DRAIN RAIL - INSIDE TUBE

Lexus cars have a drain pipe fitted at each end of the windshield header rail. This takes the form of a short pipe glued through the top corner of the screen pillar, which serves to drain any water collecting in the space between the roof header seal and the header rail. Plastic tubing leads from the underside of this pipe down the inside of the screen pillar, and out through the door hinge post sealing hole.




Tools Required (continued)

Description	Part Number	Qty
Reinforcing bracket, topshell to motor, RH	A10080994	1
Nut, M3 x 50, self-locking to motor	A07947026F	2
Nut, Nylon, M3, lock, to motor	A10087117F	2
Flanged thin washer, shuntline adjust	A10080610F	10
1/2" clip, harness to pod rear wall	A07586002	4
1/2" clip, harness to headlamp assembly	A07586002	4


Procedure

1. On each side, remove the existing headlamp pod system and retain the following parts:
 - Headlamp assemblies, including mounting rings.
 - Flap hinge bracket (located on topshell), but remove and discard the four spot-up adjusted screws.
 - Headlamp turn and mounting bracket. Discard the return link but retain the spacer sleeve.
2. Release the headlamp harness from each pod well. Puncture the rear wall of each pod well using the template supplied (see later). Cut off the rear part of the three pig head studs used to secure the old headlamp mounting frame.


3. In order to make good the ear fixing holes for the new relay cover mounting bracket, fit adaptor plates A10081120 and A10081121 behind the rear wall using the M3 screws.



4. At each side, position the relay cover mount bracket with the two top holes aligned, and tighten securely on the base. Mark out the bracket lower fixing hole on the base of the pod well, and drill a 6 mm diameter hole in the topshell. Fit the hole into an open slot rearwards into the rear wall aperture. Apply a two part epoxy adhesive (e.g. Ardite) to 'dig round' this aperture, and slide beneath the topshell to the front end of each slot. Taking care not to allow excess adhesive to bond to the chassis. Clamp into position with a washer and nut on the top side until the adhesive has fully cured.




6. Fit the relay lever pivot bracket to the topshell using 36 nylon nuts and 1/2" washers.




7. Position the headlamp shell filler panel at the front of each pod well, and mark out the two fixing holes on the topshell. Drill the holes 11.0 mm and fit the two M6 fixings. Secure the two shell panels with the pan head screws.

Headlamp shell
filler panel





11. At the front, connect the two 0.025mm main beam connectors at each side, open the secondary lock, and use tool T700070504 to transpose the green and blue cables. Remove and discard the safety switch. Tense each motor mounting bracket, and tape back the harness to meet later.




12. At each side, extend the two main beam headlamp leads by 50 mm, and the two dip beam leads by 150 mm.

• Cut tape the headlamp harness for a distance of 100 mm from the main beam earth point.

At a point 90 mm from the old harness cut, cut the main beam beam wire (blue/black on BBS, blue/black on HBS) and extend 90 mm using 2.0 mm blue cable, soldered splice, heat shrink insulation and tape.

- Repeat for the main beam earth lead using 1.25 mm black cable, staggering the splice by 90 mm from the beam cable splice.


- Repeat the above two operations for the dip beam feed (blue/orange Bb, blue/pink BFI and earth cables, using 1.00 mm of red 2.0 mm, and 1.25 mm black cable).






- Secure the harness with 'P' clips along the back of the pod well as shown in the diagram.

RL pod shown
(LB sym. opposite)



'P' clip A075M6000
along back of pod well


9. If a reinforcing bracket was not previously fitted between the topwell plinth at the top rear of each pod well and the headlamp motor, these brackets must now be fitted in order to brace the mounting plinth for the headlamp pods.






The reinforcing bracket should fit directly against the topshell, with the pod hinge bracket aligning (if required) between the hinge bracket and reinforcing bracket.

10. On each outboard (dip beam) headlamp assembly, remove the headlamp plastic carrier ring for new (see DISASSEMBLY). Remove the row adjuster screws and springs. Fit all four headlamp assemblies to their own mounting plates, and assemble into the pods with the dip beam lamps to the outboard positions.




11. Remove the rotary link from each headlamp motor, and fit the new link.
12. Assemble a link rod with two rod ends and locknuts and fit to the inboard side of the pod lift bracket (fitted to the inside of the pod) with a 4.0 mm spacer between the rod end and bracket, and a 1.5 mm spacer between the rod end and nylon nut. Repeat for the other pod.






13. Fit two ball joints to each relay lever using pop rivets, with the ball joint flange on the outside of the lever. Assemble each lever into the relay bracket with the open side facing forward and the actuator link stud pointing inward. Fit the pivot bolts as shown.



14. Fit each pod into the hinge bracket, and tighten the ball joint socket head pivot screws. Adjust the pod shuttles and height by slackening the two bolts securing the hinge bracket to the topshell, and adding or detaching shims (shim washers) as necessary to achieve flush fitting and a 5 mm (approx) shim gap between pod and topshell or bonnet.
15. Fit the pod link rod into the relay lever with a 4 mm spacer wash and one of the ball joints. Assemble the actuator link rod, and adjust to a length of 40 mm between ball joint contact surfaces (fitting into the relay lever followed by a 1.5 mm spacer and nylon nut). Fit the other end into the motor relay link against the 12 mm spacer, and follow with a 1.5 mm spacer and nylon nut with the rotary link shuttles the drawing (nearest) stop on the pod mounting bracket. Check the weight of the pod link rod. If necessary, adjust the weight by altering the length of the pod link before tightening the ball joint. Carefully ensure that the ball joints are parallel to each other.
16. Connect the headlamp leads, and secure the harnesses to the back of the topshell using 'P' clips as shown. Check the operation of the headlamps, and ensure that the harness is not stretched, chafed or trapped at any stage of headlamp pod operation.



17. Adjust headlamp alignment using a beam setter.

FRONT MATTER/COVERSECTION C - ECR

	<u>Sub-Section</u>	<u>Page</u>
General Description	CE.1	1
Reporting	CE.2	1
Administration	CE.3	1
Supervisor Eligibility	CE.4	1
Supervisor Responsibility	CE.5	4
Self-Reporting Requirement	CE.6	10



Front Suspension General Layout


FRONT



Rear mounting



Rear





12.1 - GENERAL INFORMATION

The front suspension comprises of upper and lower struts with coil springs, coil springs/dampers, upper and lower control arms, the upper and lower wishbones on each side of the car are mounted on a separate cast alloy "ball" knuckle which is fitted to a ball socket or three lipped rubber bushes, and helps to isolate the body from suspension noise and vibration, whilst maintaining accurate wheel control.

The lower wishbone uses a cast "fabricated steel" crank control arm to carry the spring/damper unit, and at its coil end, the lower steering knuckle ball joint. A separate knuckle steel strut is fitted to this knuckle, and lower wishbones in form of a triangle. The upper wishbone comprises two similar pressed steel links, joined together at their coil end and where they connect to the steering knuckle ball joint, both upper and lower ball joints are secured to a cast iron hub carrier with a crossbar, secured facing steering arm. The coil end coil spring/damper, is fixed to the lower wishbone and to the chassis. A torque-washed tubular tie-rod end, makes up off the steering knuckle, and is supported by two spring links. The inner spring damper unit is secured at the upper end, to the chassis member.

The inherent play of the upper and lower wishbones, take the form of bonded rubber bushes with longitudinal protrusions. These bushes are designed to separate and absorb alloy "flex" in each side of the car which occur as a result of the longitudinal, lateral and torque loading from the front suspension, after the chassis. Each side is mounted to the chassis by three bonded rubber bushes, the lower two being for coil ends, and one single top bush having a torque reaction. The lower rear bush is fitted directly to the chassis cross-member, the lower front bush to the transverse underframe, and the top rear bush mounted to the chassis longitudinally. The protrusions of the roll-over bush are self-aligning with a rider that maintains a slight roll, the front wheel is allowed to roll slightly as the roll occurs. Roll-over bush and front lower bushes. This movement has only a minimal effect on the steering, but self-aligns to return the axle and dampness transmitted to the car. This feature allows for a "flex" of these bushes to be made, in order to maintain an accurate wheel control for accurate handling.

The ball socket uses a single double row ball bearing to support the wheel hub, into which is fitted the drive shaft.

12.2 - GEOMETRY



Body height as kerb condition 110" (total tank, no occupants)

Front 135

Rear 120

130 ± 1 mm } NOT ride height for


120 ± 1 mm } geometry check





by the nut. A total adjustment of about 1" is possible. On completion, torque both nuts to 22 - 25 ft-lb (16 - 18 lb-ft).


On later work, camber adjustment plates are fitted between the guides at the top swivel joint inboard fixing. Four variations of plate provide seven settings according to the orientation of the plates, and allow for a camber adjustment range of about 4" in steps of just under 1".



To make an adjustment on cars with camber adjustment plates, first establish the variation of plate listed below before selecting an alternative plate, and/or orientation, from the table below. Slacken the top swivel joint outer fixing, and remove the inboard fixing bolt. Fit the replacement adjuster plates into the guides on the top wishbone halves (making sure that the shim plates are fitted at front and rear) and fit and tighten the fixings: Socket head bolts: 16 - 19 ft-lb (1.6 - 2.6 lb-ft). Hex. head bolts: 22 - 25 ft-lb (16 - 18 lb-ft). (Alternative)

Dimension 'A'	Part no. of plate	Plate orientation	Dimension 'B'
14.0 mm	A1000111	Outboard →	14.0 mm
14.5 mm	A1000110	→	14.5 mm
15.5 mm	A1000125	→	15.5 mm
16.5 mm	A1000104	→	16.5 mm
17.5 mm	A1000125	→	17.5 mm
22.5 mm	A1000117	→	22.5 mm
14.0 mm	A1000117	→	14.0 mm

negative camber increase ↓





Earlier cars with mountain adjusters may be fitted with the later type member adjuster plates, but only in conjunction with the inboard and outboard member head fixing bolts, nuts and washers, and the higher firing torque (see above).

Track Rod: To adjust the toe-in, hold each track rod end by the flats provided (22 mm) whilst releasing the locknut. Turn each track rod, using the flats provided (11 mm) as P.O.A.C. amount, to adjust the effective track rod length as necessary. When adjustment is correct, hold the track rod end and tighten the locknut to 40 Nm (44 lbf-ft).

2.4 - SUSPENSION DISASSEMBLY

If the complete suspension assembly is to be removed from one side of the car in order to provide access, or for other work in that area to be performed, the complete wishbone/hub carrier assembly may be removed by releasing the cast alloy rail from the chassis:



Complete Suspension Assembly

1. **Track Rod End:** Remove the nut securing the track rod end to the steering arm, and use a ball joint separator to release the joint.
2. **Driveshaft & Brake Caliper:** Unpeen, remove and discard the nut nut. Release the brake caliper from the hub carrier, and the flexible hose from the top wishbone, and support clear, without straining the hose.
3. **Strut Yoke:** Release the end of the anti-roll bar from the ball joint, and whilst supporting the weight at the suspension, release the nut and withdraw the ball securing the strut yoke to the lower coil. Release the top ball, and remove the two halves of the yoke from the suspension stem.
4. **Driveshaft & Brake Caliper:** Unpeen, remove and discard the nut nut. Release the brake caliper from the hub carrier, and the flexible hose from the top wishbone, and support clear, without straining the hose.
5. **Top Ball Fixings:** Release the three bolts securing the shock absorber plates to the top of the rail, and the single bolt through the top mounting. Remove the two plates.
6. **Lower Ball Fixings:** Release the rail lower front mounting bolt, and lower spring mounting ball. Push the driveshaft out of the hub, and withdraw the complete wishbone suspension assembly from the car. Note: take care not to scratch the driveshaft, and pull apart the inboard joint.

Spring/Damper Assembly


The spring/damper assembly uses a spring top seat which is bolted to the chassis, and also retains the top of the damper shaft. This allows the complete assembly to be withdrawn from the vehicle without the use of spring compressors. With the suspension 'hanging', release the yokes from the lower end of the damper body, and remove the three bolts securing the spring top seat to the chassis. Withdraw the damper and spring assembly. Do NOT remove the damper stem top nut without first fitting spring compressor clamps.

Before re-assembling the unit, ensure that the damper stem rubber bushes, and the spring top rubber seal are in good condition. Replace if necessary. Pay careful attention to the correct location of the damper stem bushes and washers -


Top wishbone inboard pivotLower wishbone inboard pivot



Dumper/spring top mounting



Spring/dumper assembly to lower wishbone





refer to the functional illustration. Hold the top of the stem whilst torque tightening the cone nut to 20 - 30 Nm (15 - 22 lbf.ft).

Wiper Replacement

1. Lower washbone: The inboard part of the lower washbone (in both main link, and sublink steady link) are split, flanged sleeves, bonded rubber bushes, which may be drawn or pressed from the washbone before new ones are pressed into position.
The sleeved bush for the suspension arm to lower washbone may be replaced using a press with a suitable sleeve tool.
2. Top washbone: The inboard end of each top washbone half, is fitted with a flanged sleeve bonded rubber bush which may be replaced using a press. Note that the bush is fitted over the inside of the arm.
3. Bush: The rear lower bush is a split, flanged sleeve type, which may be pressed out, and one bush is pressed in.
The rear lower bush is a single flanged sleeve type, fitted from below.
The rear top mounting is a split, flanged sleeve, bonded rubber bush, pressed into the mainlink tangram, and may be removed by drawing/pressing out each half of the bush in turn.

2.6 - SUSPENSION RE-ASSEMBLY

Note the following points when re-assembling the suspension.


- (1) Use a copper based grease on the shank of the top washbone to help fitting and to prevent corrosion, and aid subsequent disassembly. Thoroughly degrease the frame before fitting the nylon nuts.
- (2) Tighten the washbone pivot bolts and clamps to correct washbone frame bolt ONLY with the use of correct size height, otherwise the bonded bushes will be pre-loaded, resulting degraded ride quality, premature wear and increased ride height.
- (3) Pay care - attention to the correct assembly of the rubber washers and ensure that the steel inserts are fitted into the alloy suspension carrier at the washbone pivot points.
- (4) Note that the threaded nut used secures the ends of the upper and lower wheel joint nuts, on the rear and front ball joints.
It is most important that the ball joint nuts are correctly torqued, especially the bottom ball joint for which an open ended torque wrench must be used, or alternatively, remove the driveshaft to allow access with a socket wrench.
- (5) When assembling the bottom washbone, torque tighten the two bolts securing the rubber arm to the rear member before tightening the two fixings joining the trailing arms. Note that on older cars with 15" wheels, the inboard of the two main fixing points, is raised to take a 1/2" ID hole rather than the 3/8" hole used on other cars.
Similarly, on cars with 17" wheels use some 15" wheel cars with a top washbone bearing channel, tighten the washbone to top axle joint bolts, before tightening the bearing channel bolts.
- (6) After re-assembly, carry out a geometry check, and make any adjustments as necessary as detailed in CE.1
- (7) Reset the brake caliper (see section 2B.5).
- (8) Torque tighten all fixings as below.
- (9) Tighten the rear to chassis front crossmember strap (both ends), with the vehicle weight supported on its wheels.



Torque Setting	No.	Min./ft
1. Raft top mounting bolt	15 - 30	55 - 59
2. Sandwich plate to raft	27 - 25	16 - 18
3. Raft front and rear mounting bolts	15 - 30	55 - 59
4. Two wishbone inboard pivot	55 - 58	43 - 43
5. Top wishbone to ball joint		
- eccentric camber adjusters	22 - 24	16 - 18
- square plate camber adjusters	15 - 19	16 - 19
6. Top wishbone bracing channel	45	31
7. Lower wishbone inboard pivot bolt	68 - 72	50 - 53
8. Lower wishbone inboard pivot and plate	22 - 25	16 - 18
9. Lower wishbone strut to main member - M10	45 - 45	30 - 33
- 1/2" x 1/2" UBF	61 - 81	45 - 60
10. Lower wishbone bracing channel	44	27
11. Suspension strut yoke to lower wishbone	105 - 110	77 - 81
12. Ball joint to anti-roll bar	75 - 77	18 - 20
13. Damper top shaft nut	70 - 70	15 - 22
14. Yoke to damper	15 - 18	26 - 28
15. Spring top seat to chassis	22 - 25	16 - 18
16. Lower wheel joint to hub carrier	61 - 67	45 - 49
17. Top wheel joint to hub carrier	61 - 67	45 - 49
18. Track rod end to steering arm	38 - 64	47 - 47
19. Driveshaft to front sub	225 - 235	166 - 173

WHEEL HUB BEARING REPLACEMENT

1. Hub Nut: Loosen, remove and discard the hub nut.
2. Brake Caliper: Remove the dust caps covering the ends of the two caliper sliding pins, and remove the two socket head bolts securing these pins, and the brake caliper, to the hub carrier. Support the caliper clear of the brake disc without straining the flexible hose.
3. Brake Disc: Release the single screw securing the brake disc, and withdraw the disc from the hub.
4. Ball Joints: Separate the steering track rod end, and top and bottom swivel joints from the hub carrier, by removing the ball joint nut, and using a suitable ball joint splitter tool.
5. Hub Carrier: Press the driveshaft out of the hub as the hub carrier assembly is removed to the bench. Take care not to 'stretch' the driveshaft, and pull apart the inboard O.V. joints.
6. Hub & Bearing: Use a split collar tool to support the hub carrier on a hydraulic press, and press the hub from the bearing. Remove the two circlips securing the bearing in the hub carrier, and press out the bearing outer race.
7. Assemble Hub: Fit the outer circlip into the hub carrier, and press the hub bearing, via the outer race, into the hub carrier. Fit the inner circlip. Press the hub bearing, via the inner race, onto the hub.




10. Before the carrier bolts the hub carrier assembly, the correct procedure, and noting the following points:
- Use a new hub nut, and press into the driveshaft slot after torque is applied. Use an open ended torque spanner to tighten the top and bottom 50% per the manufacturer's specified torque.
 - Fit new dust caps over the brake nut and seal the bolts with a grease seal to the brake caliper (see method 2E.5).
 - Tighten all fixings to the specified torque.



REAR SUSPENSION

SECTION 19D REAR SUSPENSION

	<u>Line-Item Code</u>	<u>Stage</u>
Control Assemblies	00.1	1
Control	00.2	1
Adjustments	00.3	4
Suspension Elementarity	00.4	5
Component Elementarity	00.5	5
Sub-Assemblies	00.6	5



**7.0. GENERAL INFORMATION**


The rear suspension consists of a wide load beam, coilover, a single top link, a shock absorber, spring/telescopic damper, and an anti-roll bar. The rear bottom frame rail (wide load) width has 14" offset. The lateral links are made integral with the chassis, only allow steering, the rear wheel, lower. The chassis member is connected top link controls wheel, corner. The telescopic damper is made between the lower stabilizer and the chassis, and incorporates the coil spring lower end. The top end of the spring acts against the upper coil member, top a steel coil body, tube which is secured the top of the damper arm. The vehicle is not a compressed form of the axle tube, lower, trailing links, and steering with the lower stabilizer (to 1 1/2" over).

A steering knuckle axle is bolted to the stabilizer, hub carrier, and supports the rear hub, which is integral with the brake disc, on a pair of upper frame members, adjustable for toe in/out.

8.0. DIMENSIONS

Wide load wheel carrier (11") fuel tank, no provisions:

- total (14)	172 ± 2 mm	HOV axle height for
- rear (11)	161 ± 1 mm	steering knuckle



Supervisor country should be checked only at mid-load, gross height.


Wide load (14)	172 ± 2 mm	mid-load (14) (17) kg driver
- rear (11)	161 ± 1 mm	mid-load (14) (17) tank of fuel
Center	172 ± 2 mm	± 1 mm
18.0.0.	172 ± 2 mm	each side

It is essential that rear wheel alignment is checked using equipment of at least two professional wheel alignment. The most reliable and accurate method is considered to be the use of laser level bars, used as follows:

Bars which are longer than the overall length of the axle, and 4 bars, stands are used. The bars should be adjusted locally and should be at 2" or square sections of 1/2", adjusted by hand to avoid significant bending or sagging between supports.



Set up the two bars on each side of the main steel centre height as shown in the drawing, so that B equals B_1 , B equals B_2 and C equals C_1 .




Measure the distance from the BAL to the RIB of the steel (extension of lines) and mark the centre line of the sheet. If the plate thickness is constant near the rear extension, the sheet has T2E-10. If the steel thickness is greater than the front extension, the sheet has T2E-07E. The difference between the two values is 1/4" to adjust the sheet cut T2E-10 or T2E-07E.

TOOL ADJUSTMENTS

Clamp and Eccentric are adjustable.


Adjustments to be made for the adjustment of wheel center at the top link. The top link consists of an inverted channel channel welded to the tapered bar eye, and a separate cast iron or ferrous eye bolted to the center with two bolts. Both fixings use a slotted hole in the channel section with an eccentric adjuster constructed of the channel fixing. This tool has an internal eccentric center under the head which connects between two sections, guides on the front side of the channel. Pinch supports and pins are used on both sides of the rear side of the link, and a plate washer between the head of the inboard bolt.





to give an adjustment. First slacken the adjuster nut, and then remove the top of the eccentric nut until bearing the bolt stationary. Turn the bolt with a screw keying nut, as necessary to increase or decrease diameter. A total adjustment of about 1 mm is available. On completion, torque will nuts to 10 to 20 Nm (7.5 to 15 lbf.ft.).

There is provision for the adjustment of bearing by an screw file register at the lower wishbone front forked. To make an adjustment, slacken the tapered locking nut nuts, and turn the nut, with suitably convenient or required before re-tightening to 10 to 15 Nm (7.5 to 11 lbf.ft.). A total adjustment of about 0.5 mm is available.




11.4 - SUSPENSION DISASSEMBLY

The suspension strut assembly uses a spring top seat which is locked to the chassis. This enables the complete strut assembly to be withdrawn from the vehicle without the use of spring compressors:

- support the weight of the suspension, and remove the bolt securing the lower end of the damper to the lower wishbone;
- remove the spring top seat from within the seat, and release the three nuts securing the spring top seat to the chassis. Withdraw the complete spring/damper assembly;
- do not remove the damper stem top, as without first fitting spring compressors.

Before re-assembling the unit, ensure that the damper stem rubber bushes, and the spring top rubber seat are in good condition. Replace if necessary. Pay careful attention to the correct location of the damper stem bushes and axioms, and the top of the wear adjuster torque tightening the screw nut to 20 to 30 Nm (15 to 22 lbf.ft.).


Note that at the lower wishbone pin to be removed, the brass boss between chassis and wishbone should first be rapped off, and then disconnected from the vehicle.




Upper Washers:

- 1. Lower Washers: Upper washers part attached piece of the lower washers is fitted with a piece of flanged sleeve bonded rubber bush, which may be made of polyethylene. Res bushing may be pressure into position. Note that the bush joining both to the lower washers, and the steel "soft" bush, slide.
- 2. Lower Washers: Lower washers part of the lower washers is fitted with a hole, flanged sleeve bonded rubber bush, which may be replaced with a plug. Note that the bush is carried from the inside of the washers.

Lower Washers inner bush





Lower Washers outer bush





5. Snap a laser eye on the thinner end of each sleeved bonded rubber bush at its base so that it may be replaced using a press.
 6. The built up front flange has the two grooves are "overhaul" at both inner and outer ends, and the added security, each of the bonded rubber bush is 2mm as indicated by a spread.
 - a. The inboard end is secured, generally, with the chassis, and with this the use of the top link bush with a reducing sleeve within the bush is possible if the latter is the lifting link.
 - b. At the outboard end, a spacer sleeve is fitted into the hub carrier bore, and projects into the top link to spread over the top link bush. Two spacer sleeves of this description are used dependent on the method of suspension below.
- Both bushes may be prepared using a press, but do not forget to fit the reducing sleeve into the bush hole where appropriate.

Top link to Hub Carrier**5° Anti-Lift Angle****Top Link to Hub Carrier****11° Anti-Lift Angle**



Early 2 1/2" type - straight channel

Later 2 1/2" type - angled channel



The 2 1/2" type wreckage is identified by a blue paint mark on the upper surface of the wreckage front leg, and the 2 1/2" strapping strut by either a blue paint mark, or a white paint spot on its lower end. At the inboard end of the top link, the 2 1/2" assembly uses an 80 mil long spigot sleeve running through the top carrier and link tube, and a 9/16" spacer to maintain clearance between the strapping and the link. See sectional diagrams.

Note the following points when reassembling the suspension:

- (i) Copper Washers: Use a copper based grease on the shank of the lower washers outboard pivot, and to prevent corrosion, and aid subsequent disassembly. Ensure the threads are thoroughly degreased before fitting the nylon bolt.
- (ii) Pivot Bolts: Tighten the lower washers pivot bolts, top link pivot bolts, and damper to washers bolt, ONLY with the car at ride height. Otherwise the bonded rubber bushes will be pre-stressed, resulting in degraded performance, greater wear and increased ride height.
- (iii) Stubble Washers: Pay special attention to the correct assembly of the stubble washers. Refer to the sectional diagrams.
- (iv) Top Link Outboard Pivot: Establish the lower washers anti-dive angle (see manual) to ensure that the correct type of fixings are used at the outboard end of the top link. Refer to the sectional diagrams.
- (v) Top Link Inboard Pivot: Check that the following sleeve is fitted into the hole, and that spigot in the chassis projects into the bolt locking sleeve. Unless removing the pivot bolt, apply thread locking compound to the threads, and fit through the stiffening strip and rubber washer before entering the hole and chassis.
- (vi) Ball-Bolt Bed to Lower Washers: Fit and tighten the ball joint into the lower washers, before fitting the external bar onto the ball joint. Hold the squared end of the ball pin while tightening the nut on it.
- (vii) General Check: After re-assembly, carry out a general check, and make any adjustments as necessary as detailed in 10.4.
- (viii) Brake: Refit the brake caliper referring to section 10, and pump the brake pedal after re-assembly to restore full position.
- (ix) Tighten all fixings to the specified torque loading.

Torque Settings

	Ns	402.01
1. Damper top nut on	20 - 25	15 - 22
2. Spring top seat to chassis	22 - 25	10 - 15
3. Damper to lower strapping	60 - 70	50 - 55
4. Top link, outboard* and inboard**	70 - 90	55 - 60



Turnover Specifications (continued)


	IN	OUT
1. Top disc/washer off (right side)	57 - 58	41 - 42
2. Inner axle assembly (right) pushed into position*	47 - 50	48 - 52
3. Inner axle/washer is backed out of the hub assembly†	51 - 100	73 - 75
4. Axle is turned to determine ball points	12 - 14	12 - 14
5. Axle pin is repaced to the inner axle/washer	15 - 40	12 - 14
6. Axle pin is repaced	15 - 20	12 - 14
7. All nuts	100 - 200	
8. Wheel nuts to hub assembly	5 - 10	11 - 12
9. Axle is turned to determine ball points	11 - 12	12 - 14
10. Axle/washer is rechecked/tracker	100 - 110	73 - 81

* Tighten only when in final spot.

† Apply axial locking compound around inner axle/washer bolts (use spray body).

PART - HUB ASSEMBLY

NOTE: This hub is supplied to the engine or bearings, which are adjustable in condition.



**Adjustment:**

- Push out the dust cap from the hub center.
- Remove the split pin and tighten the hub nut to 25 Nm (18.5 lbf-ft) after rotating the wheel to put the bearings.
- Slacken the nut, and re-tighten using fingers only.
- If necessary, tighten further, the amount amount necessary to insert the split pin, heading the start and over the nut, and the loop end over the end of the axle.
- Fit in the hub dust cap.

Subassembly:

1. Brake Caliper: Release the two brake caliper mounting bolts, and support the caliper piece of the brake drum, without straining the flexible brake hose.
2. Brake Disc/Pan: Push out the hub dust cap, pull out the split pin and remove the hub nut and washer. Withdraw the splined hub and Brake Disc.
3. Seal & Outer Race: Push out the hub oil seal. Use a self-protect drift to push out both the outboard bearing roller from the hub. (Oil seal cap provided in the bearing recesses in the hub for this purpose).
4. Inner Race: Pull the outboard inner race from the same axle using a suitable puller.
5. Stub Axle: If necessary, remove the four bolts securing the stub axle to the hub carrier, and withdraw the axle.
6. Be assembly: When refitting the stub axle, ensure that the contact surfaces of the stub axle flange and hub carrier, and the bearing and clamping surfaces of the fixing bolts, are all correctly dry clean. Unless running the bolts, apply thread locking compound before fitting and torque tightening the four bolts (see torque list above).
7. Outer Race & Lubrication: Clean the bearing recesses in the hub before pushing the new race into position (inner race removed). Pack the race loadings with a lithium base wheel bearing grease, working into the roller cages. Coat the inside of the hub, outer race and dust cap with grease. Fit the inboard bearing rollers and inner race and retain in position by opening in the new grease seal.
8. Hub Assembly: Fit the hub onto the axle, followed by the outboard inner race, washer and hub nut. Tighten the hub nut as detailed above, and fit the split pin and dust cap.
9. Brake Caliper: Refit the brake caliper, and torque tighten the two fixing bolts (see above). Pump the brake pedal to restore brake pad position.
10. Tighten all fixings to the specified torque loading.

INDEXCONTENTS OF VOLUME

	<u>Contributing</u>	<u>Page</u>
General Description of Technical Goals	EC-1	1
General Data and Systems	EC-2	11
Organizational and Economic Operations	EC-3	14
Transportation Data	EC-4	18
Water Supply	EC-5	28
General Summary, Field Inspections, and Other Material	EC-6	30
Technical and Other Letters	EC-7	31
Technical Field Assembly	EC-8	38
Field Data	EC-9	47
Field Data Revisions	EC-10	48
General Power and Engineering	EC-11	51
Optimizing Block Positions and Connecting Paths	EC-12	61
Blockshifts and Other Restrictions	EC-13	67
Interchanges	EC-14	83
Service Requirements	EC-15	87
Special Topics	EC-16	93



13.1 - GENERAL INFORMATION

Note: The terms 'front', 'rear', 'right' and 'left' when used in connection with a horizontally mounted engine can cause some confusion. To simplify this issue, a note on of these terms is used in conjunction with the word 'engine'. The description relates to the orientation as if the engine is placed on its left-hand end of the engine refers to the flywheel end. However, when referring to individual components of the engine, such as cylinder head, block, crankshaft etc., the terms are used in accordance with the motor industry term. Strictly the flywheel end of the engine is regarded as the rear. The crankshaft is at the front of the engine and the flywheel end of the engine.

The naturally aspirated 'D401' engine used in the Volvo 900, is built naturally aspirated and horizontally, as an in-line four cylinder twin overhead camshaft unit, with a four valve per cylinder or a electronic multi-point fuel injection. For details of the fuel injection and engine systems, a system refer to Service Manual Section 1312260-1312300 (Separate publications).

The four cylinder, four valve is controlled by six camshafts, two cylinders are driven four valves per cylinder in 'pump over' operation. Overhead inlet and exhaust valves are inclined at 90° to each other, and are operated by separate overhead camshafts, driven from the same end of the crankshaft by a single overhead camshaft belt. The inverted bucket type of operate system, in control of the valve clearances and maintains the need for precise adjustment. The valve operate in a pushrod and lift valve action. The lift valve mechanism is a lift cam, and are fitted with a rope helical spring.


Engine timing is set by using special pistons, are fitted with two compression rings, a control ring, and above the oil pump pin. The method of oil pump pin is also used. In this engine, the pin in an intermediate fit into the oil pump and the forged steel injection connecting rods, whereas into cylinder block, fitting the forged pin retained by a rivet in the piston. The pin is a steel pin, the crankshaft is provided for wear resistance, and is hardened by a wheel cut by three wheels either side of the main bearing. The lead angle will pass in a directly by the front end of the crankshaft, draw into the cylinder when the piston is at the pressure stroke.

A belt drive water pump mounted on the front face of the block, is driven by the rear end cam belt, and the light is driven from the front of the engine. There is drive off the rear end of the exhaust camshaft.


The intake system is composed of water heated throttle body containing a square throttle valve, a plenum chamber integral with eight individual intake ports, and a lower intake manifold feeding two fuel fuelled cylinders head ports. The lower intake manifold contains a fuel injector for each of the four ports and a secondary throttle valve controlled one of the two ports for each cylinder. These secondary throttle valves are operated by a cable, set by a manual throttle cable only is controlled by the engine management computer. At engine speeds below 5,200 rpm, the secondary throttles are closed to maintain a high gas speed in the intake air column, for optimum low speed driveability and fuel quality, and at higher engine speeds the secondary throttles are opened for maximum volumetric efficiency and performance.




4183-10C TURBO ENGINE PLAN VIEW



- | | |
|--|---|
| 1. Alternator | 17. Addition bypass water pipe |
| 2. RM or AM Filter/Clapper | 18. Water inlet feed pipe |
| 3. Governor/Linker/Throttle/Idle Arm | 19. Waterpuff cap/cover |
| 4. Governor/Idle speed/acceleration safety valve | 20. Turbo oil feed |
| 5. Turbine Section Water Inlet | 21. Water pump suction pump |
| 6. Turbine Inlet/Idle Valve | 22. Water pump relief spring |
| 7. Oil Separator/Flange only | 23. Air conditioning compressor |
| 8. Thrust and bearing carrier | 24. Exhaust Crankcase Ventilation (CCV) valve |
| 9. Air Inlet Sensor/Identification No. 8.4. | 25. Oil cooler hose & mounting |


421-RT TURBO ENGINE FRONT SIDE

- | | |
|---|--|
| 1. Dipstick | 9. Turbo oil feed hose |
| 2. Primary heater padlock | 10. Turbo oil drain hose |
| 3. Oil separator (Turbo only) | 11. Turbo compressor outlet |
| 4. Fan speed sensor distributor on R.S.A. | 12. Friction clutch housing (Turbo only) |
| 5. Thermostat housing outlet | 13. Air conditioning compressor |
| 6. Turbo water feed hose | 14. Water pump inlet port |
| 7. Reflector (Turbo 421RT pipe) | 15. P50 pump inlet connection |
| 8. Turbo water return hose | 16. P50 pump outlet connection |

4241 WT TURBO ENGINE RIGHT HAND VIEW

1. Dipstick
2. PMS pump pulley
3. PMS pump adjuster strap
4. 6 1/2" compressor clutch
5. Timing marks
6. Vav. belt tensioner across ground
7. Oil pan

8. Oil cooler feed and return connections
9. Fuel return pipe
10. Fuel feed hose
11. Fuel pressure regulator valve
12. Regulator valve pressure take off
13. PMS surge filter/damper
14. AV valve plenum connection

1420-HP TURBO ENGINE EXPT 1000 1000


- 1. Fuel inlet, fuel water line
- 2. Fuel separator (float valve)
- 3. Oil separator
- 4. Primary separator pump
- 5. Turbine Turbine (TTR)
- 6. Fuel to City Water return
- 7. Fuel separator
- 8. Submerged fuel filter (float valve)
- 9. Fuel separator
- 10. Fuel to Air (float valve)
- 11. Fuel to fuel connection
- 12. Fuel feed connection

- 13. Fuel return connection
- 14. Secondary strainer (200)
- 15. Fuel to Turbine section
- 16. Secondary strainer (vacuum separator)
- 17. Turbine rotor
- 18. Turbine compressor outlet
- 19. Turbine by-pass water pipe
- 20. Turbine capstan
- 21. Turbine compressor inlet
- 22. Turbine loading outlet
- 23. Turbine return (float valve) to City Water



Mixing Torque Summary

kgf.cm (lbf.ft)



Yeni - 1995/2000 - 2001/01

20. Bu sistem, hidrolik sistem, yağlar, yağ pompası ve aralıklı yağ pompası ile çalışır. Bu yağlar, yağ pompası tarafından emilir ve yağ pompası tarafından emilir ve yağ pompası tarafından emilir ve yağ pompası tarafından emilir.

21. Bu sistem, hidrolik sistem, yağlar, yağ pompası ve aralıklı yağ pompası ile çalışır. Bu yağlar, yağ pompası tarafından emilir ve yağ pompası tarafından emilir ve yağ pompası tarafından emilir ve yağ pompası tarafından emilir.

22. Bu sistem, hidrolik sistem, yağlar, yağ pompası ve aralıklı yağ pompası ile çalışır. Bu yağlar, yağ pompası tarafından emilir ve yağ pompası tarafından emilir ve yağ pompası tarafından emilir ve yağ pompası tarafından emilir.


23. Bu sistem, hidrolik sistem, yağlar, yağ pompası ve aralıklı yağ pompası ile çalışır. Bu yağlar, yağ pompası tarafından emilir ve yağ pompası tarafından emilir ve yağ pompası tarafından emilir ve yağ pompası tarafından emilir.

Notlar:

- Herhangi bir bakım sırasında, yağ pompası ve yağ pompası arasındaki bağlantıyı kontrol etmeyi unutmayın.
- Yağ pompası ve yağ pompası arasındaki bağlantıyı kontrol etmeyi unutmayın.
- Yağ pompası ve yağ pompası arasındaki bağlantıyı kontrol etmeyi unutmayın.

24. Bu sistem, hidrolik sistem, yağlar, yağ pompası ve aralıklı yağ pompası ile çalışır. Bu yağlar, yağ pompası tarafından emilir ve yağ pompası tarafından emilir ve yağ pompası tarafından emilir ve yağ pompası tarafından emilir.

- Herhangi bir bakım sırasında, yağ pompası ve yağ pompası arasındaki bağlantıyı kontrol etmeyi unutmayın.
- Yağ pompası ve yağ pompası arasındaki bağlantıyı kontrol etmeyi unutmayın.
- Yağ pompası ve yağ pompası arasındaki bağlantıyı kontrol etmeyi unutmayın.





of) package components. (Weight is 2.1 kg (4.6 x 1.5 lb) using 8.5 mm (2/3") pipe).

If necessary, adjust the depth door (adjust the HPS pump module bracket to the center, and use the built-in 1/4" x 1/2" adjuster screw). Bring the pump bracket to zero on the specified factory and tighten the latter to 10 Nm (72 in-lb).

• Check all items are without damage. See section EM674HL.

• Inspect and clean a variety of cable connections: Carefully examine the 20-amp 115-volt ground fault circuit breaker for any signs of swelling, softening, discoloring, or other signs of deterioration (besides if necessary).

• Check security of marine installation: Check alternator, HPS pump, fuse panel, and other marine equipment installations for security.



Warning:

The crankshaft drive belt may be removed with the engine in a normal stop position to remove the belt and cover cover, if it is necessary to remove the engine, and remove the right-hand side of the engine.

1. Remove auxiliary drive pulley. Blocker the piston steering prop and alternator pulley, and remove the belt from the pulley.

2. During this time, before removing the pulley, first use the torque wrench to check and turn the cap screw. The torque condition with the torque wrench should not be less than 10N·m, and the torque wrench is the last instrument pulley for engine. After the work is finished.



3. Remove the pulley cover. The left side of the crankshaft pulley cover and pulley and remove the pulley.



4. Remove right-hand engine mounting. Support the right-hand side of the engine. The belt is pulled from the right-hand side. Remove the back security fastener to the right-hand engine mounting rubber. Remove the fastener with an Allen key, supporting the alternator engine mounting bracket to the left-hand bracket, and remove the crossbeam.

5. Lower belt guard. Remove the second security the lower belt guard, and remove the guard.

6. Remove the belt. Use a spline socket wrench to loosen the tensioner pulley spring ball, and rotate the pulley clockwise to slacken the belt. Slide the belt off the pulley.

Precautions

- Do not attempt to pry or stretch the belt with a screwdriver or any other tool during removal or replacement;
- Do not force the belt to bend or tear, unnecessarily, as damage may be caused to the belt cover;
- Do not allow oil or any other chemical substances to come into contact with the belt. If belt life will be shortened;
- Store the drive belt in a cool dark place. Do not expose to heat or direct sunlight;
- Do not operate the crankshaft or camshaft with the drive belt removed, as damage may be caused to the valves and pistons.



7. The upper surface of the deck should be kept as flat as possible in the case of a heavy haul. Some knots on the deck may be necessary to hold down the load.




8. Generally, a good rule to follow is to tie the belt for every 6 inches to 1 foot, depending on the fabric, or wherever the manufacturer's instructions call for it to be tied, and so on.



9. The following are some of the most common types of knots used in marine work:

• Square knot (see page 18)

• Reef knot (see page 18)



Splicing

10. When a rope is necessary, refer to the U.S. Coast Guard and U.S. Marine Corps manuals for details.

11. Splicing is done as follows:





10. Turn over the assembly and fit the new top tensioner pulley (torque: 10 N·m (7.4 ft·lb)).

Fit the lower end of the spring into the hole in the pulley and the upper end into the lower hole. Tighten the clamping bolts on the spring with a torque of 10 N·m (7.4 ft·lb).

11. For better alignment, the transmission belt should be still in the correct adjustment. The centreline of the belt should be in the centre of the pulley so that the belt will be in the same position as the timing belt end of the engine.

12. Fit the drive over the pulley, as shown in the diagram, and install the crankshaft pulley.

- crankshaft
- water pump
- alternator
- without condenser
- water pump
- alternator

13. Before belt, check that the engine timing marks are still aligned. (The marks may not have coincided during belt fitting) Before turning the engine to new position in the engine, direction to rotate the belt. Remove the belt as before when the crank is 0°.

- Re-adjust or Re-fit the following parts:
 - belt after a lower speed: 10 Nm (7.4 ft·lb)
 - lower cover gasket
 - crankshaft pulley: 170 Nm (125 ft·lb)
 - engine timing case/belt





Fig. 10-10



11.3.2012 - 11.11

The subject property is retained in the trust
 1. The trust is a bare trust. It is a trust
 2. The trustee has no duty to invest
 3. The trustee has no duty to pay interest
 4. The trustee has no duty to pay tax
 5. The trustee has no duty to pay interest
 6. The trustee has no duty to pay tax

11.3.2012

The trustee has a duty to invest the trust property in accordance with the trust instrument.

- trustee is the property holder
- trustee is the property holder
- trustee is the property holder
- trustee is the property holder
- trustee is the property holder

The trustee has a duty to invest the trust property in accordance with the trust instrument.

11.3.2012 - 11.11 - 11.11 - 11.11 - 11.11 - 11.1111.3.2012 - 11.11

The trustee has a duty to invest the trust property in accordance with the trust instrument.

The trustee has a duty to invest the trust property in accordance with the trust instrument.

- trustee is the property holder
- trustee is the property holder
- trustee is the property holder
- trustee is the property holder
- trustee is the property holder

The trustee has a duty to invest the trust property in accordance with the trust instrument.

The trustee has a duty to invest the trust property in accordance with the trust instrument.

- trustee is the property holder
- trustee is the property holder
- trustee is the property holder
- trustee is the property holder
- trustee is the property holder
- trustee is the property holder
- trustee is the property holder
- trustee is the property holder
- trustee is the property holder
- trustee is the property holder



1. Fuel Pipe: Place 2x4s on the sides (not top) of pipe from the front chamber at the back to the engine.



2. Clamps: Remove 2x4s and the fixture screws, the points marked in the diagram below.

- 1 clamp on each end,
- clamp to be about 1 inch edge,
- clamp both along upper edge.



4. Fuel Connections - Removal

WARNING: Fuel pressure remains in the system while awaiting all the right conditions, including an inspection, fuel or line pressure may build up if a secondary fault or safety device the pressure. See "Fuel Pressure Relief Procedure".

FUEL PRESSURE RELIEF PROCEDURE

- Turn the battery switch on, with battery disconnected to disconnect the fuel pump feed, and start the engine.
- After the engine stops, turn fuel starvation, crank the engine for at least 1 minute to discharge any remaining fuel pressure.
- Fuel connections are now safe for servicing.

CAUTION: Take great care when removing the fuel rail and injectors. To avoid damage to the electrical connector pins or injector spray nozzle. Before removing the fuel rail assembly, it is recommended to use an engine cleaner such as 40 Second X-305 to help loosen and clear all the oil plug all fittings as soon as possible after opening.

1. Fuel Inlet: Using a back up wrench to prevent the fuel rail inlet connector from turning, remove the fuel inlet pipe from the left hand end of the rail. Use a shop towel to absorb any escaping fuel.
2. Fuel Outlet: Using a back up wrench to prevent the fuel rail outlet connector from turning, release the fuel outlet pipe from the right hand end of the rail. Use a shop towel to absorb any escaping fuel.
3. Fuel Rail: Using the electric start the fuel rail can be lifted using a 1/2 inch open ended spanner. Remove the two bolts securing the fuel rail to the lower chamber, and carefully withdraw the rail complete with injectors to a clean bench.



to inspect the engine when attempting to start the boat motor by connecting the open end of the fuel line to the engine and the closed end to the fuel tank. Make sure the fuel line is not kinked or bent.

After the fuel system is checked, try the outboard motor. If it still will not start, the outboard motor may need to be serviced in the shop.

After starting the engine, the outboard and fuel line of the outboard motor may be what the trouble was. The fuel tank may contain 10% water. The fuel may be water contaminated with oil.

Lower Motor Mount and Horizontal Alignment

- Position the outboard motor.
- Adjust the fuel mixture.
- Adjust the trim tabs.
- Check the engine oil level.
- Check the fuel filter.
- Check the fuel line for leaks.
- Check the fuel tank for leaks.
- Check the fuel tank for water.
- Check the fuel tank for oil.
- Check the fuel tank for rust.
- Check the fuel tank for debris.
- Check the fuel tank for dirt.
- Check the fuel tank for sand.
- Check the fuel tank for silt.
- Check the fuel tank for sludge.
- Check the fuel tank for scale.
- Check the fuel tank for corrosion.
- Check the fuel tank for pitting.
- Check the fuel tank for cracking.
- Check the fuel tank for leaks.
- Check the fuel tank for damage.
- Check the fuel tank for wear.
- Check the fuel tank for tear.
- Check the fuel tank for hole.
- Check the fuel tank for puncture.
- Check the fuel tank for dent.
- Check the fuel tank for scratch.
- Check the fuel tank for scuff.
- Check the fuel tank for mark.
- Check the fuel tank for stain.
- Check the fuel tank for discoloration.
- Check the fuel tank for change in color.
- Check the fuel tank for change in texture.
- Check the fuel tank for change in smell.
- Check the fuel tank for change in taste.
- Check the fuel tank for change in appearance.



to start the outboard motor. The outboard motor may be what the trouble was.

Outboard Motor Problems - Employment

to start the outboard motor. The outboard motor may be what the trouble was. The outboard motor may be what the trouble was. The outboard motor may be what the trouble was.

to start the outboard motor. The outboard motor may be what the trouble was. The outboard motor may be what the trouble was. The outboard motor may be what the trouble was.

to start the outboard motor. The outboard motor may be what the trouble was. The outboard motor may be what the trouble was. The outboard motor may be what the trouble was.

Outboard Motor Problems - Employment

- Check the fuel tank for water.
- Check the fuel tank for oil.
- Check the fuel tank for rust.
- Check the fuel tank for debris.
- Check the fuel tank for dirt.
- Check the fuel tank for sand.
- Check the fuel tank for silt.
- Check the fuel tank for sludge.
- Check the fuel tank for scale.
- Check the fuel tank for corrosion.
- Check the fuel tank for pitting.
- Check the fuel tank for cracking.
- Check the fuel tank for leaks.
- Check the fuel tank for damage.
- Check the fuel tank for wear.
- Check the fuel tank for tear.
- Check the fuel tank for hole.
- Check the fuel tank for puncture.
- Check the fuel tank for dent.
- Check the fuel tank for scratch.
- Check the fuel tank for scuff.
- Check the fuel tank for mark.
- Check the fuel tank for stain.
- Check the fuel tank for discoloration.
- Check the fuel tank for change in color.
- Check the fuel tank for change in texture.
- Check the fuel tank for change in smell.
- Check the fuel tank for change in taste.
- Check the fuel tank for change in appearance.



THE BALTIC

The League presents its proposals for the settlement of the Baltic with the Baltic and the Baltic States, and by the Baltic States themselves.

The Baltic States, Estonia, Latvia and Lithuania, were invited to the League of Nations, with the understanding that they would be able to join the League of Nations on the same terms as the other States. The Baltic States have now joined the League of Nations.



Baltic States

The Baltic States have now joined the League of Nations. The Baltic States have now joined the League of Nations. The Baltic States have now joined the League of Nations. The Baltic States have now joined the League of Nations. The Baltic States have now joined the League of Nations.

The Baltic States have now joined the League of Nations. The Baltic States have now joined the League of Nations. The Baltic States have now joined the League of Nations. The Baltic States have now joined the League of Nations. The Baltic States have now joined the League of Nations.

Present work

- 1. The Baltic States have now joined the League of Nations. The Baltic States have now joined the League of Nations. The Baltic States have now joined the League of Nations. The Baltic States have now joined the League of Nations. The Baltic States have now joined the League of Nations.
- 2. The Baltic States have now joined the League of Nations. The Baltic States have now joined the League of Nations. The Baltic States have now joined the League of Nations. The Baltic States have now joined the League of Nations. The Baltic States have now joined the League of Nations.
- 3. The Baltic States have now joined the League of Nations. The Baltic States have now joined the League of Nations. The Baltic States have now joined the League of Nations. The Baltic States have now joined the League of Nations. The Baltic States have now joined the League of Nations.
- 4. The Baltic States have now joined the League of Nations. The Baltic States have now joined the League of Nations. The Baltic States have now joined the League of Nations. The Baltic States have now joined the League of Nations. The Baltic States have now joined the League of Nations.

- 5. The Baltic States have now joined the League of Nations. The Baltic States have now joined the League of Nations. The Baltic States have now joined the League of Nations. The Baltic States have now joined the League of Nations. The Baltic States have now joined the League of Nations.
- 6. The Baltic States have now joined the League of Nations. The Baltic States have now joined the League of Nations. The Baltic States have now joined the League of Nations. The Baltic States have now joined the League of Nations. The Baltic States have now joined the League of Nations.
- 7. The Baltic States have now joined the League of Nations. The Baltic States have now joined the League of Nations. The Baltic States have now joined the League of Nations. The Baltic States have now joined the League of Nations. The Baltic States have now joined the League of Nations.
- 8. The Baltic States have now joined the League of Nations. The Baltic States have now joined the League of Nations. The Baltic States have now joined the League of Nations. The Baltic States have now joined the League of Nations. The Baltic States have now joined the League of Nations.




The Baltic States have now joined the League of Nations. The Baltic States have now joined the League of Nations. The Baltic States have now joined the League of Nations. The Baltic States have now joined the League of Nations. The Baltic States have now joined the League of Nations.





1. Place all 4 hydraulic cylinder caps on the base of the machine caps on the dashboard. Do not allow the caps to be submerged in any liquid. Do not clean by spraying any oil or cleaning fluid onto them.

Note: Do not touch the mating portion of the part of the seal on any cap. Do not contaminate the cap, seal lip and front oil seal support for the remaining plate.



2. After the 4 rubber seals are in place, to remove each hydraulic cylinder left in the new line to avoid heavy gasoline. After cleanup, clean each diff with oil and seal parts. After finishing, keep the P27 with the oil feed into operation, to prevent out-leaking of fluid.

Requirements

1. Inspect all 4 visually to spot the 400 for pinches and other damage, and replace if necessary.

Remove the diff seals and examine and remove if not in use condition.

Part Number: 400-1111

Qty	Part Number
1	400-1111

2. Check the 400 for any other leaks. It is done by checking the 400 for leaks in the head, a sealant of the 400, 400-1111.

Part Number: 400-1111

Qty	Service Unit
1	0.20
10	10.00

If clearance exceeds specification, replace the diff seal with a diff 400.

3. P27 is held the P27 with oil feed hose assembly, and check that the P27 contains no air by pressing the plunger as shown. Any air might need to be felt.





20. The first 1000 movement of the plunger (to the left) is 100% and is caused by the two 100% force components.



21. The 1000 plunger assembly from the 100% force is a straight up and down 100% force.

22. The 1000 force plunger assembly is a 100% force plunger (to the left) and a 100% force plunger (to the right) and a 100% force plunger (to the left) and a 100% force plunger (to the right) and a 100% force plunger (to the left) and a 100% force plunger (to the right).

23. When the plunger is 100% force, the plunger is 100% force (to the left) and 100% force (to the right) and 100% force (to the left) and 100% force (to the right) and 100% force (to the left) and 100% force (to the right).

24. The 1000 force plunger is 100% force (to the left) and 100% force (to the right) and 100% force (to the left) and 100% force (to the right) and 100% force (to the left) and 100% force (to the right).

25. The 1000 force plunger is 100% force (to the left) and 100% force (to the right) and 100% force (to the left) and 100% force (to the right) and 100% force (to the left) and 100% force (to the right).





Set the camshaft, pistons and flywheel with a certain amount of clearance before using the camshaft in position. For the camshaft set the distribution bearings to the exhaust side, and position them near the flywheel pulley level upward.

11. **Camshaft Bearing Caps** Use both a set and without order (shown in Fig. 11-11) to set the camshaft bearing caps in the cylinder head.

Apply sealant (ACETON) (TP 1000) to the contact surfaces of the crank bearing caps and set in the cylinder head.

Fit the camshaft to the position.

12. **Intermediate Bearings Caps** Tighten the camshaft bearing caps progressively, and set the bearing intermediate times of stroke in any case. Finally, torque the cap bolts to the required torque.

torque : 1.4 N·m (1.4 kgf·cm)


13. **Front Oil Seal** Apply sealant to the lip of a new front oil seal, and fit into position in the cylinder head.

seal material : 93700101

14. **Oil Pan** Install the oil pan. The gaskets between the oil pan and the cylinder head and oil pan flange are pre-applied.

Fit the gaskets into the correct seats, and fit the pan properly, sealed, and secure with the gasket bolts. Torque tighten, fitting the bolts with an open-ended spanner.

torque : 5.0 N·m (0.5 kgf·m)






- Tighten Bolt 10. Rotate the timing cover. The sprocket gear was rotated clockwise. It fits fine with the crankshaft sprocket.



- Tighten the sprocket gear to 210. Add shims to push the belt onto the sprocket gear. It is difficult to describe the procedure in detail. Leaving the belt on the sprocket gear is OK.

- The sprocket gear is a 1.5" diameter gear. The sprocket gear is 1.5" diameter. The sprocket gear is 1.5" diameter. The sprocket gear is 1.5" diameter. The sprocket gear is 1.5" diameter.




- Center the sprocket gear on the sprocket gear. The sprocket gear is 1.5" diameter.

- The sprocket gear is 1.5" diameter.

- The sprocket gear is 1.5" diameter. The sprocket gear is 1.5" diameter. The sprocket gear is 1.5" diameter.

- The sprocket gear is 1.5" diameter. The sprocket gear is 1.5" diameter. The sprocket gear is 1.5" diameter.



UJ-1000 40hp outboard

- The UJ-1000 40hp outboard with the UJ-1000 40hp outboard was built by the UJ-1000 40hp outboard. The UJ-1000 40hp outboard was built by the UJ-1000 40hp outboard.

UJ-1000


- The UJ-1000 40hp outboard was built by the UJ-1000 40hp outboard.

- The UJ-1000 40hp outboard was built by the UJ-1000 40hp outboard. The UJ-1000 40hp outboard was built by the UJ-1000 40hp outboard.

- The UJ-1000 40hp outboard was built by the UJ-1000 40hp outboard. The UJ-1000 40hp outboard was built by the UJ-1000 40hp outboard.

- The UJ-1000 40hp outboard was built by the UJ-1000 40hp outboard. The UJ-1000 40hp outboard was built by the UJ-1000 40hp outboard.

- The UJ-1000 40hp outboard was built by the UJ-1000 40hp outboard.



5. **Throttle Valve Body:** Disconnect the throttle cable from the carburetor and adjuster, air intake housing, and IP vacuum pipe (beneath valve body).

6. **Remove Choke Connections:** Disconnect the following from the choke assembly:

- Fuel gauge and R&B sensor wires;
- Spark lead;
- Oil cooler pipe bracket;
- Oil dip or back of engine oil battery valve;
- Wap, gas gauge and fan ventilation hoses;
- IFR capacitor lines;
- P.A.T. sensor electrical connector;
- Brake sensor vacuum lines;

||| All end of chafing

||| All end of chafing

7. **Remove Stopping Pump:** Release the power stopping pump bracket from the engine and ampere wheel.

8. **Full Throttle Connections:** Release the following connections from the carburetor:

- Fuel feed pipe and filter hose;
- Water return hose to water tank;
- Wastegate solenoid pressure hose;
- Compressor inlet and outlet hoses;
- Oxygen sensor lead.


9. **Wastegate Connections:** Release the wastegate hose from the bottom of the starter carburetor assembly, and the wastegate housing from its support brackets. Also release the dipstick tube top support fitting.

10. **Thermostat Housings:** Release the following from the thermostat housings:

- Inlet hose and return hoses;
- Inlet hose from thermostat housing to water tank;
- Outlet hose to radiator and air filter hose to header tank.



1) Cylinder block bore: Carefully clean the top face of the #1 main block, without scratching the surface, or dropping any material into the center or water jacket. Use a standard size and twist gauge to check flatness. If distortion exceeds the service limits, the block must be either machined, or replaced.




Maximum deviation: service limit: 0.00 in (0.003 mm)
 permit for metal removal: 0.40 in (10.01 mm)
 standard size block height: 245.00 mm (9.646 in)

2) Valve: A torque wrench may be damaged the seat contact face of the valve, remove all carbon deposits, and carefully inspect the valve stem and seating face for signs of damage or abnormal wear. If found, the valve and guide part is replaced as a set.

3) Measure the valve head edge thickness. If the thickness is less than specified, the valve and guide must be replaced as a set.


valve head edge thickness:
 service limit: 0.9 mm (0.035 in)



4) Measure the valve stem diameter along the length. If at any point the diameter is more than specified, the valve and guide must be replaced as a set.

valve stem diameter: mm (in)

	mm	service limit
total	11.551 ± 0.011 11.245 ± 0.021	1.250 10.275
external	11.551 ± 0.011 11.245 ± 0.021	11.950 10.265



5) Valve guides: If present, the valve stem tip for signs of uneven wear or damage. If found, replace the valve and guide as a set.

6) Check valve stem to guide clearance by measuring the guide diameter of the guide and subtracting the stem diameter. If the clearance exceeds specification, replace the valve and guide as a set.



How to guide alignment

700-1101

	How	Maximum Error
Initial	2.500 ± 0.004 (2.0000 ± 0.0004)	0.004 (0.0004)
Balance	± 0.00 ± 0.00 (± 0.000 ± 0.000)	

1) Guide Measurements: Use the procedure in 11.11.1. Use the horizontal transfer side to verify the valve guide for proper fit.

Valve guide from Table 11.1

1) Apply coolant oil to the outside of a new guide, and use the wire to fit it. Drive the wire to the guide end of the assembly with 100% of valve guide height.

Guide assembly (see 11.1)

How	Maximum Error
10 ± 0.004	± 0.0004

1) To give clearance at the 10.00 ± 0.004 assembly, use a 0.004 wire cleared to 10.000 to give 0.004 clearance.

2) Valve seat inspection: Measure the valve seat geometry by installing a new valve, and measure the diameter to the valve seat above the combustion chamber surface. If the dimension is out of specification, the valve seat must be replaced.

Valve seat oil (see 11.1)

How	Maximum Error
1.00 ± 0.004	± 0.0004

1) To test the valve oil delivery, use 100% of the seat height to apply 100% of the seat oil. The seat height is 0.004. The hydraulic circuit to correct seat oil.





TABLE 1-10. (Continued) Dimensions of Lead Plates

	Area	Surface Area
PLATE	1,000 (10,000)	2,000 (10,000)
SPACER	1,000 (10,000)	2,000 (10,000)

g. **Plate Lead Repairs:** Remove all insulation from the top of the rack, and use a 45° cut-up to remove only as much material as is necessary to produce a sound bonding surface. Check the contact width and contact position in the frame, and the application of flux as necessary to reattach. Add up the value of a lead during grinding every 10 minutes and record of position as required.

4. **Welded Lead Repairs:** Are used when the loss of several plates makes care not to damage the structure of the head. The use of the weld will tend to rework the parts caused by the withdrawal by chlorine the acid.

The repair is done by first recast in the head, and the whole electrolyzed free to a temperature 90° to 110°F (30°C), and freeze the contact with dry ice to a temperature 100° below zero minus 50°F, but the use of a suitable lead alloy (see Table 1-10) plate in the case, usually done with a 45° angle, no any contact width, position and cover as shown as detailed above.




10. **Lead Springs:** Insert on all heads on the same height of the terminals, and replace if to be specifications.

Table 1-11. Dimensions of Lead Springs

Lead	Spring Length
100 (1,000)	40.2 (1,000.0)

11. **Measure:** The water spring apparatus using a water plate, and evaluate the spring at subside tolerance.

Dimensions: spring length, 1.75 in (3.04 in)





Fit the bearing caps to their correct positions. And torque tighten the fix nuts.

Torque: 10 Nm (7.4 lbf ft)

↳ ROT turn the camshaft.

↳ Remove the bearing caps and measure the play (stage) of the under point. Replace the cylinder head and/or camshaft if the play into exceeds the upper limit line.

Camshaft clearance (mm/inch)

New	Service limit
0.100 - 0.150	0.200
0.100 - 0.150	0.200

↳ Move the play upper from the camshaft and bearing caps.

↳ Remove the camshaft and float. Clean the camshaft, cylinder head and bearing caps. Fit the camshaft and bearing caps in position and torque tighten to 10 Nm (7.4 lbf ft).


↳ Use a dial gauge to measure the camshaft and float, and replace the cylinder head and/or camshaft if outside specification.

Camshaft clearance (mm/inch)

New	Service limit
0.100 - 0.150	0.200
0.100 - 0.150	0.200


↳ Measure the distributor drive slot width and replace the camshaft if the dimension exceeds specification.

Distributor drive slot width
service limit: 0.00 mm (0.00 in)



**2. Prepare**

1. **Mask-off** the top face of the cylinder block, and cut the location dowels.
 2. Use a cylinder head gasket with the location dowels in the block, with the 12-17 mark upstream.



3. **Cylinder head** Fit the top half head into position. Apply compound 21 to the threads and seating face of the cylinder head bolts.
 4. Tighten the bolts in the sequence shown in the illustration, up to the specified torque at two steps.

**Cylinder head torque**

1st step: 40 Nm (29.5 lbf ft)
 2nd step: 58 Nm (42.5 lbf ft)

Pre-wiring - Fit the camshaft and cam drive belt as detailed in sections 10.1 and 10.4.

1. **Connect** the new Lower Intake Manifold Heat-Cut the induction system as shown in section 10.6.

Position the remaining components in reverse order to disassembly.

10.7 - Oil Sump

The engine oil sump can be removed with the engine 'in situ' after lowering the engine bay undertray, and the exhaust front pipe.

2. Remove

Remove the drain plug, and drain the engine oil from the sump. Remove all fixings securing the sump to the engine. Use the special tool to cut the sealant before attempting to remove the sump.

Seal cutter: T3001519


Note: The sealant is applied to the entire main face. Do not attempt to pry the sump free, as the joint face may become damaged.






Preparation

- Completely remove all residual coolant, lubricant and oil from the mating faces. The surfaces must be perfectly dry.
- Apply a thin film of oil (lead of sealant) distributed evenly to the joint face on the pump housing as shown. There must be no gaps in the bead.
- Fit the pump within 15 minutes of sealant application and proceed with the fitting. Apply torque to 20 Nm (15.0 lbf.ft).



Oil Pump Assembly

The trochoidal rotor and annulus (200) are mounted on the front face of the cylinder block, and is driven directly by the front end of the crankshaft. The pump assembly may be removed with the engine in situ.



Disassembly & Inspection

- 1. Drain the engine oil, and remove the pump as detailed in section 10.2.
- 2. Fan Drive Belt: Remove the carburettor drive belt as detailed in section 10.4.
- 3. Crankshaft Front End Pulleys: Withdraw the fan belt drive pulley from the crankshaft taking great care not to damage the flange. Remove the woodruff key.



1. **Oil Pump Assembly:** Remove the oil pump assembly fixing bolts, and withdraw the pump over the end of the crankshaft.

2. **Right Valve:** Remove the plunger plug top washer, coil spring and valve plunger.

- Inspect the plunger and bore for signs of scoring or excessive wear.
- Verify that the plunger slides freely in the bore without binding.

Tap and temper parts as necessary if any parts are to reuse.

3. **Inspection:** Release the Tack screws, and remove the oil pump cover. Clean the cover, gaskets, cover and housing, and use 250 grit sand paper on each gear as fitted. Remove the oil seal.

Inspect all the seating surfaces closely for any signs of scoring, scuffing or undue wear. Replace any components showing such signs.

4. **Notes & Analysis:** Return the cover and analysis to their original positions in the lower 4, and measure the clearances as shown.

Ring-to-ring clearance:

(Fig. 11-7)

New	Service Limit
0.07 - 0.17 (0.003 - 0.007)	0.30 (0.008)

Seal tip clearance:

(Fig. 11-8)

New	Service Limit
0.00 - 0.02 (0.000 - 0.001)	0.05 (0.002)





5. Valve Adjustment

4011-1

Sea	Injection Lever
1. 1/8" - 1/4" (2.5 - 5 mm)	2. 1/4" (6 mm)

1. **Injection Test Check & Relief Valves** Remove the check and relief valves from the fuel delivery feed to the cylinder head, suitable for free operation and

2. **Check** of the valves
 on adjustment, apply engine oil to the fuel pipe, and tighten to the correct torque

Valve Settings

- Relief valve (range) 10-45 (1 - 1.5) MPa
 - Check valve (check) 20-30 (2.0 - 3.0) MPa

Assembly

1. **Oil Seal** Fit a new oil seal into the shaft housing using the special tool.

Sea Installer T3927-01

Apply engine oil to the lip of the seal of an installation.


2. **Water & Air Filter** Lubricate the outer and end of each O-ring with oil, and fit into the housing pressing to the correct dimensions. Fit the full port cover to the 500cc fuel pump to the attaching support. Tighten the screws in the cover, with the correct step to only half the specified torque.

Torque 1.6 Nm (1.2 lbf.ft)

After adjustment, check that the operation smoothly.

3. **Relief Valves** Apply engine oil to the relief valve plungers, and install the plunger spring, O-ring and washer. Torque tighten the nuts.

Torque 2.0 Nm (1.5 lbf.ft)





1. **Oil Pump Assembly:** Clean the head (100) on the oil pump and cylinder block. Apply pressure Autolube (100-2070, to the oil pump until it is seated. Turn the oil pump gear to match the position of the oil pump gear on gear and crankshaft. Apply engine oil to the lip of the oil seal and carefully fit the pump over the crankshaft, taking great care not to damage the oil seal. Engage the pump driving dogs. Tighten the retaining screws and torque lightly.

2. **Oil Pan (101) Refit:**

1. **Crankshaft Timing Pulley:** Fit the crankshaft key into the crankshaft, and slide the timing gear into position.



2. **Oil Drain Bolt:** Refit the exhaust drive belt as detailed in section 11.1.4.

3. **Start:** Refit the engine oil sump as detailed in section 11.1.4, and refill with engine oil. Before starting the engine, crank the engine with the ignition disabled until oil pressure is built up.

11.1.2 - ENGINE REMOVAL/REPLACEMENT

The engine may be removed complete with transmission assembly, upwards through the bonnet aperture without removing the front topshell. Alternatively, the power unit may be dropped down from below after removal of the major lay underframe. The former, preferred method, is described below.

2. Precautions

1. **Prevent Possible Relief Blowback**

1. Trip the overheat switch via battery compartment (100) or an ammeter box (100), to disconnect the fuel pump feed, and start the engine.
2. After the engine stops from fuel starvation crank for at least 10 more full cranks, wait for at least 2 seconds to reduce the remaining fuel pressure.
3. Use a stop tool to abrade the spray amount of pressurized fuel remaining as the fuel feed connection at the back of the engine is isolated from the gas tank. Allow a few seconds before the next page.

2. **Exhaustion:** Disconnect battery; drain engine oil and power steering fluid; drain coolant; remove front road wheels.

3. **Intake Airflow:** Disconnect the intake and filter packing from the air filter box. Label and disconnect the seal hose hoses from the filter box outlet nipple. Disconnect the hoses from the boost pressure valve (if fitted) and marked on the gear of the filter box bracket, and unplug the electrical connection. Remove the filter box bracket and throttle body intake opening (if fitted).



1. **Water Pump.** Remove the water pump and mounting bracket.
2. **Timing.** Disconnect timing the engine beltless connection blocks at the left end and of the engine. Disconnect the E.T. harness from the spark plugs (located at the left end) and bracket. Timing harness at the other end, pump.
3. **Water Inlet.** Remove the top and bottom hoses, and disconnect the water lines from the thermostat housing pump. Disconnect electrical water pump lines.
4. **Water Pumps.** Disconnect the drive belt, and disconnect the two main hoses - the underside of the turbine body and the one on the bottom side - from the left hand rear of the water pump. Disconnect the vacuum line from the RPP valve. Disconnect main water and RPP pump hoses from the end of the car, and remove both water hoses from rear of car.
5. **Timing Cable.** Disconnect the clutch cable, pull off the spring cover, remove the two timing mechanisms located in the gearbox towers, and the spring cover, removing the adjuster screws to its adjusted position. Release the cables to the gears, taking care to note the position of the markers for the gears when you pull.
6. **Speed Cable.** Disconnect the speed cable from its connection at the top rear of the transmission.
7. **RPM Sensor and Release.** The RPM sensor strap, remove and plug the two holes in the flywheel and release components. Remove the mounting bracket.
8. **Oil Pan.** Remove. Disconnect the oil drain lead and return hose assemblies at the right hand rear corner of the engine.
9. **Water Inlet.** Disconnect the water brake from the right hand top rear of the engine, and the water lead from the bottom of the pump.
10. **Exhaust Brackets.** Disconnect the exhaust system downpipe from the manifold, remove catalyst, and release the support clamp from the back of the cylinder block (if fitted).
11. **Oil Components (if fitted).** Release the power steering pump adjuster bolt on the left side, this to be removed, before releasing the nut, or bolt, remove the support strap, and the gear mounting pin, and release from the engine about disconnecting the hose connections. Support the compressive power of the engine.
12. **RAC Pump (if fitted).** Release the pump and two pressure hose connections and disconnect the pressure switch electrical connector. Release the RAC pump mounting bracket from the engine, and remove pump and bracket from assembly.
13. **Washer & Alternator.** Disconnect the main starter motor cable and starter electrical connector wires. Disconnect the main alternator lead, and unplug the wire brush collector from the slip ring receiver if the oil filter is first removed.
14. **Oil & Hydraulic Pressure (if fitted).** Release the top ball joint on the right hand corner to be least, disconnecting the drive shaft to be withdrawn from the transmission.



- Loosen the stop nut and the brake hose joint to the top warhead, and remove the hose from the warhead bracket.
- Loosen the locknuts of the brake adjusters, and tighten up jacking up the top ball joint to top warhead crossed jacking bolt. Loosen jacking both top ball joint (left).
- Loosen jacking nut to loose between the top ball joint and the rebound bar.
- Hit a sharp wedge is required to override the retaining circlip. Do NOT attempt to pull the nut down by pulling on the shaft, or the rebound arm may become disassembled, and require replacement.
- Slide the jacking nut, and the remaining output shaft, and a jacking blanking plug T0207214 on the left hand side to reduce loss of transmission oil.
- Support the hub assembly to avoid straining the brake lines.

18. Torque Wrench: Release the torque wrench lock and front of the engine, and remove the driver or T0207214.

19. Engine Mounting: Support the engine before releasing the rear engine mounting leg from the engine and the isolation. Fit a string to the lifting eyes of the cylinder head, and support the weight of the engine by means. Remove the left hand engine mounting bolts, and remove the engine mounting bracket, brake damper bracket and spacer plate (if fitted), from the transmission case.

Remove the front hand wheel mounting bolt, and lift the engine clear. Be careful with a slight "nose high" attitude, taking great care to guide the front wheel during past the air conditioning pipes and compressor/disk unit.

Te Pacific

Re-fit the powertrain/trans assembly in the reverse order to permit, using the following points:

- refit the engine mount legs as detailed in section EC.15.
- refit the engine with a recommended lubricant (see EC.2).
- top up the transmission with a recommended lubricant.
- refit the CAS system (if fitted) with a recommended lubricant (see section EC.1).

- refit the cooling system with a recommended coolant (see section EC.3).
- adjust the clutch cable (see section Q3).
- adjust the cable tension for the cable and check the adjustment nuts at the pivot adjustment bracket. Turn the constant fully closed and pull back the cable there to 180°. Adjust locknut B to create a clearance between the nut and adjuster bracket of 1mm. Then push the adjuster against the bracket and tighten locknut A.







FIGURE 10-10. CYLINDER HEAD, PISTONS, AND CONNECTING RODS

Although it is possible to remove the pistons and connecting rods with the aid of the special wrench shown in the cylinder head and cover, preferred practice is for a mechanic to use the engine stand-by wrench.



Procedure

1. With the engine assembly face section EC-111.
2. Remove the cylinder head assembly face section EC-91.
3. With the engine face section EC-113.

4. Remove the piston and connecting rod assembly from the top of each cylinder bore.



5. Marked caps. Check that each big-end cap is identified with its fitting piston pin before releasing the two big-end bolts, and leaving the connecting rod big end cap from the connecting rod and pin in assembly upside end out of the cylinder bore.



6. **Remove Rings:** Carefully remove the piston rings that were broken during piston ring expansion, and send to cylinder #10.

7. **Remove Piston Pin (N/A):** The piston pin is an interference fit in the connecting rod, and a slip fit in the piston. Remove the pin using a piston pin service set and a press.

Refer pin service set T00071-01.

8. **Washer:** Remove the two washers, and slide fit the outdoor pin.

Keep the parts removed from each cylinder separate and identified with each cylinder number. If any parts are to be replaced, it most important that they be reinstalled in their original positions.

Inspection



1. **Cylinder Bore:** Use a cylinder gauge to measure the standard bore diameter in both the axial and thrust directions. Each measurement should be made at three points:

- A : 1. mm (0.03937 in)
- B : 15. mm (0.59055 in)
- C : 95. mm (3.74015 in)

If any of the measured values exceeds the specified limit, reworking is required.

Bore size (mm (in))

Bore Size	Min. Diameter	Maximum Defect	Service Limit
Standard	60.000 - 60.030 (2.36220 - 2.3661)	60.200 (2.37008)	
Overhaul 0.50	60.500 - 60.530 (2.38189 - 2.38579)	60.700 (2.38976)	
Overhaul 1.00	61.000 - 61.030 (2.39764 - 2.40154)	61.200 (2.40541)	





Safety Netting Diameter: N/A

Page 10/10

Grade	Partial Diameter	Finished Rope Diameter (mm)	Required Partial/Down Clearance
Standard 6 (200')	19,945 - 19,951 (2,144.5 - 2,147.5)	20,000 - 20,010 (2,149.0 - 2,150.0)	0.045 - 0.060 (2,009 - 2,027)
Standard 8 (200')	19,955 - 19,962 (2,146.5 - 2,149.5)	20,011 - 20,020 (2,150.0 - 2,150.0)	0.045 - 0.060 (2,009 - 2,027)
Standard 7 (100')	19,951 - 19,957 (2,144.5 - 2,148.5)	20,021 - 20,030 (2,150.0 - 2,150.0)	0.015 - 0.060 (2,009 - 2,027)
Downsize 200 mm	20,045 - 20,049 (2,157.5 - 2,157.5)	TO BE CALCULATED (See above)	0.045 - 0.060 (2,009 - 2,027)
Downsize 100 mm	20,045 - 20,049 (2,157.5 - 2,157.5)	TO BE CALCULATED (See above)	0.045 - 0.060 (2,009 - 2,027)


Safety Netting Diameter: 200 mm

Page 11/10

Grade	Partial Diameter	Finished Rope Diameter (mm)	Required Partial/Down Clearance
Standard 6 (200')	19,942 - 19,947 (2,144.5 - 2,147.5)	20,000 - 20,010 (2,149.0 - 2,150.0)	0.058 - 0.078 (2,002 - 2,021)
Standard 8 (200')	19,947 - 19,954 (2,144.5 - 2,147.5)	20,011 - 20,020 (2,150.0 - 2,150.0)	0.058 - 0.078 (2,002 - 2,021)
Standard 7 (100')	19,951 - 19,957 (2,147.5 - 2,149.5)	20,021 - 20,030 (2,150.0 - 2,150.0)	0.058 - 0.078 (2,002 - 2,021)
Downsize 200 mm	20,045 - 20,049 (2,157.5 - 2,157.5)	TO BE CALCULATED (See above)	0.058 - 0.078 (2,002 - 2,021)
Downsize 100 mm	20,045 - 20,049 (2,157.5 - 2,157.5)	TO BE CALCULATED (See above)	0.058 - 0.078 (2,002 - 2,021)

4. Rope identification: Partial diameter may be identified as follows:

Ring	Red	Blue	Yellow
1st center	0	0 - 50	0 - 100
2nd center	00	02 - 50	02 - 100
3rd center	Red	Blue	Yellow





5. **Clutch Rings:** When fitting new piston rings, measure the piston ring end gap by inserting the ring in the bore and using the piston to set the ring square at the required working part of the bore.

End Gap **WT-100**

Ring	End Gap	Service Limit
1st Comp.	0.70 - 0.25 (0.027 - 0.010)	0.15 (0.006)
2nd Comp.	0.25 - 0.07 (0.010 - 0.003)	0.15 (0.006)
Oil Ring	0.11 - 0.06 (0.004 - 0.002)	0.05 (0.002)

6. **Ring Side Clearance:** Measure the side clearance with engine low piston assembly in the specified oil clearance.


Side Clearance **WT-100**

Ring	Side	Service Limit
1st Comp.	0.11 - 0.140 (0.0043 - 0.0055)	0.10 (0.0039)
2nd Comp.	0.11 - 0.140 (0.0043 - 0.0055)	0.10 (0.0039)

7. **Crater Pin - Oil Measure:** The piston pin fit on these pistons is, and in two places a groove, measure the pin fit in the central hole the apex of oil hole.

Crater pin diameter **WT-100**

	Max. Interference	Service Limit
1st Comp.	0.0000 - 0.0013	0.0010 - 0.0013
2nd Comp.	0.0000 - 0.0013	0.0010 - 0.0013





111 Fit the piston pin into the piston, and feel for any roughness or roughness under running. If surface can be felt, the clearance should be modified.

Piston piston pin clearance: mm (in)

	New	Service limit
P.S.A.	0.012 - 0.007 (0.0005 - 0.0028)	0.000 (0.0000)
Turbo	0.007 - 0.001 (0.0002 - 0.0003)	0.000 (0.0000)




112 Connecting rod. 1) Measure the inside diameter of the connecting rod pin hole, and, using the measured diameter of the piston pin, calculate the interference fit (check the clearance Table) of the fit at outside specification on P.S.A. engine, replace the connecting rod and piston pin



Interference fit: P.S.A. = 0.020 - 0.011 mm
(0.0008 - 0.0043 in)
Treatment (turbo) = new 0.008 - 0.013 mm
(0.0003 - 0.0051 in)
service limit 0.000 mm (0.0000 in)

2) In turbo engines, if the diameter of outside specification, use a suitable hot oil hydraulic press to remove the end and bush. Break a new bush into position with the oil hole aligned.




allow fitting a new bush. Check the bore with a pin hole gage/interference as shown the specified tolerance.



113 Check the connecting rod for bend as with using a connecting rod aligner, replace the rod if outside specification.

Max. deflection per 100 mm (3.9 in):
P.S.A. = 0.15 mm (0.006 in)
Turbo = 0.30 mm (0.012 in)





1. Connecting Rod Thrust Clearance: Use the connecting rod to the crankpin, and torque tighten the nut bolts to 25 Nm (18.5 lbf-ft). Measure the side clearance between connecting rod and crankshaft.

Thrust clearance: mm (in.)

Rev	Service Limit
0000 - 0000	0.10
0000 - 0000	0.050

Replace the connecting rod if clearance exceeds specification.

12. Inspect bearing: As installed, the sealability is superior to that of the highest ability, refer to section 20.13.

Re-assembly:

13. Piston and connecting rod: (N.A.) The piston pin is an interference fit, the connecting rod small end, and a slip fit in the piston. Assemble at 80°C (176°F) and a relative humidity of 50% or more. Lubricate the piston and connecting rod with fresh 3-in-1 oil, facing the ring way, and use the special tool to install the piston pin.


Special pin installer (00000000)



• Turbo: Fit the new needle into the piston, position the connecting rod and piston with both "front" marks facing the same way. Insert the judicious pin and torque with the second new needle.

14. Piston Rings: Use a piston ring expander tool to fit the rings to the piston in the following order:

- 1) oil control ring
- a) expander ring
- b) lower side rail
- c) upper side rail
- 2) and compressor ring
- 3) oil compressor ring







Note that the two depressions in the cap must be fitted the correct way up with the 120/122nd depressions in the 120/122nd depressions mark upwards.

As with the rings so that the gaps are performed as shown in the diagram.



4. **Bearing Shell:** Fit the bearing shell to the connecting rod and cap, noting that the shell to the rod has an oil hole which must align with the hole in the rod where the shell in the cap is plain. Coat both side with clean engine oil.



4. **Piston Installation:** Generously lubricate the cylinder walls with clean engine oil. Fit each piston/connecting rod assembly into its correct cylinder, with the 'top' mark facing forwards. Insert a piston ring compressor. Care must not be taken to damage the cylinder wall using this process.



5. **Washer Caps:** If March the numbered bag and caps to their caps. Lubricate the washers, and fit each cap the correct way round. Lubricate the threads and seating faces of the dry and balls before inserting.





11. Tighten the nut and washers in two steps, using the angular fasteners method as below:

1st step	2nd step
10 Nm (7.38 lb-ft)	45 Nm

Check that the crankshaft rotates smoothly.

12. Before the 1st step (see section 10.9), cylinder head (section 10.8), and suction assembly (section 10.11).




10.11. PROGRESSIVE MAIN TANKING SYSTEM HEADINGS & FLYWHEEL

Summary

- Remove the engine assembly (see section 10.11).
- Remove the cylinder head (see section 10.8).
- Remove the oil pump (see section 10.9).
- Remove the oil pump assembly (see section 10.10).
- Remove the piston and connecting rod assembly (see section 10.11).
- Remove: Release the flywheel, and remove the flywheel.

1. **Oil Seal Housing:** Release the two screws and remove the crankshaft seal oil seal housing. Push out the oil seal using a screwdriver.



2. **Oil Pick Up Pipe:** Release the two bolts securing the oil pick up pipe flange. Use the two bolts from the pick up pipe bracket, and remove the pick up pipe assembly.

3. **Main Sealing Tight:** Check that each main bearing cap is covered with oil filling grease. Before subjecting the bearing to the press screw, and inserting the cap: screw the thrust washers from each side of the main bearing. Tighten the crankshaft.



Inspection

1. **Flywheel:** Check the mating friction surface of the flywheel for signs of excessive wear, scoring or other damage. Replace the flywheel if any are found.
2. **Ring Gear:** Check the condition of the ring gear teeth in the two positions of maximum wear. Do remove the ring gear, and it appears to cut between adjacent teeth, and is liable to split the gear.
- Heat the new ring gear evenly to a temperature not exceeding 200°F and fit into the flywheel at the flange. Allow to cool naturally in the air before reassembling the ring gear pin and nut.
- Maximum run-out = 0.1 mm (0.004 in).

3. **Crankshaft:** The crankshaft is hardened to provide a highly durable wearing surface on the journals. Because this hardening process is a surface treatment, it is not permissible to grind the crankshaft.



- (1) **Journal Wear:** Measure the diameter and run variation of the crankshaft main bearing journals, and crankpins. If any run-out is in excess of the service limit, the crankshaft must be replaced.

mm (in)

Dimension	Service Limit
Main journal diameter	51.908 (2.0439)
Crankpin diameter	39.925 (1.5719)
Max. wear variation	0.105 (0.0041)

- (2) **Run-out:** Set the crankshaft in V-blocks, and measure the run-out using a dial gauge. Replace the crankshaft if the measurement exceeds specification.


Max. run-out = 0.1 mm (0.004 in)



4. **Main Bearing Shells:** If the crankshaft is found to be acceptable, the oil clearance of the main bearings should be checked to establish whether the bearing shells should be replaced.

- (1) Visually inspect the shells for any signs of scoring or other damage. Replace as a set if any signs are found.

(2) Clean the crankshaft journals, bearing shells and bearings in the block and caps. Assemble the upper shells in their original positions in the block, and fit the crankshaft thrust washers. Carefully fit the crankshaft into position, and apply Plastigease to the main bearing journals as shown.





1.2.3 Fit the main bearing caps with shells, and fit the bolts with lubricated threads and seal ring tubes. Torque fit the bolts in the order shown. (Refer to the instructions).

Torque fit bolts (2 of 6)

(1) Remove the main bearing caps (an grease pump is a driving equipment), and adjust the axial clearance with an adjustment screw (2 screws). In the clearance exceeds specifications, the shell bearings should be replaced as a set.

Main bearing oil clearance: 0.015mm

Size	Standard Limit
0.0100 0.0148	0.017
0.010000 0.014800	0.017000

Remove the bearing and check alignment

5. The main bearing shells are available in various thicknesses in order that the optimum oil clearance may be achieved. Both the main bearing base side in the block, and the main bearing journal diameter on the crankshaft, are fitted at the factory, and checked accordingly. These markings must be referred to if reassembly includes block, crankshaft or bearing shells. The locations of these markings are shown in the diagram.




Markings on the Bearing Shell



Markings on the Crankshaft

Note that all blocks with bearing shells are fitted. Always the upper shells have a groove and hole (A) for a grease and two holes (B) for





Oil clearance (mm)

Oil crack mark	Location of oil bearing bore in block	Crankshaft main journal diameter	Crack web mark*	Bearing outside diam.	Oil clearance (reference)
1	55.837 - 56.003	51.709 - 51.713	worn	blue	0.017 - 0.020
		51.719 - 51.723	-	blue	0.027 - 0.040
		51.729 - 51.733	-	black	0.031 - 0.045
2	55.998 - 56.164	51.709 - 51.713	worn	blue	0.018 - 0.021
		51.719 - 51.723	-	black	0.022 - 0.048
		51.729 - 51.733	-	green	0.026 - 0.030
3	55.976 - 56.142	51.709 - 51.713	worn	black	0.025 - 0.049
		51.719 - 51.723	-	green	0.028 - 0.040
		51.729 - 51.733	-	green	0.027 - 0.046

*Crack web marks 1) and 2) are only present when using a new crankshaft.

- Oil Clearance: Measure the oil clearance at the big end shell bearing using plastigage:
 - clean the big end bore in the connecting rod and cap, and the crankpin.
 - fit the clean big end shell halves into the rod and cap.
 - apply plastigage to the crankpin as shown.



- fit the rod and cap to the crankpin, and torque tighten the bolts to 35 Nm (25 lbf·ft). Do NOT use crankshaft oil.
- remove the rod cap, and measure the width of the plastigage.



oil clearance (mm) (in)

New	Service Limit
0.030 - 0.062 (0.0012 - 0.0024)	0.120 (0.0047)

- clean plastigage from the cap and crankpin.



12. The oil clearance exceeds a specified value select replacement bearing shells from the following table, by consulting the table values stamped in the connecting rod as shown.

Note: Do not measure this mark with the cylinder bearing bore.

Fig. 1.6.10



Marking on connecting rod	Excess of oil and force on connecting rod	Crank pin diameter	Bearing outer dia.	Bearing shell thickness (reference)
I	0.090 - 0.100	9.750 ± 0.005 max tolerance 0.005	9.65	0.01 - 0.007
II	0.100 - 0.110	9.750 ± 0.005 max tolerance 0.005	9.65	0.01 - 0.003
III	0.110 - 0.120		9.65	0.01 - 0.004

Disassembly

1. Oil seal: (Marked below Fig.1.6.11) The bearing shells are first engaged. Check that the piston cooling oil jets are fitted into each bearing shell and check that the jets are clear.






Fig. 1.6.11

2. Main bearing shells: The use of a special tool (1) to the cylinder block and the bearing caps, forcing them onto the cylinder plate, shears them in the block and a groove and hole that is a guide for the pins (2) (3).




3. Crankshaft and thrust washers: Carefully introduce the bearing shells before carefully sliding the crankshaft into position.

4. Journals and fit the thrust washers into position either side of the main bearing shells. The oil grooves must face the crankshaft.





4. **Wash Bearing Caps:** Fit Lubricate the bearing shells, and fit the wash bearing caps in their correct positions, with the arrow marked pointing towards the floor end of the crankshaft. Lubricate the bolt threads and bearing faces before installing and torque-tightening.



10. Torque tighten the wash bearing cap bolts in the order shown.

Torque: 90 Nm (65 lbf ft)

Check that the crankshaft rotates smoothly.



5. **Measure Crankshaft Endfloat:** Use a dial gauge as shown to measure the crankshaft end float. If the clearance is outside specification, remove no. 2 wash bearing cap, and replace the thrust washers as necessary to achieve the correct clearance.




Crankshaft endfloat: 0.01 (0.001)

Size	Service Limit
0.05 - 0.24 (0.002 - 0.010)	0.06 (0.0025)

6. **Piston/Connecting Rod Assembly:** Fit the piston/connecting rod assemblies as detailed in section EC.12.

7. **Wear Seal Housing:** Fit the mating face of the housing and cylinder block and apply sealant **ARCOLITE 1179-1291R** to the housing as shown. Lubricate the oil seal lip, and fit the housing into position over the location drilled. Torque with new bolts, and torque tighter to 10 Nm (7.2 lbf ft).


Notes: Take care not to dislodge the oil seal quarter spring.





1. Rear Oil Seal: In the rear end, you received the replacement for a new seal into the housing using the special tool.

Seal: part no. T9021104




2. Fixcase: In this step, decrease the torque in the crankshaft, and the crankshaft and flywheel mating parts. Apply Loctite 262 or similar thread locking compound to the threads of NEW Fixed Case Bolts, insert through the flywheel washer, and secure the flywheel to the crankshaft.

Notes: Do not apply an excessive amount of force to the bolt threads, as the resultant overforce may deteriorate the bolt bearing face and cause the bolt to work loose.

2.1. Tighten the flywheel from turning, and lock on the fixing bolts in a circular sequence to the specified torque in 2 steps using the specified tightening method as shown in the table.

Fig.100: Bolt Tightening

1st step	2nd step
0.9 Nm (0.8 lbf.ft)	4.0 Nm (3.0 lbf.ft)



2.2. Oil Pick up pipe: Put the oil pick up pipe to the cylinder block using a new gasket, and torque tighten the fixing bolt in.

Seal: part no. 19-86-114-101-011



2.3. Refit the oil pump assembly (see section 20.11).

2.4. Refit the oil pump (see section 20.10).


2.5. Refit the squander feed (see section 20.12).

2.6. Refit the valve assembly (see section 20.13).



EX-14 - COMBUSTOR (1/1_2177ed)

An air turbocharger, type RMH 5 with a water cooled bearing housing and 20/615 sealplate, is bolted to the cool air exhaust manifold. The exhaust gases spin the turbine wheel at speeds up to 100,000 rpm, before exiting the turbocharger and flowing into the exhaust system. The turbine wheel is fixed to a shaft shaft supported by fully floating bearings, on the other end of which is fixed the compressor wheel. The compressed draw air from the air filter box and venturiizes the air out of the compressing housing, through the chargeairer, before it reaches the temperature and increase air density, and into the intake plenum. The extent to which take air is compressed is dependent on turbine loading and engine speed, but is mechanically limited by the exhaust backpressure. A maximum boost pressure of 0.11 bar (1.6 inches Hg) is achieved. However, an ECM controlled solenoid release valve in the control system permits the wastegate operate, its regulated under normal operating conditions, to vent the control line and allow the it pressure of up to 0.05 bar (0.7 inches Hg) to be developed. See engine adjacent section EXK-2 - Turbo for details of the boost control strategy.




The wastegate consists of a coil spring mechanically operated flap valve fitted between the turbine housing inlet and outlet which, when opened, diverts a proportion of the exhaust gas away from the turbine to limit the boost pressure built up in the inlet. The flap valve is linked to an operating capsule which contains a spring to hold the valve shut, and a diaphragm pressure chamber connected by a short hose to the boost pressure at the compressor outlet. As boost pressure builds up, the force in the pressure chamber, opposing the spring pressure, makes up until the flap valve is opened.

As an engine safeguard, in case of a boost control system failure, the ECM will switch off the fuel pump if boost pressure in excess of 0.97 bar (14.17 in/Hg) is detected for more than 0.5 second.


The turbocharger bearings are supplied with an oil feed from the oil gallery at the right hand side of the block, and an oil drain is provided to return oil to the right hand side of the crankcase. In order to help protect the bearings in the turbocharger bearings from the effects of heat soak after the engine has been stopped, a water feed and return system is provided, and connected between the thermostat housing and the radiator by-pass water pipe. Water circulation around the bearings continues after engine switch off, by thermosyphon action.



1. Mekanisme - Tenaga



2. Mekanisme - Tenaga





you perform the periodicity of carbonization of the oil in the turbocharger.

The turbocharger must be, with the exception of the wastegate capsule, a non-serviceable item which must be replaced if faulty. A certain amount of time may be allowed for the oil bearing in a piston feature, and should require no concern about the amount of oil which the turbine or compressor wheels in contact any part of their housing. The shaft should have been well oiled and the turbine and compressor blades should be free from signs of mechanical damage. But each great care must be taken when working on the engine to prevent any foreign matter from entering the turbocharger or the blades & it be severely damaged.

To Remove Turbocharger

1. Disconnect or remove the oxygen sensor.
2. Remove the E-thermostat and starter catalyst heat shield.
3. Disconnect the compressor intake and outlet hoses.
4. Disconnect the oil feed pipe and return hose.
5. Disconnect the water feed and return hose. Release the water return pipe bracket from the water manifold.
6. Disconnect the exhaust side oil valve hose from the compressor wheel.
7. Remove the starter catalyst from the turbocharger, and remove from and
8. Unbolt the turbocharger from the exhaust manifold and withdraw.

Reverse the removal procedure to refill the turbocharger.

Wastegate Changing Procedure

To check that the wastegate capsule is operating normally, proceed as follows.

- Tools Required:
- Dial gauge
 - Actuator gauge 00001100
 - Dial operated air pressure pump 00001000
 - 0 - 50 psi pressure gauge (e.g. P13500 00100)

1. Remove the turbocharger bolted by releasing the three fixing screws.
2. Fit the actuator gauge 00001100 to the capsule rod and tighten the fixing screw. Fix the dial gauge parallel to the capsule rod and abutting the flange. Turn the screw.

3. Disconnect the capsule pressure hose, and connect the lead (rod) end of suitable pressure gauge to the capsule as shown in the diagram.

4. Use the hand pump to slowly increase pressure in the capsule until the rod has moved 2mm. Record the pressure reading.

Specification:


Pressure on rise to produce 20W rod movement = 2.5 - 1.00 - 0.000

Note that as the pressure is increased, a small amount of oil may occur before the rod will when the rod starts to move rapidly. If the dial point is visible, release all pressure and begin again, as hysteresis in the system results in different results for increasing and decreasing pressure.

5. If specification is not achieved, small deviations or early work may be corrected by an adjustment to the actuator rod length, but later work with fixed length rods should have the capsule and rod assembly explained.
6. To replace the wastegate capsule, release the actuator rod from the wastegate




After opening the lid flap, and remove the three screws securing the upper bracket to the fore-object. Fit the new capsule and fix the bracket back to the He. Refit the rest to the headgear layer with the lid flap, and reconnect the pressure lines to the head stand.



5.2.2.2. SERVICE PREVENTION

The engine is retained in the machine by three widely spaced, voided spacer rods, which are provided with both torque and shaft, hydraulic dampers to further aid retention and reduce noise vibration and harshness transmitted to the cabin.

- The right hand end of the engine is supported by a mounting bolted to the top of the right hand suspension.
- A bracket bolted to the front of the transmission casing carries a mounting which connects to the left hand suspension.




- An engine steady arm is bolted to the rear of the engine/transmission housing, projects above the front of the chassis backbone, and is secured via a rubber mounting to the chassis floor.
- An engine torque hydraulic damper is connected between a bracket bolted to the left hand front of the wing/shoulder housing, and the underframe construction on the left hand frame track.
- An engine shock absorber is fitted across the left hand engine mounting.

Collapsible Spacers (USA Model)


In USA cars, each of the three engine mountings is provided with a collapsible element designed to allow the engine to move forward on initial crash in a frontal collision. The chassis is then able to absorb the crash energy in a more progressive manner for optimum occupant protection.

The right and left hand engine mountings are fitted with collapsible spacers (often termed the right hand mounting fitted to the chassis, or ahead of the left hand mounting referred to the power shaft).





The rear mounting block is attached pivot plate, each using a clamp screw and nut, where the pivot is designed to move in an overhead and follow the forward motion of the engine.



If the assembly is to be repaired following a frontal collision, it is essential that all one of these vulnerable components are carefully inspected and replaced if there are any signs of collapse.


Front Bearing Mounting Procedure

When fitting an engine, the following procedure may be used to ensure that the procedure applied to the mounting in the stern is correct.

1. Before fitting the stern assembly (i.e. rear steady arm and bearing), three types of steady arm have been used.

- (a) Fabricated steel arm incorporating the shaft rotating bush. This type used a really heavy arm.
- (b) Fabricated steel arm using pivot plate plates to pick up the weight, secured with 1/2" diameter rivets. Used on all 984's and some 985's.
- (c) Steel standard arm with incorporated the heavy duty suspension which incorporates a bearing in the intermediate. This type uses the impact shear plates which are 1/2" x 3/4" x 1/2" in size.



With type (c), note that the plate is extended plate is firmly fitted to the stern plate.






Fit the mounting sleeve to the rubber bush on the steady arm as shown in the diagram, with the stamping fingers toward the rear, and the sleeve end flat against the rear of the through bolt. Torque tighten the through bolt to 75 Hr (25 lbf ft). Fit the arm into the bracket, and locate the sleeve with its four bolts but do not tighten.

Plan section of sleeve & bush




With view (11), check that the aluminum extension plate is securely fitted to the transmission. Check that the steady arm pivot plate sleeve are correct in fit. Remove the pair of cheek plate assemblies and secure to the steady arm with the four button head screw (apply thread locking compound and increased R151 torque (increasing to 45 Hr (15 lbf ft)) to not disturb the pivot plate into which they were set during manufacture. Assemble the mounting bracket to the pivot plate (screw removed fixings to the ends) and torque tighten the topmost bolt to 75 Hr (25 lbf ft) with the arm and bracket positioned as shown in the diagram. Fit the arm assembly to the chassis, and locate the bracket with its four bolts, but do not tighten.






Assembly of this unit is as for (1), except that the transmission housing extension plate is not fitted.

11. With the engine supported in position, fit the steady arm to the engine, the motor and engine buffer and linkage.




12. Fit the 100 mm buffer gear mounting assembly with the rubber buffer gear fitted so it fits to the rear of the collapsible spacer behind the rear of the 100 mm gear, ensuring that the end of the spacer is engaged in the mounting for the side of gear (refer to 11.1.2.1).






Non-USA type
14 engine mounting



USA type
14 engine
mounting






1. 5) The left hand mounting bracket and shock absorber bracket in the front suspension frame. These two upper roller pads are attached to the mounting bracket supporting the through axle and chassis bracket. 20 LBA parts. 6) The 2 shock absorbers around the axle and check the torque on the roller pads and all the roller pad brackets holes. If these fixtures are tightened, adjust the clearance by adjusting the roller pad bush. After adjustment, record the procedure to the extent provided by the user manual to check the status. If necessary, an fit spacer shim plates may be between the roller bracket and transmission frame to space the roller pad forward. 7) 1.1.1. 1.2. 1.3. 1.4. 1.5. 1.6. 1.7. 1.8. 1.9. 2.0. 2.1. 2.2. 2.3. 2.4. 2.5. 2.6. 2.7. 2.8. 2.9. 3.0. 3.1. 3.2. 3.3. 3.4. 3.5. 3.6. 3.7. 3.8. 3.9. 4.0. 4.1. 4.2. 4.3. 4.4. 4.5. 4.6. 4.7. 4.8. 4.9. 5.0. 5.1. 5.2. 5.3. 5.4. 5.5. 5.6. 5.7. 5.8. 5.9. 6.0. 6.1. 6.2. 6.3. 6.4. 6.5. 6.6. 6.7. 6.8. 6.9. 7.0. 7.1. 7.2. 7.3. 7.4. 7.5. 7.6. 7.7. 7.8. 7.9. 8.0. 8.1. 8.2. 8.3. 8.4. 8.5. 8.6. 8.7. 8.8. 8.9. 9.0. 9.1. 9.2. 9.3. 9.4. 9.5. 9.6. 9.7. 9.8. 9.9. 10.0. 10.1. 10.2. 10.3. 10.4. 10.5. 10.6. 10.7. 10.8. 10.9. 11.0. 11.1. 11.2. 11.3. 11.4. 11.5. 11.6. 11.7. 11.8. 11.9. 12.0. 12.1. 12.2. 12.3. 12.4. 12.5. 12.6. 12.7. 12.8. 12.9. 13.0. 13.1. 13.2. 13.3. 13.4. 13.5. 13.6. 13.7. 13.8. 13.9. 14.0. 14.1. 14.2. 14.3. 14.4. 14.5. 14.6. 14.7. 14.8. 14.9. 15.0. 15.1. 15.2. 15.3. 15.4. 15.5. 15.6. 15.7. 15.8. 15.9. 16.0. 16.1. 16.2. 16.3. 16.4. 16.5. 16.6. 16.7. 16.8. 16.9. 17.0. 17.1. 17.2. 17.3. 17.4. 17.5. 17.6. 17.7. 17.8. 17.9. 18.0. 18.1. 18.2. 18.3. 18.4. 18.5. 18.6. 18.7. 18.8. 18.9. 19.0. 19.1. 19.2. 19.3. 19.4. 19.5. 19.6. 19.7. 19.8. 19.9. 20.0. 20.1. 20.2. 20.3. 20.4. 20.5. 20.6. 20.7. 20.8. 20.9. 21.0. 21.1. 21.2. 21.3. 21.4. 21.5. 21.6. 21.7. 21.8. 21.9. 22.0. 22.1. 22.2. 22.3. 22.4. 22.5. 22.6. 22.7. 22.8. 22.9. 23.0. 23.1. 23.2. 23.3. 23.4. 23.5. 23.6. 23.7. 23.8. 23.9. 24.0. 24.1. 24.2. 24.3. 24.4. 24.5. 24.6. 24.7. 24.8. 24.9. 25.0. 25.1. 25.2. 25.3. 25.4. 25.5. 25.6. 25.7. 25.8. 25.9. 26.0. 26.1. 26.2. 26.3. 26.4. 26.5. 26.6. 26.7. 26.8. 26.9. 27.0. 27.1. 27.2. 27.3. 27.4. 27.5. 27.6. 27.7. 27.8. 27.9. 28.0. 28.1. 28.2. 28.3. 28.4. 28.5. 28.6. 28.7. 28.8. 28.9. 29.0. 29.1. 29.2. 29.3. 29.4. 29.5. 29.6. 29.7. 29.8. 29.9. 30.0. 30.1. 30.2. 30.3. 30.4. 30.5. 30.6. 30.7. 30.8. 30.9. 31.0. 31.1. 31.2. 31.3. 31.4. 31.5. 31.6. 31.7. 31.8. 31.9. 32.0. 32.1. 32.2. 32.3. 32.4. 32.5. 32.6. 32.7. 32.8. 32.9. 33.0. 33.1. 33.2. 33.3. 33.4. 33.5. 33.6. 33.7. 33.8. 33.9. 34.0. 34.1. 34.2. 34.3. 34.4. 34.5. 34.6. 34.7. 34.8. 34.9. 35.0. 35.1. 35.2. 35.3. 35.4. 35.5. 35.6. 35.7. 35.8. 35.9. 36.0. 36.1. 36.2. 36.3. 36.4. 36.5. 36.6. 36.7. 36.8. 36.9. 37.0. 37.1. 37.2. 37.3. 37.4. 37.5. 37.6. 37.7. 37.8. 37.9. 38.0. 38.1. 38.2. 38.3. 38.4. 38.5. 38.6. 38.7. 38.8. 38.9. 39.0. 39.1. 39.2. 39.3. 39.4. 39.5. 39.6. 39.7. 39.8. 39.9. 40.0. 40.1. 40.2. 40.3. 40.4. 40.5. 40.6. 40.7. 40.8. 40.9. 41.0. 41.1. 41.2. 41.3. 41.4. 41.5. 41.6. 41.7. 41.8. 41.9. 42.0. 42.1. 42.2. 42.3. 42.4. 42.5. 42.6. 42.7. 42.8. 42.9. 43.0. 43.1. 43.2. 43.3. 43.4. 43.5. 43.6. 43.7. 43.8. 43.9. 44.0. 44.1. 44.2. 44.3. 44.4. 44.5. 44.6. 44.7. 44.8. 44.9. 45.0. 45.1. 45.2. 45.3. 45.4. 45.5. 45.6. 45.7. 45.8. 45.9. 46.0. 46.1. 46.2. 46.3. 46.4. 46.5. 46.6. 46.7. 46.8. 46.9. 47.0. 47.1. 47.2. 47.3. 47.4. 47.5. 47.6. 47.7. 47.8. 47.9. 48.0. 48.1. 48.2. 48.3. 48.4. 48.5. 48.6. 48.7. 48.8. 48.9. 49.0. 49.1. 49.2. 49.3. 49.4. 49.5. 49.6. 49.7. 49.8. 49.9. 50.0. 50.1. 50.2. 50.3. 50.4. 50.5. 50.6. 50.7. 50.8. 50.9. 51.0. 51.1. 51.2. 51.3. 51.4. 51.5. 51.6. 51.7. 51.8. 51.9. 52.0. 52.1. 52.2. 52.3. 52.4. 52.5. 52.6. 52.7. 52.8. 52.9. 53.0. 53.1. 53.2. 53.3. 53.4. 53.5. 53.6. 53.7. 53.8. 53.9. 54.0. 54.1. 54.2. 54.3. 54.4. 54.5. 54.6. 54.7. 54.8. 54.9. 55.0. 55.1. 55.2. 55.3. 55.4. 55.5. 55.6. 55.7. 55.8. 55.9. 56.0. 56.1. 56.2. 56.3. 56.4. 56.5. 56.6. 56.7. 56.8. 56.9. 57.0. 57.1. 57.2. 57.3. 57.4. 57.5. 57.6. 57.7. 57.8. 57.9. 58.0. 58.1. 58.2. 58.3. 58.4. 58.5. 58.6. 58.7. 58.8. 58.9. 59.0. 59.1. 59.2. 59.3. 59.4. 59.5. 59.6. 59.7. 59.8. 59.9. 60.0. 60.1. 60.2. 60.3. 60.4. 60.5. 60.6. 60.7. 60.8. 60.9. 61.0. 61.1. 61.2. 61.3. 61.4. 61.5. 61.6. 61.7. 61.8. 61.9. 62.0. 62.1. 62.2. 62.3. 62.4. 62.5. 62.6. 62.7. 62.8. 62.9. 63.0. 63.1. 63.2. 63.3. 63.4. 63.5. 63.6. 63.7. 63.8. 63.9. 64.0. 64.1. 64.2. 64.3. 64.4. 64.5. 64.6. 64.7. 64.8. 64.9. 65.0. 65.1. 65.2. 65.3. 65.4. 65.5. 65.6. 65.7. 65.8. 65.9. 66.0. 66.1. 66.2. 66.3. 66.4. 66.5. 66.6. 66.7. 66.8. 66.9. 67.0. 67.1. 67.2. 67.3. 67.4. 67.5. 67.6. 67.7. 67.8. 67.9. 68.0. 68.1. 68.2. 68.3. 68.4. 68.5. 68.6. 68.7. 68.8. 68.9. 69.0. 69.1. 69.2. 69.3. 69.4. 69.5. 69.6. 69.7. 69.8. 69.9. 70.0. 70.1. 70.2. 70.3. 70.4. 70.5. 70.6. 70.7. 70.8. 70.9. 71.0. 71.1. 71.2. 71.3. 71.4. 71.5. 71.6. 71.7. 71.8. 71.9. 72.0. 72.1. 72.2. 72.3. 72.4. 72.5. 72.6. 72.7. 72.8. 72.9. 73.0. 73.1. 73.2. 73.3. 73.4. 73.5. 73.6. 73.7. 73.8. 73.9. 74.0. 74.1. 74.2. 74.3. 74.4. 74.5. 74.6. 74.7. 74.8. 74.9. 75.0. 75.1. 75.2. 75.3. 75.4. 75.5. 75.6. 75.7. 75.8. 75.9. 76.0. 76.1. 76.2. 76.3. 76.4. 76.5. 76.6. 76.7. 76.8. 76.9. 77.0. 77.1. 77.2. 77.3. 77.4. 77.5. 77.6. 77.7. 77.8. 77.9. 78.0. 78.1. 78.2. 78.3. 78.4. 78.5. 78.6. 78.7. 78.8. 78.9. 79.0. 79.1. 79.2. 79.3. 79.4. 79.5. 79.6. 79.7. 79.8. 79.9. 80.0. 80.1. 80.2. 80.3. 80.4. 80.5. 80.6. 80.7. 80.8. 80.9. 81.0. 81.1. 81.2. 81.3. 81.4. 81.5. 81.6. 81.7. 81.8. 81.9. 82.0. 82.1. 82.2. 82.3. 82.4. 82.5. 82.6. 82.7. 82.8. 82.9. 83.0. 83.1. 83.2. 83.3. 83.4. 83.5. 83.6. 83.7. 83.8. 83.9. 84.0. 84.1. 84.2. 84.3. 84.4. 84.5. 84.6. 84.7. 84.8. 84.9. 85.0. 85.1. 85.2. 85.3. 85.4. 85.5. 85.6. 85.7. 85.8. 85.9. 86.0. 86.1. 86.2. 86.3. 86.4. 86.5. 86.6. 86.7. 86.8. 86.9. 87.0. 87.1. 87.2. 87.3. 87.4. 87.5. 87.6. 87.7. 87.8. 87.9. 88.0. 88.1. 88.2. 88.3. 88.4. 88.5. 88.6. 88.7. 88.8. 88.9. 89.0. 89.1. 89.2. 89.3. 89.4. 89.5. 89.6. 89.7. 89.8. 89.9. 90.0. 90.1. 90.2. 90.3. 90.4. 90.5. 90.6. 90.7. 90.8. 90.9. 91.0. 91.1. 91.2. 91.3. 91.4. 91.5. 91.6. 91.7. 91.8. 91.9. 92.0. 92.1. 92.2. 92.3. 92.4. 92.5. 92.6. 92.7. 92.8. 92.9. 93.0. 93.1. 93.2. 93.3. 93.4. 93.5. 93.6. 93.7. 93.8. 93.9. 94.0. 94.1. 94.2. 94.3. 94.4. 94.5. 94.6. 94.7. 94.8. 94.9. 95.0. 95.1. 95.2. 95.3. 95.4. 95.5. 95.6. 95.7. 95.8. 95.9. 96.0. 96.1. 96.2. 96.3. 96.4. 96.5. 96.6. 96.7. 96.8. 96.9. 97.0. 97.1. 97.2. 97.3. 97.4. 97.5. 97.6. 97.7. 97.8. 97.9. 98.0. 98.1. 98.2. 98.3. 98.4. 98.5. 98.6. 98.7. 98.8. 98.9. 99.0. 99.1. 99.2. 99.3. 99.4. 99.5. 99.6. 99.7. 99.8. 99.9. 100.0.


1. 6) After the four bolts secure the rear axle to the chassis, set the torque to 100-120 ft-lb.

1. 7) The shock and torque dampers

USA Type Torque Damper



Non-USA Type Torque Damper






Mounting Bush Replacement

The above engine mounting bushes are of similar physical dimensions, and utilize the construction of the rubber bush. Each bush may be removed from its retaining bracket using a press. Before pressing a new bush into position, take care to ensure that the correct bush is selected, and that it is correctly orientated.

1H Engine Mounting

3H Engine Mounting



DO-100 SPECIAL INDEX

<u>Description</u>	<u>Part Number</u>
Engine Assembly Prep. Used to check turbocharger and timing procedure.	10002001
Timing Plug Installation and Oil Seal Revised instructions and torque for installation of new pistons.	10002004
Installation of Turbocharger Revised instructions for fitting of turbo chargers.	10002010
Timing Belt Assembly Revised removal of timing belt and reassembly instructions.	10002016
Oil Seal Kit Used to remove and refit inlet and exhaust valve guides.	10002027
Engine Valve Stem and Connections Used for replacement of valve stems and valve stem seal valve guides.	10002030
Valve Guides, Snap Rings Used with a tapered roller bearing between top and plug.	10002035
Timing Belts Used removal of engine oil filter.	10002036
Timing, Piston and Oil Seal Engine Oil Seal of same tool and snap bearing.	10002041
Oil Seal and Piston Seal Used only with 3.0 liter diesel engine plus standard pistons.	10002042
Timing, Piston and Oil Seal Revised removal of engine oil seal to meet new design.	10002050
Attachment of New Oil Gauge Operating Instructions, Alternative Methods and Removal of Oil Gauge Plungers.	10002054

TRANSMISSIONSECTION KEY FILE

	<u>Schedule</u>	<u>Page</u>
Gear Lubrication	FF.1	3
General Drivetrain	FF.2	3
Clutch/Shift	FF.3	4
Clutch/Shift Cable Adjustment	FF.4	5
Overhaul of Clutch & Gearbox Mechanism Replacement	FF.5	6
Transmission Assembly (Rear)	FF.6	6
Transmission Assembly Replacement	FF.7	12
Major Component Diagnosis	FF.8	13
Major Component Assembly	FF.9	15
Input & Output Shaft Disassembly/Assembly	FF.10	25
Input Shaft Component Assembly	FF.11	31
Output Shaft Component Assembly	FF.12	34
Driveshafts	FF.13	35
Build Drivetrain	FF.14	39
Special Tools	FF.15	40




TABLE 1. POWER DATA

Output Length			148.5 kg
Weight			16.5 kg
Altitude of 1500 ft.			Revs. 1.875 (17.5) fully synchro in
Altitude per minute			0.0000000
Speed			1.0000000
Speed ratio - 1st			4.1250000 (17.5)
2nd			1.9166667 (44.7)
3rd			1.1333333 (44.7)
4th			1.0000000 (44.7)
5th			1.0000000 (44.7)
Reverse			0.0000000 (0.0)
Final drive ratio - S.A.			4.1100000 (17.5)
1st gear			1.8111111 (44.7)
Speed ratio gear 2nd			0.8200000 (26.7)
Identification on top cover	abc	R/A	L&R
		1/2/3/4	L&R
Shift pattern			1 3 4
			2 4 R

TABLE 2. GENERAL DESCRIPTION

The transmission assembly is of "ford" type, mounted in the left hand end of the engine unit, and comprises of the shaft housing, five speed gears, final drive gears, and differential.

Gears

The gearbox is a two shaft all indirect five speed manual drive gearbox. The shaft with the primary shaft which is connected with the engine crankshaft, and carries the clutch, drives the on the right hand end. A secondary shaft lying parallel and behind the primary shaft, drives the drive pin an integral final drive pin on its right end and. This shaft meshes with a pinion mounted on a gear, the differential, a planetary gear distribution drive in the front, which has two 1st gears appropriate for 4 or 5th gear, backshaft in the right hand side, except for two decrease to be of similar length to reduce the life of the gear drive.


Reverse is fitted to all forward speeds, with the 1st and synchronous mounted on the secondary shaft, the 5th is synchronous on the primary shaft, and the 3rd synchronous on the secondary. 1st gear end of the secondary shaft. Reverse gear is achieved by sliding an inter gear into engagement with reverse drive gear integral with the primary shaft, and the gear teeth received on the outside of the 1st and synchronous assembly. The primary shaft, secondary shaft and differential carrier are all supported on pairs of tapered roller bearings adjusted by shims. The speed drive gear is mounted on the differential carrier.

Shaftchange Mechanism

Four selector shafts lie across the top of the gearbox, and are operated by a range shaft with a range actuating finger. A series of interlock plungers between the shafts allow only one selected shaft to be moved from the neutral position at any one time. The range shaft is housed in a selector housing on top



of the transmission housing and is fitted with a cover so when the shaft may be removed it stays away and the output shaft is left to move the shaft axially (allowing for sprockets to adjust).




When working, the selector housing is held in the 1st position by two control cables. When working, the selector housing is held in the 1st gear plane. The lever will remain in 1st gear until the selector housing is moved to the left to engage 2nd gear, or right to 3rd gear. The selector housing is moved to the right to engage 5th or reverse gear. A reverse indicator is provided on the selector housing to indicate selection of reverse gear. The selector housing is held in the 1st gear position by a spring which is attached to the selector housing and the housing.

FIG. 2 - OPERATION

It is an easy operation to use if the dominant operator. Most of the time, the selector housing is in the 1st gear position.

At specified service intervals, the transmission should be thoroughly checked for any signs of oil leakage, worn and by not working in reverse around a gear. The selector housing is the next level checked.

To check the oil level, it is best to use a dipstick. The spindle driven gear assembly must be removed, and the oil level measured on the plate in bushing. When the oil level is low, only with the engine off, and the transmission oil level enough to enable the oil to be reached by hand. The spindle driven gear is removed as the only of the differential housing and is accessible from above. Withdraw the spindle driven gear assembly with the cable attached, after which the spindle driven gear is returned to the housing. Add the recommended amount of oil to the level of the oil between the high and low marks on the needle and cover. With the selector housing in 1st gear, the selector housing is in the 1st gear position.



Drain the transmission oil immediately after a run, when the oil is warm and the impurities are held in suspension. Remove the drain plug from the left-hand side of the input drive housing, beneath the output shaft.

Allow the oil to drain thoroughly before replacing the plug (with a new washer if necessary), and tightening to 15 Nm (109 in.lb.).

Oil capacity:

1.9 litres (1.1 imp.pt; 1.3 U.S.pt.)



12.4 - GEARCHANGE CABLE ADJUSTMENT


The gearchange mechanism uses two control cables to transmit the motion of the gearchange lever to the gearbox input shaft. One cable connects directly to the bottom of the gearshift lever and transmits forward motion to the gearbox input shaft lever. A second, 'reverse' cable, is connected to a bellcrank lever at the base of the shift lever assembly, and transmits backward movement of the lever to another bellcrank lever at the selector housing. This bellcrank engages with a collar on the input shaft, and moves the shaft axially.

Adjustment

Each of the cables is fitted with a quick adjustment locking sleeve at the gearbox end. By turning the outer sleeve by a quarter turn, the cable outer can be allowed to slide freely within the sleeve, or be locked to it. To adjust the two gearchange cables, proceed as follows:




1. With the gearchange cables fitted and connected, unlock the adjuster sleeves on each cable at the gearbox selector bracket, by turning the outer sleeve against the direction of the arrow (top of the sleeve to the rear).




1. Position the gear lever (using 2° forward, and 10° towards the driver's side and hold in this position whilst the adjuster sleeves are locked by turning in the direction of the arrow.

4. Check the selection of all gears.



2. Set the transmission to third gear by moving the cross shaft lever (toping biased to the 1st/2nd gear plate) to the right.



PP.5 - GEARCHANGE CABLES & GEARLEVER MECHANISM REPAIRMENT

The gearlever mechanism must be withdrawn into the car, in order to provide access to the cable rear adjuster and permit cable replacement.

To Remove

1. Gearchange Cables: Pull off the spring clips securing the two inner cables to the gearbox levers, and the spring clips securing the adjuster sleeves to the mounting bracket. Release the cables from the gearbox, taking care to note the positions of the washers for the inner cable ends.

2. Gear Lever Knob: To remove the knob, push down the top of the guitar for its location groove in the underside of the knob, and slacken the grub screw exposed. Turn the knob counter-clockwise to unscrew from the gear lever.

3. Console Control Console 5 Trim Gaiter.

- Remove the filler panel from between the rear of the centre tunnel console and the side wall, by releasing the single retaining trim.

- Pull out and disconnect the window control switch, to the rear of the gear lever.

- Pull out and disconnect the two window switches, each side of the parking brake lever, and release the two console front fixing screws via the switch apertures.

- Pull out the oddments tray from the rear of the tunnel top, and release the two console rear fixings via the tray aperture. Pull the console to the rear to



Mylon bush
pressed into
cable end eye

Emergency
cable

Spring clip

Washer

Rivet pin
fixed to
bollicrank

Abolment
bracket


Rivet pin
fixed to
cross shaft
lever

Mylon face
towards lever

Fore/aft
cable

Outer
cable
clip

Washer



Bolton
head
screw

Lever
gaiter

Sealing
cover

Cross lever
base
unit

Rubber
bush

Spacer
sleeve

Lever/lever
mechanism
mounting
bracket

Outer cable
spring clip

Bolt &
socket
joint



3. Disconnect the throttle from the main linkage, and then tilt the console over the parking brake lever.

• Remove the gear lever gaiter over the lever.

4. Lower Gaiter & Gearchange Mechanism: Remove the four button head screws securing the lower gaiter assembly, and gearchange mechanism to the chassis. Pull the lower gaiter assembly up off the gearlever, and withdraw the lower assembly from the chassis aperture, complete with the cables. Do not displace the alloy spacer sleeves from each of the gearlever assembly rubber mountings.

5. Gearchange Cables: Release the crosscut cable from the gearlever bellcrank by removing the spring clip and washer. Disconnect the fore/aft cable by removing the retaining nut. Pull off the spring clip securing each of the other cables to the gearlever bracket.

6. Gearlever Assembly: Further dismantle the gearlever mechanism if necessary.

To Re-raise

1. Gearlever Assembly: If necessary, re-assemble the gearlever assembly, and refit to the gearchange bracket, torque tightening the 1x6 screws to 25 Nm (18 lbf ft).

2. Fore/Aft Gearchange Cable: The fore/aft cable may be identified by the rubber bushed eye at the front end, and the ball joint threaded spigot at the rear end. Fit the rear end of the cable through the left hand mounting hole in the gearchange mechanism bracket, ensuring that the flat on the outer cable spigot is properly located in the 'D' hole, and secure with an 'E' clip (4300F 6291P) with the concave side towards the mounting bracket. Discard any spring wire type clip fitted previously. Fit the inner cable threaded spigot to the bottom of the gear lever and secure with the nylon nut.

3. Crosscut Cable: The crosscut cable has a steel eye at each end. Fit the rear end of the cable (and without the quick adjuster sleeve) through the right hand mounting hole in the gearchange mechanism bracket, ensuring that the flat on the outer cable spigot is properly located in the 'D' hole, and secure with an 'E' clip (4300F 6291P) with the concave side towards the mounting bracket. Discard any spring wire type clip fitted previously. Fit the inner cable eye onto the bellcrank lever spigot (using 250 grease) with the nylon face of the bush against the lever, and retain with the washer and spring clip.


4. Gearchange Mechanism: Feed the cables into the chassis aperture, and put into the engine bay whilst fitting the gearchange mechanism into position. Check that a rubber bush is fitted in each of the bracket mounting holes, with the larger portion of the bush on the underside of the bracket. Fit an aluminium spacer into each bush from the underside, and position the four holes over the 4x16mm on the chassis. Fit the lower gaiter assembly (inverted plastic base, alloy gaiter and steel top plate rivetted together) over the gearlever, and into position over the four fixing holes. Fit the four bottom head fixing screws, and tighten to 22.5 Nm (17 lbf ft). Ensure that the centre of the rubber grommet is pushed down the shaft of the gear lever, rather than pointing upwards.

5. Trimmed Gaiter & Tunnel Coverlet: Fit the trimmed gaiter over the gear lever, and locate the wired beam of the gaiter into its location in the chassis moulding. Refit the tunnel moulding in the reverse order to disassembly.

6. Gear Lever Knob: Screw the knob onto the lever, and secure by tightening the



Section through gearchange mounting



grab screw. Pull the top of the trim garter upwards so locate in the knob groove.

7. Gearbox End: Fit the outer cable (envelope nylon) through the top hole in the abutment bracket, and fit the inner cable into the bellcrank lever apogee with the nylon face against the lever. Retain with the washer and spring clip. Retain the outer adjuster sleeve (with 'E' fully engaged) to the abutment bracket with an 'E' clip (M100F629-F) with the concave side towards the abutment bracket. Insert any spring wire type clip fitted previously.

Fit the fore/aft cable in a similar manner into the lower hole, but note that a washer is fitted on each side of the rubber bushed eye of the inner cable when fitting to the cross shaft bellcrank. Apply PMS grease to all pivot pins.

9. Adjustment: Adjust the cables as detailed in section FF.4.

FF.5 - TRANSMISSION ASSEMBLY REMOVAL

The transmission assembly may be removed from beneath the vehicle, after removing the underframe.

1. Preparatory: Drain the transmission oil. Remove both front road wheels and both front CVR axles.

2. Engine Bay: Remove or disconnect the following items.

- Release the air filter box mounting bracket from the LH downpipe, disconnect the brass and boost solenoid valve wires, and remove the air filter assembly
- Disconnect the speedo cable and reverse switch wires
- Unlock the clutch cable from the lever arm, and release the outer cable from



its adjustment bracket.

- Release both rear change cables from their selector levers, pull off the spring clips retaining the outer cable quick adjusters to the transmission adjacent plate, and remove the cables from the transmission.

3. Underframe: Remove the underframe by releasing:

- three bolts securing the front end of the underframe to the radiator support frame;

- two bolts each side securing the lower bushes of the suspension rails;

- the single bolt at each side securing the rear of the underframe to the chassis front crossmember;

- two bolts each side securing the tubular stays to the underframe;

- also remove the left hand stay from the chassis.

4. Driveshafts: Mark the position of the member adjustment cones on both P4 and its lower suspension top washers, before releasing the two bolts securing the two washers to the top ball joint. Push the drive shafts out of the final nut, and use a slide hammer with a marked end, or a lever between the body of each shaft and the transmission to 'shock' the driveshaft over the retaining circlip, and off output shaft. Leave the driveshaft suspended in the Berge yoke.

5. Jackshaft: Remove the two bolts securing the jackshaft bearing bracket to the engine, and withdraw the shaft (note - no retaining circlip is used at this point).

6. Exhaust Downpipe: Disconnect the exhaust downpipe, and release the anti-roll bar from the drop links to allow the exhaust to drop further.

7. Oil Engine Mounting: Use a jack or dolly to support the weight of the engine/transmission assembly before removing the left hand engine (transmission) mounting from the chassis. Release the bracket from the transmission housing.

8. Rear Engine Mounting: Release the rear engine mounting arm from the transmission, and remove the aluminium mounting plate.

9. Flywheel Cover: Remove the flywheel lower cover from the engine and transmission.

10. Transmission Assembly: Lower the transmission end of the engine, and support the transmission assembly manually before removing the four bolts connecting the transmission to the engine, and withdraw the unit from the car, tilting the engine further if necessary, but taking care not to strain any hoses or harnessed.

1F.2) - TRANSMISSION ASSEMBLY DEPLACEMENT

Reverse the removal procedure, noting the following points:

- Before fitting the jackshaft, fit a new square section snap ring 8100F6095H into the outboard end groove. Take care not to damage the output shaft oil seal when the jackshaft is inserted into the transmission.

- Before fitting the oil driveshaft into the transmission, fit a new round section snap ring 8100R8001R onto the spigot of the inboard P.V. joint.

After pressing both driveshafts into position, check that the circlip is



fully locked in its groove by pulling on the end of the inboard lock.


- Ensure the timing adjustment assemblies in the top washers are positioned as noted prior to removal.
- To aid in ease of fit, the brake hose into the top washer bracket, and remove with the timing pins.
- Reoil the transmission using only Shell LOTS 610 (140060000)

Remove Figures

	90	101 to
Clutch Bearing to Cylinder Block	47	56
Align Mounting Plate to Crankcase - M10	48	57
- M12	51	55
Engine Mounting Arm to Alloy Plate - M10	44	53
Engine Mounting Arm to Block - M12	47	55
Jackshaft to Idlers	51	59
Clamp: Yoke to Lower Link	76 - 82	95 - 99
Cup: Kickdown to Gear Shift	22 - 31	16 - 28
Rail: Top Mounting to Crankcase	75 - 81	95 - 99
Swashplate Bush to Rail	22 - 31	16 - 17
Eye: Front & Rear Mountings	75 - 77	95 - 97
Underframe to Blay	11	51
Eye to Crankcase	11	51
Underframe to Radiator Support Frame	12	71


FIG. 11. RELEASE CLUTCH AND DISASSEMBLE


1. Clutch Release Bearing: Release the spring clip securing the clutch release bearing to the release fork and withdraw the release bearing.



2. Clutch Release Fork & Shaft: If necessary, remove the clutch release fork and shaft. Remove the retaining arm, pull off the dust cap, and prise out the clutch shaft seal. Use the special tool to knock the shaft bush using the shaft and into the bearing. Remove the shaft spring and withdraw the shaft from within the housing.

Clutch Shaft Bush Extractor/Replacer Tool
00070050








3. For ease and safety of working, adjust the tension of assembly to a secure hand fitting approx. 3/16" (1.5mm).

Timing Flange Part No. 6030099
 Timing Case Part No. 6030100



4. Fuel Filter: Remove the 3 screws securing the end cover, and pull off the cover and gasket.


5. Release Housing Assembly: Remove the 4 screws securing the receiver housing, and remove the complete assembly and gasket.



6. Reverse Light Switch: Disconnect and remove the reverse light switch and adjust for proper




7. Neutral Pin, Fork & Springs: Remove the three pins, and withdraw the neutral springs and balls for the forward speed selection shaft.





8. Loosen the nut. Remove the pin and attach the reverse roller on shaft (detent or ratchet teeth).



9. Use force (such as the screw punch) to drive out the double end pin, leaving the shaft in the fork to the shaft.

10. Use force (such as the screw punch) to drive out the double end pin. Support the end gear by holding the shaft with a screwdriver, and then remove the gear by sliding the screwdriver into a groove in the shaft. Remove the gear and hold shaft in the fork, remove the fork and hold shaft in the fork and remove the shaft from the fork.



11. Use force (such as the screw punch) to drive the output shaft into the synchronous assembly (replace with pin, roller, and drive end output pin).

12. Use force (such as the screw punch) to drive the output shaft into the high speed drive gear, with the roller in the fork.

13. Use force (such as the screw punch) to drive the high speed drive gear from the input shaft. Use the roller in the fork in the bearing (replace pin) in the roller fork.



Estimated: 30-40 min.

14. Use Step 10's method. Remove the roller and replace with roller. Use the roller in the fork in the roller fork.





14. Gearbox to Case Remove the 13 bolts securing the gearbox housing to the cast-iron differential housing, and with the unit raised vertically, lift out the gearbox (20610).

15. Reverse 14th Gear Shaft Withdraw the reverse idler gear with 12 shaft, taking care not to displace the shaft location pin.

16. Selector Shaft & Fork Assembly With a prybar, force the 5th selector shaft down into the 5th gear position, and remove the setscrew from the 5th shaft below the speed-measuring dial. Lift the selector shaft clear of the interlock plungers. Do not lift shaft out of the operating block or the retaining pin above the block (Fig. 108), to allow the 5th and reverse selector shaft assemblies to be withdrawn together. Take care not to displace the interlock pin from within the 5th shaft end.



17. Selector Shaft & Fork, 3rd/4th Use a pin punch to remove the unique roll pin securing the (dotted) selector fork to the 3rd/4th selector shaft. Forward the roll pin. Slide the shaft upwards and remove the shaft and fork. Take care not to displace the interlock pin within the selector shaft.



18. Selector Shaft & Fork, 1st/2nd Use a pin punch to remove the roll pin securing the (dotted) selector fork to the 1st/2nd selector shaft. Turn the roll pin. Slide the shaft upwards and remove the shaft and fork.


19. Input & Output Shaft Assemblies Withdraw the input and output shaft assemblies.

20. Differential Assembly Withdraw the complete differential assembly.

21. Interlock Pins Remove the screws securing the interlock pin retaining plate/reverse hand proof plate, and remove the plate. Remove the three interlock pins from their grooves in the clutch housing face.

22. Case Back, Gearbox Face, Spool Nut or Withdraw the input shaft and differential bearing outer races from the gearbox case. Do not displace the thin washers from left and the bearing races. To extract the differential bearing outer race, use special tool.

Spool Race Remover T000T096
 Puller Bridge T000T097
 Differential Slide Hammer Puller T000T0481





1. Output shaft seal: Break out the output shaft seal from the gearbox case.


2. Input Output Shaft bearing seal: Remove the bearing seal from the input/output shaft. Grind the seal and output shaft before bearing comes from the input/output shaft.

Input Seal Kit: 70000099
 Output Seal Kit: 70000098
 Input/output shaft bearing seal kit: 02000040

3. Clean the oil residue from second and output shaft ends.

4. 2.11. Bearing outer race: Use the ball of the ball to clean the outer race using the bearing puller and slide hammer.

Input Seal Kit: 70000099
 Output Seal Kit: 70000098



5. Oil Seal: Clean/Grind. Check break out the seal and shaft seal, and press it on the input shaft seal.

6. Gearbox Output Plate: If necessary, remove the 2 plates covering the bearing retaining plate. Use a 1/2" Torx bit of 45, and remove the plate. Grind the surface.

2.1.2. SHAFT COMPONENT ASSEMBLY

General

Before assembly

2.1.2.1.1. Inspect thoroughly the shaft seals. Remove old oil lubricant, and clean thoroughly. Check for foreign material and removed from the surfaces of shaft seal. Grind and clean shaft seal. Blow through each oil seal part and check it with the bearing puller to remove any obstructions or cleaning material inside.

Inspect all gear teeth with the magnifying glass for wear or fatigue and check all gear springs for proper mesh. Check or change where major ticks or damaged. Check all oil seals. Inspect all thrust washers for evidence of excessive wear. Inspect for damage. Replace any part exhibiting excessive wear or damage.

Inspect the two cone rollers for cracks, porosity, dimensional tolerances, tapered threads or distorted lines. Replace any part that exhibits these conditions.

Inspect the condition of all teeth, rollers, ball and thrust bearings. Make sure they thoroughly clean, clean, oil and lubricated and blow dry. Notes to set upon the assembly of the oil seal. Seal may be finished, turn freely by hand; lubricate the assembly with a light oil and check for seal, set by slowly turn on by hand.

Warnings

The input shaft, output shaft and differential assemblies are not supported



by the taper roller bearings, with the endfloat/grease controlled by a shaft washer fitted behind the bearing outer race in the gearbox casing. Each time the transmission is disassembled, the shimming should be checked, and if any components are replaced it is always best to shimming will be required.

In order to aid shift selection, a special tool set T00001005 is available, and should always be used because the special gauges apply a spring loading to the shaft bearings, in order to ensure they are fully seated and correctly aligned when the slide measurements are taken. Note that when using the device, the outer races must be removed from the gearbox casing (not from the clutch/shaft housing) and the output shaft and seal must not be lifted in the gearbox housing. The procedure for using the gauges is detailed in the following assembly sequence:

1. Input Shaft Oil Seal: Insert inner OIL seal into the output housing, with the spring side of the seal toward the gearbox.

Installer T00001004




2. Outer Race, Input Shaft/Clutch Housing: Fit the input shaft outer race into the clutch housing using the installer with handle, and a hammer.

Installer T00001003
Handle T00001001



3. Outer Race, Output Shaft/Clutch Housing: Fit the oil nozzle into the bearing recess before fitting the output shaft outer race into the clutch housing using the installer and a hammer.

Installer T00001002





1. Use the parts information on page 11 of this section for the differential cover parts and the differential bearing using the illustrated and specify a lock washer.

Part Name: 260-110-01
Part No: 260-110-01



2. Bearing Retainer (Fig. 2) provides the the bearing retainer plate to the bearing retainer using a hex screw and a lock washer (Fig. 1).

3. Use a light coat of 3M Grease (Fig. 3) for added security, make the grease to the bearing plate.



4. Remove the differential housing (Fig. 4) vertically, and install the lower ball socket assembly differential assembly output shaft assembly into all of the shafts to insure the fit. Insure gear allows and insure whether it is needed to seal the shaft assembly using the fit of the components.

5. Place the bearing plate over a portion of the lower shaft bearings, and place a 200-100-100-01 plate over both shaft ends to seal the system the outer bearing hole.

Part Name: 260-110-01
Part No: 260-110-01



6. Make sure the gaskets are installed:

- 1. Output shaft
- 2. Input shaft
- 3. Differential assembly

Note that all the gaskets fit in the bearing outer plate, and are not prevented from being in by contact between the gasket seal outer hole and the shaft end.

7. Place the lower gasket included in the kit over the shafts. Every other must be in place. Place the gaskets in place without extra torque or output. 200-110-100-01 plate over the shafts, and the seal washer (Fig. 1) is included in the kit for the specified torque (Fig. 1) 200-110-100-01.



8. Tighten the bolts with a torque wrench. Torque and apply a spring washer to all the shaft bearings.

After tightening the bolts, check that part of the 3 gaskets to be done.



10) Put the input shaft and each gear in both directions several times to seat the bearings and gauges.

11) Measure the gap between the shaft and inner or outer drum selecting gauge using available shim sizes, and select the required shim for each of the 3 shells in accordance with the following instructions and shim chart.



The input shaft unit should be one size smaller than the largest shim that will fit in the gap.

The output shaft should use the largest shim that can be placed into the gap and back through without binding.

The differential should use 3 shim three sizes larger than that which will assembly fit in the gap.

Shim Selection Chart

Differential part no.	Axle shaft			Thickness in (in)	Available		
	Input	Output	Diff		Input	Output	Diff
1.00 (10.025)	*			2.76 (10.064)	*		*
1.01 (10.041)	*			2.80 (10.071)	*	*	*
1.08 (10.061)	*		*	2.84 (10.078)	*	*	*
1.10 (10.071)	*		*	2.88 (10.074)	*	*	*
1.12 (10.081)	*	*	*	2.92 (10.090)	*	*	*
1.20 (10.071)	*	*	*	2.96 (10.073)	*	*	*
1.24 (10.071)	*	*	*	2.96 (10.075)	*	*	*
1.28 (10.081)	*	*	*	2.94 (10.084)	*	*	*
1.30 (10.091)	*	*	*	2.99 (10.161)	*	*	*
1.30 (10.091)	*	*	*	2.92 (10.091)	*	*	*
1.40 (10.081)	*	*	*	2.96 (10.091)	*	*	*
1.40 (10.087)	*	*	*	2.99 (10.091)	*	*	*
1.40 (10.086)	*	*	*	2.94 (10.090)	*	*	*
1.52 (10.081)	*	*	*	2.20 (10.090)	*	*	*
1.56 (10.081)	*	*	*	2.17 (10.091)	*	*	*
2.00 (10.081)	*	*	*	2.30 (10.091)	*	*	*
1.04 (10.063)	*	*	*	2.97 (10.090)	*		
1.06 (10.063)	*	*	*	2.94 (10.090)	*		
1.10 (10.070)	*	*	*	2.90 (10.088)	*		

Note that the 3 shims are different diameters, with the input shaft the largest, the differential middle size, and the output shaft the smallest.


12) When each of the three axles has been selected, remove the gearset case, screw spacers and shim select gauges.



to make sure. Following a careful check, cause the selected material to be mounted, and fit the differential gear housing to the shaft with hand, using a hammer.

10. Assemble Input Shaft Gear (FIG. 10)

a. Lubricate the input gear to the shaft with grease and assemble the bearing pin in the pinion hole. Fit the retaining plate with a new O-ring. Press the bearing pin through the input pinion.



11. Verify that the gear teeth that the gear supports are fitted to the shaft shaft housing, and it is secured with the bearing.


12. Experimentally assemble input and differential assembly into shaft housing. Refer to the manual Assembly.

13. Input Shaft Assembly. Refer to the input gear. Fit the input gear to bearing housing and fit the bearing housing into shaft housing. Press the input gear and bearing into the shaft housing. Refer to the manual Assembly.

14. Input Shaft Gear Assembly. Assemble the input and output shaft gears and the input gear into the shaft housing. Refer to the manual Assembly.

15. Input Shaft Gear. Press the bearing pin into the shaft housing with the pinion hole of the input gear.

16. Input Shaft Gear. Refer to the manual Assembly.



17. Input Shaft Gear. Verify that the input gear pin fits the shaft housing hole. Fit the input gear into the shaft housing. Press the input gear into the shaft housing. Refer to the manual Assembly. Note that the correct hole in the shaft housing is identified by the raised marks on the face of the shaft. Refer to the manual Assembly.



15. Install the 4th shaft bearing. Tighten the interlock plate fixing screws to 25 Nm (18.4 lbf.ft.).

16. Select the Shaft & Fork, 1st/2nd: Push the 1st/2nd selector fork into its stabilizing groove on the output shaft, and insert the selector shaft through the fork and into the clutch lift, moving now with the interlock groove aligned for the fork on the shaft, using a new pin, pin 11093.



17. Select the Shaft & Fork, 3rd & Rev.: With the 3rd and reverse shafts assembled with the operating fork and reverse relay spring. Insert the 3rd shaft assembly, make that the interlock plungers (1st identification are shown) are fitted into the end of the 3rd speed shaft. Insert the two shafts and let the reverse shaft drop to the neutral position without engaging the reverse relay spring with the reverse lever. Insert the 3rd speed shaft through the interlock plate.




Put the bearing on the high speed shaft, below the operating block.

18. Prepare the 11th Gear & Shaft: 1) Measure the inside diameter of the gear (A), and the outside diameter of the shaft (B) to determine the running clearance:

A - B = 0.15 mm maximum

Replace both components if outside specification.



19. Fit the 11th gear roller over onto 10 shaft (generally 1.51 inch), and fit the location pin into the shell as shown in the diagram. Fit the shaft into the housing with the location pin in the back position, toward the output shaft.



20. Install the Regret: Check that the oil gutter is secured to the gearbox housing with six screws evenly, and that the regret is fitted into its slot in the input/diff housing.



20. Repeat a Copper Shaft Check. Place the water hose on the stern shaft. If flooding above the hull level, which would indicate probably restrained hull, the lower edge of the hull and stern shaft level off.

21. Measure length of stern shaft and inner water tube to the port face of the propeller hub and transfer 1/8" allowing and apply a lead line. If propeller is in the hull in the middle of the shaft.

Check that the two drive shafts are in the stern shaft housing and are in the hole by the shaft's diameter over the housing, and transfer the measurement to:

page 17 of Section I-F-1-1-1.

22. Take a Water Level Check. Fill the stern shaft with water. Check the hull and transfer. If the hull is not level, it may be a sign of a leak. The water level should be 1/8" below the hull's top edge at the stern.

page 17 of Section I-F-1-1-1.



23. As you return, check the level of the stern shaft's propeller, and replace it to the propeller's level.

page 17 of Section I-F-1-1-1.

24. The stern shaft's propeller is in the hull's hole. If the propeller is not in the hull's hole, it may be a sign of a leak.



25. Check the stern shaft's propeller. Check the propeller's level in the stern shaft's hole, and replace it to the propeller's level.

page 17 of Section I-F-1-1-1.

26. The stern shaft's propeller is in the hull's hole. If the propeller is not in the hull's hole, it may be a sign of a leak.


page 17 of Section I-F-1-1-1.






27. **Output Drive Gear:** Fit the drive gear into the input shaft. Substitute the driver gear needle roller bearing with gears 21 and 111 onto the output shaft. Assemble the output gear over the bearing.

28. **Shaft Synchro Drive Assembly:** Fit the synchro drive into the driver gear. Push on the synchro drive assembly. The contact key should seat the syn detector tone connections in the groove, and fit the two components together onto the output shaft and detector shaft, respectively. Ensure that the synchro drive does engage with the synchro drive slots.



29. **Output Gear Drive:** Fit the synchro driver plate over the output shaft. Clean the threads on both shafts and apply a thread locking compound (Loctite 262 or equivalent). Fit the gear to both shafts. Turn the shafts by engaging and disengaging, and then engaging into gear by sliding the detector tone into shaft torque (tighten lock nuts).



Torque to 11 Nm (99 lbf.ft)

Lock both the nuts securely in two places. Select neutral.

30. **Pin Detector Fork:** Scraper fork securely lock to the shaft using a pin (11).


31. **Reverse Warning:** Install and tighten the reverse light switch with all electrical cables.



32. **Detector Mechanism Assembly:** Fit the detector into the assembly using a new washer, and fit and tighten the fitting screws.

Torque to 13 Nm (10 lbf.ft)

Check that all gears can be selected.





2. Inspect lower shock strap. The upper shaft is available as a fitted unit to the main spring, and the lower shaft, fork, knuckle, and lower tie rod leg can be applied to the lower portion of the shock strap in the main unit.

Figure 1. 10-10-100-100



3. Inspect front coil spring. The coil spring is available as a fitted unit to the main spring, and the lower shaft, fork, knuckle, and lower tie rod leg can be applied to the lower portion of the shock strap in the main unit.

Figure 2. 10-10-100-100



4. Inspect front coil spring. The coil spring is available as a fitted unit to the main spring, and the lower shaft, fork, knuckle, and lower tie rod leg can be applied to the lower portion of the shock strap in the main unit.

Figure 3. 10-10-100-100

5. Inspect rear coil spring. The coil spring is available as a fitted unit to the main spring, and the lower shaft, fork, knuckle, and lower tie rod leg can be applied to the lower portion of the shock strap in the main unit.



6. Inspect rear coil spring. The coil spring is available as a fitted unit to the main spring, and the lower shaft, fork, knuckle, and lower tie rod leg can be applied to the lower portion of the shock strap in the main unit.

Figure 4. 10-10-100-100

7. Inspect rear coil spring. The coil spring is available as a fitted unit to the main spring, and the lower shaft, fork, knuckle, and lower tie rod leg can be applied to the lower portion of the shock strap in the main unit.






27.11 INPUT SHAFT DRIVE SHAFT DISASSEMBLY/ASSEMBLY

Input Shaft Disassembly


The input shaft assembly consists of the input shaft with its integral third, second and forward gear drive pinions, first and left hand taper roller bearings, third/first gears, third and fourth gear free drive pinions, and the third/fourth speed synchroniser assembly.



1. Input Shaft, R.H. Bearing: Remove the right hand bearing with a suitable bearing remover and a press.



2. Input shaft L.H. Bearing, 3rd & 4th Drive Gears & 3rd/4th Synchroniser Assembly: Fit the bearing remover over the 3rd drive gear and use a press to remove the complete bearing/gear/synchroniser assembly.



Output Shaft Disassembly

The output shaft assembly consists of the output shaft with integral final drive pinion, right and left hand taper roller bearings, third/second gears, third and second speed free pinions, and the first/second speed synchroniser assembly.



1. To install the 1st gear, check that the 1st and 2nd gears have been properly assembled prior to installation of the output shaft. Place the 1st/2nd synchronizer sleeve to prevent one of the synchro rings from slipping on the gear, and reverse the clearance between the synchronizer ring and the 1st gear. It should be the same



as between the 2nd gear and sleeve.

2. To install the 1st gear assembly, fit the 1st gear, the 1st gear synchronizer ring assembly and the 1st gear sleeve.

3. Mount the 1st/2nd B.B. Bearing, hence the bearing on the 1st gear. The 1st bearing must be fitted to the 1st gear shaft with a press.

4. Assemble the 1st/2nd shaft.

5. Output Gear B.B. Bearing 5 and 4th gear bearing the 1st hand bearing together with the 1st/2nd driven gear pinion, 1st driven gear sleeve, bushes and bearing mounting sleeve. Use a special cover tool and adjust the 1st gear sleeve, and a press. Also, hence the 1st/2nd gear key from the shaft keyway.





4. Put away Needle Bearing & Synchro Ring. Slide off the 1st speed shaft cover with the needle roller bearing. Remove the 2nd speed 1st gear synchro ring set.

5. Inspect Synchro Ring. 1st Gear is mounted in a press to remove the 1st speed 1st gear, 1st/2nd synchroniser assembly, and 1st gear needle roller bearing in one operation.
It is normal the 1st gear needle roller bearing, needle roller thrust bearing and shaft spacer.



Inspection of component

6. Synchro Ring: Fit the 1st, 2nd and 3rd speed needle rings, and the 1st, 2nd and 3rd speed 1st gear synchro ring assembly with their corresponding gears, and measure the clearance between the ring and the dog teeth flange.




Clearance = 0.10 mm maximum

Replace the synchro ring if 0.10 mm specification.

7. Measure the clearance between each synchro ring slot and a rib (max).

Clearance = 1st/2nd = 0.10 mm max
2nd/3rd, 5th = 0.15 mm max.



Replace the synchro ring if the dimension exceeds the specification.

8. Synchro Ring: Measure the clearance between the synchro sub-stem and needle.

Clearance = 0.05 mm maximum

If the clearance exceeds specification, replace the synchroniser assembly.





1. 4th Gear Sleeve: Fit the 4th gear needle bearing sleeve into the shaft and the needle bearings with a press to fit into place.

Installed: 00007430



2. 4th Gear: Insert the 4th gear roller splines into the 4th gear needle roller bearing with a press against the end of the shaft.


3. The 4th speed synchronizer ring with CV synchronizers.

4. Fit the 4th gear over the needle bearing on the shaft.

5. Insert the 4th gear thrust washer, and fit into the shaft with the stepped side toward the gear.

6. 4th Gear Lock: Fit the 4th gear lock roller bearing into the shaft with the dust sleeve and a press.

Installed: 00007430



6. 1st Gear Thrust Washer: Fit the 1st gear thrust washer onto the shaft with the dust sleeve and a press.

Installed: 00007430



1st Gear Shaft Assembly:

1. 1st Gear & Bearings: Fit the 1st gear thrust washer onto the output shaft. Insert the needle roller bearing with transmission oil, and fit into the shaft. Insert the 1st gear needle bearing, and fit onto the shaft followed by the 1st speed gear.

**2. Install 2nd gear pinion and bearing**

2. Install the 2nd gear pinion and bearing assembly into the case of the 2nd gear housing. Position the spring on opposite side of the pinion. Press the bearing onto the shaft and secure the bearing with the lock washer and lock nut.

3. Install the gear oil seal onto the shaft assembly with the lock washer and lock nut. Press the gear oil seal into the case and secure the lock washer and lock nut.

4. Install the 2nd gear 1st shaft and gear pinion into the shaft assembly. Press the pinion into the case and secure the pinion with the lock washer and lock nut. Press the lock washer and lock nut into the case of the shaft.

Reference location (1) for 2nd gear

Reference location (2) for 2nd gear

Note: Be sure that the 1st and 2nd gears mesh fully with the synchro hub shafts as the gears are pushed into position.

5. Install the 2nd gear, synchro hub, 2nd gear pinion and gear oil seal onto the shaft assembly and fit onto the shaft. Lubricate the pinion and gear pinion with gear oil. Fit onto the synchro hub assembly. Fit and secure gear oil seal onto shaft assembly.



6. Install the 2nd gear shaft and gear pinion into the gear housing with the lock washer and lock nut. Press the lock washer and lock nut into the case of the shaft.

7. Install the 2nd gear pinion and gear oil seal onto the shaft assembly with the lock washer and lock nut. Press the lock washer and lock nut into the case of the shaft.

Reference: T00071009

8. Press the gear pinion into the bearing case. Press the gear pinion into the case and secure the lock washer and lock nut.

Reference: T00071011





12) Break the shakedown on the pinion gear and locking pin using a low drill. Drive the free locking pin using a pin driver and adjust the planet gear side. Press the differential gears, taking care to set the initial adjustment of the gears and thrust washers.



13) Mount washers A and B. Measure the external diameter of the cluster gear, and compare diameter to the washers to establish the clearance between the two components.

Drawn: 1:2 see caption.

Measure the gear and axle fit clearance around this figure.



14) Set gears. Measure the inside diameter of the sun gear assembly, the inside and the outside diameters inside diameter of the diff housing. Formulate the clearance around.

Drawn: 2:15 see caption.

Measure the pin gear and differential carrier fit clearance around this figure.



15) Alignment on shaft. Measure the diameter of the diff carrier at each differential gear.


Drawn: 2:15 see caption.

Measure the ball carrier fit diameter around this figure.




**Assemble**

1. Reinstall the side drive components with lubrication as set before assembly. Fit the sun gears and third shafts into the carrier in their original positions. Fit the intermediate gear, and align so that it meshes with the gears. The planet gear sets with the lock pin into a lip. Check back and adjust pins as in (3) above.



2. Turn the "lock". The planet gear sets lock pin is used as a punch to drive the pin to the bottom of the bore. Shake the unit in the lock pin to ensure a pin is retained.




- 1. Third gear
- 2. Lock pin

3. Second Gear. Fit only a new speed drive gear. Press the gear to press. Fit (2) Balling gear and bearing on the pin. Do **NOT** use oil when installing the gear on the carrier.

4. Lock bearing in the following order to press into the carrier into position on the carrier.


- 1. Balling bearing (1)
- 2. Gear (2)
- 3. Balling bearing (1)



5. Apply Gear. Apply (1) to the mating surfaces of the ring gear and dull. Contact and fit the ring gear in position. Remove the gear using (2) to the teeth pre-applied the oil lock compound with uncoated threads.



torque 16-20 N·m (11-14.5 ft·lb)

4F.1.1. RELEASE OF THE SHOCK ASSEMBLY ASSEMBLY

1. To release the shock absorber from the two wheel drive vehicle, remove the four wheel drive shafts, the U-bolts, and remove the complete assembly and center.

2. The parts needed to Remove the shock coil and pivot pins to release the shock coil are listed below.

3. The shock absorber has a pivot pin to remove the spring pin, stripping the oil seal to fit it to the cross shaft, and remove the seal. With the cross shaft, washers, the distal air housing, cross shaft springs and shock coil.

4. To use the oil seal, wash the seal, the distal air housing, shock coil and spring coil. The seal is at the end of the cross shaft oil seal.

assembly

5. Cross shaft springs: Measure the free length of the cross shaft spring, and compare it to the free length of the shock coil.

Free length of the coil is 15.2 mm (0.598 in)
Free length of the spring is 61.6 mm (2.425 in)

6. To install from a new cross shaft oil seal into the housing.



9. Remove all parts of the stopper bar, spring, and bolt.

10. Cross Shaft Assembly: Attach the cross shaft, spring and seals, and attach the spring into the housing, making sure that the larger (15112490) spring is fitted at the inboard (starboard) end of the housing. Insert the cross shaft, making sure to align a cutting mark on the shaft with the mark, with the teeth, and at the inboard finger. Use a new spring pin to secure the finger to the cross shaft.

After assembly, make sure the reverse shaft of Technician 6 is correct manually.

11. Torque Balllinks fit the balllinks, wear rate prohibit, and fit the lock pin and cap ring.

12. Fit support for the hub and assembly using a lock washer, and fit and tighten the locking screw. Refit gearchange nutlock.

Torque bearing 2 washers to 28 Nm (20.7 lbf-ft).

11.14 - DRIVESHAFTS



To enable shorter length drive shafts to be used, and thus reduce the effects of torque shock, a 'backlash' is used on the inboard side in order to extend the transmission output shaft to a position commensurate with the inboard side. The gearbox is supported at its outboard end by a ball bearing fitted to the end of the shaft.

When drive shafts are fitted use planetary mesh type (Shurex 10) seals, and protect shafts with edge reinforced U.V. joints. The outboard joint is available as a service unit, as is the inboard joint complete with shaft. Engineers' quality kits are available for both joints. The seals themselves are packed with grease to initial assembly, and are maintenance free. It is however of great importance that the protective coatings are carefully inspected at service intervals. To check for splits, tears or a network, wash the joints with detergent very quickly once contaminated with dirt or water. Damaged gaskets should be renewed immediately, once the availability of the joint has been established.

Drive shafts tend to wear more freely than inboard shafts due to their greater irregularity in operation, but if an inboard joint is found to be worn due to high mileage, fitting this component via a 'service body' kit is recommended as is a complete replacement drive shaft assembly. A clacking noise and/or a 'clunk' is a typical symptom of a worn outboard joint. A check procedure by engine torque reversal, or a procedure of vibration when accelerating, can indicate a worn inboard joint. Any vibration that could be due to worn inboard joint assemblies, should be investigated and repaired without delay, since safety implications can be a very real issue.

11.14.1 - Removal

1. Put Key between the driveshaft hub and...
2. Make Note: Remove the clip securing the brake hose to the top wishbone, and release the brake hose from the bracket.
3. Top Ball Joint: Mark the position of the rubber adjustment concentric on the top ball joint to facilitate future work. Fit pressure the top ball joint bolts. Note and record the positions of the dust adjustment shims plates.

III Driveshaft AssemblyIII Inboard Joint

to allow for wear. The inboard joint is retained on the transmission output shaft by a square section clamp (Fig. 17-12), and is secured by applying a lock pin to the inboard joint body. Use a slide hammer with a hooked end, an $11/16 \times 2$ clamp bar to remove the yokes later.

CAUTION: Do not attempt to remove the inboard I.V. joint feet. The clamps are retained on the shafts. This action will cause the shaft to become disassembled and may affect replacement of the joints. The components of the inboard planetary joint are held in position. For repair purposes, they are held in place when the bearing shell will be considered of separate area. Drive is needed. Apply grease bearing to the shaft or drive shell to the shaft.




5. Sliding Fork: Rotate the inboard CV joint from the transmission output shaft and the driving yoke (T607011) to the transmission to lower the amount of transmission oil loss.
6. Dasher Yoke: Insert the yoke into the bolt, securing the yoke to the dasher only, and the nut from the bolt, securing the yoke to the lower link. Lower the yoke to place it against the weight of the air assembly, and tighten the nut all at the same time.
7. Insert the inboard CVL shaft from the hub bearings.

Driveshaft Replacement

Note that the LH driveshaft assembly has a split spring on the inboard joint and the air assembly a double spring.

Each drive shaft is retained to its transmission output shaft by a slipring, which should be replaced EACH TIME a driveshaft is removed. Note that the slipring fitted on the male splines of the LH inboard CV joint is of round section, whereas the female retaining and the inboard CV joint is of flared on the end of the transmission output extension shafts. It square in section. The two shafts are therefore NOT interchangeable, and care should be taken to ensure that either is replaced.



1. Inboard joint: For a new vehicle only the inboard CV joint spring shaft (top of transmission output extension shaft) (RH) cross the inboard air fully to left of the output shaft. If the retaining bracket is located on the column, (mark by painting) at the shaft.

2. Air assembly: Feed the inboard joint into shaft through the yoke bearings, and ensure that cooperation in reverse order to dis-assembly, taking care to refit external center adjuster & slip plates, and rather adjust your attention to their original positions.

Lower settings:

- Dasher yoke to lower link: 75 - 70 Nm (55 - 52 lbf ft)
- Dasher yoke to shaft: 35 - 33 Nm (26 - 25 lbf ft)
- Top ball joint to top link: 22 - 15 Nm (16 - 11 lbf ft)
- Hub nut: 225 - 215 Nm (165 - 155 lbf ft) & before put into recess of shaft end

CV Axle and Carrier Replacement

1. Driveshaft Assembly: Remove the driveshaft assembly from the air (see above).
2. Suspend: Cut off the gears and slugs from both driveshaft joints.

1. Remove Outboard Joint: The outboard joint is retained by a round section slipring on the end of the shaft. To remove the joint, hold the drive shaft in a vice, and use a slip roller to tap the joint over the slipring and off the shaft.



If the front is subjected to stress, use a inner drift on the front side of the wheel base.

NOTE: Do not attempt to remove an inflated joint from a tube. First remove the inflator assembly from the tube. Allow the tube to naturally deflate to a pressure slightly below the inflation pressure. Then remove the inflated joint assembly.

12. Measure and inspect the diameter of the hole in the wheel base. If the hole is not the correct diameter, use a press to enlarge it and decrease the air volume. A wear pattern, such that the interference fit portion is likely to pull out, requires further work.

13. If the grease is the joint is in the wheel base, it is likely that the joint is damaged, and needs an overhaul. If the grease is not in the wheel base, the joint should be removed by walking in a straight line over the wheel base until the joint is removed.

14. The wheel base hole type should vary the inner base to the tube to expose the tube to the grease. The hole should be drilled to a diameter of 1/2 inch (12.7 mm) and the hole should be drilled to a depth of 1/2 inch (12.7 mm).

15. The inner base hole type should vary the inner base to the tube to expose the tube to the grease. The hole should be drilled to a diameter of 1/2 inch (12.7 mm) and the hole should be drilled to a depth of 1/2 inch (12.7 mm). The hole should be drilled to a diameter of 1/2 inch (12.7 mm) and the hole should be drilled to a depth of 1/2 inch (12.7 mm). The hole should be drilled to a diameter of 1/2 inch (12.7 mm) and the hole should be drilled to a depth of 1/2 inch (12.7 mm).

16. Replace the grease in the wheel base and secure the inner base to the tube with the inner base hole type. The hole should be drilled to a diameter of 1/2 inch (12.7 mm) and the hole should be drilled to a depth of 1/2 inch (12.7 mm). The hole should be drilled to a diameter of 1/2 inch (12.7 mm) and the hole should be drilled to a depth of 1/2 inch (12.7 mm).

17. If the hole type over the hole is not drilled to prevent damage to the wheel base, use the inner base hole type. The hole should be drilled to a diameter of 1/2 inch (12.7 mm) and the hole should be drilled to a depth of 1/2 inch (12.7 mm).

18. The hole type over the hole is not drilled to prevent damage to the wheel base.

19. The hole type over the hole is not drilled to prevent damage to the wheel base. The hole should be drilled to a diameter of 1/2 inch (12.7 mm) and the hole should be drilled to a depth of 1/2 inch (12.7 mm). The hole should be drilled to a diameter of 1/2 inch (12.7 mm) and the hole should be drilled to a depth of 1/2 inch (12.7 mm). The hole should be drilled to a diameter of 1/2 inch (12.7 mm) and the hole should be drilled to a depth of 1/2 inch (12.7 mm).

NOTE: The grease provided in the tube is specially formulated for high resistance and durability. Do not use substitutes or use any other lubricants.


20. The hole type over the hole is not drilled to prevent damage to the wheel base. The hole should be drilled to a diameter of 1/2 inch (12.7 mm) and the hole should be drilled to a depth of 1/2 inch (12.7 mm). The hole should be drilled to a diameter of 1/2 inch (12.7 mm) and the hole should be drilled to a depth of 1/2 inch (12.7 mm). The hole should be drilled to a diameter of 1/2 inch (12.7 mm) and the hole should be drilled to a depth of 1/2 inch (12.7 mm).

21. The hole type over the hole is not drilled to prevent damage to the wheel base. The hole should be drilled to a diameter of 1/2 inch (12.7 mm) and the hole should be drilled to a depth of 1/2 inch (12.7 mm). The hole should be drilled to a diameter of 1/2 inch (12.7 mm) and the hole should be drilled to a depth of 1/2 inch (12.7 mm). The hole should be drilled to a diameter of 1/2 inch (12.7 mm) and the hole should be drilled to a depth of 1/2 inch (12.7 mm).



Part 1 - 1000000000

Component Assembly Drawing (Example) 1000000000



Part 2 - 1000000000


Part 3 - 1000000000



Part 4 - 1000000000



Part 5 - 1000000000



Part 6 - 1000000000



Part 7 - 1000000000



Part 8 - 1000000000



Part 9 - 1000000000



Part 10 - 1000000000



Part 11 - 1000000000





Output Shaft Oil Seal Installer T000T1052



Oil Pan Adapter Gage Set T000T1055



Output Shaft Oil Bearing Remover T000T1057



Oil Pan Seals Installer T000T1060



Oil Seal Sleeve Installer (2) pcs. T000T1063 & T000T1064



Output Shaft Oil Bearing Installer T000T1067



Oil Seal Springs Installer T000T1068



Oil Seal Springs Pad 6 T000T1070



Output Shaft Aperture Flangeing Plug T000T1074

Output Sealless Ring Sealless Ring T000T0997



WHEELS & TIRESSECTION 410 - WHEEL

	<u>Sub-Section</u>	<u>Page</u>
Alloy Wheels	00-1	1
Tyres	00-2	1
Spare wheel & Tyre	00-3	2
Wheel Tyres	01-4	4
Steel Tyre Assembly Balancing	01-5	6




WARNING: Spare wheels, used on the EMERGENCY (SAFETY), and must be replaced with the correct wheel and type equipment as soon as possible. Only one spare wheel may be used on the vehicle at any one time. When the spare wheel is in use, differential type wear will be accelerated, and the racing and braking character of the axle will be modified. It is therefore necessary to observe the following recommendations:

1. Less than normal speeds and maximum loads should be employed (i.e., no more than half the rated potential) relative to the prevailing road conditions subject to a recommended maximum speed of at least 50 mph under the most favorable conditions.
2. When following road curves, take maximum that consistent in with the U.S. Highway Test or American Safety Council guidelines for vehicle operation; this advice applies equally to spare wheel usage as to all other vehicle conditions.
3. Spare wheel tire pressure 4.2 bar (60 lb/in²).



The spare wheel, wheel-brake and jack are mounted beneath the body floor, and up the centre section of the floor, and remove the spare wheel crimp ball.

Before re-fitting the standard wheel, ensure that the mating face on both the wheel and hub is clean, and free from corrosion. Observe a wheel rotation and/or tension at the wheel bolts, as usual.

Note: Directional Tread The Goodyear "cople 18-8" type used on some vans with van wheels, have a preferred direction of rotation which is indicated both by an arrow on the tyre sidewall, and by the tread pattern itself as shown in the illustration. The tyre is safe to use in the non-recommended direction, and doing so will result only in a marginally reduced wet surface performance. However, this condition should not be retained for excessive periods, and it is recommended that the tyre is returned to address the correct condition of preferred rotation at the earliest opportunity.



Always remove the spare wheel and wheel clamping equipment in their correct location to prevent unnecessary flexing causing damage to other components of the body. Place the spare wheel into the body floor recess with the outside of the wheel upwards, and a shoulder hole positioned near the securing thread hole in the body. Two types of spare wheel retention were ever used. Early vans showed the jack handle fastened with the wheel-brake in the spare wheel dish.

FIG. 1. - Repair wheel clampingFIG. 2. - Repair wheel clamping



Fit the jacking handle into the wheel, with the handle through the bottom steel eye bolt. Fit the shoe brake through the clamp screw clamp. Fit the clamp screw through the wheel-hub fixing hole. Put strap into the frame, before tightening the clamp screw. Fit the lock pin between the jacking handle and steel eye of clamp tighter the clamp screw.


In other cases, the jacking handle is placed in either on the underside of the jacking handle frame. Fit the strappin screw through the shoe-eye clip, and fit the shoe-eye positioned as shown in the diagram, with the hook and pin into one of the shoe eye holes, across the wheel hub shoulder. And the pin into the threaded bearing.

NOTE - WHEEL TYRES (NOT USA vehicles)

Winter tyres must not be fitted performance or snow and ice conditions, not cannot be expected to reach the wear-related performance level of the standard equipment tyre under all other conditions when they are encountered. Winter tyres should not therefore be used as a 'year-round' fitment.


Michelin 2 MS (steels) with winter tyres, with or without studs, may be fitted only to complete the sets, POC or PMA wheel-hubs using the specified 4 x 4 steel wheels AND S-SPLIT WHEEL BOLTS (A00000000). When refitting the standard alloy wheels, the standard correct wheel nuts must be used.

Standard 4 x 4 steel bolts
A10000000 - Chrome plated



Winter tyre - type
- size
- part number
Wheel Bolt - part number
- torque
Winter tyre - type
- size
- pressure (bar/kPa)
Speed limitation - without studs
- with studs

Altered wheel base
A10000000 - Black zinc



Steel, 4 bolt fixing
63 x 14
A10000000
A10000000 (10 sets)
80 - 95 lbs (36 - 43 kg ft)
Michelin 2 MS, with or
without studs
185/60 x 14
2.0 bar (29 lb/in²)
110 mph (180 km/h)
see table

The tyre without studs, a regular speed of 110 mph (180 km/h) must be observed. If studded tyres are fitted, in conditions that limit their use, further speed restrictions will apply, and a warning sticker must be applied to the back of the vehicle by the tyre fitting depot. Details of the speed restrictions for studded tyre usage in Europe countries, are listed below.

STAIRINGSECTION 10 STAIRS

	<u>Sub-Section</u>	<u>Page</u>
General Description	10.1	1
MS Steel Deck & Stair Frame	10.2	1
Stairing Steel & S. Deck Assembly	10.3	5
Steel & Timber Ball Track Systems	10.4	10
MS Lull & Landing Enclosure	10.5	11
Landing Deck Assembly Between/Recessed	10.6	14
MS Deck Assembly Steel & Post Erection	10.7	15
General Deck Assembly Adjustment & Finish Replacement	10.8	17




NEW POWER TRAIN

The steering system comprises an upper valve assembly, fixed in case with a rack and pinion assembly in case without. Both types being collapsible in the event of damage to the hull structure, and a control or power assisted rack and pinion assembly.

The rack and pinion assembly is secured rigidly to the chassis front and supported by two bearing brackets, and connects with 200 lb/in² fluid high steering gear via 1 1/2" diameter brass rods. The constant ratio steering rack assembly are made of 1 1/2" diameter or 1 1/4" diameter brass rods 1/2" long.

Power Assisted Steering Unit


The PMS system uses a hydraulic pump, located at the front side of the engine driven by a drive belt on the main shaft, to supply oil to the valve body of the steering rack. When a valve body hydraulic connection is either made or a piston is fitted to the steering rack to cause loss of the steering assist. A reservoir for the hydraulic fluid is mounted at the right hand rear of the engine bay.





The steering rack assembly comprises a steel tube which houses the steering pinion, with a steering knuckle fixed at one end, which supports the pump and valve body assembly. The end of the rack tube is hydraulically actuated by the sliding rack bar by means of ramps, and a piston at the end of the rack controls the tube through hydraulic chambers, with each chamber in fluid with the valve body by steel pinions.

The rack body, which is integral with the rack housing, contains three main sections: a pinion sleeve, which consists of a cylindrical sleeve fitted with a ball bearing to provide the hydraulic pressure, and an integral piston which engages with the rack teeth; a steering knuckle which fits the middle of the pinion sleeve to connect the steering column to the pinion gear, and a rack which is secured together with the top of the steering knuckle to the steering column, and engages within the pinion sleeve to control the hydraulic piston. The rack body is provided with four hydraulic connections:





- main pressure input to the pump
- the pressure return to the reservoir
- high pressure output to the left hand side of the rack piston
- high pressure output to the right hand side of the rack piston

When the torque is applied to the steering wheel, all four ports are inter-connected so that oil from the pump flows through the valve body and back to the reservoir, and to both of the rack steering hydraulic chambers to apply an equal pressure to both sides of the rack piston.

When the steering wheel is turned, the ratio is turned by the column, but the rotation of the pump sleeve is governed by the steering resistance at the rack wheels. At the subsequent turn of the steering wheel, the steering resistance between the rack and pinion assembly depends on the steering conditions and subsequent torque. As the torque (and angular displacement) increases, one of the output ports to the rack is progressively biased towards the low resistance return chamber to the reservoir, while the other output port is biased towards the pump pressure feed from the pump. In that way, a pressure differential is created between the two rack chambers, which tends to move the rack and provide steering assistance. Now, the input torque at the steering wheel is higher, the angular displacement between the rack and pinion sleeve is small so that the pressure balance across rack is restored, and steering assist is reduced. The same sequence happens when the wheel is turned in the opposite direction, and a pressure differential is created in the opposite sense.

The resulting angular displacement between rack and pinion sleeve is limited substantially to prevent excessive torque being applied to the steering bar, and to provide a mechanical limit to the steering wheel of a certain size failure. The amount of the steering wheel that is returned, either with a manual amount or with the self.

The engine driven variable hydraulic pump, incorporated a pressure relief valve to control maximum pressure at the rack reservoir, the lock stop, and steering torque is small applied. The output of the pump is designed to last all day, at low speed gear speed, in order to provide a reserve of "reserve pump capacity" for higher power assistance being provided at low engine speed for parking manoeuvres, and rack assistance at high speed. It operates with a the right side of the pump return with a high pump pressure at developed with a high engine load, and signals the engine management how to increase the pressure at the idle and return, valve to maintain idle speed and prevent stall.


4. - DO NOT OVER FILL & OIL CHANGE FREQUENTLY

Hydraulic Fluids

The recommended fluids for use in the power steering hydraulic system are listed in the "Bosch Automotive Fluids" data part number 610000000
 75% power steering fluids (oil) part number 610000000

Fluid Level Check

The reservoir to be inspected is located at the right hand rear of the engine bay, secured by the engine bracket to the chassis. At every vehicle service, check the top and top of the fluid reservoir before unscrewing the cap and inspecting the fluid level shown on the dipstick (align with the cap). The two marks on the fluid are compared to the correct oil level (top mark is low when oil has been below several miles, and the reservoir is up to the front), and to the correct cold level (lower mark). Top up if necessary using ONLY the approved fluid (see above).



Pressure Fluid Change

The power steering oil should be changed at intervals specified in the 14. Reference Schedule (see section 04). To change the fluid, proceed as follows:

- Drain the fluid by removing the reservoir cap and disconnecting the high pressure feed and low pressure return hoses from the valve body on the steering shaft (see 16). Run the low pressure line from valve body to rack housing, and collect the oil.

- After the oil has drained thoroughly, reattach the low hoses to the rack, torque the setting nut. High pressure feed (finger, 8135, 19 - 21 Nm (14 - 15 lbf.ft))

Low pressure return (finger, 8136, 19 - 21 Nm (14 - 17 lbf.ft))

- Fill the reservoir with new fluid. Keep the ignition switch in position 15, engine cranking, and pump the engine in short bursts while turning the steering fully from lock to lock. Keep the reservoir topped up during this procedure, which is an essential action to fill sufficiently for air to enter the system while the engine is being cranked, so the pump may be purged. Continue with this procedure until there is no evidence of air bubbles appearing in the reservoir.

- Top up the reservoir to the fluid mark on the dipstick.

- Test the entire system, run engine, operate steering and inspect for leaks and correct pressure steering speeds, etc.

WIPER - STEERING COLUMN & COLUMN ASSEMBLY

The type of upper steering column and base on the Escort, a tilt adjustable column for models outside the UK, and a non-adjustable version with S.I.F. (steering interference free) installation on UK vehicles. The following section applies only to non-RSE models. Any work on RSE vehicles with WIP, requires that a 1000R safety bracket and/or laces, which are fully detailed in a separate manual Section 801 part number E10011233, be not attempt any work on an RSE type of wiper motor or column without reference to section 801.


If the vehicle is involved in an accident, the multipoint steering system should be carefully inspected and repaired if any deformation has occurred. Before the following checks involve, the steering wheel and/or column should first be inspected.

1. Wheel 201450


- Measure the overall length of the upper column as shown in the diagram.

Min/lt length = 461.2 mm

replace the column assembly if outside these tolerances.



4000-00A Type Height
Subject to our return program



• Remove the return assembly, secure the return to suitable beam fixing bolts and check that the two slings (shown with inserts) are secured, attached to the beam, for 6m.

• Insert column

• Check that the centreline of the top of the lower end of the column is out a 10mm of the pivot axis in the rubber return lower bracket. If greater, the return replace the column assembly.

• Measure the overall length of the inner column.

Minimum length = 601.2 mm

Replace the return assembly if outside specification.

• Remove Wheel, Removal (Non-MRP)

1. From the centre beam pad and turn counterclockwise to release from the bearing-type fixing.
 2. Separate the end and washer retaining the steering wheel and tack the relative position of the wheel and inner column to aid rebuilding.
 3. Pull the wheel out the bottom using prybar force. If necessary, use a suitable screw and approach to the wheel; remove the fixing ring and the wheel head screws, taking the horn pump spring assembly; withdraw the bearing assembly and disconnect the horn lead (see page terminal).
DO NOT apply excessive axial force to either the inner or outer column without the use of a steering wheel puller, or the mechanism retaining the bearings, as damage to the collapsible column may be exacerbated, necessitating return replacement.
- Relax the steering wheel in the reverse sense to removal, and torque 1/4 turn the steering wheel out to 45 Nm (33 lbf ft).

Open Steps to Column Assembly (Non-Bike)

1. Remove the steering column assembly and empty the electrical connector blocks for the column switches, ignition switch, and horn. Depress the plastic tabs, and slide out the two return springs.
2. Remove the pin bolts securing the lower upper $2\frac{1}{2}$ " to the intermediate shaft.
3. Remove the two bolts securing the bottom of the column to the pedal box, and fasten the bolts securing the top of the column to the switch base.
4. Withdraw the column assembly, pulling the upper $2\frac{1}{2}$ " off the splines of the steering shaft.
5. If necessary, the tube column may be withdrawn from the lower upper receiving the $2\frac{1}{2}$ " pin from the top end of the lower column.
6. If necessary, remove the three bolts securing the top bearing housing to the lower column. Use a center punch to align, to remove the two return springs from the bearing housing, and pull out the ball bearing from the shaft.

Pre-Disassembly

1. Label the column and the return spring, and label the following locations:
 - a. Place label on the column top bearing housing, do not cut the bearing spacer between the bearing and the shaft housing.
 - b. Label the column lock shell halves, and hardware (if secured).
 - c. Label the lock:
2. Label the pedal box (pinion) 10-89-111 (inches).
3. Label the switch base 10-89-111 (inches).
4. Label the intermediate shaft 10-89-111 (inches using vernier caliper).

Intermediate Column

A short intermediate shaft with two universal joints (1971) was used to connect the steering column from the upper column assembly to the steering shaft and column. The universal joints are right in relation to each other in operation, and operate in the same direction of steering wheel.


The upper $2\frac{1}{2}$ " is integral with the upper column, and the intermediate shaft will fit into the $2\frac{1}{2}$ " in only one position, a rubber spline, and a "flat" machined to approximate the pinion bolt. The lower $2\frac{1}{2}$ " will fit into the rack pinion shaft in only one position, as followed by the pinion ball groove. Flight of the intermediate shaft into the lower $2\frac{1}{2}$ " provides the only method of making wheel orientation.

If removing the upper column assembly, remove the upper pinion bolt from the upper $2\frac{1}{2}$ " shaft orientation, and then be retained. If the lower $2\frac{1}{2}$ " is to be a round $2\frac{1}{2}$ " rack assembly removal:


1. Disconnect the upper column from the intermediate shaft (see above).
2. Remove the pinion bolt securing the lower $2\frac{1}{2}$ shaft to the ballhead, and withdraw the shaft over the intermediate shaft.
3. Remove the pinion bolt securing the lower $2\frac{1}{2}$ to the pinion shaft, and rotate the shaft until the ball may be removed and the joint withdrawn.
4. If necessary: If the intermediate shaft has been separated from the lower $2\frac{1}{2}$, the orientation may be set in assembly.



Take the end of the pinch bolt which secures the lower u/j to the intermediate shaft as a datum, first set the shaft so that the flat on the spline at the top end of the shaft is parallel with the pinch bolt. Then turn the shaft 180 degrees counter-clockwise so u/j turns, so 3 splines clockwise is 180 degrees, before inserting the shaft into the lower u/j . See diagram. Tighten pinch bolt and tighten to 25 ft. lbs (25 lbf ft).



12B column assembled



12B column assembled



ways and any alignment on EOP parts is affected by the LRF specification, please refer to section III.3 in the separate manual 210012529.

4. For the track roller, set the track assembly pin at 2075 with the pin hole well aligned with the groove in the shaft. Fit the pin, O-ring and torque nut to 25 Nm (18 lbf.ft).
5. Fit the lower rail guard over the intermediate shaft and secure to the hull frame.
6. Re-fit the upper rail assembly face at rest.

III.2. TRACKS & UNDERCARRIAGE JOINTS & GUIDES

Track Final Tension

The undercarrage track (track rod & eye) are secured to the hull frame by means of a tapered metal pin through and under tube. The track roller is inserted into the roller hole and pulled a certain amount of adjustment of track.

Track adjustment: To adjust the tension, turn each track rod end by the lock pin and adjust wheel according to the LRF. Turn each track rod, using the lock pin, to adjust the effective track rod length. To adjust the effective track rod length, it is necessary when adjustment is incorrect, add the track rod end and tighten the lock pin to the LRF.

Roller wear: If the roller and guide is damaged, so it will play a role in the operation, the roller should be replaced. Before removing the roller, measure the length of track protruding in order that the initial setting of the new roller may be approximately correct. Remove the roller nut, and add a roller nut and eye to the roller shaft from the opposite end. Turn a roller nut, and tighten the eye from the track rod.

Remove the roller nut from track rod to the maximum allowed value, and fit the roller nut, eye to the track rod arm. Fit a new roller nut, the roller eye torque tighten to 25 ± 6 Nm (18 ± 4 lbf.ft). Check adjustment, and add roller nut and eye where.

Track Ball Joint

Worn track ball joints should be replaced, preferably to prevent loss of alignment, lost steering and damage to the other ball joints. To remove ball joint, remove the track rod nut, and then fit the roller stop nut and adjust the roller from the track.

Remove the track rod nut, remove the nut and eye of the track ball joint, and remove the necessary eye below.

Remove the pin and eye of the track rod, fit the new ball joint into its position, and secure with the eye housing, and secure with a new clip. Before fitting the roller stop of the track rod, ensure the groove in the rod with the groove to enable the track rod to be turned for trackings adjustment without locking the roller.

Fit the roller stop and adjust. Fit on the roller stop and guide, adjust the roller stop to the large end of the track on the opposite side of the vehicle to give a 10% full running ball, and adjust the track tooth area with 10% (10% of steering).

Track Rod, Eye Ball Joint Assembly

The track rod are secured with the roller ball joints, which are fit



check until it is possible to do any key. If the play is considerable in a joint, the rack and pinion gear assembly should be replaced in the following manner:

- Remove the rack and pinion gear assembly from the fan case (section 22.6f).
- Remove both rack wheels.
- Mark each gear with a colored ink or enamel at the mesh area, and as provided with flats to help in the joint to be formed. It is most important that the previous gear teeth are not allowed to provide the reaction torque when fitting or removing the inner ball joints. An load one of the wheels, whilst supporting the other. Use one of the pinion gears to hold the rack across the width of the teeth to prevent the second tooth.
- Fit the new flange of the reverse gear to dimensionally. Lighten up with sand to 72.5 HRC for the shaft and attack the pinion gear teeth to bear any of the reaction load.
- Remove the fan case into the slot provided on the rack body.
- Refit the rack gears and shaft.
- Refit the gear housing with care.

22.4. PUMP AND VALVE REPAIR PROCEDURES


Check Ball

The 12 mm diameter displacement pump is a non-rotatable unit mounted on the left hand end of the cylinder block, driven by main cam ball. See the exploded view. The inner ball should be replaced by 40 x 12 mm 6145 - 15 1201 using a bench vice. To adjust ball clearance, slacken the pivot ball, separate the pump mounting bracket to the cylinder block, and the two balls securing the screw at screw. Bring the pin bracket to achieve the specified tension, and tighten the screw balls to 15 Nm (10 120 10).

Check Steering Pressure Relief (SPRS)

When a high torque is applied to the steering wheel, and a heavy load placed on the pump, a pressure switch on the outlet side of the pump, closes at about 40 kg/cm² (570 lb/in²) and a queue the suction arrangement ECM to open the solenoid valve and raise the speed to prevent stalling. The air conditioning compressor is also equipped to turn switched off when the power steering pressure switch is first closed.

PAS pump viewed from front side





2. Check that the RPM is functioning, let the engine idle, and hold the timing adjuster the left hand lock stop. The idle speed should increase after 30 sec with throttle linkage and repeat the test. The computer should correct idle, and the idle speed increases. If the system did not perform as specified verify RPM with timing device and check gauges across the switch terminals.

3. To confirm the seal, first verify the radiator bottom hose for approved service, replace increasing the switch from the underside of the prop body. Stop the fuel immediately to remove seal lines.

Pressure Test

To check both the pump output, and the steering rack assembly seals for leakage, a test gauge (BENTON) is needed to measure the fluid pressure, and the size of the output hose from the pump.

1. To measure the output pipe pressure, cut into the top of the pipe, adding a edge to seal to hold any remaining fluid, and for the test valve between the pump and the disconnected pipe. Tap up to 1/2" diameter of 1/2" NPT.

2. Turn the engine off, fully start the engine, set the gauge pressure to 100 psi, and observe the gauge. The gauge should be in the green area. Run the engine at 1500 rpm, the system pressure should be rising temperature in 30 seconds, the gauge should be increasing, all hoses on the system, and bring the test valve to the "max" mark.

3. Reduce engine speed to 1000 rpm. Gradually increase the gauge valve fully and partially to gauge pressure reading. **NOTE:** Do not seal the valve for gauge, this is done because the fluid temperature will rise quickly, reducing its volume, and the reading. The test will run until the valve is closed, and closed the pump to seal hose.

Use the gauge valve to 1000 rpm, 1500 rpm, 2000 rpm.

4. The gauge valve is closed, and the gauge is removed, the pump should be operated.

5. When the valve is closed, hold the steering wheel. The left side lock stop is a moment, and hold the steering pressure, and then hold against the right hand side stop and record the pressure.

6. Examine the valve, then 800 rpm, 1500 rpm, 2000 rpm, 2500 rpm, and 3000 rpm, and record the pressure.

7. To check the steering rack, set the gauge valve to 1000 rpm, set the gauge valve to 100 psi, and observe the gauge. The gauge should be in the green area.

8. To check the rack, set the gauge valve to 1000 rpm.

9. To check the rack, set the gauge valve to 1000 rpm, and observe the gauge. The gauge should be in the green area, and observe the gauge. The gauge should be in the green area.

10. To check the rack, set the gauge valve to 1000 rpm.

11. To check the rack, set the gauge valve to 1000 rpm, and observe the gauge.

Page 11 of 11

12. The gauge valve to 1000 rpm, and observe the gauge. The gauge should be in the green area, and observe the gauge. The gauge should be in the green area.

13. Examine the rack, then 800 rpm, 1500 rpm, 2000 rpm, 2500 rpm, and 3000 rpm, and record the pressure.



2. Disconnect both hose lines from the pump and drain the fluid into a suitable container. Unplug the knife electrical connector.
3. Slack the belt tensioning, release the belt assembly, the pump or the mounting bracket, and remove the pump and pulley assembly.
4. If the pump is to be fitted, use a suitable pulley to withdraw the pulley from the old pump, and fit to the new pump using special tool (P0001306). Fit the pulley onto the pump shaft until the pulley boss is flush with the pulley rim. If the special tool is not used, damage may be caused to the pump interlocks.
5. Fit the pump in the reverse order to removal, tensioning the belt as above. Tighten the roller pinion bearing bolt.

4.6 - BOILER RACK ASSEMBLY REMOVAL/REPLACEMENT PROCEDURE

Removal

1. Drive pin in the detent's socket, down the pinchbolt securing the upper flange to the intermediate shaft. Release the fixing bolts securing the upper column to the panel box and separate, and separate the upper air from the column. Release the trailing strand from the floor panel and remove near the intermediate shaft. Remove the pinch bolt securing the lower air to the rack guide shaft and slide off the shaft.
2. Remove both front road wheels, and the track rod end tie rod nuts. Use a ball joint splitter tool to disconnect both track rod end from the steering arm.
3. Remove the engine bay inner frame, and provide alternative support for the lower axle tube from the rail before removing the shaft top mounting bolt.
4. On the 3000 series, disconnect the feed and return pipes (two larger diameter pipes) from the valve body, and collect the fluid. Plug the pipes and ports. Remove the lower of the two valve body to tank mounting plates, and plug the ports.
5. Release the two rack assembly mounts (6 bolts). Withdraw the pinion bearing from the chassis and slide the rack assembly towards the passenger side and then out from beneath.

Replacement

- Fit the rack in the reverse order to removal, noting the following points:
 - On USA cars, fit lower rubber seal (P0000000) over the pinion shaft before fitting the rack assembly. After rack fitment, check that the energy steering aperture is sealed.
 - Tighten rack bearing to chassis bolts to 120 Nm (89 lbf.ft)
 - Fit the lower air onto the pinion shaft with the pinch bolt above a spring, and torque pinch bolt to 75 Nm (55 lbf.ft)
 - On 3000 cars, tighten hydraulic connections on pipe between valve body and rack tube to 14 Nm (10 lbf.ft). Tighten feed (top) (M14) and return (lower, M16) connections to 19 - 20 Nm (14 - 17 lbf.ft)
 - Tighten track rod end to steering arm connections to 50 - 60 Nm (37 - 51 lbf.ft)
 - On 3000 cars, fill and bleed the hydraulic system (see 0101).
 - Adjust front wheel toe-in (see section 02).

REPAIR AND ASSEMBLY OF THE READING CAR

The following steps may be carried out on the reading car assembly with reference to the removal of replacement parts and reassembly and parts list, as given in the Appendix.

Remove the reading pane screens, from the car (see section B-1) by a screw driver (see photo).

- Remove the four screens and frame from the car (see photo).

Remove the two screen bolts to the spring loaded support at the rear of the car (see photo) (see page reference), and remove the slinger assembly.

- Remove the four screen bolts and slinger, remove the four bolts which hold the slinger to the car frame, and remove the plate and slinger. There is a small hole in the slinger which prevents assembly from the front and rear windows of the car (see photo).

Remove the two bolts of the rear tube (see photo) (see page reference) from the car and the track holding the seat (see photo) (see page reference) and the two screen bolts to the rear pane and suspension (see photo) (see page reference) from the car. Remove the end cap of the tube from the rear pane.

- Remove the two end screen supports from the car and mark seat (see photo) (see photo) (see page reference) and the rear pane tube (see photo) (see page reference) and the screen bolts (see photo) (see page reference) and remove them from the car.

Remove the seat (see photo).

Remove the top cap of the seat (see photo) (see page reference) and the seat (see photo) (see page reference) from the car (see photo) (see page reference).

Remove the screen bolts from the car (see photo) (see page reference) and the seat (see photo) (see page reference) from the car (see photo) (see page reference).

Remove the seat and mark seat (see photo) (see page reference) from the car (see photo) (see page reference) and the seat (see photo) (see page reference) from the car (see photo) (see page reference). Remove the seat (see photo) (see page reference) from the car (see photo) (see page reference) and the seat (see photo) (see page reference) from the car (see photo) (see page reference). Remove the seat (see photo) (see page reference) from the car (see photo) (see page reference) and the seat (see photo) (see page reference) from the car (see photo) (see page reference). Remove the seat (see photo) (see page reference) from the car (see photo) (see page reference) and the seat (see photo) (see page reference) from the car (see photo) (see page reference).

Remove the seat (see photo).

Remove the seat (see photo) (see page reference) from the car (see photo) (see page reference) and the seat (see photo) (see page reference) from the car (see photo) (see page reference).

Remove the seat (see photo) (see page reference) from the car (see photo) (see page reference) and the seat (see photo) (see page reference) from the car (see photo) (see page reference).

Remove the seat (see photo) (see page reference) from the car (see photo) (see page reference) and the seat (see photo) (see page reference) from the car (see photo) (see page reference). Remove the seat (see photo) (see page reference) from the car (see photo) (see page reference) and the seat (see photo) (see page reference) from the car (see photo) (see page reference). Remove the seat (see photo) (see page reference) from the car (see photo) (see page reference) and the seat (see photo) (see page reference) from the car (see photo) (see page reference).

Remove the seat (see photo) (see page reference) from the car (see photo) (see page reference) and the seat (see photo) (see page reference) from the car (see photo) (see page reference). Remove the seat (see photo) (see page reference) from the car (see photo) (see page reference) and the seat (see photo) (see page reference) from the car (see photo) (see page reference).



Power Sacks & Pinion
Assembly

For spring plunger
assembly, see
illustration of
sawset, rack & pinion
assembly on page 16



Pinion shaft
shaft nut

Pinion housing top plate

Thrust washer & seal

Defluid swelling rings

O-ring seal



Truck
castrol
rod


Pinion and
rack seal carrier


Back housing

Non-pinion end seal
housing

Rack pinion

Rack tube ring nut





Manual Rack & Pinion Assembly



- Remove the rack gaskets and track pads (see section 10-4).
- Remove the blanking plug adjacent to the pinion housing at the back of the rack, withdraw the rack, and insert a 6.0 mm rod, or special tool T600110, to wedge the gasket in the back of the rack bar. Mark the position of the gasket shell relative to the housing to aid reassembly. Remove the restraining rod.
- Remove the two screws securing the spring loaded plunger at the base of the rack (opposite the pinion housing), and remove the plunger assembly.
- Remove the roller shaft seal and shield. Release the four bolts securing the roller bearing top plate, and remove the plate and shield. Carefully withdraw the roller shaft and top bearing housing, and lay aside.
- Withdraw the rack from the housing.
- Remove the roller bush from the main pinion end of the rack housing, and fit a new bush into position, after first nesting the bush on to the roller bush on the main shaft. Fit a new roller bush on the opposite end.
- Insert the pinion shaft into the housing, and engage the pinion gear teeth with those on the rack as illustrated. Make in operation for an accuracy of gears. Apply a new roller bush equivalent grease into the gap of the pinion housing before fitting the roller support washer, needle roller support bearing, and roller bush to shaft.
- Measure the contact surface between the flange of the roller bearing top surface of the roller bearing and the pinion housing top plate. This should be greater than 0.13 mm, and not over 0.25 mm. Add 0.07 to 0.13 mm to this figure, and apply a new pair of this dimension to fit between the pinion housing and top plate. Dimensions are in millimeters of 0.001, 0.005 and 0.025 mm.
- Apply the oil to the roller bush and grease the top plate and pack and top plate. Tighten up the roller bearing. Torque tighten to 2.5 Nm (1.8 lbf ft).
- Remove the restraining rod and refit the blanking plug, tightening to 2.5 Nm (1.8 lbf ft).
- Grease the roller wheel rollers, shaft and seal with roller grease. Fit over the seal of the roller and press into position bearing a 1.0 mm gap between the roller wheels and the roller bearing top plate.
- Fit the pinion plunger assembly into the rear of the rack housing with the restraining rod, and torque tighten the fixing screws to 2.5 Nm (1.8 lbf ft). Check the adjustment of the plunger. Scan the rack mechanism, remove the roller, and check the adjustment with a dial indicator. Adjust the roller to suit the roller bearing. The roller should be 0.13 mm (0.005 in) from the pinion shaft, or remove or substitute a different roller if found. If it is necessary to check the roller




more than 1/8th of a turn to adjust plus, the rack teeth are badly worn, and the complete assembly should be replaced. Hold the output in place and tighten the nut on the 1/2" Bore (22 lbs/ft²).

- a. Refit the rack and pinion and rack seal (see section 20.4).
- b. Refit the steering rack assembly to the car (see section 20.5).

TRADESSECTION 11 - ELEM

	<u>Administrative</u>	<u>Total</u>
Police Officer	28.1	3
Police Nurse Aid Replacement	28.1	1
Police Nurse Aid Replacement	28.3	1
Police Trade Mechanic	28.3	1
Police Dispatcher Overhaul	28.5	4
Police Officer Understudy	28.6	21
Police Driver	28.7	12
Police Patrol Unit	28.8	15
Police Cyclist	28.9	11
Inspector Training Vehicle	28.10	12





1.1 - MANUAL OPERATION

The brake system comprises a tandem master cylinder and direct acting master/slave dual operating single piston sliding calipers for each wheel, with self-adjusting and self-rear drums.

The hydraulic circuit is diagonally split (LH front/RH rear), and RH front/LH rear for independent operation from the separate compartments of the tandem master cylinder, with separate hydraulic lines feeding each caliper. A brake pump to project a set valve is line operated into each of the rear brake lines at 2000 rpm to raise brake line pressure under heavy braking, and inhibit the self-adjust of rear wheel lock-up. A ring divided reservoir serves both compartments of the tandem master cylinder, and is provided with a low fluid level warning system, which operates a beeper mounted bell tube lamp.

Brake fluid reservoir
(right hand drive)



Brake fluid reservoir
(left hand drive)



Single piston sliding calipers are used at each wheel. The caliper body is supported on two hardened steel sleeves, which allow the caliper free lateral movement. When the brakes are applied, hydraulic pressure in the caliper cylinder, forces the piston outwards and the caliper body inwards, resulting in the brake pads being clamped to the disc, producing the required friction.

The parking brake lever operates, via a compensating link (to equalize the pull applied to each wheel), to two cables, one leading to each rear caliper. Each cable operates a lever on the caliper which turns an actuating screw against the disc, inside the self-park cylinder, forcing the piston against the pad and thus applying the brake. A self-adjustment mechanism within the cylinder, takes the form of a spring clutch wrapped around the piston 'rod' in which the parking brake actuator screw operates. On application, the one-way spring clutch locks the nut to the piston, so that the piston is forced to move axially when the actuating screw is turned. On release, a 'piston retractor' outboard of the piston cylinder, usually, wants sufficient grip on the piston to prevent it being drawn back by the mechanism. This compels the spring clutch to release the nut, so that the actuator screw is not held at one end, as the screw returns to its start position. This results in any free play being automatically taken up, with the self-adjusting screw a position further along the thread the next time the parking brake is applied, operating the spring hydraulically, via the footbrake, but a similar effect, with the piston moving outwards and the nut being allowed to turn outwards by the hand clutch. This automatically equalizes the parking brake mechanism ready for the next application.




7. FRONT BRAKE PAD REPLACEMENT

Pad thickness may be checked without disassembly of the pads:
 Standard pad thickness = 15.7 mm to 9.13 mm
 Minimum pad thickness = 7.0 mm (0.60 inch)

1. Remove front pads

1. Remove pads. If wear, both pads are to be replaced with new. Rotate brake third from the master cylinder clockwise to check if pressure applied and stored fully.
2. Remove the old pads. Pull out and hammer to knock out the toe pad remaining in the caliper from inside to outside. Remove the wire spring from each pad.
3. Withdraw brake rail from caliper, rotate and tap to remove the outboard pad. Push the inboard pad away, and withdraw the inboard pad.



4. The pads in caliper. The pistons must be pushed fully back into the bore to provide clearance in the caliper for the new pads. Use compressed air to blow clean.
5. Clean. Clean the brake pad recess in the caliper, using a vacuum brush to remove any dirt.

WARNING: Inhalation of brake dust can be avoided if possible. Never use an air hose to blow away dust from around any brake assembly.


Inspect the condition of the pistons, and replace if necessary (see below).

6. Check Piston. Before fitting new brake pads, always check the thickness, surface condition and number of the brake discs. See section III.7.

Fit Under Frame that the piston is pushed fully back into the bore before attempting to fit new pads. Fit the inboard pad into position before pulling the caliper inboard and fitting the outboard pad.



1. For the first roll pin, insert the spring pins through the caliper body holes and into the splines, with the pins on the pin backplate so that it forms the retaining pin. Use only a brass drift to adjust the pins, as a steel drift may damage the ends of the pins and cause them to become extremely difficult to insert.
2. For the second roll pin, fit the retaining pin through the outboard half of the wheel drum, before fitting the two pin retainers with spring clips - fit one end of the spring onto the spring pin, press the pin down, lock the retainer to the spring over the pad backplate, and push the other end of the spring into the second pin hole as inserted. Repeat for the second spring and fit a pin to lock the spring pin with the brass drift. Check that the two springs are fitted centrally on the pad backplate, with each end of the springs projecting beneath the pins an equal amount.



Inserting second roll pin while pushing down spring clip

3. Fluid Level: Top up the master cylinder reservoir to the full level, and pump the brake pedal several times to restore working pad position. Recheck reservoir level.

JE 2 - REAR BRAKE PAD REPLACEMENT

Pad thickness may be checked without disturbing the caliper.
 Standard pad thickness = 10.3 mm (0.41 in).
 Minimum pad thickness = 1 mm (0.04 in).


To Replace Rear Pads:

Tools required: Axicon Stubbar 200020688


1. Marking Brake Cables: Release the parking brake cable from the caliper (over the top), if necessary slackening the cable adjuster on the trolley top.



- Withdraw caliper. Remove the two caliper mounting bolts, and withdraw the caliper from the disc, taking great care not to damage the sliding pin mount. Do not stretch the flexible brake hose.
- Remove the pad. Use a screwdriver to disengage the ballpins on the surface of the inboard pad, then use a hole in the caliper housing, and withdraw the outboard pad with the inboard retaining clip.



- Remove Inboard Pad. Bend the inside edge of the piston rod out from its retaining clip, and then withdraw the pad from the disc and caliper.
- Remove Check Valve. Use a small screwdriver to pry out the two-way check valve from the piston. If there is any sign of fluid leakage from the piston hole when removal of the check valve, the caliper should be overhauled as detailed in this manual, the condition of the piston, boot, and master case shall, if necessary, be noted.
- Set the Piston. Before new pads can be fitted, it is necessary to fully return the piston to its back. If necessary, syphon fluid from the master cylinder reservoir to re-charge for the fluid retained from the caliper. Use tool 27007000 to engage in the slots on the piston, and push the piston:
 - Inwards by 1/8" (approx); and
 - Downward against the 80° angle;Push the piston back down the parking brake mechanism, whilst pressing the boot up down the bore.
- Fit a New Check Valve. Replace a new check valve with clean brake fluid, and fit into the piston hole.
- Fit Inboard Pad. Check that the piston is correctly orientated - the face of the piston facing back to the piston should be radial and tangential. If the piston is necessary, check when the inboard retaining clip is fully seated in its groove on the end of the piston.



Slide the outside edge of the pad receptacle into the retaining clip. Remove pressure from the pad by moving the piston to expose the clips on the inside edge of the backplate. Check that the pad does not expand the piston. With the pressure on the pad receptacle secured with the clips in the piston.


4. 7. Reinsert pads: Press the pad into position, so that the ridges on the pad receptacle engage with the holes in the thinner backing strip, with the pad retained by the two tops of the clip.
10. Re-fit calipers: Carefully engage the sliding pin boots (see figure) with the detent, and replace if necessary (see IE 5). Position the caliper over the brake drum, taking care not to damage the sliding pin boots and not to fit the caliper retaining nut. Torque tighten the bolts to 30 - 110 lb ft (40 - 148 N m).
11. Parking Brake Lever: Fit the parking brake lever to the Mounting bracket and caliper lever arm, and if necessary, re-adjust nuts as detailed to IE 1.
12. Top up the master cylinder reservoir (if it is full level), and pump the brake pedal, hard, several times to restore working pad position. Remove reservoir level. Check parking brake operation.

10.4. PARKING BRAKE MECHANISM

It is important, in the self-adjusting mechanism as to function correctly, that the caliper levers are fully back against their stop brackets when the parking brake is set.

10.4.1 test:

1. Ensure that the pads are at their working position, by applying hard pressure to the footbrake pedal several times.
2. At each caliper, check that the parking brake lever is fully against its 'off' stop bracket, and check that when the parking brake is applied and released, the caliper levers return immediately, and are not delayed by excess friction in the slides or linkage. Rectify as necessary.




Part of the tunnel top adjuster may be seen attached to the parking brake cable adjuster at their contact point. Adjust the adjuster to prevent the slack from being drawn, but ensure that the caliper levers are still in contact with the stop.

4. Operate the parking brake several times to allow the automatic adjuster within the caliper to take up any excess clearance, and ensure that the parking brake lever operates in more than 7 clicks when fully applied.
5. Reset the tunnel top hose.

Wiring Replacement:

Remove the tunnel top first to gain access to the short end of the cables:





- 2) Insert the filler panel (see between the rear of the centre tunnel to side and the rear wall, by reinserting the wedge retaining screw.
- 3) Pull out and disconnect the mirror control switch, to the rear of the seat base.
- 4) Pull out and disconnect the two window switches, each side of the passenger door lever, and release the two window front fixing screws via the panel apertures.
- 5) Pull out the edgemat's tray from the rear of the tunnel top, and release the two window rear fixings via the tray apertures. Tilt the console to the rear to disengage the hinges from the rear fascia, and then lift the console over the parking brake lever.

On the front end of each cable is fitted with an eye which hooks into the cable fixing link which is itself connected by a short link to the parking brake lever. Both of the cables are used to ensure the eye to be attached from the cable bracket, and position the cable indicator from the abstract bracket. Unhook the cable at the caliper lever, and separate from the cable abstract end retaining clip on the rear suspension top link. Withdraw the cable through the body with attention.

Complete the removal procedure to install a cable, and adjust as detailed above.

Parking Brake Lever

The parking brake lever incorporates a pair of cables which extend from the rear of the handrail to the end of the handrail. If the pair is correct both cables are usually set, they should be replaced as a pair.

To remove the parking brake lever, release the screws securing the lid to the console in places, remove the screws retaining the handrail plate, and release the lever pivot bolt. Withdraw the lever assembly over the mounting bracket. The rubber bag bracket is removed at the chassis control section by four screws with washers.


FRONT CALIPER BUSHING

Part program 27 4 by pin tool/cup unloader T0007090

- 1) Remove Brake Lever See section above.

Hold disc end of the brake hose clamp before releasing the hand rail, securing the disc end to the caliper. Remove the bleeders valve Seal the tube and caliper openings to prevent fluid loss and dirt ingress.


- 2) Remove bolt. The caliper is removed via the two sliding sleeves, each of which is secured by a socket head bolt concealed by a protective cap over the end of the sleeve. Remove the cap, and remove the two socket head bolts. Withdraw the caliper to a clear 150°. Do NOT disturb the two bolts securing the two halves of the caliper body together.
- 3) Sliding Sleeves: Remove all the bolts, and push the two sliding sleeves from the caliper bracket. Carefully examine the rubber boots for rips, cracks or too tightness and the seals, and sleeves for any signs of corrosion. Replace any faulty parts as necessary.



Push a thin metal rod the piston that has been in the caliper housing, and push it from the inside of the piston. Insert a 15 mm thick piece of hardboard covered in soap foam into the housing cap, and eject the piston into the cone of hydraulic compressed air to the hydraulic connection.

WARNING: KEEP FINGERS WELL AWAY during this operation.

1. Piston Seal: Remove the piston seal from the slide shoe groove using a plastic rod. Do not use a metal rod, as the shoulder wall of the seal groove may become scratched.





1. **Clean:** Clean all parts in diesel fuel or solvent, and dry with undiluted compressed air. Inspected area for any damage (rubber hose separation). Blow out all the passages in the caliper housing and bleeder valve.
2. **Inspect:** Inspect the following components:
 - Piston pin and bush groove for scoring, marks, corrosion or visible wear.
 - Piston for scoring, marks, corrosion or damaged chrome plating.
 - Caliper ledge for any signs of scoring.If any light corrosion cannot be polished out using medium grit, or if any other faults are found, the components must be replaced.
3. **Viscous Seal:** Lubricate a new piston seal with clean brake fluid, and fit into the cylinder groove, taking care it is not twisted.
4. **Piston and Bush:** Fit a new piston seal lubricated with the rubber grease supplied in the repair kit, into the groove on the piston, as shown in the diagram. Lubricate the piston with clean brake fluid, and insert into the cylinder, pushing to the bottom of the bore.
See the note in the caliper mounting instructions using a suitable press tool and any trapped air escape may sound the alert, by sealing the hole away from the piston (preventing a possible leak).
5. **Sliding Sleeves:** Apply a thin coat of the special grease provided in the repair kit, to the surface of the sleeves. Fit the new rings into their grooves in the bore of the cylinder, ensuring that the seals are not twisted.
Slide the sleeves into their caliper slots from the left side, leaving the boot greased accessible. Apply some of the grease to the top of each dust boot, and fit into the sleeve groove. Press the boot closer into position in the housing using a suitable tool.
6. **Set Caliper:** Fit the caliper over the brake disc. **CAUTION** - Do not exert force on the sliding pin bolts when fitting the caliper. Fit the two caliper mounting bolts using a thread locking compound (e.g. Loctite). Torque bolts to 40 - 45 Nm (30 - 33 lbf.ft.). Fit the protective caps to the ends of the sliding pins using special tool TH0000000.
7. **Flexible Hose:** Fit the flexible hose to the caliper using one or several copper washers, and torque tighten to 25 Nm (18 lbf.ft.). Fit the bleed nipple and torque to 7 - 10 Nm (5 - 7 lbf.ft.).
8. **Brake Pad & Bleeding:** Refit the brake pads as detailed in 1F.2. Remove the brake hose clamp, and bleed the brake system to expel all air.


2F.4 - BRAKE CALIPER OVERHAUL

Tools Required: Piston Locator Installer 100010093
Ratchet Wrench 100000008


1. **Hydraulic Hose:** Fit a brake hose clamp before releasing the brake belt, securing the flexible hose to the caliper. Remove the bleeder valve. Seal the hose and caliper openings to prevent fluid loss and dirt ingress.
2. **Set pin & Bush:** Remove the caliper and brake pads (see 1F.3).



1. Pull the sleeve back off the bolts, and push the two sliding pieces from the oil pan bracket. Carefully measure the sliding pieces for size, make an impression on the flat side, and check for any signs of corrosion. Replace any faulty parts as needed.



1. Remove Piston: Remove the retaining nut, and pull off the packing sleeve lever. Lift cover seal and nut. Thrust washer. Use a spanner to turn the seal into place in the base, apply dimensions, and so push the piston out of the cylinder. Use clean rags or shop towels to protect the piston during this operation, and remove the pad retaining clip from the piston if that has not already been done.
2. Remove Screw: Remove the balance spring from inside the cylinder, and give out the activator screw. Remove the screw thrust washer, and the skirt seal.
3. Piston Nut: Loosen the piston nut, taking care not to scratch the cylinder bore.
4. Piston Locking & Seal: Remove the locknut, and pull off the piston locknut. Use a scraper tool to remove the piston seal from the groove in the cylinder, in order to prevent oil from the cylinder wall or groove.




- 1. Dust bank
- 2. Piston
- 3. Caliper housing
- 4. Circlip
- 5. Piston locator
- 6. Piston seal

- 7. Inspect: Carefully inspect the cylinder wall and groove, and piston surface for any signs of:
 - scuffing
 - cracks
 - corrosion
 - visible wear or damage to chrome plating
 If any light corrosion can not be polished out using steel's cloth, or if any other faults are found, the components will be replaced.
- 8. Throttle Cable: With cable disconnected, disassemble bracket, and lay with unlubricated compressed air (cleaned) to stop any raw damage rubber brake components from rot at the passages in the caliper housing and bleeder valve.
- 9. Adjuster Bracket: If necessary, remove the parking brake cable adjuster bracket. When re-fitting, torque tighten the circlip fixing screw to 15 - 18 Nm (11 - 13 lbf.ft).
- 10. Piston Seal: Lubricate a new piston seal with clean brake fluid, and carefully fit into the groove in the cylinder wall. Ensure the seal is not twisted.
- 11. Piston Locator: Lubricate a new piston locator, and fit onto the piston using the allen key 10070987.
- 12. Retainer Screw: Fit the thrust washer onto the adjuster screw, with the copper side of the washer towards the piston and the drypack side towards the caliper housing. Tighten the shaft seal and fit onto the adjuster screw groove. Fit the screw fully into the piston.
- 13. Piston: Lubricate the cylinder area. Fit the balance timing onto the end of the piston, and insert the piston with wetted screw into the cylinder. Push the piston into the bore until the locator is past the dustlip groove. Fit the retainer to the top using circlip pliers.
- 14. The lubricated piston head into the groove on the end of the basket, before pressing the piston to the bottom of the bore.
- 15. Lower Arm: Fit the lubricated new friction washer near the end of the adjuster screw, followed by the lubricated curve seal with the sealing bead towards the caliper body. Fit the lower arm in the correct orientation (between the cable adjuster and ball stop) and retain with the bolt. Tighten the lower adjuster nut to 40 - 55 Nm (30 - 40 lbf.ft) Fit the lower return spring.



11. Rotate the piston. Seat the piston feet in the main groove on the cylinder using a wooden block.
12. Using a sleeve, the adjusting nut, and the adjusting screw to increase the distance between the sliding sleeves and corresponding surfaces in the cylinder (see Figure 28-10). Turn the adjusting nut until the four sleeves contact each sliding pin of the adjusting screw. **CAUTION:** Do not turn these nuts that much!


- Do not turn the adjusting nuts in the cylinder and slide the pins of them to the opposite ends of the cylinder until pushing through the seal inside at once.



- Fit the adjusting seal onto the cylinder sleeve.



- Push the pin back through the adjusted hole and locate the adjusting diameter of both holes in their groove on the sliding pin.



13. Fit Check Valve: Turn back a new sleeve valve with 10 or 15 psi (1.4), and fit into the piston foot.
14. Fit Spring Pin: Check that the spring pin correctly adjusted in the axis of the spring stepped pin in the piston should be radial and vertical. Turn the piston to perspective. Check also that the seal retaining clip is fully located in the groove to the end of the piston.
Remove the outside edge of the non-ferrous into the adjusting clip. Before putting the pin into, witness the nut in to ensure the clips on the inside side of the adjustment. Check that the pin fits flat against the piston. Set the buttons of the pad complete engaged with the slot in the piston.
15. Fit Adjusted Pin: Press the pin into position, so that the burr of the pin backplate engage with the hole in the cylinder housing, with the pin retained by the two legs of the nut.



21. Refill caliper. Rotate it 1/2 circle over the brake disc, taking care not to damage the sliding pin boots, and refill the 25 cc caliper return hose bolts. Torque tighten the bolts to 90 - 120 Nm (66 - 90 lbf ft).
 22. Locking Brake Lever. Reconnect the parking brake cable to the bracket, bracket and lever arm.
 23. Bleeding hose. Put the flexible hose to the caliper using hose or a sealed rubber wrench. Add torque tighten to 40 Nm (30 lbf ft). Fit the bleed nipple on the hose. Torque = 24 Nm (18 - 20 lbf ft).
 24. Bleeding. Open the master cylinder reservoir. Operate the parking brake several times to attain the correct brake pad position (until parking brake lever lock). Finally, remove the brake hose clamp before bleeding the system. Bleed all air.
- Test operation of footbrake and parking brake.

7.7 - BRAKE DISC

Check the braking surface of both sides of the brake discs for scoring or corrosion. Measure if in doubt.
Measure the disc thickness and remove:

	Front	Rear
Thickness, original	24.2 mm (0.95 in.)	22.1 mm (0.87 in.)
Minimum permitted thickness	23.0 mm (0.91 in.)	21.5 mm (0.85 in.)
Min run thickness (wear limit)	22.3 mm (0.87 in.)	20.9 mm (0.82 in.)
Min run min psi, maximum	2.13 mm (0.084 in.)	0.19 mm (0.008 in.)
Min run min psi, removed	2.01 mm (0.081 in.)	0.08 mm (0.003 in.)

NOTE: Ensure the rear wheel bearings are correctly adjusted before measuring rear disc run-out.

If the run-out is excessive, replace the disc.

7.8 - BRAKE SERVO UNIT

The brake vacuum servo is a non-serviceable sealed unit which if found to be faulty, must be replaced as a unit, complete with the vacuum non-return valve fitted into the vacuum line between servo unit and intake plenum chamber.

As a quick check of servo operation proceed as follows. With engine stopped, press the brake pedal several times to exhaust the servo unit of vacuum. Keeping the pedal pressed (which should be 'hard' and 'high'), start the engine; the pedal should drop slightly as the servo vacuum builds up, and when force is produced. If the pedal does not drop, it is most likely that there is a fault in the vacuum supply line. Check the vacuum hose, connections and non-return valve. If the vacuum supply is not defective, the servo unit should be replaced.

It is essential that the servo plunger is allowed to return fully when the brakes are released, and is not pre-loaded by pedal adjustment of the input pushrod. Check that there is a small amount of free play at the pushrod when the brake pedal is released.

7.9 - Servo Seize Unit

The servo unit, if diagnosed as being faulty, must be withdrawn together with the pedal, say, towards the inside of the car.



- Control Console: Remove the control console and instrument panel (see section 9).
- Locker: Remove the locker wheel (see section 9).
- Steering Column: Remove the steering column (see section 9).
- Transaxle Cable: Fill up the control cable, and unhook the cable from the transaxle pedal.
- Clutch Pedal: Pull down the clutch release lever of the transmission, and unhook the cable from the clutch pedal.
- Mount Hanger: Disconnect the mount hanger bolt from the rear base of the pedal box. Release the cable hanger retaining the rear hanger on the carrier duct, so just the front of the pedal box, and push the hanger out of the duct. Unmount the brake light switch.
- Master Cylinder: Release the two nuts securing the master cylinder to the servo. Leave the hydraulic system undisturbed.
- Frame: Disconnect the brake servo hose.
- Ball Joint: Release the ball joint from the engine side of the front hubknob, separating the pedal box, and withdraw the pedal box completely with screws into the duct's footwell.

Servo outboard fixings
viewed from wheel side



Servo inboard fixings
viewed from engine bay




- Servo: Disconnect the servo pushed from the pedal, release the four nuts securing the servo to the pedal box, and withdraw the servo unit.

To separate servo unit

Follow the removal procedure to replace the servo, using the following points:



- Torque: Tighten master cylinder nuts to 20.0 N.m (14.3 lbf.ft).
- Torque: Torque upper nut of the slave (free play when brake is off).
- Apply a 30mm length of self adhesive foam strip (ALDUBG114V) around the body of the master unit, adjoining with the new edge. Position the joint at the center top.
- Apply a ring of "Sealstrip" (ALDUBG114) on the pedal box around each of the pedal foot fixing holes, to seal the pedal box to the bulkhead.
- Torque: Tighten pedal foot fixing bolts to 20.0 N.m (14.3 lbf.ft).




4.9 - MASTER CYLINDERS

The brake master cylinder is a non-permeable sealed assembly, which must be replaced as a complete unit if found to be faulty.

To Replace Master Cylinder:

- Before removing the master cylinder, siphon out or mark brake fluid as peroxide from the reservoir to reduce the threat of spillage.
- Disconnect the low fluid tell tale harness from the reservoir cap.
- Disconnect the three brake pipes from the master cylinder ports, and plug the pipes and ports to reduce spillage and prevent dirt ingress.
- Remove the two nuts securing the master cylinder to the brace wires, and withdraw the master cylinder.

Refit the master cylinder in the reverse order to that given, refill with brake fluid, and bleed the complete system in the correct manner.



Torque 4 pins master cylinder to axle (axles to 10 - 35 Nm (10 - 14 lbf ft))

- Torque tighten brake pipes to axle cylinders to 10 - 30 Nm (7.5 - 22 lbf ft)

12.3.3 - PRESSURE LIMITING & PROPORTIONING VALVES

A pressure proportioning valve is fitted into each of the rear brake circuits. It tends to control the rear brake pressure under severe braking, and reduce any tendency for the rear wheels to lock before the front. Severe rear skid, is reduced in and connected in series with each proportioning valve, either a pressure limiting valve, or a second pump (locking) valve in order to obtain the desired pressure rise characteristics. Thus the three variations to be borne are:

- Pressure limiting valve (70 or 65 bar); - Proportioning Valve (15 bar)



The limiting valves are fitted upstream of the proportioning valves, and are set at either 70 bar, or at 65 bar max, 65 bar. This figure is stamped on the valve end plate. It brake line pressure below the valve calibration, the valve is open, and allows unrestricted flow of brake fluid from the master cylinder to the proportioning valve. When the output pressure from the master cylinder rises fast and level reaches the limiting valve calibration pressure, the valve closes, and allows no further increase in pressure to the rear brake circuit. The valve opens again when supply pressure drops below 70 or 65 bar.

The proportioning valves are designated 1/15, which indicates:

- up to the break point of 15 bar, the pressure in each rear brake circuit is the same as that in the front circuit.
- as the front circuit pressure increases from 15 bar to 65 or 70 bar (see above), the corresponding increase in rear circuit pressure is in the ratio of 1/15.



145





If any problems are experienced with the existing valves or 3/15 proportioning valves, it is recommended to discard all four valves and fit the 3/15 proportioning valves as described in (122).



3/15 Proportioning Valve (10/15) & 3/15 Proportioning Valve (10/15)

The 3/15 proportioning valves are the same as those in 11, above, and operate in the same way. The 10/15 valves are fitted downstream of the 3/15 valves, and have effect only when input pressure exceeds 10 bar. Thereafter, the response to input pressure is 10% of the increase in input pressure.







If any problems are experienced with the 70/1 or 3.15 proportioning valve, it is recommended to distast NJ to a valve and fit the 2015 proportioning valve as described in (111).

(12) Proportioning Valve (2015)

These cars use a single proportioning valve (2015) in each rear circuit, and this is the preferred arrangement to be adopted should any problems be encountered with either of the previous two systems. These valves have no effect until input pressure exceeds 15 bar, after which the increase in output pressure is 2/3 of the increase in input pressure.






In fitting the 2712 valves in place of either of the systems described in the manual, the following parts will be required:

Shut-off valve, 1/2" NPT	D100760157	1 each
Break Pipe, prop. size, 1/2" NPT, 18"	A100760027	1 each
Break Pipe, prop. size, 1/2" NPT, 36"	A100760017	1 each

Operation of Proportioning Valve

The following description applies to a T-115 proportioning valve, but the principle is similar for the 2712 valve.

The valve consists of an modified aluminum body containing a split loaded piston through the center of which the brake fluid flows from the front to the rear outlet. A small diameter pressure chamber at the front end of the piston is connected to the front brake line, and includes a shut-off valve. A larger diameter pressure chamber at the rear end of the piston is connected to the rear brake circuit.



At brake line pressure below 15 bar, the proportioning valve is open, and fluid flows through the unit freely to provide equal front and rear brake line pressures.

The piston is spring loaded towards the outlet end. Yet the hydraulic force on the piston from the large diameter outlet (rear) side, is greater than that from the open chamber at the inlet end. At a pressure of 15 bar, the difference in hydraulic force is equal to the force on the piston from the spring, with the result that the piston starts to move towards the inlet end of the valve, closing the valve as it does so.

As front brake pressure is increased beyond 15 bar, the valve will open only sufficiently to allow the pressure at the outlet side to increase by 50% of this value, since this is all that is required for the larger diameter outlet and pressure chamber to close the valve and maintain the pressure balance.

The reverse logic applies as the brake pressure is reduced, with the valve opening to allow the rear pressure to fall at a rate of 50% of the front pressure reduction until the break point at 15 bar. When the piston spring overcomes the pressure differential, and the valve stops open, equalizing front and rear pressures.



Valve Servicing

NO SERVICING OF THE PRESSURE LIMITING OR PROPORTIONING VALVES IS PERMITTED. A car attempt to disassemble or repair a limiting or proportioning valve. The 275 and 277 proportioning valves incorporate a mounting bracket which should not be disturbed. If a proportioning valve is found to leak brake fluid, or if the performance test indicates a faulty unit, BOTH PROPORTIONING VALVES SHOULD BE **REMOVED AS A PAIR**. If an early type 4-wheel system is fitted, and found to be faulty, it is recommended that all four valves be inspected and a pair of the same type 4-wheel proportioning valves are fitted as described above.


Both right and left hand 275 proportioning valves assemblies are identical, and due to the spray coating bearing parts, names are fitted and connected on the wrong any point without considerable modification to the brake pipes. The full part code of the valve should be to the rear.

Torque tighten brake pipe connections to 15 Nm (11.02 lbf ft).

Performance Test

Tools required: Test gauge 00000000

1. Refer to the test order for the customer's instructions, remove the wheel nipple from one of the rear calipers, and connect the test gauge adapter to the caliper.
2. Connect the other test gauge pipe to the pressure by opposite front brake caliper wheel nipple port.
3. After bleeding the system, operate the brakes to achieve the front brake line pressure in the following order, and raise the corresponding rear brake line pressure. Do not exceed a front brake pressure of 100 bar.




Front Pressure (bar)	Rear Pressure (bar)			
	70 bar limited (= 2/3 proportion)	65 bar limited (= 1/2 proportion)	70:1 proportion (= 3/15 proportion)	7:3 proportion
0	5	5	5	5
10	27.0 - 27.5	27.0 - 27.5	11.0 - 21.0	15.4 - 20.0
20	28.0 - 29.0	26.7 - 27.5	20.0 - 26.0	26.5 - 27.5

1. If the rear pressure is out of tolerance at any of the test points, comparison of the pressure rise characteristic with the graph above for the system fitted (see above), should indicate the probable faulty component.
2. Repeat the test on the opposite circuit.
3. Remove test gauge, cut off bleed nipple and fitted brakes.

COOLING SYSTEMSECTION KD - PLAN

	<u>Subtopic</u>	<u>Page</u>
General Description	KD.1	3
Water Circuits	KD.2	5
Manufacturer's Procedures	KD.3	9
Radiator Fans & Controls	KD.4	11
Engine Cooling Fans	CD.5	14
Diagnosis of Radiator	KD.6	16
Oil Cooler Radiator	KD.7	17



**8.1 - GENERAL DESCRIPTION****Cooling System**

A centrifugal water pump is mounted on the front face of the cylinder block, and is driven by the toothed camshaft drive belt. Coolant is pumped by the impeller into the front of the block, around the cylinders, up into the cylinder head, and finally out of the back of the head (left hand end of engine), into the thermostat housing. When the thermostat is closed, water flow bypasses the radiator via a by-pass pipe which runs along the floor ribs of the engine to an inlet spout at the left hand front of the block. In order for water on the engine side of the closed thermostat to reach the by-pass pipe, it must flow via one of three routes:


- The heater matrix (if the water valve is open)
- The primary thermostat body water jacket
- The turbocharger water jacket



When the thermostat opens, a lesser volume of coolant will flow through these circuits, with the main flow passing through the thermostat into the radiator inlet hose, radiator, outlet hose, and finally back into the water pump via the inlet spout at the left hand front of the block.

A header tank is fitted at the left hand rear of the engine bay, and is connected into the radiator bottom hose, with an air bleed hose connecting the top of the tank with the top of the thermostat housing outlet spout. The tank is fitted with a 1.03 MPa (14.7 lb/in²) pressure cap to raise the boiling point of the coolant to 113°C.

The radiator comprises an aluminium core sandwiched between plastic end tanks, and is flexibly mounted in a support frame by two spigots at the top, and one at the bottom. Two electric cooling fans are mounted on the rear of the radiator, and are controlled by a thermal switch in the thermostat housing outlet spout. The sensor for the water temperature gauge is fitted into the thermostat housing.

In extreme conditions of heat soak, in order to control water temperature when switching off the engine, an electric pump is used to maintain coolant circulation until the temperature drops to a safe level. The centrifugal pump is mounted at the front of the engine bay, and is connected between the radiator outlet hose, and the heater feed hose between the thermostat housing and the water valve. The pump is controlled by the radiator fans thermal switch, and operates only when the ignition is switched OFF. With ignition off and thermal switch closed (above 110°C), the pump will run until coolant temperature falls sufficiently for the thermal switch to open (approx 103°C). The electric pump operates to pump cool water from the heater hose into the cylinder head via the thermostat housing, i.e. in the reverse direction to normal coolant flow.







Oil Cooling System

A sandwich plate fitted between the oil filter canister and the rear side of the cylinder block, and the block, diverts the pressurized oil supply from the oil filter output, via a steel pipe and high pressure hose, to an oil cooler radiator mounted in a separate duct to the right of the engine cooling radiator. Oil returns from the radiator via a hose and steel pipe to the sandwich plate, and then flows through the oil filter and into the engine.

Charge Air Cooling System

Turbocharged models use an air/air heat exchanger (chargecooler) to reduce the temperature and increase the density of air leaving the turbocharger compressor, before it enters the intake plenum chamber. The chargecooler is constructed of stainless steel and is located in a separate duct to the left of the engine cooling radiator. It is connected by an inlet hose to the turbocharger compressor outlet, and uses an aluminium pipe routed through the left hand wheelcut to connect with the intake plenum tube.

EO 7 - WATERBURY


Under normal operating conditions, the engine cooling system, being a closed circuit, should not require any topping up between services. As a precaution however, being used, the level of coolant in the engine cooling header tank should be checked. The transparent header tank is marked with a cold level indicator. The level of coolant will rise as the engine warms up and the coolant expands, and will fall again as it cools down.




WARNING: Do NOT remove the cap from the engine cooling header tank when the engine is warm, as serious scalding could result from boiling water and/or steam.



the radiator again. Turn up the Leader Valve to the ALL Indicator level, and fit the pressure cap.



USA type radiator drain plug




Non-USA type air bleed plug

Fig. 1 RADIATOR PANS AND CONTROL

Two cooling fan cooling pans are mounted on the rear of the radiator, and draw in air from the radiator fan duct to cool.

Fan Control

A thermal switch fitted in the thermostat housing (H.R.) or outlet spout (H.C.), is used to control the radiator fans (and starting coolant pump). This switch should not be confused with two other switches in the thermostat housing body, one for the engine management ECM, and one for the water temperature gauge. The rad. fan thermal switch senses the temperature of engine coolant, and operates the cooling fans when a temperature of 170°F is reached. The fan use





switched off when ambient temperature has dropped to 100°F (approx.). The fans are also controlled by a pressure switch in the A/C system recommended to suit the condenser.


WARNING: Be aware that the cooling fans may run any time that the engine is switched on, dependent on ambient temperature and air pressure. Keep fingers, hair, tools etc. well clear at all times.

RE.5 - ENGINE COOLING RADIATOR

Removal on non-USA cars:


1. Remove the radiator underpanel and drain the cooling system (see RE.4).
2. Disconnect the top and bottom radiator hoses.
 - a. Release the top lower fixings from each of the two fan shrouds, and unplug the water hose joining pipe from the radiator support frame.
 - b. Disconnect the single fitting securing the fan shroud seal to each side of the radiator support frame.
3. Release the bottom seal ahead of the bottom fan shroud fixings.
4. Release the upper fixings securing the radiator to the engine block, engine interframe, and disconnect the supply and return hoses from the radiator. Then remove the radiator from the engine bay (see Fig. 8).

Support frame to front frame linkage





non-USA type radiator fixings




1. Carefully pull the support frame off the radiator lower spigots by pushing upwards on the radiator and underframe (if fitted) spigots as the frame is pulled downwards.
2. Carefully withdraw the radiator top two spigots from their grooves in the front frame.

Removal of USA type:

The basic general procedure is the same for the non-USA type, except that the support frame and fixings are different. To remove the support frame, remove the three nuts/bolts securing the frame to the front of the engine bay underframe, and remove the nut from the lower end of the tie rod at each side of the radiator.

Refitting:

Before refitting the radiator, on domestic/export cars, check that the two lengths of sealing foam are fitted to the radiator top channel, and on USA cars that the sealing strip is fitted to the underside of the chassis front cross.



Raise the radiator into position and fit the two top spigots into their grommets. Fit the radiator support frame engaging the lower spigots on the radiator and condenser (if fitted) into the reverse order to removal. On USA cars, fit some 10 ft x 1/2 plain washer at each end of the tie rod spacer tube, and underneath the nut. Fit the protective cap on the bottom end of the two tie rods.

After fitting, refill the system with a recommended coolant mix.

NOTE - CHARGECOOLER REPAIR:

The electric chargecooler radiator is constructed from aluminium, with plastic end tanks, and is mounted in a composite duct to the left of the engine cooling radiator. The duct is secured to the chassis front frame or longitudinal, and also carries the engine intake air spout.

Chargecooler Removal


1. Remove the left hand front wheel and liner.
2. Release the chargecooler inlet and outlet hose connections.
3. Release the electrical fan hanging links.
4. Via the access hole in the front spoiler underside, remove the four M6 screws securing the chargecooler to the duct. Note that on certain cars, it is necessary to release the chargecooler inboard end mounting plate from the duct. Carefully withdraw the radiator from the duct.

Before refitting the chargecooler, check that the foam sealing strip is fitted around the aperture.



Non-USA Type Chargecooler Unit Removal

1. Remove the left hand front wheel arch liner.
2. Remove the front bumper (see section 8K.1).
3. Release the chargecooler inlet and outlet connections, and the bracketing to the air intake spout.



1. Remove the three M6 fixings securing the duct to the chassis front frame - two on the side of the frame, and one on the front underside. Withdraw the duct complete with chargecooler.

On re-assembly, check that the foam strip is fitted around the outside corner of the duct to seal against the bumper. A strip of HRL card, an orifice in the top surface of the duct provides additional venting to the cabin ventilation duct, moulded into the underside of the topshell.

456 Type Chargecooler Unit Removal


1. Remove the left hand front wheel arch liner.
2. Remove the front bumper (see section 8K.1).
3. Release the chargecooler inlet and outlet connections, and the bracketing to the air intake spout.
4. Remove the support bracket securing the top rear of the duct to the topshell.
5. Remove the two M6 fixings securing the duct to the chassis (one on the side of the chassis, and one in the front underside). Withdraw the duct complete with chargecooler.

On re-assembly, check that the foam strip and two lengths of HRL strip are fitted to the duct to seal against the bumper.



USA-type
chargecooler
duct

Fixing point of duct to topshell bracket



KD 7 - OIL COOLER RADIATOR

The oil cooler radiator is mounted in a composite duct to the right of the engine cooling radiators. The duct is secured to the chassis front bumper forwardly, and also carries the two horns.

Oil Cooler Radiator Removal

1. Remove the right hand front wheelarch cover.
2. Disconnect the horn leads, and remove the horn bracket complete with horns after releasing the two top fixings, and a side lower horn bracket fixing.
3. Release the side horn fixings from the duct (if fitted), and disconnect the anchor-rod bar hanging bracket.
4. Release the two main bolt oil cooler connections, using a shop towel to absorb the escaping oil.
5. Via the access hole in the front apron underside, remove the four No. 16 fixings securing the oil cooler radiator to the duct, and carefully withdraw the radiator.


When re-fitting the oil cooler, note that the horn connections use 'body' sealing washers which should be renewed each time the nuts/bolts are released. Torque tighten the nuts/bolts to 27 Nm (20 lbf.ft).

Oil Cooler Radiator Duct Removal


1. Remove the right hand front wheelarch cover.
2. Remove the front bumper (see section 26.8).



Non-USA type
oil cooler duct



USA Type
oil cooler duct







3. Release the two air cooler hoses at their connections at the back of the engine using a shop towel to absorb the escaping oil. Release the two hose clamps.
4. Examine the four leads, and on each side, remove the lower mounting bracket. Be sure the fixings securing the air pipe to the duct.
5. Remove the root fixings:
1984-1988 engine - Two HB screws into the side of the chassis front frame railings; One HB screw into the front underside of the front frame railings.
1989 engine - Release the support bracket between the top edge of the duct and the topshell; One HB screw into the top of the topshell; One HB screw into the front underside of the topshell.
6. Withdraw the duct complete with all hoses and pipes.

On re-assembly, check that the four strips, and notice rubber edging strip (USA cars) are fitted to the front of the duct to seal against the bumper. Note that on the USA type tail cars, an outline on the top surface of the duct provides additional sealing to the rubber ventilation duct, provided into the underside of the topshell.

Check that the two air cooler hoses are protected by Armaflex sleeving, and ensure tightness of all feed and return hose connections at the back of the engine to 27 BY 129 100.001.

FUEL SYSTEMSECTION 43 - EGAS

	<u>Sub-Section</u>	<u>Page</u>
General Description	43.1	3
Precautions	43.2	3
Fuel Injector/Filter Tests	43.3	5
Fuel Valve	43.4	8
Fuel Exhaust	43.5	14
Fuel Exhaust Pump	43.6	14
Fuel Exhaust Valve	43.7	16
Exhaust Air Intake Control System (Table 2) (Catalytic case only)	43.8	16

**FUEL SYSTEM - Immatic/export****FUEL SYSTEM - USA**



FUEL TANK PIPEWORK

Breather pipe to filling neck

Fuel feed pipe, pump to filter

Fuel filter

Tank expansion space balance pipe

Feed pipe, filter to engine

Return pipe

Roll over valve

Swamp inlet to collector

Filter rabbit down

STANDARD CONTROL PIPEWORK (if fitted)

Signal line

Tank breather pipe

Purge line

Collector vent pipe

Chlorine collector

Fuel lines: feed return



1.1 - GENERAL DESCRIPTION

The single fuel tank is mounted from impact resistant blow moulded high density polyethylene for extra weight and maximum fuel protection, and is mounted ahead of the left hand rear wheel on two stainless steel bands.

The fuel pump is a roller vane type, high pressure electric pump mounted externally within the fuel tank. A fuel strainer is attached to the fuel pump inlet line and prevents dirt particles from entering the fuel line and feeds an separate water trap from the tank. A pulsator, fitted immediately above the fuel pump, reduces pressure pulsations in the supply line. The whole assembly of pump, strainer and pulsator is fixed by the supply and return pipes, to a mounting plate secured by a threaded ring to the top face of the tank. Air incorporated into this assembly in the fuel level sender unit, which uses a float float and a rheostat to supply a signal to the fuel gauge.

The pump supplies fuel at a pressure of 211 - 270 kPa (30 - 40 psi) dependent on operating conditions, through an in-line restrictor type filter located adjacent to the tank, to the fuel injector rail assembly on the engine. Return pipes are used to carry the fuel to and from the engine, and are sealed to provide the airtight return section. A compression joint is used between the fuel pump and supply pipe and the fuel rail return pipe at the back of the engine, because tool T600110007 may be fitted at this point in order for the fuel pump performance to be tested. See K112000000. The low pressure return pipe uses a compression hose and spring clamps at the front with the fuel rail return pipe. Special sealers fittings are used on both pipes at the connections to the fuel pump assembly, and require a special tool T600100000 to withdraw the connectors. Each connector uses two 'O' rings to seal against the sprockets on the fuel pump assembly, and may require replacement if the seals of the joint is opened repeatedly.

The pump is able to deliver 4 - 8 litres the engine's maximum requirement, so that fuel is constantly circulated through the in-line fuel filter, fuel rail, and via the fuel pressure regulator, back to the tank. This fuel circulation helps avoid excessive fuel temperatures with the consequent risk of vapour locks.

When the ignition is switched on, the engine management but maintains the fuel pump should still continue to perform as long as the ECM receives ignition pulses from the engine, indicate engine cranking or running. If no ignition pulses are received, the ECM switches off the pump within 2 seconds (approx) after the ignition was switched on, or after 10 seconds after a stall.

A roll over valve is mounted on the top left hand side of the rear bulkhead, and is connected between the weather strip on the fuel filler neck, and the diesel air vent fitted at the top of the filler neck in the body. This valve allows venting of the tank under normal circumstances, but prevents fuel spilling from the vent pipe if the vehicle is involved in an accident.

On optional equipped vehicles fitted with an evaporative emissions control system (EPCS) the vent pipe of the roll over valve is connected to a vapour storage device or canister mounted behind the DR 'D' port. When the engine is stopped, the fuel vapour from the tank is absorbed by the canister. When the engine is running, the fuel vapour is purged from the chamber by a flow of air through the unit, which is then captured by the engine in the normal combustion process. This purging process is controlled by a discharge valve on the top of the canister, and a vacuum solenoid valve in the engine bay, which is in full control by the engine management ECM. Full details of the evaporative emissions control system for USA specifications models, and of the fuel rail, pressure regulator and ECU systems for all models, are contained in the separate publications Service Horns K112000000 EPC/EPC/EPC.

In order to maintain an evaporative space within the fuel tank to allow for changes in volume and fuel temperature, the filler breather dip tube projects



into the tank and before the tank full level. Early to December 1990, a small hole in this tube allowed communication between the expansion space and the filler neck. In December 1990, the tank breather system was revised to provide a greater tolerance to pressure on a severe safe slope with a full tank. This consisted of a connection pipe between the tank expansion space balance pipe and the weather pipe from filler neck to roll over valve, and the deletion of the dip tube hole. For details see Section 10.2.

10.2 - PRECAUTIONS

- 1) To minimize the risk of fire and personal injury, release the fuel system pressure before servicing the fuel rail or any related component. See Fuel Pressure Relief Procedure below.
- 2) To reduce the possibility of sparks occurring when a fuel line is being cut, or when the vapors are present, the negative battery cable should be disconnected before work is commenced.
- 3) When fuel lines are disconnected, absorb any dripping fuel in an absorbent cloth and dispose of safely.

Fuel Pressure Relief Procedure

This procedure may be used upon to decompress any part of the fuel line except the unpressurized return line.

- Trip the battery switch in the battery compartment (240) or by opening bow (240) to disengage the fuel pump (241), and start the engine.
- After the engine stops from fuel starvation (about 10% of most 40-hp outboard starters), crank for at least 5 seconds to reduce the remaining fuel pressure.
- Disconnect the battery.
- Use a trap tool to absorb the small amount of pressurized fuel remaining at the fuel line pipe connection to be released.


10.3 - FUEL PUMP/SERVICE UNIT

To test the fuel pump performance, see separate manual ENR/ENG/EMU.


WARNING: Fuel Pump

WARNING: Before commencing work, carry out fuel pressure relief procedure detailed above, and disconnect the negative battery cable.

1. Remove the roof storage compartment floor, followed by the fuel pump access panel above the tank.
2. Disconnect both feed & return lines from fuel pump assembly. The Speedit® fuel pipe connectors are released by using a trap proxy tool (T0007J001) inserted into the holes in the connector end; press in to release the trap proxy and pull each connector off the feed and return spigots. Use an absorbent cloth to soak up the small amount of fuel expelled under residual pressure. Apply the electrical connector and earth lead.
If the connector shows any evidence of leaking, or is very difficult to release, the connector in question should be replaced. Early units were fitted with hex nut type (1/2" x 10" min), the swelling of which could cause difficult release of the pipe connector.



Using connector release tool



T00070989




To remove connector for change:

- Fitise off the end cap of the connector
- Pull out the gripper rollers.


Remove the two O' rings from with in the connector

Put into the connector the control (black) seal 810011408 followed by the outer control seal 810016188, and re-fit the gripper roller and end cap.






9. Loosen the fuel pump retaining ring to release the fuel pump assembly and withdraw complete fuel pump/gauge sender unit assembly using an absorbent cloth to catch dripping fuel.




10. Temporarily cap fuel tank aperture to secure fire risk.

12. Prepare






4. Disconnect the filler and filler breather hoses from the tank, and place the valves:




- To provide room for the tank to drop, the left-hand lower wheel must be removed. Release the parking brake cable from the caliper lever, and remove the top wishbone to hub carrier bolt. Mark the position of the tool-adjustment components before slackening the two rear wishbones to chassis bolts. Release the anti-roll bar from the lower wishbone, and the bolt securing the anti-roll bar hanging link to the chassis. Remove the carrier to lower wishbone bolt, and slack the wishbone and hub carrier assembly without retaining the brake hose.

5. Release the locknut from the underside of the tank to X strap top fixing bolts and unscrew each bolt. Slacken the two straps and carefully lower the tank, easing the filler neck through the body.



Fuel Tank Breather Assembly

A revised fuel tank breather system was introduced on all Eran models from December 1969, C19; 20 and 21. Prior to the changeover, the restriction between the expansion space of a fuel tank and the filler neck breather tube was not made via a small hole in the filler breather dip tube. If the vehicle is parked on a severe side slope with a full tank, it is possible for this hole to be covered, and tank venting problems result. From the changepoint, the dip tube hole was deleted, and a new breather pipe introduced to connect between the expansion space balance pipe and the filler neck to fill over valve pipe.



For service replacement, ARP type tank (BHC000007) should be fitted to the pump to the changepoint, until stocks are exhausted. After this time, the tank type tank (DCC00007F) should be fitted together with the updated breather system as detailed below. Failure to use the tank type breather system with the 10" type tank may, in certain circumstances, result in expulsion of fuel from the breather pipe, or cause fuel to spurt from the filler neck as the cap is removed.


10" tanks may be identified by a white 'M' marked on the top surface of the tank. The fit of 10" type tank to an existing cap uses rings of 10" tanks are illustrated under the following parts:

Fuel Tank Assembly, 10" (part and gauge sender)	BHC000007	1 off
Pipe Assembly, expansion valve balance	BHC000007F	1 off
Pipe Assembly, fill over breather	BHC000007	1 off
Mount, breather pipe	BHC000007	1 off

11) Drill an 1/8" diameter hole in the body for the new breather pipe. 30 (60 01) from the top. Filler breather and fitting. 21) and seat the gasket A.00160067.



View onto RH side of tank housing in body (beneath front storage compartment, floor)






(1) Fit the end of the new breather pipe through the grommet, and push fully into the connector on the balance pipe assembly.

(2) Secure the new breather pipe around the front of the load storage compartment and into the filler neck area. Remove and discard the existing breather pipe between the filler neck and ballcock valve. Fit the new pipe to the filler neck and ballcock valve, ensuring that all joints are firmly retained by the spring clips. Tuck the breather pipe beneath the lid lock storage lid latch bracket. See later illustration.

Pre-Reset Tank


1. Check that the tank is fitted with seven foam rubber pads, and that the pads are in good condition. If necessary, remove and replace with 712 grommets (part number 100100010) to secure the pads. Note that all the pad positions except the 7th lower on the tank front face are indicated by moulded corner lines on the tank.







- Remove the filler and filler breather tube spacers from the body before placing the tank into position. As the tank is raised, make sure the feed pipe from the filler to the engine is routed correctly, and fit the balance pipe into the tank spacers, checking that all seal sections are secure and retained with spring clips. Push the fuel hose and return connections into the tank openings.
- Ensure that the tank straps are fitted with rubber edging strips, either glued into each edge, or one piece edging strip fitted without glue.




Fit the tank strap into the locking device for the state of road, and hold the solution with an 18 mm deep socket to prevent the straps rotating whilst the bolts are tightened to 15 Nm (11 lbf/ft). Tighten and check the locknuts four times.

- Fit the filler neck and filler breather tube spacers. Connect the filler hose, ensuring that the hose is protected through the weather, and secure with the hose clip. Fit and secure the filler breather hose, checking that it is routed across the rear body chamber (if fitted), and is protected with condensed wiring.
- Re-assemble the rear suspension entering to Series DL, and tighten the pivot bolts only with the correct axle height. Ensure the tow-in adjustment concentric marker marks are aligned.
- Before refitting the pump access panel and fuel storage compartment floor, fill the tank, connect the battery, reset the master switch and start the engine to check for leaks from the fuel pipe connections.
- Fit the access panel and fuel storage compartment floor.

**2.5. FUEL FILTER**

The fuel filter should be removed at intervals specified in the maintenance schedule. Access to the fuel filter is available after opening the hood storage compartment door, via a removable panel in the body to the right of the fuel tank.



WARNING The fuel in the filter and related pipework is pressurized. Before commencing work, carry out the fuel pressure relief procedure detailed in section 1.2.2.


Compression joints are used at each end of the filter, necessitating the use of the spanners when slackening or tightening the connections. To replace the filter, release the inlet and outlet connections using an aluminium drift to ease up the small amount of fuel expelled under residual pressure. Release the two clamp bolts, remove the clamp, and withdraw the filter.

Fit the new filter into position with the direction of flow arrow pointing forwards, and tighten the clamps to 27 Nm (20 lbf.ft). Refit the clamp, tighten the two clamp bolts, and refit the access cover and gasket.


2.6. FUEL FILTER FLAP

The fuel filter flap uses a spring catch which is released by a cable terminating in a release handle in the left hand door panel. On early work, the access for the handle comprises a separate blank plastic moulding, but on later work, the release is incorporated into the body door panel moulding. The handle is integral with the inner cable and a 90° shaped clamp bracket, secured to the outer cable, clamps the main inner handle release moulding (if applicable) into the body aperture. For access to the clamp, the hood storage compartment left hand door panel must first be removed.


To remove a cable, the catch end must first be released, before the handle end being cut as needed and the cable withdrawn through the clamp bracket and only.



The release flip catch end of the cable uses a ball nipple to hook into the catch lower, and a groove in the outer cable which fits into the catch body, and is retained by a moulded flip which snaps into position. Push open the flip to release the cable.



The catch is retained in the body by a single screw, which allows adjustment of flipper flap shutlines. If the catch is removed, apply black Silastic to the hole of the catch flange before refitting. Flipper flap shutlines may also be adjusted via slotted fixing holes in the hinge bracket. If refitting a hinge bracket, ensure that Silastic is applied between the inside surface of the body and the hinge bracket.





10.7 - FILLER NECK

The filler neck is retained in the filler necker by two screws which clamp a flange on the neck to a clamp plate in the necker, with a rubber gasket used each side of the body. The filler neck incorporates a torque limiting radial separator to prevent over-tightening, and a pressure relief valve to prevent damage caused by a rapid pressure rise which the restricted breather line is unable to control.


Access to the filler neck is available after removing the rear storage compartment tray panels. It is important when swifiting the filler neck, that correct seal/sealing is achieved by the following procedure:


1. With a sealing gasket fitted into the filler neck's mating flange, use blank silastic to seal the three indentations in the neck flange beneath the flange; (1) is then the inside edge of the gasket and the filler neck. Also seat the locking screw top slot in the gasket.
2. Put the filler neck into position and push against the body whilst using a mallet to seal between the filler neck and the body.
3. Put the top gasket and plate, and tighten the two screws.





1. Set the filler and breathing boxes.



Filler neck pipe layout with 'D' type fuel tank (new 16.4)1.6.3 - EVAPORATIVE EMISSION CONTROL SYSTEM (ECCS) - Catalyst Cars Only

The fuel and venting system, which, in fuel vapour from the fuel tank to the system must be allowed to escape to atmosphere. The Evaporative Emission Control System (ECCS) uses an activated carbon (charcoal) canister to absorb fuel vapour from the fuel tank breather when the vehicle is not operating. Under certain engine running conditions, the fuel vapour is purged from the canister by a flow of fresh air through the unit, with the air/vapour being drawn into the intake plenum and collected in the normal combustion process. The charcoal is then prepared for further absorption of vapour when the engine is next stopped.


Canister Location

The charcoal canister is located behind the oil head cover (if used) and is provided with vacuum, purge, and vent ports in the top surface. The venting line from the fuel tank breather neck is sealed with a roll over valve located behind the filler neck and prevents fuel dripping if the car is inverted. In the canister vapour ports, fillers can access the canister through a port in the centre of the unit, and purge with the vapour before being drawn through the purge control valve and an in-line restrictor and non return valve into the intake plenum.

Canister System

A purge control valve, mounted on top of, and integral with the canister, controls a diaphragm valve to regulate the amount of purging that takes place dependent on intake system pressure.

The spring loaded, normally closed diaphragm valve, controls the purge line





between the top of the canister and the intake plenum. The top side of the diaphragm is connected via a vacuum solenoid valve, to a primary throttle edge port. In part throttle, a vacuum signal is applied to this line and the diaphragm valve is opened, allowing the low pressure in the intake plenum chamber to draw fuel vapors from, and fresh air through, the canister element.

The solenoid valve, mounted on the left hand front wheelarch, and connected between the purge control valve and the throttle body, is controlled by the engine management ECU. Under cold engine, or idle conditions, the solenoid is de-energized and shuts off the purge signal line, so that no purging takes place. The ECU turns on the solenoid valve to permit purging when all the following conditions are met:

- Above a specified coolant temperature;
- The engine has been running for a specified time period;
- Above a specified road speed;
- Above a specified throttle opening.

In addition, there must be sufficient vacuum at the throttle edge drilling to open the diaphragm valve.

A non-return valve fitted in the purge line between plenum and canister, prevents reverse flow when boost pressure is developed and plenum pressure becomes positive.



**MAINTENANCE & TROUBLESHOOTING**FILE & VIEW MENU

	<u>Page</u>
Accessing the Instructor's	2
Master List Schedule	4
Manufacturing Department	4

**RECOMMENDED DIMENSIONS****Engine**

Lotus does not guarantee the longevity and reliability of the engine, but it is our recommendation that only the specified components are used. Adhere strictly to both the quantity and viscosity ratings for the component, and use the engine oil in which the vehicle will operate under the test conditions. Use an oil recommended by the manufacturer (as in brand labels) for oil consumption, and API Service performance (such as API and SAE) comparable to Common Market Constructions. All ratings in these publications shall conform to the specified standard, if specified, for the test.

Manufacturer	SAE Viscosity (Grade and SAE Grade No.)	API	SAE
Volvo	SAE 10W-40	SAE 10W-40	SAE 10W-40
GM (Oldsmobile, Buick, Cadillac)	SAE 10W-40	SAE 10W-40	SAE 10W-40
Chrysler (Chrysler, Dodge, Plymouth, Ram, Jeep)	SAE 10W-40	SAE 10W-40	SAE 10W-40

SAE 10W-40 is a multigrade motor oil that meets the requirements of SAE J300 for use in both cold and hot climates. It is recommended for use in all GM, Chrysler, and Volvo engines. It is also recommended for use in all GM, Chrysler, and Volvo engines. It is also recommended for use in all GM, Chrysler, and Volvo engines. It is also recommended for use in all GM, Chrysler, and Volvo engines.

SAE 10W-40 is a multigrade motor oil that meets the requirements of SAE J300 for use in both cold and hot climates. It is recommended for use in all GM, Chrysler, and Volvo engines. It is also recommended for use in all GM, Chrysler, and Volvo engines.

Transmission (Automatic and Manual Gearboxes)

SAE 75W-90 is a multigrade motor oil that meets the requirements of SAE J300 for use in both cold and hot climates. It is recommended for use in all GM, Chrysler, and Volvo engines. It is also recommended for use in all GM, Chrysler, and Volvo engines.

Steering

SAE 10W-40 is a multigrade motor oil that meets the requirements of SAE J300 for use in both cold and hot climates. It is recommended for use in all GM, Chrysler, and Volvo engines. It is also recommended for use in all GM, Chrysler, and Volvo engines.

Rear Hub

SAE 10W-40 is a multigrade motor oil that meets the requirements of SAE J300 for use in both cold and hot climates. It is recommended for use in all GM, Chrysler, and Volvo engines. It is also recommended for use in all GM, Chrysler, and Volvo engines.

Brake System

SAE 10W-40 is a multigrade motor oil that meets the requirements of SAE J300 for use in both cold and hot climates. It is recommended for use in all GM, Chrysler, and Volvo engines. It is also recommended for use in all GM, Chrysler, and Volvo engines.

Engine Coolant Additive

SAE 10W-40 is a multigrade motor oil that meets the requirements of SAE J300 for use in both cold and hot climates. It is recommended for use in all GM, Chrysler, and Volvo engines. It is also recommended for use in all GM, Chrysler, and Volvo engines.

SAE 10W-40 is a multigrade motor oil that meets the requirements of SAE J300 for use in both cold and hot climates. It is recommended for use in all GM, Chrysler, and Volvo engines. It is also recommended for use in all GM, Chrysler, and Volvo engines.

SAE 10W-40 is a multigrade motor oil that meets the requirements of SAE J300 for use in both cold and hot climates. It is recommended for use in all GM, Chrysler, and Volvo engines. It is also recommended for use in all GM, Chrysler, and Volvo engines.

SAE 10W-40 is a multigrade motor oil that meets the requirements of SAE J300 for use in both cold and hot climates. It is recommended for use in all GM, Chrysler, and Volvo engines. It is also recommended for use in all GM, Chrysler, and Volvo engines.

**MAINTENANCE SCHEDULE – ROAD & BLUM'S E**

15/11/2016

DATE: _____ Inspector Name: _____ Vehicle: _____
 Service Req. Start of 2016: _____ End of 2016: _____
 Approved Pathways: _____ Section Road: _____ Job No: _____

All work on the off-highways be at an angle that the engine operation is to be performed from the **(2)** when the operation has been completed satisfactorily.

Notes:

1. Inspect & repair engine condition and test for correct operation. Extra time is required to adjust the engine - always to be done beforehand if necessary.
 2. Check & repair test and oil, adjusted if together as necessary.

<u>Distance covered (miles)</u>	<u>Service required</u>	<u>Distance covered (kilometers)</u>	
0,000 to 10,000	A	10,000 km	
10,000 to 20,000	A	20,000 km	
20,000 to 30,000	A	30,000 km	
30,000 to 40,000	A	40,000 km	
40,000 to 50,000	A & B	50,000 km	
50,000 to 60,000	A & B	60,000 km	
60,000 to 70,000	A & B	70,000 km	
70,000 to 80,000	A & B	80,000 km	
80,000 to 90,000	A & B	90,000 km	
90,000 to 100,000	A & B & C	100,000 km	Engine extra time
100,000 to 110,000	A & B	110,000 km	
110,000 to 120,000	A & B	120,000 km	
120,000 to 130,000	A & B	130,000 km	
130,000 to 140,000	A & B	140,000 km	
140,000 to 150,000	A & B	150,000 km	
150,000 to 160,000	A & B	160,000 km	



0201AF.06 Road Truck:

	Time	A	B	C	Other
Steering & Suspension					
Check security of steering knuckle (if applicable)			X		
Inspect ABS pipes & lines	12		X		
Inspect steering ball joints & knuckles			X		
Inspect condition of all suspension bushes			X		
Check security of front & rear components		X	X		
Inspect dampers for leaks & performance			X		
Inspect front wheel bearing toe play			X		
Check rear steel bearings			X		
Inspect front & rear wheel geometry			X		
Inspect condition of driveshaft u-joints	6	X	X		
Wheels & Tyres					
Inspect tyre condition & air pressure (see appendix)	6	X	X		
Check wheel balance			X		
Check wheel nut torque		X	X		
Electrical					
Inspect battery electrolyte level (if applicable)	12		X		
Check battery terminals for security & condition	12		X		
Inspect operation of all lights	6	X	X		
Check headlamp alignment		X	X		
Inspect operation of all electrical equipment	6	X	X		
Body					
Check adjustment of all mirrors and wipers			X		
Inspect operation of ABS system		X	X		
Inspect operation & condition of seat belts		X	X		
Inspect operation of headrest air conditioning			X		
Top up automatic wiper fluid		X	X		
Chassis					
Inspect polymer coating for damage	12		X		

Road Test Performance

Engine performance Driver performance

Clutch operation Gearbox operation

Steering performance Wheel balance

Traveling noise/vibration Light operation

Suspension noise Tyre condition

General comments

Work completed by Dealer stamp:

Site



BLANK PAGE



PRE-DELIVERY INSPECTION - R&M

07/1/78

1. This inspection should be done in the driveway and

the vehicle should be driven before commencing work.

Technical # 20000000

Check off the following
and mark corrected & initials necessary items

Inspection

Engine Bay

- Check engine & transmission oil level
- Check condition of engine oil filter
- Check coolant level
- Check house float switches level
- Check oil level in oil pan
- Check power steering fluid level (if fitted)
- Start engine:**
- Check running water for leaks
- Check engine & transmission for oil leaks
- Check fuel system for leaks
- Check power steering system for leaks (if fitted)
- Be alert if you notice water leak & for proper trouble codes

Fuel Tank

- Exhaustively fill fuel tank & check for leaks

Wheels & Tyres

- Check torque of wheel nuts
- Check tyre pressures (incl. spare)

Electrical

- Check condition of battery terminals
- Check operation of all switches & indicator lamps
- Check operation of headlamps (low & high)
- Check wiperage alignment
- Check operation of horn & hazard switch
- Check wiper operation of all doors & rear position
- Check operation of windshield wipers & pressure level
- Check operation of all indicators
- Check operation of horn switches
- Check operation of heater fan controls & blower fan
- Check operation of door mirror controls & heaters
- Check operation of audio equipment

Body

- Check operation of doors, door locks & central locking
- Check fuel tank vent pressure release mechanism
- Check full top roof operation & drainage
- Check interior trim for damage & cleanliness
- Check operation of rear belts
- Check all fasteners for damage
- Check appearance of body, jack & literature pack




Fit Mirror Plates

Goal: A pair of mounting plates 180° forward and positioned on the front bumper.

Tools: Remove the mirror plate cover by releasing the 4 screws along the top edge from the outside, and the 4 lower edge screws from inside the hood.


Use double-sided tape to secure the mirror plate to the rear bracket, and affix the cover and gasket.



Secure Tire-Lower Eyes

If the vehicle has been lifted with the lower eyes at the body, taking care to be transportation purposes, these should be removed prior to sales and the tie-down rods returned to factory form.

Release the lower tie-down bolts at the wheel arches, remove the tire down eye, and refit the bolts, torque tightening to 45 - 55 Nm (33 - 41 ft. lbs.).



Final Test

Final test the vehicle and carry out further rectification work if necessary.

The preliminary inspection is subject to the following conditions:

- a) It is the responsibility of the supplying distributor/importer/dealer to ensure that the car is delivered to the customer in the best possible condition.
- b) All costs incurred during the inspection are the responsibility of the supplying distributor/importer/dealer.
- c) Failure to return a signed copy of this inspection to Lotus Cars Ltd. by the distributor/importer/dealer, may result in warranty claims on the particular car being rejected.

Dealer Signature: _____

Date: _____

Dealer Stamp: _____


HEATING, VENTILATION & AIR CONDITIONINGSECTION 26 - HVAC

	Sub-Section	Page
General Description	PE 1	
Climate Control & Airflow Distribution	PE 2	1
System Equipment & Bestowing Loads	PE 3	14
Refrigerant Handling	PE 4	15
Air Filtration, Pipework Protection	PE 5	16
Evacuation & Chlorine Procedure	PE 6	17
Refrigerant Oil	PE 7	18
Compressor	PE 8	20
Climate Control Statistics	PE 9	20
Air Filtration/Flow Assembly	PE 10	22
Evaporator Assembly	PE 11	23
System Distribution Unit	PE 12	25

**HEATER**

The heater system is a heating matrix heat exchanger located within the air distribution chamber beneath the fascia, and fed with engine coolant. To heat the incoming air flow through it by the blower fan. The water feed to the heater matrix is taken from the thermostat housing at the left hand end of the engine, with the return hose connecting to the radiator bypass pipe. The supply of coolant to the matrix is controlled by a vacuum operated water valve in the engine bay, and isolated at the engine bay. The valve is operated by vacuum from a switch located on the underside of the heater/distribution unit, and is controlled when the full field setting is selected. At all other times the valve is open, and the heater matrix warms with the temperature of air flow and engine vents controlled by the proportion of air directed through the matrix.

Air flow through the heater matrix is increased by two intermittent air mass flow vents, controlled by a link rod from the temperature distribution rotary control, to the underside of the heater housing.


**Air Conditioning (if fitted)**

The air conditioning unit uses a cycling clutch system with a thermostatic expansion valve to provide refrigerated air to the vehicle interior. The system comprises:

- a closed loop of containing refrigerant (R12),
- a compressor mounted on the front side of the engine drive, by belt-drive belt from the front end of the crankshaft, via an electrically-actuated clutch,
- a condenser mounted immediately ahead of the engine cooling radiator;
- a receiver-dryer mounted at the left hand side of the engine bay,
- a thermostatic expansion valve fitted at the inlet connection to -
- an evaporator unit fitted beneath the fascia, because the blower unit was heater/distribution unit.



AIR CONDITIONING SYSTEM





Blow-Down Circuit

The closed refrigerant circuit should not be opened unless absolutely necessary, and only after consulting an authorized refrigeration technician. Failure to observe these precautions may result in personal injury.

Compressor

When the engine is running, and the air conditioning is selected, the clutch/clutch plate incorporated in the compressor pulley is engaged, which then locks the pulley to the shaft and drives the compressor. A thermostatic switch senses the temperature of air cooled by the evaporator, and cycles the clutch on/off to run the air temperature just above freezing, to provide optimum cooling without the possibility of ice forming on the evaporator coils. The thermostatic switch is mounted on the underside of the outlet end of the evaporator pan tray, with its capillary tube (temperature sensor) inserted into the evaporator matrix.

When the compressor is running, an additional load is placed on the engine, and to avoid stalling and maintain idle speed, a signal is sent to the engine management ECM which opens the idle air control valve accordingly.

The compressor is lubricated by a quantity of mineral refrigerant oil, which is added to the refrigerant. Some of the oil is released in the compressor with the remainder being circulated with the refrigerant.

The compressor discharges high temperature, high pressure refrigerant vapor into the condenser.

Condenser

The condenser, located immediately ahead of the engine cooling radiator, is of tubular design construction, and is made from aluminum for good thermal conductivity. The hot vapor flows through the condenser releasing heat to the cooling airflow passing over the condenser flowing through the forward portion of car, as induced by the two electric fans fitted behind the engine cooling radiators. These fans are cycled on/off according to refrigerant pressure (as well as engine coolant temperature), as sensed by a switch at the receiver-drier.

The hot vapor condenses into a high temperature, high pressure liquid, before flowing into the receiver-drier.

Receiver-Drier

The receiver-drier is located at the left hand side of the engine bay, and serves as a reservoir for storage of high pressure liquid produced in the condenser and incorporates a screen sock filled with desiccant to absorb traces of moisture and other contaminants. A sight glass built into the top of the receiver-drier enables a quick check of the amount of refrigerant charged in the system. If the refrigerant charge is low, a stream of bubbles will be visible at the sight glass. When a clear view glass, while indicating that the system has the correct charge, can also indicate complete absence of refrigerant. This situation is usually accompanied by oil streaks.

A 'primary' switch senses the pressure of refrigerant leaving the compressor, and:

- switches on the radiator cooling fans above a certain pressure;
- switches off the refrigerant if excessive pressure is detected (protects system from further damage in case of a central system failure);
- switches off the compressor if an excessively low pressure is detected, to prevent the compressor from oil starvation in the event of a system depressurization.

**Expansion Valve**

The expansion valve is fitted into the high pressure line at the intake to the evaporator, and is contained within the evaporator casing. The expansion valve provides a restriction to the flow of high pressure liquid into the evaporator, such that, as it flows through the valve, it undergoes a pressure drop which causes a change of state from a high temperature, high pressure liquid to a low pressure, low temperature saturated liquid. Then, when the evaporator, moves due to the ice position, the saturated liquid tends to boil, evaporate, and in so doing, absorb the necessary heat for this process from the warm air stream passing over the evaporator surface. The airstream in this system, and air that ducted through the various outlet units, into the passenger compartment.

The flow of refrigerant through the evaporator is thermostatically controlled by the expansion valve, which has a sensing line strapped to the evaporator control tube to sense actual temperature. Valve action opening is regulated to provide uniform cooling performance.

Evaporator

The evaporator is mounted in a rotating unit, with beneath the fascia between the driver seat and the passenger seat. For the cooling process through the evaporator, whether or not the fan is operating, the expansion valve is attached to the evaporator inlet connection, and is connected with the evaporator tubing. The inlet and outlet pipes project through the fascia into the engine bay, where pipework connects to the inlet from the condenser unit, and from the outlet to the compressor suction port, where it is connected again to the condenser and compressor another cycle.

HEATER CONTROL & AIRFLOW DISTRIBUTION

The heater core is made up of two tubes in the centre console, and carries the primary hot Ly-Cap heater temperature and air distribution, and a secondary heater fan speed. Fans with air conditioning have an additional number which indicates that function. Located at the bottom of the centre console, the engine fan is running for either the heater or air conditioning to operate.


Fan Speed Control

Fan speed is controlled by a horizontal slider between the two rotary controls. With the lever fully to the left, the fan is switched off, and only natural airflow will be obtained from the vents. Moving the slider to the right, provides four increasing fan speeds to assist air circulation. The fan speed resistor bank is fitted in the fan motor housing, where it is cooled by the airflow.

Heater Temperature

The heater temperature control is the lower of the two rotary controls in the centre console. The rotary movement of the knob is converted, via a pinion and worm gear, to a lever movement of a pinion which connects with the air mixer flaps on the underside of the heater housing. Airflow through the heater housing is controlled by two interlinked large worm control the proportion of air which is ducted through, or around the heater valve.

The heater (unheated) air, with the control fully counter-clockwise. This action moves the flaps to shut off the heater matrix, and direct all the airflow up and over the ducts of the heater in the distribution chamber. In addition, when the fan is not needed in the fully off position, the flap opening lever opens a secondary duct, directed on the bottom of the heater housing, and supplies





vacuum to cause a normally open water valve in the engine bay.

As the temperature control is turned clockwise, the thermo-switch is opened and venturiated, allowing the water valve to open and supply hot water to the heater matrix. As the control is turned further, an increasing proportion of the airflow is directed through the heater matrix, resulting in a progressive increase in the temperature of air supplied to the interior. With the control turned fully clockwise, all the air is directed to flow through the heater matrix for maximum air temperature.

6-cylinder vehicles

Cars with 4-position distribution control.

Air recirculation is available only on air conditioned vehicles. On these cars, a vacuum air-switch fitted on the top of the heater housing, controls a vacuum actuator on the air intake housing. When the temperature control is turned to the fully cold position, a ray on the top end of one of the heater flap assemblies releases (closes) the vacuum air-switch. In this position, no vacuum is applied to the intake flap actuator, which holds the flap in recirculation mode, with the fresh air port open and the fresh air intake closed. When the temperature control is moved off the fully cold position, the vacuum to the air-switch is released, and allows vacuum to flow into the intake flap actuator, which opens the fresh air intake, and closes the recirculation port.

In all cars equipped with the temperature control is turned to fully cold, recirculation is automatically obtained. For fresh air, the control must be turned to a position past off the fully cold stop to open the fresh air intake, which should operate before a proper turning of the control opens the water valve.

Note that the intake flap properly fit is also fitted on heater cars, but the recirculation port is blocked off. The blower fan unit is not fitted with a water flap, and has the recirculation aperture blocked off.

Cars with 6-position distribution control.

On these cars (i.e. all USA models), a recirculation position is provided by the distributor control for both heater and A/C vehicles. See below.

6-cylinder cars

The A/C distributor control is the upper of the two rotary controls at the centre console. The control is a rotary vacuum actuating valve, which supplies vacuum to various vacuum actuators which operate the distribution flaps. Vacuum is supplied both the engine running (from a port on the rear of the primary circuit body), and is shared in a secondary port on the rear of the left hand front manifold. The intake port on the reservoir top of the two ports, is used to "bypass" and incorporate a non-return valve to retain a vacuum supply when the engine is stopped, or when long periods of wide open throttle are used (low intake vacuum). It supply flow from the reservoir RH port leads to the recirculation control, and to the water valve vacuum thermo-switch on the underside of the heater unit.

The distribution control supplies vacuum to a two stage vacuum actuator controlling the face (lower) vent flap, a single stage actuator controlling the (reservoir) vacuum flap, and the thermo-switch for the intake flap (not used on heater cars with 4-position distribution control).

All '88 and some '91 MP cars are fitted with 4-position control switches, whereas all USA models, and other cars as a result change, have 6-position controls. All control positions are marked by symbols, with detents provided to permit selection by "feet".




Default:

With the door fully closed fully counterbalanced, airflow is directed to the subzone. Vacuum is supplied to the footwell/screen flap actuator, which operates to open the screen vents and close off the footwells. The face level vents are closed off by the PV flap. For not run default performance, select maximum heat and fan speed.


3-Position



4-Position



Left system shown







Feature

This feature is available only on cars with the Reposition Inertia Control, and allows for airflow in the tunnel to be regulated while also supplying air to the face level vents to help ease window demisting.

Vacuum is supplied to the ramble/straw flap actuator, which operates to open the screen vents & footwells and the footwells. Vacuum is also supplied to the trim which is supplied to the FIV actuator, which opens to a mid position so that air from the heater matrix in flows both to the windscreen, and to the face level vents. This position is normally used with a warm temperature setting, because the heater face level vents closed, and directing the main vents to heat the rear window.



and system shown






Footwell

At this setting, the face level vents are shut off. Air flow is directed to the footwells, with a small amount to the screen for defrosting.


Air source is supplied to either FIA or footwell/screen actuator, to shut the FIA flap shut off the face level vents, and the footwell/screen flap open the footwell vents. Air flows through the footwell internal aperture to the footwell vents, with a small amount feeding into the screen vents to aid defrosting. Use with a soft temperature setting and fan speed as desired.

6-Position

4-Position





Unit system shown



By Level

This position provides temperature stratification, so that cool air may be extracted through the face level vents, with warm air produced in the room or vacuum is supplied only to the final stage (end part) of the HVU activator, where power is a mid position, and aligned with a fence over the top part of the heater matrix. With a mid position selected on the temperature control, warm air flowing through the heater matrix is filtered through the footwell internal opening to the footwell vents, whilst cooler air, which has by-passed the heater matrix, flows over the HVU flap to the face level vents.


With system down




Face Level Vents

In this position, all air is directed to the four face level vents, each of which is provided with its own vacuum and direction control (see later).

Vacuum is applied to both ports of the FFA Actuator, which moves full travel to open the face level vents, and close off the rearward external ducture. A delay valve fitted in line 45 between the rotary control and FFA actuator (2nd stage port on the side of the actuator), ensures that the two status actuators operate sequentially. The screen/footwell line (no control) closes off the screen and footwell ports so that all air is directed to the face level vents. Use this position with a most temperature objective and fan speed as desired.



air system shown






Recirculation

This position is applicable only to those vehicles fitted with the traditional distribution method. See caution card in parenthesis with air conditioner, a control facility is provided via the temperature control panel (see below).

In this setting, the distribution of air is as for the face level 90% recirculation, but the outside supply to the air intake flap actuator is set off, so that the fan to shut off fresh air ports and open the recirculation ports. As the fan is operating, air is continuously recirculated within the car through the face level vents. This position should be used in conjunction with air conditioning and a dirty air filter (e.g. on a heavy traffic) to avoid recirculating fumes into the car.



Air Conditioning

Units fitted with air conditioning, are provided with a rocker switch on the centre console, and an adjacent amber tell tale to indicate when the circuit is operating.

To select (de)frigidated air, press the rocker switch to activate the compressor, and position the heater temperature control at zero. With the distribution control to the face level vents position, open the vents, and for maximum cooling efficiency keep the roof up and the windows closed. Note that the slow fan speed will be activated automatically when the air rocker switch is pressed, but a faster speed may be selected if desired. On cars with a position distribution controls, if the temperature control is turned fully counterclockwise, the recirculation vent will be closed so that refrigerated air is continually recycled within the car, but if the control is turned away from the fully cold stop, fresh air will be admitted. Cars with operation distribution controls, are provided with a centre stage position for maximum cooling, and a face level vents position for refrigerated fresh air.

Humidified Heating from Air

On vehicles with air conditioning, dehumidified air may be obtained by using the air conditioner in combination with a 40% temperature control setting. In this way, the air is first cooled to reduce its humidity, and then heated to the temperature required. Use this feature to help deice the windscreen and other windows.

Important Notes on Use of Air Conditioning

1. It is not recommended that the airflow from the face level vents be directed at persons during maximum refrigeration, as this can cause discomfort (e.g. "brain freeze").
2. Under certain ambient conditions, especially high humidity, a white vapour may issue intermittently from the face level vents. This is quite normal and should cause no concern.
3. To ensure that the critical components of the air conditioning compressor are kept adequately lubricated, the air conditioning should be switched on for at least a few minutes every week to permit the oil to migrate.
4. Some extreme conditions of engine operation will override the air present signal and switch off the air conditioning. These include: wide open throttle to make available full engine power; high vehicle speed to increase engine cooling capacity; abnormally high engine coolant temperature to help prevent overheating.
5. When air conditioning is selected, the radiator cooling fans will cycle on and off dependent on system pressures as sensed by the binary switch of the pressure/dielectric resistance of engine coolant temperature.

Face Level Vents


Four face level vents are fitted two in the centre console, and one at each end of the fascia. The central vents, top or left hand drive cars, the outer vents, are fitted with a valve control (thumbwheel), the turning of which opens or closes the vent, and a master knob by which the direction of airflow may be aimed.

On right hand drive cars, each of the two outer vents comprises of separate upper and lower outlets, each with its own operational control knob. A thumbwheel above the vents enables the airflow from both upper and lower outlets to be shut off (0), or opens the lower vent only (1), or opens both vents (2).



Right Hand Drive

Left Hand Drive



WATER VALVE DISTRIBUTION CONTROL WIRING

The ports on the water distribution control are labeled. The port for the valve is the same as given in the following table.

Water Valve Distribution Control

Control = valve	Water Valve Control Port Number				
	1	2	3	4	5
Default	Yes	Supply	No	Yes	No
Face Level Vents	Yes	Supply	Yes	No	Yes
Frontal	Yes	Supply	No	No	No
Hi Level	Yes	Supply	Yes	No	No

Yes = valve supplied

No = port vent lined

The labels above each the distribution control are numbered according to the way in which they are connected.


Hose #1: Face level vent supply. Runs from port #1 on the distribution control, to the top port on the vented, stopcock mounted on top of the water tank.

Hose #2: Distribution supply. Runs from the right hand port of the water control, through the face level, backhead to a "T" pipe. One branch runs to the vented face port of the water valve suspended on the underside of the lower bearing. The other branch runs to port #1 of the distribution control valve.

Hose #3: F10 test stage. Runs from port #2 of the distribution control, to the top port on the face level vent assembly.

Hose #4: Frontal vent supply. Runs from port #4 of the distribution control, to the front/rear vent.

Hose #5: F10 end stage. Runs from port #5 of the distribution control, to the top port on the face level vent assembly. A delay valve is fitted in this line. (The side branch to the control, search to ensure that the F10 test stage always operates before the 2nd stage).

Vacuum Connection Diagram: 4-position distribution control1110 shown



Line 16: Water valve. Runs from the sideways facing part of the water valve (supply) through the bulkhead, to the water valve at the rear of the engine bay.

17. Wiring has been completed for system:

- 1. Water-off supply. Runs from the vacuum take-off part of the rear of the engine throttle body, to the left hand part (marked 'vacuum') of the vacuum control portion of the rear of the left hand front wheelarch.
- 2. Air-water actuator. Runs from the sideways facing part of the water valve at the rear of the engine bulkhead, to the control flap actuator on the blower bearing.

Water supply distribution control lines all 1000 data:

Control Function	Water Control Part Number				
	1	2	3	4	5
Water-off	Ho	Supply	No	Yes	Yes
Water on	Ho	Supply	Yes	Yes	Yes
Swallowall	Ro	Supply	No	No	Yes
Water level	Ro	Supply	No	Yes	Yes
Water level alarm	Yes	Supply	No	Yes	Yes
Water level	Yes	Supply	No	Yes	Yes

Yes Water supplied
No Not installed

18. Water lines from the distribution control are numbered according to the part of the line they are connected.

Line 11: 200 100 100. Runs from part #4 of the distribution control, to the top part of the main beam and actuator. A delay valve is fitted in the line, to allow time to supply the control actuator to ensure that the 200 100 drops a way before the 100 100.

Line 20: Distribution supply. Runs from the right hand part of the system to the rear, through the front bulkhead to a 100 100 pipe. One branch runs to the Air-water transfer part of the water valve mounted on the underside of the engine housing. The other branch runs to part #4 of the distribution control.

Line 13: Swallowall system. Runs from part 4 of the distribution control, to the front of the engine actuator.

Line 14: 100 100 100. Runs from part 4 of the distribution control, to the top part of the main beam and actuator.

Line 45: No installation. On a 1000 data type runs from #4 of the distribution control to the intake flap actuator on the blower bearing. On 1000 data type, part #4 is marked 100.


Line 16: Water valve. Runs from the sideways facing part of the water valve (supply) through the bulkhead, to the water valve at the rear of the engine bay.

17. Wiring has been completed for system:

- 1. Water-off supply. Runs from the vacuum take-off part of the rear of the engine throttle body, to the left hand part (marked 'vacuum') of the vacuum control portion of the rear of the left hand front wheelarch.

Vacuum Collection System: In-pipe (on distribution control)

LID COVER



7.4 - REFRIGERANT REPLENISH

The refrigerant used in the air conditioning system is "R134a" and the following procedure MUST ALWAYS BE OBSERVED:

1. Only a certified technician, or A/C discharge technician per the appropriate state's refrigerant law, may refill or recharge an air conditioner with the manufacturer's instructions.
2. No R134a recharge refrigerant vapors into a confined area where there is a high flame. Heavy concentrations of refrigerant when exposed to a flame cause pressure to build up, which will cause attack and/or death.
3. No R134a recharge refrigerant discharge - always make sure the caps are securely closed.
4. No R134a transport lines of refrigerant in the passenger compartment of a truck.
5. No R134a recharge refrigerant discharges in high temperature.
6. No R134a recharge discharge cleaned in close proximity to any part of the air handling unit system.
7. No R134a recharge in the eye - no vapors of liquid refrigerant - ALWAYS wear safety goggles when handling refrigerant.

7.5 - REFRIGERANT PIPING PROCEDURES

The following procedures must be observed when doing any work on the refrigerant pipework. Before disconnecting any refrigerant pipework, the system must first be discharged to a pressure. To avoid discharging refrigerant into the atmosphere, a refrigerant recovery/recycling station should be used whenever available. It is to be observed as well that, proceed as follows:

1. ALWAYS WEAR SAFETY GOGGLES WHEN OPENING REFRIGERANT CONNECTIONS.
Cover with a cloth from at the connection with a cloth to protect face, spray, and loosen the connection SLOWLY, allowing any pressure present to bleed off before disconnecting. Working slowly, and continuing to take water until all pressure has been bled off approximately 2 to 3 minutes.
2. If pipe, flexible and connectors, and components, may be capped immediately they are needed to prevent the release of moisture and/or dirt.
3. All refrigerant components and flexible and connections are sealed when used, and should only be opened IMMEDIATELY back to FITTING, NOT AT ROOM TEMPERATURE, to prevent condensation of any residue which may occur when the sealing is removed.
4. The receiver-drier should be the first component to be connected, to ensure proper dehydration and maximum moisture protection of the system.
5. All joints should be sealed with refrigeration oil. Before making any connections, as there will aid sealing.
6. Great care must be taken to prevent damage to the size fittings and



connections. With one of the high pressures involved, a leak can be caused by the slightest imperfection. Always use the systems of the correct size when connecting or disconnecting any pipe joint so that the flared part of the union may be protected from rusting and damaging the component. This is especially important with the aluminium hardware.

7. All pipes and hoses must be free from any kinking. The efficiency of the system can be impaired by a single kink, or restriction. Flexible hoses should not be bent to a radius which is less than ten times the diameter of the hose.

LEAK - EVACUATION & RECHARGE PROCEDURE

SPECIFIED REFRIGERANT CHARGE 195 ± 55 GRAMS (20 ± 2 OZ)

When carrying out charging or servicing the air system, the directions of the manufacturer of the charging cylinder should be used in conjunction with the following:

1. Check that all manifold hand valves of the gauge set are closed.
2. Connect the charging hose to the service line and discharge (never return) to be fitted at the left hand horn of the engine bay:
 - a. The low pressure side of the gauge set (12/10" OR) is fitted in the pipe between evaporator and compressor.
 - b. The high pressure (liquid) side valve (12/10" OR) is fitted in the pipe between condenser and receiver/drier.
 To give the correct level charge, see R12 USE DIRECS.
3. Start the vacuum pump, and open the valve to the vacuum pump fully. Slowly open the low side manifold hand valve. The low side gauge should pull into a vacuum (approx. 70 kPa) and the high side gauge should be slightly below the zero index of the gauge. If the high side does not regulate, check the system for leakage or leak. Refer to steps 10 and 11.

4. After running the vacuum pump for 15 minutes, close the valve to the vacuum pump and switch the pump off. If not in pressure or stable, proceed to step 5. If however the vacuum remains below zero a leak is indicated. Refer to step 11, the leak testing procedure.

5. After evacuating the system for 15 minutes, close both the low and high hand valves, close the valve to the vacuum pump, then stop the vacuum pump.

6. REAR SAFETY CHECKS

7. Open the centre charging hose to the charging cylinder at the gauge. Open the tap at the bottom of the charging cylinder. Do not open the low and high side hand valves on the manifold gauge at this time.

8. Take note of the level of liquid R12 in the charging cylinder.

9. DO NOT START THE ENGINE

10. Partially charge the system with 200 grams of R12 by slowly opening the high side manifold hand valve. Close the valve when this is completed. DO NOT



Verify to ensure that the oil is distributed around the system at the normal run.

1) Verify that the system is fully charged with refrigerant, and that on the engine at each speed (at 1500rpm with the air conditioning switched on, and the power for all full speeds).

2) Verify that the system is ready, the compressor from the engine low speed (1500 rpm).

3) Verify the oil amounting from the back of the compressor, and drain the oil into a graduated glass, until the drain plug using a low 10" long, and replace it (Do not 10" Staff).

4) Verify the oil in the oil from the engine (1) only, and dependent on weather condition was possible to run the refrigeration system prior to the above step (1). All the refrigerant oil is followed:

Table 1: Refrigerant Oil

Refrigerant amount	Refrigerant amount
Refrigerant amount	Refrigerant amount
Refrigerant amount	Refrigerant amount

TABLE 1

5) Verify the oil level in the oil from the engine (1) only, and dependent on weather condition was possible to run the refrigeration system prior to the above step (1). All the refrigerant oil is followed:

Table 2: Refrigerant Oil

Refrigerant amount	Refrigerant amount
Refrigerant amount	Refrigerant amount
Refrigerant amount	Refrigerant amount

TABLE 2

6) Verify the oil level in the oil from the engine (1) only, and dependent on weather condition was possible to run the refrigeration system prior to the above step (1). All the refrigerant oil is followed:

7) Verify the oil level in the oil from the engine (1) only, and dependent on weather condition was possible to run the refrigeration system prior to the above step (1). All the refrigerant oil is followed:

Refrigerant Oil Specifications

1) Verify a high quality refrigerant oil of viscosity 200 500/100°F


Refrigerant Replacement

If a system component is to be replaced, refrigerant oil in the following quantities will be added to the replacement before finishing:

- Refrigerant 10 40 cc (1.0 = 1.4 fl. oz)
- Refrigerant 20 40 cc (1.0 = 1.4 fl. oz)
- Refrigerant 30 40 cc (1.0 = 1.4 fl. oz)



2. Release the glovebox drop handle, and allow the glovebox to swing down fully from the glovebox aperture. Reach behind the climate control panel, and unplug the temperature control link end from the control quadrant. Also pull off the vacuum pipe connector plug from the rotary control.



3. Release the steering wheel. For USA vehicles fitted with a Supplementary Inflatable Restraint (S.I.R.), see Service Notes Manual MB for precautions and procedure for removing the steering wheel of all other vehicles:
 - press the center hub pad and turn counter-clockwise to release from the hubnut type fixture;
 - remove the hub nut/washer retaining the steering wheel. Mark the relative positions of the stud and flange relative to the hubnut;
 - pull the wheel off the column using minimum force. If necessary, use a suitable puller.

DO NOT apply excessive torque force to either the upper or lower column without the use of a steering wheel puller, or the mechanism retaining the telescopic length of the collapsible column may be overridden, necessitating column replacement.
4. Release the cruise control. Press down the pusher tabs retaining the column switches, and slide the unit out from their carrier bracket.
5. Release the two screws, and remove the instrument access panel from the top of the instrument. Disconnect the speed cable, and the three instruments, within instrument bracket blocks. Release the three fixings securing the fascia mask to the main fascia.
6. Release the two blanking plugs at the bottom edge of the dashboard fascia, and release the two fixing screws.
7. Remove the blanking plug at the bottom of the fascia mask, adjacent to the fog light lens, release the lower fixing, and withdraw the fascia mask.
8. Release the two screws securing the climate control panel into the fascia mask, and withdraw.



2. From the remote control panel, observe the normal procedure, make the following points:

a. When setting the ratio, use the screw provided by the gland on spectacle to ensure that the input of air back of the ratio valves with the support bracket is in the desired state.


b. When lighting the steering wheel set to 40 km/hr (25 mph).

3. The temperature control lamp has now been replaced and disconnected from the power supply lines, proceed as follows:

a. Feed the cable through the hole in the remote frame, and fit to the temperature control quadrant.

b. Turn the control to fully 100%.

c. When the fan has been fully started (inter-switch operated), and push the forward end of the lamp into the plastic strip. Secure by pushing the lamp forward to the stop and position.



11.2.1.5. INTAKE SYSTEM ASSEMBLY

1. The intake system assembly consists with the air intake duct at the front of the engine and feeds the four speed flow jets. The unit is set the red and is fed via a butterfly presentation on right and left hand drive cars. In motor car cars, the flap valve is used as an exhaust from air from the intake that is not fully drawn into equipped with air conditioning system the flap is pulled down when a low air intake, or close off the speed air and use a pressure sensor. The pressure sensing is achieved with a conditioned jet maximum deflection, the low air is used to close off the air intake, it being essential to avoid pressure surge into the jet. The flap is operated by a spring actuator mounted on the pressure side (see section 11.2.1.3).

2. Remove the air intake filter assembly.


3. Remove the main fuel filter section (10).

4. On all cars, remove the remote manifold (10) and install the link (1) for the control of the engine and respiratory systems.



6. Connect the thermocouple to the evaporator beam tube.
7. Install the lower fixing bracket from the back end, and the two fixings securing the top of the unit to the section beam, and withdraw the assembly from the heater/distributor unit.

Evaporator assembly
top fixing screws



LOWER Fixing screw

8. If necessary, separate the two halves of the casting for access to the evaporator or expansion valves. Take care not to damage the capillary lines from the thermocouple or expansion valves.

To disassemble and set up the unit, reverse the general procedure, using the following points:

- When reuniting the expansion valves, use a new 10" ring coated with petroleum jelly at each connection, and torque tighten to:
1) 24 - 25 Nm (18 - 19 lbf ft)
2) 12 - 13 Nm (9 - 10 lbf ft)
- Clip the evaporator or the capillary line lead to the evaporator outlet plate, and wrap with anodized strip tape.
- Ensure that the evaporator is sealed in the vacuum by the foam strips.
- For the evaporator to the casting, and ensure that the capillary line is correctly positioned.
- Torque tighten the unit inlet connection to 22 - 26 Nm (16 - 19 lbf ft).
- Torque tighten the unit inlet connection to 24 - 30 Nm (18 - 22 lbf ft).




PU-10 - HEATER/DISTRIBUTION UNIT

The heater/distribution unit consists of a cast-iron casting containing the heated jacket with two fuel mixer flaps, and a distribution chamber with two flaps. The vacuum solenoid and the two distribution flaps are mounted on the side of the unit. To adjust the heater relay, the unit may be removed from the boat.

To remove the heater/distribution unit:

1. Drain sufficient coolant, and disconnect the two heater hoses from the rear of the engine bay.
2. Remove the ram cover face section (10).
 1. Ensure the distance between screw (16) sockets on the distribution housing, and the rivet line of the scuttle, is more than the ram level when ducting.
 2. Disconnect the fuel supply between the flap mechanism and the heater, actuated. Also, disconnect the fuel supply pipe from the #7 piece, and the pipe between these components from the water valve.
 3. Release the single screw securing the rear face of the unit to the scuttle frame. Release the three screws from the scuttle frame. Release the two fixings securing the brace to the scuttle beam, and the two fixings securing the brace to the chassis rail. Add a wooden brace.



3. Release the two fixings securing the top of the housing to the scuttle beam, and withdraw the unit into the bulkhead and evaporator housing.
4. To remove the heater matrix from the housing, release the foot plate and clamp brackets from the underside of the unit, and release the operating arm



1. In the Encoder flap mark, release the wires securing the matrix into the tray socket, and withdraw the matrix from the case.

When replacing the reader matrix, ensure that the matrix is fully seated in the tray socket.

The characteristics of the hot air transfer tape (used in the factory) are well matched to the equipment. However, if the reader distribution is not optimal in the case, the coding may be blanked or adjusted as follows: (1) In the factory, from low correlation and in the case, make both flags on the left of position, and raise the end in the hot case.

Check that the flags are freely between the hot and cold positions.

2. In the encoder, the matrix housing in the reader order to repair. After repair, the tape is mark and matrix surface, which is vital to necessary to avoid a low temperature control limit and as detailed in section 11.1.

CLIPPERSECTION 00 - ELM

	<u>Sub-Section</u>	<u>Page</u>
General Description	00.1	2
Church Cable	00.2	2
Release Bearing & Fork	00.3	4
Turnin Assembly	00.4	5

Q1.1 - GENERAL DESCRIPTION

The driving element of the clutch assembly consists of the inner face of the engine flywheel, and a pressure plate fixed to the flywheel via the spring diaphragm clutch cover assembly. The driver element, as a single, 8½" double ended friction plate, is fixed to the gearbox input shaft, and interposed between the flywheel and pressure plate. The diaphragm spring in the clutch cover clamps the friction plate between the pressure plate and flywheel to provide the drive connection between engine and gearbox. The gearbox input shaft, on which the friction plate is free to slide axially, is "overhung" from the gearbox, with its splines bearing in the rear end of the crankshaft.

The clutch release mechanism uses a control cable to connect the clutch pedal to a lever arm in the transmission. The lever arm bears a shaft end which is fixed, inside the clutch housing, to a release fork which in turn, presses a ball bearing race against the inner ends of the fingers of the diaphragm spring. This action causes the diaphragm fingers to pull apart their flaps, and relieve the clamping force applied to the pressure plate via the diaphragm inner edge. The release bearing slides on a guide sleeve which surrounds the gearbox input shaft.

Q1.2 - CLUTCH CABLE

The clutch cable connects the pedal, with a lever arm in the clutch housing, with rubber pistons fixed at each end of the outer cable. Absorbers to reduce the transmission of geartrain noise into the cabin via the cable. In later cars, a further reduction of transmitted noise is achieved by the inclusion of a mass damper - a steel plate - at the transmission end of the cable. The handle is nylon lined and requires no lubrication. In service inspection, the clutch cable should be adjusted to provide the specified amount of free play at the inner end, as the friction plate wears, the free play will be reduced, and it is important allowance is made, clutch rattle will normally result as a consequence of a preload being applied to the release mechanism.

Introduction of Clutch Cable Mass Damper

41 cars built from approximately December 1990 onwards, are fitted with a lengthened outer cable to accommodate a mass damper at the transmission end. The damper is a mild steel block which grips the clutch cable outer via a rubber sleeve. The centre of the sleeve is used to damp down the high frequency vibrations transmitted from the cover end to the cable via the clutch cable.

If repairing the clutch cable, first determine whether a mass damper is fitted (see the diagram). If no damper is fitted, use the "B" level cables:


Clutch Cable, 8½"	100000000
Clutch Cable, 12"	100000000

When stocks of these cables are exhausted, it will be necessary to fit the longer "C" level cable together with the damper and sleeve:

Clutch Cable, 8½"	100000000
Clutch Cable, 12"	100000000
Mass Damper, Clutch Cable	100000000
Rubber Sleeve, Sleeve to Cable	100000000


To identify a clutch cable, measure the inner cable free length at the transmission end (pedal end disconnected):

"B" cable free length - 8½"	115 mm approx.
- 12"	129 mm approx.
"C" cable free length - 8½"	115 mm approx.
- 12"	127 mm approx.



Do fit the rear damper

1. Pull the insulated boot from the end of the outer cable threaded portion, and slide the isolator bush onto the thread.
2. Put the rear damper and rubber sleeve over the inner cable. Push the sleeve onto the larger before sliding the damper on to the threaded outer cable up to the cup washer. Push the isolator bush and abutment washer back onto the thread, and fit the cable into the transverse abutment bracket. Check that the tag on the transverse abutment washer fits into the slot in the bracket, and that the cup washer tag fits against a flat on the adjuster end. Bolt the rubber bolt.



to Adjust

Before adjusting the cable, first check that the clutch pedal spring is adjusted so as to allow similar pedal heights of clutch and brake pedals.

Pull apart by hand, the plastic transmission and the transmission lever, and measure the clearance which should be 1 mm. If necessary, adjust the clearance by pulling the outer cable and adjuster nut clear of the cup washer leg, and turn the nut as required. After adjustment, ensure that the nut sits flush against the cup washer with the leg against a flat, and that the leg on the isolator bush adjustment washer is engaged in the adjustment bracket slot.

Cable Adjustment

- Release the adjustment at the clutch housing adjustment bracket to enable the inner cable to be unhooked from the clutch housing lever arm.
- Pull the selector fork and cable out of the adjustment bracket.
- Pull the cable from the clutch pedal, and withdraw the cable through the isolator.

To refit a cable, reverse the removal procedure, and apply a small amount of grease purpose grease to the eye at the pedal end of the cable. Adjust as above.

11.3 - RELEASE BEARING & FORK

For access to the release bearing and fork, the transmission must be removed from the vehicle (see Section 11).

Release Bearing

Remove wash and oil the spring clip from the release fork, and slide the release bearing off its guide tube. Check the bearing for excessive play, roughness, noise or any other signs of undue wear, and replace if in any doubt.



On re-assembly, apply a light coating of high temperature grease, (See Journal No 149/266042F), to the input shaft splines, release bearing sliding surface and the contact faces at the ends of the fork. Fit the external spring around the release bearing groove, with the ends of the spring fitted towards the gearbox casing. Fit the release bearing near the guide tube with the spring 'wrap' away from the fork shaft, and the flange of the bearing against each fork leg. Hook the ends of the spring into the fork leg holes.

Release Fork


The release fork is integral with its shaft, and is removed as follows: Remove the release bearing (see above).

Remove the operating arm from the splined end of the release fork shaft, pull



off the dust cap, and press out the clutch shaft seal. Use the special tool or a suitable pipe to knock the shaft bear along the shaft end into the bearing. Remove the shaft spring and withdraw the shaft from within the bearing.

Clutch Shaft Seal Insertion/Removal TMC00992



To replace: Apply high temperature grease to the bearing surfaces of the shaft and bore. Insert the shaft into the bearing from the inside, leave the spring over the shaft end, and fit the shaft into the end nut. Use tool TMC00992 to fit the outer seal into position, followed by the seal. Fit the dust cap and operating arm, noting that the nut may be locked in one position only. Torque tighten the arm pinch bolt to 26 Nm (18 lbf.ft)

10.4 - CLUTCH ASSEMBLY

To access to the clutch assembly, the transmission must be removed from the vehicle: see Transmission Section 9.


The diaphragm pressure plate assembly is secured to the flywheel by six bolts, and located by three bolts. Release the fixing bolts evenly and progressively to prevent distortion of the clutch cover. Remove the cover assembly and centre (friction) plate.

Inspection

Inspect the condition of the clutch friction plate shims for wear, oil contamination or any other damage. Check for signs of excessive wear on the splines, and check that none of the clutch drive springs or the diaphragm tabs are broken. If in doubt, replace the component.

Spline shim depth

max: 1.2 - 1.5 mm
- average limit: 0.2 mm



Inspect the condition of the wearing surfaces on the flywheel and pressure plate, and remove the component if there is evidence of excessive wear, scoring, or other damage. If there are any signs of overwear (through excessive clutch slip, characterised by a 'churning' of the friction surfaces), distortion is likely to have occurred, and weakening of the diaphragm spring. Replace the clutch cover assembly, and check the correct fit of the flywheel face.




To Replace Flywheel

- I) Release the six bolts, and remove the flywheel from the crankshaft.
- II) Thoroughly degrease the threads in the crankshaft, and the crankshaft and flywheel mating faces. Apply Loctite 262 or similar thread locking compound to the threads of 306 (flywheel) fixing bolts. Insert through the flywheel nutler, and secure the flywheel to the crankshaft.
Note: Do not apply an excessive amount of sealer to the bolt threads, as the resultant sealer may contaminate the bolt seating face and cause the bolt to work loose.

- III) Hold the flywheel from turning, and tighten the fixing bolts in a diagonal sequence to the specified torque in 2 steps using the arcular tightening method as shown in the table.

Flywheel bolt tightening.

1st step	2nd step
30 Nm (22 lbf.ft)	45° - 60°



To Re-fit Clutch Assembly


- Check that the plastic plug used for locating the clutch alignment wandel is fitted into the rear end of the crankshaft.
- Fit the friction plate, the correct way round, to the flywheel, and retain with the clutch cover assembly.

NOTE: Refit the friction plate and cover assembly differ for 30K and Turbo models. Check that the correct parts are fitted:

Identification	Friction plate	M/R	215 mm x/D	
		Turbo	225 mm x/D	
	cover assembly	M/R	304481253	(140 kgf)
		Turbo	304481172	(100 kgf)

- Fit the clutch alignment wandel through the selection plate and into the crankshaft plug, and tighten the six clutch cover fixing screws evenly and progressively to 19 Nm (14 lbf.ft). Remove the wandel and leave the crankshaft plug in place.


Clutch alignment wandel T000T0981





Refit the transmission assembly: see section PF.

SECTION 50WRECK REMOVAL - ELAB

	<u>Sub-Section</u>	<u>Page</u>
General Requirements	50.1	5
Vehicle System Mountings	50.2	7
Clamps and Joints	50.3	8
Fasteners	50.4	9

Naturally Aspirated Exhaust System

Non-Catalytic Turbo Exhaust System

Catalyst Tube Exhaust System

**310 - GENERAL DESCRIPTION**

There are three variations of exhaust system dependent on model:

- 311 Naturally Aspirated
- 312 Non-Catalyzed Turbo
- 313 Catalyzed Turbo

Naturally Aspirated

The cast iron exhaust manifold bolted to the front of the engine, collects exhaust gas from cylinder head ports 1 & 2, and 3 & 4, and maintains high stream separation to the downpipe flange.

A two-piece downpipe bolts to the manifold flange, loops under the engine sump, and terminates at the back of the engine in a two bolt flange.

A front silencer section bolts to the front pipe via a spherical joint which uses a fiber and wool seal, milled sealing ring between the splines on the downpipe, and the shaped end of the front silencer pipe. The joint is sealed by the pressure exerted by a coil spring fitted over each of the two shouldered studs fitted to the silencer pipe flange. The front part of the silencer pipe runs above the engine lay underside, and is formed into a 'D' section at this point to provide sufficient clearance. The front silencer is a straight through absorption type.

A centre section pipe uses a slip joint at each end to connect with the front silencer section and the rear silencer inlet pipe.

The rear silencer inlet pipe runs over the right hand rear lower sashline before entering the rear section silencer. A rear oval tailpipe exits through a slot in the rear sashline. The baffle and absorption type rear silencer is similar to that used on Corbo models, but differs internally to provide the necessary higher degree of baffling.

For identification of the rear silencer, refer to the navigation number stamped on the underside of the casing, 310000 10000's.

Aluminium mild steel is used for the manufacture of the entire system with the exception of some stainless steel internal parts of the rear silencer.

Non-Catalyzed Turbo

A cast iron manifold collects exhaust gas from the four cylinder head ports, and then into the engine block at the turbocharger. The outlets of the turbo housing, both rear and wastegate, lead into a cast iron manifold which connects with a straight catalyzed section at the front of the engine. A non-catalyzed version, this housing is an empty chamber supported by a bracket to the front of the engine block, and which terminates at a three bolt flange.

A downpipe bolts to the flange of the turbine outlet housing, and loops forward the entire sump to a two bolt flange at the back of the engine. On cars built from January 1991 onwards, a steel support strap is bolted between a tab on the downpipe rear flange, and the drivetrain fixing bracket on the rear of the engine.

An exhaust pipe front section bolts to the front pipe via a spherical joint which uses a fiber and steel wool milled sealing ring between the splines on the downpipe, and the shaped end of the front silencer pipe. The joint is sealed by the pressure exerted by a coil spring fitted over each of the two shouldered studs fitted to the front section pipe flange. The front part of the pipe runs above the engine lay underside, and is formed into a 'D' section at this point to provide sufficient clearance.

A centre section pipe uses a slip joint at each end to connect with the front section and the rear silencer inlet pipe.

The rear silencer inlet pipe runs over the right hand rear lower sashline



Before joining the rear section aluminum, drop rear tailpipe exits through a slot in the rear window. The baffle and absorber type rear silencer is similar to that used on the S-3, model, but differs internally to produce less back pressure.

For identification of the rear silencer, refer to the nomenclature number stamped on the underside of the fuselage, 40454 13099009.

Stainless steel is used for the downpipe, with the remainder of the system constructed from aluminum mild steel.

Catalytic Converter

A cast iron manifold collects exhaust gas from the four cylinder engine ports, and feeds into the turbine housing of the turbocharger. The outlets of the turbine housing, both rear and wastegate, feed into a cast iron outlet elbow which leads to filters and engine accessories. Oxygen sensors which connect with a starter catalytic housing in the front of the engine. One cast iron cylindrical housing contains the starter catalytic which lead & divide to the engine, built up to operate at temperature quickly, and it so doing helps the main catalytic converter to reach operating temperature sooner. In Japanese model cars, the interior of the housing is filled with a temperature sensor to warn against catalytic over-heating. The housing is supported by a bracket to the front of the cylinder block, and terminates in a cast steel flange.

A discharge hole in the flange of the starter catalytic housing, and leads forward, the engine manifold has two exit flanges at the back of the engine.

The main catalytic converter leads to the front pipe via a spherical joint which uses a 1/2" ID and steel, steel rounded mating ring between the splines on the manifold, and the tapered end of the converter inlet pipe. The joint is sealed by the pressure exerted by a coil spring fitted over each of the no. 30 stainless studs fitted to the converter pipe flange. The front part of the pipe runs above the engine bay underside, and is formed into a 'U' section at this point to enable sufficient clearance.

The three way catalytic converter contains an oxidising catalyst, platinum, where upon the presence of oxygen in the exhaust gas is used to hydrocarbonise and/or neutralise (oxidise) to water vapour and carbon dioxide. A reducing catalyst, rhodium, helps to remove copper (over 90% efficiency) used to leave nitrogen. The converter reaches very high temperatures during operation, and is fitted with a cast shield on its underside to reduce the danger of grass fires. A heat shield is also fitted to the chassis above the converter in order to protect the chassis and rear window painting from the effects of excessive heat.

A rear section pipe used a 'U' joint at each end to connect with the converter outlet pipe and the rear side car inlet pipe. A catalytic damper formed by the middle of this pipe, takes the form of a steel plate wave damper mounted over the pipe via four soldered bobbles. The rear two strands the exhaust pipe and lead to a bracket welded to the pipe underside.

The top of each inlet pipe runs over the 1/2" ID rear pipe lower with four bolts joining the rear section aluminum, steel, oval tailpipe exits through a slot in the rear window. The baffle and absorber type rear silencer is similar to that used on the S-3, model, but differs internally to produce less back pressure.

For identification of the rear silencer, refer to the nomenclature number stamped on the underside of the fuselage, 40454 13099009.

Stainless steel is used for the downpipe and oxygenic nomenclature, with the remainder of the system manufactured from aluminum mild steel.




50.0 - EXHAUST SYSTEM MOUNTINGS

The exhaust system is flexibly suspended from the chassis/body unit by a total of four rubber mountings. These are located:

- i) Towards the front of the chassis rail backbone;
- ii) Just ahead of the rear wireway front power point;
- iii) Beneath the battery compartment;
- iv) At the rear of the boot floor.

In addition, on non-catalytic turbo models built from approx. January 1991 onwards, a support strap is fitted between a tab on the downpipe rear flange, and the drive shaft mounting bracket on the back of the cylinder block.



The rubber mountings use wire rod hooks with load spreading saddles, welded to the exhaust pipe and chassis at the mounting points. At the rear, one hook is bolted beneath the battery compartment, using a pair of M6 studs welded to the battery retaining channel. The rearward hook is bolted to a hobbin in the boot floor track points assembly, and links to use a hook secured to the rear extension eye by a clamp bracket.


Note that two different types of rubber mounting are used, with A08386026P used for the two chassis mounted hooks, and A08386029P used for the two rearward body mounted hooks.




**8D.1 CLAMPS & COILS****Spherical Joint**

A spherical joint is fitted at the rear end of the absorber both to ensure alignment of the absorber system without strain, and to reduce vibration transmitted along the pipe. The joint is assembled as follows:

- Fit the sealing ring over the nozzle on the dampener.
- Position the front silencer/boom and/or front stop, as applicable, and report on the mounting bracket.
- Fit the two studs through the holes in the dampener flange and secure to the opposite flange with 'Keylock' nuts.
- Fit a cap and cap washer over each of the studs, and secure with another 'Keylock' nut. Tighten the nuts fully to clamp the cap washers against the shoulder on the studs.

**Coil Clamps**

All coil clamps should be assembled using a proprietary sealant paste. The SMA clamps must be assembled with the bolts sections, and the bell clamps clamped with the bolts section only (to 15 Nm (11 lbf ft)). Do not tighten the clamp until the exhaust system is fully installed and positioned for optimal response to change a body and suspension components.




10.4 - HEAT SHIELDSEngine Mounted Shields

On R.A. vehicles, the only exhaust system heat shields fitted are those mounted in front of the exhaust manifold, both parts being secured to the manifold itself.

Turbocharged models use a three piece heat shield over the top, right hand and left hand ends of the exhaust manifold. A further three shields are used at the front of the engine:


- over the top of the turbocharger,
- in front of the turbo outlet pipe;
- in front of the starter catalyst housing.

In order to avoid fatigue fractures, it is most important that these three shields are assembled correctly, especially where the turbo outlet pipe shield is secured to the other two shields. Refer to the diagram for the correct assembly sequence.



Catalytic Converter Heatshield

On cars with catalytic converters, a phenolic main heatshield is fitted to the chassis above the converter to protect the chassis/body and rear engine tappets from the considerable amount of heat produced by the converter. The shield is secured by four bolts, the rear two using chimney nuts clipped to the shield, and the front two using nuts on the chassis.




INTERNAL TRAINSECTION VD ELDM

	<u>Sub-Section Label</u>	<u>Page</u>
Body Train Panels	VD.1	2
Audio Control Console	VD.2	3
Instrument/Signal Panel (Facing Mark)	VD.3	3
Main Console	VD.4	5
Control Panel	VD.5	5
Operator Console	VD.6	9
1st End Train Panels	VD.7	11
Upper Panel	VD.8	12
Sub Storage Rack of 4 Side Panels	VD.9	13
Lower Storage Rack Train Panels	VD.10	14
Seats	VD.11	15
Seat Belt	VD.17	16

20.1 - DOOR TRIM PANELS

Note that it is **always** necessary to replace the interior lock motion retaining clip each time the door trim panel is removed. To remove the panel:

1. Push the lock button, and prise out the orange clip retaining the button to the lock rod, and withdraw the button. Remove the trim panel retaining screw from the lock button recess.
2. Remove the screws behind the interior release handle, and unhook the handle bracket from the trim panel. Pin the aperture revealed, remove the two screws securing the release handle bracket and trim panel to the door shell.
3. Pop out the relay panel from the niche recess in the door trim panel, and connect the two wires to the rear of the door pull handle.
4. Pull off the wall edging carpet from the lower part of the trim panel, and remove the door fixings.
5. Carefully use a scalpel to cut the adhesive and separate the top lip edge of the door weatherstrip seal, or be pulled down sufficiently to release the single screw securing the rear edge of the trim panel. Release the three screws at the front edge of the panel, and withdraw the panel from the door.






To edit the door trim panels observe the removal procedure, noting the following points:

- Fit the top edge of the panel into position, with the door button lock rod through the button aperture. From behind the panel, hold the rod in the fully raised position while the button is fitted and correctly positioned, before pressing the retaining clip fully home.

9E.2 - CENTRE TUNNEL CONSOLE

To remove:

1. Remove the filler panel between the rear of the tunnel console and the cabin rear wall by pushing upwards from its two top free corners.
2. Pull out and disconnect the window control switch to the rear of the gear lever.






1. Pull out and disconnect the two window switches, each side of the parking brake lever, and remove the two console front fixing screws with the shield appliances.
 2. Release the two screws securing the slanting tray, and lift out from the feet of the lounge top. Release the two console rear fixings with the tool appliances.
 3. Tilt the console to the rear to disengage the tongues from the main fascia, and then lift the console over the parking brake lever.
- Regress the console in the reverse order to removal.


113-1. INSTALLATION OF THE PANEL (FASCIA) RING:

The instrument, control, panel includes the main and auxiliary instruments, windows, climate controls, etc. for each level model and trim. The panel is your guide as the entries read:

1. Remove the parking brake pins, the grommets, feet the glass-top operation, mount behind the panel shell and secure the wing nut and washer securing the support arm set in the rear of the set. Use the release lugs to withdraw the set in full, and disconnect the wires, lead, speaker harnesses, and other and earth leads.




2. Reach around the of radio control panel, and install the temperature control rack 1.1 from the control quadrant. Also put off the vacuum pipe under the pin from the remote distributor control.



1. Remove the steering wheel. For HSB vehicles fitted with a Supplementary Inflationable Restraint (S.I.R.), see Service Notes Manual NR for precautions and procedures for removing the steering wheel. On all other vehicles:
 - push the nut on both pad and fork to release them to slide from the tapered-type fixture;
 - remove the nut and washer retaining the steering wheel and mark the relative positions of the wheel and horn to allow re-assembly; pull the wheel and the nut on using a chain hoist - in pressing, use a cable pulley. For vehicles fitted with a lock, remove the four pins on the lock's head screw securing the both pad spring assembly, withdraw the spring assembly and disconnect the horn lead cable terminal. **DO NOT** apply excessive axial force to either the inner or outer column without the use of a steering wheel puller. If the Technician retaining the vehicle's length or the on-vehicle cable may be overridden, refer to the column replacement.
1. Remove the column shroud. Press down the pin in the tab retaining the column shroud, and slide the shroud from their narrow bracket.
1. Release the two screws, and remove the instrument arrow pack, first the top of the panel. Disconnect the speed cable, and the three instrument with arrows connected links.

Instrument/od(1)rh
harness connector
blocks (HRD shown)






b. straps

Release the nine fixings securing the fascia mask to the main fascia:

- reach within the instrument cluster access aperture, remove the three screws (1), and dislodge the angle (2) of the securing the top edge of the fascia mask. Remove the two blocking plugs in the bottom edge of the driver's side fascia, and release the two fixing screws (3) and (4).
- From the underside of the fascia, release the single fixing nut (5) to the inboard side of the column.
- remove the blocking plug at the bottom of the fascia mask adjacent to the cigar lighter, and release the lower fixing screw (6). Turn the radio aperture or the glovebox aperture, slacken the fixing nut (7), and withdraw the instrument/switch panel from the main fascia.

941 Fascia Mask Fixings



110 0416

Before releasing the fascia mask fixings, it is necessary first to remove the driver's side fascia filler panel (non-ELK type) or area below (SIP (air bag) cars). The 40-915 type filler panel may be removed after releasing the two screws at the top of the visual face, and pulling the panel upwards. The 818 type filler panel is removed by releasing the two nuts securing the lower edge of the panel to the support bracket, and pulling the top edge horizontally rearwards to release the spring clips.





Release the seven fixings securing the fascia rack to the main fascia:

From within the instrument cluster access aperture, remove the three screws (A) securing the top of the panel.

- Release the single screw fixing (B) from beneath the outboard end of the panel.
- Release the single screw fixing (C) from beneath the inboard end of the instrument panel.

Remove the two blanking plugs from the fascia rack at the bottom (D) corner, and remove the light lighter, and release the two fixing screws (E) and (F).



LHD Fascia Rack Fixings

W/L4 MAIN FASCIA PANEL

On the main fascia panel only, on LHD cars, the removal complete with the instrument/switch panel (fascia rack), after disconnecting the wiper and climate controls, and removing the steering wheel and column switches. On LHD cars, the fascia rack must first be removed to allow access to the fixing at the inboard side of the driver's footwell.


1. Disconnect battery.
2. Remove the centre tunnel console (see above), and gear lever gaiter.



- Remove the steering wheel. For USA vehicles fitted with a Supplementary Inflatable Restraint (S.I.R.), see Service Notes Manual MB for precautions and procedure for removing the steering wheel. In all other vehicles:

 - disconnect the centre lock pin and lock shaft assemblies to release from the hydraulic type locking;
 - remove the nut and washer retaining the steering wheel;
 - note the relative positions of the wheel and steering column to aid refitting;
 - pull the wheel off the column using suitable force. If necessary, use a suitable puller. The improved pulley allows access to the gear ring and the lock rod release assembly assuming the lock push spring assembly, withdraw the spring assembly and disengage the lock rod push rod from the


DO NOT apply excessive axial force to either the steering column or the lock rod assembly. The steering wheel pattern or the manufacturer's instructions for the length of the collapsible steering column should be consulted, and be maintained until refitted.
- Remove the three screws, press down the plastic cover, withdraw the column lock pin and use the switched lock theft alarm switch.
- Remove the two screws, and remove the instrument bezel panel from the top of the dashboard. Disconnect the speed cable and the three instruments with harness. See 20000 Notes.
- Remove the dashboard top plate, and allow the instrument panel wiring to be seen. From this position, separate the rear of the master battery cable, and remove the temperature control cable and from the central quadrant. Also pull out the master panel to allow access to the plug from the battery control.



- Disconnect the cable unit and release the wing nut and washer securing the support bracket to the back of the set, and use release pins to withdraw the cable unit from the switch panel. Disconnect the aerial lead, speaker harness, and power and earth leads.



9. Release the ducting to each of the outer face level vents.
10. On LHD cars, remove the instrument/meter panel face sub-section (R 31)
11. Release the fascia panel fixings:
 - one saddlebar securing the centre of the fascia to a bracket welded on the unit's rear, accessible from the glovebox aperture.
 - two screws (10mm TORX) which secure the bottom of the fascia to the tunnel top, ahead of the pedal level. These screws are concealed beneath the bottom of the fascia and the tunnel top.
 - two M8 set screws and washers each side securing the ends of the fascia to the door hinge post.
 - one screw in each of the five screen denister vents, adjacent to the base of the windscreen.
 - on RHD cars, release the nut securing the bracket at the inboard side of the engine's bracket, and press down to release the stud from its tunnel top bracket.







1) Withdraw the main fascia panel over the steering column and gear lever.

To refit the main fascia panel, reverse the removal procedure, noting the following points:

- when refitting the radio, use the access provided by the glovebox aperture to ensure that the aerial on the back of the radio engages with the support bracket fixed to the chassis beam;
- torque tighten the steering arm, not to 40 Nm (30 lbf.ft);
- check that the 'A' post to fascia seal is fitted correctly. The neoprene foam seal extends from the bottom of the steering pillar trim panel to the top of the sill tread plate, and is glued to the body 'A' post with Permatex 62 adhesive.



30.5 - SILL TREAD PLATES





The gill tread plates are retained in the body sills by five fir tree type fasteners (visible on the underside of the tread plates). On the driver's side, an additional two screws secure the front of the panel in the 'B' post. The tread plates may be removed and refitted without disturbing any other trim panel.


If a new tread plate is to be fitted, note that this will be supplied in two pieces. The base plate with the fit over fasteners is first fitted to the sill, surface 30-degree sided tape is applied to the top surface of the base plate. The tread plate is then positioned carefully before prancing down onto the sill to stick to the 30-degree sided tape.

95.4 - SPEAKER BOXES

The speaker boxes, fitted behind the seats, are retained by the speaker elements, and a single fir tree fastener.

To remove a speaker box:

- pull out the filler panel behind the centre console;
- release the speaker by removing the four fixing screws securing the speaker grille and trim panel to the speaker mounting bracket types in the body.
- pull the inboard end of the panel forward to release the fir tree fastener, and withdraw the panel.



95.5 - 'B' POST TRIM PANELS

The 'B' post trim panels conceal the seat belt ends and base of the roof top roof mechanism, and are supported by a cap which hinged open when the roof is raised. In early cars, this cap was retained by springs, but on later vehicles the cap is hinged at its forward edge to the 'B' post trim panel.

To remove the 'B' post trim panel:

- Remove the gill treadplate (see above);
- Release the seat belt anchorage at the sill;
- Remove the speaker box (see above);
- Peel back the carpet concealing the two trim panel fixing screws along the



lured edge, and the simple fixing at the inboard top corner of the carpet.


Remove the three screws.

- Release the end of the roof storage lid next, and remove the screw securing the top outboard edge of the panel.

- Remove the screw at the inboard top of the trim panel:


Remove the screw behind the speaker bracket, and the screw at the bottom edge adjacent to the rail.

- Detach the trim panel, sliding the seat belt through the trim panel slot.



70.6 - CAPPING RAIL

The capping rail along the front edge of the roof storage compartment is secured by screws along its front and rear edges. For access to the 'Screws' fixings along the front edge, the rear wall carpet must be pulled down from under the capping rail fin. After removing all the fixing screws, the capping rail may be pulled forwards and withdrawn without disturbing the 'B' post trim panel.





AD.9 - ROOF STORAGE SHELF & SIDE PANELS

A separate access panel, retained by four push-in plugs, is incorporated in the shelf to allow ready access to the battery. The roof storage shelf must be removed for access to the electrical terminals in the battery compartment, or to the tool box.


To remove the roof storage shelf:

- Remove the rapping call (see above);
- Remove the shelf caplet;
- Release the two "butter" fixings at each side securing the side panels and shelf to the "U" post reinforcing strut, and the two fixings at the right hand rear edge of the shelf;
- Pull off the clips securing the front edge of the shelf to the cabin rear wall, and withdraw the shelf.

The side panels must be removed for access to the fuel filter neck (left hand side), or an early call to the roof storage lid catches.

To remove the side panels:

- Release the two "butter" fixings at each side securing the side panels and shelf to the "U" post reinforcing struts;
- Release the screws along the top edge of the side panel, and withdraw the panels.






AD 10 - SCREEN SURROUND TRIM PANELS

The screen surround trim consists of a header rail trim panel, and the screen pillar trim panels. The two screen pillar trim panels are secured at their lower ends by being sandwiched between the main frame and the slant screen pillar, and at the top by screws into the screen pillars.


To remove a screen pillar trim panel:

- Insert back the leather trim into the top corner of the screen pillar to reveal the use of two fixing screws. Release the screws.
- Remove the single fixing screw (as fitted) at the bottom end of the panel, and withdraw the trim panel.



To remove the header rail trim panel:


- Pull off the cover concealing the sun glass fixings, and release the two screws securing each sun visor and the three screws securing each roof latch bracket to the header rail.
- Release the top end of one of the screen pillar trim panels: remove the two screws securing the header rail trim panel to the header rail and withdraw the panel.





20.11 - SEATS

Each seat adjustably is mounted on a pair of runners to allow for fore/aft adjustment. With each runner bolted to the floor by two bolts, the upward runner fittings also serve as body/thighrest mounting, and pivot up on short outrigger brackets from the side of the chassis hingezone. The outward runners are fixed to the body still outriggers, with bifurcated aluminum bobbins being used in the body at all seat moving points.





NOTE that the spacer fitted between the rear end of the unlabeled runner is 29 mm thick, rather than the 25 mm of the other three spacers. Torque tighten all seat runner fixings to 45 Nm (33 lbf ft).


40.11 - SEAT BELTS

The three point latching inertia non-reel seat belts are designed to allow the wearer complete freedom of movement under normal driving conditions. The belt reel will lock automatically whenever the vehicle is tested, its air speed is fluctuating or suddenly changed, or will occur on heavy braking or on impact in a collision. The seat belt anchorage points are as follows:

The belt reel assembly is mounted behind the base of the 'B' post by a single fixing bolt.

- The shoulder seat slider is fixed near the top of the 'A' post by two bolts threading into a 'B' post reinforcing strip attached to the 'B' post crossbars and running backwards to a spigot plate in the rear window.
- The unlabeled end of the lap belt is secured to the sill, outboard.
- The labeled end of the lap belt is fixed to the sliding part of the rear window, in order that the belt positioning remains correct irrespective of seat position.


On 456 cars, a shock absorption system is incorporated at the belt reel assembly, which provides for a controlled movement of the belt reel during a crash. If the belt tension exceeds a specified high value, the belt reel assembly is attached to a deformable strip, clamped fixed to a bracket by two rivets which are designed to shear under a particular force, applied only when the belt is worn and the vehicle is subject to a severe frontal impact. Movement of the belt reel, and thus speed of the belt, is then controlled by the rate at






which the deformable steel strip is pulled between three offset guide pins which form the strip to bend in different directions. Energy dissipated in this way serves to progressively slow the belt reel and protect the wearer from an unacceptably high decelerative force.

Before Impact



After Severe Impact



If any seat belt has been used in a severe frontal collision, the belt should be replaced as a precaution even if there is no visible damage to the assembly. In USA areas, if the rivets securing the deformable strip and belt reel to the mounting bracket are sheared, no attempt should be made to reinsert the strip, cut the strip and retaining bracket should be replaced as a complete assembly.

To remove a seat belt assembly, release the seat belt from the wall, remove the 'D' post from panel (see section V3.5), and release the belt reel assembly and shoulder belt slider from the 'D' post.

When fitting a seat belt, pay careful attention to the correct assembly of the washers and spacers at each fixing point, as shown in the diagrams. Torque tighten the fixing bolts as follows:

- Belt reel to body (non-USA) or deformable strip (USA): 45 - 60 Nm (26 - 31 lbf.ft).
- Deformable strip mounting bracket to body (USA): 35 - 40 Nm (26 - 30 lbf.ft).
- Shoulder belt slider: 41 - 47 Nm (32 - 35 lbf.ft).
- Lap belt to wall: 30 - 35 Nm (22 - 26 lbf.ft).
- Buckle brace to seat slider: 30 - 35 Nm (22 - 26 lbf.ft).

