

PACKARD SERVICE MANUAL

PART I

STANDARD SPECIFICATIONS
626-633-640-645



REVISED SEPTEMBER, 1928

PRICE \$1.00

This book is copyrighted by the Packard Motor Car Company and
may be recalled and the purchase price refunded at any
time in the discretion of the Company.

Copyright 1928

SERVICE DEPARTMENT
PACKARD MOTOR CAR COMPANY
DETROIT, MICHIGAN

packardinfo.com

**Brakes—Front—Adjust
(Bendix Brakes)**

626 A11

1. Raise the four wheels off the ground.
2. Adjust eccentric screw on the brake support plate and turn brake shoe adjusting cam until brakes drag. Then back off just enough so that wheels can be turned without brake dragging. Hold the adjusting cams in this position while tightening.
- Note: Make sure linkage and cross shaft are perfectly free.
3. Loosen check nuts on front brake cable and rear brake pull rods. Take up on self-locking adjusting nuts, until, with adjusting nuts in its proper position (resting firmly in the socket), the brake starts to drag—then back off the adjusting nuts until wheels turn freely.
- Note: Check adjustment to see that there is approximate equalization, by checking up the four wheels. First the two front wheels and then later the two rear wheels, trying the wheels first on one side and then the other.
4. Adjust brake pedal connecting rod to a clearance of .010" between brake levers and brake lever stop.
- Note: Be sure brakes do not drag before the car leaves service station.

Material


Same as 626

640

Material



Tool No. S. T. 186 All Bendix Brakes



Tool No. S. T. 190 All Models

A11*Cont.***HOW PACKARD BENDIX BRAKES OPERATE**

When you press your foot down on the brake pedal, the cam turns, forcing the primary shoe against the brake drum. The primary shoe is floating and is anchored only to the secondary shoe at "A" as shown on Fig. 2. It does not attach to the backing plate at all. The secondary shoe anchors to the backing plate at "B." The auxiliary shoe anchors to the backing plate at "C." The overlapping joints permit independent movement of the shoes. Friction of the primary shoe against the drum tends to carry the shoe with the drum, thus forcing the secondary shoe against the drum, the self-energizing action. The auxiliary shoe operates directly from the cam for reverse. It should be noticed that one end of the cam is




Figure 2

longer than the other as shown on Fig. 2. The long end of the cam operates the primary shoe, the short end operates the auxiliary shoe. Care should be taken that the cam is assembled properly.

FOOT AND HAND BRAKES

Brakes are provided on all four wheels and are of the self-energizing internal expanding type. Each brake consists of three shoes with wire woven asbestos facings which contact with the wheel drum. Four brakes are operated by the foot pedal. The two brakes on the rear wheels can be operated by the hand lever independently of the foot pedal so as to provide a standing or parking brake.

Adjustments for wear can be made by taking up on the ball socket nuts "A" at the ends of front brake cables and rear brake pull rods. Best results will be obtained when making this adjustment by raising the four wheels off the ground so that the brakes can be properly equalized.

When making the following adjustment, an equal braking effect should be secured between each right and left front wheel and then between each right and left rear wheel but no attempt should be made to equalize the braking effect between the front and rear wheels as this is automatically accomplished by equalizing linkage:


1. Make sure that linkage and cross shafts are perfectly free and yoke pins lubricated

2. Loosen check nut on ball socket nut "A" and take up on this nut until brake starts to drag, then back off until wheel just turns free, following this procedure on each wheel

3. Then, with brake pedal slightly depressed, check the equalizing effect on the two front wheels by turning the wheels forward against the brake action. If the effort required to turn each wheel is not approximately equal, loosen the ball socket nut on the tight wheel and take up slightly on the opposite one. When a satisfactory result has been obtained, tighten the check nuts

4. Repeat this operation on the rear wheels, bearing in mind that rear wheels will not turn as freely as front wheels on account of the differential action

When brakes have become worn to an extent where the foregoing adjustments have caused the brake regulation levers "B" to assume a nearly vertical position



when brakes are released, it will then be necessary to make an adjustment of the shoes as follows:

1. Loosen the two brake shoe support bolt nuts "C" on each brake shield.
2. Apply brake pedal hard several times to seat shoes in drums, then, with a medium pressure on brake pedal so as to keep shoes in contact with drums, pull all nuts "C" down very tightly.
3. With brakes released, loosen jam nut "D" on brake shield and turn

A11
Cont.

A11*Cont.*

brake shoe adjusting cams "E" clockwise until the brake binds in the drum, then back off just enough so wheel can be turned without brake dragging. Hold the adjusting cam in this position while tightening the jambs out. Again check to see that wheel turns without dragging. Repeat this operation on each wheel.

4. Remove ball socket nuts "A" and clamp screws in front brake operating levers "B".

5. Carefully mark each lever with reference to a certain shaft serration, remove lever from shaft and replace so that lever is moved forward just three serrations from its original position.

6. Replace clamp screws and ball socket nuts.

7. Adjust and equalize brakes as explained in paragraphs covering first adjustments.

8. Repeat this operation on rear brake operating levers, moving these levers three serrations toward rear of car, after which adjust and equalize rear brakes. Note: After above adjustments have been made, the center line of the brake operating levers should form an angle of sixty to seventy degrees with the center line of the brake pull rod with brakes in a released position.

A12Brakes—Foot—Reline and Adjust
(Bendix Brakes)

626

(Includes A310)

1. Remove front wheels, using puller.

2. Remove upper brake shoe guides.

3. Unhook brake shoe springs.

Note: If return springs are not in good condition, replace with new ones.

4. Remove anchor pin nuts.

5. Remove the three shoes, they can now be slipped off the anchor bolts in a group.

6. Remove the old lining from shoes and reline brake shoes.

Note: Lining must be countersunk so that rivet heads are $\frac{1}{8}$ of an inch below face of lining.

7. Free up all brake connections and ball joints using an oil can or grease gun.

8. Replace all brake shoes and tighten with anchor pins and nuts.

Note: When replacing brake shoes with new lining, it is necessary to loosen all adjustment. The long end of the foot brake operating lever cam operates the primary shoe and the short end of the cam operates the auxiliary shoe. Care should be taken that the cam is assembled properly.

9. Replace front wheels.

10. Replace hub cap, axle shaft nut and cotter pin.

11. Adjust front wheel bearing.

12. Adjust foot brakes.

Note: Adjust eccentric screw on the brake support plate until brakes drag. Then turn eccentric screw again, try wheel and see that the wheel can just be turned without dragging. Adjust front and rear camshaft operating lever check nuts for equalization by checking up the four wheels. Check the two front wheels, then the two rear wheels, having someone sit in the driver's seat and hold the brake on tightly while trying the wheels for equalization.

13. Test.

Note: Be sure that brakes do not drag before the car leaves the service station.

Material


112 In. 106486 Lining

72 In. 156499 Lining

Miscellaneous

Brake Relining Equipment Complete


Tool No. S. T. 300




Tool No. S. T. 300

In selecting the best all-around brake relining equipment, practically all the well-known makes were tried. The units that we have to offer are, we believe, the best obtainable for their particular use. This has been proved by a long test in one of our large Service Stations.


Hub Cap Wrench



Rear Axle Shaft Nut Wrench



Tool No. S. T. 124 All Models



Tool No. S. T. 684

A real heavy-duty wheel puller that will pull the toughest wheel. All parts are forgings and extremely rugged. Pulling is done by the wedge principle which does not transmit shock to the wheel bearing when struck with a hammer.

Same as 626

Material

112 In. 106886 Lining

72 In. 156499 Lining

Miscellaneous**640****A12***Cont.***Pedal Depression Gauge**

Tool No. S. T. 659 - All Models

**Brakes—Foot—Reline, Adjust
and Adjust Hand Brakes****(Bendix Brakes)****(Includes A310)**

1. Jack up chassis, front

2. Remove hub caps

3. Remove front wheels

4. Remove upper brake shoe guides

5. Unhook brake shoe springs

Note: If return springs are not in good condition replace with new springs

6. Remove anchor bolts and nuts

7. Remove the three shoes, they can now be slipped off the anchor bolts in a group

8. Remove the old lining from shoes and reline brake shoes

Note: Lining must be countersunk so that rivet heads are $\frac{1}{8}$ of an inch below face of lining

9. Free up all brake connections and ball joints using oil can or grease gun

10. Replace all brake shoes and tighten with anchor bolts and nuts

Note: When replacing brake shoes with new lining it is necessary to loosen all adjustment. The long end of the foot brake operating lever cam operates the primary shoe. The short end of the cam operates the auxiliary shoe. Care should be taken that the cam is assembled properly

11. Replace front wheels

12. Replace hub cap

13. Adjust front wheel bearings

14. Adjust foot brakes. (See operation A116)

15. Test

Note: Be sure that brakes do not drag before the car leaves the service station

Material

112 In. 106886 Lining

72 In. 156499 Lining

Miscellaneous

Same as 626

Material

112 In. 106886 Lining

72 In. 156499 Lining

Miscellaneous**640**

**A16 Brakes—Front, Reline, Turn Down Drums and
Adjust Both Sets of Brakes** 626
 (Includes A310)

(Bendix Brakes)

1. Remove all hub caps
2. Remove front wheels
3. Remove upper brake shoe guides
4. Unhook brake shoe springs
 Note: If return springs are not in good condition, replace with new springs
5. Remove anchor pins
6. Turn down brake drums
7. Remove the three shoes—they can now be slipped off the anchor pins in a group
 Note: Lining must be countersunk so that rivet heads are $\frac{1}{8}$ of an inch below face of lining
8. Remove old lining from shoes and reline brake shoes
 Note: Lining must be countersunk so that rivet heads are $\frac{1}{8}$ of an inch below face of lining
9. Free up all brake connections and ball joints using an oil can or grease gun
10. Replace all brake shoes and tighten with anchor pins and nut
 Note: When replacing brake shoe with new lining, it is necessary to loosen all adjustments
11. Replace front wheels
12. Adjust front wheel bearings
13. Replace axle shaft nuts, cotter pins and hub caps
14. Adjust front brakes
 Note: Adjust eccentric screw on the brake support plate until brakes drag and then turn eccentric screw again and try wheel and see that it can just be turned without dragging—adjust front and rear camshaft operating lever. Check adjustment for equalization by checking up the four wheels. Check the two front wheels and then the rear wheels having someone sit in the driving seat and hold the brake on tightly while trying the wheels for equalization
15. Test
 Note: Be sure that brakes do not drag before the car leaves the service station

Material

112 In. 106886 Lining
72 In. 156499 Lining
Miscellaneous

**Brakes—Front—Reline, Turn Down Drums and
Adjust Both Sets of Brakes** 640

Same as 626

Material

112 In. 106886 Lining
72 In. 156499 Lining
Miscellaneous

**A17 Brake Shoe and Facing Assemblies
Front or Rear—Renew One Set** 626
 (Includes A348)
 (Bendix Brakes)

1. Remove brake anchor pins
2. Remove the three shoes—they can now be slipped off the anchor pins in a group
 Note: If return springs are not in good condition, replace with new springs
3. Supply and install new brake shoe
 Note: See that brake shoe releases properly

4. Replace front or rear wheel
 5. Adjust foot brakes (See operation A11 on Bendix brakes)

A17*Cont.***Material**

- 1-164636 Primary Shoe
 1-164635 Auxiliary Shoe
 1-164637 Secondary Shoe
 1-164004 Spring

**Brake Shoe and Facing Assemblies -
 Front or Rear - Renew One Set
 (Bendix Brakes)**

Same as 626

Material

- 1-164616 Primary Shoe
 1-164635 Auxiliary Shoe
 1-164637 Secondary Shoe
 1-164001 Spring

Brakes—Foot—Free Up and Adjust

1. Raise both rear wheels clear of floor and remove, using puller S. T. 123
2. Free up and lubricate all foot brake connections
3. Replace wheels and adjust brakes
 Note: Brakes—Foot—Adjust (See Operation A11)

A19**Material**

Same as 626

640**Material**

**Brakes—Hand and Foot—Adjust
 (Bendix Brakes)**

A116

1. Raise the four wheels off the ground
 Adjust eccentric screw on the brake support plate and turn brake shoe adjusting cam until brakes drag, then back off just enough so that wheels can be turned without brake dragging. Hold the adjusting cam in this position while tightening
 Note: Make sure linkage and cross shaft are perfectly free
2. Loosen check nuts on front brake cable and rear brake pull rods
3. Take up on self locking adjusting nuts until with adjusting nut in its proper position (resting firmly in the socket), the brake starts to drag, then back off the adjusting nuts until wheel turns freely
 Note: Check adjustment to see that there is approximate equalization by checking up the four wheels. First the two front wheels and then the two rear wheels

To Adjust Hand Brakes

1. Adjust hand brake pull rods by means of the adjusting clevis at the front end so that there is at least $\frac{1}{8}$ of an inch clearance between the bottom of the slot and the pin on the brake lever, with brakes in off position

Material

Same as 626

640**Material**

A119 Brakes—Hand and Foot—
Free Up and Adjust



616

1. Remove hub caps, using special wrench S. T. 129
2. Remove both rear wheels, using a special wheel puller S. T. 1883 (report condition of expanding rings)
3. Free up all brake connections
4. Adjust expanding rings, using a dummy drum
5. Replace wheels
6. Adjust foot brakes (See operation A11)
7. Adjust front cap shaft, adjusting screws equally until the wheels are just free
8. Adjust hand brake pull rod and check equalization of rear wheels
9. Report to foreman on any additional work required

Material

Same as A26

640

Material**Front Brake Lever Gauge****Rear Brake Lever Gauge**

Rear Axle Shaft Nut—Tighten One Side	626	A30
1. Jack up rear wheel		
2. Remove hub cap and cotter pin		
3. Tighten axle shaft nut, using special long handle wrench S. T. 133		
4. Fit new cotter pins and replace hub cap		
Material		
Same as 626	640	
Material		
Wheels Rear—Tighten on Axles	626	A31
1. Jack up rear end of chassis		
2. Remove hub caps and cotter pins		
3. Tighten axle shaft nuts, using special long handle wrench S. T. 133		
4. Fit new cotter pins and replace hub caps		
Material		
Same as 626	640	
Material		
Front Axle Brake Support Plate—Renew Both (Includes S251)	626	A32
1. Disconnect front brake cable		
2. Remove brake shoes		
3. Remove front brake camshaft leather boot and camshaft from support plate		
4. Remove front wheel brake support plate		
5. Assemble new plates, drawing nuts tight Note: Check for proper steering knuckle and foot brake adjustment. See Operation A11		
6. Replace camshaft and leather boot		
Material		
1-163202 Plate Left		
1-163208 Plate Right		
Miscellaneous		
Same as 626	640	
Material		
1-163202 Plate Left		
1-163208 Plate Right		
Miscellaneous		
Axle Shaft Key—Renew One	626	A33
1. Remove hub cap, cotter pin, nut, rear wheel, using cap wrench S. T. 129, nut wrench S. T. 133, and puller S. T. 681		
2. Fit new axle shaft key		
3. Replace wheel, drawing nut up tight		
4. Install cotter pin and hub cap		
Material		
1-120489 Key		
Same as 026	640	
Material		
1-140073 Key		

A34 Front Axle Brake Support Plate—Renew One 626
 (Includes S220)

1. Remove brake shoes
2. Remove old brake support plate
3. Supply and install new plate
 Note: Check steering knuckle for proper adjustment
4. Adjust foot brakes (See Operation A11)

Material

1-163202 Plate—Left

or

1-163208 Plate—Right

Miscellaneous

Same as 626 640**Material**

1-163202 Plate—Left

1-163208 Plate—Right

Miscellaneous

A35 Front Axle Brake Cable—Renew Both 626

1. Remove the old cable
2. Supply and install new cable
3. Adjust front cables so that the camshaft lever is $\frac{1}{2}$ inch ahead of camshaft center or use two gauges. See Operation A11 for foot brake adjustment

Material

2-157944 Cable

4- 7515 Yoke

4-126586 Studs

Same as 626 640**Material**

2-157945 Cable

4- 7515 Yoke

4-126586 Studs

A36 Front Axle Brake Cable—Renew One 626

1. Remove the old cable
2. Supply and install cable
3. Adjust front cable so that the cam-shaft lever is $\frac{1}{2}$ inch ahead of cam-shaft center, or use gauge. See Operation A11 for foot brake adjustment

Material

1-157945 Cable

2- 7515 Yoke

2-126586 Studs

Same as 626 640**Material**

1-157945 Cable

2- 7515 Yoke

2-126586 Studs

Front Axle—Renew

626 A38

1. Disconnect steering connecting rod and cross tube
2. Remove wheels and hubs, using special hub cap wrench S. T. 129
3. Disconnect hydraulic shock absorber
4. Remove front brake support plate with shoes
5. Remove steering knuckles
6. Remove axle from chassis
7. Supply and install new front axle
8. Reassemble

Note: See that steering knuckles have proper adjustment and trim wheels, using alignment jig No. S. T. 128

Material

1-157762 Front Axle

1 Lb. Grease

Same as 626

640

Note: See that the front spring center bolt enters hole in spring seat on axle and that springs are securely fastened

Material

1-157762 Front Axle

1 Lb. Grease

**Wheels—Front and Rear—Tighten Clamping Ring Bolts
(Disteel Wheel)**

626 A39

1. Draw up on clamping ring bolts

Material

Same as 626

640

Material**Wheels—Rear—Remove and Replace**

626 A310

1. Remove hub cap, cotter pin and axle shaft nut, using wrenches S. T. 129 and S. T. 133
2. Remove both wheels with puller, using S. T. 083
3. Replace on axle shafts and draw nuts tight
4. Replace cotter pin and hub caps

Note: Be sure that hand brake is in off position before pulling rear wheels
Report condition of brake shoes

Material

Same as 626

640

Material

A311 Brake Drum Assy. Front Renew One
(DSteel Wheel) (Wheels Off) 626

1. Assemble new drum in place.
 2. Slack away brake bands to allow new drum ample room, draw up wheel tight on axle stud and replace center and hub cap.
 3. Adjust brakes.
- Note: Be sure to lubricate bearings with grease.

Material

1-163079 Drum - Front

1-lb. Grease

Same as 626

640

Material

1-163029 Drum - Front

1-lb. Grease

A312 Rear Axle Shaft Bearing Dust Washer and Retainer—626
Renew Both
(Includes A310)

1. Disconnect brake end.
2. Remove brake support plate and pull axle shaft retainer.
3. Supply and install new leather washers. Felt washer into retainer.
4. Pack axle shaft bearings with grease.
5. Replace axle shaft and support plate and tighten.
6. Replace brake end.

Material

2-138599 Leather Washers

2-121110 Felt Washers

2-121111 Retainer

Grease

Wheel Rear Dust Washer and Retainer —Renew Both
(Includes A310) 640

Same as 626

Material

2-138524 Leather Washers

2-121655 Felt Washers

2-124715 Retainer

Grease

A313 Rear Axle Shaft Bearing Retainer Dust Washer 626
Renew (One Side) (Includes A348)

1. Remove bearing retainer and pull axle shaft.
2. Remove retainer and dust washer.
3. Pack axle shaft with grease.
4. Supply and install new retainer and dust washer.

Material

1-121110 Washer

1-121111 Retainer

1-138599 Leather Washer

Same as 626

640

A313
Cont.**Material**

1-124635 Bolt Washer

1-124715 Retainer

1-138524 Leather Washer

**Wheel—Rear—Hub Assembly—
Renew One (Disteeel Wheel) Wheels Off**626 **A322**

1. Replace hub assembly and wheel

2. Adjust brakes (See operation A11)

Note: For removing hub cap, use hub cap wrench S. T. 129. To remove axle shaft nut, use wrench S. T. 133. Use wheel puller S. T. 1183 to remove wheels.

Before pulling rear wheels be sure hand brake lever is in off position

Material

1-163028 Hub Assembly

1-120480 Key

Same as 626

640

Material

1-163027 Hub Assembly

1-140073 Key

Axle Shaft Bearing—Renew626 **A324**

1. Jack up chassis and remove rear wheel using puller S. T. 123
2. Disconnect brake rod
3. Remove brake support plate from axle (do not remove brake shoes)
4. Remove axle shaft and sleeve
5. Remove axle shaft bearing, check nut lock and nut
6. Remove bearing and replace with new
7. Replace check nut and tighten
8. Replace lock and tighten set screw
9. Pack axle shaft with grease
10. Reassemble and tighten axle shaft and wheels

Material

1- 63165 Bearing

Same as 626

640

Note: Axle shaft bearing check nut is drilled in place and locked with lock wire

Material

1- 62580 Bearing

Rear Axle Case Assembly—Renew626 **A329**

Note: Protect trimming from oil and grease by using seat covers

1. Hoist rear of car, using chain falls and jack up rear of body
2. Remove hub caps and wheels and axle shaft
3. Drain oil and remove universal joint
4. Remove differential carrier, cap screws and carrier
5. Pull carrier from under chassis
6. Remove rear axle spring clips
7. Remove all brake connections and shoes
8. Reassemble all parts into the new rear axle case
9. Replace case and tighten clips
10. Replace carrier to housing and fill with oil
11. Replace axle shaft and wheels
12. Rebuild the entire job and set up foot brakes
13. Test for quiet axle

A 329 Material

Cont. 3 Qts. Oil
1-140431 Gasket
1-157763 Case

Same as 626

640

Material

1-157767 Case
1-141345 Gasket
 $3\frac{1}{2}$ Qts. Oil

A 330 Rear Axle Case Rear Cover - Renew

626

1. Drain oil
2. Remove cap screws
3. Report condition of differential gear to foreman
4. Install new cover and tighten
5. Fill with new oil

Material

3 Qts. Oil
1-140431 Gasket
1-140433 Cover

Same as 626

640

Material

1-141345 Gasket
1-141344 Cover
 $3\frac{1}{2}$ Qts. Oil

A 331 Rear Axle Case Rear Cover Gasket - Renew

626

1. Drain oil
2. Remove cap screws from rear cover
3. Report condition of differential gears to foreman
4. Install new gasket
5. Replace cover and tighten. Fill with oil

Material

3 Qts. Oil
1-140431 Gasket

Same as 626

640

Material

$3\frac{1}{2}$ Qts. Oil
1-141345 Gasket

Rear Axle and Differential—Remove, Inspect for Necessary Repairs and Replace (Due to Accident)
626 A334

Note: Protect trimmings from oil and grease by using seat covers

1. Hoist rear of car, using chain falls and jack up rear of body
 2. Remove hub caps and wheels and axle shaft and inspect for bent axle
 3. Drain oil and remove universal joint
 4. Remove differential carrier, cap screws and carrier
 5. Pull carrier from under chassis
 6. Dismantle differential for inspection for sprung parts
 7. Wash and clean all parts thoroughly and blow off with air hose
 8. Remove spring bolts and drop rear axle case assembly and hydraulic shock absorbers
 9. Make thorough inspection on differential case. If sprung or broken report to foreman
 10. Reassemble parts into differential carrier
 11. Replace rear axle case and tighten spring bolts.
- Note: The front faces of the ring gear and pinion should be flush. For detail information on adjusting ring gear and pinion, see Technical Letter No. 1735
12. Replace carrier to housing and fill with oil
 13. Replace axle shaft and wheels
 14. Rebuild the entire job
 15. Set up foot brakes

Material

3 Qts. Oil

2-140-631 Rear Axle Case Gasket

Same as 626

640
Material

3½ Qts. Oil

1-141345 Rear Axle Case Gasket

Rear Axle Shaft Key - Renew Both
626 A335

1. Hoist rear of car, using chain falls
2. Pull both rear wheels
3. Replace with two new axle shaft keys
4. Replace wheel and tighten

Note: Be sure that hand brake is in off position before pulling rear wheels and report condition of hand brakes

Material

2-120489 Keys

Same as 626

640
Material

2-140073 Key

Rear Axle Case and Differential—Overhaul Complete (Due to Accident) (Includes A-334) (Labor Only)
626 A336

1. Use new parts necessary to put in first class condition
2. Test for quiet axle

Note: Add material to this operation only

Material

Same as 626

640
Material

A 337 Rear Axle Case--Rear Cover - Remove, Inspect Differential Gears and Replace 626

1. Remove differential cover and drain oil
2. Inspect differential gears thoroughly. Report to foreman if necessary to put in first class condition
3. Replace cover and tighten, using new gasket
4. Rebill with old oil

Material

1-140131 Gasket

Same as 626

640

Material

1-141345 Gasket

A 348 Wheel- Rear—Remove and Replace One 626

1. Remove hub cap, using wrench S. T. 129
2. Remove cotter pin and axle nut, using S. T. 133
3. Pull wheel, using puller S. T. 183
4. Reassemble and adjust brakes if necessary. See Operation A11
Note: Hand brake lever should be in off position before pulling rear wheel. Be sure and pack axle shaft bearing with grease

Material

Same as 626

640

Material

A 350 Rear Axle Bearing Jam Nut - Tighten (Includes A348) 626

1. Remove axle shaft
2. Remove set screw in check nut
3. Tighten check nut
4. Drill new hole in axle shaft and tighten set screw
5. Pack axle shaft bearing with grease
6. Replace axle shaft and tighten

Material

Same as 626

640

Material

A 352 Brake Drums—Turn Down (Includes A310) 626

1. Turn down drums to smooth up

Material

Miscellaneous

Brake Drums - Turn Down (Includes A310) 640

1. Turn down drums to smooth up
Note: Report condition of hand brake shoes

Material

Miscellaneous

**Rear Axle Shaft -- Remove and Straighten One
(Includes A348)****626 A 361**

1. Remove bearing retainer and pull axle shaft
2. If it is sprung to any extent, place it between centers in a lathe, or axle shaft can be straightened in an arbor or straightening press by supporting the two ends with blocks and applying the pressure on the center where it is sprung
3. Pack axle shaft bearing with grease. Replace and tighten

MaterialSame as 626 **640****Material****Front Axle—Remove, Straighten and Replace
(Includes A40) (Labor Only)****626 A 380**

1. Remove and place axle into blacksmith shop and straighten

MaterialSame as 626 **640****Material****Front Axle Rubber Bumper -- Renew One****626 A 381**

1. Remove the old rubber bumper bracket
2. Install new rubber bumper and tighten

Material

1-147298 Bumper

Same as 626 **640****Material**

1-147298 Bumper

Front Axle Remove, Dismantle and Replace

626

A40

1. Disconnect steering connecting rod front end and hydraulic shock absorbers
2. Remove wheels
3. Remove front brake support plates with shoes
4. Remove steering knuckles
5. Remove front spring clips
6. Raise weight of car and pull axle from under
7. Clean parts thoroughly and inspect for wear and bent axle
8. Replace front axle
9. Replace spring clips, reassemble connecting rod and hydraulic shock absorber
10. Replace steering knuckles and support plates
Note: See that steering knuckles have proper adjustment. See S119 and trim wheels, using aligning jig S. T. 128
11. Replace wheels (See S221 for wheel adjustment)
12. Let weight of car down on axles

Material

1 Lb. Grease

Front Axle—Remove, Dismantle and Replace

640

1. Disconnect steering connecting rod and cross tube
2. Remove wheels and hub caps, using hub cap wrench S. T. 129
3. Disconnect hydraulic shock absorbers
4. Remove front brake support plate with shoes
5. Remove steering knuckles
6. Remove axle from chassis
7. Replace axle and reassemble
8. Replace springs clips, reassemble connecting rod and hydraulic shock absorber
Note: See that steering knuckles have proper adjustment
9. Let weight of car down on axle
10. Turn front wheels, using S. T. 128

Material

1 Lb. Grease

Rear Axle Shaft—Replace One

626

A41

(Includes A348)

1. Remove brake support plate from axle housing
Note: Do not remove brake shoes
2. Remove axle shaft
3. Remove axle shaft bearing from retainer
4. Remove set screw and check nut
5. Remove axle shaft from bearing
6. Supply and install new axle shaft
7. Replace bearing, check nut and tighten
8. Drill new hole in axle shaft and tighten set screw
9. Pack axle shaft bearing with grease
10. Replace and tighten brake support plate

Material

1-120489 Key

1-140390 Axle Shaft

Same as 626

640

Material

1-140073 Key

1-138163 Axle Shaft

**A42 Rear Axle Brake Support Plate—Renew One
(Includes A34B)**

626

1. Remove brake shoes from support plate
2. Remove axle shaft and support plates
3. Remove brake cam-shaft and bearing
4. Install new brake support plate
Note: Pack axle shaft bearings with grease
5. Replace brake cam-shaft and bearing
6. Replace brake support plate and axle shaft
7. Replace brake shoes and adjust brakes (See operation A11 for foot brake adjustment)

Material

1-164203 Support Plate - Left

or

1-164209 Support Plate - Right

Same as 626

640

Material

1-163264 Support Plate - Left

or

1-1n5216 Support Plate - Right

**A43 Differential Ring Gear and Pinion—Renew
(Includes A410)**

626

1. Install new ring gear and pinion
2. Adjust for standard clearance (.000" to .010" backlash)
Note: Front faces of gear and pinion teeth should be flush. Detail information on assembling carrier at Technical Letter No. 1735

Material

1-141462 Gear and Pinion Assembly

or

1-141461 Gear and Pinion Assembly

or

1-141912 Gear and Pinion Assembly

Miscellaneous

Same as 626

640

Material


1-141460 Gear and Pinion Assembly

or

1-141903 Gear and Pinion Assembly

or

1-141459 Gear and Pinion Assembly

Miscellaneous

Tools Nos. S. T. 670-671

The hypoid gear tooth ends do not run flush and it is necessary to set the depth of the pinion by measurement. The gauge shown here is an accurately ground gauge for this purpose.

**Differential Pinion Shaft - Adjust
To Eliminate End Play****626 A45**

1. Loosen lock nut and snug up on the (inside sleeve) and lock adjustment
2. Test for quiet axle.

Note: If further adjustment is necessary report to foreman.

Material

Same as 626

640**Material****Rear Axle Brake Support Plate - Renew Both
(Includes A310)****626 A46**

1. Remove brake rod
2. Remove brake shoe assembly from support plates
3. Remove axle shaft and support plates
4. Remove brake camshaft and bearing from support plates


Note: The long end of the foot brake operating lever cam operates the primary shoe; the short end of the cam operates the auxiliary shoe. Care should be taken that the cam is assembled properly.

5. Install new brake support plates
6. Note: Pack axle shaft bearing with grease
7. Replace brake camshaft and bearing
8. Replace brake support plate and axle shaft

Note: See Operation A11 for foot brake adjustment.

Material1-163203 Support Plate
1-163209 Support Plate

Same as 626

640**Material**1-163204 Support Plate
1-163210 Support Plate

Combination Shop Jack
Tool No. S. T. 154 - All Models


A47 Differential Carrier and Caps Assembly Renew

626

Note: It is not necessary to pull hub caps, axle shaft nuts or wheels. To protect tripping from oil and grease, use seat covers S. T. 145 and double door covers S. T. 146.

1. Jack up rear end of chassis, using jacks S. T. 164 or 165.
2. Disconnect rear brake rods.
3. Remove one upper bolt from rear brake support plate assembly.
Note: Use a $\frac{1}{4}$ x 20 stud, with a slot cut in end of stud so that it can be turned with a screw driver and insert stud in hole from which bolt was removed. This stud acts as a guide when reattaching wheel and support plate assembly and must enter original hole in axle case from which it was taken. Mark rear axle case and support plate with a screw driver, so that support plate can be returned to its original position.
4. Drain oil.
5. Remove remaining bolts holding brake support plate to rear axle.
Note: Pull wheels, axle shafts and brake support plates in one unit just far enough to remove differential.
6. Disconnect universal joint and move to one side.
7. Remove differential carrier, cap screws and carrier.
8. Pull carrier from under chassis.
9. Remove two ring gear bearing adjusting nuts and ring gear.
10. Remove pinion bearing sleeve lock.
11. Remove inner and outer pinion bearing sleeves.
12. Remove pinion.
13. Wash and clean all parts thoroughly and inspect.
14. Reassemble old parts into new carrier.
15. Reassemble pinion inner and outer sleeve.
16. Replace ring gear and bearing adjusting nuts and adjust to standard clearance, from .008" to .010" backlash.
Note: Adjust so that the pinion teeth are flush with the ends of the ring gear teeth, with the teeth properly meshed. For further detail information on adjustment see Technical Letter 1679.
17. Replace differential and fill with oil.
18. Replace axle shaft, wheel and brake support plate units.
19. Test for quiet axle.

Universal Joint Flange Puller



Material

3 Qts. Oil
1-143318 Carrier
1-140431 Gasket
Same as 626

A47*Cont.***640****Material**

1-143319 Carrier
1-141345 Gasket
3½ Qts. Oil

**Differential Remove
and Dismantle, Report and Replace****626 A410**

Note: It is not necessary to pull hub caps, axle shaft nuts or wheels. To protect trimming from oil and grease, use seal covers S. T. 145 and double door covers S. T. 146.

1. Jack up rear end of chassis, using jacks S. T. 154 and S. T. 155
2. Disconnect rear brake rods
3. Remove one upper bolt from rear brake support plate assembly
Note: Use a 5/8 x 20 stud, with a slot cut in end of stud so that it can be turned with a screw driver and insert stud in hole from which bolt was removed. This stud acts as a guide when replacing wheel and support plate assembly and must enter original hole in axle case from which it was taken. Mark rear axle case and support plate with a screw driver, so that support plate can be returned to its original position.
4. Drain oil
5. Remove remaining bolts holding brake support plate to rear axle
Note: Pull wheels, axle shafts and brake support plates in one unit just far enough to remove differential.
6. Disconnect universal joint and move to one side
7. Remove differential carrier, cap screws and carrier
8. Pull carrier from under chassis
9. Remove two ring gear bearing adjusting nuts and ring gear
10. Remove pinion bearing sleeve lock
11. Remove inner and outer pinion bearing sleeves
12. Remove pinion
13. Wash and clean all parts thoroughly and inspect
14. Reassemble pinion inner and outer sleeve
Note: Reassemble old parts into new carrier.
15. Replace ring gear and bearing adjusting nuts and adjust to standard clearance, from .000" to .010" backlash
Note: Adjust so that the pinion teeth are flush with the ends of the ring gear teeth, with the teeth properly meshed. For further detail information on adjustment, see Technical letter 1678.
16. Replace differential and fill with oil
17. Replace axle shaft, wheel and brake support plate units
18. Test for quiet axle

Material

1-140431 Gasket
3 Qts. Oil
Same as 626

640**Material**

1-141345 Gasket
3½ Qts. Oil

A411**Differential--Recondition (Labor Only)****626**

Note: It is not necessary to pull hub caps, axle shaft, nuts or wheels. To protect trimmings from oil and grease, use seat covers S. T. 145 and double door covers S. T. 146.

1. Jack up rear end of chassis, using jacks S. T. 154 or 155.
2. Disconnect rear brake rods.
3. Remove one upper bolt from rear brake support plate assembly.
Note: Use a $\frac{1}{4}$ x 20 stud, with a slot cut in end of stud so that it can be turned with a screw driver and insert stud in hole from which bolt was removed. This stud acts as a guide when replacing wheel and support plate assembly and must enter original hole in axle case from which it was taken. Mark rear axle case and support plate with a screw driver, so that support plate can be returned to its original position.
4. Drain oil.
5. Remove remaining bolts holding brake support plate to rear axle.
Note: Pull wheels, axle shafts and brake support plates in one unit just far enough to remove differential.
6. Disconnect universal joint and move to one side.
7. Remove differential carrier cap screws and carrier.
8. Pull carrier from under chassis.
9. Remove two ring gear bearing adjusting nuts and ring gear.
10. Remove inner and outer pinion bearing sleeves.
11. Remove pinion.
12. Wash and clean all parts thoroughly and inspect.
13. Use new parts necessary to put in first class condition.
14. Reassemble pinion inner and outer sleeve.
15. Replace ring gear and bearing adjusting nuts and adjust to standard clearance, from .006" to .010" backlash.
Note: Adjust so that the pinion teeth are flush with the ends of the ring gear teeth, with the teeth properly meshed. For further detail information on adjustment see Technical Letter 1679.
16. Replace differential and fill with oil.
17. Replace axle shaft, wheel and brake support plate units.
18. Test for quiet axle.
Note: The estimated zone prices of parts required to recondition differential are: 1st zone, \$39.25; 2nd zone, \$41.15; 3rd zone, \$45.00. All parts listed should not be required.


Material

1-140411 Rear Axle Case Gasket or
1-141402 Driving Gear and Pinion Assembly .4-08 to 11 or
1-131401 Driving Gear and Pinion Assembly .4-09 to 11 or
1-141902 Driving Gear and Pinion Assembly .4-38 to 11.
2-139708 Differential Bearings
2-124616 Differential Gears
1-138920 Pinion Bearing
1-138440 Pinion Bearing
1-124618 Differential Spitzer
1-138564 Dust Washer and Retainer Assembly
4-124617 Pinions
5 Qts. Oil

Differential Recondition**640**

Same as 626

Note: The estimated zone prices of parts required to recondition differential are: 1st zone, \$42.05; 2nd zone, \$44.10; 3rd zone, \$48.85. All parts listed should not be required.



Rear Axle Brake Construction

Material

- 1-141315 Rear Axle Case Gasket
 1-141460 Driving Gear and Pinion Assembly (4.67 to 1) ...
 or
 1-141450 Driving Gear and Pinion Assembly (4.07 to 1) ...
 or
 1-141903 Driving Gear and Pinion Assembly (4.38 to 1) ...
 2-139587 Differential Bearings ...

A411
Cont.

A411	2-124616 Differential Gears
	1-138908 Pinion Bearing
<i>Cont.</i>	1-138141 Pinion Bearing
	1-138584 Dust Washer and Retainer
	1-124638 Differential Spider
	4-124617 Differential Pinions
	3 $\frac{1}{2}$ Qts. Oil

A416 Differential Carrier Assembly - Renew 626

Note: It is not necessary to pull hub caps axle shaft, nuts or wheels
To protect trimming from oil and grease use seat covers S. T. 145 and double
door covers S. T. 146


1. Jack up rear end of chassis using jacks S. T. 164 and S. T. 165
2. Disconnect rear brake rods
3. Remove one upper bolt from rear brake support plate assembly
Note: Use a 17-20 stud, with a slot cut in end of stud so that it can be turned with a screw driver and insert stud in hole from which bolt was removed. This stud acts as a guide when replacing wheel and support plate assembly and must enter original hole in axle case from which it was taken. Mark rear axle case and support plate with a screw driver so that support plate can be returned to its original position
4. Drain oil
5. Remove remaining bolts holding brake support plate to rear axle
Note: Pull wheels, axle shaft and brake support plates in one unit just far enough to remove differential
6. Disconnect universal joints and move to one side
7. Remove differential carrier cap screws and carrier
8. Pull carrier from under chassis
9. Replace new differential and fill with oil
10. Replace axle shaft, wheel and brake support plate units
11. Test for quiet axle

Material

1-140431 Gasket
1-138593 Carrier Assembly (5.08 to 1) (326-333)
1-141368 Carrier Assembly (4.38 to 1) (326) ^{DR}
1-144173 Carrier Assembly (4.69 to 1) ^{DR}
1-140435 Carrier Assembly (5.08 to 1) ^{DR}
Same as 626	640

Material

1-111345 Gasket
1-141367 Carrier Assembly (4.07 to 1) (326)
1-141376 Carrier Assembly (4.69 to 1) ^{DR}
1-144174 Carrier Assembly (4.38 to 1) ^{DR}
1-144174 Carrier Assembly (4.38 to 1) (443) ^{DR}



**Side Wheel Carrier Renew (Right or Left
(Labor Only)**

1. Remove wheel lock and wheel
 2. Remove four bolts from carrier bracket
 3. Install new wheel carrier and tighten
 4. Install wheel and lock

4. Material

Material

645 A531

**Windshield Glass - Reset
(Closed Bodies - Labor Only)**
626 B47

1. Loosen wing nuts and swing upper half of windshield upward as far as it will go
2. Remove screws holding hinge of upper half of windshield to body
3. Remove upper half of windshield
4. Remove four screws holding lower windshield frame in position
5. Shake windshield, so as to loosen windshield lower frame from fence, and remove lower frame
6. Remove screws and caps holding glass in top and bottom windshield frames
7. Remove glass and old felt filler
Note: To remove glass, tap windshield frame lightly on bench or use soft hammer
8. Fit new felt to old glass and replace glass to frames
9. Replace upper and lower halves of windshield to body and tighten securely

Material**Filler**
**Windshield Glass - Reset
(Open Bodies - Labor Only)**
626

1. Remove all side curtains and unfasten both rear side quarters
2. Remove nuts at top of windshield stanchion
3. Lay top back far enough so that windshield can be removed
4. Remove nuts and lock washers at bottom of windshield stanchion
5. Remove windshield
6. Remove stanchion wing nuts, screws and both halves of windshield
7. Remove screws and caps holding windshield glass in frames and remove glass and felt filler
Note: To remove glass, tap windshield frame lightly on bench or use soft hammer
8. Fit new felt to old glass and replace glass to frames
Note: Be sure that glass is notched properly so that glass retaining clips set in their proper place
9. Replace upper and lower halves of windshield to stanchions and tighten securely
10. Replace windshield assembly to body and tighten nuts at bottom of stanchion
11. Fasten top to windshield and replace any curtains that were removed

Material**Filler**
(Closed Bodies - Labor Only)
640

Same as 626

Material**Filler**
(Open Bodies - Labor Only)
640

Same as 626

Material**Filler**

B48 Windshield Glass Renew (One Piece Windshield) 626
(Open Body) (Labor Only)

1. Remove all side curtains and unfasten both rear side quarters
2. Remove nuts at top of windshield stanchion holding top to windshield
3. Lay top back far enough so that windshield can be removed
4. Remove nuts and lock washers at bottom of windshield stanchion
5. Remove windshield and stanchion assembly
6. Remove six screws holding windshield frame to stanchion
7. Remove four screws holding upper section of windshield frame to lower section and remove upper section
8. Remove glass and felt filler
 Note: To remove glass, tap frame lightly on bench or use soft hammer
9. Fit old felt to new glass and replace to windshield frame
10. Reassemble in reverse order of removal

Material

1-139119 Glass
 or
 1-139020 Glass

(Labor Only) 640

Same as 626

Material

1-139119 Glass
 or
 1-139020 Glass

Windshield Glass - Renew One-Piece Windshield 626
(Closed Body) (Labor Only)

1. Loosen clamp screws, swing windshield inward and tighten clamp screws so as to hold windshield open
2. Remove six screws holding lower section of windshield frame to upper section and remove lower section and clamp screws
3. Remove glass and old felt filler
 Note: To remove glass, tap windshield frame lightly on bench or use soft hammer
4. Fit old felt to new glass and replace glass to frame
5. Replace and tighten lower section of windshield frame to upper section
6. Replace windshield to body and tighten securely
7. Replace and tighten clamp screws

Material

1-139073 Glass

(Labor Only) 640

Same as 626

Material

1-139074 Glass

**Speedometer Driving Shaft—Renew
(Labor Only)**626 **B51**

1. Remove old shaft.
2. Install new driving shaft of correct length properly lubricated. (See that head operates freely.)
Note: Be sure ends of cable enter driving shaft and speedometer elbow properly.
3. Assemble to car with no sharp bends (limit 6° radius).
Note: If the speedometer vibrates or jumps, look for loose coupling or connections, too sharp a bend in the flexible shaft, lack of lubrication, or gears that do not mesh properly.

Material

1-146618 Speedometer Driving Shaft

(Labor Only)

640

Same as 626

Material

1-146618 Speedometer Driving Shaft

**Speedometer Head—Renew
(Labor Only)**626 **B54**

1. Disconnect cable and remove old head from instrument board.
2. Install new head and connect up.
Note: If the speedometer vibrates or jumps, look for loose coupling or connections, too sharp a bend in the flexible shaft, lack of lubrication, or gears that do not mesh properly.

Material

1-158252 Head

^{or}

1-158251 Head

^{or}

1-158250 Head

^{or}

1-158249 Head

Same as 626

640

Material

1-158252 Head

^{or}

1-158251 Head

^{or}

1-158250 Head

^{or}

1-158249 Head

Body Bolts Tighten All

626

B61

Note: To eliminate body squeaks, it is advisable to loosen body bolts, raise body, using a crow bar or chisel to pry up body, and apply cup grease to body liner, using a hack saw blade or some other suitable tool.

1 Tighten all body to frame bolts securely

Note: If bolts turn in body sill and cannot be tightened cut them off and install new ones. A large machine hack saw blade with a wooden handle attached should be used. Drive a steel wedge in between body sill and frame close to the bolt to be removed. Insert saw blade between body sill and frame. Cut bolt in two. Remove the old bolt, install a new one and tighten nut securely.

Material

Same as 626

640

Material**Door Lock Striker—Renew One
(Open Body)**

626

B62

1. Remove screws holding old striker in place and remove old striker
2. Supply and install one door lock striker

Note: Door lock striker must be fitted so that the door can be easily slammed shut, with the bushings holding a slight pressure against the door lock.

Material

1-131797 Striker

(Open Body)

640

Same as 626

Material

1-131197 Striker

**Door Glass—Front or Rear—Renew
(Closed Body) (Labor Only)**

626

B63

Note: Remove glass without disturbing upholstering.

1. Run glass down to the bottom of the door

2. Remove door lock lever handle, nut and lever handle

Note: Do not mar handle on handle.

3. Remove screws and moulding

Note: It is not necessary to remove runway channels.

4. Turn window regulator, raise window within an inch or two of the top, tip the glass toward the inside of the door and remove glass from window regulator roller

5. Replace glass

Note: When replacing glass be sure to engage arm roller in slot in glass channel.

6. Replace moulding and lever handle

Note: Window must operate freely. If broken glass is found lying at the bottom of the door, it is necessary to remove the upholstery at the bottom to remove broken glass. This will help to eliminate rattles.

Material

1 Glass

**Door Glass—Front or Rear—Renew
(Closed Body) (Labor Only)**

640

Same as 626

Material

1 Glass

B610 Body Change

(Open to Closed or Vice Versa)

626

Note: Use front seat covers S. T. 144 and S. T. 145 rear seat covers and cowl cover S. T. 148 to protect trimming and finish of body.

1. Remove rear fenders.
2. Remove all body bolts.
- Note: If bolts turn in body sill and cannot be removed, cut them off, using a hack saw blade. Drive a steel wedge in between the body sill and the frame, close on the bolt, insert hack saw blade between the body sill and frame and cut bolt in two.
3. Disconnect all electrical connections leading to dash and engine.
4. Remove steering wheel.
5. Remove toe boards, floor boards and accelerator pedal.
6. Disconnect speedometer and gasoline gauge cables.
7. Disconnect and remove lubricating tank and oil gauge.
8. Remove ammeter, speedometer head and cigar lighter and coil.
9. Disconnect steering to dash bracket.

Note: If car is equipped with spot light, disconnect same.

10. Remove body.
- Note: Hoist up body and remove chassis from under body.
11. Supply and install new body.

12. Tighten all body bolts and check entire body for rattles.
- Note: Shim body to correct clearance around doors. Loosen body bolt just below the door that is to be shimmed. If the clearance between the top of the door and body is not enough, shims must be added between the body and frame. If there is too much clearance between the top of the door and body, shims must be removed. Shims can be made of brake lining or wood. A slot should be cut in each shim so that it can be slipped in place around body bolts.
13. Replace floor boards, toe boards, accelerator pedal, rear fenders and steering wheel.

Note: To eliminate rattles around doors, change the position of door bumpers.

Material

Miscellaneous Bolts, etc.

(Open to Closed or Vice Versa)

640

Same as 626.

Material

Miscellaneous Bolts, etc. .

B627 Monogram (Standard) - Install

626

1. Select the desired monogram and place in position on body.
2. Use a chalk pouch to transfer design to body.
3. Select desired color paint and fill in monogram.

Material

Same as 626.

640

Material

Wash and Polish - Open Car**Eight C1**

1. Place car on wash rack equipped with suitable light and water supply.
2. Raise bonnet and cover motor with waterproof material to protect electrical and other parts.
3. Soak mud or dust off with plenty of running water. Do not use excessive water pressure.
Note: Use block of wood, hold radiator shutter open, clean radiator core with running water.
4. Use body sponge kept for that purpose to remove remainder of dirt, working in straight lines from top to bottom, NIP T.N.CIRCLLES. Rinse sponge often. If soap is necessary, use only the best commercial soft soap which is free from alkali or acids.
5. Dry each panel with clean chamois wrung out in clear water, working from top to bottom.
6. The chassis and under side of fenders should be flushed off with plenty of running water, using a sponge kept for the purpose. Oil and grease must be removed with a soap solution.
7. Polish nickel parts with a good nonabrasive silver polish. Frequent rubbing with an oily cloth will keep nickel surfaces bright. Interior fittings should never be polished.
Note: Wire wheel equipment, \$1.50 extra.

Material**Closed Car****Eight**

Same as above


Material**Wash Motor****Eight C3**

- Note: Always have a fire extinguisher at hand and be sure of its operating or disconnect battery cable.
1. Remove hood.
 2. Cover fenders and cowl, using fender covers S. T. 140 and cowl cover S. T. 148.
 3. Use kerosene gun and clean thoroughly and wipe off surplus kerosene or use air hose.
 4. Replace hood.
- Note: Do not use gun on newly painted jobs.

Material**Kerosene****Wash Motor and Transmission****Eight C6**

- Note: Have fire extinguisher at hand or disconnect battery cable.
1. Remove hood and front floor board.
 2. Cover fenders and cowl, using fender covers S. T. 140 and cowl cover S. T. 148, front seat cover S. T. 144 and double door covers S. T. 146.
 3. Use kerosene gun and clean motor and transmission thoroughly, then wipe dry.
 4. Replace floor board and hood.
- Note: Do not use gun on newly painted jobs.

Material**Kerosene**



Sectional View 626) Distributor

**Contact Arm Assembly and Adjusting Screw
Renew Both Sets**
626 E10

1. Remove distributor head and take out both contact arms and adjusting screws
2. Replace both contact sets and center
3. Adjust points .015" to .020"

Note: The contact points are made of thin discs of tungsten welded to alloy buttons, so care must be taken to remove only enough metal when truing points to get parallel surfaces. When the tungsten has been removed by reason of frequent refiling a new adjustable screw and contact arm is the only remedy

Material

- 2-19796 Breaker Arm
2-15959 Contact Screw

Name as 626

640
Material

Order from nearest North East station

- 2-19796 Breaker Arm
2-15959 Contact Screw

**Contact Arm Assembly and Adjusting Screw
Renew One Set**
626 E11

1. Remove distributor block and take out contact arm and adjusting screw
2. Supply and install new contact arm assembly and adjusting screw
3. Adjust points .015" to .020"
4. Clean head with sandpaper and wipe out with oily rag

Note: The contact points are made of thin discs of tungsten welded to alloy buttons, so care must be taken to remove only enough metal when truing points to get parallel surfaces. When the tungsten has been removed by reason of frequent refiling a new adjustable screw and contact arm is the only remedy

Material

- 1-19796 Breaker Arm
1-15959 Contact Screw

Order from nearest North East station

Name as 626

640
Material

- 1-19796 Breaker Arm
1-15959 Contact Screw

Order from nearest North East station

Ignition Coil - Renew One
626 E13

1. Supply and install one new ignition coil

Note: See that all terminals are tight. Frequently coils are replaced when it is unnecessary. Try alighting the points before you replace a coil. Misfiring is often caused by the breaker and spark plug points not being properly adjusted. To test ignition coil remove distributor cover and high tension wire leading to center of distributor cover. Turn on ignition switch, place end of high tension wire about $\frac{1}{8}$ of an inch of being grounded to any part of motor. Turn motor over until breaker points are both closed. Make and break contact points with finger or spread them apart. If the spark jumps from high tension wire to any part of the motor the coil is not defective.

E13**Material**

1-21106 Ignition Cut-off Lock

Cont. Same as 626

640

Material

1-21106 Ignition Cut-off Lock

E14 Condenser Renew One

626

1. Remove old condenser and install new.

Note: Check defective condenser by substituting a known good condenser and noting the effect upon the ignition. Its purpose is to prevent arcing and burning of the contact points and to interrupt the high tension current.

Material

1-16870 Condenser

Same as 626

640

Material

1-16870 Condenser

E16 Ignition High Tension Wires-
Renew All - Labor Only

626

1. Remove old high tension wiring and strip off terminals.
2. Use old wires for sample and cut new cable to length.
3. Solder on terminals and assemble on motor.
4. Test for correctness of assembly.

Note: When the ignition high tension wiring system gives trouble make sure that the wiring is in good condition, all terminals tight and connected up according to the wiring diagram, Part 1. A short circuit occurs when two wires of opposite polarity come in contact. This will discharge the storage battery in a very short time; therefore the greatest care should be taken to see that all connections remain tight and insulation of wires is not broken or cut.

Material

18 Ft. 78390 High Tension Wire

9-23800 Terminal Tube

9-13950 Terminal

Same as 626

640

Material

22 Ft. 78390 High Tension Cable

11-23800 Terminal Tube

9-13950 Terminal

E17 Distributor Head - Renew

626

1. Remove and dismantle.
2. Supply and install new distributor head.

Note: Be sure to get wires in their relative positions. See wiring diagram in Part 2.

IMPOSSIBLE CAUSES OF MISSING

- (a) If in any case no spark is observed, the cause of the trouble will be found in a grounded H. T. lead between distributor head and plug or—a burned distributor head. Remove ground or replace head.
- (b) If a good spark is observed in each case and miss is still present, the trouble will be found in a fouled or defective spark plug or in poor engine compression in one or more cylinders.

Material

1-20989 Head
1-20153 Cap

Name as 626

1-20989 Cover
1-20154 Cap

E17
Cont.

640

Delco Points—Adjust

626

E18

Note: Protect enameled surfaces from oil and scratches by using fender covers
S. T. 130

- 1 Remove head and rotor
2. Remove points and clean

Note: The contact points will require a little attention or refiling. They may be very rough when they become so badly burned, so as to cause missing. They should be trueed, so that their contact surfaces are exactly parallel. Adjust the contact points so that a gap of .015" to .020" is secured at their greatest separation

3. Clean head with sand paper and wipe with oily rag
4. Replace head and rotor

Note: See that condenser cable terminal does not lie against distributor housing, otherwise this will cause a short circuit and lack of power.

Material

Name as 626

640

Material**Spark Plugs—Clean and Adjust**

626

E19

Note: When cleaning spark plugs care should be taken so that nothing drops into the cylinder through the openings

- 1 Remove spark plug and clean

Thickness Gauge

Tool No. S. T. 457—All Models



E19

REGULAR MISSES IN ONE OR MORE CYLINDERS
POSSIBLE CAUSES

Cont.

1. Broken or defective spark plug
 2. Wire set of spark plug
 3. Wire clip of distributor head terminal
 4. Broken wire to the spark plug
 5. Wire to spark plug grounded
 6. Bad distributor head
2. Test and set standard $\frac{1}{16}$ " gap
 3. Replace and test motor oil filter
- Note: When replacing plug, be sure that plug gaskets are in proper position

Material

Same as 626

640**Material****E111**

Steering Gear Case Lighting Switch- Renew

626

1. Disconnect switch from steering
2. Remove all headlight wires from switch
3. Install new switch and connect all wires and see that all headlights and tail-light operate properly

Material

1-145657 Switch

Same as 626

640**Material**

1-145657 switch

E114

Ignition Timing - Set Standard

626

1. Remove starter motor
2. Turn motor to No. 1 cylinder firing center or on compressor and line up the mark "S1" on flywheel with crankcase timing indicator
3. Set spark advance lever in full advanced position on quadrant
4. Loosen clamp screw and rotate flywheel
5. Breaker points should just be rotated so rotor comes into No. 1 contact
6. Place a six volt lamp in series with breaker points
7. Turn ignition switch on and move cam clockwise until light goes out
- Note: Be sure contact points are not pitted. This will affect timing of ignition
8. Tighten clamp screw and retighten
9. Replace starter motor

Material

Same as 626

640**Material**

Ignition - Check Automatic Advance

626

E20

1. Remove starter motor.
2. Take off No. 6 spark plug wire and connect it with a wire extension about six feet long. The wire is easier to operate if it has an insulated handle with a metal point, although any piece of insulated high tension wire may be used.
3. When the motor is started and wire pointer is held just over surface of flywheel, with side of crankcase timing indicator which will be comparatively dark, will be illuminated by flash of spark, and since this occurs at exactly the same point each time, flywheel will have appearance of remaining stationary and any marks on circumference of wheel will be very clearly shown. After noting manner in which flywheel is illuminated, the motor should be stopped and flywheel marked in the following manner:
4. Put a short chalk mark ahead to the left of No. 6 top dead center to represent amount of fixed spark advance. This mark will be at point which is always used in checking fixed advance, or as follows:
Note: The advance setting is 18° on model 626 left on the flywheel.
5. After amount of fixed advance has been established in this way, make another and longer chalk mark across flywheel 18-30° ahead to the left of short mark. This long mark will indicate the automatic advance in manner noted below. The same dimension is used for all three models. Next, mark center line of motor on crankcase just over flywheel.
6. Start motor with throttle approximately closed, holding wire extension so that it flashes on flywheel. If flywheel will appear stationary and if spark is properly set, the short chalk mark which registers fixed advance will appear directly opposite crankcase dead center. If it appears on either side of crankcase center, the fixed spark is either too early or too late.
7. Now check the automatic advance by holding pointer in its position over the flywheel and speeding up motor until chalk mark appears to move. This means that the automatic is commencing to advance.
8. When motor is running slowly, the long chalk mark, which is to be used to check automatic advance, will be noted well to the left of crankcase dead center, but as motor speeds up, the mark will appear to move to the right. It should reach a position opposite crankcase dead center at a speed of approximately thirty miles per hour.

Material

Same as 626

640

Material**Generator - Renew**

626

E21

1. Remove three generator to crankcase stud nuts.
Note: Do not remove bronze housing into which the generator fits (generator sprocket support) as such removal will release front end chain, affecting timing of ignition and necessitate the dismantling of front end to get chain back into place.
2. Slip generator back, being sure not to disturb generator sprocket support.
3. Install new unit and adjust front end chain.
4. Test for quietness.
Note: Before making the following test see that all brushes are properly fitted and that the adjustment of the third brush does not change the output to desired value. If the generator cuts in late and does not deliver over 7 amperes at its peak, look for a short in the armature or an open in the light shunt field. Raising the third brush does not cut out the field, but only removes the regulating action. When the third brush alone is raised, the machine becomes a compound generator, giving a very high charging rate at high speeds. Therefore, to stop the machine from generating, it is necessary to raise two brushes. Any two brushes will do. When only one brush is raised, it will still leave one of the shunt field coils in operation.

E21	Material 1-125875 Generator	
Cont.	Same as 626	640
	Material 1-125875 Generator	

E22	Ignition Switch Renew (Labor Only)	626
------------	---	------------

1. Remove old switch
2. Replace new switch
3. Test

SWITCH TROUBLE POSSIBLE CAUSES

- 1—Loose connections or wire off switch
- 2—Burnt contacts
- 3—Shorted or grounded terminal
- 4—Loose internal switch connections
- 5—Circuit breaker contacts being held open

Switch circuits, combination switches Nos. 1277 and 1278. Both lighting and ignition levers off, terminals 1 and 2—4 and 5 are connected

Ignition lever on terminals 1, 2, 3 and 7 connected

Light lever in 1st position terminals 1, 7 and 4 connected

Light lever in 2nd position terminals 1, 4, 7 and 8 connected

Light lever in 3rd position terminals 1, 4, 7 and 6 connected

Light lever in 4th position terminals 1, 7, 4 and 5 connected

In order to test ignition switch to see if the current flows through it, turn on ignition switch. The ammeter on dash should show a discharge. If not disconnect wire marked ignition from the ignition switch and touch on terminal marked battery. If the ammeter shows a discharge, there is an open circuit in switch. Be sure that all terminals are tight. Do not leave ignition switch on when the engine is idle, as this discharges the battery needlessly, if the contacts happen to be closed. The circuit breaker, mounted on the back of the switch, protects the wiring and indicates by a clicking sound a ground in any of the lighting circuits.

Material

Order from nearest North East station

Switch

Same as 626	640
--------------------	------------

Material

Switch

E23	Generator Adjust Charging Rate	626
------------	---------------------------------------	------------

1. Remove generator brush cover
2. Adjust the main brush so that ammeter registers from 10 to 12 amperes
Note: See that generator commutator is clean and that brushes are making good contact. If necessary to change the charging rate shift the third brush holder as follows: To increase the generator charging rate, move the third brush holder up slightly. To decrease the charging rate, move the brush downward. Use a voltmeter to test charging rate. Dash ammeter is not reliable enough for testing output of generator. Run motor at a speed of from 18 to 20 miles per hour
3. Replace generator brush cover

Material

Same as 626

Material

640

Backing Light Switch Assembly—Renew**626 E24**

1. Remove floor boards
2. Disconnect the switch from cable
3. Install new switch
4. Test for proper functioning

Material

1-141951 Switch

Same as 626

640**Material**

1-141951 Switch

Stop Light Switch—Adjust**626 E25**

1. Remove floor boards
2. Adjust set screw

Note: For adjusting set screw, stop light should light when the pedal is depressed 1½ inches from floor boards. It is always advisable before making the adjustment on the stop light switch to see that the tail lamp bulb is in good condition.

Material

Same as 626

640**Material****Generator Cut-Out Assembly—Renew**

(Labor Only)

626 E26

1. Supply and install new generator cut-out assembly
2. Test

Note: The generator cut-out requires very little attention. You will note in some cases where the ammeter shows a discharge with the ignition switch in off position. This is caused by the contact points being burned or pitted through constant use, causing points to stick. This can be remedied by removing the burns or pits. Ammeter should register "0" when ignition switch is off. If the points burn off entirely or if the contact spring breaks, installing new parts is the only remedy.

Material

1-22248 Cut Out Assembly

Same as 626

640**Material**

1-22248 Cut Out

Dash Ammeter—Renew**626 E27**

1. Install new dash ammeter

Note: Examine generator brushes to see that they work freely, and are making good contact. See that commutator is perfectly clean. Examine circuit breaker and see that the points make contact. If not, clean them with your fingers. If the ammeter registers charge, with the engine running at a fair speed, ammeter is working properly. With the lights turned on and the engine idle, the ammeter should register discharge. If it stands at zero, remove the ammeter and replace with new. See that ammeter hand registers in the right direction, and if not, reverse wires on terminals.

Material

1-158234 Ammeter

Same as 626

640**Material**

1-158234 Ammeter

E28 Stop Light Switch - Renew 626

1. Remove switch.
2. Reassemble and adjust.

Note: For adjusting set screw the stop light should light when the pedal is depressed $\frac{1}{2}$ inches from floor boards.

Material

1-135009 Switch

Same as 626

640

Material

1-135008 switch

E211 Generator Commutator - Face Off and Renew Brushes (Includes E221) 626

1. Place armature in lathe and face off commutator.
 2. Underrut area between the segments, using a broken hack saw blade.
 3. Fit new brushes.
- Note: It is not advisable to change the central brush when fitting a new set of brushes. If the output of the generator is not the same as with the old brushes, when the new brushes run into perfect fit on the commutator, this output will automatically adjust itself. Brushes must move freely in brush guides.
4. Place springs back in position.
- Note: To test generator, connect one end of a six volt line to frame of generator, former; the other wire to the generator terminal. Close cut-out points. If generator has been assembled correctly, the armature should revolve the same direction as when in operation on the motor.

Material

1-22677 Fuse

1-22679 Insulator

1-22761 Brush

2-22762 Brush

Same as 626

640

Material

1-22677 Fuse

1-22679 Insulator

1-22761 Brush

2-22762 Brush

E220 Generator - Remove and Replace 626

1. Remove three (3) nuts holding generator in place and remove generator.
2. Slip generator back, being sure not to disturb generator sprocket support.
Note: Do not remove bronze housing into which generator fits, as such removal will release the front end chain, affecting timing of ignition and necessitate the disassembling of front end to get chain back into place.
3. Replace and adjust chain.

Material

Same as 626

640

Material

Generator Inspect (Off Car)**626 E221**

1. Remove band and brushes and brush head
Note: Do not pull the brush out by the head without lifting the spring as the spring may chip the brush when it snaps back
2. Remove commutator front end bearing and housing
3. Test armature and field for short circuits with test light. There are several methods for testing armatures. They can be tested with test lights and test points with a meter or with a gowker.
Note: (a) Test for grounds by fastening one end of the test line to armature shaft
 (b) Touch the other end of the test line to each commutator segment. The bulb should not burn. If a ground exists, the lamp will light
 (c) To test for open circuit, touch one end of the test line to each commutator segment
 (d) Beginning with the adjoining segment, touch each one with the other end of the test line
 (e) The bulb should burn on each segment
 (f) To test frame field for grounds, fasten one end of test line to generator frame
 (g) Touch the other end of the test line to each field connection. The bulb should not burn
 (h) To test frame field for open circuits, touch end of test line across the two field leads. The bulb should burn
 (i) If any grounds or open circuits are found, call the foreman's attention to it
4. Undercut mica between the segments
5. Reassemble

Note: It is not advisable to change the control brush when fitting new set of brushes

Material:

Same as 626

640**Material:**

Starter Motor—Renew**626 E32**

1. Disconnect cables
2. Remove cap screw in flywheel housing and slide motor forward and repeat
3. Replace unit, leaving cap screw hole and draw up screws
Note: Do not drive motor into place

Material

1-138092 Dynamo

Same as 626

640

Material

1-138083 Dynamo

Starter Switch—Renew**626 E34**

1. Remove accelerator pedal, pedal pads and floor boards
2. Disconnect starter switch from the board
3. Remove toe board
4. Disconnect battery
Note: This will remove all possibility of fire arising from igniting of gasoline around motor
5. Remove cable from starter switch
6. Supply and install new starter switch
7. Replace toe board, floor board and pedal pads
8. Connect battery cable and test on floor

Material

1-137015 Switch

Same as 626

640

Material

1-137015 Switch

Starter Motor Commutator—Face Off and Renew Brushes (Includes E331)**626 E311**

1. Place armature in lathe and face off
2. Undercut commutator between the segments, using a broken hack saw blade
3. Supply and fit new brushes
Note: Be sure that brushes bear on commutator and move freely in their guides

Material

2-13394 Brush

2-14481 Clip

Same as 626

640

Material

2-13383 Brush

2-14483 Clip

**E327 Starter Motor Drive Spring Screws—
Renew (Includes E331)** 626

1. Remove "Bendix" spring and shaft
2. Replace damaged screws
Note: Always use a new special lock washer when installing screws. Be sure that the bent tongue of each lock washer enters the spring eye.
3. Replace "Bendix" shaft and drive end housing
Note: Be sure "Woodruff" key enters slot properly.
4. Replace starter motor drive spring screw (front end)
5. Tighten both spring screws and bend the tongue of the lock washers tightly against the flat side of the screw head so it will not work out of position

Material

- 1-13093-6 Bendix Driving Screw
1-13093-5 Bendix Spring Clip
2-14483 Washers

Same as 626 626

Material

- 1-13093-5 Screw
1-13093-6 Screw
2-14483 Washers

E330 Starter Motor—Remove and Replace 626

1. Disconnect cables
2. Remove cap screw in flywheel housing and slide motor forward
3. Replace and tighten starter motor

Material

Same as 626 626

E331 Starter Motor Inspect (Off Car) 626

1. Remove brush lead and Bendix screws, spring and shaft
2. Test for grounds and open circuits
*Note: (a) To test for grounds, fasten one end of test line to armature shaft.
(b) Touch the other end of test line to armature segments. The bulb should not burn.
(c) To test for open circuits, touch one end of the test line to commutator segments.
(d) Beginning with the next segments, touch each one with the other end of the test line.
(e) The bulb should burn on each segment if the armature circuits are complete and free from grounds.
(f) To test the frame fields for grounds, fasten one end of the test line to the starter motor frame.
(g) Touch the other end of the test line to each field connection. The bulb should not burn.*
3. Undercut mica between the segments

Note: Be sure that brushes bear on commutator and move freely in their guides.

Reassemble**Material**

Same as 626 626

Material

Tail Lamp Renew

626 E42

- Supply and install new tail lamp.

Note: Be sure that stop light operates properly.

Material

1-141779 Lamp

Same as 626

640

Material

1-141779 Lamp

Head Lamp Renew One

626 E44

- Remove old head lamp and install new.
- Focus head lamps.

Note: Focus and adjust head lamps to throw a light 25 feet or more ahead of car. Focus the electric bulb by moving it nearer or farther away from the parabolic reflector until a small light disc, less than twenty four (24) inches in diameter appears on the wall. Cover one lamp and observe the disc of light thrown on the wall or screen by the other headlight. Cover the other lamp and repeat the operation. Have both headlight lamps uncovered and observe that the centers of the light discs on the wall or screen are the same distance apart.

Material

1-159716 Head Lamp

Same as 626

640

Material

1-159717 Head Lamp

**Head Lamp Door Glass—
Renew One**

626 E413

- Remove head lamp door and take out old glass.
- Supply and fit new glass.

Note: Be sure headlight lenses are fastened firmly so that they cannot turn in the mounts through rattling or vibration caused by rough roads.

Material

1-162080 1/2 cc

Same as 626

640

Material

1-166823 Glass

**E414 Headlight Reflectors—Resilver
(Labor Only)** 626

1. Remove head glass
2. Remove head lamp reflector
3. Resilver and replace
4. Focus head lamps
5. Reassemble

Note: Lamps should be adjusted so as to throw a light 25 feet or more ahead of car. See Part 2 for further instructions on adjusting headlights.

Material

(Labor Only) 640

Same as 626

Material

**E450 Instrument Board Panel Assembly, Remove, Dismantle—
Reassemble and Replace** 626

1. Remove wires from ammeter and dash light and breaker
2. Remove oil pump tube
3. Disconnect speedometer and gasoline gauge
4. Remove instrument panel assembly and dismantle for inspection
5. Reassemble panel and replace in instrument board and tighten
6. Replace all wires, oil tube, speedometer cable and gasoline gauge
7. Test unit

Material

Same as 626 640

Material

Battery Box - Renew**626 E52**

1. Remove battery box cover
2. Remove cables and battery
3. Disconnect rear end of tender from running board
Note: It is not necessary to remove tender
4. Remove battery box
5. Supply and install new battery box
6. Replace and tighten tender bolts
Note: Be sure that battery box liner is in proper position
7. Replace battery and cables
Note: See that water in battery is up to level

Material

- 1-162501 Battery Box Assembly 626
1-162512 Battery Box Assembly 603

Same as 626

640**Material**

- 1-146910 Battery Bus Assembly 610
1-163407 Battery Bus Assembly 645

**Battery to Ground Cable - Renew
(Labor Only)****626 E53**

1. Remove old wire and install new
Note: Be sure both terminals are tight on new cable before installing and see that terminal posts are cleaned thoroughly. Use a sheet lead shim around terminal post to secure a tight connection, if necessary

Material

Same as 626

640**Material****Battery to Starter Switch Cable - Renew
(Labor Only)****626 E54**

1. Remove starter switch
2. Clean switch
3. Attach new cable
4. Assemble starter in place
Note: Be sure that both terminals are tight before installing. Use a sheet lead shim around terminal posts to secure a tight connection, if necessary

Material

Same as 626

640**Material**

Horn - Clean, Oil and Adjust626 **E61**

Note: Horn should respond the minute the button is pressed.

1. Remove cover and clean commutator with sand paper.
2. undercut commutator between segments, using a broken hacksaw blade. Do not use emery cloth.
3. Insert 2 or 3 drops of oil at front and rear armature bearings and a drop on brushes.

Note: To adjust horn, loosen adjusting screw, turn with screw driver and adjust to get the best possible sound. Always have a properly charged extra battery ready to test the horns on a car, independent of the battery wiring of the car. A loose end plate screw will cause a binding of the bearing in the motor, which will slow up the speed, reducing the quality of the tone and eventually causing the motor to burn out. Clean commutator and brushes and oil and adjust properly.

Material

Same as 626

640

Material

Battery Recharge

626 E71

1. Remove owner's battery, install service battery.
2. Recharge owner's battery.

Note: Test with 1V voltmeter. With battery fully charged reading should be between 1290 and 1300. A reading of 1270 indicates a fully discharged battery. The average battery in good condition shows from 1200 to 1250. It is never advisable to allow a battery to continue in operation in a car when it is a discharged condition. This caution is extremely important especially during the winter months, when a spell of zero weather will cause a low density electrolyte to freeze and ruin the battery. The level of the electrolyte should be maintained about 1/8 of an inch above the tops of the separators. A lowering of this level is due to evaporation of the water from the electrolyte and it should be replaced only with distilled water.

3. Remove service battery and install owner's battery.

Note: Be sure all connections are clean and tight and free from corrosion. Should terminal posts become corroded they should be scraped and cleaned with a kinked and gasoline applied before replacing cables.

Material

Same as 625

640

Material

Hydraulic Shock Absorber Connecting Link - Renew Front or Rear**626 F12**

1. Remove connecting link and replace with new
Material

1-158057 Link - Front

or

1-158058 Link - Rear

Same as 626

640**Material**

1-158057 Link - Front

or

1-158058 Link - Rear

or

1-158059 Link - Rear

**Hydraulic Shock Absorber - Renew One
Front or Rear****626 F13**

1. Remove nut from shock absorber connecting link
2. Remove bolts from axle and remove shock absorber
3. Replace new shock absorber and tighten all connecting link

Material

1-157978 Shock Absorber

or

1-157979 Shock Absorber


Same as 626

640**Material**

1-157978 Shock Absorber

or

1-157979 Shock Absorber



No. 626 Shock Absorber

F110 Fender—Rear—Remove and Replace One

626

1. Remove all body to fender bolts.
2. Remove running board to fender bolts.
3. Remove splasher to fender bolts.
4. Remove fender.
5. Replace fender.
Note: Be sure that liners are in place. When replacing fender, start all fender bolts before drawing up any of the bolts.
6. Touch up bolts and nuts with air dry enamel or paint.

Material

Miscellaneous Bolts, etc.

Same as 626

640

Material

Miscellaneous Bolts, etc.

F111 Fender—Rear—Renew One

626

1. Remove all body to fender bolts.
2. Remove running board to fender bolts.
3. Remove splasher to fender bolts.
4. Remove fender.
5. Replace fender.
Note: Be sure that liners are in place. When replacing fender, start all fender bolts before drawing up any of the bolts.
6. Touch up bolts and nuts with air dry enamel or paint.

Material

- 1-146816 Fender—Left (Touring)
 1-146812 Fender—Left (Phaeton)
 1-145236 Fender—Left (Sedan)
 1-146840 Fender—Left (Sedan Limousine)
 1-146841 Fender—Left (Club Sedan)
 1-146828 Fender—Left (Coupe)
 1-146815 Fender—Right (Touring)
 1-146811 Fender—Right (Phaeton)
 1-145235 Fender—Right (Sedan)
 1-146839 Fender—Right (Sedan Limousine)
 1-146843 Fender—Right (Club Sedan)
 1-146827 Fender—Right (Coupe)
 1-148326 Fender—Left (Sport)
 1-148325 Fender—Right (Sport)
 1-146817 Fender—Right (Roadster)
 1-146826 Fender—Left (Roadster)
 1-146823 Fender—Right (Roadster)
 1-146821 Fender—Left (Roadster)
 1-157077 Fender—Right (Tub Sedan)
 1-157078 Fender—Left (Club Sedan)

Same as 626

640

Material

- 1-146816 Fender—Left (Touring)
 1-146836 Fender—Left (Phaeton)
 1-146840 Fender—Left (Sedan)
 1-146844 Fender—Left (Tub Sedan)
 1-146828 Fender—Left (Coupe)
 1-146815 Fender—Right (Touring)
 1-146833 Fender—Right (Phaeton)
 1-146839 Fender—Right (Sedan)
 1-146843 Fender—Right (Club Sedan)
 1-146827 Fender—Right (Coupe)
 1-146825 Fender—Right (Roadster)
 1-146824 Fender—Left (Roadster)


I-145117 Fender Right (Phantom)
I-145176 Fender Left (Phantom)
I-157077 Fender Right Chf. Syst.
I-157078 Fender Left Chf. Syst.
Miscellaneous Bolts, Nuts and Washers . . .

Sedan, Station, Limousine

I-141002 Fender - Right (Sedan, Sedan Limousine)
I-141003 Fender - Left (Sedan, Sedan Limousine)
I-146839 Fender - Right (Sedan Limousine)
Miscellaneous Bolts, Nut and Washers

F11
Cont.

packardinfo.com

**Spring Front Renew One****626 F21**

1. Remove spring clip.
 2. Hoist up weight of car to release spring.
 3. Remove spring bolts and clear oil passages.
 4. Install new spring (short half to the front).

Note: Timing in left rear of left front spring must be better. Bolt drawn too tight will not allow the transmission to operate properly.
 5. Replace spring plate (spring eyes must be free in hanger or shackle). Pull mid up tight, then back off $\frac{1}{2}$ or $\frac{1}{4}$ turn.
 6. Replace spring clip and tighten.
 7. Lubricate bolts with high pressure grease gun.
 8. Let down hoist.
- Note: When removing spring on 626-627, upper or lower shackle bolts must be loosened and removed with lack of slack.

Material

1-162597 Spring;

or

1-162598 Spring;

or

1-163009 Spring.

Same as 626

640**Material**

1-162597 Spring;

or

1-162598 Spring;

or

1-163009 Spring.

F22 Spring Rear Renew

626

Note: Spring shackle bolts are pressed into shackle.

1. Remove spring clips.
2. Jack or hoist up weight of car to relieve spring.
3. Remove spring bolts and clear out passages.
4. Install new rear spring (short half to the front).
5. Replace spring bolts (spring eyes must be free in hanger or shackle).
Note: Be sure to lubricate spring bolts.
6. Replace clips and tighten.
7. Remove hoist.

Material

1-163075 Spring

or

1-163077 Spring

or

1-163076 Spring

or

1-163022 Spring

or

1-164673 Spring

or

1-164674 Spring

Same as 629

640

Material

1-163072 Spring

or

1-163076 Spring

or

1-163126 Spring

or


1-163074 Spring

or


1-164077 Spring

Front Axle Spring Clip Nut Wrench

Tool No. S. 1.608—All Models

**Rear Axle Spring Clip Nut Wrench**

Tool No. S. T. 408—All Models



**Spring Clip—Front or Rear—
Renew One**626 **F24**

1. Remove old clip.
2. Supply and install new spring clip.

Material

1-138551 Clip

1-139512 Clip

Same as 626

640

1-138551 Clip

1-139512 Clip

**Spring Clips, Bolts and Shackles—
Tighten All**626 **F25**

1. Draw up tight all spring clip nuts.
2. Tighten and adjust all spring and shackle bolts.
3. Release all spring bolt nuts except at front end of rear spring, where the bracket allows for no adjustment.
Note: Trunnion bolt at rear of left front spring must be free. Bolt drawn too tight will not allow the trunnion to operate properly.
4. Draw each spring bolt tight, then back off a half turn. Hold in this position and lock with spring bolt nut.
Note: There should be no perceptible side play, but spring eye should be free in shackle or hanger. Bolts drawn too tight will cause hard riding and are liable to break spring or hanger.

Material

Same as 626

640

Material**Spring Bolts—Tighten All**

626

F26

1. Release all spring bolt nuts except at front end of rear spring, where the bracket allows for no adjustment.
Note: Trunnion bolt at rear of left front spring must be free. Bolt drawn too tight will not allow the trunnion to operate properly.
2. Draw each spring bolt tight, then back off a half turn. Hold in this position and lock with spring bolt nut.
Note: There should be no perceptible side play, but spring eye should be free in shackle or hanger. Bolts drawn too tight will cause hard riding and are liable to break spring or hanger.

Material

Same as 626

640

Material

**F27 Spring Bolts and Bushings—
Renew All**

626

Note: Spring shackle bolts are pressed into spring shackle.

1. Jack up car.
2. Remove old bolts and bushings and install new ones.

Note: Trunnion bolt or rear of left front spring must be free. Bolt drawn too tight will not allow the trunnion to operate properly. Use puncher or some other suitable tool to pry spring down. It is necessary to remove shackles to renew spring bolts. Resize bushings to size, using a $\frac{3}{4}$ inch expansion reamer.

3. Fill all spring bolt lubricator connectors.

Note: Spring eyes must be free in hangers and shackles.

There should be no perceptible side play, but spring eye should be free in shackle or hanger. Bolts drawn too tight will cause hard riding and are liable to break spring or hanger.

Material

4-132108 Bolts.....

2-132017 Bolts.....

2-145808 Bolts

4-132011 Bolts

4- 64383 Bushings.....

4-116795 Bushings.....

2-135949 Bushings.....

2-135950 Bushings

1-164719 Bushing

1-132017 Bolt

Same as 626

640

Material

4-132108 Bolts.....

2-132017 Bolts.....

2-145808 Bolts

4-132011 Bolts

4- 64383 Bushings

4-116795 Bushings.....

2-135949 Bushings

2-135950 Bushings

1-164719 Bushing

1-132017 Bolt

**F210 Spring Front—Remove and
Replace One**

626

1. Remove spring clip and hoist up weight of car.
2. Remove front and rear spring bolts and remove spring.
3. Reassemble in place.

Note: Spring shackle bolts are pressed in spring shackle. Bolts drawn too tight will cause hard riding and are liable to break spring or hanger. When reassembling spring, see that the spring center bolt enters hole in spring seat on axle and that springs are securely fastened.

Material

Same as 626

640

Material

**Spring - Front - Front Bolt—
Renew One****626 F211**

Note: Spring shackle bolts are pressed in spring shackle. Remove both spring bolts and shackle.

1. Jack up car and remove old bolt and install new.

Note: Use crowbar or some other suitable tool and pry down spring when renewing spring bolt.

2. Fit lubricator connector.

Note: Spring bolt should be drawn up tight and then not backed off $\frac{1}{2}$ to $\frac{3}{4}$ turn.

Material

1-132108 Bolt

Same as 626

640**Material**

1-132108 Bolt

**Spring--Front--Rear Bolt—
Renew One****626 F212**

1. Raise weight on front spring.

2. Remove old bolt and take off lubricator connector.

3. Supply and install new bolt.

Note: Use crowbar or some other suitable tool and pry down spring when renewing spring bolt.

4. Fit lubricator connector and fill with grease.

Material

1-142017 Bolt

Same as 626

640**Material**

1-142017 Bolt

**Spring - Front - Front Bolt and
Bushing - Renew One****626 F213**

Note: Spring shackle bolts are pressed into spring shackle. Remove both spring bolts and shackle.

1. Raise weight on front spring.

2. Remove old bolt and drive out old bushing.

Note: Renew bushings to size, using a $\frac{1}{4}$ -inch expansion reamer.

3. Supply and fit new bushing and bolt.

Note: It is not necessary to renew springs. Use bushing recovery tool S. T. 125. Use crowbar or some other suitable tool to pry down spring.

4. Fit lubricator connector and fill with grease.

Material

1-132108 Bolt

1-216795 Bushing

Same as 626

640**Material**

1-132108 Bolt

E-1116795 Bushing

F214 Spring—Front—Rear Bolt and Bushing - Renew One 626

1. Raise weight off front springs.
2. Remove old bolt and drive out old bushing.
Note: Ream bushings to size, using a $\frac{3}{4}$ -inch expansion reamer.
3. Supply and install new bushing and bolt.
Note: It is not necessary to remove springs. Use bushing remover tool S. T. 125. Use crowbar or some other suitable tool to pry down spring.
4. Fit lubricator connector and fill with grease.

Material

1-132017 Bolt
1-116795 Bushing

Same as 626 640

Material

1-132017 Bolt
1-116795 Bushing

F215 Spring Shackle Link - Front or Rear - Renew One Pair 626

1. Remove spring bolt units.
2. Jack up chassis to allow removal of spring bolts.
3. Remove spring bolts.
Note: To remove rear spring on 626-640 both shackle bolts must be loosened and removed with shackle. Bolts are pressed into shackle.
4. Supply and install new shackle links.
5. Replace spring bolts.
6. Replace and tighten spring bolt units.
7. Remove jack.
Note: There should be no perceptible side play, but spring eye should be free in shackle or hanger.

Material

1-132109 Link
1-132110 Link

Same as 626 640

Material

1-132109 Link
1-132110 Link

F216 Spring—Front—Rebush One Includes F210 626

Note: Spring shackle bolts are pressed into spring shackle.

1. Press out old bushings.
2. Supply and press in new bushings.
Note: After spring bolts are drawn up tight, back off nuts $\frac{1}{2}$ to $\frac{3}{4}$ turn.
Ream bushings to size, using a $\frac{3}{4}$ -inch expansion reamer.

Material

2-116795 Bushings...



Same as 626 640

Material

2-116795 Bushings

Spring Bushing Replacer

Tool No. S. T. 161



Tool No. S. T. 161


A spring bushing replacer (fig.) removes the old bushing and installs the new bushing in the same operation. The Tri handle wrench shown in the illustration is part of the Pulley and Speaker Puller equipment S. T. 113.

Tool No. S. T. 162

The blind bushing at the front spring rear hanger bracket is easily removed with this puller, as the end of the puller screw is in effect a coarse tap that cuts threads in the old bushing. The other half bushing is quickly removed by use of the special punch included with the puller.

Shackle Bracket Bushing Puller

Tool No. S. T. 162



**F217 Spring—Rear Front Bolt
Renew One**

626

1. Raise weight off rear springs.
 2. Remove old bolt and take off lubricator connector.
 3. Supply and install new bolt.
 4. Fit lubricator connector and fill with grease.
- Note:* After spring bolt is drawn up tight, back off nut $\frac{1}{2}$ to $\frac{3}{4}$ turn.

Material

1-115808 Bolt

Same as 626

640

1-145808 Bolt

**F218 Spring—Rear—Front Bolt and Bushing—
Renew One**

626

1. Raise weight off rear springs.
 2. Remove old bolt and drive out old bushing.
 3. Supply and install new bushing and bolt.
- Note:* It is not necessary to remove springs. Use bushing remover tool S. T. 125. Use crowbar or some other suitable tool to pay down spring. Ream bushings to size, using a $1\frac{1}{4}$ inch expansion reamer.
4. Fit lubricator connector and fill with grease.
- Note:* After spring bolt is drawn up tight, back off nut $\frac{1}{2}$ to $\frac{3}{4}$ turn.

Material

1-145808 Bolt

1-64383 Bushing

Same as 626

640

Material

1-115808 Bolt

1-64383 Bushing

F219 Spring—Rear—Rear Bolt—Renew One

626

- Note:* Spring shackle bolts are pressed into shackle.
1. Raise weight off rear springs.
 2. Remove old bolt and take off lubricator connector.
 3. Supply and install new bolt.
 4. Fit lubricator connector and fill with grease.
- Note:* After spring bolt is drawn tight, back off nut $\frac{1}{2}$ to $\frac{3}{4}$ turn.

Material

1-142011 Bolt

Same as 626

640

Material

1-142011 Bolt

**F220 Spring—Rear—Remove and
Replace One**

626

- Note:* Spring shackle bolts are pressed into shackle.
1. Remove clips and hoist up weight of car.
 2. Remove front and rear spring bolts and remove spring.

3. Reassemble in place.

Note: When replacing spring, be sure that short half is placed toward the front. See that the spring center bolt enters hole in spring seat on axle and that springs are securely fastened.

F220
Cont.

Same as 626

640

Material**Spring: Rear--Rear Bolt and Bushing--****(Renew One)**

626 F221

Note: Spring shackle bolts are pressed into shackles.

1. Raise weight off rear spring.
 2. Remove old bolt and drive out old bushing.
 3. Supply and install new bushing and bolt.
- Note: Ream bushings to size, using a $\frac{3}{4}$ inch expansion reamer.
4. Fit lubrication connector and fill with grease.
- Note: After spring bolt is drawn up tight, back off nut $\frac{1}{2}$ to $\frac{3}{4}$ turn.

Material

1-132011 Bolt

1- 64383 Bushing

Same as 626

640

Material

1-132011 Bolt

1- 64383 Bushing

**Rear Axle Spring Front Bolts and Bushings
(Renew Both Springs)**

626 F222

1. Hoist up weight of car.

2. Remove spring bolts and bushing.

Note: Use crowbar or some other suitable tool and pry down spring when renewing bushing. Ream bushings to size using a $\frac{3}{4}$ inch expansion reamer.

3. Lubricate all spring bolts.

4. Replace spring bolts.

Note: Spring bolts should be drawn up tight and then nut backed off $\frac{1}{2}$ to $\frac{3}{4}$ turn.

Material

2-145808 Bolts

2- 64383 Bushings

Same as 626

640

Material

2-145808 Bolts

2- 64383 Bushings

**Spring: Rear--Rebush One
(Includes F220)**

626 F223

1. Press out old bushing, using an arbor press.

2. Supply and install new bushings.

Note: Ream bushings to size, using a $\frac{3}{4}$ -inch expansion reamer.

Material

2- 64383 Bushings

Same as 626

640

Material

2- 64383 Bushings

F224 Spring- Front—Center Bolt—Renew One 626
 (Includes F210)

1. Remove spring center bolt and disassemble spring
 2. Clean leaves and lubricate with graphite
 3. Supply and install new spring center bolt
 4. Assemble on bench and compress in vise, using a tool length of $1\frac{1}{4}$ " cold rolled steel rod for a pilot to keep center bolt holes lined up
 5. Remove pilot and install center bolt from lower side; tighten and peen
- Note: After tightening spring bolts, back off nuts $\frac{1}{2}$ to $\frac{1}{4}$ turn

Material

4-116627 Spring Center Bolt and Nut

Same as 626 640**Material**

4-116627 Spring Center Bolt and Nut

F226 Spring Clips—Tighten All 626

1. Tighten all spring clips

MaterialSame as 626 640**Material**

**F227 Rear and Front Axle Spring Bolts—
Remove, Clean Oil Grooves and Adjust** 626

1. Jack up chassis
2. Remove front and rear spring bolts
3. Clean oil grooves

Note: Be sure that all Magrite cups are working properly or check magazine oiling system, hand pump giving only one or two strokes. If not working properly report condition to Forman.

Note: Trunnion bolt at rear of left front spring must be free. Bolt drawn too tight will not allow the trunnion to operate properly.
4. Replace spring bolts and adjust

Note: Bolts drawn too tight will cause hard riding and are liable to break spring or hanger.

MaterialSame as 626 640**Material**

F228 Front and Rear Axle Spring Bolts—Shim and Adjust 626

1. Draw each spring bolt tight. Then back off a half turn. Hold in this position and lock with spring bolt nut

Note: Trunnion bolt at rear of left front spring must be free. Bolt drawn too tight will not allow the trunnion to operate properly.
2. Except at front end of rear spring, where the bracket does not allow adjustment
3. Remove spring bolt and shim if necessary for side play

Note: There should be no perceptible side play. Spring eye should be free in shackle or hanger. Bolt drawn too tight will cause hard riding and are liable to break spring or hanger.

Material4-120320 Shim 640

Same as 626

Material

4-120320 Shim

**Front Axle Spring Center Leaf Renew
(Labor Only)****626 F241**

1. Hoist up weight of car.
 2. Remove front and rear spring bolts and clips.
 3. Remove spring center bolt and renew center leaf.
 4. Reassemble spring leaf and center bolt, replace to axle.
Note: Trunnion bolt at rear of left front spring must be free. Bolts drawn too tight will not allow the trunnion to operate properly.
 5. Take the broken spring leaf over to some blacksmith shop and have new leaf made.
Note: Bolts drawn too tight will cause hard riding and are liable to break spring or hanger.
- When assembling spring, see that the spring center bolt enters hole in spring seat on axle; and that springs are securely fastened.

Material

Same as 625

640**Material****Spring—Front Remove and Replace Both****626 F251**

1. Remove front spring clips.
2. Raise weight of car off front springs. Use jacks S. T. 155.
3. Remove front and rear spring bolt.
4. Remove springs.

Material

Same as 626

640**Material****Front Axle Springs—Install All New Bolts and Bushings****626 F252**

1. Hoist up weight of car.

Note: Trunnion bolt at rear of left front spring must be free. Bolt drawn too tight will not allow the trunnion to operate properly.

2. Remove old bolts and bushings and install new.

Note: It is not necessary to remove springs. Use bushing remover tool ST126. Use crowbar or some other suitable tool to pry spring down. Ream bushing to size using a $\frac{3}{4}$ inch expansion reamer.

3. Fill all spring bolts lubricator connectors.

Note: Spring eyes must be free all fasteners and shackle. There should be no perceptible side play. Bolts drawn too tight will cause hard riding and are liable to break spring or hanger.

Material

- 4-132108 Bolt
- 2-132017 Bush
- 4-116795 Bushings
- 2-135949 Bushing

Same as 626

640**Material**

- 4-132108 Bolt
- 2-132017 Bush
- 4-116795 Bushings
- 2-135949 Bushing

F261 Spring—Rear—Remove and Replace Both

626

Note: To remove rear springs on 626-640 both shackle bolts must be loosened and removed with shackle. Bolts are pressed into shackle.

1. Remove rear spring clips.
2. Raise weight of car off rear springs. Use jacks S. T. 155 and place under frame cross member.
3. Remove rear spring bolts and lift out both springs.
4. Reassemble in place.

Material**Spring - Rear - Remove and Replace Both**

640

1. Disconnect stabilizer straps and remove rear spring clips.
2. Raise weight of car off rear springs. Use jacks S. T. 155 and place under frame cross member.
3. Remove rear spring bolts and lift out both springs.
4. Reassemble spring and attach stabilizer.

Material**F262 Spring --Rear- Rebush Both
(Includes F261)**

626

1. Press out old bushings, using an arbor press.
 2. Supply and install new bushings in both rear springs.
- Note: Ream bushings to size, using a $\frac{1}{4}$ inch expansion reamer.

Material**4-64383 Bushings**

Same as 626

640

Material**4-64383 Bushings****F263 Spring--Rear Center Bolt—Renew One
(Includes F220)**

626

1. Clean leaves and lubricate with graphite.
2. Assemble on bench and compress in vice, using a foot length of cold rolled steel as a pilot to keep center bolt holes lined up.
3. Remove pilot and install center bolt from the upper side, tighten and peen.

Material**1-23731 Spring Center Bolt..**

Same as 626

640

Material**1-23731 Spring Center Bolt**

**Rear Axle Spring Bolts and Bushings --
Renew Both Springs**

626 F264

1. Hoist up weight of car.
2. Remove old bolts and bushings and install new.

Note: It is not necessary to remove springs. Use bushing remover tool ST125. Use crowbar or some other suitable tool to pry spring down. Renew bushing to size, using a $\frac{3}{4}$ inch expansion reamer.

3. Lubricate all spring bolts.

Note: Spring eyes must be free in hanger and shackle. There should be no perceptible side play. Bolts drawn too tight will cause hard riding and are liable to break spring or hanger.

Material

2-145808 Bolts
4-132011 Bolts
2-135950 Bushings
4-64383 Bushings

Same as 626

640

Material

2-145808 Bolts
4-132011 Bolts
4-64383 Bushings
2-135950 Bushings

Rear and Front Axle Rebound Clip Bolts - Tighten All

626 F276

1. Tighten all springs, using wrench tool No. ST607 for rear and Tool No. ST608 for rear.

Material

Same as 626

640

Material

**Spring Front Front Hanger
Renew One**

626 F31

1. Remove front fender, radiator splasher and bumper frame ledge
2. Raise weight off front springs and remove front spring bolt
3. Cut and drive out old rivets
4. Supply and fit rivet new hanger into place, using an air hammer
5. Reassemble

Material

1-145702 Spring Bracket Right
or
1-145703 Spring Bracket Left

Miscellaneous

Same as 626

640

Material

1-145702 Spring Bracket
or
1-145703 Spring Bracket

Miscellaneous

**Spring Front Rear Bracket
Bushing Renew Both**

626 F34

- Note: Shackle bracket is located at front of spring on 626-640
1. Disconnect stabilizer strap and raise weight of chassis off front spring
 2. Disconnect spring shackle
 3. Drive out old bushings
 4. Supply and fit new bracket bushings
 5. Reassemble springs in place

Material

2-135949 Bushings

Same as 626

640

Material

2-135949 Bushings ..

**Spring Rear Shackle Bracket Assembly
Renew One**

626 F35

Note: Spring bracket is located at front of rear spring

1. Raise weight of car off rear springs
2. Remove rear spring bolt
3. Cut rivets and remove old bracket
4. Press new bushing in new bracket and rivet bracket in place, using an air hammer
5. Reassemble

Material

1-135950 Bushing
1-145714 Bracket Right
or

1-145715 Bracket Left

Miscellaneous

Same as 626

640

Material

1-135950 Bushing

1-145714 Bracket Right
or

1-145715 Bracket Left

Miscellaneous

F36 Frame Assembly Renew

626

1. Remove hood, radiator tie rod, headlights and radiator
2. Remove front and rear fenders
3. Remove toe board and floor board
4. Remove speedometer cable, electrical connections, and controls at dash
5. Remove starter motor
6. Remove steering gear case and post assembly
7. Remove floor body bolts on each side of body
8. Raise rear of body far enough to allow a length of $2\frac{1}{2}$ " pipe to be worked under body for lifting purposes. Pipe should be about 9 ft. long
9. Using a punch lot under the dash, raise front of body and place a similar piece of $2\frac{1}{2}$ " pipe under front of body
10. Lift off body
11. Remove battery
12. Disconnect exhaust pipe at motor
13. Remove right and left running board and splasher
14. Remove muffler and brackets from frame
15. Using chain falls, remove motor from frame (See Operation MO for detailed specifications)
16. Remove snubbers front and rear, right or left
17. Disconnect snubber straps
18. Disconnect torque arm at front end by removal of hinge bolt
19. Remove gas tank
20. Remove right and left running board
21. Remove spring and shackle bolts
22. Remove front and rear axle assembly
23. Replace old frame assembly with new
24. Reassemble in reverse order of removal

Material

I-158683 Frame 626

or
I-159279 Frame 633

Same as 626

640

Material

I-158620 Frame 610

or
I-158286 Frame 615**F37 Spring Front Rear Trunnion Bracket Left Renew**

626

1. Remove front wheel
2. Remove spring bolts.
Note: Use crowbar or some other suitable tool to pry springs down
3. Raise weight of chassis off front spring
4. Loosen mud pan one side
5. Remove spring trunnion bracket bolt
6. Cut and drive out old rivets
7. Supply and hot rivet new bracket in place, using an air hammer
8. Install bolt and four (4) front trunnion springs using hand jack
9. Reassemble

Material

1-164713 Bracket - Left

Miscellaneous

Same as 626

640

Material

1-164713 Bracket

Miscellaneous

Rear Axle Spring Bracket Bushing - Renew One

626 F38

1. Jack up car and remove spring bolt
2. Remove old bushing and install new.
Note: Use crowbar or some other suitable tool and pry down spring when removing bushing.
3. Ream bushing to size, using a $\frac{3}{4}$ " expansion reamer
4. Replace spring bolt
Note: Spring bolts should be drawn up tight and then nuts backed off $\frac{1}{2}$ to $\frac{3}{4}$ turn.

Material

1-135050 Bushing

Same as 626

640

Material

1-64383 Bushing

Same as 626

Rear Axle Spring Front Bracket - Rivet

626 F396

1. Remove splash on one side
2. Jack up chassis one side
3. Remove spring bolt
Note: Use crowbar or some other suitable tool and pay down spring.
4. Cut old rivets from bracket
5. Install new hot rivets using air hammer
6. Replace spring bolt
7. Replace splash and tighten

Material

Miscellaneous

Same as 626

640

Material

Miscellaneous

Rear Axle Spring Rear Hanger - Rivet

626 F397

1. Jack up rear of chassis
2. Remove rear spring bolt
Note: Use crowbar or some other suitable tool to pry spring down.
3. Cut old rivets from hanger
4. Supply and install hot rivets using an air hammer
5. Lubricate and adjust spring bolt

Material

Miscellaneous

Same as 626

640

Material

Miscellaneous

F398 Front Axle Spring Hanger Front Rivet 626

1. Cut the old rivet
2. Supply hot rivets in place, using an air hammer
Note: Do not cut all rivets. Cut one at a time, then supply hot rivets. It is not necessary to remove bracket from frame.

Material

Miscellaneous

Same as 626 640

Material

Miscellaneous

F399 Front Axle Spring Rear Bracket Left or Right Rivet 626

1. Cut old rivets
2. Supply hot rivets in place, using an air hammer
Note: Do not cut all rivets. Cut one at a time. Then supply hot rivet. It is not necessary to remove bracket from frame.

Material

Miscellaneous

Same as 626 640

Material

Miscellaneous

Fender Front Left Renew One626 **F41**

1. Remove head lamps assembly and shock absorber ball nut and lower shock absorber arm
2. Disconnect fender from running board and splasher
3. Remove radiator splasher one side
4. Remove indicator connection
5. Remove fender lower bracket bolts
6. Remove old fender
7. Install new fender
 Note: When attaching new fender, start all fender bolts before drawing up tight any bolts and see that bolts are in proper position.
8. Replace shock absorber and head lamps assembly
 Note: Connect head lamp cables and see that they operate properly

Material

1-158632 Fender (626)

or

1-159853 Fender (626)

or

1-159852 Fender, with Well (626)

or

1-159620 Fender, with Well

3 ft. 96983 Liner, Long

1 ft. 96984 Liner, Short

Miscellaneous Bolts, etc.

Same as 626

640

Material

1-158632 Fender

or

1-158629 Fender, with Well

1 ft. 96984 Liner (Short)

3 ft. 96983 Liner (Long)

Miscellaneous Bolts, Nuts, etc.

Fender Front Right Renew626 **F42**

1. Remove battery box cover and battery
2. Remove battery box bolts and nuts and disconnect fender
3. Remove head lamp and bracket bolts at the lower end
4. Remove radiator splasher one side
5. Remove shock absorber ball nut and remove arm
6. Remove indicator connection
7. Disconnect fender from running board and splasher
8. Remove old fender
 Note: When attaching new fender, start all fender bolts before drawing up tight any bolts.
9. Supply and install new right front fender
10. Reassemble head lamp and battery in place

Material

1-159831 Fender (626)

or

1-159835 Fender (626)

or

1-159830 Fender, with Well (626)

or

1-159837 Fender, with Well (626)

1 ft. 96984 Liner

3 ft. 96983 Liner

Miscellaneous Bolts, etc.

F42 Same as 626 640
Material

Cont. 1-159880 Fender (640)
 1-159883 Fender, with Well (640-645)
 1-ct. 96684 Liner (Shore)
 3-ct. 96685 Fender Flare
 Miscellaneous Bolts, Nuts, etc.

F410 Fender - Front - Left - Remove and Replace One 626

1. Remove head lamp assembly and bracket bolts
2. Remove shabblers and fenders (splinter and running board)

Note: If running board bolts are rusted, use a cold chisel and cut off bolts
3. Remove left fender
4. Replace left fender

Note: When attaching new fender, start all fender bolts, before drawing any bolts tight
5. Replace head lamps and shabblers

Note: Connect head lamp cables and see that they operate properly
6. Tighten all bolts and nuts

Material

Miscellaneous

Same as 626 640

Material

Miscellaneous

F411 Bonnet Assembly - Renew 626

Note: Protect fenders and body by using fender covers See 1-130 and cowl covers See 1-148

1. Remove old bonnet

Note: Carefully remove hood so as not to damage body
2. Line up and fit new hood
3. Adjust radiator tie rod until the hood and radiator line up at the top
4. If necessary file hood for proper fit

Material

1-159846 Bonnet

or

1-159840 Bonnet

Same as 626 640

Material

1-159842 Bonnet

or

1-159844 Bonnet

or

1-162816 Bonnet

or

1-163043 Bonnet

F413 Bonnet Clamp Assembly - Renew One 626

1. Remove old clamp assembly
2. Supply and install new clamp assembly

Note: See that clamp assembly holds hood properly

Material

1-163486 Clamp Assembly

Same as 626 640

Material

1-163629 Clamp Assembly

Fender Front Right Remove and Replace

626 F415

1. Remove battery box cover and battery
2. Remove battery box bolts and nuts and disconnect fender
3. Remove head lamp and bracket bolts
4. Disconnect fender from running board and splasher
5. Remove right front fender
6. Replace right front fender
Note: When attaching fender, start all fender bolts, before drawing any bolts tight
7. Reassemble head lamps and battery in place
Note: Touch up all bolts and nuts with proper color paint

Material**Miscellaneous**

Same as 626

640

Material**Miscellaneous**

Same as 626

Running Board and Splasher—Remove and Replace One

626 F420

1. Disconnect front and rear fenders from splasher and running board
2. Disconnect splasher from frame
3. Disconnect running board from brackets
Note: If bolts are rusted cut off with cold chisel
4. Replace running board and splasher
Note: When attaching splasher and running board start all bolts and nuts before drawing any up tight
5. Tighten all bolts and nuts
Note: Be sure all liners are in place

Material**Miscellaneous Bolts, Nuts and Washers**

Same as 626

640

Material**Miscellaneous Bolts, etc.****Running Board - Right or Left—Renew**

626 F422

1. Remove front and rear fender from running board
2. Disconnect running board from splasher
3. Disconnect running board from brackets and remove board
Note: If bolts are rusted use a cold chisel and cut off bolts
4. Install new running board
5. Fasten front or rear fender and splasher

Material

1-159804 Board Assy Left .626

or

1-146031 Board Assy Left .626

or

1-159805 Board Assy Right .626

or

1-146021 Board Assy Right .626

Miscellaneous

F422 Same as 626 **640**

Material

- Cont.*
- 1-158916 Board Assy., Left (640)
 - ^{or}
 - 1-159864 Board Assy., Left (645)
 - ^{or}
 - 1-158813 Board Assy., Right (640)
 - ^{or}
 - 1-159866 Board Assy., Right (645)
- Miscellaneous

F423 Running Board - Right or Left **626**

Recover (Labor Only)

1. Remove front and rear fender from running board
2. Disconnect running board from splasher
3. Disconnect running board from brackets and remove board
Note: If bolts are rusted, use a cold chisel and cut off bolts
4. Remove moulding from one end of running board and take off matting
Note: It is not necessary to remove all moulding
5. Cut matting to size and glue down
6. Slip new matting into place under moulding
7. Replace moulding and reassamble board on chassis

Material

Same as 626 **640**

Material

F424 Running Board to Frame Splasher **626**
Right or Left - Renew One

1. Disconnect front and rear leaders from splasher
2. Disconnect and remove running board, splasher, and step brackets
3. Remove bracket and frame bolts from splasher
4. Remove splasher
5. Reassemble, using new splasher
Note: See that splasher and running board liners are in place. Start all bolts and nuts before driving them tight

Material

- 1-140128 Splasher - Left (640)
 - ^{or}
 - 1-140129 Splasher - Left (645)
 - ^{or}
 - 1-140130 Splasher - Right (640)
 - ^{or}
 - 1-140131 Splasher - Right (645)
- Miscellaneous

Same as 626 **640**

Material

- 1-159814 Splasher - Left (640)
 - ^{or}
 - 1-159816 Splasher - Left (645)
 - ^{or}
 - 1-159815 Splasher - Right (640)
 - ^{or}
 - 1-159817 Splasher - Right (645)
- Miscellaneous

**Oiling and Greasing Operation
(Every 500 Miles)**

626 L01

1. Use "Magazine Oiling system" hand pump, giving only one stroke.
2. Use a high pressure grease gun, giving two or three turns into:
 - (a) Counter or one each front steering knuckle.
 - (b) Remove plug from water pump and fill with grease.
 - (c) Remove 1/2" plug on each rear axle brake operating shaft bracket and fill with grease.
3. Use hand oiler circuit:
 - (a) Starter motor oiler
 - (b) Generator oiler
 - (c) Distributor oiler
 - (d) Horn
 - (e) Brake rod clevis pin
 - (f) Door latches and hinges, spark and throttle control connections
4. Battery - add distilled water to cover plates 1/2"

Material

Grease

**Oiling and Greasing Operation
(Every 500 Miles)**

640

Same as 626

Note: Care should be taken not to cover body of connector on water pump on 640 model.

Material

Grease

**Oiling and Greasing Operation
(Every 1000 Miles)**

626 L02

1. Crankcase oil - drain and renew.
2. Use "Magazine Oiling System" hand pump, giving only one stroke. Fill and check.
3. Use high pressure grease gun, giving two or three turns into:
 - (a) Counter or one each front steering knuckle
 - (b) Remove plug from water pump and fill with grease.
 - (c) Remove 1/2" plug on each rear axle brake operating shaft bracket and fill with grease.

Note: Use 1/2" portion of ranker mounting.
4. Use hand oiler circuit:
 - (a) Starter motor oiler
 - (b) Generator oiler
 - (c) Distributor oiler
 - (d) Horn
 - (e) Brake rod clevis pin
 - (f) Door latches and hinges
 - (g) Spark and throttle control connections
5. Renew and clean oil pump screen
6. Battery - add distilled water to cover plates 1/2"
7. Universal joints - fill

Material

Grease

1-114640 Case

8 Qts. Cylinder oil

1 Qt. Filtered Medium oil

**L02 Oiling and Greasing Operation
(Every 1000 Miles)**

640

Cont. Same as 626

Note: Care should be taken not to overlook (1) connector on water pump on Model 604 and 615.

Material**Grease**

- 10 Qts. Cylinder Oil
- 1 Qt. Filtered Medium Oil
- 1-114886 Gasket

**L03 Oiling and Greasing Operation
(Every 5000 Miles)**

626

1. Crankcase oil—drain and renew.
 2. Use "Magazine Oiling System" hand pump, giving only one stroke. Fill and check.
 3. Use high pressure grease gun, giving two or three turns firm:
 - (a) 1 Connector on each front steering knuckle
 - (b) 1 Connector on water pump shaft
 Remove 3/8" plug on each rear axle brake operating shaft bracket and fill with grease.
 - (c) Remove plug from water pump and fill with grease.
 4. Use hand oil can at:
 - (a) Starter motor oiler
 - (b) Generator oiler
 - (c) Distributor
 - (d) Horn
 - (e) Brake rod clevis pins
 - (f) Door latches and hinges
 - (g) Spark and throttle control connections
 5. Battery—add distilled water to cover plates $\frac{3}{4}$ "
 6. Remove and clean oil pump screen.
 7. Transmission and differential—bring oil to level, using 600 W or Whitmores Compound.
 8. Front wheels—pack with medium cup grease.
 9. Steering gear—fill with gear oil, using 600 W or Whitmores Compound.
 10. Distributor head—clean and oil.
 11. Universal joints refill.
- Note: Check circulation tank & operating.

Material

- 1-114886 Gasket
- 1 Qt. Gear Oil or Whitmores Compound
- 8 Qts. Medium Cylinder Oil
- 1 Qt. Filtered Medium Oil

**Oiling and Greasing Operation
(Every 5000 Miles)**

640

Same as 626

Material

Note: Care should be taken not to overlook (1) connector on water pump on Model 604 and 615.

- 1 Qt. Gear Oil or Whitmores Compound
- 10 Qts. Cylinder Oil ...
- 1 Qt. Filtered Medium Oil
- 1-114886 Gasket

**Oiling and Greasing
(Every 10,000 Miles)**

626 L04

1. Crankcase oil—drain and renew
2. Use "Magazine Oiling System" hand pump, giving only one stroke. Fill and check
3. Use high pressure grease gun, giving two or three turns plus:
 - (a) 1 Connector on each front steering knuckle
 - (b) 1 Connector on water pump shaft
 - (c) Remove $\frac{1}{8}$ " plug on each rear axle brake operating shaft bracket and fill with grease
 - (d) Remove plate from water pump and fill with grease
4. Use hand oil can all:
 - (a) Starter motor oiler
 - (b) Generator oiler
 - (c) Distributor
 - (d) Horn
 - (e) Brake rod clevis pin
 - (f) Spark and throttle control connection
 - (g) Door latches and hinges
5. Battery—add distilled water to cover plates $\frac{1}{2}$ "
6. Remove and clean oil pump screen
7. Transmission and differential oil—drain and renew using 600 W or Whitmores Compound
Note: Check purulator tank to see if operating
8. Universal joints—fill
9. Front wheels—pack with medium cup grease
10. Steering gear—fill with gear oil or Whitmores Compound
11. Distributor head—clean and oil
Note: Use front and rear seal cover to protect trimming from oil and grease
12. Remove rear wheels and repack rear axle shaft bearing

Material

- 5½ Qts. Gear Oil or Whitmores Compound
- 1 Gal. Kerosene
- 8 Qts. Cylinder Oil
- $\frac{1}{2}$ Lb. Grease
- 1 Qt. Filtered Medium Oil
- 1-114886 Gasket

**Oiling and Greasing
(Every 10,000 Miles)**

640

Same as 626

Note: Care should be taken not to overlook (b) connector on water pump on Models 610 and 615.

Material

- 6 Qts. Gear Oil or Whitmores Compound
- 1 Gal. Kerosene
- 10 Qts. Cylinder Oil
- $\frac{1}{2}$ Lb. Grease
- 1 Qt. Filtered Medium Oil
- 1-114886 Gasket

L05 Rear Axle Shaft Bearing Repack
(Includes AM10)

626

1. Remove bearing retainer
2. Pack axle shaft bearing with grease
3. Replace bearing retainer

Material

1 lb. Grease

Same as 626

640

Material

1 lb. Grease

L06 Mechanical Adjustment and Lubrication Schedule -1,000 Miles

626

Lubrication

- (a) Chassis lubricator - fill tank and check
- (b) Battery - fill with distilled water, clean and tighten connections
- (c) Crankcase - drain and renew oil
- (d) Mixture connection
- (e) Distributor head - oil and clean
- (f) Generator, horn, starter motor - oil
- (g) Brake rod connection - oil
- (h) Steering case - fill to oil level
- (i) Universal joints - oil
- (j) Clean oil screen
- (l) Check pulsator
- (m) Door latches and hinges
- (n) Spark and throttle control

Motor Adjustment

1. Distro points - adjust
2. Valve caps - adjust
3. Front end chain - adjust
4. Water pump gland nut - tighten - loose connection
5. Fan belt - adjust
6. Clean gasoline filter

Chassis Adjustment

1. Foot brakes - adjust - not include free-ups
2. Clutch pedal - adjust
3. Axle spring clip - tighten all
4. Wheel bolts - tighten all

Material

1 lb. Grease

3 Qts. Cylinder Oil

1 Qt. Filtered Medium Oil

1 114886 Gasket

1 Pt. Whitewares Compound

Same as 626

640

Material

1 lb. Grease

30 Qts. Cylinder Oil

1 Qt. Filtered Oil

1 114886 Gasket

1 Pt. Whitewares Compound

Mechanical Adjustment and Lubrication Schedule -2,500 Miles

626

L07**Lubrication**

- (a) Chassis lubricator - fill tank and check
- (b) Battery - fill with distilled water - clean and tighten connection
- (c) Brake master - drain and renew oil
- (d) Oil screen - clean
- (e) Alemite connectors
- (f) Generator, lamp, starter motor - oil
- (g) Check pipe filter
- (h) Brake rod connection - oil
- (i) Steering case - fill to oil level
- (j) Universal joints - oil
- (k) Door latches and hinges
- (l) Spark and throttle connection
- (m) Distributor head - oil and clean

Motor Adjustment

1. Delco points - adjust
2. Spark plugs - clean and adjust
3. Carburetor - clean and adjust
4. Fan belt - adjust
5. Clean gasoline filter

Chassis Adjustment

1. Clutch pedal - adjust
2. Axle spring clips - tighten

Material

- 1-163315 Gasket
 1-126456 Gasket
 1-116281 Gasket
 1-45944 Gasket
 1-1b. Thread
 8 Oz. Cyclonite
 1 Qt. Filtered Mineral Oil
 1-114886 Gasket
 1 Pt. Whitmores Compound

Same as 626

640

Material

- 1-141480 Gasket
 1-142717 Gasket
 1-116281 Gasket
 1-49533 Gasket
 1-1b. Thread
 10 Qt. 4 cylinder oil
 1 Qt. Filtered oil
 1-114886 Gasket
 1 Pt. Whitmores Compound

Mechanical Adjustment and Lubrication Schedule - 5,000 Miles

626

L08**Lubrication**

- (a) Chassis lubricator - fill tank and check
- (b) Battery - fill with distilled water - clean and tighten connection
- (c) Brake master - drain and renew
- (d) Alemite connection

- L08**
- Cont.**
- (e) Distributor head - oil and clean
 - (f) Generator, starter motor, horn - oil
 - (g) Brake rod connection
 - (h) Front wheels - grease and adjust
 - (i) Transmission - fill to oil level
 - (j) Differential - fill to oil level
 - (k) Steering case - fill to oil level
 - (l) Universal joints - fill
 - (m) Check purulator
 - (n) Door latches and hinges
 - (o) Spark and throttle control

Motor Adjustment

1. Delsco points - adjust
2. Valve tappets - adjust
3. Water pump gland nut - tighten - hose connection
4. Clean gasoline filter
5. Front end chain - adjust

Chassis Adjustment

1. Foot brakes - adjust (not include free up)
2. Clutch pedal - adjust
3. Axle spring clips - tighten
4. Tighten wheel bolts

Material

- 1-114886 Gasket
- 3 Pts. Whitmores Compound
- 8 Ozs. Cylinder Oil
- 1 Qt. Medium Filtered Oil
- 1/2 Lb. Grease

Same as 626

648

Material

- 1-114886 Gasket
- 3 Pts. Whitmores Compound
- 10 Ozs. Cylinder Oil
- 1 Qt. Medium Filtered Oil
- 1/2 Lb. Grease

L09

Mechanical Adjustment and Lubrication Schedule - 7,500 Miles

626

Lubrication

- (a) Chassis lubricator - fill tank and check
- (b) Battery - fill with distilled water (clean and tighten connection)
- (c) Crankcase - drain and renew
- (d) Alemite connection - fill six
- (e) Distributor head - oil and clean
- (f) Generator, horn, starter motor - oil
- (g) Brake rod connection
- (h) Steering case - fill to oil level
- (i) Universal joints - oil
- (j) Check purulator
- (k) Door latches and hinges - oil
- (l) Spark and throttle control - oil

Motor Adjustment

1. Delsco points - adjust
2. Spark plugs - clean and adjust
3. Carburetor - clean and adjust
4. Fan belt - adjust
5. Clean gasoline filter

L09
Cont.

Chassis Adjustment

1. Clutch pedal - adjust
2. Axle spring clips - tighten

Material

- 1 1m3305 Gasket
- 1-126456 Gasket
- 1-116281 Gasket
- 1 45953 Gasket
- 1/2 Lb. Grease
- 8 Qts. Cylinder Oil
- 1 Qt. Filtered Medium Oil
- 1-114886 Gasket
- 1 Pt. Whitmore's Compound

Same as 626

640**Material**

- 1-141440 Gasket
- 1-142717 Gasket
- 1-116281 Gasket
- 1-49553 Gasket
- 1/2 Lb. Grease
- 10 Qts. Cylinder Oil
- 1 Qt. Filtered Oil
- 1-114886 Gasket
- 1 Pt. Whitmore's Compound

Mechanical Adjustment and Lubrication Schedule - 10,000 Miles**626****L010****Lubrication**

- (a) Chassis lubricator - fill tank and check
- (b) Battery - fill with distilled water (clean and tighten connection)
- (c) Crankcase - drain and renew oil
- (d) Alemite connection - fill six
- (e) Distributor head - oil and clean
- (f) Generator, horn, starter motor - oil
- (g) Brake rod connection
- (h) Front wheel - grease and adjust
- (i) Steering case - fill to oil level
- (j) Universal joints - fill
- (k) Transmission - drain - renew oil
- (l) Differential - drain - renew oil
- (m) Check radiator
- (n) Door latches, hinges
- (o) Spark and throttle control - oil

Motor Adjustment

1. Delco points - adjust
2. Valve tappets - adjust
3. Front end chain - adjust
4. Water pump gland nut - tighten - hose connection
5. Clean gasoline filter

Chassis Adjustment

1. Foot brakes - adjust (not include free up)
2. Clutch pedal - adjust
3. Axle spring clip - tighten
4. Wheel bolts - tightened all

L010 Material

Cont. 5 1/2 Qts. Whitmores Compound
8 Qts. Cylinder Oil
1/2 Lb. Grease
1 Qt. Filtered Oil
1-114886 Gasket

Same as 620 640

Material

6 Qrs. Whitmores Compound
10 Qrs. Cylinder Oil
1/2 Lb. Grease
1 Qt. Filtered Oil
1-114886 Gasket

L020 Mechanical Adjustment Schedule 1,000 Miles

626

Motor Adjustment

1. Heflo points - adjust
2. Valve tappets - adjust standard
3. Front end chain - adjust
4. Water pump gland nut - tighten - hose connection
5. Fan belt - adjust
6. Clean gasoline filter

Chassis Adjustment

1. Foot brakes - adjust - not include free up
2. Clutch pedal - adjust
3. Axle spring clips - tighten
4. Wheel bolts - tighten

Material

Same as 620 640

Material**L021 Mechanical Adjustment Schedule 2,500 Miles**

626

Motor Adjustment

1. Heflo points - adjust
2. Spark plugs - clean and adjust
3. Carburetor - clean and adjust
4. Fan belt - adjust
5. Clean gasoline filter

Chassis Adjustment

1. Clutch pedal - adjust
2. Axle spring clips - tighten
3. Adjust horn

Material

1-163495 Gasket
1-126456 Gasket
1-116281 Gasket
1- 49533 Gasket

Same as 620 640

Material

1-411440 Gasket
1-142717 Gasket
1-116281 Gasket
1- 49533 Gasket

Mechanical Adjustment Schedule - 5,000 Miles**626 L022****Motor Adjustment**

1. Dolen points - adjust
2. Valve tappets - adjust
3. Front end chain - adjust
4. Water pump gland nut - tighten - hose connection
5. Clean gasoline filter

Chassis Adjustment

1. Front brakes - adjust - not include free up
2. Clutch pedal - adjust
3. Axle sprng. clips - tighten
4. Wheel bolts - tighten

Material

Same as 626.

640**Material****Mechanical Adjustment Schedule - 7,500 Miles****626 L023****Motor Adjustment**

1. Dolen points - adjust
2. Spark plug - clean and adjust
3. Carburetor - clean and adjust
4. Fan belt - adjust
5. Clean gasoline filter

Chassis Adjustment

1. Clutch pedal - adjust
2. Axle sprng. clips - tighten
3. Adjust horn

Material

- 1-121026 Casker
- 1-121029 Casker
- 1-116281 Casker
- 1- 359434 Casker

Same as 626.

640**Material**

- 1-111410 Casker
- 1-142717 Casker
- 1-116281 Casker
- 1- 19533 Casker

Mechanical Adjustment Schedule - 10,000 Miles**626 L024****Motor Adjustment**

1. Dolen points - adjust
2. Valve tappets - adjust standard
3. Front end chain - adjust
4. Water pump gland nut - tighten - hose connection
5. Fan belt - adjust
6. Clean gasoline filter

L024 **Chassis Adjustment***Cont.*

1. Foot brakes adjust (not include free up)
2. Clutch pedal adjust
3. Axle spring clips tighten
4. Wheel bolts tighten

Material

Same as 62b	640
-------------	------------

Material

Crankcase Oil - Drain and Renew

626 L1

1. Remove crankcase oil drain plug and drain out old oil
Note: Do not flush with kerosene
2. With ignition OFF turn motor over a few times by hand or with starter to clear oil lines of sediment, then drain, removing cover from under oil pump
3. Remove oil pump screen, clean and replace
Note: If there is an indication of considerable sediment in crankcase, lower half, use operation 1-24
4. Replace drain plug and cover and refill crankcase to level with eight quarts fresh medium cylinder oil

Material

8 Qts. Medium Cylinder Oil
1-114886 Oil Strainer Cover Plate Gasket.....

Same as 626 640

Material

10 Qts. Medium Cylinder Oil
1-114886 Oil Strainer Cover Plate Gasket.....

Transmission Oil - Drain and Renew

626 L2

- Note: Use seat covers S. T. 141 and S. T. 145
1. Remove floor boards
 2. Remove drain plug and drain out old oil
 3. Jack up rear wheels
 4. Replace drain plug and put in one (1) gallon of kerosene
 5. Replace cover with two cap screws
 6. Run motor in reverse and first speed for a few seconds, drain kerosene and replace drain plug
 7. Refill to level with good transmission fluid oil, using 600 W or Whitmores Compound and replace cover
 8. Replace floor boards

Note: To prevent floor board rattles be sure floor boards are locked

Material

1 Gal. Kerosene
2 Qts. Transmission Fluid Oil or Whitmores Compound.....

Same as 626 640

Note: To prevent floor board rattles be sure floor boards are locked

Material

1 Gal. Kerosene
2 Qts. Transmission Fluid Oil or Whitmores Compound.....

Differential Oil - Drain and Renew

626 L3

- Note: Protect upholstery by using seat covers S. T. 44 and S. T. 145
1. Remove floor boards
 2. Remove differential cover plate two lower bolts and drain oil

- L3**
3. Replace cover bolts temporarily and put in one (1) gallon of kerosene
 4. Jack up rear wheels and run a few seconds to flush
- Cont.**
5. Remove cover bolts and drain kerosene
 6. Replace cover bolts and fill to level with good differential fluid oil, using 600 W or Whitmore's Compound
 7. Remove jack and replace floor boards

Note: To prevent floor board rattles be sure floor boards are locked

Material

1 Gal. Kerosene
3 Lts. Gear Oil or Whitmore's Compound
Same as 626	640	

Material

1 Gal. Kerosene	...
1 1/2 Quts. Gear Oil or Whitmore's Compound	...

L6 Speedometer Shaft - Grease 626

1. Remove front door board
 2. Disconnect both ends of shaft
 3. Pull cable and lubricate with graphite grease
 4. Replace cable and connect both ends of shaft
 5. Replace floor board
- Note: Speedometer head and shaft should be tested, to make sure that they turn freely. A binding or sticking shaft will throw a very considerable load on the shaft. Jack up one rear wheel, start motor and see that speedometer shaft is functioning properly

Material

Same as 626	640	
-------------	-----	--

Material

L8 Universal Joints - Refill 626

1. Remove floor board
2. Use standard Aleinite lubricator and force both joints full of universal joint heavy oil
3. Replace floor board

Material

1 Qt. Universal Joint Oil
Same as 626	640	

Material

1 Qt. Universal Joint Oil
Same as 626	640	

Delco Head Repack

1. Remove cover plate on distributor head and pack with vaseline

626 L9

Material

Vaseline

Same as 626

640

Material

Vaseline

Wheels - Front - Clean and Repack with Grease

1. Jack up front end of chassis

626 L13

2. Remove hub caps

3. Remove adjusting nuts

4. Remove wheels

5. Clean bearings and wheels

6. Repack wheels and bearing with grease

7. Replace wheels and adjust bearings

8. Tighten adjusting nuts and hub caps

Note: Be sure bearings are not too tight. Wheels should turn freely under pressure of one finger.

Material

2 lbs. Grease

Same as 626

640

Material

2 lbs. Grease

Hydraulic Shock Absorbers - Level Oil

1. Remove plug and two valve bolts to relieve air pressure

626 L18

2. Evacuate in shock absorbers

3. Replace plug and two valve bolts

Material

1 qt. oil

Same as 626

640

Material

1 qt. oil

Transmission Oil**Thin for Winter Use****626 L22**

Note: Use semi-synthetic S. T. 144 and S. T. 145 to protect material from oil star-gazing.

1. Remove floor board and drain plug.
2. Drain one quart of oil from transmission.
3. Replace drain plug.
4. Add one pint of cylinder oil.
5. If oil is not up to proper level, add gear oil, using 600 W or Whitmores Compound.
6. Replace floor board.

Note: No necessity for thinning indicated by hard gear shifting.

Material

1 Qt. Oil

Same as 626

640**Material**

1 Qt. Oil

Differential and Transmission Oil—**Drain and Renew****626 L23**

Note: Use semi-synthetic S. T. 144 and S. T. 145 to protect trimming from oil and grease.

1. Remove floor board.
2. Remove transmission case drain plug, differential housing cover and drain out old oil.
3. Replace plug and cover, pour a gallon of kerosene into each unit, through filler plug holes.
4. Raise one rear wheel clear of floor and run motor a few seconds in each speed, then drain.
- a. Replace rear end cover and fill each unit to level with a good grade of gear oil, use 600 W or Whitmores Compound.
- b. Lower rear wheel.
5. Replace floor board.

Material

2 Gals. Kerosene

54 lbs Gear Oil or Whitmores Compound

Same as 626

640**Material**

2 Gals. Kerosene

54 lbs Gear Oil or Whitmores Compound

Crankcase Lower Half**Remove, Clean and Replace****626 L24**

1. Drain oil from crankcase and tilt lower half. Clean oil pump thoroughly.
2. Remove oil screen and clean lower half thoroughly.
3. Reassemble and tighten lower half, using new gaskets.
4. Fill receiver with fresh medium cylinder oil.

Material

1-11485 Oil Screen Cover Plate Basket

8 lbs. Cast Iron

1-158701 Crankcase Basket — Left

or

1-158703 Crankcase Basket — Right

Same as 626

640**Material**

10 lbs. Cast Iron

1-114880 Oil Screen Cover Plate Basket

1-158702 Crankcase Basket — Left

1-158704 Crankcase Basket — Right

**Transmission and Differential Oil—
Thin for Winter Use****626 L32**

This operation is a combination of 1.23 and L33.

Material

2 Qts. Oil.

Same as 626

640**Material**

2 Qts. Oil

Differential Oil - Thin for Winter Use**626 L33**Note: To protect trimming from oil and grease use seat covers S. T. 144 and
S. T. 145.

1. Remove rear floor board and differential oil level plug
2. Remove two lower differential cover cap screws and drain off one pint of oil
3. Replace cap screws and add one pint cylinder oil
4. If oil is not up to level after addition of cylinder oil add gear oil or Whitmore's Compound
5. Replace level plug and floor board and see that floor boards are locked

Material

1 Qt. Oil.

Same as 626

640**Material**

1 Qt. Oil

Lubricator Connector--Replace One

626 L41

1. Remove old or broken connector and tap unit with $\frac{1}{8}$ " pipe tap.
2. Install new connector and fill with grease.

Material

1-114955 Connector

Same as 626

640

Material

1-114955 Connector

Lubricator Oil Tube--Renew One (Labor Only)

626 L42

1. Disconnect feed pipe at each union, and remove clamps.
2. Replace oil tubes and tighten union nuts.

Note: Be sure oil tubes line up straight with both connections. Use "Magnetic Oiling System" hand pump, giving one stroke and check for leaks.

Material

Miscellaneous


Lubricator Oil Tube--Renew One (Labor Only)

640

Same as 626

Material

Miscellaneous

**Oil Lubricating Tank--Renew One**

626 L43

1. Disconnect oil tube from tank.
2. Remove two nuts holding tank to dash bracket.
3. Remove button from pump handle and remove pump.
4. Install new tank and connect oil tube to tank.
5. Fill with filtered lubricating oil.

Material


1-146641 Tank

Same as 626

640

Material

1-146641 Tank



L45 Lubricator System - Inspect all Connections 626

1. Use "Magazine Oiling System" hand pump giving one stroke and check for leaks
2. Be sure oil tube connections are tight and line up straight with both connections

Material

Same as 626

640

Material

L46 Oil Filter Tank - Renew 626

1. Disconnect oil tube from tank
2. Remove nuts holding tank to motor
3. Install new tank and connect oil tube to tank


Material

1-158412 Tank

640

Material

1-159712 Tank



Spring Leaves - Lubricate

1. Apply penetrating lubricant to the edges of spring leaves
Note. This operation does not include spreading leaves

626 **L71****Material**

Grease.....

Same as b46

b40**Material**

Grease.....

Front Hub Caps - Repack

626 L91

1. Remove both front hub caps using hub cap wrench ST129, and pack with non-fluid oil such as Aermite grease
Note: Grease should just show through felt washer on inner side of wheel hub--then wipe off
2. Replace hub caps
Note: Wheels should be tested regularly for wear by shaking back and forth to make if they are loose and wobbly. See operation S721 or S119 for proper adjustment

Material

- 1 Lb. Grease
Same as 626 640

Material

- 1 Lb. Grease
.....

Steering Gear Housing - Refill to Level

626 L92

1. Remove steering gear housing plug and fill housing to level with 600 W or Whitmores Compound
Note: Oil steering pillar tube upper end bearing through steering wheel oiler
2. Replace housing plug and wipe off surplus oil

Material

- 1 Pt. Whitmores Compound
Same as 626 640

Material

- 1 Pt. Whitmores Compound

Steering Gear Housing - Wash Out and Refill with Whitmores Oil No. 52

626 L93

1. Wash out steering
2. Fill steering with heavy oil

Material

- 1 Pt. Whitmores Compound
Same as 626 640

Material

- 1 Pt. Whitmores Compound

Level Oil in Motor, Transmission and Differential**626 L111**

Note: To prevent soiling of upholstery use front and rear seat covers, S. T. 144 and S. T. 145.

1. Bring oil to proper level in motor, transmission and differential by adding to or drawing off as each case may require. Replace transmission and differential oil level plugs.

Material

Oil

Same as 626

640**Material**

Oil

Crankcase, Differential and Transmission Oil—Drain and Renew**626 L123**

Note: Protect upholstery from oil and grease by using seat covers, S. T. 144 and S. T. 145.

This operation is a combination of:

- (a) L1 Crankcase oil—drain and renew
- (b) L2 Transmission oil—drain and renew using 600W or Whitmores Compound
- (c) L3 Differential oil—drain and renew using 600W or Whitmores Compound

Material

1 Gal. Kerosene

5 Qts. Gear Oil or Whitmores Compound

8 Qts. Medium Cylinder Oil

1-114886 Oil Strainer Cover Plate Gasket

640**Crankcase, Differential and Transmission Oil—Drain and Renew**

This operation is a combination of:

- (a) L1 Crankcase oil—drain and renew
- (b) L2 Transmission oil—drain and renew using 600W or Whitmores Compound
- (c) L3 Differential oil—drain and renew using 600W or Whitmores Compound

Material

1 Gal. Kerosene

5 1/2 Qts. Gear Oil or Whitmores Compound

10 Qts. Medium Cylinder Oil

1-114886 Oil Strainer Cover Plate Gasket

Level Oil in Transmission and Differential

626

L231

Note: Be sure and protect trimming from oil and grease by using seat covers S. T. 144 and S. T. 145.

1. Remove floor boards.

2. Remove oil level plugs and allow oil to drain down to level, or raise to the proper level by adding oil through filter plug holes, as each case requires.

3. Replace plugs and floor boards.

Note: To prevent rattle be sure floor boards are properly locked.

Material

Oil

Same as 626

640

Material

Oil

**Motor—Remove from Chassis
and Replace**

626

M0

- Note: Use fender covers S. T. 130, front seat cover S. T. 144, double door cover S. T. 146 and cowl cover S. T. 148.
- Wash motor using a power washer and air dryer.
1. Remove headlight assembly and hood.
 2. Drain all water or anti-freeze, preserving the solution if used, and remove radiator.
 3. Disconnect universal joint shaft, speedometer cable, foot brake and clutch pedal pads, body battery wires, accelerator connection, tire pump tube connection, foot brake connecting rod front connection, exhaust pipe, floor boards, mudguards and all electrical connections leading to dash.
 4. Remove front support and rear cross member to frame bolts and lift motor from chassis.
 5. Take up weight of motor with chain falls, in order to clear steering case, and tilt motor upward at front end at the same time sliding motor forward, to clear support blocks—now pull front end of motor to left side and lifting right rear motor leg about 4 inches back off on chain falls until the motor rests lightly on frame in tilted position, then bring motor forward, passing under steering gear case, or release hand brake and roll car from under motor.
 6. Reassemble and test.
- Note: Inspect thoroughly for water leaks and loose electrical connections. See that "stop light" switch operates properly.

Material

Miscellaneous Bolts, etc.

Same as 626

640

Material

Miscellaneous Bolts, etc.

**Motor—Remove, Dismantle for Inspection
and Reassemble**

626

M051

Note: Use fender, cowls, seat and door covers to protect surfaces.

1. Drain cooling system.
2. Wash motor using a power washer and air dryer.
3. Note: Preserve the anti-freeze solution, if used.
4. Remove hood and head lamp assembly.
5. Remove front universal joint and exhaust pipe.
6. Disconnect speedometer cable and all controls from dash to motor.
7. Disconnect mudguards and all electrical connections leading to dash.
8. Remove front support and rear cross member to frame bolts and lift motor from chassis, using heavy chair falls. See operation M0 for detail instructions for removing motor.
9. Place motor on jack.
10. Remove front end cover for inspection, using puller S. T. 113 to remove fan pulley.
11. Remove distributor head, wiring assembly and cylinder head, using speed wrench tool No. 16, S. T. 202 and lifter S. T. 121.
12. Remove cylinder block, for inspection and manometer cylinders.
13. Drain motor oil and remove crankcase lower half for inspection.
14. Pull connecting rods and pistons for inspection.
15. Note: See operation M641 for specifications.
16. Remove transmission and clutch assembly.
17. Note: Make a thorough inspection to determine work required. (See foreman.)
18. Reassemble in reverse order of removal.
19. Note: Use the old cylinder oil and inspect thoroughly for water leaks and loose electrical connections. See that stop light switch operates properly.

M051**Material**

- Cont.**
- 1-132585 Gasket
 - 1-158293 Gasket
 - 1-158668 Gasket
 - 1-158704 Gasket
 - 1-158705 Gasket
 - 9-111687 Gaskets
 - 1-115274 Gasket
 - Miscellaneous

Same as 626

640

Material

- 1-141535 Gasket
- 1-159721 Gasket
- 1-158668 Gasket
- 1-158786 Gasket
- 1-158787 Gasket
- 9-111687 Gaskets
- Miscellaneous

M052 Motor Inspection

626

Note: Use fender, hood, seat and door covers to protect surfaces

1. Jack up chassis using jacks & U-74
2. Drain crankcase oil and remove lower half for inspection
Note: Wash motor using a power washer and air drier
3. Make oil test on bearings to locate the loose bearing. By putting pressure on the connecting rod and main bearing, the looseness can be detected. The flow of oil from the bearing should be in drops before reaching floor. (equivalent to 70 to 80 drops per minute) Be sure to examine the bearings fully as it may save you the trouble of again removing the crankcase lower half
4. Drain cooling system. Preserve the anti-freeze solution if used
5. Remove Delco head and wiring assembly
6. Remove cylinder head using aped wrench and cylinder head
7. Clean carburetor cylinder head and piston head using Electric Drill and Electro Type carbon Brush and No. ST204 and ST205. Use air hose to remove all loose carbon
8. Remove connecting rods and pistons for inspection, micrometer piston and cylinder bore. Report condition of cylinder, pistons, rings, pins, timing chain and bearing
9. Remove rocker arms and the check rocker drivers pins and rollers and check camshaft
Note: Make a thorough inspection to determine work required. (See form man)
10. Replace connecting rods to assure and tighten
11. Replace cylinder head, Delco head and wiring assembly
12. Replace crankcase lower half using the old oil
13. Refill cooling system and check for leaks

Material

- 1-158293 Head Gasket
- 1-158701 Crankcase Gasket
- 1-158668 Crankcase Gasket

Same as 626

640

Material

- 1-159721 Head Gasket
- 1-158786 Crankcase Gasket
- 1-158787 Crankcase Gasket

Motor - Tune

626

M11

- Note: Use fender covers to protect enameled surfaces from oil and scratches
- Clean and adjust breaker points, setting .015" to .020" when fully separated
Note: Clean distributor head
 - Clean spark plugs and adjust to $\frac{1}{16}$ " gap
 - Adjust fan belt. See Operation M-817
Note: Remove gasoline filter from dash and clean
 - Clean vacuum tank screen and carburetor suction tube elbow
 - Adjust timing chain (report when limit of adjustment is reached)
Note: Chain should, when adjusted, have $\frac{1}{4}$ " to $\frac{1}{2}$ " deflection up and down when checked through inspection hole
 - Set tappets standard. Not less than .004" with motor warm and idling
Be sure all tappet adjusting screws are properly locked
 - Clean and adjust carburetor (in car). Note: Carburetor air valve adjusting nuts should have $\frac{1}{16}$ " free drag for inside spring. Set outside spring so that with the throttle closed and spark retarded the motor idles smoothly. Be sure primary intake shutter is open when choke control rod is against instrument board
Note: No material other than specified included in standard price

8. Test**Material**

1-163195 Gasket

Same as 626 except that air valve has a $\frac{1}{16}$ " drag on the inside spring

640

Material

1-141440 Carburetor Gasket

Special Tune Up

626

M12

Note: This operation should be used when an owner requires immediate service. Use fender covers to protect enameled surfaces.
These specifications meet a popular request for service that will produce a clean motor in addition to the average tune up and fill in the gap in prices between M11 and M24. Cylinder head and valves are not disturbed on this operation.

- Remove spark plugs and open petcocks
- Burn carbon through spark plug holes using sheet of asbestos to protect wires from flame
Note: See that piston in each cylinder to be burned is in firing center
- Fill combustion chamber with oxygen, ignite with battery and feed oxygen until carbon is removed
Note: Have fire extinguisher handy and be sure that it operates properly
- Clean and adjust Deleo points from .015" to .020" when fully separated
Note: Remove gasoline filter from dash and clean
- Clean distributor head with sand paper and wipe with oily cloth
- Clean spark plugs and set gap $\frac{1}{16}$ "
- Remove and clean carburetor
- Adjust carburetor
Note: Set air valve adjusting nuts so that the inside spring allows air valve to drop $\frac{1}{16}$ inch on all six models. Set the outside spring so that with the throttle closed and spark retarded, the motor operates smoothly. Be sure that primary intake shutter is open when choke control rod is against instrument board
- Adjust chain so that there is a deflection of from $\frac{1}{4}$ to $\frac{1}{2}$ inch when checked through inspection hole
Note: Report when limit of chain adjustment is reached
- Adjust fan belt (See Operation M817 for adjustment)
- Adjust valve tappets to .004" clearance with the motor warm and idling
- Test

M12 Material

1-163395 Casket

Cont. Oxygen.....

Same as 626

640

Material

1-141440 Carburetor basket

Oxygen.....

M13 Service Float Tune Up

626

1. Clean and adjust spark plug to $\frac{1}{16}$ " gap
2. Clean and adjust breaker points setting—.015" to .020" when fully separated
Note: Remove points and clean if necessary. They will require a little attention or refiling. They may be very rough. When they become so badly burned as to cause missing, they should be trued so that their contact surfaces are exactly parallel
Note: Cause of miss in one or more cylinders
Possible Causes:
 - (a) Broken or defective spark plug
 - (b) Wire off spark plug
 - (c) Wire out of distributor head terminal
 - (d) Broken wire to spark plug
 - (e) Wire to spark plug grounded
 - (f) Burnt distributor head
 - (g) Defective coil—check by substitution of a known good coil
 - (h) Defective condenser
 - (i) Improperly adjusted or pitted contact points
 - (j) Incorrect ignition timing
 - (k) Dead or low battery
 - (l) Poor carburetion or lack of gasoline
3. Adjust carburetor
Note: Carburetor air valve adjusting nuts should allow $\frac{1}{16}$ " free drop on inside spring on all six models, set outside spring so that with the throttle closed and spark retarded, the motor operates smoothly
4. Remove gasoline filter from dash and clean
5. Test

Material

Same as 626

640

Material**M15 Motor Throttle Stop Adjust so That Motor Will Idle Properly and Adjust Carburetor**

626

1. Adjust—Set air valve adjusting nuts so that air valve has $\frac{1}{16}$ " drop on inside spring, set outside spring so that with throttle closed and spark fully retarded, the motor operates smoothly. Be sure that choke control rod is against instrument board
2. Adjust throttle stop set screw so the motor will idle properly

Material

Same as 626

640

Material

Motor Tune and Test Compression

626

M16

Note: Use fender covers to protect enameled surfaces from oil and grease.

1. Clean and adjust breaker points setting .015" to .020" when fully separated
Note: Clean distributor head
2. Clean spark plug and adjust to $\frac{3}{16}$ " gap
3. Adjust fan belt
Note: Remove gasoline filter from dash and clean
4. Clean vacuum tank screen and carburetor suction tube elbow
5. Adjust timing chain
6. Set tappets standard not less than .004" with motor warm and idling
7. Clean and adjust carburetor
8. Test compression on all cylinders, using gauge tool No. S. T. 193. Turn the engine over with the starter motor (with switch off). Have all but one relief cock closed. The maximum compression is determined when the gas throttle is wide open. The compression in the light should show 85 lbs. If an engine lacks power, nine times out of ten it will be traced to poor compression. Frequent causes of leakage are pitted valves or valves riding which will by not closing tightly, permit the pressure to escape. Leaky valves should be ground. Therefore, the power of an engine depends on good compression and good compression must be maintained.

Material

1 163395 Gasket

Same as 626

640

Material

1 141441 Gasket

Test Motor Compression

626

M17

1. Test compression on all cylinders using test gauge tool No. S. T. 193. Turn engine over with the starter motor (with switch off). Have all but one relief cock closed. The maximum compression is determined when the gas throttle is wide open, the compression in the light should show 85 lbs. If the resistance of the compression of one or more cylinders is less than in the other, then this particular cylinder is leaking compression. Grinding the valves will rectify this, if the leak is not due to leaky piston rings. If an engine lacks power, nine times out of ten it will be traced to poor compression. Frequent causes of leakage are pitted valves or by not closing tightly which will permit the pressure to escape. Therefore, the power of an engine depends on good compression and good compression must be maintained.

Material

Same as 626

640

Material**Motor Support and Motor to Frame Bolts - Thirteen**

626

M117

1. Tighten all motor support and motor to frame bolts

Material

Same as 626

640

Material

Clean Carbon—Grind Valves—Tune Motor Head Off:**626 M20**

Note: See M21 for specifications after the head is removed.


Material

1-163395 Gasket

Same as 626.

640**Material**

1-141440 Carburetor Gasket

Valve Guide Cleaner

Tool No. S. T. 212

Burn Carbon**626 M21**

Note: This operation to be used only when an engine requires immediate service. To protect channeled surfaces use trodler covers S. T. 130.

1. Remove spark plugs and pointer wires from engine with sheet asbestos.
Note: Have fire extinguisher ready at hand and be sure of its operation.
2. With No. 1 piston at top dead center and valves closed fill combustion chamber with oxygen—quite with rotary valve fed with oxygen until combustion is completed.
Note: Move oxygen tube around combustion chamber to assure removal of all carbon.
3. Blow out combustion chamber with air—repeat operations with other cylinders.
Note: Introduce a little cylinder oil into each cylinder after burning carbon.
4. Clean and adjust spark plugs.
5. Replace plugs and start engine for test.

M21 Material

Oxygen
Cont. Miscellaneous

Name as 626 640

Material

Oxygen
Miscellaneous

M23 Clean Carbon and Tune Motor 626

Note: This operation is advisable when valves have been ground within a reasonable mileage and the general action of the car indicates the valves do not need regrounding. Use feeder covers S. T. 130.

1. Drain three gallons of water from cooling system and preserve the anti-freeze solution, if used.
 2. Remove thermometer tube from head.
 3. Remove distributor head and wiring assembly.
- Before removing distributor head, turn motor to No. 1 cylinder firing center, lift off distributor head without disturbing position of drive shaft and mark drive shaft so it can be reassembled in the original position. To reassemble, motor must again be turned to No. 1 firing center, drive shaft replaced in accordance with mark, and head replaced with rotor on No. 1.
4. Loosen radiator inlet hose and remove cylinder head, using wrench S. T. 202.
 5. Remove carbon from cylinder and piston heads by using an electric drill and carbon brushes S. T. 201 and 205. Clean relief cocks and remove all loose carbon with air hose. Use S. T. 211 cylinder jet cock cleaner to clean relief cocks.
- Note: Valves are not removed in this operation.
6. Replace cylinder head, using a new gasket.
 7. Tighten cylinder head nuts, using a speed wrench.
 8. Replace wiring assembly and distributor head.
 9. Replace thermometer tube and tighten.

Note: To remove the burrs and pits from the contact points which have become burnt through constant use, a nail file may be used. This file, being perfectly flat, may, without any injurious effect, be placed between the contact points, and, with the movable points held lightly against the file, the file should be pulled out. It may be necessary to repeat this operation several times in order to secure a perfectly flat and clean contact surface. Do not move the file back and forth between the points as this motor has a tendency to round the edges, causing them to have a convex surface, rather than a flat surface. If the points burn out entirely or if the contact spring breaks, reinstalling new parts is the only remedy.

10. Clean distributor points and adjust to front 015° to 020° when fully separated.
- Note: Remove gasoline filter from dash and clean.

11. Clean and adjust spark plugs to $\frac{1}{2}$ gap.
 12. Remove, clean and adjust carburetor.
- Note: Set air valve adjusting nut so that air valve has a $\frac{1}{2}$ inch drop on the inside spring. Set outside spring so that with the throttle closed and spark retarded, the motor operates smoothly.

13. Adjust tappets to .001" clearance, with motor warm and idling. Use feeler gauge holder S. T. 153.

14. Adjust fan belt, running carburetor test.


Material

1-136293 Cylinder Head Gasket
1-163395 Carburetor Gasket

Name as 626 640

Material

1-139721 Cylinder Head Gasket
1-141440 Carburetor Gasket






Tool No. S. T. 669

A precision tool for resurfacing valves accurately in line with the gasket. Also counterboring and fitting replacement seats. You cannot properly service valves without this equipment. By fitting replacement seats many cylinder blocks that would have to be scrapped can be saved and put into service again.

Valve Resurfacing Equipment

Tool No. S. T. 669

**T Handle Cylinder Head Nut Wrench****Cylinder Head Nut Speed Wrench**


M24 Clean Carbon, Grind Valves, Tune Motor

626

Note: Carefully remove hood so as not to damage body; also protect fenders and cowl; use tender covers S. T. 130 and rowl covers S. T. 148.


1. Drain water from cooling system and save anti-freeze solution if used.
2. Remove thermometer tube.
3. Remove distributor head and wiring assembly. Before removing distributor head, turn motor to No. 1 cylinder firing center, lift off distributor head without disturbing position of drive shaft, mark drive shaft; so it can be reassembled in its original position. To reassemble, motor must again be turned to No. 1 firing center, drive shaft replaced in accordance with mark, and head replaced with rotor on No. 1.
4. Remove cylinder head nuts and cylinder head, using cylinder head nut wrench S. T. 204 or 226 and cylinder head lifter S. T. 121.
5. Clean carbon. Use electric drill and carbon brushes S. T. 204 and S. T. 205 to clean carbon from cylinder head and pistons. Use air hose to remove all loose carbon.
6. Remove valve cover plate and valves, using special valve lifter S. T. 215 or S. T. 220. Remove springs and push rods and polish valves.
Note: If seats of valve set screws are badly worn, operation M221 should be specified!
7. Face off valves if pitted too deeply. Seats must be straight and true before facing. (See foreman.)
8. Reseat valve seats if pitted too deeply, (see foreman.)
9. Grind all valves to proper seats and tighten cylinder base nuts. Use S. T. 105, cylinder base nut wrench, to tighten cylinder base nuts.
Important: Be sure to remove all valve grinding compound.
10. Reassemble valves in cylinder and set tappets standard (not less than .001") with motor warm and idling and tighten all lock nuts. Use feeler gauge holder S. T. 153 and tappet adjusting wrenches S. T. 216 to adjust and lock tappet adjusting screws.
11. Replace head, using new gasket.
Note: If distributor shaft cannot be easily pushed into place do not drive it, but turn motor slightly with starting crank.
12. Reassemble wiring and distributor head.
13. Replace thermometer tube and tighten.
14. Remove, clean and adjust distributor points if necessary - set points .015" to .020" gap when fully separated.
Note: To remove the burrs and pits from the contact points which have become blunt through constant use, a nail file may be used. This file, being perfectly flat, may without any injurious effect, be placed between the contact points and with the movable points held lightly against the file, the file should be pulled out. It may be necessary to repeat this operation several times in order to secure a perfectly flat and clean contact surface. Do not move the file back and forth between the points as this motion has a tendency to round the edges, causing them to have a convex surface rather than a flat surface. Remove gasoline filter from dash and clean.
15. Clean and adjust spark plugs - set plugs $\frac{1}{16}$ " gap.
16. Remove, clean and adjust carburetor.
Note: Set air valve adjusting nuts so that air valve has a $\frac{1}{16}$ inch drop on the inside spring. Set outside spring so that with the throttle closed and spark retarded the motor operates smoothly.
17. Adjust fan belt.
Note: The standard fan belt adjusting should be so that by grasping the rim of the fan it will be just possible to slide belt on pulley.
18. Adjust timing chain.
Note: Proper tension can be determined by adjusting generator with the motor running until a slight humming noise develops. Slack off until noise disappears.

Cylinder Head Speed Wrench



S. T. 102

Feeler Gauge Holder




S. T. 133

Valve Lifter




Cylinder Head Lifter




Valve Holder

Tool No. S. T. 221 - All Models




Carbon and Valve Equipment



S. T. 204

Carbon Brush



S. T. 204



Carbon Brush - Carbon Type

Series 730, S. T. 205 - All Models

Note: Be sure all cylinder head nuts are drawn down tight and cooling system is free from water leaks.

Test

M24
Cont.

Material

1-158291 Cylinder Head Gasket
1-163995 Carburetor Gasket

Same as 626

640

Material

2-159721 Cylinder Head Gasket
1-141440 Carburetor Gasket

Valves - Remove for Inspection and Replace
Includes M1610

626 **M25**

1. Remove valve cover plates

2. Remove valve spring seat locks, springs and valves, using valve lifter

3. Replace valves and keys

Note: When removing valve lifter be sure that keys are in proper position

4. Set lifters to .084" clearance with motor warm and idling and be sure lock nuts are properly locked

Note: Use top set adjusting wrenches S. T. 916 shown in Part II. These wrenches will allow one to make adjustments more easily

Replace valve cover plates

Note: Before replacing valve cover plates be sure center stud is perfectly tight, otherwise it may be against distributor drive shaft and cause a rattle

Material

Same as 626

640


Material

Valve Refacing Machine



Tool No. S. T. 405

6" Electric Bench Grinder



Tool No. S. T. 404

M26 Valves - Grind All - Includes M25 626

1. Clean valves and polish stems.
2. Reface valves and re-cut cylinder valve seats if necessary. (See foreman.)
3. Grind all valves.
Note: An electric drill is recommended for grinding valves. Be sure to remove oil grinding compound.

Material

Same as 626 640

Material**M27 Valves - Reface - Includes M26** 626

1. See that valve stems are straight and true.
2. Cut or grind off just enough stock to clean up pits in face of valve, using a valve refacing file having 100 grit. Note: Be sure that all carbon is removed from valves after valve stems are well lubricated.

Material

Same as 626 640

Material**M28 Valve Seats - Reseat - Includes M26** 626

1. Use reseating tool and take off just enough stock to clean up seats, using tool S. T. 699.
Note: Use air to blow all cuttings out of valve seats and ports.

Material

Same as 626 640

Material**M29 Valve Spring - Renew One Head on** 626

Note: To test tension of stock or new valve spring, insert a screw driver or some other suitable tool between the coil of the spring while the motor is running. A twist or turn of the screw driver increases the spring tension. Should the noise disappear, this indicates a weak spring, which should be replaced with a new one.

1. Remove valve cover plate and tappet adjusting screw.
2. Remove spark plug and insert screw driver to hold valve closed.
3. Compress valve spring using valve lifter and remove valve spring lock.
4. Remove old valve spring.
5. Raise valve and place new spring into position.
6. Insert screw driver through spark plug hole to hold valve closed.
7. Compress valve spring - Use valve lifter and replace valve key.
8. Adjust valve tappet to not less than .004" clearance with motor warm and idling, using tappet weights S. T. 218.
9. Replace valve cover plate.
Note: Before replacing valve cover plate see that center stud is tight so as not to touch dist. drive shaft, causing a rattle.

Material

1-147289 Valve Spring 640

Same as 626

Material

1-147289 Spring

Valve Tappet Adjusting Screws—Renew All 626 **M215**
 (This operation should be used with operation 3124 when the valves are out)

- Note: Protect fenders from oil and scratches by using fender covers S. T. 130
 1. Remove old screws and replace with new and be sure tappet adjusting screws are properly locked

Material

16-132179 Screws	
8-132178 Lock Nut	
Same as 626	640

Material

16-132179 Screws	
8-132178 Lock Nut	

Valve Tappets—Adjust 626 **M216**

1. Remove valve cover plate and adjust tappets standard—not less than .004" clearance with motor warm and idling. Use tappet adjusting wrench S. T. 216
 Note: Be sure valve tappet adjusting screws are properly locked. See that valve cover plate center stud is tight so it will not lie against distributor drive shaft, causing rattle

2. Replace valve cover plate

Material

Same as 626	
Material	640

Valve Tappet Adjusting Screw—Renew One 626 **M217**

1. Remove valve cover plate
 2. Raise valve with lifter, using special lifter
 3. Remove old screw and replace with new screw
 4. Adjust tappet disturbed to not less than .004" clearance with motor warm and idling
 Note: Be sure valve tappet adjusting screw is locked. Use tappet adjusting wrench S. T. 216
 5. Replace valve cover plate

Material

1-132179 Screw	
1-132178 Lock Nut	
Same as 626	640


Material

1-132179 Screw	
1-132178 Lock Nut	

Valve Push Rod and Guide—Renew One 626 **M218**


- Note: Use fender covers to protect surfaces from oil and scratches
 1. Remove valve cover plate
 Note: Use leather arm protectors to protect arms from burns when removing cover plate
 2. Raise valve, using special lifter and remove valve push rod and adjusting screw
 3. Remove guide clamp, push rod and guide
 4. Install new push rod and guide

Feeler Gauge Holder



S. T. 184

Tappet Wrench



Tool No. S. T. 216

5. Replace set screw and adjust tappet to .004" clearance, using adjusting wrenches S. T. 250
 Note: Be sure set screw locking nut is properly locked
6. Replace valve cover plate
 Note: Be sure that valve cover plate is drawn tight so as to prevent oil leaks

M218
Cont.

Material

- 1-132177 Push Rod.....
 1-147447 Push Rod Guide

Same as 626 640

Material

- 1-132177 Push Rod
 1-147447 Push Rod Guide

Valve Push Rods and Guides Renew All

626 **M219**

Note: Should be used in conjunction with operation M24 when valves are out

1. Remove valve push rod adjusting screws and guide clamps
 2. Remove old assemblies and install new

Material

- 16-132177 Rods
 16-147447 Guides

Same as 626 640

Material

- 16-132177 Rods
 16-147447 Guides

Valve Tappet Set Screws Remove, Reface and Replace

626 **M221**

Note: This operation to be used when grinding valves or with valves out

1. Remove valve tappet set screws, place in lathe and reface
 Note: If base of set screws are badly worn, the operation should be performed in conjunction with M24—Clean carbon, grind valves and tune motor

Material

Same as 626 640

Material**Valve Cover Plate Renew**

626 **M250**

1. Remove old cover

Note: Check cylinder to see that it does not project over oil return grooves and cause an oil leak at valve cover plate

2. Replace and tighten valve cover

Material

- 1-158363 Valve Cover Plate Assembly

Same as 626 640

Material

- 1-143090 Valve Cover Plate Assembly

M251 Valve Cover Plate Gasket--Renew 626

(Labor Only)

1. Remove valve cover
2. Remove the old gasket
3. Install and glue on new gasket
Note: Check cylinder to see that it does not project over oil return grooves and cause an oil leak at valve cover plate
4. Replace and tighten valve cover

MaterialSame as 626 640**Material****M252 Valve Exhaust - Renew One** 626

This operation should be used in conjunction with M24 when valves are out

1. Supply and grind in new valve
Note: Be sure to remove all grinding compound

Material1-158059 Exhaust Valve ...Same as 626 640**Material**1-146988 Exhaust Valve ...**M253 Valve Inlet - Renew One** 626

This operation should be used in conjunction with M24 when valves are out

1. Supply and grind in new valve
Note: Be sure and remove all grinding compound

Material1-158055 Valve Inlet ...Same as 626 640**Material**1-146989 Valve Inlet ...**M254 Valves - Exhaust - Renew All** 626

1. Supply and grind new valve
Note: This operation should be used in conjunction with M24 operation when valves are out
2. Be sure to remove all grinding compound

Material6-158049 Exhaust Valve ...Same as 626 640**Material**6-146988 Exhaust Valve ...**M255 Valves - Inlet - Renew All** 626

1. Supply and grind new valves
Note: This operation should be used in conjunction with M24 operation when valves are out
2. Be sure to remove all grinding compound

Material		M255
8-158035 Inlet Valves		
Same as 626	640	<i>Cont.</i>
Material		
8-146989 Inlet Valves		
 Valve Springs - Renew All	626	M256
(Should be used in conjunction with M24)		
1. Remove the old valve spring and replace with new spring		
Material		
16-147289 Valve Spring		
Same as 626	640	
Material		
16-147289 Valve Spring..		
 Valves - Renew All (Inlet and Exhaust)	626	M257
1. Supply and grind new valves		
Note: This operation should be used in conjunction with M24 operation when valves are out		
2. Be sure to remove all grinding compound		
Material		
8-158039 Valves		
8-158035 Valves		
Same as 626	640	
Material		
8-146988 Valves		
8-146989 Valves		
 Valve Rocker Lever Housing Remove One for Inspection and Replace	626	M260
1. Remove valve cover plate		
2. Remove exhaust bolts and move exhaust pipe to one side if necessary		
3. Remove nuts on housing to crankcase studs and lift housing assemblies		
4. Remove rocker lever housing plugs		
5. Remove pins and levers		
6. Inspect condition of rocker levers and pins and report		
7. Reassemble rocker pin and levers		
Note: To replace rocker levers housing, turn motor over by hand and push housing into position with all push rods up		
8. Adjust tappets affected to .004" clearance with motor warm and idling		
9. Replace valve cover		
Material		
1-158123 Gasket		
Miscellaneous		
Same as 626	640	
Material		
1-31887 Gasket		
Miscellaneous..		

M261 Valve Rocker Lever Housing --Remove Both for Inspection and Replace 626

- Note: Use leather covers S. T. 130 or S. T. 131
1. Remove valve cover plate
 2. Remove exhaust bolts and move exhaust pipe to one side
 3. Remove nuts on housing to crankcase studs and lift housing assemblies
 4. Remove rocker lever housing plug
 5. Remove rocker lever housing pins
 6. Inspect condition of rocker levers and pins and repair
 7. Reassemble rocker levers, pins and housing plug and use white lead at plug
- Note: To replace rocker lever housing, turn motor over by hand and push housing into position with all push rods up
8. Adjust tappets after set to .001" clearance with motor warm and idling and be sure tappet adjusting screw is properly locked. Use adjusting wrenches S. T. 216
 9. Note: To protect your arms from exhaust burns when adjusting tappets, use leather arm protectors
 10. Replace and tighten valve cover plates to prevent oil leaks
 11. Replace and tighten exhaust pipe

Material

2-158123 Rocker Lever Housing Gasket	
1-132585 Exhaust Pipe to Cylinder Manifold Gasket	
Same as 626	640

Material

2-131987 Rocker Lever Housing Gasket	
1-141535 Gasket	

M262 Valve Rocker Levers--Renew All (Includes M261) 626

Supply and install new rocker levers

Material

16-158723 Rocker Levers, Assembled	
Same as 626	640

Material

16-158723 Rocker Levers, Assembled	
------------------------------------	--

M264 Valve Rocker Lever Pin--Renew One 626

1. Remove housing
 2. Remove old pin
 3. Supply and install new rocker pin
 4. Replace housing
 5. Adjust tappets after set, using tappet adjusting wrenches S. T. 216
- Note: To protect your arm from exhaust burns when adjusting tappets, use leather arm protectors

Material

1-158050 Pin	
Same as 626	640

Material

1-131988 Pin	
--------------	--

**Valve Rocker Lever Pins - Renew All
(Includes M1621)****626 M265**

See Operation M194 for detailed specifications
1. Supply and fit new rocker lever pins.


Material

2-158050 Pins

Same as 626

640**Material**

2-131888 Pins



Carburetor - Clean and Adjust

6-26 M31

Note: Use leather protectors to prevent damaged surfaces from oil and scratches.

1. Disconnect choke rod at vis pin
 2. Disconnect gasoline feed pipe from carburetor
 3. Remove carburetor from manifold
 4. Remove following parts from carburetor
 - a) Carburetor air valve
 - b) Carburetor float chamber cover and float
 - c) Remove float chamber and spray plug
 5. Clean and blow out all parts with air hose

Note: Be sure that carburetor is perfectly clean and all dust and dirt that may have accumulated is removed. This will insure the life of the carburetor and also relieve any possibility of carburetor giving trouble at a very inopportune time.
 6. Reassemble all parts

Note: Remove gasoline filter from dash and clean
 7. Adjust carburetor and test; set air valve adjusting nuts so that air valve has $\frac{1}{2}$ " drop on its sole spring

Material

- 1-301-1925 *Clarionellus linsleyi*

- 120-120 AIR VALVE

- 1-119281 Float Chamber Silver Vase

- 1-113233 Spray July 1981 masked

M31 Same as 626 except that air valve has $\frac{1}{2}$ drop on inside spring. 640

Cont.

Material

1-141340 Carburetor Gasket
 1-142717 Air Valve Gasket
 1-116281 Float Chamber Cover Gasket
 1-45933 Spray Tube Base Gasket

M32 Gasoline Tank—Clean Out 626

1. Remove drain plug and drain gasoline
2. Replace drain plug and flush out tank with $\frac{1}{2}$ gallon gas—rocking car
3. Remove drain plug and drain tank
4. Replace drain plug and replace gasoline, using chamois strainer

Material

Same as 626 640

Material

M33 Carburetor Choke—Adjust 626

1. Adjust choke connecting rod clevis so that shutter closes completely when choke control is pulled all the way out
 Note: Check the choke valve or shutter in carburetor to see if it works properly
 If it does not close full, the motor will start hard in cold weather and if it does not open full the gasoline mileage will be lowered
 Note: Be sure to check the motor piston lubricator so it will open and close properly

Material

Same as 626 640

Material

M35 Gasoline Tank Gauge Unit—Renew 626

1. Loosen toe boards—do not remove
2. Disconnect gasoline tube from gauge
3. Loosen gasoline gauge tube from frame
4. Drain gasoline tank and remove fittings
5. Lower gas tank far enough to allow removal of gauge unit
6. Supply and install new unit
7. Replace gas tank, tighten and lock gas tank support strap nuts with wire
8. Replace gasoline, using a chamois strainer
9. Tighten tube to frame
10. Tighten toe boards
11. Test for accuracy

Material

1-t45260 Gauge Assembly 640

Material

1-162426 Gauge Assembly 640

Gasoline Tank Assembly Renew

626 M37

1. Disconnect gas gauge tube.
2. Remove gas tank drain plug - draw out gasoline.
3. Disconnect feed line at tank - loosen 3 support bolts and drop tank.
4. Remove gas float assembly.
5. Assemble old float in new tank.
Note: Turn it a 20 tap to clean threads in new tank.
6. Install new tank and support bolts and seal bolts with wire.
7. Connect feed line at tank and tighten cable to frame.
8. Replace drain plug and drained gasoline, using chamois strainer.
9. Test for leak at drain plug.
10. Test for accuracy.

Material

1-146328 Gas Tank Assembly ...

Same as 626

640

Material

1-1625004 Gas Tank Assembly ...

Gasoline Gauge Renew

626 M38

1. Remove old gauge from instrument board and install new gauge and tighten tube.
2. Drain gasoline from tank and refill tank using chamois strainer so that the gasoline gauge will register correctly when the gasoline tank is refilled.
Note: Clean new gauge head and make gauge read exactly zero. Liquid can be added or removed at top of the brass tube. To fill or to remove liquid, use tooth pick or a match to absorb some from the brass tube.

Material

1-158242 Gauge

Same as 626

640

Material

1-158410 Gauge

Gas Tank, Lines, Carburetor and Vacuum Tank, Clean Out

626 M39

Use fender covers S. T. 147 and cowl covers S. T. 148

1. Remove drain plug from gasoline tank and drain gas.
2. Disconnect gas line at tank and vacuum tank and blow out gas tank.
Note: Be sure both ends of gasoline lines are always disconnected, otherwise sediment will be blown into tanks.
3. Remove carburetor filter well spray plug cap and float chamber cover and clean out float chamber.
4. Remove vacuum tank cover, wipe clean the interior of vacuum tank and clean inlet screen.
5. Remove lines from vacuum tank to carburetor and blow out lines and carburetor. Note: Remove gasoline filter from dash and clean.
6. Reassemble, being sure to prime vacuum tank by turning engine with starter with choke pulled out away from dash.
7. Replace gasoline using a chamois strainer.

Material

Miscellaneous.....

Same as 626

640

Material

Miscellaneous.....

M310 Carburetor, Remove, Dismantle, Report and Reassemble

626

Note: Use fender covers S. T. 130

1. Disconnect gasoline feed pipe
2. Remove choke rod clevis pin
3. Remove carburetor from exhaust manifold
4. Remove following parts from carburetor
 - (a) Carburetor air valve
 - (b) Float chamber cover and float
 - (c) Remove fuel chamber and spray plug
5. Wash and clean all parts and blow out with air hose
6. Reassemble in the reverse order of removal
 Note: Set air valve adjusting nuts so that valve has $\frac{1}{4}$ " drop on the inside spring. Set outside spring so that with the throttle closed and spark retarded the motor operates smoothly
7. Test

Material

- 1-163495 Carburetor Gasket
 1-126456 Air Valve Seat Gasket
 1-116281 Float Chamber Cover Gasket
 1- 45943

Same as 626 except that air valve has $\frac{1}{4}$ " drop on inside spring

640

Material

- 1-141440 Carburetor Gasket
 1-142717 Air Valve Seat Gasket
 1-116281 Float Chamber Cover Gasket
 1- 45943

M311 Carburetor - Adjust Only

626

1. Remove two cap screws and cap from carburetor

Note: Check the choke valve or shutter in carburetor to see that it works properly. If it does not close fully the motor will start hard in cold weather and if it does not open fully the gasoline mileage will be lowered.

2. Remove suction tube, blow and clean

Note: Gasoline mileage depends largely upon proper carburetor adjustment. See that the carburetor is properly adjusted. It is also well to check over connections between the carburetor and the intake manifold and the cylinder block, to see if there are any leaks. A small gasoline leak around the carburetor or somewhere along the line, which carries the fuel from the main supply tank to the carburetor, may cause trouble.

3. Adjust carburetor

Note: Set air valve adjusting nuts so that air valve has $\frac{1}{4}$ " drop on the inside spring. Set outside spring so that, with the throttle closed and the spark retarded, the motor operates smoothly.

4. Replace carburetor cap and tighten two set screws holding cap in place

Note: Remove gasoline filter from dash and clean

5. Test on floor

MaterialSame as 626 except that air valve has $\frac{1}{4}$ " drop on the inside spring

640

Material

Carburetor Float Level--Adjust626 **M313**

1. Remove carburetor
2. Adjust float chamber needle valve collar so that float level is $\frac{1}{16}$ " below primary jet. This adjustment is made on the bench, using a test tank having a gravity feed and connected to carburetor
Carburetor should be absolutely level during the test. When proper adjustment has been made, remove needle valve and solder collar in place
3. Replace carburetor

Material

Same as 626

640

Material**Carburetor Float Renew (On Car)**626 **M315**

1. Disconnect vacuum tank tube
2. Remove float cover and float
3. Install new float and replace cover. Tighten tube
4. Start motor and test on float

Material1-114751 Float Assembly
1-116281 Float Chamber Cover Gasket

Same as 626

640

Material1-114751 Float Assembly
1-116281 Float Chamber Cover Gasket**Vacuum Tank Remove, Dismantle, Repair and Reassemble**626 **M320**

Note: Use fender covers S. T. 130 and cowl cover S. T. 148

1. Remove gasoline intake tube
2. Disconnect gasoline line to carburetor
3. Disconnect vacuum suction tube at tank
4. Remove four screws holding vacuum tank straps and remove tank
5. Remove vacuum tank cover, float, and inner shell
6. Clean all parts thoroughly
7. Inspect float valve and see if valve opens and closes properly
8. Reassemble
9. Replace tank
10. Connect gasoline intake tube and vacuum suction tube
Note: Turn on vacuum tank by turning engine with starter and holding choke closed—run engine and check connections for leaks

Material

Same as 626

640

Material**Carburetor Assembly Renew**626 **M340**

Note: Use fender covers

1. Disconnect gasoline feed pipe and choke rod
2. Remove carburetor from exhaust manifold
3. Install new carburetor
4. Connect gas line and choke rod
5. Adjust carburetor and test on float
6. Remove gasoline filter from dash and clean

M340 Material

1-163891 Carburetor

Cont.

Same as 626

640

1-145999 Carburetor ...

M352 Carburetor Float—Renew and Adjust Gas
Level (Includes M310)

626

1. Supply and install new float
2. Reassemble carburetor and adjust float level of gasoline in float chamber
 Note: Adjust float chamber needle valve collar so that float level is $\frac{1}{4}$ " below primary jet. This adjustment is made on the bench, using a test tank having a gravity feed and connected to carburetor. Carburetor should be absolutely level during the test. When proper adjustment has been made, remove needle valve and solder collar in place

Material

1-114751 Float Assembly

Same as 626

640

Material

1-114751 Float Assembly

M353 Carburetor Needle Valve and Seat—Renew
(Includes M310)

626

1. Remove float chamber needle valve and seat
2. Supply and install new needle valve and seat
3. Tap needle valve into seat and grind carefully, using powdered glass
 Note: Be sure to wash with gas and blow out thoroughly so as to remove all grinding compound. Adjust float chamber needle valve collar so that float level is $\frac{1}{4}$ inch below primary jet. This adjustment is made on bench using a test tank having a gravity feed and connecting it with carburetor. Carburetor should be perfectly straight during this test. When proper adjustment has been made, remove needle valve and solder collar in place

Material

1-114760 Needle Valve

1-116650 Seat

Same as 626

640

Material

1-114760 Needle Valve

1-116650 Seat

M354 Carburetor Spray Tube—Renew
(Includes A310)

626

1. Remove spray tube wrench furnished in tool kit
2. Install new spray tube

Material

1-163479 Spray Tube Assembly

Same as 626

640

Material

1-111964 Spray Tube Assembly

**Carburetor Body—Renew
(Includes M318)**626 **M357**

- Supply and assemble new fuelizer body, using new gaskets and parts taken from old body

Material

1-163494 Body

Same as 626

Material

1-162948 Body

640

**Vacuum Tank Remove, Clean
and Replace**626 **M361**

Note: Use fender covers S. T. 130 and cowls covers S. T. 648

- Remove all gasoline line tubes
- Remove four screws holding vacuum tank strap and remove tank
- Clean all parts thoroughly

- Replace tank and tighten all gasoline line tubes

Note: Prime vacuum tank by turning engine with starter and holding choke closed. Run engine and check connections for leaks

Material

Same as 626

Material

640

Vacuum Tank Float—Renew626 **M362**

- Supply and install new float
- Replace cover, using new gasket

Material

1-3830 Gasket

1-17730 Float Assembly

Order from nearest Stewart-Warner Corp.

See List Page

Same as 626

640

Material

1-17730 Float Assembly

1-3830 Gasket

Vacuum Tank—Renew626 **M363**

Note: Use fender covers and cowls covers

- Remove all gasoline line tubes
- Remove four screws holding vacuum tank strap and remove tank
- Install new tank and tighten all gasoline line tubes

Note: Prime vacuum tank by turning engine with starter and holding choke closed. Run engine and check connections for leaks

Material

1-148463 Tank

Same as 626

640

Material

1-148429 Tank (645)

or

1-148463 Tank (640)

M368 Vacuum Tank Cover Gasket Renew 626

Note: Use fender covers and cowl covers.

1. Disconnect upper gasoline line tubes.
2. Remove screws holding vacuum tank cover and remove old gasket.
3. Install new gasket and tighten covers.

Note: Be sure that vacuum tank float valves seat properly.

Material

1-3830 Gasket

Same as 626

640

Material

1-3830 Gasket

Timing Chain - Adjust

626

M40

1. Loosen two nuts on generator flange.
2. Move top of generator away from motor until chain is properly adjusted.
Note: Do not remove iron core housing into which generator fits, as such removal will release the front end chain, affecting timing of ignition and necessitate the dismantling of front end to get chain back into place.
3. Report when limit of adjustment has been reached.
4. Secure generator in new position by tightening nuts and replace plug.
Note: The proper adjustment of timing chain may be made as follows: With engine running, loosen two upper nuts on generator and shift the position of the generator away from motor to a point where the timing chain will give a slight hum, indicating that the chain is too tight. Shift the position of generator toward the motor to a point where the timing chain hum disappears, then tighten both nuts.

Material

Same as 626.

640

Material**Motor Front Cover - Renew
(Includes M410)**

626

M42

1. Remove parts from old cover and assemble on new cover.

Material

1-158492 Cover Cover

Includes M410

640

Same as 626.

1-158492 Cover Cover

**Motor Front Cover - Remove for
Inspection and Replace**

626

M410

Note: Use care in removal of bonnet so as not to scratch cowl. Use fender covers S. T. 147 or hood cover S. T. 148.

1. Drain cooling system and remove radiator.
Note: Pre-coat with anti-freeze solution.
2. Remove fan belt and vibration damper.
3. Remove front cover bolts and nuts, using a speed wrench.
4. Jack up weight of engine front end to allow removal of engine front support and front cover as one piece.
5. Inspect fan belt.
6. Reverse order of disassembling, using new front cover gasket.
7. Remove jack and secure motor in place.
8. Replace radiator.
Note: Be sure radiator pads are in place.
9. Adjust fan belt.
Note: Standard fan belt adjustment should be determined by grasping rim of fan. It will be just possible to slide belt on pulley.
10. Refill cooling system.

Material

1-158668 Cover Cover Gasket

Same as 626.

640

Material

1-158668 Cover Cover Gasket


M411 Timing Chain—Take Out Link (Includes M410)

626

1. Remove generator and sprocket support
2. Remove chain and take out "Master Link" (chain link composed of thin sections)
Note: When reassembling chain see that rocker is not assembled backward, that is, with the flat side against the seat pin. This will result in noise and possible destruction of chain. See Technical Letter No. 1698. See Mouse chain in Part II.
3. Reassemble chain in place, care being taken not to disturb relative positions of sprockets on camshaft and crank-shaft.
Note: Arrows on chain should be outside and travel with chain
4. Replace generator, adjust chain and tighten adjustment
Note: Adjust chain tension so that when all the slack of chain is between the camshaft and generator sprockets, the middle of this section of chain can be moved up and down a total of $\frac{1}{2}$ to 1 inch
5. Check ignition and valve timing before replacing front cover
Note: Set crankshaft and camshaft sprockets, so that four teeth marked O O are the nearest together and line up

Material

- 1-114683 Generator Support to Framecase Gasket
- 1- 76056 Driving Chain Rocker Pin
- 2- 76057 Driving Chain Eye Washers
- 1- 76058 Driving Chain Seat Pin
- t-115274 Generator Gasket



Same as 626

640 M411
Cont.**Material**

- 1-76056 Driving Chain Rocker Pin ...
- 2-764057 Driving Chain Pin Washers ...
- 1-76058 Driving Chain Seat Pin ...
- 1-114883 Generator Support to Crankcase Gasket ...
- 1-115274 Generator Gasket ...

**Timing Chain—Renew
(Includes M410)****626 M412**

1. Remove generator and sprocket support
2. Remove old chain by taking out generator sprocket
3. Install new chain holding sprocket in position while generator support is slipped into place, using new gasket
Note: Arrows on chain should be outside and travel with chain
4. Replace generator, adjust chain and tighten adjustment
Note: Adjust chain tension so that when all the slack of chain is between the camshaft and generator sprockets the middle of this section of chain can be moved up and down a total of $\frac{1}{8}$ to 1 inch
5. Check ignition and valve timing before replacing front cover
Note: Set crankshaft and camshaft sprockets so that four teeth marked O-O are the nearest together and line up

Material

- 1-147446 Driving Chain ...
- 1-114883 Generator Gasket ...
- 1-115274 Generator Gasket ...

Same as 626

640**Material**

- 1-147446 Driving Chain ...
- 1-114883 Generator Gasket ...
- 1-115274 Generator Gasket ...

**Camshaft Sprocket—Renew
(Includes M410)****626 M413**

1. Loosen stud nuts on generator and release timing chain to "Loose" position and pull generator
2. Remove chain, rocker pin and sprocket nut
Note: Do not tighten camshaft sprocket nut too tight, this will eliminate camshaft end-play
3. Remove old sprocket, using puller No. 1-113, and install new sprocket
*Note: Adjust chain tension so that when all the slack of the chain is between the camshaft and generator sprockets, the middle of this section of chain can be moved up and down a total distance of $\frac{1}{2}$ to 1 inch
Set crankshaft and camshaft sprockets so that the four teeth marked O-O are the nearest together and line up*
4. Replace chain and generator
5. Check valve and ignition timing
Note: Camshaft sprocket must be up snug against shoulder on camshaft. If not, timing chain will run out of true and set up front end noise

Material


- 1-148050 Camshaft Sprocket

Same as 626

640**Material**

- 1-148050 Camshaft Sprocket

Pulley and Sprocket Puller



M414 Vibration Damper - Front End Sprockets and Chain - Renew (Includes M410) 626

1. Remove fan pulley and fan and damper.
Note: Be sure to have two clamps for removing damper from crankshaft and place in vise. Remove sprocket.
2. Remove generator and front end chain and pull all sprockets, using special puller No. 1-111.
3. Supply and install new sprockets, front end damper, chain and generator.
Note: Adjust chain tension so that when all the slack of the chain is between the crankshaft and generator sprocket, the middle of this section of chain will be moved up and down a total distance of $\frac{1}{2}''$ to $\frac{1}{4}''$.
4. Check valve and ignition timing.

Material

- 1-137145 Generator Sprocket
 1-148050 Cam-shaft Sprocket
 1-147446 Crank-shaft Driving Chain
 2-158750 Vibration Damper Lining
 2-158783 Vibration Damper Flywheel
 1-158112 Vibration Damper Hub
 1-132402 Crank-shaft Sprocket
 1-158781 Friction Ring

Same as 626

640**Material**

- 1-147446 Chain
 1-148050 Cam-shaft Sprocket
 1-137145 Generator Sprocket
 2-158730 Damper Lining
 2-158783 Damper Flywheel
 1-158729 Damper Hub
 1-158781 Friction Ring
 1-132402 Crank-shaft Sprocket

Vibration Damper Renew**626 M415**

1. Remove radiator

2. Remove fan belt

3. Remove fan pulley and nut

Note: Be sure to have two clamps for removing damper from crankshaft and place in vise and remove springs.

4. Replace damper in crankshaft and lubricate for satisfactory adjustment

5. Tighten damper

Note: Be sure that damper does not run out of line and set up front end noise.

Material

6-158784 Damper Spring

2-158730 Damper Facing

2-158783 Damper Flywheel

1-158712 Damper Hub

1-158731 Friction Ring

Same as 626

646**Material**


2-158730 Damper Facing

2-158783 Damper Flywheel

1-158729 Damper Hub

1-158731 Friction Ring

6-158784 Spring



Tool No. S. T. 144 Front seat cover
 Tool No. S. T. 145 Rear seat cover
 Tool No. S. T. 146 Double door cover
 Tool No. S. T. 147 Single door cover
 Tool No. S. T. 148 Bowd cover



Tool No. S. T. 130 - Fender Cover
 Tool No. S. T. 131 - Fender Cover

M416 Vibration Damper—Free Up and Adjust 626

1. Remove radiator
2. Remove fan belt
3. Remove fan pulley and nut
Note: Be sure to have two clamps for removing damper from crankshaft and place in vise and remove springs
4. Replace damper to crankshaft and lubricate for satisfactory adjustment
5. Tighten damper

Material

Same as 626

640

Material**M482** Front End Sprockets—Renew All (Includes M416) 626

1. Remove generator and sprocket support
2. Remove front end chain and pull all sprockets, using special puller tool No. S. T. 113
3. Supply and install new sprockets
4. Replace chain and generator and adjust chain
Note: Adjust chain tension so that when all the slack of the chain is between the camshaft and generator sprockets, the middle of this section of the chain can be moved up and down a total distance of from $\frac{1}{2}$ to 1 inch.
5. Check valve and ignition timing
Note: Set crankshaft and camshaft sprockets so that the four teeth marked O are the nearest together and line up

Material

1-132402 Crankshaft Sprocket Assembly

1-148050 Cam-shaft Sprocket

1-137145 Generator Sprocket

(Includes M416)

Same as 626

640

Material

1-132402 Crankshaft Sprocket

1-148050 Cam-shaft Sprocket

1-137145 Generator Sprocket

M483 Front End Sprockets and Chain—Renew (Includes M416) 626

1. Remove generator and sprocket support
2. Remove front end chain and pull all sprockets, using puller tool No. S. T. 113
3. Supply and install all new sprockets and chain
Note: Adjust chain tension so that when all the slack of the chain is between the camshaft and generator sprocket, the middle of this section of the chain can be moved up and down a total distance of from $\frac{1}{2}$ to 1 inch
4. Check valve and ignition timing
5. Reverse this order for reassembling
Note: Set camshaft and crankshaft sprockets so that the four teeth marked O are the nearest together and line up

Material

1-132402 Crankshaft Sprocket

1-148050 Cam-shaft Sprocket

1-137145 Generator Sprocket

1-147446 Chain

Same as 626

640

Material

1-132402 Crankshaft Sprocket

1-148050 Cam-shaft Sprocket

1-137145 Generator Sprocket

1-147446 Chain

Front End Sprocket—Replace (Renewing front cover when chain has jumped)

626 M484

Note. Use care in removal of bonnet so as not to scratch cowl. Use fender covers ST L30.

1. Drain cooling system and remove radiator
2. Remove fan belt and pulley
3. Remove damper
4. Remove motor front cover, nuts, using speed wrench
5. Jack up weight of engine (front end) to allow removal of motor front end cover
6. Remove generator and sprocket
7. Set crankshaft and camshaft sprocket so that four teeth marked (00) are the nearest together and line up
8. Replace generator and sprocket support
9. Adjust chain tension
10. Reverse order of disassembling to reassemble
11. Retune ignition

Material

1-158668 Gear Cover Gasket

Same as 626

640

Material

1-158668 Gear Cover Gasket

Generator Sprocket - Renew Cover Off:

626 M485

1. Remove generator and sprocket support
Note. If a new sprocket support is used, charge material only to this operation
2. Install new sprocket
3. Replace generator and tighten using new gasket

Material

1-115274 Gasket

1-114883 Gasket

1-137145 Sprocket

Same as 626

640

Material

1-115274 Gasket

1-114883 Gasket

1-137145 Sprocket

Generator Sprocket Support - Renew (Cover Off):

626 M486

1. Remove generator and sprocket support
Note. If a new generator sprocket is used, charge material only to this operation
2. Install new sprocket support using a new gasket
3. Replace generator and tighten

Material

1-142694 Support

1-115274 Gasket

1-114883 Gasket

Same as 626

640

Material

1-142694 Support

1-115274 Gasket

1-114883 Gasket

M493 Motor Front Cover Felt Washer Renew 626

Note: Use care in removal of bumper so as not to scratch cowl

1. Drain cooling system and remove head lamps and radiator
2. Remove fan belt and damper
3. Remove front cover bolts and nuts, using a speed wrench
4. Jack up weight of engine (front end)
5. Remove front cover
6. Dismantle cover and install felt washer
7. Rebuild the entire job

Note: Be sure radiator pins are in place

8. Adjust fan belt standard
9. Adjust front end chain, report condition of front end chain

Material

- 1-147220 Washer
1-146997 Retainer

Same as 626

640

Material

- 1-147220 Washer
1-146997 Retainer

Crankcase Lower Half - Renew

626 M51

1. Jack up front wheels, using jacks No. S. T. 155
 2. Drain crankcase lower half
 3. Disconnect crankcase oil level gauge
 4. Remove lower half and charnante
 5. Assemble oil parts on new crankcase lower half
 6. Install new lower half and fill to level with fresh medium cylinder oil
- Note: Be sure all front cover bolts are tight so as to prevent oil leaks.

Material

- 1-158616 Lower Half
 1-158701 Crankcase Gasket - Left
 1-158705 Crankcase Gasket - Right
 1-158266 Oil Gauge Gasket
 1-158280 Oil Gauge Gasket
 9 Qts. Oil

Same as 626

640

Material

- 1-158630 Lower Half
 1-158786 Crankcase Gasket - Left
 1-158787 Crankcase Gasket - Right
 1-158266 Oil Gauge Gasket
 1-158280 Oil Gauge Gasket
 10 Qua. Oil

Crankcase Lower Half Gaskets - Renew

626 M52

1. Jack up front wheels, using jacks No. S. T. 155
 2. Drain oil from motor crankcase and drop lower half
 3. Remove old gaskets
 4. Supply and install new gaskets, using cup grease on one side
 5. Reassemble, using old oil
- Note: Be sure all front end cover bolts are tight so as to prevent oil leaks. If necessary to renew oil, add prior to oil in operation.

Material

- 1-158704 Crankcase Gasket - Left
 1-158705 Crankcase Gasket - Right

Same as 626

640

Material

- 1-158786 Crankcase Gasket - Left
 1-158787 Crankcase Gasket - Right

**Crankcase Mud Guard - Right or Left
Renew**

626 M53

- Use fender cover, See, P. 130
1. Remove old mud guard and salvage as many screws, nuts and washers as possible
 2. Supply and install new right or left crankcase mud guard

Material

- 1-158725 11/4" Mud Guard - Right
 or
 1-158717 11/4" Mud Guard - Left

Miscellaneous Screws, Nuts and Washers

Use fender cover, See, P. 131

Same as 626

640

Material

- 1-158718 11/4" Mud Guard - Left
 or
 1-158613 11/4" Mud Guard - Right

Miscellaneous Screws, Nuts and Washers

M55	Crankcase Mud Guards - Tighten Both	626
	Note: To protect enameled surfaces, use tender covers S. E. 130	
1.	Supply and install missing screws and tighten crankcase mud guards	
	Note: To hold crankcase mud guard to frame use $\frac{1}{4} \times 28$ screws and use $\frac{1}{4} \times 20$ screws to hold mud guard to crankcase	
Material		
Miscellaneous		
Same as 626		648
Material		
Miscellaneous		
M57	Crankcase Oil Gauge and Fllear Assembly - Renew	626
1.	Drain oil from Crankcase	
2.	Remove Oil Level Gauge	
3.	Install New Gauge	
Material		
1-158230 Flfeat		
1-158267 Gasket		
1-158277 Gasket		
Same as 626		640
Material		
1-158230 Flfeat		
1-158267 Gasket		
1-158277 Gasket		
M59	Connecting Rod Bearings Take Up - Includes M510	626
This specification applies to bearing work known as "swaging up," the need of which has already been determined by earlier examination		
1.	Remove spark plugs to relieve all compression	
2.	Remove cap screws or nuts and lock washers or cutter pins from connecting rod	
3.	Remove one cap at a time and dress down in surface plate. Replace connecting rod cap to crankshaft using fine or hemphard to heat high spots and draw up tight. Turn flywheel over by hand several times or use starter motor. Remove bearing, examine for high spots and resurface. Continue this process until bearing is properly fitted to .0001" clearance. Bearing should not have any up or down play. Motor should be free enough to turn over easily with flywheel by hand. If bearings are set up too snug there is a danger of scoring or burning them. Make an oil test to see that bearings have been properly fitted. See operation M76 for oil test. Block off cap screws or nuts to leave bearing free for fitting and trying each of the others in this operation. Pistons are not removed	
	Note: Numbers on connecting rods and caps should be on right side of motor	
4.	Draw up cap screws or nuts solid and fit lock washers or cutter pins	
	Note: Motor should be allowed to run under its own power for some time which will have a tendency to work in bearings properly	
5.	Replace spark plugs and crankcase lower half and fill to level with ten and one-half quarts of cylinder oil	
Material		
16-5566 Lock Washers		
Same as 626		640
Material		

Crankcase Lower Half--Remove for Inspection and Replace
626 M510

1. Jack up front wheels, using jacks No. S. T. 155.
2. Drain oil from motor crankcase and drop lower half.
3. Remove oil screen and clean lower half thoroughly.
4. Reassemble and replace lower half, using new gasket.
5. Fill to level with fresh medium cylinder oil.

Note: Be sure all front end cover bolts are tight so as to prevent oil leaks.

Material

- 1-158705 Crankcase Gasket - Right
 1-158704 Crankcase Gasket - Left
 8 Qts. Medium Cylinder Oil

Same as 627

640

- 1-158786 Crankcase Gasket - Left
 1-158787 Crankcase Gasket - Right
 10 Qts. Medium Cylinder Oil

Connecting Rod Bearings--Refit--Removing Connecting Rods (Includes M641)
626 M511

1. Remove one connecting rod cap at a time and rub down on surface plate. Use blue or lampblack to locate high spots and scrape down. Continue this process until bearings are properly fitted to .005" clearance. Bearings should not have any up and down play. If bearings are set up too snug, there is a danger of scoring or burning them. Make an oil test to see that bearings are properly fitted. For oil test see operation M76. Remove piston from cylinder to this operation.
2. After proper clearance is secured, back off cap screws or nuts on each to allow for testing to one each of the others.
3. Draw up all rod cap screws or nuts solid and install lock washers or cotter pins are in place. Motor should be free enough to turn over easily with starting crank when assembled.
Note: Motor should be allowed to run under its own power for some time, which will help a tendency to work in the bearings properly.
4. Test.

Material

Same as 626

640
Material
Main Bearings--Take Up (Includes M510)
626 M512

This specification applies only to such bearing work known as "smashing up" and only one cap can be removed and worked on at a time, the upper half remaining intact. Rear main bearing cap should not be filed. Bearing must be smashed instead.

When there is evidence of having been refiled, or with improper lubrication, a scraping in and refitting operation which entails the removal and possibly the reglazing of the crankshaft is usually necessary. In such cases the entire motor should be taken out of chassis. An oil test and lifting and lowering the crankshaft in its bearings will indicate looseness at this point. This test is usually the result of the inspector's road report, when loose main bearings are suspected.

1. Remove oil mandrel and remove cotter pins, nuts or cap screws holding on main bearing cap.

M512

Cont.

2. Take off one cap at a time and roll down on surface of flat. Use blue or lamp-black to locate high spots and scrape down. Renew the operation until the bearing surface is smooth and matches the crankshaft at all points. Face true the cap is fitted, lay a .001" thickness gauge lengthwise across as a guide for proper clearance. When a slight drag is felt remove gauge and replace cap, having nuts within a turn of being tight.
Note: Numbers on main bearing caps should be on left side of motor.
 3. Treat each cap in the same manner.
 4. Tighten all nuts on cap screws and fit new cotter pins or lock washers.
 5. Replace oil manifold.
- Note: Motor should be hot enough to turn easily with starting gear.

Material**(Includes M510)****640**

Same as 626, except that a 1/2" main motor hub is required.

Material**M514****Connecting Rod Bearing - Renew One
On Exchange Basis (Includes M510-M610)****626**

Note: When a bearing is burnt either from lack of lubrication or from having been set up too tight and not properly worked in, refitting new bearing (on exchange basis) is the only remedy. A scored bearing, that has been slightly roughened, but where lead-belt metal has not been burnt or run, can be refitted.


1. Remove connecting rod cap screws or bolts and nuts.

Note: Slide connecting rod and piston assembly upward through cylinder bore, or remove wrist pin from connecting rod at the top of bore and make the rough inspection.

Reassemble in the reverse order of removal.

Connecting Rod Nut Wrench**Main Bearing Nut Wrench**

Tool No. S. T. 191 - All Models
Used on 640-645



Tool No. S. T. 192 - All Models

2. Fit new rod to crankshaft

Note: Dress end of cap by rubbing on emery cloth laid on a surface plate. Adjust bearing, using blue or lampblack to locate high spots and scrape down.

3. Fit piston to new rod and ream bushing to size using a $\frac{3}{4}$ inch expansion reamer. Piston pin should be fitted so that it can easily be pressed through bearing by hand without any side play. Space ring gaps evenly around piston.

4. Assemble piston on new rod.

Note: Do not attempt to rebush rod rods.

Material

1-158648 Connecting Rod Assembly - Left (Exchange)
or

1-158647 Connecting Rod Assembly - Right (Exchange)

Name as 626

M514
Cont.

1-158688 Connecting Rod Assembly - Exchange

640

**Main and Connecting Rod Bearings—
Take Up (Includes M510-M610)**

626 M515

This operation is a combination of connecting rod bearings take up and main bearings take up.

Note: Rear main bearing cap should not be filed. Bearing must be shimmed instead.

Note: Numbers on main bearing cap should be on left side and rod bearing caps must be on right side. Place caps on surface plate and dress down. Replace connecting rod to crankshaft and drive up tight. Turn flywheel over by hand several times or use starter motor. Remove bearing, examine for high spots and scrape down. Continue this process until bearing is properly fitted to $.001$ " clearance. Bearing should not have any up or down play. Motor should be free enough to rotate easily with flywheel. If bearings are set up too tight there is danger of scoring or burning them. Make an oil test to see that bearings have been properly fitted. See operation M76 for oil test. Main bearings are fitted in some manner as connecting rod bearings.

Material

Name as 626

640

Material

**Connecting Rod Bearings - Renew All (On Exchange Basis)
(Includes M641)**

626

M516

Note: When a bearing is burnt either from lack of lubrication or from having been set up too tight and not properly worked in, replacing new bearing on exchange basis, is the only remedy. A scored bearing that has been slightly roughened, but where babbit metal has not been eaten or run, can be refitted.

1. Fit new rods to crankshaft.

Note: Dress end of cap and rod by rubbing on emery cloth laid on a surface plate.

Adjust bearing, using blue or lampblack to locate high spots and scrape down. Repeat the operation until the bearing surface is smooth and touches the crankshaft at all points until bearings are properly fitted to $.001$ " clearance.

2. Piston pin should be fitted so that it can easily be pressed through bushing by hand without any side play.

Material

4-158648 Connecting Rod Assemblies - Left (Exchange)

4-158647 Connecting Rod Assemblies - Right (Exchange)

Name as 626

640

Material

8-158688 Connecting Rod Assemblies

M520 Connecting Rod Bearing - Refit One (Includes M510) 626

1. Open all petcock to relieve all compression
2. Pull connecting cap screws or bolts and nuts
3. Remove one cap and dress down on surface plate. Replace connecting rod cap to crankshaft, using blue or lampblack to locate high spots and draw up tight. Turn flywheel over by hand several times or use starter motor. Remove bearing, examine for high spots and scrape down. Continue this process until bearing is properly fitted to .001" clearance. Bearing should not have any up or down play.
4. Piston is not removed in this operation
5. Cotter connecting rod

Material

Same as 626

Material**M521 Connecting Rod - Align One (Rod Out)** 626

1. Align one connecting rod and piston. This is one of the most important repair operations that can be performed on a motor.
2. See specification operation M641
The connecting rod with the piston must be tested for alignment by using aligning jig.
Note: Mis-alignment produces knocks and causes vibration.

Material



Same as 626

Material**M522 Connecting Rods - Align All (Rods Out)** 626

1. Align all connecting rods and pistons. This is one of the most important repair operations that can be performed on a motor.
The connecting rods with the piston must be tested for alignment by using aligning jig tool S. T. 87.
Note: Mis-alignment produces knocks and causes vibration.

Material

Same as 626

Material**Connecting Rod Aligning Jig Piston Sleeve**

Used on 640-645

**Rear Camshaft Bearing Leak Repair or
Flywheel—Remove and Replace**

626 M540

Note: Use seat covers S. T. 144 and leader covers S. T. 130


1. Remove toe pads, toe board and floor board
2. Drop front end universal joint shaft and brake rods
3. Remove clutch casing screws and clutch housing bolts
4. Remove clutch and transmission unit and flywheel
5. Drain crankcase oil
6. Remove crankcase lower half
7. Drop rear main bearing cap and slip out change bolts at bottom one at a time and remove flywheel. If test is deemed necessary when inspecting for camshaft rear bearing leak, see operation M76
8. Install old flywheel in place and reassemble
9. Replace oil

Note: Be sure all new cotters are in place

Material1-158704 Crankcase Gasket - Left
1-158705 Crankcase Gasket - Right

Same as 626

640

Material1-158786 Crankcase Gasket - Left
1-158787 Crankcase Gasket - Right**Camshaft Rear Bearing Cover Plate Wrench**

Tool No. S. T. 639

**Camshaft—Remove for Inspection and Replace
(Includes M416)**

626 M541

1. Remove generator and sprocket
2. Remove chain and camshaft gear, use puller S. T. 113
3. Remove cylinder base nuts
4. Remove rocker lever housings

M541*Cont.*

5. Remove dowel pins holding camshaft bearings in place, insert $\frac{1}{4} \times 2\frac{1}{8}$ bolt and tap lightly
6. Remove front camshaft bearing and pull camshaft with bearings
7. Remove set screws and bearing from camshaft
Note: Raise cylinder block to clear studs enough to allow removal of motor oil pump shaft driving gear
8. Replace camshaft and front bearing
Note: When installing new cam-shaft or bearings be sure to check end play, should not exceed $.001\frac{1}{2}$. Use thickness gauge behind cam-shaft front bearing adjusting plate
Care should be taken so that each bearing is returned to its original position. When reusing old dowel pins be sure that dowel pin holes in camshaft bearing line up with pin hole in crankcase and insert dowel pins
9. Replace rocker lever housings
10. Replace camshaft gear
Note: Do not tighten cam-shaft sprocket nut too tight, this will eliminate cam-shaft end play
11. Check valve timing by verifying marks "O" on camshaft gear and camshaft gear. Marks should be directly opposite at nearest points on gears
12. Replace timing chain and generator and adjust chain
Note: Adjust chain tension so that when all the slack of the chain is between the camshaft and generator sprockets, the middle of this section of the chain can be moved up and down a total distance of from $1\frac{1}{2}$ to 1 inch
13. Adjust tappets to $.001\frac{1}{2}$ clearance with engine Warm and Idle

Material

2-158123 Rocker Lever Housing Gasket

640

Same as 626

Material

2-151587 Rocker Lever Housing Gasket

M542 Camshaft Bearing—Front—Renew
(Includes M410)

620

1. Remove generator and sprocket support
2. Remove chain and camshaft sprocket, using puller S. T. 113
3. Remove old bearing and install new
Note: Cam-shaft not removed in this operation. When installing new cam-shaft or bearing be sure to check end play, should not exceed $.001\frac{1}{2}$. Use thickness gauge behind cam-shaft front bearing adjusting plate
4. Replace camshaft sprocket
5. Replace timing chain and generator
6. Adjust chain
Note: Adjust chain tension so that when all the slack of the chain is between the camshaft and generator sprockets, the middle of this section of the chain can be moved up and down a total distance of from $\frac{1}{2}$ to 1 inch
7. Check valve and ignition timing
Note: Set camshaft and crankshaft sprockets so that the four teeth marked "O" are the nearest together or directly opposite one another

Material1-458032 Front Bearing
1-158140 End Plate**Camshaft Bearing—Front—Renew**
(Includes M410)

640

Same as 626

Material

1-137029 Front Bearing

Camshaft Rear Bearing—Renew
 (Includes M540)

 626 **M543**

1. Remove rear camshaft bearing.
2. Install new camshaft rear bearing.

Note: Return bearing to size, using an expansion reamer if necessary. Be sure to assemble bearing with the word "UP" in upright position so as not to block the oil passage.

Material
 1-156936 Rear Bearing
 1-117237 Gasket

Same as 626

640
Material
 1-158036 Rev. Bearing
 1-147237 Gasket

Camshaft Intermediate Bearing--Front or Rear -Renew One
 (Includes M544)

 626 **M544**

1. Supply and renew intermediate bearing to camshaft on bench before installing to crankcase.

Note: Bearing should fit to camshaft so that shaft will turn free and with a clearance not to exceed .001". After bearings have been properly fitted the motor should be allowed to run idle under its own power for some time, which will have a tendency to work in the bearing properly. Use plenty of lubrication during this process, as the bearings which are set up too snug will heat up readily at first; therefore there is considerable danger of scoring or burning them.

Material
 1-132735 No. 2 Bearing
 or
 1-158306 No. 3 Bearing
 or
 1-132737 No. 4 Bearing
 or
 1-132738 No. 5 Bearing
 or
 1-158307 No. 6 Bearing
 or
 1-132740 No. 7 Bearing

Same as 626

640
Material
 1-132735 No. 2 Bearing
 or
 1-132736 No. 3 Bearing
 or
 1-132737 No. 4 Bearing
 or
 1-132738 No. 5 Bearing
 or
 1-132739 No. 6 Bearing
 or
 1-152740 No. 7 Bearing

M546 Camshaft Bearings Renew All. (Includes M540-M541) 626

- Place camshaft on bench and remove two set screws holding camshaft bearings together.
- Supply and fit all new camshaft bearings.
Note: Fit bearings to camshaft before installing to crankcase. Do not get bearings too tight, as the danger of scoring or burning them is very great, until bearings are properly worked in. Bearing clearance should not exceed .001". Note: When replacing dowel pins be sure that dowel pin hole in camshaft bearings line up with pin hole in crankcase and insert dowel pin.

Material

- 1-158140 End Adjusting Plate
 1-158032 Front Bearing
 1-132735 No. 1 Bearing
 1-158364 No. 3 Bearing
 1-132737 No. 4 Bearing
 1-132738 No. 5 Bearing
 1-158367 No. 6 Bearing
 1-132739 No. 7 Bearing
 1-158654 Rear Bearing
 1-147247 Bearing Gasket
 1-311880 Bearing Cover Plate Gasket

Same as 626 640

(Includes M540-M541)**Material**

- 1-137029 Bearing Front
 1-132745 No. 2 Bearing
 1-132746 No. 3 Bearing
 1-132747 No. 4 Bearing
 1-132748 No. 5 Bearing
 1-132749 No. 6 Bearing
 1-132740 No. 7 Bearing
 1-158656 Rear Bearing
 1-147247 Gasket
 1-311880 Gasket

M547 Flywheel Renew On Exchange Basis 626

Note: To protect exposed surfaces use seat covers S. T. 244 and fender covers S. T. 180.

- Remove pedal pads, floor board and toe board.
- Drop front end universal joint shaft.
- Remove clutch housing screws and clutch housing nuts and slide.
- Remove clutch and transmission bearing and flywheel bottom cover.
- Dismantle.
- Take off crankcase lower half.
- Drop rear main bearing cap and slip out flange bolts at bottom one at a time and remove flywheel.
- Install new flywheel in place, reassemble and replace oil.

Note: Pack clutch shaft front bushing with grease and be sure all new rotors are in place.

Material

- 1-158332 Flywheel Assembly
 1-158730 Crankcase Gasket
 1-158735 Crankcase Gasket

Same as 626 640

Material

- 1-158376 Flywheel Assembly
 1-158736 Crankcase Gasket
 1-158737 Crankcase Gasket

Crankshaft - Renew (Includes M5-II)626 **M549**

- Supply and install new crankshaft

Material

1-157984 Crankshaft

Same as 626

640

Material

1-147256 Crankshaft

Cylinder Head and Crankcase Lower Half - Remove, Inspect, Report and Reassemble626 **M553**

Note: Use fender covers S. T. 130. Use care when removing head so as not to damage fender paint.

- Drain three gallons from cooling system
- Remove Dolen head and wiring assembly
- Remove upper head and cylinder head nuts
- Remove cylinder head, clean carbon from head and piston
- Drain oil lower half
- Jack up front end of chassis
- Remove lower half and inspect and report
- Reverse order of disassembly to reassemble
- Refill with new oil

Material

1-158293 Cylinder Head Gasket

1-158701 Crankcase Gasket

1-158705 Crankcase Gasket

8 Qts. Oil

Same as 626

640

Material

1-159721 Cylinder Head Gasket

1-158706 Crankcase Gasket

1-158707 Crankcase Gasket

10 Qts. Oil

Main Bearings - Re-fit (Motor Out)626 **M583**

- Remove oil manifold and pull center pin on main bearing
- Lake up one bearing and cap at a time
- Remove crankshaft if necessary
- When there is evidence of having been run hot, or with improper lubrication, scraping in and refitting operation which entails the removal and regrinding of the crankshaft is usually necessary. Refit the bearings and caps one at a time and rule down on surface plate. Use file or lampblack to locate high spots and scrape down. Repeat the operation until the bearing surface is smooth and touches the crankshaft at all points. Each time the cap is fitted lay a .001" thickness gauge lengthwise in it as a guide for proper clearance. When a slight drag is felt, remove gauge and replace cap. Treat each cap in the same manner.

Note: Number on main bearing caps should be on left side of motor. Check rear main bearing for proper end play .002" clearance

Material

9-114681 Gasket

Same as 626

640

Material

9-114684 Gasket

**M584 Main Bearing Front—Renew
(Includes M051)**

626

1. Remove generator and front end chain
2. Remove oil manifold and all main bearing caps
3. Lift out crankshaft
4. Supply and fit new front main bearing assembly and adjust all main bearings
Note: Place bearing on surface plate and dress down. Replace to crankshaft, turn flywheel over by hand several times or use starter motor. Remove bearing, examine for high spots and scrape down. Continue this process until bearing is properly fitted to .001" clearance. Check rear main bearing for proper end play .001" clearance.
The number on main bearing caps should be toward left side of motor
5. Tighten bearing caps and fit roller pins
6. Replace oil manifold, generator and front end chain

1-164814 Front Main Bearing

(Includes M051)

640

Same as 626

Material

1-164820 Front Main Bearing

**M585 Main Bearing Rear--Renew
(Includes M051)**

626

1. Remove generator and front end chain
2. Remove oil manifold and all main bearing caps
3. Lift out crankshaft
4. Supply and fit new rear main bearing assembly
Note: Place bearing on surface plate and dress down. Replace to crankshaft, turn flywheel over by hand several times or use starter motor. Remove bearing, examine for high spots and scrape down. Continue this process until bearing is properly fitted to .001" clearance. Check rear main bearing for proper end play .001" clearance.
5. Adjust all main bearings
6. Tighten all bearing caps and roller pin
Note: The numbers on main bearing caps should be to the left side of motor
7. Replace oil manifold after drawing out with air
8. Replace generator and chain
Note: Rear main bearing cap should not be bent. Bearing should be shimmed instead

Material

1-164822 Rear Main Bearing

2-158670 Bearing Cap Hole Plugs

Same as 626

640

Material

1-164822 Rear Main Bearing

2-158670 Bearing Cap Hole Plugs

**M586 Main Bearing Center—Renew
(Includes M051)**

626

1. Remove generator and front end chain
2. Remove oil manifold and all main bearing caps
3. Lift out crankshaft
4. Supply and fit new center main bearing assembly

Note: Place bearing on surface plate and press down. Replace to crankshaft, turn flywheel over by hand several times or use starter motor. Remove bearing, examine for high spots and scrape down. Continue this process until bearing is properly fitted to .001" clearance. Check rear main bearing for proper end play, .002" clearance.

M586*Cont.*

5. Adjust all main bearings
6. Tighten all bearing caps and cotter pin
Note: The numbers on main bearing caps should be to left side of motor
7. Replace oil manifold after blowing out with air
8. Replace generator and chain

Material

1-164816 Center Main Bearing

Same as 626

640**Material**

1-164816 Center Main Bearing

626 M587**Main Bearing Intermediate—Renew One (Includes M1051)**

1. Remove generator and front end chain
2. Remove oil manifold and all main bearing caps
3. Lift out crankshaft
4. Supply and fit new intermediate bearing
Note: Place bearing on surface plate and dress down. Replace to crankshaft, turn flywheel over by hand several times or use starter motor. Remove bearing, examine for high spots and scrape down. Continue this process until bearing is properly fitted to .001" clearance
5. Adjust all main bearings
6. Tighten all bearing caps and cotter pin
Note: The number on main bearing caps should be to the left side of motor.
7. Replace oil manifold after blowing out with air
8. Replace generator and chain

Material

1-164817 Intermediate Main Bearing

Same as 626

648**Material**

1-164818 Intermediate Main Bearing

Main Bearings Renew All (Motor Out)**626****M588**

1. Remove oil manifold and pull cotter pin
2. Remove all main bearings
3. Remove crankshaft from motor
4. Install all new main bearings. The upper and lower halves of the bearings are tightened in place with the crankshaft removed and aligned. The bearing cutters are adjusted to ream the bearings to size. If the crankshaft diameter is 2.375" plus .0005"-.0005", then care should be taken to adjust the cutters to 2.376" plus .0005"-.0005" so it will give .001" clearance. The crankshaft should then be returned to the crankcase and the bearing caps returned to their original position and tightened securely. The crankshaft should turn over very easily by hand and must not bind in any way. If the crankshaft turns too hard, do not loosen up the nut on the bearing caps to remedy this. Remove the crankshaft and scrape the upper and lower half of the bearing for high spots. Continue this process until bearings are properly fitted to .001" clearance. Before scraping bearings, remove all

M588

Cont.

metal chips and see that the oil grooves are not clogged and are deep enough. Numbers on main bearing caps should be on left side of motor. Check rear main bearing for proper end play .002" clearance

Material

1-164920 Bearing Assembly	Front
1-164916 Bearing Assembly	Center
1-164822 Bearing Assembly	Rear
4-164921 Bearing Assembly	Intermediate
2-164817 Bearing Assembly	Intermediate

Same as 626

640

Material

3-164820 Bearing Assembly	Front	
4-164821 Bearing Assembly	Intermediate	Short
2-164818 Bearing Assembly	Intermediate	Long
1-164816 Bearing Assembly	Center	
1-164822 Bearing Assembly	Rear	

**M589 Main and Connecting Rod Bearings—Renew All
(Includes M051) (On Exchange Basis)**

626

1. Remove generator and front end chain
2. Remove oil manifold and all main bearing caps
3. Lift out crankshaft and place in vise
4. Supply and fit all new rod bearing assemblies
Note: Rear main bearing cap should not be filed. Bearing must be shimmed instead.
5. Supply and fit all new main bearing assemblies, using blue or lampblack to locate high spots and then scrape down. Each time a cap is fitted lay a .001" thickness gauge in the cap as a guide for proper clearance and when a slight drag is felt remove gauge and replace cap.
Note: Number on main bearing caps should be on left side and numbers on connecting rod bearing should be on right side of motor
6. Tighten main bearing caps and cutter pin
Note: Bearings should be free enough to turn easily by hand. Motor should be allowed to run under its own power for some time, which will have a tendency to work in bearings properly
7. Reassemble rods and engine, using jig S. T. 108 and cutter pin
8. Replace oil manifold
9. Replace generator and chain
Note: Front end chain should be adjusted so that when all the slack of the chain is between the generator and crankshaft sprockets, this section of the chain can be moved up and down a total distance of from $\frac{1}{2}$ to 1 inch
10. Renew connecting rod piston pin bushings to size, using a $\frac{3}{4}$ or $\frac{5}{8}$ inch expansion reamer. Piston pin should be fitted so that it can easily be pressed through bushing by hand without any side play

Material

5-164822 Rear Main Bearing	
1-164819 Front Main Bearing	
1-164816 Center Main Bearing	
4-164921 Intermediate Main Bearings	
2-164817 Intermediate - Long	
4-158648 Connecting Rod - Exchange Basis	
4-158647 Connecting Rod - Exchange Basis	

Same as 626

640 M589

Cont.

Material

- 8-158388 Crankshaft Rod Bearing.
4-164821 Intermediate Main Bearing - Short
2-164818 Intermediate Main Bearings - Long
1-164920 Main Bearing - Front
1-164916 Main Bearing - Center
1-164822 Main Bearing - Rear

**Main Bearings Take Up Lower Half
(Motor Out)**

626 M591

This specification applies only to such bearing work known as "slugging up" and only one cap can be removed and worked on at a time, the upper half remaining intact.

When there is evidence of having been run hot or with improper lubrication, a scraping in and refitting operation which entails the removal and possibly the regrounding of the crankshaft is usually necessary.

1. Remove all manifold and pull cotter pins on main bearing.
2. Take off one cap at a time and rub down on surface plate. Use blue or lampblack to locate high spots and scrape down. Repeat the operation until the bearing surface is smooth and touches the crankshaft at all points. Each time the cap is fitted, lay a .0001" thickness gauge lengthwise in it as a guide for proper clearance. When a slight drag is felt, remove gauge and replace cap. Treat each cap in the same manner.

Note: Numbers on main bearing caps should be on left side of motor.

Material


9-114684 Gaskets

Same as 626

640

Material

9-114684 Gaskets



Carbon Brush
Tool No. S. T. 264



Carbon Brush - Flared Type
Tool No. S. T. 265

Cylinder Head - Renew

626

M61

Note: Use fender covers S. T. 130 to protect enamel surface from oil and scratches. Be careful when removing head so as not to damage body.

1. Remove hood and drain three gallons from cooling system.
Note: Preserve anti-freeze solution if used.
2. Remove thermostat tube.
3. Disconnect radiator to flush the rod at front end and remove radiator inlet hose.
4. Remove wiring assemblies and Delco head.
Note: Before removing Delco head turn motor to No. 1 cylinder firing center. Lift off head without disturbing position of drive shaft. Mark drive shaft so it can be reassembled in its original position. To reassemble, motor must again be turned to No. 1 firing center, drive shaft replaced in accordance with mark and head replaced with rotor on No. 1 contact.
5. Take off cylinder head nuts and lift off head, using tool S. T. 121.
6. Transfer thermostat assembly, petcocks, etc., to new head and reassemble on motor.
7. Rebuild motor.
8. Refill cooling system with clean water or anti-freeze solution.
9. Test for leaks.
Note: Tighten cylinder head nuts before car leaves station.

Material

1-158261 Cylinder Head

1-158293 Head Gasket

1-117855 Thermostatic Valve Seat Gasket

Same as 626

640

Material

1-158261 Cylinder Head

1-159721 Head Gasket

1-112875 Thermostatic Valve Seat Gasket

Cylinder Head Gasket - Renew

626

M62

Note: Use fender covers S. T. 130. Use care when removing head so as not to damage coil point.

1. Drain three qts. from cooling system. If anti-freeze solution is used preserve the glass.
2. Remove thermostat tube.
3. Remove Delco head and wiring assembly. Before removing Delco head, turn motor to No. 1 cylinder firing center. Lift off head without disturbing position of drive shaft, marking drive shaft so it can be reassembled in its original position. To reassemble, motor must again be turned to No. 1 firing center, drive shaft replaced in accordance with mark and head replaced with rotor on No. 1 contact.
4. Loosen radiator and remove radiator fastener and cylinder head, using cylinder head lifter tool No. S. T. 121.
5. Clean carbon and resin cokes.
Note: Use electric drill and carbon brushes S. T. 204 and S. T. 205 to clean carbon from cylinder head and pistons. Use tool S. T. 211 to clean relief cocks. Use air hose to remove all loose carbon.
6. Reverse order of disassembling to reassemble. Use new gaskets, refill cooling system with clean water or use anti-freeze solution.
Note: Be sure cylinder head nuts are drawn tight before car leaves station.

Material

1-158293 Head Gasket

Same as 626

640

Material

1-159721 Head Gasket

M66 Cylinder Base Gasket Renew 626

Note: Use fender covers S. T. 130 to protect enameled surfaces from oil and scratches. Be careful when removing hood so as not to damage body.

1 Remove hood and drain cooling system

Note: Preserve the anti-freeze solution

2. Loosen lower water hose and remove upper hose

3. Disconnect exhaust pipe and remove fan belt

4. Remove cylinder to crankcase stud nuts, using special wrench

5. Hoist cylinder block, using block lifter S. T. 107 to clear studs enough to allow removal of old gasket and fitting of new. Mortised joints can be cut in gasket to permit passage around connecting rods

6. Reassemble

Note: Check cylinder to see that it does not project over oil return groove and cause oil leak at valve cover plate

7. Adjust tappets not less than .004" with motor warm and idling

Material

1-158088 Base Gasket

Same as 626

640

Material

1-132702 Base Gasket

M67 Cylinder Head Nuts Tighten 626

1. Use socket wrench S. T. 201 and draw down all cylinder head nuts

Note: Care should be taken so as not to strip stud or nut

Material

Same as 626

640

Material**M68 Cylinder Base Nuts Tighten** 626

Note: Use fender covers to protect surfaces

1. Remove valve cover plates

2. Tighten all cylinder base nuts (use special socket wrench)

Note: See that cylinder block does not project over valve tappet oil return groove and cause oil leak at valve cover plate

3. Adjust valve tappets not less than .004" clearance with motor warm and idling.

Note: See that adjusting screws are properly locked. Before replacing valve cover plate be sure center stud is tight so it will not be against distributor drive shaft and cause a rattle

4. Replace valve cover plates

Material

Same as 626



640

Material


**Kerosene Drain Cap and Tube Assembly for
Cylinder Grinder**



Cylinder Grinder (Elutto)



Kerosene Feed Can for Cylinder Grinder



Tool No. S. T. 655

**M602 Cylinder—Hone One and Install Piston Assembly
(Includes M510-M610)**

626

Note. See operation M611 for specification.

1. Remove piston and connecting rod
2. Hone cylinder using Hutto grinder

Note: Caution should be taken to prevent grindings from getting into bearings. Always remember to start the Hutto grinder at the bottom of the bore which is larger, due to taper condition of cylinder caused by piston ring travel, then grinding it larger using the bottom as guide, working the grinder upward then remove the ridge left by ring travel.

Always grind one bore a few strokes to discover the real condition of the cylinder bore. Then get a piston to fit cylinder out of stock. Use a dial gauge or micrometer. Some mechanics use a piston as a gauge. How to determine proper fit of piston; place piston into cylinder placing .0015" feeler alongside of piston. Under this condition, the piston must move its entire travel without sticking. The pistons are fitted to .0015" clearance. It should be possible to pull out the feeler from between piston and cylinder wall with grip of finger and thumb only. Do not let the grinder run free in the bore. Make it groan by turning up on the adjusting screw at top of grinder, use sufficient kerosene, as constant flow must be had at all times while grinding.

3. After completing the grinding operation, see that the cylinder and piston are washed with kerosene and then blown off thoroughly with air hose
4. Ream piston pin bushing to size using seamer, tool No. S. T. 614 or S. T. 616 and align connecting rod

Material

1-163182 Piston Assembly (.004" Oversize $\frac{3}{8}$ " Pin)
1-163183 Piston Assembly (.006" Oversize $\frac{3}{8}$ " Pin)
1-163184 Piston Assembly (.009" Oversize $\frac{3}{8}$ " Pin)
1-163185 Piston Assembly (.015" Oversize $\frac{3}{8}$ " Pin)
1-163186 Piston Assembly (.020" Oversize $\frac{3}{8}$ " Pin)
1-163187 Piston Assembly (.030" Oversize $\frac{3}{8}$ " Pin)
1-163188 Piston Assembly (.045" Oversize $\frac{3}{8}$ " Pin)

Same as 626

640

Material

1-148786 Piston Assembly (.004" Oversize $\frac{7}{16}$ " Pin)
1-148785 Piston Assembly (.006" Oversize $\frac{7}{16}$ " Pin)
1-148784 Piston Assembly (.010" Oversize $\frac{7}{16}$ " Pin)
1-148783 Piston Assembly (.015" Oversize $\frac{7}{16}$ " Pin)
1-148782 Piston Assembly (.020" Oversize $\frac{7}{16}$ " Pin)
1-148781 Piston Assembly (.030" Oversize $\frac{7}{16}$ " Pin)
1-148780 Piston Assembly (.045" Oversize $\frac{7}{16}$ " Pin)

**Cylinder - Hone All - Install Piston Assemblies --
Grind Valves and Tune Motor (Includes M641)**
626 M603
1. Hone cylinder using Hutto grinder

Note: Caution should be taken to prevent grinding from getting into bearings. Always remember to start the Hutto grinder at the bottom of the bore which is larger, due to taper condition of cylinder caused by piston ring travel, then grinding it larger using the bottom as guide, working the grinder upward then removing the ridge left by ring travel.

Always grind one more a few strokes to discover the real condition of the cylinder bore, then get a piston to fit cylinder out of stock, use a dial gauge or micrometer. Some mechanics use a piston as a gauge.

How to determine proper fit of piston: Place piston into cylinder placing .0015" feeler alongside of piston. Under this condition the piston must move its entire travel without sticking. Pistons are fitted in .0015" clearance. It should be possible to pull out the feeler from between piston and cylinder wall with grip of finger and thumb only.

Do not let the grinder run free in the bore, make it green by turning up on the adjusting screw at the top of grinder. Use sufficient kerosene as a constant flow must be had at all times while grinding.

2. After completing the grinding operation, see that the cylinder and piston are washed with kerosene and then blown off thoroughly with an air hose.
3. Ream piston pin bushing to size using reamers, tool No. S. T. 614 or S. T. 616
4. Clean carbon, grind valves and tune motor. (See operation M24 for specification)

Material

1-164192 Carburetor basket	
8-163182 Piston Assembly (.003" oversize $\frac{7}{8}$ " Pin)	
or	
8-163183 Piston Assembly (.003" oversize $\frac{7}{8}$ " Pin)	
or	
8-163184 Piston Assembly (.010" oversize $\frac{7}{8}$ " Pin)	
or	
8-163185 Piston Assembly (.015" oversize $\frac{7}{8}$ " Pin)	
or	
8-163186 Piston Assembly (.020" oversize $\frac{7}{8}$ " Pin)	
or	
8-163187 Piston Assembly (.030" oversize $\frac{7}{8}$ " Pin)	
or	
8-163188 Piston Assembly (.045" oversize $\frac{7}{8}$ " Pin)	

20006 as 626

640
Material

1-144450 Carburetor basket	
8-148786 Piston Assembly (.003" oversize $\frac{7}{8}$ " Pin)	
or	
8-148785 Piston Assembly (.005" oversize $\frac{7}{8}$ " Pin)	
or	
8-148781 Piston Assembly (.010" oversize $\frac{7}{8}$ " Pin)	
or	
8-148783 Piston Assembly (.015" oversize $\frac{7}{8}$ " Pin)	
or	
8-148782 Piston Assembly (.020" oversize $\frac{7}{8}$ " Pin)	
or	
8-148781 Piston Assembly (.030" oversize $\frac{7}{8}$ " Pin)	
or	
8-148780 Piston Assembly (.045" oversize $\frac{7}{8}$ " Pin)	

**M604 Cylinder - Hone One and Renew Piston
(Piston Out)**

626

1. Hone cylinder, using Hone cylinder.

Note: Caution should be taken to prevent grinding front getting into bearings. Always remember to start the Hone grinder at the bottom of the bore which is larger, due to taper condition of cylinder caused by piston ring travel; then grinding it larger using the bottom as guide working the grinder upward, then removing the ridge left by ring travel.

Always grind one hole a few strokes to discover the real condition of the cylinder bore. Then set a piston to fit cylinder out of stock. Use a dial gauge or micrometer. Some mechanics use a new piston as a gauge.

How to determine proper fit of piston. Place piston into cylinder placing .0015" feeler alongside of piston. Under this condition the piston must move its entire travel without sticking. The piston is fitted to .0015" clearance. It should be possible to pull out the feeler from between piston and cylinder walls with grip of finger and thumb only.

Do not let the grinder run free in the bore. Make it green by turning up on the adjusting screw at top of grinder. Use sufficient kerosene as constant flow should be had at all times while grinding.

2. After completing the grinding operation see that the cylinder and piston are washed with kerosene and then blown off thoroughly with air hose.

3. Ream piston pin bushing to size using reamers tool No. S. T. 614 or S. T. 616

Material

- 1-163182 Piston Assembly - .001" oversize $\frac{1}{2}$ " Pin
or
1-163183 Piston Assembly - .0025" oversize $\frac{1}{2}$ " Pin
or
1-163184 Piston Assembly - .0010" oversize $\frac{1}{2}$ " Pin
or
1-163185 Piston Assembly - .0015" oversize $\frac{1}{2}$ " Pin
or
1-163186 Piston Assembly - .0020" oversize $\frac{1}{2}$ " Pin
or
1-163187 Piston Assembly - .0030" oversize $\frac{1}{2}$ " Pin
or
1-163188 Piston Assembly - .0035" oversize $\frac{1}{2}$ " Pin
Same as 626

626

Material

- 1-148786 Piston Assembly - .001" oversize $\frac{1}{2}$ " Pin
or
1-148785 Piston Assembly - .005" oversize $\frac{1}{2}$ " Pin
or
1-148784 Piston Assembly - .010" oversize $\frac{1}{2}$ " Pin
or
1-148783 Piston Assembly - .015" oversize $\frac{1}{2}$ " Pin
or
1-148782 Piston Assembly - .020" oversize $\frac{1}{2}$ " Pin
or
1-148781 Piston Assembly - .030" oversize $\frac{1}{2}$ " Pin
or
1-148780 Piston Assembly - .045" oversize $\frac{1}{2}$ " Pin

**M605 Cylinder - Hone Two and Renew Pistons
(Pistons Out)**

626

1. Hone cylinder using Hone grinder tool
2. (See operation M604 for specifications)

Material

- 2-163182 Piston Assembly +.003" Oversize $\frac{7}{8}$ " Pin
 or
 2-163183 Piston Assembly +.005" Oversize $\frac{7}{8}$ " Pin
 or
 2-163184 Piston Assembly +.000" Oversize $\frac{7}{8}$ " Pin
 or
 2-163185 Piston Assembly +.015" Oversize $\frac{7}{8}$ " Pin
 or
 2-163186 Piston Assembly +.010" Oversize $\frac{7}{8}$ " Pin
 or
 2-163187 Piston Assembly +.030" Oversize $\frac{7}{8}$ " Pin
 or
 2-163188 Piston Assembly +.045" Oversize $\frac{7}{8}$ " Pin

Same as 626

M605
*Cont.***640****Material**

- 2-148786 Piston Assembly +.003" Oversize $\frac{7}{8}$ " Pin
 or
 2-148785 Piston Assembly +.005" Oversize $\frac{7}{8}$ " Pin
 or
 2-148784 Piston Assembly +.000" Oversize $\frac{7}{8}$ " Pin
 or
 2-148783 Piston Assembly +.015" Oversize $\frac{7}{8}$ " Pin
 or
 2-148782 Piston Assembly +.020" Oversize $\frac{7}{8}$ " Pin
 or
 2-148781 Piston Assembly +.040" Oversize $\frac{7}{8}$ " Pin
 or
 2-148780 Piston Assembly +.045" Oversize $\frac{7}{8}$ " Pin

**Cylinders - Hone All and Renew Pistons
(Block Off)****626 M606**

1. Hone cylinder using Hone grinder tool
2. See operator's Manual for specification

Material

- 8-163182 Piston Assembly +.003" Oversize $\frac{7}{8}$ " Pin
 or
 8-163183 Piston Assembly +.005" Oversize $\frac{7}{8}$ " Pin
 or
 8-163184 Piston Assembly +.000" Oversize $\frac{7}{8}$ " Pin
 or
 8-163185 Piston Assembly +.015" Oversize $\frac{7}{8}$ " Pin
 or
 8-163186 Piston Assembly +.020" Oversize $\frac{7}{8}$ " Pin
 or
 8-163187 Piston Assembly +.030" Oversize $\frac{7}{8}$ " Pin
 or
 8-163188 Piston Assembly +.045" Oversize $\frac{7}{8}$ " Pin

Same as 626

640**Material**

- 8-148786 Piston Assembly +.003" Oversize $\frac{7}{8}$ " Pin
 or
 8-148785 Piston Assembly +.005" Oversize $\frac{7}{8}$ " Pin
 or

M606 8-148784 Piston Assembly (.010" oversize $\frac{1}{2}$ " Pin)
or

8-148783 Piston Assembly (.015" oversize $\frac{1}{2}$ " Pin)

or

8-148782 Piston Assembly (.020" oversize $\frac{1}{2}$ " Pin)

or

8-148781 Piston Assembly (.030" oversize $\frac{1}{2}$ " Pin)

or

8-148780 Piston Assembly (.040" oversize $\frac{1}{2}$ " Pin)


Cont.

M610 Cylinder Head—Remove for Inspection,
Clean Carbon and Replace Head 626

Note. Use leader carbon S. T. 140. Use care when removing head, so as not to damage head pins.

1. Drain three gallons from cooling system. If anti-freeze solution is used, preserve the same.
2. Remove thermometer tube.
3. Remove Delco unit, and wiring assembly. Before removing Delco head, turn number on No. 1 cylinder firing center. Turn off head without disturbing position of drive shaft mark; drive shaft can be reassembled in its original position. To reassemble, slot must again be turned in No. 1 firing center, drive shaft replaced in accordance with mark and head replaced with rotor on No. 1 contact.
4. Loosen and remove nuts.
5. Remove nuts, holding cylinder head in place.

Tool No. S. T. 121—Cylinder Head lifter



6. Remove cylinder head, using cylinder head bitter tool S. T. 121.
7. Clean carbon and relief cocks.
8. Inspect cylinder.

Note: Use electric drill and carbon brushes S. T. 204 and S. T. 205 to clean carbon from cylinder head and piston.

Use air hose to remove all loose carbon.

9. Reverse order of disassembling to reassemble—use new gaskets, refill cooling system with clean water or use anti-freeze solution.

Note: Be sure cylinder head nuts are drawn tight before car leaves station.

Material

1-158293 Cylinder Head Gasket

Same as 626

1-159721 Cylinder Head Gasket

M610
Cont.**640****Cylinder Head Remove, Inspect
Cylinder Bore and Replace****626 M611**

Note: Use leather covers S. T. 130 to protect enameled surfaces from oil and scratches. Be careful when removing hood so as not to damage body.

1. Drain three gallons from cooling system.

Note: Preserve the anti-freeze solution if used.

2. Remove Delco heat and wiring assembly.

3. Remove thermometer tube.

Note: Before removing Delco head turn motor to No. 1 cylinder firing center and lift coil head without disturbing position of drive shaft. Mark drive shaft so that it can be assembled in its original position. To reassemble, the motor must again be turned to No. 1 firing center, drive shaft replaced in accordance with mark and head replaced with motor on No. 1 contact.

4. Loosen hose clamps and remove cylinder head.

Note: Use speed wrench to loosen cylinder head nuts.

5. Clean carbon and relief cocks.

Note: Use electric drill and carbon brushes S. T. 204 and S. T. 205 to clean carbon from cylinder head and piston. Use air hose to remove all loose carbon.

6. Inspect cylinder bore with inside micrometers.

7. Reverse order of disassembling to reassemble.

8. Refill cooling system.

Note: Be sure that cylinder head nuts are drawn tight before car leaves service station.

Material

1-158293 Cylinder Head Gasket

Same as 626

640**Material**

1-159721 Cylinder Head Gasket

**Cylinder Head Stud- Renew One
(Includes M610)****626 M615**

1. Remove old stud.

2. Supply and install new stud.

Note: When threads in cylinder, holding cylinder head stud, are stripped, drill cylinder to $\frac{1}{2}$ and tap out $\frac{3}{8} \times 18$. Care should be taken so as not to drill through boss, causing water leak. Install plug No. 67541, tighten securely and cut flush with cylinder, using a back saw blade. Dress down the remaining surface of plug with a flat file or hone. Drill $\frac{1}{2}$ hole in plug, tap $\frac{1}{4} \times 20$ and install standard stud.

Material

1-125485 Stud

Same as 626

640**Material**

1-125485 Stud

M630 Cylinder Block—Remove for Inspection and Replace 626
 (Includes M610)

1. Drain cooling system and remove radiator
2. Remove vacuum tank and disconnect gas lines and control rods
3. Disconnect exhaust pipe
Note: Loosen and tilt radiator forward as far as possible and remove fan
4. Remove fan belt
5. Remove valve cover plate
6. Remove cylinder to crankcase stud nuts, using S. T. 105
Note: If the connecting rods are out and block is off, replace piston and connecting rod assemblies into cylinder block before replacing block on crankcase as this is the proper way to replace rods with block off.
7. Remove cylinder block, using block lifter S. T. 107
Note: Pistons are not removed in this operation
8. Inspect block and report condition
Note: Check cylinder to see that it does not project over oil return grooves and cause an oil leak at valve-cover plate
9. Reassemble block in place, using new base gasket. Care should be taken in lowering block over pistons

Material

- 1-158088 Cylinder Base Gasket
Same as 626 640
- 1-132702 Cylinder Base Gasket

M631 Piston Rings—Renew on One Piston 626
 (Includes M510 and M610)

1. Remove connecting rod and piston assembly
2. Remove old rings from one piston and clean grooves
Note: To remove piston rings, place a feeler gauge back of the rings and, guiding the feeler around the piston, with one hand, force the rings out of the groove with the other hand. Remove the piston rings over the top of the piston. It will be found easier to remove the top ring first, then the center and lastly the bottom. Be careful when handling a piston—its walls are light and may be easily sprung, causing the piston to burst if forced.
3. Select oversize rings to fit cylinder
Note: In checking ring gaps, place ring on cylinder and push it down, using the old piston until it rests squarely against piston at all points. It may be necessary to file ring gaps to $.0005"$ clearance when new or oversize. Do not remove more metal than necessary.
4. Fit rings to piston grooves
Note: See that ring rolls entirely around the piston groove. If the ring is properly fitted, a slight drag should be felt. If it is too loose try another ring. If too thick, try a shot of very fine emery cloth on a surface plate and slide ring back and forth until proper fit has been secured. Do not ring separately.
5. Install rings on piston
Note: Rings must not stick in any position or have any up and down play
6. Spacing evenly around the piston
Note: Align connecting rods, using alignment jig. A straight edge should be laid along the lip of piston to make sure that it does not project. If it sticks out it can be tapped in with a soft hammer or block of wood
7. Replace connecting rod and piston assembly, using piston ring compressing sleeve
Note: The number on connecting rod and cap must be to right side of motor (See operation M611 for specifications.)

Material

- 1-164809 Ring Slotted .0013
3-163881 Ring Oversize .0014"

3-163882 Ring Oversize .005"
 3-164630 Ring Oversize .010"
 3-164631 Ring Oversize .015"

Same as 626

(Includes M510-M610)

Using one Teflon ring in lower ring groove

Material

1-166700 Ring Sintered
 3-166699 Ring Oversize .005"
 3-143415 Ring Oversize .015"
 3-144595 Ring Oversize .010"
 3-143314 Ring Oversize .015"

M631

Cont.

626

Piston Ring Expander



Motor Overhaul Complete - Starter Motor, Generator, Hone and Install Piston - Renew Main and Crankshaft Bearings
 (Includes M641, Labor Only)

M633

626

- Specifications are the same as M635 except to expand bore cylinder to proper size. See operation M635 Fit and install set of alloy piston assemblies.
- Overhaul starter motor and generator. See operation E221 and E331.
- Remove the old main bearing and install new main bearing and align seam.
- Renew crankshaft bearings.

Note: Be sure to index downdraft back on crankshaft and crankshaft. If it is sprung to any extent, place it between two center lathe. By using dial indicator, the exact amount it is out of place can be determined and if it is sprung to any extent, renew the crankshaft.

The bearing cutters are adjusted to renew the bearing to size. If the crankshaft diameter is 2.375" plus .0005"-.0005", then care should be taken to adjust the reamers to 2.371" plus .0005"-.0005" so it will give .001" clearance. The crankshaft should then be returned to the original size and the bearing caps returned to their original position and tightened securely.

The crankshaft should turn over very easily by hand and must not bind in any way. If the crankshaft turns too hard, do not loosen up the nut on the bearing cap to remedy this. Remove the crankshaft and scrape the

M633*Cont.*

upper and lower half of the bearing for high spots. Continue this process until bearings are properly fitted to .001" clearance. Check the rear main bearing for proper end play .002" clearance. The same as above applies to camshaft bearing.

All parts listed should not be required.

Note: The connecting rod wrist pin bushing projects out on one side. Connecting rod number (1) one is called right. Wrist pin bushing should be toward the front of motor. Connecting rod number (2) two is called left. Wrist pin bushing should be toward rear of motor. The other end of connecting rod wrist pin bushing must be flush with rod, etc.

Material

- 1-164819 Main Bearing Assembly Front
- 4-164821 Main Bearing Assembly Intermediate Short
- 2-164817 Main Bearing Assembly Long
- 1-164816 Main Bearing Assembly Center
- 1-164822 Main Bearing Assembly Rear
- 1-159032 Camshaft Bearing Front
- 1-132735 No. 2 Bearing
- 1-159306 No. 3 Bearing
- 1-132737 No. 4 Bearing
- 1-132738 No. 5 Bearing
- 1-159307 No. 6 Bearing
- 1-132740 No. 7 Bearing
- 1-158656 Rear Bearing
- 2-158214 Exhaust Manifold Gasket Small
- 2-158033 Exhaust Manifold Gasket Intermediate
- 2-158035 Exhaust Manifold Gasket Large
- 1-129047 Water Pump Body Gasket
- 1-1271164 Camshaft Driving Chain
- 1-114883 Generator Support Gasket
- 16-158223 Rocker Levers
- 2-148425 Rocker Lever Housing Gaskets
- 1-158088 Cylinder to Crankcase Gasket
- 1-158668 Gear Cover Gasket
- 1-115254 Generator Gasket
- 1-103395 Carburetor Gasket
- 1-45935 Carburetor Body Plug Gasket
- 1-116626 Carburetor Suction Plug Gasket
- 9-114681 Oil Manifold Gasket
- 16-112293 Valve Springs
- 2-163181 Alloy Piston Assorted
- 1-158203 Cylinder Head Gasket
- 1-67648 Water Pump Back
- 9-158222 Piston Pin Bushing
- 1-158504 Crankcase Gasket
- 1-158705 Crankcase Cover
- 4-158648 Connecting Rod Lockwashers
- 4-158647 Connecting Rod Bolts
- 4-158045 Inlet Valve
- 4-158039 Exhaust Valve
- 8 qts. Cylinder Oil

Miscellaneous

Same as 630

640


All parts listed should not be required.

Material

- 1-164820 Main Bearing Assembly Front
- 4-164821 Main Bearing Assembly Intermediate Short
- 2-164818 Main Bearing Assembly Long
- 1-164816 Main Bearing Assembly Center
- 1-164822 Main Bearing Assembly Rear

- 1-157029 Crankshaft Bearing - Front
- 1-132735 No. 2 Bearing
- 1-132736 No. 3 Bearing
- 1-132737 No. 4 Bearing
- 1-132738 No. 5 Bearing
- 1-132739 No. 6 Bearing
- 1-132740 No. 7 Bearing
- 1-158656 Rear Bearing
- 2-141478 Exhaust Manifold Gasket - Small

M633
Cont.



- 2-141436 1-141437 Manifold Gasket - Intermediate
- 1-141437 1-141436 Manifold Gasket - Large
- 1-129037 Water Pump Body Gasket
- 1-141446 Crankshaft Driving Chain
- 1-144683 Generator Support Gasket
- 16-158724 Rocker Arms
- 2-141887 Rocker Arms, Housing Gaskets
- 1-132762 Cylinder to Crankcase Gasket
- 1-158668 Cam Cover Gasket
- 1-131711 Cylinder Water Inlet Flange Gasket
- 1-115273 Generator Gasket
- 1-141440 Clutchcket Cover Gasket
- 1-45933 Clutchcket Body Plug Gasket
- 1-456626 Clutchcket Strainer Plug Gasket
- 9-114684 Oil Manifold Gasket
- 16-147286 Valve Springs
- 8-148778 Alloy Piston Assemblies
- 1-159721 Cylinder Head Gasket

M633*Cont.*

- 1- 67618 Water Pump Packing
 8-156648 Piston Pin Bushings
 1-158786 Crankcase Gasket
 1-158787 Connecting Rod Gasket
 8-158388 Connecting Rod Bolts
 4-146989 Inlet Valve
 4-146985 Exhaust Valve
 10 Qts. Cylinder Oil
 Miscellaneous

M635**Cylinder and Piston Assembly, Standard Pins and Bushings, Supply and Install (Includes M641) (Labor Only)**

626

The price of overhauling starter motor and generator is not included in the price of this operation.

Note: Protect surfaces from oil, grease and scratches by using covers for fenders, seats, doors, hood and steering wheel. Be careful when removing hood, so as not to damage body.

1. Check oil at gauge.
2. Drain cooling system, preserve anti-freeze solution and remove head lamp assembly, radiator (in cool), wiring assembly, spark plugs, fan belt, water pump, distributor head and cylinder head, using cylinder head lifter S. T. 121.
3. Take off carburetor assembly and clean and adjust.
 Note: Carburetor adjustment. Set air valve adjusting nuts so that the valve has $\frac{3}{16}$ of an inch drop on the inside spring on 626 model. On the 640 model the valve has a $\frac{1}{8}$ inch drop on the inside spring. Set outside spring so that with the throttle closed and spark retarded, the motor operates smoothly.
4. Remove exhaust manifold, using wrench S. T. 101.
 Note: If car is equipped with heater add operation M955.
5. Remove cylinder base nuts, using cylinder base nut wrench.
6. Remove cylinder block, using block lifter S. T. 107 and take out valves, springs, push rods and set screws, using valve lifter S. T. 220.
7. Clean carburetor, using an electric drill and carbon brushes S. T. 204 and S. T. 205 to clean carbon from cylinder head. Use tool No. S. T. 211 to clean relief ports. Use air hose to remove all loose carbon.
8. Drop lower half of crankcase and remove connecting rods.
9. Blow out of 1/4 in. oil line, clean oil pump and adjust oil pressure.
 Note: The pressure of the oil pump works directly against the spring and ball check. To increase the pressure on gauge it is necessary to increase the spring tension, and to decrease the pressure, reduce the tension of spring. Gauge should register from 20 to 50 pounds.
10. Clean lower half of crankcase and wash in acetone thoroughly using power washer and air dryer.
11. Grind valves but standard file block and assemble.
 Note: Be sure that grinding compound is removed from cylinder and valve seats.
12. Replace valves and stems.
13. Take up main and connecting rod bearings.
 Note: Remove one cap at a time and dress down on surface plate. Replace connecting rod cap to crankshaft, using blue or tan chalk to locate high spots and draw up tight. Turn flywheel over by hand several times or use starter motor. Remove bearing, examine for high spots and scrape down. Continue this process until bearing is properly fitted to .001" clearance. Bearing should not have any up or down play. Motor should be free enough to turn over easily with flywheel by hand. If bearings are set up too snug, there is a danger of scoring or burning them. Make an oil test to see that bearings have been properly fitted. See operating M70 for oil test. Back off nuts to leave bearing free for fitting and trying each of the others on this operation. Numbers on connecting rods and caps should be on right side of motor.
14. Reassemble rods with pistons, rings, pins and bushings.
 Note: After fitting the pistons to the connecting rods a further check should be made to see that rods are lined up properly. Use aligning jig S. T. 87.

M635
Cont.

Pistons should be fitted so that they will rock back and forth on the pins. Piston pins fitted too tightly are likely to freeze and score the piston and cylinder.

Note: The connecting rod wrist pin bushing prevents oil on one side. Connecting rod number "1" one is called right. Wrist pin bushing should be toward the front of motor. Connecting rod number "2" two is called left. Wrist pin bushing should be toward rear of motor. The other end of connecting rod wrist pin bushing must be flush with rod, etc.

15. Renew bushings to size, using a $\frac{3}{4}$ or $\frac{7}{8}$ " expansion reamer. Piston pins should be fitted so that they can just be pressed through bushings by hand and without any up or down play.

Note: When renewing piston pin bushings care should be taken not to allow the bearing to chatter, as the bushing should be perfectly smooth.

16. Replace connecting rods to motor, using a piston ring compressing sleeve. Note: See that the ring rolls entirely around the piston groove. If the rings are properly fitted a slight drag should be felt.

17. Remove camshaft rocker lever housings, replace worn levers and pins and replace assembly.

18. Renew front gear cover and renew chain and overdrive vibration damper.

Note: Adjust chain tension so that when all the slack of the chain is between the camshaft and generator sprockets, the middle of this section of the chain can be moved up and down a total distance of from $\frac{1}{2}$ to 1 inch.

19. Install cylinder block and adjust tappets standard to not less than .004" clearance with motor warm and idling.

20. Paint cylinder head.

21. Replace cylinder head, using a new gasket.

Note: Shims should never be placed on a gasket when installing a cylinder head. Oil grease should be applied on both sides of seal gasket.

22. Replace distributor head and adjust points. (Renew points if necessary.)

Note: The contact points will require much attention or refiling. They may be very rough when they become badly burnt so as to cause missing. They should be trued so that the contact surfaces are exactly parallel. Adjust contact points so that the gap of ".015" to ".020" is secured at their greatest separation.

23. Remove ignition. (See operation E114.)

24. Replace and adjust spark plugs to $\frac{1}{8}$ " gap. (Renew plugs if necessary.)

Note: When replacing spark plugs be sure that contacts are in position.

25. Replace water pump and fan belt. (See operation M-17 for belt adjustment.)

Note: Before replacing water pump, take end play out of water pump shaft by shrinking thrust button. End play should not exceed .010".

26. Refill cooling system with water or anti-freeze solution.

27. Fill motor crankcase to level with fresh oil and test.

Note: Under no circumstances should a motor after an overhaul be run at high speed. Racing the motor is entirely injurious and may cause serious trouble.

28. Adjust tappets to .004" clearance with the motor warm and idling.

Note: Be sure cylinder head nuts are drawn tight and water pump and hose connections do not leak before car leaves service station.

Be sure that valve tappet adjusting screw lock nut is properly locked.

29. Replace valve cover plate.

Note: \$172.15, \$181.15, \$198.65 are the estimated zone prices of parts required to recondition the motor. All parts listed should not be required.

Material

1-194801 Cylinder and Piston Assembly (Standard) (.25" Pin)
1-158704 Camcase Gasket - Right
1-158705 Camcase Gasket - Left
1-417416 Camshaft Driving Chain
1-115274 Generator Support Gasket
1-163159 Radiator Outlet Hose (Use $6\frac{1}{4}$ " of 96749)
8-158724 Camshaft Rocker Lever
2-158050 Rocker Lever Pin
12-132179 Valve Push Rod Set Screw

M635*Cont.*

8-147447 Push Rod Guide
1-158088 Cylinder to Crankcase Gasket
1-158668 Gear Cover Gasket
1-162201 Radiator Inlet Hose (Use 3 $\frac{3}{4}$ " of 96739)
1-137145 Generator Sprocket (Used Hydrot)
1-132402 Crankshaft Sprocket
1-148050 Camshaft Sprocket
2-147289 Valve Spring
2-158039 Exhaust Valve
2-158035 Inlet Valves
8-132177 Valve Push Rod
2-158648 Connecting Rods (Exchangers)
2-158647 Connecting Rods (Exchange)
1-129047 Water Pump Body Gasket
1-114883 Generator Sprocket Support to Crankcase Gasket
8-158122 Piston Pin Bushings
2-19796 Contact Arm Assembly, North East
2-19959 Contact Screw Assembly, North East
2-142711 Spark Plugs
2-158214 Exhaust Manifold Gasket
2-158034 Exhaust Manifold Gasket
1-158033 Manifold Gasket
1-132585 Exhaust Pipe to Manifold Gasket
1-121711 Cylinder Water Inlet Flange Gasket
1-50669 Oil Pump Relief Valve Ball
2-158123 Rocker Lever Housing Gasket
1 Gall. Kerosene
8 Quts. Cylinder Oil
Miscellaneous

Cylinder and Piston Assembly, Standard Pins and Bushings, Supply and Install (Includes M641) (Labor Only)**648**

Note: The price of overhauling the starter motor and generator is not included in the price of this operation.

Specifications same as 626.

Note: \$182.15, \$191.15, \$211.05 are the estimated zone prices of parts required to recondition the motor. All parts listed should not be required.

Material

1-164805 Cylinder and Piston Assembly (Standard)
2-141478 Exhaust Manifold to Cylinder Gasket
2-141486 Exhaust and Brake Manifold to Cylinder Gasket
1-141437 Exhaust Manifold to Cylinder Gaskets
1-141535 Exhaust Pipe Gasket
1-147446 Camshaft Driving Chain
1-163199 Radiator Outlet Hose (Use 6 $\frac{1}{4}$ " of 96739)
1-121711 Cylinder Water Inlet Flange Gasket
2-131888 Rocker Lever Pins
16-132179 Valve Push Rod Set Screws
8-147447 Valve Push Rod Guides
8-158723 Rocker Levers
1-132702 Cylinder to Crankcase Gasket
1-158786 Crankcase Gasket - Left
1-159787 Crankcase Gasket - Right
1-158668 Gear Cover Gasket
1-162201 Radiator Inlet Hose (Use 3 $\frac{3}{4}$ " of 96739)
1-146988 Exhaust Valve
1-146989 Inlet Valves
1-114883 Generator Sprocket Support to Crankcase Gasket
1-129047 Water Pump Body Gasket
8-156648 Piston Pin Bushings

1-137145 Generator Sprocket (Owen-Dynet)		M635 <i>Cont.</i>
1-115274 Generator Gasket or		
1-132402 Crankshaft Sprocket		
1-148060 Camshaft Sprocket		
2-147289 Valve Springs		
8-132177 Valve Push Rods or		
2-158368 Connecting Rod (On Exchange)		
2- 19796 Contact Arm Assembly (North East)		
2- 19959 Contact Screw Assembly (North East)		
2-142711 Spark Plugs		
1- 5069 Oil Pump Relief Valve Ball		
2-191887 Rocker Lever Housing Gaskets		
1 Gal. Kerosene		
10 Qts. Medium Cylinder Oil		
Miscellaneous		

Cylinder and Piston Assembly—Supply**On Exchange Basis and Install (Includes M641) (Labor Only)**626 **M636**



Note: The price of overhauling starter motor or generator is not included in the price of this operation.

See operation M645 for specifications.

Note: \$111.05, \$117.05, \$120.05 are the estimated zone prices of parts required to recondition the motor. All parts listed should not be required.

Material

1-164802 Cylinder and Piston Assembly .015" Oversize (Exchange)	
1-164803 Cylinder and Piston Assembly .030" Oversize (Exchange)	
1-164804 Cylinder and Piston Assembly .045" Oversize (Exchange)	
2-158214 Exhaust Manifold to Cylinder Gaskets	
2-158034 Exhaust and Intake Manifold to Cylinder Gasket	
1-158013 Exhaust Manifold to Cylinder Gaskets	
1-129847 Water Pump Body Gasket	
1-158704 Crankcase Gasket	
1-158705 Crankcase Gasket	
1-147446 Crankshaft Driving Chain	
1-114883 Generator Sprocket Support to Crankcase Gasket	
1-162201 Radiator Inlet Hose (Use 3/4" of 96739)	
16-132179 Valve Push Rod Screws	
8-158723 Rocker Levers	
2-158030 Rocker Lever Pins	
8-141447 Valve Push Rod Guides	
1-158058 Cylinder to Crankcase Gasket	
1-158668 Gear Cover Gasket	
1-163109 Radiator Outlet Hose (Use 6 3/4" of 96739)	
2-158039 Exhaust Valves	
2-158036 Inlet Valves	
1-121711 Cylinder Water Inlet Flange Gasket	
1-137145 Generator Sprocket (Owen-Dynet)	
1-115274 Generator Gasket	
1-132402 Crankshaft Sprocket	
1-148060 Camshaft Sprocket	
2-147289 Valve Springs	
8-132177 Valve Push Rods	
1-158648 Connecting Rod (On Exchange)	
1-158647 Connecting Rod (On Exchange)	
1- 19796 Contact Arm Assembly (North East)	



1- 19959 Contour Screw Assembly (North East)
2-142711 Spark Plugs
1- 5069 Oil Pump Relief Valve Ball
1-163395 Cam follower to Manifold Gasket
1-132585 Exhaust Pipe Flange Front Gasket
2-152186 Rocker Lever Housing Gaskets
1 Gal. Kerosene
8 Qts. Cylinder Oil
Miscellaneous

M636
Cont.

**Cylinder and Piston Assembly - Supply on Exchange
Basis and Install Includes M641 (Labor Only)**

640

Note: The price of overhauling starter motor and generator is not included in the price of this operation.

See operation M645 for specifications.

Note: \$147.95, \$123.65, \$146.45 are the estimated prices of parts required to recondition the motor. All parts listed should not be required.

Material

1-164806 Cylinder and Piston Assembly .015" oversize Exchangers
1-164807 Cylinder and Piston Assembly .030" oversize Exchangers
1-164808 Cylinder and Piston Assembly .045" oversize Exchangers
2-142474 Exhaust Manifold to Cylinder Gaskets
2-142436 Intakes and Intake Manifold to Cylinder Gasket
1-142437 Intake Manifold to Cylinder Gaskets
1-129043 Water Pump Body Gasket
1-158787 Camshaft Gasket - Right
1-158786 Camshaft Gasket - Left
1-147446 Camshaft Driving Chain
1-215853 Generator Sprocket Support to Frame Gasket
1-162201 Radiator Inlet Flange - 1 cu. ft. of 96.7%
16-142159 Valve Plug Rod Screws
8-158723 Rocker Levers
2-131888 Rocker Lever Pins
8-157417 Valve Push Rod Guides
1-152702 Cylinder to Intake Gasket
1-158668 Cam Cover Gasket
1-163109 Radiator Outer Housing - 1 cu. ft. of 87.5%
2-146988 Exhaust Valves
2-146989 Inlet Valves
1-151711 Cylinder Water Inlet Union Gasket
1-137145 Generator Sprocket - Overhead Timing
1-115271 Generator Gasket
1-1481504 Arms-Jet Sprocket
1-132402 Camshaft Sprocket
2-147200 Valve Springs (North East)
2-147200 Valve Springs (North East)
6-152177 Valve Pull Rods
2-158388 Connecting Rods (In Exchange)
2-19796 Generator Arm Assembly
2-19959 Contour Screw Assembly
2-142711 Spark Plugs
1- 5069 Oil Pump Relief Valve Ball
1-141440 Cam follower to Manifold Gasket
1-141535 Exhaust Pipe Flange Front Gasket
2-152187 Rocker Lever Housing Gaskets
1 Gal. Kerosene
10 Qts. Cylinder Oil
Miscellaneous

M638**Cylinder and Piston Assembly (Standard or Oversize)****Install (Includes M641) and Overhauling Starter Motor, Generator and Removing and Replacing Heater (Labor Only)**

626

Note: \$172.15, \$181.15 and \$198.65 are the estimated zone prices of parts required to recondition the motor. All parts listed should not be required.

1. Specifications are the same as (Operation M635)
2. Overhaul starter and generator and test armature and field for short circuits see (Operation E221 and E331).
3. Remove and replace heater from manifold

Material

1-164801 Cylinder and Piston Assembly (Standard)

1-164802 Cylinder and Piston Assembly (.015")

or

1-164803 Cylinder and Piston Assembly (.030")

or

1-164804 Cylinder and Piston Assembly (.045")

1-158704 Crankcase Gasket Right

1-158705 Crankcase Gasket Left

1-147446 Camshaft Driving Chain

1-115274 Generator Support Gasket

1-163199 Radiator Outlet Hose (Use 6 $\frac{3}{4}$ " of 96739)

8-158723 Camshaft Rocker Levers

2-158050 Rocker Lever Pin

12-132179 Valve Push Rod Set Screw

8-147447 Push Rod Guide

1-158098 Cylinder to Crankcase Gasket

1-158608 Gear Cover Gasket

1-162201 Radiator Julet Hose (Use 37 $\frac{1}{2}$ " of 96739)

1-129047 Water Pump Body Gasket

1-1148083 Generator Support Gasket

8-158222 Piston Pin Bushing

6-132177 Valve Push Rod

1-148050 Camshaft Sprocket

2-147289 Valve Spring

2-158039 Exhaust Valve

2-158035 Inlet Valve

1-158648 Connecting Rod (Exchange)

1-158647 Connecting Rod (Exchange)

2-19796 Contact Arm Assembly (North East)

2-19959 Contact Screw Assembly (North East)

2-142711 Spark Plugs

1-5069 Oil Pump Relief Ball

2-158214 Exhaust Manifold Gasket

2-158034 Exhaust Manifold Gasket

1-132585 Exhaust Pipe Gasket

1-158043 Exhaust Gasket

2-152183 Rocker Lever Housing Gasket

1 Gal. Kerosene

8 Qts. Oil

Miscellaneous

Cylinder and Piston Assembly (Standard or Oversize)**Install (Includes M641) and Overhauling Starter Motor, Generator, Removing and Replacing Heater****(Labor Only)**

640

Specifications same as 626

Note: \$182.15, \$191.15 and \$211.05 are the estimated zone prices of parts required to recondition the motor. All parts listed should not be required.

M638

Cont.

Material

- 1-164805 Cylinder and Piston Assembly
 1-164806 Cylinder and Piston Assembly .015" over
 1-164807 Cylinder and Piston Assembly .020" over
 1-164808 Cylinder and Piston Assembly .015" over
 2-131178 Exhaust Manifold to Cylinder Gasket
 2-141436 Intake Manifold to Cylinder Gasket
 1-141347 Intake Manifold to Cylinder Gasket
 1-745746 Camshaft Driving Chain
 1-163199 Radiator Outlet Hose (Use no. 1 of 96739)
 1-121711 Cylinder Water Inlet Flange Gasket
 2-131888 Rocker Lever Pad
 16-132179 Valve Push Rod Set Screw
 8-117147 Push Rod Guides
 8-158723 Rocker Levers
 1-132702 Cylinder to Crankcase Gasket
 1-158737 Crankcase Gasket
 1-158738 Crankcase Gasket
 1-158739 Case Lower Gasket
 1-163201 Radiator Inlet Hose (Use 37 cu" of 96739)
 2-146988 Exhaust Valve
 2-146989 Inlet Valve
 1-220147 Water Pump Gasket
 8-136618 Piston Pin Bearing
 1-186352 Camshaft Gasket
 2-147280 Valve Spring
 8-132177 Valve Push Rod
 2-1583884 Intake Rod Exchange
 1-18796 Counter Arm Assembly (North East)
 1-196899 Counter Arm Assembly (North East)
 2-142712 Spark Plugs
 1-5069 Oil Pump Ball
 2-131887 Rocker Lever Gasket
 1 Gal. Kerosene
 10 Qua. oil

Miscellaneous**Cylinder Reground with Piston, Install Clean Carbon, Grind Valves and Tune Motor****626 M639**

1. Drain cooling system and remove radiator
 2. Disconnect exhaust pipe, valve cover plate and exhaust manifold
 3. Remove fan belt and water pump
- Note: See operation M1641 for specification
4. Remove cylinder head and clean carbon
 5. Drain oil and remove crankcase lower half
 6. Remove cylinder block and replace with new block and tighter on crankcase
 7. Remove valves from old block, clean carbon and grind valves into new block. See operation M1243
 8. Remove connecting rod and piston. Re-fit pistons and pins and align rods using jib
 9. Replace connecting rod and piston and tighten to crankshaft
 10. Replace cylinder head and new gasket
 11. Replace crankcase and rebuild with new oil
 12. Tune air cleaner and adjust怠速 to standard

Material

- 1-158294 Cylinder Head Gasket
 1-163195 Carburetor Gasket

M639**Cont.**

- 1-158088 Cylinder Base Gasket
 1-158704 Crankcase Gasket - Left
 1-158705 Crankcase Gasket - Right
 1-164802 Cylinder and Piston Assembly (.015" Oversize)
 or
 1-164803 Cylinder and Piston Assembly (.030" Oversize)
 or
 1-164804 Cylinder and Piston Assembly (.045" Oversize)
 8 Qts. Oil

Same as 626

640**Material**

- 1-159721 Cylinder Head Gasket
 1-141440 Carburetor Gasket
 1-132702 Cylinder Base Gasket
 1-158786 Crankcase Gasket
 1-158787 Crankcase Gasket
 1-164816 Cylinder and Piston Assembly (.015" Oversize)
 or
 1-164807 Cylinder and Piston Assembly (.030" Oversize)
 or
 1-164808 Cylinder and Piston Assembly (.045" Oversize)
 10 Qts. Oil

M641**Connecting Rods and Piston Assemblies
Remove for Inspection and Replace
(Includes M510 and M610)****626**

Note: Wash motor using power washer and air dryer before an inspection is made

1. Remove connecting caps screws

Note: There is just one way to remove and replace connecting rods and pistons, which is as follows: Slide connecting rod and piston assembly upward through cylinder bore. Remove wrist pin lock and pin at top of bore. While one mechanic is removing wrist pin the other mechanic is holding the connecting rod under the motor.

2. Make a thorough inspection and align rods using special aligning jig

Note: Number on connecting rods and caps must be on right side of motor

3. To reassemble, place connecting rod into cylinder bore from the bottom. Place piston into cylinder bore. While one mechanic is holding rod, the other mechanic is reassembling and bring up the piston and wrist pin at the top of cylinder bore, using wrist pin aligning tool

Note: The connecting rod wrist pin bushing projects out on one side. Connecting rod number one (1) is called right. Wrist pin bushing should be toward the front of motor. Connecting rod number two (2) is called left. Wrist pin bushing should be toward rear of motor. The other end of connecting rod wrist pin bushing must be flush with rod, etc.

4. Oil piston pin thoroughly and space piston rings gap evenly around piston. Replace and tighten connecting rods, using new lock washers, also using piston ring compressing sleeve**Material**

- 16-5506 Lock Washers

**Connecting Rod and Piston Assemblies - Remove for
Inspection and Replace
(Includes M510 and M610)****640**

Note: Wash motor, using power washer and air dryer before an inspection is made

1. Pull rod bearing bolt cotter pins and remove all connecting rod assemblies.
 2. Remove piston from connecting rod.
- Note: Remove rod and piston assembly from motor by pushing upward through cylinder bore and make a thorough inspection. To replace assembly, use piston ring compressing sleeve S. T. 106. Align rods, using aligning jig S.T. 87 and space ring gaps evenly around piston.
3. Assemble rod to crankshaft and see that cotter pins are in place.
- Note: Numbers on connecting rods and caps must be on right side of motor.

Material**M641**
*Cont.***Piston Pin Bushing - Renew One**
(Includes M510-M610)**626 M642**

1. Remove rod from crankshaft and push piston upward through cylinder bore. Remove wrist pin lock and pin at the top of bore. While one mechanic is removing wrist pin, the other mechanic is holding the connecting rod under the motor.
- Note: The connecting rod wrist pin bushing projects out on one side. Connecting rod number one (1) is called right. Wrist pin bushing should be toward the front of motor. Connecting rod number two (2) is called left. Wrist pin bushing should be toward rear of motor. The other end of connecting rod wrist pin bushing must be flush with rod, etc.
2. Press out old bushings and replace with new bushings, using arbor press.
 3. Ream bushings to size, using a $\frac{7}{8}$ " expansion reamer.
- Note: Piston pin should be fitted so that it can be pressed through bushing by hand without any up or down play. Be careful when reaming bushings so that the reamer does not chatter. The bushings should be perfectly smooth.
4. Replace piston pin and set screw up tight.
 5. Oil piston pin thoroughly and space piston ring gaps evenly around piston. See operation M641 for specification.
 6. Replace rod, using piston ring compressing sleeve.
- Note: Add M642 for each additional piston pin bushing.

Material

1-158222 Piston Pin Bushing

Same as 626

640**Material**

1-156648 Bushing

Piston Pins and Bushings--Renew All
(Includes M641)**626 M643**

1. Press out old bushings and install new bushings, using an arbor press.
- Note: The connecting rod wrist pin bushing projects out on one side. Connecting rod number one (1) is called right. Wrist pin bushing should be toward the front of motor. Connecting rod number two (2) is called left. Wrist pin bushing should be toward rear of motor. The other end of connecting rod wrist pin bushing must be flush with rod, etc.
2. Ream piston and bushings to size, using a $\frac{7}{8}$ " expansion reamer.
- Note: Piston pin should be fitted so that it can just be pressed through bushing by hand without any up or down play. Be careful when reaming piston pin bushings so that the reamer does not chatter. The bushings should be perfectly smooth.
3. Replace pistons and pins.
 4. Oil piston pins and space ring gaps evenly around pistons.
 5. Replace rod, using piston ring compressing sleeve.

Material

8-158222 Bushing

8-163879 Pin

Same as 626

640**Material**

8-156648 Bushing

8-134305 Pin

M644 Piston and Connecting Rod Assembly—Remove One
for Inspection and Replace (Includes M510-M610) 626

See operation M641 for specification.

Material

Same as 626 640

Material

M645 Piston and Connecting Rod Assembly—Remove two for
Inspection and Replace (Includes M510-M610) 626

See operation M641 for specification.

Note: This operation should be used in conjunction with hone and renew piston.

Material

Same as 626 640

Material

M661 Piston Rings—Renew All (Includes M641) 626

1. Remove old rings and clean grooves.

Note: To remove piston rings, place a feeler gauge back of the rings and guiding the feeler around the sides of the piston, force the rings out of the grooves with the other hand. Remove the piston rings over the top of the piston. It will be found easier to remove the top ring first, then the center and lastly the bottom. Be careful when handling a piston—it's walls are light and may be easily sprung, causing the piston to be out of round.

2. Select oversize rings to fit cylinder.

Note: When checking ring gap, place ring in cylinder and push ring down, using the old piston, until it rests snugly against piston at all points. It may be necessary to file ring gaps to .006" clearance when new or oversize. Do not remove more metal than necessary.

3. Fit ring to piston grooves.

Note: Set the ring off squarely around the piston grooves. If the ring is properly fitted a slight drag should be felt. If too loose try thicker ring. If too thick, lay a sheet of very fine emery cloth on a surface plate, slide it back and forth until a groove has been secured. Fit each ring separately.

4. Install rings on pistons.

Note: Ring must not stick in any position and should not have any up or down play.

5. Space ring gaps evenly around piston.

6. Replace connecting rod and piston assembly, using a piston ring compressing sleeve.

Note: Number on rod and cap should be on right side of motor.

Material

8-164809 Rings—Slotted (.001")
24-163881 Rings (.003")
24-163882 Rings (.005") Oversize
24-164630 Rings (.010") Oversize
8-164810 Rings—Slotted (.005") Oversize
8-164811 Rings (.010") Oversize

Same as 626

Material

- 8-166700 Rings - Slotted .003" (1)
 24-166700 Rings .003" Oversize
 24-144415 Rings .005" Oversize
 24-144595 Rings .010" Oversize
 8-136705 Rings - Slotted .005" Oversize
 8-144595 Rings - Slotted .010" Oversize

640 M661*Cont.***Piston Pins - Renew All (Includes M641)****626 M662**

1. Select an U. S. Piston Pin

2. Run a piston pin bushing to size using a $\frac{7}{8}$ " expansion reamer until a complete bearing surface is obtained.

Note: Piston pin should be turned so it can be pressed through bushing with load without any open down play. When running piston pin bushing care should be taken not to allow the reamer to chatter as bushing should be perfectly smooth.

Material

- 8-163879 Pin .003" oversize (.75" Pin)


- 8-163880 Pin .006" oversize (.75" Pin)

Same as 626

640**Material**

- 8-134305 Pin .003" oversize (.75" Pin)

- 8-134306 Pin .006" oversize (.75" Pin)

Piston Reamer**Bushing Reamer**

M663 Piston Assembly—Renew One
(Includes M610-M620)

626

Note: Micrometers should be used to determine the condition of a cylinder bore. If it is necessary to replace pistons on account of piston slaps or oil pumping, due to the excess clearance, it is found that by fitting to a proper clearance, the upper part of the cylinder, where the piston rings bear on the wall, will wear the most. If the piston binds or does not have sufficient clearance at the lower part of the cylinder, the cylinder should be reground. To determine proper fit of piston, place piston in cylinder, placing a .0015" feeler alongside of piston. Under this condition the piston must move its entire travel without sticking and it should be possible to pull out the feeler from between piston and cylinder wall with grip of finger and thumb only. This indicates proper clearance. There should not be less than $\frac{1}{16}$ " clearance between piston pin boss and connecting rod after rod has been replaced to crankshaft.

1. Remove connecting cap screw.

Note: Push rod and piston upward through cylinder bore. Remove pin at top of bore (See M641 for specifications).

2. Ream bushings to size, using a $\frac{3}{16}$ " expansion reamer.

Note: Piston pin should be fitted so that it can just be pressed through bushing by hand without any up or down play. When reaming piston pin bushings care should be taken not to allow the reamer to chatter as the bushings should be perfectly smooth.

3. Reassemble piston in connecting rod, using a new piston pin.

4. Round up piston and align rod, using aligning tool.

Note: Numbers on connecting rod caps to right side of motor.

5. Space ring gap evenly, replace rod, using piston ring compressing sleeve tool No. S. T. 106.

Material

1-163182	Piston Assembly	.0005" Oversize	$\frac{1}{2}$ " Pin
1-163183	Piston Assembly	.0005" Oversize	$\frac{3}{8}$ " Pin
1-163184	Piston Assembly	.0010" Oversize	$\frac{1}{2}$ " Pin
1-163185	Piston Assembly	.0015" Oversize	$\frac{3}{8}$ " Pin
1-163186	Piston Assembly	.0020" Oversize	$\frac{1}{4}$ " Pin
1-163187	Piston Assembly	.0030" Oversize	$\frac{1}{4}$ " Pin
1-163188	Piston Assembly	.0035" Oversize	$\frac{1}{8}$ " Pin

Same as 626

640

Material

1-148786	Piston Assembly	.0005" Oversize	$\frac{1}{2}$ " Pin
1-148785	Piston Assembly	.0005" Oversize	$\frac{3}{8}$ " Pin
1-148784	Piston Assembly	.0010" Oversize	$\frac{1}{2}$ " Pin
1-148783	Piston Assembly	.0015" Oversize	$\frac{3}{8}$ " Pin
1-148782	Piston Assembly	.0020" Oversize	$\frac{1}{4}$ " Pin
1-148781	Piston Assembly	.0030" Oversize	$\frac{1}{4}$ " Pin
1-148780	Piston Assembly	.0045" Oversize	$\frac{1}{8}$ " Pin

M664 Piston Assembly—Renew All
(Includes M641)

626

Note: Micrometers should be used to determine the condition of a cylinder bore. If it is necessary to replace pistons on account of piston slaps or oil pumping, due to the excess clearance, it is found that by fitting to a proper clearance, the upper part of the cylinder, where the piston rings bear on the wall, will show the greatest wear. If the piston binds or does not have sufficient clearance at the lower part of the cylinder, the cylinder should be reground. To determine the proper fit of piston, place piston in cylinder with a .003" feeler between the cylinder wall and piston. Under this condition the piston must move its entire travel without sticking. The feeler must pull out from between piston and cylinder wall by grip of a finger and thumb only. This will indicate proper clearance.

1. Remove pistons from connecting rods.

Note: Ream bushing to size, using a $\frac{1}{8}$ " expansion reamer. Piston pin should be fitted so that it can just be pressed through bushing by hand, without any up or down play. See that reamer does not chatter when reaming bushings and cause oil uneven surface.

2. Reassemble pistons on connecting rods and round up pistons. Align rods, using a special rig.

Note: Space ring gaps evenly around pistons. Rings must not stick in any position.

Material8-164182 Piston Assembly (.003" Oversize) ($\frac{3}{8}$ " Pin)

or

8-163183 Piston Assembly (.005" Oversize) ($\frac{3}{8}$ " Pin)

or

8-163184 Piston Assembly (.010" Oversize) ($\frac{3}{8}$ " Pin)

or

8-163185 Piston Assembly (.015" Oversize) ($\frac{3}{8}$ " Pin)

or

8-163186 Piston Assembly (.020" Oversize) ($\frac{3}{8}$ " Pin)

or

8-163187 Piston Assembly (.030" Oversize) ($\frac{3}{8}$ " Pin)

or

8-163188 Piston Assembly (.045" Oversize) ($\frac{3}{8}$ " Pin)

Same as 626

640**Material**8-148785 Piston Assembly (.005" Oversize) ($\frac{7}{8}$ " Pin)

or

8-148784 Piston Assembly (.010" Oversize) ($\frac{7}{8}$ " Pin)

or

8-148783 Piston Assembly (.015" Oversize) ($\frac{7}{8}$ " Pin)

or

8-148782 Piston Assembly (.020" Oversize) ($\frac{7}{8}$ " Pin)

or

8-148781 Piston Assembly (.030" Oversize) ($\frac{7}{8}$ " Pin)

or

8-148780 Piston Assembly (.045" Oversize) ($\frac{7}{8}$ " Pin)**Piston Pin--Renew One
(Includes M510-M610)****626 M665**

Note: See operation M641 for specification.

1. Remove connecting cap screws.

Note: To allow removal of connecting rod, push piston upward through cylinder bore and remove wrist pin at the top of bore while one mechanic is removing wrist pin the other mechanic is holding the connecting rod under the motor.

2. Select an O. S. piston pin.

3. Ream piston and bushing to size, using a $\frac{1}{8}$ " expansion reamer until a complete bearing surface is obtained.

Note: Piston pin should be fitted so it can be pressed through bushing with hand, without any up or down play. When reaming piston pin bushings, care should be taken not to allow the reamer to chatter, as bushings should be perfectly smooth.

4. Assemble piston, piston pin and connecting rod.

5. Align rod and round up piston.

6. Oil piston jet thoroughly and space ring gaps evenly around piston.

Note: Add M510 for each additional piston pin.

7. Replace rod to crankshaft.

M664*Cont.*

M665 Material*Cont.*

1-163879 Pin (.003" Oversize)

or

1-163880 Pin (.006" Oversize)

Same as 626

640

Material

1-134305 Pin (.003" Oversize)

or

1-134306 Pin (.006" Oversize)

M667 Piston Pin Bushing...Renew All (Includes M641) 626

1. Press out old bushing and install new bushing using arbor press.
2. Ream piston pin bushing to size using a $7\frac{1}{8}$ " expansion reamer until a complete bearing surface is obtained. If the piston pin bushing has become too loose in the upper end of the connecting rod, use an oversize bushing—piece No. 145326.

Piston pin should be fitted so it can be pressed through bushing with hand without any up or down play.

Note: The connecting rod wrist pin bushing projects out on one side. Connecting rod number one (1) is called right. Wrist pin bushing should be toward the front of motor. Connecting rod number two (2) is called left. Wrist pin bushing should be toward rear of motor. The other end of connecting rod wrist pin bushing must be flush with rod, etc.

Material

8-158222 Bushing

Same as 626

640

Material

8-156648 Bushing.

Motor Oil Pressure Gauge—Renew**626 M72**

- Supply and install new oil pressure gauge

Material

1-158213 Oil Gauge

Same as 626

640**Material**

1-158243 Oil Gauge

**Motor Oil Pressure—Adjust
(Supply Fresh Oil)****626 M74**

- Drain crankcase oil
 - Remove oil pump cover and take out screen
 - Remove lock wire and take out adjusting screw
 - See that face of oil check is smooth
 - Adjust oil pressure 20 to 50 pounds by regulating adjusting screw, turning it clockwise to raise pressure and anti-clockwise to lower. One turn produces a difference of from 3 to 5 pounds in pressure
 - Replace bottom of oil pump and fill to level with fresh medium cylinder oil
- Note: Oil pressure reading should be taken with motor at running temperature

Material

8 Qts. Medium Cylinder Oil


1-114886 Oil Strainer Cover Plate Gasket

Same as 626

640**Material**

10 Qts. Medium Cylinder Oil

1-114886 Oil Strainer Cover Plate Gasket

Test Tank for Lubricating System

Tool No. S. T. 104

M76 Make Oil Test on Bearings

(Includes M510)

626

1. Disconnect oil manifold from oil pump.
2. Fill special tank, S. T. 106, two thirds full of oil out of motor, if not too thin for testing purposes.
3. Connect test tank hose to motor oil manifold and pump up and maintain 30 pounds air pressure on tank during test.
4. Gauge on instrument board should check very close to gauge on tank, except when number one and six pistons are on upper dead center. See Technical Letter No. 1746.
5. Crank motor over by hand.
6. Flow of oil from connecting rod and main bearings should be in DROPS before reaching floor. (Equivalent to 20 to 60 drops per minute.)
Note: This test is used in making a motor inspection indicating loose bearings and in re-tightening main and connecting rod bearings. It should also be used for checking bearing work after an overhaul.

Material

2 Qts. Cylinder Oil

(Includes M510)

640

Same as 626

Material

2 Qts. Cylinder Oil

M710**Motor Oil Pump-- Remove, Clean and Replace**

626

1. Start motor and note amount of oil pressure.
2. Drain oil and remove lower half of crankcase and clean oil pump screen.
3. Remove oil pump assembly.
Note: Care must be taken that oil pump driving shaft and gear does not drop down and allow the distributor driving shaft to pull out of head and throw motor ignition out of time.
4. Remove oil pressure adjusting screw, spring valve and shaft collar. Note location of adjusting screw by measuring or counting number of turns.
5. Take off pump cover by removing four screws.
6. Clean housing and gear thoroughly, reassemble and adjust. It may be desirable to adjust oil pressure before replacing bottom half of crankcase. This can be done by attaching one end of a short hose to pump, the other end dipping into fresh oil and running the motor until proper pressure is determined.
Note: The standard oil pressure reading is 20 to 50 pounds. To raise oil pressure, increase the spring tension by turning adjusting screw clockwise with a screwdriver; to lower pressure, the spring tension should be decreased. Be sure the check out is tightened before replacing crankcase lower half.
7. Remove screen in crankcase lower half, clean, reassemble and replace.
8. Fill to level with fresh oil.

Material

8 Qts. Cylinder Oil

1-158704 Gasket—Right

or

1-158705 Gasket—Right

1-114886 Oil Strainer Cover Plate Gasket

Same as 626

640

Material

1-158786 Crankcase Gasket

or

1-158787 Crankcase Gasket

1-114886 Gasket...

10 Qts. Cylinder Oil

Motor Piston Lubricator Control Valve Assembly - Renew

626 M711

1. Disconnect oil tube from lubricator
2. Remove choke rods
3. Remove nuts holding lubricator to crankcase
4. Install new lubricator

Note: Check the choke rod so it will close the lubricator valve when the choke rod is closed, that is, up against the dash. If it does not close properly, remove, loosen nut holding control lever and turn shaft with screw driver until the valve closes. The valve should have $\frac{1}{16}$ " play before the choke rod starts to open the valve. If the lubricator is not fully closed it will pump oil at all times.

Material

1-157452 Valve Assembly

1-157438 Gasket

Same as 626

640

Material

1-157452 Valve Assembly

1-157438 Gasket

Motor Piston Lubricator Valve - Renew

626 M712

1. Disconnect oil tube from lubricator
2. Remove choke rods
3. Remove nuts holding lubricator to crankcase and diaphragm
4. Replace with new valve and reassemble to motor

Note: Be sure to check the choke rod so it will close the lubricator valve when the choke rod is closed that is, up against the dash. If it does not close properly, remove, loosen nut holding control lever and turn shaft with screw driver until the valve closes. The valve should have $\frac{1}{16}$ " play before the choke rod starts to open the valve. If the lubricator is not fully closed it will pump oil at all times.

Material

1-147392 Valve

1-157438 Bracket


Same as 626

640

Material

1-147392 Valve

1-157438 Bracket



**M752 Motor Oil Pump Shaft Bushing—Renew
(Includes M510-M630)**

626

1. Remove drive shaft bushing
Note: Take a piece of cold rolled steel or some other suitable tool and drive out bushing from below.
2. Supply and install one new drive shaft bushing.
3. Reassemble oil pump and replace.
4. Adjust oil pressure (See M730 for method of adjusting).

Material

1-114886 Oil Strainer Cover Plate Gasket
1-132173 Oil Pump Shaft Bushing

Same as 626

640

Material

1-114886 Oil Strainer Cover Plate Gasket
1-132173 Oil Pump Shaft Bushing

...
...**M753 Motor Oil Pump Shaft and Driven Impeller
Assembly—Renew
(Includes M710)**

626

1. Supply and install new pump shaft and driven impeller assembly.
2. Reassemble and replace.
3. Adjust oil pressure (See M730 for method of adjusting).

Material

1-156609 Oil Pump Shaft Assembly

(Includes M710)

640

Same as 626

Material

1-156609 Oil Pump Shaft Assembly

**M754 Motor Oil Pump Assembly—Renew
(Includes M510)**

626

1. Disconnect oil manifold from pump.
2. Remove two nuts holding oil pump and drop pump.
3. Supply and install new oil pump.
4. Replace and tighten oil manifold.
5. Adjust oil pressure.

Note: The standard oil pressure reading is from 20 to 50 pounds. To raise the oil pressure, increase the spring tension by turning adjusting screw clockwise with a screw driver. To lower the pressure, the spring tension should be decreased.

Material

1-157451 Oil Pump Assembly

**Motor Oil Pump Assembly—Renew
(Includes M510)**

640



Same as 626

Material

1-157451 Oil Pump Assembly ..

**Oil Pump Relief Valve
Re-setter**

Tool No. S. 4. 628



Sectional View of Motor Oil Pump

Radiator Core and Shell and Shutter Renew

626 M80

Note: To protect surfaces from oil and scratches, use fender covers S. T. 130 and cowl cover S. T. 148.

1. Drain cooling system, preserve anti-freeze solution and remove bonnet and tie rod.
 2. Remove upper and lower hose.
 3. Remove radiator to frame bolts.
 4. Supply and assemble new core and shell and shutter.
- Note: Be sure to lubricate radiator shutter when reassembling.
5. Replace radiator, being sure that leather pads are in place between radiator and frame.
 6. Replace upper and lower hose.
 7. Replace and adjust tie rod.
 8. Refill cooling system.
 9. Check for leaks.

Material

- 1-158854 Core Assembly
 1-158798 Shell Assembly
 1-159725 Shutter Assembly
 1-21662 Gasket
 1-159710 Felt

Specifications same as 626

640

Material

- 1-159711 Core Assembly
 or
 1-159309 Core Assembly (645)
 1-159726 Shutter Assembly
 1-159290 Shell Assembly (640)
 or
 1-158845 Shell Assembly (645)
 1-21662 Flange Gasket
 1-159709 Felt

Radiator Flush Out

626 M81

Note: This operation should be performed on a wash dock.

1. Drain cooling system.
 2. Remove bottom hose and force water upward through radiator and motor cooling system.
- Note: If engine overheats, possible causes: incorrect ignition timing, defective cooling system, incorrect fan belt adjustment, defective radiator shutter, defective thermostat.
3. Replace hose and refill cooling system.
 4. Test for leaks.

Material

Same as 626

640

Material**Radiator Core Renew**

626 M83

Note: Protect fenders and cowl from oil and scratches by using fender covers S. T. 130 and cowl cover S. T. 148.

1. Drain cooling system, preserve the anti-freeze.
 2. Remove bonnet and tie rod.
 3. Remove radiator and take off shell.
 4. Remove radiator shutter and thermostat.
- Note: Be sure to lubricate radiator shutter when reassembling.
5. Supply and install new radiator core, using original shell and shutter.

M83 6. Replace tie rod and refill cooling system
7. Replace bonnet

Cont. 8. Check for leaks

Material

1-158854 Core Assembly

1-159295 Gasket

Same as 626

640**Material**

1-159711 Core Assembly

or

1-159309 Core assembly (645)

1-159295 Gasket

M85 Radiator Shell - Renew (Chromium Plated).**626**Note: Protect exposed surfaces from oil and scratches by using fender covers
S. T. 130 and cowl cover S. T. 118

1. Remove bonnet and radiator tie rod

2. Remove radiator from frame

3. Remove shell from radiator

4. Disconnect radiator shutter

5. Remove thimble cover with thimble cover lock from old shell

6. Supply and install new nickel radiator shell

7. Reassemble radiator shutter

8. Attach thimble cover lock to new shell

9. Replace tie rod and bonnet and adjust for proper bonnet fit

1-158798 Shell

Same as 626

640**Material**

1-159296 Radiator Shell (646)

or

1-158845 Radiator Shell (645).

M86 Radiator Thimble Cover Gasket —**626**

1. Remove old thimble cover gasket

2. Supply and install new thimble cover gasket

Material

1-158831 Gasket

1-158843 Retainer

Same as 626

640**Material**

1-158837 Gasket

1-158850 Retainer

M88 Radiator Shell Replate (Chromium)
(Labor Only.)**626**Note: Protect exposed surfaces from oil and scratches by using fender covers
S. T. 130 and cowl cover S. T. 118

1. Remove hood, remove thimble cover and tie rod

2. Remove radiator from frame

3. Remove shell from radiator, disconnect shutter

4. Renickel shell


5. Replace shell, shutter, radiator and tie rod

6. Replace hood and cap

Material

Same as 626

640**Material**

**Radiator Drain Cock Renew**

1. Drain radiator and preserve anti-freeze solution if used
2. Remove old drain cock and clean threads with $\frac{1}{4}$ " standard pipe tap
3. Supply and install new drain cock, using white lead to prevent rust and to secure tight joint
4. Refill cooling system with water or anti-freeze solution

626 M89

M89 Material

1-111752 Drain Cock

Cont. Same as 626

640

Material

1-111752 Drain Cock

M810 Radiator—Remove and Replace

626

Note: Protect exposed surfaces with fender covers S. T. 130 and cowl cover S. T. 148

1. Drain cooling system and remove hood (Preserve anti-freeze solution)
 2. Disconnect radiator to dash tie rod
 3. Loosen clamps on upper and lower hose connections
 4. Remove radiator stud nuts
 5. Lift off radiator assembly
 6. Replace radiator
- Note: See that leather washers are between radiator and frame
7. Replace upper and lower hose
 8. Replace and adjust tie rod
 9. Refill cooling system and replace hood
 10. Check for water leaks

Material

Same as 626

640

Material

M811 Fan—Renew

626

Note: Use fender covers S. T. 130 to protect enameled surfaces from oil and scratches

1. Remove hood
 2. Drain cooling system (Preserve anti-freeze solution)
 3. Disconnect radiator to dash tie rod
 4. Loosen radiator stud nuts; tilt radiator forward
 5. Remove old fan, install new, and adjust fan belt
 6. Tighten radiator and refill cooling system
- Note: A fan belt will give maximum service if it is kept pliable—dressing once a month with oil. This application will allow the belt to drive the fan without slipping
7. Adjust tie rod and replace hood

Material

1-158180 Motor Fan

640

Material

1-125521 Motor Fan

M812 Fan Belt - Renew (Rubber Belt Only)

626

1. Remove bonnet and tie rod
 2. Release water pump clamp plate nuts and rotate water pump shaft and cover to lowest position
 3. Remove radiator and vibration damper
 4. Remove fan belt
 5. Replace radiator and vibration damper
 6. Rotate pump cover to secure proper belt tension (See note)
 7. Tighten clamp plate nuts
- Note: Standard fan belt adjustment should be so that by grasping the rim of the fan it will be just possible to slide belt on pulley
8. Replace tie rod and hood

Material

1-163405 Fan Belt

640

Material

1-163405 Fan Belt

**Fan Belt-- Adjust by Removing Link
(Leather Link Belt Only)**626 **M813**

1. Drain three gallons from cooling system
 2. Release water pump clamp plate nuts
 3. Rotate water pump shaft and cover to lowest position
 4. Remove fan belt and take out link
 5. Replace rotating pump cover to secure proper belt tension (See note)
 6. Tighten clamp plate nuts
 7. Refill cooling system and test for leaks
- Note: Standard fan belt adjustment should be so that by grasping the rim of the fan it will be just possible to slide belt on pulley

Material

Same as 626

640

Material**Thermostat Sylphon- Renew (Cylinder Head)**626 **M814**

1. Drain three gallons of water from cooling system
 2. Remove thermostat outlet flange
 3. Remove thermostat sylphon
- Note: To test old sylphon—submerge in hot water about 160° temperature
4. Reassemble, using new sylphon
 5. Replace outlet flange
- Note: Be sure that intake port side of flange is toward cylinder head. Thermostat valve should open between 125°-150° Fahrenheit

Material

1-117776 Sylphon

1- 78945 Thermostat Sylphon Gasket

2-117855 Thermostat Valve Seat Gaskets

Same as 626

640

Material

1-117776 Sylphon

1- 78945 Thermostat Sylphon Gasket

2-117855 Thermostat Valve Seat Gaskets

Radiator Splasher-- Renew Right or Left626 **M815**

1. Remove bolts and nuts from bonnet frame ledge
 2. Remove nuts from spring bolts
 3. Remove cable from headlight and pull through bonnet frame ledge
 4. Remove splasher
 5. Reassemble new splasher in place
- Note: Be sure cable conduit bushing is in place in bonnet frame ledge

Material

1-159304 Splasher (left)

1-162064 Splasher (right)

Same as 626

640

Material

1-159304 Splasher (left)

1-162064 Splasher (right)

M817 Fan Belt--Tighten 626

- This operation does not include removing link.
1. Drain cooling system to a level below water pump.
 2. Loosen clamp plate and rotate water pump to increase belt tension.
Note: Fan belt will render service if kept pliable with Neats Foot Oil once a month. "Leather Belt Oily".
 3. Tighten clamp plate nuts and refill cooling system.
Note: Standard fan belt adjustment should be determined by grasping rim of fan; it will be just possible to slide belt on pulley.

Material

Same as 626 640

Material**M820 Water Pump Assembly Renew** 626
Radiator Off

- Note: Use fender covers.
1. Remove old water pump and install new pump.
 2. Rebuild water pump and adjust fan belt.
Note: Tighten water pump gland nut.

Material

1-129047 Gasket
1-158310 Water Pump Assembly 640

Same as 626

Material

1-129047 Gasket
1-158311 Water Pump Assembly

M823 Water Pump Body Gasket Renew 626
Radiator Off

- Note: Use fender covers.
1. Remove water pump and install new gasket.
 2. Rebuild the entire job and adjust fan belt.
Note: Tighten water pump gland nut.

Material

1-129047 Gasket 640

Same as 626

Material

1-129047 Gasket

M824 Water Pump Body Clamp Plate Renew 626
Radiator Off

- Note: Use fender covers.
1. Remove worn pump clamp plate and install new clamp plate.
 2. Rebuild the entire job and adjust fan belt.

Material

1-156982 Plate
1-129047 Gasket 640

Same as 626

Material

1-156983 Clamp Plate
1-129047 Gasket

Water Pump—Remove, Dismantle for Inspection and Replace626 **M830**

Note: To protect exposed surfaces from oil and scratches, use fender covers S. T. 130 and cowl cover S. T. 148.

1. Remove hood.
2. Drain cooling system, preserve anti-freeze and remove radiator.
3. Remove four (4) water pump clamp plate nuts, loosen fan belt and remove pump.
4. Dismantle pump, inspect and repair.
5. Reassemble and tighten water pump, adjust fan belt.
Note: Standard fan belt adjustment should be so that grasping rim of fan it is just possible to slide belt on pulley.
6. Replace radiator.
Note: Be sure that radiator pads are in place.
7. Refill cooling system and check for leaks.
8. Replace hood.

Material

1-129047 Water Pump Body Gasket ...

Same as 626

640

Material

1-129047 Water Pump Body Gasket

Water Pump—Recondition (Includes M810)

626

M831

Note: Use fender covers S. T. 130 and cowl cover S. T. 148 to protect exposed surfaces from oil and scratches.

1. Remove four (4) water pump clamp plate nuts, loosen fan belt and remove pump.
2. Disassemble pump and reassemble, using new parts to put in first class condition.
3. Replace water pump, adjust fan belt.

Note: Standard fan belt adjustment should be so that grasping rim of fan it is just possible to slide belt on pulley.

Material

1-117960 Pump Impeller

1-158262 Pump Shaft Bushing

1-129047 Pump Body Gasket

1-114822 Pump Shaft Thrust Button

147-96840 Pump Shaft Packing

1-158074 Pump Shaft Bearing

Same as 626

640

Material

1-117960 Pump Impeller

1-117968 Pump Shaft Bushing

1-129047 Pump Body Gasket

1-114822 Pump Shaft Thrust Button

147-96840 Pump Shaft Packing

1-117963 Pump Shaft Bearing

M832 Water Pump—Reark / Includes M830: \$26

- Supply and install new packing and tighten nut.
Note: Tighten nut solid to seat packing. Use Alemite gun and grease water pump shaft.

Material

16-96840 Packing
1-129047 Gasket

Water Pump--Reark \$40

- Drain three gallons of water or anti-freeze and preserve the solution.
- Back off packing nut and remove old packing with the use of pointed tool bent "L" shaped.
- Supply and install new packing and tighten nut.
Note: Tighten nut solid to seat packing, then back off 1 to 2 turns. Use Alemite gun and grease water pump shaft.
- Refill cooling system.

Material

16-67618 Packing

M833 Hose, Thermostat to Radiator—Renew \$26

- Drain three gallons from cooling system and preserve anti-freeze solution.
- Remove old radiator hose.
- Clean surface and install new hose.
- Refill cooling system and test for leaks.
Note: New hose clamps not included.

Material

1-162201 Hose

Same as 626 \$40

Material

1-162201 Hose

M835 Hose, Radiator Lower—Renew \$26

- Completely drain cooling system and preserve anti-freeze.
- Remove old hose and clean surfaces.
- Install new hose, refill and check for leaks.
Note: New hose clamps not included.

Material

1-163199 Hose

Same as 626 \$40

Material

1-163199 Hose

M836 Hose and Clamps, Radiator Lower—Renew \$26

- Drain cooling system.
Note: Preserve the anti-freeze solution.
- Remove old clamps and hose.
- Clean surfaces and install new hose and clamps.
- Refill cooling system and test for leaks.

Material

1-163199 Hose

2-163196 Clamps

Same as 626 \$40

Material

1-163199 Hose

2-163196 Clamps

Hose and Clamps, Thermostat to Radiator—Renew

626 M838

1. Drain cooling system, preserve anti-freeze solution
2. Remove old hose, clean surfaces and install new hose and clamps
3. Refill cooling system and check for leaks

Material

1-162201 Hose
2-163196 Clamps

Same as 626

640

Material

1-162201 Hose
2-163196 Clamps...

**Water Pump Shaft Impeller and Bearing—Renew
Radiator Off**

626 M839

1. Remove water pump and dismantle. Install new impeller and bearing
2. Clean water pump thrust button if necessary
3. Rebuild the entire job and adjust fan belt
Note: Tighten water pump gland nut

Material

1-158074 Bearing
1-117960 Impeller

Same as 626

640

Material

1-117963 Bearing
1-117960 Impeller

Hose -Renew All

626 M841

1. Drain cooling system, preserve anti-freeze
2. Remove old hose, clean surfaces and install new hose
3. Refill cooling system and check for leaks

Material

1-162201 Hose
1-163199 Hose

Same as 626

640

Material

1-162201 Hose
1-163199 Hose

M842	Hose and Clamps-- Renew All	626
	1. Drain cooling system; preserve anti-freeze 2. Remove old hose; clean hose surfaces and install new hose and clamps 3. Refill cooling system and check for leaks	
	Material 1-162201 Hose 1-163199 Hose 4-163196 Clamps	
	Same as 626	640
	Material 1-162201 Hose 1-163199 Hose 4-163196 Clamps ...	
M843	Hose Clamp (Large) - Renew One	626
	1. Drain the cooling system Note: Preserve the anti-freeze solution if used 2. Remove old hose clamp and install new 3. Refill cooling system and check for leaks	
	Material 1-163196 Clamp Assembly	
	Same as 626	640
	Material 1-163196 Clamp Assembly	
M850	Water Pump Eliminate End Play (Radiator Off)	626
	1. Remove water pump and water pump cover 2. Shim water pump thrust button to eliminate end play using flat washer 3. Rebuild the entire job and adjust fan belt Note: Tighten water pump gland nut	
	Material	
	Same as 626	649
	Material	

Radiator Shutter Renew**626 M865**

Note: To protect surfaces from oil and scratches, use fender covers, S. T. 130 and cowl covers S. T. 148.

1. Drain cooling system, preserve anti-freeze solution, remove bonnet and tie rod
2. Remove upper and lower hose
3. Remove radiator from frame
4. Remove radiator shell
5. Remove radiator shutter and disconneer thermostat using new shutter
6. Rebuild radiator and replace, being sure that leather pads are in place
7. Remove upper and lower hose and refill cooling system

Material

- 1-159725 Radiator Shutter
1-159740 Felt
1-21662 Gasket

Same as 626

640

Material

- 1-159725 Radiator Shutter
1-159741 Felt
1-21662 Gasket

Radiator Shutter Thermostat Renew

626

M866

Note: To protect surfaces from oil and scratches, use fender covers S. T. 130 and cowl covers S. T. 148.

1. Drain cooling system, preserve anti-freeze solution, remove bonnet and tie rod
2. Remove upper and lower hose
3. Remove radiator from frame
4. Remove radiator shell
5. Remove thermostat from core and install new thermostat
6. Rebuild radiator, being sure that leather pads are in place
7. Replace upper and lower hose and refill cooling system

Material

- 1-158855 Radiator Shutter Thermostat
1-21662 Gasket

Same as 626

640

Material

- 1-158855 Radiator Shutter Thermostat
1-21662 Gasket

Exhaust Manifold Gasket - Renew All

626

M91

- Note: To protect exposed surfaces from oil and scratches, use fender covers S. T. 130 and cowl covers S. T. 148
1. Shut off gasoline at vacuum tank and remove carburetor
 2. Remove exhaust manifold, using a special wrench to fit exhaust manifold nuts S. T. 101
 3. Supply and install new exhaust manifold gaskets
 4. Replace carburetor, using new gaskets

Material

- 1-158033 Manifold Gasket
2-158034 Manifold Gaskets
2-158214 Manifold Gaskets
1-163395 Carburetor Gasket
1-132585 Pipe Gasket

Same as 626

640

Material

- 1-141437 Exhaust Manifold to Cylinder Gasket - Large
2-141436 Exhaust Manifold to Cylinder Gaskets - Intermediate
2-141478 Exhaust Manifold to Cylinder Gaskets - Small
1-141535 Exhaust Pipe Flange Front Gasket
1-141540 Carburetor Gasket

Exhaust Manifold - Weld Broken Boss

626

M93

- Note: Use fender covers S. T. 130 and cowl covers S. T. 148 to protect exposed surfaces
1. Shut off gasoline at vacuum tank and remove carburetor
 2. Disconnect exhaust pipe and remove manifold, using a special wrench to fit exhaust manifold nuts S. T. 101
 3. Weld bridge part and dress down
 4. Replace manifold and assemble carburetor in place

Material

- 2-158034 Exhaust Manifold to Cylinder Gaskets - Large
1-158033 Exhaust Manifold to Cylinder Gasket - Large
1-132585 Exhaust Pipe to Manifold Gasket
2-158214 Exhaust Manifold Gaskets
1-163395 Carburetor Gasket

Same as 626

640

Material

- 2-141436 Manifold Gaskets
2-141478 Manifold Gaskets
1-141430 Carburetor Gasket
1-141535 Pipe Gasket
1-141437 Gasket

Exhaust Pipe to Manifold Gasket - Renew

626

M94

- Note: Protect fenders from oil and scratches by using fender covers S. T. 130
1. Remove exhaust pipe flange bolts and nuts
 2. Push exhaust pipe to muffler to allow removal of old gasket
 3. Install new gasket
 4. Replace and tighten exhaust pipe

Material

- 1-132585 Gasket

Same as 626

640

Material

- 1-141535 Gasket 13460

M98 Exhaust Manifold--Renew 626

Note: Use fender covers S. T. 130 and cowls cover S. T. 148 to protect surfaces from oil and scratches.

1. Remove hood and carburetor assembly.
2. Disconnect exhaust to muffler pipe and remove exhaust manifold, using S. T. 101 to remove stud nuts.
3. Strip and assemble studs in new manifold.
4. Reassemble, using all new gaskets.

Note: Be sure all exhaust nuts are pulled up tight to prevent air leaks.

Material

- 1-132585 Pipe Gasket
 1-158033 Exhaust Gasket
 1-164395 Carburetor Gasket
 2-158034 Exhaust Manifold to Cylinder Gaskets
 2-158214 Exhaust Manifold to Cylinder Gaskets
 1-158330 Manifold

Same as 626 640

Material

- 1-141437 Manifold Gasket
 2-141426 Manifold Gaskets
 2-141478 Manifold Gaskets
 1-141440 Carburetor Gasket
 1-141535 Pipe Gasket
 1-158361 Manifold

M951 Exhaust Manifold--Remove and Replace 626

Note: Use fender covers S. T. 130 to protect channeled surfaces from oil and scratches.

1. Shut off gasoline at vacuum tank and remove carburetor.
2. Disconnect exhaust pipe and remove manifold, using S. T. for manifold nuts.
3. Replace manifold and tighten.
4. Replace carburetor.

Note: Be sure all exhaust nuts are pulled up tight to prevent air leaks.

4. Replace carburetor.

Material

- 2-158214 Exhaust Manifold Gaskets
 2-158034 Exhaust Manifold to Cylinder Gaskets
 1-158033 Exhaust Manifold to Cylinder Gasket
 1-132585 Exhaust Pipe to Manifold Gasket
 1-164395 Carburetor Gasket

Same as 626 640

Material

- 2-141436 Manifold Gaskets
 2-141476 Manifold Gaskets
 1-141437 Manifold Gasket
 1-141440 Carburetor Gasket
 1-141535 Pipe Gasket

M955 Francisco Heater--Remove and Replace 626

1. Remove carburetor from manifold.
2. Remove carburetor control.
3. Remove Francisco heater.
4. Reverse order for reassembling.

Material

Same as 626 640

Material

Steering Connections - Tighten All626 **S11**

1. Remove boots and tighten steering connections at:

- (a) Steering lever on yoke shaft
- (b) Both ends of connecting rod
- (c) Both ends of steering cross rod
- (d) Steering knuckle levers in knuckles

Note: Use new cutter keys and see that steering is free after all adjustments are made.

Material

Same as 626

640

Material**Steering Connections - Free Up
and Grease**626 **S12**

1. Remove boot and disconnect front end of steering connecting rod to determine location of tight joints
 2. Disconnect one end of steering cross tube to find out which steering knuckle, if either, is tight
 3. Disconnect remaining joints, clean oil passages, grease thoroughly and reassemble
- Note: Do not dislodge steering knuckles if found by the foregoing inspection to be perfectly free.

Material

1 lb. Grease

Same as 626

640

Material

1 lb. Grease

Steering Connecting Rod - Renew626 **S13**

1. Remove old steering connecting rod
2. Supply and install new steering connecting rod
3. Tighten connections and trim front wheels
See Operation S222

Material

1-163475 Connecting Rod

Same as 626

640

Material

1-138427 Connecting Rod

**Steering Cross Tube Ball Socket Spring—
Renew One**626 **S16**

1. Disconnect one end of cross tube and remove old spring
2. Supply and install one new ball socket spring
3. Trim front wheels (See operation S222) and tighten lock nuts

Material

1-116313 Spring

Same as 626

640

Material

1-116313 Spring

Steering Cross Tube Ball Joint Puller



Tool No. S. T. 653

**S17 Steering Cross Tube Ball Joints—
Renew Both**

626

1. Disconnect both ends of cross tube.
2. Remove old ball joints.
3. Supply and install two ball joints.
4. Turn front wheels, using tool S. T. 128 (see operation S222).

Material

2-126145 Ball Joints

640

Material

2-126145 Ball Joints

**S112 Steering Knuckle Pin Bearing—Upper—
Renew One**

626

1. Remove hub cap, wheel and brake drum.
2. Remove brake shoe.
3. Remove brake support plate.
4. Remove steering knuckle plunger.
5. Remove bearing.
6. Install new bearing and reassemble.

Note: Use proper shims for adjustment of steering knuckle, so as to be free without any play and yet not too tight. For removing and replacing hub cap, use wrench S. T. 129.

Material
 1-126399 Bearing
 2-126433 Shims (.025")
 2-126255 Shims (.016")

640

Material
 1-126399 Bearing
 2-126433 Shims (.025")
 2-126455 Shims (.010")

Steering Knuckle Lever - Left - Renew**626 S113**

1. Disconnect left end of steering cross tube and connecting rod
2. Remove old steering lever
3. Supply and install new steering lever - left
4. Reassemble cross tube and connecting rod and trim front wheels. See Operation S222

Material

- 1-164480 Lever - Left
1-132142 Ball Joint.....

Same as 626

640**Material**

- 1-164480 Lever - Left
1-132142 Ball Joint

Steering Knuckle Lever--Right - Renew**626 S114**

1. Disconnect right end of cross tube
2. Remove old steering lever
3. Supply and install new steering lever - right
4. Reassemble cross tube and trim front wheels. See Operation S222

Material

- 1-146088 Lever--Right
1-132142 Ball Joint

Same as 626

640**Material**

- 1-146088 Lever - Right
1-132142 Ball Joint

**Steering Knuckle Pin Bearing
Lower - Renew****626 S115**

1. Remove hub cap using S. T. 129
 2. Remove wheel and brake drum
 3. Remove Brake shoes
 4. Remove Brake support plate
 5. Remove steering knuckle plug
 6. Remove bearing
 7. Install new bearing and reassemble
- Note: Use proper shims for adjustment of steering. Knuckle should be free without any play. Grease thoroughly.


Material

- 9- 47035 Bearing Ball
2-120133 Shims .005"
2-120255 Shims .010"

Same as 626


640**Material**

- 9- 47035 Bearing Ball
2-120133 Shims .005"
2-120255 Shims .010"

Steering Lever Puller

Tool No. S. T. 135

Will pull any steering lever quickly and without damage to parts in steering gear. See Technical Letter No. 1774 for complete instructions.

Ideal Wheel Gauge

Tool No. S. T. 128

The best measuring device we have discovered. It positively eliminates guesswork in taking up front wheels, irrespective of condition of wheel or tire.

S116 Steering Knuckle - Renew One

1. Remove hub cap, using S. T. 129
 2. Remove front wheel
 3. Remove brake shoes
 4. Remove front axle brake support plate
 5. Remove steering knuckle
 6. Install new knuckle and reassemble.
- Note: Use proper shims for adjustment of steering knuckle and grease thoroughly.

1-138893 Steering Knuckle

1-125433 Knuckle Bearing Dust Washer

1-137158 Retainer

2-126433 Shims (.025")

or

2-126255 Shims (.010")

Same as 626

Material

1-138893 Steering Knuckle

1-125433 Washer

1-137158 Retainer


2-126432 Shims (.020")

or

2-126255 Shims (.015")

626

649



S118 Steering Adjustment - Worm and Sector Type

626

1. Jack up front of chassis.
2. Disconnect steering drag link.
3. Loosen steering pillar tube lock bolt and nut.
4. Adjust pillar tube for proper end play.
Note: Pillar tube should be adjusted so that worm is just free.
5. Adjust sector shaft for end play.
Note: To take up end play remove lock and turn sector plug clockwise. Tighten sector adjusting plug until steering is rough and stiff, then turn plug anti-clockwise until sector is free and replace lock.
6. Remove lock holding eccentric bushing at spline end of steering sector shaft and adjust bushing.
Note: Adjust eccentric bushing by turning clockwise until all play is eliminated and steering is free, then lock adjustment.

Material

Same as 626

640

Material**S119 Steering Knuckle Bearings - Adjust**



626

1. Remove front wheels and hub caps, using wrench S. T. 129.
2. Remove brake shoes.
3. Remove front axle brake support plates.
4. Remove steering knuckle thrust plugs and adjust bearings with necessary shims.
5. Reassemble.
Note: Be sure bearings are not too tight and hub caps are packed with grease. Wheels should turn freely under pressure of one finger.
See Technical Letter 18-III.

Material2-120255 Shims (.005")
2-126433 Shims (.025")

Same as 626

640

Material2-120255 Shims (.005")
2-126433 Shims (.025")**Steering Knuckle Plug Wrench**

Tool No. S. T. 195

Wheel—Front—Remove One for Inspection and Replace**626 S220**

1. Raise one front wheel clear of floor.
2. Remove front wheel and repeat.
3. Repack bearings, replace and adjust. See operation S221 for wheel adjustment.
Note: Be sure bearings are not too tight. Wheel should turn freely under the pressure of one finger.

Material

1 lb. Grease

Same as 626

640**Material**

1 lb. Grease

Wheel—Front—Adjust Bearings**S221**

Note: Wheels should be tested regularly against wear of the bearings. The axle should be jacked up and the wheels shaken back and forth in an effort to see whether they are loose or worn.

1. Remove hub cap, using hub cap wrench S. T. 120, and roller pin.
2. Tighten adjusting nut (nearest bearing) as tight as possible with one hand, using a 12" monkey wrench.
3. Back off one-half turn, locking in position with the pin that goes through the locking washer and adjusting nut.
4. Tighten outside nut and insert roller pin.
5. Pack hub cap with grease and replace.

Note: Be sure bearings are not too tight. Wheels should turn freely under pressure of one finger.

Material

Same as 626

640**Material****Wheels—Front—Tire****626 S222**

1. Check toe-in.
2. Place the wheel gauge between the wheels at the front, with the end of the gauge bearing against tire, both tires barely touching the floor. Set the scale so the pointer registers at zero. Then move the car forward; this will allow the gauge to go to the rear, until no gauge is brought to a position back of the axle, with the chain barely touching the floor. Adjust tie rod if necessary.
3. Adjust steering cross rod so that the front wheel toe-in is $\frac{1}{4}$ ".

Material

Same as 626

640**Material****Wheel—Front or Rear—Dismantle****Renew One****626 S223**

1. Jack up wheel and remove tire and wheel.
2. Install new wheel and apply tire.
3. Inflate tire with air.
4. Adjust wheel bearings.

Note: Wheel must balance when stopping.

5. Pack hub cap with grease and replace.

Note: Proper front wheel bearing adjustment is secured by drawing up adjusting nut tight with 12" wrench, then backing off one-half turn. Fit lock in place and lock with lock nut. Be sure center pin is in place. On rear wheel brake band must not drag and the wheel tire must run true when the operation is completed. If wheel change is due to damaged wheel, check toe-in. See Operation S222.

S223 Material
1-157504 Wheel

Cont. Same as 626 640

Material
1-157504 Wheel

S225 Wheel Hub Cap Renew One 626

1. Remove the old or damaged hub cap.
 2. Supply and install front or rear hub cap, using S. T. 129. Be sure and pack new hub cap with grease.
- Note: This specification limits repairs on wheel hub to "chasing" damaged threads

Material

1-114388 Hub Cap

Grease

Same as 626

640

Material

1-114388 Hub Cap

Grease

S226 Wheel Front—Hub Assembly—Renew One (Disteele Wheel) 626

1. Jack front wheel clear of floor.
 2. Remove hub cap, using wrench S. T. 129.
 3. Remove cotter key and bearing adjusting nuts.
 4. Remove front wheel and bearings.
 5. Remove hub assembly and replace with new assembly.
 6. Replace wheel and bearings.
 7. Tighten adjusting nut (nearest to bearing), with one hand, using a 12-inch monkey wrench. Back off one-half turn, locking in position with a pin that goes through the locking washer and adjusting nut. Tighten outside nut and insert cotter pin.
- Note: Be sure that bearing is not too tight. Wheel should turn freely under pressure of one finger.
8. Replace hub cap and pack with grease.
 9. Remove jack.
- Note: Use hub cap wrench S. T. 129 to prevent marring of hub cap.

Material

1-163029 Hub Assembly

1 lb. Grease

Same as 626

640

Material

1-163029 Hub Assembly

1 lb. Grease

**Wheel—Front—Dust Washer and
Retainer Renew
(Includes S226)**

626 S227

1. Remove retainer and dust washer.
- Note: Use a screw driver or a cold rolled bar to drive out retainer.
2. Supply and install new retainer and dust washer.

Material

1-125144 Washer

1-137153 Retainer

Same as 626

640

Material

1-125129 Washer

1-137153 Retainer

Front or Rear Wheels—Balance Two

626 S232

1. Remove front or rear wheels or balance them on front wheels.
2. Use an old steering knuckle with brake drum assembly.
- Note: Be sure bearings are not too tight. Wheels should turn freely under pressure of one finger.
3. Balance wheels.
4. Remove lug nut and remove washers whenever the wheel is heavy and place it where the wheel is light. Then check for proper balance of wheels.
5. Replace wheel and tighten.

Material

1/2 lb. Grease

Same as 626

640

Material

1/2 lb. Grease

Front and Rear Wheels—Balance All

626 S233

1. Remove front and rear wheels or balance them on front wheels.
2. Use an old steering knuckle with brake drum assembly.
- Note: Be sure bearings are not too tight. Wheels should turn freely under pressure of one finger.
3. Balance wheels.
4. Remove lug nut and remove washers whenever the wheel is heavy and place it where the wheel is light. Then check for proper balance of wheels.
5. Replace wheel and tighten.

Material

1/2 lb. Grease

Same as 626

640

Material

1/2 lb. Grease

S245 Steering Knuckle Inboard Bearing Cone, Rollers and Cup- Renew

626

Note: Wheels should be tested regularly against wear of the bearings. The axle should be jacked up and the wheel shaken back and forth in an effort to see whether they are loose or worn.

1. Jack up car and remove front wheel and hub cap, using tool S. T. 129.
2. Drive out old inboard bearing cup and replace with new.
3. Reassemble, using new inboard cone and rollers and pack bearing with grease.
4. Adjust wheel bearing. See Operation S221.

Material

- 1-139769 Bearing Assembly
- 1-125433 Dust Washer
- 1-137153 Dust Washer Retainer
- 1 lb. Grease

Same as 646

640

Material

- 1-137153 Dust Washer Retainer
- 1-125433 Dust Washer
- 1-139769 Bearing Assembly
- 1 lb. Grease

S246 Steering Knuckle Outboard Bearing Cone, Rollers and Cup- Renew

626

Note: Wheels should be tested regularly against wear of the bearings. The axle should be jacked up and the wheel shaken back and forth in an effort to see whether they are loose or worn.

1. Jack up car and remove front hub cap and wheel, using S. T. 129.
2. Drive out old outboard bearing cup and replace with new.
3. Reassemble, using new outboard cone and rollers, packing with grease.
4. Adjust wheel bearing. See Operation S221.

Material

- 1-97056 Bearing Assembly
- 1-125433 Dust Washer
- 1-137153 Dust Washer Retainer
- 1 lb. Grease

Same as 646

640

Material

- 1-137153 Dust Washer Retainer
- 1-125433 Dust Washer
- 1-97056 Bearing Assembly
- 1 lb. Grease

S251 Wheels- Front- Remove Both and Replace

626

Note: Wheels should be tested regularly against wear of the bearings. The axle should be jacked up and the wheel shaken back and forth in an effort to see whether they are loose or worn.

1. Raise front wheel clear of floor.
2. Remove hub cap, using tool S. T. 129 and take off both front wheels.
3. Inspect bearings and cones and report condition to foreman.

4. Replace and adjust wheel bearings
5. Tighten adjusting nut (nearest bearing) with one hand using a 12" monkey wrench
6. Back off one-half a turn, locking in position with a pin that goes through locking washer and adjusting nut
7. Tighten outside nut and insert cotter pin
8. Replace hub caps and pack with grease
Note: Be sure that bearings are not too tight. Wheels should turn freely under the pressure of one finger
9. Remove jack from under car

S251
Cont.

Material**Grease**

Same as 626

640**Material****Grease**

packardinfo.com

Steering Gear--Tighten to Frame

1. Tighten all steering gear case to frame bolts

626 S31**Material**

Same as 626

640**Material****Steering Lever--Tighten on
Yoke Shaft**

1. Tighten lever on yoke shaft using good size wrench

626 S32**Material**

Same as 626

640**Material****Steering Wheel--Renew**

1. Remove eight screws from hub flange

626 S33

2. Remove upper hub

3. Remove old steering wheel

4. Supply and install new steering wheel

Note: Be sure that spark and throttle levers work freely and steering wheel is perfectly tight

Material

1-176171 Steering Wheel

Same as 626

640**Material**

1-176171 Steering Wheel

**Steering Worm and Sector--Renew
(Includes S310)**

1. Extract sector and worm

626 S35

Note: Steering should be free after all adjustments are made

Material

1-139492 Worm

1-139865 Sector

Same as 626

640**Material**

1-139492 Worm

1-139865 Sector

**Steering Gear Case--Renew
(Includes S310)**

1. Supply and install new steering gear housing

626 S36

Note: Be sure and check spark and throttle adjustments before car leaves service station

S36 Material

Cont. 1-128541 Packing
 1-159862 Case
 1-132143 Gasket

Same as 626

640**Material**

1-159863 Case
 1-128541 Packing
 1-132143 Gasket
 1-132048 Gasket

S310 Steering Remove for Inspection, Disassemble and Report, Reassemble and Replace**626**

Note: Protect trimmings from paint, oil and scratches by using fender covers S. T. 127, front seat covers S. T. 111, and double door covers S. T. 146.

1. Remove floor board, pedal rods and toe board
2. Remove steering wheel
3. Remove starter motor
4. Remove spark and throttle control rods and horn wire
5. Remove nut on steering spine and remove steering arm
6. Loosen steering from frame and remove from chassis
7. Remove headlight switch from steering gear case
8. Dismantle and report
9. Reassemble steering
10. Replace worm and tighten set screw holding bearing retainer from turning
11. Replace pillar tube and adjust tube for end play
 Note: Pillar tube should be adjusted so that worm is just free
12. Report sector
 Note: When assembling sector and worm, be sure that the key way in worm shaft is at top center and the sector is as far to the right as it will go or up against the stop in case
13. Replace steering case cover and tighten
 Note: Be sure case is filled with heavy oil
14. Replace sector adjusting plug and adjust for proper end play
15. Replace adjusting plug lock and tighten
16. Remove lock holding eccentric bushing at spine end of steering sector shaft and adjust bushing
 Note: Adjust eccentric bushing by turning clockwise until all play is eliminated and steering is free and lock adjustment
17. Replace in chassis and reassemble
18. Replace steering arms and tighten
 Note: The zero mark on dial indicator steering sector shaft must line up with zero mark on steering arm

Material


Oil

640

Same as 626

Material

Oil



S351 Steering Gear Remove and Replace **626**

Note: Protect trimmings and finish from oil and scratches by using fender covers S. T. 131, seat covers S. T. 111, double door covers S. T. 146.

1. Remove front compartment floor boards.
2. Disconnect steering lever, using lever puller S. T. 135, control rods and horn cable.
3. Remove steering column to instrument board anchorage.
4. Take out steering gear to frame bolts and lift out assembly.
5. Replace steering assembly and reassemble.

Note: Before replacing steering lever, be sure and lock center of steering wheel travel with front wheels perfectly straight.

Material

Same as 626 **649**

Material**S352 Steering Gear Adjust and Fill with Whitmores NO-52** **626**

1. Adjust pillar rule so that worm is just free.
2. Adjust sector shaft for end play. Turn sector plug clockwise until steering is rough and stiff. Then turn plug anti-clockwise until sector is free and then replace lock.
3. Adjust eccentric bushing by turning clockwise until all play is eliminated and steering is free.
4. Fill steering with heavy oil, Whitmores NO-52.

Material

1 Pt. Whitmores Compound **640**

Material

1 Pt. Whitmores Compound

Clutch Pedal - Adjust**626 T11**

1. Adjust clutch shifter lever connecting rod nut to permit one inch free travel of clutch pedal arm between the floor board and the point where the shifter lever begins to function.

Material

Same as 626

640**Material****Clutch Driven Plate - Renew (One Plate Clutch)
(Includes T110)****626 T15**

1. Install New Clutch Plates

Material

1-148016 Driven Plate Assembly

**Clutch Driven Plates—Renew
(Includes T110)****640**

Same as 626

Material

2-143407 Driven Plate Assembly

**Clutch and Transmission Assembly
Remove and Replace****626 T109**

Note: To protect exposed surfaces in seat covers S. T. 144 double door covers S. T. 146 and steering wheel covers S. T. 149

1. Remove floor boards and pedal pads and toe boards
2. Disconnect brake rod and speedometer cable
3. Remove front universal joint and swing joint to one side
 Note: Remove frame front intermediate channel reinforcement
4. Remove $\frac{1}{2}$ " bolts from clutch case or spring cover assembly to one side and lower the assembly to be removed from under car
 Note: Do not dismantle clutch or transmission on this operation
5. Replace clutch and transmission in reverse order of removal

Material


Same as 626

640**Material****Clutch—Remove for Inspection, Dismantle -
Reassemble and Replace (One and Two Plate Clutch)****626 T110**

Note: To protect exposed surfaces, use seat covers S. T. 144 double door covers S. T. 146 and steering wheel cover S. T. 149

1. Remove floor boards and pedal pads
2. Remove toe boards and remove shifter lever screws
3. Disconnect brake rod at foot brake pedal
4. Disconnect turn signal light cable and speedometer cable
5. Remove front universal joint. Swing joint to one side
6. Remove frame front intermediate channel reinforcement
7. Remove $\frac{1}{2}$ " nuts and bolts from clutch case and lower clutch and transmission to floor. Jack up left front wheel so as to allow assembly to be removed from under car
8. Disconnect and remove cover plate and spring assembly from flywheel

Clutch Release Lever Gauge



Tool No. 645

Clutch Plate Aligning Bar



Tool No. S. T. 638

T110

Cont.

9. Remove driven plate unit from flywheel and dismantle plates and clutch shaft.
Note: The lining of clutch plates must be free from oil and in good condition, and have good bearing surfaces. Place the clutch plates on a surface plate to locate the sprung or warped plates.

10. Eliminate end play in clutch shaft.

11. Reassembly in reverse order of removal.

Note: When reassembling plates see that the center driving plates and clutch plates have $\frac{1}{2}$ " clearance. It is also necessary to have an old clutch shaft handy to line up the clutch plates when tightening the cover and spring assembly to the flywheel. This is important. There are three adjusting screws on the spring and cover assembly which should be adjusted in $\frac{1}{4}$ " after the cover and spring assembly have been replaced and tightened to the flywheel or screw down until point seats on driving plates, then back off three notches.

Material

2 Qua. Oil

Same as 626

610

Material

2 Qua. Oil

T111 Clutch Driven Plate and Pressure Plate—Renew
(One Plate Clutch) (Includes T110)

626

1. Install new clutch plate.
2. Remove and dismantle clutch pressure plate and install.

Material

1-148016 Driven Plate Assembly
1-148017 Pressure Plate
6-143476 Bolt
6-143478 Nut
6-148021 Washer

T111
*Cont.***Clutch Center Plate Driven Plates and Pressure Plate--Renew
(Includes T110 - Two Plate Clutch)**

640

1. Install new plates

Material

2-143467 Driven Plate Assembly
1-148017 Pressure Plate Assembly
1-143484 Center Driving Plate
6-143476 Bolt
6-143478 Nut
6-143477 Washer

**Clutch Pressure Plate - Renew
(Includes T110)**626 **T112**

1. Remove and disassemble clutch pressure plate and install

Material

1-148017 Pressure Plate
6-143476 Bolt
6-143478 Nut
6-148021 Washer

Same as 626

640

Material

1-143471 Pressure Plate
6-143476 Bolt
6-143478 Nut
6-143477 Washer

**Clutch Shaft Front Bearing - Renew
(Includes T109)**626 **T113**

1. Remove old bearing from flywheel
2. Supply an liberal new bearing
3. Be sure to lubricate bearing with grease

Material

1-107389 Bearing
1-156461 Retainer

**Clutch Shaft Front Bearing - Renew
(Includes T109)**

640

Same as 626

1-107389 Bearing
1-156461 Retainer

**T114 Clutch Shaft Rear Bearing- Renew
(Includes T110)** 626

1. Remove clutch shaft rear bearing retainer
2. Press out old bearing sleeve
3. Supply and install new bearing and collar assembly
4. Lubricate bearing and replace retainer

Material

- 1-116601 Roller Assembly
1-116600 Sleeve
1-117814 Thrust Washer
1-117985 Rear Bearing Housing Crasket

(Includes T110) 640

Same as 626

Material

- 1-116601 Roller Assembly
1-116600 Sleeve
1-117814 Thrust Washer
1-117985 Rear Bearing Housing Crasket

**T116 Clutch Shaft- Renew
(Includes T110)** 626

1. Remove clutch shaft rear bearing retainer from transmission
2. Supply and reassemble new clutch shaft
Note: Shine transmission housing shaft thrust bearing. Should have not more than .000" end play

Material

- 1-138103 Shaft
1-117985 Rear Bearing Housing Crasket

(Includes T110) 640

Same as 626

Material

- 1-138103 Shaft
1-117985 Rear Bearing Housing Crasket

**T117 Clutch Shifter Thrust Bearing- Renew
(Includes T110)** 626

1. Remove clutch shifter bearing and install new

Material

- 1-138119 Bearing

(Includes T110) 640

Same as 626

Material

- 1-138119 Bearing

T120 Clutch- Recondition (Labor Only) 626

Note: The estimated labor prices of parts required to recondition clutch are:
1st zone, \$21.15; 2nd zone, \$22.55; 3rd zone, \$25.00. All parts listed will not be required.

Note: To protect exposed surfaces, use seal covers S. T. 144 double door covers S. T. 149 and steering wheel cover S. T. 149

1. Remove floor boards and pedal pads.
2. Remove toe boards.
3. Disconnect brake rod at foot brake pedal.
4. Disconnect rear stop lamp cable and speedometer cable.
5. Remove frame from intermediate channel reinforcement.
6. Remove shifter lever screws.
7. Remove front universal joint, swing joint to one side.
8. Remove $\frac{1}{2}$ " nuts and bolts from case and lower the clutch and transmission to floor. Jack up left front wheel so as to allow assembly to be removed from under car.
9. Disconnect and remove cover plate and spring assembly from flywheel.
10. Remove shaper and clutch plates from flywheel and dismantle plates and clutch shaft.

Note: The inner clutch plates must be free from oil and in good condition and have good bearing surfaces. Place the clutch plates on a surface plate to locate the sprung or warped plates.

11. Eliminate end play in clutch shaft.
12. Rebuild clutch using new parts to put in first class condition.

Note: When reassembling plates see that the outer driving plates and clutch plates have $\frac{1}{2}$ " clearance. It is also necessary to have an old clutch shaft bandy to line up the clutch plates, when tightening the cover and spring assembly to the flywheel.

(This is important. There are three adjusting screws on the spring and cover assembly which are to be adjusted to $\frac{1}{2}$ " clearance after the cover and spring assembly have been replaced and tightened to the flywheel or screw down until point starts on driving plate, then back out three notches.)

T120
Cont.

Material

- 1-113267 Clutch Driving Plate Assembly
- 1-148196 Clutch Release Bearing
- 1-148104 Clutch Bush
- 1-143467 Clutch Intermediate Assembly
- 1-143142 Clutch Release Lever
- 6-143439 Clutch Release Bolt Spring
- 3-143480 Clutch Separation Spring
- 1-143181 Clutch Driving Plate
- 1-143180 Clutch Spring
- 6-143185 Clutch Release Lever
- 1-143188 Clutch Intermediate Motor Assembly
- 6-143557 Clutch Separation Screw Spring
- 1-143121 Pin, Mounting
- 6-143126 Bush
- 6-143178 Nut

Service Notes

648

Material

- 1-143467 Clutch Driving Plate Assembly
- 1-148119 Clutch Release Bearing
- 1-148104 Clutch Bush
- 1-143171 Clutch Intermediate Assembly
- 1-143172 Clutch Release Lever
- 6-143126 Clutch Release Bolt Spring
- 3-143480 Clutch Separation Spring
- 1-143181 Clutch Driving Plate
- 1-143180 Clutch Spring
- 6-143185 Clutch Release Lever
- 1-143188 Clutch Intermediate Motor Assembly
- 6-143188 Clutch Separation Screw Spring
- 6-143776 Bush
- 6-143178 Nut

T121 Clutch Shifter Fork Shaft-- Renew

626

- Note: Protect exposed surfaces, use seat covers.
1. Remove floor boards and pedal pads
 2. Remove toe boards, brake rod at foot pedal
 3. Remove clutch case inspection plate
 4. Use $\frac{3}{8}$ " long shank socket wrench and remove clutch casing cap screws
 5. Remove universal joint at transmission and swing joint and shaft to one side
 6. Remove $\frac{1}{8}$ " nuts and bolts from clutch case and lower clutch and transmission to floor
 7. Remove clutch shifter fork and install new shifter fork
 8. Reassemble in the reverse order of removal

Material

1-142000 Fork

Same as 626

640

Material

1-142000 Fork.

**T130 Clutch and Transmission
Recondition (Labor Only)**

626

Note: The estimated zone prices of parts required to recondition clutch and transmission are: 1st zone, \$67.50, 2nd zone, \$71.10, 3rd zone, \$78.70.
All parts listed will not be required.

1. Remove floor boards and pedal pads
 2. Remove toe boards
 3. Disconnect brake rod at foot brake pedal
 4. Disconnect rear stop light cable and speedometer cable
 5. Remove front universal joint. Swing joint to one side
 6. Remove front front longitudinal channel reinforcement
 7. Remove shifter lever screw
 8. Remove $\frac{3}{8}$ " nuts and bolts from case and lower the clutch and transmission to floor. Jack up left wheel so as to allow assembly to be removed from under car
 9. Disassemble and remove cover plates and spring assembly from flywheel
 10. Remove driver and clutch plates from flywheel and disassemble plates
 11. Rebuild clutch using new parts to put in first class condition
 - Note: When reassembling plates see that the center driving plates and clutch plates have $\frac{1}{8}$ " clearance. It is also necessary to have an old clutch shaft band to line up the clutch plates. When tightening the cover and spring assembly to the flywheel there are three adjusting screws on the spring and cover assembly. This is important which should be adjusted to $\frac{1}{8}$ " clearance after the cover and spring assembly have been replaced and tightened to the flywheel
 12. Remove clutch shaft and bearing and eliminate end play in clutch shaft
 13. Drain oil from transmission
 14. Remove transmission case cover
 15. Remove shifter shaft interlocking plunger. This will permit the removal of shifter shaft after the interlocking screws have been removed from shifter
 16. Remove speedometer drive at rear bearing housing
 17. Pull out direct drive shaft
 18. Lift out first and second speed gear
 19. Remove countershaft nut. Also remove small locking screws at rear of countershaft
 20. Use brass drift punch. Drive on counter-shaft toward the rear of case and fit out countershaft
 21. Rebuild transmission, using new parts necessary to put in first class condition
 22. After thorough inspection has been made, reverse this order for reassembling
- Note: Transmission driving shaft thrust button located within the direct driving gear should not have more than .006" end play. Shim if necessary

Material

Transmission

1-111112	Driving Shaft Bearing—Rear
1-126822	Countershaft First Speed and Reverse Gear
1-126824	Countershaft Second Speed Gear
1-126823	Countershaft Constant Mesh Gear
1-126113	Direct Drive and Second Speed Gear
1-126141	First Speed and Reverse Gear
1-124353	Driving Shaft
1-124151	Driving Shaft Bearing—Front
2-124347	Countershaft Bearings
2 Qts. Oil	

(One Plate Clutch)

1-148016	Driven Plate Assembly
1-143471	Pressure Plate
6-143476	Bolt
6-143478	Nut
1-142000	Clutch Shaft

Same as b26

640

Note: The estimated zone prices of parts required to recondition clutch and transmission are: 1st zone, \$67.85; 2nd zone, \$71.10; 3rd zone, \$78.70. All parts listed will not be required.

Material

Clutch

2-143467	Clutch Driven Plate Assembly
1-138119	Clutch Snifter Thrust Bearing
1-138103	Clutch Shaft
1-143471	Clutch Pressure Plate Assembly
1-143472	Clutch Spline Hub
6-143479	V-Notch Release Bolt Springs
4-143480	Clutch Separation Springs
1-143484	Clutch Center Driving Plate
12-143486	Clutch Springs
6-143485	Clutch Release Levers
1-154668	Clutch Inulator Mat Assembly
1-141488	Cover Plate
3-143488	Adjuster Screw Springs

Transmission

1-111112	Driving Shaft Bearing—Rear
1-126822	Countershaft First Speed and Reverse Gear
1-126824	Countershaft Second Speed Gear
1-126823	Countershaft Constant Mesh Gear
1-126113	Direct Drive and Second Speed Gear
1-126141	First Speed and Reverse Gear
1-124353	Driving Shaft
1-124151	Driving Shaft Bearing—Front
2-124347	Countershaft Bearings
2 Qts. Oil	

Clutch and Transmission—Remove for Inspection, Dismantle, Report and Reassemble

626

T140

Note: Protect exposed surfaces use seat covers S. T. 144, double door covers S. T. 146 and steering wheel cover S. T. 149

1. Remove foot board and pedal pads
2. Remove toe boards
3. Disconnect brake rod at foot brake pedal
4. Disconnect rear stop light cable and speedometer cable
5. Remove front universal joints. Swing joint to one side

T140*Cont.*

6. Remove $\frac{3}{8}$ " nuts and bolts from case and lower the clutch and transmission to floor. Jack up left front wheel so as to allow assembly to be removed from under car.
7. Disconnect and remove cover plates and spring assembly from flywheel.
8. Remove driven and clutch plates from flywheel and dismantle plates.
Note: When reassembling plates see that the center driving plates and clutch plates have $\frac{3}{16}$ " clearance. It is also necessary to have an oil clutch shaft handy to line up the clutch plates. When tightening the cover and spring assembly to the flywheel there are three adjusting screws on the spring and cover assembly (this is important), which should be adjusted to $\frac{3}{16}$ " after the cover and spring assembly have been replaced and tightened to the flywheel.
9. Remove clutch shaft and bearing.
10. Drain oil from transmission.
11. Remove transmission case cover.
12. Remove shifter shaft interlocking plunger. This will permit the removal of shifter shaft after the interlocking screws have been removed from shifter.
13. Remove speedometer drive at rear bearing housing.
14. Pull out direct drive shaft.
15. Lift out first and second speed gear.
16. Remove countershaft nut; also remove small locking screw at rear of countershaft.
17. Use brass drift punch. Drive on countershaft toward the rear of case and lift out countershaft.
18. After a thorough inspection has been made, reverse this order for reassembly.
Note: Transmission driving shaft thrust bearing located within the direct driving gear should not be over .006" end play. Shim if necessary.

Material

2 Qts. Oil

Same as 675

640

Material

2 Qts. Oil

Transmission Gear Shifter Fork--Renew**626 T20**

Note: Use seat covers

1. Remove floor boards and shifter lever cover
2. Remove transmission shifter shaft interlocking plunger. This will permit the removal of shifter shaft after the interlocking screws have been removed from shifter fork
3. Remove the old shifter fork and install new
4. Rebuild the entire job

Material

1-158111 Fork

Same as 626

640

Material

1-158144 Fork

Change Speed Lever - Renew**626 T21**

Note: Use seat covers S. T. 144 to protect surfaces from oil and grease

1. Remove floor board and toe boards
2. Remove change speed lever nut and dust cover
3. Supply and install new change speed lever

Note: Be sure both shifter forks are in neutral position

Material

1-158428 Lever

Same as 626

640

Material

1-158428 Lever

Transmission Cover Gasket--Renew**626 T25**

Note: To prevent trimming from oil and grease, use seat covers S. T. 144

1. Remove floor board and toe boards
2. Remove cover and install new gasket
3. Reassemble cover in place
4. Replace floor boards and tighten screws in toe board

Material

1-124304 Gasket

Same as 626

640

Material

1-124303 Gasket

Transmission Case - Supply and Install**626 T26**

Note: Use seat covers S. T. 144 to protect exposed surfaces from oil and grease

1. Remove toe pads, floor boards and toe boards
2. Remove universal joint, clutch cover and clutch casing screws
3. Remove transmission and clutch assembly. (See operation T140)
4. Drain oil
5. Remove transmission case cover
6. Remove transmission shifter shaft interlocking plunger. This will permit the removal of shifter shafts after the locking screws have been removed from shifter fork

T26*Cont.*

7. Remove speedometer drive at rear bearing housing
8. Remove nuts from driving shaft rear bearing housing
9. Pull out direct drive shaft
10. Lift out 1st and 2nd speed gears
11. Remove drive shaft front bearing
12. Remove clutch shaft
13. Remove countershaft nut; also small locking screws at rear of countershaft
14. Use brass drift punch, drive out countershaft toward the rear of case and lift out countershaft gears
15. Supply and install new case, using original parts
Note: Transmission driving shaft thrust bearing, located within the direct driving gear should not have more than .006" end play...shim if necessary

Material

1-159271 Case
2 Qts. Gear Oil

Same as 626

640

Material

1-159271 Case
2 Qts. Gear Oil

T27**Transmission Gear Shifter Lock Plunger and Spring: Renew**

626

Note: Use seat covers to protect exposed surfaces from oil and grease

1. Remove floor board
2. Remove transmission shifter shaft interlocking plunger
3. Renew shifter lock plunger and spring
4. Rebuild the entire job and test on floor

Material

1-148283 Spring
1-158128 Plunger

Same as 626

640

Material

1-118283 Spring
1-158128 Plunger

T28**Transmission Direct Drive and Second Speed Gear: Renew**

626

Note: To protect trimming from oil and grease, use seat covers S. T. 141

1. Remove floor board
2. Disconnect speedometer cable at transmission
3. Loosen screws in floor board
4. Remove transmission cover and shifter lever
5. Loosen lock screws on shifter forks and gear shifter shaft interlocking plungers, then remove shifter shaft cover and pull out shifter shafts
6. Replace front universal joint
7. Remove rear bearing housing of direct drive shaft
8. Pull direct drive shaft far enough to release direct drive and 2nd speed gear
9. Lift out old direct drive and 2nd speed gear
10. Install new gear and reassemble in reverse order of disassembly
Note: Drive shaft end play should not exceed .006". Shim if necessary
11. Reassemble and fill to level with fresh gear oil

Material

1-126173 Gear
2 Qts. Gear Oil

Same as 626

T28

Cont.

640

Material

1-128173 Gear
2 Qts. Gear Oil

Transmission Drive Shaft--Renew

626 T29

Note: Use seat covers S. T. 144 to protect exposed surfaces

1. Remove floor board
2. Disconnect speedometer cable at transmission
3. Loosen screws in toe board
- Note: Shift gears to register in third speed
4. Remove transmission cover and shifter lever
5. Remove front universal joint
6. Remove rear bearing housing of direct drive shaft
7. Pull direct drive shaft
8. Press off universal joint flange speedometer driving gear and rear bearing
9. Assemble bearing, speedometer driving gear and universal flange to new shaft
- Note: Be sure that rear bearing oil thrower is assembled after pressing on speedometer drive gear with outer edge toward the rear of shaft. Also see that shaft nut is pulled up tight
10. Install new shaft and reassemble in reverse order of disassembly. End play of shaft should not exceed .008". Shim if necessary

Material

1-117984 Rear Bearing Housing Gasket
1-146597 Shaft
2 Qts. Oil

Same as 626

640

Material

1-117984 Rear Bearing Housing Gasket
1-146597 Shaft
2 Qts. Oil

Transmission—Remove, Dismantle, Report and Reassemble

626 T210

Note: Use seat covers S. T. 144 to protect exposed surfaces from oil and grease

1. Remove floor and toe boards
2. Disconnect universal joint and remove transmission and clutch assembly from chassis
3. Jack up chassis to permit removal of transmission and clutch assembly
4. Remove clutch assembly from transmission. (See operation T140)
5. Drain oil from transmission case
6. Remove transmission case cover
7. Remove transmission shifter shaft interlocking plunger. This will permit the removal of shifter shafts after the locking screws have been removed from shifter fork
8. Remove speedometer drive at rear bearing housing
9. Remove nuts from driving shaft rear bearing housing
10. Pull out direct drive shaft
11. Lift out 1st and 2nd speed gears
12. Remove drive shaft front bearing
13. Remove clutch shaft

T210*Cont.*

14. Remove countershaft nut; also remove small locking screw at rear of countershaft
15. Use brass drift punch, drive out countershaft toward the rear of case and lift out countershaft gears
16. Report on condition of transmission parts
17. Reassemble in reverse order of removal
Note: Transmission driving shaft thrust button located within the direct driving gear should not have more than .006" end play—if necessary shim

Material

2 Qts. Gear Oil

Same as 626

640**Material**

2 Qts. Gear Oil

T211**Transmission Case Cover—Renew****626**

Note: Use seat covers S.T. 144

1. Remove floor board and shifter lever cover
2. Remove shifter lever from cover and install new cover and gasket
3. Rebuild the entire job

Material1-124393 Gasket
1-159271 Cover

Same as 626

640**Material**1-124393 Gasket
1-159271 Cover**T213****Transmission Speedometer Gear—Tighten on Shaft****626**

Note: Use seat covers

1. Remove floor boards and clutch shifter lever and cover
2. Remove speedometer shaft and bushing
3. Remove shifter fork
4. Remove nuts from driving shaft rear bearing housing
5. Pull out direct drive shaft and lift out first and second speed gears
6. Tighten speedometer gear and rebuild the entire job

Material

Same as 626

640**Material**

**Transmission Gear Shifter Fork Shaft - Renew
(Transmission Off Car)**
626 T216

1. Remove transmission shifter shaft interlocking plunger. This will permit the removal of shifter shaft after the interlocking screws have been removed from shifter tool.
2. Remove the old shaft and install new.

Material

1-158095 Shaft

(1)

1-158091 Shaft

(1)

Same as 626

640

Material

1-158095 Shaft

(2)

1-158091 Shaft

(2)

**Transmission Direct Drive Shaft and Shifter
Fork - Remove and Replace**
626 T217

1. Remove door boards and shifter.
2. Remove shifter fork.
3. Remove universal joint.
4. Disconnect speedometer cable.
5. Remove rear bearing housing and pull direct drive shaft and second speed gear.
6. Inspect transmission for broken fork parts that dropped into transmission oil.
7. Reassembly.

Note: This operation should be used in conjunction with T-26 Transmission Shifter Fork - Renew.

Material

Same as 626

640

Material

Universal Joint Flange Bolts—Front and Rear—Tighten**626 T34**

1. Tighten bolts front and rear
Note: Be sure all lock washers are in place

Material

Same as 626

640**Material****Universal Joint Drive Shaft—Renew****626 T36**

1. Remove rear universal joint flange bolts and pull assembly clear of spline joint in front
 2. Disassemble rear joint and mount on new shaft
 3. Assemble in place with joint yokes in same place and pack with universal joint grease or fill with oil
- Note: Be sure that each bolt has at least one lock washer

Material

1-158447 Shaft 16200

OF

1-158448 Shaft 16330

1 Qt. Oil

Same as 626

640**Material**

1-158449 Shaft 16400

1-158450 Shaft 16450

1 Qt. Oil

**Universal Joint Front or Rear Recondition
Labor Only:****626 T37**

Note: This specification does not include universal joint shaft

1. Remove universal joint front or rear
2. Remove joint lock plate
3. Remove eight (8) nuts holding the two oil retaining housing halves together
Note: A slight tapping on the ends of the protruding studs will cause the housing to separate. Care should be taken not to damage the ground surfaces where the two half housings join together
4. Recondition and replace with new parts necessary to put in first class condition
5. In reassembling care should be taken to see that four cork packing washers are in place

Note: It is advisable to paint the ground surfaces of the housing where they join together with a thin shellac

Material

4-134317 Lock Plate

4-134327 Cork Washers

1-134322 Joint Flanged Yoke

1-134315 Yoke Pin

1-134313 Joint Housing Plain

1-134314 Joint Housing with Oil Holes

4-134316 Trunnion Bearings

T37 Same as 626 640

Material

Cont. 4-134317 Lock Plates...

4-134327 Cork Washers...

1-134322 Joint Flanged Yoke...

1-134315 Yoke Pin...

1-134313 Joint Housing Plain...

1-134314 Joint Housing with Oil Holes...

4-134316 Tennenum Bearings...

T316 Universal Joint, Bolts and Nuts - Renew One End 626

1. Remove old bolts and install new bolts and nuts.

Note: Be sure lock washers are in place.

2. Refill universal joint with oil.

Material

6- 7005 Nuts

6-140065 Bolts

1 Qt. Oil

Same as 626 640**Material**

6- 7005 Nuts

6-140065 Bolts

1 Qt. Oil

T317 Universal Joint, Bolts and Nuts - Renew All 626

1. Remove old bolts and install all new bolts and nuts at the front and rear joint.

Note: Be sure that all lock washers are in place.

2. Refill universal joint with grease.

Material

12- 7005 Nuts

12-140065 Bolts

1 Qt. Oil

Same as 626 640**Material**

12- 7005 Nuts

12-140065 Bolts

1 Qt. Oil

T320 Transmission - Recondition - Labor Only 626

1. Remove foot board pedal pads and toe board.
2. Disconnect universal joint and remove transmission and clutch assembly from chassis.
3. Remove clutch from transmission.
4. Drain oil from transmission case.
5. Remove transmission case cover.
6. Remove transmission shifter shaft interlocking plunger. This will permit the removal of shifter shafts as the locking screws have been removed from shifter fork.
7. Remove speedometer drive in rear bearing housing.
8. Remove nuts from driving shaft rear bearing housing.
9. Pull out direct drive shaft.
10. Lift out 1st and 2nd speed gears.

11. Remove drive shaft front bearings
12. Remove clutch shaft
13. Remove countershaft gear; also remove small locking screw at rear of countershaft
14. Use brass drift pinion, drive out countershaft toward the rear of case and lift ten countershaft gears
15. Relight transmission, using new parts necessary to put in first class condition
 Note: Transmission driving shaft thrust bearing, located within the direct driving gear, should not have more than .000" end play if necessary stem
 Note: The estimated zone prices of parts required to recondition transmission are: 1st zone, \$40.00; 2nd zone, \$42.00; 3rd zone, \$46.50. All parts listed will not be required.

T320
Cont.

Material

- 1-11112 Driving Shaft Ball Bearing—Rear
 1-126822 First Speed and Reverse Gear
 1-126824 Second Speed Gear
 1-126826 Constant Mesh Gear
 1-126173 Direct Drive and Second Speed Gear
 1-126141 First Speed and Reverse Gear
 1-124353 Driving Shaft
 1-124354 Driving Shaft Bearing—Front
 2-121447 Counter-shaft Bearings
 2 Qua. Oil

Same as 626

640

Material

- 1-11112 Driving Shaft Ball Bearing—Rear
 1-126822 First Speed and Reverse Gear
 1-126824 Second Speed Gear
 1-126826 Constant Mesh Gear
 1-126173 Direct Drive and Second Speed Gear
 1-126741 First Speed and Reverse Gear
 1-124353 Driving Shaft
 1-124354 Shaft Bearing—Front
 2-124357 Counter-shaft Bearings
 2 Qua. Oil

Universal Joint Flange Bolts Tighten One End

1. Tighten flange bolts front or rear

Note: Be sure that lock washers are in place

Material

Same as 626

626 T321

Material

Same as 626

640

Universal Joints Remove, Inspect, Report and Replace

1. Remove universal joint, front and rear
2. Remove point lock plates
3. Remove outer housing holding the two oil retaining housing halves together
 Note: A slight tapping on the ends of the pin retaining studs will cause the housing to separate. Care should be taken not to damage the ground surfaces where the two half bearings join together
4. Report to foreman condition found
5. Reassemble universal joint. Care should be taken to see that four lock packing washers are in place
 Note: It is advisable to paint the ground surfaces of the housing where they join together with thin shellac

626 T322

T322 Material1 Qt. Oil
Same as 626

640

Conf. Material
1 Qt. Oil**T323** Universal Joint—Front or Rear Remove, Inspect, Report and Replace

626

1. Remove universal joint front or rear
2. Remove joint lock plates
3. Remove eight (8) nuts holding the two oil retaining housing halves together
 Note: A slight tapping on the ends of the protruding studs will cause the housing to separate. Care should be taken not to damage the ground surfaces where the two half housings join together.
4. Report to foreman the condition found
5. Reassemble universal joint. Care should be taken to see that four cork packing washers are in place.
 Note: It is advisable to joint the ground surfaces of the housing where they join together with thin shellac.

Material

1 Qt. Oil
Same as 626

640

Material

1 Qt. Oil

Operations Listed in Service Manual Index

6th, 7th, 8th and 9th Series

Oper. No.	Page No.										
A											
A10	11	B153	61	B420	17	E49	35	E512	67	F275	62
		B155	51	B1543	14	E51	7	E610	55	F276	62
A11	10	B156	51	B530	21	E51	7	E705	7	F277	62
A12	10	B157	61	B601	3	E54	64			F368	51
A13	10	B158	41	B604	37	E55	7			F369	51
A14	10	B159	41	B605	52	E56	64	E12	60	F371	51
A15	6	B161	1	B607	9	E61	15	E13	60	F372	51
A16	6	B162	13	B608	4	E64	16	E14	61	F376	51
A17	10	B163	79	B610	9	E71	7	E15	62	F377	51
A18	10	B164	79	B611	79	E72	7	E16	63	F378	51
A19	5	B167	74	B612	79	E73	7	E25	63	F382	51
A20	73	B212	69	B613	79	E74	7	E46	67	F390	51
A21	5	B213	69	B615	79	E76	7	E27	61	F391	51
A22	5	B221	69	B645	75	E78	7	P13	64	F393	51
A23	10	B222	69	B645	79	E100	37	P14	61	F396	62
A24	23	B223	69	B654	24	E101	27	P15	61	F397	62
A25	23	B225	69	B655	24	E102	27	F35	64	F398	61
A26	10	B226	69	B659	24	E303	27	F16	31	F399	61
A27	10	B227	68	B671	24	E306	32	F17	61	F410	29
A28	10	B228	68	B662	24	E107	32	F38	61	F411	29
A29	10	B229	68	B643	24	E109	23	F39	41	F413	29
A30	10	B230	68	B664	24	E111	24	F41	29	F415	29
A31	10	B234	69	B665	24	E114	37	F42	29	F416	48
A32	10	B235	69	B666	24	E117	37	F45	29	F417	29
A33	10	B240	69	B667	24	E120	37	F46	29	F420	56
A34	24	B241	61	B668	24	E121	37	F47	29	F421	56
A35	24	B242	61	B669	24	E124	24	F101	60	F422	56
A36	24	B243	61	B670	24	E125	24	F102	60	F423	56
A37	24	B244	61	B671	24	E130	27	F108	60	F424	56
A38	24	B245	61	B672	24	E134	26	F109	60	F426	57
A39	24	B252	11	B674	24	E111	24	F110	29	F427	57
A40	24	B253	11	B675	24	E114	34	F111	29	F428	57
A41	5	B254	11	B676	24	E114	31	F113	29	F429	57
A42	5	B257	21	B677	24	E115	24	F119	30	F430	29
A43	6	B259	21	B678	24	E120	24	F130	60	F431	29
A44	5	B260	63	B679	24	E121	24	F132	60	F432	29
A45	73	B261	61	B680	24	E130	24	F140	60	F433	29
A46	5	B312	11	B687	68	E132	34	F141	60	F436	56
A47	73	B312	11	B689	68	E133	34	F142	60	F439	29
A48	5	B311	11	B690	29	E134	34	F150	60	F440	29
A49	61	B314	21	B691	26	E235	24	F160	60	F441	56
A50	5	B315	21	B692	29	E111	61	F170	61	F442	56
A51	23	B316	21	B693	29	E112	61	F211	61	F443	56
A52	23	B311	29			E114	61	F212	61	F445	31
A53	23	B343	29			E117	61	F213	61	F446	31
A54	23	B353	61	C1	21	E318	61	F214	61	F447	29
A55	23	B354	61	C1	21	E320	61	F215	61	F450	29
A56	23	B355	61	C1	21	E121	61	F216	61	F451	29
A57	23	B356	50	E10	24	E123	61	F218	61	F454	29
A58	23	B357	50	E11	21	E124	61	F219	61	F482	56
A59	23	B358	50	E12	21	E125	61	F220	61		
A60	23	B359	50	E13	21	E126	61	F221	61	G105	1
A61	23	B364	50	E14	21	E127	64	FF233	62	G101	1
A62	23	B365	50	E15	21	E128	65	F224	61	G106	2
A63	23	B366	50	E16	21	E129	63	F226	61	G107	2
A64	23	B367	50	E17	24	E130	63	F228	61	G108	2
A65	23	B368	50	E18	24	E131	61	F230	62	G109	2
A66	23	B369	50	E19	21	E143	35	F231	62	G110	2
A67	23	B370	50	E20	17	E145	35	F232	61	G111	2
A68	23	B371	50	E21	11	E146	7	F233	61	G112	2
A69	23	B372	50	E22	11	E147	62	F234	62	G113	2
A70	23	B373	50	E23	11	E435	61	F240	62	G115	4
A71	23	B374	50	E24	11	E436	61	F241	61	G116	4
A72	23	B375	50	E25	11	E438	61	F242	62	G117	2
A73	23	B376	50	E26	11	E439	61	F243	62	G120	2
A74	23	B377	50	E27	5	E440	61	F244	62	G123	2
A75	23	B378	50	E28	11	E441	61	F245	62	G125	4
A76	23	B379	50	E29	11	E451	17	F261	62	G126	2
A77	23	B380	50	E32	61	E452	17	FF262	61	G127	2
A78	23	B381	50	E34	64	E453	17	F271	62	G128	2
A79	23	B382	50	E42	66	E454	17	F274	62	G129	2
A80	23	B383	50	E43	15	E458	17	F275	62	G130	2
A81	68	B416	50	E44	15	E459	17	F276	62	G131	2
A82	61	B417	50	E46	35	E464	61	F277	62	G132	2

Oper. No.	Page No.										
G141	2	L49	47	M255	21	M484	65	M821	22	P101	50
G142	2	L51	47	M256	24	M485	14	M824	22	P104	49
G143	1	L52	48	M257	27	M490	64	M825	27	P105	49
G144	4	L53	48	M258	24	M510	19	M829	67	P106	49
G145	4	L54	47	M260	36	M512	8	M830	77	P107	49
G146	4	L55	47	M261	36	M514	8	M831	27	P108	50
G147	2	L56	47	M262	36	M515	7	M832	27	P109	50
G148	2	M4	NE	M264	36	M516	8	M833	56	P110	50
G149	4	M46	43	M265	36	M517	19	M834	57	P111	50
G150	2	M51	43	M266	36	M520	8	M835	55	P112	50
G151	2	M52	43	M270	36	M521	18	M836	55	P113	50
G152	1	M53	43	M270	36	M522	18	M837	55	P114	50
G153	4	M54	43	M271	36	M530	7	M838	72	P115	50
G154	4	M55	43	M272	36	M531	7	M841	55	P116	50
G155	2	M56	43	M273	36	M532	7	M842	55	P117	50
G156	4	M57	43	M274	36	M533	7	M843	55	P118	50
G157	2	M58	43	M275	36	M534	7	M844	55	P119	50
G158	4	M59	43	M276	36	M535	7	M845	55	P120	50
G159	2	M60	73	M277	38	M536	7	M850	22	P121	50
G160	1	M61	71	M278	38	M537	7	M853	55	P122	49
G161	3	M62	74	M279	38	M538	30	M854	55	P123	50
G162	4	M63	74	M280	38	M539	31	M855	55	P124	49
G163	4	M64	74	M281	38	M540	7	M856	55	P125	50
G164	2	M65	73	M282	38	M541	47	M862	33	P126	50
G165	3	M66	14	M283	38	M542	47	M863	72	P127	51
G166	2	M67	33	M284	38	M543	19	M865	55	P128	51
G167	2	M68	73	M285	38	M544	19	M866	55	P129	51
G168	1	M69	71	M286	38	M545	7	M867	55	P130	50
G169	3	M70	74	M287	38	M546	19	M868	72	P131	51
G170	4	M71	74	M288	38	M547	30	M869	55	P132	49
G171	4	M72	74	M289	38	M548	31	M870	55	P133	50
G172	4	M73	74	M290	38	M549	47	M870	35	P134	49
G173	3	M74	14	M291	38	M550	19	M870	35	P135	51
G174	3	M75	33	M292	38	M551	47	M870	35	P136	51
G175	2	M76	33	M293	38	M552	19	M870	35	P137	50
G176	1	M77	14	M294	38	M553	47	M870	35	P138	51
G177	1	M78	33	M295	38	M554	19	M870	35	P139	50
G178	1	M79	33	M296	38	M555	47	M870	35	P140	50
G179	1	M80	33	M297	38	M556	19	M870	35	P141	51
G180	1	M81	14	M298	38	M557	47	M870	35	P142	51
G181	1	M82	33	M299	38	M558	19	M870	35	P143	51
G182	1	M83	33	M300	38	M559	47	M870	35	P144	51
G183	2	M84	33	M301	38	M560	19	M870	35	P145	51
G184	1	M85	33	M302	38	M561	47	M870	35	P146	50
G185	1	M86	33	M303	38	M562	19	M870	35	P147	51
G186	1	M87	68	M304	14	M563	47	M880	55	P148	51
G187	1	M88	45	M305	15	M564	15	M892	29	P149	50
G188	1	M89	29	M306	15	M565	15	M893	27	P150	50
G189	1	M90	29	M307	15	M566	15	M894	27	P151	51
G190	1	M91	29	M308	15	M567	15	M895	27	P152	51
G191	2	M92	19	M309	15	M568	15	M896	27	P153	51
G201	2	M93	19	M310	15	M569	15	M897	27	P154	50
G202	2	M94	19	M311	15	M570	21	M898	27	P155	50
G203	2	M95	19	M312	15	M571	21	M899	27	P156	50
G204	4	M96	21	M313	15	M572	21	M900	27	P157	50
G205	2	M97	21	M314	15	M573	21	M901	21	P158	50
G206	2	M98	21	M315	15	M574	21	M902	21	P159	50
G207	2	M99	21	M316	15	M575	21	M903	21	P160	50
G208	2	M100	43	M317	15	M576	21	M904	21	P161	50
G209	4	M101	53	M318	15	M577	21	M905	21	P162	50
G210	3	M102	53	M319	15	M578	21	M906	21	P163	50
G211	4	M103	43	M320	15	M579	21	M907	21	P164	50
G212	4	M104	43	M321	15	M580	21	M908	21	P165	50
G213	2	M105	21	M322	15	M581	21	M909	21	P166	50
G214	2	M106	21	M323	15	M582	21	M910	21	P167	50
G215	2	M107	21	M324	15	M583	21	M911	21	P168	50
G216	2	M108	21	M325	15	M584	21	M912	21	P169	50
G217	2	M109	43	M326	15	M585	21	M913	21	P170	50
G218	2	M110	43	M327	15	M586	21	M914	21	P171	50
G219	2	M111	43	M328	15	M587	21	M915	21	P172	50
G220	2	M112	43	M329	15	M588	21	M916	21	P173	50
G221	2	M113	43	M330	15	M589	21	M917	21	P174	50
G222	2	M114	43	M331	15	M590	21	M918	21	P175	50
G223	2	M115	43	M332	15	M591	21	M919	21	P176	50
G224	2	M116	43	M333	15	M592	21	M920	21	P177	50
G225	2	M117	43	M334	15	M593	21	M921	21	P178	50
G226	2	M118	43	M335	15	M594	21	M922	21	P179	50
G227	2	M119	43	M336	15	M595	21	M923	21	P180	50
G228	2	M120	43	M337	15	M596	21	M924	21	P181	50
G229	2	M121	43	M338	15	M597	21	M925	21	P182	50
G230	2	M122	43	M339	15	M598	21	M926	21	P183	50
G231	2	M123	43	M340	15	M599	21	M927	21	P184	50
G232	2	M124	43	M341	15	M600	21	M928	21	P185	50
G233	2	M125	43	M342	15	M601	21	M929	21	P186	50
G234	2	M126	43	M343	15	M602	21	M930	21	P187	50
G235	2	M127	43	M344	15	M603	21	M931	21	P188	50
G236	2	M128	43	M345	15	M604	21	M932	21	P189	50
G237	2	M129	43	M346	15	M605	21	M933	21	P190	50
G238	2	M130	43	M347	15	M606	21	M934	21	P191	50
G239	2	M131	43	M348	15	M607	21	M935	21	P192	50
G240	2	M132	43	M349	15	M608	21	M936	21	P193	50
G241	2	M133	43	M350	15	M609	21	M937	21	P194	50
G242	2	M134	43	M351	15	M610	21	M938	21	P195	50
G243	2	M135	43	M352	15	M611	21	M939	21	P196	50
G244	2	M136	43	M353	15	M612	21	M940	21	P197	50
G245	2	M137	43	M354	15	M613	21	M941	21	P198	50
G246	2	M138	43	M355	15	M614	21	M942	21	P199	50
G247	2	M139	43	M356	15	M615	21	M943	21	P200	50
G248	2	M140	43	M357	15	M616	21	M944	21	P201	50
G249	2	M141	43	M358	15	M617	21	M945	21	P202	50
G250	2	M142	43	M359	15	M618	21	M946	21	P203	50
G251	2	M143	43	M360	15	M619	21	M947	21	P204	50
G252	2	M144	43	M361	15	M620	21	M948	21	P205	50
G253	2	M145	43	M362	15	M621	21	M949	21	P206	50
G254	2	M146	43	M363	15	M622	21	M950	21	P207	50
G255	2	M147	43	M364	15	M623	21	M951	21	P208	50
G256	2	M148	43	M365	15	M624	21	M952	21	P209	50
G257	2	M149	43	M366	15	M625	21	M953	21	P210	50
G258	2	M150	43	M367	15	M626	21	M954	21	P211	50
G259	2	M151	43	M368	15	M627	21	M955	21	P212	50
G260	2	M152	43	M369	15	M628	21	M956	21	P213	50
G261	2	M153	43	M370	15	M629	21	M957	21	P214	50
G262	2	M154	43	M371	15	M630	21	M958	21	P215	50
G263	2	M155	43	M372	15	M631	21	M959	21	P216	50
G264	2	M156	43	M373	15	M632	21	M960	21	P217	50
G265	2	M157	43	M374	15	M633	21	M961	21	P218	50
G266	2	M158	43	M375	15	M634	21	M962	21	P219	50
G267	2	M159	43	M376	15	M635	21</				

STANDARD SERVICE

Operations Index

Oper. No.	Page No.										
S129, ..	63	S221, ..	78	S257	78	T2, ..	78	T110, ..	17	T24, ..	70
S131, ..	78	S222, ..	78	S310	64	L21, ..	70	T211, ..	17	T25, ..	70
S132, ..	78	S223, ..	78	S312	64	T22, ..	70	T112, ..	17	L212, ..	70
S133, ..	78	S225	78	S313	65	L23, ..	70	T113, ..	17	Y230, ..	70
S134, ..	75	S227, ..	78	S314, ..	64	T24, ..	70	L124	7	T22, ..	74
S140, ..	64	S228	75	S315, ..	64	T25, ..	70	T115, ..	17	T216, ..	71
S141, ..	64	S229	75	S316, ..	65	T26, ..	70	T116, ..	17	L117, ..	71
S142, ..	74	S230	78	S317, ..	61	L28, ..	70	T117, ..	17	T118, ..	71
S143, ..	64	S243	65	S332, ..	61	T32, ..	21	T118, ..	17	T270, ..	70
S144, ..	64	S246	65	T34	71	T33, ..	71	T119, ..	17	T119, ..	71
S146, ..	65	S251	75	T35	71	T36, ..	71	T120, ..	10	T121, ..	71
S151, ..	65	S255	75	T41	17	L37	71	T210	10	T122, ..	71
S120, ..	78	S256	75	T25	17	L102	70	T123, ..	70	T124, ..	71

packardinfo.com

Packard Standard Service and Index

After several years' experience with Packard Standard Prices and Operations we are fully convinced that this system of selling repair work is the only satisfactory method, both from the viewpoint of the owner and the Service Department.

We recognize the fact that these Standard Specifications cannot always be performed in the same time. Sometimes it will take more than the specified time, again it will take less, depending on varying conditions. Obstacles are encountered in some jobs which are absent in others. No two mechanics are equal in efficiency. The times and prices given are fair, being determined only after a number of Distributors and the Factory had proved definitely that the allotted times represented a fair average which can be met by the mechanic.

After all is said, the fairness of these Suggested Prices can be judged best by a comparison with those of our competitors.

Courtesy Operations

A few operations in this book are listed with the word "Gratis." A charge should not be made for any work which is ordinarily performed gratis by a local garage. Even though a price may be shown for such work in this book, service managers and service salesmen should exercise care in making a charge for minor work, especially when an owner waits for the work to be completed.

Packard Standard Operations

Packard Standard Operations are grouped for reference purposes in eleven major divisions, each heading up under its initial letter, as "A" for Axle.

Each division is subdivided into mechanical groups with an affixed numeral, as "A-1" for Axle Brakes. Individual repair operations are identified by adding one or more digits to the basic symbol, as "A-11" for "Brakes, Foot--Adjust," and indicates a complete repair operation. Certain conditions will require a preliminary internal inspection before the exact nature of the repair can be determined. Detail repair operations, such as ordinarily follow an internal inspection, are clearly indicated by double letters.

An alphabetical index is provided, listing the name of the Operation, Models covered, Mechanical Time, Standard Price, Symbol, and the Page on which the Standard Specifications may be found.

There are two sets of sheets, the index giving "Mechanical Times and Prices," and "Standard Specifications." The Times and Prices will be kept in line with material price changes and other factors that affect shop operating costs. All Standard Prices should be net to the customer in his respective zone.

Where the model is not shown, prices are for all cars, beginning with the 6th series. Specifications for the 6th series apply in 7th, 8th and 9th series also.

Detail repair operations as designated by double letters are embodied in the complete repair specifications under the single letter of the same number instead of being listed separately.

For Example: On the Packard Eight Model, if it is desired to remove the front gear case cover, the proper operation for this is M410 - \$ 5.00

Now let us assume that while doing this work a new front chain is necessary. To cover this additional work, we should sell double letter operation. MM412 - 10.85

This being a double letter operation, the price is quoted after the front cover has been removed and the total charge to the owner is the same as M412 or 316.65

This principle of non-overlapping operations is used throughout the Manual.

On Time and Material Operations, 25% should be added to the actual time it takes to perform the operations and this multiplied by the hourly rate should be what the customer pays for this kind of work. This, then, would be on about the same basis as our Mechanical Times as shown in the Manual.

This 25% is to cover Service Salesman's time, paper work in writing and costing the order, placing the car in the shop and final test.


We recommend that Accessories be installed at Manual Labor Rate since the Accessory profit is in the sale price of the article itself.

Special Repair Operations

There will always be a number of repair operations performed which, due to their uncommon occurrence, cannot be covered by a Standard Specification. In each case of this kind we recommend the quotation of a flat or contract price based on your past experience. There are a number of operations listed in index which are not covered by specifications but upon which a time is quoted. These times are to be used merely as a guide in estimating the cost of servicing these operations and may vary either one way or the other. It is our intention to eliminate all time and material operations. The effect of this policy on your customers will be far-reaching, in that it will demonstrate to them that you are making an honest effort to service Packard Vehicles efficiently and economically.

Packard Motor Car Company

Service Department



TITLED INDEX—ZONE I
ACCESSORIES

WANTS

Front Fender Lights—Supply and Install (Labor Only).....	726.826.901	G117
Headlight Microscope—Install (Labor Only).....		G102
Magnetic Trouble Lamp.....		G142
Pilot Ray Light—Install (Labor Only).....		G128
Spot Light—Lorraine—Install (Labor Only).....		G159
Saf-de-lites—Install (Labor Only).....		G203

MISCELLANEOUS SUPPLIES

Awning—Install Two—Enclosed Cars (Labor Only)		G107
Bonnet Louver Cover—Install (Labor Only)		G108
Bulb Box—Complete		G226
Chassis Lubricator Oil—1 Gallon Can		G113
Cowl Bands and Side Lamps—Supply and Install (Labor Only)	626 640	G156
De Luxe Equipment—Two Front Fenders With Wells, Two Side Wheel Carriers, Trunk Rack, Trunk, Cowl Band and Lamp or Fender Lamp —Install (Labor Only)		G148
Door Curtains—Silk—Install Two (Labor Only)		G112
Door Hinge Mirror—Install—Enclosed Cars (Labor Only)	626 640	G166
Fender Guards—Rear—Install (Labor Only)		G154
Fender Mirror—Install (Labor Only)		G168
Flower Vases—Each—Install (Labor Only)		G179
Golf Bag Holder—Install (Labor Only)		G137
Handy Andy Touch Up Black		G123
Hub Cap—Custom—Per Set—Install (Labor Only)		G138
Mirror—Double Vision—Install (Labor Only)		G142
Monogram—Door—Sterling Silver—Install (Labor Only)		G147
Monogram Emblem—Headlight Cross Tube—In- stall (Labor Only)		G111
Motor Oiler—Mo-toj—Install (Labor Only)		G201
Mo-top Oil—Supply		G212
Pedal Pads—Install (Labor Only)		G148
Toggle Clips—Install Pair (Labor Only)		G155
Window Eaves—Pair—Install (Labor Only)	626 640 711-740-810, 841-851-901	G141 G141
Window Wings—Closed Car—Install (Labor Only)		G146

AIR CLEANER		Symbol	Page	Zone I		
Carburetor Air Cleaner - Remove, Clean and Replace.....	901-901.....	M395	0.2	\$ 50.....		
Carburetor Air Cleaner - Renew.....	901-900.....	M396	0.2	6.95.....		
.....		
.....		
.....		
.....		
.....		
.....		
.....		
.....		
.....		
.....		
.....		
.....		
.....		
.....		
.....		
.....		
.....		
AMMETER						
Ammeter - Renew.....	B27	0.4	47 1.30.....		
.....		
.....		
.....		
.....		
.....		
.....		
AXLE, FRONT						
Front Axle - Check Caster, Camber and Toe-In.....	A382	1.2	1.65.....		
Front Axle - Renew.....	A38	2.0	13 41.70.....		
Front Axle - Remove, Disassemble and Replace.....	A40	5.8	23 12.40.....		
Front Axle - Remove, Straighten and Replace (Includes A40). Front axle should be replaced rather than straightened if sprung more than slight amount.....	A380	8.8	21 17.65.....		
Front Axle - Straighten (After A40).....	AA380	3.0	1.75.....		
Front Axle Spring Rubber Bumper - Renew One.....	A381	0.4	1.45.....		
.....		
.....		
.....		
.....		
.....		
.....		
.....		
AXLE, REAR						
Rear Axle Case Rear Cover - Renew.....	A330	0.6	18 5.65.....		
Rear Axle Case Rear Cover - Remove, Inspect Differential Gears and Replace.....	A337	1.2	20 7.85.....		
Rear Axle Case Rear Cover Gasket - Renew.....	A331	0.8	18 7.85.....		
Rear Axle Differential Unit - Remove, Disassemble— Inspect and Replace. This includes removing an Inspecting and replacing of axle shafts and bearings		
Rear Axle Shaft - Renew One (Includes A340).....	626-726-826-901..... 640-740-840-901.....	A350	12.2	21 24.95..... A41	2.0	14.45.....
.....	A41	2.0	23 15.55.....		
Rear Axle Shaft - Renew One (After A340).....	626-726-826-901..... 640-740-840-901.....	A341	1.2	12.70..... A341	1.2	13.80.....
.....	A341	1.2	17 10.45.....		
Rear Axle Shaft Bearing - Renew One Side	626..... 640-740-840-903.....	A324	2.0	17 11.65..... A324	2.0	17 15.60.....
.....	A324	2.0	17 15.60.....		
Rear Axle Shaft Bearing Jam Nut - Tighten (Includes A340).....	A354	1.6	20 3.50.....		
Rear Axle Shaft Bearing Jam Nut - Tighten (After A340).....	AA354	0.8	1.75.....		
Rear Axle Shaft Bearing Sleeve, Discwasher and Retainer - Renew (One Side) (Includes A340).....	626-726-826-903..... 640-740-840-901.....	A313	1.4	16 3.50..... A313	1.4	4.15.....
Rear Axle Shaft Bearing Sleeve, Discwasher and Retainer - Renew (One Side) (After A340).....	626-726-826-901..... 640-740-840-903.....	AA313	0.6	1.75..... AA313	0.6	2.40.....
Rear Axle Shaft Bearing Sleeve, Discwasher and Retainer - Renew (Both Sides) (Includes A313).....	626-726-826-901..... 640-740-840-901.....	A312	2.4	16 6.15..... A312	2.4	7.35.....

Part Description	Symbol	Page	Zone 1
BEARINGS—Cont'd			
Connecting Rod Bearing—Take Up Lower Caps— Rods Are Not Removed—Crankcase Lower Half Off.....	M59	6.4	154 513 10, ...
Connecting Rod Bearing—Renew One On Exchange Basis (Rods Out) (For Each Addi- tional Bearing Renewed Add Price of M514).....	M514	6.9	156 5 10, ...
Connecting Rod Bearing—Take Up One Lower Cap—Crankcase Lower Half Off (Add M520 for Each Cap Taken Up).....	M520	0.8	158 1.75, ...
Connecting Rod Bearings—Renew All On Exchange Basis (Rods Out).....	M516	6.0	157 18.50, ...
Differential Sleeve Bearing—Adjust.....	A414	1.2	2.65, ...
Front Wheel Bearings—Adjust Both.....	S221	0.5	273 1.40, ...
Generator Bearing—Renew (Includes E221) (Labor Only).....	E235	0.8	1.75, ...
Generator Bearing—Renew (After E221) (Labor Only).....	EH235	0.490, ...
Main Bearing Lower Caps—Remove for Inspection and Replace (Rods Out).....	M593	1.2	7.00, ...
Main Bearings—Renew All (Motor Kit).....	M585	21.5	81.35, ...
Main Bearings—Take Up—Crankcase Lower Half Off.....	M512	9.6	155 21.00, ...
Maintained Connecting Rod Bearings—Take Up (Rods Out), If New Connecting Rods Are Required, Add Price of Rods Only	M415	17.2	157 37.65, ...
Main Bearing—Center Renew (After M51).....	MM586	14.5	... 30.10, ...
Main Bearing—Front—Renew (After M51).....	MM584	14.5	... 30.85, ...
Main Bearing—Intermediate—Renew One (After M51).....	MM587	14.5	... 30.10, ...
(After M51) (After Motor Nos. 258513 and 174811).....	MM587	14.5	... 33.05, ...
Main Bearing—Rear—Renew (After M51).....	MM585	14.5	... 13.60, ...
(After M51) (After Motor Nos. 258513 and 174811).....	MM585	14.5	... 30.10, ...
Oil Test Oil Bearings—Lower Half Off.....	M76	0.5	198 1.75, ...
Rear Axle Shaft Bearing—Renew One Side.....	A324	2.0	17 10.45, ...
640-740-840-900.....	A324	2.0	17 11.65, ...
726-826-901.....	A324	2.0	... 15.60, ...
Rear Axle Shaft Bearings—Repack Both (After A310).....	A305	1.0	... 2.25, ...
Speedometer Driven Pinion and Shaft and Bearing —Renew.....	B57	1.2	... 8.05, ...
Starter Motor Center Bearing—Free Up—Off Car (Includes E331).....	E314	0.7	... 1.75, ...
Starter Motor Center Bearing—Free Up—Off Car (After E331).....	E6314	0.3	.90, ...
Steering Knuckle Bearings—Adjust Both.....	S119	2.6	222 6.30, ...
Steering Knuckle Inboard Bearing Cup, Cone and Rollers—Renew.....	S245	1.1	226 9.60, ...
Steering Knuckle Outboard Bearing Cup, Cone and Rollers—Renew.....	S246	0.8	226 7.00, ...
Steering Knuckle Pin Bearing—Lower Renew.....	S115	2.3	219 5.75, ...
Steering Knuckle Pin Bearing—Upper Renew One 625-10.....	S112	2.3	218 4.15, ...
726-826-740-840-900-905.....	S112	2.3	218 8.05, ...
Water Pump Bearing, Impeller and Shaft—Renew —Radiator Off.....	MH64	0.6	... 14.85, ...
726-750.....	MH65	0.6	... 18.20, ...
826-840-901-903.....	MH63	0.6	... 14.40, ...
Water Pump Impeller and Bearing— Renew—Radiator Off	M839	0.8	231 7.40, ...
726-826-740-840-900-903.....	MK839	0.8	231 6.15, ...

Part	Description	Symbol	Page	Zone 1
BOX--See Battery				
BRACKETS--See Body, Bonnet, Brakes, Fender, Gasoline, Motor, Muffler, Running Board, Springs or Tail Lamp				
BRAKES				
Brake Drum--Turn Down One, Wheel Off (For Each Axle) and Brake Drum Turned Down Add Operation A333)		A355	6.4	... 5.105...
Brake Drum Assembly--Front--Review One Wheel Off (Diesel Wheels) (For Each Additional Front Brake Drum Renewed Add Operation A311)		A511	0.4	10 45.15...
Brake Drum Assembly--Rear--Review One Wheel Off (Diesel Wheels) (For Each Additional Rear Brake Drum Renewed Add Operation A312)		A322	0.4	13 15...
Brake Shoe--Reline--Off Cae (Bendix Brakes) Using Molded Lining		A151	2.2	... 11.20...
Brake Shoe and Facing Assemblies--Front (For Each Renew One Set (Includes A110))		A17	3.2	10 20.00...
Brake Shoe and Facing Assemblies--Front or Rear (On One Wheel (After A348))		AA17	2.4	... 18.25...
Foot Brakes--Adjust (Includes Setting Cam Lever)		A11	1.5	3 3.50...
Foot Brakes--Adjust (Quick Service Adjustment)		A10	0.8	1.75...
Foot Brakes--For Up--Wheels Off		A103	1.9	... 3.85...
Foot Brakes--Fix Up and Adjust (Includes Removing and Replacing Wheels)		A19	3.2	11 7.00...
Foot Brakes--Reline Front and Adjust Rear--Using Molded Lining (Includes S251)		A122	6.0	... 14.60...
Foot Brakes--Reline Front and Adjust Rear--Using Molded Lining (After S251)		AA122	4.5	... 10.55...
Foot Brakes--Reline Rear and Adjust Front--Using Molded Lining (Includes A100)		A128	6.0	... 14.60...
Foot Brakes--Reline Rear and Adjust Front--Using Molded Lining (After A10)		AA128	4.3	... 11.10...
Foot Brakes--Reline and Adjust--Using Molded Lining (Includes A110)		A12	8.6	... 14.50...
Foot Brakes--Renew and Adjust--Using Molded Lining (After A310)		AA12	7.0	... 21.00...
Foot Brake Front Camshaft and Bracket--Right or Left--Renew One Side--Bendix Brakes (Includes S220) (Prior to Frame Nos. 172441 and 172444), (Includes S220) (After Frame Nos. 230021 and 172443)	620-640...	A127	2.0	... 12.90...
Foot Brake Front Camshaft and Bracket--Right or Left--Renew One Side--Bendix Brakes (After S220) (Prior to Frame Nos. 230021 and 172443)	620-640...	A127	2.0	... 9.50...
Foot Brake Front Camshaft and Bracket--Right or Left--Renew One Side--Bendix Brakes (After S220) (Prior to Frame Nos. 230021 and 172443)	620-640...	AA127	1.2	... 11.00...
Foot Brake Pedal Retracting Spring--Renew		AA127	1.2	... 7.60...
Front Axle Brake Caliper--Belt & Oil--Add Operation Air When Renewing Two Calipers		A448	0.2	... 1.50...
Front Axle Brake Operating Shaft Support Arm Bracket--Renew One Side--Kardan and Wheel Off		A36	0.8	14 5.10...
Front Axle Brake Support Plate--Renew One (Including S210) (Add Operation A31 When Renewing Two Plates)		A44	2.0	... 10.30...
Front Axle Brake Support Plate--Renew One (After S210)		AA44	1.2	... 8.40...
Front Axle Brake Support Plate--Renew One (After A318) (Add A314 For Each Plate Renewed)		AA442	2.0	... 10.15...
Front Axle Brake Support Plate--Renew One (Including S210) (Add Operation A31 When Renewing Two Plates)	
Front Axle Brake Support Plate--Renew One (After S210)	
Front Axle Brake Support Plate--Renew One (After A318) (Add A314 For Each Plate Renewed)	
Front Axle Brake Support Plate--Renew One (Including S210) (Add Operation A31 When Renewing Two Plates)	
Front Axle Brake Support Plate--Renew One (After S210)	
Front Axle Brake Support Plate--Renew One (After A318) (Add A314 For Each Plate Renewed)	

BUSHINGS—See Clutch, Oil Pump, Piston, Speedometer, Spring, Starter Motor, or Steering.

	Symbol	Page	Zone 1
CARBURETOR			
Carburetor—Adjust	M311	0.2	140 8.55
Carburetor—Clean and Adjust	M311	0.2	137 2.45
Carburetor—Remove, Disassemble, and Reassemble	M310	1.3	140 2.65
Carburetor Accelerator Pedal Shaft—Free Up	M331	0.4	... 2.40
Carburetor Accelerator Pump Plunger Assembly—Renew—40 Cu. (After Motor No. 250837)	M346	0.4	... 2.45
(After Motor No. 173112)	M346	0.4	... 2.70
Carburetor Accelerator Pump Assembly—Renew (Includes M310)	M346	1.7	... 7.25
	M346	1.7	... 8.20
Carburetor Accelerator Pump Assembly—Renew (After M310)	M346	0.4	... 4.10
	M346	0.4	... 4.45
Carburetor Accelerator Pump Body—Renew—(In Car) (After Motor No. 250837)	M350	0.4	... 3.30
(After Motor No. 173112)	M350	0.4	... 3.30
Carburetor Air Cleaner—Remove, Clean and Replace	M395	0.2	... 6.90
Carburetor Air Cleaner—Renew	M396	0.2	... 6.94
Carburetor Air Horn—Renew—On Car (After Motor No. 250837)	M314	0.2	... 3.40
(After Motor No. 173112)	M314	0.2	... 3.40
	M314	0.2	... 3.40
	M314	0.2	... 1.65
Carburetor Air Valve and Choke—Adjust for Hard Starting	M733	0.6	... 1.25
Carburetor Air Valve Piston—Renew (Includes M310)	M365	1.7	... 5.80
	M365	1.7	... 5.45
Carburetor Air Valve Piston—Renew (After M110)	MM365	0.4	... 1.45
	MM365	0.4	... 1.41
Carburetor Air Valve Spring—Renew (Includes M110) (After Motor No. 250837)	M344	1.7	... 4.50
(After Motor No. 173112)	M344	1.7	... 4.80
Carburetor Air Valve Spring—Renew (After M110) (After Motor No. 250837)	MM344	0.2	... 1.15
(After Motor No. 173112)	MM344	0.2	... 1.15
Carburetor Air Valve Stem Spring—Renew (Includes M310)	MM344-826-840-901-903	MM344	1.7 ... 4.60
Carburetor Air Valve Stem Spring—Renew (After M110)	MM344-826-840-901-903	MM344	0.295
Carburetor Aspirating Tube—Renew (Includes M110)	M364	1.7	... 5.20
	M364	1.7	... 5.65
Carburetor Aspirating Tube—Renew (After M110)	M364	0.4	... 1.55
	M364	0.4	... 2.00
Carburetor Assembly—Renew (Prior to Motor No. 250837)	M340	2.0	141 34.50
(Prior to Motor No. 173112)	M340	2.0	141 39.60
(After Motor No. 173112)	M340	2.0	141 28.80
(After Motor No. 173112)	M340	2.0	141 33.40
Carburetor Body—Renew (Includes M310) (Prior to Motor No. 250837)	M357	1.2	143 17.65
(Prior to Motor No. 173112)	M357	1.2	143 21.31
Carburetor Body—Renew (After M110) (Prior to Motor No. 250837)	MM357	0.5	... 14.00
(Prior to Motor No. 173112)	MM357	0.5	... 17.65
Carburetor Butterfly Valve—Renew (Includes M310) (After Motor No. 250837)	M358	1.7	... 4.80
(After Motor No. 173112)	M358	1.7	... 4.80
Carburetor butterfly Valve—Renew (After M110) (After Motor No. 250837)	MM358	0.4	... 1.15
(After Motor No. 173112)	MM358	0.4	... 1.15
Carburetor Choke—Adjust	M333	0.1	138 .90
Carburetor Economizer Lever—Renew—Off Car (After Motor No. 250837)	M359	0.6	... 1.80
(After Motor No. 173112)	M359	0.6	... 1.81
Carburetor Economizer Tube Assembly—Renew—On Car (After Motor No. 250837)	M343	0.4	... 1.15
(After Motor No. 173112)	M343	0.4	... 1.45
Carburetor Float—Renew—On Car (Prior to Motor No. 250837)	M345	0.2	141 1.20
(Prior to Motor No. 173112)	M345	0.2	141 1.20

CARBURETOR—Cont'd		Symbol	Page	Zone I
Carburetor Float Assembly—Review Includes M-10 (After Motor No. 140-1571) ...	624	M105	1-7	141
After Motor No. 173111, ...	625	M105	1-7	141
	726-740-821-840-871-120-1	M105	1-7	141
Carburetor Float Assembly—Review (After M-10) Prior Motor No. 240-1 ...	626	MM105	0-7	141
After Motor No. 173111, ...	627	MM105	0-7	141
	726-740-821-840-871-120-1	MM105	0-7	141
Carburetor Float—Review and Adjust Gas Level Includes M-10 (Prior to Motor No. 240-1) ...	628	M351	2-9	142
(Prior to Motor No. 173112) ...	629	M352	2-9	142
Carburetor Float—Review and Adjust Gas Level (After M-10) (Prior to Motor No. 240-1) ...	630	MM352	1-5	142
(Prior to Motor No. 173112) ...	649	MM352	1-5	142
Carburetor Float Chamber and Stabilizer Well— Review (On Car) (After Motor No. 140-1) ...	631	M345	0-7	142
(After Motor No. 173112) ...	632	M345	0-7	142
Carburetor Float Lever—Adjust — Carburetor		M313	1-6	141
Carburetor Idle Air-Adjusting Screw and Choke Assembly—Review (On Car) (After Motor No. 240-1) ...	629	M349	0-5	141
After Motor No. 173111, ...	630	M349	0-5	141
Carburetor Inlet Strainer Screen— Carburetor Off		M356	0-2	141
Carburetor Lower Half Assembly—Review Includes M-10 (After Motor No. 240-1) ...	626	M341	2-4	142
(After Motor No. 173112) ...	627	M341	2-4	142
Carburetor Lower Half Assembly— New w. (After M-10) (After Motor No. 240-1) ...	628	MM341	0-5	142
(After Motor No. 173112) ...	629	MM341	0-5	142
Carburetor Lower Half—Review (Includes M-10)	726-740-821-840-871-120-1	M340	1-2	142
Carburetor Lower Half—Review (Includes M-10)	726-740-821-840-871-120-1	MM340	1-2	142
Carburetor Lower Half Assembly— New w. (After M-10) (After Motor No. 240-1) ...	626	MM341	0-5	142
(After Motor No. 173112) ...	627	MM341	0-5	142
Carburetor Lower Housing— Review (Includes M-10) (After Motor No. 240-1) ...	628	M341	2-4	142
(After Motor No. 173112) ...	629	M341	2-4	142
Carburetor Lower Housing— Review (Includes M-10) (After Motor No. 240-1) ...	726-740-821-840-871-120-1	MM341	2-4	142
Carburetor Metering Pin Assembly—Review (Includes M-10) ...	626	M369	1-7	141
	726-740-821-840-871-120-1	M369	1-7	141
Carburetor Metering Pin Assembly—Review (After M-10) ...	627	MM369	1-4	141
	726-740-821-840-871-120-1	MM369	1-4	141
Carburetor Needle Valve and Seat Assembly— Review (Includes M-10) (After Motor No. 240-1) ...	628	M353	1-7	142
(After Motor No. 173112) ...	629	M353	1-7	142
Carburetor Needle Valve and Seat Assembly— Review (Includes M-10) (After Motor No. 240-1) (After Motor No. 173112) ...	630	MM353	0-4	142
	726-740-821-840-871-120-1	MM353	0-4	142
Carburetor Needle Valve and Seat— Review (Includes M-10) (Prior to Motor No. 240-1) (Prior to Motor No. 173112) ...	631	M353	1-7	142
	726-740-821-840-871-120-1	M353	1-7	142
Carburetor Needle Valve and Seat— Review (Includes M-10) (Prior to Motor No. 240-1) (Prior to Motor No. 173112) ...	632	MM353	0-4	142
	726-740-821-840-871-120-1	MM353	0-4	142
Carburetor Spray Nozzle and Hushing Assembly— Review (On Car) (After Motor No. 240-1) ...	626	M318	1-4	142
(After Motor No. 173111) ...	627	M318	1-4	142
	726-740-821-840-871-120-1	M318	1-4	142
Carburetor Spray Nozzle and Hushing Assembly— Review (On Car) (After Motor No. 173111) ...	628	M318	1-4	142
	726-740-821-840-871-120-1	M318	1-4	142
Carburetor Spray Nozzle Packing— Review (On Car) (After Motor No. 240-1) ...	629	M322	0-4	142
(After Motor No. 173112) ...	630	M323	0-4	142
Carburetor Spray Tube— Review (Includes M-10) ...	631	M354	1-7	142
(Prior to Motor No. 240-1) ...	632	M354	1-7	142
	726-740-821-840-871-120-1	M354	1-7	142
Carburetor Spray Tube— Review (After Motor No. 173112) ...	633	MM354	0-5	142
(Prior to Motor No. 240-1) ...	634	MM354	0-5	142
	726-740-821-840-871-120-1	MM354	0-5	142
Carburetor Stabilizer Rod Assembly— Review (Includes M-10) (After Motor No. 240-1) ...	625	M338	1-7	141
(After Motor No. 173112) ...	626	M338	1-7	141
Carburetor Strainer Housing Stand— Review (Includes M-10) ...	726-740-821-840-871-120-1	M351	0-4	141

CARRIER—See Differential or Wheels

**CASE—See Auto Rear, Battery, Body,
Differential, Steering, or Transmission**

CHAINS

Front End Sprockets and Chain—Renew (Includes M410)	M483	4.2	190	31.20
Front End Sprockets and Chain—Renew (After M410)	MM484	1.7	145	25.40
Timing Chain—Adjust	M46	0.2	145	.35
Timing Chain—Renew (Includes M410)	M412	3.9	147	16.65
Timing Chain—Renew (After M410)	MM412	1.3	145	10.85
Timing Chain—Take out Link (Includes M410)	M411	4.2	146	9.45
Timing Chain—Take out Link (After M410)	MM411	1.6	145	5.65

	Symbol	Page	Zone 1
CHANGE SPEED LEVYR—See Transmission			
CHOKE—See Carburetor			
CLAMPS—See Battery, Bonnet, Bumper, Distributor, Radiator, Steering, Thermo- stat or Water Pump			
CLEANING			
Wash and Polish Car (Open).....	G3	1.4	\$9
Wash and Polish Car (Closed).....	G3	1.8	\$9
Wash Motor—Using Power Washer.....	G3	0.9	\$9
Wash Motor and Transmission—Using Power Washer.....	G6	1.3	\$9
.....
.....
.....
.....
.....
.....
.....
.....
.....
CLIPS—See Springs			
CLOCK			
Clock—Renew (Or Exchange).....	B520	...	
.....
.....
.....
.....
.....
.....
.....
.....
.....
.....
CLUTCH			
Note: If car is equipped with radio or heater add time for removing and replacing same if nec- essary.			
Clutch—Remove for Inspection, Dismantle, Reassemble and Replace (Add Time for Remov- ing and Replacing Radio or Heater if Necessary).....	T10	6.2	214
Clutch Cover Plate Assy. (One Plate Clutch)— Renew—Clutch Out.....	626-726-826-901	0.4	14.45
(Two Plate Clutch).....	649	0.4	14.45
740-840-903	0.4	11.10	...
Clutch Driven Plates and Hub Assy. (One Plate Clutch)—Renew—Clutch Out.....	626-726-826-901	0.4	11.10
(Two Plate Clutch).....	640-740-840-901	0.4	18.70
Clutch Driven Plate and Pressure Plate—Renew —Clutch Out (One Plate Clutch)	626-726-826-901	0.4	19.00
(Two Plate Clutch)	649-740-840-901	0.4	26.50
Clutch Pedal—Adjust.....	TT11	0.2	233
Clutch Pedal Bushing—Renew.....	TT12	1.6	4.55
Clutch Shaft—Renew (After T110).....	TT13	0.4	16.80
Clutch Shaft Front Bearing—Renew— Clutch Out	TT13	0.4	215
Clutch Shaft Rear Bearing—Renew (After T110).....	TT14	0.4	6.65
Clutch Shifter Shaft—Renew.....	TT21	6.2	218
Clutch Shifter Thrust Bearing—Renew (After T110).....	TT217	0.4	5.95

		Symbol	Page	Zone 1
CONTACT ARM—See Distributor				
CORE—See Radiator				
COVER—See Axle Rear, Motor, Oil, Radiator, Springs, Steering, Transmission, Vacuum Tank, or Valves				
CRANKCASE				
Crankcase, Differential and Transmission Oil—Drain and Renew (Using Gear Oil).....	626-726-826-901 640-740-840-903	L133 L133	111 111
(Using Whitmore's Compound in Differential Only).....	626-726-826-901 640-740-840-903	L133 L133	111 111
Crankcase Lower Half—Renew.....	626-726-826-901 640-740-840-903	M51 M51	2.4 2.4	153 153 \$32.70 35.95
Crankcase Lower Half—Remove for Inspection and Replace.....	626-726-826-901 640-740-840-903	M510 M510	2.0 2.0	155 155 7.00 7.50
Crankcase Lower Half—Remove, Make Oil Test, Report Condition of Bearings and Replace.....	M512	4.1	155 9.35
Crankcase Mud Guards—Tighten Both.....	M513	0.4	154 1.15
Crankcase Mud Guard—Front—Remove and Replace.....	M514	0.5	1.25
Crankcase Mud Guard—Right or Left—Renew.....	626-726-826-901 640-740-840-903	M513 M513	1.1 1.1	111 4.75 5.10
Crankcase Oil—Drain and Renew.....	626-726-826-901 640-740-840-903	L1 L1	111 111	97 97
Crankcase Oil—Level (Material Only).....	M507	0.0	1.75
Crankcase Oil Gauge—Drain Oil and Check Gauge for Correct Reading.....	M508	0.5	1.25
Crankcase Oil Gauge Glass—Remove, Clean and Replace.....	M509	0.0	1.75
Crankcase, Transmission and Differential Oil—Bring to Level.....	M511	1.1	111
Crankcase Upper Half—Renew (Includes M051) This Operation Includes Taking Up All Bearings and Carbon Valve Job.....	626-726-826-901 640-740-840-903	M514 M514	63.0 63.0	379.35 390.35
Crankcase Upper Half—Renew (After M051).....	626-726-826-901 640-740-840-903	MM514 MM514	34.2 34.2	313.55 324.55
Crankcase Upper Half—Renew—On Exchange Basis (Labor Only). If Other Work Is Required Use Suitable Incomplete Operation.....	626-726-826-901 640-740-840-903	M517	28.0	61.25
CRANKSHAFT				
Crankshaft—Renew (Includes M051) (Includes Re-Setting Bearings).....	626-726-826-901 640-740-840-903	M506 M506	63.0 63.0	269.30 280.30
Crankshaft—Renew (After M051).....	626-726-826-901 640-740-840-903	MM506 MM506	34.2 34.2	203.50 214.50
Crankshaft Crank Pins—Turn Down All and Install (.015") Underpin Connecting Rods (On Exchange Basis) Rods Out (Labor Only).....	M576	10.9	13.30

CROSS TUBES—See Frame or Steering

CUSHION

Cushion—Front or Rear—Renew Plait (Labor Only).....	B339
Cushion—Front or Rear—Rebuild—Touring Car (New Springs \$6.00 Extra).....	B331
Cushion—Large—Recover with New Material— Touring Car (Labor Only).....	B332
Cushion—Small—Recover with New Material— Coupe (Labor Only).....	B333
Cushion—Small—Rebuild (Labor Only).....	B334
Cushion Retainer—Recover One—Large— Touring Car (Labor Only).....	B344
Sedan (Labor Only).....	B344
Cushion Retainer—Recover One—Small— Touring Car (Labor Only).....	B345
Sedan (Labor Only).....	B345
Driver's Seat Back—Rebuild—Coupe (Labor Only).....	B338
Front Seat Back—Rebuild—Touring, Roadster, Sedan (Labor Only).....	B337
Make Up Back Rest Cushion (Labor Only).....	B359
Rear Seat Back—Rebuild (Labor Only).....	B336
Seat Back—Renew Plait (Labor Only).....	B338

STANDARD SERVICE

165

STANDARD SERVICE

148

PISTRIEUTOR

Distributor Condenser—Review One.....	E14	0.4	42	2.90.....
Distributor Condenser --Remove—Test and Replace.....	E108	0.6	...	1.05....
Distributor Contact Arm Assembly and Adjusting Screw—Review One Set.....	E11	0.3	11	3.45.....

BOOKS

Door—Upper Half—Metal Work—Renew (Labor Only).....	B678	9.8	...	21.35
Door Glass—Rattle in Runway—Eliminate All.....	B679	1.8	...	3.85
Door Check Strap—Either Type—Renew One (Labor Only).....	B681	1.1	...	2.45
Door—Line Up One—Renew Bumpers and Strikers (Labor Only).....	B684	1.2	...	2.65
Door—Line Up All—Renew Bumpers and Strikers (Labor Only).....	B685	4.0	...	8.75
Door Glass—Front or Rear—Renew (Labor Only).....	B683	1.2	37	2.65
Door Glass Lower Weatherstrip Rubber—Renew on One Door.....	B611	0.8	...	2.10
Door Glass Lower Weatherstrip Rubber—Renew on Two Doors.....	B612	1.6	...	4.20
Door Glass Lower Weatherstrip Rubber—Renew on Four Doors.....	B613	3.3	...	8.40
Door Handle—Free Up One.....	B678	0.355
Door Hinge—Renew Three—Closed Body (Labor Only)—Used in Case of Accident Only.....	B655			
Door Hinge Pin—Renew Three (Oversize).....	626-640			
Door Hinge Pin Bushings—Renew on One Door.....	B677	1.6	...	3.85
Door Hinge—Renew One Upper or Lower—Open Body (Labor Only).....	B654	0.6	...	2.00
Door Hinge—Renew One Upper or Lower (Closed Body) (Labor Only).....	B646	0.7	...	1.60
Door Lock Lever Handle—Renew One—Open and Closed Body (Labor Only).....	B667	0.7	...	1.60
Door Lock Outside Handle—Renew One (Labor Only).....	B668	0.390
Door Lock—Renew One—Open and Closed Body (Labor Only).....	B669	0.255
Door Lock Striker—Renew One.....	B676	1.5	...	3.15
Door Moulding—Renew One (Labor Only).....	B62	0.8	37	2.50
Door Pull-to Handle—Supply and Attach (Labor Only).....	B672	0.6	...	1.75
Door Rattle—Eliminate—One Door.....	B676	0.7	...	1.60
Door Rubber Bumper—Renew One Door (Labor Only).....	B674	0.6	...	1.75
Door Rubber Bumper—Renew All Doors (Labor Only).....	B660	0.690
Door Rubber Bumper—Shim Out—One Door (Labor Only).....	B661	1.0	...	2.10
Door Rubber Bumper—Shim Out—All Doors (Labor Only).....	B662	0.690
Head Lamp Door and Glass Assy.—Renew.....	626-640-641-716-826-901	B668	1.3	...
	740-715-840-845-903-904	B649	0.5	...
		B649	0.5	...

STANDARD SERVICE

九

DRAIN CREEK—See Radiator

DRUMS—See Broken, Foot Broken or Wheats.

DUST WASHER—See Auto Body, Bedding, Transportation or Wheels.

	Symbol	Page	Zone 1
ELECTRICAL SYSTEM			
Battery—See Battery.			
Check Lighting System—Lights—Horn, etc.	E101	0.1	\$.20
Distributing—See Distributor.			
Electrical System—Inspection	E130	0.2	1.75
Electrical Wiring Left Assembly—Renew	E103	6.0	23.25
Electrical Wiring Right Assembly—Renew	E102	1.0	5.90
Generator—See Generator.			
Horn—See Horn.			
Ignition Coil—See Ignition.			
Ignition Timing—See Ignition.			
Lamps—See Head Lamps or Tail Lamp.			
Spark Plugs—See Spark Plugs.			
Starter Motor—See Starter Motor.			
Switch—See Switch.			
Wires—See Wires.			
EXHAUST			
Exhaust Expansion Chamber—Renew	826	34971	0.8
	840	34971	0.8
Exhaust Heater (Francisco)—Remove and Replace		34955	0.8
Exhaust Manifold—Renew and Replace	626-726-640-740	34951	2.0
	826-840-901-901	34951	1.6
Exhaust Manifold—Renew	626-726-640-740	3498	2.0
	826-840	3498	1.6
Exhaust and Intake Manifold Assembly—Complete—Renew	901-903	3498	1.6
Exhaust Manifold Gaskets—Renew All	646-640-726-740	3491	2.0
	826-840-901-901	3491	1.6
Exhaust Muffler Assembly—Renew	903-904	3492	2.4
Exhaust Muffler Brackets—Tighten		34978	0.4
Exhaust Muffler Outlet Pipe Assembly—Renew	626-726-826	34977	0.8
	640-740-843	34977	0.8
	901-903	34977	0.8
Exhaust Pipe—Renew	626-726-826-840-901-903	3490	1.0
	640-740	3490	1.0
Exhaust Pipe—Weld at Flange		3492	1.5
Exhaust Pipe to Manifold Gasket—Renew		3494	0.7

		Symbol	Page	Zone 1
BAN				
Fan--Renew (Radiator Off)	626-726-826-901	M811	0.2	206 \$ 3.85
Fan Belt--Renew (Baked Leather Belt) (Not Removing Radiator)	640-740-840-903	M811	0.2	206 4.95
(Rubber Belt) (Removing Radiator--New Style Tension)	626	M812	0.5	206 4.25
(Rubber Belt) (Not Removing Radiator)	640	M812	1.1	206 5.75
(Rubber) (Double Belt) (Not Removing Radiator)	640	M812	0.8	206 5.40
Fan Belt--Rubber--Renew--Radiator Off Two Belts	726-826-901	M809	0.2	206 3.45
Fan Belt--Lighten	740-840-903	M817	0.3	206 2.70
Fender				
Front Fender--Straighten on Car (Slight)--Estimate Time	626	P46
Front Fender--Straighten on Car (Bad) - Estimate Time	626	P47
Front Fender--Left--Renew (Without Wells)	626 640-645-726-826	P41	3.3	81 40.75
	740-745-840-945	P41	3.3	81 46.25
	901-902	P41	4.0	81 42.50
	903-904	P41	4.0	81 48.00
	901-902-903-904	P41	3.3	83 55.15
	626 726-826-901	P42	4.0	81 56.90
	640-645-740-745-940- 945-901-904	P42	4.0	81 42.50
		P42	4.0	83 48.00
		P42	4.0	83 56.90
Front Fender--Right--Remove and Replace	626-726-740-826-940	P43	4.0	83 9.00
Front Fender--Left--Remove and Replace	901-902-903-904	P44	3.3	84 7.25
Front Fender--Renew--Copper Only	626-726-826-901	P45	0.8	83 4.05
Front Fender--Renew--Linen on Car	626-726-826-901	P430	0.8	83 1.75
Front Fender--Lang--Right or Left--Renew One (Labor Only)	726-826-901 740-840-903 745-845-903	P467	0.5	...
Front Fender Tool Box--Renew--Under Off	745-845-903	P447	0.5	...
Rear Fender--Remove and Replace One	901-902-903-904	P416	0.5	...
Rear Fender--Renew One--Touring, Phaeton, Sedan, Sedan Limousine	626-726-826-901 640-740-840-901 645-745	P119	1.9	62 4.10
Rear Fender--Renew One--Sedan, Sedan Limousine	645-904	P111	2.2	62 22.80
Rear Fender--Renew One--Roadster	626-726-826-901 640-740-840-901	P111	2.0	62 25.75
Rear Fender--Renew One--Coupe, Club Sedan	645-745	P111	2.0	62 12.15
Rear Fender--Renew One--Coupé, Club Sedan	626-726-826-901 640-740-840-901	P111	2.2	62 24.35
Rear Fender--Straighten and Touch Up on Car (Slight) (Labor Only) (Estimate Time)	645-745	P119	2.2	62 30.30

	Symbol	Page	Zone 1
FENDERs - Cont'd			
Rear Fender—Straighten and Touch Up on Car (Ball) (Labor Only) (Estimate Time).....	P119
FLOATS- See Carburetor, Crankcase, Oil or Vacuum Tank			
FLOOR BOARDS			
Toe Board—Remove and Replace.....	B640	12	3 1.65.....
Toe Board—Inclined—Renew (Labor Only).....	B647	12	3.65.....
Toe Board—Inclined—Tighten (Labor Gratis).....	B649
FLYWHEEL			
Flywheel—Renew on Exchange Base.....	M547	12.0	29.25.....
Flywheel—Vibration Damper—Remove for Inspection and Replace.....	M426	2.0	4.40.....
Flywheel Vibration Damper—Renew.....	M415	2.2	4.40.....
640.....	M415	2.2	21.80.....
Flywheel Vibration Damper—Free Up and Adjust —Radiator Hif.....	M417	0.8	1.75.....
Rear Camshaft Bearing Leak Repair or Flywheel— Renew and Replace.....	M548	12.0	25.10.....
FOOT BRAKES			
Foot Brakes—Adjust (Includes Sorting Gear Levers).....	A11	1.5	5 3.50.....
Foot Brakes—Adjust—Quick Service Adjustment.....	A19	0.8	1.75.....
Foot Brakes—Free Up—Wheels Off.....	A103	1.9	3.85.....
Foot Brakes—Free Up and Adjust (Includes Removing and Replacing Wheels).....	A19	3.2	7.00.....
Foot Brakes—Reline Front and Adjust Rear— Using Molded Lining (Includes S251).....	A122	6.0	14.60.....
Foot Brakes—Reline Front and Adjust Rear— Using Molded Lining (After S251).....	AA122	4.3	10.95.....
Foot Brakes—Reline Rear and Adjust Front— Using Molded Lining (Includes A310).....	A128	6.0	14.60.....
Foot Brakes—Reline Rear and Adjust Front— Using Molded Lining (After A310).....	AA128	4.3	11.10.....

STANDARD SERVICE

5

FRONT COVER—Stan Meyer

BUSS

Generator Fuse—Renew—Material Only	E312	...	10.
Lighting Circuit Fuse—Renew—Material Only	E186	...	10.
Lighting Circuit Fuse Assembly—Renew	E187	0.3	1.75
	E187	0.3	2.30

STANDARD SERVICE

Footer

	Symbol	Page	Zone 1
GASKET —See Axle Rear, Crankcase, Cylinder, Exhaust, Gasoline, Ignition, Motor, Radiator, Spark Plug, Thermostat, Transmission, Vacuum Tank, Valve or Water Pump			
GASOLINE			
Gasoline Gauge—Fill with Liquid (Labor Only)....	M329	0.5	\$ 1.35....
Gasoline Gauge—Renew.....	M330	0.6	5.25....
Gasoline Gauge Tube—From Tank to Gauge— Renew.....	M3281	1.8	5.85....
Gasoline Line—Blow Out.....	M3273	0.3	.90....
Gasoline Line and Gauge—Inspect for Correct Reading.....			
Gasoline Pump—Renew and Replace.....	M3273	0.8	1.75....
Gasoline Pump—Remove, Disassemble for Inspec- tion, Test Clean, Reassemble and Replace.....	M3271	0.3	.70....
Gasoline Pump Operating Plunger—Renew—Front Cover Off.....	M3270	0.6	1.40....
Gasoline Mileage Test—Make and Report.....	M3271	0.1	.90....
Gasoline Supply Tube to Vacuum Tank—Renew (Labor Only).....	M3272	0.1	.90....
Gasoline Tank—Clean Out.....	M326	1.6	3.50....
Gasoline Tank—Clean Out and Adjust Gauge.....	M3276	1.7	4.40....
Gasoline Tank—Renew.....	M327	0.8	2.10....
Gasoline Tank Bracket—Tighten to Frame.....	M327	1.1	2.45....
Gasoline Tank Filler Cap Gasket—Renew.....	M327	2.1	29.20....
Gasoline Tank Gauge Unit—Renew.....	M327	2.1	31.90....
Gasoline Tank, Lines, Carburetor and Vacuum Tank or Gasoline Pump—Clean Out (Old and New Type Carburetor).....	M327	1.2	27.95....
Gasoline Vacuum Tank—Remove, Clean Out and Replace.....	M329	1.9	6.65....
Gasoline Vacuum Tank—Renew.....	M341	1.0	3.30....
Gasoline Vacuum Tank Cover Gasket—Renew.....	M326	0.6	18.75....
Gasoline Vacuum Tank Float and Cover Assembly —Renew.....	M326	0.8	19.45....
Gasoline Vacuum Tank Screen—Clean.....	M326	0.3	.85....
GAUGE—See Crankcase, Gasoline or Oil			
GEARS —See Differential, Oil Pump, Speedo- meter, Steering or Transmission			
GENERATOR			
Generator—Inspect (Off Car).....	E221	0.4	.90....
Generator—Recondition (Includes E220 and E221) (Labor Only).....	E214	2.1	6.75....
Generator—Recondition (After E220 and E221) (Labor Only).....	E214	1.2	3.65....
Generator—Remove and Replace.....	E220	0.5	1.35....
Generator—Renew (Dymeto) (Labor Only).....	E21	0.9	2.10....
Generator—Adjust Voltage Regulator and Charg- ing Rate.....	E23	0.5	1.05....

		Symbol	Page	Zone 1
GENERATOR—Cont'd				
Generator and Starter Motor Oil		L15		
Generator Armature—Renew (Includes E221) (After E221)		E230	0.8	\$19.85
Generator Armature, Fields and Brushes—Renew (Includes E221) (After E221)		EE230	0.4	12.95
Generator Brushes—Renew All (Includes E221) (After E221)		E232	0.8	27.65
Generator Brushes—Renew All (Includes E221) (After E221)		E232	0.4	26.75
Generator Brushes—Renew All (Includes E221) (After E221)		E234	0.8	3.65
Generator Brushes—Renew All (Includes E221) (After E221)		E234	0.4	2.75
Generator Brushes and Spring Holders—Renew All (Includes E221) (After E221)		E235	0.8	5.40
Generator Brushes and Spring Holders—Renew All (Includes E221) (After E221)		EE235	0.4	4.50
Generator Bearing—Renew (Includes E221) (Labor Only) (After E221) (Labor Only)		E235	0.8	1.75
Generator Commutator—Face Off and Renew Brushes Off Car (Includes E221)		EE235	0.4	.50
Generator Commutator—Face Off and Renew Brushes Off Car (After E221)		E211	1.2	4.70
Generator Cut Out Assembly—Renew (Dyneto—Type CD777)	616-640...	E26	0.8	47
Dyneto—Type CD840	616-640-726-740	E26	0.8	9.25
Dyneto—Type CD746	616-840-501-901	E26	0.8	9.25
Generator Facile—Renew (Includes E221) (After E221)		E215	0.8	7.85
Generator Fuse—Renew—Material Only		RR215	0.4	6.15
Generator Sprocket Support—Renew—Cover Only		E212		.10
Generator Sprocket Support—Renew—Cover Only		M486	0.8	151
				8.80

GLASS—See **Curtains**, **Door**, **Head Lamp**, **Running Board**, **Speedometer**, **Spot Light**, **Stop Light**, **Tail Lamp**, **Window Glass** or **Windshield**.

STANDARD SERVICE

104

	Symbol	Page	Zone 1
IGNITION			
Ignition—Set Standard and Check Automatic Advance	E39	0.6	45 \$ 1.40.....
Ignition and Valve Retain (When Chain Has Jumped) Without Removing Front Cover—Removing Generator	M124	1.2	11 1.65.....
Ignition Coil—Renew One (Labor Only)	E53	0.4	11 5.90.....
Ignition Coil—Remove, Test and Replace	E104	0.4	11 .90.....
Ignition High Tension Wire—Renew All	E16	1.2	42 6.75.....
Ignition Spark Plug—Clean and Adjust	E19	0.3	43 .70.....
Ignition Spark Plug—Renew One (Material Only)	E120	...	75.....
Ignition Spark Plug—Renew All (Material Only)	E121	...	6.00.....
Ignition Switch—Renew—Lose Coils (Labor Only)	E22	0.4	46 .90.....
Ignition Switch—Repair (Labor Only)	E29	0.6	12.25.....
Ignition Switch Lock—Make Operate	E117	0.4	11 .90.....
Ignition Timing—Set Standard	E114	0.4	44 .90.....
INSTRUMENT BOARD			
Instrument Board—Renew (Labor Only)	E604	6.0	11 12.35.....
Instrument Board—Renew—Body Od (Labor Only)	E605	4.0	11 9.75.....
Instrument Board Cigar Lighter—Renew (Labor Only)	E456	0.3	11 .90.....
Instrument Board Cigar Lighter Heater Tip—Renew (Material Only)	E459	...	1.40.....
Instrument Board Light—Renew (Labor Only)	E451	0.6	11 1.40.....
Instruments Board Light Multi—Renew (Material Only)	E456	0.1	11 .15.....
Instrument Board Motor Thermometer—Standard—Renew	E454	0.4	11 7.30.....
INTAKE MANIFOLD			
Motor Intake Manifold—Renew and Replace	S26-840-901-204	...	M390 2.0 .. 4.90.....
Motor Intake Manifold—Renew	S26-840-901-901	...	M391 2.0 .. 24.70.....
Motor Intake Manifold—Weird Broken Base	S26-840-901-314	...	M392 2.0 .. 7.00.....
Motor Intake Manifold Gasket—Renew All	S26-840-901-905	...	M393 2.0 .. 4.90.....
Motor Intake Manifold Gaskets—Renew All—Block (id.)	S26-840-901-903	...	M394 1.8 .. 2.80.....

	Symbol	Page	Zone I
KEY—See Axle—Rear			
KNuckle—See Steering			

packardinfo.com

STANDARD SERVICE

Index

STANDARD SERVICE

Index

MANIFOLD—See Exhaust or Intake	Symbol	Page	Zone I
MATS—See Accessories—Tourneau Mats			
MOTOR			
Clean Carbon—Gated Valves and Tune Motor— Head Oil—Carburetor Air Cleaner	626-726-826-901	M20	4.4
640-740-840-901	M20	5.0	121
Clean Carbon—Gated Valves and Tune Motor— Includes Retaining Liquids and Cleaning Air Cleaner. If new breaker points or spark plugs are required, add the price of breaker point or spark plugs only	626-726-826-901	M24	7.0
640-740-840-901	M24	7.4	124
.	M652	17.8	116
Motor—Inspection—Includes Washing Motor	M8	16.0
Motor—Remove and Replace—Includes Washing Motor	M051	28.8
Motor—Remove, Disassemble for Inspection and Reassembly—Includes Washing Motor	M051	35.75
Motor—Retain Valves and Ignition (When Chain Has Jumped)—Without Removing Front Cover —Removing Generator	M124	1.2
Motor—Tune and Combination Tightening—If new breaker points or spark plugs are required, add the price of breaker points or spark plugs only—Clean Air Cleaner	M11	2.2
Motor—Tune (See also Floor Tune Up)—If new breaker points or spark plugs are required, add the price of breaker points or spark plugs only —Clean Air Cleaner	M13	1.4
Motor Compression—Test	M17	0.5
Motor Front Cover—Remove for Inspection and Replace	M410	1.6
Motor Front Cover—Renew (After M410)	M442	0.6
Motor Piston Lubricator—Adjust	M714	0.4
Motor Piston Lubricator—Eliminate Leak at Flood Valve	M716	1.5
Motor Piston Lubricator Control Valve—Renew	626-640-726-740	M712	1.6
Motor Piston Lubricator Control Valve and Body Assembly—Renew	M711	1.7
Motor Support and Motor to Frame Bolt— Tighten	M117	0.5
Motor Thermometer—Instrument Repair— Standard—Renew	E454	0.4
Motor Vacuum Pump Ball Check—Renew (Labor Only)	726-740	M118	0.2
Motor Vacuum Pump Connecting Rod—Renew (Labor Only)—Front Cover Is Not Removed	726-740	M112	0.6
Motor Vacuum Pump Cylinder and Piston—Re- move, Disassemble for Inspection and Replace— Front Cover Is Not Removed	726-740	M110	0.6
Motor Vacuum Pump Cylinder and Piston Assem- bly—Renew (Labor Only)—Front Cover Is Not Removed	726-740	M111	0.6
Starter Motor—Inspect Off Car	K51	0.4	
Starter Motor—Recondition—Off Car (Includes E311) (Labor Only)	E348	2.0	
Starter Motor—Recondition—Off Car (After E311) (Labor Only)	E234H	1.6	
Starter Motor—Renew (Off Car) (Labor Only)	E32	0.1	
E234H	E32	0.1	
E348	E32	0.1	
Starter Motor to Starter Switch Cable Assembly— Renew (Labor Only)	E34	0.4	
Starter Motor—Renew and (Off Car)	E330	0.2	
Starter Motor Armature—Renew (Includes E311)	E320	0.8	
626-726-826-901	E320	0.8	
640-740-840-901	E320	0.8	
626-726-826-901	E320	0.4	
640-740-840-901	E320	0.4	
Starter Motor Armature Shaft—Straighten (Includes E311)	E323	1.2	
Starter Motor Armature Shaft—Straighten (After E311)	E332	0.8	
Starter Motor Armature and Fields—Renew (Includes E311)	E325	0.8	
Starter Motor Armature and Fields—Renew (After E311)	E2325	0.4	
626-726-826-901	E325	0.4	
640-740-840-901	E325	0.4	

	Symbol	Page	Zone 1	
MOTOR—Cont'd				
Starter Motor Bendix Drive Shaft and Gear Assembly—Renew (Includes E331).....	E312	0.8	\$ 8.60...	
Starter Motor Bendix Drive Shaft and Gear Assembly—Renew (After E331).....	E3313	0.4	2.70...	
Starter Motor Bendix Spring—Renew.....	E32H	0.5	1.90...	
Starter Motor Bendix Support Bushing (Large)—Renew (Includes E331).....	626-726-826-901 640-740-840-903.....	E326	0.8	2.15...
Starter Motor Bendix Support Bushing (Large)—Renew (After E331).....	626-726-826-901 640-740-840-903.....	E326	0.6	1.25...
Starter Motor Brushes—Renew (Includes E331).....	E322	0.8	2.95...	
Starter Motor Brushes—Renew (After E331).....	E3312	0.4	1.05...	
Starter Motor Brushes and Brush Springs—Renew (Includes E331).....	E323	0.8	3.15...	
Starter Motor Brushes and Brush Springs—Renew (After E331).....	E3323	0.4	1.25...	
Starter Motor Center Bearing—Free Up—Off Car (Includes E331).....	E314	0.7	1.75...	
Starter Motor Center Bearing—Free Up—Off Car (After E331).....	E3314	0.3	.90...	
Starter Motor Clutch—Remove, Inspect and Replace (Includes E330).....	E417	0.6	1.35...	
Starter Motor Clutch—Remove, Inspect and Replace (After E330).....	E3317	0.4	1.00...	
Starter Motor Commutator—Face Off and Renew Brushes—Off Car (Includes E331).....	E311	1.2	\$1 1.95...	
Starter Motor Commutator—Face Off and Renew Brushes—Off Car (After E331).....	E3311	0.8	1.05...	
Starter Motor Drive Spring Screws—Renew (Includes E331).....	E327	0.7	1.80...	
Starter Motor Drive Spring Screws—Renew (After E331).....	E3327	0.1	.90...	
Starter Motor Fields—Renew (Includes E331).....	626-726-826-901 640-740-840-903.....	E324	0.8	6.85...
Starter Motor Fields—Renew (After E331).....	626-726-826-901 640-740-840-903.....	E3324	0.4	3.95...
Starter Motor Switch—Renew.....	E324	0.4	7.45...	
Starter Motor Switch to Junction Box Cable Assembly—Renew (Labor Only).....	E54	0.8	1.75...	
Wash Motor—Using Power Washer.....	C3	0.9	1.75...	
Wash Motor and Transmission—Using Power Washer.....	C6	1.3	2.45...	

STANDARD SERVICE

Index

		Symbol	Page	Zone 1
OIL				
Check Lubrication in Steering Case, Transmission, Differential, Universal Joints, and Four Wheel Drive and Review Using Gear Oil ...	626-726-826-901 640-740-840-901	L123 L123
(Using Whitmore's Compound in Differential Only) ...	626-726-826-901 640-740-840-901	L123 L123
Crankcase Lever Multi-Remove, Stake Oil Test, Report Condition of Bearings and Replace ...	626-726-826-901 640-740-840-901	M552 L10	4.1 ...	\$ 4.45 ...
Crankcase Oil Drain and Review ...	626-726-826-901 640-740-840-901	1.1 1.1	92 97	...
Crankcase Oil Level (Material Only) ...	626-726-826-901 640-740-840-901	L10
Crankcase Oil Gauge—Drain Oil and Check Gauge for Correct Reading ...	626-726-826-901 640-740-840-901	M552	0.6	...
Crankcase Oil Gauge Glass—Remove, Clean and Replace ...	626-726-826-901 640-740-840-901	M556	0.6	1.75 ...
Crankcase, Transmission and Differential Oil—Bring to Level ...	626-726-826-901 640-740-840-901	L121
Differential Oil—Drain and Review (Using Gear Oil) ...	626-726-826-901 640-740-840-901	1.3 1.3	97 97	...
(Using Whitmore's Compound) ...	626-726-826-901 640-740-840-901	L123
Differential Oil—Oil to Level ...	626-726-826-901 640-740-840-901	L123
Differential Oil—Thin for Winter Use				
(Using Gear Oil) ...	626-726-826-901 640-740-840-901	2.33 2.33	103 103	...
(Using Whitmore's Compound) ...	626-726-826-901 640-740-840-901	L23
Differential and Transmission Oil—Drain and Review Using Gear Oil				
(Using Whitmore's Compound in Differential Only) ...	626-726-826-901 640-740-840-901	L23	...	101
Differential and Transmission Oil—Drain and Review Using Gear Oil ...	626-726-826-901 640-740-840-901	L231	...	101
Differential and Transmission Oil—Top for Winter Use (Using Gear Oil) ...	626-726-826-901 640-740-840-901	L32	...	103
(Using Whitmore's Compound in Differential Only) ...	626-726-826-901 640-740-840-901	L32	...	103
Distributor Head—Repacking ...	626-726-826-901 640-740-840-901	1.9
Generator and Starter Motor—Oil ...	626-726-826-901 640-740-840-901	1.15
Hub Caps—Replace ...	626-726-826-901 640-740-840-901	1.97	...	102
Lubricator Lubricator, LHM ...	626-726-826-901 640-740-840-901	1.4
Lubricator Oil Tank—Remove ...	626-726-826-901 640-740-840-901	1.43	0.5	103
Lubricator Oil Tank—Replace ...	626-726-826-901 640-740-840-901	1.43	0.5	103
Lubricator Oil Tank—Top (Material Only) ...	626-726-826-901 640-740-840-901	1.44
Lubricating Oil—Tubes—Pencil at Connections Using Electric Soldering Iron ...	626-726-826-901 640-740-840-901	L47	0.8	...
Miscellaneous Oil—Door Hinges, Linkage, Spark Plugs, Brake Pedal and Clutch Lever ...	626-726-826-901 640-740-840-901	1.14
"Mo-Pop" Oil—Oil, Material and ...	626-726-826-901 640-740-840-901	1.49
Oiling Operation—50 Miles ...	626-726-826-901 640-740-840-901	1.01	...	87
Oiling Operation—10,000 Miles ...	626-726-826-901 640-740-840-901	1.02	...	87
Oiling Operation—500 Miles and 100 Miles Between Oil Changes in Differential Oils ...	626-726-826-901 640-740-840-901	1.03	...	88
Oiling Operation—10,000 Miles (Includes Repacking Rear Axle Shift Housing) Using Gear Oil ...	626-726-826-901 640-740-840-901	1.03	...	88
Oil System, Rear Axle Shift Housing (Using Gear Oil), Add 0.3 Hour for Cars Having Wire Wheels. Note: The cooling system should be flushed every 10,000 miles. This operation should be sold with lubrication unless it has recently been flushed ...	626-726-826-901 640-740-840-901	1.04	...	89
(Using Whitmore's Compound in Differential Only, Add 0.3 Hour for Cars Having Wire Wheels) ...	626-726-826-901 640-740-840-901	1.04	...	89
Oiling Operation—10,000 Miles (Less Repacking Rear Axle Shift Housing) Using Gear Oil, Note: The cooling system should be flushed every 10,000 miles. This operation should be sold with lubrication unless it has recently been flushed ...	626-726-826-901 640-740-840-901	1.04	...	89
(Using Whitmore's Compound in Differential Only) ...	626-726-826-901 640-740-840-901	1.04	...	89

		Symbol	Page	Zone 1
OIL—Cont'd				
Oil Pressure—Adjust—Use Old Oil.....	...	M724	0.8	...
Oil Pressure Gauge—Renew.....	...	M722	0.4	197 2.35.....
Oil Pump—Recondition (Labor Only) (After M710).....	...	MM7209	0.8	...
Oil Pump—Remove, Dismantle, Clean and Replace—Not Removing Lower Half.....	626-726-826-901 640-740-840-903	M718 M719	1.2 1.2	198 4.70..... 198 5.20.....
Oil Pump—Remove, Dismantle, Clean and Replace—Lower Half Off.....	...	M715	0.8	...
Oil Pump Assembly—Renew—Not Removing Lower Half.....	...	M724	1.2	...
Oil Pump Gear—Renew (After M710).....	626-726-826-901	MM7205	0.8	4.30.....
Oil Purulator Cartridge—Renew.....	640-740-840-903	L46	0.4	4.00.....
Oil Seal no Bearing—Lower Half Off.....	...	L46	0.4	4.75.....
Rear Axle Shaft Bearings—Repack & Rech (After A310).....	...	M726	0.5	1.75.....
Shock Absorbers—Level Oil.....	...	L7.85	1.0	...
Shock Absorbers—Level Oil and Adjust Adj.....	...	L18
Shock Absorber—Renew One Felt Washer and Fill With Oil.....	...	L20
Speedometer Shift—Grease.....	...	F108	0.6	2.05.....
Steering Gear Housing—Refill to Level (Using Gear Oil).....	...	L42
Steering Gear—Adjust to Eliminate Play and Fill with Whitmore's No. 52 Oil.....	...	L92
Steering Gear Housing—Wash Out and Refill with Whitmore's.....	...	8252	1.0	192 2.60.....
Transmission Oil—Drain and Renew (Using Gear Oil).....	...	L2	...	97.....
Transmission—Fill to Level.....	...	L12
Transmission Oil—Drain for Winter (Using Gear Oil).....	...	L22	...	101.....
Universal Joints—Refill.....	...	L8	...	98.....
Wheels—Front—Clean Out and Repack with Grease.....	...	L13	1.2	...
OIL PUMP				
Oil Pump—Remove, Dismantle, Clean and Replace—Not Removing Lower Half.....	626-726-826-901 640-740-840-903	M718 M719	1.2 1.2	198 4.70..... 198 5.20.....
Oil Pump—Remove, Dismantle, Clean and Replace—Lower Half Off.....	...	M715	0.8	...
Oil Pump—Recondition (After M710) (Labor Only).....	...	MM7209	0.8	...
Oil Pump Assembly—Renew—Not Removing Lower Half.....	...	M724	1.2	...
Oil Pump Gear—Renew (After M710).....	...	MM7205	0.8	4.30.....

PAINT WORK

	Synbol	Page	Zone 1	
BODY, HOOD AND WHEELS--Change Color--Standard Color--Sand Down to Bare Metal All Places where Paint is Chipped Off--Fill in All Bare Spots with Prime and then Surface Sand Down using Body Mask Spray with Clear Oil Sand, Polish, Touch Up and Stripe--Closed Cars--Labor Only.....	P73	\$4.0	2118.35.....	
BODY, HOOD AND WHEELS--Change Color--Special--Operation Same as P73--Closed Cars--Labor Only.....	P74	64.0	140.00.....	
BODY AND HOOD--Resurface--Closed Cars--Labor Only.....	726-826-901 740-840-901 626-640.....	P122	4.0	15.25..... 8.75.....
BODY, HOOD AND WHEELS--Resurface--Labor Only.....	726-826-904 740-840-903.....	P81 P71 P73	8.5 4.0 6.0	18.55..... 8.75..... 13.15.....
Chassis--Refinish Black--Labor Only.....	P84	8.0	17.50.....
Chassis--Refinish Special Color--Labor Only.....	P85	6.0	13.15.....
Cowl--Burn Off, Repair and Resurface--Operation same as P97--Labor Only.....	P86	8.0	17.50.....
Cowl--Refinish and Resurface--Operation same as P97--Labor Only.....	P87	4.0	8.75.....
Doors--Refinish Complete and Stripe--Operation same as P73--Labor Only.....	P93	1.5	3.45.....
Doors--Refinish and Resurface--Lower Panel--Operation same as P73--Labor Only.....	P94	1.0	2.10.....
Fender--Spray One in Color--After Burn Off--Labor Only.....	P95	1.0	6.50.....
Fender--Spray One in Black--After Burn Off--Use this operation only in cases where not more than 1/2 of a Fender has to be Sprayed--Labor Only.....	P96	2.4	5.10.....
Fender--Front--Spray Black--Complete--Operation same as Symbol P73--Labor Only.....	P97	4.0	8.75.....
Fender--Front--Spray Any Color--Complete--Operation same as Symbol P73--Labor Only.....	P98	1.0	4.40.....
Fender Rear--Spray Any Color--Complete--Operation same as Symbol P73--Labor Only.....	P99	2.0	4.40.....
Fender--Rear--Spray Black--Complete--Operation same as Symbol P73--Labor Only.....	P100	1.0	6.50.....
Garnish Mouldings in Color--Operation same as Symbol P73 and use Operation P106, in addition--Labor Only.....	P101	5.0	10.85.....
Hood--Complete, Refinish and Resurface--Operation same as Symbol P73--Labor Only.....	P102	6.0	13.15.....
Hood--Refinish and Resurface One Side of Top Only--Operation same as Symbol P73--Labor Only.....	P103	2.0	4.40.....
Hood--Refinish and Resurface One Side Only--Labor Only.....	P104	3.0	6.50.....
Hood--Prepare for Paint and Repaint after Paint--Labor Only.....	P105	2.0	4.40.....
Hood--Top Only--Refinish and Resurface--Operation same as Symbol P73--Labor Only.....	P106	3.5	7.70.....
Hood--Complete--Burn Off, Repaint and Resurface--Burn Off, Sand, Prime, Surface Sand, Spray Clear, Oil Seal, Spray Thinner, Polish, Touch Up and Stripe--Labor Only.....	P97	8.0	17.50.....
Hood--Complete with Lower Doors Complete--Burn Off, Repaint and Resurface--Operation same as Symbol P73--Labor Only.....	P98	9.0	19.60.....
Hood--With Three Lower Doors on Each Side--Including Paint Hood to Match Car--Labor Only.....	640-740	P141	4.0	8.75.....
Interior Moldings--Wood--Delinsh, Sand, Shellac, Varnish and Rub to Polish--Labor Only.....	P103	7.0	15.25.....
Interior Moldings--Wood--Delinsh, Sand, Shellac, Varnish and Rub to Polish--Labor Only.....	P104	5.0	10.85.....
Interior Moldings--Remove and Replace--Labor Only.....	P105	2.0	4.40.....
Metal Tire Covers--Lacquer Any Color--Labor Only.....	P106	1.0	2.10.....

	Sym#	Page	Zone 1
PAINT WORK - Cont'd			
Monogram Panel—Change Color—Operation same as Symbol P73—Labor Only	P103	2.0	\$ 4.40.....
Mouldings—Closed Car Body—Repaint Upper—Labor Only	P82	8.0	17.50....
Open Car—Change Color on Body, Bonnet and Wheels—Operation same as Symbol P73—Labor Only	P108	54.0	18.15.....
Open Car—Step Car for Paint—Operation same as Symbol P76—Labor Only	P109	8.0	17.50....
Open Car—Center Panel Between Doors—Refinish and Restripe—Operation same as Symbol P73—Labor Only	P110	1.5	5.25.....
Open Car Dent—Refinish and Restripe Complete—Operation same as Symbol P73—Labor Only	P111	4.0	8.75.....
Open Car Cold Compartment Door—Refinish and Restripe—Operation same as Symbol P73—Labor Only	P112	2.0	4.40.....
Open Car Rear Side Panel—Refinish and Restripe—Operation same as Symbol P73—Labor Only	P113	6.0	13.15....
Open Car Rumble Seat Deck—Burn Off, Repair and Restripe—Operation same as Symbol P117—Labor Only	P114	9.0	19.60....
Open Car Rumble Seat Deck—Refinish and Restripe—Operation same as Symbol P73—Labor Only	P115	6.0	13.15.....
Open Car Rumble Seat Deck Door—Burn Off and Repair—Operation same as Symbol P73—Also use Operation P117 in addition—Labor Only	P116	5.5	13.90....
Open Car Rumble Seat Deck Door—Refinish—Operation same as Symbol P73—Labor Only	P117	4.0	8.75....
Open Car Rumble Seat Deck Door—Remove and Replace—This is for Operation P116	P118	0.8	1.75.....
Open Car Tonneau—Burn Off, Repair and Restripe—Operation same as Symbol P77—Labor Only	P119	9.0	19.60....
Open Car Tonneau—Patch Up, Refinish and Restripe—Operation same as Symbol P73—Labor Only	P120	6.0	13.15....
Radiator Core—Spray—Labor Only	P121	0.5	1.25.....
Rear Panel—Lower—Burn Off or Refinish—Operation same as Symbol P73—Labor Only	P122	9.0	19.60.....
Rear Panel—Upper—Burn Off or Refinish—Operation same as Symbol P73—Labor Only	P123	11.0	24.00.....
Standard Enamel Parts—Lucquer Any Color—Operation same as Symbol P71—Labor Only	P88	20.0	41.25.....
Standard Enamel Parts—Remove and Replace All Front Fenders, Rear Fenders, Side Splanders, Radiator Splash Pan, Hood Ledges and Trunk Platform—Labor Only	P89	17.0	36.75....
Standard Enamel Parts—Remove and Replace All—Send out to be Enamored—Labor Only	P90	17.0	36.00....
Steering Wheel—Re-Lucquer Wheel Removal—Labor Only	P124	0.8	1.75....
Strip Car for Paint and Replace Standard Parts—Rear Fenders, Headlamps and Crossbar, Door Handles, Trunk Rack Strips, Hood Fitments, Bumper Strips and on Open Job, Windshield Frame—Closed Car—Labor Only	P75	7.0	15.25....
Strip Car for Paint and Replace De Luxe Equipment—in Addition to Standard Parts, Remove and Replace Trunk Rack, Trunk Rack Strips, Spare Wheel Carriers, Coal Lampas and Radios, New Bumpers—On Coupes, Remove Rear Deck Cold Compartment Door Hinge, Hood Hinge Where Nickel'd, Remove Garnish Mouldings on Open Cars—Closed Cars—Labor Only	P76	8.0	17.50....
Stripe Around Each Revolving—Labor Only	P127	0.5	1.05.....
Trunk—Refinish or Lucquer—Labor Only	P128	6.0	13.15.....
Wheel—Steel—Burn Off, Repair and Restripe One—Burns Off Old Paint, Sand, Prime, Surface Sand, Spray Color, Seal, Spray Thinner, Polish and Scribe—Labor Only	P129	2.0	4.40.....
Wheel Hub Cap Centers—Renew One—Labor Only	P130	0.2	.55.....
Wheel Rim—Recoat One—Labor Only	P131	0.4	.90.....
Wire Wheel—Repaint One—Labor Only	P132	1.5	3.15.....

	Symbol	Page	Zone 1
PISTON - Cont'd			
Piston and Cylinder Assembly—Supply on Exchange Base and Insert (Includes M641) Starter Motor and Generator Overhaul and Repair Renewal and Replacing Not Included in This Price (Labor Only)	M636	40.0	157 881.25
Piston and Cylinder Assembly—Supply on Exchange Base and Insert (After M641) (Labor Only)	M646-36	31.5	67.50
Piston Assemblies—Renew and Hone All Cylinders -Block Oil	M646	11.0	175 6.40
Piston Lubricator—Adjust	M714	0.4	... 90
Piston Lubricator—Eliminate Leak at Filled Valve	M716	1.5	3.75
Piston Lubricator Control Valve—Renew	M712	1.0	1.00
Piston Lubricator Control Valve and Body Assembly—Renew	M711	1.2	1.00
Piston Pin—Renew One (Rod Out) For Each Additional Pin Renewed Add Operation M65	M645	0.8	2.45
Piston Pins—Renew All—Rod Out	M644	3.2	17.15
Piston Pins and Bushings—Renew All—Rod Out	M643	3.5	22.40
Piston Pins and Bushings—Renew One (Piston Out)—For Each Additional Pin and Bushing Renewed Add Operation M64	M684	0.8	3.00
Piston Rings—Renew on One Piston (After M310-M640)	M526-51	0.6	2.75
Piston Rings—Renew All—Rods Out	M641	1.7	14.30
PLATES—See Brake, Clutch, Cylinder, Valve or Water Pump			
PLATING			
Bonnet Clamp Assembly—Remove and Replace All Joggles Off Car—Used When Removing and Replacing Parts to Be Plated	P209	1.2	2.65
Bonnet Clamp Bumper—Remove and Replace All Used When Removing and Replacing Parts to Be Plated	P210	0.4	1.60
Bonnet Hanger—Plate All—Chromium or Nickel (Labor Only)	P211	1.2	2.65
Bonnet Hinge—Plate—Chromium or Nickel (Labor Only)	P209	1.7	3.50
Cowl Bands—3 Strips—Plate—Chromium or Nickel (Labor Only)	P208	1.0	2.10
Cowl Lamp With Bracket—Complete—Plate— Chromium or Nickel (Labor Only)	P207	1.0	2.10
Crank Fluke Cover Cap—Plate One—Chromium or Nickel (Labor Only)	P206	0.1	.20
Disc Wheel—Plate One—Chromium or Nickel (Labor Only)	P21	0.8	1.75
Door Handle—Remove and Replace All—Used When Removing and Replacing Parts to Be Plated	P220	1.0	2.30
Gasoline Tank Cap and Bail—Plate Both— Chromium or Nickel (Labor Only)	P204	0.1	.70
Goddess of Speed—Plate One—Chromium or Nickel (Labor Only)	P29	0.1	.35
Golf Compartment Door Hinge—Plate— Chromium or Nickel (Labor Only)	P205	0.9	1.95

STANDARD SERVICE

Index

1134 KUHN

	Symbol	Page	Zone I	
RADIATOR				
Radiator and Pumping System - Adjust, Drain, Re- viewing Water Flow, ...	M807	0.7	\$ 1.70	
Radiator - Tighten to Frame	M854	0.5	.90	
Radiator Bonnet Ledge (Liner) - Remove	626-40-826-40-501-103	M859	0.7	2.45
Radiator Bonnet Ledge (Liner) - Install	740-740	M859	0.5	2.00
Radiator - Remove, Disassemble, Clean and Replace (Includes Shell, Shutter, Core and Thermostat)	M800	1.0	6.15	
Radiator - Remove and Replace	M840	1.4	2.45	
Radiator Core - Remove	626-726-81-501	M843	1.3	51.50
640-740-81-501	M843	2.5	54.80	
645-745-81-501	M843	2.5	60.30	
626	M840	2.5	109.60	
726-826-501	M840	2.5	112.55	
640	M840	2.5	115.40	
740-840-501	M840	2.5	115.65	
645	M850	2.5	126.65	
745-845-501	M840	2.5	133.15	
Radiator Hose - Remove All If Radiator Is Off or Drained, Change Material Only	626-640	M841	0.5	2.20
726-740-81-501-103	M841	0.5	1.40	
715	M841	0.8	2.95	
601-901	M841	0.9	3.20	
Radiator Hose and Clamps - Remove All If Radiator Is Off or Drained, Change Material Only	626-640	M842	0.8	2.50
726-740-81-501-103	M842	0.8	2.70	
715	M842	0.8	3.15	
601-901	M842	0.8	3.45	
Radiator Hose Clamp - Service Only	M843	0.1	212	
Radiator Hose Clamp - Tighten (Loosening)	M844	
Radiator Lower Hose - Remove If Radiator Is Off or Drained, Change Material Only	626-640-715	M845	0.3	1.20
M845	0.1	...	1.30	
Radiator Lower Hose and Clamps - Remove All If Radiators Is Off or Drained, Change Material Only	626-640	M846	0.3	1.20
M846	0.3	...	1.50	
Radiator Shell - Clean and Paint	610-614	M855	1.5	15.65
745	M855	1.5	11.15	
M855	1.5	204	46.65	
Radiator Shell - Replace (Cadmium or Nickel (Labour Only))	P29	2.0	104	
Radiator Shell - Remove and Replace	M850	1.5	2.65	
Radiator Shell - Straighten (Do Not Remove or Bend Metal Frame)	M862	
Radiator Shell - Welded, ... (With Galvanite Coating)	M816	1.5	1.05	
M816	1.5	...	1.40	
Radiator Shells, Shutters, Core and Thermostat - Remove and Replace - Radiator Old Car	M803	1.4	3.50	
Radiator Shutter - Free Pin - Release Spring Up Operating Lever Bracket and Thermostat	M867	1.0	6.15	
Radiator Shutter Assembly - Remove	M865	2.0	213	
726-740-81-501-103	M865	2.0	12.70	
626-845	M863	2.0	12.70	
Radiator Shutter Thermostats - Remove, Test and Install New Thermostats	626-640	M866	2.0	12.80
726-740	M866	2.0	12.80	
626-840	M866	0.8	5.80	
Radiator Splasher - Remove (4 Bolts) (10-46-606 Time)	M846	
Radiator Splasher - Replace (10-46-606)	M855	1.2	207	
Radiator Thimble Cover Gasket - Remove (Material Only)	126-610	M866	...	15. . . .
726-740-81-501-103	M866	...	15. . . .	
745-604	M866	...	140. . . .	
Radiator Thimble Cover Gasket - Remove (Material Only)	M853	...	40	
Radiator Upper Hose and Clamps - Remove All If Radiators Is Off or Drained, Change Material Only	M838	0.4	1.25	
745	M838	0.3	211	
601-901	M838	0.3	211	

STANDARD SERVICE

14/15

			Syndication	Page	Zone 1
SHACKLE—See Spring					
SHAFTS—See Axle Rear, Brakes, Carburetor, Clutch, Differential, Oil Pump, Speedometer, Starter Motor, Transmission, Universal Joint or Water Pump					
SHELL—See Headlamps or Radiator					
SHOCK ABSORBERS					
Shock Absorbers—Level Oil...			1.88		
Shock Absorbers—Level Oil and Adjust All			1.30		
Shock Absorber—Remove and Replace One	626-726-610-740	F101	0.6		\$ 1.40
Shock Absorbers—Remove One, Replace All	626-726-610-740	F102	2.5		5.60
Shock Absorber—Front or Rear—Renew One	626-726-610-710	F13	0.6	61	12.40
Shock Absorber—Renew One, Left Washer and Ball with Oil	626-726-610-710	F106	0.6		2.05
Shock Absorber Connecting Link—Front—Renew One	626-726-610-710	F12	0.4	61	3.55
Shock Absorber Connecting Link—Rear—Renew One	626-726-610-740	F12	0.4	61	3.65
Shock Absorber Metering Valves—Renew All—(Labor Only)	626-726-610-710	F109	0.3		1.75
Shock Absorber—Remove and Replace One, Rear	626-726-610-901	F140	0.4		5.60
Shock Absorber—Remove and Replace One, Front	626-810-901	F150	0.6		14.40
Shock Absorber—Remove and Replace All	626-810-901	F161	2.0		4.05
Shock Absorber Connecting Link—Renew One	626-810-903	F132	0.4		3.55
Shock Absorber—Change All, Metering Valves (Labor Only)	626-810-903	F130	1.0		3.10
Shock Absorber—Renew One, Front	626-810-903	F141	0.6		17.35
Shock Absorber—Renew One, Rear	626-810-903	F142	0.4		19.65
SHOES—See Brake					
SHUTTERS—See Radiator					
SPARK PLUGS					
Spark Plugs—Clean and Adjust		E119	0.1	41	.70
Spark Plug—Renew One—Material Only		E120			.75
Spark Plug—Renew All—Material Only		E121			6.00

	Symbol	Page	Zone 1
SPEEDOMETER			
Speedometer Drive, Gear—Renew	B54	1-2	3-120
Speedometer Driven Pinion and Steering Gear Housing —Renew	B57	1-2	8-106
Speedometer Driving Pinion—Renew	B51	0-6	15-110
Speedometer Head—Renew, Seal Out for Repair and Replace (Labor Only)	B56	0-4	50-100
Speedometer Head Glass—Renew (Material Only)	B55	0-1	50-100
Speedometer Liquid Pillar on F. L. T. —Renew	B58	0-5	5-15
Speedometer Shaft Inside Gasket—Renew (Labor Only)	B53	0-8	1-75
Speedometer Shaft, Outer—	B56	1-6	1-75
SPIDER—See Clutch			
SPLASHER —See Enamel, Frame, Radiator or Running Board			
SPOTLIGHT			
Spotlight Bulb—Renew (Material Only)...	B445
SPRAY TUBE —See Carburetor			
SPRINGS			
Front Axle Spring—Renew One (After 1-210)	F2016	0-2	1-15
Front Axle Spring—Renew One	F21	1-8	60-11-SD
Front Axle Spring and Cover Assembly—Renew One	F20-526-601		
Front Axle Spring—Renew and Replace One	F20-541-601		
Front Axle Spring Center Bolt—Renew One	F210	1-8	11-12
Front Axle Spring Center Bolt—Renew One (Labor Only)	F224	1-6	4-7
Front Axle Spring Front Bolt—Renew One	F241	1-6	1-40
Front Axle Spring Front Bolt and Bushing— Right	F241	0-4	1-75
Front Axle Spring Hanger, Front—Replace One	F205	0-8	3-20
Front Axle Spring Rear Bolt—Renew One	F208	0-5	82-10-SD
Front Axle Spring Rear Bolt and Bushing— Renew One	F212	0-7	7-20
Front Axle Spring Rear Bracket, Right— Renew One	F214	1-1	70-4-10
Front Axle Spring Rear Bracket—Left or Right Renew	F32	5-5	13-14
Front Axle Spring Rear Trim-on Bolt— Renew	F399	5-5	10-60
Front Axle Spring Trim-on Bracket—Left— Renew	F232	1-2	3-50
Front Axle Spring Trim-on Springs—Left— Renew	F234	1-1	3-60
Front Axle Spring Trim-on Bracket—Left— Renew	F37	5-10	15-60
Front and Rear Axle Spring Bolts and Bushings— Renew All	F27	6-2	65-14-SD
Front and Rear Axle Spring Bolts—Shims and Adjust—When the Bracket Allows No Adjust- ment	F228	1-6	74-1-100

		Symbol	Page	Zone I
STARTER MOTOR—Cont'd				
Starter Motor Drive Spring Screw—Renew (Includes E311)		E327	0.7	32 8 1 80
Starter Motor Drive Spring Screws—Renew (After E311)		EE327	0.3	32
Starter Motor Fields—Renew (Includes E311)	626-726-826-901	E324	0.8	33
	640-740-840-904	E324	0.9	33
Starter Motor Fields—Renew (After E311)	626-726-826-901	EE324	0.4	33
	640-740-840-904	EE324	0.4	33
		E34	1.5	31 4 90
Starter Motor Switch—Renew				
Starter Motor Switch to Junction Box Cable Assembly—Renew (Labor Only)		E36	0.4	1 75
Starter Motor Switch to Starter Motor Cable Assembly—Renew (Labor Only)		E54	0.4	55
STARTING CRANK				
Starting Crank Cap—Renew (Material Only)		M49090
STEERING				
Steering—Remove for Inspection Dimensions— Inspect Reasonable and Replace		S310	6.5	110 14.25
Steering Assembly—Raise or Lower	726-826-901	S312	0.8	112 1.75
	740-840-901	S312	0.3	112
Steering Column—Adjust to Eliminate End Play		S318	3.0	118
Steering Column Upper Bushing—Renew (Open Cars) (Labor Only)		S314	3.0	118
Steering Column Upper Bushing—Renew (Closed Cars) (Labor Only)		S315	4.5	118 10.50
Steering Connections—Adjust Play		S144	0.8	114
Steering Connecting Rod—Renew (To Tram Wheels add Operation S222)	626-726-826-901	S13	0.9	117 7.60
	640-740-840-903	S13	0.8	117 8.00
Steering Connecting Rod—Straighten		S14	1.6	118 3.50
Steering Connecting Rod Ball Socket Dust Cover—Renew One		S140	0.8	118 2.10
Steering Connecting Rod Ball Socket Dust Cover 4 Lamps—Renew		S141	0.8	118 2.45
Steering Cross Tube—Renew		S142	1.3	118 6.40
Steering Cross Tube—Straighten		S143	1.3	118 2.65
Steering Gear—Adjust to Eliminate Play and Fill with Whitmore's No. 52 Oil		S351	1.0	212 2.60
Steering Gear—Remove and Replace		S353	4.2	212 10.50
Steering Gear—Tighten to Frame		S31	0.3	219
Steering Gear Case—Renew (Includes S310)		S36	8.0	219 13.75
Steering Gear Case—Renew (After S310)		S36	1.5	219 19.50
Steering Gear Case Lighting Switch—Renew	626-640	E111	0.6	44 2.50
	726-740-826-840-901-903	E111	0.6	44 2.85

STANDARD SERVICE

九九归一

STRAP—See Dvor

STRIKER—Ses Door

SUPPORT PLATE—See Brakes.

SWITCH—See Backing Light, Ignition, Starter Motor, Steering, Stop Light or Tail Lamp.

SYLPHON—See Thermosyphon

	Symbol	Page	Zone I
TIMING			
Front End Sprockets—Retime (Removing Front Cover) When Chain Has Jumped.....	M484	1.2	151 8 8.35.....
Front End Sprockets and Chain—Renew (Includes M410).....	M483	4.2	152 11.20.....
Front End Sprockets and Chain—Renew (After M410).....	MN483	4.7	155 15.40.....
Front End Sprockets—Renew All (Includes M410).....	M482	4.2	156 15.95.....
Front End Sprockets—Renew All (After M410).....	MN482	4.7	157 17.25.....
Ignition Timing—Set Standard.....	K144	0.4	.44 .90.....
Timing Chain—Adjust.....	M440	0.2	.45 .35.....
Timing Chain—Renew (Includes M410).....	M442	5.0	147 16.15.....
Timing Chain—Renew (After M410).....	M51442	1.3	10.45
Timing Chain—Take Out Link (Includes M410).....	M431	4.2	146 9.45
Timing Chain—Take Out Link (After M410).....	MN431	4.6	147 10.05
TIRE PUMP			
Tire Pump—Clean and Adjust Check Valve.....	350	1.6	... 3.50.....
TOE BOARDS			
Toe Board—Remove and Replace.....	B680	1.2	... 2.65.....
Toe Board—Inclined—Repair (Labor Only).....	B687	1.2	... 2.65.....
Toe Board—Inclined—Tighter (Labor Gratis).....	B689
TOOL BOX			
Tool Box—Renew—Fender (All).....	901-902-903-904	F416	0.3 .. 7.65.....
TOP			
Top—Renew—Including Rear Curtains and Side Curtain, Less Rear Glass Bow and Sockets— Touring (Labor Only).....	626-726-826-901	B128	36.5 .. 71.40.....
Touring (Labor Only).....	546-740-840-903	B228	36.0 .. 73.50.....
Roadster (Labor Only).....		H228	21.6 .. 47.15.....
Top—Take Off Bag (Labor Only).....		B227	2.0 .. 4.40.....
Top—Re-cover—Less Side Curtains (Roadster Only).....		B230	18.0 .. 36.75.....
Top—Repair Tear (Six Inches) (Roadster Only).....		B200	0.8 .. 1.75.....

	Symbol	Page	Zone 1
TOP - Continued			
Top—Repair Tear (Twelve Inches) (Labor Only).	B261	1.5	... \$ 3.15....
Top Binding—Front or Rear—Renew (Labor Only)	B226	0.6	... 1.75....
Top Complete, Including Bows and Sockets—Rear and Side Curtains—Renew—Touring (Labor Only).	B229	4.0	... \$ 74....
Roadster (Labor Only).	B229	4.0	... \$ 74....
Top Deck—Sedan—Renew (Includes B244) (Labor Only).	B244	8.8	... 19.25....
Top Deck—Sedan—Renew (After B254) (Labor Only).	B244	4.8	... 10.50....
Top Deck—Coupe—Renew (Includes B244) (Labor Only).	B245	8.8	... 19.25....
Top Deck—Coupe—Renew (After B244) (Labor Only).	B245	4.8	... 10.50....
Top Deck Strip Moulding—Renew (Labor Only).	B234	3.5	... 8.75....
Top Deck Auxiliary Moulding—Install (Labor Only).	B235	2.0	... 4.40....
Top Envelope—Make Up and Attach (Labor Only).	B212	1.2	... 7.00....
Top Midsection—Rear—Touring (Labor Only). Touring (Labor Only).	B212	5.0	... 11.40....
Roadster (Labor Only).	B217	7.0	... 15.05....
Roadster (Labor Only).	B217	4.0	... 8.75....
Top Midsection and Two Sides (Quarter—Renew— Renew—Touring (Labor Only).	B222	6.8	... 14.00....
Touring (Labor Only).	B222	8.0	... 17.50....
Roadster (Labor Only).	B222	5.5	... 11.40....
Top Midsection and One Side (Quarter—Renew— Touring (Labor Only).	B225	6.0	... 12.25....
Touring (Labor Only).	B225	8.0	... 17.50....
Roadster (Labor Only).	B225	5.0	... 10.50....
Top Side Quarter—Right or Left—Renew— Touring (Labor Only).	B221	5.8	... 11.40....
Touring (Labor Only).	B221	7.0	... 14.00....
Roadster (Labor Only).	B221	4.0	... 8.75....
Top Side Quarter—Both—Renew—Touring or Roadster (Labor Only).	B223	6.0	... 13.15....
Touring (Labor Only).	B223	7.0	... 14.00....
Roadster (Labor Only).	B223	4.0	... 8.75....
Touring (Labor Only).	B223	8.0	... 17.50....
Roadster (Labor Only).	B223	5.0	... 11.40....
Touring (Labor Only).	B223	9.0	... 19.25....
Roadster (Labor Only).	B223	6.0	... 13.15....
Touring (Labor Only).	B223	10.0	... 22.50....
Roadster (Labor Only).	B223	7.0	... 14.00....
Touring (Labor Only).	B223	11.0	... 24.25....
Roadster (Labor Only).	B223	8.0	... 16.00....
Touring (Labor Only).	B223	12.0	... 26.00....
Roadster (Labor Only).	B223	9.0	... 17.50....
Touring (Labor Only).	B223	13.0	... 27.75....
Roadster (Labor Only).	B223	10.0	... 19.25....
Touring (Labor Only).	B223	14.0	... 29.50....
Roadster (Labor Only).	B223	11.0	... 21.00....
Touring (Labor Only).	B223	15.0	... 31.25....
Roadster (Labor Only).	B223	12.0	... 22.50....
Touring (Labor Only).	B223	16.0	... 33.00....
Roadster (Labor Only).	B223	13.0	... 24.25....
Touring (Labor Only).	B223	17.0	... 34.75....
Roadster (Labor Only).	B223	14.0	... 26.00....
Touring (Labor Only).	B223	18.0	... 36.50....
Roadster (Labor Only).	B223	15.0	... 27.75....
Touring (Labor Only).	B223	19.0	... 38.25....
Roadster (Labor Only).	B223	16.0	... 29.50....
Touring (Labor Only).	B223	20.0	... 40.00....
Roadster (Labor Only).	B223	17.0	... 31.25....
Touring (Labor Only).	B223	21.0	... 41.75....
Roadster (Labor Only).	B223	18.0	... 33.00....
Touring (Labor Only).	B223	22.0	... 43.50....
Roadster (Labor Only).	B223	19.0	... 34.75....
Touring (Labor Only).	B223	23.0	... 45.25....
Roadster (Labor Only).	B223	20.0	... 36.50....
Touring (Labor Only).	B223	24.0	... 47.00....
Roadster (Labor Only).	B223	21.0	... 38.25....
Touring (Labor Only).	B223	25.0	... 48.75....
Roadster (Labor Only).	B223	22.0	... 39.50....
Touring (Labor Only).	B223	26.0	... 50.50....
Roadster (Labor Only).	B223	23.0	... 41.25....
Touring (Labor Only).	B223	27.0	... 52.25....
Roadster (Labor Only).	B223	24.0	... 43.00....
Touring (Labor Only).	B223	28.0	... 54.00....
Roadster (Labor Only).	B223	25.0	... 44.75....
Touring (Labor Only).	B223	29.0	... 55.75....
Roadster (Labor Only).	B223	26.0	... 46.50....
Touring (Labor Only).	B223	30.0	... 57.50....
Roadster (Labor Only).	B223	27.0	... 48.25....
Touring (Labor Only).	B223	31.0	... 59.25....
Roadster (Labor Only).	B223	28.0	... 50.00....
Touring (Labor Only).	B223	32.0	... 61.00....
Roadster (Labor Only).	B223	29.0	... 51.75....
Touring (Labor Only).	B223	33.0	... 62.75....
Roadster (Labor Only).	B223	30.0	... 53.50....
Touring (Labor Only).	B223	34.0	... 64.50....
Roadster (Labor Only).	B223	31.0	... 56.25....
Touring (Labor Only).	B223	35.0	... 66.25....
Roadster (Labor Only).	B223	32.0	... 58.00....
Touring (Labor Only).	B223	36.0	... 68.00....
Roadster (Labor Only).	B223	33.0	... 59.75....
Touring (Labor Only).	B223	37.0	... 70.00....
Roadster (Labor Only).	B223	34.0	... 61.75....
Touring (Labor Only).	B223	38.0	... 71.75....
Roadster (Labor Only).	B223	35.0	... 63.50....
Touring (Labor Only).	B223	39.0	... 73.50....
Roadster (Labor Only).	B223	36.0	... 65.25....
Touring (Labor Only).	B223	40.0	... 75.00....
Roadster (Labor Only).	B223	37.0	... 67.00....
Touring (Labor Only).	B223	41.0	... 76.75....
Roadster (Labor Only).	B223	38.0	... 68.50....
Touring (Labor Only).	B223	42.0	... 78.50....
Roadster (Labor Only).	B223	39.0	... 70.25....
Touring (Labor Only).	B223	43.0	... 80.00....
Roadster (Labor Only).	B223	40.0	... 71.75....
Touring (Labor Only).	B223	44.0	... 81.75....
Roadster (Labor Only).	B223	41.0	... 73.50....
Touring (Labor Only).	B223	45.0	... 83.50....
Roadster (Labor Only).	B223	42.0	... 75.25....
Touring (Labor Only).	B223	46.0	... 85.00....
Roadster (Labor Only).	B223	43.0	... 76.75....
Touring (Labor Only).	B223	47.0	... 86.75....
Roadster (Labor Only).	B223	44.0	... 78.50....
Touring (Labor Only).	B223	48.0	... 88.50....
Roadster (Labor Only).	B223	45.0	... 80.25....
Touring (Labor Only).	B223	49.0	... 90.00....
Roadster (Labor Only).	B223	46.0	... 81.75....
Touring (Labor Only).	B223	50.0	... 91.75....
Roadster (Labor Only).	B223	47.0	... 83.50....
Touring (Labor Only).	B223	51.0	... 93.50....
Roadster (Labor Only).	B223	48.0	... 85.25....
Touring (Labor Only).	B223	52.0	... 95.00....
Roadster (Labor Only).	B223	49.0	... 86.75....
Touring (Labor Only).	B223	53.0	... 96.75....
Roadster (Labor Only).	B223	50.0	... 88.50....
Touring (Labor Only).	B223	54.0	... 98.50....
Roadster (Labor Only).	B223	51.0	... 90.25....
Touring (Labor Only).	B223	55.0	... 100.00....
Roadster (Labor Only).	B223	52.0	... 91.75....
Touring (Labor Only).	B223	56.0	... 101.75....
Roadster (Labor Only).	B223	53.0	... 93.50....
Touring (Labor Only).	B223	57.0	... 103.50....
Roadster (Labor Only).	B223	54.0	... 95.25....
Touring (Labor Only).	B223	58.0	... 105.00....
Roadster (Labor Only).	B223	55.0	... 96.75....
Touring (Labor Only).	B223	59.0	... 106.75....
Roadster (Labor Only).	B223	56.0	... 98.50....
Touring (Labor Only).	B223	60.0	... 108.50....
Roadster (Labor Only).	B223	57.0	... 99.25....
Touring (Labor Only).	B223	61.0	... 110.00....
Roadster (Labor Only).	B223	58.0	... 101.75....
Touring (Labor Only).	B223	62.0	... 111.75....
Roadster (Labor Only).	B223	59.0	... 103.50....
Touring (Labor Only).	B223	63.0	... 113.50....
Roadster (Labor Only).	B223	60.0	... 105.25....
Touring (Labor Only).	B223	64.0	... 115.00....
Roadster (Labor Only).	B223	61.0	... 106.75....
Touring (Labor Only).	B223	65.0	... 116.75....
Roadster (Labor Only).	B223	62.0	... 108.50....
Touring (Labor Only).	B223	66.0	... 118.50....
Roadster (Labor Only).	B223	63.0	... 110.25....
Touring (Labor Only).	B223	67.0	... 119.75....
Roadster (Labor Only).	B223	64.0	... 112.50....
Touring (Labor Only).	B223	68.0	... 121.50....
Roadster (Labor Only).	B223	65.0	... 114.25....
Touring (Labor Only).	B223	69.0	... 123.50....
Roadster (Labor Only).	B223	66.0	... 116.75....
Touring (Labor Only).	B223	70.0	... 125.00....
Roadster (Labor Only).	B223	67.0	... 118.25....
Touring (Labor Only).	B223	71.0	... 126.75....
Roadster (Labor Only).	B223	68.0	... 120.50....
Touring (Labor Only).	B223	72.0	... 128.50....
Roadster (Labor Only).	B223	69.0	... 121.75....
Touring (Labor Only).	B223	73.0	... 130.00....
Roadster (Labor Only).	B223	70.0	... 123.25....
Touring (Labor Only).	B223	74.0	... 131.75....
Roadster (Labor Only).	B223	71.0	... 125.50....
Touring (Labor Only).	B223	75.0	... 133.50....
Roadster (Labor Only).	B223	72.0	... 127.25....
Touring (Labor Only).	B223	76.0	... 135.00....
Roadster (Labor Only).	B223	73.0	... 128.75....
Touring (Labor Only).	B223	77.0	... 136.75....
Roadster (Labor Only).	B223	74.0	... 130.50....
Touring (Labor Only).	B223	78.0	... 138.50....
Roadster (Labor Only).	B223	75.0	... 131.75....
Touring (Labor Only).	B223	79.0	... 140.00....
Roadster (Labor Only).	B223	76.0	... 133.25....
Touring (Labor Only).	B223	80.0	... 141.75....
Roadster (Labor Only).	B223	77.0	... 135.50....
Touring (Labor Only).	B223	81.0	... 143.50....
Roadster (Labor Only).	B223	78.0	... 137.25....
Touring (Labor Only).	B223	82.0	... 145.00....
Roadster (Labor Only).	B223	79.0	... 138.75....
Touring (Labor Only).	B223	83.0	... 146.75....
Roadster (Labor Only).	B223	80.0	... 140.50....
Touring (Labor Only).	B223	84.0	... 148.50....
Roadster (Labor Only).	B223	81.0	... 141.75....
Touring (Labor Only).	B223	85.0	... 150.00....
Roadster (Labor Only).	B223	82.0	... 143.25....
Touring (Labor Only).	B223	86.0	... 151.75....
Roadster (Labor Only).	B223	83.0	... 145.50....
Touring (Labor Only).	B223	87.0	... 153.50....
Roadster (Labor Only).	B223	84.0	... 147.25....
Touring (Labor Only).	B223	88.0	... 155.00....
Roadster (Labor Only).	B223	85.0	... 148.75....
Touring (Labor Only).	B223	89.0	... 156.75....
Roadster (Labor Only).	B223	86.0	... 150.50....
Touring (Labor Only).	B223	90.0	... 158.50....
Roadster (Labor Only).	B223	87.0	... 151.75....
Touring (Labor Only).	B223	91.0	... 160.00....
Roadster (Labor Only).	B223	88.0	... 153.25....
Touring (Labor Only).	B223	92.0	... 161.75....
Roadster (Labor Only).	B223	89.0	... 155.50....
Touring (Labor Only).	B223	93.0	... 163.50....
Roadster (Labor Only).	B223	90.0	... 157.25....
Touring (Labor Only).	B223	94.0	... 165.00....
Roadster (Labor Only).	B223	91.0	... 158.75....
Touring (Labor Only).	B223	95.0	... 166.75....
Roadster (Labor Only).	B223	92.0	... 160.50....
Touring (Labor Only).	B223	96.0	... 168.50....
Roadster (Labor Only).	B223	93.0	... 161.75....
Touring (Labor Only).	B223	97.0	... 170.00....
Roadster (Labor Only).	B223	94.0	... 163.25....
Touring (Labor Only).	B223	98.0	... 171.75....
Roadster (Labor Only).	B223	95.0	... 165.50....
Touring (Labor Only).	B223	99.0	... 173.50....
Roadster (Labor Only).	B223	96.0	... 167.25....
Touring (Labor Only).	B223	100.0	... 175.00....
Roadster (Labor Only).	B223	97.0	... 168.75....
Touring (Labor Only).	B223	101.0	... 176.75....
Roadster (Labor Only).	B223	98.0	... 170.50....
Touring (Labor Only).	B223	102.0	... 178.50....
Roadster (Labor Only).	B223	99.0	... 171.75....
Touring (Labor Only).	B223	103.0	... 180.00....
Roadster (Labor Only).	B223	100.0	... 173.25....
Touring (Labor Only).	B223	104.0	... 181.75....
Roadster (Labor Only).	B223	101.0	... 175.50....
Touring (Labor Only).	B223	105.0	... 183.50....
Roadster (Labor Only).	B223	102.0	... 177.25....
Touring (Labor Only).	B223	106.0	... 185.00....
Roadster (Labor Only).	B223	103.0	... 178.75....
Touring (Labor Only).	B223	107.0	... 186.75....
Roadster (Labor Only).	B223	104.0	... 180.50....
Touring (Labor Only).	B223	108.0	... 188.50....
Roadster (Labor Only).	B223	105.0	... 181.75....
Touring (Labor Only).	B223	109.0	... 190.00....
Roadster (Labor Only).	B223	106.0	... 183.25....
Touring (Labor Only).	B223	110.0	... 191.75....
Roadster (Labor Only).	B223	107.0	... 185.50....
Touring (Labor Only).	B223	111.0	... 193.50....
Roadster (Labor Only).	B223	10	

		Symbol	Page	Zone 1
UNIVERSAL JOINT				
Universal Joints—Remove, Inspect, Report and Replace.....	901-903-904.....	T322 T322 1.8	2.0 1.0 ...	249 \$ 6.65... 6.40....
Universal Joints—Replace.....	902-901-904.....	T37	3.2	247 2.65....
Universal Joint—Front or Rear—Recondition (Labor Only).....	902-901-904.....	T37	1.5	...
Universal Joint—Front or Rear or Center—Recondition (Labor Only).....	902-901-904.....	T37	1.2	250 2.90....
Universal Joint—Front or Rear—Inspect, Report and Replace.....	902-901-904.....	T323	1.2	250 2.90....
Universal Joint—Front Rear or Center—Remove, Inspect, Report and Replace.....	902-901-904.....	T323	1.5	3.40....
Universal Joint Bolts and Nuts—Front One End.....	902-901-904.....	T316	0.4	248 1.75....
Universal Joint Bolts and Nuts—Both or All.....	902-901-904.....	T317	0.8	248 3.20....
Universal Joint Drive Shaft—Less Joints—Renew.....	626-726-826-901.....	T36	1.8	247 14.90....
Universal Joint Drive Shaft—Front—Less Joints—Renew.....	610-740-745-840.....	T36	1.8	247 15.95....
Universal Joint Drive Shaft—Rear—Less Joints—Renew.....	745-845.....	T36	1.8	247 17.85....
Universal Joint Drive Shaft—Intermediate Bearing—Renew.....	902-901-904.....	T36	3.1	...
Universal Joint Drive Shaft—Intermediate Bearing—Renew.....	902-901-904.....	T34	1.6	...
Universal Joint Flange Bolts—Front or Rear End—Tighten.....	902-903-904.....	T32	3.1	11.55....
Universal Joint Flange Bolts—Front and Rear—Tighten.....	902-903-904.....	T321	0.2	249 1.35....
Universal Joint Flange Bolts—Front and Rear—Tighten.....	902-903-904.....	T34	0.3	247 1.70....
UPHOLSTERY				
Remove and Replace Upholstery—Sedan—Rear Seat Back Only.....	B311	1.8	...	3.85....
Remove and Replace Upholstery—Rear Side Panels.....	B312	7.8	...	17.50....
Remove and Replace Upholstery—Sedan—Upper Panel (Labor Only).....	B315	2.2	...	5.25....
Rebind Touring Car Door (Labor Only).....	B313	0.8	...	1.75....
Recover Door Pull-to Handle—Each (Labor Only).....	B316	1.6	...	3.50....
Upholster Touring Car Door—Remove and Replace (Labor Only).....	B35	1.8	...	3.50....
Upholster Sedan Door—Remove and Replace (Labor Only).....	B36	1.8	...	3.50....
Upholstery—Remove and Replace to Repair Door Lock (Labor Only).....	B37	0.8	...	1.75....
Upholstery—Remove and Replace to Take Dent Out of Rear Panels—\$2.00 to \$20.00.....	B38
Upholstery—Remove and Replace to Take Dent Out of Side Panels—\$5.00 to \$10.00.....	B39
Weatherstrips—Bottom of Sedan Door—Renew (Labor Only).....	B34	0.8	...	1.75....

		Symbol	Page	Zone I
VACUUM PUMP				
Motor Vacuum Pump Ball Check -Review (Labor Only)	726-740	M118	0.2	... 5 .55.....
Motor Vacuum Pump Connecting Rod -Review (Labor Only) Front Cover is Not Required	726-740	M119	0.6	... 1.40.....
Motor Vacuum Pump Cylinder and Piston - Remove, Dismantle for Inspection and Replace - Front Cover is Not Required	726-740	M119	0.6	... 1.40.....
Motor Vacuum Pump Cylinder and Piston Assembly - Review (Labor Only) Front Cover is Not Removed	726-740	M119	0.6	... 1.40.....
VACUUM TANK				
Vacuum Tank - Remove, Clean and Replace	626-640-726-740	M361	1.0	145 2.30.....
Vacuum Tank - Renew	626-640-726-740-645	M364	0.8	145 18.25.....
	745	M363	0.8	145 19.45.....
Vacuum Tank Cover Gasket - Renew	626-640-726-740	M368	0.3	144 .85.....
Vacuum Tank Float and Cover Assembly - Renew	626-640-726-740	M369	0.4	145 6.10.....
Vacuum Tank or Gasoline Pump - Renew, Carburetor and Gasoline Tank - Clean Out	626-640-726-740	M39	1.2	129 4.65.....
Vacuum Tank Screen - Clean	626-640-726-740	M360	0.1	129 .20.....
VALVES				
Clean Carbon, Grind Valves and Tune Motor - Head Oil - Clean Air Cleaner	626-726-826-901	M26	4.4	121 8.60.....
Clean Carbon, Grind Valves, Tune Motor - Includes Rebuilding Ignition, Cleaning Air Cleaner (II), New Printed Points, Spark Plugs and Replacing, Adjust the Value of the Ignition Points of Spark Plug Oil	640-740-840-901	M26	5.0	121 10.60.....
Valves - Open Up - By Lubricating Seats With Kerosene Through Spark Plug Openings - Check Tappets	626-726-826-901	M24	7.0	124 14.00.....
Valves - Grind All (Includes M22) (Charge Material Only, or New Valves)	640-740-840-901	M24	7.4	124 16.00.....
Valves - Grind All (After M22)		M26	6.6	125 11.60.....
Valves - Reface (Includes M22)		MM26	1.3	125 3.15.....
Valves - Reface (After M22)		M27	5.5	125 11.70.....
Valves - Remove for Inspection and Replace (Includes M22)		MM27	0.9	125 2.10.....
Valves - Remove for Inspection and Replace (After M22)		M28	5.4	127 8.45.....
Valves - Remove for Inspection and Replace (After M22)		MM28	1.4	127 3.15.....
Valves - Remove All - Valves Out (Material Only)		M297	... 150	29.20.....
Valves and Ignition Timing - Renew (When Chain Has Jumped) Without Removing Front Cover - Rebuilding Generator		M324	1.2	... 2.65.....
Valve Exhaust - Renew One Valve Out (Material Only)		M252	... 132	2.20.....
Valves - Exhaust - Renew All - Valves Out (Material Only)		M254	... 132	17.60.....
Valves - Inlet - Renew All - Valves Out (Material Only)		M255	... 132	11.60.....

	Symbol	Page	Zone 1	
WHEELS				
Wheels—Front—Clean Out and Repack with Grease.....	L13	1.2	... \$ 2.95.....	
Wheel—Front—Tire Up One Steel Wheel.....	S256	2.6	... 5.75.....	
Wheel—Front—Adjust Stops.....	S255	0.5	... 1.05.....	
Wheel—Front or Rear (Steel or Disteel)— Renew Hub (Less Ring)	S223	1.1	223 21.45	
Wheels—Front—Front	S222	0.8	223 1.75	
Wheels—Front—Remove One for Inspection and Replace.....	S220	0.8	223 1.90.....	
Wheels—Front—Remove Both for Inspection and Replace.....	S251	1.0	227 3.65.....	
Wheel—Front or Rear—Less Hub—Remove and Replace One—Renew and Mount Tire (Used When Sending Wheel Out for Repair).....	S132	0.5	... 1.05.....	
Wheels—Eliminate Squeak—One Wheel	S258	0.8	... 1.75.....	
Wheel and Tire—Change One.....	S131	0.4	... 0.90.....	
Wheel—Front—Dust Washer and Retainer Renew (Excludes S220).....	S227	1.2	225 3.10.....	
Wheel—Front—Dust Washer and Retainer Renew (After S220)	SS227	0.4	223 1.20	
Wheels—Front—Adjust Bearings	S221	0.5	223 1.40	
Wheels—Front and Rear—Tighten Clamping Ring Bolts and Retaining Nuts (Disteel Wheels).....	A39	0.3	15 2.70	
Wheel—Rear—Renew (Wood) (Painted)	A328	1.2	... 32.00.....	
Wheel—Rear—Remove One for Inspection and Replace.....	A348	0.8	20 1.75.....	
Wheels—Rear—Remove Bobb for Inspection and Replace.....	A310	1.5	15 3.50.....	
Wheel—Rear—True Up One—Steel Wheel	A325	2.6	... 5.75.....	
Wheel—Rear Axle Shaft Bearing Sleeve—Dust Washer and Retainer—Renew Both (Includes A310)	626-726-826-901 640-740-840-901	A312	2.4	16 6.15.....
Wheel—Rear Axle Shaft Bearing Sleeve—Dust Washer and Retainer—Renew Both (Excludes A310)	626-726-826-901 640-740-840-901	AA312	0.8	16 2.65
Wheel Brake Drum Assembly—Front—Renew One —Wheels 1/2 (Disteel Wheel) For Each Additional Front Brake Drum Renewed Add Operation A111	A311	0.4	16 15.75	
Wheel Brake Drum Assembly—Rear—Renew One —Wheel Off (Disteel Wheel) For Each Additional Rear Brake Drum Renewed Add Operation A122	A322	0.4	... 10.15	
Wheel Brake Drum—Tighten Down One Wheel 1/2 For Each Additional Brake Drum Tighened Down Add Operation A351	A353	0.2	... 1.95	
Wheel Carrier—Double—Furnished (Retail (Labor Only))	A320	2.0	... 3.50	
Wheel Carrier—Double—Furnish and Install (Labor Only) Includes Wheel, Tire and Tube, Tire Cover and Rear Fender Guard (Allow \$5.00 for old bumper if turned in)	A521	3.0	... 5.25	
Wheel Carrier Lock Plate—Renew (Wood or Steel) Wire Wheel	A522	0.3	... 6.40	
Wire Wheel	626-640-726-740 626-640-808-903	A522	0.3	... 7.05
Wire Wheel Carrier Lock and Key—(For wood)	A523	0.3	... 2.55	
Wire Wheel Carrier Bracket Price—Renew One	A524	0.3	... 3.15	
Wire Wheel Carrier Lock Plate, Lock and Key—Renew Supply One New Key	A525	0.2	... 2.95	
Wire Wheel Carrier Lock—Remove Broken Key— Supply One New Key	A527	0.3	... 12.75	
Wheel Carrier—Side—Supply and Install Two (Labor Only)	A528	0.8	... 2.05	
Wheel Carrier—Side—Supply and Install One (Labor Only)	A529	10.6	... 22.75	
Wheel Carrier—Side—Right or Left—Renew One (Labor Only)	A530	5.3	... 11.40	
Wheel Hub Adapter—Renew Hub (One Wheel)	640-740-840-901 826-840-901-901	A531	0.5	... 1.05
Wood Wheel	826-840-901-901	S228	0.5	... 1.80
Wood Wheel	726-740	S229	0.5	... 2.70
Wheel Hub Cap—Renew One (Material Only)	626-726-826-901 640-645 740-745	S225	... 224 1.40	
Wheel Hub Cap—(cont)—Repack	640-845-903-904	S226	... 1.00	
Wheel Hub—Front or Rear—Chase Thread	L91	109	1.75	
Wheel Hub—Front or Rear—Repack	S257	0.4	... 1.90	

WORMS See Steering

STANDARD SERVICE**Index**

	Symbol	Page	Zone I
WINDOWS - Cont'd			
Window Channel--Replace One Large Channel Out (Labor Only)	B643	0.8	... 5.125
Window Channel--Replace One Small Channel Out (Labor Only)	B645	0.6	1.40 . . .
Window Channels--Remove, Re-cover and Replace (Does Window) (Labor Only)	B642	0.8	5.75 . . .
(Quarter Window) (Labor Only)	B692	1.2	2.65 . . .
Window Channels--Renew Latch (Labor Only)	B693	3.2	7.00 . . .
Window Regulator--Reset	B694	1.5	4.50 . . .
WINDOW GLASS			
Body Rep. Front Glass--Renew--Front or Coupe (Labor Only)	B64	3.0	6.15 . . .
Center Partition Glass--Renew (Labor Only)	B67	2.5	5.95 . . .
Door Glass--Front or Rear--Coupe or Sedan--Renew (Labor Only)	B63	2.0	4.40 . . .
Rear Window Glass--Stop Leak (Labor Only)	B615	1.7	3.50 . . .
Rear Quarter Glass--Renew--Coupe or Sedan (Labor Only)	B65	2.5	4.40 . . .
Window Glass Lower Weatherstrip Rubber--Renew on One Door	B611	0.8	2.25 . . .
Window Glass Lower Weatherstrip Rubber--Renew on Two Doors	B612	1.4	4.45 . . .
Window Glass Lower Weatherstrip Rubber--Renew on Four Doors	B615	3.3	8.00 . . .
WINDSHIELD			
Windshield Cleaner--Install--Renew, Balance, and Replace	B61-640	0.5	1.20 . . .
Windshield Cleaner--Balance on Floor--Renew (Labor Only)	B61-725-640-740	0.2	0.45 . . .
Windshield Glass--Vision--Renew (Labor Only)	B62	0.4	90 . . .
Windshield Glass--Make Operate (Labor Only)	B619	0.3	35 . . .
Windshield Glass--Reset (One Piece Windshield) Open or Closed Bridge (Labor Only)	B67	4.8	11 . . .
Windshield Glass--Renew (One Piece Windshield) Open or Closed Bridge (Labor Only)	B68	2.8	6.15 . . .
Windshield Stopholders--Right or Left--Renew Open Bodies (Labor Only)	B69	1.2	2.65 . . .
Windshield Regulator--Repair (Labor Only)	B612	1.1	3.60 . . .
WINTER ENCLOSURES			
Install Packaged Winter Enclosures--New--Made Up (Labor Only)	B233	6.0	17.50 . . .
Removing Packaged Winter Enclosures--Rear Side Curtains (Labor Only)	B231	5.0	10.50 . . .
Remove Packaged Winter Enclosures (Labor Only)	B232	5.0	10.50 . . .
WINTER SIDES			
Winter Sides--Renew (Insulating Glass Only)	B388
WIRES --See Distributor, Bone, Ignition, Instrument Board, Stop Light or Tail Lamp			
WORMS --See Steering			

