

**ARMY CODE No.
18358**

Issued March 1962

(Reprinted March 1966 incorporating
amendments 1 to 5)

**TRUCK, $\frac{1}{4}$ TON, GS, FFR, 4,
ROVER 8**

**TRUCK, $\frac{3}{4}$ TON, GS, FFR, 4,
ROVER 9**

For Vehicle Contract Nos. See Title Page

USER HANDBOOK

(VEHICLES WITH 24 VOLT
ELECTRICAL EQUIPMENT)

PRODUCED TO THE REQUIREMENT OF
THE MINISTRY OF DEFENCE

ARMY
CODE NO.

RL58

Issued March 1962

(Revised March 1966 incorporating amendments 1 to 5)

TRUCK, 3 TON, GS, FTR, 4x4, ROVER 3

TRUCK, 3 TON, GS, FFR, 4x4, ROVER 3

CONTRACT Nos.
Wpr Office

RL780129

RL781350

RL781362

WV-11

WV-24

WV-147

WV-148

WV-200

WV-1651, Amend 1 and 4

WV-2963

WV-420

WV-450

WV-1382

WV-3654

WV-4628

WV-4636

USER HANDBOOK

STAINLESS STEEL CASE ELECTRICAL EQUIPMENT

Part No. 4154

Ar-11, No. 1, 2, 3 and 5

AMENDMENTS

It is essential that this book be kept up to date with all amendments. Immediately an amendment is received, particulars will be entered hereunder.

No.	Date	Description	Page	Page	Page

April No. 1, 2, 3, 4 and 5

Contents

List of Illustrations	i
Names of Books	xii
List of Associated Publications	xiii

SECTION I

GENERAL DESCRIPTION

Chapter		
1	Introduction	1
	VEHICLE SERIAL NUMBERS	1
	ABBREVIATIONS	1
2	Description of Vehicle	3
3	Uses	5

SECTION II

OPERATION

1.	Controls and Instruments	
	CONTROLS	18
	INSTRUMENTS	26
2.	Operating Instructions	
	BEFORE STARTING OR LEAVING	29
	STARTING THE ENGINE	30
	WHEN THE ENGINE STARTS	31
	STOPPING	32
	GEAR SHIFTING	31
	EXERCISING FOUR-WHEEL DRIVE	33
	PARKING THE VEHICLE	34
	STOPPING RUNNING	34
3.	Special Instructions	
	REMOVING PIPES	35
	MAXIMUM SPEEDS IN ALL GEAR	35
	LIGHT PROCEDURES	35
	LOWEST GEARMENT	35
	FIRE AND SAFETY PRECAUTIONS	35
	TOWING JACKS	36
	TOWING	36
	TOWING EQUIPMENT	36
	DAYS AND NIGHTS	37

CONTENTS (continued)		CONTENTS (continued)	
Chapter	Page	Chapter	Page
SECTION III		3. Fuel System	
USER-SERVICING AND ADJUSTMENTS		Fuel Tanks	
1. Engine		Description	55
Description	34	Checks	55
<hr/>		Fuel Pump and Filter	
Fuel Filter(s)		Description	56
Oil Level	38	Checks	56
Oil Pressure	40	Routine Adjustments and Servicing	56
Engine Oil Changes	45	Clear Fuel Sediment Bowl	56
Oil Filter	40	Fuel Pump Fault Location	57
Engine Breather Filter	4		
Checks	42	Air Cleaner	
Engine Oil Cooler	41	Description	57
Engine Timing		Checks	57
Routine Adjustments and Servicing	42	Routine Adjustments and Servicing	57
Timing Markings	40	Air Cleaner, Change Oil and Clean Bowl	57
To Fit New Timing Chain	44		
Tight Adjustment	47	Carburetor	
Diagnosis		Description	59
Cylinder Head, To Remove	46	Lubrication	59
Inlet Valves, To Remove	48	Checks	60
Outlet Valves, To Remove	49	Routine Adjustments and Servicing	60
Demounting	48	Cleaning Choke/Idle Filter	60
Valve Grinding	49	Carburetor Slow-running Adjustment	61
Reassembling	49	Cleaning Carburetor Jets	61
		Accelerator Pump Operating Rod	61
		Draining the Fuel System	61
2. Cooling System		4. Clutch	
Description	51	Description	61
Regulator Valve	51	Clutch Operation	61
Cooling Fan	51	Clutch and Brake Free Movement	64
Fan Belts	52	Lubrication	64
Checks	52	Routine Adjustments and Servicing	64
Routine Adjustments and Servicing		Clutch Adjustment	64
Generator and Fan Belt Adjustment	52	Master Cylinder, Free Play, to Adjust	65
Draining and Flushing the Cooling System	54	Pedal, Free Play, to Adjust	65
		Bleeding the Clutch System	65

CONTENTS

Chapter	Page
4. Gearbox	
Main Lubrication	67
Description	67
Lubrication	67
Oil Level	68
Hot Oil Control Valve Adjustment	68
Check	68
Transfer Gearbox	
Description	69
Lubrication	69
Oil Level	70
Transfer Gearbox Oil Changes	70
Check	70
5. Propeller Shaft	
Description	71
Lubrication	71
Check	71
6. Rear Axle, Fully Floating	
Description	72
Lubrication	72
Differential Lubrication	72
Differential Oil Changes	73
Check	73
Routine Adjustments and Services	73
Hub Adjustment	73
7. Front Axle	
Description	74
Lubrication	74
Differential Lubrication	74
Differential Oil Changes	74
Level for Housing Lubrication	75
Level for Housing Oil Level	75
Level for Housing Oil Changes	75
Check	75
Routine Adjustments and Services	75
Hub End-Fit Adjustment	75

CONTENTS (continued)

Chapter	Page
8. Steering	
Rear-wheel-drive Rear Type	
Description	76
Steering Box	76
Lubrication	76
Check	76
Routine Adjustments and Servicing	
Rocker Shaft Adjustment	78
Steering Column Adjustment	78
Steering Ball Joints	78
Steering Link Adjustment	78
Front Wheel Alignment	78
Lock Stop Bolt Adjustment	78
9. Brake System	
Description	79
Foot Brake	
Brake and Clutch Fluid Reservoir	80
Master Cylinder	80
Type System	80
Wheel Brake Lining Ranges	80
Wheel Brake Disc - Rotor	80
Brake Pedal	80
Hand Brake	80
Lubrication	80
Check	80
Routine Adjustments and Servicing	
Wheel Brake Adjustment, Rotor B	80
Wheel Brake Adjustment, Rotor D	80
Master Cylinder Adjustment	80
Hand Brake (Friction Brake) Adjustment	80
Bleeding the Brake System	80
10. Chassis and Suspension	
Description	
Chassis Frame	80
Front Bumper and Bumpers	80
Suspension	
Description	80
Check	80

Chapter		Page
12	Wheels and Tires	
	WHEELS	
	Description	91
	Checks	91
	Routine Adjustments and Servicing	
	Wheel Chaining	92
	Tires	
	Description	
	Tire Grades	92
	Factors Affecting Tire Life	93
	Checks	93
	Routine Adjustments and Servicing	
	Tire Pressures	95
	Changing Wheel Position	95
	Tire Removal	96
	Tire Replacement	96
	Wheel and Tire Balance	97
13	Electrical Equipment	
	Suppression of Unwanted Interference to Radio Services	97
	Ignition System	
	Distributor	
	Description	97
	Lubrication	98
	Checks	98
	Routine Adjustments and Servicing	98
	Clean and Adjust Distributor Points	99
	To Adjust Ignition Timing	99
	Ignition Coil	100
	Fitter Unit	100
	Sparking Plugs	100
	High Tension Cable	101
	Batteries	
	Description	101
	Checks	102
	Routine Adjustments and Servicing	102
	Topping-up Vehicle and Radio Batteries	103
	Charging Equipment	103
	Refractory Battery Construction	104
	Lighting System	
	Generator CAN Type A.C. 124.1	
	Description	104
	Generator No. 10 Mk 2	104A
	Lubrication	104B
	Checks	104B

Chapter		Page
	Motor	
	Description	105
	Generator Parts CAN Type 124.1	
	Description	106
	Servicing	105A
	Generator Parts No. 9 Mk 1	
	Description	106A
	Servicing	106A
	Description of W. Amp. Generator System	
	Fuse Boxes	
	Description	107
	STARTER Motors	
	Description	108
	Checks	108
	Routine Adjustments and Servicing	109
	Check Starter Motor Brush Gear Commutator	109
	Commutator	109
	Starter Supplement Switch	
	Description	109
	Horns	
	Description	109
	Checks	109
	Routine Adjustments and Servicing	109
	To Adjust	109
	Buses, Kebab	
	Description	110
	Windscreen Wipers	
	Description	110
	Wipers	
	Description	111
	Checks	111
	Routine Adjustments and Servicing	
	Headlight Lamp Replacement	112
	Headlight Setting	112
	Side-Light Stop and Turnlight Lamp Replacement	113
	Number Plate Light Lamp Replacement	114
	Instrument Panel and Warning Light Lamp Replacement	114
	Convex Light Lamp Replacement	114
	Water and NATO Trailer Plug Sockets	114

Chapter		Page
14	Billings for Main Stages	
	General	115
	FFR Equipment	118
	To Demolition of FFR Equipment	125
	FFR Equipment to be Transferred	127
	To Other FFR Equipment	127
15	Body	
	Description	129
	Rebars	129
	Spine Wheel	130
	R-16 Clips	130
	Foot Steps	130
	Radio Operator's Seat	131
	Foot Rests	131
	Wardroom	131
	Wardroom Wiper	131
	Wardroom Wiper Motor and Wiper Blades	131
	Wardroom Washdown	131
	Flare	131
	Tailboard	131
	Clamping Bolt	131
	Rearm Hatch	131
	Seat Belt	131
	Clack	131
	Control Switches	131

SECTION 1A

FAULT-FINDING CHART

Excess Fuel to Start	132
Excess Start Fuel Wastage	137
Excess Minutes	137
Excess Engine Power	138
Excess Fuel	138
Excess Oil	138
Excess Vibration	138
Excess Heat	138

APPENDIX 1

Check References to Starting Operations	141
---	-----

List of Illustrations

Figure No.	Description	Page
1	Vehicle Serial Number	1
2	Engine Serial Number	1
3	Three-Quarter Front View - Rover 1	1
4	Three-Quarter Front View - Rover 9	1
5	General Side View	4
6	General Top View	6
7	Main Start Range Lever	8
8	Transfer Gear Change Lever and Front Wheel Drive Control	18
9	Horn Buzzer	19
10	Starter Switch and Mixture Control (Cold Start)	19
11	Layout of Controls and Instruments	20
12	Hand Throttle Control	22
13	Ignition Switch and Key	22
14	Light Switch (5-Way)	25
15	Headlight Dip Switch	25
16	Instruments Panel (Cold Start)	25
17	Layout of Bell Location, Warning and Warning Light	25
18	Wardroom Wiper Motor	26
19	Impulsion Level Socket	26
20	Fuel Change-over Tap and Switch	26
21	Burner Catches	26
22	Assessment and Fuel Line, 40 amp model	26
23	Assessment and Fuel Line, 90 amp model	26
24	Oil Pressure Gauge	27
25	Speedometer	27
26	Ignition Warning Light	27
27	Mixture Control Warning Light	28
28	Headlight Main Beam Warning Light	28
29	Oil Temperature Gauge	29
30	Mixture Control (Cold Start)	29
31	Main Start Range Lever	32
32	Transfer Gear Change Lever and Front Wheel Drive Control	33
33	7-Cross Top Tower Bracket	36
34	Rotation Tower Head	37
35	Assessment and Fuel Line	37
36	Engine Oil Drain Plug	40
37	Engine Oil Filter	41
38	Engine Breather Filter, 40 amp model	41
39	Engine Breather Filter, 90 amp model	41
40	Engine Oil Cooler	43
41	Engine Markings	44

LIST OF ILLUSTRATIONS—Continued

Page No.	Description	Page
41	Chestnut No. 1 Engine Valve Timing Operation	85
42	Timing Gear Arrangement	86
43	Tapet Adjustment	87
44	Order of Checkmate Cylinder Head Bolts	88
45	Ratchet Lock	88
46	<u>Lubrication Adjustment (Generator)</u>	89
47	Generator Belt Adjustment, 40 amp models	89
47a	Generator Belt Adjustment, 90 amp models	89
47b	Generator and Fan Belt Layout, 90 amp models	89
48	Lean Taps	89
49	Fuel Filler—Twin Fuel Tanks	89
50	Fuel Pump and Sediment Bowl	89
51	Air Cleaner	89
52	Carburetor Face	89
52	Carburetor Adjustment	89
53	Carburetor Jets	89
54	Setting of Valve Timing, 40 amp models	89
55a	Flat-Type Clutch Mechanism	89
55b	Leaf-Type Clutch Mechanism	89
56	Clutch Adjustment	89
57	Clutch Release Bearing	89
58	Block Supply for Clutch Slave Cylinder	89
59	Generator Oil Filter, 40 amp models	89
59a	Generator Oil Filter, 90 amp models	89
59b	Belt Routing, Drive Pulley	89
60	Generator Drive Pulley	89
61	Transfer Belt Lubrication	89
62	Properly Shalt Lubrication	89
63	Transfer Screen on Fully Flushing Wash Man	89
64	Identification of Sintered Differential Units and Axle Shafts	89
65	Rear Differential Lubrication	89
66	Shims, Axle Cross Section	89
67	Front Differential Lubrication	89
68	Special Pre-Lubrication Lubrication	89
69	Special Pre-Lubrication Lubrication	89
70	Special Pre-Lubrication Lubrication	89
71	Special Pre-Lubrication Lubrication	89
72	Steering Box Oil Filler Plug	89
73	Backstop Shaft Adjustment	89
74	Steering Roll Joint	89
75	Adjusting Lock Stop Bolt	89
76	Brake and Clutch Fluid Reservoir	89
77	Wheel Brake Adjustment, Rower 9	89

LIST OF ILLUSTRATIONS—Continued

Page No.	Description	Page
78	Wheel Brake Adjustment, Rower 9, Front	87
79	Wheel Brake Adjustment, Rower 9, Rear	87
80	Transmission Brake Adjustment	88
81	Leaf Clips and U-Bolts	91
82	Driveline Wheel	92
83	<u>Chassis Wheel Position</u>	92
84	Sequence of Tightening Lugnut #08 Nuts	93
85	Electrical Equipment in Engine Compartment, 40 amp Generator	93
85a	Electrical Equipment in Engine Compartment, 90 amp Generator	93a
86	Ignition Timing	91
87	Headlight	91
88	Flywheel Markings	99
89	Spark Plug	100
90	Vehicle Hardware	101
91	Radio Hardware	102
92	Warning Plate, Rectified A.C. System	102
93	Generator, CAV type A.C. 724 I, 40 amp	104a
93a	Generator No. 10 614 2, 90 amp	104b
94	Oil Cooler and Radiator	105
95	Generator Panel, CAV Type 521 2	106
95a	Generator Panel No. 9, 90 amp	106a
96	Fuse Box and Amperage, 40 amp models	97
96a	Amperage, 90 amp models	97
97	Fuse Block on Engine Side of Bulkhead, 40 amp models	98
97a	Fuse Block on Engine Side of Bulkhead, 90 amp models	98
98	Wiper Adjustment	110
99	Washdown Wiper	110
100	Headlight Vertical Dip	111
101	Headlight Spring Hinderbars	111
102	Sixlight and Four Turnlights	111
103	Stop Taillights and Rear Turnlights	113
104	Nameplate Light	117
105	Warning Light, 40 amp models	117
106	Warning Light, 90 amp models	117
107	Acetal Mounting Bracket	117
108	Acetal Mounting Bracket	117
109	Front Wing Strngthening Plate	118
110	Acetal Co-Axials Removed from Damper Socket and Located on Front Wing	119
111	Acetal Co-Axials in Rear Body	119

Page No.	Description	Page
17	Adjusting the Fan and Timing Belts on W-100 Models	19
18	Cable Clips for Front Locking Brakes	20
19	Radio Table	26
19	Radio Reference	27
19	Timing Belts	27
121	Illustrated Glossary	121
122	Operator's Seat	122
129	Amusement and Radio Use - 40 amp models	124
129	Amusement - 90 amp models	124
130	Radio Table - Radio Model	125
131	Position of Battery - Operator Models	127
132	Position of Battery - Table Entry Model	128
133	Holes for Angle Brackets	129
134	Burner Orifices	135
135	Spare Wheel Mounting Bracket	136
139	How Adjustment - Ropes & Cables	137
7	How - Operator's Seat	7
125	Wrenches Using Screws - City models	131
124	Wrenches Using Screws - Am models	131
129	Wrenches - Water Motor	132
130	Wrenches - Generator	132
131	Eye Protectors	133
132	Control Diagram - 40 Amp Generator	134
132	Control Diagram - 90 Amp Generator	134

NOTES TO READERS

The subject of this publication may be affected by Army General Instructions. If possible, a reference should be made to the publication accordingly. When the Instruction regarding any portion of this publication, the Instruction is to be taken as the governing authority.

~~The following page numbers of these 40 and 90 amp models~~

When the suffix figure after Rows 8 and 9, i. e., 82, 91, appears in the nomenclature on the vehicle description plate it indicates the following:

(1) Suffix "1" indicates that strengthened differential axle shafts are fitted to the rear axle only.

(2) Suffix "2" indicates that neither differential axle shafts nor rear axle shafts are strengthened.

When no suffix figure is shown on the vehicle description plate after "Row 8" or "Row 9" it indicates the following:

Row 8 indicates a 50 hp. W. D. model with strengthened front and rear differentials and strengthened rear axle shafts.

Row 9 indicates a 109 hp. W. H. model with strengthened front and rear differentials and strengthened rear axle shafts.

LIST OF ASSOCIATED PUBLICATIONS

Publication	Army Code No.
Paris List	2075
Technical Handbook	UNTR. Wh. Vols. Q-22
Sawing Schedule	1494
Our Handbooks	
Radio Stamps for Rover 8 and 9	1279
Wireless Sender C11	1262
Wireless Stamp No. C32	1119
Wireless Set C13	1156
Wireless Set B47	1179
Receptet Set R210	1201

SECTION I

General Description

CHAPTER I

INTRODUCTION

VEHICLE SERIAL NUMBERS

1. The vehicle serial number, comprising eight digits and a suffix letter, will be found on the insulator box instruction plate on the dash panel over the gearbox cover. It is the same as the chassis number, which is stamped on the left-hand rear spring shackle bracket.

The engine serial number is stamped on the left-hand side of the cylinder block of the engine.



Fig. 1
Chassis Serial Number



Fig. 2
Engine Serial Number

Other unit serial numbers are detailed below, but they should not be quoted unless specifically requested.

Gearbox number. Right-hand side of gearbox casing at rear.

Rear axle. On top of axle casing on left-hand side.

Front axle. On top of axle casing on left-hand side.

NOTE ON LETTERS.

2. Reference is made throughout the text to the "left-hand" and "right-hand" sides of the vehicle, rather than to "near side" and "off-side". The "left-hand" side is that to the left-hand when sitting in the driver's seat.

In some instances the abbreviation "R.H.D." is used to denote right-hand drive.




Fig. 1 Three-wheeled motor vehicle, Patent 2




Fig. 4 Three-wheeled motor vehicle, Patent 3




Fig. 3. General side view
General arrangement

	Barce 8	Slaver 9
A Overall length (incl. hood)	1624 in. (41.1 m)	1953 in. (49.5 m)
B Wheel length (incl. hood)	127 in. (3.25 m)	180 in. (4.57 m)
C Overall width	72 in. (1.82 m)	72 in. (1.82 m)
D Overall height (incl. hood)	173 in. (4.39 m)	174 in. (4.41 m)




Fig. 4. General plan view
General Arrangement

	Power K	Power P
P. Wheelbase	68 in. (1.73 m)	109 in. (2.77 m)
L. Track, front	54 in. (1.37 m)	74 in. (1.88 m)
L. Track, rear	54 in. (1.37 m)	54 in. (1.37 m)
M. Length of body (internal)	43 in. (1.09 m)	72 in. (1.83 m)
N. Width of body (internal)	32 in. (0.81 m)	36 in. (0.91 m)

**CHAPTER 2
DESCRIPTION OF VEHICLE**

3. The vehicle drive on the rear wheels with the option of front wheel drive when conditions make it necessary to drive on all four wheels. The description that follows applies to all vehicles unless the paragraph states otherwise.

4. Engine, four-cylinder, detachable cylinder head; flywheel mounted on rubber at four points; three crankshaft bearings, four camshaft bearings, overhead inlet and exhaust valves operated by followers and push rods; camshaft driven by duplex chain, automatically adjusted by hydraulic tensioner.

5. Lubrication is full pressure from gear type oil pump to all bearings and valve gear, external A.C. full-flow oil filter and an intake filter on the oil pump.

6. Impeller type coolant pump and fan driven from crankshaft, temperature controlled by thermostat, regulated system to decrease flow of coolant under load working conditions.

7. Four-wheel drive is transmitted through spiral bevel gears and normal type differential to the half shafts and thence via enclosed universal joints to the front hubs.

8. The rear axle is of the "fully floating" type, the drive being transmitted by spiral bevel gearing and normal type differential to the axle shafts.

9. The gearbox unit comprises a main gearbox, four forward speeds and a reverse and a two-speed transfer box mounted on the rear of the main gearbox with output shafts to front and rear axle.

10. The suspension is by semi-elliptic leaf springs at both front and rear. An A is integrated in the event of main spring failure. The ends of each second leaf are curled over the bushes to effect a more measure of support until the defect can be repaired.

11. The steering is of the recirculating ball type.

12. Hydraulic brakes on all wheels, with mechanical emergency brake operating on the main drive output shaft from the transfer box.

13. All vehicles have a 24-volt negative earth electrical system with an alternating current (A.C.) generator. Some vehicles give a D output voltage protection with an electrical relay after to convert the A.C. output to direct current (D.C.). Others have a 96 ampere generator with a built-in generator system. A filtered and water-proofed oil cooling system is fitted.

The vehicles are equipped to receive a radio signal and are completely protected to prevent interference to radio. See Chapter 11.

Arabi No. 4

CHAPTER 3

Dimensions	Rover 6		Rover 8	
	Imperial	Metric	Imperial	Metric
Overall length	147 in.	3,733 mm	160 in.	4,064 mm
Overall width	72 in.	1,829 mm	72 in.	1,829 mm
Overall wheelbase height	73 1/2 in.	1,867 mm	73 in.	1,854 mm
Wheel shown screen up	48 in.	1,219 mm	48 in.	1,219 mm
Wheel shown screen down	51 1/2 in.	1,308 mm	51 in.	1,295 mm
Wheel base	36 in.	914 mm	36 in.	914 mm
Track	51 1/2 in.	1,308 mm	51 in.	1,295 mm
Ground body dimensions				
Length, between capings	43 in.	1,092 mm	43 in.	1,092 mm
Width, between capings	54 in.	1,371 mm	54 in.	1,371 mm
Depth	29 1/2 in.	750 mm	29 in.	737 mm
Height of wheelbase	83 in.	2,108 mm	83 in.	2,108 mm
Width of wheelbase to b of axle	112 in.	2,845 mm	112 in.	2,845 mm
Width of flange, between wheel arches	35 1/2 in.	901 mm	36 in.	914 mm
Turning circle	54 ft.	16,461 mm	52 ft.	15,848 mm
Subsides ground clearance	8 1/2 in.	213 mm	9 in.	228 mm
				244 mm

	Metric		British	
	British	Metric	British	Metric
Unladen Fuel, oil, less coolant and fuel Running with coolant, oil, 20 gallon fuel Front axle Rear axle	1,508 lbs.	1,508 kg	3,895 lb.	1,760 kg
	3,690 lbs.	1,674 kg	4,077 lb.	1,849 kg
	4,224 lbs.	1,918 kg	4,205 lb.	1,899 kg
	1,701 lbs.	769 kg	1,474 lb.	668 kg
Laden: * Total, maximum approved gross loaded Front axle Rear axle	4,432 lbs.	2,010 kg	5,705 lb.	2,588 kg
	1,828 lbs.	829 kg	2,140 lb.	971 kg
	2,604 lbs.	1,180 kg	3,565 lb.	1,617 kg
Shipping tonnage: Tread down, tare down	-	-	-	-

* Gross weight with total payload must be reduced by 200 lbs. (91 kg.)

Bridge dimensions	-
Shallow fording depth (optional)	30 in. (762 mm)
Performance	
Average safe speed (maximum)	7-10 m.p.h., depending upon terrain.
Maximum gradient climbable (nally laden)	
Rover 8	Over 1 : 1 (1)
Rover 9	1 : 1 (1)
Range of action on road (average speed 30 m.p.h. (50 km/h))	
Rover 8	350 miles (560 km)
Rover 9	290-360 miles (460-580 km)
Fuel consumption (average) (actual road tests)	
Rover 8	18 m.p.g. (6.4 km/liter)
Rover 9	14-17 m.p.g. (4.9-6.02 km/liter)
Net power/gross weight	
Rover 8	59.7 a.h.p./ton
Rover 9	50.2 b.h.p./ton
Maximum tractive effort—top gear and high transfer engaged (95 per cent efficiency)	
Rover 8	206 lb./ton
Rover 9	160 lb./ton
Tyre size	5.50x16, or 7.50x16 cross-country sps dual purpose.
Tyre pressure (recommended) - Road (normal)	Front 25 lb./sq. in. Rear 25 lb./sq. in.
(Fully laden)	Front 25 lb./sq. in. Rear 30 lb./sq. in.
Cross-country (soft ground—load under 5 cwt.)	Front 15 lb./sq. in. Rear 15 lb./sq. in.
Soft ground—load over 5 cwt.	Front 15 lb./sq. in. Rear 20 lb./sq. in.
(1) Reference to be made to current instructions.	
Wheel type	Divided rim

Capacities

	Imp	Qtrs	U.S. Gals	Liters
Fuel	90	24	40	150
Coolant	17 1/2	21	82	310
Engine sump, 5 pints (11,25 liter) extra when refilling after filling new filter	11	15	6,0	22,5
Overhaul	21	5	1,5	5,5
Transfer box	4	5 1/2	2,5	9,5
Rear axle	1	5 1/2	1,25	4,75
Front axle	1	5 1/2	1,25	4,75
Hydraulic hoists	—	—	—	—
Swivel pin housing (each)	1	1,2	0,5	1,8
Air cleaner	1 1/4	2	0,85	3,15

Engine

Type	Gasoline
Number of cylinders	4
Cylinder arrangement	Vertical in line
Maximum h.k.p. at clutch	72 at 4,250 r.p.m.
Loss of efficiency at altitudes of	
5,000 feet	15 per cent
10,000 feet	24 per cent
Maximum torque	124 lb. ft. (17 kg. m.) at 2,500 r.p.m.
Bore	90,47 mm (3,562 in.)
Stroke	88,9 mm (3,500 in.)
Cylinder capacity	2,246 cc (138,2 cu. in.)
Compression ratio	7.0:1
Tappet clearance (inlet)	0.05 in. (0,25 mm) engine cold or at room temp.
Tappet clearance (exhaust)	0.05 in. (1,25 mm) engine cold or at room temp.
Valve train (No. Exhaust Valve per cyl.)	95° B.T.D.C.

Igition

Distributor (Model)	Lucas type D 75-4A (Screened) Part No. 40753
Distributor contact breaker gap	0.04 in. (0,4 mm) to 0.045 in. (1,14 mm)
Ignition timing (static - full retard)	1 D.C. when using 90-96 octane fuel 1 deg. B.T.D.C. when using 90-95 octane fuel. 2 deg. B.T.D.C. when using 90-96 octane fuel.
Timing order	1-4-2
Coil	Lucas type SC-5
Spark plug (based on Production)	Screened type Champion R5N BPA
Replacement sparking plugs	LV6-MT4-1501 or LV6-MT4-25004
Spark plug point gap	0.015 to 0.018 in. (0,381 to 0,457 mm).

Engine Lubrication System

Type	Full pressure
Oil filter—intake	Gauge pump intake filter in sump.
Oil filter—external	Full-flow filter, AC type: K.F. element AC type FF 50
Oil pump	Gear type, camshaft operated
Oil pressure	45 to 65 lb./sq. in. (3,2 to 4,6 kg/cm ²) at 30 m.p.h. (190 k.t.h.) in top gear with engine warm
Pressure relief valve	55 to 55 lb./sq. in. (3,9 to 4,7 kg/cm ²)

Cooling System

Type	Pressurant, 9 h. sq. in.
Radiator	Fun and tube type
Fan	Light-bladed belt driven from crankshaft
Circulator	By centrifugal impeller type coolant pump
Cooling method	By thermostat. Start to open at 164° (172° F., 73-78°C.), fully open at 193° (197,8°C.)

15

Fuel System	
Fuel pump	A.C. mechanical with sediment bowl.
Carburetor	Down-draught type 5-hole type, 40 P.A. III-2-A
Exhauster jets	Main jet 135 Jet booster pump 65 Choke tube 28 Correction jet 185 Pilot jet 20 Inc. air bleed 1.5 Starter jet, gasoline 185 Starter jet, air 6.5
Air cleaner	A.C. oil bath type with integral centrifugal pre-cleaner.
Filter	Sediment bowl type
Choke	
Type	Single dry plate 9 in. (230 mm) diameter Borg and Beck.
Adjustment	1/4 in. (11 mm) free movement at pedal pad.
Operation	Hydraulic
Main Gears	
Type	Single bevel constant mesh on top, third and second with synchromesh top and third speeds.

Main Gearbox Ratios

	Contract	
	Prior to W/2985	From W/2985 onwards
Top	Over	Over
Third	1.57:1	1.57:1
Second	2.05:1	2.05:1
First	2.96:1	2.96:1
Reverse	3.47:1	3.47:1

16

Unit No. 4

Transfer Gearbox	
Type	Two-speed reduction on main gearbox output.
Free-wheel drive	Two (top wheel) drive controlled on transfer gearbox output.

Transfer Gearbox Ratios

	Contract	
	Prior to W/2985	From W/2985 onwards
High transfer	1.16:1	1.16:1
Low transfer	2.88:1	2.88:1

Front Axle	
Differential	Spiral bevel
Front wheel drive	Enclosed universal joints
Ratio	4.2:1

Rear Axle	
Type	Spiral bevel, fully-floating shafts
Ratio	4.2:1

Overall Ratio Including Final Drive

	Contract		Contract	
	Prior to W/2985		From W/2985 onwards	
	High transfer	Low transfer	High transfer	Low transfer
Top	5.43:1	11.65:1	5.43:1	11.28:1
Third	7.80:1	18.66:1	8.15:1	15.90:1
Second	11.00:1	27.20:1	12.05:1	25.30:1
First	16.30:1	40.68:1	18.45:1	40.60:1
Reverse	13.77:1	32.65:1	16.30:1	34.95:1

Change speeds for all the above ratios. See page 41

Brakes

Front and rear brakes—	
Type	Oiling hydraulics, by leading and trailing shoes.
Size of lining: Length	4 1/2 in. (115 mm)
Width	3 1/2 in. (90 mm)
Total lining area	304 sq. in. (1973.5 cm ²)
Brake drum diameter	10 in. (254 mm)
Brake pedal free movement at master cylinder	3/4 in. (19 mm)

17

Unit No. 4

		Power 3
Front brake—		
Type		Coil spring hydraulic by two leading shoes.
Size of lining: Length		10.45 in. (265.4 mm)
Width		2½ in. (63.5 mm)
Total braking area of linings		94 sq. in. (606.89 cm ²)
Brake drum diameter		11 in. (279.4 mm)
Brake pedal free movement at master cylinder		¾ in. (15 mm)
Rear brake—		
Type		Coil spring hydraulic by leading shoe trailing shoes.
Size of lining: Length		8.6 in. (218.4 mm)
Width		2½ in. (63.5 mm)
Total braking area of linings		77.9 sq. in. (501.64 cm ²)
Brake drum diameter		11 in. (279.4 mm)
Brake pedal free movement at master cylinder		¾ in. (15 mm)

		Power 4 and 5
Rear brake—		
Type		Mechanical on transfer box output shaft
Size of lining: Length		7.69 in. (195.3 mm)
Width		2½ in. (63.5 mm)
Area		27 sq. in. (173.2 cm ²)
Drum diameter		9 in. (228 mm)

		Power 4 and 5
Steering (Re-circulating Ball Type)		
Type		Downman type recirculating
Construction: variable		straight ahead 15.6° left lock 21.6°
Diameter of steering axle		17 in. (431 mm)
Front wheel offset		6 in. (152.4 mm)
Camber angle		1°
Caster angle		1°
Swivel pin inclination		1°
Steering wheel free movement		1 in. (25 mm)

16

Suspension	
Road spring	Semi-elliptic leaf
Hydraulic dampers	Telescopic, non-adjustable, Mater: Woodward-Monroe, Front and Rear

Electrical Equipment System	
	24-volt, negative earth having a certified AC generating system.

	Volvo with 40-Amp generator	Volvo with 60-Amp generator
Radio	Lucas type 31124	Lucas type BT1A
Wiper	200 F 127 40 series	200 F 127 40 series
Clutch	3848	3848
Generator	CAV type AC240	No. 30 M6 2 JV546125
Generator Panel	CAV type 1241	No. 3 M6 2—FV546128
Brake	CAV type SC A 120	CAV type SC A 120
Brake pedal	30-Amp cartridge type	30-Amp cartridge type
Brake pedal	40-Amp (2) SWG (solid contact)	

	Position	Make and Type	Wattage
Headlights (vertical dip)	Lucas No. 368	24	50/50 double filament
Sidelights	Lucas No. 49	24	6
Stop-lamp	Lucas No. 127	24	Double filament 1/40
Instrument panel lights	Lucas No. 450	24	2 K M.E.S.
Warning lights	Lucas No. 450	24	2 K M.E.S.
Console light	Lucas No. 149	24	6
Turnlights	Lucas No. 129	24	24
Number light	Lucas No. 149	24	6

17

Audi. No. 1, 4 and 5

SECTION II
Operation

CHAPTER I
 CONTROLS

Controls

14. The controls and instruments are illustrated in Fig. 11.

Foot

15. Pedal type accelerator, footbrake and clutch with hydraulic clutch operation.



Fig. 7. Multi-gear change lever.

Main Gear Change Lever

16. The lever position for engaging the gears is indicated on the knob of the lever. See para. 48 for gear changing instructions.

Transfer Gearbox Lever

17. The lever controlling the two-speed transfer box is situated to the right of the gearbox cover. It must be pulled right forward for normal high ratio work. See para. 50 for instructions on use of the transfer box.



Fig. 8. Transfer gear change lever and Gear shaft drive control.
 A—Transfer gear change lever. B—Gear shaft drive control.

Front Wheel Drive Control

18. The yellow knob protruding from the gearbox cover, engages the front wheel drive. The operation is described in para. 51.



Fig. 9. Hand brake.

Hand Brake

19. Pulls down through the front of the gear box. To release the brake, pull upwards slightly, depress the button in the top of the hand grip and push down as far as possible; to apply the brake, pull the lever upwards.

Work, Push Button

20. The brass push is on the centre of the steering wheel.



Fig. 10. Starter switch and release control knob (work).
 A—Starter switch. B—Release control knob (work).
 ☐—If start control knob starts warning light.

Starter Switch

21. The starter switch is located centrally on the main instrument panel between the speedometer and instrument group. It is marked "S" for identification purposes and should be depressed to operate the starter motor and released as soon as the engine fires.

Minimum Control (MCM) Switch

22. Marked "MCM Switch" and mounted on the dash panel below the speedometer. See para. 41 for operation.




Fig. 11. Layout of controls and instruments

Fig. 11

Part No.	Part Name	Part No.	Part Name
1	Fare boxes (mounted in vehicles with fare collector)	17	Radar amplifier (used in trucks on vehicles with 90A generator)
2	Vehicle amplifier (used in trucks with 90A generator)	18	Oil temperature gauge
3	Amplifier (used in trucks with 90A generator)	19	Oil pressure warning light
4	Inspection window	20	Main beam warning light
5	Hand level gauge	21	Hand throttle control
6	Wing mirror	22	Main gear lever
7	Roll stop	23	Front wheel drive control
8	Speedometer	24	Mixture control (cold start)
9	Panel lamp switch	25	Mixture control (cold start)
10	Wiper switch	26	Throttle gear change lever
11	Switch for lights	27	Handbrake
12	Ignition key	28	Fuel change over switch
13	Windscreen wiper	29	Dip switch
14	Hand push	30	Clutch pedal
15	Wing mirror	31	Brake pedal
16	Wing mirror	32	Accelerator

NOTE: Control warning light (with control of emergency brake) is not shown.

Head Lamps Control

23. The head lamp control, which is the quadrant type, is mounted just below the instrument panel.

The quadrant has a number of notches for the operating lever. The notch to the extreme right is for use when the head lamp is not required. In order to bring the head lamp control into operation, move the lever to the left into one of the remaining notches.

See Para. 24 for use of the control when various, or various, lighting is required.



Fig. 23. Head lamp control.

Ignition Switch and Key

24. Integral with the light switch (located in a panel on the right-hand side of the instrument panel), and the key (shown in Fig. 25). The key is detachable.



Fig. 25. Ignition switch and key.

This switch controls the engine electrical equipment and the windshield wipers. See wiring diagram.

Light Switch, 6-way

25. Mounted in a panel on the right-hand side of the instrument panel. Also fixed to the panel is an indicator plate showing the switch position.

Stop and turn lights are on at all switch positions except when turned to right, i.e., when turn to left is on.

Turn Switch (right)

First position—foggy light.

Second position—side and corner lights.

Turn Switch (left)

First position—tail and number lights.

Second position—side, tail and number lights.

Third position—head, side, tail and number lights.



Fig. 26. Light switch, 6-way.



Fig. 27. Headlight dip switch.

Headlight Dip Switch

26. When the foot-operated dip switch, located in the left of the clutch pedal, is used it replaces the primary filament in both headlamps by secondary filaments directed downwards or upwards.



Fig. 28. Instrument panel light switch.

Instrument Panel Light Switch

27. The push-pull switch controlling the panel lights, in the top right-hand corner of the panel, is only operative with the light switch in 1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 14, 15, 16, 17, 18, 19, 20, 21, 22, 23, 24, 25, 26, 27, 28, 29, 30, 31, 32, 33, 34, 35, 36, 37, 38, 39, 40, 41, 42, 43, 44, 45, 46, 47, 48, 49, 50, 51, 52, 53, 54, 55, 56, 57, 58, 59, 60, 61, 62, 63, 64, 65, 66, 67, 68, 69, 70, 71, 72, 73, 74, 75, 76, 77, 78, 79, 80, 81, 82, 83, 84, 85, 86, 87, 88, 89, 90, 91, 92, 93, 94, 95, 96, 97, 98, 99, 100.



Fig. 15. Turnlight self-canceling switch and warning light

Turnlight Switch

25. The self-canceling switch, complete with warning light, is attached to the steering column and is controlled by movement of the steering wheel.

When the turnlights are functioning correctly the warning light will flash and the flasher unit will be audible.

Should water or rain accumulate in the other lamp will continue to flash, but the warning light will not glow and the Buzzer will not be heard.




Fig. 18. Washdown wiper motor

A—Water motor; B—Left lead; C—Support for water motor;
D—Lead for suppression; E—Black cover; F—Signal lamp

Washdown Wiper Switch

26. To set the wiper in operation, pull out the blade lever, turn it to clear the switch lever and turn the latter through 90°. To park the Wiper, reverse these operations.

Two washdown wipers are fitted, each is operated independently as detailed above.



Fig. 19. Inspection Light Switch

A—Fuel pressure warning light; B—Inspection Light switch;
C—Fuel gauge.

Inspection Light Switch

26. In the top left-hand corner of the instrument panel are a pair of inspection light switches; the black socket is marked

Fuel Change-over Tap and Switch

27. The combined fuel change-over tap and switch is located on the sea-board. Turn lever to left for L.H. tank and right for R.H. tank. Movement of the control arm sockets on the fuel level tank unit for the particular tank is used and so indicates on the fuel level gauge the amount of fuel in either tank according to the position of the control.



Fig. 20.

Fig. 20. Fuel change-over tap and switch

Heater

28. The heater top panel is secured by two pull-out type catches, one at each side.

To open, remove release catches and raise until it is held open by the support stay. To close, release support stay, lower and secure the bezel with the catches on either side.



Fig. 21. Bezel catches

INSTRUMENTS

Ammeters

23. Situated on the left of the main instrument panel are two ammeters. The upper ammeter is identified by a large label marked "VEHICLE", the lower one is marked "RADIO". On vehicles fitted with a 40A generator the ammeters are graduated 0-40-0 and indicate the charge or discharge currents in the respective batteries. On other vehicles the ammeters are graduated 0-200A and indicate the charging current in the respective batteries.



Fig. 23. Ammeters and fuse box.
A - Vehicle ammeter
B - Radio ammeter
C - Fuse box



Fig. 24. Ammeters.
A - Vehicle ammeter
B - Radio ammeter

Fuel Level Gauge

24. The fuel level gauge, in the multiple panel, only operates with the ignition "on". The gauge is not a precision instrument and cannot be used to derive fuel consumption figures. See para. 21 for fuel level reading.

And No. 7, 1 and 4



Fig. 22. Fuel level gauge.
A - Oil pressure warning light
B - Impersonal gas ticks
C - Fuel gauge

Speedometer

25. A speedometer is situated to the right of the multiple gauge, it indicates the speed of the vehicle and also shows total mileage.



Fig. 25. Speedometer

Ignition Warning Light, vehicles fitted with 40A generator



Fig. 26. Ignition warning light
A - Ignition warning light

25A. The red warning light, at the bottom centre of the multiple panel, glows when the engine is "off" in charge or the generator charging rate is low. It will glow when the engine is switched on and the engine is stationary or running slowly and will go out when the engine speed rises.

Oil Pressure Warning Light, fig. 25A

26. The green light, at the bottom left-hand corner of the panel, glows when the engine oil pressure drops below a preset figure. It will light up when the engine is stationary and fade out when the engine starts and the oil pressure builds up to normal. See para. 20 for further details.

And No. 4

Mixture Control (Cold Start) Warning Light

37. The amber light at the bottom right-hand corner of the panel, glows when the engine is hot and the mixture control (cold start) is "out", thus reminding the driver to park in the control. See para. 45.



Fig. 26. Mixture control (cold start) warning light

- A. Starter switch D. Mixture control (cold start) meter
C. Mixture control (cold start) warning light

Headlight Main Beam Warning Light



Fig. 27. Headlight main beam warning light

38. The one red light at the bottom center of the multiple gauge glows after the main headlight beams are in use, its purpose is to remind the driver to switch off or dip the headlights or enter a brightly-lit area.

Oil Temperature Gauge

39. The oil temperature gauge mounted on a panel at the left-hand side of the instrument panel gives a continuous indication of the oil temperature. The oil temperature should never exceed 90°C and the engine must be switched off and the oil allowed to cool down if this temperature is reached under working conditions.



Fig. 28. Oil temperature gauge

CHAPTER 2

OPERATING INSTRUCTIONS

BEFORE STARTING THE ENGINE

40. Before attempting to start the engine, read the following notes concerning the mixture control (cold start) and accelerator.



Fig. 29. Mixture control (cold start)

- A. Starter switch B. Mixture control (cold start) meter
C. Mixture control (cold start) warning light

Mixture Control (Cold Start)

41. Marked "Cold Start" and mounted on the dash below the speedometer.

It is fully progressive and it is only necessary to pull it out sufficiently to start the engine.

The ball valve position which is indicated when a light flash is felt, would be sufficient to start the engine at temperatures around freezing point.

The control should only be pulled out fully when starting at extremely low temperatures such as 0°F (-17°C) or below.

When the engine has started, the control must be returned to the normal position as soon as possible, consistent with even running.

Accelerator

42. The carburettor is fitted with an accelerator pump, so that when the accelerator is fully depressed, an extra rich mixture is provided to assist acceleration. As this is not required when starting the engine, except under abnormal starting conditions, the accelerator must not be touched when starting with a cold engine.

It may assist starting a hot engine if the accelerator is depressed half-way and then released as soon as the engine fires.

Never pump the accelerator pedal under any circumstances.

STARTING THE ENGINE

43. To start the engine adopt one of the methods detailed below.

(1) Ensure that the main gear lever is in the neutral position and that the transfer lever is in high ratio position (if right-handed).

(2) Start the engine as follows:

(a) Engine cold

(i) Pull the mixture control approximately half way out. (See para. 41)

(ii) Keep the foot on the accelerator.

(iii) Search on the ignition, check that the green oil pressure warning light and, when fitted, the ignition warning light, both glow.

(iv) Press the starter button, when the engine should start after a few seconds. Release the starter button immediately the engine fires.

(b) Engine warm or hot

(i) Set the mixture control right in.

(ii) Depress the accelerator half-way.

(iii) Search on the ignition, check that the green oil pressure warning light and, when fitted, the ignition warning light, both glow.

(iv) Press the starter button.

(v) Release the starter button, remove the foot from the accelerator as soon as the engine fires.

NOTE: If the engine starts a few times when the starter is used to start the engine, the starter button again should be used to start the engine after each of these attempts, to prevent and remove the cause of the failure or the danger involved.

WHEN THE ENGINE STARTS

44. The following points should be noted when the engine starts.

(1) The mixture control must be returned to the normal position as soon as possible, consistent with cold starting.

(2) A glow from the 'Amber Warning Light' on the instrument panel will indicate that the control has been left out in-adequately and must be pushed in at once.

(3) Do not race the engine (over 2500) at moderate speed immediately after starting, as disturbing lubrication of the cylinder walls as the engine warms up.

(4) Check that the green (oil) and, when fitted, the red (ignition) warning lights go out. (See Para. 40 and 35).

Warning Lights

45. Like all mechanical devices, the mixture control warning system is not completely fool-proof and the responsibility for guarding against lamp failure rests with the driver, especially as the warning light may not glow due to lamp failure. Suspected lamp failure may be confirmed by pulling out the mixture control (and start) momentarily when the engine is hot, when the lamp should be illuminated.

To guard against lamp failure in red oil pressure and, when fitted, the ignition warning lights, a check should be made that the lamps glow each time the ignition is switched on.

MOVING OFF

46. Start the engine as detailed in para. 43 and select the appropriate gear. The latter will be dependent upon the type of terrain to be negotiated. (See para. 48, 49, 50 and 51).

After observing the above, proceed as follows:—

(1) Depress the clutch pedal fully and engage first gear. Increase the engine speed slightly, release the hand brake lever and gradually release the clutch pedal. As the engine begins to take the load, increase the engine speed.

(2) Accelerate the engine sufficiently to enable the next higher gear to be engaged without overloading the engine. (See para. 48)

GEAR SELECTION

Main Gear Lever

47. The positions of the main gear change lever are marked on the lever knob. It should be noted that the only reverse stop is a spring on the selector mechanism which tends to hold the lever away from the reverse selector shaft.



Fig. 30. Main gear change lever

Gear Changing

48. Synchronesh gears are provided for changing from second to third, third to top and top to third and in these cases single clutching may be used. For all other changes, it is advisable to use the double clutch method.

Direct experience is gained under differing operating conditions; the following speeds may be used as a guide when changing gear—

	High ratio	Low ratio
First to second	5-8 m.p.h. (8-13 k.p.h.)	Within two or three vehicle lengths of starting
Second to third	13 m.p.h. (19 k.p.h.)	6 m.p.h. (10 k.p.h.)
Third to top	20-25 m.p.h. (31-40 k.p.h.)	10 m.p.h. (16 k.p.h.)

Transfer Box Lever

49. The transfer box gives two ratios in the output train for main gearbox, termed "high" and "low", thus giving a total of eight forward and two reverse speeds in all. It is controlled by the lever to the right of the gearbox cover; this has three positions—right for high ratio, mid-way for neutral and left back for low ratio.

For normal usage and road work the lever should be in the high position. Low ratio is used when the vehicle is to be operated on heavy ground and for heavy pulling.

The neutral position, the lever between "high" and "low" is quite definite and is used with the power take-off for stationary work; the vehicle cannot be driven with the lever in neutral.

Transfer Gear Changing

50. Changing from "high" to "low" transfer ratio should only be attempted when the vehicle is stationary. The engine may be left running, but the main gear lever must be in the neutral position. Depress the clutch pedal and pull the transfer box lever right back, engage the clutch. Should there be any hesitation in the gear engaging, do not force the lever. With the engine running, engage a gear in the main gearbox and let in the clutch momentarily, then return the main gear lever to neutral and try the transfer control again.

Changing from "low" to "high" transfer ratio may be accomplished at any time, regardless of vehicle speed. Release the accelerator pedal, depress the clutch pedal and push the transfer box lever right forward, passing slightly to the neutral position; let in the clutch.



Fig. 31. Transfer gear change lever and drive shaft drive control
A. Forward gear change lever B. Road wheel drive control

ENGAGING FOUR-WHEEL DRIVE

51. If a vehicle may be operated in two-wheel or four-wheel drive as required, the drive to the front wheels is through a dog-clutch in the casing on the front of the transfer box, controlled by the yellow knob on the gearbox cover.

When operating the vehicle in "high" transfer ratio, the drive is normally to the rear wheels only; should conditions call for drive on all four wheels, the driver, increasing with caution or descending a steep, muddy gradient, the front-wheel drive should be engaged by pressing down the knob on the gearbox cover. To return to rear two-wheel drive, on returning to full road speed, slip the vehicle into "low" transfer ratio, gear lever to red knob—and return to "high" transfer ratio, when the dog-clutch is automatically disengaged and the yellow control knob returns to the "up" position.

On surfaced roads, never engage four-wheel drive.

When operating the vehicle in "low" transfer ratio, four-wheel drive is automatically engaged at the same time as "low" ratio is selected; the four-wheel drive is automatically disengaged on engaging "high" transfer ratio.

Low transfer should only be engaged with the vehicle stationary.

PARKING THE VEHICLE

52. Stop the vehicle and apply the hand brake. If the vehicle is standing on a gradient it is advisable to engage first gear in the gearbox.

STATIONARY RUNNING

53. When the engine is operated for stationary running, see para. 45 and 46.

CHAPTER 3

SPECIAL INSTRUCTIONS

RUNNING-IN PERIOD

54. Progressive running-in of a new vehicle is of the utmost importance and has a direct bearing on durability and smooth running throughout its life.

The running-in period is 300 to 175 (225) km, during which time 35-40 m.p.h. (55-65 k.p.h.) in high transfer ratio top gear should not be exceeded. The engine must not be allowed to labour at any time and full use should be made of the inferior gears to ensure that full throttle is not used over to achieve 40 m.p.h. (65 k.p.h.). If the vehicle is used in low transfer ratio when new, 13 (16 p.h.) (24 k.p.h.) should not be exceeded in top gear. Corresponding maximum speeds should be used in the lower gears.

Thereafter, maximum speeds may be increased gradually, but the vehicle should not be driven at prolonged high speeds until it has done 1,000 miles (1,500 km).

Never race the engine above 4,000 at any time during the life of the vehicle.

MAXIMUM SPEEDS IN ALL GEARS AT 4,000 R.P.M.

Gear	M.P.H.	
	High transfer	Low transfer
Top	62	25
Third	45	16
Second	30	12
First	21	8
Reverse	24	10

FIREST PRECAUTIONS

56. In cold weather, when the temperatures may drop to or below freezing point, precautions must be taken to prevent freezing of the coolant in the cooling system.

As a thermostat is fitted in the system, it is possible for the radiator block to freeze in cold weather even though the engine running temperature is quite high.

57. In cold weather, unless the vehicle is kept in a well-heated garage or an engine room has been used, the cooling system must be completely drained. After the coolant has drained out, it is well to run the engine at a fast idling speed for not more than half a minute, so as to dry out any coolant that may have been retained in the bottom of the jacketing.

For draining instructions see para. 97.

Precautions concerning the battery will be found in Chapter 13.

TOWED EQUIPMENT

58. Before commencing to tow, the driver of the towing vehicle and the officer in charge must refer to the User Handbook/Service Schedule of the towed equipment or plant in order to familiarise themselves with —

- (1) Special checks that may be required before starting and during the journey.
- (2) Types of lubricant required for road wheel bearings, etc., and method of application.
- (3) Speed restriction and bridge classification imposed by the nature of the towed equipment or plant.

NOTE — When a vehicle towed in equipment or plant, exceeds the rate of a standard road when the dual classification is usually given, the classification of the tow should normally be taken as the sum of the separate classification of the prime mover and the towed equipment or plant.

FIRE AND SAFETY PRECAUTIONS

59. One fire extinguisher is provided with each vehicle. This is mounted horizontally on the dash panel below the instrument panel.

To operate proceed as follows —

- (1) Tilt the extinguisher from the upright stop with a sharp pull and lift it out of the support cup.
- (2) Hold in one hand and point the nozzle in the base of the container towards the base of the fire.

- 15) With the other hand grip the handle a half-turn to unlock it from the body and pull the handle outwards in an ordinary pumping cycle until the fire is out.

NOTE — The pump has a double-acting seal with spray on the air side and discharge.

- 16) If the fire is extinguished before the liquid content of the unit is exhausted the handle can be relocked in position and the extinguisher used again. It must, however, be replenished as soon as possible.

USE OF JACKS

60. When lifting the vehicle, place the jack under the main spring (below the axle casing) or below the chassis rear cross-member, ensuring that the wheels remaining on the ground are switched.

TOWING

61. Towing depth is given below.
Maximum depth in proper ... 20 in.

TOWING EQUIPMENT

Lifting and Towing Brackets

62. Lifting and towing lugs are incorporated in the front bumper, one on each side of the front bumper.



Fig. 22. Lifting and towing bracket

Rotating Towing Hook

63. This is a rotating towing hook and is attached to the rear of the chassis frame.

64.



Fig. 23. Rotating towing hook

Fig. 23. Rotating towing hook

Bumpers

64. Bumpers are fitted to the front and rear. At the front they incorporate the lifting and towing lugs.



Fig. 24. Bumper, front (detail)

Fig. 24. Bumper, front (detail)

DO'S AND DON'TS

65. Don't keep your foot on the clutch pedal longer than is necessary. It will avoid unnecessary wear.

Don't slacken the clamping nut holding the two halves of the clutch together, unless the tire is fully deflated. This is not applicable when the wheels with well-bare tires are used.

Don't agitate the accelerator pedal when starting the engine.

Don't push a foreign object through the radiator grille as it may clog the radiator, and cause serious damage. This only applies to vehicles fitted with 45% generator.

Do keep radiator filled with clean water.

Do maintain recommended pressures in tyres, including the spare wheel.

Do ensure front panel is fastened before driving away.

66.

SECTION III

User Servicing and Adjustments

GOOD SERVICING IS ESSENTIAL FOR SUCCESSFUL FOLDING.

CHAPTER I THE ENGINE

Description

66. The four cylinder engine has overhead inlet and exhaust valves operated by push rods and rocker levers.
67. The engine is built in unit construction with a dry single-plate clutch and its main and transfer gearboxes, the whole being mounted on four flexible rubber mountings.
68. The crankshaft is carried in three main bearings. At the front of the crankshaft is a pulley which drives the coolant pump and generator, while a spiral damper at the rear, carries the flywheel.
69. Aluminium alloy pistons with two compression rings, and one oil-ring are fitted.
70. The camshaft is driven from the crankshaft by a duplex roller chain and runs on four white metal steel-backed bearings. The chain is kept in adjustment by the hydraulic tensioner.
71. The detachable "hat" cylinder head carries both the inlet and exhaust valves.
72. A removable pressed steel sump carries the oil, which is pressure fed by a gear type oil pump in the sump driven from the crankshaft through screw-gearing, to the main and connecting rod bearings and valve rocker shafts through a gallery pipe in the cylinder block. The oil is cleaned by means of a paper strainer on the pump intake and an external filter on the line.
73. An oil cooler is fitted to maintain the correct running temperature when the engine is run for long periods with the vehicle stationary. See para. 85.

11

74. A thermostat is fitted in the coolant system and the coolant is circulated by means of an impeller type pump, driven by a "V" belt from the crankshaft pulley. The belt tension is adjustable.

75. The fuel supply is by Solex down-draught carburettor, incorporating a two-phase accelerator and economy device.

76. Ignition is by screened coil, the distributor being mounted on an extension of the oil pump driving shaft. Adjustable advance and retard mechanism is fitted, and, in addition, hand-setting facilities are provided to give control over the ignition setting when low quality fuel is used.

77. The sparking plugs are fully screened to prevent radio interference.

ENGINE LUBRICATION

Oil Level

78. A certain amount of oil is contained during the normal operation of the vehicle, the oil in the sump must be checked and replenished daily, in addition to periodic oil changes.



Fig. 20. Engine oil level dipstick

The oil level dipstick is on the left-hand side of the engine and is accessible when the bonnet panel is raised. There are three marks (Full, L. Flow, and Min. Minimum). When using the Land Rover on the road the oil level should not be allowed to fall below the minimum level mark, that is the lower line on the dipstick. However, when using the Land Rover on cross-country work in circumstances which involve a long and so steep angles the oil should not be allowed to fall below the intermediate mark, that is the low level. This will obviate any danger of oil pump starvation when the vehicle is facing downhill at a steep angle. The oil filler is on the right-hand front corner of the engine. (See Fig. 20).

12

35. To check the oil level, proceed as follows:—

Scrub the vehicle as prescribed and allow 30 minutes for the oil to drain back into the pump from the sump gear, etc. Wipe the dipstick assembly, wipe a clean measure to its full depth and remove a second time to take the reading. Add oil as necessary, never fill above the H mark.

Oil Pressure

36. The oil pressure warning light (on instrument panel) will glow when, for any reason, the pressure drops below 10 to 12 lb. sq. in. (0.7 to 0.8 kg/cm²). It will light up when the engine is stationary and will go out when the engine has started and the oil pressure has built up to exceed this figure.

NOTE.—The light may flicker when the engine is running at idling speed, but provided it lights up, immediately the engine is started up, the oil pressure can be considered satisfactory.

Should the warning light appear at any time when the engine is running above idling speed, stop the engine immediately and investigate the cause; usually it will be due to low oil level in the sump, or occasionally, to a choked oil pump intake filter.



Fig. 36. Engine sump drain plug
A. Drain plug.

Engine Oil Changes

37. To change the engine oil, proceed as follows:—

Run the engine to warm up the oil, screw off the inspection and remove the drain plug in the right hand side of the sump. Allow time for the oil to drain away completely and replace the plug.

Refill with oil at the correct grade through the filter in the front of the engine, the capacity is 11 litres (approximately) (see page 24).

It is essential to add a further 2 litres (2.2 litres) of engine oil after the full flow filter element has been changed, to bring the oil level up to the High level mark on the dipstick.

Oil Filters. (Type carried out by a self-priming pump.)

38. In addition to the gauge pump-pickle filter on the sump, the oil is cleaned by means of a full-flow pressure filter mounted externally on the engine.

The elements of the full-flow filter should be removed at regular intervals, preferably at a routine oil change.

To remove the external filter element proceed as follows:— Place oil into under the filter. Unscrew the body in the bottom of the filter container and remove the container complete with the filter element. Remove and discard the used filter element and fit a new rubber washer. Wash the residual in kerosene. Place the new filter element in the container and reassemble the unit using the new O-ring rubber washer supplied with the element. Ensure that all the sealing surfaces are in position and ensure that the container is accurately seated in the top cover.

Re-fill with correct grade of engine oil and run engine for five minutes, then check for leaks. Check oil level and top-up, if necessary.



Fig. 37. Engine oil filter.

Engine Breather Filters

39. To prevent water, dirt, etc. being fitted to the top rocker cover breather and oil filter pipe cap should be changed at regular intervals in the following manner:—

Remove the filter and wash the gauze thoroughly by washing in kerosene. Remove the gauze by dipping in clean engine oil and shake off the surplus; replace the top rocker cover breather (B) with the dust from the front of the vehicle and the oil filter pipe cap (A) with the dust from the rear. (See Fig. 38).



Fig. 38. Engine breather filter
at top rocker
cover.
A. Oil filter cap.
B. Dust from rear.



Fig. 39. Engine breather filter
at top rocker
cover.
A. Oil filter cap.
B. Dust from front.

Checks

64. The following checks should be made:—

- (1) Check the engine pump for oil leaks and the securing bolts for tightness.
- (2) Check the front cover for oil leaks and the securing bolts for tightness.
- (3) Check the exhaust system for oil leaks and the securing cap bolts for tightness.
- (4) Check for leaks at the timing belts and the oil pipe exchanger head to cylinder block at the front of the engine. Check the bolts for tightness.

NOTE: After the bolts have been checked for tightness, no less than 100 gals. oil must be put in. Oil to be replaced.

(5) To be carried out by a vehicle mechanic:

Ensure that the clamps securing the exhaust manifold are tight and correctly positioned. Also check the nuts securing the front exhaust pipe to the manifold, the front exhaust pipe to the intermediate exhaust pipe in front of the rear (left-hand) wheel and the intermediate exhaust pipe to the silencer. Check the exhaust pipe mountings to the chassis side members in front of the rear axle and behind the rear (right-hand) wheel.

(6) To be carried out by a vehicle mechanic:

Check the nuts securing the inter-manifold for tightness. Also check the two nuts securing the carburettor to the manifold for tightness.

(7) Inspect the front engine mountings. The rubber bushes should be free from oil or grease and the mounting bolts tight.

(8) Check the oil filter adaptor for leaks, and the securing bolts for tightness. The gasket washer should be renewed if necessary. Ensure that the bolt at the bottom of the filter is drawn tight and that there is no oil leak at the gasket (Fig. 37).

(9) Check the tension of the fan and generator belts and adjust if necessary. See para. 90.

(10) Ensure that the engine pump draining plug is tight.

(11) To be carried out by a vehicle mechanic:

Check cylinder head bolts for tightness.

Proceed as follows:—

- (a) Loosen the hex nuts.
- (b) Remove air cleaner obstruction base.
- (c) Disconnect the vacuum leads from the pressure plugs.

(d) Remove the top rocker cover.

(e) Tighten the cylinder head nuts in the order shown in Fig. 44. For tightening torque, see para. 90.

(f) Reverse the removal procedure, renewing the rocker 2.5% seal washer if there is any sign of deterioration. Carry out ignition timing. See Chapter 13.

Engine Oil Cooler

45. The oil cooler radiator is mounted in the engine oil system and mounted just in front of the engine coolant radiator, see para. 67. A gauge on the dash panel gives continuous indication of the oil temperature.

The oil temperature should never exceed 90°C, and the engine must be switched off and the oil allowed to cool down if this temperature is reached under working conditions.



Fig. 44. Engine oil cooler

A. Engine oil cooler. B. Pacific 140A generator vehicle only.

Checks

66. The following checks should be made:—

- (1) Check all pipe connections for oil leaks at oil cooler, engine oil sump, oil filter adaptor and thermometer pocket.
- (2) Check all connections for tightness.
- (3) Check fan belt for proper. See para. 95.

ENGINE TIMING

Routine Adjustments and Servicing

Flywheel Markings

67. Ignition and valve timing is based on markings on the flywheel which are visible, adjacent to a pointer, under the inspection cover on the right-hand side of the flywheel housing.



Fig. 40. Flywheel markings.

The markings and their meanings are as follows.—

- (1) The line against which the letters "T.D.C." are stamped when brought opposite the pointer, indicates that No. 1 (left) piston is at top dead centre, *i.e.* at the top of its stroke.
- (2) The line against which the letters "T.D.C." are stamped is also used for ignition timing, that is the position at which the distributor points should be just in phase with the gear in the firing position on No. 1 cylinder. For ignition timing details see page 12.
- (3) The line against which the letters "E.P." are stamped when set opposite the pointer, indicates the point at which No. 1 exhaust valve should be at the peak of its lift (usually open 90° before T.D.C.).

To Fit New Timing Chain. (To be carried out by a repair mechanic)

RE. Proceed as follows:

- (1) Drain and remove radiator.
- (2) Remove the air and generator belts.
- (3) Remove spark plug damper.
- (4) Remove timing chain cover in order with water pump.
- (5) Remove the distributor drive gear.
- (6) Remove the piston and rings.
- (7) Remove the camshaft into the dust cover and remove the piston and rings. (The distributor is removed in the next job and the tappet clearance is 0.075 in 0.025 mm.)
- (8) Fit a dial test indicator so that the "fully open" position of the valve can be ascertained in the following manner—

(9) The use of a dial indicator is the only reliable method of determining lift point. It should be mounted on a pad (shown in No. 1 exhaust rocker and with its aid the possibility of its being in determining the exhaust peak is eliminated. It is possible to do the job correctly without a dial indicator, but much time is wasted and the possibility of an error is very much magnified.

(10) Turn the camshaft in direction of rotation until the tube of cam has nearly opened the valve fully, then stop turning and track the chain and timing raising to record the position.

(11) Note the reading on dial test indicator, then continue to turn the camshaft slowly in direction of rotation until the needle has again reached the same position.



Fig. 41. Checking No. 1 exhaust valve "fully open" position.

(12) Mark the camshaft at a point opposite to the mark on timing casing and make a third mark on the camshaft, exactly between the two marks previously.

(13) Turn the camshaft against direction of rotation until the third mark is in line with the timing casing, whereon the screw should be fully open.

(14) Fit timing chain with "no slack" on the drive side. It may be necessary to remove and re-position the distributor camshaft to obtain this "no slack" condition on the drive side when the flywheel and distributor are correctly mounted.

(15) Fit the compression spring over piston, locate the spring assembly, compress the spring and hold in compressed position.




Fig. 41. Timing gear adjustment

Place the idler wheel on pin on spindle and offer the assembly to the cylinder block, locating by means of the dowels. Also ensure that the spigot for the idler wheel spindle on the piston is correctly located in the slot on the cylinder block. Screw the adjuster bolt with washer and spring in position into cylinder block, then finally secure with set bolt and nut. Release the spring and allow the idler wheel to take up the chain slack.

- (16) Turn the flywheel against direction of rotation and allow it to stop slowly in direction of rotation, checking that the exhaust valve reaches the "fully open" position as indicated by the dial revolution counter, when the "F.P." mark on the flywheel is in line with the pointer on flywheel housing.
- (17) Adjust as necessary by means of the flywheel speed screw on the timing chain bed. This adjustment allows a variation of 1.2 to 2.0 mm slack position.

Valve Adjustment. (To be carried out by a skilled mechanic)

It is most important that tappet clearance be maintained at the correct figure and adjustment is therefore provided on each valve rocker. If anything less than the correct clearance is used, a fall in power output will follow, while greater clearance will mean noisy tappets.




Fig. 42. Tappet adjustment

The correct clearance is 0.010 in. (0.25 mm) for both inlet and exhaust valves, with the engine either cold or at starting temperature. The cylinder firing order is 1, 3, 4, 2.

To carry out tappet adjustment proceed as follows:

- (1) Remove the top rocker cover.
- (2) Run the engine with the starting handle in the running direction until the valve that you are about to fully open and then rotate the engine one complete turn to bring the tappet up to the back of the cam.
- (3) Check the tappet clearance with a feeler gauge. If an adjustment is required, slacken the locknut and rotate the tappet adjusting screw up or the clearance is correct, tighten the locknut, holding the adjusting screw in position, if turning feeler the clearance to ensure that it is still correct.
- (4) Repeat for the other valves in turn.

DECARBONIZING

90. (1) (a) (continued) (b) (c) (valve mechanism)

The following procedure should be carried out when decarbonizing:

Cylinder Head, to remove

Joint face "Eco" type gasket.

Copper and brasses. Normal modulus 217 in. Compressed thickness .017 in.

Tightening torque for securing bolts: 4 in. U.N.F. 65 in. lb. (8.9 kg.m) 5/16 in. U.N.F. 12 h. ft. (16.1 kg.m). Engine not for final check.

- (1) Remove the filler cap and open the top of tank of radiator and drain the coolant from this point only.
- (2) Remove spare wheel and (c) battery panel cover.
- (3) Remove the oil cleaner and carburettor or intake pipe complete.
- (4) Disconnect throttle return spring linkage, as a ball joint, positive control cable, or clamp-bar; hand throttle control at rail joint.
- (5) Disconnect plug leads, oil feed pipe to head and petrol pipe to carburettor.
- (6) Remove sparking plugs. Disconnect distributor cap and remove (correctly) from side-head of cylinder head.
- (7) Disconnect the hot water hose at radiator, and thermostat by pipe hose.
- (8) Remove governor adjusting nut eye bolt, unscrew locking nut and slide adjusting bolt clear of the cylinder head.
- (9) Remove oil pump cover-head shield and securing nuts for fuel oil pump pipe.
- (10) Unscrew the dome nuts securing rocker cover and lift the cover off.
- (11) Remove the square padlock securing bolts, then pivoting the cover and pistons towards the centre of the rocker cover to allow complete assembly clear.
- (12) Withdraw the pistons, but ensure that they are retained in the correct order for refitment.
- (13) Shift the cylinder head bolts evenly from across their complete width to the end clear.

- (14) Remove the carburettor, intake and exhaust manifolds.

To Remove Inlet and Exhaust Valves

- (15) Using a valve spring compressing tool, remove the valves, valve springs and retaining collars.
Position each valve with its springs and collars together and mark main the bench to create reference in the guide from which they were removed. Inlet and outlet valve springs are a selected interference fit and must not be interchanged.

Decarbonizing

- (16) Remove the carbon from the cylinder head, face and ports and stem from the piston crowns, using a flap scraper.
- (17) Examine the valves and valve guides for wear and repair, as necessary. The guides may be drilled out and new ones fitted.

Valve Grinding

- (18) Grind the valves to 45°—1 exhaust, and 30°—1 inlet, then lap them into their seats. Re-cut valve seats only when necessary and then remove the minimum amount of metal.
- (19) Wash the valve seats and ports thoroughly with kerosene and wipe down with a smooth rag for a new rubber seal in each guide.
- (20) Refit the valves, springs and collars, then pour kerosene into each port and check for tightness.

Re-assembly

- (21) Reverse the removal procedure.
- (22) Refit all joint washers.
The cylinder head gasket must be correctly fitted with the fitting "Petrol 22059" facing the cylinder head, painting compound must not be used.
- (23) Tighten down the cylinder head bolts in the order indicated in Fig. 40. The 4 in. U.N.F. bolts including those that secure the rocker shaft inserts must be pulled down to 65 in. ft. (1 kg.m) 5/16 in. U.N.F. bolts should be tightened to 12 h. ft. (16 kg.m). Engine not for final check.

Damage to the tappet shoes can be caused when refitting the cylinder head and rocker assembly to the cylinder block by rotating the engine before any tappet adjustment is carried out. Excessive tappet clearance at this stage of assembly can allow the pins to be lifted out of the spherical seat and on to the top of the tappet shoe. Further rotation of the engine will then cause the pins to damage the tappet, as the rocker fully compresses the valve spring. It is therefore important that excessive tappet clearance is eliminated as follows:

- Being rotating the engine or the crankshaft after a complete stop-down, adjust all the tappets which are slack.
- Then rotate engine or crankshaft a quarter of a turn at a time. After each movement of the crankshaft adjust any tappets which are slack.
- When the excessive clearance on all the tappets has been eliminated, finally adjust the tappets in the normal manner to the correct clearance.



Fig. 44. Order of adjusting cylinder head valves

1 in bolts to 25 lb. (11.3 kg/m)
 2 in bolts to 12 lb. (5.4 kg/m).

- Carry out ignition timing, start full retard T.D.C. See para 218.
- Adjust the tappet clearances to .010 in (0.25 mm). See para 22.
- Adjust generator belt, para 96.
- Run the engine for a few minutes and check for leaks.
- Finally check the tightening torque of the cylinder head bolts with the engine hot.

CHAPTER 2 THE COOLING SYSTEM

Description

- Coolant enters the pump through a pipe from the bottom of the radiator, and is then forced down into the cylinder block

14

Arch No. 3 and 4

The coolant circulates round the cylinder jackets in the block, from where it rises to the cylinder head. After circulating round the valve ports in the cylinder head casting, the greater part of the coolant passes in the front of the head and on into the thermostat housing. If the thermostat is open, it circulates through the top hose to the radiator.

On vehicles with a 40A generator there are two 1 1/2" type fan belts driven from the crankshaft pulley, one driving the generator, the other driving the water pump and fan.

On vehicles with a 90A generator there are three 1 1/2" type fan belts driven from the crankshaft pulley, two driving the generator, the other driving a water pump and fan.

Radiator Filter

- Access to the radiator filter is gained by lifting the coolant tank.



Fig. 45. Radiator filter

The cooling system is primed and given one final bleed when covering the radiator filler cap, especially when the engine is hot, to avoid steam which may be blown out with considerable force.

When removing the filler cap, first turn it anti-clockwise to the stop and allow all pressure to escape, before breaking it down and turning further in the same direction to lift it off.

When replacing the filler cap it is important that it is tightened evenly all round, not just in the first step. Failure to tighten the filler cap properly may result in water boiling away rapidly, with possible damage to the engine through overheating.

The correct coolant level is one inch below the bottom of the filler neck. The total capacity of the system is 17 1/2 Imperial pints (12 litres).

The radiator incorporates an overflow pipe, fitted with a valve, from the filler neck which serves as a steam trap and an inlet to the second filler cap. It also prevents re-filling of the system.

NOTE—Do not over-charge the radiator with coolant water, as this will result in a high water level.

Coolant Pump

- The impeller type coolant pump is mounted on the front of the cylinder block and is belt driven. See para 91.

Arch No. 4

Thermostat

94. Fan belt use the thermostat fitted above the coolant pump casing. Its purpose is to provide rapid warming up by causing the coolant to circulate only round the engine until a pre-determined temperature is reached, when it opens to allow full circulation through the radiator. The unit operates at 162°-191° F (72°-89°C).

Checks

95. Check the following points are page 92.

- (1) Examine the hose connections, which should be free from cracks or signs of peeling. Tighten the hose clips as necessary.
- (2) Examine the cylinder block water plugs for signs of leaks. Renew if necessary.
- (3) Check the following connections for signs of leakage. Tighten manifold to water pipe, inlet elbow to thermostat, inlet pipe to coolant pump.
- (4) Check connection between coolant pump and thermostat housing. Check coolant pump and thermostat housing for signs of leakage.
- (5) Check that the radiator water tap and cylinder block drain tap are fully closed. See para. 97, Fig. 43.
- (6) Ensure that the bolts securing the radiator neck to the grille panel are tight.
- (7) Check that the bolts and nuts securing the fan to the fan pulley are tight.
- (8) Check that the bolts securing the coolant pump and the thermostat housing to the cylinder block are tight.
- (9) Check the fan belt tension and adjust if necessary. See para. 96.
- (10) Check that the radiator block is not damaged.

Routine Adjustments and Servicing

Fan and Generator Belt Adjustment. To be carried out by a qualified Mechanic.

96. As the fan belts are of the "V" type, the drive is on the sides of the belts and it is, therefore, necessary to adjust their tightness and to put on reserve load on the coolant pump and generator bearings. The tension is critical when the belts can be depressed as follows:

Fan belt (to 1 mm) to 1.7 mm)

Generator belt (to belt) (to 1.5 to 1.7 to 1.9 mm)

To check pressure between the two pulleys

(1) Fan belt adjustment (coolant pump)

Fan belt adjustment is by means of a jockey pulley situated on the left-hand side of the engine. See Fig. 45. To adjust:

- (a) Slacken the jockey pulley fixing bolt.
- (b) Slacken the adjustment nut.
- (c) Push the jockey pulley upwards or outwards until the correct tension is obtained.
- (d) Tighten the jockey pulley fixing bolt and adjustment nut.



Fig. 45. Fan belt adjustment (coolant pump)

A—Jockey pulley fixing bolt. B—Jockey pulley adjustment nut.

(2) Generator belt adjustment

Generator belt adjustment is by means of an adjustment stud at the top of the generator. See Fig. 47 and 48. To adjust:

- (a) Slacken the two generator pivot bolts.
- (b) Unscrew the adjuster nut on the generator adjustment stud.
- (c) Adjust by screwing or unscrewing the inner nut until the correct tension has been obtained.



Fig. 47. Generator belt adjustment, 40 mm models.

A—Generator adjustment stud. B—Inner nut for adjustment of belt adjusting stud.



Fig. 47a. Generator belt adjustment, 50 amp model.

A—Generator. B—Adjustment nut. C—Drive nut on adjustment nut.

(2) 90 amp model only. A steady pulley is fitted to the generator belts to prevent oval at fluctuating engine speeds. See Fig. 47b. It is important that the steady pulley is not used for generator belt adjustment otherwise premature bearing wear will occur. If at any time such generator belts are fitted, the steady pulley should be set so that the belts are inside the grooves on the pulley. After positioning the unit so that the pulley can just be turned by hand, but does not distort the belts in any way.




Fig. 47b. Generator and fan belt setup, 90 amp model.

- A—Nut for generator belt adjustment.
- B—Pulley for generator, twin groove.
- C—Pulley for generator.
- D—Check all the nuts on generator belt.
- E—Steady pulley for generator belt, 90 amp model.
- F—Check that pulley, drive pulley.
- G—Pulley for water pump, single groove.
- H—Pulley for water pump, triple groove.
- I—Belt for fan.

16) The generator and fan belt layout on 40 amp models is similar to that used on 90 amp models but there is a single belt drive to the generator and to steady pulley.

Drainage and Flushing the Cooling System

97. As a precaution against corrosion, the cooling system should be drained and flushed out at least once each year in the following manner:

NOTE: The cooling system is pressurized and care must be taken when draining the radiator. Also, be cautious when the engine is hot to avoid burns when the engine oil with considerable heat. When necessary, the oil can be drained into a clean pan to the floor and allow all pressure to escape before draining it into a drain pan or in the tank of water to kill it off.

- (1) Remove the radiator filler cap.
- (2) Open the coolant drain tap at the bottom of the radiator and on the right hand side of the cylinder block at the rear.
- (3) When the coolant flow has ceased, insert a piece of wire in each tap to make sure that a blockage has not been caused by rust or scale.
- (4) Place a hose in the radiator filler neck and adjust the flow of water in equal part draining from the tap.



Fig. 48 (1) Drain tap



(2) Radiator filler neck

- (5) Add the liquid for a short time to ensure thorough filling of the whole system.
- (6) Switch off the engine, turn on the hose and close the tap. Refill the system with clean coolant to the bottom of the filler neck and replace the filler cap. The total capacity is 17½ Imperial pints (10.0 litres).

NOTE: The oil sump sump should be drained and flushed when the engine is started in the next 24 hours.

- (7) Run the engine until working temperature is reached and re-purify the coolant level as necessary.

CHAPTER 3 FUEL SYSTEM

98. The fuel system comprises two tanks, fuel lines, solenoid bowl, pump, carburetor and jet cleaner.

It is most important that the entire system be kept clean and free from fouling.

FUEL TANKS

Description

99. Two fuel tanks are fitted, they are both located under the seat box.

The fuel filler caps are located beneath the locker lids on each side of the seat box, whenever after the seat cushions are removed. When the cap is removed, a telescopic tube may be drawn out of the tank neck and locked by a slight anti-clockwise movement, to facilitate filling. Each tank capacity is 10 Imperial gallons (45 litres).



Fig. 49 Fuel filler tube (left hand)

Checks

100. The following points on the fuel tank should be checked -
 - (1) Check that the bolts securing the tanks to the chassis brackets are tight.
 - (2) Check that the drain plug is tight.
 - (3) Check that the gauge electrical lead fitted to each fuel tank is secure.
 - (4) Ensure that the vent holes on each filler cap is clear.

FUEL PUMP AND FILTER

Description

101. The mechanically operated fuel pump with hand primer, located on the right hand side of the engine, is actuated by a lobe on the camshaft. The selected fuel is delivered to the pump.

Checks

102. The following parts should be checked on the pump—

- (1) Check the inlet and outlet hoses for signs of leakage and tighten if necessary.
- (2) Check for tightness the screws securing the two halves of the pump together, and the bolts securing the pump to the engine.
- (3) Check for signs of a leak from the diaphragm, replace if necessary.

Routine Adjustments and Servicing

Clean filter sediment bowl: To be carried out by a vehicle mechanic.

103. Should the filter become choked with an appreciable amount of foreign matter has collected in the bowl the user should be cleaned as follows—

- (a) Remove the bowl by slackening the thumb screw and swinging the receiver aside.
- (b) Remove and clean filter gauze in gasoline.
- (c) Ensure that the sealing washer is in good condition.
- (d) Replace gauze and re-fit bowl.
- (e) Prime by operating hand lever.



Fig. 48. Fuel pump and sediment bowl.
A—Hand priming lever. B—Filter gauze. C—Sealing washer.
D—Sediment bowl. E—Receiver.

Fuel Pump Troubleshooting

104. If fuel pump trouble is suspected—

- (1) Disconnect the fuel pipe from the carburettor and check that fuel is delivered to the carburettor when the hand lever on the fuel pump is operated. If fuel is not delivered from the pipe—
 - (a) Check that the fuel pipe and fittings are clear.
 - (b) Check that there are no air leaks in the suction line to the fuel pump.
 - (c) Check that the diaphragm is not leaking and that the retaining screws are tight.

Failure to locate and remedy the fault in the manner well indicate that the pump itself is at fault and it should receive workshop attention.

AIR CLEANER

Description

105. The AC oil-bath type air cleaner is mounted on a carrier bracket over the right-hand exhaust manifold, in which it is secured by means of a clamping strap.

An integral centrifugal pre-cleaner separates out the coarse particles of foreign matter. The air passes down a large diameter tube in the centre of the cleaner, at the bottom of which a sharp reversal of direction takes place, thus depositing the majority of the dust into the oil reservoir or the detachable tray forming the bottom of the cleaner. It then passes up through the woven steel packing, while the remaining particles are entrained.

Checks

106. Check the air cleaner as follows—

- (1) Check the operation of the strap and securing the air cleaner.
- (2) Inspect oil in bowl. See para. 107.
- (3) Examine the hose connections. Tighten the clip if necessary.

Routine Adjustments and Servicing

Air Cleaner, Change Oil and Clean Bowl

107. Attention to the oil change is extremely important, especially under dusty conditions, as regular oil changes generally will be seriously affected if the bowl is clogged with an excessive amount of sludge in the cleaner oil bowl.




Fig. 51. Carburetor
A - 111 100-1 B - 111 100-2, 3, 4

Under normal or maximum conditions, the float valve should be checked and refilled periodically. In cases where the vehicle is operated under heavy load or high conditions, adjustment may be more frequent, even to the extent of a daily adjustment. Under extremely hot conditions, checking twice daily may be needed.

Proceed as follows:

- (1) Release the float pump stop securing the float chamber, disconnect the suction pipe from the carburetor, a like pipe by disconnecting the float valve of the float chamber from the vehicle.

- (2) Remove the oil bowl from the bottom of the float chamber by releasing the three securing clips.
- (3) Clean all dirt and sludge from the bowl and refill with test rigging with the level indicated by a ring formed in the casting. The capacity is approximately 1.5 Imperial pints (0.33 liter).
- (4) Clean the filter in the float chamber by skimming the complete body in kerosene and shake off the surplus.
- (5) Replace the float.
- (6) Refill the complete unit to the vehicle.

CARBURETOR

Description

106. This carburetor, type 40 P.A. 105. No adjustment is normally required to the carburetor, and the only maintenance provided is that to obtain smooth engine running.

A gauze filter is provided in the fuel line in the float chamber and this should be removed and cleaned periodically. See Fig. 52.

"Economy"

107. This gives a wider running range mixture and improves the accuracy of measuring under full throttle conditions. At the same time it is non-mechanical in operation, avoiding valves, diaphragms, or other moving parts.

Progressive Fuel Mixture

108. The progressive fuel valve is linked to the carburetor, it is operated by the float stop control and ensures easy and certain starting from cold.

The Accelerator Pump

109. An accelerator pump is provided in the carburetor to eliminate a weak mixture fuel spray during during heavy throttle opening by toping fuel into the engine during the start-over time when running to cruising conditions.

Lubrication

110. The throttle linkage should be lubricated by means of oil at the following points:

- (1) At each link point that all points of contact with sockets.
- (2) The ball points on the ends of the metal shaft to wire shaft, and from wire shaft to cable return.

- (5) Relay shaft at points of contact with brushes.
- (6) Carburetor bell-crank and spindle, or inlet manifold.

Checks

- 113. The following points should be checked on the carburetor:
 - (1) A general examination of the carburetor and pipe line should be made for dirt clogs, for tightness of the unions and securing bolts (check wire condition if necessary).
 - (2) Examine the cold start control cable for any damage that would prevent the control from fully closing the cold start control lever.
 - (3) Check the accelerator and hand throttle linkage for damaged or weak return springs and the throttle restriction mechanism on all vehicles.
 - (4) Examine ball joints for excessive wear and ensure that the levers are secure on the shafts.
 - (5) Check that the spring on the accelerator pump control rod is not broken or weak.
 - (6) Check hose connections on evaporative control. Tighten if necessary.

Carburetor Adjustments and Servicing

114. The carburetor if adjusted on assembly and apart from occasional cleaning of the filter, should require no further attention. The only normal adjustment provided is that to obtain smooth engine idling.

Cleaning Carburetor Filter. (To be carried out by a vehicle mechanic)

115. When necessary, disconnect the fuel pipe from the carburetor and withdraw the gauze filter from the float chamber cover. Clean the filter in gasoline, using a stiff brush.



Fig. 41. Carburetor filter

41

Carburetor Idling-Speed Adjustment. (To be carried out by a vehicle mechanic)

116. It may occasionally become necessary to adjust the idling speed of the carburetor, in which case proceed as follows:—

- (1) Run the engine until fully warmed up the idling with a cold engine.
- (2) Set the idling speed to 700 rev/min and then adjust the idling angle.
- (3) Slowly lean the mixture screw until the engine begins to lean.
- (4) Note that it very gradually and the idling jet disappears.
- (5) If the engine speed is too high, adjust the slow-running screw to slow it down to idling speed or not more than 500 rev/min.
- (6) This may cause a temporary loss of idling. If so, turn the volume control screw gently in a clockwise direction until the idling is once more established.



Fig. 59. Carburetor adjustment
A. Slow-running screw B. Volume control screw

Cleaning Carburetor Jets. (To be carried out by a vehicle mechanic)

117. The jet sizes are given on page 14, Duty Fuel System.

When trouble is experienced with blocked jets, the following notes will assist in location of the jets which need cleaning:—

- (1) Slow jet—the jet passage is tapered into the inner end of the needle which must be removed to get access to the jet.
- (2) Pilot jet has a cross-drill and is in the leakage hole.
- (3) Accelerator pump jet is located above the starter jet.
- (4) Starter jet is a plain hole you can see through the top of the carburetor.
- (5) Under no circumstances should wire be used for cleaning jets. Use compressed air or a sand pump.

42



Fig. 54. Carburetor jet.

A—Mixer jet B—Pilot jet C—Accelerator jet D—Venturi jet.

Accelerator Pump Operating Rod (To be removed only if a repair is necessary.)

120. To adjust:

- (1) Remove the split pin behind the spring and allow the spring to move back along the rod.
- (2) Slacken the slow-running screw right off.
- (3) With the throttle fully closed and the operating lever just about to operate the pump diaphragm, add washers or washers to the end of the rod up to the narrow split pin hole, ensuring that there results a 0.002 to 0.003 inch clearance between the lever and the first washer when the outer split pin is held. (See Fig. 55). This clearance ensures the correct travel of the pump lever.




Fig. 55. Setting carburetor pump operating rod. Showing 0.002 inch clearance.

(4) Compress the spring and replace the inner split pin.

(5) Check that the spring is not coil-bound when the throttle is fully open.

Draining the Fuel System

119. If the vehicle is to be stored for an extended period, the fuel system should be completely drained to prevent the formation of gum in the pump and carburetor. Remove the drain plug from the bottom of each fuel tank and replace when the tanks are empty; then run the engine until the fuel in the pipes (not in each tank) is exhausted.

CHAPTER 4

CLUTCH

Description

120. The Borg and Beck type clutch unit is of the single disc plate type, consisting of a driver plate and a cover assembly.

121. The 1 1/2 inch (38 mm) diameter plate is of the spring type pattern, in which the spring hub is indirectly attached to a disc bearing the main drive force through three drive and three cover-disc coil springs.

122. The cover assembly consists of a pressed steel cover and a cast iron pressure plate loaded by two thrust springs. Mounted in the pressure plate are three operating release levers, which pivot on a casting pin retained by a bolt.

123. The clutch withdrawal mechanism is carried in a housing, bolted inside the bell housing to the front face of the gearbox casing. The withdrawal bearing and clutch release fork are mounted in it from the rear gearbox.

124. Pressure on the clutch release fork, spring-loaded to the cross-shaft protruding from an aperture in the side of the bell housing, is transmitted through the withdrawal bearing and sleeve to the operating lever, to pull the pressure plate from the driver plate.

Clutch Operation

125. The clutch, which is automatically operated, must only be used when starting the vehicle from rest or when changing gear. At all other times the foot should be kept clear of the clutch pedal to avoid unnecessary lining wear.

The clutch, which works on pressure, a perthum lock plate mounted in the disc and operating in reverse, which is used to connect the reverse gear, is connected to the disc by a fitted adjuster in the bell housing. The slave cylinder is connected to the clutch lever by means of a rod, which is push rod.

Clutch and Brake Fluid Reservoir

124. The combined fluid reservoir for the brakes and clutch is mounted above the foot pedals on the right side of the 351s.

Check the fluid level in reservoir as follows—

The level is correct when the fluid is just above the top of the inner reservoir; periodically remove the filler cap and replenish as necessary, making sure that both clutch and brake reservoirs are topped up.

Lubrication

125. The withdrawal housing is filled with oil from the main gearbox casing and triple lubrication is thereby ensured for the three ball bearings; an individual lubrication attention is required for the withdrawal mechanism.

The only regular lubrication attention required for the linkage is to the relay shaft. Lubricate by means of an oil-can the following joints:

- (1) At relay shaft joint.
- (2) Adjuster rod joint pin.

Routine Adjustments and Servicing

Clutch Adjustment. (To be carried out by a service mechanic)

Late models are fitted with a hydraulic clutch, that is a clutch mechanism which is normally set or fixed, assembly to give approximately 1/2 in. (12 mm) free movement at the pedal pad, and which requires no adjustment throughout the life of the clutch plate. Models with the basic type clutch mechanism can be easily identified as follows:

- (a) The support bracket for clutch slave cylinder on early models encloses the cylinder; on late models the cylinder is exposed.
- (b) The operating lever on early models is straight; on late models it is curved.
- (c) The return spring is not fixed to the operating lever on late models.

All these differences are clearly shown in Figs. 55A and 55B.



Fig. 55A

Early type clutch mechanism.

- A—Pedal slave cylinder
- B—Slave operating lever
- C—Return spring for operating lever



Fig. 55B

Late type clutch mechanism.

- A—Exposed slave cylinder
- B—Curved operating lever

Do not adjust the pedal free movement on models fitted with a hydraulic clutch.

126. Early type only. See Fig. 55A. To ensure efficient operation of the clutch unit, there must be free movement to the extent of 2 1/2 in. (32 mm) measured at the pedal pad.



Fig. 56. Clutch adjustment, early models only.

- A—Lower limit rod.
- B—Push rod.

Make frequent air ventings, the operation of hydraulic clutch mechanism is used to prevent slipping and excess wear.

1. Do not use water; thus, the floor of the pedal is in those cases.

2. Move cylinder free plus adjust the pedal return spring.

3. Move cylinder free plus the slightly increase system and adjust the C-12 cylinder return spring.

4. Operating the clutch against the full force of the pedal return spring.

These points must be checked from time to time. If the free movement is increased, adjustment must be made as follows:

Master cylinder free play to adjust. Early and late type clutch mechanism. (7) To be carried out on a vehicle equipped:

- (1) Check the free play between the master cylinder piston and the push rod. (See Fig. 57). This free play should be $\frac{1}{8}$ in. (3.2 mm) if the push rod is left, is approximately $\frac{1}{8}$ in. (3.2 mm) if the road pad. If the movement is less than the given figure.
- (2) Slacken off the locknut and rotate the push rod with the fingers until the correct movement has been obtained.

Pedal free play to adjust. Early type only. (See Fig. 55). (7) To be carried out on a vehicle equipped:

- (1) Slacken the push rod locknut at the slave cylinder. (See Fig. 56).
- (2) Adjust the pedal rod by rotating and the free movement of the pedal is $\frac{1}{4}$ in. (12.7 mm). The total free play is felt as two stages:
 - (a) Light movement of approximately $\frac{1}{8}$ in. (3.2 mm) which takes up the master cylinder free play against the pedal return spring.
 - (b) Slightly heavier movement which should be approximately $\frac{1}{8}$ in. (3.2 mm) which takes up the slave cylinder free play through the hydraulic system and against the slave cylinder return spring.
- (3) When the correct movement of the pedal rod has been obtained secure the push rod with the locknut.

Bleeding the Clutch System. (7) To be carried out by a vehicle owner (unit 129). If the level of the fluid in the combined brake and clutch reservoir is allowed to fall too low or if the pipe has been disconnected, the clutch will not operate correctly due to air having been absorbed in the system. This air lock must be removed by bleeding the hydraulic system of the slave system:

- (a) Attach a length of rubber tubing to the bleed nipple and place the lower end of the tube in a clean jar.
- (b) Slacken the nipple and pump the clutch pedal, pressing at each end of each stroke, until the fluid issues from the tube without sign of air bubbles when the tube is held below the surface of the fluid in the jar.




Fig. 27. Clutch linkage setting.

- A—Pedal pivot adjusting bolt.
- B—Free play against master cylinder push rod. A in 0.1 mm.
- C—Master cylinder push rod locknut.
- D—Master cylinder push rod.
- E—Master cylinder push rod.
- F—Master cylinder push rod.
- G—Master cylinder push rod.

(ii) Hold the tube under the final surface and tighten the steel nut.

(iii) Adjust pedal more into as necessary.



Fig. 28. Final check for clutch slave cylinder.

(iv) The fluid in the reservoir should be replenished throughout the operation to prevent another air-lock being formed. Note particularly that the fluid reservoir for the clutch is the small central tube in the combined reservoir.

CHAPTER 5 GEARBOX

130. The gearbox unit comprises the main gearbox (four speeds forward and reverse), the two speed transfer box and the output shafts to the front and rear axles.

MAIN GEARBOX

Description

131. The complex gearbox is flexibly mounted as a unit with the engine, the main gearbox being offset to the left to allow clearance for the engine side drive. Synchronisation operates on third and top speeds, second speed is through constant mesh helical gears and first and reverse speeds through sliding spur gears. The main gear change lever, centrally mounted, is secured directly to the gearbox casing.

Lubrication

132. The main gearbox and clutch mechanical mechanism are lubricated as one unit.

Oil Level

133. The main gearbox oil level must be checked periodically and replenished as necessary to the bottom of the oil level plug hole. This plug is accessible from under the vehicle; it can be seen when the rubber grommet on the side of the gearbox cover is removed. The filler plug is accessible through the grommet on the gearbox cover.



Fig. 29. Location of filler hole nozzle.

- A—Filler cap.
- B—Oil level plug.
- C—Rubber grommet.



Fig. 30a. Location of filler hole nozzle.

- A—Oil level filler plug.

Bell Housing Drain Plug

134. A plug is provided for fitting into a drain hole in the bottom of the flywheel bell housing to seal it against the entry of mud or water when landing. When not in use, the plug is pressed into a bracket adjacent to the bearing drain hole.



Fig. 59B. Bell housing drain plug

The plug should only be fitted into the drain hole when the vehicle is fording or traveling over very muddy terrain and it must be removed periodically to allow all oil to drain before being replaced.

Transfer Oil Changes

135. To change the oil, remove the drain plug from the bottom of the main gearbox casing, immediately after a run when the oil is warm, allow the oil to drain away completely, then replace the plug. Refill with oil of the correct grade. The capacity is approximately 2 1/2 Imperial pints (13 liters).



Fig. 59. Main gearbox casing

A—Bell housing plug B—Gearbox plug C—Transfer case plug

Checks

136. Check the following points for oil leakage and mounting bolts for tightness. Tighten the bolts and nuts if necessary:

- (1) Bell housing to frame, mating
- (2) Gearbox casing to bell housing
- (3) Top cover to gearbox casing
- (4) Gearbox drain plug

Anti No. 4 and 1

TRANSFER OF ARBOX

Description

137. The rear end of the main gearbox transmits torque into the transfer casing, bolted at right angles to the gearbox. From a gear on the mainshaft, the drive is through an intermediate gear cluster of high and low speed gears on the output shaft. High speed is obtained through constant mesh bevel gears and low speed through a sliding spur gear. Transfer gear changing is obtained via a dog clutch shaft pivoting to carry through the front output housing to the transfer gear change lever on the right of the main case. The transfer control is interlocked with that for the front wheel drive.

138. The rear axle output shaft is bolted to the rear of the output shaft, which passes through the speedometer drive housing. The housing also carries the main rear transmission brake operated by the hand brake lever.

139. The forward end of the output shaft is splined into the sliding member of the front wheel drive dog clutch which, along with the front output shaft, is enclosed in a slip housing on the front of the transfer casing. This housing carries the front bearing for the front output shaft, which is located at its rear end on a phosphor bronze bush running on an extension of the transfer output shaft.

Lubrication

140. The transfer box and front wheel drive housing are lubricated as one unit.




Fig. 60. Transfer box assembly
A—Bell housing plug B—Transfer plug

Oil Level

141. The regular box oil level must be checked periodically and replenished as necessary. Until oil commences to flow from the level plug hole. The level plug is in the rear face of the transfer box and the filler plug on the cover plate on top of the box on the right-hand side (see Fig. 61). Both are accessible when the sea box cover panel is removed.

Transfer Box Oil Change

142. To change the oil, remove the drain plug (see Fig. 60) from the bottom of the transfer box immediately after a run when the oil is warm. Allow the oil to drain away completely, replace the drain plug, then remove the filler and level plugs. Refill with oil to the correct grade. The capacity is 4.4 Imperial pints (2.5 litres).

Checks

143. Check the following points for oil leakage and mounting for tightness. Tighten bolts and nuts as necessary and report oil leakage promptly.

- (1) Bottom cover plate to transfer casing
- (2) Transfer casing to inner gearbox casing
- (3) Rear main shaft bearing housing to transfer casing
- (4) Front output shaft housing to main casing
- (5) Speedometer pulley housing to transfer casing
- (6) Transfer box drain plug
- (7) Propeller box oil level plug

Check front and rear output shafts for sign of leakage. Check the seal ring mountings, situated on either side of transfer box. They should be free from oil or grease and the mounting bolts tight.

CHAPTER 6 PROPELLER SHAFTS

Description

144. The two propeller shafts, of Hardi Special manufacture are identical in design. To accommodate fore and aft movement of the sails and the bow of the engine and gearbox unit, one end of each shaft is provided with a splined sliding joint. Each universal joint consists of a rubber spider, four needle roller bearing assemblies and two yokes.

Lubrication

145. At regular intervals apply oil, using the oil gun, at the lubrication nipple on the sliding portion of the propeller shafts.

Apply oil at the lubrication nipple fitted to the universal joint. It is preferable to use the oil gun, but if high pressure equipment is used care must be taken not to damage the seals in the joints.

A rubber protection is fitted over the sliding splines, to prevent ingress of dirt and water. This does not affect lubrication in any way.




Fig. 62. Propeller shaft assembly
A—Sliding spline yoke. B—Universal joint spider

Checks 170 to be carried out by a watch mechanic)

146. The following points should be checked—

- (1) Periodically check the security of the propeller shaft securing bolts and nuts as necessary
- (2) Check the bearing races and spider joints for excessive wear.
Wear on the three fingers of the bearings can be located by testing for lift in the room, either by hand or with the pig on a bar suitably pivoted.
Any excessive end-to-end wobble of the shaft relative to the flange indicates excessive wear on the roller bearings or the splined joint
- (3) Check the universal joint bearings for oil leaks
- (4) Check the rubber spider seal on propeller shaft is not damaged and is securely fastened

CHAPTER 7
REAR AXLE, FULLY FLOATING




Fig. 47. Cross section of fully floating rear axle.

Description

145. The rear hub is bored on the hub mounting ends on the final axle and many of the parts are interchangeable between front and rear axles. The unit comprises rear hub bearing sleeves bolted to the existing rear axle casing, with the rear hubs fitted in these sleeves and retained by a key, washers, special nuts and lockers in exactly the same way as the front hub.

The non-pure axle shafts are sprung into the differential wheels at the inner end with hub driving members sprung to springs at the outer end. The hub driving members are bolted to the rear hubs and secured to the axle shafts by means of washers, nuts and split pins.

Rear axles, fitted with strengthened differential gears and axle shafts, are identified by a brass or aluminium plate punched to the front end bearing, embossed with a part number. See Fig. 48 and also NOTES TO READER on page 50.



Fig. 48. Identification of strengthened differential axle and axle shafts.

Lubrication

Differential Oil Level

146. The differential oil level must be checked periodically, immediately after a run when the oil is warm and replenished as necessary to the bottom of the filler plug hole. The level filler plug is on the right-hand side of the differential casing. (See Fig. 45).

Differential Oil Change

146. Immediately after a run, when the oil is warm, drain off the oil by removing the drain plug (to the bottom of the axle casing). Replace the drain plug(s) and refill with oil of the correct grade; the capacity of each differential is approximately 3 imperial pints (1.5 litres).



Fig. 45. Rear differential cap/washer.
A. Drain plug B. Level filler plug

Check:

150. Check the following:

- (1) Check that the nuts securing the wheel pinion housing to the axle casing are tight and that there is no oil leak at this point.
- (2) Check that the wheel pinion and hub oil seals do not leak.
- (3) Check that the oil level and drain plug are right.

**Routine Adjustments and Services:
Fully-floating rear axle**

Hub adjustment: (To be carried out by a vehicle overhauler)

151. The adjusting procedure for the rear hub is exactly as that of the front hub. Page 37, Paragraph 46 covers the procedure to be carried out except that items 1 and 3 are not applicable. See Fig. 70.

**CHAPTER 8
FRONT AXLE**

Description:

152. The front axle is a live driving axle of the "fully-floating" type, the drive being transmitted through spiral bevel gearing and conical type differential to the half shafts and thence via universal joints to the wheel hubs.

153. The outer end of each half shaft is splined into the differential assembly while the inner end is carried in a taper roller bearing mounted in a spherical housing secured to the axle casing.

154. The lower wheel pin is mounted in a lower roller bearing carried in a spherical housing, while the upper pin is carried in a spring loaded cone to provide additional steering damping.

155. Vehicles on Contracts prefixed with the letters "WV" have rubber bush type steering dampers.

156. The spherical and conical pin bearings fit over the ends of the axle pin housing, securing the universal joint.

157. The driving shaft is carried in a bush pressed into the hole in stub axle housing of the axised pin housing. Two taper roller bearings support the hub of the truck axle.




Fig. 64. Front axle cross section.

158. A nut and a locknut provide adjustment of the hub end-flare. The drive is transmitted from the driving shaft to the hub by means of a driving member, which also serves to enclose the hub assembly.

Contracts prefixed with the letters "WV" for Models 1 and 9 models are fitted with a strengthened differential at the front. Identification is by a plate attached to the pinion seal housing and embossed with a part number. See Fig. 64 and also **NOTES TO READERS** on page 261.



Fig. 65. Front differential observation.
A. Differential housing. B. Drive pin.

Lubrication

Differential Oil Level

159. The differential oil level must be checked periodically, immediately after a run when the oil is warm, and replenished as necessary to the bottom of the filler plug hole. The front axle level filler plug is at the front of the axle casing.

NOTE—A second plug found in the rear of the front axle casing can be disregarded.

Differential Oil Change

160. See Para. 146, Fig. 45.

Swivel Pin Housing Lubrication

161. The front-wheel drive universal joints and the swivel pin and front hubs, receive their lubrication from the swivel pin housing.

Swivel Pin Housing Oil Level

162. The swivel pin housing oil level must be checked periodically and replenished as necessary to the bottom of the filler level plug holes in the rear of the housing. See Fig. 46.



Fig. 46. Swivel pin housing lubrication.
A—Filler level plug. B—Filler hole.

Swivel Pin Housing Oil Change

163. To change the oil, remove the drain plug from the bottom of the housing (see Fig. 45) immediately after a run when the oil is warm. Allow the oil to drain completely and replace the plug. Refill with oil to the correct grade through the filler level plug holes. The quantity of each grade is stamped directly on the oil can.

Swivel Pin Housing Grease

164. Chamois leather greases fitted to the spherical and swivel pin housings give protection to the ball of the spherical housing. They do not interfere with draining or refilling the swivel pin housing and should not be disturbed when causing out-ride operation.



Fig. 46. Swivel pin housing grease.

A—Grease. B—Regrease. C—Oil. D—Cap.

Checks

165. The following points should be checked:—

- 1) Check that the nuts securing the beam pinion housing to the axle casing are tight and that there is no oil leak at this point.
- 2) Check that the level pinion oil seal, swivel pin housing oil seal and hub oil seal do not leak.
- 3) Check that the balls and nuts securing the axel pins to the housing are tight.
- 4) Check that the balls securing the driving member to the front hubs are tight.
- 5) Check that the differential and swivel pin housing filler and drain plugs are tight.
- 6) Report any oil leakage from the flange joints.
- 7) Check of amon leather greases on swivel pin housing for signs of leakage displacement or loss.

Routine Adjustments and Servicing

Hub End-Bear Adjustment. (Do not exceed out-ride wheel markings.)

166. Check and adjust hub end-bear as follows:—

- 1) Jack up the front of the vehicle and remove the lead wheel and brake drum.

- (2) Drain off the oil from the universal joint housing, remove both drain and filler plugs.
- (3) Remove hub cap (press it on the driving member).
- (4) Place a drip tray below the hub and remove the driving member and joint washer from the stub shaft and the hub.
- (5) Mount a dial test indicator on one of the road wheel studs, using the bracket illustrated at Fig. 70. The total hub movement should be .004 to .006 in. (.10 to 0.15 mm).




Fig. 70. Checking hub end-float.

- (6) Should the end-float prove to be correct, reassemble by reversing the stripping procedure. Replace the drain plug and refill the universal joint housing with oil.
- (7) If the end-float is not correct, prise-up the lockup tabs and unscrew the outer locknut.
- (8) Adjust the inner hub nut, tighten the locknut and again check the end-float. When the hub movement is correct, adjust the locknut and bend over two new tabs of the locking washer. As a safeguard, the end-float should be checked once more after locking the nuts.
- (9) Replace the driving member and joint washer and complete the assembly by reversing the stripping procedure, taking care not to over-tighten the nut securing the driving shaft to the driving member.

- (10) Replace the drain plug and refill the universal joint housing with oil.

NOTE 1—If an oil test system is available, the hub end-float can be satisfactorily adjusted by filling up the adjusting nut until the bearing oil film is visible between the nut and shaft, and to retract the hub to several feet, but without releasing end-float (as presented at described above).

NOTE 2—The oil filler plug located in the driving member of the universal joint, should be not removed unless it is necessary to measure the oil level. After the oil level has been measured, the hub should be in further adjustment of the bearing. With the hub released or the bearing stripped down for any reason, it should be filled and covered with a standard piece of the same grade of oil as used in the differential.



Fig. 71. Oil filler plug with dip.

CHAPTER 9 STEERING

RECIRCULATING BALL TYPE

Description

167. The steering unit is secured to a steering knuckle at the steering knuckle and to a bracket on the dash panel at its upper end. In a recirculating ball type, the inner column fitting a spiral thread on which operates the main nut assembly.

The nut is free to move longitudinally on the steering box. The steering box is fitted with two separable bushes in which operates the rocker shaft. The rocker shaft is attached to the main nut assembly by a fork and roller joint.

168. The 12 in. steering wheel is attached to the inner column and secured by a pinch bolt.

169. A longitudinal steering tube, having left-hand and right-hand threaded ball joints, connects the drop arm to the upper lever of the steering shaft and is mounted on the chassis cross-member below the radiator. This tube and cross-member being loaded with "Torsion" cone springs which damp the steering action and prevent minor road shocks being transmitted to the steering wheel.

170. The lower end of the plug tube is connected to one steering arm by the drag link, which has left-hand and right-hand ball joints. The system is completed by the track rod connecting both steering arms, which is of a similar construction to the drag link.

Steering Box

Lubrication

171. The steering box oil level must be checked periodically and replenished as necessary to the bottom of the filler plug hole on the top cover plate. Access to the plug is gained by lifting the bonnet panel. See Fig. 72.



Fig. 72. Steering box oil filler plug.
A—Filler plug.

Checks

172. The following points should be checked—

- (1) Check for tightness the bolts securing steering box to the chassis bracket.
- (2) Check the side and bottom plates of the steering box for oil leakage and tightness.
- (3) Check that the drag arm, mounted on the steering box, proper action is secure.
- (4) Check steering column for wear or end play. Adjust as necessary (see para. 174).
- (5) Check for tightness the bolts securing the steering column support bracket to dash panel.
- (6) Check end play in master shaft and adjust as necessary (see para. 175).
- (7) Check ball joint for wear. (See para. 173).

Routine Adjustments and Servicing

Master Shaft Adjustment

173. End play in the master shaft may be taken up by means of the adjuster in the top cover plate; need for attention at this point will be indicated by a slight rattle from the steering column.

The adjustment should be carried out after the first 100 miles (1,000 km), but thereafter will only be required at long intervals.

Proceed as follows—

With the road wheels set straight ahead, slacken the locknut and screw the adjuster down by hand until it contacts the top of the master shaft. This setting will not locknut. See Fig. 73.




Fig. 73. Master shaft adjustment.
A—Filler plug. B—Adjuster.

Steering Column Adjustment (To be carried out by a vehicle mechanic)

174. End play in the steering column is taken up by repositioning shims and joint washers under the bearing seats at the steering box.

Wear or end play in the steering unit can therefore be taken up when necessary in the following manner—

- (1) This adjustment will be made more accessible by the removal of the offside front wheel.
- (2) Remove bottom cover of steering box which is secured by 6 bolts only.
- (3) Withdraw bearing cover and remove all shims and joint washers. Take care that the inner column ball races are not disturbed, otherwise it will be necessary to remove the steering and to make replacement to be made.
- (4) Replace bottom cover only and tighten up until no end-play is experienced on rotating the steering shaft. Measure with a feeler gauge the gap that has been caused by the removal of the shims and joint washers.
- (5) Remove bottom plate and insert required number of shims and alternate joint washers, working as possibly that no end-play is apparent.

174. Set wheel and top up steering box and correct grade of oil.

Steering Ball Joints

175. The steering joints have been designed in such a way as to retain the initial filling of grease for the normal life of the ball joints, however that applies only if the rubber boot remains in position on the ball joint. The rubber boot should be checked every 3,000 miles (5,000 km) to ensure that they have not become dislodged or 'fir joint damage'.

To check for wear move the ball joint vigorously up and down. Should there be any appreciable free movement the complete joint must be replaced. Should any of the rubber boots be pulled out of position proceed as follows —

- (1) Remove ball end from lever.
- (2) Remove rubber boot.
- (3) Thoroughly clean all parts.
- (4) Apply suitable grease round upper of ball joint and also fill the boot.
- (5) Reassemble all parts using new rubber boot and springs as required.




Fig. 14. Steering ball joint

Steering Link Adjustment

176. All ball joints are of the non-adjustable type and are secured into the ends of the steering tubes and retained by clips and pins or bolts. Adjustment to each steering link can be made by releasing the ball joint clips and turning the tube to lengthen or shorten the link as required.

Front Wheel Alignment. (To be carried out by a vehicle mechanic)

177. No adjustment is provided for camber, caster or wheel toe inclination.

The toe-in is adjustable. Proceed as follows —

- (1) Set vehicle on level ground with the road wheels in the straight-ahead position and push it forward a short distance.
- (2) Measure the distance between the edges of the rims, at the height of the hub centers, in front of the axle, marking the points by a coin which the measure here is taken.
- (3) Move the vehicle forward until the marks on the rim are in alignment at the rear of the axle.
- (4) Measure the distance between the marks. The measurement at the front of the axle should be $\frac{1}{8}$ to $\frac{1}{4}$ in. (1.2 to 3.4 mm) less than that at the rear.
- (5) If correction is required to the toe-in, slacken the edge securing the ball joints to the track rod, and turn the rod to decrease or increase its effective length as necessary, until the toe-in is correct.
- (6) Tighten the ball joint clips.

Lock Stop Bolt Adjustment (To be carried out by a vehicle mechanic)

178. An adjustable lock stop bolt is fitted to each wheel pin housing and seal retainer.

To adjust —

- (1) Slacken the stop bolt locknut.
- (2) Adjust the stop bolt so that the distance from the head of the bolt to the face of the seal retainer is $\frac{1}{8}$ in. (1.5 mm).
- (3) Tighten the locknut.



Fig. 15. Adjusting lock stop bolt

A—Lock stop bolt. B—Seal retainer

Distance between head of bolt and seal retainer pin is 1.5 mm.

CHAPTER 10 BRAKE SYSTEM

Description

Foot Brake

129. The wheel brakes, operated by a pendant foot pedal, are of the lifting hydraulic type, while the hand brake operates a lifting mechanical brake unit installed on the engine crankshaft in the master foot.

Brake and Clutch Fluid Reservoir

130. The combined fluid reservoir for the brake and clutch is mounted above the foot pedals on the engine side of the dash.

The level is correct when the fluid is just above the top of the inner reservoir, periodically remove the filler cap and inspect, as necessary, making sure that both brake and clutch reservoirs are topped up.



Fig. 10. Brake and clutch fluid reservoir

Master Cylinder

131. The master cylinder is bolted to a bracket on the engine side of the dash.

Line System

132. From the master cylinder a pipe leads to a pressure port on the chassis side member. Two separate pipes lead to each front wheel cylinder via flexible hoses, the third pipe runs to a "T" junction on the rear axle casing, via a flexible hose, secured between the right-hand chassis side member and the rear axle casing. The connection is completed by pipe to the rear wheel cylinder, secured to the axle casing with a 1/2" to 3/4" diameter wing nut, secured to a hole in the axle casing.

Wheel Brake Units—Rover 2

133. Hydraulic wheel brake units with leading and trailing shoes are fitted to each front and rear wheel. The hydraulic cylinders fitted to the front brakes are slightly larger than those fitted to the rear.

The brake shoes pivot at a common point and are free to float at one hydraulic expander and wheel cylinder. Two pistons having pressure seals (poppets) in the wheel cylinder are held apart by a spring which prevents misalignment of the caps and keeps the pistons in light contact with the brake shoes. A bleed screw nipple and non-return valve are provided on the wheel cylinder, access to the nipple being gained from the rear of the anchor plate (Fig. 77). Rubber covers are fitted over the bleed nipple and poppet to exclude dirt and road. Two adjusting screws, one for each shoe, are fitted to each brake anchor plate.

Wheel Brake Units—Rover 3

134. Rover 3 Front. Two leading shoe, an integral operated hydraulically by a tandem wheel cylinder, operated to each other by an external pipe.

Each piston has one pressure seal (poppet) which keeps the piston in light contact with the brake shoe. A bleed screw nipple and non-return valve is fitted in one cylinder, access to the nipple is gained from the rear of the anchor plate. Fig. 78. Rubber covers are fitted over the bleed nipple and poppet to exclude dirt and road. Two adjusting screws, one for each shoe, are fitted to both the front anchor plates. See Fig. 78.

Rover 3 Rear. Hydraulically operated with leading and trailing shoes.

The brake shoes pivot at a common point and are free to float at one hydraulic expander and wheel cylinder. Two pistons having pressure seals (poppets) in the wheel cylinder are held apart by a spring which prevents misalignment of the caps and keeps the pistons in light contact with the brake shoes. A bleed screw nipple and non-return valve are provided on the wheel cylinder, access to the nipple being gained from the rear of the anchor plate (Fig. 79). Rubber covers are fitted over the bleed nipple and poppet to exclude dirt and road. Two adjusting screws, one for each shoe, are fitted to the rear anchor plates.

Brake Pedal

135. The pendant type brake pedal is mounted on the dash and operates the master cylinder by means of a steel push-rod. The adjustment of the push-rod is controlled by the position of the brake pedal, which is mounted on a bracket on the dash and is adjustable.

Hand Brake

136. The hand brake lever is mounted on the rear of the master foot, on the chassis side, and is mounted on the master foot support plate.

The brake shoes pivot on two adjuster plungers and are operated by an expander cone and two expander plungers. The hand brake lever of the normal ratchet type, is mounted on the right-hand chassis side member, and is connected to the relay lever by means of a vertical adjuster rod. The relay lever, mounted on a spindle in the chassis side member, pulls forward the operating rod fixed to the expander cone when the hand brake is operated.

Under adverse conditions it is advisable to engage low-wheel drive as well as applying the hand brake. By this method the hand brake will be effective on all road wheels.

Lubrication

137. The hand brake linkage should be lubricated by means of an oil can at the following points:

- (1) At the connection between hand brake lever and operating rod.
- (2) At the joints on the hand brake bell crank lever.

Checks

138. The following points should be checked:—

- (1) Check the three flexible hoses and the pipe lines for signs of damage and the unions for tightness.
- (2) Check the level of the fluid in the supply tank. See para. 130.
- (3) Check the bolts securing the master cylinder to dash bracket for tightness.
- (4) Check the six screws fixing the brake drums for tightness after the road wheels have been removed.
- (5) Check that the master cylinder push rod has $\frac{1}{8}$ in. (1.5 mm) free movement.

Regular Adjustments and Servicing

Wheel Brake Adjustment, Rear 8. (To be carried out by a vehicle mechanic)

139. When lining wear has reached the point where the pedal travel becomes excessive, it is necessary to adjust the brake shoes in closer relation to the drum.

Proceed as follows:—

- (1) Jack up the vehicle.
- (2) On the back face of the brake anchor plate will be found a hexagon adjustment bolt (Fig. 77) (A), which operates a thrust adjuster bearing on the leading shoe. Only one of these is fitted to each wheel brake and, thereby providing angular adjustment.

- (3) Spin the wheel on a turn table adjuster until the brake shoe contacts the drum, then ease the adjuster until the wheel again rotates freely.

- (4) Repeat for the other rear wheels.



Fig. 77. Wheel brake adjustment, Rear 8, front and rear.
A—Adjustment bolt B—Brake shoe

Wheel Brake Adjustment, Rear 9. (To be carried out by a vehicle mechanic)

140. When lining wear has reached the point where the pedal travel becomes excessive, it is necessary to adjust the brake shoes in closer relation to the drum.



Fig. 78. Wheel brake adjustment, Rear 9, front and rear.
A—Thrust adjuster bolt B—Brake shoe



Fig. 79. Wheel brake adjustment, Rear 9, rear.
A—Adjuster bolt B—Brake shoe

Wash and Worn: Each shoe is independently set by means of an adjuster operating through a serrated metal drum.

- (1) With the wheels jacked up, ensure that the wheels rotate freely; slacken off the adjuster if necessary by turning anti-clockwise.
- (2) Turn the adjuster for each shoe clockwise until the shoe contacts the brake drum, then slacken off until the wheel rotates freely.

Master Cylinder Adjustment: (To be carried out by a vehicle mechanic.)

99. If the free movement on the master cylinder push rod is less than $\frac{1}{8}$ in (1.5 mm) adjust as follows —

- (1) Remove top cover plate from master cylinder mounting bracket.
- (2) Slacken off the locknut and rotate the push rod with the fingers until the correct movement has been obtained.
- (3) Tighten the locknut and re-check the free play.
- (4) Refit the top cover plate.

Hand Brake (Transmission Brake) Adjustment: (To be carried out by a vehicle mechanic.)

102. Periodic adjustment of the transmission brake unit will be required: proceed as follows —

- (1) Release the hand brake.
- (2) Adjustment is made by means of the adjuster wedge spindle (A) (Fig. 101) protruding from the front of the brake back-plate, accessible from beneath the vehicle: during rotation of the adjuster a tick will be felt and heard at each quarter revolution.
- (3) Rotate the spindle as far as possible in a chosen direction, so that the brake shoes contact the drum.
- (4) Then unscrew the adjuster two clicks and give the brake a firm application to transmit the stress: the brake drum should now be quite free to rotate.
- (5) No other adjustment to the hand brake system is necessary as complete for heavy work.




Fig. 101. Transmission brake adjustment.
A. Adjuster.

Bleeding the Brake System: (To be carried out by a vehicle mechanic.)
103. If the level of fluid in the reservoir is allowed to fall too low or if any section of the brake pipe system is disconnected, the brakes will feel "spongy", due to air having been absorbed into the system. This air lock must be removed by bleeding the hydraulic system at the wheel cylinders. Bleeding must always be carried out at all wheels, irrespective of which portion of the pipe line is affected.

- (1) Attach a length of rubber tubing to the bleed nipple on the wheel unit furthest from the brake pedal and raise the lower end of the tube to a glass jar.
- (2) Slacken the bleed screw below the nipple and pump the brake pedal slowly two or three times and then more slowly, pumping it the way it rick stooke until the fluid squirting from the nipple is seen to spurt out as bubbles when the tube is held below the surface of the fluid in the jar.
- (3) Hold the tube under the fluid surface and tighten or hand screw.
- (4) Repeat for the other three wheels in turn, finishing up at the one nearest the brake pedal.
- (5) Readjust the brakes.
- (6) The fluid in the reservoir should be replenished throughout the operation, to prevent air or air getting into the system. Note particularly that the fluid reservoir of the brake is of a different colour to the reservoir of the steering.

CHAPTER 11 CHASSIS AND SUSPENSION

CHASSIS

Chassis Frame

194. The chassis frame is of hot section construction, providing extreme rigidity, and requires no treatment.

Front Bumper and Bumperettes

195. Attached by belts and readily detachable for attention to accidental damage. Bumperettes incorporating front lifting and towing brackets are located on each side of the front bumper.

Rear bumperettes are attached to the rear cross member.

SUSPENSION

Description

196. The suspension is by semi-elliptic leaf springs at both front and rear. As a safeguard, in the event of main spring leaf fracture, the ends of each second leaf are curled over the bushes, to afford some measure of support until the defect can be rectified.

197. The road springs are attached directly to the chassis at the front, while swinging shackles are fitted at the rear ends of the springs. Each shackle pin is mounted through a bonded rubber bush; the bushes do not rotate, angular movement being taken by torsional deflection of the rubber elements. Flexible fabric check straps secured to the chassis side members, are provided to limit the downward movement of the rear axle. To avoid the possibility of the check straps chafing through the rear track plates, scuffing shields are fitted between the axle casing and the road springs.

198. A rubber bump block is secured to the anti-side of the chassis side member above each main spring.

199. Non-adjustable telescopic hydraulic dampers are fitted to each spring; they are secured in rubber mounting bushes in pins in the chassis side members, and rear swing bottom plates. This type of damper incorporates a special seal which prevents leakage of hydraulic fluid, consequently no "topping-up" or other servicing attention is required at any time.

Checks (To be done first by a vehicle mechanic)

200. The following points should be checked.—

- (1) The A. bolt nuts (Fig. 81 (B)) should be tight and the wash-plates correctly seated.

- (2) Examine the spring ends for cracks or displacement and correct as necessary.

- (3) Check that leaf clips (Fig. 81 (A)) are tight.

- (4) Check that all damper retaining nuts are tight.

- (5) Check the spring bushes for excessive wear or damage and replace as necessary.

- (6) Check that the bump rubbers are secure and undamaged, repair as necessary.

- (7) Ensure that the check straps are not excessively worn or damaged, and that the securing belts are tight.

- (8) Check the hydraulic dampers by bouncing each corner of the vehicle in turn. Uniform movement would indicate that no attention is required, but if the damping effect is slight or erratic, the damper should be renewed.




Fig. 81. Leaf clips and bushes.
A. Leaf clips. B. Bushes.

CHAPTER 12 WHEELS AND TYRES WHEELS

Description

201. Divided type wheels are attached to the axle flange at the rear and to the hub at the front by means of five studs and nuts.

Checks

202. The points detailed below should be checked.

- (1) Ensure that the wheel securing nuts are tight.
- (2) Ensure that the clamping nuts which hold the two halves of the wheel together are tight. See para. 201, Fig. 12 for tightening order.



Fig. 12. Double wheel

Routine Adjustments and Servicing

Wheel Changing

203. Proceed as follows:--

- (1) Slacken the double-ended wheel securing nuts.
- (2) Jack up the corner of the vehicle, fitting the jack under the road spring below the axle rating.
- (3) Remove the nut and withdraw the wheel over the studs.
- (4) If available, place a drop of oil on the stud threads, to assist in subsequent removal.
- (5) Fit the new wheel, with the "V" tread directed to the front on the top; tighten the nuts securely and lower the vehicle to the ground.

WARNING—*Double type wheels.* Do not touch the outer ring of nuts painted red unless the wheel is removed and the tyre fully inflated, otherwise severe personal injury may result.

TYRES

Description

204. Dual purpose 6.50 x 14 cross country type are fitted to Rover 4 vehicles and 7.00 x 14 cross-country tread to Rover 9 vehicle.

Tyre Treads

205. The tread pattern of the tyres wears there undamaged. They may be used with the "V" or arrow in the tread pattern pointing towards the top of the wheel, to ensure maximum grip and reduce road draining when operating on wet ground. For the reason, it may be necessary to rotate the spare tyre as its tread (depending on which side of the vehicle it is to be fitted) wears putting it into service.

Factors Affecting Tyre Life

206. The most important factors among many which have an adverse effect on tyre life, are:--

- (1) Incorrect tyre pressures.
- (2) High average speeds.
- (3) Harsh acceleration.
- (4) Frequent hard braking.
- (5) Warm, dry climatic conditions.
- (6) Poor road surfaces.
- (7) Impact fractures caused by striking a kerb or loose brick, etc.
- (8) Incorrect front wheel alignment. Alignment should be checked periodically and adjusted as necessary. See para. 177.

Checks

207. Check tyre pressures, including the spare wheel.

Routine Adjustments and Servicing

Tyre Pressures

208. Butyl synthetic rubber inner tubes are fitted and can be identified by the Bur ring round the valve stem, or the blue valve stem.

- (1) Check the pressure with the tyre gauge, as the pressure is about 2 lb./sq. in. (0.14 kg/cm²) higher at running temperature.
- (2) Always replace the valve caps, so they form a positive seal on the valves.
- (3) Any unusual pressure loss (in excess of 1 to 3 lb./sq. in. (0.07 kg/cm² to 0.21 kg/cm²) per week) should be investigated and corrected.
- (4) Always check the spare wheel, so that it is ready for use at all times.
- (5) Remove embedded stones, etc., from the tyre treads with the aid of a penknife or similar tool. Clean off any oil or grease on the tyre, using pressure sprays.

Changing Wheel Position

209. In the interests of tyre mileage and even wear, it is desirable to change the position of the tyres on the vehicle (including the spare) at regular intervals. The front and rear wheels should be interchanged on each side of the vehicle. At the same time, the spare wheel (see Fig. 15) should be fitted so give a 30 per cent of duty and one of the other wheel's run, to become the spare.



Fig. 83. Changing wheel position

Tyre Removal. Divided Rim Type Wheels

218. Do not touch the pins securing the two halves of the wheel together before the tyre is deflated or serious personal injury may result.

Remove the tyre as follows:—

- (1) Remove the valve cap and core to deflate the tyre.
- (2) Press each bead of tyre away from the flange, using levered and working round the tyre in small steps. Two or three circuits of the tyre may be necessary to free the beads completely.
- (3) Slacken and remove the clamping nut. Remove the upper half of the wheel. Push the valve through the lower half of the wheel and remove the cover and tube.

Minor tyre injuries, such as from nails, require no attention, other than removal of the object, but more severe tread or wall cuts require substituted repairs. Avoid the use of gaskets or liners except as a temporary expedient.

Owing to "butyl" synthetic inner tubes being fitted, all repairs must be retreaded.

Tyre Replacement. Divided Rim Type Wheel

219. Proceed as follows:—

- (1) Thoroughly examine the cover for nails, flats, etc., and ensure that no loose objects have been left inside. Clean the wheel rim flanges and readings.
- (2) Inflate the inner tube until it is just extended out, then with french chalk and level it in the cover with the white spots near the cover head, avoiding any of the black spots on the tube.
- (3) Fit the protection flap, starting at the valve position. Make sure that the edges of the flap are not turned over inside the cover and that it lies centrally between the beads. See that the flap fits closely against the tube round the valve.

4) Lay the matted half of the wheel on the floor or bench with the studs pointing upwards. Fit the cover over the wheel and thread the valve through the hole, making sure that it points downwards.

5) Fit the other half of the wheel and tighten the clamping nut tightly. Finally, tighten the nuts in the sequence illustrated. Check that the valve is free and inflate the tyre to the recommended pressure.



Fig. 84. Sequence of tightening divided rim nuts

Wheel and Tyre Balance

221. Wheel and tyre units are accurately balanced as initial assembly with the aid of small weights secured to the inner side of the wheel rim flange by means of set bolts. In the interests of smooth riding and even tyre wear, it is advantageous to check the balance whenever a tyre is refitted.

CHAPTER 13

ELECTRICAL EQUIPMENT

SUPPRESSION OF ELECTRICAL INTERFERENCE TO RADIO SERVICES

222. The intention of NHT regulations, the services calls for a high standard of vehicle suppression of interference is to be adequately suppressed and full advantage of the sets obtained. Good maintenance of the electrical system is therefore essential. It should be remembered that even if a radio set is not fitted the vehicle electrical system can cause interference to nearby radio sets. Attention to the following points will do much to maintain the required standard of suppression.

(1) Sparking plugs

Ensure that the running surfaces of the plug gasket and cylinder head are clean and that the plug is fitted tightly into the cylinder head.

(v) Ignition leads

- (i) Ensure that connections to the plugs are clean and tight
- (ii) Ensure that the screening is not corroded or frayed. It is continuous and properly earthed at both ends

(vi) Distributor

- (i) Keep all connections and rubbing surfaces tight. It is clean free from dirt, corrosion, and lubricant.
- (ii) Maintain a good contact between green of L 1 and H 1 ignition leads and contact of the distributor which must be properly earthed.

(vii) Coil

- (i) Ensure good, clean and tight connection to all coil leads.
- (ii) Maintain a good metal-to-metal contact free from paint, corrosion and lubricant, between the body of the coil and its mounting and between the junction of the screen.

(viii) Battery

Keep the battery terminals and leads clean and properly wired to provide a good electrical connection

(ix) Earthing and bonding steps

Keep all junctions clean, free from corrosion or paint and ensure that they are tight.

(x) Remainder of electrical systems

- (i) Ensure that there is no intermittent contact on any of the fuses, leads, switches or connections.
- (ii) Ensure that any screening is continuous and is properly earthed at both ends.

(iii) Do not interfere with the vehicle wiring system

(i) Avoid making unnecessary connections to the electrical system

(ii) Avoid tampering with any parts of the electrical system which are not understood

(iii) Do not paint, solder, bond, tape or attach leads or other parts intended to be in electrical contact

(iv) Do not remove any suspension equipment that may be fixed to the vehicle

(v) Refrain from using switches unnecessarily

(vi) Report immediately any defects which may affect the standard of suspension of the vehicle



Fig. 24 Electrical equipment in engine compartment, 1966 motor vehicle

- | | |
|--|---|
| 1. Fuse box, switches feed to NACG socket and warning lights when used | 9. Governor switch (AV type 3002) |
| 2. Turnlight relay | 10. Bonding for suspension |
| 3. Fuse box, A, B, C, fuse and stop light | 11. Motor control switch (MCC) start |
| 4. Fuse box, 32-44, ignition and gear and wiper/washers | 12. Pad change-over for end-over-end |
| 5. Horn relay | 13. Starter solenoid switch |
| 6. Wiper/wash | 14. Screened high voltage leads to ignition |
| 7. Filter unit for fuel | 15. Distributor |
| 8. Air filter | 16. Governor |
| | 17. Rectifier - coils rated with 80A, 60V/15A |

**IGNITION SYSTEM
DISTRIBUTOR**

Description

214. The distributor is mounted on an extension of the oil pump driving shaft. It is of the vee-roset type having a centrifugal advance mechanism which has an operating range of 0-12 degrees over a distributor speed range of 750-2,400 rev./min (1,300-4,400 rev./min engine speed)

115. Further adjustment to the distributor may be made by slackening off the retaining bolts and moving distributor body toward or either B (retard) or A (advance) as shown on the calibrated scale. The standard setting is with the hole in the center of the scale, allowing maximum possible advance and minimum retard. See 1-2-56.




Fig. 21A. Typical equipment in engine compartment. No part indicated.

- | | |
|--------------------|-------------------------------------|
| 1. Key, stop light | 8. Filter for fuel |
| 2. Fuel box | 9. Motor control switch (fuel pump) |
| 3. Key, indicator | 10. Charge air switch (fuel gauge) |
| 4. Fuel box | 11. Starter control switch |
| 5. Fuel box | 12. Starter high voltage switch |
| 6. Relay, horn | 13. Distributor |
| 7. Coil | 14. Governor |

VIA

Aviation No. 1

- (3) The distributor rear detail now corresponds with No. 1 cylinder high tension lead circuit.
- (4) Set distributor adjustment so that the rotating bolt is central between the "A" and "B" marks on the contact side.
- (5) Sacken the pins below the base of the distributor, create the distributor body and the contact breaker points (2) just using with the fibre cam follower on the leading side of the cam, distribute as per Fig. 6.

IGNITION COIL

Description

228. The ignition coil is a 20 volt (or 1000 vms) and to make it suitable for the 24 volt system a ballast resistor is connected in series with the primary winding of the coil. The ballast resistor is braced with the filter coil.

FILTER COIL

Description

229. The filter unit is fitted to suppress interference to radio equipment. It consists of a choke, connected in series with the supply to the ignition coil, and two capacitors connected one across each end of the choke and earth.

SPARKING PLUG

Description

230. The sparking plug is a 14 mm (1/2 in.) reach, 3-piece type with a heater 1000-1500 ohm resistor and a rolled-steel washer. The resistor suppresses interference to radio equipment and also reduces the burning rate of the electrodes.



Fig. 6. Sparking plug

A—Sparking plug. B—Rolled steel. C—Resistor for heating plug

Positive Adjustments and Setting

Claps and Adjust Sparking Plug. (1) Be careful not to rotate crankshaft.

225. As regular overalls run over the claps, clean and if necessary, reset the electrode gaps to .0015 to .0018 in. (.038 to .044 mm) from 1 coil to the second cylinder.

HIGH TENSION CABLES

226. Ensure the correct size glands on each cable to ensure that the contact surface is uncovered and metal-to-metal contact is maintained throughout the ignition system system.

BATTERIES

Description

227. Vehicle and radio batteries are located as follows.

- (1) **Vehicle Batteries.** A negative earth wiring system is used, employing two 12 v. 60 amp. batteries connected in series, giving 24 volts output. They are located at the centre of the seat box between the driver and passenger seats, and are protected by a metal cover secured by two wing nuts. See Fig. 8.



Fig. 8. Vehicle batteries

- (2) **Radio Batteries.** Two 1.5 volt batteries connected in series giving 3 volts output are used for the radio system. They are housed in the body beneath the radio table and are protected by a metal cover. See Fig. 9.

228. The gases liberated from a battery are highly inflammable. Therefore, it is important that electric connections are maintained clean and tight as an insulator against fire.

It is equally important to ensure that the vents in the battery cell filler plugs are open, since, as pressure within the battery cell is produced, if the gases are not able to change cannot escape. A blocked cell vent may result in a burst battery.



Fig. 91. Battery cabinet

NOTE: For full performance on lead acid battery, reference should be made to C/PR's Notes 1379 and 1380.

WARNING: This vehicle is fitted with a sealed AGM battery. See Para. 91.

- (1) The battery enclosure is not always locked and tight.
- (2) Never run the engine without the vehicle being supported by jacks from the upper cross member (see Para. 100).
- (3) The car's battery lead must be removed to be replaced or to be tested. See para. 100.
- (4) Cover the unit adequately when not in use (see para. 100).



Fig. 92. Battery plug, vented AGM system

Checks

227.

- (1) Check the state of charge of the batteries. See para. 225.
- (2) Check that the battery terminals are clean. Clean if necessary by removing the top, and refer to described in para. 200.
- (3) Check that the lead from the battery to starter (to 60) is not damaged and is secured tightly at the starter switch.
- (4) Check that the earth lead is not damaged and has a good connection with the chassis (see member).
- (5) Ensure that the vent holes in the centre of the filler plugs are clear.
- (6) Ensure that the battery clamps and bearings are tight.

100

Battery Adjustments and Servicing

Topping-up Vehicle and Replenish Electrolyte (Two 12 volt in Series)

228. Proceed as follows:—

- (1) Wipe the dirt and remove the filler safety cap.
- (2) Remove the filler plug from each cell in turn. If necessary add sufficient distilled water to raise the level to the top of the separator. Replace the filler plug. Avoid the use of a naked light when servicing the cells.

In hot climates it will be necessary to top-up the battery at more frequent intervals.

In very cold weather it is essential that the vehicle be used immediately after topping-up, to ensure that the distilled water is thoroughly mixed with the electrolyte. Neglect of this precaution may result in the distilled water freezing and causing damage to the battery.

To Check Electrolyte (To be carried out by a senior mechanic)

229. Periodically check the condition of the battery by measuring the specific gravity of the electrolyte in each cell using a hydrometer. Specific gravity readings and their indications are as follows:

1.280 to 1.300 (127 to 140 Baumé) Battery fully charged.

About 1.210 (127 Baumé) Battery about half discharged.

Below 1.180 (127 Baumé) Battery fully discharged.

These figures assume an electrolyte temperature of 60°F (15.5°C). If one cell gives a reading very different from the rest, it may be that water has leaked from that particular cell, or there may be a short circuit between the plates, in which case the battery would be expected to be worked.

Never leave the battery in a discharged condition for any length of time. It should be given a short recharging charge every fortnight, or every 1000 miles, to keep it in the fit state.

Recharging Battery Connections

230. If any battery connections have been loosened for any reason (see para. 100, para. 200 WARNING), they must also be refitted as follows:

- (1) Clean the contact part and connection.

100

b) The brushes are secured to their holders in the end shield of the slip-ring end of the machine, they are secured by means of a pin attached to the cover shaft inside the generator which draws air through the machine via apertures in the end shields.

4. The rotor consists of two laminated and stamped patterns mounted on the shaft to form a 2.500 amp. field coil of 40000 turns around the shaft, and is enveloped by the 12 poles of the rotor, the field current being supplied through carbon brushes and the slip rings which, since the field current is approximately only half amp, will give long and trouble-free service.

(ii) As stated above the generator itself is fed, the field circuit being taken from the positive line of the generator via the regulator (para. 215C(1)).

(iii) The rotor is covered by a ball bearing at the slip-ring end and a roller bearing at the driving end, the bearings being located in a compressed bearing, which are packed with grease XG371 or assembly and require no additional lubrication to be given under normal conditions of the car.

(iv) Water can enter into the body of the unit, but is prevented from reaching the bearing housings and the brush gear assembly from the inside and from the outside by means of oil seals, sealing packets and by the application of water compound to screws and nuts.

(v) The brush gear assembly is enclosed in the bearing housing, the bearing at this end being of the semi-sealed type, the seal being located leaving the brush gear to prevent grease reaching the assembly. The brush gear is covered by an insulating insulating which is bolted to a web of the housing and helps to prevent air bearing from the brush gear.

(vi) Connections to the generator is made via a multi-core plug.

Lubrication, 40A and 90A generators.

212. The generator requires no lubrication to its bearings as they are pre-packed on receipt.

Checks, 40A and 90A generators.

213. The following points should be checked on the generator:

- (1) Check the driving belt, (para. 190).
- (2) Check that the cable number is correct.

mm

(3) Ensure that pilot lights using generator in another location are tight.

(4) Check alignment with nuts for tightness.

NOTE: The field connection of the AC 1241 generator is "alive" when the ignition switch is ON. When checking the generator this switch must be turned OFF.

RECTIFIER, CAV Type RL-3, FOR USE WITH THE AC 1241 GENERATOR.

Description.

124. The rectifier (Fig. 91) used in conjunction with the AC 1241 generator, is a 3-phase full-wave rectifier with selenium elements. It is mounted in front of the engine radiator and is protected by a metal grille. Never push a metallic object through the radiator grille, as it may touch the rectifier, and cause serious damage.

There are three groups of three rectifier cells, each group being connected to the three phases of the generator. (See wiring diagram). The arrangement is such that the generator is connected to the right-hand two of the groups, the three leads of the output side of each of these two groups are joined together and constitute the positive connection to the vehicle and radio harness respectively. The third group is connected in the return circuit, its input side is joined together and connected to "earth" via the current coil of the regulator and its output side is connected to the three phases of the generator.

The generated 3-phase alternating current is therefore rectified and divided into the two battery lead level circuits, the return circuit being as outlined above. If both batteries are connected the generator output is shared between them in an inverse proportion to their state of charge.



Fig. 91. CAV rectifier and rectifier.
A—Full Load; B—Return.

108

**GENERATOR PANEL CAV type 333-2, FOR USE WITH 110K
40 amp GENERATOR**

Description

2M. This generator set is used in conjunction with the AC 224-1 generator. It is found on the left-hand wing surface of the engine compartment. The unit is assembly oriented toward the battery and should require no further attention under normal circumstances.

It incorporates a CAV 'N' type regulator together with associated resistors and radio interference suppression chokes and capacitors.

The regulator is of the current-voltage control type, it consists of a circuit and a voltage regulator (of the open, shunting contact type) mounted on a common base with a vertically disposed support pillar and block to which are secured the two contact assemblies. The regulator controls the position of a contact surface in the generator field circuit to control the generator output.




Fig. 95. Generator Panel CAV type 333-2

- | | |
|----------------------|----------------------------------|
| A—Battery commutator | B—Control spring, front of plate |
| Q—Combs | F—Commutating resistor |
| U—Adjustable contact | G—Capacitor |
| D—Current regulator | H—Choke |
| J—Voltage regulator | |

135A. A normal type circuit is not fitted because the rectifier itself prevents the battery from discharging through the generator when the generator is either stationary or is not delivering a voltage in excess of the voltage in the battery. There is, however, a very small leakage of current through the rectifier which is maintained to adversely affect the battery provided the battery is efficiently and regularly serviced.

NOTE: If the vehicle is not in use it is important to ensure that the discharge does not drain the battery. A more frequent maintenance cycle must be adopted; approximately 21 day intervals is suggested.

Service

135B. Over servicing of the generator panel is not permitted; the panel must not be tampered with.

**GENERATOR PANEL No. 3 MK 3, FOR USE WITH 110K
40 amp GENERATOR**

Description

2PM. Generator Panel No. 3 MK 3 is used in conjunction with generator No. 10 MK 2. It is located on the rear body of the right-hand front corner and is fitted in a bracket attached to the body side above the wheel arch, it is a cast aluminium box with cover housing the control unit for the generator.

(a) The interior of the unit is divided into two compartments, one of which houses a B.C.K. 100 relay and the other the regulator and its associated resistances, high/low voltage setting link and radio interference suppression filter. The partition between the compartments, together with capacitors, provide a radio interference screen around the regulator.

(b) A shunting contact CAV 'N' type regulator is used to control the voltage of the generator, current regulation is inherent in the design of the generator, maximum impedance being related to its rated output of 90A.



Fig. 96. Generator panel No. 3, MK 3

- (c) The regulator contacts are connected in the field circuit, the main operating coil being connected across the output terminals of the generator and hence responds to output voltage.
- (d) The regulator operating voltage can be set to a high or low range by means of the high-low setting line. The low position is for high ambient temperature conditions (typically, the high position is for normal ambient temperatures).
- (e) The CAM BCK 102 relay is fitted to connect the radio batteries when fitted in parallel with the vehicle batteries for charging purposes when the generator is functioning. The operating coil of the relay is connected to the auxiliary regulated output terminal of the generator. Two pairs of contacts are fitted to the relay. These are used to connect the positive line of the generator to the vehicle battery positive connection and to the radio battery positive connection respectively when the relay closes.
- (f) A normal type of contact is not fitted but the relay has a second winding incorporated to work in conjunction with two blocking diodes to hold the relay open in the event of reversed battery connections.

Servicing

235D. Last servicing of the generator pump is not permitted: see panel instructions for tampering with.

Operation of 90 amp charging system

235E. Closing the ignition switch preparatory to starting the engine completes the 235E circuit through the closed contacts of the relay and of the regulator.

- (a) As the engine is started and its speed increases the generated voltage rises and when it reaches 17.2V only the BCK relay closes and the generator positive line is connected to the vehicle and radio batteries. The rate of charge of the two circuits is regulated by armatures in front of the driver. If the radio battery connections are reversed the RADIO armature will read erroneously high.
- (b) When the generated voltage reaches 21.5-23.0 volts the regulator contacts open to insert a resistance in the field circuit, the voltage falls and the regulator contacts close again. This cycle repeats continuously and rapidly until the speed of the generator is reduced and the voltage is below the regulator operating voltage. The generated voltage is reduced to 21.5-23.0 volts for the low setting (para 235G).

1060

- (c) If the batteries are discharged and normal running of the vehicle is not contemplated they may be charged by running the engine with the vehicle stationary. The hand throttle control should be adjusted so that the engine runs at the lowest speed at which maximum generator output is obtained. As the battery voltage rises and the charging rate falls the speed should be decreased.

FUSE BOXES

Description

236. These fuse boxes are fitted on the engine side of the bulkhead; Fig. 91 and 92a show their location and list the circuits protected. The fuses are of the 35 amp cartridge type and a spare fuse is carried in each fuse box.

An auxiliary fuse with an AC 224.1 generator an additional fuse box is fitted on the left-hand side of the instrument panel (Fig. 95 and 96) to protect the radio circuit. It is fitted with a 40 amp 125 B.W.G. (fine) spare fuse wire is wrapped round the fuse holder.



Fig. 91. Fuse box and 235E relay.

A 40 amp spare fuse

A. Vehicle armature

B. Radio armature

C. Fuse box



Fig. 92a.

Instrument, 90 amp system

A. Vehicle armature

B. Radio armature

C. Fuse box

A blown fuse is indicated by the failure of all the units protected by it and is confirmed by examination of the fuse. Before replacing a blown fuse, locate and remedy the fault in the wiring of the units which have failed. If the cause of the trouble cannot be found and a new fuse shows normal action, the vehicle should be examined at a workshop.

Only use the correct size fuse as a replacement.

1061



Fig. 92. Back lead on engine side of back lead, 48 amp switch

- A—Fuse box, auxiliary feed to MAGU socket and interior light wire (10A)
- B—Fuse box A1-A2 for turn and stop lights
- C—Fuse box A1-A4, engine accessories and windshield wiper




Fig. 93. Top leads on engine side of back lead, 48 amp switch

- 1—Fuse box, auxiliary feed to NATO socket and alarm light when fitted
- 2—Fuse box, A10-A engine radiator and windshield wiper
- 3—Fuse box, A1-A2 turn and stop light

STARTER MOTOR

Description

237. The starter motor is of the standard 24 volt type, situated at the left-hand side of the engine and mounted to die flywheel housing. It is operated by a remote switch on the dash.

In the event of the starter pinion becoming jammed in mesh with the flywheel, it can usually be freed by withdrawing the dust cap and turning the starter handle by means of a spanner applied to the shaft extension at the commutator end.

Checks

238. The following points should be checked at the start of motor —

- (1) Check that the nuts securing the starter to the flywheel housing are tight.
- (2) Check that the electrical connections are tight.
- (3) Check that the feed lead is not damaged and is secure at the remote switch.

Routine Adjustments and Servicing

Check Starter Motor Break Gear. (To be carried out by a vehicle workshop)

239.

- (1) Remove the supply main cap cover

108

And: See A and C

- (2) Check that the brushes move freely in their holders by holding back the brush springs and pulling gently on the flexible connectors. If a brush is inclined to stick, remove it from its holder and clean it with a gasoline-moistened rag.

- (3) If the brushes are worn, or if the brush flexible connector is exposed to the elements, the new brushes should be fitted to the motor (120)

Commutator

240. At the same time examine the commutator, which should have a bright buffed appearance. Remove any oil or dirt with a gasoline-moistened cloth.

STARTER SOLENOID SWITCH

Description

241. A solenoid type switch is fitted to the back lead and operates the starter motor. No adjustment is necessary. See Fig. 25(113).

HORN

Description

242. The horn is mounted on the left-hand radiator baffle and is secured by two bolts.

Checks

243. Check horn as follows.—

- (1) Check that the bolts securing the horn are tight.
- (2) Check that the connection of the feed lead is not loose.

Routine Adjustments and Servicing

To Adjust. (To be carried out by a vehicle workshop)

244. The horn is adjusted on a trial assembly and should not require adjusting for a considerable time. Adjustment merely makes up wear of the moving parts and is not intended to alter the tone produced as follows:—

- (1) Ascertain that the horn failure is fully note is not due to some outside source, such as a discharged battery, loose connection, loose post adjacent to the horn, etc.
- (2) If the above suggestions are in order proceed as follows:— Disconnect the leads at the horn, then remove the securing bolts and screw down the unit. Then adjust by rotating screw 'A' (Fig. 94) clockwise or anti-clockwise until the tone is satisfactory.
- (3) If adjustment of the horn does not produce satisfactory results, it should then be returned to a workshop.

109



Fig. 78. Horn adjustment. 24 rel.
A—Adjusting screw

HORN RELAY

Description

245. The horn relay (Fig. 78) is mounted at the top center of the engine side of the dash. It is of the simple-pole totally enclosed type fitted to prevent burning of the horn push-button contacts.

246. The operating coil of the relay is connected to the vehicle supply and to the horn push-button; as normally open contacts are connected to the supply and to the horn. Operation of the horn push-button energizes the relay which operates to close its contacts and to complete the horn circuit.

WINDSCREEN WIPERS

Description

247. Two windscreen wipers are fitted. They have a radio interference suppresser and an arc shield (Fig. 99 IC) and a lead which plugs into sockets located on the ledge above the instrument panel.




Fig. 99. Windscreen wiper.
A—Windscreen wiper motor
B—Fork lead
C—Suppressor lead
D—Lead to suppressor unit
E—Arc parking lever
F—Wiper wiper

Description

Headlights

248. The headlights, mounted in the auxiliary grille panel, incorporate a combined reflector and front lens assembly known as the Lucas Light Unit. Adjustable filament lamps give a vertical dip.

Side Lights

249. The side lights are mounted in the wing front panel, and the covers are secured by a threaded type holder.

Stop/Tail Lights

250. Two combined stop/tail lights similar to the side lights are fitted at the rear body.

Turnlights

251. The front turnlights are mounted in the front wing panels above the side lights. The rear turnlights are situated on the rear body below the stop/tail lights.

Number Plate Light

252. The number plate light is mounted on the right-hand side at the rear of the body adjacent to the ryalight.

Convoy Light

253. The convoy light is situated centrally under the rear chassis member.

Instrument Panel Lamps

254. The instrument panel incorporates an arrangement of lamps, the ignition, mixture control, oil pressure and main beam warning lamps.

Checks

255. The following points should be checked:-

- (1) Check lights for broken or cracked glass. If the headlight glass is broken the complete light unit must be renewed. If the lamps are disintegrated as a result of long service they should be renewed.
- (2) Ensure that the stop/tail light, turnlight and side light covers are secure.

Headlight Adjustments and Servicing

Headlight Lamp Replacement

256. Press on the light unit against the return of the springs of the three adjustment screws. Turn it anti-clockwise and withdraw. Twist the back shell of an appropriate direction and pull it off the light unit. The lamp can then be replaced and the unit reassembled.



Fig. 189. Headlight, vertical type

- | | |
|--------------------------------------|------------------------------|
| A—Main adjusting screw | L—Lens contact housing |
| B—Fitting securing main adjuster rim | M—Parking rim |
| C—Light unit parking rim, front | N—Light shade |
| D—Light unit | O—Adjuster pointer |
| E—Lens | P—Adjusting screw—vertical |
| F—Light unit securing rim, rear | Q—Adjusting screw—horizontal |

Headlight Setting (To be carried out by a vehicle mechanic)

257. The headlights should be set so that the main driving beams are parallel with the road surface. If adjustment is required, the vertical light setting can then be made by turning the screw at the top of the lamp and horizontal adjustment by means of the screw at the side of the unit.

When checking headlights to the dimensions shown at Fig. 261, the vehicle must be unladen, on level ground and 12 ft. (3.65 m) from the level marks. Adjust so that best test of concentrated light corresponds with marks.



Fig. 261. Headlight setting dimensions

- | | |
|--|--|
| A—Concentrated area of light, L.H. headlight | |
| B—Concentrated area of light, R.H. headlight | |
| C—25 in. (635 mm) | |
| D—12 ft. (3.65 m) (10 ft. (3.05 m) for vehicles 12 ft. (3.65 m) or over) | |
| E—15 ft. (4.57 m) (12 ft. (3.65 m) for vehicles 12 ft. (3.65 m) or over) | |
| F—Ground level | |

Side Light and Turnlight Lamp Replacement

258. All lights are of the same design, the difference being in the colour of the lens, side lights have white, rear lights red, and turnlights amber lenses.

To replace lamps in any of the above the glass is unscrewed from its threaded holder when the lamp is readily accessible and can be replaced. Finally screw back the lens.



Fig. 188. Side lights and front turnlight
A—Side light, B—Front turnlight



Fig. 190. Stop/tail lights and rear turnlight
A—Stop/tail light, B—Rear turnlight



Fig. 186. Number plate light

Number Four Light Lamp Replacement

259. To replace lamp, unscrew the lightlocking ring which is threaded inside the vehicle body and withdraw holder.

Instrument Panel and Warning Light Lamp Replacement

260. Should a warning lamp burn out, operation of the corresponding component will not be affected, but it should be replaced at the earliest opportunity to safeguard that particular item of equipment.

The engine coolant and oil pressure warning lamps can be replaced after unscrewing the respective bezels from the front of the instrument panel. Access to the instrument panel illumination and headlight warning lamps is gained by withdrawing the instrument panel fascia; this is effected by removing the five bolts, washers and nuts securing the panel.

Corner Light Lamp Replacement

261. To replace the lamp, remove the screws holding the wire cover and withdraw lamp and glass cover. The lamp can now be removed. Push new lamp into the holder turning the lamp to the left.

Warner and NATO Trailer Plug Sockets

NATO Trailer Socket

262. A NATO 12-pin trailer socket is supplied on the left-hand side body rear panel. The sockets are protected by a spring-loaded flap (Fig. 105 (B)). See circuit diagram for wiring connections.



Fig. 105. Warner and NATO trailer plug sockets.
A—Warner trailer socket. B—NATO trailer socket.
C—Adaptor for Warner socket cap.

Warner Trailer Socket

263. A 4-pin Warner trailer socket is situated to the right of the NATO socket (Fig. 105 (A)). It is protected by a screw cap secured by a chain fastener. An adaptor is provided to the left of the NATO socket to retain the screw cap when the trailer plug is connected. See circuit diagram for wiring connections.

CHAPTER 14

FITTINGS FOR RADIO STATIONS

General

264. Various radio systems are authorized for this vehicle in its different roles, and to facilitate the installation the items comprising the complete installations are divided into kits—multi-purpose kit, set kit and set/auxiliary kit. (Note Fitted For Radio (FFR) equipment stock is fitted in the vehicle during manufacture. The use and location of FFR equipment is described below.)

265. The multi-purpose kit is fitted by the user. It consists of items which are common to all radio stations.

266. The set kit consists of the radio set, power supply unit, set carrier and standard set connections. The set/auxiliary kit is 'fitted' to the set kit and consists of those items required to fit the set kit into the vehicle; it includes the aerial base and special connectors for the set.

267. Boxes 6 and 4 cargo vehicles are, as a measure, prepared to receive a radio station in the event of an emergency. If certain items of FFR equipment may readily be transferred from an FFR vehicle to a cargo vehicle. References to cargo vehicles in the following paragraphs refer to 6 and 4 vehicles only.

268. The cargo vehicle has certain stiffening plates fitted and holes provided to accept the appropriate components. These holes are normally sealed with slave nuts and bolts or grommets, some have captive nuts to facilitate the fitting of the components.

269. Cargo vehicles have a 12 volt vehicle supply and when a station is transferred to these vehicles the radio equipment is connected directly to the radio harness.

270. Certain items of the kit may be removed from the vehicle when it is required to use the vehicle's own ground rods.

271. The introduction of VLF radio into the service calls for a high degree of suppression and filtering of interference to be avoided (see Chapter 15). Each headset is located at the following:

- (a) Seat back, P 11 and 1, 11.
- (b) Exhaust tail pipe.
- (c) Starter motor to chassis.
- (d) Clutch to seat.
- (e) Gearbox to engine.
- (f) Bumper to vehicle.
- (g) Radio table.
- (h) Wiper motor (2 off).

Aerial Tuning Unit

Plate and Screw Assembly

278. In installations where two VHF sets are used the associated Aerial Tuning Units (ATUs) are fitted to the top of the front wings. In installations where only one VHF set is used, the left-hand position is used. The ATUs are part of the auxiliary kit and separable socket.

279. Three holes (Fig. 109B) are provided in each wing to accept the ATU's, these holes are temporarily sealed by nuts and bolts or grommets by the vehicle creator. The centre hole accepts the special winged screw securing the ATU; the two outer holes are for locating dowels.



Fig. 109. Front wing strengthening plate
A—Strengthening plate. B—Blanking screws.

280. The front wings are strengthened to carry the ATU by plates bolted to their undersides. Similar strengthening plates are fitted to cargo vehicles. See Fig. 109A).

Connector Co-Axial

281. Two connector co-axials (Fig. 110) are fitted to the vehicle to connect the ATU to the appropriate radio set. The rear end of the connector (Fig. 110A) are stowed vertically at the centre of the driver's compartment seat rest adjacent to the location of the VHF sets. Captive screw caps (Fig. 110B) are provided to protect the ends of the connectors when disconnected. The sockets on the front end of the connectors fit the dummy plugs (Fig. 112) fitted to the inside of the wing vehicle towards the engine bonnet.

282. These connectors are not transferable to a cargo vehicle. To re-locate the front end of the connector in preparation for connection to the ATU:—

- 1) Unscrew the locking ring securing the connector socket to the dummy plug and withdraw the socket. See Fig. 112.



Fig. 110. Aerial co-axial removed from dummy socket and stored at front wing.



Fig. 111. Aerial co-axial in car body
A—Aerial co-axial. B—Captive screw cap.



Fig. 112. Aerial co-axial and dummy socket on wing vehicle
A—Aerial co-axial. B—Dummy socket.

- (2) Release the last two cable clips (Fig. 113), each secured by a screw and captive nut. Replace the screws to seal the holes.
- (3) Unscrew the two screws (Fig. 133) located in the holes leading to the APU. Captive nuts are fitted to the underside of these holes.



Fig. 113. Cable clips for aerial to aerial leads
A—Clips to be removed and transferred to wing top

- (4) Re-route the conductor using the clips at the points uncovered at (3) above. A suitable notch is formed in the side of the engine harness to accommodate the conductor; the conductor and clips must be arranged so that the conductor located in the notch and runs directly to the APU. Similar notches are formed in cargo vehicle benches.

Table top

Drawer assembly

Stiffening plate

243. A table top (Fig. 114 (A)) to carry one or two radio sets is located symmetrically behind the driver's compartment seat (241). It is secured by four wire clamps (Fig. 114 (D)) to a pair of proper assemblies (Fig. 114 (B)) bolted to the vehicle body steel arches. The table top is caulked to the vehicle by a copper head located at the right hand side.



Fig. 114. Radio table

- A. Table top
B. Clamping bracket
C. Rubber assembly
D. Wire clamp

244. Stiffening plates are riveted to the underside of each wheel arch and also to the wheel arch of cargo vehicles.

Batteries and Associated Equipment

Battery Carrier

245. A battery carrier (Fig. 115) is bolted to the floor plate of the vehicle beneath the table. This carrier is designed to house two sets of two 12 volt batteries connected in series to give 24 volts. One set is fitted at the front of the carrier, the remaining set being fitted in space if the radio station requires additional power, and is connected in parallel with the first set.

246. Each set of batteries is secured in the carrier by a suitable disposed screw bolt with clamp plate and wingnut. The clamp plate engages on the rear top edge of the batteries (Fig. 109 (1)).



Fig. 115. Battery carrier

Reference, see page 102, para. 226 WARNING

247. The batteries are of the lead acid type and require the same maintenance as the vehicle batteries (see para. 225). To obtain access to the batteries see para. 242 (1), (2), (3), (6) and (7) and to replace the cover para. 248 (1) and (2).

Battery Cover

248. Protection of the batteries is afforded by a box shaped cast-iron cover in front and battery sides open. The top front edge of the cover is located by two angle brackets fitted to the back of the driver's compartment seat row. The cover is secured at its rear end by means of two spring-loaded fasteners (Fig. 105 (1)) bolted to the floor plate which engage with a slot in the cover.

249. The cover is extensively designed to permit its use as a platform for the radio sets when the station is being used in the forward role.

Battery Post Connection

290. Radio set battery leads are fitted with spade terminals, and when the set is used in a charge vehicle or in the ground cable, the 11-inch connecting bar on the set is connected directly to the battery. To accommodate these terminals, special battery post connectors are provided. These connectors are of the split clamp type to fit the battery terminal post and incorporate a radiomated terminal stud fitted with a D.I. spring washer and wire nut to which the cable terminals are fitted.



Fig. 116. Terminal box
A—Radio battery and charging circuit terminal box.
B—Radio station box. C—Capacitor. D—Spring clip.

Battery Terminal, 2-Point, No. 4

291. Two 2-point terminal boxes (Fig. 116) are located on the left side of the vehicle adjacent to the table.

292. The radio batteries and the charging circuit are connected together at the forward terminal box (Fig. 116) (A) which is identified as "BTY" and hence the batteries are charged simultaneously with the vehicle battery. See Wiring Circuit and page 234.

293. The radio station is connected to the second box (Fig. 116) (B) which is identified as "PORT" and has a 2-micro farad capacitor (Fig. 116) (C) connected across its terminals. The positive network is also connected to the posterior side of the radio amplifier and the negative terminals of the two boxes are connected together and to earth. The radio station is therefore connected to the radio amplifier via the amplifier.

294. The radio amplifier and its supply battery charge is carried when the generator is "on line" and discharge current when the generator is not "on line" and the radio station is being fed from the car battery.

Am 3-27

295. The terminals of the capacitor are very close to the sides of the terminal box cover (Fig. 116) (D) and to prevent short circuiting, before removing the cover, the fuse located at the left side of the instrument panel must be withdrawn and one terminal of the radio battery disconnected either at the engine or at the "PT" terminal box.

Insulated Terminals

296. A pair of insulated terminals (Fig. 117) are provided in a bracket attached to the left wheel arch beneath the radio table. These terminals provide a safe passage for the ends of the battery terminal lead leads when disconnected from the battery. When the engine is running, these leads are "live" and must be covered by the insulated terminals when disconnected.



Fig. 117. Insulated supports
A—Insulated terminals. B—Spring clip.

Table Clips, Special

297. Two open-ended spring clips, bolted to the wheel arch below the insulated terminals, are provided to bring the battery interconnections when the radio batteries are disconnected.

298. Two clips, similar to the above but larger, are bolted to the ends of the bulkhead between cable and charge compartments to accommodate the cables connecting the radio batteries to the junction box and also to accommodate their cables when connected to the car or insulated terminals (para. 296).

Slotted Angle Framework

299. A slotted angle framework (Fig. 118) is mounted transversely across the vehicle just forward of the radio table. This framework provides a mounting for a continuous radio terminal and



Fig. 110. Operator's seat.

A—Backrest. B—Seat cushions. C—Snap retaining nut.

Seats

308. Two operators' seats are provided in 9 1/2-ton vehicles and one in 8 1/2-ton vehicles (Fig. 110). These are lightweight, quickly detachable seats which rest upon the wheel arches of the vehicle and have hooks on their backs to locate on the sides of the body.

The seats are secured particularly for cross-country work, by means of a strap fitted to the underside of the seat which locates on a stud (Fig. 111 (C)) fixed to the side of each wheel arch. In 1-ton vehicles, there is a stud on the left side only.

Top Hat Sections

309. When it is required to fit additional radio equipment this may be done by fitting three top hat sections to the rear of each wheel arch.

Slave nuts and bolts are used to plug the fixing holes for these sections.



Fig. 112. Assembly and radio base.

A—Slave nut
B—Radio assembly
C—Base bolt



Fig. 113. Assembly of strap holder.

A—Slave nut
B—Strap holder
C—Radio bracket

124

Anti No. 124/5

To dismantle FFR Equipment

302. To dismantle the FFR equipment for transfer to a cargo vehicle:

- (1) Remove the face (Fig. 113 (C)) located on the left side of the instrument panel assembly and store in arms convenient box.
- (2) Unscrew the four table top clamping screws (Fig. 114 (D)).
- (3) Slide the retaining brackets from the runners.
- (4) Release the cable (with least 175-120 LBS) from its fixing at the right-hand forward stay of the sloped stanchion framework (Fig. 106 (D)) and lift off the table.



Fig. 114. Radio table with cable fixed.

A—Front hook. B—Table top.

- (5) Release the two runner assemblies, each is secured by four bolts with nuts and lockwashes.
- (6) Release the two spring-loaded fasteners from the hooks on the front of the battery cover.
- (7) Carefully withdraw the cover forwards from the batteries.
- (8) Slacken the wingnuts securing the sloped battery interconnector and remove the connection. Do not remove the battery post connector. If can sets or sockets are fitted, disconnect the second set immediately.
- (9) Similarly release the remaining two battery connections, double back the leads and secure the spare terminals in the spare steel terminals (Fig. 117 (A)) on the side of the left cell. Locate the doubled-back section of the leads in the spring clips (Fig. 117) just alongside their forward run.
- (10) Release the batteries secured by the swivel type clamps, and lift them from the carrier.
- (11) Release the battery carrier secured by ten countersunk bolts with nuts and spring washers.

125

- (12) Release the two spring-loaded fasteners used to secure the battery cover. Two bolts with spring washers secure each fastener; capwash nuts are provided beneath the floor.
- (13) Uncrew the four nuts and bolts securing each aerial mounting bracket (left-hand bracket for one 11.1 set installation) and remove the bracket complete with mounting. Alternatively first remove the mounting from the bracket by unscrewing the captive nut at the bottom of the mounting and then withdrawing the mounting; use a torque bar to turn the nut.
- (14) Only if required, release the slotted angle framework. Six bolts with plain washers screw into captive nuts secure the assembly.
- (15) Release the seat straps from the studs on the wheel axles and lift the seats from the vehicle.
- (16) For 4½ ton vehicles only.
 - (a) Release the small table, if fitted, secured by four nuts and spring washers.
 - (b) Release the three tray (jet) sections of BMSL from each wheel arch; each section is secured by two bolts with nuts and spring washers and distance pieces.
- (17) Re-route and show the AT31 connector connectors in the reverse sequence to that indicated in para 728.

FFR Equipment to be transferred

303. Transfer the following items of FFR equipment to the cargo vehicle:-

- (1) Radio batteries complete with battery post connectors.
- (2) Battery inter-connections.
- (3) Battery carrier with fixing bolts, nuts and spring washers.
- (4) Battery cover.
- (5) Two spring-loaded fasteners with securing bolts, and spring washers for securing the battery cover.
- (6) Aerial mounting brackets each with four bolts, nuts and washers.
- (7) Aerial base mounting.
- (8) Table top complete with four clamping screws and brackets, together with the earth braid and securing wingnut, plain washer and shake-proof washer.
- (9) Two tunnel assemblies each complete with two mounting stocks and four bolts with nuts and locknuts.

117

(10) If required, the slotted angle framework complete with up bolts and washers. If the framework is not required the table top earth braid securing bolt and washer must be transferred.

(11) Operators seat or seat.

(12) If required for 8.1 vehicles:-

(a) Small table.

(b) Straps for sections of table, each complete with a stud, nut and spring washers and distance pieces.

To Fit FFR Equipment

304. To fit the FFR equipment in a cargo vehicle:-

- (1) Remove the nuts and bolts or grommets from the holes in the vehicle's top plate immediately behind the driver's compartment seat post, for the battery carrier and post for the battery cover securing fasteners.

NOTE: Four additional water holes are provided in the top plate for use as a drainage system and, unless a grommet is fitted, a hole must be covered and the hole sealed.



Fig. 128 Position of battery carrier holes.

A—Position for battery carrier B—Position for carrier post

- (2) Fit the battery carrier and the two spring-loaded battery cover fasteners.
- (3) Locate the batteries in the carrier. Forward section only: one set of batteries are being used, and secure by the cover clamps. The clamp locates on the top rear edge of the batteries.
- (4) Ensure that the battery post connectors are clean and tight.
- (5) Fit the battery inter-connections and fully tighten the securing wingnuts.
- (6) Remove the four nuts and bolts or grommets from the top plate immediately behind the seat post.

117

- (7) Fit the two runner assemblies (see Fig. 114 (9)).
- (8) If disconnected, fit the earth braid to the stud on the underside of the table and secure by the plain washer, shake-proof washer and wingnut. Ensure that the connection is clean and tight.
- (9) Slide the four table top clamping brackets in the channels and secure the table top by the clamping screws. The earth braid locates in the forward, right-hand position.




Fig. 122. Portion of radio cable earth lead.
A—Earth lead; B—Table top.

- (10) Remove the six nuts and bolts or greenings from the holes in the side cappings of the vehicle, adjacent to the table top, for the diamond angle framework (Fig. 123).
- (11) Fit the sloped angle framework. Secure the table top earth lead by the rear hole of the forward stay. The braid locates on the top of a shake-proof washer. Ensure that the earth connections are clean and tight.



Fig. 123. Holes for angle framework and aerial bracket.
A—Position for angle framework; B—Position for aerial bracket.

- (12) Remove the four nuts and bolts or greenings from the holes (Fig. 122) (B) in the two side plates for the aerial mounting bracket. Loosen the side for use (14, 15, 16).
- (13) Fit the aerial mounting bracket.
- (14) Locate the aerial base mounting in the base on the bracket and secure by the massive screw. Use a torque bar to tighten the screw.
- (15) Remove the three nuts and bolts or greenings from the left-hand, front wing (Fig. 109 (34)) and fit the A.T.U. assembly (see para. 279). If required, fit the second A.T.U. assembly on the right-hand, front wing.
- (16) With the radio station in trial, connect the station leads to the battery and fully tighten the securing wingnuts.
- (17) Carefully slide the battery cover forward over the batteries, and locate the top front edge under the two brackets on the rear rest.
- (18) Fit the spring fasteners to the staples on the battery cover.
- (19) Locate the operator's seat in the vehicle.

CHAPTER 15 BODY

Description

305. With the exception of the dash panel, which is steel, the body panels are constructed throughout from Formabright 2 with steel caplight and corner plates, which are galvanized.

Notes

306. The bonnet (op panel) is secured by two pull-on type catches, one at either side of the bonnet.



Fig. 124. Hood catches.

To open the bonnet, release the catches and raise until it is held open by the support stay. To close, release support stay, lower and secure by catches.

The panel can be removed from the vehicle as follows: -

- (a) Withdraw one of the split pins securing the panel
- (b) Slide the panel off the hinges on the dash

Spare Wheel

307. The spare wheel is mounted on the bottom panel.



Fig. 125. Spare wheel mounting on bottom

Rifle Clips

308. Rifle clips are fitted behind the front seats and on top of the dash panel.

Front Seats

309. The fore-and-aft position of the driver's seat, on the 9 vehicles, is easily adjusted by pushing to the left the lever on the left-hand side of the seat base and moving the seat into the most convenient position.

The seat cushions can be removed by lifting at the front and pulling forward.

The seat backs are secured in the upright position to the backrest panel by straps. If the vehicle is parked in inclement weather without a covering, they may be folded down on to the seat cushions.



Fig. 126. Seat adjustment - Rover 9 vehicles

Radio Operator's Seat

310. Rover 8 vehicles have a single seat mounted on the left-hand wheel arch. On Rover 9 vehicles two seats are used, one at each side of the rear wheel arch.



Fig. 127. Radio operator's seat

A. Rover 8 B. Rover 9 C. Rear view of Rover 9

The seat can be quickly removed by pulling the retaining straps off the studs and lifting the complete seat upwards.

Tool Storage

311. Small tools are carried in a container underneath the foot of the adjutant to the rear of the left hand wing or the bulkhead.

Windscreen

312. Provision is made for folding the windscreen down on to the bonnet as follows: -

Remove the hood, then disconnect the windscreen wiper (rod at the plug adjacent to the wiper motor). Unblock the pins at the bottom corners of the windscreen. Connect the wiper motor to the main.



Fig. 128. Windscreen being folded down on to bonnet.



Fig. 129. Windscreen fully down on bonnet.

Windscreen Wipers

313. To set the wipers in operation, pull out the blade over, turn it to clear the wiper lever and turn the latter through 90°. To park the blade, reverse these operations.

Windscreen Wiper Arm and Blade Replacement

To replace windscreen wiper blade, remove the rubber bush securing the old blade to the arm. Insert the tongue on the replacement blade through the slot in the arm and secure it by fitting the rubber bush through the hole in the tongue.



Fig. 125. Windscreen wiper arm.

- | | |
|--------------------|-----------------------------|
| A—Wiper arm | D—Nut for replacement unit. |
| B—Rubber bush | E—Wiper blade. |
| C—Replacement arm. | F—Wiper switch. |

To replace windscreen wiper arm and blade, slacken the nut and tap sharply to release the nut; which clings the arm on of the spindle; then remove the complete assembly.

When fitting the replacement arm and blade, slacken the securing nut and push the arm into over the end of the spindle as far as it will go. Secure by tightening the nut.

Windscreen Ventilators

314. The two ventilators in the windscreen panel may be opened independently. One of the ventilators may be used as an exhaust when traversing dusty roads as they greatly reduce the amount of dust blown into the vehicle from the rear.

The glass sections are fixed over the apertures. To open or close the ventilator, the lever is raised or lowered as necessary.

To open ventilator, push lever upwards to register in required notch. To close, reverse the operation.



Fig. 126. Windscreen ventilator.

Door

315. Occasionally apply a few drops of oil on the door hinges and door locks.

Tailboard

316. In the horizontal position, the tailboard is retained by two chains. To remove the tailboard completely, remove the split pin and pull washer down out of the hinges, unhook the chains and slide it off its lugs.

Cleaning Body

317. It is always preferable to clean the bodywork with water and sponge, using plenty of water, whenever possible the surface should be freely soaked. Dry with a chamois leather.

Periodically wash the underside of the vehicle, to prevent the formation of mud pockets.

American Holder

318. A jerrycan holder is provided between the front legs. Close the vehicle batteries.

Soft Hood

319. The soft hood completely encloses the vehicle and can be opened at the rear to facilitate loading.

Should the hood and busal seats have been removed at any time, they may be refitted in the following sequence:

- (1) Fit the two fixed sticks in the sockets at the corners of the rear body and secure with clamps arms, nuts, washers and nuts.
- (2) Secure the air hose, by screw the clamps to means of a split locking nut.
- (3) Fit the intermediate fixed stick between the brackets securing it with clamps.

- (4) Secure the door top drain channels between the windshield and frame hood stick with bolts, plain washers and self-locking nuts.
- (5) If not already done, secure the door rear drain channels to the front hood stick with bolts, plain washers and self-locking nuts.
- (6) Place the hood over the trucks and secure it to the windshield top rail.
- (7) Secure the front support straps to the support stays at the top of the windshield.
- (8) Secure the rear hood straps to the staples on the body and the side curtain straps to the front hood stick.
- (9) Pass the side ropes through the hooks at the front corners of the body, secure under the side hooks and, together with the rear ropes, which have been previously laced round the rear hood stick, to the hooks at the rear of the body.
- (10) Pass the rear curtain into flaps through the side pockets and secure.

If it is desired to raise the rear curtain, place the side flaps and the curtain bottom rope. Fold in the flaps and roll the curtain into three folds. Secure by means of the short straps given inside the curtain.

Checks

128. The following points on the body should be checked:
 - (1) Check that nuts and screws securing the lock to the door are tight.
 - (2) Check that the bolts fixing the support bracket to the workup plate are tight.
 - (3) Check that the door slightly compresses the rubber draught excluder when fully closed. If necessary, adjust the position of the striking plate by slackening the two securing bolts and nuts.
 - (4) Check bolts securing door hinges.
 - (5) Check the rear body securing bolts for tightness at the rear of chassis frame and at chassis brackets in front of the rear wheels.
 - (6) Check for tightness the bolts securing the front works to the dash when installed, plus, discs and ring nuts.

- (7) Check for tightness the bolts securing the radiator grille panel to the chassis frame.

Fire Extinguisher

129. The fire extinguisher is secured in the dash panel below the instrument panel. Ensure vacuum screws are tight.



Fig. 121. Fire extinguisher

SECTION IV FAULT-FINDING CHART

322. Although every precaution is taken to eliminate all possible causes of trouble, failure may occasionally develop through lack of attention to the equipment, or damage to the wiring. The following pages set out the recommended procedure for a systematic examination to locate and remedy the causes of some of the more probable faults which may occur during the life of the vehicle.

All the checks listed can be readily carried out without special equipment, if the fault is not located in this way, the vehicle should receive workshop attention.

ENGINE FAILS TO START

123. Proceed as follows:
 - (1) Check that the ignition is switched on.
 - (2) Check that there is sufficient fuel in the tank.
 - (3) Check that the cold start control is set correctly (see Chapter 41).
 - (4) Check that the engine is being turned at an adequate speed by the starter motor. This speed will be recognized when some experience with the vehicle.
 - If the starting speed is too low:
 - (a) Check the battery connections for tightness and cleanliness.

- (ii) Check the state of charge of the batteries by switching on the headlights and pressing the starter button: if the headlights do not or are very dim when the starter is operated, the battery requires recharging. See para. 231. It should be possible to start the engine by cranking with the starting handle.
- (3) Remove the screened lead from each sparking plug terminal in turn and hold it so that the end is about 1 in. (25 mm) away from some metal part of the chassis, while the engine is turned over. If sparks jump the gap regularly, the coil and distributor are functioning correctly.
 - (i) If the sparks are strong and regular, remove and clean the sparking plugs and reset the side electrode to give a .015 to .018 in. (0.38 to 0.45 mm) gap.
 - (ii) If the sparks are not regular:
 - (a) Check that the distributor rotor is in position.
 - (b) Check that the L.T. connections on the coil and distributor are clean and tight.
 - (c) Check that the distributor points are —
 - 1. Clean.
 - 2. Opening and closing correctly.
 - A. Correctly set when open—gap .014 to .016 in. (0.35 to 0.40 mm).
 - (d) Check that contact is present at the SW terminal on the coil, by disconnecting the wire at the coil end and touching it against the SW terminal, with the ignition switch on and the distributor contact-breaker points closed. If sparks occur, low tension current is flowing through the coil correctly: if there is no spark, either the coil or the low tension wiring is defective and the vehicle should receive workshop attention.
 - (iii) If the sparks are weak and in addition there is a flashing action, distributor contact breaker points, a faulty distributor condenser is indicated.
 - (iv) If the sparks are present on some leads, but not on others, check the distributor cap for cracks and the plug leads for damage.
 - (4) Disconnect the petrol pipe from the carburettor and check that petrol is delivered to the carburettor when the hand lever on the petrol pump is operated. If petrol is not delivered from the pipe —
 - (i) Check that the petrol pipes and filters are clear.

- (ii) Check that there are no air leaks in the vacuum line to the petrol pump.
- (iii) Check that the diaphragm is not leaking and that the retaining screws are tight.

ENGINE STARTS BUT SOON STOPS

324. Check as detailed below:
- (1) Check that the vents are set correctly (see para. 231).
 - (2) Check the fuel feed to the carburettor. See para. 323. Item 6. If there is little or no flow —
 - (i) Check the fuel level in the tank.
 - (ii) Check that the air wire of the filler neck is clear.
 - (iii) Check the fuel pump for correct operation (see para. 104).
 - (iv) Check that the fuel filters are clear.
 - (v) Check that the fuel pipes are clear (see para. 113).
 - (3) Check that the carburettor jets are clear, in the following order (para. 117)—
 - (i) Starter fuel jet.
 - (ii) Main jet.
 - (iii) Pilot jet.
 - (4) Check for a fault in the ignition circuit by connecting a wire between the ammeter and the SW connection on the coil that bypasses the ignition switch. At the same time the wire from the ignition switch must be disconnected from the coil.
 - (5) Remove the carburettor top cover and check that there is no water in the float chamber.

ENGINE MISFIRING

325. Engine running on less than 1000 rev/min, rattle irregularly & continuously.
- (1) Stop the engine and check on its operation with the starter in use to check the state of the battery and carburettor. If the battery is in a low state of charge, the distributor points should be checked as detailed under charging circuit below.

(2) Remove the screened lead from each sparking plug in turn and check.

(a) By holding the end of the lead about 4 in. (100 mm) away from a metal part of the engine with the engine running. Sparks should jump the gap regularly.

If no spark is present on one or more cylinders -

(a) Check for pressure of the ignition system.

(b) Check, clean and reset the distributor's contact-breaker points. - 014 (a) (iii) or (ii) 35 or 0.40 mm if necessary.

(c) Check the distributor cap for cracks and the plug leads for damage.

If the spark is regular on all cylinders -

(a) Check for misfires as in (i) (a).

(b) Check the distributor points as in (b) (i).

(c) Check the cap and leads as in (i) (c).

(d) Check the L.T. connections for tightness and cleanliness.

(e) Check for fasting or "blowing" of the contact-breaker points. If present, the distributor condenser should be replaced.

(f) Check for a fault in the ignition circuit by connecting a wire between the ammeter and the SW connection on the coil, thus bypassing the ignition switch. At the same time, the wire from the ignition switch must be disconnected from the coil.

(g) For any possible alteration in the running of the engine, as each screened lead is removed. No alteration will indicate that the sparking plug in question is at fault.

(a) Remove and clean the plug - refer the gap to 012 to 013 or 01,02 to 0.45 mm as directed.

(a) If still faulty fit a new sparking plug.

(4) If the "misfire" is accompanied by "quitting back" through the transmission, a valve may be sticking. This can often be cured by studs dripping oil on upper cylinder intake valve (see chapter 22) while the engine is running.

LACK OF ENGINE POWER

236 Check the following points -

(a) Check that the engine oil throttle is opening fully.

(b) Check that air intakes are not binding and that the tyre pressures are correct.

(c) Check that the carburettor jets are not blocked (in the following order) - See para. 117.

(i) Main jets.

(ii) Pump jet.

(iii) Jetting jet.

(d) Check the ignition timing.

(e) Check the tappet adjustment.

(f) If items 1-5 are satisfactory, it is probable that the engine needs decarbonising.

CHARGING CIRCUIT

237 Proceed as follows -

(1) Battery in low state of charge.

(a) The system will be shown by lack of power when starting, poor light from the lamps and hydrometer readings below 1.200, and may be due to the generator either not charging or giving low or intermittent output. Check the ammeter reading when the vehicle is running steadily in top gear with no lights on. A definite steady charge should be indicated.

(b) Examine the charging and field circuit wiring, tightening any loose connections, or replacing broken cables. Pay particular attention to the battery connections.

(c) If, even so, the car will generate nothing left, take up any undue slackness by turning the generator on its mounting (see para. 38).

(d) In the case of the trouble is an apparent, the vehicle should receive workshop attention.

(2) Battery overcharged.

This will be indicated by numerous bubbles, very frequent and not improving if battery and high potential readings. This indicates that the regulator setting should be checked and adjusted.

STARTER MOTOR

228. Check points drilled below —

(1) Starter motor lacks power or fails to turn engine.

- (a) See if the engine can be turned over by hand. If not, the cause of the stiffness of the engine must be located and remedied.
- (b) If the engine can be turned by hand, check that the trouble is not due to a discharged battery.
- (c) Examine the connections to battery, starter and starter switch, making sure that they are tight and that the cables connecting these units are not damaged.
- (d) It is also possible that the starter pinion may have jammed in mesh with the flywheel, although this is by no means a common occurrence. To disengage the pinion, pull off the dust cap and rotate the squared end of the starter shaft by means of a spanner.

(2) Starter operates, but does not crank engine.

This fault will occur if the pinion of the starter drive is not allowed to move along the squared sleeve into engagement with the flywheel, due to dirt having collected on the squared sleeve. Clean the sleeve carefully with kerosene.

(3) Starter pinion will not disengage from flywheel when engine is running.

Stop the engine and ascertain if the starter pinion is jammed in mesh with the flywheel. Release it, if necessary, by withdrawing the dust cap and rotating the squared end of the starter shaft in the opposite direction to normal rotation. If the pinion persists in sticking in mesh, the wheels should receive workshop attention. Serious damage may result to the starter if it is driven by the flywheel.

LIGHTING CIRCUITS

229. Check the following points —

(1) Lamps give insufficient illumination.

- (a) Test the state of charge of the battery, recharge if it is necessary. (See para. 221.)
- (b) Check the setting of the headlamps (see para. 257.)
- (c) If the lamps are questioned as a result of (b) above, they should be renewed.

(2) Lamps light when switched on, but gradually fade out.
(See para. 164.)

(3) Brilliance varies with speed of vehicle.

- (a) See para. 164.
- (b) Examine the battery connections, making sure that they are tight, replace faulty cables.

(4) Lights flicker.

Examine the circuits of the lamps for loose connections.

(5) Failure of lights.

- (a) See para. 164.
- (b) Examine the wiring for a loose or broken connection and remedy.

GOOD SERVICING IS ESSENTIAL FOR
SUCCESSFUL FORDING

Fig. 121 Circuit Diagram of Lamp System

KEY TO CABLE COLOURS


B—BLACK	H—BROWN	K—RED	M—WHITE
G—GREEN	O—ORANGE	S—SLATE	Y—YELLOW
P—PURPLE		U—BLUE	

When taken from the cable below the Pin in the main wiring and the speed of the speed, or NO. of the main circuit
 Cable in the main circuit, but not in the vehicle from the battery

KEY TO WIRING DIAGRAM

1	1	16	16	16	16
2	2	17	17	17	17
3	3	18	18	18	18
4	4	19	19	19	19
5	5	20	20	20	20
6	6	21	21	21	21
7	7	22	22	22	22
8	8	23	23	23	23
9	9	24	24	24	24
10	10	25	25	25	25
11	11	26	26	26	26
12	12	27	27	27	27
13	13	28	28	28	28
14	14	29	29	29	29
15	15	30	30	30	30
16	16	31	31	31	31
17	17	32	32	32	32
18	18	33	33	33	33
19	19	34	34	34	34
20	20	35	35	35	35
21	21	36	36	36	36
22	22	37	37	37	37
23	23	38	38	38	38
24	24	39	39	39	39
25	25	40	40	40	40
26	26	41	41	41	41
27	27	42	42	42	42
28	28	43	43	43	43
29	29	44	44	44	44
30	30	45	45	45	45
31	31	46	46	46	46
32	32	47	47	47	47
33	33	48	48	48	48
34	34	49	49	49	49
35	35	50	50	50	50
36	36	51	51	51	51
37	37	52	52	52	52
38	38	53	53	53	53
39	39	54	54	54	54
40	40	55	55	55	55
41	41	56	56	56	56
42	42	57	57	57	57
43	43	58	58	58	58
44	44	59	59	59	59
45	45	60	60	60	60
46	46	61	61	61	61
47	47	62	62	62	62
48	48	63	63	63	63
49	49	64	64	64	64
50	50	65	65	65	65
51	51	66	66	66	66
52	52	67	67	67	67
53	53	68	68	68	68
54	54	69	69	69	69
55	55	70	70	70	70
56	56	71	71	71	71
57	57	72	72	72	72
58	58	73	73	73	73
59	59	74	74	74	74
60	60	75	75	75	75
61	61	76	76	76	76
62	62	77	77	77	77
63	63	78	78	78	78
64	64	79	79	79	79
65	65	80	80	80	80
66	66	81	81	81	81
67	67	82	82	82	82
68	68	83	83	83	83
69	69	84	84	84	84
70	70	85	85	85	85
71	71	86	86	86	86
72	72	87	87	87	87
73	73	88	88	88	88
74	74	89	89	89	89
75	75	90	90	90	90
76	76	91	91	91	91
77	77	92	92	92	92
78	78	93	93	93	93
79	79	94	94	94	94
80	80	95	95	95	95
81	81	96	96	96	96
82	82	97	97	97	97
83	83	98	98	98	98
84	84	99	99	99	99
85	85	100	100	100	100

CIRCUIT DIAGRAM, 48 AMP GENERATOR



E787




Fig. 152 Circuit diagram 48 amp generator

KEY TO CABLE COLOURS

B - BLACK	H - BROWN	R - RED	W - WHITE
U - GREEN	O - ORANGE	S - SLATE	Y - YELLOW
V - VIOLET	P - PURPLE	L - LIME	

When cables are laid into the machine, the key to the cable colours and the correct the number of P.C. - P.C. with Green Cover is a key for the cable and must when the cable is laid into the machine.

APPENDIX 1

CROSS-REFERENCES TO SERVICING OPERATIONS

The Op. No. in the table below refers to operation numbers in the Servicing Schedule contained in the Vehicle Log Book.

Among the operation numbers are the numbers of the paragraphs in the Handbook describing how the operations will be carried out and the Fig. Nos. of the appropriate illustrations.

Op. No.	Proc. No.	Fig. No.	Op. No.	Proc. No.	Fig. No.
1	90 (27)	44	20	129, 160	65, 67
2	90 (27)	47	21	165	68
3	84 (51, 60)	-	30	171	72
4	172	-	31	-	-
5	500 (1)	75	32	180	76
6	-	-	33	-	-
7	-	-	34	-	4b
11	89	43	38	115	-
12	222	60	39	101	50
13	216, 216	67	40	-	-
14	96 (2)	42	41	-	-
15	-	-	42	-	-
16	185, 191	-	46	148	62
17	126	57	43	-	-
18	173	-	49	145	61
20	81, 112	41	49	-	51
20	107	51	51	127	-
24	176	70	54	-	-
25	147	-	55	147	-

CIRCUIT DIAGRAM, 90 AMP GENERATOR




Fig. 1A2A. Circuit diagram 90 amp generator

KEY TO CABLE COLOURS

B—BLACK	H—BROWN	R—RED	W—WHITE
G—GREEN	C—CRIMSON	S—SLATE	Y—YELLOW
	P—PURPLE	U—BLUE	

Wires within each 194 cable bundle, the first is the outer colour and the second the inner. A. & C.—Red with Green.
Cables to start left are not listed when the cables leave the Battery.

KEY TO CABLE COLOURS

R—BLACK
G—GREEN

M—BROWN
O—ORANGE
Y—YELLOW

B—BROWN
S—SLATE
U—BLUE

W—WHITE
V—YELLOW

When cables have two ends fitted, the first is the main colour and the second the prefix, i.e. BR—Red with Brown Clauses to avoid confusion; FR—Red when the vehicle makes the battery.

KEY TO WIRING DIAGRAM

S Part & VIN plate
VIN

1. Vehicle battery—only 12 volt
2. Radio battery—see 12 volt
3. Radio receiver
4. Radio accessories
5. Horn
6. Relay for horn
7. Horn push button
8. Windscreen wiper control—off and on
9. Power windows
10. Horn indicator
11. Aerial light B.H.
12. Aerial light L.H.
13. Aerial light
14. Aerial indicator (left), A.L.L.
15. Aerial light R.H.
16. Aerial indicator (right)
17. Tail light B.H.
18. Head light B.H. main beam
19. Head light L.H. main beam
20. Headlight B.H. off beam
21. Headlight L.H. off beam
22. Headlight B.H. side beam
23. Headlight L.H. side beam
24. Headlight B.H. fog light
25. Headlight L.H. fog light
26. Headlight B.H. fog light
27. Headlight L.H. fog light
28. Headlight B.H. fog light
29. Headlight L.H. fog light
30. Headlight B.H. fog light
31. Headlight L.H. fog light
32. Headlight B.H. fog light
33. Headlight L.H. fog light
34. Headlight B.H. fog light
35. Headlight L.H. fog light
36. Headlight B.H. fog light
37. Headlight L.H. fog light
38. Headlight B.H. fog light
39. Headlight L.H. fog light
40. Headlight B.H. fog light
41. Headlight L.H. fog light
42. Headlight B.H. fog light
43. Headlight L.H. fog light
44. Headlight B.H. fog light
45. Headlight L.H. fog light
46. Headlight B.H. fog light
47. Headlight L.H. fog light
48. Headlight B.H. fog light
49. Headlight L.H. fog light
50. Headlight B.H. fog light
51. Headlight L.H. fog light
52. Headlight B.H. fog light
53. Headlight L.H. fog light
54. Headlight B.H. fog light
55. Headlight L.H. fog light
56. Headlight B.H. fog light
57. Headlight L.H. fog light
58. Headlight B.H. fog light
59. Headlight L.H. fog light
60. Headlight B.H. fog light
61. Headlight L.H. fog light
62. Headlight B.H. fog light
63. Headlight L.H. fog light
64. Headlight B.H. fog light
65. Headlight L.H. fog light
66. Headlight B.H. fog light
67. Headlight L.H. fog light
68. Headlight B.H. fog light
69. Headlight L.H. fog light
70. Headlight B.H. fog light
71. Headlight L.H. fog light
72. Headlight B.H. fog light
73. Headlight L.H. fog light
74. Headlight B.H. fog light
75. Headlight L.H. fog light
76. Headlight B.H. fog light
77. Headlight L.H. fog light
78. Headlight B.H. fog light
79. Headlight L.H. fog light
80. Headlight B.H. fog light
81. Headlight L.H. fog light
82. Headlight B.H. fog light
83. Headlight L.H. fog light
84. Headlight B.H. fog light
85. Headlight L.H. fog light
86. Headlight B.H. fog light
87. Headlight L.H. fog light
88. Headlight B.H. fog light
89. Headlight L.H. fog light
90. Headlight B.H. fog light
91. Headlight L.H. fog light
92. Headlight B.H. fog light
93. Headlight L.H. fog light
94. Headlight B.H. fog light
95. Headlight L.H. fog light
96. Headlight B.H. fog light
97. Headlight L.H. fog light
98. Headlight B.H. fog light
99. Headlight L.H. fog light
100. Headlight B.H. fog light

11. Power switch on instrument panel
12. Ignition and lighting switch 4 way
13. Oil pressure gauge (instrument)
14. Fuel gauge
15. Speed light switch
16. Speed light switch
17. Speed light switch
18. Speed light switch
19. Speed light switch
20. Speed light switch
21. Speed light switch
22. Speed light switch
23. Speed light switch
24. Speed light switch
25. Speed light switch
26. Speed light switch
27. Speed light switch
28. Speed light switch
29. Speed light switch
30. Speed light switch
31. Speed light switch
32. Speed light switch
33. Speed light switch
34. Speed light switch
35. Speed light switch
36. Speed light switch
37. Speed light switch
38. Speed light switch
39. Speed light switch
40. Speed light switch
41. Speed light switch
42. Speed light switch
43. Speed light switch
44. Speed light switch
45. Speed light switch
46. Speed light switch
47. Speed light switch
48. Speed light switch
49. Speed light switch
50. Speed light switch
51. Speed light switch
52. Speed light switch
53. Speed light switch
54. Speed light switch
55. Speed light switch
56. Speed light switch
57. Speed light switch
58. Speed light switch
59. Speed light switch
60. Speed light switch
61. Speed light switch
62. Speed light switch
63. Speed light switch
64. Speed light switch
65. Speed light switch
66. Speed light switch
67. Speed light switch
68. Speed light switch
69. Speed light switch
70. Speed light switch
71. Speed light switch
72. Speed light switch
73. Speed light switch
74. Speed light switch
75. Speed light switch
76. Speed light switch
77. Speed light switch
78. Speed light switch
79. Speed light switch
80. Speed light switch
81. Speed light switch
82. Speed light switch
83. Speed light switch
84. Speed light switch
85. Speed light switch
86. Speed light switch
87. Speed light switch
88. Speed light switch
89. Speed light switch
90. Speed light switch
91. Speed light switch
92. Speed light switch
93. Speed light switch
94. Speed light switch
95. Speed light switch
96. Speed light switch
97. Speed light switch
98. Speed light switch
99. Speed light switch
100. Speed light switch

11. Fuel tank L.H. top
12. Fuel tank L.H. bottom
13. Fuel tank L.H. middle
14. Fuel tank L.H. side
15. Fuel tank L.H. rear
16. Fuel tank L.H. front
17. Fuel tank L.H. left
18. Fuel tank L.H. right
19. Fuel tank L.H. top
20. Fuel tank L.H. bottom
21. Fuel tank L.H. middle
22. Fuel tank L.H. side
23. Fuel tank L.H. rear
24. Fuel tank L.H. front
25. Fuel tank L.H. left
26. Fuel tank L.H. right
27. Fuel tank L.H. top
28. Fuel tank L.H. bottom
29. Fuel tank L.H. middle
30. Fuel tank L.H. side
31. Fuel tank L.H. rear
32. Fuel tank L.H. front
33. Fuel tank L.H. left
34. Fuel tank L.H. right
35. Fuel tank L.H. top
36. Fuel tank L.H. bottom
37. Fuel tank L.H. middle
38. Fuel tank L.H. side
39. Fuel tank L.H. rear
40. Fuel tank L.H. front
41. Fuel tank L.H. left
42. Fuel tank L.H. right
43. Fuel tank L.H. top
44. Fuel tank L.H. bottom
45. Fuel tank L.H. middle
46. Fuel tank L.H. side
47. Fuel tank L.H. rear
48. Fuel tank L.H. front
49. Fuel tank L.H. left
50. Fuel tank L.H. right
51. Fuel tank L.H. top
52. Fuel tank L.H. bottom
53. Fuel tank L.H. middle
54. Fuel tank L.H. side
55. Fuel tank L.H. rear
56. Fuel tank L.H. front
57. Fuel tank L.H. left
58. Fuel tank L.H. right
59. Fuel tank L.H. top
60. Fuel tank L.H. bottom
61. Fuel tank L.H. middle
62. Fuel tank L.H. side
63. Fuel tank L.H. rear
64. Fuel tank L.H. front
65. Fuel tank L.H. left
66. Fuel tank L.H. right
67. Fuel tank L.H. top
68. Fuel tank L.H. bottom
69. Fuel tank L.H. middle
70. Fuel tank L.H. side
71. Fuel tank L.H. rear
72. Fuel tank L.H. front
73. Fuel tank L.H. left
74. Fuel tank L.H. right
75. Fuel tank L.H. top
76. Fuel tank L.H. bottom
77. Fuel tank L.H. middle
78. Fuel tank L.H. side
79. Fuel tank L.H. rear
80. Fuel tank L.H. front
81. Fuel tank L.H. left
82. Fuel tank L.H. right
83. Fuel tank L.H. top
84. Fuel tank L.H. bottom
85. Fuel tank L.H. middle
86. Fuel tank L.H. side
87. Fuel tank L.H. rear
88. Fuel tank L.H. front
89. Fuel tank L.H. left
90. Fuel tank L.H. right
91. Fuel tank L.H. top
92. Fuel tank L.H. bottom
93. Fuel tank L.H. middle
94. Fuel tank L.H. side
95. Fuel tank L.H. rear
96. Fuel tank L.H. front
97. Fuel tank L.H. left
98. Fuel tank L.H. right
99. Fuel tank L.H. top
100. Fuel tank L.H. bottom