



1876
1-7-24
3.8

**2 SEATER—4 SEATER
COUPÉ**

**SPARE PARTS
• LIST •**

Price - 1/6

**MORGAN MOTOR CO., LTD.
MALVERN LINK, WORCS.**

Telephone: Malvern 106 Telegrams: Morgan Motors

INDEX

SECTION	Page
CHASSIS FRAME	3
ENGINE —	
CYLINDER BLOCK	3
ROCKER COVER	3
SUMP	3
ENGINE PLATE AND MOUNTINGS	3
TIMING COVER	4
CRANKSHAFT AND BEARINGS	4
CONNECTING ROD	4
PISTONS	4
VALVE GEAR AND ROCKERS	4
CAMSHAFT	5
OIL PUMP AND FILTER	5
DIPSTICK	5
FLYWHEEL	5
PETROL PUMP	5
CARBURETTOR	5
AIR CLEANER	5
WATER PUMP	5
MANIFOLD	5
CLUTCH	6
COOLING SYSTEM	6
FUEL SYSTEM	6
EXHAUST SYSTEM	6
SUSPENSION —	7
FRONT	7
REAR	8
AUTO-LUBRICATION	7
HUBS—FRONT	8
WHEELS	8
BRAKES	8
STEERING	10
GEARBOX	11
TRANSMISSION	12
REAR AXLE	12
BODY DETAILS	13
ELECTRICAL	15
TOOLS	15

Part Number	Description	Price £ s. d.	Part Number	Description	Price £ s. d.
V4-10-70.	TIMING COVER		V4-10-120.	Rocker Pedestal, drilled	3 6
V4-10-71.	Timing Cover Assembly	5 0	V4-10-121.	" plain	2 9
V4-10-72.	Joints, for cover	1 3	V4-10-122.	" Spring, intermediate	3 3
	Chain-tensioner	1 6	V4-10-123.	" outer	3 0
V4-10-73.	CRANKSHAFT AND BEARINGS		V4-10-124.	" No. 1 Assembly, with bush	5 0
V4-10-74.	Crankshaft	14 0 0	V4-10-125.	" Bush	4 4
V4-10-75.	Main Bearing (pair)	5 6	V4-10-126.	" No. 2 Assembly, with bush	5 0
V4-10-76.	"	6 6	V4-10-127.	Valve Guide, in combustion head	1 0
V4-10-77.	"	6 6	CAMSHAFT		
V4-10-78.	Thrust Washer, top	6 6	V4-10-128.	Camshaft	3 6 0
V4-10-79.	" bottom	1 3	V4-10-129.	Bearing, camshaft, front, phosphor bronze	10 0
V4-10-80.	Chain Wheel	1 3	V4-10-130.	Chain-wheel, on camshaft	17 6
V4-10-81.	Pulley Hub	10 6	V4-10-131.	Timing Chain	1 0 0
V4-10-82.	" Assembly	5 0	OIL PUMP AND FILTER		
V4-10-83.	Starter Jaw Assembly	10 6	V4-10-132.	Oil Pump Assembly	1 12 6
V4-10-84.	CONNECTING ROD		V4-10-133.	Oil Filter Assembly, sump suction	14 6
V4-10-85.	Connecting Rod Assembly, with bolts	2 2 0	V4-10-134.	Oil Filter Element (Percolator)	10 6
V4-10-86.	Bush, connecting rod, small end	1 0	DIPSTICK		
V4-10-87.	Bearing, connecting rod (pair)	3 6	V4-10-135.	Engine Dipstick Assembly	2 6
V4-10-88.	"	4 6	FLYWHEEL		
V4-10-89.	"	4 6	V4-10-136.	Flywheel Assembly	3 18 6
V4-10-90.	Bolt, connecting rod	6 3	V4-10-137.	Gear, ring	1 11 0
V4-10-91.	PISTONS		PETROL PUMP		
V4-10-92.	Piston Assembly, split skirt	1 10 6	V4-10-138.	Fuel Pump (A.C.)	2 0 0
V4-10-93.	" plus .020"	2 5 0	V4-10-139.	Washer	5
V4-10-94.	" plus .030"	5 0	CARBURETTOR		
V4-10-95.	Pressure Ring, top	5 0	V4-10-140.	Carburettor	8 15 0
V4-10-96.	" plus .020"	4 6	V4-10-141.	Air Jet, G.A. air correction	2 6
V4-10-97.	" plus .030"	3 0	V4-10-142.	Petrol Jet, G.S. Starter	3 9
V4-10-98.	" plus .010"	2 2	V4-10-143.	Main Jet (No. 120, 135 or 140)	1 10
V4-10-99.	" plus .030"	2 8	V4-10-144.	Auxiliary Jet, pilot	3 0
V4-10-100.	Scraping Ring	2 8	V4-10-145.	Choke Tube (No. 23 or 25)	6 8
V4-10-101.	" plus .020"	2 8		Float	4 10
V4-10-102.	" plus .030"	2 8	WATER PUMP		
V4-10-103.	Gudgeon Pin	5 6	V4-10-147.	Water Pump Assembly	4 15 0
V4-10-104.	Circlip	4	V4-10-148.	Housing, with grease nipple	10 7
V4-10-105.	VALVE GEAR AND ROCKERS		V4-10-149.	Gasket, water pump housing to body	2
V4-10-106.	Tappet, in block	2 6	V4-10-150.	pump to cylinder block	2
V4-10-109.	Push Rod	2 1	V4-10-151.	Fan Pulley, and extension	1 11 6
V4-10-110.	Inlet Valve	6 3	V4-10-152.	Fan	8 0
V4-10-111.	Exhaust Valve	7 0	V4-10-153.	" Belt	9 6
V4-10-112.	Spring Collar	8	V4-10-5.	Fan Pulley, extension and fan assembly	1 19 6
V4-10-113.	Valve Spring, outer	1 7	MANIFOLD		
V4-10-114.	" inner	10	V4-10-154.	Exhaust Manifold	2 15 0
V4-10-115.	" auxiliary	2 3	V4-10-155.	Inlet	2 4 9
V4-10-116.	Collar	1 6	V4-10-156.	Manifold Joint	6 6
V4-10-117.	Spring, outer	1 7	V4-10-157.	Exhaust Manifold Assembly	4 11 0
V4-10-118.	Valve Cap	3 8			
V4-10-119.	Rockershaft	10 0			
	" Spring, centre	3			

Price
£ s. d.

Description

Part Number

Price
£ s. d.

Description

Part Number

Filler Cap—2-Str. and Coupe
4-Str.
Accelerator Cable Assy.—R.H. Drive
L.H.
Pedal Assembly
For Fuel Pump and Carburettor refer to engine section

V4-9-9.
V4-2-2.
V4-9-47.
V4-9-16A.
V4-9-52.

4 7 5
16 0
1 0
1 7 0
2 4
1 7
1 7

CLUTCH

Cover Assembly, containing springs, pressure plate and toggle
Cover only
Thrust Spring
Pressure Plate
Eye Bolt
Nut, Eye Bolt
Release Lever
Anti-Rattle Spring
Driven Plate Assembly
Facings and Rivets, driven plate
Sleeve, throw out, with carbon ring
Carbon Ring
Eye Bolt, sleeve
Rod, throw out with yoke ends
Yoke End, rod, L.H. Thread
" " R.H.
Lever, actuating
Spring, return
Pedal
Rubber, pedal
Lever, pedal shaft
Link, lever to rod
Dowel Pin, long
" " short
Housing and transmission tube
Sealing Rubber Ring, housing

V4-11-44.
V4-11-48.
V4-11-49.
V4-11-50.
V4-11-51.
V4-11-52.
V4-11-53.
V4-11-54.
V4-11-45.
V4-11-47.
V4-11-31.
V4-11-38.
V4-11-34.
V4-11-35.
V4-11-39.
V4-11-40.
V4-11-33.
V4-11-41.
V4-11-36.
V4-11-22.
V4-11-29.
V4-11-32.
V4-11-42.
V4-11-43.
V4-11-30.
V4-11-46.

16 4
1 5 9
1 9
1 6
1 3
1 3
3 0
5 0
2 9
3 6
9 9
7 10 0
8 6

1 10 0
5 9
5 0
6 6
10 6

EXHAUST SYSTEM

Bend—Manifold to Flexible Pipe
Flexible Pipe
Silencer
Tail Pipe
Clip, flexible pipe
Clip, silencer
Flange, manifold
Washer, flange
Rubber, silencer, plain
" tail pipe, plain shaped
" " shaped
Bracket, silencer, front
" rear
" tail pipe

V4-8-20.
V4-8-30.
V4-8-22.
V4-8-24.
V4-8-21.
V4-8-29.
V4-8-32.
V4-8-31.
V4-8-23.
V4-8-28.
V4-8-16.
V4-8-17.
V4-8-25.
V4-8-26.
V4-8-27.

8 6
1 4 9
1 17 6
1 1 3
1 2 3
2 6
2 4
6 6
6 6
6 6
2 3
2 3
2 3

SUSPENSION - FRONT

Main Spring
Rubber Spring
Dust Cover
Sliding and Sub-Axle Assy., with bushes—R.H.
L.H.
King Pin
Union Bolt, auto lubrication
Bush
Steering Damper Assembly—L.H.
R.H.
Shock Absorber
" Fixing Pin
" Bracket
" Rubber—top
" " bottom
Steering Damper Blade—L.H.
R.H.
Clamp for Blade

V4-3-48.
V4-3-4.
V4-3-45.
V4-3-41.
V4-3-42.
V4-3-39.
V4-3-40.
V4-3-9.
V4-3-37.
V4-3-57A.
V4-3-51.
V4-3-46.
V4-3-47.
V4-3-50.
V4-3-55.
V4-3-55A.
V4-3-56.

10 6
6 0
2 6
3 19 3
3 19 3
12 4
5 0
8 3
14 3
15 0
2 0
3 0
9 9
2 6
2 6
9

AUTO LUBRICATION - FRONT SUSPENSION

Valve Assembly
Oil Pipe Assembly valve to stub axle
Oil Pipe, valve to flexible pipe
Flexible Pipe, oil gauge

V4-1-92.
V4-1-90.
V4-1-87.
V4-1-88.
V4-1-114.

1 7 6
15 0
1 6
3 10

COOLING SYSTEM

Radiator—clw grille, badge, filler cap and hinged number plate
Grille
Badge
Filler Cap
Drain Tap and Washer
Tape and Rivets
Support Bracket
Rubber Mounting Pad
Block
Shell (Chromium Plated)
Relief Valve Assembly
Hose—top
" bottom
Clip, hose, top
" bottom
Number Plate and Hinge Assembly
Hinge
Hinged Plate Assembly (used with bumper)
Tie Bar

V4-2-1.
V4-2-44.
V4-1-103.
V4-2-2.
V4-2-7.
V4-2-28.
V4-2-39.
V4-2-4.
V4-2-8.
V4-2-5.
V4-2-52.
V4-2-45.
V4-2-53.
V4-2-47.
V4-2-17/18/19.
V4-2-19.
V4-2-55.
V4-2-43.

28 15 0
4 15 0
15 0
6 9
5 0
9 6
2 6
10 7 3
4 15 0
3 6
2 0
6 6
1 3
17 9
4 6
10 6
3 6

FUEL SYSTEM

Tank, 2-Str.
Coupe
4-Str.
Tank Drain Plug

V4-9-54.
V4-9-57.
V4-9-58.
V4-9-4.

3 12 6
3 12 6
3 12 6
9

2-1/2-10

Part Number

Description

Price
£ s. d.

Part Number

Description

Price
£ s. d.

STEERING

GEARBOX

STEERING

GEARBOX

Part Number	Description	Price £ s. d.	Part Number	Description	Price £ s. d.
V4-5-90/2	Hose, L. or R.	11 8	V4-12-120	Case	6 6 7
V4-5-90/3	Pipe four-way to rear hose	7 2	V4-12-200	Cover, top	5 17 8
V4-5-90/13	Tee Piece—hose	5 1	V4-12-126	Cover, end—front	1 18 4
V4-5-179	Hose, pipe to tee	11 0	V4-12-128	Oil Seal	2 4
V4-5-90/3	Pipe, tee to rear—L.H.	3 3	V4-12-195	Cover, end—rear	4 19 9
V4-5-90/4	" " " " R.H.	9 5	V4-12-196	Oil Seal	6 2
V4-7-56	Column Complete—R.H. Drive	9 3 9	V4-12-121	Drain Plug	1 4
V4-7-65	" " " " L.H.	9 3 9	V4-12-201	Cap, top cover	2 8
V4-7-71R	Inner Column and Nut—R.H. Drive	2 9 11	V4-12-235	Dipstick Rod	6 7
V4-7-71L	" " " " L.H.	2 9 11	V4-12-236	" " Knob	6 0
V4-7-74R	Cover Plate for Box—R.H. Drive	3 2	V4-12-237	" " Felt Washer	11
V4-7-74L	" " " " L.H.	3 2	V4-12-238	" " Bush	4 5
V4-7-66	Plug	5	V4-12-133	Primary Shaft	5 16 8
V4-7-76	Cover Plate Weather	1	V4-12-125	Bush	7 7 7
V4-7-25	Drop Arm	15 3	V4-12-140	Mainshaft	1 3
V4-7-82	Rocker Shaft	1 1 0	V4-12-152	Locking Plunger	4
V4-7-82	Bush, rocker shaft	1 3 8	V4-12-153	Spring	1 0 5
V4-7-77	Trunnion Bush	3 8	V4-12-171	Countershaft	6 9
V4-7-83	Oil Plug	1 1	V4-12-172	Retaining Pin, front	2 9
V4-7-84	Key, steering wheel	4	V4-12-173	Thrust Washer	6 2
V4-7-57	Steering Wheel	5 0	V4-12-174	Retaining Ring	5 7
V4-7-23	Wheel Fixing Nut	2 6	V4-12-179	Thrust Washer, inner—rear	5 7
V4-7-63	Column Support Bar—2- and 4-Str.	6 0	V4-12-180	" " outer	2 3 11
V4-7-64	" " " " Coupe	6 0	V4-12-181	Constant Mesh Piston	1 1 4
V4-7-38	" " Clip, 1 1/2"	4 6	V4-12-159	Speedometer Gear—driver	1 9 6
V4-7-38A	" " " " 1"	4 6	V4-12-166	" " driven	15 4
V4-7-40	Clip Bolt, long	1 6	V4-12-167	Bush	4 1 3
V4-7-41	" " short	6	V4-12-156	Synchro Sleeve 2nd	3 12 4
V4-7-52	Column Fixing Distance Piece—L.H.	3 0	V4-12-142	Synchro Sleeve 3rd and top	2 10 9
V4-7-53	" " " " R.H.	3 0	V4-12-143	Operating Sleeve	2
V4-7-59	" " Bolt	1 3	V4-12-157	Spring, synchro sleeve	2
V4-7-62	Stop	1 9	V4-12-158	Ball	2 2
V4-7-24	Rubber Collar	3 6	V4-12-207	Lever, Gear Change	1 15 5
V4-7-68	Track Rod Assembly	2 10 0	V4-12-208	Knob	1 4
V4-7-69	Track Rod and Drag Link Assembly	1 5 0	V4-12-182	Cluster Gear	12 16 3
V4-7-54	" " only	3 15 0	V4-12-184	Reverse Wheel	3 6 10
V4-7-53	Drag Link	5 0	V4-12-185	Bush, Reverse Wheel	11
V4-7-43	Track Rod End—L.H.	3 6	V4-12-155	Spindle, Reverse Wheel	12 0
V4-7-44	" " R.H.	5 6	V4-12-154	Gear, 1st	6 2 3
V4-7-45	Washer, track rod end—top	4 6	V4-12-147	" " 2nd	4 18 8
V4-7-46	" " " " bottom	9	V4-12-146	" " 3rd	4 5 9
V4-7-47	Pin, track rod	9	V4-12-219	Locking Ring	18 1
V4-7-47A	Rubber Bush, track rod	3 3	V4-12-221	Selector, 1st and 2nd	1 7 0
V4-7-11	Lock Nut, track rod and drag link	1 9	V4-12-221	" " 3rd and top	1 0 5
V4-7-27	Ball Joint Assembly—long pin	1 8	V4-12-223	" " reverse	1 3 2
V4-7-28	" " short pin	13 3	V4-12-220	rod, 1st and 2nd	1 15 8
V4-7-26	" " Socket	13 0	V4-12-222	Distance Tube	1 6 7
V4-7-15	Pin, ball joint—long	3 6	V4-12-222	Selector Rod, 3rd and top	1 15 8
V4-7-13	" " short	2 6	V4-12-225	" " reverse	2 0 5
V4-7-14	Lock Nut	2 8	V4-12-217	Distance Tube	4 5
V4-7-29	Spring	6	V4-12-244	Thumble, Selector Rod	1 9
V4-7-30	Cap	1 6	V4-12-177	Rubber Washer, layshaft	3 2
V4-7-31	Adjuster	2 6	V4-12-178	" " reverse shaft	2
			V4-12-135	Ball Bearing, primary shaft—SKF 6306	1 4 0
			V4-12-136	Circclip	9

Part Number

Part Number	Description	Price £ s. d.
V4-12-137	Circclip for Primary Shaft	1 4 3
V4-12-247	Bearing, tail primary shaft	1 4 3
V4-12-138	Roller Bearing, constant mesh pinion	6 6 6
V4-12-141	Ball Bearing, mainshaft, SKF, RMS(I)	1 10 0
V4-12-170	Needle roller (2nd and 3rd Gear Wheels)	3 1
V4-12-175	" (Countershaft)	3 1
V4-12-5	Bolt, front fixing, long	1 6
V4-12-4	" " " short	1 6
V4-12-7	" " " and brake cable stop	1 9
V4-12-8	" " holding down	2 0
V4-12-10	Metal Cover	1 17 6
V4-12-11	*Leather Cover (Purchase Tax 12/3)	3 5 6
V4-1-89	Silentbloc	9 4
V4-1-86	Screw, silentbloc	1
	*Add Purchase Tax	

TRANSMISSION

V4-13-9	Shaft, engine to gearbox	1 15 0
V4-13-11	Muff Coupling	1 6
V4-13-12	*Propeller Shaft Complete	8 3 0
V4-13-16	*Journal Unit Package	1 12 4
V4-13-25	*Bolt, flange	7
V4-13-26	*Nut, flange bolt	3 1
V4-13-27	*Lock Washer, flange bolt	3 1
V4-13-13	*Plus 35%	11 6

†Includes Journal assembly, four bearing race assemblies and four circlips.

REAR AXLE

V4-14-5	U Bolt	2 0
V4-14-2	U Bolt, with shock absorber fixing	5 6
V4-14-11	Drive Gear and Pinion Assy. complete, comprising drive gear, pinion gear, nut, cotter, bolts and lock straps	10 8 9
V4-14-12	Gear Carrier Cover Assembly	9 8
V4-14-13	Companion Flange Assembly	1 2 6
V4-14-14	Rear Hub Assembly	2 17 6
V4-14-15	Hub Oil Seal Assembly	6 0
V4-14-16	Diff. Case Assembly	7 9 0
V4-14-17	Diff. Case Brg. Cap Bolt	8
V4-14-18	" " Lock Washer	2
V4-14-19	Drive Gear Bolt	9
V4-14-20	" " Lock Strap	3
V4-14-21	Diff. Case	3 15 0
V4-14-22	" " Case Side Gear	1 5 0
V4-14-23	" " Thrust Washer	12 6
V4-14-24	" " Pinion Mate	4
V4-14-25	" " Thrust Washer	7 4
V4-14-26	" " Shaft	4
V4-14-27	" " Lock Pin	4
V4-14-28	Axle Shaft Spacer	7 0
V4-14-29	Diff. Bearing Shim .003"	3
V4-14-30	" " .005"	3
V4-14-31	" " .010"	3
V4-14-32	" " .030"	3

Part Number

Part Number	Description	Price £ s. d.
V4-14-33	Pinion Adj. Shim, .003" Inner	...
V4-14-34	" " " .005"	...
V4-14-35	" " " .010"	...
V4-14-36	" Brg. Adj. Shim, .003" Outer	...
V4-14-37	" " " " "	...
V4-14-38	" " " " "	...
V4-14-39	" " " " "	...
V4-14-40	" " " " "	...
V4-14-41	" " " " "	...
V4-14-42	" " " " "	...
V4-14-43	" " " " "	...
V4-14-44	" " " " "	...
V4-14-45	" " " " "	...
V4-14-46	" " " " "	...
V4-14-48	" " " " "	...
V4-14-49	" " " " "	...
V4-14-50	" " " " "	...
V4-14-52	" " " " "	...
V4-14-53	" " " " "	...
V4-14-54	" " " " "	...
V4-14-55	" " " " "	...
V4-14-56	" " " " "	...
V4-14-57	" " " " "	...
V4-14-58	" " " " "	...
V4-14-59	" " " " "	...
V4-14-60	" " " " "	...
V4-14-61	" " " " "	...
V4-14-62	" " " " "	...
V4-14-63	" " " " "	...
V4-14-64	" " " " "	...
V4-14-65	" " " " "	...
V4-14-66	" " " " "	...
V4-14-68	" " " " "	...
V4-14-69	" " " " "	...
V4-14-70	" " " " "	...
V4-14-71	" " " " "	...
V4-14-72	" " " " "	...
V4-14-73	" " " " "	...

NOTE.—From ord including V4-14-11 add 5% (excluding Bearings)

BODY DETAILS

MUDGUARDS

V4-15-107	Mudguard, front—R.H.	8 8 9
V4-15-107A	" " " L.H.	8 8 9
V4-15-109	" " " rear—R.H.	6 3 9
V4-15-108	" " " " L.H.	6 3 9
V4-15-311A	Tread Rubber Aluminium Moulding with Screws and Nuts	9 3
V4-1-95/6	Valance Stay—front, R.H.	3 0
V4-1-97/98	" " " L.H.	3 0
V4-1-87	Valance Stay, rear	2 6
V4-1-93	Stay, main, front	3 6

Part Number	Description	Price £ s. d.
V4-15-43.	Cushion Insulator, air	1 5 0
V4-15-23.	Clamp Plate, Adjustment	1 6 6
V4-15-161.	Seat Runner	4 6
V4-15-90.	Squab, 2-Str. and Coupe (Purchase Tax 10/4)	12 10 0
V4-15-137.	" 4-Str. (Purchase Tax 6/7)	3 7 6
BUMPERS		
V4-15-159.	Bumper—front	10 15 0
V4-15-160.	rear (pair)	4 5 0
FACIA		
V4-15-149.	Facia Board, 2- and 4-Str.	2 17 6
V4-15-150.	" " Coupe	2 17 6
MISCELLANEOUS		
V4-17-33.	License Holder	3 9
V4-17-30.	Driving Mirror	10 6
V4-17-29.	Towing Bar	3 10 0
V4-17-32.	Luggage Grid	8 10 0

Add Purchase Tax where shown

Part Number	Description	Price £ s. d.
V4-16-23(4)14.	Lamp Bar with support tubes, Coupe	2 10 0
V4-16-14.	" " " 2-Str. and 4-Str.	3 10 0
V4-16-11.	" " " Coupe	3 0 0
V4-16-31.	" " " 2-Str. and 4-Str.	2 0 0
V4-16-311.	Support Tubes and Lugs	12 0
V4-16-311.	Speedometer Flexible Drive	1 5 6
V4-16-60.	Speedometer Inner Cable on Outer Casing only	12 9
V4-16-60.	Choke Control	5 9

ELECTRICAL, FACIA AND PANEL SUNDRIES

Lamps and other electricals, Facia and Panel Instruments, as makers' lists

NOTE—Most items can be exchanged for factory replacement units at exchange prices

TOOLS

V4-17-14.	Jack	1 10 0
V4-17-23.	Starting Handle	15 0
V4-17-23A.	" " for bumper	15 6
V4-17-15.	Tyre Inflator	10 0
V4-17-17.	Oil Can	3 6
V4-17-31.	Tool Kit complete (includes following separate tools)	2 12 6
V4-17-18.	Tool Roll	3 0
V4-17-16.	Grease Gun	8 9
V4-17-24.	Feeler Gauge	1 3

Part Number	Description	Price £ s. d.
BONNET		
V4-15-121.	Bonnet c/w hinge and fasteners, 2-Str. and 4-Str.	7 10 0
V4-15-122.	" " " Coupe	7 10 0
V4-15-76(7)B.	Bonnet Hinge with Chrome Strip Composites	1 15 0
V4-15-57.	Hinge End Piece	2 6
V4-15-47.	Bonnet Fastener Assembly	7 5
V4-15-169.	Knob only	2 6
V4-15-103.	Buffer Stop	2 6
WINDSCREEN		
V4-15-110.	Windscreen c/w brackets, 2-Str.	13 12 0
V4-15-125.	4-Str.	11 16 6
V4-15-111.	" " " Coupe	8 7 6
V4-15-139.	Screen Pillar—R.H., 2 or 4-Str. (pair)	4 0 0
V4-15-140.	L.H.	4 0 0
V4-15-143.	Rubber Pad, screen pillar (pair)	4 4
V4-15-141.	Screws, screen pillar	3
V4-15-142.	Bolt and Nut, fixing	5
V4-15-144.	Lift-the-dot Stud—top rail	5 0
V4-15-145.	Knurled nut windscreen	5 2 0
V4-15-114.	Side Window Coupe—R.H.	5 2 0
V4-15-115.	L.H.	5 2 0
V4-15-138.	Rear Window, hood, coupe	3 7 6
SIDESCREENS		
V4-15-112.	Sidescree—R.H. 2-Str. (pair)	14 10 0
V4-15-113.	L.H.	14 10 0
V4-15-126.	front R.H. 4-Str.	17 10 0
V4-15-128.	rear R.H.	
V4-15-127.	front L.H.	
V4-15-129.	rear L.H.	
V4-15-164.	Knurled Nut, fixing	7 6
DOORS		
V4-15-37.	Door Lock—Coupe, R. or L.	1 10 0
V4-15-26.	Handle, outside, Coupe R. or L.	9 6
V4-15-167.	inside	5 0
V4-15-38.	Striker Plate	5 0
V4-15-39.	Door Lock, 2- and 4-Str., R. or L.	15 0
V4-15-123.	Handle, outside, 2- and 4-Str., R. or L.	15 0
V4-15-40.	Striker Plate	3 6
V4-15-162.	Hinges, door, Coupe	8 6
V4-15-163.	" " " 2-Str. and 4-Str.	5 0
V4-15-166.	Strap, door stop, Coupe	6 6
V4-15-155.	Dovetail Rubber	1 3
SEATS AND SQUABS		
V4-15-133.	Seat frame, 4-Str.—R.H.	4 16 3
V4-15-134.	L.H.	4 16 3
V4-15-135.	" Cushion, 4-Str., front (Purchase Tax 7/1)	2 17 6
V4-15-136.	" " " rear (Purchase Tax 13/10)	3 15 0
V4-15-170.	" " " Composites, 2-Str. and Coupe (Purchase Tax 10%)	3 17 6

Part Number	Description	Price		
		£	s.	d.
V4-17-25.	Tube Spanner ...	2	6	
V4-17-26.	" " " " " "	2	6	
V4-17-27.	Open Ended Spanner ...	2	6	
V4-17-28.	" " " " " "	2	6	
V4-17-1.	Tyre Lever (2) ...	3	0	
V4-17-2.	Valve Tool ...	4	0	
V4-17-4.	Hammer ...	3	9	
V4-17-5.	Pliers ...	2	0	
V4-17-6.	Screwdriver ...	2	0	
V4-17-8.	Tommy Bar ...	1	6	
V4-17-9.	3/16 x 1/2 Spanner ...	3	3	
V4-17-10.	5/16 x 3/4 " "	3	0	
V4-17-11.	7/16 x 1 " "	6	0	
V4-17-12.	Adjustable Spanner ...	2	6	
V4-17-13.	Wheel Nut Spanner ...	2	6	
V4-17-7.	Plug Spanner ...	5	0	