




ELECTRICAL WIRING DIAGRAM.  
SILVER DAWN CHASSIS SERIES SBA TO SHD. (R.H. DRIVE)





ELECTRICAL WIRING DIAGRAM.  
SILVER WRAITH CHASSIS SERIES WTA TO WFC. (R.H. DRIVE)




ELECTRICAL WIRING DIAGRAM  
 SILVER WRAITH CHASSIS SERIES WGC TO WSG. (R.H. DRIVE)



ELECTRICAL WIRING DIAGRAM  
 BENTLEY CHASSIS SERIES AK TO DA. (R.H. DRIVE)



ELECTRICAL WIRING DIAGRAM.  
BENTLEY CHASSIS SERIES OZ TO PU. (R.H. DRIVE)



ELECTRICAL WIRING DIAGRAM.  
 BENTLEY CHASSIS SERIES "R" TYPE. (R.H. DRIVE. NON-AUTOMATIC)