

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

<b>make</b>	<b>model</b>	<b>year</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
NISSAN	All Mode	Up to 2018	Engine	Read Fault Code	
NISSAN	All Mode	Up to 2018	Engine	Clear Fault Code	
NISSAN	All Mode	Up to 2018	Engine	Read Data Stream	
NISSAN	All Mode	Up to 2018	Engine	Read Freeze Frame	
NISSAN	All Mode	Up to 2018	Engine	Module Information	
NISSAN	All Mode	Up to 2018	Engine	Function Test	
NISSAN	All Mode	Up to 2018	Engine	Actuation Test	IACV-AAC/V OPENING
NISSAN	All Mode	Up to 2018	Engine	Actuation Test	EGR CONT(MODE 1)
NISSAN	All Mode	Up to 2018	Engine	Actuation Test	TARGET FAN RPM
NISSAN	All Mode	Up to 2018	Engine	Actuation Test	EGR SOLENOID VALVE
NISSAN	All Mode	Up to 2018	Engine	Actuation Test	P/REG CONT SOL/V
NISSAN	All Mode	Up to 2018	Engine	Actuation Test	VALVE TIMING SOL
NISSAN	All Mode	Up to 2018	Engine	Actuation Test	SWIRL CONT SOL VALVE
NISSAN	All Mode	Up to 2018	Engine	Actuation Test	AIR COND RLY
NISSAN	All Mode	Up to 2018	Engine	Actuation Test	VVL S/V
NISSAN	All Mode	Up to 2018	Engine	Actuation Test	INTAKE DUCT S/V
NISSAN	All Mode	Up to 2018	Engine	Actuation Test	MAP/BARO SW/V
NISSAN	All Mode	Up to 2018	Engine	Actuation Test	VC/V BYPASS/V
NISSAN	All Mode	Up to 2018	Engine	Actuation Test	Power Balance
NISSAN	All Mode	Up to 2018	Engine	Actuation Test	VENT CONT/V
NISSAN	All Mode	Up to 2018	Engine	Actuation Test	ENG COOLANT TEMP
NISSAN	All Mode	Up to 2018	Engine	Actuation Test	FUEL INJECTION
NISSAN	All Mode	Up to 2018	Engine	Actuation Test	Fuel/T Temp SEN
NISSAN	All Mode	Up to 2018	Engine	Actuation Test	PURG VOL CONT/V
NISSAN	All Mode	Up to 2018	Engine	Actuation Test	Fuel Pump Relay
NISSAN	All Mode	Up to 2018	Engine	Actuation Test	IGNITION TIMING
NISSAN	All Mode	Up to 2018	Engine	Actuation Test	V/T ASSIGN ANGLE
NISSAN	All Mode	Up to 2018	Engine	Actuation Test	VIAS S/V-1
NISSAN	All Mode	Up to 2018	Engine	Actuation Test	ENGINE MOUNT
NISSAN	All Mode	Up to 2018	Engine	Actuation Test	TUMBLE CONTROL VALVE
NISSAN	All Mode	Up to 2018	Engine	Actuation Test	FAN DUTY CONTROL
NISSAN	All Mode	Up to 2018	Engine	Actuation Test	ALTERNATOR DUTY
NISSAN	All Mode	Up to 2018	Engine	Actuation Test	VIAS S/V-2
NISSAN	All Mode	Up to 2018	Engine	Actuation Test	INT V/T ASSIGN ANGLE
NISSAN	All Mode	Up to 2018	Engine	Actuation Test	EXH V/T ASSIGN ANGLE
NISSAN	All Mode	Up to 2018	Engine	Actuation Test	COOLING FAN
NISSAN	All Mode	Up to 2018	Engine	Actuation Test	FPCM
NISSAN	All Mode	Up to 2018	Engine	Actuation Test	SUB FUEL CONT SOL/V
NISSAN	All Mode	Up to 2018	Engine	Actuation Test	Sub Fuel Pump Relay
NISSAN	All Mode	Up to 2018	Engine	Actuation Test	FUEL RETURN VALVA
NISSAN	All Mode	Up to 2018	Engine	Actuation Test	ALTERNATOR VOLTAGE
NISSAN	All Mode	Up to 2018	Engine	Actuation Test	Auto Stop Start
NISSAN	All Mode	Up to 2018	Engine	Actuation Test	FUEL SHUTOFF VALVE 1
NISSAN	All Mode	Up to 2018	Engine	Actuation Test	FUEL SHUTOFF VALVE 2
NISSAN	All Mode	Up to 2018	Engine	Actuation Test	FUEL SHUTOFF VALVE 3
NISSAN	All Mode	Up to 2018	Engine	Actuation Test	FUEL SHUTOFF VALVE
NISSAN	All Mode	Up to 2018	Engine	Actuation Test	FP RELAY2
NISSAN	All Mode	Up to 2018	Engine	Actuation Test	FP RELAY3
NISSAN	All Mode	Up to 2018	Engine	Actuation Test	EGR VOL CONT/V
NISSAN	All Mode	Up to 2018	Engine	Actuation Test	Pres Regulator
NISSAN	All Mode	Up to 2018	Engine	Special Function	Idle Air Vol Learn
NISSAN	All Mode	Up to 2018	Engine	Special Function	EVAP System Close
NISSAN	All Mode	Up to 2018	Engine	Special Function	Fuel Pressure Release
NISSAN	All Mode	Up to 2018	Engine	Special Function	Self-Learning Cont
NISSAN	All Mode	Up to 2018	Engine	Special Function	TARGET IGN TIM ADJ
NISSAN	All Mode	Up to 2018	Engine	Special Function	EXH V/T CONTROL LEARN
NISSAN	All Mode	Up to 2018	Engine	Special Function	TARGET IDLE RPM ADJ
NISSAN	All Mode	Up to 2018	Engine	Special Function	CO ADJUSTMENT
NISSAN	All Mode	Up to 2018	Engine	Special Function	ETHANOL M/R ADJ
NISSAN	All Mode	Up to 2018	Engine	Special Function	Vin Registration
NISSAN	All Mode	Up to 2018	Engine	Special Function	AP POS LEARN CLR
NISSAN	All Mode	Up to 2018	Engine	Special Function	TARGET IGN TIM HLD
NISSAN	All Mode	Up to 2018	Engine	Special Function	CLSD THL POS LEARN
NISSAN	All Mode	Up to 2018	Engine	Special Function	VVEL POS SEN ADJ PREP
NISSAN	All Mode	Up to 2018	Engine	Special Function	M/T NEUTRAL POS LEARN
NISSAN	All Mode	Up to 2018	Engine	Special Function	IGNITION TIMING ADJ
NISSAN	All Mode	Up to 2018	Engine	Special Function	CHECK FUEL LINES
NISSAN	All Mode	Up to 2018	Engine	Special Function	V/T CONTROL LEARN
NISSAN	All Mode	Up to 2018	Engine	Special Function	WRT FUEL LEARN VALUE
NISSAN	All Mode	Up to 2018	Engine	Special Function	A/F Initial Learning
NISSAN	All Mode	Up to 2018	Engine	Special Function	Saving Data For Replc CPU
NISSAN	All Mode	Up to 2018	Engine	Special Function	Writing Data For Replc CPU
NISSAN	All Mode	Up to 2018	Engine	Special Function	STRT OPRN CNTR CLEAR
NISSAN	All Mode	Up to 2018	Engine	Special Function	CML B/DCHRG CRNT CLEAR
NISSAN	All Mode	Up to 2018	Engine	Special Function	G Sensor Calibration
NISSAN	All Mode	Up to 2018	Engine	Special Function	Valve Timing Offset Data Writing
NISSAN	All Mode	Up to 2018	Engine	Special Function	Valve Timing Offset Data Clear

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
NISSAN	All Mode	Up to 2018	Engine	Special Function	SC MAGNETIC CLUTCH ENGAGE COUNT CLEAR
NISSAN	All Mode	Up to 2018	Engine	Special Function	Cumulative Sub-Battery Dischg Current Clear
NISSAN	All Mode	Up to 2018	Engine	Special Function	SUB-STARTER&GENERATOR OPER COUNT CLEAR
NISSAN	All Mode	Up to 2018	Engine	Special Function	Active Control Engine Mounting A
NISSAN	All Mode	Up to 2018	Engine	Special Function	Active Control Engine Mounting B
NISSAN	All Mode	Up to 2018	Engine	Special Function	A/F Sensor Response Diagnosis Status B1
NISSAN	All Mode	Up to 2018	Engine	Special Function	A/F Sensor Response Diagnosis Status B2
NISSAN	All Mode	Up to 2018	Engine	Special Function	Engine Coolant Bypass Valve
NISSAN	All Mode	Up to 2018	Engine	Special Function	Misfire count (real-time)
NISSAN	All Mode	Up to 2018	Engine	Special Function	Misfire count (past)
NISSAN	All Mode	Up to 2017	Engine	Read Fault Code	
NISSAN	All Mode	Up to 2017	Engine	Clear Fault Code	
NISSAN	All Mode	Up to 2017	Engine	Read Data Stream	
NISSAN	All Mode	Up to 2017	Engine	Module Information	
NISSAN	All Mode	Up to 2017	Engine	Function Test	
NISSAN	All Mode	Up to 2017	Engine	Actuation Test	THRTL POSITION
NISSAN	All Mode	Up to 2017	Engine	Actuation Test	EGR/V ANGEL
NISSAN	All Mode	Up to 2017	Engine	Actuation Test	SWIRL CONT S/V1
NISSAN	All Mode	Up to 2017	Engine	Actuation Test	GLOW RLY
NISSAN	All Mode	Up to 2017	Engine	Actuation Test	COOLING FAN
NISSAN	All Mode	Up to 2017	Engine	Actuation Test	TC BOOST CONT/V
NISSAN	All Mode	Up to 2017	Engine	Special Function	Enter Injctr Calib Data
NISSAN	All Mode	Up to 2017	Engine	Special Function	EGR/V LEARN CLR
NISSAN	All Mode	Up to 2017	Engine	Special Function	TP POS LEARN CLR
NISSAN	All Mode	Up to 2017	Engine	Special Function	DIF EX PRE LRN CLR
NISSAN	All Mode	Up to 2017	Engine	Special Function	Service Regeneration
NISSAN	All Mode	Up to 2017	Engine	Special Function	DPF Data Clear
NISSAN	All Mode	Up to 2017	Engine	Special Function	A/F SEN LEAN CLR
NISSAN	All Mode	Up to 2017	Engine	Special Function	PTO REGISTRATION
NISSAN	All Mode	Up to 2017	Engine	Special Function	Vin Registration
NISSAN	All Mode	Up to 2017	Engine	Special Function	Injector Learning Value Clear
NISSAN	All Mode	Up to 2017	Engine	Special Function	Mixture Ratio Learning Value Clear
NISSAN	All Mode	2006 - 2012	Engine	Read Fault Code	
NISSAN	All Mode	2006 - 2012	Engine	Clear Fault Code	
NISSAN	All Mode	2006 - 2012	Engine	Read Data Stream	
NISSAN	All Mode	2006 - 2012	Engine	Module Information	
NISSAN	All Mode	2006 - 2012	Engine	Actuation Test	INJECTOR CYLINDER 1
NISSAN	All Mode	2006 - 2012	Engine	Actuation Test	INJECTOR CYLINDER 2
NISSAN	All Mode	2006 - 2012	Engine	Actuation Test	INJECTOR CYLINDER 3
NISSAN	All Mode	2006 - 2012	Engine	Actuation Test	INJECTOR CYLINDER 4
NISSAN	All Mode	2006 - 2012	Engine	Actuation Test	PREHEATER RELAY
NISSAN	All Mode	2006 - 2012	Engine	Actuation Test	FUEL PRESSURE SOLENOID/V
NISSAN	All Mode	2006 - 2012	Engine	Actuation Test	AIR INLET FLAP
NISSAN	All Mode	2006 - 2012	Engine	Actuation Test	FUEL FLOW SOLENOID/V
NISSAN	All Mode	2006 - 2012	Engine	Actuation Test	TURBOCHARGER CNTRL SOL/V
NISSAN	All Mode	2006 - 2012	Engine	Actuation Test	PRE ELEC CONSUM
NISSAN	All Mode	2006 - 2012	Engine	Actuation Test	HIGH PRES CIRCUIT LEAK TEST
NISSAN	All Mode	2006 - 2012	Engine	Actuation Test	Idle Speed Set Increment
NISSAN	All Mode	2006 - 2012	Engine	Actuation Test	STATIC TEST OF ACTUATOR
NISSAN	All Mode	2006 - 2012	Engine	Special Function	Vin Registration
NISSAN	All Mode	2006 - 2012	Engine	Special Function	EGR Adaptives
NISSAN	All Mode	2006 - 2012	Engine	Special Function	Programmed Values
NISSAN	All Mode	2006 - 2012	Engine	Special Function	Prgrm Reinitialize
NISSAN	All Mode	2006 - 2012	Engine	Special Function	Pres REG Adaptive
NISSAN	All Mode	2006 - 2012	Engine	Special Function	Saving Data For Replc CPU
NISSAN	All Mode	2006 - 2012	Engine	Special Function	Writing Data For Replc CPU
NISSAN	All Mode	2006 - 2016	Engine	Read Fault Code	
NISSAN	All Mode	2006 - 2016	Engine	Clear Fault Code	
NISSAN	All Mode	2006 - 2016	Engine	Read Data Stream	
NISSAN	All Mode	2006 - 2016	Engine	Actuation Test	TC BST CONT S/V
NISSAN	All Mode	2006 - 2016	Engine	Actuation Test	FRP CONTROL VALVE
NISSAN	All Mode	2006 - 2016	Engine	Actuation Test	GLOW CONTROL UNIT
NISSAN	All Mode	2006 - 2016	Engine	Actuation Test	EGR COOLER BYPASS CONT S/V
NISSAN	All Mode	2006 - 2016	Engine	Actuation Test	TROTTLER VALVE
NISSAN	All Mode	2006 - 2016	Engine	Actuation Test	Fuel Pump
NISSAN	All Mode	2006 - 2016	Engine	Actuation Test	TURBOCHARGER COOLING PUMP
NISSAN	All Mode	2006 - 2016	Engine	Special Function	Service Regeneration
NISSAN	All Mode	2006 - 2016	Engine	Special Function	LEARNING
NISSAN	All Mode	2006 - 2016	Engine	Special Function	INTJ ADJ VAL REGIST
NISSAN	All Mode	2006 - 2016	Engine	Special Function	ZFC VALUE RESET
NISSAN	All Mode	2006 - 2016	Engine	Special Function	P062F EXCLUSIVE FUNCTION

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
NISSAN	All Mode	2006 - 2016	Engine	Special Function	EGR/V LEARN CLR
NISSAN	All Mode	2006 - 2016	Engine	Special Function	DPF Data Clear
NISSAN	All Mode	2006 - 2016	Engine	Special Function	Saving Data For Replc CPU
NISSAN	All Mode	2006 - 2016	Engine	Special Function	Writing Data For Replc CPU
NISSAN	All Mode	2007 - 2017	Engine	Read Fault Code	
NISSAN	All Mode	2007 - 2017	Engine	Clear Fault Code	
NISSAN	All Mode	2007 - 2017	Engine	Read Data Stream	
NISSAN	All Mode	2007 - 2017	Engine	Module Information	
NISSAN	All Mode	2007 - 2017	Engine	Actuation Test	Fuel Pump RLY
NISSAN	All Mode	2007 - 2017	Engine	Actuation Test	DOWN/ST O2 HT
NISSAN	All Mode	2007 - 2017	Engine	Actuation Test	UP/ST O2 HTR
NISSAN	All Mode	2007 - 2017	Engine	Actuation Test	Canister Bleed Sol/V
NISSAN	All Mode	2007 - 2017	Engine	Actuation Test	Motorrised Throttle
NISSAN	All Mode	2007 - 2017	Engine	Actuation Test	A/C compressor relay control
NISSAN	All Mode	2007 - 2017	Engine	Actuation Test	FAN UNIT LOW
NISSAN	All Mode	2007 - 2017	Engine	Actuation Test	FAN UT HI SPD
NISSAN	All Mode	2007 - 2017	Engine	Actuation Test	Flex-fuel additional solenoid valve
NISSAN	All Mode	2007 - 2017	Engine	Actuation Test	Flex-fuel additional pump
NISSAN	All Mode	2007 - 2017	Engine	Special Function	Programmed Values
NISSAN	All Mode	2007 - 2017	Engine	Special Function	WRITE V. I. N.
NISSAN	All Mode	2006 - 2012	Engine	Read Fault Code	
NISSAN	All Mode	2006 - 2012	Engine	Clear Fault Code	
NISSAN	All Mode	2006 - 2012	Engine	Read Data Stream	
NISSAN	All Mode	2006 - 2012	Engine	Module Information	
NISSAN	All Mode	2006 - 2012	Engine	Actuation Test	INJECTOR CYLINDER 1
NISSAN	All Mode	2006 - 2012	Engine	Actuation Test	INJECTOR CYLINDER 2
NISSAN	All Mode	2006 - 2012	Engine	Actuation Test	INJECTOR CYLINDER 3
NISSAN	All Mode	2006 - 2012	Engine	Actuation Test	INJECTOR CYLINDER 4
NISSAN	All Mode	2006 - 2012	Engine	Actuation Test	PREHEATER RELAY
NISSAN	All Mode	2006 - 2012	Engine	Actuation Test	FUEL PRESSURE SOLENOID/V
NISSAN	All Mode	2006 - 2012	Engine	Actuation Test	AIR INLET FLAP
NISSAN	All Mode	2006 - 2012	Engine	Actuation Test	FUEL FLOW SOLENOID/V
NISSAN	All Mode	2006 - 2012	Engine	Actuation Test	TURBOCHARGER CNTRL SOL/V
NISSAN	All Mode	2006 - 2012	Engine	Actuation Test	PRE ELEC CONSUM
NISSAN	All Mode	2006 - 2012	Engine	Actuation Test	HIGH PRES CIRCUIT LEAK TEST
NISSAN	All Mode	2006 - 2012	Engine	Actuation Test	STATIC TEST OF ACTUATOR
NISSAN	All Mode	2006 - 2012	Engine	Actuation Test	AC COMPRESSOR RELAY
NISSAN	All Mode	2006 - 2012	Engine	Actuation Test	HEATER PLUG3
NISSAN	All Mode	2006 - 2012	Engine	Actuation Test	HEATER PLUG1 AND 2
NISSAN	All Mode	2006 - 2012	Engine	Actuation Test	HEATER PLUG4
NISSAN	All Mode	2006 - 2012	Engine	Actuation Test	Fuel Pump Relay
NISSAN	All Mode	2006 - 2012	Engine	Actuation Test	EXHAUST FUEL INJECTOR
NISSAN	All Mode	2006 - 2012	Engine	Actuation Test	DIAG CAP TEMP DPF
NISSAN	All Mode	2006 - 2012	Engine	Special Function	Service Regeneration
NISSAN	All Mode	2006 - 2012	Engine	Special Function	Vin Registration
NISSAN	All Mode	2006 - 2012	Engine	Special Function	EGR Adaptive
NISSAN	All Mode	2006 - 2012	Engine	Special Function	Programmed Values
NISSAN	All Mode	2006 - 2012	Engine	Special Function	Prgrm Reinitialize
NISSAN	All Mode	2006 - 2012	Engine	Special Function	Pres REG Adaptive
NISSAN	All Mode	2006 - 2012	Engine	Special Function	DPF Data Clear
NISSAN	All Mode	2006 - 2012	Engine	Special Function	Saving Data For Replc CPU
NISSAN	All Mode	2006 - 2012	Engine	Special Function	Writing Data For Replc CPU
NISSAN	All Mode	Up to 2017	Engine	Read Fault Code	
NISSAN	All Mode	Up to 2017	Engine	Clear Fault Code	
NISSAN	All Mode	Up to 2017	Engine	Read Data Stream	
NISSAN	All Mode	Up to 2017	Engine	Module Information	
NISSAN	All Mode	Up to 2017	Engine	Function Test	
NISSAN	All Mode	Up to 2017	Engine	Actuation Test	INJECTOR CYLINDER 1
NISSAN	All Mode	Up to 2017	Engine	Actuation Test	INJECTOR CYLINDER 2
NISSAN	All Mode	Up to 2017	Engine	Actuation Test	INJECTOR CYLINDER 3
NISSAN	All Mode	Up to 2017	Engine	Actuation Test	INJECTOR CYLINDER 4
NISSAN	All Mode	Up to 2017	Engine	Actuation Test	PREHEATER RELAY
NISSAN	All Mode	Up to 2017	Engine	Actuation Test	FUEL PRESSURE SOLENOID/V
NISSAN	All Mode	Up to 2017	Engine	Actuation Test	AIR INLET FLAP
NISSAN	All Mode	Up to 2017	Engine	Actuation Test	FUEL FLOW SOLENOID/V
NISSAN	All Mode	Up to 2017	Engine	Actuation Test	TURBOCHARGER CNTRL SOL/V
NISSAN	All Mode	Up to 2017	Engine	Actuation Test	PRE ELEC CONSUM
NISSAN	All Mode	Up to 2017	Engine	Actuation Test	HIGH PRES CIRCUIT LEAK TEST
NISSAN	All Mode	Up to 2017	Engine	Actuation Test	STATIC TEST OF ACTUATOR
NISSAN	All Mode	Up to 2017	Engine	Actuation Test	AC COMPRESSOR RELAY
NISSAN	All Mode	Up to 2017	Engine	Special Function	Vin Registration
NISSAN	All Mode	Up to 2017	Engine	Special Function	EGR Adaptive
NISSAN	All Mode	Up to 2017	Engine	Special Function	Programmed Values
NISSAN	All Mode	Up to 2017	Engine	Special Function	Prgrm Reinitialize
NISSAN	All Mode	Up to 2017	Engine	Special Function	Pres REG Adaptive
NISSAN	All Mode	Up to 2017	Engine	Special Function	Saving Data For Replc CPU
NISSAN	All Mode	Up to 2017	Engine	Special Function	Writing Data For Replc CPU
NISSAN	All Mode	2006 - 2012	Engine	Read Fault Code	

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
NISSAN	All Mode	2006 - 2012	Engine	Clear Fault Code	
NISSAN	All Mode	2006 - 2012	Engine	Read Data Stream	
NISSAN	All Mode	2006 - 2012	Engine	Module Information	
NISSAN	All Mode	2006 - 2012	Engine	Actuation Test	INJECTOR CYLINDER 1
NISSAN	All Mode	2006 - 2012	Engine	Actuation Test	INJECTOR CYLINDER 2
NISSAN	All Mode	2006 - 2012	Engine	Actuation Test	INJECTOR CYLINDER 3
NISSAN	All Mode	2006 - 2012	Engine	Actuation Test	INJECTOR CYLINDER 4
NISSAN	All Mode	2006 - 2012	Engine	Actuation Test	PREHEATER RELAY
NISSAN	All Mode	2006 - 2012	Engine	Actuation Test	FUEL PRESSURE SOLENOID/V
NISSAN	All Mode	2006 - 2012	Engine	Actuation Test	AIR INLET FLAP
NISSAN	All Mode	2006 - 2012	Engine	Actuation Test	FUEL FLOW SOLENOID/V
NISSAN	All Mode	2006 - 2012	Engine	Actuation Test	TURBOCHARGER CNTRL SOL/V
NISSAN	All Mode	2006 - 2012	Engine	Actuation Test	PRE ELEC CONSUM
NISSAN	All Mode	2006 - 2012	Engine	Actuation Test	HIGH PRES CIRCUIT LEAK TEST
NISSAN	All Mode	2006 - 2012	Engine	Actuation Test	STATIC TEST OF ACTUATOR
NISSAN	All Mode	2006 - 2012	Engine	Actuation Test	AC COMPRESSOR RELAY
NISSAN	All Mode	2006 - 2012	Engine	Actuation Test	HEATER PLUG3
NISSAN	All Mode	2006 - 2012	Engine	Actuation Test	HEATER PLUG1 AND 2
NISSAN	All Mode	2006 - 2012	Engine	Actuation Test	HEATER PLUG4
NISSAN	All Mode	2006 - 2012	Engine	Actuation Test	Fuel Pump Relay
NISSAN	All Mode	2006 - 2012	Engine	Actuation Test	EXHAUST FUEL INJECTOR
NISSAN	All Mode	2006 - 2012	Engine	Actuation Test	DIAG CAP TEMP DPF
NISSAN	All Mode	2006 - 2012	Engine	Special Function	Service Regeneration
NISSAN	All Mode	2006 - 2012	Engine	Special Function	Vin Registration
NISSAN	All Mode	2006 - 2012	Engine	Special Function	EGR Adaptives
NISSAN	All Mode	2006 - 2012	Engine	Special Function	DPF Data Clear
NISSAN	All Mode	2006 - 2012	Engine	Special Function	Programmed Values
NISSAN	All Mode	2006 - 2012	Engine	Special Function	Prgrm Reinitialize
NISSAN	All Mode	2006 - 2012	Engine	Special Function	Pres REG Adaptive
NISSAN	All Mode	2006 - 2012	Engine	Special Function	Saving Data For Replc CPU
NISSAN	All Mode	2006 - 2012	Engine	Special Function	Writing Data For Replc CPU
NISSAN	All Mode	2006 - 2012	Engine	Read Fault Code	
NISSAN	All Mode	2006 - 2012	Engine	Clear Fault Code	
NISSAN	All Mode	2006 - 2012	Engine	Read Data Stream	
NISSAN	All Mode	2006 - 2012	Engine	Actuation Test	TC BST CONT S/V
NISSAN	All Mode	2006 - 2012	Engine	Actuation Test	FRP CONTROL VALVE
NISSAN	All Mode	2006 - 2012	Engine	Actuation Test	GLOW CONTROL UNIT
NISSAN	All Mode	2006 - 2012	Engine	Actuation Test	EGR COOLER BYPASS CONT S/V
NISSAN	All Mode	2006 - 2012	Engine	Actuation Test	TROTTL VALVE
NISSAN	All Mode	2006 - 2012	Engine	Actuation Test	Fuel Pump
NISSAN	All Mode	2006 - 2012	Engine	Actuation Test	TURBOCHARGER COOLING PUMP
NISSAN	All Mode	2006 - 2012	Engine	Special Function	LEARNING
NISSAN	All Mode	2006 - 2012	Engine	Special Function	INJ ADJ VAL REGIST
NISSAN	All Mode	2006 - 2012	Engine	Special Function	ZFC VALUE RESET
NISSAN	All Mode	2006 - 2012	Engine	Special Function	P062F EXCLUSIVE FUNCTION
NISSAN	All Mode	2006 - 2012	Engine	Special Function	EGR/V LEARN CLR
NISSAN	All Mode	2006 - 2012	Engine	Special Function	DPF Data Clear
NISSAN	All Mode	2006 - 2012	Engine	Special Function	OC DATA CLEAR
NISSAN	All Mode	2006 - 2012	Engine	Special Function	Service Regeneration
NISSAN	All Mode	2006 - 2012	Engine	Special Function	Saving Data For Replc CPU
NISSAN	All Mode	2006 - 2012	Engine	Special Function	Writing Data For Replc CPU
NISSAN	All Mode	2006 - 2017	Engine	Read Fault Code	
NISSAN	All Mode	2006 - 2017	Engine	Clear Fault Code	
NISSAN	All Mode	2006 - 2017	Engine	Read Data Stream	
NISSAN	All Mode	2006 - 2017	Engine	Actuation Test	TC BST CONT S/V
NISSAN	All Mode	2006 - 2017	Engine	Actuation Test	FRP CONTROL VALVE
NISSAN	All Mode	2006 - 2017	Engine	Actuation Test	GLOW CONTROL UNIT
NISSAN	All Mode	2006 - 2017	Engine	Actuation Test	EGR COOLER BYPASS CONT S/V
NISSAN	All Mode	2006 - 2017	Engine	Actuation Test	TROTTL VALVE
NISSAN	All Mode	2006 - 2017	Engine	Actuation Test	Fuel Pump
NISSAN	All Mode	2006 - 2017	Engine	Actuation Test	TURBOCHARGER COOLING PUMP
NISSAN	All Mode	2006 - 2017	Engine	Actuation Test	ENGINE MOUNTING
NISSAN	All Mode	2006 - 2017	Engine	Special Function	Service Regeneration
NISSAN	All Mode	2006 - 2017	Engine	Special Function	INT ADJ VAL REGIST
NISSAN	All Mode	2006 - 2017	Engine	Special Function	TP POS LEARN CLR
NISSAN	All Mode	2006 - 2017	Engine	Special Function	EGR/V LEARN CLR
NISSAN	All Mode	2006 - 2017	Engine	Special Function	DPF Data Clear
NISSAN	All Mode	2006 - 2017	Engine	Special Function	EXH Fuel Inj Data Clear
NISSAN	All Mode	2006 - 2017	Engine	Special Function	ZFC VALUE RESET
NISSAN	All Mode	Up to 2011	Engine	Read Fault Code	
NISSAN	All Mode	Up to 2011	Engine	Clear Fault Code	
NISSAN	All Mode	Up to 2011	Engine	Read Data Stream	
NISSAN	All Mode	Up to 2011	Engine	Module Information	
NISSAN	All Mode	Up to 2011	Engine	Actuation Test	EGR SOLENOID VALVE
NISSAN	All Mode	Up to 2011	Engine	Actuation Test	PREHEATER UNIT
NISSAN	All Mode	Up to 2011	Engine	Actuation Test	TURBO SOL VALVE
NISSAN	All Mode	Up to 2011	Engine	Actuation Test	RAIL PRESS REG
NISSAN	All Mode	Up to 2011	Engine	Actuation Test	DAMPER FLAP
NISSAN	All Mode	Up to 2011	Engine	Actuation Test	LOCK INJECTOR CTRL
NISSAN	All Mode	Up to 2011	Engine	Actuation Test	UNLK INJECTOR CTRL

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
NISSAN	All Mode	Up to 2011	Engine	Actuation Test	PRE ELEC CONSUM
NISSAN	All Mode	Up to 2011	Engine	Special Function	Saving Data For Replc CPU
NISSAN	All Mode	Up to 2011	Engine	Special Function	Writing Data For Replc CPU
NISSAN	All Mode	Up to 2011	Engine	Special Function	Programmed Values
NISSAN	All Mode	Up to 2011	Engine	Special Function	Enter Injctr Calib Data
NISSAN	All Mode	Up to 2011	Engine	Special Function	EGR Adaptives
NISSAN	All Mode	Up to 2017	Engine	Read Fault Code	
NISSAN	All Mode	Up to 2017	Engine	Clear Fault Code	
NISSAN	All Mode	Up to 2017	Engine	Read Data Stream	
NISSAN	All Mode	Up to 2017	Engine	Module Information	
NISSAN	All Mode	Up to 2017	Engine	Actuation Test	PREHEATER UNIT
NISSAN	All Mode	Up to 2017	Engine	Actuation Test	EGR SOLENOID VALVE
NISSAN	All Mode	Up to 2017	Engine	Actuation Test	INJECTOR CYLINDER 1
NISSAN	All Mode	Up to 2017	Engine	Actuation Test	INJECTOR CYLINDER 2
NISSAN	All Mode	Up to 2017	Engine	Actuation Test	INJECTOR CYLINDER 3
NISSAN	All Mode	Up to 2017	Engine	Actuation Test	INJECTOR CYLINDER 4
NISSAN	All Mode	Up to 2017	Engine	Actuation Test	HIGH PRESSURE PUMP
NISSAN	All Mode	Up to 2017	Engine	Actuation Test	STATIC TEST
NISSAN	All Mode	Up to 2017	Engine	Actuation Test	HIGH PRESS CIRC LEAK T
NISSAN	All Mode	Up to 2017	Engine	Special Function	Vin Registration
NISSAN	All Mode	Up to 2017	Engine	Special Function	Programmed Values
NISSAN	All Mode	Up to 2017	Engine	Special Function	EGR Adaptives
NISSAN	All Mode	Up to 2017	Engine	Special Function	Reset Pump Forcefeeding
NISSAN	All Mode	Up to 2017	Engine	Special Function	Reset Injctr Adaptive
NISSAN	All Mode	Up to 2017	Engine	Special Function	Saving Data For Replc CPU
NISSAN	All Mode	Up to 2017	Engine	Special Function	Writing Data For Replc CPU
NISSAN	All Mode	Up to 2017	Engine	Special Function	Enter Injctr Calib Data
NISSAN	All Mode	Up to 2017	Engine	Special Function	Speed Limiter
NISSAN	All Mode	Up to 2017	Engine	Read Fault Code	
NISSAN	All Mode	Up to 2017	Engine	Clear Fault Code	
NISSAN	All Mode	Up to 2017	Engine	Read Data Stream	
NISSAN	All Mode	Up to 2017	Engine	Actuation Test	COOLING FAN
NISSAN	All Mode	Up to 2017	Engine	Actuation Test	INJ TIMING
NISSAN	All Mode	Up to 2017	Engine	Actuation Test	ENG COOLANT TEMP
NISSAN	All Mode	Up to 2017	Engine	Actuation Test	Fuel/T Temp SEN
NISSAN	All Mode	Up to 2017	Engine	Actuation Test	ALTERNATOR DUTY
NISSAN	All Mode	Up to 2017	Engine	Actuation Test	Tc boost control actuator
NISSAN	All Mode	Up to 2017	Engine	Actuation Test	EGR COOLER BYPASS VALVE
NISSAN	All Mode	Up to 2017	Engine	Actuation Test	PRES REGULATOR
NISSAN	All Mode	Up to 2017	Engine	Actuation Test	TARGET ETC ANGLE
NISSAN	All Mode	Up to 2017	Engine	Actuation Test	Power Balance
NISSAN	All Mode	Up to 2017	Engine	Actuation Test	TRG EGR/V angel
NISSAN	All Mode	Up to 2017	Engine	Actuation Test	GLOW RLY
NISSAN	All Mode	Up to 2017	Engine	Actuation Test	ENGINE MOUNTING
NISSAN	All Mode	Up to 2017	Engine	Special Function	Enter Injctr Calib Data
NISSAN	All Mode	Up to 2017	Engine	Special Function	Service Regeneration
NISSAN	All Mode	Up to 2017	Engine	Special Function	P/O REGISTRATION
NISSAN	All Mode	Up to 2017	Engine	Special Function	Pump Leant Clear
NISSAN	All Mode	Up to 2017	Engine	Special Function	A/F SEN 1 LEARN CLR
NISSAN	All Mode	Up to 2017	Engine	Special Function	DF EXH PRES SEN LEARN CLR
NISSAN	All Mode	Up to 2017	Engine	Special Function	E/R AIR TEMP SEN LEARN CLR
NISSAN	All Mode	Up to 2017	Engine	Special Function	Fuel INJ quantity learning
NISSAN	All Mode	Up to 2017	Engine	Special Function	DPF Data Clear
NISSAN	All Mode	Up to 2017	Engine	Special Function	Config CLR
NISSAN	All Mode	Up to 2017	Engine	Special Function	INJ ADJ VAL CLR
NISSAN	All Mode	Up to 2017	Engine	Special Function	A/F SEN 2 LEARN CLR
NISSAN	All Mode	Up to 2017	Engine	Special Function	EGR/V LEARN CLEAR
NISSAN	All Mode	Up to 2017	Engine	Special Function	Exh Prsr Sen Learn Clear
NISSAN	All Mode	Up to 2017	Engine	Special Function	OC DATA CLEAR
NISSAN	All Mode	Up to 2017	Engine	Special Function	Saving Data For Replc CPU
NISSAN	All Mode	Up to 2017	Engine	Special Function	Writing Data For Replc CPU
NISSAN	All Mode	Up to 2017	Engine	Special Function	Desulfuration
NISSAN	All Mode	Up to 2017	Engine	Special Function	TC BOOST CONTROL ACTUATOR POSITION LEARNING
NISSAN	All Mode	Up to 2017	Engine	Special Function	Vin Registration
NISSAN	All Mode	Up to 2017	Engine	Special Function	Service Regene
NISSAN	All Mode	2006 - 2016	Engine	Read Fault Code	
NISSAN	All Mode	2006 - 2016	Engine	Clear Fault Code	
NISSAN	All Mode	2006 - 2016	Engine	Read Data Stream	
NISSAN	All Mode	2006 - 2016	Engine	Actuation Test	TURBOCHARGING SOLENOID VALVE
NISSAN	All Mode	2006 - 2016	Engine	Actuation Test	AIR INLET FLAP
NISSAN	All Mode	2006 - 2016	Engine	Actuation Test	EGR BYPASS
NISSAN	All Mode	2006 - 2016	Engine	Actuation Test	THERMOPLNGR RLY N1
NISSAN	All Mode	2006 - 2016	Engine	Actuation Test	THERMOPLNGR RLY N2
NISSAN	All Mode	2006 - 2016	Engine	Actuation Test	THERMOPLNGR 3 RLY
NISSAN	All Mode	2006 - 2016	Engine	Actuation Test	PREHEATER RLY
NISSAN	All Mode	2006 - 2016	Engine	Actuation Test	DPF INJECTOR
NISSAN	All Mode	2006 - 2016	Engine	Actuation Test	DPF INJECTOR SOLENOID VALVE
NISSAN	All Mode	2006 - 2016	Engine	Actuation Test	EGR VALVE

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
NISSAN	All Mode	2006 - 2016	Engine	Actuation Test	INJECTION SOL/V OPENING PF
NISSAN	All Mode	2006 - 2016	Engine	Actuation Test	ENGINE ADAPTIVES
NISSAN	All Mode	2006 - 2016	Engine	Actuation Test	DPF RELATIVE PRESSURE SENSOR
NISSAN	All Mode	2006 - 2016	Engine	Actuation Test	EXHAUST FUEL INJECTOR CIRCUIT
NISSAN	All Mode	2006 - 2016	Engine	Actuation Test	CC/SL PRGRM
NISSAN	All Mode	2006 - 2016	Engine	Actuation Test	E/O CC/SL PRGRM
NISSAN	All Mode	2006 - 2016	Engine	Actuation Test	FUEL SPLY PREV
NISSAN	All Mode	2006 - 2016	Engine	Actuation Test	EGR VALVE PROGRAMMING
NISSAN	All Mode	2006 - 2016	Engine	Actuation Test	AIR DAMPER VALVE PROGRAMMING
NISSAN	All Mode	2006 - 2016	Engine	Actuation Test	PRESSURE REGULATION ADAPTIVES
NISSAN	All Mode	2006 - 2016	Engine	Special Function	Service Regeneration
NISSAN	All Mode	2006 - 2016	Engine	Special Function	Enter Injector Codes
NISSAN	All Mode	2006 - 2016	Engine	Special Function	After Dpf Regeneration
NISSAN	All Mode	2006 - 2016	Engine	Special Function	After Dpf Replacement
NISSAN	All Mode	2006 - 2016	Engine	Special Function	Saving Data For Replc CPU
NISSAN	All Mode	2006 - 2016	Engine	Special Function	Writing Data For Replc CPU
NISSAN	All Mode	Up to 2017	Engine	Read Fault Code	
NISSAN	All Mode	Up to 2017	Engine	Clear Fault Code	
NISSAN	All Mode	Up to 2017	Engine	Read Data Stream	
NISSAN	All Mode	Up to 2017	Engine	Actuation Test	HIGH PRESSURE CIRCUIT LEAK TEST
NISSAN	All Mode	Up to 2017	Engine	Actuation Test	AIR INLET FLAP
NISSAN	All Mode	Up to 2017	Engine	Actuation Test	TURBOCHARGING SOLENOID VALVE
NISSAN	All Mode	Up to 2017	Engine	Actuation Test	EGR VALVE
NISSAN	All Mode	Up to 2017	Engine	Actuation Test	THERMOPLNGR RLY N1
NISSAN	All Mode	Up to 2017	Engine	Actuation Test	THERMOPLNGR RLY N2
NISSAN	All Mode	Up to 2017	Engine	Actuation Test	THERMOPLNGR 3 RLY
NISSAN	All Mode	Up to 2017	Engine	Actuation Test	PREHEATER RLY
NISSAN	All Mode	Up to 2017	Engine	Actuation Test	EGR BYPASS
NISSAN	All Mode	Up to 2017	Engine	Actuation Test	DPF INJECTOR
NISSAN	All Mode	Up to 2017	Engine	Actuation Test	DPF INJECTOR SOLENOID VALVE
NISSAN	All Mode	Up to 2017	Engine	Actuation Test	INJECTOR CYLINDER 1
NISSAN	All Mode	Up to 2017	Engine	Actuation Test	INJECTOR CYLINDER 2
NISSAN	All Mode	Up to 2017	Engine	Actuation Test	INJECTOR CYLINDER 3
NISSAN	All Mode	Up to 2017	Engine	Actuation Test	INJECTOR CYLINDER 4
NISSAN	All Mode	Up to 2017	Engine	Actuation Test	RAIL PRS SEN ADAPTIVES
NISSAN	All Mode	Up to 2017	Engine	Actuation Test	PRESSURE REGULATION ADAPTIVES
NISSAN	All Mode	Up to 2017	Engine	Actuation Test	EGR VALVE PROGRAMMING
NISSAN	All Mode	Up to 2017	Engine	Actuation Test	AIR PATH PROGRAMMING
NISSAN	All Mode	Up to 2017	Engine	Actuation Test	DPF RELATIVE PRESSURE SENSOR
NISSAN	All Mode	Up to 2017	Engine	Actuation Test	FUEL FLOW REGULATOR
NISSAN	All Mode	Up to 2017	Engine	Actuation Test	EXHAUST FUEL INJECTOR CIRCUIT
NISSAN	All Mode	Up to 2017	Engine	Actuation Test	AIR DAMPER VALVE PROGRAMMING
NISSAN	All Mode	Up to 2017	Engine	Actuation Test	ENGINE ADAPTIVES
NISSAN	All Mode	Up to 2017	Engine	Actuation Test	After DPF Regeneration
NISSAN	All Mode	Up to 2017	Engine	Actuation Test	FUEL SPLY PREV
NISSAN	All Mode	Up to 2017	Engine	Actuation Test	STP FUEL SPLY PREV
NISSAN	All Mode	Up to 2017	Engine	Actuation Test	SPEED LIMITER/CRUISE CONTROL ACTIVATION
NISSAN	All Mode	Up to 2017	Engine	Special Function	Vin Registration
NISSAN	All Mode	Up to 2017	Engine	Special Function	Service Regeneration
NISSAN	All Mode	Up to 2017	Engine	Special Function	Commercial VHCL idle SPD MOD
NISSAN	All Mode	Up to 2017	Engine	Special Function	Speed Limiter
NISSAN	All Mode	Up to 2017	Engine	Special Function	Enter Injector Codes
NISSAN	All Mode	Up to 2017	Engine	Special Function	Saving Data For Replc CPU
NISSAN	All Mode	Up to 2017	Engine	Special Function	Writing Data For Replc CPU
NISSAN	All Mode	2007 - 2017	Engine	Read Fault Code	
NISSAN	All Mode	2007 - 2017	Engine	Clear Fault Code	
NISSAN	All Mode	2007 - 2017	Engine	Read Data Stream	
NISSAN	All Mode	2007 - 2017	Engine	Module Information	
NISSAN	All Mode	2007 - 2017	Engine	Actuation Test	INJECTOR CYLINDER 1
NISSAN	All Mode	2007 - 2017	Engine	Actuation Test	INJECTOR CYLINDER 2
NISSAN	All Mode	2007 - 2017	Engine	Actuation Test	INJECTOR CYLINDER 3
NISSAN	All Mode	2007 - 2017	Engine	Actuation Test	INJECTOR CYLINDER 4
NISSAN	All Mode	2007 - 2017	Engine	Actuation Test	Fan Unit Low Speed RLY
NISSAN	All Mode	2007 - 2017	Engine	Actuation Test	Fan Unit High Speed RLY
NISSAN	All Mode	2007 - 2017	Engine	Actuation Test	A/C compressor relay control
NISSAN	All Mode	2007 - 2017	Engine	Actuation Test	Fuel Pump RLY
NISSAN	All Mode	2007 - 2017	Engine	Actuation Test	Canister Bleed SOL/V

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
NISSAN	All Mode	2007 - 2017	Engine	Actuation Test	Motorised Throttle
NISSAN	All Mode	2007 - 2017	Engine	Actuation Test	FLYWHL TGT PG
NISSAN	All Mode	2007 - 2017	Engine	Actuation Test	Richness Regulation Programming
NISSAN	All Mode	2007 - 2017	Engine	Actuation Test	Programming Throttle Limits
NISSAN	All Mode	2007 - 2017	Engine	Actuation Test	ENGINE ADAPTIVES
NISSAN	All Mode	2007 - 2017	Engine	Special Function	Vin Registration
NISSAN	All Mode	2007 - 2017	Engine	Special Function	Start OBD test: Catalytic converter
NISSAN	All Mode	2007 - 2017	Engine	Special Function	Start OBD test: O2 sensor
NISSAN	All Mode	2007 - 2017	Engine	Special Function	Write Saved Data
NISSAN	All Mode	2007 - 2017	Engine	Special Function	Save Computer Data
NISSAN	NV400	2011	Engine	Read Fault Code	
NISSAN	NV400	2011	Engine	Clear Fault Code	
NISSAN	NV400	2011	Engine	Read Data Stream	
NISSAN	NV400	2011	Engine	Module Information	
NISSAN	NV400	2011	Engine	Actuation Test	TURBOCHARGING SOLENOID VALVE
NISSAN	NV400	2011	Engine	Actuation Test	AIR INLET FLAP
NISSAN	NV400	2011	Engine	Actuation Test	THERMOPLNGR 3 RLY
NISSAN	NV400	2011	Engine	Actuation Test	AIR CONDITIONING PREVENTION
NISSAN	NV400	2011	Engine	Actuation Test	LOW PRESS PUMP RLY
NISSAN	NV400	2011	Engine	Actuation Test	THERMOPLNGR RLY N1
NISSAN	NV400	2011	Engine	Actuation Test	THERMOPLNGR RLY N2
NISSAN	NV400	2011	Engine	Actuation Test	PREHEATER RLY
NISSAN	NV400	2011	Engine	Actuation Test	EGR VALVE
NISSAN	NV400	2011	Engine	Actuation Test	EGR BYPASS
NISSAN	NV400	2011	Engine	Actuation Test	PUMP PRESSURE REGULATOR
NISSAN	NV400	2011	Engine	Actuation Test	WATER PUMP RELAY
NISSAN	NV400	2011	Engine	Actuation Test	DPF INJECTOR
NISSAN	NV400	2011	Engine	Actuation Test	DPF INJECTOR SOLENOID VALVE
NISSAN	NV400	2011	Engine	Actuation Test	INJECTION SOL/V OPENING PF
NISSAN	NV400	2011	Engine	Actuation Test	FIRST EGR COOLING PUMP
NISSAN	NV400	2011	Engine	Actuation Test	SECOND EGR COOLING PUMP
NISSAN	NV400	2011	Engine	Actuation Test	ENGINE ADAPTIVES
NISSAN	NV400	2011	Engine	Actuation Test	EGR VALVE PROGRAMMING
NISSAN	NV400	2011	Engine	Actuation Test	AVERAGE AIR TEMPERATURE
NISSAN	NV400	2011	Engine	Actuation Test	DPF RELATIVE PRESSURE SENSOR
NISSAN	NV400	2011	Engine	Actuation Test	FLYWHL TGT PG
NISSAN	NV400	2011	Engine	Actuation Test	EXHAUST FUEL INJECTOR CIRCUIT
NISSAN	NV400	2011	Engine	Actuation Test	AIR DAMPER VALVE PROGRAMMING
NISSAN	NV400	2011	Engine	Actuation Test	RAIL PRS SEN ADAPTIVES
NISSAN	NV400	2011	Engine	Actuation Test	CC/SL PRGRM
NISSAN	NV400	2011	Engine	Actuation Test	E/O CC/SL PRGRM
NISSAN	NV400	2011	Engine	Actuation Test	PREHEATER UNIT
NISSAN	NV400	2011	Engine	Actuation Test	PRPR RICH SEN PROG
NISSAN	NV400	2011	Engine	Actuation Test	FUEL SPLY PREV
NISSAN	NV400	2011	Engine	Special Function	Enter Injector Codes
NISSAN	NV400	2011	Engine	Special Function	Particle Filter Regeneration
NISSAN	NV400	2011	Engine	Special Function	Vin Registration
NISSAN	NV400	2011	Engine	Special Function	Speed Limiter
NISSAN	NV400	2011	Engine	Special Function	After Dpf Replacement
NISSAN	NV400	2011	Engine	Special Function	After Dpf Regeneration
NISSAN	NV400	2011	Engine	Special Function	Write Saved Data
NISSAN	NV400	2011	Engine	Special Function	Save Computer Data
NISSAN	All Mode	2010 - 2012	Engine	Read Fault Code	
NISSAN	All Mode	2010 - 2012	Engine	Clear Fault Code	
NISSAN	All Mode	2010 - 2012	Engine	Read Data Stream	
NISSAN	All Mode	2010 - 2012	Engine	Module Information	
NISSAN	All Mode	2010 - 2012	Engine	Actuation Test	TURBOCHARGING SOLENOID VALVE
NISSAN	All Mode	2010 - 2012	Engine	Actuation Test	AIR INLET FLAP
NISSAN	All Mode	2010 - 2012	Engine	Actuation Test	THERMOPLNGR RLY N1
NISSAN	All Mode	2010 - 2012	Engine	Actuation Test	THERMOPLNGR RLY N2
NISSAN	All Mode	2010 - 2012	Engine	Actuation Test	THERMOPLNGR 3 RLY
NISSAN	All Mode	2010 - 2012	Engine	Actuation Test	PREHEATER RLY
NISSAN	All Mode	2010 - 2012	Engine	Actuation Test	EGR VALVE
NISSAN	All Mode	2010 - 2012	Engine	Actuation Test	PUMP PRESSURE REGULATOR
NISSAN	All Mode	2010 - 2012	Engine	Actuation Test	SWIRL FLAP VOLTAGE
NISSAN	All Mode	2010 - 2012	Engine	Actuation Test	CONTROLLED CL THERMOS
NISSAN	All Mode	2010 - 2012	Engine	Actuation Test	Fuel Pump
NISSAN	All Mode	2010 - 2012	Engine	Actuation Test	EXHAUST E/THROTTLE CONTROL ACTUATOR
NISSAN	All Mode	2010 - 2012	Engine	Actuation Test	LOW PRESSURE EGR VALVE
NISSAN	All Mode	2010 - 2012	Engine	Special Function	Enter Injector Codes

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

<b>make</b>	<b>model</b>	<b>year</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
NISSAN	All Mode	2010 - 2012	Engine	Special Function	Particle Filter Regeneration
NISSAN	All Mode	2010 - 2012	Engine	Special Function	Vin Registration
NISSAN	All Mode	2010 - 2012	Engine	Special Function	Egr Valve Programming
NISSAN	All Mode	2010 - 2012	Engine	Special Function	Air Damper Valve Programming
NISSAN	All Mode	2010 - 2012	Engine	Special Function	CC/SL PRGRM
NISSAN	All Mode	2010 - 2012	Engine	Special Function	E/O CC/SL PRGRM
NISSAN	All Mode	2010 - 2012	Engine	Special Function	Flywhl TGT PG
NISSAN	All Mode	2010 - 2012	Engine	Special Function	Prpr Rich Sen Prog
NISSAN	All Mode	2010 - 2012	Engine	Special Function	Exhaust Throttle Valve Programming
NISSAN	All Mode	2010 - 2012	Engine	Special Function	Swirl Flap Programming
NISSAN	All Mode	2010 - 2012	Engine	Special Function	Turbocharger Programming
NISSAN	All Mode	2010 - 2012	Engine	Special Function	Adaptives On ETC Actuator Malfunction
NISSAN	All Mode	2010 - 2012	Engine	Special Function	Air Flow Meter Programming
NISSAN	All Mode	2010 - 2012	Engine	Special Function	Manifold Pressure Sensor Programming
NISSAN	All Mode	2010 - 2012	Engine	Special Function	Diff Exh PRES. SEN
NISSAN	All Mode	2010 - 2012	Engine	Special Function	Low Pressure EGR Valve Programming
NISSAN	All Mode	2010 - 2012	Engine	Special Function	Engine Adaptives
NISSAN	All Mode	2010 - 2012	Engine	Special Function	Swirl Flap
NISSAN	All Mode	2010 - 2012	Engine	Special Function	RAIL PRESSURE SENSOR ADAPTIVES
NISSAN	All Mode	2010 - 2012	Engine	Special Function	Number Of Starting Cycles
NISSAN	All Mode	2010 - 2012	Engine	Special Function	Injection Pump Adaptatives
NISSAN	All Mode	2010 - 2012	Engine	Special Function	Fuel Sply Prev
NISSAN	All Mode	2010 - 2012	Engine	Special Function	H/P Fuel Pump Initial Starts Counter Reset
NISSAN	All Mode	2010 - 2012	Engine	Special Function	H/P Fuel Pump Total Starts Counter Reset
NISSAN	All Mode	2010 - 2012	Engine	Special Function	Write Saved Data
NISSAN	All Mode	2010 - 2012	Engine	Special Function	Save Computer Data
NISSAN	All Mode	2010 - 2012	Engine	Special Function	After Dpf Replacement
NISSAN	All Mode	2010 - 2012	Engine	Special Function	After Dpf Regeneration
NISSAN	All Mode	2010 - 2012	Engine	Special Function	Engine OIL Oxidation Data Reset
NISSAN	All Mode	2010 - 2012	Engine	Special Function	Engine OIL Dilution Data Reset
NISSAN	All Mode	2006 - 2009	Engine	Read Fault Code	
NISSAN	All Mode	2006 - 2009	Engine	Clear Fault Code	
NISSAN	All Mode	2006 - 2009	Engine	Read Data Stream	
NISSAN	All Mode	2006 - 2009	Engine	Module Information	
NISSAN	All Mode	2006 - 2009	Engine	Actuation Test	TURBOCHARGING SOLENOID VALVE
NISSAN	All Mode	2006 - 2009	Engine	Actuation Test	Thermoplunger Relay No.1
NISSAN	All Mode	2006 - 2009	Engine	Actuation Test	AIR INLET FLAP
NISSAN	All Mode	2006 - 2009	Engine	Actuation Test	Thermoplunger Relay No.2
NISSAN	All Mode	2006 - 2009	Engine	Actuation Test	Rail Pressure Regulator
NISSAN	All Mode	2006 - 2009	Engine	Actuation Test	THERMO NO. 3 RELAY
NISSAN	All Mode	2006 - 2009	Engine	Actuation Test	EGR BYPASS
NISSAN	All Mode	2006 - 2009	Engine	Actuation Test	ADDITIONAL HEATING
NISSAN	All Mode	2006 - 2009	Engine	Actuation Test	PROPORTIONAL RICHNESS SENSOR HEATING
NISSAN	All Mode	2006 - 2009	Engine	Actuation Test	PREHEATER RELAY
NISSAN	All Mode	2006 - 2009	Engine	Actuation Test	Fan Unit Low Speed RLY
NISSAN	All Mode	2006 - 2009	Engine	Actuation Test	Fan Unit High Speed RLY
NISSAN	All Mode	2006 - 2009	Engine	Special Function	Fuel Sply Prev
NISSAN	All Mode	2006 - 2009	Engine	Special Function	STP FUEL SPLY PREV
NISSAN	All Mode	2006 - 2009	Engine	Special Function	Vin Registration
NISSAN	All Mode	2006 - 2009	Engine	Special Function	Pump Pressure Regulator Type
NISSAN	All Mode	2006 - 2009	Engine	Special Function	Programmed Values
NISSAN	All Mode	2006 - 2009	Engine	Special Function	Ecu Memory
NISSAN	All Mode	2006 - 2009	Engine	Special Function	Enter Injector Codes
NISSAN	All Mode	2006 - 2009	Engine	Special Function	High Pressure Fuel Circuit Fault Finding
NISSAN	All Mode	2006 - 2009	Engine	Special Function	AFTER REPLACING THE COMPUTER WITHOUT HAVING SAVED DATA
NISSAN	All Mode	2006 - 2009	Engine	Special Function	Save Computer Data
NISSAN	All Mode	2006 - 2009	Engine	Special Function	Write Saved Data
NISSAN	All Mode	2006 - 2009	Engine	Special Function	Cylinder Function Fault Finding
NISSAN	All Mode	2006 - 2009	Engine	Special Function	Injector
NISSAN	All Mode	2006 - 2009	Engine	Special Function	EGR Valve
NISSAN	All Mode	2006 - 2009	Engine	Special Function	INLET Flap



**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
NISSAN	All Mode	2006 - 2009	Engine	Special Function	After Replacement Of The Particle Filter
NISSAN	All Mode	2006 - 2009	Engine	Special Function	After Particle Filter Regeneration With The Diag Tool.
NISSAN	All Mode	2006 - 2009	Engine	Special Function	Interval Of Oil Change (OCS) Oxidation
NISSAN	All Mode	2006 - 2009	Engine	Special Function	OIL Change Interval (Ocs): Dilution
NISSAN	All Mode	2006 - 2009	Engine	Special Function	Speed Limiter
NISSAN	All Mode	2006 - 2009	Engine	Read Fault Code	
NISSAN	All Mode	2006 - 2009	Engine	Clear Fault Code	
NISSAN	All Mode	2006 - 2009	Engine	Read Data Stream	
NISSAN	All Mode	2006 - 2009	Engine	Module Information	
NISSAN	All Mode	2006 - 2009	Engine	Actuation Test	TURBOCHARGING SOLENOID VALVE
NISSAN	All Mode	2006 - 2009	Engine	Actuation Test	AIR INLET FLAP
NISSAN	All Mode	2006 - 2009	Engine	Actuation Test	Thermoplunger Relay No.1
NISSAN	All Mode	2006 - 2009	Engine	Actuation Test	Thermoplunger Relay No.2
NISSAN	All Mode	2006 - 2009	Engine	Actuation Test	PUMP PRESSURE REGULATOR
NISSAN	All Mode	2006 - 2009	Engine	Actuation Test	THERMO NO. 3 RELAY
NISSAN	All Mode	2006 - 2009	Engine	Actuation Test	PREHEATER RELAY
NISSAN	All Mode	2006 - 2009	Engine	Actuation Test	EGR BYPASS
NISSAN	All Mode	2006 - 2009	Engine	Actuation Test	FAN UNIT LOW SPEED
NISSAN	All Mode	2006 - 2009	Engine	Actuation Test	FAN UNIT HIGH SPEED
NISSAN	All Mode	2006 - 2009	Engine	Special Function	Vin Registration
NISSAN	All Mode	2006 - 2009	Engine	Special Function	Fuel Sply Prev
NISSAN	All Mode	2006 - 2009	Engine	Special Function	Programmed Values
NISSAN	All Mode	2006 - 2009	Engine	Special Function	Ecu Memory
NISSAN	All Mode	2006 - 2009	Engine	Special Function	Enter Injector Codes
NISSAN	All Mode	2006 - 2009	Engine	Special Function	Save Computer Data
NISSAN	All Mode	2006 - 2009	Engine	Special Function	Write Saved Data
NISSAN	All Mode	2006 - 2009	Engine	Special Function	High Pressure Fuel Circuit Fault Finding
NISSAN	All Mode	2006 - 2009	Engine	Special Function	Cylinder Function Fault Finding
NISSAN	All Mode	2006 - 2009	Engine	Special Function	Thermoplunger
NISSAN	All Mode	2006 - 2009	Engine	Special Function	Injector
NISSAN	All Mode	2006 - 2009	Engine	Special Function	EGR Valve
NISSAN	All Mode	2006 - 2009	Engine	Special Function	INLET Flap
NISSAN	All Mode	2006 - 2009	Engine	Special Function	Speed Limiter
NISSAN	All Mode	2006 - 2009	Engine	Special Function	Interval Of Oil Change (OCS) Oxidation
NISSAN	All Mode	2006 - 2009	Engine	Read Fault Code	
NISSAN	All Mode	2006 - 2009	Engine	Clear Fault Code	
NISSAN	All Mode	2006 - 2009	Engine	Read Data Stream	
NISSAN	All Mode	2006 - 2009	Engine	Module Information	
NISSAN	All Mode	2006 - 2009	Engine	Actuation Test	TURBOCHARGING SOLENOID VALVE
NISSAN	All Mode	2006 - 2009	Engine	Actuation Test	A/C COMPRESSOR
NISSAN	All Mode	2006 - 2009	Engine	Actuation Test	AIR INLET FLAP
NISSAN	All Mode	2006 - 2009	Engine	Actuation Test	Thermoplunger Relay No.1
NISSAN	All Mode	2006 - 2009	Engine	Actuation Test	Thermoplunger Relay No.2
NISSAN	All Mode	2006 - 2009	Engine	Actuation Test	Rail Pressure Regulator
NISSAN	All Mode	2006 - 2009	Engine	Actuation Test	THERMO NO. 3 RELAY
NISSAN	All Mode	2006 - 2009	Engine	Actuation Test	PUMP PRESSURE REGULATOR
NISSAN	All Mode	2006 - 2009	Engine	Actuation Test	PREHEATER RELAY
NISSAN	All Mode	2006 - 2009	Engine	Actuation Test	EGR BYPASS
NISSAN	All Mode	2006 - 2009	Engine	Actuation Test	FAN UNIT LOW SPEED
NISSAN	All Mode	2006 - 2009	Engine	Actuation Test	FAN UNIT HIGH SPEED
NISSAN	All Mode	2006 - 2009	Engine	Special Function	Vin Registration
NISSAN	All Mode	2006 - 2009	Engine	Special Function	Fuel Sply Prev
NISSAN	All Mode	2006 - 2009	Engine	Special Function	Programmed Values
NISSAN	All Mode	2006 - 2009	Engine	Special Function	Ecu Memory
NISSAN	All Mode	2006 - 2009	Engine	Special Function	Speed Limiter
NISSAN	All Mode	2006 - 2009	Engine	Special Function	High Pressure Fuel Circuit Fault Finding
NISSAN	All Mode	2006 - 2009	Engine	Special Function	Save Computer Data
NISSAN	All Mode	2006 - 2009	Engine	Special Function	Write Saved Data
NISSAN	All Mode	2006 - 2009	Engine	Special Function	Cylinder Function Fault Finding
NISSAN	All Mode	2006 - 2009	Engine	Special Function	Interval Of Oil Change (OCS) Oxidation
NISSAN	All Mode	2006 - 2009	Engine	Special Function	Thermoplunger
NISSAN	All Mode	2006 - 2009	Engine	Special Function	Injector
NISSAN	All Mode	2006 - 2009	Engine	Special Function	Enter Injector Codes
NISSAN	All Mode	2006 - 2009	Engine	Special Function	EGR Valve
NISSAN	All Mode	2006 - 2009	Engine	Special Function	INLET Flap
NISSAN	All Mode	2006 - 2009	Engine	Special Function	Heater Plugs
NISSAN	All Mode	2006 - 2009	Engine	Read Fault Code	

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
NISSAN	All Mode	2006 - 2009	Engine	Clear Fault Code	
NISSAN	All Mode	2006 - 2009	Engine	Read Data Stream	
NISSAN	All Mode	2006 - 2009	Engine	Module Information	
NISSAN	All Mode	2006 - 2009	Engine	Actuation Test	Fuel Pump Relay
NISSAN	All Mode	2006 - 2009	Engine	Actuation Test	Fan Unit Low Speed RLY
NISSAN	All Mode	2006 - 2009	Engine	Actuation Test	CANISTER BLEED SOLENOID VALVE
NISSAN	All Mode	2006 - 2009	Engine	Actuation Test	Fan Unit High Speed RLY
NISSAN	All Mode	2006 - 2009	Engine	Actuation Test	UPSTREAM O2 SENSOR HEATING
NISSAN	All Mode	2006 - 2009	Engine	Actuation Test	Air Conditioning Compressor Relay Control
NISSAN	All Mode	2006 - 2009	Engine	Actuation Test	DOWNSTREAM OXYGEN SENSOR HEATING
NISSAN	All Mode	2006 - 2009	Engine	Actuation Test	Motorised Throttle
NISSAN	All Mode	2006 - 2009	Engine	Special Function	Vin Registration
NISSAN	All Mode	2006 - 2009	Engine	Special Function	Unlock Injector Control
NISSAN	All Mode	2006 - 2009	Engine	Special Function	Lock Injector Control
NISSAN	All Mode	2006 - 2009	Engine	Special Function	Programmed Values
NISSAN	All Mode	2006 - 2009	Engine	Read Fault Code	
NISSAN	All Mode	2006 - 2009	Engine	Clear Fault Code	
NISSAN	All Mode	2006 - 2009	Engine	Read Data Stream	
NISSAN	All Mode	2006 - 2009	Engine	Module Information	
NISSAN	All Mode	2006 - 2009	Engine	Actuation Test	TURBOCHARGING SOLENOID VALVE
NISSAN	All Mode	2006 - 2009	Engine	Actuation Test	Thermoplunger Relay No.1
NISSAN	All Mode	2006 - 2009	Engine	Actuation Test	AIR INLET FLAP
NISSAN	All Mode	2006 - 2009	Engine	Actuation Test	Thermoplunger Relay No.2
NISSAN	All Mode	2006 - 2009	Engine	Actuation Test	Rail Pressure Regulator
NISSAN	All Mode	2006 - 2009	Engine	Actuation Test	THERMO NO. 3 RELAY
NISSAN	All Mode	2006 - 2009	Engine	Actuation Test	EGR BYPASS
NISSAN	All Mode	2006 - 2009	Engine	Actuation Test	ADDITIONAL HEATING
NISSAN	All Mode	2006 - 2009	Engine	Actuation Test	PROPORTIONAL RICHNESS SENSOR HEATING
NISSAN	All Mode	2006 - 2009	Engine	Actuation Test	PREHEATER RELAY
NISSAN	All Mode	2006 - 2009	Engine	Actuation Test	Fan Unit Low Speed RLY
NISSAN	All Mode	2006 - 2009	Engine	Actuation Test	Fan Unit High Speed RLY
NISSAN	All Mode	2006 - 2009	Engine	Special Function	Fuel Sply Prev
NISSAN	All Mode	2006 - 2009	Engine	Special Function	STP FUEL SPLY PREV
NISSAN	All Mode	2006 - 2009	Engine	Special Function	Vin Registration
NISSAN	All Mode	2006 - 2009	Engine	Special Function	Programmed Values
NISSAN	All Mode	2006 - 2009	Engine	Special Function	Ecu Memory
NISSAN	All Mode	2006 - 2009	Engine	Special Function	Save Computer Data
NISSAN	All Mode	2006 - 2009	Engine	Special Function	Write Saved Data
NISSAN	All Mode	2006 - 2009	Engine	Special Function	AFTER REPLACING THE COMPUTER WITHOUT HAVING SAVED DATA
NISSAN	All Mode	2006 - 2009	Engine	Special Function	Enter Injector Codes
NISSAN	All Mode	2006 - 2009	Engine	Special Function	EGR Valve
NISSAN	All Mode	2006 - 2009	Engine	Special Function	INLET Flap
NISSAN	All Mode	2006 - 2009	Engine	Special Function	After Replacement Of The Particle Filter
NISSAN	All Mode	2006 - 2009	Engine	Special Function	After Particle Filter Regeneration With The Diag Tool.
NISSAN	All Mode	2006 - 2009	Engine	Special Function	Speed Limiter
NISSAN	All Mode	2006 - 2009	Engine	Read Fault Code	
NISSAN	All Mode	2006 - 2009	Engine	Clear Fault Code	
NISSAN	All Mode	2006 - 2009	Engine	Read Data Stream	
NISSAN	All Mode	2006 - 2009	Engine	Module Information	
NISSAN	All Mode	2006 - 2009	Engine	Actuation Test	TURBOCHARGING SOLENOID VALVE
NISSAN	All Mode	2006 - 2009	Engine	Actuation Test	Thermoplunger Relay No.1
NISSAN	All Mode	2006 - 2009	Engine	Actuation Test	AIR INLET FLAP
NISSAN	All Mode	2006 - 2009	Engine	Actuation Test	Thermoplunger Relay No.2
NISSAN	All Mode	2006 - 2009	Engine	Actuation Test	Rail Pressure Regulator
NISSAN	All Mode	2006 - 2009	Engine	Actuation Test	THERMO NO. 3 RELAY
NISSAN	All Mode	2006 - 2009	Engine	Actuation Test	EGR BYPASS
NISSAN	All Mode	2006 - 2009	Engine	Actuation Test	ADDITIONAL HEATING
NISSAN	All Mode	2006 - 2009	Engine	Actuation Test	PROPORTIONAL RICHNESS SENSOR HEATING
NISSAN	All Mode	2006 - 2009	Engine	Actuation Test	PREHEATER RELAY
NISSAN	All Mode	2006 - 2009	Engine	Actuation Test	Fan Unit Low Speed RLY
NISSAN	All Mode	2006 - 2009	Engine	Actuation Test	Fan Unit High Speed RLY
NISSAN	All Mode	2006 - 2009	Engine	Special Function	Fuel Sply Prev
NISSAN	All Mode	2006 - 2009	Engine	Special Function	STP FUEL SPLY PREV
NISSAN	All Mode	2006 - 2009	Engine	Special Function	Vin Registration
NISSAN	All Mode	2006 - 2009	Engine	Special Function	Programmed Values
NISSAN	All Mode	2006 - 2009	Engine	Special Function	Ecu Memory
NISSAN	All Mode	2006 - 2009	Engine	Special Function	High Pressure Fuel Circuit Fault Finding

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

<b>make</b>	<b>model</b>	<b>year</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
NISSAN	All Mode	2006 - 2009	Engine	Special Function	Save Computer Data
NISSAN	All Mode	2006 - 2009	Engine	Special Function	Write Saved Data
NISSAN	All Mode	2006 - 2009	Engine	Special Function	Cylinder Function Fault Finding
NISSAN	All Mode	2006 - 2009	Engine	Special Function	AFTER REPLACING THE COMPUTER WITHOUT HAVING SAVED DATA
NISSAN	All Mode	2006 - 2009	Engine	Special Function	Enter Injector Codes
NISSAN	All Mode	2006 - 2009	Engine	Special Function	EGR Valve
NISSAN	All Mode	2006 - 2009	Engine	Special Function	INLET Flap
NISSAN	All Mode	2006 - 2009	Engine	Special Function	After Replacement Of The Particle Filter
NISSAN	All Mode	2006 - 2009	Engine	Special Function	After Particle Filter Regeneration With The Diag Tool.
NISSAN	All Mode	2006 - 2009	Engine	Special Function	Speed Limiter
NISSAN	All Mode	2006 - 2009	Engine	Special Function	Interval Of Oil Change (OCS) Oxidation
NISSAN	All Mode	2006 - 2009	Engine	Special Function	OIL Change Interval (Ocs): Dilution
NISSAN	All Mode	2006 - 2009	Engine	Read Fault Code	
NISSAN	All Mode	2006 - 2009	Engine	Clear Fault Code	
NISSAN	All Mode	2006 - 2009	Engine	Read Data Stream	
NISSAN	All Mode	2006 - 2009	Engine	Module Information	
NISSAN	All Mode	2006 - 2009	Engine	Actuation Test	PREHEATER RELAY
NISSAN	All Mode	2006 - 2009	Engine	Actuation Test	PUMP PRESSURE REGULATOR
NISSAN	All Mode	2006 - 2009	Engine	Actuation Test	Thermoplunger Relay No.1
NISSAN	All Mode	2006 - 2009	Engine	Actuation Test	Thermoplunger Relay No.2
NISSAN	All Mode	2006 - 2009	Engine	Actuation Test	THERMO NO. 3 RELAY
NISSAN	All Mode	2006 - 2009	Engine	Actuation Test	COOLANT CIRC SWITCHING S/V
NISSAN	All Mode	2006 - 2009	Engine	Actuation Test	FIRST EGR COOLING PUMP
NISSAN	All Mode	2006 - 2009	Engine	Actuation Test	SECOND EGR COOLING PUMP
NISSAN	All Mode	2006 - 2009	Engine	Actuation Test	TURBOCHARGING SOLENOID VALVE
NISSAN	All Mode	2006 - 2009	Engine	Actuation Test	AIR INLET FLAP
NISSAN	All Mode	2006 - 2009	Engine	Actuation Test	DPF INJECTOR
NISSAN	All Mode	2006 - 2009	Engine	Actuation Test	DPF INJECTOR SOLENOID VALVE
NISSAN	All Mode	2006 - 2009	Engine	Actuation Test	INJECTION SOL/V OPENING PF
NISSAN	All Mode	2006 - 2009	Engine	Actuation Test	EGR BYPASS
NISSAN	All Mode	2006 - 2009	Engine	Actuation Test	EGR VALVE
NISSAN	All Mode	2006 - 2009	Engine	Actuation Test	Fan Unit Low Speed RLY
NISSAN	All Mode	2006 - 2009	Engine	Actuation Test	Fan Unit High Speed RLY
NISSAN	All Mode	2006 - 2009	Engine	Actuation Test	WATER PUMP RELAY
NISSAN	All Mode	2006 - 2009	Engine	Special Function	Vin Registration
NISSAN	All Mode	2006 - 2009	Engine	Special Function	Fuel Sply Prev
NISSAN	All Mode	2006 - 2009	Engine	Special Function	Engine Adapives
NISSAN	All Mode	2006 - 2009	Engine	Special Function	Cylinder Function Fault Finding
NISSAN	All Mode	2006 - 2009	Engine	Special Function	High Pressure Fuel Circuit Fault Finding
NISSAN	All Mode	2006 - 2009	Engine	Special Function	Egr Valve Programming
NISSAN	All Mode	2006 - 2009	Engine	Special Function	Average Air Temperature
NISSAN	All Mode	2006 - 2009	Engine	Special Function	Air Damper Valve Programming
NISSAN	All Mode	2006 - 2009	Engine	Special Function	CC/SL PRGRM
NISSAN	All Mode	2006 - 2009	Engine	Special Function	Flywhl TGT PG
NISSAN	All Mode	2006 - 2009	Engine	Special Function	Rail Pressure Sensor Adapives
NISSAN	All Mode	2006 - 2009	Engine	Special Function	Preheater Unit
NISSAN	All Mode	2006 - 2009	Engine	Special Function	Prpr Rich Sen Prog
NISSAN	All Mode	2006 - 2009	Engine	Special Function	Exhaust Air Flap Programming
NISSAN	All Mode	2006 - 2009	Engine	Special Function	Adapives After Regenerating PF
NISSAN	All Mode	2006 - 2009	Engine	Special Function	Save Computer Data
NISSAN	All Mode	2006 - 2009	Engine	Special Function	Write Saved Data
NISSAN	All Mode	2006 - 2009	Engine	Special Function	Enter Injector Codes
NISSAN	All Mode	2006 - 2009	Engine	Special Function	Speed Limiter
NISSAN	All Mode	2006 - 2009	Engine	Special Function	DPF Relative Pressure Sensor
NISSAN	All Mode	2006 - 2009	Engine	Special Function	Exhaust Fuel Injector Circuit
NISSAN	All Mode	2006 - 2009	Engine	Special Function	IDL SPD REFFR
NISSAN	All Mode	2006 - 2009	Engine	Special Function	Cabin Filter Regeneration
NISSAN	All Mode	2006 - 2009	Engine	Special Function	Interval Of Oil Change (OCS) Oxidation
NISSAN	All Mode	2006 - 2009	Engine	Special Function	OIL Change Interval (Ocs): Dilution
NISSAN	All Mode	2006 - 2009	Engine	Read Fault Code	
NISSAN	All Mode	2006 - 2009	Engine	Clear Fault Code	

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
NISSAN	All Mode	2006 - 2009	Engine	Read Data Stream	
NISSAN	All Mode	2006 - 2009	Engine	Module Information	
NISSAN	All Mode	2006 - 2009	Engine	Actuation Test	TURBOCHARGING SOLENOID VALVE
NISSAN	All Mode	2006 - 2009	Engine	Actuation Test	A/C COMPRESSOR
NISSAN	All Mode	2006 - 2009	Engine	Actuation Test	AIR INLET FLAP
NISSAN	All Mode	2006 - 2009	Engine	Actuation Test	ADDITIONAL HEATING
NISSAN	All Mode	2006 - 2009	Engine	Actuation Test	Rail Pressure Regulator
NISSAN	All Mode	2006 - 2009	Engine	Actuation Test	EGR BYPASS
NISSAN	All Mode	2006 - 2009	Engine	Actuation Test	PROPORTIONAL RICHNESS SENSOR HEATING
NISSAN	All Mode	2006 - 2009	Engine	Actuation Test	PREHEATER RELAY
NISSAN	All Mode	2006 - 2009	Engine	Actuation Test	Fan Unit Low Speed RLY
NISSAN	All Mode	2006 - 2009	Engine	Actuation Test	Fan Unit High Speed RLY
NISSAN	All Mode	2006 - 2009	Engine	Special Function	Vin Registration
NISSAN	All Mode	2006 - 2009	Engine	Special Function	Pump Pressure Regulator Type
NISSAN	All Mode	2006 - 2009	Engine	Special Function	STP FUEL SPLY PREV
NISSAN	All Mode	2006 - 2009	Engine	Special Function	Fuel Sply Prev
NISSAN	All Mode	2006 - 2009	Engine	Special Function	Programmed Values
NISSAN	All Mode	2006 - 2009	Engine	Special Function	Ecu Memory
NISSAN	All Mode	2006 - 2009	Engine	Special Function	High Pressure Fuel Circuit Fault Finding
NISSAN	All Mode	2006 - 2009	Engine	Special Function	Cylinder Function Fault Finding
NISSAN	All Mode	2006 - 2009	Engine	Special Function	Write Saved Data
NISSAN	All Mode	2006 - 2009	Engine	Special Function	Save Computer Data
NISSAN	All Mode	2006 - 2009	Engine	Special Function	Enter Injector Codes
NISSAN	All Mode	2006 - 2009	Engine	Special Function	EGR Valve
NISSAN	All Mode	2006 - 2009	Engine	Special Function	INLET Flap
NISSAN	All Mode	2006 - 2009	Engine	Special Function	Speed Limiter
NISSAN	All Mode	2006 - 2009	Engine	Special Function	Interval Of Oil Change (OCS) Oxidation
NISSAN	NV400	2011	Engine	Read Fault Code	
NISSAN	NV400	2011	Engine	Clear Fault Code	
NISSAN	NV400	2011	Engine	Read Data Stream	
NISSAN	NV400	2011	Engine	Actuation Test	TURBOCHARGING SOLENOID VALVE
NISSAN	NV400	2011	Engine	Actuation Test	AIR INLET FLAP
NISSAN	NV400	2011	Engine	Actuation Test	THERMO NO. 3 RELAY
NISSAN	NV400	2011	Engine	Actuation Test	EGR VALVE
NISSAN	NV400	2011	Engine	Actuation Test	PREHEATER RELAY
NISSAN	NV400	2011	Engine	Actuation Test	THERMOPLUNGER RELAY No.1
NISSAN	NV400	2011	Engine	Actuation Test	THERMOPLUNGER RELAY No.2
NISSAN	NV400	2011	Engine	Actuation Test	EGR BYPASS
NISSAN	NV400	2011	Engine	Actuation Test	PUMP PRESSURE REGULATOR
NISSAN	NV400	2011	Engine	Actuation Test	WATER PUMP RELAY
NISSAN	NV400	2011	Engine	Actuation Test	DPF INJECTOR
NISSAN	NV400	2011	Engine	Actuation Test	DPF INJECTOR SOLENOID VALVE
NISSAN	NV400	2011	Engine	Actuation Test	FIRST EGR COOLING PUMP
NISSAN	NV400	2011	Engine	Actuation Test	SECOND EGR COOLING PUMP
NISSAN	NV400	2011	Engine	Actuation Test	COOLANT CIRC SWITCHING S/V
NISSAN	NV400	2011	Engine	Actuation Test	Fuel Pump
NISSAN	NV400	2011	Engine	Special Function	Vin Registration
NISSAN	NV400	2011	Engine	Special Function	Fuel Sply Prev
NISSAN	NV400	2011	Engine	Special Function	Cylinder 1 Injector Code
NISSAN	NV400	2011	Engine	Special Function	Cylinder 2 Injector Code
NISSAN	NV400	2011	Engine	Special Function	Cylinder 3 Injector Code
NISSAN	NV400	2011	Engine	Special Function	Cylinder 4 Injector Code
NISSAN	NV400	2011	Engine	Special Function	Number Of Starting 1
NISSAN	NV400	2011	Engine	Special Function	Number Of Starting 2
NISSAN	NV400	2011	Engine	Special Function	Number Of Starting 3
NISSAN	NV400	2011	Engine	Special Function	Number Of Starting 4
NISSAN	NV400	2011	Engine	Special Function	Adaptives After Regenerating PF
NISSAN	NV400	2011	Engine	Special Function	Enter Injector Codes
NISSAN	NV400	2011	Engine	Special Function	Egr Valve Programming
NISSAN	NV400	2011	Engine	Special Function	Adaptives On Air Intake Flap Malfunction
NISSAN	NV400	2011	Engine	Special Function	Average Air Temperature
NISSAN	NV400	2011	Engine	Special Function	DPF Relative Pressure Sensor
NISSAN	NV400	2011	Engine	Special Function	Flywhl TGT PG
NISSAN	NV400	2011	Engine	Special Function	Exhaust Fuel Injector Circuit
NISSAN	NV400	2011	Engine	Special Function	Air Damper Valve Programming(R044)
NISSAN	NV400	2011	Engine	Special Function	Rail Pressure Sensor Adaptives
NISSAN	NV400	2011	Engine	Special Function	CC/SL PRGRM

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

<b>make</b>	<b>model</b>	<b>year</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
NISSAN	NV400	2011	Engine	Special Function	Prpr Rich Sen Prog
NISSAN	NV400	2011	Engine	Special Function	Fuel Pump Programming
NISSAN	NV400	2011	Engine	Special Function	Turbocharger Programming
NISSAN	NV400	2011	Engine	Special Function	Manifold Pressure Sensor Programming
NISSAN	NV400	2011	Engine	Special Function	Air Flow Meter Programming
NISSAN	NV400	2011	Engine	Special Function	Injection Pump Adaptatives
NISSAN	NV400	2011	Engine	Special Function	EGR Bypass Programming
NISSAN	NV400	2011	Engine	Special Function	Air Damper Valve Programming(R088)
NISSAN	NV400	2011	Engine	Special Function	Pressure Regulation Adaptives
NISSAN	NV400	2011	Engine	Special Function	EGR Programming
NISSAN	NV400	2011	Engine	Special Function	Air Path Programming
NISSAN	NV400	2011	Engine	Special Function	Number Of Starting Cycles
NISSAN	NV400	2011	Engine	Special Function	Engine Adaptives
NISSAN	NV400	2011	Engine	Special Function	Interval Of Oil Change (OCS) Oxidation
NISSAN	NV400	2011	Engine	Special Function	Oil Change Interval(Ocs):Dilution
NISSAN	NV400	2011	Engine	Special Function	Save Computer Data
NISSAN	NV400	2011	Engine	Special Function	Write Saved Data
NISSAN	NV400	2011	Engine	Special Function	Cylinder Function Fault Finding
NISSAN	NV400	2011	Engine	Special Function	High Pressure Fuel Circuit Fault Finding
NISSAN	NV400	2011	Engine	Special Function	Speed Limiter
NISSAN	NV400	2011	Engine	Special Function	Fast Idle Speed Modification
NISSAN	NV400	2011	Engine	Special Function	Cabin Filter Regeneration
NISSAN	All Mode	2013 - 2018	Engine	Read Fault Code	
NISSAN	All Mode	2013 - 2018	Engine	Clear Fault Code	
NISSAN	All Mode	2013 - 2018	Engine	Read Data Stream	
NISSAN	All Mode	2013 - 2018	Engine	Module Information	
NISSAN	All Mode	2013 - 2018	Engine	Actuation Test	Check Coolant Pump For Proper Operation
NISSAN	All Mode	2013 - 2018	Engine	Actuation Test	Check Engine Diagnosis Indicator Lamp
NISSAN	All Mode	2013 - 2018	Engine	Actuation Test	Check Engine Oil Pump Valve
NISSAN	All Mode	2013 - 2018	Engine	Actuation Test	Check EGR Actuator
NISSAN	All Mode	2013 - 2018	Engine	Actuation Test	Check EGR Cooler Bypss Sw Over Valve
NISSAN	All Mode	2013 - 2018	Engine	Actuation Test	Check Glow Plugs
NISSAN	All Mode	2013 - 2018	Engine	Actuation Test	Check Oil Spray Nozzles Shutoff Valve
NISSAN	All Mode	2013 - 2018	Engine	Actuation Test	Check O2 Upstream Of Catalytic Converter
NISSAN	All Mode	2013 - 2018	Engine	Actuation Test	Check Rail Pressure Sensor
NISSAN	All Mode	2013 - 2018	Engine	Actuation Test	CK Temp Sen Upstream Of Dsl Prtcl Sen
NISSAN	All Mode	2013 - 2018	Engine	Actuation Test	Check Temp Sen Upstream Turbocharger
NISSAN	All Mode	2013 - 2018	Engine	Actuation Test	Check Tm Oil Clng Clnt Circulation Pump
NISSAN	All Mode	2013 - 2018	Engine	Actuation Test	Rail Pressure Sensor Offset Test
NISSAN	All Mode	2013 - 2018	Engine	Actuation Test	Check Boost Pressure Positioner
NISSAN	All Mode	2013 - 2018	Engine	Actuation Test	Check Fuel System High Pressure Pump
NISSAN	All Mode	2013 - 2018	Engine	Actuation Test	Check Cylinder 1 Glow Plug
NISSAN	All Mode	2013 - 2018	Engine	Actuation Test	Check Fuel HI Press Circ For Leaktightness
NISSAN	All Mode	2013 - 2018	Engine	Actuation Test	Exhaust Gas Regulation Dynamic Test
NISSAN	All Mode	2013 - 2018	Engine	Actuation Test	Check Pres Regulating Valve For Leaks
NISSAN	All Mode	2013 - 2018	Engine	Actuation Test	Check Preglow System
NISSAN	All Mode	2013 - 2018	Engine	Actuation Test	Automatic Leak Test Of Charge Air System
NISSAN	All Mode	2013 - 2018	Engine	Actuation Test	Compression Test
NISSAN	All Mode	2013 - 2018	Engine	Actuation Test	Ck Cont Response Of Press Reg Vlv At Idle
NISSAN	All Mode	2013 - 2018	Engine	Actuation Test	CK Cont Response Of Press Regulating VLV
NISSAN	All Mode	2013 - 2018	Engine	Actuation Test	Check Control Response Of Quantity Control Valve At Idle
NISSAN	All Mode	2013 - 2018	Engine	Actuation Test	Collation Of Diagnosis Performance Data

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

<b>make</b>	<b>model</b>	<b>year</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
NISSAN	All Mode	2013 - 2018	Engine	Actuation Test	Check Fuel Filter Heater
NISSAN	All Mode	2013 - 2018	Engine	Actuation Test	Auto Stop Start
NISSAN	All Mode	2013 - 2018	Engine	Actuation Test	Check Intake Port Shutoff Actuator Motor
NISSAN	All Mode	2013 - 2018	Engine	Actuation Test	Ck Eng And Ac With Intgrted Cont Fan Motor
NISSAN	All Mode	2013 - 2018	Engine	Actuation Test	Alternator Diagnosis
NISSAN	All Mode	2013 - 2018	Engine	Special Function	Bleeding Of High Pressure Fuel Circuit
NISSAN	All Mode	2013 - 2018	Engine	Special Function	Diesel Particle Filter Regeneration
NISSAN	All Mode	2013 - 2018	Engine	Special Function	OPR Time Basic Diag Of TM Neutral Pos Sen
NISSAN	All Mode	2013 - 2018	Engine	Special Function	Teach In Boost Pressure Positioner
NISSAN	All Mode	2013 - 2018	Engine	Special Function	QK TCH IN OF ZERO QUNTY CALIB VAL AT IDL
NISSAN	All Mode	2013 - 2018	Engine	Special Function	Reset Of Contamination Level Of Air Filter
NISSAN	All Mode	2013 - 2018	Engine	Special Function	Reset Of Lambda Values
NISSAN	All Mode	2013 - 2018	Engine	Special Function	Replace Diesel Particulate Filter
NISSAN	All Mode	2013 - 2018	Engine	Special Function	Activation Of Fuel Pump
NISSAN	All Mode	2013 - 2018	Engine	Special Function	Reset Of Learned Values Of Cmsft Hall Sen
NISSAN	All Mode	2013 - 2018	Engine	Special Function	Teach In Of Intake Port Shutoff
NISSAN	All Mode	2013 - 2018	Engine	Special Function	QK TCH In Zero Qunty Calib Val While Driving
NISSAN	All Mode	2013 - 2018	Engine	Special Function	Teach In Of Throttle Valve Stop
NISSAN	All Mode	2013 - 2018	Engine	Special Function	Vin Registration
NISSAN	All Mode	2013 - 2018	Engine	Special Function	Injector Injection Quantity Adjustment
NISSAN	All Mode	2013 - 2018	Engine	Special Function	Control Deviation Charge Air System
NISSAN	All Mode	2013 - 2018	Engine	Special Function	STRT OPRIN CNTR CLEAR
NISSAN	All Mode	2013 - 2018	Engine	Special Function	H/P Fuel Pump Total Starts Counter Clear
NISSAN	All Mode	2013 - 2018	Engine	Special Function	Saving Data For Replc CPU
NISSAN	All Mode	2013 - 2018	Engine	Special Function	Writing Data For Replc CPU
NISSAN	All Mode	Up to 2018	Engine	Read Fault Code	
NISSAN	All Mode	Up to 2018	Engine	Clear Fault Code	
NISSAN	All Mode	Up to 2018	Engine	Read Data Stream	
NISSAN	All Mode	Up to 2018	Engine	Module Information	
NISSAN	All Mode	Up to 2018	Engine	Actuation Test	ENG COOLANT TEMP
NISSAN	All Mode	Up to 2018	Engine	Actuation Test	FUEL INJECTION
NISSAN	All Mode	Up to 2018	Engine	Actuation Test	PURG VOL CONT/V
NISSAN	All Mode	Up to 2018	Engine	Actuation Test	Fuel/T Temp SEN
NISSAN	All Mode	Up to 2018	Engine	Actuation Test	EGR VOL CONT/V
NISSAN	All Mode	Up to 2018	Engine	Actuation Test	Power Balance
NISSAN	All Mode	Up to 2018	Engine	Actuation Test	INT V/T ASSIGN ANGLE
NISSAN	All Mode	Up to 2018	Engine	Actuation Test	EXH V/T ASSIGN ANGLE
NISSAN	All Mode	Up to 2018	Engine	Actuation Test	Fuel Pump Relay
NISSAN	All Mode	Up to 2018	Engine	Actuation Test	VIAS S/V-1
NISSAN	All Mode	Up to 2018	Engine	Actuation Test	VENT CONTROL/V
NISSAN	All Mode	Up to 2018	Engine	Actuation Test	Supercharger Clutch Relay
NISSAN	All Mode	Up to 2018	Engine	Actuation Test	FAN DUTY CONTROL
NISSAN	All Mode	Up to 2018	Engine	Actuation Test	ALTERNATOR DUTY
NISSAN	All Mode	Up to 2018	Engine	Actuation Test	TUMBLE CONTROL VALVE
NISSAN	All Mode	Up to 2018	Engine	Actuation Test	VIAS S/V-2
NISSAN	All Mode	Up to 2018	Engine	Actuation Test	ALTERNATOR VOLTAGE
NISSAN	All Mode	Up to 2018	Engine	Actuation Test	Active Grille Shutter
NISSAN	All Mode	Up to 2018	Engine	Actuation Test	Auto Stop Start
NISSAN	All Mode	Up to 2018	Engine	Actuation Test	COOLING FAN
NISSAN	All Mode	Up to 2018	Engine	Actuation Test	FPCM
NISSAN	All Mode	Up to 2018	Engine	Actuation Test	IGNITION TIMING
NISSAN	All Mode	Up to 2018	Engine	Actuation Test	EGR CONTROL VALVE
NISSAN	All Mode	Up to 2018	Engine	Actuation Test	WASTEGATE ACTUATOR
NISSAN	All Mode	Up to 2018	Engine	Actuation Test	TC BYPASS VALVE
NISSAN	All Mode	Up to 2018	Engine	Actuation Test	ENGINE COOLANT ELECTIC WATER PUMP
NISSAN	All Mode	Up to 2018	Engine	Special Function	Cumulative Sub-Battry Dischg Current Clear
NISSAN	All Mode	Up to 2018	Engine	Special Function	Vin Registration
NISSAN	All Mode	Up to 2018	Engine	Special Function	EVAP System Close
NISSAN	All Mode	Up to 2018	Engine	Special Function	Idle Air Vol Learn
NISSAN	All Mode	Up to 2018	Engine	Special Function	Self-Learning Cont
NISSAN	All Mode	Up to 2018	Engine	Special Function	A/F Initial Learning

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
NISSAN	All Mode	Up to 2018	Engine	Special Function	SUB-STARTER & GENERATOR OPER COUNT CLEAR
NISSAN	All Mode	Up to 2018	Engine	Special Function	CML B/DCHRG CRNT CLEAR
NISSAN	All Mode	Up to 2018	Engine	Special Function	SC MAGNETIC CLUTCH ENGAGE COUNT CLEAR
NISSAN	All Mode	Up to 2018	Engine	Special Function	Fuel Pressure Release
NISSAN	All Mode	Up to 2018	Engine	Special Function	CLSD THL POS LEARN
NISSAN	All Mode	Up to 2018	Engine	Special Function	Active Control Engine Mounting A
NISSAN	All Mode	Up to 2018	Engine	Special Function	Active Control Engine Mounting B
NISSAN	All Mode	Up to 2018	Engine	Special Function	G Sensor Calibration
NISSAN	All Mode	Up to 2018	Engine	Special Function	TARGET IGN TIM ADJ
NISSAN	All Mode	Up to 2018	Engine	Special Function	TARGET IDLE RPM ADJ
NISSAN	All Mode	Up to 2018	Engine	Special Function	Valve Timing Offset Data Writing
NISSAN	All Mode	Up to 2018	Engine	Special Function	Valve Timing Offset Data Clear
NISSAN	All Mode	Up to 2018	Engine	Special Function	STRT OPRTN CNTR CLEAR
NISSAN	All Mode	Up to 2018	Engine	Special Function	VALVE TIMING ADJUSTMENT
NISSAN	All Mode	Up to 2018	Engine	Special Function	WASTEGATE ACTUATOR POSI LEARN VALUE CLEAR
NISSAN	All Mode	Up to 2018	Engine	Special Function	Engine Coolant Bypass Valve
NISSAN	All Mode	Up to 2018	Engine	Special Function	Saving Data For Replc CPU
NISSAN	All Mode	Up to 2018	Engine	Special Function	Writing Data For Replc CPU
NISSAN	All Mode	Up to 2018	Engine	Special Function	Write Starter Operation Count
NISSAN	All Mode	Up to 2018	Engine	Special Function	EGR control valve closed position learning
NISSAN	All Mode	Up to 2018	Engine	Special Function	Electric intake valve timing control learning
NISSAN	All Mode	2013 - 2018	Engine	Read Fault Code	
NISSAN	All Mode	2013 - 2018	Engine	Clear Fault Code	
NISSAN	All Mode	2013 - 2018	Engine	Read Data Stream	
NISSAN	All Mode	2013 - 2018	Engine	Module Information	
NISSAN	All Mode	2013 - 2018	Engine	Actuation Test	Check Deceleration Air Switchover Valve
NISSAN	All Mode	2013 - 2018	Engine	Actuation Test	Check Engine Oil Pump Valve
NISSAN	All Mode	2013 - 2018	Engine	Actuation Test	Boost Pressure
NISSAN	All Mode	2013 - 2018	Engine	Actuation Test	Check Fuel Injectors
NISSAN	All Mode	2013 - 2018	Engine	Actuation Test	Check Fuel HI Press Circ For Leaktightness
NISSAN	All Mode	2013 - 2018	Engine	Actuation Test	Check Fuel High Pressure Circuit
NISSAN	All Mode	2013 - 2018	Engine	Actuation Test	Check Fuel Press And Temp Sensor
NISSAN	All Mode	2013 - 2018	Engine	Actuation Test	Auto Stop Start
NISSAN	All Mode	2013 - 2018	Engine	Actuation Test	Ck Coolant Thermostat Heating Element(<100 Degree C)
NISSAN	All Mode	2013 - 2018	Engine	Actuation Test	Ck Coolant Thermostat Heating Element(<55 Degree C)
NISSAN	All Mode	2013 - 2018	Engine	Special Function	Resetting Of Adaption Values
NISSAN	All Mode	2013 - 2018	Engine	Special Function	Activation Of Fuel Pump
NISSAN	All Mode	2013 - 2018	Engine	Special Function	Teach In Of Throttle Valve Stop
NISSAN	All Mode	2013 - 2018	Engine	Special Function	Status Of Teach In Processes
NISSAN	All Mode	2013 - 2018	Engine	Special Function	Injector Injection Quantity Adjustment
NISSAN	All Mode	2013 - 2018	Engine	Special Function	Vin Registration
NISSAN	All Mode	2013 - 2018	Engine	Special Function	STRT OPRTN CNTR CLEAR
NISSAN	All Mode	2013 - 2018	Engine	Special Function	H/P Fuel Pump Total Starts Counter Clear
NISSAN	All Mode	2013 - 2018	Engine	Special Function	Saving Data For Replc CPU
NISSAN	All Mode	2013 - 2018	Engine	Special Function	Writing Data For Replc CPU
NISSAN	All Mode	2013 - 2018	Engine	Special Function	Camshaft Reference Adaptation
NISSAN	All Mode	2013 - 2018	Engine	Special Function	Teach In Of Camshaft Position
NISSAN	NV400	2014	Engine	Read Fault Code	
NISSAN	NV400	2014	Engine	Clear Fault Code	
NISSAN	NV400	2014	Engine	Read Data Stream	
NISSAN	NV400	2014	Engine	Module Information	
NISSAN	NV400	2014	Engine	Actuation Test	TURBOCHARGING SOLENOID VALVE
NISSAN	NV400	2014	Engine	Actuation Test	AIR INLET FLAP

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
NISSAN	NV400	2014	Engine	Actuation Test	HIGH PRESSURE CIRCUIT LEAK TEST
NISSAN	NV400	2014	Engine	Actuation Test	THERMO NO.3 RELAY
NISSAN	NV400	2014	Engine	Actuation Test	EGR VALVE
NISSAN	NV400	2014	Engine	Actuation Test	THERMOPLUNGER RELAY No.1
NISSAN	NV400	2014	Engine	Actuation Test	THERMOPLUNGER RELAY No.2
NISSAN	NV400	2014	Engine	Actuation Test	EGR BYPASS
NISSAN	NV400	2014	Engine	Actuation Test	ELECTRIC WATER PUMP
NISSAN	NV400	2014	Engine	Actuation Test	FIRST EGR COOLING PUMP
NISSAN	NV400	2014	Engine	Actuation Test	SECOND EGR COOLING PUMP
NISSAN	NV400	2014	Engine	Actuation Test	COOLANT CIRC SWITCHING S/V
NISSAN	NV400	2014	Engine	Actuation Test	Fuel Pump
NISSAN	NV400	2014	Engine	Actuation Test	HIGH PRESSURE COMPRESSOR
NISSAN	NV400	2014	Engine	Actuation Test	HIGH PRESSURE TURBINE
NISSAN	NV400	2014	Engine	Actuation Test	PREHEATER RELAY
NISSAN	NV400	2014	Engine	Special Function	Vin Registration
NISSAN	NV400	2014	Engine	Special Function	Fuel Sply Prev
NISSAN	NV400	2014	Engine	Special Function	Number Of Starting 1
NISSAN	NV400	2014	Engine	Special Function	Number Of Starting 2
NISSAN	NV400	2014	Engine	Special Function	Number Of Starting 3
NISSAN	NV400	2014	Engine	Special Function	Number Of Starting 4
NISSAN	NV400	2014	Engine	Special Function	Engine Adaptives
NISSAN	NV400	2014	Engine	Special Function	Egr Valve Programming
NISSAN	NV400	2014	Engine	Special Function	Air Damper Valve Programming
NISSAN	NV400	2014	Engine	Special Function	Turbocharger Programming
NISSAN	NV400	2014	Engine	Special Function	P/FLT DIFF PRS SEN
NISSAN	NV400	2014	Engine	Special Function	Injection Pump Adaptatives
NISSAN	NV400	2014	Engine	Special Function	Fuel Pump Programming
NISSAN	NV400	2014	Engine	Special Function	Adaptives On Air Intake Flap Malfunction
NISSAN	NV400	2014	Engine	Special Function	CC/SL PRGRM
NISSAN	NV400	2014	Engine	Special Function	Prpr Rich Sen Prog
NISSAN	NV400	2014	Engine	Special Function	Swirl Flap
NISSAN	NV400	2014	Engine	Special Function	Swirl Flap Programming
NISSAN	NV400	2014	Engine	Special Function	Hp Turbine Bypass SOL VLV Programming
NISSAN	NV400	2014	Engine	Special Function	Enter Injector Codes
NISSAN	NV400	2014	Engine	Special Function	Interval Of Oil Change (OCS) Oxidation
NISSAN	NV400	2014	Engine	Special Function	Oil Change Interval(Ocs):Dilution
NISSAN	NV400	2014	Engine	Special Function	Save Computer Data
NISSAN	NV400	2014	Engine	Special Function	Write Saved Data
NISSAN	NV400	2014	Engine	Special Function	Speed Limiter
NISSAN	NV400	2014	Engine	Special Function	Fast Idle Speed Modification
NISSAN	NV400	2014	Engine	Special Function	Air Flowmeter Programming
NISSAN	NV400	2014	Engine	Special Function	Cabin Filter Regeneration
NISSAN	All Mode	2010 - 2016	Engine	Read Fault Code	
NISSAN	All Mode	2010 - 2016	Engine	Clear Fault Code	
NISSAN	All Mode	2010 - 2016	Engine	Read Data Stream	
NISSAN	All Mode	2010 - 2016	Engine	Module Information	
NISSAN	All Mode	2010 - 2016	Engine	Actuation Test	TURBOCHARGING SOLENOID VALVE
NISSAN	All Mode	2010 - 2016	Engine	Actuation Test	AIR INLET FLAP
NISSAN	All Mode	2010 - 2016	Engine	Actuation Test	HIGH PRESSURE CIRCUIT LEAK TEST
NISSAN	All Mode	2010 - 2016	Engine	Actuation Test	THERMO NO.3 RELAY
NISSAN	All Mode	2010 - 2016	Engine	Actuation Test	EGR VALVE
NISSAN	All Mode	2010 - 2016	Engine	Actuation Test	PREHEATER RELAY
NISSAN	All Mode	2010 - 2016	Engine	Actuation Test	THERMOPLUNGER RELAY No.1
NISSAN	All Mode	2010 - 2016	Engine	Actuation Test	THERMOPLUNGER RELAY No.2
NISSAN	All Mode	2010 - 2016	Engine	Actuation Test	LOW PRESSURE EGR VALVE PROGRAMMING
NISSAN	All Mode	2010 - 2016	Engine	Actuation Test	EXHAUST AIR FLAP PROGRAMMING
NISSAN	All Mode	2010 - 2016	Engine	Actuation Test	COOLANT CIRC SWITCHING S/V
NISSAN	All Mode	2010 - 2016	Engine	Actuation Test	Fuel Pump
NISSAN	All Mode	2010 - 2016	Engine	Actuation Test	Fuel Pump Relay
NISSAN	All Mode	2010 - 2016	Engine	Actuation Test	FUEL HEATER RELAY
NISSAN	All Mode	2010 - 2016	Engine	Special Function	SOx MASS OPERATION
NISSAN	All Mode	2010 - 2016	Engine	Special Function	Vin Registration
NISSAN	All Mode	2010 - 2016	Engine	Special Function	Fuel Sply Prev
NISSAN	All Mode	2010 - 2016	Engine	Special Function	Number Of Starting 1
NISSAN	All Mode	2010 - 2016	Engine	Special Function	Number Of Starting 2
NISSAN	All Mode	2010 - 2016	Engine	Special Function	Number Of Starting 3
NISSAN	All Mode	2010 - 2016	Engine	Special Function	Number Of Starting 4
NISSAN	All Mode	2010 - 2016	Engine	Special Function	Engine Adaptives
NISSAN	All Mode	2010 - 2016	Engine	Special Function	Egr Valve Programming



**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
NISSAN	All Mode	2010 - 2016	Engine	Special Function	Air Damper Valve Programming
NISSAN	All Mode	2010 - 2016	Engine	Special Function	Exhaust Flap Low Setting
NISSAN	All Mode	2010 - 2016	Engine	Special Function	Turbocharger Programming
NISSAN	All Mode	2010 - 2016	Engine	Special Function	Low Pressure EGR Valve Programming
NISSAN	All Mode	2010 - 2016	Engine	Special Function	P/FLT DIFF PRS SEN
NISSAN	All Mode	2010 - 2016	Engine	Special Function	Pressure Regulation Adaptives
NISSAN	All Mode	2010 - 2016	Engine	Special Function	Fuel Pump Programming
NISSAN	All Mode	2010 - 2016	Engine	Special Function	Adaptives On Air Intake Flap Malfunction
NISSAN	All Mode	2010 - 2016	Engine	Special Function	CC/SL PRGRM
NISSAN	All Mode	2010 - 2016	Engine	Special Function	Prpr Rich Sen Prog
NISSAN	All Mode	2010 - 2016	Engine	Special Function	Enter Injector Codes
NISSAN	All Mode	2010 - 2016	Engine	Special Function	Service Regeneration
NISSAN	All Mode	2010 - 2016	Engine	Special Function	Speed Limiter
NISSAN	All Mode	2010 - 2016	Engine	Special Function	Interval Of Oil Change (OCS) Oxidation
NISSAN	All Mode	2010 - 2016	Engine	Special Function	OIL Change Interval (Ocs): Dilution
NISSAN	All Mode	2010 - 2016	Engine	Special Function	Volume Control Valve Learning Value Clear
NISSAN	All Mode	2010 - 2016	Engine	Special Function	EGR Bypass Programming
NISSAN	All Mode	2010 - 2016	Engine	Special Function	Air Flow Meter Programming
NISSAN	All Mode	2010 - 2016	Engine	Special Function	DPF Relative Pressure Sensor
NISSAN	All Mode	2010 - 2016	Engine	Special Function	Adaptives After Regenerating PF
NISSAN	All Mode	2010 - 2016	Engine	Special Function	After Dpf Replacement
NISSAN	All Mode	2010 - 2016	Engine	Special Function	Clutch Pedal End Stroke
NISSAN	All Mode	2010 - 2016	Engine	Special Function	Save Computer Data
NISSAN	All Mode	2010 - 2016	Engine	Special Function	Write Saved Data
NISSAN	All Mode	2010 - 2016	Engine	Special Function	Air Damper Valve Programming(R044)
NISSAN	All Mode	2010 - 2016	Engine	Special Function	NOX TRAP
NISSAN	All Mode	2010 - 2016	Engine	Special Function	SAVE COMPUTER DATA
NISSAN	All Mode	2010 - 2016	Engine	Special Function	WRITE SAVED DATA
NISSAN	All Mode	2010 - 2016	Engine	Special Function	After Dpf Regeneration
NISSAN	CABSTAR	2012	Engine	Read Fault Code	
NISSAN	CABSTAR	2012	Engine	Clear Fault Code	
NISSAN	CABSTAR	2012	Engine	Read Data Stream	
NISSAN	CABSTAR	2012	Engine	Module Information	
NISSAN	CABSTAR	2012	Engine	Actuation Test	THRTL POSITION
NISSAN	CABSTAR	2012	Engine	Actuation Test	EGR/V ANGLE
NISSAN	CABSTAR	2012	Engine	Actuation Test	GLOW RLY
NISSAN	CABSTAR	2012	Engine	Actuation Test	High Pressure Tc Boost Cont S/V
NISSAN	CABSTAR	2012	Engine	Actuation Test	Low Pressure Tc Boost Cont S/V
NISSAN	CABSTAR	2012	Engine	Actuation Test	Exhaust Shutter Solenoid Valve
NISSAN	CABSTAR	2012	Engine	Special Function	Vin Registration
NISSAN	CABSTAR	2012	Engine	Special Function	EGR/V LEARN CLR
NISSAN	CABSTAR	2012	Engine	Special Function	TP POS LEARN CLR
NISSAN	CABSTAR	2012	Engine	Special Function	DPF Data Clear
NISSAN	CABSTAR	2012	Engine	Special Function	A/F SEN LEAN CLR
NISSAN	CABSTAR	2012	Engine	Special Function	Injector Learning Value Clear
NISSAN	CABSTAR	2012	Engine	Special Function	Mixture Ratio Learning Value Clear
NISSAN	CABSTAR	2012	Engine	Special Function	Enter Injctr Calib Data
NISSAN	CABSTAR	2012	Engine	Special Function	Service Regeneration
NISSAN	CABSTAR	2012	Engine	Special Function	Battery discharge current totalizing clear
NISSAN	CABSTAR	2012	Engine	Special Function	Common rail switching clear
NISSAN	CABSTAR	2012	Engine	Special Function	Saving Data For Replc CPU
NISSAN	CABSTAR	2012	Engine	Special Function	Writing Data For Replc CPU
NISSAN	All Mode	2010 - 2017	Engine	Read Fault Code	
NISSAN	All Mode	2010 - 2017	Engine	Clear Fault Code	
NISSAN	All Mode	2010 - 2017	Engine	Read Data Stream	
NISSAN	All Mode	2010 - 2017	Engine	Module Information	
NISSAN	All Mode	2010 - 2017	Engine	Actuation Test	TURBOCHARGING SOLENOID VALVE
NISSAN	All Mode	2010 - 2017	Engine	Actuation Test	AIR INLET FLAP
NISSAN	All Mode	2010 - 2017	Engine	Actuation Test	THERMO NO.3 RELAY
NISSAN	All Mode	2010 - 2017	Engine	Actuation Test	EGR VALVE
NISSAN	All Mode	2010 - 2017	Engine	Actuation Test	PREHEATER RELAY
NISSAN	All Mode	2010 - 2017	Engine	Actuation Test	Fan Unit Low Speed RLY
NISSAN	All Mode	2010 - 2017	Engine	Actuation Test	Fan Unit High Speed RLY

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
NISSAN	All Mode	2010 - 2017	Engine	Actuation Test	THERMOPLUNGER RELAY No.1
NISSAN	All Mode	2010 - 2017	Engine	Actuation Test	THERMOPLUNGER RELAY No.2
NISSAN	All Mode	2010 - 2017	Engine	Actuation Test	EGR BYPASS
NISSAN	All Mode	2010 - 2017	Engine	Actuation Test	Air Conditioning Compressor Relay Control
NISSAN	All Mode	2010 - 2017	Engine	Actuation Test	Low Pressure Fuel Pump
NISSAN	All Mode	2010 - 2017	Engine	Actuation Test	PUMP PRESSURE REGULATOR
NISSAN	All Mode	2010 - 2017	Engine	Actuation Test	LOW PRESSURE EGR VALVE
NISSAN	All Mode	2010 - 2017	Engine	Actuation Test	Exhaust Air Flap
NISSAN	All Mode	2010 - 2017	Engine	Actuation Test	COOLANT CIRC SWITCHING S/V
NISSAN	All Mode	2010 - 2017	Engine	Actuation Test	Fuel Pump
NISSAN	All Mode	2010 - 2017	Engine	Actuation Test	Active Grille Air Shutter
NISSAN	All Mode	2010 - 2017	Engine	Actuation Test	Fuel Pump Relay
NISSAN	All Mode	2010 - 2017	Engine	Actuation Test	FUEL HEATER RELAY
NISSAN	All Mode	2010 - 2017	Engine	Special Function	Save Computer Data
NISSAN	All Mode	2010 - 2017	Engine	Special Function	Write Saved Data
NISSAN	All Mode	2010 - 2017	Engine	Special Function	Cylinder Function Fault Finding
NISSAN	All Mode	2010 - 2017	Engine	Special Function	High Pressure Fuel Circuit Fault Finding
NISSAN	All Mode	2010 - 2017	Engine	Special Function	Vin Registration
NISSAN	All Mode	2010 - 2017	Engine	Special Function	Fuel Sply Prev
NISSAN	All Mode	2010 - 2017	Engine	Special Function	Number Of Starting 1
NISSAN	All Mode	2010 - 2017	Engine	Special Function	Number Of Starting 2
NISSAN	All Mode	2010 - 2017	Engine	Special Function	Number Of Starting 3
NISSAN	All Mode	2010 - 2017	Engine	Special Function	Number Of Starting 4
NISSAN	All Mode	2010 - 2017	Engine	Special Function	Egr Valve Programming
NISSAN	All Mode	2010 - 2017	Engine	Special Function	Air Damper Valve Programming
NISSAN	All Mode	2010 - 2017	Engine	Special Function	CC/SL Prgrm
NISSAN	All Mode	2010 - 2017	Engine	Special Function	Flywhl TGT PG
NISSAN	All Mode	2010 - 2017	Engine	Special Function	Exhaust Air Flap Programming
NISSAN	All Mode	2010 - 2017	Engine	Special Function	Turbocharger Programming
NISSAN	All Mode	2010 - 2017	Engine	Special Function	Adaptives On Air Intake Flap Malfunction
NISSAN	All Mode	2010 - 2017	Engine	Special Function	Manifold Pressure Sensor Programming
NISSAN	All Mode	2010 - 2017	Engine	Special Function	P/FLT DIFP PRS SEN
NISSAN	All Mode	2010 - 2017	Engine	Special Function	Low Pressure EGR Valve Programming
NISSAN	All Mode	2010 - 2017	Engine	Special Function	Engine Adaptives
NISSAN	All Mode	2010 - 2017	Engine	Special Function	Number Of Starting Cycles
NISSAN	All Mode	2010 - 2017	Engine	Special Function	Injection Pump Adaptatives
NISSAN	All Mode	2010 - 2017	Engine	Special Function	Fuel Pump Programming
NISSAN	All Mode	2010 - 2017	Engine	Special Function	Injector Adaptives
NISSAN	All Mode	2010 - 2017	Engine	Special Function	Air Path Programming
NISSAN	All Mode	2010 - 2017	Engine	Special Function	EGR Adaptives
NISSAN	All Mode	2010 - 2017	Engine	Special Function	DPF Relative Pressure Sensor
NISSAN	All Mode	2010 - 2017	Engine	Special Function	Rail Pressure Sensor Adaptives
NISSAN	All Mode	2010 - 2017	Engine	Special Function	EGR Programming
NISSAN	All Mode	2010 - 2017	Engine	Special Function	Prpr Rich Sen Prog
NISSAN	All Mode	2010 - 2017	Engine	Special Function	Programmed Values
NISSAN	All Mode	2010 - 2017	Engine	Special Function	Fuel Rail Press Limiting Injctn Countr Clear
NISSAN	All Mode	2010 - 2017	Engine	Special Function	Service Regeneration
NISSAN	All Mode	2010 - 2017	Engine	Special Function	Enter Injector Codes
NISSAN	All Mode	2010 - 2017	Engine	Special Function	Speed Limiter
NISSAN	All Mode	2010 - 2017	Engine	Special Function	Adaptives After Regenerating PF
NISSAN	All Mode	2010 - 2017	Engine	Special Function	Interval Of Oil Change (OCS) Oxidation
NISSAN	All Mode	2010 - 2017	Engine	Special Function	Oil Change Interval(Ocs):Dilution
NISSAN	All Mode	2010 - 2017	Engine	Special Function	After Dpf Regeneration
NISSAN	All Mode	2010 - 2017	Engine	Special Function	Alternator Setpoint Voltage
NISSAN	All Mode	2010 - 2017	Engine	Special Function	NOX TRAP
NISSAN	All Mode	2013 - 2016	Engine	Read Fault Code	
NISSAN	All Mode	2013 - 2016	Engine	Clear Fault Code	
NISSAN	All Mode	2013 - 2016	Engine	Read Data Stream	
NISSAN	All Mode	2013 - 2016	Engine	Module Information	
NISSAN	All Mode	2013 - 2016	Engine	Actuation Test	Auto Stop Start
NISSAN	All Mode	2013 - 2016	Engine	Actuation Test	Gas Pump Command State (Gasoline)
NISSAN	All Mode	2013 - 2016	Engine	Actuation Test	Intake Comshaft Phaser Pwm Command
NISSAN	All Mode	2013 - 2016	Engine	Actuation Test	Boost Pressure Pwm Command (Gasoline)

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

<b>make</b>	<b>model</b>	<b>year</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
NISSAN	All Mode	2013 - 2016	Engine	Actuation Test	Catalyst Exhaust Gas Upstream Oxygen Resistance Heater Pwm Command
NISSAN	All Mode	2013 - 2016	Engine	Actuation Test	Catalyst Exhaust Gas Downstream Oxygen Resistance Heater Pwm Command
NISSAN	All Mode	2013 - 2016	Engine	Actuation Test	Oil Pressure Rco Command With Monitool
NISSAN	All Mode	2013 - 2016	Engine	Actuation Test	Controlled Thermostat
NISSAN	All Mode	2013 - 2016	Engine	Actuation Test	Throttle Valve Position Setpoint
NISSAN	All Mode	2013 - 2016	Engine	Actuation Test	Canister Drain Valve Command (Conti)
NISSAN	All Mode	2013 - 2016	Engine	Actuation Test	Vvt Control Solenoid (Exhaust)
NISSAN	All Mode	2013 - 2016	Engine	Special Function	After throttle valve replacement
NISSAN	All Mode	2013 - 2016	Engine	Special Function	After turbocharger component replacement
NISSAN	All Mode	2013 - 2016	Engine	Special Function	After rail pressure sensor replacement
NISSAN	All Mode	2013 - 2016	Engine	Special Function	After injector replacement
NISSAN	All Mode	2013 - 2016	Engine	Special Function	After TDC sensor replacement
NISSAN	All Mode	2013 - 2016	Engine	Special Function	After turbocharger solenoid valve replacement
NISSAN	All Mode	2013 - 2016	Engine	Special Function	After end stroke clutch contactor replacement
NISSAN	All Mode	2013 - 2016	Engine	Special Function	After camshaft sensor replacement
NISSAN	All Mode	2013 - 2016	Engine	Special Function	Starter Operation Counter Clear
NISSAN	All Mode	2013 - 2016	Engine	Special Function	Write Starter Operation Count
NISSAN	All Mode	2013 - 2016	Engine	Special Function	Vin Registration
NISSAN	All Mode	2013 - 2016	Engine	Special Function	H/P Fuel Pump Total Starts Counter Clear
NISSAN	All Mode	2013 - 2016	Engine	Special Function	Write H/P Fuel Pump Total Starts Count
NISSAN	All Mode	2013 - 2016	Engine	Special Function	Fuel Sply Prev
NISSAN	All Mode	2013 - 2016	Engine	Special Function	Engine Adaptives
NISSAN	All Mode	2013 - 2016	Engine	Special Function	Injection Pump Adaptatives
NISSAN	All Mode	2013 - 2016	Engine	Special Function	Interval Of Oil Change (OCS) Oxidation
NISSAN	All Mode	2013 - 2016	Engine	Special Function	After High Pressure Fuel Pump Replacement
NISSAN	All Mode	2013 - 2016	Engine	Special Function	Inhibit Evap System
NISSAN	All Mode	2013 - 2016	Engine	Special Function	Activate Evap System
NISSAN	All Mode	2013 - 2016	Engine	Special Function	Air Fuel Ratio Sensor
NISSAN	All Mode	2013 - 2016	Engine	Special Function	Clutch Pedal End Stroke
NISSAN	All Mode	2013 - 2016	Engine	Special Function	Vacuum Pump
NISSAN	All Mode	2013 - 2016	Engine	Special Function	High Pressure Fuel Circuit Fault Finding
NISSAN	All Mode	2013 - 2016	Engine	Special Function	Save Computer Data
NISSAN	All Mode	2013 - 2016	Engine	Special Function	Write Saved Data
NISSAN	All Mode	2013 - 2016	Engine	Special Function	Start OBD test: Catalytic converter
NISSAN	All Mode	2013 - 2016	Engine	Special Function	Start OBD test: O2 sensor
NISSAN	All Mode	2013 - 2016	Engine	Special Function	After Tc Solenoid Valve Replacement
NISSAN	All Mode	2013 - 2016	Engine	Special Function	AFTR ELECTRIC THRRTL CNTRL ACTUATOR RPLCMNT
NISSAN	All Mode	2013 - 2016	Engine	Special Function	After Crankshaft Pos Sensor Replacement
NISSAN	All Mode	2013 - 2017	Engine	Read Fault Code	
NISSAN	All Mode	2013 - 2017	Engine	Clear Fault Code	
NISSAN	All Mode	2013 - 2017	Engine	Read Data Stream	
NISSAN	All Mode	2013 - 2017	Engine	Module Information	
NISSAN	All Mode	2013 - 2017	Engine	Actuation Test	COOLING FAN 2
NISSAN	All Mode	2013 - 2017	Engine	Actuation Test	COOLING FAN 1
NISSAN	All Mode	2013 - 2017	Engine	Actuation Test	Exhaust Throttle
NISSAN	All Mode	2013 - 2017	Engine	Actuation Test	EGR VOLUME CONTROL VALVE
NISSAN	All Mode	2013 - 2017	Engine	Actuation Test	Throttle Valve
NISSAN	All Mode	2013 - 2017	Engine	Actuation Test	Turbocharger Boost Pressure
NISSAN	All Mode	2013 - 2017	Engine	Actuation Test	COOLANT FLOW VALVE
NISSAN	All Mode	2013 - 2017	Engine	Actuation Test	GLOW PLUG
NISSAN	All Mode	2013 - 2017	Engine	Actuation Test	A/C COMPRESSOR
NISSAN	All Mode	2013 - 2017	Engine	Actuation Test	THERMO PLUNGER
NISSAN	All Mode	2013 - 2017	Engine	Actuation Test	Fuel Pump

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

<b>make</b>	<b>model</b>	<b>year</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
NISSAN	All Mode	2013 - 2017	Engine	Actuation Test	Fuel Pump Relay
NISSAN	All Mode	2013 - 2017	Engine	Actuation Test	EGR WATER PUMP 1
NISSAN	All Mode	2013 - 2017	Engine	Actuation Test	Auto Stop Start
NISSAN	All Mode	2013 - 2017	Engine	Special Function	Fuel Pump Programming
NISSAN	All Mode	2013 - 2017	Engine	Special Function	Air Flow Meter Programming
NISSAN	All Mode	2013 - 2017	Engine	Special Function	Adaptives On Air Intake Flap Malfunction
NISSAN	All Mode	2013 - 2017	Engine	Special Function	Air Damper Valve Programming(R088)
NISSAN	All Mode	2013 - 2017	Engine	Special Function	Exhaust Flap Low Setting
NISSAN	All Mode	2013 - 2017	Engine	Special Function	Turbocharger Programming
NISSAN	All Mode	2013 - 2017	Engine	Special Function	Manifold Pressure Sensor Programming
NISSAN	All Mode	2013 - 2017	Engine	Special Function	Egr Valve Programming
NISSAN	All Mode	2013 - 2017	Engine	Special Function	EGR Bypass Programming
NISSAN	All Mode	2013 - 2017	Engine	Special Function	Injection Pump Adaptatives
NISSAN	All Mode	2013 - 2017	Engine	Special Function	Rail Pressure Sensor Adaptives
NISSAN	All Mode	2013 - 2017	Engine	Special Function	DPF Relative Pressure Sensor
NISSAN	All Mode	2013 - 2017	Engine	Special Function	P/FLT DIFF PRS SEN
NISSAN	All Mode	2013 - 2017	Engine	Special Function	Prpr Rich Sen Prog
NISSAN	All Mode	2013 - 2017	Engine	Special Function	Air Damper Valve Programming(R044)
NISSAN	All Mode	2013 - 2017	Engine	Special Function	Low Pressure EGR Valve Programming
NISSAN	All Mode	2013 - 2017	Engine	Special Function	Swirl Flap Programming
NISSAN	All Mode	2013 - 2017	Engine	Special Function	Swirl Flap
NISSAN	All Mode	2013 - 2017	Engine	Special Function	Enter Injector Codes
NISSAN	All Mode	2013 - 2017	Engine	Special Function	Service Regeneration
NISSAN	All Mode	2013 - 2017	Engine	Special Function	Vin Registration
NISSAN	All Mode	2013 - 2017	Engine	Special Function	UDS Implementation Validation
NISSAN	All Mode	2013 - 2017	Engine	Special Function	Variable Valve Timing
NISSAN	All Mode	2013 - 2017	Engine	Special Function	Target Idle Speed(Increase)
NISSAN	All Mode	2013 - 2017	Engine	Special Function	Target Idle Speed(Decrease)
NISSAN	All Mode	2013 - 2017	Engine	Special Function	DPF Regeneration
NISSAN	All Mode	2013 - 2017	Engine	Special Function	Exhaust Fuel Injector Leakage
NISSAN	All Mode	2013 - 2017	Engine	Special Function	A/F Sensor Upstream Catalyst
NISSAN	All Mode	2013 - 2017	Engine	Special Function	Fuel Rail Pressure Test
NISSAN	All Mode	2013 - 2017	Engine	Special Function	Fuel Injector Test
NISSAN	All Mode	2013 - 2017	Engine	Special Function	Static Test
NISSAN	All Mode	2013 - 2017	Engine	Special Function	Fuel Pump
NISSAN	All Mode	2013 - 2017	Engine	Special Function	Immobilizer System Check 2
NISSAN	All Mode	2013 - 2017	Engine	Special Function	Number Of Starting 1
NISSAN	All Mode	2013 - 2017	Engine	Special Function	Number Of Starting 2
NISSAN	All Mode	2013 - 2017	Engine	Special Function	Number Of Starting 3
NISSAN	All Mode	2013 - 2017	Engine	Special Function	Number Of Starting 4
NISSAN	All Mode	2013 - 2017	Engine	Special Function	Starter Operation Counter Clear
NISSAN	All Mode	2013 - 2017	Engine	Special Function	H/P Fuel Pump Total Starts Counter Clear
NISSAN	All Mode	2013 - 2017	Engine	Special Function	Write Starter Operation Count
NISSAN	All Mode	2013 - 2017	Engine	Special Function	Write H/P Fuel Pump Total Starts Count
NISSAN	All Mode	2013 - 2017	Engine	Special Function	Bypass Solenoid Valve For HP Turbine Componet
NISSAN	All Mode	2013 - 2017	Engine	Special Function	Adaptives After Regenerating PF
NISSAN	All Mode	2013 - 2017	Engine	Special Function	Interval Of Oil Change (OCS) Oxidation
NISSAN	All Mode	2013 - 2017	Engine	Special Function	Oil Change Interval(Ocs):Dilution
NISSAN	All Mode	2013 - 2017	Engine	Special Function	High Pressure Fuel Circuit Fault Finding
NISSAN	All Mode	2013 - 2017	Engine	Special Function	Cylinder Function Fault Finding
NISSAN	All Mode	2013 - 2017	Engine	Special Function	Speed Limiter
NISSAN	All Mode	2013 - 2017	Engine	Special Function	Fast Idle Speed Modification
NISSAN	All Mode	2013 - 2017	Engine	Special Function	Save Computer Data
NISSAN	All Mode	2013 - 2017	Engine	Special Function	Write Saved Data
NISSAN	All Mode	2013 - 2017	Engine	Special Function	Clutch Pedal End Stroke
NISSAN	All Mode	2013 - 2017	Engine	Special Function	Fuel Sply Prev
NISSAN	All Mode	2013 - 2017	Engine	Special Function	Programmed Values
NISSAN	All Mode	2013 - 2017	Engine	Special Function	Thermoplunger Programming
NISSAN	All Mode	2013 - 2017	Engine	Special Function	SAVE COMPUTER DATA

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
NISSAN	All Mode	2013 - 2017	Engine	Special Function	WRITE SAVED DATA
NISSAN	All Mode	2013 - 2017	Engine	Special Function	After Dpf Regeneration
NISSAN	All Mode	2013 - 2017	Engine	Special Function	High Pressure Turbine Bypass Solenoid Valve
NISSAN	All Mode	2013 - 2017	Engine	Special Function	Alternator Setpoint Voltage
NISSAN	All Mode	2013 - 2017	Engine	Special Function	NOX TRAP
NISSAN	All Mode	2013 - 2016	Engine	Read Fault Code	
NISSAN	All Mode	2013 - 2016	Engine	Clear Fault Code	
NISSAN	All Mode	2013 - 2016	Engine	Read Data Stream	
NISSAN	All Mode	2013 - 2016	Engine	Module Information	
NISSAN	All Mode	2013 - 2016	Engine	Actuation Test	A/F SENSOR HEATER
NISSAN	All Mode	2013 - 2016	Engine	Actuation Test	FUEL FLOW ACTUATOR
NISSAN	All Mode	2013 - 2016	Engine	Actuation Test	COOLING FAN 2
NISSAN	All Mode	2013 - 2016	Engine	Actuation Test	COOLING FAN 1
NISSAN	All Mode	2013 - 2016	Engine	Actuation Test	EXHAUST FUEL INJECTOR
NISSAN	All Mode	2013 - 2016	Engine	Actuation Test	FUEL RAIL PRESSURE
NISSAN	All Mode	2013 - 2016	Engine	Actuation Test	INTAKE MANIFOLD RUNNER VALVE
NISSAN	All Mode	2013 - 2016	Engine	Actuation Test	EGR COOLER BYPASS VALVE
NISSAN	All Mode	2013 - 2016	Engine	Actuation Test	Exhaust Throttle
NISSAN	All Mode	2013 - 2016	Engine	Actuation Test	TC COOLING WATER PUMP
NISSAN	All Mode	2013 - 2016	Engine	Actuation Test	EGR COOLER BYPASS PWM
NISSAN	All Mode	2013 - 2016	Engine	Actuation Test	EGR VOLUME CONTROL VALVE
NISSAN	All Mode	2013 - 2016	Engine	Actuation Test	Throttle Valve
NISSAN	All Mode	2013 - 2016	Engine	Actuation Test	Turbocharger Boost Pressure
NISSAN	All Mode	2013 - 2016	Engine	Actuation Test	COOLANT FLOW VALVE
NISSAN	All Mode	2013 - 2016	Engine	Actuation Test	PTC 3
NISSAN	All Mode	2013 - 2016	Engine	Actuation Test	PTC 2
NISSAN	All Mode	2013 - 2016	Engine	Actuation Test	PTC 1
NISSAN	All Mode	2013 - 2016	Engine	Actuation Test	GLOW PLUG
NISSAN	All Mode	2013 - 2016	Engine	Actuation Test	IDLE SPEED
NISSAN	All Mode	2013 - 2016	Engine	Actuation Test	A/C COMPRESSOR
NISSAN	All Mode	2013 - 2016	Engine	Actuation Test	Auto Stop Start
NISSAN	All Mode	2013 - 2016	Engine	Special Function	Enter Injector Codes
NISSAN	All Mode	2013 - 2016	Engine	Special Function	Service Regeneration
NISSAN	All Mode	2013 - 2016	Engine	Special Function	Vin Registration
NISSAN	All Mode	2013 - 2016	Engine	Special Function	Number Of Starting 1
NISSAN	All Mode	2013 - 2016	Engine	Special Function	Number Of Starting 2
NISSAN	All Mode	2013 - 2016	Engine	Special Function	Number Of Starting 3
NISSAN	All Mode	2013 - 2016	Engine	Special Function	Number Of Starting 4
NISSAN	All Mode	2013 - 2016	Engine	Special Function	Fuel Pump Programming
NISSAN	All Mode	2013 - 2016	Engine	Special Function	Air Flow Meter Programming
NISSAN	All Mode	2013 - 2016	Engine	Special Function	Adaptives On Air Intake Flap Malfunction
NISSAN	All Mode	2013 - 2016	Engine	Special Function	Air Damper Valve Programming(RO88)
NISSAN	All Mode	2013 - 2016	Engine	Special Function	Exhaust Flap Low Setting
NISSAN	All Mode	2013 - 2016	Engine	Special Function	Turbocharger Programming
NISSAN	All Mode	2013 - 2016	Engine	Special Function	Egr Valve Programming
NISSAN	All Mode	2013 - 2016	Engine	Special Function	EGR Bypass Programming
NISSAN	All Mode	2013 - 2016	Engine	Special Function	Flywhl TGT PG
NISSAN	All Mode	2013 - 2016	Engine	Special Function	Injection Pump Adaptatives
NISSAN	All Mode	2013 - 2016	Engine	Special Function	Rail Pressure Sensor Adaptives
NISSAN	All Mode	2013 - 2016	Engine	Special Function	DPF Relative Pressure Sensor
NISSAN	All Mode	2013 - 2016	Engine	Special Function	P/FLT DIFF PRS SEN
NISSAN	All Mode	2013 - 2016	Engine	Special Function	Prpr Rich Sen Prog
NISSAN	All Mode	2013 - 2016	Engine	Special Function	Low Pressure EGR Valve Programming
NISSAN	All Mode	2013 - 2016	Engine	Special Function	Swirl Flap
NISSAN	All Mode	2013 - 2016	Engine	Special Function	Swirl Flap Programming
NISSAN	All Mode	2013 - 2016	Engine	Special Function	UDS Implementation Validation
NISSAN	All Mode	2013 - 2016	Engine	Special Function	Variable Valve Timing
NISSAN	All Mode	2013 - 2016	Engine	Special Function	Target Idle Speed(Increase)
NISSAN	All Mode	2013 - 2016	Engine	Special Function	Target Idle Speed(Decrease)
NISSAN	All Mode	2013 - 2016	Engine	Special Function	Exhaust Fuel Injector Leakage
NISSAN	All Mode	2013 - 2016	Engine	Special Function	A/F Sensor Upstream Catalyst
NISSAN	All Mode	2013 - 2016	Engine	Special Function	Fuel Rail Pressure Test
NISSAN	All Mode	2013 - 2016	Engine	Special Function	Fuel Injector Test
NISSAN	All Mode	2013 - 2016	Engine	Special Function	Static Test
NISSAN	All Mode	2013 - 2016	Engine	Special Function	Fuel Pump
NISSAN	All Mode	2013 - 2016	Engine	Special Function	Immobilizer System Check 2
NISSAN	All Mode	2013 - 2016	Engine	Special Function	Air Damper Valve Programming(R044)
NISSAN	All Mode	2013 - 2016	Engine	Special Function	Starter Operation Counter Clear

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

<b>make</b>	<b>model</b>	<b>year</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
NISSAN	All Mode	2013 - 2016	Engine	Special Function	H/P Fuel Pump Total Starts Counter Clear
NISSAN	All Mode	2013 - 2016	Engine	Special Function	Write Starter Operation Count
NISSAN	All Mode	2013 - 2016	Engine	Special Function	Write H/P Fuel Pump Total Starts Count
NISSAN	All Mode	2013 - 2016	Engine	Special Function	Adaptives After Regenerating PF
NISSAN	All Mode	2013 - 2016	Engine	Special Function	Interval Of Oil Change (OCS) Oxidation
NISSAN	All Mode	2013 - 2016	Engine	Special Function	Oil Change Interval(Ocs):Dilution
NISSAN	All Mode	2013 - 2016	Engine	Special Function	Speed Limiter
NISSAN	All Mode	2013 - 2016	Engine	Special Function	Save Computer Data
NISSAN	All Mode	2013 - 2016	Engine	Special Function	Write Saved Data
NISSAN	All Mode	2013 - 2016	Engine	Special Function	Clutch Pedal End Stroke
NISSAN	All Mode	2013 - 2016	Engine	Special Function	Fuel Sply Prev
NISSAN	All Mode	2013 - 2016	Engine	Special Function	SAVE COMPUTER DATA
NISSAN	All Mode	2013 - 2016	Engine	Special Function	WRITE SAVED DATA
NISSAN	All Mode	2013 - 2016	Engine	Special Function	After Dpf Regeneration
NISSAN	All Mode	2013 - 2016	Engine	Special Function	NOX TRAP
NISSAN	All Mode	2013 - 2016	Engine	Read Fault Code	
NISSAN	All Mode	2013 - 2016	Engine	Clear Fault Code	
NISSAN	All Mode	2013 - 2016	Engine	Read Data Stream	
NISSAN	All Mode	2013 - 2016	Engine	Module Information	
NISSAN	All Mode	2013 - 2016	Engine	Actuation Test	Fuel Pump Relay
NISSAN	All Mode	2013 - 2016	Engine	Actuation Test	Intake Valve Timing Control Solenoid Valve
NISSAN	All Mode	2013 - 2016	Engine	Actuation Test	TC Wastegate Control Solenoid Valve
NISSAN	All Mode	2013 - 2016	Engine	Actuation Test	Engine Oil Pressure Control Solenoid Valve
NISSAN	All Mode	2013 - 2016	Engine	Actuation Test	Exhaust Valve Timing Control Solenoid Valve
NISSAN	All Mode	2013 - 2016	Engine	Actuation Test	Thermostat Heater Control Solenoid Valve
NISSAN	All Mode	2013 - 2016	Engine	Actuation Test	Electric Throttle Control Actuator
NISSAN	All Mode	2013 - 2016	Engine	Actuation Test	EVAP Canister Purge Control Solenoid Valve
NISSAN	All Mode	2013 - 2016	Engine	Special Function	Vin Registration
NISSAN	All Mode	2013 - 2016	Engine	Special Function	After throttle valve replacement
NISSAN	All Mode	2013 - 2016	Engine	Special Function	After turbocharger componet replacement
NISSAN	All Mode	2013 - 2016	Engine	Special Function	After turbocharger solenoid valve replacement
NISSAN	All Mode	2013 - 2016	Engine	Special Function	After end stroke cluthc contactor replacement
NISSAN	All Mode	2013 - 2016	Engine	Special Function	After camshaft sensor replacement
NISSAN	All Mode	2013 - 2016	Engine	Special Function	After TDC sensor replacement
NISSAN	All Mode	2013 - 2016	Engine	Special Function	After injection pump replacement
NISSAN	All Mode	2013 - 2016	Engine	Special Function	After rail pressure sensor replacement
NISSAN	All Mode	2013 - 2016	Engine	Special Function	After injector replacement
NISSAN	All Mode	2013 - 2016	Engine	Special Function	Fuel Sply Prev
NISSAN	All Mode	2013 - 2016	Engine	Special Function	Engine Adaptives
NISSAN	All Mode	2013 - 2016	Engine	Special Function	Injection Pump Adaptatives
NISSAN	All Mode	2013 - 2016	Engine	Special Function	Interval Of Oil Change (OCS) Oxidation
NISSAN	All Mode	2013 - 2016	Engine	Special Function	High Pressure Fuel Circuit Fault Finding
NISSAN	All Mode	2013 - 2016	Engine	Special Function	Air Fuel Ratio Sensor
NISSAN	All Mode	2013 - 2016	Engine	Special Function	After High Pressure Fuel Pump Replacement
NISSAN	All Mode	2013 - 2016	Engine	Special Function	After Tc Solenoid Valve Replacement
NISSAN	All Mode	2013 - 2016	Engine	Special Function	AFTR ELECTRIC THRRTL CNTRL ACTUATOR RPLCMNT
NISSAN	All Mode	2014 - 2017	Engine	Read Fault Code	
NISSAN	All Mode	2014 - 2017	Engine	Clear Fault Code	
NISSAN	All Mode	2014 - 2017	Engine	Read Data Stream	
NISSAN	All Mode	2014 - 2017	Engine	Module Information	
NISSAN	All Mode	2014 - 2017	Engine	Actuation Test	Fuel Pump
NISSAN	All Mode	2014 - 2017	Engine	Actuation Test	TURBOCHARGING SOLENOID VALVE
NISSAN	All Mode	2014 - 2017	Engine	Actuation Test	AIR INLET FLAP

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
NISSAN	All Mode	2014 - 2017	Engine	Actuation Test	PREHEATER RELAY
NISSAN	All Mode	2014 - 2017	Engine	Actuation Test	COOLANT CIRC SWITCHING S/V
NISSAN	All Mode	2014 - 2017	Engine	Actuation Test	EGR VALVE
NISSAN	All Mode	2014 - 2017	Engine	Actuation Test	HIGH PRESSURE CIRCUIT LEAK TEST
NISSAN	All Mode	2014 - 2017	Engine	Actuation Test	HIGH PRESSURE TURBINE
NISSAN	All Mode	2014 - 2017	Engine	Actuation Test	EGR BYPASS
NISSAN	All Mode	2014 - 2017	Engine	Actuation Test	SECOND EGR COOLING PUMP
NISSAN	All Mode	2014 - 2017	Engine	Actuation Test	FIRST EGR COOLING PUMP
NISSAN	All Mode	2014 - 2017	Engine	Actuation Test	HIGH PRESSURE COMPRESSOR
NISSAN	All Mode	2014 - 2017	Engine	Actuation Test	ELECTRIC WATER PUMP
NISSAN	All Mode	2014 - 2017	Engine	Special Function	Fuel Sply Prev
NISSAN	All Mode	2014 - 2017	Engine	Special Function	Vin Registration
NISSAN	All Mode	2014 - 2017	Engine	Special Function	Number Of Starting 1
NISSAN	All Mode	2014 - 2017	Engine	Special Function	Number Of Starting 2
NISSAN	All Mode	2014 - 2017	Engine	Special Function	Number Of Starting 3
NISSAN	All Mode	2014 - 2017	Engine	Special Function	Number Of Starting 4
NISSAN	All Mode	2014 - 2017	Engine	Special Function	Air Damper Valve Programming
NISSAN	All Mode	2014 - 2017	Engine	Special Function	Egr Valve Programming
NISSAN	All Mode	2014 - 2017	Engine	Special Function	Injection Pump Adaptatives
NISSAN	All Mode	2014 - 2017	Engine	Special Function	Engine Adaptives
NISSAN	All Mode	2014 - 2017	Engine	Special Function	Fuel Pump Programming
NISSAN	All Mode	2014 - 2017	Engine	Special Function	Turbocharger Programming
NISSAN	All Mode	2014 - 2017	Engine	Special Function	CC/SL PRGRM
NISSAN	All Mode	2014 - 2017	Engine	Special Function	Prpr Rich Sen Prog
NISSAN	All Mode	2014 - 2017	Engine	Special Function	P/FLT DIFF PRS SEN
NISSAN	All Mode	2014 - 2017	Engine	Special Function	Hp Turbine Bypass SOL VLV Programming
NISSAN	All Mode	2014 - 2017	Engine	Special Function	Enter Injector Codes
NISSAN	All Mode	2014 - 2017	Engine	Special Function	Interval Of Oil Change (OCS) Oxidation
NISSAN	All Mode	2014 - 2017	Engine	Special Function	OIL Change Interval (Ocs): Dilution
NISSAN	All Mode	Up to 2018	Engine	Read Fault Code	
NISSAN	All Mode	Up to 2018	Engine	Clear Fault Code	
NISSAN	All Mode	Up to 2018	Engine	Read Data Stream	
NISSAN	All Mode	Up to 2018	Engine	Module Information	
NISSAN	All Mode	Up to 2018	Engine	Actuation Test	TC BYPASS VALVE
NISSAN	All Mode	Up to 2018	Engine	Actuation Test	Auto Stop Start
NISSAN	All Mode	Up to 2018	Engine	Special Function	EGR control valve closed position learning
NISSAN	All Mode	Up to 2018	Engine	Special Function	(TBD)VCR base position learning
NISSAN	All Mode	Up to 2018	Engine	Special Function	Self-Learning Cont
NISSAN	All Mode	Up to 2018	Engine	Special Function	A/F Initial Learning
NISSAN	All Mode	Up to 2018	Engine	Special Function	TARGET IGN TIM ADJ
NISSAN	All Mode	Up to 2018	Engine	Special Function	TARGET IDLE RPM ADJ
NISSAN	All Mode	Up to 2018	Engine	Special Function	VALVE TIMING ADJUSTMENT
NISSAN	All Mode	Up to 2018	Engine	Special Function	Engine Coolant Bypass Valve
NISSAN	All Mode	Up to 2018	Engine	Special Function	Idle Air Vol Learn
NISSAN	All Mode	Up to 2018	Engine	Special Function	Saving Data For Replc CPU
NISSAN	All Mode	Up to 2018	Engine	Special Function	Writing Data For Replc CPU
NISSAN	All Mode	Up to 2018	Engine	Special Function	Electric intake valve timing control learning
NISSAN	All Mode	Up to 2018	Engine	Special Function	Valve Timing Offset Data Writing
NISSAN	All Mode	Up to 2018	Engine	Special Function	Valve Timing Offset Data Clear
NISSAN	All Mode	Up to 2018	Engine	Special Function	STRT OPRTN CNTR CLEAR
NISSAN	All Mode	Up to 2018	Engine	Special Function	CML B/DCHRG CRNT CLEAR
NISSAN	All Mode	Up to 2018	Engine	Special Function	SC MAGNETIC CLUTCH ENGAGE COUNT CLEAR
NISSAN	All Mode	Up to 2018	Engine	Special Function	Fuel Pressure Release
NISSAN	All Mode	Up to 2018	Engine	Special Function	EVAP System Close
NISSAN	All Mode	Up to 2018	Engine	Special Function	CLSD THL POS LEARN
NISSAN	All Mode	Up to 2018	Engine	Special Function	Active Control Engine Mounting A
NISSAN	All Mode	Up to 2018	Engine	Special Function	Active Control Engine Mounting B
NISSAN	All Mode	Up to 2018	Engine	Special Function	G Sensor Calibration
NISSAN	All Mode	Up to 2018	Engine	Special Function	Wastegate Actuator Posi Learn Value Clear
NISSAN	All Mode	Up to 2018	Engine	Special Function	Vin Registration
NISSAN	All Mode	Up to 2018	Engine	Special Function	SUB-STARTER & GENERATOR OPER COUNT CLEAR
NISSAN	All Mode	Up to 2018	Engine	Special Function	Cumulative Sub-Battry Dischg Current Clear
NISSAN	All Mode	2015 - 2017	Engine	Read Fault Code	
NISSAN	All Mode	2015 - 2017	Engine	Clear Fault Code	

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
NISSAN	All Mode	2015 - 2017	Engine	Read Data Stream	
NISSAN	All Mode	2015 - 2017	Engine	Module Information	
NISSAN	All Mode	2015 - 2017	Engine	Actuation Test	INJECTOR CYLINDER 1
NISSAN	All Mode	2015 - 2017	Engine	Actuation Test	INJECTOR CYLINDER 2
NISSAN	All Mode	2015 - 2017	Engine	Actuation Test	INJECTOR CYLINDER 3
NISSAN	All Mode	2015 - 2017	Engine	Actuation Test	INJECTOR CYLINDER 4
NISSAN	All Mode	2015 - 2017	Engine	Actuation Test	Fuel Pump Relay
NISSAN	All Mode	2015 - 2017	Engine	Actuation Test	CANISTER BLEED SOLENOID VALVE
NISSAN	All Mode	2015 - 2017	Engine	Actuation Test	IGNITION CYLINDER 1
NISSAN	All Mode	2015 - 2017	Engine	Actuation Test	IGNITION CYLINDER 2
NISSAN	All Mode	2015 - 2017	Engine	Actuation Test	IGNITION CYLINDER 3
NISSAN	All Mode	2015 - 2017	Engine	Actuation Test	IGNITION CYLINDER 4
NISSAN	All Mode	2015 - 2017	Engine	Actuation Test	ADDITIONAL PETROL CIRCUIT SOLENOID VALVE
NISSAN	All Mode	2015 - 2017	Engine	Actuation Test	Additional Fuel Pump Relay
NISSAN	All Mode	2015 - 2017	Engine	Actuation Test	CAMSHAFT DEPHASER:SOLENOID VALVE SLIDE MOVEMENT
NISSAN	All Mode	2015 - 2017	Engine	Actuation Test	EXHAUST CAMSHAFT DEPHASER SOLENOID VALVE
NISSAN	All Mode	2015 - 2017	Engine	Actuation Test	DRAIN CUT VALVE
NISSAN	All Mode	2015 - 2017	Engine	Actuation Test	Fan Unit Low Speed RLY
NISSAN	All Mode	2015 - 2017	Engine	Actuation Test	Fan Unit High Speed RLY
NISSAN	All Mode	2015 - 2017	Engine	Actuation Test	Fuel Pump
NISSAN	All Mode	2015 - 2017	Engine	Actuation Test	Air Conditioning Compressor Relay Control
NISSAN	All Mode	2015 - 2017	Engine	Special Function	Vin Registration
NISSAN	All Mode	2015 - 2017	Engine	Special Function	Fuel Sply Prev
NISSAN	All Mode	2015 - 2017	Engine	Special Function	Start OBD test: Catalytic converter
NISSAN	All Mode	2015 - 2017	Engine	Special Function	Start OBD test: O2 sensor
NISSAN	All Mode	2015 - 2017	Engine	Special Function	Save Computer Data
NISSAN	All Mode	2015 - 2017	Engine	Special Function	Write Saved Data
NISSAN	All Mode	2015 - 2017	Engine	Special Function	Engine Adaptives
NISSAN	All Mode	2015 - 2017	Engine	Special Function	Programming Throttle Limits
NISSAN	All Mode	2015 - 2017	Engine	Special Function	Richness Regulation Programming
NISSAN	All Mode	2015 - 2017	Engine	Special Function	Flywhl TGT PG
NISSAN	All Mode	2015 - 2017	Engine	Special Function	Injector Adaptives
NISSAN	All Mode	2015 - 2017	Engine	Special Function	Prpr Rich Sen Prog
NISSAN	All Mode	2015 - 2017	Engine	Special Function	Camshaft Sensor Programming
NISSAN	All Mode	2015 - 2017	Engine	Special Function	CC/SL Prgrm
NISSAN	All Mode	2015 - 2017	Engine	Special Function	Alcohol level prog.
NISSAN	All Mode	2015 - 2017	Engine	Special Function	Flywheel Target Programming (R106)
NISSAN	All Mode	2015 - 2017	Engine	Special Function	Flywheel Target Programming (R105)
NISSAN	All Mode	2015 - 2017	Engine	Special Function	Flywheel Target Programming (R103)
NISSAN	All Mode	2015 - 2017	Engine	Special Function	Flywheel Target Programming (R102)
NISSAN	All Mode	2015 - 2017	Engine	Special Function	Flywheel Target Programming (R065)
NISSAN	All Mode	2015 - 2017	Engine	Special Function	Flywheel Target Programming (R061)
NISSAN	All Mode	2015 - 2017	Engine	Special Function	Flywheel Target Programming (R104)
NISSAN	All Mode	2015 - 2017	Engine	Read Fault Code	
NISSAN	All Mode	2015 - 2017	Engine	Clear Fault Code	
NISSAN	All Mode	2015 - 2017	Engine	Read Data Stream	
NISSAN	All Mode	2015 - 2017	Engine	Module Information	
NISSAN	All Mode	2015 - 2017	Engine	Actuation Test	INJECTOR CYLINDER 1
NISSAN	All Mode	2015 - 2017	Engine	Actuation Test	INJECTOR CYLINDER 2
NISSAN	All Mode	2015 - 2017	Engine	Actuation Test	INJECTOR CYLINDER 3
NISSAN	All Mode	2015 - 2017	Engine	Actuation Test	INJECTOR CYLINDER 4
NISSAN	All Mode	2015 - 2017	Engine	Actuation Test	Fuel Pump Relay
NISSAN	All Mode	2015 - 2017	Engine	Actuation Test	CANISTER BLEED SOLENOID VALVE
NISSAN	All Mode	2015 - 2017	Engine	Actuation Test	IGNITION CYLINDER 1
NISSAN	All Mode	2015 - 2017	Engine	Actuation Test	IGNITION CYLINDER 2
NISSAN	All Mode	2015 - 2017	Engine	Actuation Test	IGNITION CYLINDER 3
NISSAN	All Mode	2015 - 2017	Engine	Actuation Test	IGNITION CYLINDER 4
NISSAN	All Mode	2015 - 2017	Engine	Actuation Test	CAMSHAFT DEPHASER:SOLENOID VALVE SLIDE MOVEMENT
NISSAN	All Mode	2015 - 2017	Engine	Actuation Test	Fan Unit Low Speed RLY
NISSAN	All Mode	2015 - 2017	Engine	Actuation Test	Fan Unit High Speed RLY
NISSAN	All Mode	2015 - 2017	Engine	Actuation Test	ADDITIONAL PETROL CIRCUIT SOLENOID VALVE
NISSAN	All Mode	2015 - 2017	Engine	Actuation Test	Additional Fuel Pump Relay



**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
NISSAN	All Mode	2015 - 2017	Engine	Actuation Test	Air Conditioning Compressor Relay Control
NISSAN	All Mode	2015 - 2017	Engine	Actuation Test	Fuel Pump
NISSAN	All Mode	2015 - 2017	Engine	Actuation Test	ELECTRIC WATER PUMP
NISSAN	All Mode	2015 - 2017	Engine	Actuation Test	STARTER RELAY
NISSAN	All Mode	2015 - 2017	Engine	Special Function	Stop And Start Function
NISSAN	All Mode	2015 - 2017	Engine	Special Function	Number Of Starting Cycles (V343)
NISSAN	All Mode	2015 - 2017	Engine	Special Function	Vin Registration
NISSAN	All Mode	2015 - 2017	Engine	Special Function	Fuel Sply Prev
NISSAN	All Mode	2015 - 2017	Engine	Special Function	Start OBD test: Catalytic converter
NISSAN	All Mode	2015 - 2017	Engine	Special Function	Start OBD test: O2 sensor
NISSAN	All Mode	2015 - 2017	Engine	Special Function	Save Computer Data
NISSAN	All Mode	2015 - 2017	Engine	Special Function	Write Saved Data
NISSAN	All Mode	2015 - 2017	Engine	Special Function	Engine Adaptives
NISSAN	All Mode	2015 - 2017	Engine	Special Function	Programming Throttle Limits
NISSAN	All Mode	2015 - 2017	Engine	Special Function	Richness Regulation Programming
NISSAN	All Mode	2015 - 2017	Engine	Special Function	Flywhl TGT PG
NISSAN	All Mode	2015 - 2017	Engine	Special Function	Injector Adaptives
NISSAN	All Mode	2015 - 2017	Engine	Special Function	Prpr Rich Sen Prog
NISSAN	All Mode	2015 - 2017	Engine	Special Function	Camshaft Sensor Programming
NISSAN	All Mode	2015 - 2017	Engine	Special Function	CC/SL Prgrm
NISSAN	All Mode	2015 - 2017	Engine	Special Function	Alcohol level prog.
NISSAN	All Mode	2015 - 2017	Engine	Special Function	Flywheel Target Programming (R105)
NISSAN	All Mode	2015 - 2017	Engine	Special Function	Flywheel Target Programming (R103)
NISSAN	All Mode	2015 - 2017	Engine	Special Function	Flywheel Target Programming (R102)
NISSAN	All Mode	2015 - 2017	Engine	Special Function	Flywheel Target Programming (R065)
NISSAN	All Mode	2015 - 2017	Engine	Special Function	Flywheel Target Programming (R104)
NISSAN	All Mode	2015 - 2017	Engine	Special Function	Number Of Starting Cycles
NISSAN	All Mode	2015 - 2017	Engine	Special Function	Regulation Waste Gate
NISSAN	All Mode	2015 - 2017	Engine	Special Function	Alternator Setpoint Voltage
NISSAN	All Mode	2015 - 2017	Engine	Special Function	High Pressure Pump Counter
NISSAN	All Mode	2015 - 2017	Engine	Special Function	Interval Of Oil Change (OCS) Oxidation
NISSAN	All Mode	2015 - 2017	Engine	Special Function	Speed Limiter
NISSAN	All Mode	2015 - 2018	Engine	Read Fault Code	
NISSAN	All Mode	2015 - 2018	Engine	Clear Fault Code	
NISSAN	All Mode	2015 - 2018	Engine	Read Data Stream	
NISSAN	All Mode	2015 - 2018	Engine	Module Information	
NISSAN	All Mode	2015 - 2018	Engine	Actuation Test	Check Boost Pressure Positioner
NISSAN	All Mode	2015 - 2018	Engine	Actuation Test	Check Rail Pressure Sensor
NISSAN	All Mode	2015 - 2018	Engine	Actuation Test	Check Intake Port Shutoff Actuator Motor
NISSAN	All Mode	2015 - 2018	Engine	Actuation Test	EGR Valve Jams
NISSAN	All Mode	2015 - 2018	Engine	Actuation Test	Injector shutoff(CYL 1)
NISSAN	All Mode	2015 - 2018	Engine	Actuation Test	Injector shutoff(CYL 2)
NISSAN	All Mode	2015 - 2018	Engine	Actuation Test	Injector shutoff(CYL 3)
NISSAN	All Mode	2015 - 2018	Engine	Actuation Test	Injector shutoff(CYL 4)
NISSAN	All Mode	2015 - 2018	Engine	Actuation Test	Fuel Pump
NISSAN	All Mode	2015 - 2018	Engine	Actuation Test	Ck Eng And Ac With Intgrted Cont Fan Motor
NISSAN	All Mode	2015 - 2018	Engine	Actuation Test	Check Glow Plugs
NISSAN	All Mode	2015 - 2018	Engine	Actuation Test	Check Engine Oil Pump Valve
NISSAN	All Mode	2015 - 2018	Engine	Actuation Test	Check Oil Spray Nozzles Shutoff Valve
NISSAN	All Mode	2015 - 2018	Engine	Actuation Test	Check Coolant Pump Switchover Valve
NISSAN	All Mode	2015 - 2018	Engine	Actuation Test	Check EGR Cooler Bypss Sw Over Valve
NISSAN	All Mode	2015 - 2018	Engine	Actuation Test	Check O2 Upstream Of Catalytic Converter
NISSAN	All Mode	2015 - 2018	Engine	Actuation Test	Check EGR Actuator
NISSAN	All Mode	2015 - 2018	Engine	Actuation Test	Coolant thermostat heating element
NISSAN	All Mode	2015 - 2018	Engine	Actuation Test	Check Fuel HI Press Circ For Leaktightness
NISSAN	All Mode	2015 - 2018	Engine	Actuation Test	EGR actuator (auto evaluation)
NISSAN	All Mode	2015 - 2018	Engine	Actuation Test	Causes of engine stop prevention

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
NISSAN	All Mode	2015 - 2018	Engine	Actuation Test	Causes of engine stop prevention combustion engine
NISSAN	All Mode	2015 - 2018	Engine	Actuation Test	Malfunction status of stop/start system
NISSAN	All Mode	2015 - 2018	Engine	Actuation Test	History of regeneration of DPF
NISSAN	All Mode	2015 - 2018	Engine	Actuation Test	Preconditions for automatic engine stop
NISSAN	All Mode	2015 - 2018	Engine	Actuation Test	Requirements for automatic engine start
NISSAN	All Mode	2015 - 2018	Engine	Actuation Test	High pressure fuel pump (pressure regulation)
NISSAN	All Mode	2015 - 2018	Engine	Actuation Test	Leak test of charge air system
NISSAN	All Mode	2015 - 2018	Engine	Special Function	Enabling of engine start after crash event
NISSAN	All Mode	2015 - 2018	Engine	Special Function	Bleeding Of High Pressure Fuel Circuit
NISSAN	All Mode	2015 - 2018	Engine	Special Function	Teach In Boost Pressure Positioner
NISSAN	All Mode	2015 - 2018	Engine	Special Function	Reset Of Learned Values Of Cmsft Hall Sen
NISSAN	All Mode	2015 - 2018	Engine	Special Function	Reset Of Contamination Level Of Air Filter
NISSAN	All Mode	2015 - 2018	Engine	Special Function	Teach In Of DPF After Replace Of CDI C/U
NISSAN	All Mode	2015 - 2018	Engine	Special Function	Replace Diesel Particulate Filter
NISSAN	All Mode	2015 - 2018	Engine	Special Function	Teach In Of Throttle Valve Stop
NISSAN	All Mode	2015 - 2018	Engine	Special Function	Fuel Injector
NISSAN	All Mode	2015 - 2018	Engine	Read Fault Code	
NISSAN	All Mode	2015 - 2018	Engine	Clear Fault Code	
NISSAN	All Mode	2015 - 2018	Engine	Read Data Stream	
NISSAN	All Mode	2015 - 2018	Engine	Module Information	
NISSAN	All Mode	2015 - 2018	Engine	Actuation Test	Check fuel tank pressure sensor
NISSAN	All Mode	2015 - 2018	Engine	Actuation Test	Purging Switchover Valve
NISSAN	All Mode	2015 - 2018	Engine	Actuation Test	Check Deceleration Air Switchover Valve
NISSAN	All Mode	2015 - 2018	Engine	Actuation Test	Check Engine Oil Pump Valve
NISSAN	All Mode	2015 - 2018	Engine	Actuation Test	Check cylinder fuel injectors
NISSAN	All Mode	2015 - 2018	Engine	Actuation Test	Check purging pressure control
NISSAN	All Mode	2015 - 2018	Engine	Actuation Test	Check EGR Actuator
NISSAN	All Mode	2015 - 2018	Engine	Actuation Test	Check EGR valve hall sensor
NISSAN	All Mode	2015 - 2018	Engine	Actuation Test	Check Intake Camshaft Solenoid
NISSAN	All Mode	2015 - 2018	Engine	Actuation Test	Check Exhaust Camshaft Solenoid
NISSAN	All Mode	2015 - 2018	Engine	Actuation Test	Engine Diagnosis Indicator Lamp
NISSAN	All Mode	2015 - 2018	Engine	Actuation Test	Rail pressure reduction
NISSAN	All Mode	2015 - 2018	Engine	Actuation Test	Boost pressure control pressure transducer
NISSAN	All Mode	2015 - 2018	Engine	Actuation Test	Partial load operation crankcase ventilation valve
NISSAN	All Mode	2015 - 2018	Engine	Actuation Test	Check activated charcoal canister shutoff valve
NISSAN	All Mode	2015 - 2018	Engine	Actuation Test	Check cylinder fuel injectors for leaks
NISSAN	All Mode	2015 - 2018	Engine	Actuation Test	Check radiator shutters actuator
NISSAN	All Mode	2015 - 2018	Engine	Actuation Test	Quantity control valve
NISSAN	All Mode	2015 - 2018	Engine	Actuation Test	Check Fuel HI Press Circ For Leaktightness
NISSAN	All Mode	2015 - 2018	Engine	Actuation Test	Fuel Pump
NISSAN	All Mode	2015 - 2018	Engine	Special Function	Enabling of engine start after crash event
NISSAN	All Mode	2015 - 2018	Engine	Special Function	Teach In Of Throttle Valve Stop
NISSAN	All Mode	2015 - 2018	Engine	Special Function	Camshaft Reference Adaptation
NISSAN	All Mode	2015 - 2018	Engine	Special Function	Teach In Of Sensor Rotor Adaptation
NISSAN	All Mode	2015 - 2018	Engine	Special Function	Status Of Teach In Processes

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

<b>make</b>	<b>model</b>	<b>year</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
NISSAN	All Mode	2015 - 2018	Engine	Special Function	Resetting Of Adaption Values
NISSAN	All Mode	2015 - 2018	Engine	Special Function	Ethanol Reading Frequency Counter Reset
NISSAN	All Mode	2015 - 2018	Engine	Special Function	Teach In The Ethanol Proportion In The Fuel
NISSAN	All Mode	2015 - 2018	Engine	Special Function	Teach In Of Camshaft Position
NISSAN	All Mode	2015 - 2018	Engine	Read Fault Code	
NISSAN	All Mode	2015 - 2018	Engine	Clear Fault Code	
NISSAN	All Mode	2015 - 2018	Engine	Read Data Stream	
NISSAN	All Mode	2015 - 2018	Engine	Module Information	
NISSAN	All Mode	2015 - 2018	Engine	Actuation Test	Check boost pressure regulator
NISSAN	All Mode	2015 - 2018	Engine	Actuation Test	Check exhaust flap controller
NISSAN	All Mode	2015 - 2018	Engine	Actuation Test	Low pressure EGR temperature sensor
NISSAN	All Mode	2015 - 2018	Engine	Actuation Test	High pressure fuel circuit leak test
NISSAN	All Mode	2015 - 2018	Engine	Actuation Test	Check DPF regeneration heater booster control unit
NISSAN	All Mode	2015 - 2018	Engine	Actuation Test	Rail Pressure
NISSAN	All Mode	2015 - 2018	Engine	Actuation Test	Check Fuel Injectors
NISSAN	All Mode	2015 - 2018	Engine	Special Function	Learned values reset - differential pressure sensor
NISSAN	All Mode	2015 - 2018	Engine	Special Function	Learned values reset - O2 sensor upstream of CAT
NISSAN	All Mode	2015 - 2018	Engine	Special Function	Teach in high pressure EGR actuator
NISSAN	All Mode	2015 - 2018	Engine	Special Function	Learned values reset - rail pressure sensor
NISSAN	All Mode	2015 - 2018	Engine	Special Function	Learned values reset - turbocharger
NISSAN	All Mode	2015 - 2018	Engine	Special Function	Teach in low pressure EGR actuator
NISSAN	All Mode	2015 - 2018	Engine	Special Function	Teach in exhaust flap controller
NISSAN	All Mode	2015 - 2018	Engine	Special Function	Teach in throttle valve actuator
NISSAN	All Mode	2015 - 2018	Engine	Special Function	Learned values reset - fuel system high pressure pump
NISSAN	All Mode	2015 - 2018	Engine	Special Function	Learned values reset - diesel particulate filter
NISSAN	All Mode	2015 - 2018	Engine	Special Function	Check glow output stage
NISSAN	All Mode	2015 - 2018	Engine	Special Function	Activation Of Fuel Pump
NISSAN	All Mode	2015 - 2018	Engine	Special Function	Status Of Teach In Processes
NISSAN	All Mode	2015 - 2018	Engine	Special Function	Injector Learning Value Clear
NISSAN	All Mode	2015 - 2018	Engine	Read Data Stream	
NISSAN	All Mode	2015 - 2018	Engine	Module Information	
NISSAN	All Mode	2015 - 2018	Engine	Actuation Test	Check EGR Cooler Bypss Sw Over Valve
NISSAN	All Mode	2015 - 2018	Engine	Actuation Test	Check Oil Spray Nozzles Shutoff Valve
NISSAN	All Mode	2015 - 2018	Engine	Actuation Test	Check Rail Pressure Sensor
NISSAN	All Mode	2015 - 2018	Engine	Actuation Test	Check Boost Pressure Positioner
NISSAN	All Mode	2015 - 2018	Engine	Actuation Test	Auto Stop Start
NISSAN	All Mode	2015 - 2018	Engine	Special Function	Teach In Boost Pressure Positioner
NISSAN	All Mode	2015 - 2018	Engine	Special Function	Reset Of Contamination Level Of Air Filter
NISSAN	All Mode	2015 - 2018	Engine	Special Function	Activation Of Fuel Pump
NISSAN	All Mode	2015 - 2018	Engine	Special Function	Reset Of Learned Values Of Cmsft Hall Sen
NISSAN	All Mode	2015 - 2018	Engine	Special Function	Teach In Of Intake Port Shutoff
NISSAN	All Mode	2015 - 2018	Engine	Special Function	Vin Registration
NISSAN	All Mode	2015 - 2018	Engine	Special Function	STRT OPRIN CNTR CLEAR
NISSAN	All Mode	2015 - 2018	Engine	Special Function	H/P Fuel Pump Total Starts Counter Clear
NISSAN	All Mode	2015 - 2018	Engine	Special Function	Teach In Of Throttle Valve Stop
NISSAN	All Mode	2015 - 2018	Engine	Special Function	Replace Diesel Particulate Filter
NISSAN	All Mode	2015 - 2018	Engine	Special Function	Injector Injection Quantity Adjustment

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
NISSAN	All Mode	2015 - 2018	Engine	Special Function	OXIDATION CATALYTIC CONVERTER
NISSAN	All Mode	2015 - 2018	Engine	Special Function	Teach In Of DPF After Replace Of CDI C/U
NISSAN	All Mode	2015 - 2018	Engine	Special Function	OPR TIME BASIC DIAG SCR CATALYTIC CONVRTR
NISSAN	All Mode	2015 - 2018	Engine	Special Function	OPE TIME BASIC DIAG TEMP SEN UPSTREAM SCR CAT
NISSAN	All Mode	2015 - 2018	Engine	Special Function	TEACH IN AFTER REPLAC ADBLUE METERING VALVE
NISSAN	All Mode	2016 - 2017	Engine	Read Fault Code	
NISSAN	All Mode	2016 - 2017	Engine	Clear Fault Code	
NISSAN	All Mode	2016 - 2017	Engine	Read Data Stream	
NISSAN	All Mode	2016 - 2017	Engine	Module Information	
NISSAN	All Mode	2016 - 2017	Engine	Actuation Test	DPF Regeneration
NISSAN	All Mode	2016 - 2017	Engine	Actuation Test	DEF System Leak Test
NISSAN	All Mode	2016 - 2017	Engine	Actuation Test	DEF Dosing Unit Override Test
NISSAN	All Mode	2016 - 2017	Engine	Actuation Test	Fuel system leakage test
NISSAN	All Mode	2016 - 2017	Engine	Actuation Test	DEF Line Heater Test
NISSAN	All Mode	2016 - 2017	Engine	Actuation Test	Def tank heater test
NISSAN	All Mode	2016 - 2017	Engine	Actuation Test	RTCV Hysteresis Test
NISSAN	All Mode	2016 - 2017	Engine	Actuation Test	Fuel Supply Pump Override Test
NISSAN	All Mode	2016 - 2017	Engine	Actuation Test	Cylinder cutout test
NISSAN	All Mode	2016 - 2017	Engine	Actuation Test	Electric Fan Override Test
NISSAN	All Mode	2016 - 2017	Engine	Actuation Test	HPCR Fuel Act Override
NISSAN	All Mode	2016 - 2017	Engine	Actuation Test	CBV position override
NISSAN	All Mode	2016 - 2017	Engine	Special Function	Reset fuel consumption short term log
NISSAN	All Mode	2016 - 2017	Engine	Special Function	AFT maintenance
NISSAN	All Mode	2016 - 2017	Engine	Special Function	Reset fuel and timing learn tables
NISSAN	All Mode	2016 - 2017	Engine	Special Function	Enter Injector Codes
NISSAN	All Mode	2016 - 2017	Engine	Special Function	Write Saved Data
NISSAN	All Mode	2016 - 2017	Engine	Special Function	Save Computer Data
NISSAN	All Mode	2016 - 2017	Engine	Special Function	RTCV actuator calibrate
NISSAN	All Mode	2016 - 2017	Engine	Special Function	Engine serial number
NISSAN	All Mode	2016 - 2017	Engine	Special Function	Vin Registration
NISSAN	All Mode	2015 - 2017	Engine	Read Fault Code	
NISSAN	All Mode	2015 - 2017	Engine	Clear Fault Code	
NISSAN	All Mode	2015 - 2017	Engine	Read Data Stream	
NISSAN	All Mode	2015 - 2017	Engine	Module Information	
NISSAN	All Mode	2015 - 2017	Engine	Actuation Test	TURBOCHARGING SOLENOID VALVE
NISSAN	All Mode	2015 - 2017	Engine	Actuation Test	HIGH PRESSURE CIRCUIT LEAK TEST
NISSAN	All Mode	2015 - 2017	Engine	Actuation Test	EGR VALVE
NISSAN	All Mode	2015 - 2017	Engine	Actuation Test	PREHEATER RELAY
NISSAN	All Mode	2015 - 2017	Engine	Actuation Test	INJECTOR CYLINDER 1
NISSAN	All Mode	2015 - 2017	Engine	Actuation Test	INJECTOR CYLINDER 2
NISSAN	All Mode	2015 - 2017	Engine	Actuation Test	INJECTOR CYLINDER 3
NISSAN	All Mode	2015 - 2017	Engine	Actuation Test	INJECTOR CYLINDER 4
NISSAN	All Mode	2015 - 2017	Engine	Actuation Test	Air Conditioning Compressor Relay Control
NISSAN	All Mode	2015 - 2017	Engine	Actuation Test	Fan Unit Low Speed RLY
NISSAN	All Mode	2015 - 2017	Engine	Actuation Test	Fan Unit High Speed RLY
NISSAN	All Mode	2015 - 2017	Engine	Special Function	Fuel Sply Prev
NISSAN	All Mode	2015 - 2017	Engine	Special Function	Vin Registration
NISSAN	All Mode	2015 - 2017	Engine	Special Function	Rail Pressure Sensor Adaptives
NISSAN	All Mode	2015 - 2017	Engine	Special Function	Pressure Regulation Adaptives
NISSAN	All Mode	2015 - 2017	Engine	Special Function	Egr Valve Programming
NISSAN	All Mode	2015 - 2017	Engine	Special Function	Fuel Flow Regulator
NISSAN	All Mode	2015 - 2017	Engine	Special Function	Engine Adaptives
NISSAN	All Mode	2015 - 2017	Engine	Special Function	Camshaft Sensor Programming
NISSAN	All Mode	2015 - 2017	Engine	Special Function	Flywhl TGT PG
NISSAN	All Mode	2015 - 2017	Engine	Special Function	CC/SL Prgrm
NISSAN	All Mode	2015 - 2017	Engine	Special Function	Injector Adaptives No.1
NISSAN	All Mode	2015 - 2017	Engine	Special Function	Injector Adaptives No.2
NISSAN	All Mode	2015 - 2017	Engine	Special Function	Injector Adaptives No.3
NISSAN	All Mode	2015 - 2017	Engine	Special Function	Injector Adaptives No.4
NISSAN	All Mode	2015 - 2017	Engine	Special Function	Write Saved Data
NISSAN	All Mode	2015 - 2017	Engine	Special Function	Save Computer Data
NISSAN	All Mode	2015 - 2017	Engine	Special Function	Enter Injector Codes
NISSAN	All Mode	2015 - 2017	Engine	Special Function	Interval Of Oil Change (OCS) Oxidation
NISSAN	All Mode	2015 - 2017	Engine	Special Function	Speed Limiter
NISSAN	All Mode	2015 - 2017	Engine	Read Fault Code	

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
NISSAN	All Mode	2015 - 2017	Engine	Clear Fault Code	
NISSAN	All Mode	2015 - 2017	Engine	Read Data Stream	
NISSAN	All Mode	2015 - 2017	Engine	Module Information	
NISSAN	All Mode	2015 - 2017	Engine	Actuation Test	TURBOCHARGING SOLENOID VALVE
NISSAN	All Mode	2015 - 2017	Engine	Actuation Test	HIGH PRESSURE CIRCUIT LEAK TEST
NISSAN	All Mode	2015 - 2017	Engine	Actuation Test	AIR INLET FLAP
NISSAN	All Mode	2015 - 2017	Engine	Actuation Test	EGR BYPASS
NISSAN	All Mode	2015 - 2017	Engine	Actuation Test	PREHEATER RELAY
NISSAN	All Mode	2015 - 2017	Engine	Actuation Test	EGR VALVE
NISSAN	All Mode	2015 - 2017	Engine	Actuation Test	Air Conditioning Compressor Relay Control
NISSAN	All Mode	2015 - 2017	Engine	Actuation Test	Fan Unit Low Speed RLY
NISSAN	All Mode	2015 - 2017	Engine	Actuation Test	Fan Unit High Speed RLY
NISSAN	All Mode	2015 - 2017	Engine	Special Function	Fuel Sply Prev
NISSAN	All Mode	2015 - 2017	Engine	Special Function	Vin Registration
NISSAN	All Mode	2015 - 2017	Engine	Special Function	Air Damper Valve Programming
NISSAN	All Mode	2015 - 2017	Engine	Special Function	Adaptives On Air Intake Flap Malfunction
NISSAN	All Mode	2015 - 2017	Engine	Special Function	DPF Relative Pressure Sensor
NISSAN	All Mode	2015 - 2017	Engine	Special Function	Egr Valve Programming
NISSAN	All Mode	2015 - 2017	Engine	Special Function	Pressure Regulation Adaptives
NISSAN	All Mode	2015 - 2017	Engine	Special Function	Engine Adaptives
NISSAN	All Mode	2015 - 2017	Engine	Special Function	CC/SL Prgrm
NISSAN	All Mode	2015 - 2017	Engine	Special Function	EGR Bypass Programming
NISSAN	All Mode	2015 - 2017	Engine	Special Function	Enter Injector Codes
NISSAN	All Mode	2015 - 2017	Engine	Special Function	Write Saved Data
NISSAN	All Mode	2015 - 2017	Engine	Special Function	Save Computer Data
NISSAN	All Mode	2015 - 2017	Engine	Special Function	Injection Prohibition
NISSAN	All Mode	2015 - 2017	Engine	Special Function	Interval Of Oil Change (OCS) Oxidation
NISSAN	All Mode	2015 - 2017	Engine	Special Function	OIL Change Interval (Ocs): Dilution
NISSAN	NV400	2014	Engine	Read Fault Code	
NISSAN	NV400	2014	Engine	Clear Fault Code	
NISSAN	NV400	2014	Engine	Read Data Stream	
NISSAN	NV400	2014	Engine	Module Information	
NISSAN	NV400	2014	Engine	Actuation Test	PREHEATER RELAY
NISSAN	NV400	2014	Engine	Actuation Test	EGR VALVE
NISSAN	NV400	2014	Engine	Actuation Test	AIR INLET FLAP
NISSAN	NV400	2014	Engine	Actuation Test	TURBOCHARGING SOLENOID VALVE
NISSAN	NV400	2014	Engine	Actuation Test	THERMOPLUNGER RELAY No.1
NISSAN	NV400	2014	Engine	Actuation Test	THERMOPLUNGER RELAY No.2
NISSAN	NV400	2014	Engine	Actuation Test	THERMO NO.3 RELAY
NISSAN	NV400	2014	Engine	Actuation Test	Fuel Pump
NISSAN	NV400	2014	Engine	Actuation Test	PUMP PRESSURE REGULATOR
NISSAN	NV400	2014	Engine	Actuation Test	HIGH PRESSURE CIRCUIT LEAK TEST
NISSAN	NV400	2014	Engine	Actuation Test	STARTER RELAY
NISSAN	NV400	2014	Engine	Actuation Test	Starter Relay Command
NISSAN	NV400	2014	Engine	Actuation Test	FUEL HEATER
NISSAN	NV400	2014	Engine	Actuation Test	ELECTRIC WATER PUMP
NISSAN	NV400	2014	Engine	Actuation Test	FIRST EGR COOLING PUMP
NISSAN	NV400	2014	Engine	Actuation Test	SECOND EGR COOLING PUMP
NISSAN	NV400	2014	Engine	Actuation Test	COOLANT CIRC SWITCHING S/V
NISSAN	NV400	2014	Engine	Special Function	STARTING AUTHORIZATION
NISSAN	NV400	2014	Engine	Special Function	Number Of Starting Cycles (V343)
NISSAN	NV400	2014	Engine	Special Function	High Pressure Pump Counter (V344)
NISSAN	NV400	2014	Engine	Special Function	Fuel Sply Prev
NISSAN	NV400	2014	Engine	Special Function	Number Of Starting 1
NISSAN	NV400	2014	Engine	Special Function	Number Of Starting 2
NISSAN	NV400	2014	Engine	Special Function	Number Of Starting 3
NISSAN	NV400	2014	Engine	Special Function	Number Of Starting 4
NISSAN	NV400	2014	Engine	Special Function	Vin Registration
NISSAN	NV400	2014	Engine	Special Function	Air Flowmeter Programming
NISSAN	NV400	2014	Engine	Special Function	Injection Pump Adaptatives (R077)
NISSAN	NV400	2014	Engine	Special Function	Fuel Pump Programming
NISSAN	NV400	2014	Engine	Special Function	Egr Valve Programming
NISSAN	NV400	2014	Engine	Special Function	Air Damper Valve Programming
NISSAN	NV400	2014	Engine	Special Function	EGR Adaptives
NISSAN	NV400	2014	Engine	Special Function	Engine Adaptives

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
NISSAN	NV400	2014	Engine	Special Function	Adaptives On Air Intake Flap Malfunction
NISSAN	NV400	2014	Engine	Special Function	Stop And Start Function
NISSAN	NV400	2014	Engine	Special Function	P/FLT DIFF PRS SEN
NISSAN	NV400	2014	Engine	Special Function	Prpr Rich Sen Prog
NISSAN	NV400	2014	Engine	Special Function	Catalytic Converter
NISSAN	NV400	2014	Engine	Special Function	CC/SL Prgrm
NISSAN	NV400	2014	Engine	Special Function	Write Saved Data
NISSAN	NV400	2014	Engine	Special Function	Save Computer Data
NISSAN	NV400	2014	Engine	Special Function	Enter Injector Codes
NISSAN	NV400	2014	Engine	Special Function	Interval Of Oil Change (OCS) Oxidation
NISSAN	NV400	2014	Engine	Special Function	OIL Change Interval (Ocs): Dilution
NISSAN	NV400	2014	Engine	Special Function	Speed Limiter
NISSAN	redi GO	2016	Engine	Read Fault Code	
NISSAN	redi GO	2016	Engine	Clear Fault Code	
NISSAN	redi GO	2016	Engine	Read Data Stream	
NISSAN	redi GO	2016	Engine	Module Information	
NISSAN	redi GO	2016	Engine	Actuation Test	INJECTOR CYLINDER 1
NISSAN	redi GO	2016	Engine	Actuation Test	INJECTOR CYLINDER 2
NISSAN	redi GO	2016	Engine	Actuation Test	INJECTOR CYLINDER 3
NISSAN	redi GO	2016	Engine	Actuation Test	Fuel Pump
NISSAN	redi GO	2016	Engine	Actuation Test	IGNITION CYLINDER 1
NISSAN	redi GO	2016	Engine	Actuation Test	IGNITION CYLINDER 2
NISSAN	redi GO	2016	Engine	Actuation Test	IGNITION CYLINDER 3
NISSAN	redi GO	2016	Engine	Actuation Test	CANISTER BLEED SOLENOID VALVE
NISSAN	redi GO	2016	Engine	Actuation Test	Air Conditioning Compressor Relay Control
NISSAN	redi GO	2016	Engine	Actuation Test	Fan Unit High Speed RLY
NISSAN	redi GO	2016	Engine	Special Function	Fuel Sply Prev
NISSAN	redi GO	2016	Engine	Special Function	Vin Registration
NISSAN	redi GO	2016	Engine	Special Function	Flywhl TGT PG
NISSAN	redi GO	2016	Engine	Special Function	Richness Regulation Programming
NISSAN	redi GO	2016	Engine	Special Function	EGR Adaptives
NISSAN	redi GO	2016	Engine	Special Function	Programming Throttle Limits
NISSAN	redi GO	2016	Engine	Special Function	Engine Adaptives
NISSAN	redi GO	2016	Engine	Special Function	UPSTREAM O2 SENSOR
NISSAN	redi GO	2016	Engine	Special Function	Start OBD test: Catalytic converter
NISSAN	redi GO	2016	Engine	Special Function	Start OBD test: O2 sensor
NISSAN	redi GO	2016	Engine	Special Function	Save Computer Data
NISSAN	redi GO	2016	Engine	Special Function	Write Saved Data
NISSAN	redi GO	2016	Engine	Special Function	Interval Of Oil Change (OCS) Oxidation
NISSAN	All Mode	2013 - 2018	Engine	Read Fault Code	
NISSAN	All Mode	2013 - 2018	Engine	Clear Fault Code	
NISSAN	All Mode	2013 - 2018	Engine	Read Data Stream	
NISSAN	All Mode	2013 - 2018	Engine	Module Information	
NISSAN	All Mode	2013 - 2018	Engine	Actuation Test	Auto Stop Start
NISSAN	All Mode	2013 - 2018	Engine	Actuation Test	Check Deceleration Air Switchover Valve
NISSAN	All Mode	2013 - 2018	Engine	Actuation Test	Check Engine Oil Pump Valve
NISSAN	All Mode	2013 - 2018	Engine	Actuation Test	Check Intake Camshaft Solenoid
NISSAN	All Mode	2013 - 2018	Engine	Actuation Test	Check Exhaust Camshaft Solenoid
NISSAN	All Mode	2013 - 2018	Engine	Actuation Test	Purging Switchover Valve
NISSAN	All Mode	2013 - 2018	Engine	Actuation Test	Check activated charcoal canister shutoff valve
NISSAN	All Mode	2013 - 2018	Engine	Actuation Test	Partial load operation crankcase ventilation valve
NISSAN	All Mode	2013 - 2018	Engine	Actuation Test	Check fuel tank pressure sensor
NISSAN	All Mode	2013 - 2018	Engine	Actuation Test	Check purging pressure control
NISSAN	All Mode	2013 - 2018	Engine	Actuation Test	Check cylinder fuel injectors
NISSAN	All Mode	2013 - 2018	Engine	Actuation Test	Check cylinder fuel injectors for leaks
NISSAN	All Mode	2013 - 2018	Engine	Actuation Test	Check Fuel HI Press Circ For Leaktightness
NISSAN	All Mode	2013 - 2018	Engine	Special Function	Resetting Of Adaption Values
NISSAN	All Mode	2013 - 2018	Engine	Special Function	Camshaft Reference Adaptation
NISSAN	All Mode	2013 - 2018	Engine	Special Function	Teach In Of Throttle Valve Stop

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
NISSAN	All Mode	2013 - 2018	Engine	Special Function	Teach In Of Camshaft Position
NISSAN	All Mode	2013 - 2018	Engine	Special Function	Injector Injection Quantity Adjustment
NISSAN	All Mode	2013 - 2018	Engine	Special Function	Vin Registration
NISSAN	All Mode	2013 - 2018	Engine	Special Function	STRT OPRTN CNTR CLEAR
NISSAN	All Mode	2013 - 2018	Engine	Special Function	H/P Fuel Pump Total Starts Counter Clear
NISSAN	All Mode	2013 - 2018	Engine	Special Function	Teach In Of Sensor Rotor Adaptation
NISSAN	All Mode	2013 - 2018	Engine	Special Function	Status Of Teach In Processes
NISSAN	ALMERA	2012	Engine	Read Fault Code	
NISSAN	ALMERA	2012	Engine	Clear Fault Code	
NISSAN	ALMERA	2012	Engine	Read Data Stream	
NISSAN	ALMERA	2012	Engine	Module Information	
NISSAN	ALMERA	2012	Engine	Actuation Test	INJECTOR CYLINDER 1
NISSAN	ALMERA	2012	Engine	Actuation Test	INJECTOR CYLINDER 2
NISSAN	ALMERA	2012	Engine	Actuation Test	INJECTOR CYLINDER 3
NISSAN	ALMERA	2012	Engine	Actuation Test	INJECTOR CYLINDER 4
NISSAN	ALMERA	2012	Engine	Actuation Test	Fuel Pump Relay
NISSAN	ALMERA	2012	Engine	Actuation Test	CANISTER BLEED SOLENOID VALVE
NISSAN	ALMERA	2012	Engine	Actuation Test	Fan Unit Low Speed RLY
NISSAN	ALMERA	2012	Engine	Actuation Test	Fan Unit High Speed RLY
NISSAN	ALMERA	2012	Engine	Actuation Test	IGNITION CYLINDER 1
NISSAN	ALMERA	2012	Engine	Actuation Test	IGNITION CYLINDER 2
NISSAN	ALMERA	2012	Engine	Actuation Test	IGNITION CYLINDER 3
NISSAN	ALMERA	2012	Engine	Actuation Test	IGNITION CYLINDER 4
NISSAN	ALMERA	2012	Engine	Actuation Test	Air Conditioning Compressor Relay Control
NISSAN	ALMERA	2012	Engine	Actuation Test	Additional Fuel Pump Relay
NISSAN	ALMERA	2012	Engine	Actuation Test	CAMSHAFT DEPHASER:SOLENOID VALVE SLIDE MOVEMENT
NISSAN	ALMERA	2012	Engine	Actuation Test	EXHAUST CAMSHAFT DEPHASER SOLENOID VALVE
NISSAN	ALMERA	2012	Engine	Actuation Test	Fuel Pump
NISSAN	ALMERA	2012	Engine	Special Function	Fuel Sply Prev
NISSAN	ALMERA	2012	Engine	Special Function	Vin Registration
NISSAN	ALMERA	2012	Engine	Special Function	Engine Adaptives
NISSAN	ALMERA	2012	Engine	Special Function	Programming Throttle Limits
NISSAN	ALMERA	2012	Engine	Special Function	Richness Regulation Programming
NISSAN	ALMERA	2012	Engine	Special Function	Camshaft Sensor Programming
NISSAN	ALMERA	2012	Engine	Special Function	Injector Adaptives
NISSAN	ALMERA	2012	Engine	Special Function	CC/SL Prgrm
NISSAN	ALMERA	2012	Engine	Special Function	Prpr Rich Sen Prog
NISSAN	ALMERA	2012	Engine	Special Function	Alcohol level prog.
NISSAN	ALMERA	2012	Engine	Special Function	Save Computer Data
NISSAN	ALMERA	2012	Engine	Special Function	Write Saved Data
NISSAN	ALMERA	2012	Engine	Special Function	Start OBD test: Catalytic converter
NISSAN	ALMERA	2012	Engine	Special Function	Start OBD test: O2 sensor
NISSAN	NV300	2016	Engine	Read Fault Code	
NISSAN	NV300	2016	Engine	Clear Fault Code	
NISSAN	NV300	2016	Engine	Read Data Stream	
NISSAN	NV300	2016	Engine	Module Information	
NISSAN	NV300	2016	Engine	Special Function	Starting Authorization
NISSAN	NV300	2016	Engine	Special Function	Number Of Starting 1
NISSAN	NV300	2016	Engine	Special Function	Number Of Starting 2
NISSAN	NV300	2016	Engine	Special Function	Number Of Starting 3
NISSAN	NV300	2016	Engine	Special Function	Number Of Starting 4
NISSAN	NV300	2016	Engine	Special Function	High Pressure Fuel Circuit Fault Finding
NISSAN	NV300	2016	Engine	Special Function	High Pressure Fuel Circuit (S032)
NISSAN	NV300	2016	Engine	Special Function	High Pressure Fuel Circuit (S072)
NISSAN	NV300	2016	Engine	Special Function	Cylinder Function Fault Finding
NISSAN	NV300	2016	Engine	Special Function	Save Computer Data
NISSAN	NV300	2016	Engine	Special Function	Write Saved Data
NISSAN	NV300	2016	Engine	Special Function	SAVE COMPUTER DATA
NISSAN	NV300	2016	Engine	Special Function	WRITE SAVED DATA
NISSAN	NV300	2016	Engine	Special Function	Cabin Filter Regeneration
NISSAN	NV300	2016	Engine	Special Function	Cabin Filter Regeneration (S079)
NISSAN	NV300	2016	Engine	Special Function	Cabin Filter Regeneration (S080)

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

<b>make</b>	<b>model</b>	<b>year</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
NISSAN	NV300	2016	Engine	Special Function	Cabin Filter Regeneration (S081)
NISSAN	NV300	2016	Engine	Special Function	Cabin Filter Regeneration (S082)
NISSAN	NV300	2016	Engine	Read Fault Code	
NISSAN	NV300	2016	Engine	Clear Fault Code	
NISSAN	NV300	2016	Engine	Read Data Stream	
NISSAN	NV300	2016	Engine	Module Information	
NISSAN	NV300	2016	Engine	Special Function	Engine Adaptives
NISSAN	NV300	2016	Engine	Special Function	Programmed Values
NISSAN	NV300	2016	Engine	Special Function	Egr Valve Programming
NISSAN	NV300	2016	Engine	Special Function	Adaptives On Air Intake Flap Malfunction
NISSAN	NV300	2016	Engine	Special Function	Air Damper Valve Programming
NISSAN	NV300	2016	Engine	Special Function	CC/SL PRGRM
NISSAN	NV300	2016	Engine	Special Function	Flywhl TGT PG
NISSAN	NV300	2016	Engine	Special Function	Prpr Rich Sen Prog
NISSAN	NV300	2016	Engine	Special Function	Exhaust Flap Low Setting
NISSAN	NV300	2016	Engine	Special Function	Low Pressure EGR Valve Programming
NISSAN	NV300	2016	Engine	Special Function	Swirl Flap Programming
NISSAN	NV300	2016	Engine	Special Function	Fuel Pump Programming
NISSAN	NV300	2016	Engine	Special Function	Air Flowmeter Programming
NISSAN	NV300	2016	Engine	Special Function	P/FLT DIFP PRS SEN
NISSAN	NV300	2016	Engine	Special Function	Swirl Flap
NISSAN	NV300	2016	Engine	Special Function	Injection Pump Adaptatives
NISSAN	NV300	2016	Engine	Special Function	EGR Bypass Programming
NISSAN	NV300	2016	Engine	Special Function	Fuel Sply Prev
NISSAN	NV300	2016	Engine	Special Function	Turbocharger Programming
NISSAN	NV300	2016	Engine	Special Function	Rail Pressure Sensor Adaptives
NISSAN	NV300	2016	Engine	Special Function	Injector Adaptives
NISSAN	NV300	2016	Engine	Special Function	Cabin Filter Regeneration
NISSAN	NV300	2016	Engine	Special Function	Speed Limiter
NISSAN	NV300	2016	Engine	Special Function	Interval Of Oil Change (OCS) Oxidation
NISSAN	NV300	2016	Engine	Special Function	OIL Change Interval (Ocs): Dilution
NISSAN	NV300	2016	Engine	Special Function	Number Of Starting 1
NISSAN	NV300	2016	Engine	Special Function	Number Of Starting 2
NISSAN	NV300	2016	Engine	Special Function	Number Of Starting 3
NISSAN	NV300	2016	Engine	Special Function	Number Of Starting 4
NISSAN	NV300	2016	Engine	Special Function	Cylinder 1 Injector Code
NISSAN	NV300	2016	Engine	Special Function	Cylinder 2 Injector Code
NISSAN	NV300	2016	Engine	Special Function	Cylinder 3 Injector Code
NISSAN	NV300	2016	Engine	Special Function	Cylinder 4 Injector Code
NISSAN	NV300	2016	Engine	Special Function	Vin Registration
NISSAN	NV300	2016	Engine	Special Function	SAVE COMPUTER DATA
NISSAN	NV300	2016	Engine	Special Function	WRITE SAVED DATA
NISSAN	NV300	2016	Engine	Special Function	Save Computer Data
NISSAN	NV300	2016	Engine	Special Function	Write Saved Data
NISSAN	NV300	2016	Engine	Special Function	ADAPTIVES AFTER REPLACING CABIN FILTER
NISSAN	NV300	2016	Engine	Special Function	Adaptives After Regenerating PF
NISSAN	NV300	2016	Engine	Special Function	Fast Idle Speed Modification
NISSAN	NV300	2016	Engine	Special Function	Cylinder Function Fault Finding
NISSAN	NV300	2016	Engine	Special Function	High Pressure Fuel Circuit Fault Finding
NISSAN	NV300	2016	Engine	Special Function	Enter Injector Codes
NISSAN	All Mode	2014 - 2017	Engine	Read Fault Code	
NISSAN	All Mode	2014 - 2017	Engine	Clear Fault Code	
NISSAN	All Mode	2014 - 2017	Engine	Read Data Stream	
NISSAN	All Mode	2014 - 2017	Engine	Module Information	
NISSAN	All Mode	2014 - 2017	Engine	Actuation Test	PREHEATER RELAY
NISSAN	All Mode	2014 - 2017	Engine	Actuation Test	EGR VALVE
NISSAN	All Mode	2014 - 2017	Engine	Actuation Test	AIR INLET FLAP
NISSAN	All Mode	2014 - 2017	Engine	Actuation Test	TURBOCHARGING SOLENOID VALVE
NISSAN	All Mode	2014 - 2017	Engine	Actuation Test	Fuel Pump
NISSAN	All Mode	2014 - 2017	Engine	Actuation Test	PUMP PRESSURE REGULATOR
NISSAN	All Mode	2014 - 2017	Engine	Actuation Test	HIGH PRESSURE CIRCUIT LEAK TEST
NISSAN	All Mode	2014 - 2017	Engine	Actuation Test	STARTER RELAY
NISSAN	All Mode	2014 - 2017	Engine	Actuation Test	Starter Relay Command
NISSAN	All Mode	2014 - 2017	Engine	Actuation Test	FUEL HEATER
NISSAN	All Mode	2014 - 2017	Engine	Actuation Test	ELECTRIC WATER PUMP



**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
NISSAN	All Mode	2014 - 2017	Engine	Actuation Test	FIRST EGR COOLING PUMP
NISSAN	All Mode	2014 - 2017	Engine	Actuation Test	SECOND EGR COOLING PUMP
NISSAN	All Mode	2014 - 2017	Engine	Actuation Test	COOLANT CIRC SWITCHING S/V
NISSAN	All Mode	2014 - 2017	Engine	Actuation Test	Auto Stop Start
NISSAN	All Mode	2014 - 2017	Engine	Special Function	Number Of Starting Cycles (V343)
NISSAN	All Mode	2014 - 2017	Engine	Special Function	High Pressure Pump Counter (V344)
NISSAN	All Mode	2014 - 2017	Engine	Special Function	Fuel Sply Prev
NISSAN	All Mode	2014 - 2017	Engine	Special Function	Number Of Starting 1
NISSAN	All Mode	2014 - 2017	Engine	Special Function	Number Of Starting 2
NISSAN	All Mode	2014 - 2017	Engine	Special Function	Number Of Starting 3
NISSAN	All Mode	2014 - 2017	Engine	Special Function	Number Of Starting 4
NISSAN	All Mode	2014 - 2017	Engine	Special Function	Vin Registration
NISSAN	All Mode	2014 - 2017	Engine	Special Function	Air Flowmeter Programming
NISSAN	All Mode	2014 - 2017	Engine	Special Function	Injection Pump Adaptatives (R077)
NISSAN	All Mode	2014 - 2017	Engine	Special Function	Fuel Pump Programming
NISSAN	All Mode	2014 - 2017	Engine	Special Function	Egr Valve Programming
NISSAN	All Mode	2014 - 2017	Engine	Special Function	EGR Adaptives
NISSAN	All Mode	2014 - 2017	Engine	Special Function	Engine Adaptives
NISSAN	All Mode	2014 - 2017	Engine	Special Function	Adaptives On Air Intake Flap Malfunction
NISSAN	All Mode	2014 - 2017	Engine	Special Function	Stop And Start Function
NISSAN	All Mode	2014 - 2017	Engine	Special Function	P/FLT DIPP PRS SEN
NISSAN	All Mode	2014 - 2017	Engine	Special Function	Prpr Rich Sen Prog
NISSAN	All Mode	2014 - 2017	Engine	Special Function	Catalytic Converter
NISSAN	All Mode	2014 - 2017	Engine	Special Function	CC/SL Prgrm
NISSAN	All Mode	2014 - 2017	Engine	Special Function	Interval Of Oil Change (OCS) Oxidation
NISSAN	All Mode	2014 - 2017	Engine	Special Function	OIL Change Interval (Ocs): Dilution
NISSAN	All Mode	2014 - 2017	Engine	Special Function	Enter Injector Codes
NISSAN	All Mode	2014 - 2017	Engine	Special Function	Write Saved Data
NISSAN	All Mode	2014 - 2017	Engine	Special Function	Save Computer Data
NISSAN	All Mode	2014 - 2017	Engine	Special Function	Speed Limiter
NISSAN	All Mode	2014 - 2017	Engine	Special Function	Alternator Setpoint Voltage
NISSAN	MICRA	2016	Engine	Read Fault Code	
NISSAN	MICRA	2016	Engine	Clear Fault Code	
NISSAN	MICRA	2016	Engine	Read Data Stream	
NISSAN	MICRA	2016	Engine	Module Information	
NISSAN	MICRA	2016	Engine	Special Function	Engine Adaptives
NISSAN	MICRA	2016	Engine	Special Function	Save Computer Data
NISSAN	MICRA	2016	Engine	Special Function	Write Saved Data
NISSAN	MICRA	2016	Engine	Special Function	Interval Of Oil Change (OCS) Oxidation
NISSAN	MICRA	2016	Engine	Special Function	Oil Change Interval(Ocs):Dilution
NISSAN	MICRA	2016	Engine	Special Function	Fuel Sply Prev
NISSAN	MICRA	2016	Engine	Special Function	Enter Injector Codes
NISSAN	MICRA	2016	Engine	Special Function	Cabin Filter Regeneration
NISSAN	MICRA	2016	Engine	Special Function	Cylinder Function Fault Finding
NISSAN	MICRA	2016	Engine	Special Function	High Pressure Fuel Circuit Fault Finding
NISSAN	MICRA	2016	Engine	Special Function	Cylinder 1 Injector Code
NISSAN	MICRA	2016	Engine	Special Function	Cylinder 2 Injector Code
NISSAN	MICRA	2016	Engine	Special Function	Cylinder 3 Injector Code
NISSAN	MICRA	2016	Engine	Special Function	Cylinder 4 Injector Code
NISSAN	MICRA	2016	Engine	Special Function	Vin Registration
NISSAN	MICRA	2016	Engine	Special Function	Number Of Starting 1
NISSAN	MICRA	2016	Engine	Special Function	Number Of Starting 2
NISSAN	MICRA	2016	Engine	Special Function	Number Of Starting 3
NISSAN	MICRA	2016	Engine	Special Function	Number Of Starting 4
NISSAN	MICRA	2016	Engine	Special Function	Alternator Setpoint Voltage
NISSAN	MICRA	2016	Engine	Special Function	Number Of Starting Cycles
NISSAN	MICRA	2016	Engine	Special Function	High Pressure Pump Counter
NISSAN	MICRA	2016	Engine	Special Function	Adaptives On Air Intake Flap Malfunction
NISSAN	MICRA	2016	Engine	Special Function	Egr Valve Programming
NISSAN	MICRA	2016	Engine	Special Function	Flywhl TGT PG
NISSAN	MICRA	2016	Engine	Special Function	Rail Pressure Sensor Adaptives
NISSAN	MICRA	2016	Engine	Special Function	CC/SL PRGRM
NISSAN	MICRA	2016	Engine	Special Function	Prpr Rich Sen Prog
NISSAN	MICRA	2016	Engine	Special Function	Exhaust Flap Low Setting
NISSAN	MICRA	2016	Engine	Special Function	Low Pressure EGR Valve Programming
NISSAN	MICRA	2016	Engine	Special Function	Fuel Pump Programming
NISSAN	MICRA	2016	Engine	Special Function	Air Flowmeter Programming

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

<b>make</b>	<b>model</b>	<b>year</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
NISSAN	MICRA	2016	Engine	Special Function	P/FLT DIFF PRS SEN
NISSAN	MICRA	2016	Engine	Special Function	Injection Pump Adaptatives
NISSAN	MICRA	2016	Engine	Special Function	EGR Bypass Programming
NISSAN	MICRA	2016	Engine	Read Fault Code	
NISSAN	MICRA	2016	Engine	Clear Fault Code	
NISSAN	MICRA	2016	Engine	Read Data Stream	
NISSAN	MICRA	2016	Engine	Module Information	
NISSAN	MICRA	2016	Engine	Special Function	Engine Adaptives
NISSAN	MICRA	2016	Engine	Special Function	Programming Throttle Limits
NISSAN	MICRA	2016	Engine	Special Function	Camshaft Sensor Programming
NISSAN	MICRA	2016	Engine	Special Function	Flywhl TGT PG
NISSAN	MICRA	2016	Engine	Special Function	Injector Adaptives
NISSAN	MICRA	2016	Engine	Special Function	Waste Gate Regulation
NISSAN	MICRA	2016	Engine	Special Function	Stop And Start Function
NISSAN	MICRA	2016	Engine	Special Function	Air Fuel Ratio Sensor
NISSAN	MICRA	2016	Engine	Special Function	Vin Registration
NISSAN	MICRA	2016	Engine	Special Function	Fuel Sply Prev
NISSAN	MICRA	2016	Engine	Special Function	Alternator Setpoint Voltage
NISSAN	MICRA	2016	Engine	Special Function	Number Of Starting Cycles
NISSAN	MICRA	2016	Engine	Special Function	Save Computer Data
NISSAN	MICRA	2016	Engine	Special Function	Write Saved Data
NISSAN	MICRA	2016	Engine	Special Function	Speed Limiter
NISSAN	ATLAS	2015	Engine	Read Fault Code	
NISSAN	ATLAS	2015	Engine	Clear Fault Code	
NISSAN	ATLAS	2015	Engine	Read Data Stream	
NISSAN	ATLAS	2015	Engine	Module Information	
NISSAN	MICRA	2016	Engine	Read Fault Code	
NISSAN	MICRA	2016	Engine	Clear Fault Code	
NISSAN	MICRA	2016	Engine	Read Data Stream	
NISSAN	MICRA	2016	Engine	Module Information	
NISSAN	All Mode	2012 - 2018	Engine	Read Fault Code	
NISSAN	All Mode	2012 - 2018	Engine	Clear Fault Code	
NISSAN	All Mode	2012 - 2018	Engine	Read Data Stream	
NISSAN	All Mode	2012 - 2018	Engine	Module Information	
NISSAN	All Mode	Up to 2017	Engine	Read Fault Code	
NISSAN	All Mode	Up to 2017	Engine	Clear Fault Code	
NISSAN	All Mode	Up to 2017	Engine	Read Data Stream	
NISSAN	All Mode	Up to 2017	Engine	Module Information	
NISSAN	All Mode	Up to 2017	Engine	Special Function	TP SW/TP SEN IDLE POS1 ADJ
NISSAN	All Mode	Up to 2017	Engine	Special Function	TP SW/TP SEN IDLE POS1 ADJ
NISSAN	All Mode	Up to 2017	Engine	Special Function	IGNITION TIMING ADJ
NISSAN	All Mode	Up to 2017	Engine	Special Function	FUEL PRESSURE RELEASE
NISSAN	All Mode	Up to 2017	Engine	Special Function	CHECK FUEL LINES
NISSAN	All Mode	Up to 2017	Engine	Special Function	IDLE AIR VOL LEARN
NISSAN	All Mode	Up to 2017	Engine	Special Function	SELF-LEARNING CONT
NISSAN	All Mode	Up to 2017	Engine	Special Function	
NISSAN	All Mode	Up to 2017	Engine	Read Fault Code	
NISSAN	All Mode	Up to 2017	Engine	Clear Fault Code	
NISSAN	All Mode	Up to 2017	Engine	Read Data Stream	
NISSAN	All Mode	Up to 2017	Engine	Module Information	
NISSAN	All Mode	Up to 2017	Engine	Special Function	
NISSAN	PRIMASTAR	2009	Engine	Read Fault Code	
NISSAN	PRIMASTAR	2009	Engine	Clear Fault Code	
NISSAN	PRIMASTAR	2009	Engine	Read Data Stream	
NISSAN	PRIMASTAR	2009	Engine	Module Information	
NISSAN	PRIMASTAR	2009	Engine	Special Function	Vin Registration
NISSAN	PRIMASTAR	2009	Engine	Special Function	Program Reinitialize
NISSAN	PRIMASTAR	2009	Engine	Special Function	Decrement Idle Speed
NISSAN	PRIMASTAR	2009	Engine	Special Function	Increment Idle Speed
NISSAN	PRIMASTAR	2009	Engine	Read Fault Code	
NISSAN	PRIMASTAR	2009	Engine	Clear Fault Code	
NISSAN	PRIMASTAR	2009	Engine	Read Data Stream	
NISSAN	PRIMASTAR	2009	Engine	Module Information	
NISSAN	PRIMASTAR	2009	Engine	Special Function	Vin Registration
NISSAN	PRIMASTAR	2009	Engine	Special Function	Egr Valve Programming
NISSAN	PRIMASTAR	2009	Engine	Special Function	Decrement Idle Speed
NISSAN	PRIMASTAR	2009	Engine	Special Function	Increment Idle Speed
NISSAN	PRIMASTAR	2009	Engine	Special Function	Saving Data For Replc CPU
NISSAN	PRIMASTAR	2009	Engine	Special Function	Writing Data For Replc CPU
NISSAN	All Mode	2006 - 2016	Engine	Read Fault Code	
NISSAN	All Mode	2006 - 2016	Engine	Clear Fault Code	
NISSAN	All Mode	2006 - 2016	Engine	Read Data Stream	
NISSAN	All Mode	2006 - 2016	Engine	Module Information	
NISSAN	All Mode	Up to 2011	Engine	Read Fault Code	
NISSAN	All Mode	Up to 2011	Engine	Clear Fault Code	
NISSAN	All Mode	Up to 2011	Engine	Read Data Stream	
NISSAN	All Mode	Up to 2011	Engine	Module Information	
NISSAN	All Mode	Up to 2011	Engine	Actuation Test	THERMO NO.3 RELAY
NISSAN	All Mode	Up to 2011	Engine	Actuation Test	FAN UNIT S SPD RLY
NISSAN	All Mode	Up to 2011	Engine	Actuation Test	FAN UNIT H SPD RLY

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

<b>make</b>	<b>model</b>	<b>year</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
NISSAN	All Mode	Up to 2011	Engine	Actuation Test	OBD LIGHT
NISSAN	All Mode	Up to 2011	Engine	Actuation Test	EGR SOLENOID VALVE
NISSAN	All Mode	Up to 2011	Engine	Actuation Test	PRHT RLY GROUP N-1
NISSAN	All Mode	Up to 2011	Engine	Actuation Test	PREHEATER LIGHT
NISSAN	All Mode	Up to 2011	Engine	Actuation Test	OVERHEATING W/L
NISSAN	All Mode	Up to 2011	Engine	Actuation Test	THERMOPLUNGER RLY1
NISSAN	All Mode	Up to 2011	Engine	Actuation Test	THERMOPLUNGER RLY2
NISSAN	All Mode	Up to 2011	Engine	Actuation Test	HIGH PRESSURE PUMP
NISSAN	All Mode	Up to 2011	Engine	Actuation Test	A/C COMPRESSOR
NISSAN	All Mode	Up to 2011	Engine	Actuation Test	INJECTOR CYLINDER 1
NISSAN	All Mode	Up to 2011	Engine	Actuation Test	INJECTOR CYLINDER 2
NISSAN	All Mode	Up to 2011	Engine	Actuation Test	INJECTOR CYLINDER 3
NISSAN	All Mode	Up to 2011	Engine	Actuation Test	INJECTOR CYLINDER 4
NISSAN	All Mode	Up to 2011	Engine	Actuation Test	LOCK INJECTOR CTRL
NISSAN	All Mode	Up to 2011	Engine	Actuation Test	UNLK INJECTOR CTRL
NISSAN	All Mode	Up to 2011	Engine	Actuation Test	HIGH PRESS CIRC LEAK T
NISSAN	All Mode	Up to 2011	Engine	Special Function	Saving Data For Replc CPU
NISSAN	All Mode	Up to 2011	Engine	Special Function	Writing Data For Replc CPU
NISSAN	All Mode	Up to 2011	Engine	Special Function	Vehicle Func Prog
NISSAN	All Mode	Up to 2011	Engine	Special Function	Decrement Idle Speed
NISSAN	All Mode	Up to 2011	Engine	Special Function	Increment Idle Speed
NISSAN	All Mode	Up to 2011	Engine	Special Function	EGR Adaptives
NISSAN	All Mode	Up to 2011	Engine	Special Function	Reset Pump Forcefeeding
NISSAN	All Mode	Up to 2011	Engine	Special Function	Reset Injctr Adaptative
NISSAN	All Mode	Up to 2011	Engine	Special Function	Enter Injctr Calib Data
NISSAN	All Mode	2006 - 2009	Engine	Read Fault Code	
NISSAN	All Mode	2006 - 2009	Engine	Clear Fault Code	
NISSAN	All Mode	2006 - 2009	Engine	Read Data Stream	
NISSAN	All Mode	2006 - 2009	Engine	Module Information	
NISSAN	All Mode	2006 - 2009	Engine	Special Function	Decrement Idle Speed
NISSAN	All Mode	2006 - 2009	Engine	Special Function	Increment Of Idle SPD
NISSAN	All Mode	2006 - 2009	Engine	Special Function	Vin Registration
NISSAN	All Mode	2006 - 2009	Engine	Special Function	EGR Adaptives
NISSAN	All Mode	2006 - 2009	Engine	Special Function	Engine Adaptives
NISSAN	All Mode	2006 - 2009	Engine	Special Function	Enter Injector Codes
NISSAN	All Mode	2006 - 2009	Engine	Special Function	Save Computer Data
NISSAN	All Mode	2006 - 2009	Engine	Special Function	Write Saved Data
NISSAN	ALMERA	2012	Engine	Read Data Stream	
NISSAN	ALMERA	2012	Engine	Module Information	
NISSAN	ALMERA	2012	Engine	Actuation Test	Motorised Throttle
NISSAN	ALMERA	2012	Engine	Actuation Test	FAN UNIT LOW SPEED
NISSAN	ALMERA	2012	Engine	Actuation Test	Fuel Pump Relay
NISSAN	ALMERA	2012	Engine	Actuation Test	FAN UNIT HIGH SPEED
NISSAN	ALMERA	2012	Engine	Actuation Test	A/C COMPRESSOR
NISSAN	ALMERA	2012	Engine	Actuation Test	ADDITIONAL PETROL CIRCUIT SOLENOID VALVE
NISSAN	ALMERA	2012	Engine	Actuation Test	HEATING RESISTOR RELAY 1
NISSAN	ALMERA	2012	Engine	Actuation Test	UPSTREAM O2 SENSOR HEATING
NISSAN	ALMERA	2012	Engine	Actuation Test	HEATING RESISTOR RELAY 2
NISSAN	ALMERA	2012	Engine	Actuation Test	DOWNSTREAM OXYGEN SENSOR HEATING
NISSAN	ALMERA	2012	Engine	Actuation Test	CANISTER BLEED SOLENOID VALVE
NISSAN	ALMERA	2012	Engine	Actuation Test	HEATING RESISTOR RELAY 3
NISSAN	ALMERA	2012	Engine	Actuation Test	OBD LIGHT
NISSAN	ALMERA	2012	Engine	Actuation Test	FAULT WARNING LIGHT
NISSAN	ALMERA	2012	Engine	Actuation Test	Major Injection Malfunction Warning Lamp
NISSAN	ALMERA	2012	Engine	Actuation Test	Coolant Temperature Warning Light
NISSAN	ALMERA	2012	Engine	Actuation Test	Additional Fuel Pump Relay
NISSAN	ALMERA	2012	Engine	Special Function	Vin Registration
NISSAN	ALMERA	2012	Engine	Special Function	Programming Reinitialisation
NISSAN	NP200	2008	Engine	Read Fault Code	
NISSAN	NP200	2008	Engine	Clear Fault Code	
NISSAN	NP200	2008	Engine	Read Data Stream	
NISSAN	NP200	2008	Engine	Module Information	
NISSAN	NP200	2008	Engine	Actuation Test	TURBOCHARGING SOLENOID VALVE
NISSAN	NP200	2008	Engine	Actuation Test	A/C compressor relay control
NISSAN	NP200	2008	Engine	Actuation Test	HIGH PRESSURE PUMP
NISSAN	NP200	2008	Engine	Actuation Test	INJECTOR CYLINDER 1
NISSAN	NP200	2008	Engine	Actuation Test	INJECTOR CYLINDER 2
NISSAN	NP200	2008	Engine	Actuation Test	INJECTOR CYLINDER 3
NISSAN	NP200	2008	Engine	Actuation Test	INJECTOR CYLINDER 4
NISSAN	NP200	2008	Engine	Actuation Test	HEATING RESISTOR RELAY 1
NISSAN	NP200	2008	Engine	Actuation Test	HEATING RESISTOR RELAY 2
NISSAN	NP200	2008	Engine	Actuation Test	STATIC TEST

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

<b>make</b>	<b>model</b>	<b>year</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
NISSAN	NP200	2008	Engine	Actuation Test	Refilling New Pump Body
NISSAN	NP200	2008	Engine	Actuation Test	HIGH PRESSURE CIRCUIT LEAK TEST
NISSAN	NP200	2008	Engine	Actuation Test	EGR SOLENOID VALVE
NISSAN	NP200	2008	Engine	Actuation Test	Prevention Electrical Cnsmers
NISSAN	NP200	2008	Engine	Actuation Test	Stop Electrical Consumer Prevention
NISSAN	NP200	2008	Engine	Actuation Test	PREHEATER UNIT
NISSAN	NP200	2008	Engine	Actuation Test	PREHEATER LIGHT
NISSAN	NP200	2008	Engine	Actuation Test	OVERHEATING W/L
NISSAN	NP200	2008	Engine	Actuation Test	Water In Fuel Warning Light
NISSAN	NP200	2008	Engine	Actuation Test	MIL LIGHT
NISSAN	NP200	2008	Engine	Actuation Test	FAN UNIT HIGH SPEED
NISSAN	NP200	2008	Engine	Actuation Test	FAN UNIT LOW SPEED
NISSAN	NP200	2008	Engine	Special Function	Vin Registration
NISSAN	NP200	2008	Engine	Special Function	Cylinder 1 Injector Code
NISSAN	NP200	2008	Engine	Special Function	Cylinder 2 Injector Code
NISSAN	NP200	2008	Engine	Special Function	Cylinder 3 Injector Code
NISSAN	NP200	2008	Engine	Special Function	Cylinder 4 Injector Code
NISSAN	NP200	2008	Engine	Special Function	Pressure Regulation Adaptives
NISSAN	NP200	2008	Engine	Special Function	EGR Adaptives
NISSAN	NP200	2008	Engine	Special Function	Lock Injector Ctrl
NISSAN	NP200	2008	Engine	Special Function	FAULT MEMORY
NISSAN	NP200	2008	Engine	Special Function	Save Computer Data
NISSAN	NP200	2008	Engine	Special Function	Write Saved Data
NISSAN	NP200	2008	Engine	Special Function	Enter Injector Codes
NISSAN	All Mode	2008 - 2016	Engine	Read Data Stream	
NISSAN	All Mode	2008 - 2016	Engine	Module Information	
NISSAN	All Mode	Up to 2011	Engine	Read Fault Code	
NISSAN	All Mode	Up to 2011	Engine	Clear Fault Code	
NISSAN	All Mode	Up to 2011	Engine	Read Data Stream	
NISSAN	All Mode	Up to 2011	Engine	Module Information	
NISSAN	All Mode	Up to 2011	Engine	Special Function	IGNITION TIMING ADJ
NISSAN	All Mode	Up to 2011	Engine	Special Function	IGNITION TIMING ADJ
NISSAN	All Mode	Up to 2011	Engine	Special Function	CHECK FUEL LINES
NISSAN	All Mode	Up to 2011	Engine	Special Function	FUEL PRESSURE RELEASE
NISSAN	All Mode	Up to 2011	Engine	Special Function	TP SW/TP SEN IDLE POSI ADJ
NISSAN	All Mode	Up to 2011	Engine	Special Function	TP SW/TP SEN IDLE POSI ADJ
NISSAN	All Mode	Up to 2011	Engine	Special Function	SELF-LEARNING CONT
NISSAN	All Mode	Up to 2011	Engine	Special Function	SELF-LEARNING CONT
NISSAN	All Mode	Up to 2011	Engine	Special Function	SELF-LEARNING CONT
NISSAN	All Mode	Up to 2011	Engine	Special Function	CLOSED TH/SW ADJ
NISSAN	All Mode	Up to 2011	Engine	Special Function	CLOSED TH/SW ADJ
NISSAN	All Mode	Up to 2011	Engine	Special Function	CLOSED TH/SW ADJ
NISSAN	All Mode	Up to 2011	Engine	Special Function	IDLE RPM ADJ
NISSAN	All Mode	Up to 2011	Engine	Special Function	IACV-AAC/V ADJ
NISSAN	All Mode	Up to 2011	Engine	Special Function	SET IDLE SPEED
NISSAN	All Mode	Up to 2011	Engine	Special Function	
NISSAN	All Mode	Up to 2011	Engine	Read Fault Code	
NISSAN	All Mode	Up to 2011	Engine	Clear Fault Code	
NISSAN	All Mode	Up to 2011	Engine	Read Data Stream	
NISSAN	All Mode	Up to 2011	Engine	Module Information	
NISSAN	All Mode	Up to 2011	Engine	Special Function	IDLE AIR VOL LEARN
NISSAN	All Mode	Up to 2011	Engine	Special Function	SELF-LEARNING CONT
NISSAN	All Mode	Up to 2011	Engine	Special Function	SELF-LEARNING CONT
NISSAN	All Mode	Up to 2011	Engine	Special Function	SELF-LEARNING CONT
NISSAN	All Mode	Up to 2011	Engine	Special Function	IGNITION TIMING ADJ
NISSAN	All Mode	Up to 2011	Engine	Special Function	IGNITION TIMING ADJ
NISSAN	All Mode	Up to 2011	Engine	Special Function	CHECK FUEL LINES
NISSAN	All Mode	Up to 2011	Engine	Special Function	FUEL PRESSURE RELEASE
NISSAN	All Mode	Up to 2011	Engine	Special Function	TP SW/TP SEN IDLE POSI ADJ
NISSAN	All Mode	Up to 2011	Engine	Special Function	TP SW/TP SEN IDLE POSI ADJ
NISSAN	All Mode	Up to 2011	Engine	Special Function	CLOSED TH/SW ADJ
NISSAN	All Mode	Up to 2011	Engine	Special Function	CLOSED TH/SW ADJ
NISSAN	All Mode	Up to 2011	Engine	Special Function	CLOSED TH/SW ADJ
NISSAN	All Mode	Up to 2011	Engine	Special Function	IDLE RPM ADJ
NISSAN	All Mode	Up to 2011	Engine	Special Function	IACV-AAC/V ADJ
NISSAN	All Mode	Up to 2011	Engine	Special Function	SET IDLE SPEED
NISSAN	All Mode	Up to 2011	Engine	Read Fault Code	
NISSAN	All Mode	Up to 2011	Engine	Clear Fault Code	
NISSAN	All Mode	Up to 2011	Engine	Read Data Stream	
NISSAN	All Mode	Up to 2011	Engine	Module Information	
NISSAN	All Mode	Up to 2011	Engine	Actuation Test	
NISSAN	All Mode	Up to 2017	Multi AV	Read Fault Code	
NISSAN	All Mode	Up to 2017	Multi AV	Clear Fault Code	
NISSAN	All Mode	Up to 2017	Multi AV	Read Data Stream	
NISSAN	All Mode	Up to 2017	Multi AV	Module Information	

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

<b>make</b>	<b>model</b>	<b>year</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
NISSAN	All Mode	Up to 2017	Multi AV	Special Function	SELF-DIAG[ETC]
NISSAN	All Mode	Up to 2017	Multi AV	Read Fault Code	
NISSAN	All Mode	Up to 2017	Multi AV	Clear Fault Code	
NISSAN	All Mode	Up to 2017	Multi AV	Read Data Stream	
NISSAN	All Mode	Up to 2017	Multi AV	Module Information	
NISSAN	All Mode	Up to 2017	Multi AV	Special Function	SELF-DIAG[ETC]
NISSAN	All Mode	Up to 2018	Multi AV	Read Fault Code	
NISSAN	All Mode	Up to 2018	Multi AV	Clear Fault Code	
NISSAN	All Mode	Up to 2018	Multi AV	Read Data Stream	
NISSAN	All Mode	Up to 2018	Multi AV	Read Freeze Frame	
NISSAN	All Mode	Up to 2018	Multi AV	Module Information	
NISSAN	All Mode	Up to 2018	Multi AV	Special Function	SELF-DIAG[ETC]
NISSAN	All Mode	As of 2012	Multi AV	Read Fault Code	
NISSAN	All Mode	As of 2012	Multi AV	Clear Fault Code	
NISSAN	All Mode	As of 2012	Multi AV	Read Data Stream	
NISSAN	All Mode	As of 2012	Multi AV	Module Information	
NISSAN	All Mode	Up to 2017	Multi AV	Read Fault Code	
NISSAN	All Mode	Up to 2017	Multi AV	Clear Fault Code	
NISSAN	All Mode	Up to 2017	Multi AV	Read Data Stream	
NISSAN	All Mode	Up to 2017	Multi AV	Read Freeze Frame	
NISSAN	All Mode	Up to 2017	Multi AV	Module Information	
NISSAN	All Mode	Up to 2017	Multi AV	Read Fault Code	
NISSAN	All Mode	Up to 2017	Multi AV	Clear Fault Code	
NISSAN	All Mode	Up to 2017	Multi AV	Read Data Stream	
NISSAN	All Mode	Up to 2017	Multi AV	Module Information	
NISSAN	NV400	2011	Multi AV	Read Fault Code	
NISSAN	NV400	2011	Multi AV	Clear Fault Code	
NISSAN	NV400	2011	Multi AV	Read Data Stream	
NISSAN	NV400	2011	Multi AV	Module Information	
NISSAN	NV400	2011	Multi AV	Special Function	Write date of last after sales OPE
NISSAN	NV400	2011	Multi AV	Special Function	Vin Registration
NISSAN	NV400	2011	Multi AV	Special Function	REVERSING CAMERA CALIBRATION
NISSAN	All Mode	Up to 2017	Multi AV	Read Fault Code	
NISSAN	All Mode	Up to 2017	Multi AV	Clear Fault Code	
NISSAN	All Mode	Up to 2017	Multi AV	Read Data Stream	
NISSAN	All Mode	Up to 2017	Multi AV	Read Freeze Frame	
NISSAN	All Mode	Up to 2017	Multi AV	Module Information	
NISSAN	All Mode	2006 - 2009	Multi AV	Read Fault Code	
NISSAN	All Mode	2006 - 2009	Multi AV	Clear Fault Code	
NISSAN	All Mode	2006 - 2009	Multi AV	Read Data Stream	
NISSAN	All Mode	2006 - 2009	Multi AV	Module Information	
NISSAN	All Mode	2006 - 2009	Multi AV	Actuation Test	DISPLAY TEST
NISSAN	All Mode	2006 - 2009	Multi AV	Special Function	Ecu Memory
NISSAN	All Mode	2006 - 2009	Multi AV	Special Function	Vin Registration
NISSAN	All Mode	2006 - 2009	Multi AV	Special Function	Write date of last after sales OPE
NISSAN	All Mode	2006 - 2009	Multi AV	Read Fault Code	
NISSAN	All Mode	2006 - 2009	Multi AV	Clear Fault Code	
NISSAN	All Mode	2006 - 2009	Multi AV	Read Data Stream	
NISSAN	All Mode	2006 - 2009	Multi AV	Module Information	
NISSAN	All Mode	2006 - 2009	Multi AV	Actuation Test	SPEAKER TEST
NISSAN	All Mode	2006 - 2009	Multi AV	Actuation Test	CD EJECT
NISSAN	All Mode	2006 - 2009	Multi AV	Actuation Test	DISPLAY TEST
NISSAN	All Mode	2006 - 2009	Multi AV	Special Function	Vin Registration
NISSAN	All Mode	Up to 2018	Multi AV	Read Fault Code	
NISSAN	All Mode	Up to 2018	Multi AV	Clear Fault Code	
NISSAN	All Mode	Up to 2018	Multi AV	Read Data Stream	
NISSAN	All Mode	Up to 2018	Multi AV	Module Information	
NISSAN	All Mode	Up to 2018	Multi AV	Special Function	ST ANG Sen Adjustment
NISSAN	All Mode	2014 - 2016	Multi AV	Read Fault Code	
NISSAN	All Mode	2014 - 2016	Multi AV	Clear Fault Code	
NISSAN	All Mode	2014 - 2016	Multi AV	Read Data Stream	
NISSAN	All Mode	2014 - 2016	Multi AV	Module Information	
NISSAN	All Mode	2014 - 2016	Multi AV	Actuation Test	MICROPHONE TEST
NISSAN	All Mode	2014 - 2016	Multi AV	Actuation Test	DISPLAY TEST
NISSAN	All Mode	2014 - 2016	Multi AV	Actuation Test	NAVIGATION VOICE TEST
NISSAN	All Mode	2014 - 2016	Multi AV	Actuation Test	AUDIO OUTPUT TONE CONTROL
NISSAN	All Mode	2014 - 2016	Multi AV	Special Function	Ecu Memory
NISSAN	All Mode	2014 - 2016	Multi AV	Special Function	Rear camera configuration
NISSAN	All Mode	2014 - 2016	Multi AV	Special Function	Write date of last after sales OPE
NISSAN	All Mode	2014 - 2016	Multi AV	Special Function	Vin Registration
NISSAN	All Mode	2014 - 2016	Multi AV	Special Function	REVERSING CAMERA CALIBRATION
NISSAN	All Mode	2015 - 2018	Multi AV	Read Fault Code	
NISSAN	All Mode	2015 - 2018	Multi AV	Clear Fault Code	
NISSAN	All Mode	2015 - 2018	Multi AV	Read Data Stream	
NISSAN	All Mode	2015 - 2018	Multi AV	Module Information	

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

<b>make</b>	<b>model</b>	<b>year</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
NISSAN	All Mode	2015 - 2018	Multi AV	Special Function	ST ANG Sen Adjustment
NISSAN	All Mode	2015 - 2018	Multi AV	Read Fault Code	
NISSAN	All Mode	2015 - 2018	Multi AV	Clear Fault Code	
NISSAN	All Mode	2015 - 2018	Multi AV	Read Data Stream	
NISSAN	All Mode	2015 - 2018	Multi AV	Module Information	
NISSAN	All Mode	2015 - 2018	Multi AV	Special Function	ST ANG Sen Adjustment
NISSAN	All Mode	2013 - 2017	Multi AV	Read Fault Code	
NISSAN	All Mode	2013 - 2017	Multi AV	Clear Fault Code	
NISSAN	All Mode	2013 - 2017	Multi AV	Read Data Stream	
NISSAN	All Mode	2013 - 2017	Multi AV	Module Information	
NISSAN	All Mode	As of 2012	Multi AV	Read Fault Code	
NISSAN	All Mode	As of 2012	Multi AV	Clear Fault Code	
NISSAN	All Mode	As of 2012	Multi AV	Read Data Stream	
NISSAN	All Mode	As of 2012	Multi AV	Module Information	
NISSAN	All Mode	Up to 2011	Multi AV	Read Fault Code	
NISSAN	All Mode	Up to 2011	Multi AV	Clear Fault Code	
NISSAN	All Mode	Up to 2011	Multi AV	Read Data Stream	
NISSAN	All Mode	Up to 2011	Multi AV	Module Information	
NISSAN	All Mode	2013 - 2018	CAN GATEWAY3	Read Fault Code	
NISSAN	All Mode	2013 - 2018	CAN GATEWAY3	Clear Fault Code	
NISSAN	All Mode	2013 - 2018	CAN GATEWAY3	Read Data Stream	
NISSAN	All Mode	2013 - 2018	CAN GATEWAY3	Module Information	
NISSAN	All Mode	Up to 2011	NATS IMMU	Read Fault Code	
NISSAN	All Mode	Up to 2011	NATS IMMU	Clear Fault Code	
NISSAN	All Mode	Up to 2011	NATS IMMU	Module Information	
NISSAN	All Mode	Up to 2012	Smart Entrance	Read Fault Code	
NISSAN	All Mode	Up to 2012	Smart Entrance	Clear Fault Code	
NISSAN	All Mode	Up to 2012	Smart Entrance	Read Data Stream	
NISSAN	All Mode	Up to 2012	Smart Entrance	Module Information	
NISSAN	All Mode	Up to 2012	Smart Entrance	Special Function	
NISSAN	All Mode	Up to 2011	Smart Entrance	Read Data Stream	
NISSAN	All Mode	Up to 2011	Smart Entrance	Module Information	
NISSAN	All Mode	Up to 2011	Smart Entrance	Special Function	REMO CONT ID ERASUR
NISSAN	All Mode	Up to 2011	Smart Entrance	Special Function	THEFT ALM TRG
NISSAN	All Mode	Up to 2011	Smart Entrance	Special Function	REMO CONT ID REGIST
NISSAN	All Mode	Up to 2011	Smart Entrance	Special Function	HZRD REM SET
NISSAN	All Mode	Up to 2011	Smart Entrance	Special Function	
NISSAN	All Mode	Up to 2011	Smart Entrance	Read Data Stream	
NISSAN	All Mode	Up to 2011	Smart Entrance	Module Information	
NISSAN	All Mode	Up to 2011	Smart Entrance	Special Function	REMO CONT ID REGIST
NISSAN	All Mode	Up to 2011	Smart Entrance	Special Function	REMO CONT ID ERASUR
NISSAN	All Mode	Up to 2017	Air Levelizer	Read Fault Code	
NISSAN	All Mode	Up to 2017	Air Levelizer	Clear Fault Code	
NISSAN	All Mode	Up to 2017	Air Levelizer	Read Data Stream	
NISSAN	All Mode	Up to 2017	Air Levelizer	Module Information	
NISSAN	All Mode	Up to 2017	Air Levelizer	Special Function	
NISSAN	All Mode	Up to 2016	Rearview Camera	Read Data Stream	
NISSAN	All Mode	Up to 2016	Rearview Camera	Module Information	
NISSAN	All Mode	Up to 2016	Rearview Camera	Special Function	
NISSAN	All Mode	Up to 2016	S/Blind Camera	Read Data Stream	
NISSAN	All Mode	Up to 2016	S/Blind Camera	Module Information	
NISSAN	All Mode	Up to 2016	S/Blind Camera	Special Function	
NISSAN	All Mode	Up to 2011	Active Engine Mount	Read Fault Code	
NISSAN	All Mode	Up to 2011	Active Engine Mount	Clear Fault Code	
NISSAN	All Mode	Up to 2011	Active Engine Mount	Read Data Stream	
NISSAN	All Mode	Up to 2011	Active Engine Mount	Module Information	
NISSAN	All Mode	Up to 2011	Active Sus	Read Fault Code	
NISSAN	All Mode	Up to 2011	Active Sus	Clear Fault Code	
NISSAN	All Mode	Up to 2011	Active Sus	Read Data Stream	
NISSAN	All Mode	Up to 2011	Active Sus	Module Information	
NISSAN	All Mode	Up to 2011	Active Sus	Actuation Test	
NISSAN	All Mode	Up to 2011	Active Sus	Read Fault Code	
NISSAN	All Mode	Up to 2011	Active Sus	Clear Fault Code	
NISSAN	All Mode	Up to 2011	Active Sus	Read Data Stream	
NISSAN	All Mode	Up to 2011	Active Sus	Module Information	
NISSAN	All Mode	Up to 2011	Active Sus	Special Function	HYDRAULIC SYSTEM
NISSAN	All Mode	Up to 2011	Active Sus	Special Function	OPERATION CHECK
NISSAN	Note e-POWER	2016	Generator	Read Fault Code	
NISSAN	Note e-POWER	2016	Generator	Clear Fault Code	
NISSAN	Note e-POWER	2016	Generator	Read Data Stream	
NISSAN	Note e-POWER	2016	Generator	Module Information	
NISSAN	Note e-POWER	2016	Generator	Special Function	CLEAR OUTPUT LIMIT REASON
NISSAN	All Mode	Up to 2011	ASCD	Read Fault Code	
NISSAN	All Mode	Up to 2011	ASCD	Clear Fault Code	
NISSAN	All Mode	Up to 2011	ASCD	Read Data Stream	
NISSAN	All Mode	Up to 2011	ASCD	Module Information	
NISSAN	All Mode	Up to 2011	ASCD	Read Fault Code	
NISSAN	All Mode	Up to 2011	ASCD	Clear Fault Code	
NISSAN	All Mode	Up to 2011	ASCD	Read Data Stream	
NISSAN	All Mode	Up to 2011	ASCD	Module Information	

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
NISSAN	All Mode	2015 - 2017	Hands Free Module	Read Fault Code	
NISSAN	All Mode	2015 - 2017	Hands Free Module	Clear Fault Code	
NISSAN	All Mode	2015 - 2017	Hands Free Module	Read Data Stream	
NISSAN	All Mode	2015 - 2017	Hands Free Module	Module Information	
NISSAN	All Mode	2015 - 2017	Hands Free Module	Special Function	Vin Registration
NISSAN	NV300	2016	Hands Free Module	Read Fault Code	
NISSAN	NV300	2016	Hands Free Module	Clear Fault Code	
NISSAN	NV300	2016	Hands Free Module	Read Data Stream	
NISSAN	NV300	2016	Hands Free Module	Module Information	
NISSAN	All Mode	Up to 2011	Distance Control	Read Fault Code	
NISSAN	All Mode	Up to 2011	Distance Control	Clear Fault Code	
NISSAN	All Mode	Up to 2011	Distance Control	Read Data Stream	
NISSAN	All Mode	Up to 2011	Motor Assist	Read Fault Code	
NISSAN	All Mode	Up to 2011	Motor Assist	Clear Fault Code	
NISSAN	All Mode	Up to 2011	Motor Assist	Read Data Stream	
NISSAN	All Mode	Up to 2011	Motor Assist	Special Function	
NISSAN	All Mode	As of 2012	Motor Assist	Read Fault Code	
NISSAN	All Mode	As of 2012	Motor Assist	Clear Fault Code	
NISSAN	All Mode	As of 2012	Motor Assist	Read Data Stream	
NISSAN	All Mode	Up to 2011	IVMS (In-Vehicle Multiplexing System)	Read Fault Code	
NISSAN	All Mode	Up to 2011	IVMS (In-Vehicle Multiplexing System)	Clear Fault Code	
NISSAN	All Mode	Up to 2011	IVMS (In-Vehicle Multiplexing System)	Read Data Stream	
NISSAN	All Mode	Up to 2011	IVMS (In-Vehicle Multiplexing System)	Module Information	
NISSAN	All Mode	Up to 2011	IVMS (In-Vehicle Multiplexing System)	Special Function	UNIVERSAL FUNCTION
NISSAN	All Mode	Up to 2011	IVMS (In-Vehicle Multiplexing System)	Special Function	
NISSAN	All Mode	2013 - 2018	CAN GATEWAY2	Read Fault Code	
NISSAN	All Mode	2013 - 2018	CAN GATEWAY2	Clear Fault Code	
NISSAN	All Mode	2013 - 2018	CAN GATEWAY2	Read Data Stream	
NISSAN	All Mode	2013 - 2018	CAN GATEWAY2	Module Information	
NISSAN	All Mode	Up to 2011	TCS (Traction Control System)	Read Fault Code	
NISSAN	All Mode	Up to 2011	TCS (Traction Control System)	Clear Fault Code	
NISSAN	All Mode	Up to 2011	TCS (Traction Control System)	Read Data Stream	
NISSAN	All Mode	Up to 2011	TCS (Traction Control System)	Module Information	
NISSAN	All Mode	Up to 2011	TCS (Traction Control System)	Special Function	THRTL_POS SEN2 ADJ
NISSAN	All Mode	Up to 2011	TCS (Traction Control System)	Special Function	CLSD/TH-P LEARN CLR
NISSAN	All Mode	2006 - 2009	CHA	Read Fault Code	
NISSAN	All Mode	2006 - 2009	CHA	Clear Fault Code	
NISSAN	All Mode	2006 - 2009	CHA	Read Data Stream	
NISSAN	All Mode	2006 - 2009	CHA	Module Information	
NISSAN	All Mode	2006 - 2009	CHA	Actuation Test	Pass. Compartment Fan Assy
NISSAN	All Mode	2006 - 2009	CHA	Actuation Test	Recycling Motor: External Air
NISSAN	All Mode	2006 - 2009	CHA	Actuation Test	Recycling Motor: Recycling
NISSAN	All Mode	2006 - 2009	CHA	Actuation Test	Distribution Motor: Demisting
NISSAN	All Mode	2006 - 2009	CHA	Actuation Test	Distribution Motor: Vent
NISSAN	All Mode	2006 - 2009	CHA	Actuation Test	Mixing Motor: All Cold
NISSAN	All Mode	2006 - 2009	CHA	Actuation Test	Mixing Motor: All Hot
NISSAN	All Mode	2006 - 2009	CHA	Actuation Test	Rear Fan : Cold
NISSAN	All Mode	2006 - 2009	CHA	Actuation Test	Rear Fan : Hot
NISSAN	All Mode	2006 - 2009	CHA	Special Function	Vin Registration
NISSAN	NV400	2011	CHA	Read Fault Code	
NISSAN	NV400	2011	CHA	Clear Fault Code	
NISSAN	NV400	2011	CHA	Read Data Stream	
NISSAN	NV400	2011	CHA	Module Information	
NISSAN	NV400	2011	CHA	Actuation Test	Pass. Compartment Fan Assy
NISSAN	NV400	2011	CHA	Actuation Test	Recycling Motor: External Air
NISSAN	NV400	2011	CHA	Actuation Test	Recycling Motor: Recycling
NISSAN	NV400	2011	CHA	Actuation Test	Mixing Motor: All Cold
NISSAN	NV400	2011	CHA	Actuation Test	Mixing Motor: All Hot
NISSAN	NV400	2011	CHA	Actuation Test	Distribution Motor: Vent
NISSAN	NV400	2011	CHA	Actuation Test	Distribution Motor: Demisting
NISSAN	NV400	2011	CHA	Special Function	Vin Registration
NISSAN	NV400	2011	CHA	Special Function	The combustion engine is running.
NISSAN	All Mode	2006 - 2009	CHA	Read Fault Code	
NISSAN	All Mode	2006 - 2009	CHA	Clear Fault Code	
NISSAN	All Mode	2006 - 2009	CHA	Read Data Stream	
NISSAN	All Mode	2006 - 2009	CHA	Module Information	
NISSAN	All Mode	2006 - 2009	CHA	Special Function	Erase Overheat Counter
NISSAN	All Mode	2006 - 2009	CHA	Special Function	ERS INCRCT CRNKG CNTR
NISSAN	NV300	2016	CHA	Read Fault Code	
NISSAN	NV300	2016	CHA	Clear Fault Code	
NISSAN	NV300	2016	CHA	Read Data Stream	
NISSAN	NV300	2016	CHA	Module Information	
NISSAN	NV400	2011	CHA	Read Fault Code	
NISSAN	NV400	2011	CHA	Clear Fault Code	
NISSAN	NV400	2011	CHA	Read Data Stream	

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
NISSAN	NV400	2011	CHA	Module Information	
NISSAN	NV400	2011	CHA	Actuation Test	Recycling Motor: External Air
NISSAN	NV400	2011	CHA	Actuation Test	Recycling Motor: Recycling
NISSAN	NV400	2011	CHA	Actuation Test	Mixing Motor: All Cold
NISSAN	NV400	2011	CHA	Actuation Test	Mixing Motor: All Hot
NISSAN	NV400	2011	CHA	Actuation Test	Distribution Motor: Vent
NISSAN	NV400	2011	CHA	Actuation Test	Distribution Motor: Demisting
NISSAN	NV400	2011	CHA	Special Function	Computer Reinitialization
NISSAN	NV400	2011	CHA	Special Function	Vin Registration
NISSAN	All Mode	2013 - 2018	FSCM (Fuel System Control Modle)	Read Fault Code	
NISSAN	All Mode	2013 - 2018	FSCM (Fuel System Control Modle)	Clear Fault Code	
NISSAN	All Mode	2013 - 2018	FSCM (Fuel System Control Modle)	Read Data Stream	
NISSAN	All Mode	2013 - 2018	FSCM (Fuel System Control Modle)	Module Information	
NISSAN	All Mode	2013 - 2018	FSCM (Fuel System Control Modle)	Actuation Test	CK Fuel Prss & Intrnl Lkghtnss Of FL Sys
NISSAN	All Mode	2015 - 2018	FSCM (Fuel System Control Modle)	Read Fault Code	
NISSAN	All Mode	2015 - 2018	FSCM (Fuel System Control Modle)	Clear Fault Code	
NISSAN	All Mode	2015 - 2018	FSCM (Fuel System Control Modle)	Read Data Stream	
NISSAN	All Mode	2015 - 2018	FSCM (Fuel System Control Modle)	Module Information	
NISSAN	All Mode	2014 - 2018	FSCM (Fuel System Control Modle)	Read Fault Code	
NISSAN	All Mode	2014 - 2018	FSCM (Fuel System Control Modle)	Clear Fault Code	
NISSAN	All Mode	2014 - 2018	FSCM (Fuel System Control Modle)	Read Data Stream	
NISSAN	All Mode	2014 - 2018	FSCM (Fuel System Control Modle)	Module Information	
NISSAN	INFINITI QX80	2016	Vehicle Data Transmitter	Read Fault Code	
NISSAN	INFINITI QX80	2016	Vehicle Data Transmitter	Clear Fault Code	
NISSAN	INFINITI QX80	2016	Vehicle Data Transmitter	Read Data Stream	
NISSAN	INFINITI QX80	2016	Vehicle Data Transmitter	Module Information	
NISSAN	INFINITI QX80	2016	Vehicle Data Transmitter	Special Function	Bluetooth Function
NISSAN	INFINITI QX80	2016	Vehicle Data Transmitter	Special Function	GPS Data Logger Connection Setting
NISSAN	INFINITI QX80	2016	Vehicle Data Transmitter	Special Function	Change Bluetooth Name
NISSAN	INFINITI QX80	2016	Vehicle Data Transmitter	Special Function	Bluetooth Pairing Erase
NISSAN	INFINITI QX80	2016	Vehicle Data Transmitter	Special Function	Vehicle Data Transmitter Setting Erase
NISSAN	INFINITI QX80	2016	Vehicle Data Transmitter	Special Function	Save Vin Data
NISSAN	INFINITI QX80	2016	Vehicle Data Transmitter	Special Function	Write Vin (Saved Data)
NISSAN	INFINITI QX80	2016	Vehicle Data Transmitter	Special Function	Write Vin (Manual Input)
NISSAN	ELGRAND	2012	PMAS	Read Fault Code	
NISSAN	ELGRAND	2012	PMAS	Clear Fault Code	
NISSAN	ELGRAND	2012	PMAS	Read Data Stream	
NISSAN	ELGRAND	2012	PMAS	Module Information	
NISSAN	ELGRAND	2012	PMAS	Special Function	G Sensor Horizon Status Learning
NISSAN	ELGRAND	2012	PMAS	Special Function	Cause Of Auto-Cancel 4
NISSAN	LEAF	2016	(TBD)HV Battery SubCPU	Read Fault Code	
NISSAN	LEAF	2016	(TBD)HV Battery SubCPU	Clear Fault Code	
NISSAN	LEAF	2016	(TBD)HV Battery SubCPU	Read Data Stream	
NISSAN	LEAF	2016	(TBD)HV Battery SubCPU	Module Information	
NISSAN	NV400	2011	RADIO	Read Fault Code	
NISSAN	NV400	2011	RADIO	Clear Fault Code	
NISSAN	NV400	2011	RADIO	Read Data Stream	
NISSAN	NV400	2011	RADIO	Module Information	
NISSAN	NV400	2011	RADIO	Actuation Test	FRONT LEFT-HAND SPEAKER LINE TEST
NISSAN	NV400	2011	RADIO	Actuation Test	FRONT RIGHT-HAND SPEAKER LINE TEST
NISSAN	NV400	2011	RADIO	Actuation Test	REAR RIGHT-HAND SPEAKER LINE TEST
NISSAN	NV400	2011	RADIO	Actuation Test	REAR LEFT-HAND SPEAKER LINE TEST
NISSAN	NV400	2011	RADIO	Actuation Test	MICROPHONE TEST
NISSAN	NV400	2011	RADIO	Actuation Test	CD EJECT
NISSAN	NV400	2011	RADIO	Special Function	Write Date Of After Sales Operation
NISSAN	NV400	2011	RADIO	Special Function	Vin Registration
NISSAN	NV400	2011	RADIO	Special Function	VEHICLE CONFIGURATION
NISSAN	NV400	2011	RADIO	Read Fault Code	
NISSAN	NV400	2011	RADIO	Clear Fault Code	
NISSAN	NV400	2011	RADIO	Read Data Stream	
NISSAN	NV400	2011	RADIO	Module Information	
NISSAN	NV400	2011	RADIO	Actuation Test	FRONT LEFT-HAND SPEAKER LINE TEST
NISSAN	NV400	2011	RADIO	Actuation Test	FRONT RIGHT-HAND SPEAKER LINE TEST
NISSAN	NV400	2011	RADIO	Actuation Test	REAR RIGHT-HAND SPEAKER LINE TEST
NISSAN	NV400	2011	RADIO	Actuation Test	REAR LEFT-HAND SPEAKER LINE TEST



**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

<b>make</b>	<b>model</b>	<b>year</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
NISSAN	NV400	2011	RADIO	Actuation Test	CD EJECT
NISSAN	NV400	2011	RADIO	Special Function	Vin Registration
NISSAN	NV400	2011	RADIO	Special Function	Write Date Of After Sales Operation
NISSAN	All Mode	2006 - 2009	RADIO	Read Fault Code	
NISSAN	All Mode	2006 - 2009	RADIO	Clear Fault Code	
NISSAN	All Mode	2006 - 2009	RADIO	Read Data Stream	
NISSAN	All Mode	2006 - 2009	RADIO	Module Information	
NISSAN	All Mode	2006 - 2009	RADIO	Actuation Test	FRONT LEFT-HAND SPEAKER LINE TEST
NISSAN	All Mode	2006 - 2009	RADIO	Actuation Test	FRONT RIGHT-HAND SPEAKER LINE TEST
NISSAN	All Mode	2006 - 2009	RADIO	Actuation Test	REAR RIGHT-HAND SPEAKER LINE TEST
NISSAN	All Mode	2006 - 2009	RADIO	Actuation Test	REAR LEFT-HAND SPEAKER LINE TEST
NISSAN	All Mode	2006 - 2009	RADIO	Actuation Test	MICROPHONE TEST
NISSAN	All Mode	2006 - 2009	RADIO	Actuation Test	CD EJECT
NISSAN	All Mode	2006 - 2009	RADIO	Special Function	Write Date Of After Sales Operation
NISSAN	All Mode	2006 - 2009	RADIO	Special Function	Vin Registration
NISSAN	All Mode	2006 - 2009	RADIO	Special Function	Configuring The Multimedia Computer
NISSAN	All Mode	2006 - 2009	RADIO	Read Fault Code	
NISSAN	All Mode	2006 - 2009	RADIO	Clear Fault Code	
NISSAN	All Mode	2006 - 2009	RADIO	Read Data Stream	
NISSAN	All Mode	2006 - 2009	RADIO	Module Information	
NISSAN	All Mode	2006 - 2009	RADIO	Actuation Test	CD EJECT
NISSAN	All Mode	2006 - 2009	RADIO	Actuation Test	FRONT LEFT-HAND SPEAKER LINE TEST
NISSAN	All Mode	2006 - 2009	RADIO	Actuation Test	FRONT RIGHT-HAND SPEAKER LINE TEST
NISSAN	All Mode	2006 - 2009	RADIO	Actuation Test	REAR RIGHT-HAND SPEAKER LINE TEST
NISSAN	All Mode	2006 - 2009	RADIO	Actuation Test	REAR LEFT-HAND SPEAKER LINE TEST
NISSAN	All Mode	2006 - 2009	RADIO	Special Function	Write Date Of After Sales Operation
NISSAN	All Mode	2006 - 2009	RADIO	Special Function	Vin Registration
NISSAN	NV400	2011	RADIO	Read Fault Code	
NISSAN	NV400	2011	RADIO	Clear Fault Code	
NISSAN	NV400	2011	RADIO	Read Data Stream	
NISSAN	NV400	2011	RADIO	Module Information	
NISSAN	NV400	2011	RADIO	Actuation Test	SUBWOOFER TEST
NISSAN	NV400	2011	RADIO	Actuation Test	CD EJECT
NISSAN	NV400	2011	RADIO	Actuation Test	FRONT LEFT-HAND SPEAKER LINE TEST
NISSAN	NV400	2011	RADIO	Actuation Test	MICROPHONE TEST
NISSAN	NV400	2011	RADIO	Actuation Test	FRONT RIGHT-HAND SPEAKER LINE TEST
NISSAN	NV400	2011	RADIO	Actuation Test	REAR RIGHT-HAND SPEAKER LINE TEST
NISSAN	NV400	2011	RADIO	Actuation Test	REAR LEFT-HAND SPEAKER LINE TEST
NISSAN	NV400	2011	RADIO	Special Function	Write Date Of After Sales Operation
NISSAN	NV400	2011	RADIO	Special Function	Parametrage Prive 1
NISSAN	NV400	2011	RADIO	Special Function	Vin Registration
NISSAN	NV400	2011	RADIO	Special Function	Customer Settings And Details
NISSAN	NV400	2011	RADIO	Special Function	Reset Radio
NISSAN	NV400	2011	RADIO	Read Fault Code	
NISSAN	NV400	2011	RADIO	Clear Fault Code	
NISSAN	NV400	2011	RADIO	Read Data Stream	
NISSAN	NV400	2011	RADIO	Module Information	
NISSAN	NV400	2011	RADIO	Actuation Test	FRONT LEFT-HAND SPEAKER LINE TEST
NISSAN	NV400	2011	RADIO	Actuation Test	FRONT RIGHT-HAND SPEAKER LINE TEST
NISSAN	NV400	2011	RADIO	Actuation Test	REAR RIGHT-HAND SPEAKER LINE TEST
NISSAN	NV400	2011	RADIO	Actuation Test	REAR LEFT-HAND SPEAKER LINE TEST
NISSAN	NV400	2011	RADIO	Actuation Test	MICROPHONE TEST
NISSAN	NV400	2011	RADIO	Actuation Test	CD EJECT
NISSAN	NV400	2011	RADIO	Special Function	Write Date Of After Sales Operation
NISSAN	All Mode	2006 - 2009	RADIO	Read Fault Code	
NISSAN	All Mode	2006 - 2009	RADIO	Clear Fault Code	
NISSAN	All Mode	2006 - 2009	RADIO	Read Data Stream	

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
NISSAN	All Mode	2006 - 2009	RADIO	Module Information	
NISSAN	All Mode	2006 - 2009	RADIO	Actuation Test	FRONT LEFT-HAND SPEAKER LINE TEST
NISSAN	All Mode	2006 - 2009	RADIO	Actuation Test	FRONT RIGHT-HAND SPEAKER LINE TEST
NISSAN	All Mode	2006 - 2009	RADIO	Actuation Test	REAR RIGHT-HAND SPEAKER LINE TEST
NISSAN	All Mode	2006 - 2009	RADIO	Actuation Test	REAR LEFT-HAND SPEAKER LINE TEST
NISSAN	All Mode	2006 - 2009	RADIO	Actuation Test	MICROPHONE TEST
NISSAN	All Mode	2006 - 2009	RADIO	Actuation Test	CD EJECT
NISSAN	All Mode	2006 - 2009	RADIO	Special Function	Write Date Of After Sales Operation
NISSAN	All Mode	2014 - 2016	RADIO	Read Fault Code	
NISSAN	All Mode	2014 - 2016	RADIO	Clear Fault Code	
NISSAN	All Mode	2014 - 2016	RADIO	Read Data Stream	
NISSAN	All Mode	2014 - 2016	RADIO	Module Information	
NISSAN	All Mode	2014 - 2016	RADIO	Actuation Test	FRONT RIGHT-HAND SPEAKER LINE TEST
NISSAN	All Mode	2014 - 2016	RADIO	Actuation Test	FRONT LEFT-HAND SPEAKER LINE TEST
NISSAN	All Mode	2014 - 2016	RADIO	Actuation Test	REAR RIGHT-HAND SPEAKER LINE TEST
NISSAN	All Mode	2014 - 2016	RADIO	Actuation Test	REAR LEFT-HAND SPEAKER LINE TEST
NISSAN	All Mode	2014 - 2016	RADIO	Actuation Test	CD EJECT
NISSAN	All Mode	2014 - 2016	RADIO	Special Function	SYSTEM CONFIGURATION
NISSAN	All Mode	2014 - 2016	RADIO	Special Function	Vin Registration
NISSAN	All Mode	2014 - 2016	RADIO	Special Function	Reset Radio
NISSAN	All Mode	2014 - 2017	RADIO	Read Fault Code	
NISSAN	All Mode	2014 - 2017	RADIO	Clear Fault Code	
NISSAN	All Mode	2014 - 2017	RADIO	Read Data Stream	
NISSAN	All Mode	2014 - 2017	RADIO	Module Information	
NISSAN	All Mode	2014 - 2017	RADIO	Actuation Test	FRONT RIGHT-HAND SPEAKER LINE TEST
NISSAN	All Mode	2014 - 2017	RADIO	Actuation Test	FRONT LEFT-HAND SPEAKER LINE TEST
NISSAN	All Mode	2014 - 2017	RADIO	Actuation Test	REAR RIGHT-HAND SPEAKER LINE TEST
NISSAN	All Mode	2014 - 2017	RADIO	Actuation Test	REAR LEFT-HAND SPEAKER LINE TEST
NISSAN	All Mode	2014 - 2017	RADIO	Actuation Test	MICROPHONE TEST
NISSAN	All Mode	2014 - 2017	RADIO	Actuation Test	CD EJECT
NISSAN	All Mode	2014 - 2017	RADIO	Special Function	Reset Radio
NISSAN	All Mode	2014 - 2017	RADIO	Special Function	Comp Configuration
NISSAN	All Mode	2014 - 2017	RADIO	Special Function	Vin Registration
NISSAN	All Mode	2014 - 2017	RADIO	Read Fault Code	
NISSAN	All Mode	2014 - 2017	RADIO	Clear Fault Code	
NISSAN	All Mode	2014 - 2017	RADIO	Read Data Stream	
NISSAN	All Mode	2014 - 2017	RADIO	Module Information	
NISSAN	All Mode	2014 - 2017	RADIO	Special Function	Write Date Of After Sales Operation
NISSAN	All Mode	2014 - 2017	RADIO	Special Function	Vin Registration
NISSAN	All Mode	2015 - 2017	RADIO	Read Fault Code	
NISSAN	All Mode	2015 - 2017	RADIO	Clear Fault Code	
NISSAN	All Mode	2015 - 2017	RADIO	Read Data Stream	
NISSAN	All Mode	2015 - 2017	RADIO	Module Information	
NISSAN	All Mode	2015 - 2018	Left front door control unit	Read Fault Code	
NISSAN	All Mode	2015 - 2018	Left front door control unit	Clear Fault Code	
NISSAN	All Mode	2015 - 2018	Left front door control unit	Read Data Stream	
NISSAN	All Mode	2015 - 2018	Left front door control unit	Module Information	
NISSAN	All Mode	2015 - 2018	Left front door control unit	Actuation Test	Front door lock actuator left
NISSAN	All Mode	2015 - 2018	Left front door control unit	Actuation Test	Front door switch illumination left
NISSAN	All Mode	2015 - 2018	Left front door control unit	Actuation Test	Front super lock actuator left
NISSAN	All Mode	2015 - 2018	Left front door control unit	Actuation Test	Front door handle illumination left
NISSAN	All Mode	2015 - 2018	Left front door control unit	Actuation Test	Front door exit and warning lamp left
NISSAN	All Mode	2015 - 2018	Left front door control unit	Actuation Test	Front door ambience illuminatin left
NISSAN	All Mode	2015 - 2018	Left front door control unit	Actuation Test	Side turn signal lamp left
NISSAN	All Mode	2015 - 2018	Left front door control unit	Actuation Test	Front power window motor left
NISSAN	All Mode	2015 - 2018	Left front door control unit	Actuation Test	Outside mirror ambient lamp left
NISSAN	All Mode	2015 - 2018	Left front door control unit	Actuation Test	Left blind spot assist warning

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
NISSAN	All Mode	2015 - 2018	Left front door control unit	Actuation Test	Auto anti-dazzling mirror
NISSAN	All Mode	2015 - 2018	Left front door control unit	Actuation Test	Power folding unit
NISSAN	All Mode	2015 - 2018	Left front door control unit	Actuation Test	Door mirror defogger
NISSAN	All Mode	2015 - 2018	Left front door control unit	Actuation Test	Adjustment actuator motor via actuation
NISSAN	All Mode	2015 - 2018	Left front door control unit	Actuation Test	Vertical and horizontal inclination adjustment
NISSAN	All Mode	2015 - 2018	Left front door control unit	Actuation Test	Left memory function
NISSAN	All Mode	2015 - 2018	Left front door control unit	Actuation Test	Denormalization of left front power window
NISSAN	All Mode	2015 - 2018	Left front door control unit	Actuation Test	Left outside mirror adjust
NISSAN	All Mode	2015 - 2018	Left front door control unit	Actuation Test	LEDs
NISSAN	All Mode	2015 - 2018	Left front door control unit	Actuation Test	Control unit reset
NISSAN	All Mode	2015 - 2018	Right front door control unit	Read Fault Code	
NISSAN	All Mode	2015 - 2018	Right front door control unit	Clear Fault Code	
NISSAN	All Mode	2015 - 2018	Right front door control unit	Read Data Stream	
NISSAN	All Mode	2015 - 2018	Right front door control unit	Module Information	
NISSAN	All Mode	2015 - 2018	Right front door control unit	Actuation Test	Front door lock actuator right
NISSAN	All Mode	2015 - 2018	Right front door control unit	Actuation Test	Front door switch illumination right
NISSAN	All Mode	2015 - 2018	Right front door control unit	Actuation Test	Front super lock actuator right
NISSAN	All Mode	2015 - 2018	Right front door control unit	Actuation Test	Front door handle illumination right
NISSAN	All Mode	2015 - 2018	Right front door control unit	Actuation Test	Front door exit and warning lamp right
NISSAN	All Mode	2015 - 2018	Right front door control unit	Actuation Test	Front door ambience illuminatin right
NISSAN	All Mode	2015 - 2018	Right front door control unit	Actuation Test	Side turn signal lamp right
NISSAN	All Mode	2015 - 2018	Right front door control unit	Actuation Test	Front power window motor right
NISSAN	All Mode	2015 - 2018	Right front door control unit	Actuation Test	Outside mirror ambient lamp right
NISSAN	All Mode	2015 - 2018	Right front door control unit	Actuation Test	Right blind spot assist warning
NISSAN	All Mode	2015 - 2018	Right front door control unit	Actuation Test	Auto anti-dazzling mirror
NISSAN	All Mode	2015 - 2018	Right front door control unit	Actuation Test	Power folding unit
NISSAN	All Mode	2015 - 2018	Right front door control unit	Actuation Test	Door mirror defogger
NISSAN	All Mode	2015 - 2018	Right front door control unit	Actuation Test	Adjustment actuator motor via actuation
NISSAN	All Mode	2015 - 2018	Right front door control unit	Actuation Test	Vertical and horizontal inclination adjustment
NISSAN	All Mode	2015 - 2018	Right front door control unit	Actuation Test	Right memory function
NISSAN	All Mode	2015 - 2018	Right front door control unit	Actuation Test	Denormalization of right rear power window
NISSAN	All Mode	2015 - 2018	Right front door control unit	Actuation Test	Right outside mirror adjust
NISSAN	All Mode	2015 - 2018	Right front door control unit	Actuation Test	LEDs
NISSAN	All Mode	2015 - 2018	Right front door control unit	Actuation Test	Control unit reset
NISSAN	All Mode	2015 - 2018	Siren control unit	Read Fault Code	
NISSAN	All Mode	2015 - 2018	Siren control unit	Clear Fault Code	
NISSAN	All Mode	2015 - 2018	Siren control unit	Read Data Stream	
NISSAN	All Mode	2015 - 2018	Siren control unit	Module Information	
NISSAN	All Mode	2015 - 2018	Siren control unit	Actuation Test	Actuation of tow away prot buttn and interior prot buttn
NISSAN	All Mode	2015 - 2018	Siren control unit	Actuation Test	Eighth to last data record
NISSAN	All Mode	2015 - 2018	Siren control unit	Actuation Test	Fifth from last data record
NISSAN	All Mode	2015 - 2018	Siren control unit	Actuation Test	Fourth from last data record
NISSAN	All Mode	2015 - 2018	Siren control unit	Actuation Test	Last data record
NISSAN	All Mode	2015 - 2018	Siren control unit	Actuation Test	Ninth to last data record
NISSAN	All Mode	2015 - 2018	Siren control unit	Actuation Test	Second from last data record
NISSAN	All Mode	2015 - 2018	Siren control unit	Actuation Test	Seventh to last data record
NISSAN	All Mode	2015 - 2018	Siren control unit	Actuation Test	Sixth to last data record
NISSAN	All Mode	2015 - 2018	Siren control unit	Actuation Test	Tenth to last data record
NISSAN	All Mode	2015 - 2018	Siren control unit	Actuation Test	Third from last data record
NISSAN	All Mode	2015 - 2018	Siren control unit	Special Function	Clear alarm history
NISSAN	All Mode	As of 2012	(TBD)Audio Amplier Unit	Read Fault Code	
NISSAN	All Mode	As of 2012	(TBD)Audio Amplier Unit	Clear Fault Code	
NISSAN	All Mode	As of 2012	(TBD)Audio Amplier Unit	Read Data Stream	
NISSAN	All Mode	As of 2012	(TBD)Audio Amplier Unit	Module Information	
NISSAN	All Mode	As of 2012	(TBD)Audio Amplier Unit	Special Function	ANC Setting
NISSAN	All Mode	As of 2012	(TBD)Audio Amplier Unit	Special Function	ASC Setting
NISSAN	All Mode	2015 - 2018	Alarm siren	Read Data Stream	
NISSAN	All Mode	2015 - 2018	Alarm siren	Module Information	
NISSAN	All Mode	2015 - 2018	Passenger seat control unit	Read Fault Code	
NISSAN	All Mode	2015 - 2018	Passenger seat control unit	Clear Fault Code	
NISSAN	All Mode	2015 - 2018	Passenger seat control unit	Read Data Stream	

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
NISSAN	All Mode	2015 - 2018	Passenger seat control unit	Module Information	
NISSAN	All Mode	2015 - 2018	Passenger seat control unit	Actuation Test	Front passenger seat sliding motor
NISSAN	All Mode	2015 - 2018	Passenger seat control unit	Actuation Test	Front passenger seat lifting motor (front)
NISSAN	All Mode	2015 - 2018	Passenger seat control unit	Actuation Test	Front passenger seat lifting motor (rear)
NISSAN	All Mode	2015 - 2018	Passenger seat control unit	Actuation Test	Front passenger seat headrest motor
NISSAN	All Mode	2015 - 2018	Passenger seat control unit	Actuation Test	Front passenger seat reclining motor
NISSAN	All Mode	2015 - 2018	Passenger seat control unit	Special Function	Normalization
NISSAN	All Mode	2015 - 2018	Intelligent battery sensor	Module Information	
NISSAN	All Mode	2015 - 2018	Upper control panel cont unit	Module Information	
NISSAN	All Mode	2015 - 2018	EC mirror compass	Module Information	
NISSAN	All Mode	2015 - 2018	Universal garage door opener	Module Information	
NISSAN	All Mode	2015 - 2018	Universal garage door opener	Special Function	Writing security byte
NISSAN	All Mode	2015 - 2018	Universal garage door opener	Special Function	Initial startup
NISSAN	All Mode	2015 - 2018	Light & rain sensor	Read Data Stream	
NISSAN	All Mode	2015 - 2018	Light & rain sensor	Module Information	
NISSAN	All Mode	2015 - 2018	Light & rain sensor	Special Function	Adaptation of component of rain sensor
NISSAN	All Mode	2015 - 2018	Overhead control panel unit	Module Information	
NISSAN	All Mode	2015 - 2018	Electronic ign switch cont unit	Read Fault Code	
NISSAN	All Mode	2015 - 2018	Electronic ign switch cont unit	Clear Fault Code	
NISSAN	All Mode	2015 - 2018	Electronic ign switch cont unit	Read Data Stream	
NISSAN	All Mode	2015 - 2018	Electronic ign switch cont unit	Module Information	
NISSAN	All Mode	2015 - 2018	Electronic ign switch cont unit	Actuation Test	Vehicle data
NISSAN	All Mode	2015 - 2018	Electronic ign switch cont unit	Special Function	Vin Registration
NISSAN	All Mode	2015 - 2018	Trailer recognition control unit	Read Fault Code	
NISSAN	All Mode	2015 - 2018	Trailer recognition control unit	Clear Fault Code	
NISSAN	All Mode	2015 - 2018	Trailer recognition control unit	Read Data Stream	
NISSAN	All Mode	2015 - 2018	Trailer recognition control unit	Module Information	
NISSAN	All Mode	2015 - 2018	Trailer recognition control unit	Actuation Test	Back-Up Lamp
NISSAN	All Mode	2015 - 2018	Trailer recognition control unit	Actuation Test	Stop Lamp
NISSAN	All Mode	2015 - 2018	Trailer recognition control unit	Actuation Test	Left Tail Lamp
NISSAN	All Mode	2015 - 2018	Trailer recognition control unit	Actuation Test	Right Tail Lamp
NISSAN	All Mode	2015 - 2018	Trailer recognition control unit	Actuation Test	Left Turn Signal
NISSAN	All Mode	2015 - 2018	Trailer recognition control unit	Actuation Test	Right Turn Signal
NISSAN	All Mode	2015 - 2018	Trailer recognition control unit	Actuation Test	Rear Fog Lamp Type
NISSAN	All Mode	2015 - 2018	Trailer recognition control unit	Actuation Test	Terminal 15g trailer socket
NISSAN	All Mode	2015 - 2018	Trailer recognition control unit	Actuation Test	Terminal 30g trailer socket
NISSAN	ALMERA	2012	AIRBAG2	Read Fault Code	
NISSAN	ALMERA	2012	AIRBAG2	Clear Fault Code	
NISSAN	ALMERA	2012	AIRBAG2	Read Data Stream	
NISSAN	ALMERA	2012	AIRBAG2	Module Information	
NISSAN	All Mode	2015 - 2018	Occupant classification unit	Read Data Stream	
NISSAN	All Mode	2015 - 2018	Occupant classification unit	Module Information	
NISSAN	All Mode	2015 - 2018	ICC sensor	Read Fault Code	
NISSAN	All Mode	2015 - 2018	ICC sensor	Clear Fault Code	
NISSAN	All Mode	2015 - 2018	ICC sensor	Read Data Stream	
NISSAN	All Mode	2015 - 2018	ICC sensor	Module Information	
NISSAN	All Mode	2015 - 2018	ICC sensor	Special Function	Calibration of long range radar sensor
NISSAN	All Mode	2015 - 2018	Parking assist	Read Fault Code	
NISSAN	All Mode	2015 - 2018	Parking assist	Clear Fault Code	
NISSAN	All Mode	2015 - 2018	Parking assist	Read Data Stream	
NISSAN	All Mode	2015 - 2018	Parking assist	Module Information	
NISSAN	All Mode	2015 - 2018	Parking assist	Special Function	Electrical contacting of sensor and functional test
NISSAN	All Mode	2015 - 2018	Steering column cont module	Read Fault Code	
NISSAN	All Mode	2015 - 2018	Steering column cont module	Clear Fault Code	
NISSAN	All Mode	2015 - 2018	Steering column cont module	Read Data Stream	
NISSAN	All Mode	2015 - 2018	Steering column cont module	Module Information	
NISSAN	All Mode	2015 - 2018	Steering column cont module	Actuation Test	Speedtronic light emitting diode
NISSAN	All Mode	2015 - 2018	Steering wheel switch pad	Read Data Stream	
NISSAN	All Mode	2015 - 2018	Steering wheel switch pad	Module Information	
NISSAN	All Mode	2015 - 2018	Radar sensor	Read Fault Code	
NISSAN	All Mode	2015 - 2018	Radar sensor	Clear Fault Code	
NISSAN	All Mode	2015 - 2018	Radar sensor	Read Data Stream	
NISSAN	All Mode	2015 - 2018	Radar sensor	Module Information	
NISSAN	All Mode	2015 - 2018	Radar sensor	Actuation Test	Check for invalid VIN
NISSAN	All Mode	2015 - 2018	Radar sensor	Actuation Test	CPA has received crash signal
NISSAN	All Mode	2015 - 2018	Radar sensor	Actuation Test	Collision prevention assist warning lamp
NISSAN	All Mode	2015 - 2018	Radar sensor	Special Function	Resetting of learned values of control unit
NISSAN	All Mode	2015 - 2018	Radar sensor	Special Function	Re learning

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

<b>make</b>	<b>model</b>	<b>year</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
NISSAN	All Mode	2015 - 2018	LED H/L control module RH	Read Data Stream	
NISSAN	All Mode	2015 - 2018	LED H/L control module RH	Module Information	
NISSAN	All Mode	2015 - 2018	LED H/L control module RH	Special Function	Reset operating hours counter of FR lamp fan motor 2
NISSAN	All Mode	2015 - 2018	LED H/L control module LH	Read Data Stream	
NISSAN	All Mode	2015 - 2018	LED H/L control module LH	Module Information	
NISSAN	All Mode	2015 - 2018	LED H/L control module LH	Special Function	Reset operating hours counter of FL lamp fan motor 2
NISSAN	All Mode	2015 - 2018	Side radar RH	Read Fault Code	
NISSAN	All Mode	2015 - 2018	Side radar RH	Clear Fault Code	
NISSAN	All Mode	2015 - 2018	Side radar RH	Read Data Stream	
NISSAN	All Mode	2015 - 2018	Side radar RH	Module Information	
NISSAN	All Mode	2015 - 2018	Side radar LH	Read Fault Code	
NISSAN	All Mode	2015 - 2018	Side radar LH	Clear Fault Code	
NISSAN	All Mode	2015 - 2018	Side radar LH	Read Data Stream	
NISSAN	All Mode	2015 - 2018	Side radar LH	Module Information	
NISSAN	All Mode	2015 - 2018	Front camera unit	Read Fault Code	
NISSAN	All Mode	2015 - 2018	Front camera unit	Clear Fault Code	
NISSAN	All Mode	2015 - 2018	Front camera unit	Read Data Stream	
NISSAN	All Mode	2015 - 2018	Front camera unit	Module Information	
NISSAN	All Mode	2015 - 2018	Front camera unit	Actuation Test	Check auxiliary heater heating element has a malfunction
NISSAN	All Mode	2015 - 2018	Front camera unit	Special Function	Retrofitting
NISSAN	All Mode	2015 - 2018	PCM (Powertrain Control Module)	Read Fault Code	
NISSAN	All Mode	2015 - 2018	PCM (Powertrain Control Module)	Clear Fault Code	
NISSAN	All Mode	2015 - 2018	PCM (Powertrain Control Module)	Read Data Stream	
NISSAN	All Mode	2015 - 2018	PCM (Powertrain Control Module)	Module Information	
NISSAN	All Mode	2015 - 2018	PCM (Powertrain Control Module)	Read Fault Code	
NISSAN	All Mode	2015 - 2018	PCM (Powertrain Control Module)	Clear Fault Code	
NISSAN	All Mode	2015 - 2018	PCM (Powertrain Control Module)	Read Data Stream	
NISSAN	All Mode	2015 - 2018	PCM (Powertrain Control Module)	Module Information	
NISSAN	All Mode	2015 - 2018	PCM (Powertrain Control Module)	Actuation Test	Check fuel filter module
NISSAN	All Mode	2015 - 2018	PCM (Powertrain Control Module)	Actuation Test	Check power supply of drivetrain control unit
NISSAN	All Mode	2015 - 2018	PCM (Powertrain Control Module)	Actuation Test	Check radiator shutter actuator
NISSAN	All Mode	2015 - 2018	PCM (Powertrain Control Module)	Actuation Test	Status Of Circuit
NISSAN	All Mode	2015 - 2018	PCM (Powertrain Control Module)	Actuation Test	Causes of engine stop prevention
NISSAN	All Mode	2015 - 2018	PCM (Powertrain Control Module)	Actuation Test	Engine start request by stop/start system
NISSAN	All Mode	2015 - 2018	PCM (Powertrain Control Module)	Actuation Test	Malfunction status of stop/start system
NISSAN	All Mode	2015 - 2018	PCM (Powertrain Control Module)	Actuation Test	Malfunction status of stop/start system stored
NISSAN	All Mode	2015 - 2018	PCM (Powertrain Control Module)	Actuation Test	Requirements for stop/start system
NISSAN	All Mode	2015 - 2018	PCM (Powertrain Control Module)	Special Function	Manual transmission main shifter shaft position sensor
NISSAN	All Mode	2015 - 2018	H/L control module RH	Read Fault Code	
NISSAN	All Mode	2015 - 2018	H/L control module RH	Clear Fault Code	
NISSAN	All Mode	2015 - 2018	H/L control module RH	Read Data Stream	
NISSAN	All Mode	2015 - 2018	H/L control module RH	Module Information	
NISSAN	All Mode	2015 - 2018	H/L control module RH	Actuation Test	Check right front lamp unit fan motor 1
NISSAN	All Mode	2015 - 2018	H/L control module RH	Actuation Test	Fan
NISSAN	All Mode	2015 - 2018	H/L control module RH	Special Function	Reset operating hours counter of FR lamp fan motor 1
NISSAN	All Mode	2015 - 2018	H/L control module RH	Special Function	Reset of operating hours counter of R pos DTRL turn sig
NISSAN	All Mode	2015 - 2018	H/L control module LH	Read Fault Code	
NISSAN	All Mode	2015 - 2018	H/L control module LH	Clear Fault Code	
NISSAN	All Mode	2015 - 2018	H/L control module LH	Read Data Stream	
NISSAN	All Mode	2015 - 2018	H/L control module LH	Module Information	
NISSAN	All Mode	2015 - 2018	H/L control module LH	Actuation Test	Check left front lamp unit fan motor 1
NISSAN	All Mode	2015 - 2018	H/L control module LH	Actuation Test	Light distribution position sensor
NISSAN	All Mode	2015 - 2018	H/L control module LH	Actuation Test	Light distribution actuator motor
NISSAN	All Mode	2015 - 2018	H/L control module LH	Actuation Test	Fan
NISSAN	All Mode	2015 - 2018	H/L control module LH	Actuation Test	Intelligent light spread
NISSAN	All Mode	2015 - 2018	H/L control module LH	Special Function	Adjustment of headlamps via diagnosis

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
NISSAN	All Mode	2015 - 2018	H/L control module LH	Special Function	Reset operating hours counter of FL lamp fan motor 1
NISSAN	All Mode	2015 - 2018	H/L control module LH	Special Function	Reset of operating hours counter of L pos DTRL turn sig
NISSAN	All Mode	2015 - 2018	H/L control module LH	Special Function	Zero position adjustment
NISSAN	All Mode	2006 - 2012	EHS/PKB	Read Fault Code	
NISSAN	All Mode	2006 - 2012	EHS/PKB	Clear Fault Code	
NISSAN	All Mode	2006 - 2012	EHS/PKB	Read Data Stream	
NISSAN	All Mode	2006 - 2012	EHS/PKB	Read Freeze Frame	
NISSAN	All Mode	2006 - 2012	EHS/PKB	Module Information	
NISSAN	All Mode	2006 - 2012	EHS/PKB	Actuation Test	EHS VALVE
NISSAN	All Mode	2006 - 2012	EHS/PKB	Actuation Test	EHS Indicator Lamp
NISSAN	All Mode	2006 - 2012	EHS/PKB	Actuation Test	EHS WARNING BUZZER
NISSAN	All Mode	2010 - 2016	EHS/PKB	Read Fault Code	
NISSAN	All Mode	2010 - 2016	EHS/PKB	Clear Fault Code	
NISSAN	All Mode	2010 - 2016	EHS/PKB	Read Data Stream	
NISSAN	All Mode	2010 - 2016	EHS/PKB	Read Freeze Frame	
NISSAN	All Mode	2010 - 2016	EHS/PKB	Module Information	
NISSAN	All Mode	2010 - 2016	EHS/PKB	Special Function	Actuator 0 Point Learning
NISSAN	All Mode	2010 - 2016	EHS/PKB	Special Function	Parking brake brake in (drag on)
NISSAN	All Mode	2015 - 2018	EHS/PKB	Read Fault Code	
NISSAN	All Mode	2015 - 2018	EHS/PKB	Clear Fault Code	
NISSAN	All Mode	2015 - 2018	EHS/PKB	Read Data Stream	
NISSAN	All Mode	2015 - 2018	EHS/PKB	Module Information	
NISSAN	All Mode	2015 - 2018	EHS/PKB	Special Function	Vin Registration
NISSAN	All Mode	2015 - 2018	EHS/PKB	Special Function	Electrical contact actuator/brake clearance setting
NISSAN	All Mode	2015 - 2018	EHS/PKB	Special Function	Calibration of electric parking brake control unit
NISSAN	All Mode	As of 2012	EHS/PKB	Read Fault Code	
NISSAN	All Mode	As of 2012	EHS/PKB	Clear Fault Code	
NISSAN	All Mode	As of 2012	EHS/PKB	Read Data Stream	
NISSAN	All Mode	As of 2012	EHS/PKB	Module Information	
NISSAN	All Mode	As of 2012	EHS/PKB	Special Function	Start Brake Pad Replacement
NISSAN	All Mode	As of 2012	EHS/PKB	Special Function	Finish Brake Pad Replacement
NISSAN	All Mode	As of 2012	EHS/PKB	Special Function	Initialization Position Adjustment
NISSAN	All Mode	As of 2012	EHS/PKB	Special Function	G Sensor Calibration
NISSAN	All Mode	As of 2012	EHS/PKB	Special Function	Clutch Sensor Reset
NISSAN	All Mode	As of 2012	EHS/PKB	Special Function	Brake Operation
NISSAN	All Mode	As of 2012	EHS/PKB	Special Function	Brake Release
NISSAN	All Mode	As of 2012	EHS/PKB	Special Function	System Mode Change
NISSAN	All Mode	As of 2012	EHS/PKB	Special Function	Auto Activation On (AT/CVT)
NISSAN	All Mode	2010 - 2017	Motor Control	Read Fault Code	
NISSAN	All Mode	2010 - 2017	Motor Control	Clear Fault Code	
NISSAN	All Mode	2010 - 2017	Motor Control	Read Data Stream	
NISSAN	All Mode	2010 - 2017	Motor Control	Read Freeze Frame	
NISSAN	All Mode	2010 - 2017	Motor Control	Module Information	
NISSAN	All Mode	2010 - 2017	Motor Control	Read Fault Code	
NISSAN	All Mode	2010 - 2017	Motor Control	Clear Fault Code	
NISSAN	All Mode	2010 - 2017	Motor Control	Read Data Stream	
NISSAN	All Mode	2010 - 2017	Motor Control	Module Information	
NISSAN	All Mode	2010 - 2017	Motor Control	Read Fault Code	
NISSAN	All Mode	2010 - 2017	Motor Control	Clear Fault Code	
NISSAN	All Mode	2010 - 2017	Motor Control	Read Data Stream	
NISSAN	All Mode	2010 - 2017	Motor Control	Module Information	
NISSAN	All Mode	2010 - 2017	Motor Control	Special Function	Clear Output Limit Reason
NISSAN	All Mode	2010 - 2017	Motor Control	Special Function	Resolver Write
NISSAN	All Mode	2013 - 2018	Motor Control	Read Fault Code	
NISSAN	All Mode	2013 - 2018	Motor Control	Clear Fault Code	
NISSAN	All Mode	2013 - 2018	Motor Control	Read Data Stream	
NISSAN	All Mode	2013 - 2018	Motor Control	Module Information	
NISSAN	All Mode	2013 - 2017	Motor Control	Read Fault Code	
NISSAN	All Mode	2013 - 2017	Motor Control	Clear Fault Code	
NISSAN	All Mode	2013 - 2017	Motor Control	Read Data Stream	
NISSAN	All Mode	2013 - 2017	Motor Control	Module Information	
NISSAN	All Mode	2013 - 2017	Motor Control	Special Function	Resolver Offset
NISSAN	LEAF	2016	Motor Control	Read Fault Code	
NISSAN	LEAF	2016	Motor Control	Clear Fault Code	
NISSAN	LEAF	2016	Motor Control	Read Data Stream	
NISSAN	LEAF	2016	Motor Control	Module Information	
NISSAN	LEAF	2016	Motor Control	Special Function	Clear Output Limit Reason
NISSAN	Note e-POWER	2016	Motor Control	Read Fault Code	
NISSAN	Note e-POWER	2016	Motor Control	Clear Fault Code	
NISSAN	Note e-POWER	2016	Motor Control	Read Data Stream	



**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
NISSAN	All Mode	2015 - 2017	EPS (Electronic Power Steering)	Special Function	Vin Registration
NISSAN	All Mode	2015 - 2017	EPS (Electronic Power Steering)	Special Function	Write date of last after sales OPE
NISSAN	All Mode	2015 - 2018	EPS (Electronic Power Steering)	Read Fault Code	
NISSAN	All Mode	2015 - 2018	EPS (Electronic Power Steering)	Clear Fault Code	
NISSAN	All Mode	2015 - 2018	EPS (Electronic Power Steering)	Read Data Stream	
NISSAN	All Mode	2015 - 2018	EPS (Electronic Power Steering)	Module Information	
NISSAN	All Mode	2015 - 2018	EPS (Electronic Power Steering)	Special Function	Calibration of EPS torque sensor
NISSAN	All Mode	2015 - 2018	EPS (Electronic Power Steering)	Special Function	Resetting center position of steering
NISSAN	All Mode	2015 - 2018	EPS (Electronic Power Steering)	Special Function	Re learning
NISSAN	All Mode	2009 - 2017	EPS (Electronic Power Steering)	Read Fault Code	
NISSAN	All Mode	2009 - 2017	EPS (Electronic Power Steering)	Clear Fault Code	
NISSAN	All Mode	2009 - 2017	EPS (Electronic Power Steering)	Read Data Stream	
NISSAN	All Mode	2009 - 2017	EPS (Electronic Power Steering)	Module Information	
NISSAN	All Mode	2009 - 2017	EPS (Electronic Power Steering)	Special Function	ST Angle Sensor Adjustment
NISSAN	redi GO	2016	EPS (Electronic Power Steering)	Read Fault Code	
NISSAN	redi GO	2016	EPS (Electronic Power Steering)	Clear Fault Code	
NISSAN	redi GO	2016	EPS (Electronic Power Steering)	Read Data Stream	
NISSAN	redi GO	2016	EPS (Electronic Power Steering)	Module Information	
NISSAN	redi GO	2016	EPS (Electronic Power Steering)	Special Function	Vin Registration
NISSAN	All Mode	Up to 2018	EPS (Electronic Power Steering)	Read Fault Code	
NISSAN	All Mode	Up to 2018	EPS (Electronic Power Steering)	Clear Fault Code	
NISSAN	All Mode	Up to 2018	EPS (Electronic Power Steering)	Read Data Stream	
NISSAN	All Mode	Up to 2018	EPS (Electronic Power Steering)	Module Information	
NISSAN	NV350 URVAN/NV350	2012	EPS (Electronic Power Steering)	Read Fault Code	
NISSAN	NV350 URVAN/NV350	2012	EPS (Electronic Power Steering)	Clear Fault Code	
NISSAN	NV350 URVAN/NV350	2012	EPS (Electronic Power Steering)	Read Data Stream	
NISSAN	NV350 URVAN/NV350	2012	EPS (Electronic Power Steering)	Module Information	
NISSAN	All Mode	As of 2012	EPS (Electronic Power Steering)	Read Fault Code	
NISSAN	All Mode	As of 2012	EPS (Electronic Power Steering)	Clear Fault Code	
NISSAN	All Mode	As of 2012	EPS (Electronic Power Steering)	Read Data Stream	
NISSAN	All Mode	As of 2012	EPS (Electronic Power Steering)	Module Information	
NISSAN	All Mode	As of 2012	EPS (Electronic Power Steering)	Special Function	DAST CALIBRATION (MODE2)
NISSAN	All Mode	As of 2012	EPS (Electronic Power Steering)	Special Function	DAST CALIBRATION (MODE1)
NISSAN	NP200	2008	EPS (Electronic Power Steering)	Read Fault Code	
NISSAN	NP200	2008	EPS (Electronic Power Steering)	Clear Fault Code	
NISSAN	NP200	2008	EPS (Electronic Power Steering)	Read Data Stream	
NISSAN	NP200	2008	EPS (Electronic Power Steering)	Read Freeze Frame	
NISSAN	NP200	2008	EPS (Electronic Power Steering)	Module Information	
NISSAN	NP200	2008	EPS (Electronic Power Steering)	Special Function	Vin Registration
NISSAN	NP200	2008	EPS (Electronic Power Steering)	Special Function	Write Date Of After Sales Operation
NISSAN	NP200	2008	EPS (Electronic Power Steering)	Read Fault Code	
NISSAN	NP200	2008	EPS (Electronic Power Steering)	Clear Fault Code	
NISSAN	NP200	2008	EPS (Electronic Power Steering)	Read Data Stream	
NISSAN	NP200	2008	EPS (Electronic Power Steering)	Read Freeze Frame	
NISSAN	NP200	2008	EPS (Electronic Power Steering)	Module Information	
NISSAN	NP200	2008	EPS (Electronic Power Steering)	Special Function	Vin Registration
NISSAN	NP200	2008	EPS (Electronic Power Steering)	Special Function	Write Date Of After Sales Operation
NISSAN	All Mode	Up to 2011	EPS (Electronic Power Steering)	Read Fault Code	
NISSAN	All Mode	Up to 2011	EPS (Electronic Power Steering)	Clear Fault Code	
NISSAN	All Mode	Up to 2011	EPS (Electronic Power Steering)	Read Data Stream	
NISSAN	ALTIMA Hybrid	2007	ABS (Anti-lock Braking System)	Read Fault Code	
NISSAN	ALTIMA Hybrid	2007	ABS (Anti-lock Braking System)	Clear Fault Code	
NISSAN	ALTIMA Hybrid	2007	ABS (Anti-lock Braking System)	Read Data Stream	
NISSAN	ALTIMA Hybrid	2007	ABS (Anti-lock Braking System)	Module Information	
NISSAN	All Mode	Up to 2018	ABS (Anti-lock Braking System)	Read Fault Code	
NISSAN	All Mode	Up to 2018	ABS (Anti-lock Braking System)	Clear Fault Code	
NISSAN	All Mode	Up to 2018	ABS (Anti-lock Braking System)	Read Data Stream	
NISSAN	All Mode	Up to 2018	ABS (Anti-lock Braking System)	Read Freeze Frame	
NISSAN	All Mode	Up to 2018	ABS (Anti-lock Braking System)	Module Information	
NISSAN	All Mode	Up to 2018	ABS (Anti-lock Braking System)	Function Test	
NISSAN	All Mode	Up to 2018	ABS (Anti-lock Braking System)	Actuation Test	FR RH SOL
NISSAN	All Mode	Up to 2018	ABS (Anti-lock Braking System)	Actuation Test	FR LH SOL
NISSAN	All Mode	Up to 2018	ABS (Anti-lock Braking System)	Actuation Test	RR RH SOL
NISSAN	All Mode	Up to 2018	ABS (Anti-lock Braking System)	Actuation Test	RR LH SOL
NISSAN	All Mode	Up to 2018	ABS (Anti-lock Braking System)	Actuation Test	ABS MOTOR
NISSAN	All Mode	Up to 2018	ABS (Anti-lock Braking System)	Actuation Test	FR RH ABS SOLENOID(ACT)
NISSAN	All Mode	Up to 2018	ABS (Anti-lock Braking System)	Actuation Test	FR LH ABS SOLENOID(ACT)
NISSAN	All Mode	Up to 2018	ABS (Anti-lock Braking System)	Actuation Test	RR RH ABS SOLENOID(ACT)
NISSAN	All Mode	Up to 2018	ABS (Anti-lock Braking System)	Actuation Test	RR LH ABS SOLENOID(ACT)
NISSAN	All Mode	Up to 2018	ABS (Anti-lock Braking System)	Special Function	ST Angle Sensor Adjustment
NISSAN	All Mode	Up to 2018	ABS (Anti-lock Braking System)	Special Function	Decel G Sen Calibration
NISSAN	All Mode	Up to 2018	ABS (Anti-lock Braking System)	Special Function	Valve Calibration
NISSAN	All Mode	Up to 2018	ABS (Anti-lock Braking System)	Special Function	Act Or Deact Roller Bench Test Mode
NISSAN	All Mode	Up to 2017	ABS (Anti-lock Braking System)	Read Fault Code	





**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

<b>make</b>	<b>model</b>	<b>year</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
NISSAN	NV400	2011	ABS (Anti-lock Braking System)	Actuation Test	FR R/H Wheel Solenoid Valves
NISSAN	NV400	2011	ABS (Anti-lock Braking System)	Actuation Test	FR L/H Wheel Solenoid Valves
NISSAN	NV400	2011	ABS (Anti-lock Braking System)	Actuation Test	RR R/H Wheel Solenoid Valves
NISSAN	NV400	2011	ABS (Anti-lock Braking System)	Actuation Test	RR L/H Wheel Solenoid Valves
NISSAN	NV400	2011	ABS (Anti-lock Braking System)	Special Function	Speedo Index
NISSAN	NV400	2011	ABS (Anti-lock Braking System)	Special Function	Write date of last after sales OPE
NISSAN	NV400	2011	ABS (Anti-lock Braking System)	Special Function	Check Target Teeth
NISSAN	NV400	2011	ABS (Anti-lock Braking System)	Special Function	BLD HYD UNIT BRK CIRC
NISSAN	NV400	2011	ABS (Anti-lock Braking System)	Read Fault Code	
NISSAN	NV400	2011	ABS (Anti-lock Braking System)	Clear Fault Code	
NISSAN	NV400	2011	ABS (Anti-lock Braking System)	Read Data Stream	
NISSAN	NV400	2011	ABS (Anti-lock Braking System)	Module Information	
NISSAN	NV400	2011	ABS (Anti-lock Braking System)	Actuation Test	Pump Motor Test
NISSAN	NV400	2011	ABS (Anti-lock Braking System)	Actuation Test	FR R/H Wheel Solenoid Valves
NISSAN	NV400	2011	ABS (Anti-lock Braking System)	Actuation Test	FR L/H Wheel Solenoid Valves
NISSAN	NV400	2011	ABS (Anti-lock Braking System)	Actuation Test	RR R/H Wheel Solenoid Valves
NISSAN	NV400	2011	ABS (Anti-lock Braking System)	Actuation Test	RR L/H Wheel Solenoid Valves
NISSAN	NV400	2011	ABS (Anti-lock Braking System)	Actuation Test	Stop Lights Activation Relay
NISSAN	NV400	2011	ABS (Anti-lock Braking System)	Special Function	Speedo Index
NISSAN	NV400	2011	ABS (Anti-lock Braking System)	Special Function	Write date of last after sales OPE
NISSAN	NV400	2011	ABS (Anti-lock Braking System)	Special Function	Longitudinal Accel Sen
NISSAN	NV400	2011	ABS (Anti-lock Braking System)	Special Function	Steering Whl Angle Sen
NISSAN	NV400	2011	ABS (Anti-lock Braking System)	Special Function	Check Target Teeth
NISSAN	NV400	2011	ABS (Anti-lock Braking System)	Special Function	BLD HYD UNIT BRK CIRC
NISSAN	NV400	2011	ABS (Anti-lock Braking System)	Special Function	Vin Registration
NISSAN	All Mode	2012 - 2018	ABS (Anti-lock Braking System)	Read Fault Code	
NISSAN	All Mode	2012 - 2018	ABS (Anti-lock Braking System)	Clear Fault Code	
NISSAN	All Mode	2012 - 2018	ABS (Anti-lock Braking System)	Read Data Stream	
NISSAN	All Mode	2012 - 2018	ABS (Anti-lock Braking System)	Module Information	
NISSAN	All Mode	2012 - 2018	ABS (Anti-lock Braking System)	Actuation Test	FR RH SOL
NISSAN	All Mode	2012 - 2018	ABS (Anti-lock Braking System)	Actuation Test	FR LH SOL
NISSAN	All Mode	2012 - 2018	ABS (Anti-lock Braking System)	Actuation Test	RR RH SOL
NISSAN	All Mode	2012 - 2018	ABS (Anti-lock Braking System)	Actuation Test	RR LH SOL
NISSAN	All Mode	2012 - 2018	ABS (Anti-lock Braking System)	Actuation Test	ABS MOTOR
NISSAN	All Mode	2012 - 2018	ABS (Anti-lock Braking System)	Actuation Test	FR RH ABS SOLENOID(ACT)
NISSAN	All Mode	2012 - 2018	ABS (Anti-lock Braking System)	Actuation Test	FR LH ABS SOLENOID(ACT)
NISSAN	All Mode	2012 - 2018	ABS (Anti-lock Braking System)	Actuation Test	RR RH ABS SOLENOID(ACT)
NISSAN	All Mode	2012 - 2018	ABS (Anti-lock Braking System)	Actuation Test	RR LH ABS SOLENOID(ACT)
NISSAN	All Mode	2012 - 2018	ABS (Anti-lock Braking System)	Actuation Test	STOP LAMP ON RELAY
NISSAN	All Mode	2012 - 2018	ABS (Anti-lock Braking System)	Special Function	ST Angle Sensor Adjustment
NISSAN	All Mode	2012 - 2018	ABS (Anti-lock Braking System)	Special Function	Decel G Sen Calibration
NISSAN	All Mode	2012 - 2018	ABS (Anti-lock Braking System)	Special Function	STROKE SENSOR CALIBRATION
NISSAN	All Mode	2006 - 2009	ABS (Anti-lock Braking System)	Read Fault Code	
NISSAN	All Mode	2006 - 2009	ABS (Anti-lock Braking System)	Clear Fault Code	
NISSAN	All Mode	2006 - 2009	ABS (Anti-lock Braking System)	Read Data Stream	
NISSAN	All Mode	2006 - 2009	ABS (Anti-lock Braking System)	Module Information	
NISSAN	All Mode	2006 - 2009	ABS (Anti-lock Braking System)	Actuation Test	Pump Motor Test
NISSAN	All Mode	2006 - 2009	ABS (Anti-lock Braking System)	Actuation Test	VEHICLE SPEED INFORMATION
NISSAN	All Mode	2006 - 2009	ABS (Anti-lock Braking System)	Actuation Test	WHEEL SPEED SENSORS SUPPLY TEST
NISSAN	All Mode	2006 - 2009	ABS (Anti-lock Braking System)	Special Function	Speedo Index
NISSAN	All Mode	2006 - 2009	ABS (Anti-lock Braking System)	Special Function	Vin Registration
NISSAN	All Mode	2006 - 2009	ABS (Anti-lock Braking System)	Special Function	Write date of last after sales OPE
NISSAN	All Mode	2006 - 2009	ABS (Anti-lock Braking System)	Special Function	VEH. Speed At Initialisation
NISSAN	All Mode	2006 - 2009	ABS (Anti-lock Braking System)	Special Function	Check Target Teeth
NISSAN	All Mode	2006 - 2009	ABS (Anti-lock Braking System)	Special Function	Bleed Hydraulic Unit And Braking Circuits
NISSAN	All Mode	2006 - 2009	ABS (Anti-lock Braking System)	Read Fault Code	
NISSAN	All Mode	2006 - 2009	ABS (Anti-lock Braking System)	Clear Fault Code	
NISSAN	All Mode	2006 - 2009	ABS (Anti-lock Braking System)	Read Data Stream	
NISSAN	All Mode	2006 - 2009	ABS (Anti-lock Braking System)	Module Information	
NISSAN	All Mode	2006 - 2009	ABS (Anti-lock Braking System)	Actuation Test	WHEEL SPEED SENSORS SUPPLY TEST
NISSAN	All Mode	2006 - 2009	ABS (Anti-lock Braking System)	Actuation Test	FR R/H Wheel Solenoid Valves
NISSAN	All Mode	2006 - 2009	ABS (Anti-lock Braking System)	Actuation Test	FR L/H Wheel Solenoid Valves

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

<b>make</b>	<b>model</b>	<b>year</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
NISSAN	All Mode	2006 - 2009	ABS (Anti-lock Braking System)	Actuation Test	RR R/H Wheel Solenoid Valves
NISSAN	All Mode	2006 - 2009	ABS (Anti-lock Braking System)	Actuation Test	RR L/H Wheel Solenoid Valves
NISSAN	All Mode	2006 - 2009	ABS (Anti-lock Braking System)	Actuation Test	Pump Motor Test
NISSAN	All Mode	2006 - 2009	ABS (Anti-lock Braking System)	Actuation Test	VEHICLE SPEED INFORMATION
NISSAN	All Mode	2006 - 2009	ABS (Anti-lock Braking System)	Special Function	Vehicle Parameters
NISSAN	All Mode	2006 - 2009	ABS (Anti-lock Braking System)	Special Function	Speedo Index
NISSAN	All Mode	2006 - 2009	ABS (Anti-lock Braking System)	Special Function	Vin Registration
NISSAN	All Mode	2006 - 2009	ABS (Anti-lock Braking System)	Special Function	Write date of last after sales OPE
NISSAN	All Mode	2006 - 2009	ABS (Anti-lock Braking System)	Special Function	VEH. Speed At Initialisation
NISSAN	All Mode	2006 - 2009	ABS (Anti-lock Braking System)	Special Function	Steering Wheel Angle Sensor
NISSAN	All Mode	2006 - 2009	ABS (Anti-lock Braking System)	Special Function	Longitudinal Acceleration Sensor
NISSAN	All Mode	2006 - 2009	ABS (Anti-lock Braking System)	Special Function	ESP Sensor Programming
NISSAN	All Mode	2006 - 2009	ABS (Anti-lock Braking System)	Special Function	Check Target Teeth
NISSAN	All Mode	2006 - 2009	ABS (Anti-lock Braking System)	Special Function	Bleed Hydraulic Unit And Braking Circuits
NISSAN	All Mode	2006 - 2009	ABS (Anti-lock Braking System)	Special Function	ESP A-Recn Thrsh
NISSAN	NV400	2011	ABS (Anti-lock Braking System)	Read Fault Code	
NISSAN	NV400	2011	ABS (Anti-lock Braking System)	Clear Fault Code	
NISSAN	NV400	2011	ABS (Anti-lock Braking System)	Read Data Stream	
NISSAN	NV400	2011	ABS (Anti-lock Braking System)	Module Information	
NISSAN	NV400	2011	ABS (Anti-lock Braking System)	Actuation Test	Pump Motor Test
NISSAN	NV400	2011	ABS (Anti-lock Braking System)	Actuation Test	FR R/H Wheel Solenoid Valves
NISSAN	NV400	2011	ABS (Anti-lock Braking System)	Actuation Test	FR L/H Wheel Solenoid Valves
NISSAN	NV400	2011	ABS (Anti-lock Braking System)	Actuation Test	RR R/H Wheel Solenoid Valves
NISSAN	NV400	2011	ABS (Anti-lock Braking System)	Actuation Test	RR L/H Wheel Solenoid Valves
NISSAN	NV400	2011	ABS (Anti-lock Braking System)	Special Function	Vin Registration
NISSAN	NV400	2011	ABS (Anti-lock Braking System)	Special Function	Speedo Index
NISSAN	NV400	2011	ABS (Anti-lock Braking System)	Special Function	Write date of last after sales OPE
NISSAN	NV400	2011	ABS (Anti-lock Braking System)	Special Function	Check Target Teeth
NISSAN	NV400	2011	ABS (Anti-lock Braking System)	Special Function	Bleed Hydraulic Unit And Braking Circuits
NISSAN	NV400	2014	ABS (Anti-lock Braking System)	Read Fault Code	
NISSAN	NV400	2014	ABS (Anti-lock Braking System)	Clear Fault Code	
NISSAN	NV400	2014	ABS (Anti-lock Braking System)	Read Data Stream	
NISSAN	NV400	2014	ABS (Anti-lock Braking System)	Module Information	
NISSAN	NV400	2014	ABS (Anti-lock Braking System)	Function Test	
NISSAN	NV400	2014	ABS (Anti-lock Braking System)	Actuation Test	FR L/H Wheel Solenoid Valves
NISSAN	NV400	2014	ABS (Anti-lock Braking System)	Actuation Test	FR R/H Wheel Solenoid Valves
NISSAN	NV400	2014	ABS (Anti-lock Braking System)	Actuation Test	RR L/H Wheel Solenoid Valves
NISSAN	NV400	2014	ABS (Anti-lock Braking System)	Actuation Test	RR R/H Wheel Solenoid Valves
NISSAN	NV400	2014	ABS (Anti-lock Braking System)	Actuation Test	Pump Motor Test
NISSAN	NV400	2014	ABS (Anti-lock Braking System)	Actuation Test	BLEED FRONT L/H WHEEL
NISSAN	NV400	2014	ABS (Anti-lock Braking System)	Actuation Test	BLEED FRONT R/H WHEEL
NISSAN	NV400	2014	ABS (Anti-lock Braking System)	Actuation Test	BLEED REAR L/H WHEEL
NISSAN	NV400	2014	ABS (Anti-lock Braking System)	Actuation Test	BLEED REAR R/H WHEEL
NISSAN	NV400	2014	ABS (Anti-lock Braking System)	Actuation Test	Stop Pump Motor
NISSAN	NV400	2014	ABS (Anti-lock Braking System)	Actuation Test	Stop Lights Activation Relay
NISSAN	NV400	2014	ABS (Anti-lock Braking System)	Actuation Test	Vehicle Speed Information
NISSAN	NV400	2014	ABS (Anti-lock Braking System)	Actuation Test	REQUEST TO SWITCH ON HAZARD WARNING LAMPS
NISSAN	NV400	2014	ABS (Anti-lock Braking System)	Special Function	Steering Wheel Angle Offset Sensor
NISSAN	NV400	2014	ABS (Anti-lock Braking System)	Special Function	Transverse Acceleration Offset Sensor
NISSAN	NV400	2014	ABS (Anti-lock Braking System)	Special Function	Brake Pressure Offset Sensor
NISSAN	NV400	2014	ABS (Anti-lock Braking System)	Special Function	RESET
NISSAN	NV400	2014	ABS (Anti-lock Braking System)	Special Function	Check Target Teeth
NISSAN	NV400	2014	ABS (Anti-lock Braking System)	Special Function	Vin Registration
NISSAN	NV400	2014	ABS (Anti-lock Braking System)	Special Function	Steering Wheel Angle Sensor
NISSAN	NV400	2014	ABS (Anti-lock Braking System)	Special Function	Write date of last after sales OPE
NISSAN	NV400	2014	ABS (Anti-lock Braking System)	Special Function	Speedo Index
NISSAN	NV400	2014	ABS (Anti-lock Braking System)	Special Function	Acceleration Sensor
NISSAN	NV400	2014	ABS (Anti-lock Braking System)	Special Function	Hill Start

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
NISSAN	All Mode	2015 - 2017	ABS (Anti-lock Braking System)	Read Fault Code	
NISSAN	All Mode	2015 - 2017	ABS (Anti-lock Braking System)	Clear Fault Code	
NISSAN	All Mode	2015 - 2017	ABS (Anti-lock Braking System)	Read Data Stream	
NISSAN	All Mode	2015 - 2017	ABS (Anti-lock Braking System)	Module Information	
NISSAN	All Mode	2015 - 2017	ABS (Anti-lock Braking System)	Actuation Test	FR L/H Wheel Solenoid Valves
NISSAN	All Mode	2015 - 2017	ABS (Anti-lock Braking System)	Actuation Test	FR R/H Wheel Solenoid Valves
NISSAN	All Mode	2015 - 2017	ABS (Anti-lock Braking System)	Actuation Test	RR L/H Wheel Solenoid Valves
NISSAN	All Mode	2015 - 2017	ABS (Anti-lock Braking System)	Actuation Test	RR R/H Wheel Solenoid Valves
NISSAN	All Mode	2015 - 2017	ABS (Anti-lock Braking System)	Actuation Test	Pump Motor Test
NISSAN	All Mode	2015 - 2017	ABS (Anti-lock Braking System)	Actuation Test	BLEED FRONT L/H WHEEL
NISSAN	All Mode	2015 - 2017	ABS (Anti-lock Braking System)	Actuation Test	BLEED FRONT R/H WHEEL
NISSAN	All Mode	2015 - 2017	ABS (Anti-lock Braking System)	Actuation Test	BLEED REAR L/H WHEEL
NISSAN	All Mode	2015 - 2017	ABS (Anti-lock Braking System)	Actuation Test	BLEED REAR R/H WHEEL
NISSAN	All Mode	2015 - 2017	ABS (Anti-lock Braking System)	Actuation Test	Stop Pump Motor
NISSAN	All Mode	2015 - 2017	ABS (Anti-lock Braking System)	Actuation Test	Stop Lights Activation Relay
NISSAN	All Mode	2015 - 2017	ABS (Anti-lock Braking System)	Actuation Test	Vehicle Speed Information
NISSAN	All Mode	2015 - 2017	ABS (Anti-lock Braking System)	Actuation Test	REQUEST TO SWITCH ON HAZARD WARNING LAMPS
NISSAN	All Mode	2015 - 2017	ABS (Anti-lock Braking System)	Actuation Test	ENGINE TORQUE REFERENCE VALUE
NISSAN	All Mode	2015 - 2017	ABS (Anti-lock Braking System)	Special Function	Speedo Index
NISSAN	All Mode	2015 - 2017	ABS (Anti-lock Braking System)	Special Function	Write date of last after sales OPE
NISSAN	All Mode	2015 - 2017	ABS (Anti-lock Braking System)	Special Function	Steering Wheel Angle Sensor
NISSAN	All Mode	2015 - 2017	ABS (Anti-lock Braking System)	Special Function	Vin Registration
NISSAN	All Mode	2015 - 2017	ABS (Anti-lock Braking System)	Special Function	Acceleration Sensor
NISSAN	All Mode	2015 - 2017	ABS (Anti-lock Braking System)	Special Function	Transverse Acceleration Offset Sensor
NISSAN	All Mode	2015 - 2017	ABS (Anti-lock Braking System)	Special Function	Steering Wheel Angle Offset Sensor
NISSAN	All Mode	2015 - 2017	ABS (Anti-lock Braking System)	Special Function	Brake Pressure Offset Sensor
NISSAN	All Mode	2015 - 2017	ABS (Anti-lock Braking System)	Special Function	RESET
NISSAN	All Mode	2015 - 2017	ABS (Anti-lock Braking System)	Special Function	Longitudinal Acceleration Sensor Offset
NISSAN	All Mode	2015 - 2017	ABS (Anti-lock Braking System)	Special Function	Check Target Teeth
NISSAN	All Mode	2015 - 2017	ABS (Anti-lock Braking System)	Special Function	Hill Start
NISSAN	All Mode	2015 - 2017	ABS (Anti-lock Braking System)	Read Fault Code	
NISSAN	All Mode	2015 - 2017	ABS (Anti-lock Braking System)	Clear Fault Code	
NISSAN	All Mode	2015 - 2017	ABS (Anti-lock Braking System)	Read Data Stream	
NISSAN	All Mode	2015 - 2017	ABS (Anti-lock Braking System)	Module Information	
NISSAN	All Mode	2015 - 2017	ABS (Anti-lock Braking System)	Actuation Test	FR L/H Wheel Solenoid Valves
NISSAN	All Mode	2015 - 2017	ABS (Anti-lock Braking System)	Actuation Test	FR R/H Wheel Solenoid Valves
NISSAN	All Mode	2015 - 2017	ABS (Anti-lock Braking System)	Actuation Test	RR L/H Wheel Solenoid Valves
NISSAN	All Mode	2015 - 2017	ABS (Anti-lock Braking System)	Actuation Test	RR R/H Wheel Solenoid Valves
NISSAN	All Mode	2015 - 2017	ABS (Anti-lock Braking System)	Actuation Test	Pump Motor Test
NISSAN	All Mode	2015 - 2017	ABS (Anti-lock Braking System)	Actuation Test	BLEED FRONT L/H WHEEL
NISSAN	All Mode	2015 - 2017	ABS (Anti-lock Braking System)	Actuation Test	BLEED FRONT R/H WHEEL
NISSAN	All Mode	2015 - 2017	ABS (Anti-lock Braking System)	Actuation Test	BLEED REAR L/H WHEEL
NISSAN	All Mode	2015 - 2017	ABS (Anti-lock Braking System)	Actuation Test	BLEED REAR R/H WHEEL
NISSAN	All Mode	2015 - 2017	ABS (Anti-lock Braking System)	Actuation Test	Stop Pump Motor
NISSAN	All Mode	2015 - 2017	ABS (Anti-lock Braking System)	Actuation Test	Vehicle Speed Information
NISSAN	All Mode	2015 - 2017	ABS (Anti-lock Braking System)	Special Function	Speedo Index
NISSAN	All Mode	2015 - 2017	ABS (Anti-lock Braking System)	Special Function	Write date of last after sales OPE
NISSAN	All Mode	2015 - 2017	ABS (Anti-lock Braking System)	Special Function	Vin Registration
NISSAN	All Mode	2015 - 2017	ABS (Anti-lock Braking System)	Special Function	RESET
NISSAN	All Mode	2015 - 2017	ABS (Anti-lock Braking System)	Special Function	Longitudinal Acceleration Sensor Offset
NISSAN	All Mode	2015 - 2017	ABS (Anti-lock Braking System)	Special Function	Transverse Acceleration Offset Sensor
NISSAN	All Mode	2015 - 2017	ABS (Anti-lock Braking System)	Special Function	Check Target Teeth
NISSAN	All Mode	2015 - 2018	ABS (Anti-lock Braking System)	Read Fault Code	
NISSAN	All Mode	2015 - 2018	ABS (Anti-lock Braking System)	Clear Fault Code	
NISSAN	All Mode	2015 - 2018	ABS (Anti-lock Braking System)	Read Data Stream	
NISSAN	All Mode	2015 - 2018	ABS (Anti-lock Braking System)	Module Information	
NISSAN	All Mode	2015 - 2018	ABS (Anti-lock Braking System)	Actuation Test	Check power supply of solenoid valves
NISSAN	All Mode	2015 - 2018	ABS (Anti-lock Braking System)	Actuation Test	Defragment memory
NISSAN	All Mode	2015 - 2018	ABS (Anti-lock Braking System)	Actuation Test	Check power supply of high press and return flow pump

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
NISSAN	All Mode	2015 - 2018	ABS (Anti-lock Braking System)	Actuation Test	Rear left pressure regulating valve pressure release
NISSAN	All Mode	2015 - 2018	ABS (Anti-lock Braking System)	Special Function	Vin Registration
NISSAN	All Mode	2015 - 2018	ABS (Anti-lock Braking System)	Special Function	Calibration of acceleration sensor
NISSAN	All Mode	2016 - 2017	ABS (Anti-lock Braking System)	Read Fault Code	
NISSAN	All Mode	2016 - 2017	ABS (Anti-lock Braking System)	Clear Fault Code	
NISSAN	All Mode	2016 - 2017	ABS (Anti-lock Braking System)	Read Data Stream	
NISSAN	All Mode	2016 - 2017	ABS (Anti-lock Braking System)	Module Information	
NISSAN	All Mode	2016 - 2017	ABS (Anti-lock Braking System)	Actuation Test	FR RH SOL
NISSAN	All Mode	2016 - 2017	ABS (Anti-lock Braking System)	Actuation Test	FR LH SOL
NISSAN	All Mode	2016 - 2017	ABS (Anti-lock Braking System)	Actuation Test	RR RH SOL
NISSAN	All Mode	2016 - 2017	ABS (Anti-lock Braking System)	Actuation Test	RR LH SOL
NISSAN	All Mode	2016 - 2017	ABS (Anti-lock Braking System)	Actuation Test	ABS MOTOR
NISSAN	All Mode	2016 - 2017	ABS (Anti-lock Braking System)	Actuation Test	FR RH ABS SOLENOID(ACT)
NISSAN	All Mode	2016 - 2017	ABS (Anti-lock Braking System)	Actuation Test	FR LH ABS SOLENOID(ACT)
NISSAN	All Mode	2016 - 2017	ABS (Anti-lock Braking System)	Actuation Test	RR RH ABS SOLENOID(ACT)
NISSAN	All Mode	2016 - 2017	ABS (Anti-lock Braking System)	Actuation Test	RR LH ABS SOLENOID(ACT)
NISSAN	All Mode	2016 - 2017	ABS (Anti-lock Braking System)	Actuation Test	STOP LAMP ON RELAY
NISSAN	All Mode	2016 - 2017	ABS (Anti-lock Braking System)	Special Function	ST Angle Sensor Adjustment
NISSAN	All Mode	2016 - 2017	ABS (Anti-lock Braking System)	Special Function	Decel G Sen Calibration
NISSAN	All Mode	2015 - 2017	ABS (Anti-lock Braking System)	Read Fault Code	
NISSAN	All Mode	2015 - 2017	ABS (Anti-lock Braking System)	Clear Fault Code	
NISSAN	All Mode	2015 - 2017	ABS (Anti-lock Braking System)	Read Data Stream	
NISSAN	All Mode	2015 - 2017	ABS (Anti-lock Braking System)	Module Information	
NISSAN	All Mode	2015 - 2017	ABS (Anti-lock Braking System)	Actuation Test	FR RH SOL
NISSAN	All Mode	2015 - 2017	ABS (Anti-lock Braking System)	Actuation Test	FR LH SOL
NISSAN	All Mode	2015 - 2017	ABS (Anti-lock Braking System)	Actuation Test	RR RH SOL
NISSAN	All Mode	2015 - 2017	ABS (Anti-lock Braking System)	Actuation Test	RR LH SOL
NISSAN	All Mode	2015 - 2017	ABS (Anti-lock Braking System)	Actuation Test	ABS MOTOR
NISSAN	All Mode	2015 - 2017	ABS (Anti-lock Braking System)	Actuation Test	FR RH ABS SOLENOID(ACT)
NISSAN	All Mode	2015 - 2017	ABS (Anti-lock Braking System)	Actuation Test	FR LH ABS SOLENOID(ACT)
NISSAN	All Mode	2015 - 2017	ABS (Anti-lock Braking System)	Actuation Test	RR RH ABS SOLENOID(ACT)
NISSAN	All Mode	2015 - 2017	ABS (Anti-lock Braking System)	Actuation Test	RR LH ABS SOLENOID(ACT)
NISSAN	All Mode	2015 - 2017	ABS (Anti-lock Braking System)	Special Function	ST Angle Sensor Adjustment
NISSAN	All Mode	2015 - 2017	ABS (Anti-lock Braking System)	Special Function	Decel G Sen Calibration
NISSAN	All Mode	2016 - 2017	ABS (Anti-lock Braking System)	Read Fault Code	
NISSAN	All Mode	2016 - 2017	ABS (Anti-lock Braking System)	Clear Fault Code	
NISSAN	All Mode	2016 - 2017	ABS (Anti-lock Braking System)	Read Data Stream	
NISSAN	All Mode	2016 - 2017	ABS (Anti-lock Braking System)	Module Information	
NISSAN	All Mode	2016 - 2017	ABS (Anti-lock Braking System)	Actuation Test	FR RH SOL
NISSAN	All Mode	2016 - 2017	ABS (Anti-lock Braking System)	Actuation Test	FR LH SOL
NISSAN	All Mode	2016 - 2017	ABS (Anti-lock Braking System)	Actuation Test	RR RH SOL
NISSAN	All Mode	2016 - 2017	ABS (Anti-lock Braking System)	Actuation Test	RR LH SOL
NISSAN	All Mode	2016 - 2017	ABS (Anti-lock Braking System)	Actuation Test	ABS MOTOR
NISSAN	All Mode	2015 - 2017	ABS (Anti-lock Braking System)	Read Fault Code	
NISSAN	All Mode	2015 - 2017	ABS (Anti-lock Braking System)	Clear Fault Code	
NISSAN	All Mode	2015 - 2017	ABS (Anti-lock Braking System)	Read Data Stream	
NISSAN	All Mode	2015 - 2017	ABS (Anti-lock Braking System)	Module Information	
NISSAN	All Mode	2015 - 2017	ABS (Anti-lock Braking System)	Actuation Test	FR L/H Wheel Solenoid Valves
NISSAN	All Mode	2015 - 2017	ABS (Anti-lock Braking System)	Actuation Test	FR R/H Wheel Solenoid Valves
NISSAN	All Mode	2015 - 2017	ABS (Anti-lock Braking System)	Actuation Test	RR L/H Wheel Solenoid Valves
NISSAN	All Mode	2015 - 2017	ABS (Anti-lock Braking System)	Actuation Test	RR R/H Wheel Solenoid Valves
NISSAN	All Mode	2015 - 2017	ABS (Anti-lock Braking System)	Actuation Test	Pump Motor Test
NISSAN	All Mode	2015 - 2017	ABS (Anti-lock Braking System)	Actuation Test	BLEED FRONT L/H WHEEL
NISSAN	All Mode	2015 - 2017	ABS (Anti-lock Braking System)	Actuation Test	BLEED FRONT R/H WHEEL
NISSAN	All Mode	2015 - 2017	ABS (Anti-lock Braking System)	Actuation Test	BLEED REAR L/H WHEEL
NISSAN	All Mode	2015 - 2017	ABS (Anti-lock Braking System)	Actuation Test	BLEED REAR R/H WHEEL
NISSAN	All Mode	2015 - 2017	ABS (Anti-lock Braking System)	Actuation Test	Stop Pump Motor
NISSAN	All Mode	2015 - 2017	ABS (Anti-lock Braking System)	Actuation Test	Vehicle Speed Information
NISSAN	All Mode	2015 - 2017	ABS (Anti-lock Braking System)	Actuation Test	REQUEST TO SWITCH ON HAZARD WARNING LAMPS
NISSAN	All Mode	2015 - 2017	ABS (Anti-lock Braking System)	Actuation Test	ENGINE TORQUE REFERENCE VALUE
NISSAN	All Mode	2015 - 2017	ABS (Anti-lock Braking System)	Special Function	Speedo Index
NISSAN	All Mode	2015 - 2017	ABS (Anti-lock Braking System)	Special Function	Write date of last after sales OPE
NISSAN	All Mode	2015 - 2017	ABS (Anti-lock Braking System)	Special Function	Steering Wheel Angle Sensor
NISSAN	All Mode	2015 - 2017	ABS (Anti-lock Braking System)	Special Function	Vin Registration
NISSAN	All Mode	2015 - 2017	ABS (Anti-lock Braking System)	Special Function	Acceleration Sensor
NISSAN	All Mode	2015 - 2017	ABS (Anti-lock Braking System)	Special Function	Transverse Acceleration Offset Sensor
NISSAN	All Mode	2015 - 2017	ABS (Anti-lock Braking System)	Special Function	Steering Wheel Angle Offset Sensor

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
NISSAN	All Mode	2015 - 2017	ABS (Anti-lock Braking System)	Special Function	Brake Pressure Offset Sensor
NISSAN	All Mode	2015 - 2017	ABS (Anti-lock Braking System)	Special Function	RESET
NISSAN	All Mode	2015 - 2017	ABS (Anti-lock Braking System)	Special Function	Longitudinal Acceleration Sensor Offset
NISSAN	All Mode	2015 - 2017	ABS (Anti-lock Braking System)	Special Function	Check Target Teeth
NISSAN	All Mode	2015 - 2017	ABS (Anti-lock Braking System)	Special Function	Hill Start
NISSAN	NV300	2016	ABS (Anti-lock Braking System)	Read Fault Code	
NISSAN	NV300	2016	ABS (Anti-lock Braking System)	Clear Fault Code	
NISSAN	NV300	2016	ABS (Anti-lock Braking System)	Read Data Stream	
NISSAN	NV300	2016	ABS (Anti-lock Braking System)	Module Information	
NISSAN	NV300	2016	ABS (Anti-lock Braking System)	Actuation Test	VEHICLE SPEED INFORMATION
NISSAN	NV300	2016	ABS (Anti-lock Braking System)	Actuation Test	REQUEST TO SWITCH ON HAZARD WARNING LAMPS
NISSAN	NV300	2016	ABS (Anti-lock Braking System)	Actuation Test	Stop Pump Motor
NISSAN	NV300	2016	ABS (Anti-lock Braking System)	Actuation Test	Pump Motor Test
NISSAN	NV300	2016	ABS (Anti-lock Braking System)	Actuation Test	Bleeding cycle 2
NISSAN	NV300	2016	ABS (Anti-lock Braking System)	Actuation Test	Bleeding cycle 1
NISSAN	NV300	2016	ABS (Anti-lock Braking System)	Actuation Test	BLEED FRONT L/H WHEEL
NISSAN	NV300	2016	ABS (Anti-lock Braking System)	Actuation Test	BLEED FRONT R/H WHEEL
NISSAN	NV300	2016	ABS (Anti-lock Braking System)	Actuation Test	ENGINE TORQUE REFERENCE VALUE
NISSAN	NV300	2016	ABS (Anti-lock Braking System)	Actuation Test	RR R/H Wheel Solenoid Valves
NISSAN	NV300	2016	ABS (Anti-lock Braking System)	Actuation Test	RR L/H Wheel Solenoid Valves
NISSAN	NV300	2016	ABS (Anti-lock Braking System)	Actuation Test	FR R/H Wheel Solenoid Valves
NISSAN	NV300	2016	ABS (Anti-lock Braking System)	Actuation Test	FR L/H Wheel Solenoid Valves
NISSAN	KICKS	2016	ABS (Anti-lock Braking System)	Read Fault Code	
NISSAN	KICKS	2016	ABS (Anti-lock Braking System)	Clear Fault Code	
NISSAN	KICKS	2016	ABS (Anti-lock Braking System)	Read Data Stream	
NISSAN	KICKS	2016	ABS (Anti-lock Braking System)	Module Information	
NISSAN	LEAF	2016	ABS (Anti-lock Braking System)	Read Fault Code	
NISSAN	LEAF	2016	ABS (Anti-lock Braking System)	Clear Fault Code	
NISSAN	LEAF	2016	ABS (Anti-lock Braking System)	Read Data Stream	
NISSAN	LEAF	2016	ABS (Anti-lock Braking System)	Module Information	
NISSAN	All Mode	Up to 2018	ABS (Anti-lock Braking System)	Read Fault Code	
NISSAN	All Mode	Up to 2018	ABS (Anti-lock Braking System)	Clear Fault Code	
NISSAN	All Mode	Up to 2018	ABS (Anti-lock Braking System)	Read Data Stream	
NISSAN	All Mode	Up to 2018	ABS (Anti-lock Braking System)	Module Information	
NISSAN	All Mode	Up to 2018	ABS (Anti-lock Braking System)	Special Function	
NISSAN	All Mode	2005 - 2011	ABS (Anti-lock Braking System)	Read Fault Code	
NISSAN	All Mode	2005 - 2011	ABS (Anti-lock Braking System)	Clear Fault Code	
NISSAN	All Mode	2005 - 2011	ABS (Anti-lock Braking System)	Read Data Stream	
NISSAN	All Mode	2005 - 2011	ABS (Anti-lock Braking System)	Module Information	
NISSAN	Venucia R50	2012	ABS (Anti-lock Braking System)	Read Fault Code	
NISSAN	Venucia R50	2012	ABS (Anti-lock Braking System)	Clear Fault Code	
NISSAN	Venucia R50	2012	ABS (Anti-lock Braking System)	Read Data Stream	
NISSAN	Venucia R50	2012	ABS (Anti-lock Braking System)	Module Information	
NISSAN	Venucia R50	2012	ABS (Anti-lock Braking System)	Special Function	
NISSAN	All Mode	2006 - 2009	ABS (Anti-lock Braking System)	Read Fault Code	
NISSAN	All Mode	2006 - 2009	ABS (Anti-lock Braking System)	Clear Fault Code	
NISSAN	All Mode	2006 - 2009	ABS (Anti-lock Braking System)	Read Data Stream	
NISSAN	All Mode	2006 - 2009	ABS (Anti-lock Braking System)	Module Information	
NISSAN	All Mode	2006 - 2009	ABS (Anti-lock Braking System)	Special Function	Steering Whl Angle Sen
NISSAN	All Mode	2006 - 2009	ABS (Anti-lock Braking System)	Special Function	Write date of last after sales OPE
NISSAN	All Mode	2006 - 2009	ABS (Anti-lock Braking System)	Special Function	Speedo Index
NISSAN	All Mode	2006 - 2009	ABS (Anti-lock Braking System)	Special Function	Vehicle Parameters
NISSAN	All Mode	2006 - 2009	ABS (Anti-lock Braking System)	Read Fault Code	
NISSAN	All Mode	2006 - 2009	ABS (Anti-lock Braking System)	Clear Fault Code	
NISSAN	All Mode	2006 - 2009	ABS (Anti-lock Braking System)	Read Data Stream	
NISSAN	All Mode	2006 - 2009	ABS (Anti-lock Braking System)	Module Information	
NISSAN	All Mode	2006 - 2009	ABS (Anti-lock Braking System)	Special Function	Write date of last after sales OPE
NISSAN	All Mode	2006 - 2009	ABS (Anti-lock Braking System)	Special Function	Speedo Index
NISSAN	All Mode	2008 - 2016	ABS (Anti-lock Braking System)	Read Fault Code	
NISSAN	All Mode	2008 - 2016	ABS (Anti-lock Braking System)	Clear Fault Code	
NISSAN	All Mode	2008 - 2016	ABS (Anti-lock Braking System)	Read Data Stream	
NISSAN	All Mode	2008 - 2016	ABS (Anti-lock Braking System)	Module Information	
NISSAN	All Mode	2008 - 2016	ABS (Anti-lock Braking System)	Special Function	Vehicle Parameters
NISSAN	All Mode	2008 - 2016	ABS (Anti-lock Braking System)	Special Function	Speedo Index
NISSAN	All Mode	2008 - 2016	ABS (Anti-lock Braking System)	Special Function	Vin Registration
NISSAN	All Mode	2008 - 2016	ABS (Anti-lock Braking System)	Special Function	Write date of last after sales OPE
NISSAN	All Mode	2008 - 2016	ABS (Anti-lock Braking System)	Special Function	Bleed Hydraulic Unit And Braking Circuits
NISSAN	All Mode	2008 - 2016	ABS (Anti-lock Braking System)	Special Function	Check Target Teeth

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

<b>make</b>	<b>model</b>	<b>year</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
NISSAN	All Mode	2008 - 2017	ABS (Anti-lock Braking System)	Read Fault Code	
NISSAN	All Mode	2008 - 2017	ABS (Anti-lock Braking System)	Clear Fault Code	
NISSAN	All Mode	2008 - 2017	ABS (Anti-lock Braking System)	Read Data Stream	
NISSAN	All Mode	2008 - 2017	ABS (Anti-lock Braking System)	Module Information	
NISSAN	All Mode	2008 - 2017	ABS (Anti-lock Braking System)	Special Function	Vehicle Parameters
NISSAN	All Mode	2008 - 2017	ABS (Anti-lock Braking System)	Special Function	Speedo Index
NISSAN	All Mode	2008 - 2017	ABS (Anti-lock Braking System)	Special Function	Vin Registration
NISSAN	All Mode	2008 - 2017	ABS (Anti-lock Braking System)	Special Function	Write date of last after sales OPE
NISSAN	All Mode	2008 - 2017	ABS (Anti-lock Braking System)	Special Function	Check Target Teeth
NISSAN	All Mode	2008 - 2017	ABS (Anti-lock Braking System)	Special Function	Bleed Hydraulic Unit And Braking Circuits
NISSAN	All Mode	Up to 2011	ABS (Anti-lock Braking System)	Read Fault Code	
NISSAN	All Mode	Up to 2011	ABS (Anti-lock Braking System)	Clear Fault Code	
NISSAN	All Mode	Up to 2011	ABS (Anti-lock Braking System)	Read Data Stream	
NISSAN	All Mode	Up to 2011	ABS (Anti-lock Braking System)	Module Information	
NISSAN	All Mode	Up to 2011	ABS (Anti-lock Braking System)	Special Function	ST ANG SEN ADJUSTMENT
NISSAN	All Mode	Up to 2011	ABS (Anti-lock Braking System)	Special Function	AIR BLEEDING
NISSAN	All Mode	Up to 2011	ABS (Anti-lock Braking System)	Special Function	
NISSAN	All Mode	Up to 2017	ABS (Anti-lock Braking System)	Read Fault Code	
NISSAN	All Mode	Up to 2017	ABS (Anti-lock Braking System)	Clear Fault Code	
NISSAN	All Mode	Up to 2017	ABS (Anti-lock Braking System)	Read Data Stream	
NISSAN	All Mode	Up to 2017	ABS (Anti-lock Braking System)	Module Information	
NISSAN	All Mode	Up to 2017	ABS (Anti-lock Braking System)	Actuation Test	
NISSAN	All Mode	Up to 2015	ABS (Anti-lock Braking System)	Read Fault Code	
NISSAN	All Mode	Up to 2015	ABS (Anti-lock Braking System)	Clear Fault Code	
NISSAN	All Mode	Up to 2015	ABS (Anti-lock Braking System)	Read Data Stream	
NISSAN	All Mode	Up to 2015	ABS (Anti-lock Braking System)	Module Information	
NISSAN	All Mode	Up to 2015	ABS (Anti-lock Braking System)	Actuation Test	
NISSAN	All Mode	Up to 2015	ABS (Anti-lock Braking System)	Read Fault Code	
NISSAN	All Mode	Up to 2015	ABS (Anti-lock Braking System)	Clear Fault Code	
NISSAN	All Mode	Up to 2015	ABS (Anti-lock Braking System)	Read Data Stream	
NISSAN	All Mode	Up to 2015	ABS (Anti-lock Braking System)	Module Information	
NISSAN	All Mode	Up to 2015	ABS (Anti-lock Braking System)	Special Function	ETS AIR BLEEDING
NISSAN	All Mode	Up to 2015	ABS (Anti-lock Braking System)	Special Function	LSD AIR BLEEDING
NISSAN	All Mode	Up to 2015	ABS (Anti-lock Braking System)	Special Function	ETS OIL PRESS CHECK
NISSAN	All Mode	Up to 2015	ABS (Anti-lock Braking System)	Special Function	ETS OIL PRESS CHECK
NISSAN	All Mode	Up to 2015	ABS (Anti-lock Braking System)	Special Function	LSD OIL PRESS CHECK
NISSAN	All Mode	Up to 2015	ABS (Anti-lock Braking System)	Special Function	LSD OIL PRESS CHECK
NISSAN	All Mode	Up to 2015	ABS (Anti-lock Braking System)	Special Function	ETS LOCK CHECK
NISSAN	All Mode	Up to 2015	ABS (Anti-lock Braking System)	Special Function	LSD LOCK CHECK
NISSAN	All Mode	Up to 2015	ABS (Anti-lock Braking System)	Special Function	ETS/LSD LOCK CHECK
NISSAN	All Mode	Up to 2015	ABS (Anti-lock Braking System)	Special Function	ETS/LSD AIR BLEEDING
NISSAN	All Mode	Up to 2017	IPDM E/R	Read Fault Code	
NISSAN	All Mode	Up to 2017	IPDM E/R	Clear Fault Code	
NISSAN	All Mode	Up to 2017	IPDM E/R	Read Data Stream	
NISSAN	All Mode	Up to 2017	IPDM E/R	Actuation Test	Head Lamp
NISSAN	All Mode	Up to 2017	IPDM E/R	Actuation Test	Front Fog Lamp
NISSAN	All Mode	Up to 2017	IPDM E/R	Actuation Test	Tail Lamp
NISSAN	All Mode	Up to 2017	IPDM E/R	Actuation Test	Rear Defogger
NISSAN	All Mode	Up to 2017	IPDM E/R	Actuation Test	Front Wiper
NISSAN	All Mode	Up to 2017	IPDM E/R	Actuation Test	Motor Fan
NISSAN	All Mode	Up to 2017	IPDM E/R	Actuation Test	Head Lamp Washer
NISSAN	All Mode	Up to 2017	IPDM E/R	Actuation Test	Lamps
NISSAN	All Mode	Up to 2017	IPDM E/R	Actuation Test	External Lamps
NISSAN	All Mode	Up to 2017	IPDM E/R	Actuation Test	Cornering Lamp
NISSAN	All Mode	Up to 2017	IPDM E/R	Actuation Test	Horn
NISSAN	All Mode	2002 - 2010	IPDM E/R	Read Fault Code	
NISSAN	All Mode	2002 - 2010	IPDM E/R	Clear Fault Code	
NISSAN	All Mode	2002 - 2010	IPDM E/R	Read Data Stream	
NISSAN	All Mode	2002 - 2010	IPDM E/R	Actuation Test	Head Lamp
NISSAN	All Mode	2002 - 2010	IPDM E/R	Actuation Test	Front Fog Lamp
NISSAN	All Mode	2002 - 2010	IPDM E/R	Actuation Test	Tail Lamp
NISSAN	All Mode	2002 - 2010	IPDM E/R	Actuation Test	Rear Defogger
NISSAN	All Mode	2002 - 2010	IPDM E/R	Actuation Test	Front Wiper
NISSAN	All Mode	2002 - 2010	IPDM E/R	Actuation Test	Motor Fan
NISSAN	All Mode	2002 - 2010	IPDM E/R	Actuation Test	Head Lamp Washer
NISSAN	All Mode	2002 - 2010	IPDM E/R	Actuation Test	Lamps
NISSAN	All Mode	2002 - 2010	IPDM E/R	Actuation Test	External Lamps
NISSAN	All Mode	2002 - 2010	IPDM E/R	Actuation Test	Cornering Lamp
NISSAN	All Mode	2002 - 2010	IPDM E/R	Actuation Test	Horn
NISSAN	All Mode	Up to 2018	IPDM E/R	Read Fault Code	
NISSAN	All Mode	Up to 2018	IPDM E/R	Clear Fault Code	
NISSAN	All Mode	Up to 2018	IPDM E/R	Read Data Stream	
NISSAN	All Mode	Up to 2018	IPDM E/R	Read Freeze Frame	
NISSAN	All Mode	Up to 2018	IPDM E/R	Module Information	
NISSAN	All Mode	Up to 2018	IPDM E/R	Actuation Test	Cornering Lamp
NISSAN	All Mode	Up to 2018	IPDM E/R	Actuation Test	Tail Lamp
NISSAN	All Mode	Up to 2018	IPDM E/R	Actuation Test	Horn
NISSAN	All Mode	Up to 2018	IPDM E/R	Actuation Test	Rear Defogger

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
NISSAN	All Mode	Up to 2018	IPDM E/R	Actuation Test	Front Wiper
NISSAN	All Mode	Up to 2018	IPDM E/R	Actuation Test	Motor Fan
NISSAN	All Mode	Up to 2018	IPDM E/R	Actuation Test	Head Lamp Washer
NISSAN	All Mode	Up to 2018	IPDM E/R	Actuation Test	Lamps
NISSAN	All Mode	Up to 2018	IPDM E/R	Actuation Test	External Lamps
NISSAN	All Mode	Up to 2012	IPDM E/R	Read Fault Code	
NISSAN	All Mode	Up to 2012	IPDM E/R	Clear Fault Code	
NISSAN	All Mode	Up to 2012	IPDM E/R	Read Data Stream	
NISSAN	All Mode	Up to 2012	IPDM E/R	Module Information	
NISSAN	All Mode	Up to 2012	IPDM E/R	Actuation Test	Head Lamp
NISSAN	All Mode	Up to 2012	IPDM E/R	Actuation Test	Front Fog Lamp
NISSAN	All Mode	Up to 2012	IPDM E/R	Actuation Test	Tail Lamp
NISSAN	All Mode	Up to 2012	IPDM E/R	Actuation Test	Rear Defogger
NISSAN	All Mode	Up to 2012	IPDM E/R	Actuation Test	Front Wiper
NISSAN	All Mode	Up to 2012	IPDM E/R	Actuation Test	Motor Fan
NISSAN	All Mode	Up to 2012	IPDM E/R	Actuation Test	Head Lamp Washer
NISSAN	All Mode	Up to 2012	IPDM E/R	Actuation Test	Lamps
NISSAN	All Mode	Up to 2012	IPDM E/R	Actuation Test	External Lamps
NISSAN	All Mode	Up to 2012	IPDM E/R	Actuation Test	Cornering Lamp
NISSAN	All Mode	Up to 2012	IPDM E/R	Actuation Test	Horn
NISSAN	NV400	2011	IPDM E/R	Read Fault Code	
NISSAN	NV400	2011	IPDM E/R	Clear Fault Code	
NISSAN	NV400	2011	IPDM E/R	Read Data Stream	
NISSAN	NV400	2011	IPDM E/R	Module Information	
NISSAN	NV400	2011	IPDM E/R	Actuation Test	WINDSCREEN WIPER:LOW SPEED
NISSAN	NV400	2011	IPDM E/R	Actuation Test	WINDSCREEN WIPER:HIG SPEED
NISSAN	NV400	2011	IPDM E/R	Actuation Test	ELECTRIC POWER SUPPLY CIRCUIT TESTING
NISSAN	NV400	2011	IPDM E/R	Actuation Test	REAR SCREEN DE-ICING
NISSAN	NV400	2011	IPDM E/R	Actuation Test	A/C CNT COMP
NISSAN	NV400	2011	IPDM E/R	Actuation Test	DIPPED HEADLIGHTS
NISSAN	NV400	2011	IPDM E/R	Actuation Test	FRONT FOG LIGHTS
NISSAN	NV400	2011	IPDM E/R	Actuation Test	MAIN H/L INF
NISSAN	NV400	2011	IPDM E/R	Actuation Test	SIDE LIGHTS
NISSAN	NV400	2011	IPDM E/R	Actuation Test	FAN UNIT LOW
NISSAN	NV400	2011	IPDM E/R	Actuation Test	FAN UT HI SPD
NISSAN	NV400	2011	IPDM E/R	Actuation Test	ALTERNATOR REGULATION
NISSAN	NV400	2011	IPDM E/R	Actuation Test	FAN UNIT
NISSAN	NV400	2011	IPDM E/R	Special Function	Vin Registration
NISSAN	NV350 URVAN/NV350	2012	IPDM E/R	Read Fault Code	
NISSAN	NV350 URVAN/NV350	2012	IPDM E/R	Clear Fault Code	
NISSAN	NV350 URVAN/NV350	2012	IPDM E/R	Read Data Stream	
NISSAN	NV350 URVAN/NV350	2012	IPDM E/R	Module Information	
NISSAN	NV350 URVAN/NV350	2012	IPDM E/R	Actuation Test	Horn
NISSAN	NV350 URVAN/NV350	2012	IPDM E/R	Actuation Test	Rear Defogger
NISSAN	NV350 URVAN/NV350	2012	IPDM E/R	Actuation Test	Front Wiper
NISSAN	NV350 URVAN/NV350	2012	IPDM E/R	Actuation Test	Motor Fan
NISSAN	NV350 URVAN/NV350	2012	IPDM E/R	Actuation Test	Head Lamp Washer
NISSAN	NV350 URVAN/NV350	2012	IPDM E/R	Actuation Test	External Lamps
NISSAN	NV350 URVAN/NV350	2012	IPDM E/R	Actuation Test	Rear Wiper
NISSAN	NV350 URVAN/NV350	2012	IPDM E/R	Actuation Test	REAR BLOWER RELAY
NISSAN	NV400	2011	IPDM E/R	Read Fault Code	
NISSAN	NV400	2011	IPDM E/R	Clear Fault Code	
NISSAN	NV400	2011	IPDM E/R	Read Data Stream	
NISSAN	NV400	2011	IPDM E/R	Module Information	
NISSAN	NV400	2011	IPDM E/R	Actuation Test	FRONT FOG LIGHTS
NISSAN	NV400	2011	IPDM E/R	Actuation Test	WINDSCREEN WIPER:LOW SPEED
NISSAN	NV400	2011	IPDM E/R	Actuation Test	FAN UNIT LOW SPEED
NISSAN	NV400	2011	IPDM E/R	Actuation Test	ALTERNATOR REGULATION
NISSAN	NV400	2011	IPDM E/R	Actuation Test	A/C CNT COMP
NISSAN	NV400	2011	IPDM E/R	Actuation Test	HEATER WATER PUMP COMMAND
NISSAN	NV400	2011	IPDM E/R	Actuation Test	DIPPED HEADLIGHTS
NISSAN	NV400	2011	IPDM E/R	Actuation Test	WINDSCREEN WIPER:HIG SPEED
NISSAN	NV400	2011	IPDM E/R	Actuation Test	VOLTAGE REGULATION
NISSAN	NV400	2011	IPDM E/R	Actuation Test	MAIN H/L INF
NISSAN	NV400	2011	IPDM E/R	Actuation Test	ELECTRIC POWER SUPPLY CIRCUIT TESTING
NISSAN	NV400	2011	IPDM E/R	Actuation Test	SIDE LIGHTS
NISSAN	NV400	2011	IPDM E/R	Special Function	Resetting Internal Protection
NISSAN	NV400	2011	IPDM E/R	Special Function	Vin Registration
NISSAN	NV400	2011	IPDM E/R	Special Function	Number Of Starting 3
NISSAN	NV400	2011	IPDM E/R	Special Function	Number Of Starting 4
NISSAN	NV400	2011	IPDM E/R	Special Function	Number Of Starting 1
NISSAN	NV400	2011	IPDM E/R	Special Function	Number Of Starting 2
NISSAN	NV400	2011	IPDM E/R	Special Function	Corrosion Battery Counter Memorised
NISSAN	NV400	2011	IPDM E/R	Special Function	Corrosion Battery Counter Estimated
NISSAN	NV400	2011	IPDM E/R	Special Function	Battery Corrosion Counter



**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
NISSAN	NV400	2011	IPDM E/R	Special Function	Battery Cycle Counter Memorised
NISSAN	NV400	2011	IPDM E/R	Special Function	Battery Cycle Counter Estimated
NISSAN	NV400	2011	IPDM E/R	Special Function	Battery Cycle Counter
NISSAN	NV400	2011	IPDM E/R	Special Function	Save Computer Data
NISSAN	NV400	2011	IPDM E/R	Special Function	Write Saved Data
NISSAN	NV400	2011	IPDM E/R	Special Function	Number Of Starting Cycles
NISSAN	NV400	2011	IPDM E/R	Special Function	Number Of Starting
NISSAN	NV400	2011	IPDM E/R	Special Function	Calculate Battery Wear Counters(R011)
NISSAN	NV400	2011	IPDM E/R	Special Function	Computer Initialisation
NISSAN	NV400	2011	IPDM E/R	Special Function	CALCULATE BATTERY WEAR COUNTERS(S006)
NISSAN	All Mode	2013 - 2017	IPDM E/R	Read Fault Code	
NISSAN	All Mode	2013 - 2017	IPDM E/R	Clear Fault Code	
NISSAN	All Mode	2013 - 2017	IPDM E/R	Read Data Stream	
NISSAN	All Mode	2013 - 2017	IPDM E/R	Module Information	
NISSAN	All Mode	2013 - 2017	IPDM E/R	Actuation Test	Horn
NISSAN	All Mode	2013 - 2017	IPDM E/R	Actuation Test	Head Lamp Washer
NISSAN	All Mode	2013 - 2017	IPDM E/R	Actuation Test	Front Wiper
NISSAN	All Mode	2013 - 2017	IPDM E/R	Actuation Test	COMPRESSOR
NISSAN	All Mode	2013 - 2017	IPDM E/R	Actuation Test	Cooling Fan (Pwm)
NISSAN	All Mode	2013 - 2017	IPDM E/R	Actuation Test	Cooling Fan (Mono)
NISSAN	All Mode	2013 - 2017	IPDM E/R	Actuation Test	Cooling Fan (Dual)
NISSAN	All Mode	2013 - 2017	IPDM E/R	Actuation Test	Headlamp (Hi)
NISSAN	All Mode	2013 - 2017	IPDM E/R	Actuation Test	HEADLAMP (LO)
NISSAN	All Mode	2013 - 2017	IPDM E/R	Actuation Test	Front Fog Lamp
NISSAN	All Mode	2013 - 2017	IPDM E/R	Actuation Test	Daytime Running Light
NISSAN	All Mode	2013 - 2017	IPDM E/R	Actuation Test	Parking Lamp
NISSAN	All Mode	2013 - 2017	IPDM E/R	Actuation Test	Tail Lamp
NISSAN	All Mode	2013 - 2017	IPDM E/R	Actuation Test	Optic Axis Active Test
NISSAN	All Mode	2013 - 2017	IPDM E/R	Special Function	Sensor Initialize
NISSAN	All Mode	2013 - 2017	IPDM E/R	Special Function	CML B/DCHRG CRNT CLEAR
NISSAN	All Mode	2016 - 2017	IPDM E/R	Read Fault Code	
NISSAN	All Mode	2016 - 2017	IPDM E/R	Clear Fault Code	
NISSAN	All Mode	2016 - 2017	IPDM E/R	Read Data Stream	
NISSAN	All Mode	2016 - 2017	IPDM E/R	Module Information	
NISSAN	All Mode	2016 - 2017	IPDM E/R	Actuation Test	Horn
NISSAN	All Mode	2016 - 2017	IPDM E/R	Actuation Test	Headlamp Washer
NISSAN	All Mode	2016 - 2017	IPDM E/R	Actuation Test	COMPRESSOR
NISSAN	All Mode	2016 - 2017	IPDM E/R	Actuation Test	Cooling Fan (MONO)
NISSAN	All Mode	2016 - 2017	IPDM E/R	Actuation Test	Cooling Fan (DUAL)
NISSAN	All Mode	2016 - 2017	IPDM E/R	Actuation Test	Cooling Fan (PWM)
NISSAN	All Mode	2016 - 2017	IPDM E/R	Actuation Test	Headlamp (HI)
NISSAN	All Mode	2016 - 2017	IPDM E/R	Actuation Test	HEADLAMP (LO)
NISSAN	All Mode	2016 - 2017	IPDM E/R	Actuation Test	Front fog lamp
NISSAN	All Mode	2016 - 2017	IPDM E/R	Actuation Test	Daytime Running Light
NISSAN	All Mode	2016 - 2017	IPDM E/R	Actuation Test	Parking Lamp
NISSAN	All Mode	2016 - 2017	IPDM E/R	Actuation Test	Tail Lamp
NISSAN	All Mode	2016 - 2017	IPDM E/R	Actuation Test	Optic Axis Active Test
NISSAN	All Mode	2016 - 2017	IPDM E/R	Actuation Test	Front Wiper
NISSAN	All Mode	2016 - 2017	IPDM E/R	Actuation Test	(TBD) IGNITION, RESET
NISSAN	All Mode	2016 - 2017	IPDM E/R	Actuation Test	(TBD) IGNITION, SET
NISSAN	All Mode	2016 - 2017	IPDM E/R	Special Function	Sensor Initialize
NISSAN	All Mode	2016 - 2017	IPDM E/R	Special Function	CML B/DCHRG CRNT CLEAR
NISSAN	NV300	2016	IPDM E/R	Read Fault Code	
NISSAN	NV300	2016	IPDM E/R	Clear Fault Code	
NISSAN	NV300	2016	IPDM E/R	Read Data Stream	
NISSAN	NV300	2016	IPDM E/R	Module Information	
NISSAN	NV300	2016	IPDM E/R	Special Function	Computer Initialisation
NISSAN	NV300	2016	IPDM E/R	Special Function	Resetting Internal Protection
NISSAN	NV300	2016	IPDM E/R	Special Function	Vehicle Parameters
NISSAN	NV300	2016	IPDM E/R	Special Function	COUNTRY MODEL
NISSAN	NV300	2016	IPDM E/R	Read Fault Code	
NISSAN	NV300	2016	IPDM E/R	Clear Fault Code	
NISSAN	NV300	2016	IPDM E/R	Read Data Stream	
NISSAN	NV300	2016	IPDM E/R	Module Information	
NISSAN	NV300	2016	IPDM E/R	Actuation Test	DIPPED HEADLIGHTS
NISSAN	NV300	2016	IPDM E/R	Actuation Test	DAYTIME RUNNING LIGHTS
NISSAN	NV300	2016	IPDM E/R	Actuation Test	FRONT FOG LIGHTS
NISSAN	NV300	2016	IPDM E/R	Actuation Test	MAIN H/L INF
NISSAN	NV300	2016	IPDM E/R	Actuation Test	REAR FOG LIGHTS
NISSAN	NV300	2016	IPDM E/R	Actuation Test	SIDE LIGHTS
NISSAN	NV300	2016	IPDM E/R	Actuation Test	S&S button LED command
NISSAN	NV300	2016	IPDM E/R	Actuation Test	WINDSCREEN WIPER: LOW SPEED
NISSAN	NV300	2016	IPDM E/R	Actuation Test	WINDSCREEN WIPER: HIGH SPEED
NISSAN	NV300	2016	IPDM E/R	Actuation Test	ALTERNATOR REGULATION

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
NISSAN	NV300	2016	IPDM E/R	Actuation Test	HEATER WATER PUMP COMMAND
NISSAN	NV300	2016	IPDM E/R	Actuation Test	Stop lights
NISSAN	NV300	2016	IPDM E/R	Special Function	Vin Registration
NISSAN	NV300	2016	IPDM E/R	Special Function	Computer Initialisation
NISSAN	NV300	2016	IPDM E/R	Special Function	Resetting Internal Protection
NISSAN	NV300	2016	IPDM E/R	Special Function	Number Of Starting Cycles
NISSAN	NV300	2016	IPDM E/R	Special Function	Save Computer Data
NISSAN	NV300	2016	IPDM E/R	Special Function	Write Saved Data
NISSAN	NV300	2016	IPDM E/R	Special Function	Save Number Of Starts
NISSAN	NV300	2016	IPDM E/R	Special Function	High Pressure Pump Learning
NISSAN	NV300	2016	IPDM E/R	Special Function	Starter Learning
NISSAN	All Mode	Up to 2017	Air Pressure Monitor	Read Fault Code	
NISSAN	All Mode	Up to 2017	Air Pressure Monitor	Clear Fault Code	
NISSAN	All Mode	Up to 2017	Air Pressure Monitor	Read Data Stream	
NISSAN	All Mode	Up to 2017	Air Pressure Monitor	Module Information	
NISSAN	All Mode	Up to 2017	Air Pressure Monitor	Actuation Test	BUZZER
NISSAN	All Mode	Up to 2017	Air Pressure Monitor	Actuation Test	Warn Lamp
NISSAN	All Mode	Up to 2017	Air Pressure Monitor	Actuation Test	Hazard Lamp
NISSAN	All Mode	Up to 2017	Air Pressure Monitor	Special Function	ID READ(TIRE SET 1)
NISSAN	All Mode	Up to 2017	Air Pressure Monitor	Special Function	ID READ(TIRE SET 2)
NISSAN	All Mode	Up to 2017	Air Pressure Monitor	Special Function	ID REGIST(TIRE SET 1)
NISSAN	All Mode	Up to 2017	Air Pressure Monitor	Special Function	ID REGIST(TIRE SET 2)
NISSAN	All Mode	Up to 2017	Air Pressure Monitor	Special Function	Switch Tpms Between On/Off
NISSAN	All Mode	Up to 2017	Air Pressure Monitor	Special Function	ID REGIST
NISSAN	All Mode	Up to 2015	Air Pressure Monitor	Read Fault Code	
NISSAN	All Mode	Up to 2015	Air Pressure Monitor	Clear Fault Code	
NISSAN	All Mode	Up to 2015	Air Pressure Monitor	Read Data Stream	
NISSAN	All Mode	Up to 2015	Air Pressure Monitor	Module Information	
NISSAN	All Mode	Up to 2015	Air Pressure Monitor	Special Function	ID REGIST
NISSAN	All Mode	Up to 2018	Air Pressure Monitor	Read Fault Code	
NISSAN	All Mode	Up to 2018	Air Pressure Monitor	Clear Fault Code	
NISSAN	All Mode	Up to 2018	Air Pressure Monitor	Read Data Stream	
NISSAN	All Mode	Up to 2018	Air Pressure Monitor	Module Information	
NISSAN	All Mode	Up to 2018	Air Pressure Monitor	Actuation Test	ID REGIST WARNING
NISSAN	All Mode	Up to 2018	Air Pressure Monitor	Actuation Test	RUN FLAT/T WARN BUZZER
NISSAN	All Mode	Up to 2018	Air Pressure Monitor	Actuation Test	Warning Lamp
NISSAN	All Mode	Up to 2018	Air Pressure Monitor	Actuation Test	Flasher
NISSAN	All Mode	Up to 2018	Air Pressure Monitor	Actuation Test	Horn
NISSAN	All Mode	Up to 2018	Air Pressure Monitor	Actuation Test	Outside Buzzer
NISSAN	All Mode	Up to 2018	Air Pressure Monitor	Special Function	ID READ
NISSAN	All Mode	Up to 2018	Air Pressure Monitor	Special Function	ID REGIST
NISSAN	All Mode	Up to 2018	Air Pressure Monitor	Special Function	Switch Tpms Between On/Off
NISSAN	All Mode	2013 - 2015	Air Pressure Monitor	Read Fault Code	
NISSAN	All Mode	2013 - 2015	Air Pressure Monitor	Clear Fault Code	
NISSAN	All Mode	2013 - 2015	Air Pressure Monitor	Read Data Stream	
NISSAN	All Mode	2013 - 2015	Air Pressure Monitor	Module Information	
NISSAN	All Mode	2013 - 2015	Air Pressure Monitor	Special Function	Vin Registration
NISSAN	All Mode	2013 - 2017	Air Pressure Monitor	Read Fault Code	
NISSAN	All Mode	2013 - 2017	Air Pressure Monitor	Clear Fault Code	
NISSAN	All Mode	2013 - 2017	Air Pressure Monitor	Read Data Stream	
NISSAN	All Mode	2013 - 2017	Air Pressure Monitor	Module Information	
NISSAN	All Mode	2013 - 2017	Air Pressure Monitor	Actuation Test	ID REGIST WARNING
NISSAN	All Mode	2013 - 2017	Air Pressure Monitor	Actuation Test	Warning Lamp
NISSAN	All Mode	2013 - 2017	Air Pressure Monitor	Actuation Test	RUN FLAT/T WARN BUZZER
NISSAN	All Mode	2013 - 2017	Air Pressure Monitor	Actuation Test	Flasher
NISSAN	All Mode	2013 - 2017	Air Pressure Monitor	Actuation Test	Horn
NISSAN	All Mode	2013 - 2017	Air Pressure Monitor	Special Function	ID REGIST
NISSAN	All Mode	2013 - 2017	Air Pressure Monitor	Special Function	Switch Tpms Between On/Off
NISSAN	All Mode	2015 - 2018	Air Pressure Monitor	Read Fault Code	
NISSAN	All Mode	2015 - 2018	Air Pressure Monitor	Clear Fault Code	
NISSAN	All Mode	2015 - 2018	Air Pressure Monitor	Read Data Stream	
NISSAN	All Mode	2015 - 2018	Air Pressure Monitor	Module Information	
NISSAN	All Mode	2015 - 2018	Air Pressure Monitor	Actuation Test	Check left front tire pressure sensor
NISSAN	All Mode	2015 - 2018	Air Pressure Monitor	Actuation Test	Check right front tire pressure sensor
NISSAN	All Mode	2015 - 2018	Air Pressure Monitor	Actuation Test	Check left rear tire pressure sensor
NISSAN	All Mode	2015 - 2018	Air Pressure Monitor	Actuation Test	Check right rear tire pressure sensor
NISSAN	All Mode	2015 - 2018	Air Pressure Monitor	Actuation Test	Activation memory
NISSAN	All Mode	2015 - 2018	Air Pressure Monitor	Actuation Test	Message memory
NISSAN	All Mode	2015 - 2018	Air Pressure Monitor	Special Function	Set autolocation disable
NISSAN	All Mode	2015 - 2018	Air Pressure Monitor	Special Function	Front or rear sensor localization was unsuccessful
NISSAN	All Mode	2015 - 2018	Air Pressure Monitor	Special Function	Saving Data For Replc CPU
NISSAN	All Mode	2015 - 2018	Air Pressure Monitor	Special Function	Writing Data For Replc CPU
NISSAN	All Mode	Up to 2011	Air Pressure Monitor	Read Fault Code	

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
NISSAN	All Mode	Up to 2011	Air Pressure Monitor	Clear Fault Code	
NISSAN	All Mode	Up to 2011	Air Pressure Monitor	Read Data Stream	
NISSAN	All Mode	Up to 2011	Air Pressure Monitor	Module Information	
NISSAN	All Mode	Up to 2011	Air Pressure Monitor	Special Function	ID REGIST (SUMMER)
NISSAN	All Mode	Up to 2011	Air Pressure Monitor	Special Function	ID REGIST (WINTER)
NISSAN	All Mode	Up to 2011	Air Pressure Monitor	Special Function	Type Set Selection
NISSAN	All Mode	Up to 2011	Air Pressure Monitor	Special Function	Tpms Cancellation
NISSAN	All Mode	Up to 2011	Air Pressure Monitor	Special Function	RECOMMEND PRESS SETTING
NISSAN	All Mode	Up to 2011	Air Pressure Monitor	Read Fault Code	
NISSAN	All Mode	Up to 2011	Air Pressure Monitor	Clear Fault Code	
NISSAN	All Mode	Up to 2011	Air Pressure Monitor	Read Data Stream	
NISSAN	All Mode	Up to 2011	Air Pressure Monitor	Module Information	
NISSAN	All Mode	Up to 2011	Air Pressure Monitor	Special Function	
NISSAN	All Mode	2014 - 2016	BAC	Read Fault Code	
NISSAN	All Mode	2014 - 2016	BAC	Clear Fault Code	
NISSAN	All Mode	2014 - 2016	BAC	Read Data Stream	
NISSAN	All Mode	2014 - 2016	BAC	Module Information	
NISSAN	All Mode	2014 - 2016	BAC	Special Function	Vin Registration
NISSAN	NV400	2011	BAC	Read Fault Code	
NISSAN	NV400	2011	BAC	Clear Fault Code	
NISSAN	NV400	2011	BAC	Read Data Stream	
NISSAN	NV400	2011	BAC	Module Information	
NISSAN	All Mode	2006 - 2009	BAC	Read Fault Code	
NISSAN	All Mode	2006 - 2009	BAC	Clear Fault Code	
NISSAN	All Mode	2006 - 2009	BAC	Read Data Stream	
NISSAN	All Mode	2006 - 2009	BAC	Module Information	
NISSAN	All Mode	2006 - 2012	Sub Meter	Read Fault Code	
NISSAN	All Mode	2006 - 2012	Sub Meter	Clear Fault Code	
NISSAN	All Mode	2009 - 2015	Convertible Roof	Read Fault Code	
NISSAN	All Mode	2009 - 2015	Convertible Roof	Clear Fault Code	
NISSAN	All Mode	2009 - 2015	Convertible Roof	Read Data Stream	
NISSAN	All Mode	2009 - 2015	Convertible Roof	Module Information	
NISSAN	All Mode	2009 - 2015	Convertible Roof	Actuation Test	ROOF SYSTEM
NISSAN	All Mode	2009 - 2015	Convertible Roof	Actuation Test	ROOF STATE OUTPUT (AUDIO)
NISSAN	All Mode	2009 - 2015	Convertible Roof	Actuation Test	FRONT POWER WINDOW (LH)/RH
NISSAN	All Mode	2009 - 2015	Convertible Roof	Actuation Test	REAR POWER WINDOW (LH)
NISSAN	All Mode	2009 - 2015	Convertible Roof	Actuation Test	REAR POWER WINDOW (RH)
NISSAN	All Mode	2009 - 2015	Convertible Roof	Special Function	Trunk Opener
NISSAN	All Mode	2009 - 2015	Convertible Roof	Special Function	FLIPPER DOOR
NISSAN	All Mode	2009 - 2015	Convertible Roof	Special Function	ROOF LATCH
NISSAN	All Mode	2009 - 2015	Convertible Roof	Special Function	Roof State Reset
NISSAN	All Mode	2009 - 2015	Convertible Roof	Special Function	Roof State Learning
NISSAN	All Mode	2009 - 2018	Convertible Roof	Read Fault Code	
NISSAN	All Mode	2009 - 2018	Convertible Roof	Clear Fault Code	
NISSAN	All Mode	2009 - 2018	Convertible Roof	Read Data Stream	
NISSAN	All Mode	2009 - 2018	Convertible Roof	Module Information	
NISSAN	All Mode	2009 - 2018	Convertible Roof	Actuation Test	ROOF LATCHED LH/RH
NISSAN	All Mode	2009 - 2018	Convertible Roof	Actuation Test	STORAGE LID
NISSAN	All Mode	2009 - 2018	Convertible Roof	Actuation Test	SOFT TOP SYSTEM
NISSAN	All Mode	2009 - 2018	Convertible Roof	Actuation Test	ROOF SYSTEM
NISSAN	All Mode	2009 - 2018	Convertible Roof	Actuation Test	5TH BOW SYSTEM
NISSAN	All Mode	2009 - 2018	Convertible Roof	Actuation Test	HYDRAULIC PRESSURE RELEASE
NISSAN	All Mode	2009 - 2018	Convertible Roof	Actuation Test	TRUNK OPENER
NISSAN	All Mode	2009 - 2018	Convertible Roof	Actuation Test	ROOF STATE OUTPUT (AUDIO)
NISSAN	All Mode	2009 - 2018	Convertible Roof	Actuation Test	POWER WINDOW (LH)/RH
NISSAN	All Mode	2009 - 2018	Convertible Roof	Actuation Test	REAR WINDOW DEFOGGER
NISSAN	All Mode	2010 - 2014	Convertible Roof	Read Fault Code	
NISSAN	All Mode	2010 - 2014	Convertible Roof	Clear Fault Code	
NISSAN	All Mode	2010 - 2014	Convertible Roof	Read Data Stream	
NISSAN	All Mode	2010 - 2014	Convertible Roof	Module Information	
NISSAN	All Mode	2010 - 2014	Convertible Roof	Actuation Test	ROOF LATCHED LH/RH
NISSAN	All Mode	2010 - 2014	Convertible Roof	Actuation Test	STORAGE LID
NISSAN	All Mode	2010 - 2014	Convertible Roof	Actuation Test	SOFT TOP SYSTEM
NISSAN	All Mode	2010 - 2014	Convertible Roof	Actuation Test	ROOF SYSTEM
NISSAN	All Mode	2010 - 2014	Convertible Roof	Actuation Test	5TH BOW SYSTEM
NISSAN	All Mode	2010 - 2014	Convertible Roof	Actuation Test	HYDRAULIC PRESSURE RELEASE
NISSAN	All Mode	2010 - 2014	Convertible Roof	Actuation Test	TRUNK OPENER
NISSAN	All Mode	2010 - 2014	Convertible Roof	Actuation Test	ROOF STATE OUTPUT (AUDIO)
NISSAN	All Mode	2010 - 2014	Convertible Roof	Actuation Test	POWER WINDOW (LH)/RH
NISSAN	All Mode	2010 - 2014	Convertible Roof	Actuation Test	REAR WINDOW DEFOGGER
NISSAN	All Mode	2010 - 2014	Convertible Roof	Actuation Test	OUTSIDE FLAP MOTOR
NISSAN	All Mode	2010 - 2014	Convertible Roof	Actuation Test	INSIDE FLAP MOTOR
NISSAN	All Mode	2010 - 2014	Convertible Roof	Actuation Test	STORAGE LID CLOSURE MOTOR
NISSAN	All Mode	Up to 2011	Head Lamp Levelizer	Read Fault Code	
NISSAN	All Mode	Up to 2011	Head Lamp Levelizer	Clear Fault Code	
NISSAN	All Mode	Up to 2011	Head Lamp Levelizer	Read Data Stream	
NISSAN	All Mode	Up to 2011	Head Lamp Levelizer	Module Information	
NISSAN	All Mode	Up to 2011	Head Lamp Levelizer	Special Function	
NISSAN	All Mode	Up to 2018	Head Lamp Levelizer	Read Fault Code	
NISSAN	All Mode	Up to 2018	Head Lamp Levelizer	Clear Fault Code	

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

<b>make</b>	<b>model</b>	<b>year</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
NISSAN	All Mode	Up to 2018	Head Lamp Levelizer	Read Data Stream	
NISSAN	All Mode	Up to 2018	Head Lamp Levelizer	Module Information	
NISSAN	All Mode	Up to 2018	Head Lamp Levelizer	Special Function	
NISSAN	All Mode	Up to 2017	IC (Instrument cluster)	Read Fault Code	
NISSAN	All Mode	Up to 2017	IC (Instrument cluster)	Clear Fault Code	
NISSAN	All Mode	Up to 2017	IC (Instrument cluster)	Read Data Stream	
NISSAN	All Mode	Up to 2017	IC (Instrument cluster)	Special Function	TURN SIGNAL BUZZER DIAGNOSIS
NISSAN	All Mode	Up to 2017	IC (Instrument cluster)	Special Function	Fuel Meter Diagnosis(Analog Pointer)
NISSAN	All Mode	Up to 2017	IC (Instrument cluster)	Read Fault Code	
NISSAN	All Mode	Up to 2017	IC (Instrument cluster)	Clear Fault Code	
NISSAN	All Mode	Up to 2017	IC (Instrument cluster)	Read Data Stream	
NISSAN	All Mode	Up to 2017	IC (Instrument cluster)	Special Function	TURN SIGNAL BUZZER DIAGNOSIS
NISSAN	All Mode	Up to 2017	IC (Instrument cluster)	Special Function	Fuel Meter Diagnosis(Analog Pointer)
NISSAN	All Mode	2006 - 2016	IC (Instrument cluster)	Read Fault Code	
NISSAN	All Mode	2006 - 2016	IC (Instrument cluster)	Clear Fault Code	
NISSAN	All Mode	2006 - 2016	IC (Instrument cluster)	Read Data Stream	
NISSAN	All Mode	2006 - 2016	IC (Instrument cluster)	Special Function	TURN SIGNAL BUZZER DIAGNOSIS
NISSAN	All Mode	2006 - 2016	IC (Instrument cluster)	Special Function	Fuel Meter Diagnosis(Analog Pointer)
NISSAN	All Mode	2002 - 2017	IC (Instrument cluster)	Read Fault Code	
NISSAN	All Mode	2002 - 2017	IC (Instrument cluster)	Clear Fault Code	
NISSAN	All Mode	2002 - 2017	IC (Instrument cluster)	Read Data Stream	
NISSAN	All Mode	2002 - 2017	IC (Instrument cluster)	Read Freeze Frame	
NISSAN	All Mode	2002 - 2017	IC (Instrument cluster)	Special Function	TURN SIGNAL BUZZER DIAGNOSIS
NISSAN	All Mode	2002 - 2017	IC (Instrument cluster)	Special Function	Outside Air Temperature Diagnosis
NISSAN	All Mode	2002 - 2017	IC (Instrument cluster)	Special Function	Fuel Meter Diagnosis(Analog Pointer)
NISSAN	All Mode	2006 - 2017	IC (Instrument cluster)	Read Fault Code	
NISSAN	All Mode	2006 - 2017	IC (Instrument cluster)	Clear Fault Code	
NISSAN	All Mode	2006 - 2017	IC (Instrument cluster)	Read Data Stream	
NISSAN	All Mode	2006 - 2017	IC (Instrument cluster)	Read Freeze Frame	
NISSAN	All Mode	2006 - 2017	IC (Instrument cluster)	Module Information	
NISSAN	All Mode	2006 - 2017	IC (Instrument cluster)	Special Function	TURN SIGNAL BUZZER DIAGNOSIS
NISSAN	All Mode	2006 - 2017	IC (Instrument cluster)	Special Function	Outside Air Temperature Diagnosis
NISSAN	All Mode	2006 - 2017	IC (Instrument cluster)	Special Function	Fuel Meter Diagnosis(Analog Pointer)
NISSAN	All Mode	Up to 2017	IC (Instrument cluster)	Read Fault Code	
NISSAN	All Mode	Up to 2017	IC (Instrument cluster)	Clear Fault Code	
NISSAN	All Mode	Up to 2017	IC (Instrument cluster)	Read Data Stream	
NISSAN	All Mode	Up to 2017	IC (Instrument cluster)	Read Freeze Frame	
NISSAN	All Mode	Up to 2017	IC (Instrument cluster)	Special Function	Outside Air Temperature Diagnosis
NISSAN	All Mode	Up to 2017	IC (Instrument cluster)	Special Function	Fuel Meter Diagnosis(Analog Pointer)
NISSAN	All Mode	Up to 2017	IC (Instrument cluster)	Special Function	Warning Lamp Diagnosis
NISSAN	All Mode	Up to 2018	IC (Instrument cluster)	Read Fault Code	
NISSAN	All Mode	Up to 2018	IC (Instrument cluster)	Clear Fault Code	
NISSAN	All Mode	Up to 2018	IC (Instrument cluster)	Read Data Stream	
NISSAN	All Mode	Up to 2018	IC (Instrument cluster)	Read Freeze Frame	
NISSAN	All Mode	Up to 2018	IC (Instrument cluster)	Special Function	TURN SIGNAL BUZZER DIAGNOSIS
NISSAN	All Mode	Up to 2018	IC (Instrument cluster)	Special Function	Outside Air Temperature Diagnosis
NISSAN	All Mode	Up to 2018	IC (Instrument cluster)	Special Function	Fuel Meter Diagnosis(Analog Pointer)
NISSAN	All Mode	2007 - 2017	IC (Instrument cluster)	Read Fault Code	
NISSAN	All Mode	2007 - 2017	IC (Instrument cluster)	Clear Fault Code	
NISSAN	All Mode	2007 - 2017	IC (Instrument cluster)	Read Data Stream	
NISSAN	All Mode	2007 - 2017	IC (Instrument cluster)	Read Freeze Frame	
NISSAN	All Mode	2007 - 2017	IC (Instrument cluster)	Module Information	
NISSAN	All Mode	2007 - 2017	IC (Instrument cluster)	Special Function	TURN SIGNAL BUZZER DIAGNOSIS
NISSAN	All Mode	2007 - 2017	IC (Instrument cluster)	Special Function	Outside Air Temperature Diagnosis
NISSAN	All Mode	2007 - 2017	IC (Instrument cluster)	Special Function	Fuel Meter Diagnosis(Analog Pointer)
NISSAN	SUNNY	2006	IC (Instrument cluster)	Read Fault Code	
NISSAN	SUNNY	2006	IC (Instrument cluster)	Clear Fault Code	
NISSAN	SUNNY	2006	IC (Instrument cluster)	Read Data Stream	
NISSAN	SUNNY	2006	IC (Instrument cluster)	Module Information	
NISSAN	SUNNY	2006	IC (Instrument cluster)	Actuation Test	Inpane Warning Light

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

<b>make</b>	<b>model</b>	<b>year</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
NISSAN	SUNNY	2006	IC (Instrument cluster)	Actuation Test	Lcd Instrument Segments
NISSAN	SUNNY	2006	IC (Instrument cluster)	Actuation Test	Water Temperature Gauge
NISSAN	SUNNY	2006	IC (Instrument cluster)	Actuation Test	Fuel Gauge
NISSAN	SUNNY	2006	IC (Instrument cluster)	Actuation Test	Speedometer
NISSAN	SUNNY	2006	IC (Instrument cluster)	Actuation Test	Rev Counter
NISSAN	SUNNY	2006	IC (Instrument cluster)	Actuation Test	BUZZER
NISSAN	SUNNY	2006	IC (Instrument cluster)	Actuation Test	Rear Screen Demister
NISSAN	SUNNY	2006	IC (Instrument cluster)	Actuation Test	Folding Mirror
NISSAN	SUNNY	2006	IC (Instrument cluster)	Actuation Test	Tail Lamp
NISSAN	SUNNY	2006	IC (Instrument cluster)	Actuation Test	Power Windows
NISSAN	SUNNY	2006	IC (Instrument cluster)	Actuation Test	Battery Saver Relay
NISSAN	SUNNY	2006	IC (Instrument cluster)	Actuation Test	Door Lock
NISSAN	SUNNY	2006	IC (Instrument cluster)	Actuation Test	Driver Door Unlock
NISSAN	SUNNY	2006	IC (Instrument cluster)	Actuation Test	Other Door Unlock
NISSAN	SUNNY	2006	IC (Instrument cluster)	Actuation Test	Door Locking Lamp
NISSAN	SUNNY	2006	IC (Instrument cluster)	Actuation Test	Theft-Warning Relay
NISSAN	SUNNY	2006	IC (Instrument cluster)	Actuation Test	Horn
NISSAN	SUNNY	2006	IC (Instrument cluster)	Actuation Test	Selectlev Lock Elecmag
NISSAN	SUNNY	2006	IC (Instrument cluster)	Actuation Test	LEFT INDICATOR
NISSAN	SUNNY	2006	IC (Instrument cluster)	Actuation Test	RIGHT-HAND INDICATOR
NISSAN	SUNNY	2006	IC (Instrument cluster)	Actuation Test	INTERIOR LIGHTING
NISSAN	SUNNY	2006	IC (Instrument cluster)	Actuation Test	Trunk Open
NISSAN	All Mode	2010 - 2018	IC (Instrument cluster)	Read Fault Code	
NISSAN	All Mode	2010 - 2018	IC (Instrument cluster)	Clear Fault Code	
NISSAN	All Mode	2010 - 2018	IC (Instrument cluster)	Read Data Stream	
NISSAN	All Mode	2010 - 2018	IC (Instrument cluster)	Module Information	
NISSAN	All Mode	2010 - 2018	IC (Instrument cluster)	Special Function	TURN SIGNAL BUZZER DIAGNOSIS
NISSAN	All Mode	2010 - 2018	IC (Instrument cluster)	Special Function	Outside Air Temperature Diagnosis
NISSAN	All Mode	2010 - 2018	IC (Instrument cluster)	Special Function	Fuel Meter Diagnosis(Analog Pointer)
NISSAN	All Mode	2010 - 2017	IC (Instrument cluster)	Read Fault Code	
NISSAN	All Mode	2010 - 2017	IC (Instrument cluster)	Clear Fault Code	
NISSAN	All Mode	2010 - 2017	IC (Instrument cluster)	Read Data Stream	
NISSAN	All Mode	2010 - 2017	IC (Instrument cluster)	Module Information	
NISSAN	All Mode	2010 - 2017	IC (Instrument cluster)	Special Function	Reset Guideline Position
NISSAN	All Mode	2010 - 2017	IC (Instrument cluster)	Special Function	Customize Reset Consult
NISSAN	All Mode	2010 - 2017	IC (Instrument cluster)	Special Function	TURN SIGNAL BUZZER DIAGNOSIS
NISSAN	All Mode	2010 - 2017	IC (Instrument cluster)	Special Function	Outside Air Temperature Diagnosis
NISSAN	All Mode	2010 - 2017	IC (Instrument cluster)	Special Function	Fuel Meter Diagnosis(Analog Pointer)
NISSAN	All Mode	2010 - 2017	IC (Instrument cluster)	Special Function	Warning Lamp Diagnosis
NISSAN	All Mode	2015 - 2018	IC (Instrument cluster)	Read Fault Code	
NISSAN	All Mode	2015 - 2018	IC (Instrument cluster)	Clear Fault Code	
NISSAN	All Mode	2015 - 2018	IC (Instrument cluster)	Read Data Stream	
NISSAN	All Mode	2015 - 2018	IC (Instrument cluster)	Module Information	
NISSAN	All Mode	2015 - 2018	IC (Instrument cluster)	Actuation Test	Instrument illumination
NISSAN	All Mode	2015 - 2018	IC (Instrument cluster)	Actuation Test	Warning buzzer
NISSAN	All Mode	2015 - 2018	IC (Instrument cluster)	Actuation Test	Indicator Lamp
NISSAN	All Mode	2015 - 2018	IC (Instrument cluster)	Actuation Test	Mechanical instrument pointers
NISSAN	All Mode	2015 - 2018	IC (Instrument cluster)	Actuation Test	Control unit reset
NISSAN	All Mode	2015 - 2018	IC (Instrument cluster)	Special Function	Teach In Combination Meter
NISSAN	All Mode	2015 - 2018	IC (Instrument cluster)	Special Function	Table Initialization Assyst
NISSAN	All Mode	2015 - 2018	IC (Instrument cluster)	Special Function	Transfer Of Manufacturer Default Settings
NISSAN	All Mode	2015 - 2018	IC (Instrument cluster)	Special Function	Oil grade factor
NISSAN	All Mode	2016 - 2017	IC (Instrument cluster)	Read Fault Code	
NISSAN	All Mode	2016 - 2017	IC (Instrument cluster)	Clear Fault Code	
NISSAN	All Mode	2016 - 2017	IC (Instrument cluster)	Read Data Stream	
NISSAN	All Mode	2016 - 2017	IC (Instrument cluster)	Module Information	
NISSAN	Venucia T90	2016	IC (Instrument cluster)	Read Fault Code	
NISSAN	Venucia T90	2016	IC (Instrument cluster)	Clear Fault Code	
NISSAN	Venucia T90	2016	IC (Instrument cluster)	Read Data Stream	
NISSAN	Venucia T90	2016	IC (Instrument cluster)	Module Information	
NISSAN	Venucia T90	2016	IC (Instrument cluster)	Read Fault Code	
NISSAN	Venucia T90	2016	IC (Instrument cluster)	Clear Fault Code	
NISSAN	Venucia T90	2016	IC (Instrument cluster)	Read Data Stream	
NISSAN	Venucia T90	2016	IC (Instrument cluster)	Module Information	
NISSAN	All Mode	As of 2012	IC (Instrument cluster)	Read Fault Code	
NISSAN	All Mode	As of 2012	IC (Instrument cluster)	Clear Fault Code	
NISSAN	All Mode	As of 2012	IC (Instrument cluster)	Read Data Stream	
NISSAN	All Mode	As of 2012	IC (Instrument cluster)	Module Information	
NISSAN	LEAF	2016	IC (Instrument cluster)	Read Fault Code	
NISSAN	LEAF	2016	IC (Instrument cluster)	Clear Fault Code	
NISSAN	LEAF	2016	IC (Instrument cluster)	Read Data Stream	
NISSAN	LEAF	2016	IC (Instrument cluster)	Module Information	

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
NISSAN	All Mode	2004 - 2017	E-4WD	Read Fault Code	
NISSAN	All Mode	2004 - 2017	E-4WD	Clear Fault Code	
NISSAN	All Mode	2004 - 2017	E-4WD	Read Data Stream	
NISSAN	All Mode	2004 - 2017	E-4WD	Read Freeze Frame	
NISSAN	All Mode	2004 - 2017	E-4WD	Module Information	
NISSAN	All Mode	2004 - 2017	E-4WD	Actuation Test	MOTOR 1 CHECK
NISSAN	All Mode	2004 - 2017	E-4WD	Actuation Test	CLUTCH CHECK
NISSAN	All Mode	2004 - 2017	E-4WD	Actuation Test	e-4WD RELAY CHECK
NISSAN	All Mode	2004 - 2017	E-4WD	Actuation Test	MOTOR 2 CHECK
NISSAN	All Mode	2004 - 2017	E-4WD	Actuation Test	GENERATOR CHECK
NISSAN	All Mode	As of 2012	E-4WD	Read Fault Code	
NISSAN	All Mode	As of 2012	E-4WD	Clear Fault Code	
NISSAN	All Mode	As of 2012	E-4WD	Read Data Stream	
NISSAN	All Mode	As of 2012	E-4WD	Module Information	
NISSAN	All Mode	As of 2012	E-4WD	Read Fault Code	
NISSAN	All Mode	As of 2012	E-4WD	Clear Fault Code	
NISSAN	All Mode	As of 2012	E-4WD	Read Data Stream	
NISSAN	All Mode	As of 2012	E-4WD	Module Information	
NISSAN	All Mode	As of 2012	E-4WD	Actuation Test	
NISSAN	All Mode	2009 - 2017	Laser/Radar	Read Fault Code	
NISSAN	All Mode	2009 - 2017	Laser/Radar	Clear Fault Code	
NISSAN	All Mode	2009 - 2017	Laser/Radar	Read Data Stream	
NISSAN	All Mode	2009 - 2017	Laser/Radar	Module Information	
NISSAN	All Mode	2009 - 2017	Laser/Radar	Special Function	Laser Beam Adjust
NISSAN	All Mode	2009 - 2017	Laser/Radar	Read Fault Code	
NISSAN	All Mode	2009 - 2017	Laser/Radar	Clear Fault Code	
NISSAN	All Mode	2009 - 2017	Laser/Radar	Read Data Stream	
NISSAN	All Mode	2009 - 2017	Laser/Radar	Module Information	
NISSAN	All Mode	2009 - 2018	Laser/Radar	Read Fault Code	
NISSAN	All Mode	2009 - 2018	Laser/Radar	Clear Fault Code	
NISSAN	All Mode	2009 - 2018	Laser/Radar	Read Data Stream	
NISSAN	All Mode	2009 - 2018	Laser/Radar	Module Information	
NISSAN	All Mode	2009 - 2018	Laser/Radar	Special Function	Milliwave Radar Adjust
NISSAN	All Mode	2009 - 2017	Laser/Radar	Read Fault Code	
NISSAN	All Mode	2009 - 2017	Laser/Radar	Clear Fault Code	
NISSAN	All Mode	2009 - 2017	Laser/Radar	Read Data Stream	
NISSAN	All Mode	2009 - 2017	Laser/Radar	Module Information	
NISSAN	All Mode	2009 - 2017	Laser/Radar	Actuation Test	Brake Actuator
NISSAN	All Mode	2009 - 2017	Laser/Radar	Actuation Test	ICC BUZZER
NISSAN	All Mode	2009 - 2017	Laser/Radar	Actuation Test	Meter Lamp
NISSAN	All Mode	2009 - 2017	Laser/Radar	Special Function	FEB Default Setting
NISSAN	All Mode	2009 - 2017	Laser/Radar	Read Fault Code	
NISSAN	All Mode	2009 - 2017	Laser/Radar	Clear Fault Code	
NISSAN	All Mode	2009 - 2017	Laser/Radar	Read Data Stream	
NISSAN	All Mode	2009 - 2017	Laser/Radar	Module Information	
NISSAN	NV350 URVAN/NV350	2012	Laser/Radar	Read Fault Code	
NISSAN	NV350 URVAN/NV350	2012	Laser/Radar	Clear Fault Code	
NISSAN	NV350 URVAN/NV350	2012	Laser/Radar	Read Data Stream	
NISSAN	NV350 URVAN/NV350	2012	Laser/Radar	Module Information	
NISSAN	All Mode	2015 - 2017	Laser/Radar	Read Fault Code	
NISSAN	All Mode	2015 - 2017	Laser/Radar	Clear Fault Code	
NISSAN	All Mode	2015 - 2017	Laser/Radar	Read Data Stream	
NISSAN	All Mode	2015 - 2017	Laser/Radar	Module Information	
NISSAN	All Mode	Up to 2016	Intelligent Key	Read Fault Code	
NISSAN	All Mode	Up to 2016	Intelligent Key	Clear Fault Code	
NISSAN	All Mode	Up to 2016	Intelligent Key	Read Data Stream	
NISSAN	All Mode	Up to 2016	Intelligent Key	Module Information	
NISSAN	All Mode	Up to 2016	Intelligent Key	Actuation Test	Outside Buzzer
NISSAN	All Mode	Up to 2016	Intelligent Key	Actuation Test	Inside Buzzer
NISSAN	All Mode	Up to 2016	Intelligent Key	Actuation Test	Indicator
NISSAN	All Mode	Up to 2016	Intelligent Key	Actuation Test	Door Lock/Unlock
NISSAN	All Mode	Up to 2016	Intelligent Key	Actuation Test	ANTENNA
NISSAN	All Mode	Up to 2016	Intelligent Key	Special Function	Confirm Key Fob ID
NISSAN	All Mode	Up to 2016	Intelligent Key	Special Function	Take Out From Window Warn
NISSAN	All Mode	Up to 2016	Intelligent Key	Special Function	Low Batt Of Key Fob Warn
NISSAN	All Mode	Up to 2016	Intelligent Key	Special Function	Keyless Function
NISSAN	All Mode	Up to 2016	Intelligent Key	Special Function	Answer Back Function
NISSAN	All Mode	Up to 2016	Intelligent Key	Special Function	Selective Unlock Function
NISSAN	All Mode	Up to 2016	Intelligent Key	Special Function	Hazard Answer Back
NISSAN	All Mode	Up to 2016	Intelligent Key	Special Function	Answer Back With I-Key Lock
NISSAN	All Mode	Up to 2016	Intelligent Key	Special Function	Answer Back With I-Key Unlock
NISSAN	All Mode	Up to 2016	Intelligent Key	Special Function	Trunk Open Delay
NISSAN	All Mode	Up to 2016	Intelligent Key	Special Function	Auto Relock Timer
NISSAN	All Mode	Up to 2016	Intelligent Key	Special Function	Trunk/Glass Hatch Open
NISSAN	All Mode	Up to 2016	Intelligent Key	Special Function	Power Slide Door Delay
NISSAN	All Mode	Up to 2016	Intelligent Key	Special Function	Engine Start By I-Key
NISSAN	All Mode	Up to 2016	Intelligent Key	Special Function	Lock/Unlock By I-Key
NISSAN	All Mode	Up to 2016	Intelligent Key	Read Fault Code	
NISSAN	All Mode	Up to 2016	Intelligent Key	Clear Fault Code	

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
NISSAN	All Mode	Up to 2016	Intelligent Key	Read Data Stream	
NISSAN	All Mode	Up to 2016	Intelligent Key	Module Information	
NISSAN	All Mode	Up to 2016	Intelligent Key	Actuation Test	Door Lock/Unlock
NISSAN	All Mode	Up to 2016	Intelligent Key	Actuation Test	ANTENNA
NISSAN	All Mode	Up to 2016	Intelligent Key	Actuation Test	Outside Buzzer
NISSAN	All Mode	Up to 2016	Intelligent Key	Actuation Test	Inside Buzzer
NISSAN	All Mode	Up to 2016	Intelligent Key	Actuation Test	Indicator
NISSAN	All Mode	Up to 2016	Intelligent Key	Actuation Test	LCD
NISSAN	All Mode	Up to 2016	Intelligent Key	Actuation Test	P Range
NISSAN	All Mode	Up to 2016	Intelligent Key	Actuation Test	Engine SW Illumi
NISSAN	All Mode	Up to 2016	Intelligent Key	Actuation Test	Lock Indicator
NISSAN	All Mode	Up to 2016	Intelligent Key	Actuation Test	ACC Indicator
NISSAN	All Mode	Up to 2016	Intelligent Key	Actuation Test	Ignition ON IND
NISSAN	All Mode	Up to 2016	Intelligent Key	Actuation Test	Key Slot Illumi
NISSAN	All Mode	Up to 2016	Intelligent Key	Special Function	Confirm Key Fob ID
NISSAN	All Mode	Up to 2016	Intelligent Key	Special Function	Take Out From Window Warn
NISSAN	All Mode	Up to 2016	Intelligent Key	Special Function	Low Batt Of Key Fob Warn
NISSAN	All Mode	Up to 2016	Intelligent Key	Special Function	I-Key Function
NISSAN	All Mode	Up to 2016	Intelligent Key	Special Function	Answer Back Function
NISSAN	All Mode	Up to 2016	Intelligent Key	Special Function	Keyless Function
NISSAN	All Mode	Up to 2016	Intelligent Key	Special Function	Selective Unlock Function
NISSAN	All Mode	Up to 2016	Intelligent Key	Special Function	Anti Key Lock In Function
NISSAN	All Mode	Up to 2016	Intelligent Key	Special Function	Hazard Answer Back
NISSAN	All Mode	Up to 2016	Intelligent Key	Special Function	Answer Back With I-Key Lock
NISSAN	All Mode	Up to 2016	Intelligent Key	Special Function	Answer Back With I-Key Unlock
NISSAN	All Mode	Up to 2016	Intelligent Key	Special Function	Auto Relock Timer
NISSAN	All Mode	Up to 2016	Intelligent Key	Special Function	Panic Alarm Delay
NISSAN	All Mode	Up to 2016	Intelligent Key	Special Function	Trunk Open Delay
NISSAN	All Mode	Up to 2016	Intelligent Key	Special Function	P/W Down Delay
NISSAN	All Mode	Up to 2016	Intelligent Key	Special Function	Power Slide Door Delay
NISSAN	All Mode	Up to 2016	Intelligent Key	Special Function	Engine Start By I-Key
NISSAN	All Mode	Up to 2016	Intelligent Key	Special Function	Lock/Unlock By I-Key
NISSAN	All Mode	Up to 2016	Intelligent Key	Special Function	LUG Room Engine Start
NISSAN	All Mode	Up to 2016	Intelligent Key	Special Function	Horn With Keyless Lock
NISSAN	All Mode	Up to 2016	Intelligent Key	Special Function	Trunk/Glass Hatch Open
NISSAN	All Mode	Up to 2016	Intelligent Key	Special Function	Short Cranking Output
NISSAN	All Mode	Up to 2016	Intelligent Key	Read Fault Code	
NISSAN	All Mode	Up to 2016	Intelligent Key	Clear Fault Code	
NISSAN	All Mode	Up to 2016	Intelligent Key	Read Data Stream	
NISSAN	All Mode	Up to 2016	Intelligent Key	Module Information	
NISSAN	All Mode	Up to 2016	Intelligent Key	Actuation Test	Door Lock/Unlock
NISSAN	All Mode	Up to 2016	Intelligent Key	Actuation Test	ANTENNA
NISSAN	All Mode	Up to 2016	Intelligent Key	Actuation Test	Outside Buzzer
NISSAN	All Mode	Up to 2016	Intelligent Key	Actuation Test	INDICATOR
NISSAN	All Mode	Up to 2016	Intelligent Key	Actuation Test	LCD
NISSAN	All Mode	Up to 2016	Intelligent Key	Actuation Test	P Range
NISSAN	All Mode	Up to 2016	Intelligent Key	Actuation Test	Engine SW Illumi
NISSAN	All Mode	Up to 2016	Intelligent Key	Actuation Test	Lock Indicator
NISSAN	All Mode	Up to 2016	Intelligent Key	Actuation Test	ACC Indicator
NISSAN	All Mode	Up to 2016	Intelligent Key	Actuation Test	Ignition ON IND
NISSAN	All Mode	Up to 2016	Intelligent Key	Actuation Test	Key Slot Illumi
NISSAN	All Mode	Up to 2016	Intelligent Key	Special Function	Confirm Key Fob ID
NISSAN	All Mode	Up to 2016	Intelligent Key	Special Function	Short Cranking Output
NISSAN	All Mode	Up to 2016	Intelligent Key	Special Function	Take Out From Window Warn
NISSAN	All Mode	Up to 2016	Intelligent Key	Special Function	Low Batt Of Key Fob Warn
NISSAN	All Mode	Up to 2016	Intelligent Key	Special Function	Answer Back Function
NISSAN	All Mode	Up to 2016	Intelligent Key	Special Function	Selective Unlock Function
NISSAN	All Mode	Up to 2016	Intelligent Key	Special Function	Horn With Keyless Lock
NISSAN	All Mode	Up to 2016	Intelligent Key	Special Function	Hazard Answer Back
NISSAN	All Mode	Up to 2016	Intelligent Key	Special Function	Answer Back With I-Key Lock
NISSAN	All Mode	Up to 2016	Intelligent Key	Special Function	Answer Back With I-Key Unlock
NISSAN	All Mode	Up to 2016	Intelligent Key	Special Function	Auto Relock Timer
NISSAN	All Mode	Up to 2016	Intelligent Key	Special Function	Panic Alarm Delay
NISSAN	All Mode	Up to 2016	Intelligent Key	Special Function	Trunk/Glass Hatch Open
NISSAN	All Mode	Up to 2016	Intelligent Key	Special Function	Trunk Open Delay
NISSAN	All Mode	Up to 2016	Intelligent Key	Special Function	P/W Down Delay
NISSAN	All Mode	Up to 2016	Intelligent Key	Special Function	Engine Start By I-Key
NISSAN	All Mode	Up to 2016	Intelligent Key	Special Function	Lock/Unlock By I-Key
NISSAN	All Mode	Up to 2016	Intelligent Key	Special Function	LUG Room Engine Start
NISSAN	All Mode	Up to 2016	Intelligent Key	Read Fault Code	
NISSAN	All Mode	Up to 2016	Intelligent Key	Clear Fault Code	
NISSAN	All Mode	Up to 2016	Intelligent Key	Read Data Stream	
NISSAN	All Mode	Up to 2016	Intelligent Key	Module Information	
NISSAN	All Mode	Up to 2016	Intelligent Key	Actuation Test	Outside Buzzer
NISSAN	All Mode	Up to 2016	Intelligent Key	Actuation Test	Inside Buzzer
NISSAN	All Mode	Up to 2016	Intelligent Key	Actuation Test	Indicator
NISSAN	All Mode	Up to 2016	Intelligent Key	Actuation Test	Door Lock/Unlock
NISSAN	All Mode	Up to 2016	Intelligent Key	Actuation Test	ANTENNA

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
NISSAN	All Mode	Up to 2016	Intelligent Key	Special Function	Take Out From Window Warn
NISSAN	All Mode	Up to 2016	Intelligent Key	Special Function	Low Batt Of Key Fob Warn
NISSAN	All Mode	Up to 2016	Intelligent Key	Special Function	Answer Back Function
NISSAN	All Mode	Up to 2016	Intelligent Key	Special Function	Selective Unlock Function
NISSAN	All Mode	Up to 2016	Intelligent Key	Special Function	Anti Key Lock In Function
NISSAN	All Mode	Up to 2016	Intelligent Key	Special Function	Horn With Keyless Lock
NISSAN	All Mode	Up to 2016	Intelligent Key	Special Function	Hazard Answer Back
NISSAN	All Mode	Up to 2016	Intelligent Key	Special Function	Answer Back With I-Key Lock
NISSAN	All Mode	Up to 2016	Intelligent Key	Special Function	Answer Back With I-Key Unlock
NISSAN	All Mode	Up to 2016	Intelligent Key	Special Function	Auto Relock Timer
NISSAN	All Mode	Up to 2016	Intelligent Key	Special Function	Panic Alarm Delay
NISSAN	All Mode	Up to 2016	Intelligent Key	Special Function	Trunk/Glass Hatch Open
NISSAN	All Mode	Up to 2016	Intelligent Key	Special Function	Trunk Open Delay
NISSAN	All Mode	Up to 2016	Intelligent Key	Special Function	P/W Down Delay
NISSAN	All Mode	Up to 2016	Intelligent Key	Special Function	Power Slide Door Delay
NISSAN	All Mode	Up to 2016	Intelligent Key	Special Function	Engine Start By I-Key
NISSAN	All Mode	Up to 2016	Intelligent Key	Special Function	Lock/Unlock By I-Key
NISSAN	All Mode	Up to 2016	Intelligent Key	Special Function	Confirm Key Fob ID
NISSAN	All Mode	Up to 2016	Intelligent Key	Read Fault Code	
NISSAN	All Mode	Up to 2016	Intelligent Key	Clear Fault Code	
NISSAN	All Mode	Up to 2016	Intelligent Key	Read Data Stream	
NISSAN	All Mode	Up to 2016	Intelligent Key	Module Information	
NISSAN	All Mode	Up to 2016	Intelligent Key	Special Function	Confirm Key Fob ID
NISSAN	All Mode	Up to 2016	Intelligent Key	Special Function	Take Out From Window Warn
NISSAN	All Mode	Up to 2016	Intelligent Key	Special Function	Low Batt Of Key Fob Warn
NISSAN	All Mode	Up to 2016	Intelligent Key	Special Function	I-Key Function
NISSAN	All Mode	Up to 2016	Intelligent Key	Special Function	Answer Back Function
NISSAN	All Mode	Up to 2016	Intelligent Key	Read Fault Code	
NISSAN	All Mode	Up to 2016	Intelligent Key	Clear Fault Code	
NISSAN	All Mode	Up to 2016	Intelligent Key	Read Data Stream	
NISSAN	All Mode	Up to 2016	Intelligent Key	Module Information	
NISSAN	All Mode	Up to 2016	Intelligent Key	Actuation Test	Door Lock/Unlock
NISSAN	All Mode	Up to 2016	Intelligent Key	Actuation Test	ANTENNA
NISSAN	All Mode	Up to 2016	Intelligent Key	Actuation Test	Outside Buzzer
NISSAN	All Mode	Up to 2016	Intelligent Key	Actuation Test	Inside Buzzer
NISSAN	All Mode	Up to 2016	Intelligent Key	Actuation Test	Indicator
NISSAN	All Mode	Up to 2016	Intelligent Key	Actuation Test	KEY LOCK SOLENOID
NISSAN	All Mode	Up to 2016	Intelligent Key	Actuation Test	P Range
NISSAN	All Mode	Up to 2016	Intelligent Key	Actuation Test	Engine SW Illumi
NISSAN	All Mode	Up to 2016	Intelligent Key	Actuation Test	Lock Indicator
NISSAN	All Mode	Up to 2016	Intelligent Key	Actuation Test	ACC Indicator
NISSAN	All Mode	Up to 2016	Intelligent Key	Actuation Test	Ignition ON IND
NISSAN	All Mode	Up to 2016	Intelligent Key	Actuation Test	Key Slot Illumi
NISSAN	All Mode	Up to 2016	Intelligent Key	Actuation Test	LCD
NISSAN	All Mode	Up to 2016	Intelligent Key	Special Function	Confirm Key Fob ID
NISSAN	All Mode	Up to 2016	Intelligent Key	Special Function	Take Out From Window Warn
NISSAN	All Mode	Up to 2016	Intelligent Key	Special Function	Low Batt Of Key Fob Warn
NISSAN	All Mode	Up to 2016	Intelligent Key	Special Function	Keyless Function
NISSAN	All Mode	Up to 2016	Intelligent Key	Special Function	I-Key Function
NISSAN	All Mode	Up to 2016	Intelligent Key	Special Function	Answer Back Function
NISSAN	All Mode	Up to 2016	Intelligent Key	Special Function	Selective Unlock Function
NISSAN	All Mode	Up to 2016	Intelligent Key	Special Function	Anti Key Lock In Function
NISSAN	All Mode	Up to 2016	Intelligent Key	Special Function	Hazard Answer Back
NISSAN	All Mode	Up to 2016	Intelligent Key	Special Function	Answer Back With I-Key Unlock
NISSAN	All Mode	Up to 2016	Intelligent Key	Special Function	Auto Relock Timer
NISSAN	All Mode	Up to 2016	Intelligent Key	Special Function	Panic Alarm Delay
NISSAN	All Mode	Up to 2016	Intelligent Key	Special Function	Trunk Open Delay
NISSAN	All Mode	Up to 2016	Intelligent Key	Special Function	P/W Down Delay
NISSAN	All Mode	Up to 2016	Intelligent Key	Special Function	Power Slide Door Delay
NISSAN	All Mode	Up to 2016	Intelligent Key	Special Function	Engine Start By I-Key
NISSAN	All Mode	Up to 2016	Intelligent Key	Special Function	Lock/Unlock By I-Key
NISSAN	All Mode	Up to 2016	Intelligent Key	Special Function	LUG Room Engine Start
NISSAN	All Mode	Up to 2016	Intelligent Key	Special Function	Trunk/Glass Hatch Open
NISSAN	All Mode	Up to 2016	Intelligent Key	Special Function	Short Cranking Output
NISSAN	All Mode	Up to 2016	Intelligent Key	Special Function	Answer Back With I-Key Lock
NISSAN	All Mode	Up to 2016	Intelligent Key	Read Fault Code	
NISSAN	All Mode	Up to 2016	Intelligent Key	Clear Fault Code	
NISSAN	All Mode	Up to 2016	Intelligent Key	Read Data Stream	
NISSAN	All Mode	Up to 2016	Intelligent Key	Module Information	
NISSAN	All Mode	Up to 2016	Intelligent Key	Special Function	Take Out From Window Warn
NISSAN	All Mode	Up to 2016	Intelligent Key	Special Function	Low Batt Of Key Fob Warn
NISSAN	All Mode	Up to 2016	Intelligent Key	Special Function	I-Key Function
NISSAN	All Mode	Up to 2016	Intelligent Key	Special Function	Answer Back Function
NISSAN	All Mode	Up to 2016	Intelligent Key	Special Function	Confirm Key Fob ID
NISSAN	NV400	2011	Intelligent Key	Read Fault Code	
NISSAN	NV400	2011	Intelligent Key	Clear Fault Code	
NISSAN	NV400	2011	Intelligent Key	Read Data Stream	
NISSAN	NV400	2011	Intelligent Key	Module Information	



**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

<b>make</b>	<b>model</b>	<b>year</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
NISSAN	NV400	2011	Intelligent Key	Actuation Test	Interior Aerial 1 Test
NISSAN	NV400	2011	Intelligent Key	Actuation Test	Interior Aerial 2 Test
NISSAN	NV400	2011	Intelligent Key	Actuation Test	External Boot Aerial Test
NISSAN	NV400	2011	Intelligent Key	Actuation Test	FR LH External Aerial Test
NISSAN	NV400	2011	Intelligent Key	Actuation Test	FR RH External Aerial Test
NISSAN	NV400	2011	Intelligent Key	Special Function	Vin Registration
NISSAN	NV400	2011	Intelligent Key	Special Function	Hands-Free Card Reading
NISSAN	NV400	2011	Intelligent Key	Special Function	Programming The Hands-Free Card
NISSAN	NV400	2011	Intelligent Key	Special Function	H-Free Cards Low Battery Counter
NISSAN	All Mode	2010 - 2016	Intelligent Key	Read Fault Code	
NISSAN	All Mode	2010 - 2016	Intelligent Key	Clear Fault Code	
NISSAN	All Mode	2010 - 2016	Intelligent Key	Read Data Stream	
NISSAN	All Mode	2010 - 2016	Intelligent Key	Module Information	
NISSAN	All Mode	2010 - 2016	Intelligent Key	Actuation Test	Door Lock
NISSAN	All Mode	2010 - 2016	Intelligent Key	Actuation Test	ANTENNA
NISSAN	All Mode	2010 - 2016	Intelligent Key	Actuation Test	INDICATOR
NISSAN	All Mode	2010 - 2016	Intelligent Key	Special Function	Hands-Free Card Reading
NISSAN	All Mode	2010 - 2016	Intelligent Key	Special Function	Programming The Hands-Free Card
NISSAN	All Mode	2015 - 2018	Intelligent Key	Read Fault Code	
NISSAN	All Mode	2015 - 2018	Intelligent Key	Clear Fault Code	
NISSAN	All Mode	2015 - 2018	Intelligent Key	Read Data Stream	
NISSAN	All Mode	2015 - 2018	Intelligent Key	Module Information	
NISSAN	All Mode	2016 - 2017	Intelligent Key	Read Fault Code	
NISSAN	All Mode	2016 - 2017	Intelligent Key	Clear Fault Code	
NISSAN	All Mode	2016 - 2017	Intelligent Key	Read Data Stream	
NISSAN	All Mode	2016 - 2017	Intelligent Key	Module Information	
NISSAN	All Mode	2016 - 2017	Intelligent Key	Actuation Test	Outside Buzzer
NISSAN	All Mode	2016 - 2017	Intelligent Key	Actuation Test	IGN CONT2
NISSAN	All Mode	2016 - 2017	Intelligent Key	Actuation Test	(TBD)AT DEVICE
NISSAN	All Mode	2016 - 2017	Intelligent Key	Actuation Test	Engine SW Illumi
NISSAN	All Mode	2016 - 2017	Intelligent Key	Actuation Test	IGNITION RELAY
NISSAN	All Mode	2016 - 2017	Intelligent Key	Special Function	Inside ANT Diagnosis
NISSAN	All Mode	2016 - 2017	Intelligent Key	Special Function	Lock/Unlock By I-Key
NISSAN	All Mode	2016 - 2017	Intelligent Key	Special Function	Engine Start By I-Key
NISSAN	All Mode	2016 - 2017	Intelligent Key	Special Function	Trunk/Glass Hatch Open
NISSAN	All Mode	2016 - 2017	Intelligent Key	Special Function	Auto Lock Set
NISSAN	All Mode	2016 - 2017	Intelligent Key	Special Function	Short Cranking Output
NISSAN	All Mode	2016 - 2017	Intelligent Key	Special Function	IGN/ACC Battery Saver
NISSAN	All Mode	2016 - 2017	Intelligent Key	Special Function	Answer Back
NISSAN	All Mode	2016 - 2017	Intelligent Key	Special Function	Door Lock-Unlock Set
NISSAN	All Mode	2016 - 2017	Intelligent Key	Special Function	Answer Back I-Key Lock Unlock
NISSAN	All Mode	2016 - 2017	Intelligent Key	Special Function	Answerback I-Key Lock Unlock
NISSAN	All Mode	2016 - 2017	Intelligent Key	Special Function	Answerback Keyless Lock Unlock
NISSAN	All Mode	2016 - 2017	Intelligent Key	Special Function	Reset Setting Value
NISSAN	All Mode	Up to 2011	DIU	Read Fault Code	
NISSAN	All Mode	Up to 2011	DIU	Clear Fault Code	
NISSAN	All Mode	Up to 2011	DIU	Read Data Stream	
NISSAN	All Mode	Up to 2015	Auto Slide Door	Read Fault Code	
NISSAN	All Mode	Up to 2015	Auto Slide Door	Clear Fault Code	
NISSAN	All Mode	Up to 2015	Auto Slide Door	Read Data Stream	
NISSAN	All Mode	Up to 2015	Auto Slide Door	Module Information	
NISSAN	All Mode	Up to 2015	Auto Slide Door	Actuation Test	CLUTCH
NISSAN	All Mode	2009 - 2017	Auto Slide Door	Read Fault Code	
NISSAN	All Mode	2009 - 2017	Auto Slide Door	Clear Fault Code	
NISSAN	All Mode	2009 - 2017	Auto Slide Door	Read Data Stream	
NISSAN	All Mode	2009 - 2017	Auto Slide Door	Read Freeze Frame	
NISSAN	All Mode	2009 - 2017	Auto Slide Door	Module Information	
NISSAN	All Mode	2009 - 2017	Auto Slide Door	Actuation Test	CLUTCH
NISSAN	All Mode	2009 - 2017	Auto Slide Door	Actuation Test	Slide Door
NISSAN	All Mode	2009 - 2017	Auto Slide Door	Actuation Test	BUZZER
NISSAN	All Mode	2009 - 2017	Auto Slide Door	Actuation Test	Lock Release
NISSAN	All Mode	2016 - 2017	Auto Slide Door	Read Fault Code	
NISSAN	All Mode	2016 - 2017	Auto Slide Door	Clear Fault Code	
NISSAN	All Mode	2016 - 2017	Auto Slide Door	Read Data Stream	
NISSAN	All Mode	2016 - 2017	Auto Slide Door	Module Information	
NISSAN	All Mode	2016 - 2017	Auto Slide Door	Actuation Test	(TBD)Clutch Hold operation
NISSAN	All Mode	2016 - 2017	Auto Slide Door	Special Function	Hands free sensor parts number
NISSAN	All Mode	2002 - 2010	Precrash Seatbelt	Read Fault Code	
NISSAN	All Mode	2002 - 2010	Precrash Seatbelt	Clear Fault Code	
NISSAN	All Mode	2002 - 2010	Precrash Seatbelt	Read Data Stream	
NISSAN	All Mode	2002 - 2010	Precrash Seatbelt	Module Information	
NISSAN	All Mode	2005 - 2015	Precrash Seatbelt	Read Fault Code	
NISSAN	All Mode	2005 - 2015	Precrash Seatbelt	Clear Fault Code	

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
NISSAN	All Mode	2005 - 2015	Precrash Seatbelt	Read Data Stream	
NISSAN	All Mode	2005 - 2015	Precrash Seatbelt	Module Information	
NISSAN	All Mode	2006 - 2015	Precrash Seatbelt	Read Fault Code	
NISSAN	All Mode	2006 - 2015	Precrash Seatbelt	Clear Fault Code	
NISSAN	All Mode	2006 - 2015	Precrash Seatbelt	Read Data Stream	
NISSAN	All Mode	2006 - 2015	Precrash Seatbelt	Module Information	
NISSAN	All Mode	2009 - 2018	Precrash Seatbelt	Read Fault Code	
NISSAN	All Mode	2009 - 2018	Precrash Seatbelt	Clear Fault Code	
NISSAN	All Mode	2009 - 2018	Precrash Seatbelt	Read Data Stream	
NISSAN	All Mode	2009 - 2018	Precrash Seatbelt	Read Freeze Frame	
NISSAN	All Mode	2009 - 2018	Precrash Seatbelt	Module Information	
NISSAN	All Mode	2009 - 2018	Precrash Seatbelt	Special Function	Door Opening Retract Retry
NISSAN	All Mode	Up to 2017	Auto Drive Position	Read Fault Code	
NISSAN	All Mode	Up to 2017	Auto Drive Position	Clear Fault Code	
NISSAN	All Mode	Up to 2017	Auto Drive Position	Read Data Stream	
NISSAN	All Mode	Up to 2017	Auto Drive Position	Module Information	
NISSAN	All Mode	Up to 2017	Auto Drive Position	Actuation Test	SEAT SLIDE
NISSAN	All Mode	Up to 2017	Auto Drive Position	Actuation Test	SEAT RECLINING
NISSAN	All Mode	Up to 2017	Auto Drive Position	Actuation Test	SEAT LIFTER FR
NISSAN	All Mode	Up to 2017	Auto Drive Position	Actuation Test	SEAT LIFTER RR
NISSAN	All Mode	Up to 2017	Auto Drive Position	Actuation Test	TILT MOTOR
NISSAN	All Mode	Up to 2017	Auto Drive Position	Actuation Test	TELESCO MOTOR
NISSAN	All Mode	Up to 2017	Auto Drive Position	Actuation Test	PEDAL MOTOR
NISSAN	All Mode	Up to 2017	Auto Drive Position	Actuation Test	Mirror Motor RH
NISSAN	All Mode	Up to 2017	Auto Drive Position	Actuation Test	Mirror Motor LH
NISSAN	All Mode	Up to 2017	Auto Drive Position	Actuation Test	MEMORY SW INDCTR
NISSAN	All Mode	Up to 2017	Auto Drive Position	Actuation Test	SEAT LIFT
NISSAN	All Mode	Up to 2017	Auto Drive Position	Special Function	Exit Seat Slide Setting
NISSAN	All Mode	Up to 2017	Auto Drive Position	Special Function	Exit Tilt Setting
NISSAN	All Mode	Up to 2017	Auto Drive Position	Special Function	Seat Slide Volume Set
NISSAN	All Mode	Up to 2018	Auto Drive Position	Read Fault Code	
NISSAN	All Mode	Up to 2018	Auto Drive Position	Clear Fault Code	
NISSAN	All Mode	Up to 2018	Auto Drive Position	Read Data Stream	
NISSAN	All Mode	Up to 2018	Auto Drive Position	Module Information	
NISSAN	All Mode	Up to 2018	Auto Drive Position	Actuation Test	SEAT SLIDE
NISSAN	All Mode	Up to 2018	Auto Drive Position	Actuation Test	SEAT RECLINING
NISSAN	All Mode	Up to 2018	Auto Drive Position	Actuation Test	SEAT LIFTER FR
NISSAN	All Mode	Up to 2018	Auto Drive Position	Actuation Test	SEAT LIFTER RR
NISSAN	All Mode	Up to 2018	Auto Drive Position	Actuation Test	TILT MOTOR
NISSAN	All Mode	Up to 2018	Auto Drive Position	Actuation Test	TELESCO MOTOR
NISSAN	All Mode	Up to 2018	Auto Drive Position	Actuation Test	PEDAL MOTOR
NISSAN	All Mode	Up to 2018	Auto Drive Position	Actuation Test	Mirror Motor RH
NISSAN	All Mode	Up to 2018	Auto Drive Position	Actuation Test	Mirror Motor LH
NISSAN	All Mode	Up to 2018	Auto Drive Position	Actuation Test	MEMORY SW INDCTR
NISSAN	All Mode	Up to 2018	Auto Drive Position	Actuation Test	SEAT LIFT
NISSAN	All Mode	Up to 2018	Auto Drive Position	Special Function	Exit Seat Slide Setting
NISSAN	All Mode	Up to 2018	Auto Drive Position	Special Function	Exit Tilt Setting
NISSAN	All Mode	Up to 2018	Auto Drive Position	Special Function	Seat Slide Volume Set
NISSAN	All Mode	Up to 2018	Auto Drive Position	Read Fault Code	
NISSAN	All Mode	Up to 2018	Auto Drive Position	Clear Fault Code	
NISSAN	All Mode	Up to 2018	Auto Drive Position	Read Data Stream	
NISSAN	All Mode	Up to 2018	Auto Drive Position	Read Freeze Frame	
NISSAN	All Mode	Up to 2018	Auto Drive Position	Module Information	
NISSAN	All Mode	Up to 2018	Auto Drive Position	Actuation Test	SEAT SLIDE
NISSAN	All Mode	Up to 2018	Auto Drive Position	Actuation Test	SEAT RECLINING
NISSAN	All Mode	Up to 2018	Auto Drive Position	Actuation Test	SEAT LIFTER FR
NISSAN	All Mode	Up to 2018	Auto Drive Position	Actuation Test	SEAT LIFTER RR
NISSAN	All Mode	Up to 2018	Auto Drive Position	Actuation Test	TILT MOTOR
NISSAN	All Mode	Up to 2018	Auto Drive Position	Actuation Test	TELESCO MOTOR
NISSAN	All Mode	Up to 2018	Auto Drive Position	Actuation Test	Mirror Motor RH
NISSAN	All Mode	Up to 2018	Auto Drive Position	Actuation Test	Mirror Motor LH
NISSAN	All Mode	Up to 2018	Auto Drive Position	Actuation Test	MEMORY SW INDCTR
NISSAN	All Mode	Up to 2018	Auto Drive Position	Special Function	Exit Seat Slide Setting
NISSAN	All Mode	Up to 2018	Auto Drive Position	Special Function	Exit Tilt Setting
NISSAN	All Mode	Up to 2018	Auto Drive Position	Special Function	Seat Slide Volume Set
NISSAN	All Mode	2015 - 2018	Auto Drive Position	Read Fault Code	
NISSAN	All Mode	2015 - 2018	Auto Drive Position	Clear Fault Code	
NISSAN	All Mode	2015 - 2018	Auto Drive Position	Read Data Stream	
NISSAN	All Mode	2015 - 2018	Auto Drive Position	Module Information	
NISSAN	All Mode	2015 - 2018	Auto Drive Position	Special Function	Normalization
NISSAN	All Mode	2013 - 2017	Auto Drive Position	Read Fault Code	
NISSAN	All Mode	2013 - 2017	Auto Drive Position	Clear Fault Code	
NISSAN	All Mode	2013 - 2017	Auto Drive Position	Read Data Stream	
NISSAN	All Mode	2013 - 2017	Auto Drive Position	Module Information	
NISSAN	All Mode	2013 - 2017	Auto Drive Position	Special Function	Exit Seat Slide Setting
NISSAN	All Mode	2013 - 2017	Auto Drive Position	Special Function	Exit Tilt Setting
NISSAN	All Mode	2013 - 2017	Auto Drive Position	Special Function	Seat Slide Volume Set
NISSAN	All Mode	2015 - 2018	Auto Drive Position	Read Data Stream	
NISSAN	All Mode	2015 - 2018	Auto Drive Position	Module Information	
NISSAN	All Mode	2015 - 2018	Auto Drive Position	Special Function	Control unit unlock

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
NISSAN	All Mode	2015 - 2018	Auto Drive Position	Special Function	Initial startup sequence locking
NISSAN	All Mode	2006 - 2016	All Mode Awd/Awd	Read Fault Code	
NISSAN	All Mode	2006 - 2016	All Mode Awd/Awd	Clear Fault Code	
NISSAN	All Mode	2006 - 2016	All Mode Awd/Awd	Read Data Stream	
NISSAN	All Mode	2006 - 2016	All Mode Awd/Awd	Read Freeze Frame	
NISSAN	All Mode	2006 - 2016	All Mode Awd/Awd	Module Information	
NISSAN	All Mode	2007 - 2018	All Mode Awd/Awd	Read Fault Code	
NISSAN	All Mode	2007 - 2018	All Mode Awd/Awd	Clear Fault Code	
NISSAN	All Mode	2007 - 2018	All Mode Awd/Awd	Read Data Stream	
NISSAN	All Mode	2007 - 2018	All Mode Awd/Awd	Read Freeze Frame	
NISSAN	All Mode	2007 - 2018	All Mode Awd/Awd	Module Information	
NISSAN	All Mode	2007 - 2018	All Mode Awd/Awd	Special Function	Unit Characteristics Data
NISSAN	All Mode	2007 - 2018	All Mode Awd/Awd	Special Function	Unit Characteristics Write
NISSAN	All Mode	Up to 2016	All Mode Awd/Awd	Read Fault Code	
NISSAN	All Mode	Up to 2016	All Mode Awd/Awd	Clear Fault Code	
NISSAN	All Mode	Up to 2016	All Mode Awd/Awd	Read Data Stream	
NISSAN	All Mode	Up to 2016	All Mode Awd/Awd	Module Information	
NISSAN	All Mode	Up to 2016	All Mode Awd/Awd	Special Function	Clutch/F RLS LIM ADJ
NISSAN	All Mode	2009 - 2017	All Mode Awd/Awd	Read Fault Code	
NISSAN	All Mode	2009 - 2017	All Mode Awd/Awd	Clear Fault Code	
NISSAN	All Mode	2009 - 2017	All Mode Awd/Awd	Read Data Stream	
NISSAN	All Mode	2009 - 2017	All Mode Awd/Awd	Module Information	
NISSAN	All Mode	2009 - 2017	All Mode Awd/Awd	Special Function	Unit Characteristics Write
NISSAN	All Mode	2009 - 2017	All Mode Awd/Awd	Special Function	Start Calibration
NISSAN	All Mode	2009 - 2017	All Mode Awd/Awd	Special Function	Lock Sleeve Sensor Initialize
NISSAN	All Mode	2009 - 2017	All Mode Awd/Awd	Special Function	Lock Sleeve Sensor Learning
NISSAN	All Mode	2009 - 2017	All Mode Awd/Awd	Special Function	Oil Deterioration Info Reset
NISSAN	All Mode	2009 - 2017	All Mode Awd/Awd	Read Fault Code	
NISSAN	All Mode	2009 - 2017	All Mode Awd/Awd	Clear Fault Code	
NISSAN	All Mode	2009 - 2017	All Mode Awd/Awd	Read Data Stream	
NISSAN	All Mode	2009 - 2017	All Mode Awd/Awd	Module Information	
NISSAN	All Mode	2009 - 2017	All Mode Awd/Awd	Actuation Test	SOLENOID LEFT
NISSAN	All Mode	2009 - 2017	All Mode Awd/Awd	Actuation Test	SOLENOID RIGHT
NISSAN	All Mode	2009 - 2017	All Mode Awd/Awd	Special Function	Unit Characteristics Write
NISSAN	All Mode	2009 - 2017	All Mode Awd/Awd	Special Function	Unit Characteristics Data
NISSAN	All Mode	2009 - 2017	All Mode Awd/Awd	Read Fault Code	
NISSAN	All Mode	2009 - 2017	All Mode Awd/Awd	Clear Fault Code	
NISSAN	All Mode	2009 - 2017	All Mode Awd/Awd	Read Data Stream	
NISSAN	All Mode	2009 - 2017	All Mode Awd/Awd	Module Information	
NISSAN	All Mode	2009 - 2017	All Mode Awd/Awd	Actuation Test	Drive Pwr Dstrbt Torque
NISSAN	All Mode	2009 - 2017	All Mode Awd/Awd	Special Function	Unit Characteristics Write
NISSAN	All Mode	2009 - 2017	All Mode Awd/Awd	Special Function	Unit Characteristics Data
NISSAN	All Mode	2015 - 2017	All Mode Awd/Awd	Read Fault Code	
NISSAN	All Mode	2015 - 2017	All Mode Awd/Awd	Clear Fault Code	
NISSAN	All Mode	2015 - 2017	All Mode Awd/Awd	Read Data Stream	
NISSAN	All Mode	2015 - 2017	All Mode Awd/Awd	Module Information	
NISSAN	All Mode	2015 - 2017	All Mode Awd/Awd	Special Function	Vin Registration
NISSAN	All Mode	2015 - 2017	All Mode Awd/Awd	Special Function	Speed Index
NISSAN	All Mode	2015 - 2017	All Mode Awd/Awd	Special Function	Computer Initialisation
NISSAN	All Mode	2015 - 2017	All Mode Awd/Awd	Special Function	Modification Of Param After Initialisation
NISSAN	All Mode	2015 - 2018	All Mode Awd/Awd	Read Fault Code	
NISSAN	All Mode	2015 - 2018	All Mode Awd/Awd	Clear Fault Code	
NISSAN	All Mode	2015 - 2018	All Mode Awd/Awd	Read Data Stream	
NISSAN	All Mode	2015 - 2018	All Mode Awd/Awd	Module Information	
NISSAN	All Mode	2015 - 2018	All Mode Awd/Awd	Special Function	Function test of solenoid valve while driving
NISSAN	All Mode	As of 2012	All Mode Awd/Awd	Read Fault Code	
NISSAN	All Mode	As of 2012	All Mode Awd/Awd	Clear Fault Code	
NISSAN	All Mode	As of 2012	All Mode Awd/Awd	Read Data Stream	
NISSAN	All Mode	As of 2012	All Mode Awd/Awd	Module Information	
NISSAN	All Mode	Up to 2017	All Mode Awd/Awd	Read Fault Code	
NISSAN	All Mode	Up to 2017	All Mode Awd/Awd	Clear Fault Code	
NISSAN	All Mode	Up to 2017	All Mode Awd/Awd	Read Data Stream	
NISSAN	All Mode	Up to 2017	All Mode Awd/Awd	Module Information	
NISSAN	All Mode	Up to 2016	All Mode Awd/Awd	Read Fault Code	
NISSAN	All Mode	Up to 2016	All Mode Awd/Awd	Clear Fault Code	
NISSAN	All Mode	Up to 2016	All Mode Awd/Awd	Read Data Stream	
NISSAN	All Mode	Up to 2016	All Mode Awd/Awd	Module Information	
NISSAN	All Mode	Up to 2016	All Mode Awd/Awd	Special Function	
NISSAN	All Mode	Up to 2011	All Mode Awd/Awd	Read Fault Code	
NISSAN	All Mode	Up to 2011	All Mode Awd/Awd	Clear Fault Code	
NISSAN	All Mode	Up to 2011	All Mode Awd/Awd	Read Data Stream	
NISSAN	All Mode	Up to 2011	All Mode Awd/Awd	Module Information	
NISSAN	All Mode	Up to 2011	All Mode Awd/Awd	Actuation Test	
NISSAN	All Mode	Up to 2016	All Mode Awd/Awd	Read Fault Code	
NISSAN	All Mode	Up to 2016	All Mode Awd/Awd	Clear Fault Code	

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
NISSAN	All Mode	Up to 2016	All Mode Awd/4wd	Read Data Stream	
NISSAN	All Mode	Up to 2016	All Mode Awd/4wd	Module Information	
NISSAN	All Mode	Up to 2016	All Mode Awd/4wd	Special Function	START TORQ OFFSET ADJ
NISSAN	All Mode	Up to 2016	All Mode Awd/4wd	Special Function	CLUTCH/F RLS LIM ADJ
NISSAN	All Mode	Up to 2016	All Mode Awd/4wd	Read Fault Code	
NISSAN	All Mode	Up to 2016	All Mode Awd/4wd	Clear Fault Code	
NISSAN	All Mode	Up to 2016	All Mode Awd/4wd	Read Data Stream	
NISSAN	All Mode	Up to 2016	All Mode Awd/4wd	Module Information	
NISSAN	All Mode	Up to 2016	All Mode Awd/4wd	Special Function	START TORQ OFFSET ADJ
NISSAN	All Mode	Up to 2016	All Mode Awd/4wd	Special Function	CLUTCH/F RLS LIM ADJ
NISSAN	All Mode	Up to 2014	All Mode Awd/4wd	Read Fault Code	
NISSAN	All Mode	Up to 2014	All Mode Awd/4wd	Clear Fault Code	
NISSAN	All Mode	Up to 2014	All Mode Awd/4wd	Read Data Stream	
NISSAN	All Mode	Up to 2014	All Mode Awd/4wd	Module Information	
NISSAN	All Mode	Up to 2014	All Mode Awd/4wd	Special Function	CLUTCH/F RLS LIM ADJ
NISSAN	All Mode	2014 - 2017	Diff Lock	Read Fault Code	
NISSAN	All Mode	2014 - 2017	Diff Lock	Clear Fault Code	
NISSAN	All Mode	2014 - 2017	Diff Lock	Read Data Stream	
NISSAN	All Mode	2014 - 2017	Diff Lock	Module Information	
NISSAN	All Mode	Up to 2017	Diff Lock	Read Fault Code	
NISSAN	All Mode	Up to 2017	Diff Lock	Clear Fault Code	
NISSAN	All Mode	Up to 2017	Diff Lock	Read Data Stream	
NISSAN	All Mode	Up to 2017	Diff Lock	Module Information	
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Read Fault Code	
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Clear Fault Code	
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Read Data Stream	
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Module Information	
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Actuation Test	Door Lock
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Actuation Test	Step Lamp Test
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Actuation Test	Int Lamp
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Actuation Test	Tail Lamp
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Actuation Test	Head Lamp
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Actuation Test	FR FOG Lamp
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Actuation Test	RR FOG Lamp
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Actuation Test	Daytime Running Light
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Actuation Test	ILL DIM Signal
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Actuation Test	FR Wiper
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Actuation Test	Head Lamp Washer
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Actuation Test	Flasher
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Actuation Test	Theft IND
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Actuation Test	Battery Saver
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Actuation Test	Trunk/Glass Hatch
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Actuation Test	Vehicle Security Horn
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Actuation Test	Head Lamp(HI)
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Actuation Test	OIL Pressure SW
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Actuation Test	Rear Defogger
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Actuation Test	IGN KEY WARN ALM
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Actuation Test	Light Warn Alm
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Actuation Test	Reverse Warning
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Actuation Test	Seat Belt Warn Test
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Actuation Test	Horn
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Actuation Test	POWER WINDOW DOWN
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Actuation Test	Cornering Lamp
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Actuation Test	RR Wiper
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Actuation Test	PBD
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Actuation Test	Power Slide Door
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Actuation Test	A/C Indicator
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Special Function	Set I/L D-Unlck Intcon
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Special Function	Room Lamp Timer Set
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Special Function	Room Lamp On Time Set
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Special Function	Room Lamp Off Time Set
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Special Function	R Lamp Timer Logic Set
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Special Function	Room Lamp On At Lock
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Special Function	Battery Saver Set
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Special Function	Custom A/Light Setting
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Special Function	ILL Delay Set
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Special Function	Wiper Speed Setting
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Special Function	Reset Setting Value
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Special Function	Security Alarm SET
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Special Function	Theft ALM TRG
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Special Function	Retained PWR Set
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Read Fault Code	
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Clear Fault Code	
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Read Data Stream	
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Read Freeze Frame	
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Module Information	
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	Door Lock
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	Super Lock
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	REAR DOOR UNLOCK TEST
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	Door Lock Ind

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

<b>make</b>	<b>model</b>	<b>year</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	Rear Defogger
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	IGN KEY WARN ALM
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	Seat Belt Warn Test
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	Key Reminder Warn
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	ID REGIST WARNING
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	Light Warn Alm
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	Reverse Warning
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	RUN FLAT/T WARN BUZZER
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	Step Lamp Test
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	Int Lamp
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	LUGGAGE LAMP TEST
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	Tail Lamp
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	Head Lamp
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	FR FOG Lamp
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	RR FOG Lamp
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	Daytime Running Light
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	Cornering Lamp
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	ILL DIM Signal
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	FR Wiper
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	Head Lamp Washer
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	RR Wiper
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	Flasher
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	SIREN
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	Theft IND
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	PW REMOTO DOWN SET
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	Battery Saver
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	Outside Buzzer
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	Inside Buzzer
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	Indicator
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	LCD
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	Horn
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	P Range
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	Engine SW Illumi
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	Lock Indicator
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	ACC Indicator
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	Ignition ON IND
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	Key Slot Illumi
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	Trunk/Back Door
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	KEYLESS PW UP/DOWN
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	Trunk/Glass Hatch
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	Vehicle Security Horn
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	Head Lamp(HI)
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	OIL Pressure SW
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	Warning Lamp
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	RUN FLAT TIER W/L
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Door Lock-Unlock Set
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	HORN CHIRP SET
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Set I/L D-Unlock Intcon
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Room Lamp Timer Set
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Room Lamp On Time Set
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Room Lamp BAT SAV SET
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Room Lamp Off Time Set
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	R Lamp Timer Logic Set
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Battery Saver Set
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Custom A/Light Setting
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	ILL Delay Set
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Wiper Speed Setting
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	HAZARD LAMP SET
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Hazard Answer Back
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Reset Setting Value
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Security Alarm SET
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Theft ALM TRG
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	SIREN SET
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Auto Lock Set
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Lock/Unlock By I-Key
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Engine Start By I-Key
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Trunk/Glass Hatch Open
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Panic Alarm Set
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Take Out From Win Warn
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Pw Down Set
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Trunk Open Delay
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	LO-BATT OF KEY FOB WARN
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Keyless Function
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Anti Key Lock In Function
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Ans Back I-Key Lock
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Ans Back I-Key Unlock
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Short Cranking Output
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Inside ANT Diagnosis
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Horn With Keyless Lock
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Automatic Door Lock Select

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Automatic Door Unlock Select
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Automatic Door Lock/Unlock Select
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Confirm Key Fob ID
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	ID REGIST
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	ID READ
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	D/LOCK VHCL SPD AJT
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Room Lamp On At Lock
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Retained PWR Set
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	REMO CONT ID CONFIR
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Welcome Light Op Set
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Answer Back Function
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Welcome Light Select
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Read Fault Code	
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Clear Fault Code	
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Read Data Stream	
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Read Freeze Frame	
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Module Information	
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Door Lock
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Super Lock
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Door Lock Ind
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Rear Defogger
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Seat Belt Warn Test
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Key Reminder Warn
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Light Warn Alm
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Reverse Warning
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Step Lamp Test
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Int Lamp
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Tail Lamp
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Head Lamp
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	FR FOG Lamp
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Daytime Running Light
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	ILL DIM Signal
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	FR Wiper
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Head Lamp Washer
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	RR Wiper
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Flasher
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	SIREN
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Theft IND
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Battery Saver
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Outside Buzzer
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Inside Buzzer
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Indicator
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	LCD
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Horn
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	P Range
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Engine SW Illumi
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Lock Indicator
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	ACC Indicator
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Ignition ON IND
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Trunk/Back Door
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Vehicle Security Horn
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Head Lamp(HI)
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Push Switch Indicator
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	RUN FLAT TIRE W/L
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Warning Lamp
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	ID REGIST WARNING
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	A/C Indication
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Intelligent Key Link
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Intelligent Key Link(CAN)
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Power Slide Door
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	OIL Pressure SW
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Retractable Mirror
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Heated Steering Wheel
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Confirm TCU ID
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Door Lock-Unlock Set
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Set I/L D-Unlock Intcon
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Room Lamp Timer Set
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Room Lamp On Time Set
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Room Lamp BAT SAV SET
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Room Lamp Off Time Set
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	R Lamp Timer Logic Set
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Battery Saver Set
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Custom A/Light Setting
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	ILL Delay Set
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Wiper Speed Setting
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Rain Sen Wip Func Set
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Drop Wipe Func Set
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Hazard Answer Back

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

<b>make</b>	<b>model</b>	<b>year</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Reset Setting Value
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Security Alarm SET
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Theft ALM TRG
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	SIREN SET
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Lock/Unlock By I-Key
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Engine Start By I-Key
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Trunk/Glass Hatch Open
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Answer Back Function
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Panic Alarm Set
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Pw Down Set
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Trunk Open Delay
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	LO-BATT OF KEY FOB WARN
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Anti Key Lock In Function
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Ans Back I-Key Lock
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Ans Back I-Key Unlock
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Short Cranking Output
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Inside ANT Diagnosis
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Horn With Keyless Lock
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Automatic Door Lock Select
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Confirm Key Fob ID
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	ID REGIST
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Switch Tpm Between On/Off
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	ID READ
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Retractable Mirror Set
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Confirm Dongle ID
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Welcome Light Op Set
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Welcome Light Select
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Intelligent Key Link Set
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Security Alarm Set(Siren)
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Signature Light Setting
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	FOG Lamp Override
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Daytime Running Light Setting
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Remote Climate Cont Answer Back Function
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	RR WIP RVRS SET
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Auto Light Logic Set
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Auto Lock Set
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Ign Battery Saver Set
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Acc Battery Saver Set
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Head Light Timer
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Automatic Door Unlock Select
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Automatic Lock/Unlock Set
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Read Fault Code	
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Clear Fault Code	
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Read Data Stream	
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Module Information	
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Door Lock
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Super Lock
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Door Lock Ind
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Rear Defogger
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Seat Belt Warn Test
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Light Warn Alm
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	IGN KEY WARN ALM
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Reverse Warning
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Int Lamp
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Power Slide Door
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Tail Lamp
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Head Lamp
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	FR FOG Lamp
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	RR FOG Lamp
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Daytime Running Light
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	ILL DIM Signal
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	FR Wiper
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Head Lamp Washer
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	RR Wiper
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Flasher
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	SIREN
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Theft IND
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Battery Saver
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Horn
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Trunk/Back Door
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Trunk/Glass Hatch
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Vehicle Security Horn
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Head Lamp(HI)
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	RUN FLAT TIRE W/L
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Warning Lamp
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	ID REGIST WARNING
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	OIL Pressure SW

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	A/C Indicator
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Set R-DEF Timer
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Door Lock-Unlock Set
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Set I/L D-Unlock Intcon
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Room Lamp Timer Set
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Room Lamp On Time Set
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Room Lamp BAT SAV SET
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Room Lamp Off Time Set
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	R Lamp Timer Logic Set
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Battery Saver Set
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Custom A/Light Setting
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	ILL Delay Set
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Auto Light Logic Set
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Wiper Speed Setting
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Rain Sen Wip Func Set
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Drop Wipe Func Set
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Reset Setting Value
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Security Alarm SET
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Theft ALM TRG
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	SIREN SET
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Panic Alarm Set
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Automatic Door Lock Select
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	ID REGIST
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	ID READ
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Confirm Dongle ID
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	REMO CONT ID ERASUR
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	REMO CONT ID REGIST
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	REMO CONT ID CONFIR
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	HORN CHIRP SET
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	MULTI ANSWER BACK SET
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	HAZARD LAMP SET
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	TRUNK OPEN SET
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Retained PWR Set
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Security Alarm Set(Siren)
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Automatic Door Unlock Select
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Automatic Lock/Unlock Set
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Read Fault Code	
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Clear Fault Code	
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Read Data Stream	
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Read Freeze Frame	
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Module Information	
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	Door Lock
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	Super Lock
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	REAR DOOR UNLOCK TEST
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	Door Lock Ind
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	Rear Defogger
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	IGN KEY WARN ALM
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	Seat Belt Warn Test
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	Key Reminder Warn
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	ID REGIST WARNING
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	Light Warn Alm
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	Reverse Warning
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	RUN FLAT/T WARN BUZZER
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	Step Lamp Test
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	Int Lamp
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	LUGGAGE LAMP TEST
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	Tail Lamp
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	Head Lamp
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	FR FOG Lamp
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	RR FOG Lamp
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	Daytime Running Light
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	Cornering Lamp
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	ILL DIM Signal
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	FR Wiper
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	Head Lamp Washer
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	RR Wiper
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	Flasher
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	SIREN
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	Theft IND
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	PW REMOTO DOWN SET
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	Battery Saver
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	Outside Buzzer
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	Inside Buzzer
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	Indicator
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	LCD
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	Horn
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	P Range
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	Engine SW Illumi
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	Lock Indicator



**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	ACC Indicator
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	Ignition ON IND
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	Key Slot Illumi
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	Trunk/Back Door
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	KEYLESS PW UP/DOWN
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	Trunk/Glass Hatch
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	Vehicle Security Horn
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	Head Lamp(HI)
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	OIL Pressure SW
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	Warning Lamp
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	RUN FLAT TIER W/L
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	D/LOCK VHCL SPD AJT
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Door Lock-Unlock Set
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Set I/L D-Unlck Intcon
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Room Lamp Timer Set
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Room Lamp On Time Set
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Room Lamp BAT SAV SET
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Room Lamp Off Time Set
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	R Lamp Timer Logic Set
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Room Lamp On At Lock
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Battery Saver Set
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Custom A/Light Setting
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	ILL Delay Set
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Wiper Speed Setting
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	HAZARD LAMP SET
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Hazard Answer Back
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Reset Setting Value
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Security Alarm SET
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Theft ALM TRG
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	SIREN SET
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Retained PWR Set
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	REMO CONT ID CONFIR
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Welcome Light Op Set
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Lock/Unlock By I-Key
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Engine Start By I-Key
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Trunk/Glass Hatch Open
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Answer Back Function
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Panic Alarm Set
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Take Out From Win Warn
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Pw Down Set
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Trunk Open Delay
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	LO-BATT OF KEY FOB WARN
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Keyless Function
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Anti Key Lock In Function
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Ans Back I-Key Lock
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Ans Back I-Key Unlock
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Short Cranking Output
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Inside ANT Diagnosis
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Horn With Keyless Lock
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Welcome Light Select
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Confirm Dongle ID
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Automatic Door Lock Select
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	HORN CHIRP SET
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Auto Lock Set
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Automatic Door Unlock Select
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Automatic Door Lock/Unlock Select
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	ID REGIST
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	ID READ
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Confirm Key Fob ID
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Read Fault Code	
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Clear Fault Code	
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Read Data Stream	
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Module Information	
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Rear Defogger
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	IGN KEY WARN ALM
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Light Warn Alm
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Seat Belt Warn Test
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Tail Lamp
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Head Lamp
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	FR FOG Lamp
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Daytime Running Light
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	CARGO Lamp
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Cornering Lamp
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	RR Wiper
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	FR Wiper
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Head Lamp Washer
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Flasher
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Trunk/Back Door

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	A/C Indicator
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Theft IND
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	OIL Pressure SW
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	FUEL LID OPEN
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Warning Lamp
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	ID REGIST WARNING
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	FLAT TIRE WARNING
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Horn
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	RUN FLAT TIRE W/L
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Automatic Door Lock Select
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Automatic Door Unlock Select
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Automatic Door Lock/Unlock Select
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Battery Saver Set
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Custom A/Light Setting
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	ILL Delay Set
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Wiper Speed Setting
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Reset Setting Value
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	ID REGIST
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	ID READ
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Read Fault Code	
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Clear Fault Code	
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Read Data Stream	
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Module Information	
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Door Lock
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Step Lamp Test
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Int Lamp
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Tail Lamp
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Head Lamp
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	FR FOG Lamp
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	RR FOG Lamp
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Daytime Running Light
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	ILL DIM Signal
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	FR Wiper
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Head Lamp Washer
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Flasher
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Theft IND
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Battery Saver
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Trunk/Glass Hatch
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Vehicle Security Horn
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Head Lamp(HI)
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	OIL Pressure SW
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Rear Defogger
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	IGN KEY WARN ALM
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Light Warn Alm
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Reverse Warning
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Seat Belt Warn Test
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Horn
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	POWER WINDOW DOWN
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Cornering Lamp
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	RR Wiper
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	PBD
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Power Slide Door
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	A/C Indicator
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Set I/L D-Unlock Intcon
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Room Lamp Timer Set
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Room Lamp On Time Set
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Room Lamp Off Time Set
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	R Lamp Timer Logic Set
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Room Lamp On At Lock
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Battery Saver Set
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Custom A/Light Setting
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	ILL Delay Set
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Wiper Speed Setting
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Reset Setting Value
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Security Alarm SET
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Theft ALM TRG
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Room Lamp BAT SAV SET
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	REMO CONT ID ERASUR
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	REMO CONT ID REGIST
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	REMO CONT ID CONFIR
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	HAZARD LAMP SET
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Auto Lock Set
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	TRUNK OPEN SET
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Panic Alarm Set
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Read Fault Code	
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Clear Fault Code	
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Read Data Stream	
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Module Information	

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

<b>make</b>	<b>model</b>	<b>year</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Actuation Test	Door Lock
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Actuation Test	Int Lamp
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Actuation Test	Super Lock
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Actuation Test	Door Lock Ind
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Actuation Test	Step Lamp Test
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Actuation Test	Tail Lamp
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Actuation Test	Head Lamp
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Actuation Test	FR FOG Lamp
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Actuation Test	RR FOG Lamp
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Actuation Test	Daytime Running Light
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Actuation Test	ILL DIM Signal
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Actuation Test	FR Wiper
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Actuation Test	RR Wiper
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Actuation Test	Head Lamp Washer
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Actuation Test	Flasher
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Actuation Test	Theft IND
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Actuation Test	Trunk/Glass Hatch
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Actuation Test	Vehicle Security Horn
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Actuation Test	OIL Pressure SW
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Actuation Test	Rear Defogger
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Actuation Test	IGN KEY WARN ALM
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Actuation Test	Light Warn Alm
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Actuation Test	Reverse Warning
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Actuation Test	Seat Belt Warn Test
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Actuation Test	Key Reminder Warn
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Actuation Test	A/C Indicator
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Actuation Test	Battery Saver
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Actuation Test	PTC HEATER
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Actuation Test	Head Lamp(HI)
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Special Function	Security Door Lock Set
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Special Function	Set R-DEF Timer
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Special Function	Set I/L D-Unlck Intcon
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Special Function	Room Lamp Timer Set
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Special Function	Room Lamp On Time Set
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Special Function	Room Lamp Off Time Set
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Special Function	R Lamp Timer Logic Set
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Special Function	Room Lamp On At Lock
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Special Function	Custom A/Light Setting
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Special Function	ILL Delay Set
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Special Function	Head Light Timer
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Special Function	Wiper Speed Setting
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Special Function	Headlamp Washer Auto Set
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Special Function	Reset Setting Value
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Special Function	Security Alarm SET
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Special Function	Theft ALM TRG
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Special Function	REMO CONT ID CONFIR
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Special Function	HAZARD LAMP SET
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Special Function	Auto Lock Set
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Special Function	TRUNK OPEN SET
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Read Fault Code	
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Clear Fault Code	
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Read Data Stream	
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Module Information	
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Door Lock
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Int Lamp
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Step Lamp Test
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Tail Lamp
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Head Lamp
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	FR FOG Lamp
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	RR FOG Lamp
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	ILL DIM Signal
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Cornering Lamp
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	FR Wiper
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Head Lamp Washer
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	RR Wiper
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Flasher
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Theft IND
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Trunk/Glass Hatch
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Vehicle Security Horn
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	OIL Pressure SW
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Rear Defogger
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	IGN KEY WARN ALM
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Light Warn Alm
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	A/C Indicator
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Battery Saver
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Set I/L D-Unlck Intcon
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Room Lamp Timer Set
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Room Lamp On Time Set
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Room Lamp Off Time Set
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	R Lamp Timer Logic Set

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Battery Saver Set
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Custom A/Light Setting
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Wiper Speed Setting
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Reset Setting Value
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Room Lamp BAT SAV SET
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	REMO CONT ID ERASUR
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	REMO CONT ID REGIST
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	REMO CONT ID CONFIR
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	TRUNK OPEN SET
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Panic Alarm Set
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Security Alarm SET
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Theft ALM TRG
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Read Fault Code	
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Clear Fault Code	
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Read Data Stream	
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Read Freeze Frame	
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Module Information	
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Door Lock
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Int Lamp
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Tail Lamp
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Head Lamp
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	FR FOG Lamp
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	RR FOG Lamp
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	ILL DIM Signal
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	FR Wiper
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	RR Wiper
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Flasher
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Theft IND
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Trunk/Glass Hatch
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	PBD
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Power Slide Door
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Vehicle Security Horn
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	OIL Pressure SW
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Rear Defogger
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	IGN KEY WARN ALM
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Light Warn Alm
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Reverse Warning
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Seat Belt Warn Test
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	A/C Indicator
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Set I/L D-Unlck Intcon
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Room Lamp Timer Set
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Room Lamp On Time Set
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Room Lamp Off Time Set
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	R Lamp Timer Logic Set
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Room Lamp On At Lock
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Battery Saver Set
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Custom A/Light Setting
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	ILL Delay Set
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Wiper Speed Setting
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Reset Setting Value
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Security Alarm SET
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Theft ALM TRG
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Retained PWR Set
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Room Lamp BAT SAV SET
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	REMO CONT ID ERASUR
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	REMO CONT ID REGIST
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	REMO CONT ID CONFIR
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	HAZARD LAMP SET
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	TRUNK OPEN SET
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Panic Alarm Set
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Read Fault Code	
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Clear Fault Code	
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Read Data Stream	
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Module Information	
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Door Lock
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Door Lock Ind
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Super Lock
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Rear Defogger
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	IGN KEY WARN ALM
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Light Warn Alm
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Key Reminder Warn
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Int Lamp
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Tail Lamp
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Head Lamp
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	FR FOG Lamp
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	RR FOG Lamp
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	FR Wiper
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	RR Wiper
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Head Lamp Washer
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Flasher

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	A/C Indicator
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Theft IND
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	OIL Pressure SW
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Battery Saver
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Vehicle Security Horn
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Custom A/Light Setting
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Head Light Timer
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Wiper Speed Setting
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Reset Setting Value
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Security Door Lock Set
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Set I/L D-Unlck Intcon
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Room Lamp On Time Set
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Room Lamp Off Time Set
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Room Lamp Timer Set
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	HAZARD LAMP SET
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	REMO CONT ID ERASUR
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	REMO CONT ID REGIST
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Security Alarm SET
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Theft ALM TRG
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Auto Lock Set
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Read Fault Code	
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Clear Fault Code	
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Read Data Stream	
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Module Information	
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Light Warn Alm
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	IGN KEY WARN ALM
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Key Reminder Warn
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Theft IND
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Reset Setting Value
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Read Fault Code	
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Clear Fault Code	
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Read Data Stream	
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Module Information	
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Door Lock
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Rear Defogger
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Seat Belt Warn Test
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Light Warn Alm
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	IGN KEY WARN ALM
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	IGN Illum
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Int Lamp
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Step Lamp Test
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	LUGGAGE LAMP TEST
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Tail Lamp
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Head Lamp
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	FR FOG Lamp
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	RR FOG Lamp
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Daytime Running Light
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	CARGO Lamp
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Cornering Lamp
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	FR Wiper
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	RR Wiper
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Head Lamp Washer
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	RISE UP WIPER TEST
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Flasher
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	A/C Indicator
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Theft IND
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Battery Saver
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Trunk/Back Door
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Vehicle Security Horn
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Head Lamp(HI)
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Retained PWR
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	OIL Pressure SW
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	BRAKE SW
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	PW REMOTO DOWN SET
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Horn
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	PSD PBD OPEN TEST
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	FUEL LID OPEN
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Warning Lamp
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	ID REGIST WARNING
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	FLAT TIRE WARNING
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	RUN FLAT TIRE W/L
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	PANIC ALARM
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Door Lock-Unlock Set
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	ANTI-LOCK OUT SET
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Automatic Door Lock Select
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Automatic Door Unlock Select
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Automatic Door Lock/Unlock Select
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Battery Saver Set

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Custom A/Light Setting
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	ILL Delay Set
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Wiper Speed Setting
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Reset Setting Value
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	ID READ
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	ID REGIST
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Set I/L D-Unlck Intcon
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Room Lamp On Time Set
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Room Lamp Off Time Set
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Room Lamp Timer Set
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Retained PWR Set
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	HORN CHIRP SET
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	HAZARD LAMP SET
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	MULTI ANSWER BACK SET
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Auto Lock Set
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Panic Alarm Set
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	TRUNK OPEN SET
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Pw Down Set
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	REMO CONT ID REGIST
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	REMO CONT ID ERASUR
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	REMO CONT ID CONFIR
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Security Alarm SET
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Theft ALM TRG
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Read Fault Code	
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Clear Fault Code	
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Read Data Stream	
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Module Information	
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Door Lock
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Rear Defogger
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Seat Belt Warn Test
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Light Warn Alm
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	IGN KEY WARN ALM
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	IGN Illum
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Int Lamp
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Step Lamp Test
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	LUGGAGE LAMP TEST
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Tail Lamp
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Head Lamp
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	FR FOG Lamp
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	RR FOG Lamp
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Daytime Running Light
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Cornering Lamp
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	FR Wiper
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	RR Wiper
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Head Lamp Washer
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	RISE UP WIPER TEST
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Flasher
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	A/C Indicator
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Theft IND
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Battery Saver
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Trunk/Back Door
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Vehicle Security Horn
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Head Lamp(HI)
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Retained PWR
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	OIL Pressure SW
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	PW REMOTO DOWN SET
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Horn
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	PSD PBD OPEN TEST
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	FUEL LID OPEN
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	PANIC ALARM
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Door Lock-Unlock Set
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	ANTI-LOCK OUT SET
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Set I/L D-Unlck Intcon
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Room Lamp On Time Set
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Room Lamp Off Time Set
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Battery Saver Set
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Custom A/Light Setting
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	ILL Delay Set
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Wiper Speed Setting
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Room Lamp Timer Set
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Security Alarm SET
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Retained PWR Set
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	HORN CHIRP SET
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	HAZARD LAMP SET
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	MULTI ANSWER BACK SET
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Auto Lock Set
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Panic Alarm Set
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	TRUNK OPEN SET
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Pw Down Set
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	REMO CONT ID REGIST

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

<b>make</b>	<b>model</b>	<b>year</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	REMO CONT ID ERASUR
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	REMO CONT ID CONFIR
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Reset Setting Value
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Read Fault Code	
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Clear Fault Code	
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Read Data Stream	
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Module Information	
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Actuation Test	Door Lock
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Actuation Test	Flasher
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Actuation Test	Power Slide Door
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Actuation Test	Inside Buzzer
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Actuation Test	starter cut relay
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Actuation Test	Indicator
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Actuation Test	Theft IND
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Special Function	Reset Setting Value
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Read Fault Code	
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Clear Fault Code	
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Read Data Stream	
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Module Information	
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Actuation Test	Door Lock (Door Lock)
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Actuation Test	Door Lock (Multi Remote Enter)
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Actuation Test	Door Lock (Intelligent Key)
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Actuation Test	Rear Defogger
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Actuation Test	IGN KEY WARN ALM
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Actuation Test	Light Warn Alm
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Actuation Test	Reverse Warning
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Actuation Test	INT LAMP (INT LAMP)
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Actuation Test	INT LAMP (MULTI REMOTE ENTER)
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Actuation Test	INT LAMP (INTELLIGENT KEY)
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Actuation Test	Tail Lamp
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Actuation Test	Head Lamp
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Actuation Test	FR FOG Lamp
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Actuation Test	FR Wiper
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Actuation Test	Head Lamp Washer
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Actuation Test	RR Wiper
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Actuation Test	Flasher (Multi Remote Enter,Flasher)
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Actuation Test	Flasher (Intelligent Key)
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Actuation Test	Trunk/Back Door
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Special Function	Battery Saver Set
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Special Function	Custom A/Light Setting
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Special Function	REMO CONT ID ERASUR
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Read Fault Code	
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Clear Fault Code	
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Read Data Stream	
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Module Information	
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Special Function	SET R/DEF -ENG INTCON
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Special Function	Set I/L D-Unlck Intcon
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Special Function	Room Lamp Timer Set
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Special Function	Custom A/Light Setting
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Special Function	Wiper Speed Setting
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Special Function	Switch Monitor
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Special Function	ST ANG Sen Adjustment
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Read Fault Code	
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Clear Fault Code	
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Read Data Stream	
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Module Information	
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Special Function	Auto RE-Lock
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Special Function	Selective Unlock
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Special Function	Trunk Open Delay
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Special Function	Audible Trailer Warning
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Special Function	Keyless Registration
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Special Function	Keyless Check
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Special Function	Keyless DI Flash
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Special Function	THEFT WARNING
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Special Function	Lastest Alarm Trigger
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Special Function	PRE-ARM Fast Flash
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Special Function	Siren Fitted
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Special Function	Previous Alarm Trigger
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Special Function	Oldest Alarm Trigger
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Read Fault Code	
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Clear Fault Code	
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Read Data Stream	
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Module Information	
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Door Lock (Door Lock)
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Door Lock Ind
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Super Lock
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	BACK/TRNK LCK RLY

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	BACK/TRNK UNLOCK
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Rear Defogger
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Light Warn Alm
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Key Reminder Warn
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	BACK DR OPEN WARN
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	DOOR WARNING IND
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Int Lamp
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Tail Lamp
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Head Lamp
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	FR FOG Lamp
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	RR FOG Lamp
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	FR Wiper
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Head Lamp Washer
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	RR Wiper
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Flasher
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Theft IND
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	PTC HEATER
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	DR FR WINDOW
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	AS FR WINDOW
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	DR RR WINDOW
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	AS RR WINDOW
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	TRUNK
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Parcel Shelf
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	VALVE
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	HYDRAULIC MOTOR
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Roof
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Battery Saver Set
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Security Door Lock Set
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Auto Lock Set
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Custom A/Light Setting
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	RR WIP RVRS SET
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	HAZARD LAMP SET
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Security Alarm SET
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Headlamp Washer Auto Set
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Read Fault Code	
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Clear Fault Code	
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Read Data Stream	
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Module Information	
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Door Lock
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Rear Defogger
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	IGN KEY WARN ALM
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Light Warn Alm
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Reverse Warning
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Seat Belt Warn Test
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Int Lamp
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Tail Lamp
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Head Lamp
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Head Lamp(HI)
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	PANIC ALARM
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	FR FOG Lamp
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	RR FOG Lamp
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Cornering Lamp
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	ILL DIM Signal
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	FR Wiper
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	RR Wiper
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Head Lamp Washer
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Flasher
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Trunk/Glass Hatch
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Theft IND
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	OIL Pressure SW
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	GLASS HATCH
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Trunk/Back Door
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Power Slide Door
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	A/C Indicator
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Inside Buzzer
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	starter cut relay
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Indicator
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Battery Saver Set
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Custom A/Light Setting
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Set I/L D-Unlock Intcon
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Room Lamp On Time Set
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Room Lamp Off Time Set
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Room Lamp BAT SAV SET
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Room Lamp Timer Set
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Wiper Speed Setting
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Reset Setting Value
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	REMO CONT ID REGIST
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	REMO CONT ID ERASUR
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	REMO CONT ID CONFIR
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	HAZARD LAMP SET



**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Auto Lock Set
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Panic Alarm Set
NISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	TRUNK OPEN SET
NISSAN	NV400	2011	BCM (Body Control Module)	Read Fault Code	
NISSAN	NV400	2011	BCM (Body Control Module)	Clear Fault Code	
NISSAN	NV400	2011	BCM (Body Control Module)	Read Data Stream	
NISSAN	NV400	2011	BCM (Body Control Module)	Module Information	
NISSAN	NV400	2011	BCM (Body Control Module)	Actuation Test	Central Door Locking
NISSAN	NV400	2011	BCM (Body Control Module)	Actuation Test	UNLOCKING THE DOORS AND BOOT
NISSAN	NV400	2011	BCM (Body Control Module)	Actuation Test	REAR FOG LIGHTS
NISSAN	NV400	2011	BCM (Body Control Module)	Actuation Test	PCHR RELAY1
NISSAN	NV400	2011	BCM (Body Control Module)	Actuation Test	PCHR RELAY2
NISSAN	NV400	2011	BCM (Body Control Module)	Actuation Test	CENTRAL LOCKING KEY LIGHT
NISSAN	NV400	2011	BCM (Body Control Module)	Actuation Test	LEFT INDICATOR
NISSAN	NV400	2011	BCM (Body Control Module)	Actuation Test	RIGHT-HAND INDICATOR
NISSAN	NV400	2011	BCM (Body Control Module)	Actuation Test	Deadlocking
NISSAN	NV400	2011	BCM (Body Control Module)	Actuation Test	HAZARD LIGHTS LED
NISSAN	NV400	2011	BCM (Body Control Module)	Actuation Test	Deadunlocking
NISSAN	NV400	2011	BCM (Body Control Module)	Actuation Test	Temperature Display
NISSAN	NV400	2011	BCM (Body Control Module)	Actuation Test	+ACCESS_FEED 3 RELAY
NISSAN	NV400	2011	BCM (Body Control Module)	Actuation Test	INTERIOR LIGHTING
NISSAN	NV400	2011	BCM (Body Control Module)	Actuation Test	LOWER DRIVER WINDOW
NISSAN	NV400	2011	BCM (Body Control Module)	Actuation Test	RAISE DRIVER WINDOW
NISSAN	NV400	2011	BCM (Body Control Module)	Actuation Test	ACCESSORIES RELAY NO. 2
NISSAN	NV400	2011	BCM (Body Control Module)	Actuation Test	Stored Energy Management Data
NISSAN	NV400	2011	BCM (Body Control Module)	Special Function	Checking A Key
NISSAN	NV400	2011	BCM (Body Control Module)	Special Function	Vin Registration
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Read Fault Code	
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Clear Fault Code	
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Read Data Stream	
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Module Information	
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	Door Lock
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	Door Lock Ind
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	Super Lock
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	Rear Defogger
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	Seat Belt Warn Test
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	Light Warn Alm
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	Reverse Warning
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	Key Reminder Warn
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	ID REGIST WARNING
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	RUN FLAT/T WARN BUZZER
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	Int Lamp
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	Step Lamp Test
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	Battery Saver
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	FR Wiper
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	RR Wiper
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	Head Lamp Washer
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	Flasher
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	Theft IND
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	FR FOG Lamp
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	RR FOG Lamp
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	Daytime Running Light
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	ILL DIM Signal
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	OIL Pressure SW
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	BRAKE SW
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	Vehicle Security Horn
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	Head Lamp(HI)
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	SIREN
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	Horn
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	Warning Lamp
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	RUN FLAT TIRE W/L
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	Intelligent Key Link(CAN)
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	Retractable Mirror
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	Trunk/Back Door
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	Outside Buzzer
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	Inside Buzzer
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	Indicator
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	IGN CONT2
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	MIRROR+5
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	Engine SW Illumi
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	Push Switch Indicator
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	ACC CONT
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	ING CONT1
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	ST CONT LOW
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	SL 12V CPU
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	IGNITION RELAY
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	REVERSE LAMP TEST
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	DOOR HANDLE LAMP TEST

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

<b>make</b>	<b>model</b>	<b>year</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	DR SEAT LAMP TEST
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	AS SEAT LAMP TEST
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	SHIFT SPOT LAMP TEST
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	Trunk/Luggage Lamp Test
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	KEYFOB P/W TEST
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	SHIFTLOCK SORENOID TEST
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Signature Light Setting
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Door Lock-Unlock Set
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Auto Unlock Type
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Auto Lock Function
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Auto Unlock Function
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Set R-DEF Timer
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Scenario Lighting Setting
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Set I/L D-Unlock Intcon
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	FOG Lamp Override
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Rear Wiper Link With Reverse Setting
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Rain Sensor
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	FR RR DRIP
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Wiper Speed Setting
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	3-TIME Flasher Setting
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Confirm Dongle ID
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Daytime Running Light Setting
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Twilight On
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Wiper Link
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Custom A/Light Setting
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	ILL Delay Set
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Security Alarm SET
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	SIREN SET
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	ID READ
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	ID REGIST
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Touch Sensor Unlock Function Setting
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	IGN/ACC Battery Saver
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Remote Engine Starter
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Answer Back I-Key Lock Unlock
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Answerback I-Key Lock Unlock
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Answerback Keyless Lock Unlock
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Welcome Light Op Set
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Answer Back
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Retractable Mirror Set
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Confirm Key Fob ID
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Lock/Unlock By I-Key
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Engine Start By I-Key
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Trunk/Glass Hatch Open
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Intelligent Key Link Set
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Short Cranking Output
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Auto Lock Set
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Inside ANT Diagnosis
NISSAN	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Reset Setting Value
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Read Fault Code	
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Clear Fault Code	
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Read Data Stream	
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Module Information	
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Actuation Test	Rear Defogger
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Actuation Test	Int Lamp
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Actuation Test	Battery Saver
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Actuation Test	Vehicle Security Horn
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Actuation Test	Tail Lamp
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Actuation Test	FR FOG Lamp
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Actuation Test	ILL DIM Signal
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Actuation Test	Head Lamp
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Actuation Test	Cornering Lamp
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Actuation Test	Head Lamp Washer
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Actuation Test	FR Wiper
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Actuation Test	Door Lock
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Actuation Test	Flasher
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Actuation Test	Theft IND
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Actuation Test	BRAKE SW
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Actuation Test	OIL Pressure SW
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Actuation Test	Trunk/Glass Hatch
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Actuation Test	IGN KEY WARN ALM
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Actuation Test	Light Warn Alm
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Actuation Test	PANIC ALARM
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Special Function	Set R-DEF Timer
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Special Function	Set I/L D-Unlock Intcon

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Special Function	Room Lamp On Time Set
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Special Function	Room Lamp Off Time Set
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Special Function	Room Lamp Timer Set
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Special Function	Room Lamp BAT SAV SET
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Special Function	Security Alarm Set(Siren)
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Special Function	Battery Saver Set
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Special Function	Custom A/Light Setting
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Special Function	Wiper Speed Setting
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Special Function	REMO CONT ID REGIST
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Special Function	REMO CONT ID ERASUR
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Special Function	Auto Lock Set
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Special Function	Panic Alarm Set
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Special Function	TRUNK OPEN SET
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Special Function	Reset Setting Value
NISSAN	All Mode	Up to 2015	BCM (Body Control Module)	Special Function	Automatic Door Unlock Select
NISSAN	NV400	2011	BCM (Body Control Module)	Read Fault Code	
NISSAN	NV400	2011	BCM (Body Control Module)	Clear Fault Code	
NISSAN	NV400	2011	BCM (Body Control Module)	Read Data Stream	
NISSAN	NV400	2011	BCM (Body Control Module)	Module Information	
NISSAN	NV400	2011	BCM (Body Control Module)	Actuation Test	UNLOCKING THE DOORS AND BOOT
NISSAN	NV400	2011	BCM (Body Control Module)	Actuation Test	REAR FOG LIGHTS
NISSAN	NV400	2011	BCM (Body Control Module)	Actuation Test	PCHR RELAY1
NISSAN	NV400	2011	BCM (Body Control Module)	Actuation Test	PCHR RELAY2
NISSAN	NV400	2011	BCM (Body Control Module)	Actuation Test	CENTRAL LOCKING KEY LIGHT
NISSAN	NV400	2011	BCM (Body Control Module)	Actuation Test	LEFT INDICATOR
NISSAN	NV400	2011	BCM (Body Control Module)	Actuation Test	RIGHT-HAND INDICATOR
NISSAN	NV400	2011	BCM (Body Control Module)	Actuation Test	HAZARD LIGHTS LED
NISSAN	NV400	2011	BCM (Body Control Module)	Actuation Test	REAR SCREEN DE-ICING
NISSAN	NV400	2011	BCM (Body Control Module)	Actuation Test	Temperature Display
NISSAN	NV400	2011	BCM (Body Control Module)	Actuation Test	REAR INTERIOR LAMPS
NISSAN	NV400	2011	BCM (Body Control Module)	Actuation Test	+ACCESS.FEED 3 RELAY
NISSAN	NV400	2011	BCM (Body Control Module)	Actuation Test	INTERIOR LIGHTING
NISSAN	NV400	2011	BCM (Body Control Module)	Actuation Test	LUGGAGE COMPARTMENT
NISSAN	NV400	2011	BCM (Body Control Module)	Actuation Test	LOWER DRIVER WINDOW
NISSAN	NV400	2011	BCM (Body Control Module)	Actuation Test	RAISE DRIVER WINDOW
NISSAN	NV400	2011	BCM (Body Control Module)	Actuation Test	ACCESSORIES RELAY NO.2
NISSAN	NV400	2011	BCM (Body Control Module)	Special Function	Stored Energy Management Data
NISSAN	NV400	2011	BCM (Body Control Module)	Special Function	Vin Registration
NISSAN	NV400	2011	BCM (Body Control Module)	Special Function	Checking A Key
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Read Fault Code	
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Clear Fault Code	
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Read Data Stream	
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Module Information	
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Door Lock
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Super Lock
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Door Lock Ind
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Rear Defogger
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	IGN KEY WARN ALM
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Seat Belt Warn Test
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	ID REGIST WARNING
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Light Warn Alm
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Reverse Warning
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	RUN FLAT/T WARN BUZZER
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Key Reminder Warn
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	FR FOG Lamp
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	RR FOG Lamp
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	STOP LAMP 1
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	STOP LAMP 2
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	STOP LAMP 3
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Daytime Running Light
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	ILL DIM Signal
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Int Lamp
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	FR Wiper
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	RR Wiper
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Head Lamp Washer
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	PTC RELAY-1
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	PTC RELAY-2
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	PTC RELAY-3
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	A/C Indicator
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Outside Buzzer
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Inside Buzzer
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	INDICATOR
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Flasher
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Horn
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	IGN CONT-2
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	MIRROR+5
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Engine SW Illumi

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Push Switch Indicator
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	ENGINE START REQUEST
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	IGNITION RELAY
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	starter cut relay
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	ENGINE START
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Trunk/Back Door
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Retractable Mirror
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	REVERSE LAMP TEST
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	AS SEAT LAMP TEST
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	KEYFOB P/W TEST
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	AUTO ACC 2
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	AUTOMATIC BACK DOOR
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	AUTO ACC 1
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Trunk/Luggage Lamp Test
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Theft LND
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Battery Saver
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	SIREN
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Vehicle Security Horn
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Head Lamp
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	OIL Pressure SW
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	BRAKE SW
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Warning Lamp
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Door Lock-Unlock Set
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Auto Unlock Type
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Auto Lock Function
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Auto Unlock Function
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Signature Light Setting
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Set R-DEF Timer
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Custom A/Light Setting
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	ILL Delay Set
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Twilight On
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Wiper Link
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Daytime Running Light Setting
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Set I/L D-Unlock Intcon
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	FOG Lamp Override
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Spicy Brightness Setting
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Wiper Speed Setting
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Rain Sensor
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	FR RR DRIP
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Rear Wiper Link With Reverse Setting
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	3-TIME Flasher Setting
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Inside ANT Diagnosis
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Lock/Unlock By I-Key
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Engine Start By I-Key
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Trunk/Glass Hatch Open
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Auto Lock Set
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	IGN/ACC Battery Saver
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Short Cranking Output
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Answer Back
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Answer Back I-Key Lock Unlock
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Answerback I-Key Lock Unlock
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Answerback Keyless Lock Unlock
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Welcome Light Op Set
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Reset Setting Value
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Confirm Dongle ID
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	SIREN SET
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Security Alarm SET
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Auto Acc Fnctn (Audio/Navl Set After Ign Off)
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	AutoFold function
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Theft ALM TRG
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Confirm TCU ID
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Remote Engine Starter
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Touch Sensor Unlock Function Setting
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Intelligent Key Link Set
NISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	(TBD)ShBW_ID_REGISTRATION FINISHED
NISSAN	All Mode	2015 - 2018	BCM (Body Control Module)	Read Fault Code	
NISSAN	All Mode	2015 - 2018	BCM (Body Control Module)	Clear Fault Code	
NISSAN	All Mode	2015 - 2018	BCM (Body Control Module)	Read Data Stream	
NISSAN	All Mode	2015 - 2018	BCM (Body Control Module)	Module Information	
NISSAN	All Mode	2015 - 2018	BCM (Body Control Module)	Actuation Test	Check left front turn signal lamp

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

<b>make</b>	<b>model</b>	<b>year</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
NISSAN	All Mode	2015 - 2018	BCM (Body Control Module)	Actuation Test	Check eco start stop function additional battery relay
NISSAN	All Mode	2015 - 2018	BCM (Body Control Module)	Actuation Test	Check right front turn signal lamp
NISSAN	All Mode	2015 - 2018	BCM (Body Control Module)	Actuation Test	Check right rear turn signal lamp
NISSAN	All Mode	2015 - 2018	BCM (Body Control Module)	Actuation Test	Check left rear turn signal lamp
NISSAN	All Mode	2015 - 2018	BCM (Body Control Module)	Actuation Test	Check Right Daytime Running Light Headlamp
NISSAN	All Mode	2015 - 2018	BCM (Body Control Module)	Actuation Test	Check Left Daytime Running Light Headlamp
NISSAN	All Mode	2015 - 2018	BCM (Body Control Module)	Actuation Test	Left front lamp unit
NISSAN	All Mode	2015 - 2018	BCM (Body Control Module)	Actuation Test	Centre brake lamp
NISSAN	All Mode	2015 - 2018	BCM (Body Control Module)	Actuation Test	License Plate Lamp
NISSAN	All Mode	2015 - 2018	BCM (Body Control Module)	Actuation Test	Left rear fog lamp
NISSAN	All Mode	2015 - 2018	BCM (Body Control Module)	Actuation Test	Windshield washer system pump
NISSAN	All Mode	2015 - 2018	BCM (Body Control Module)	Actuation Test	Headlamp clean system pump
NISSAN	All Mode	2015 - 2018	BCM (Body Control Module)	Actuation Test	Tank cap central locking actuator
NISSAN	All Mode	2015 - 2018	BCM (Body Control Module)	Actuation Test	Side marker lamp
NISSAN	All Mode	2015 - 2018	BCM (Body Control Module)	Actuation Test	Inner left rear lamp unit
NISSAN	All Mode	2015 - 2018	BCM (Body Control Module)	Actuation Test	Left rear power window
NISSAN	All Mode	2015 - 2018	BCM (Body Control Module)	Actuation Test	Right rear lamp unit
NISSAN	All Mode	2015 - 2018	BCM (Body Control Module)	Actuation Test	Front turn signal lamp
NISSAN	All Mode	2015 - 2018	BCM (Body Control Module)	Actuation Test	Erase alarm sources
NISSAN	All Mode	2015 - 2018	BCM (Body Control Module)	Actuation Test	Circuit 30G Relay
NISSAN	All Mode	2015 - 2018	BCM (Body Control Module)	Actuation Test	Rear fuse box
NISSAN	All Mode	2015 - 2018	BCM (Body Control Module)	Actuation Test	Engine compartment fuse and relay module
NISSAN	All Mode	2015 - 2018	BCM (Body Control Module)	Actuation Test	Symbol illumination
NISSAN	All Mode	2015 - 2018	BCM (Body Control Module)	Actuation Test	Activate demo mode of exterior lamp
NISSAN	All Mode	2015 - 2018	BCM (Body Control Module)	Actuation Test	Rear Doors
NISSAN	All Mode	2015 - 2018	BCM (Body Control Module)	Actuation Test	Liftgate central locking motor
NISSAN	All Mode	2015 - 2018	BCM (Body Control Module)	Actuation Test	Right rear power window
NISSAN	All Mode	2015 - 2018	BCM (Body Control Module)	Actuation Test	Running board courtesy light
NISSAN	All Mode	2015 - 2018	BCM (Body Control Module)	Actuation Test	Illuminated door sill moldings
NISSAN	All Mode	2015 - 2018	BCM (Body Control Module)	Actuation Test	Right front lamp unit
NISSAN	All Mode	2015 - 2018	BCM (Body Control Module)	Actuation Test	Left rear lamp unit
NISSAN	All Mode	2015 - 2018	BCM (Body Control Module)	Actuation Test	Footwell lamp
NISSAN	All Mode	2015 - 2018	BCM (Body Control Module)	Actuation Test	Back-Up Lamp
NISSAN	All Mode	2015 - 2018	BCM (Body Control Module)	Actuation Test	Trunk Lamp
NISSAN	All Mode	2015 - 2018	BCM (Body Control Module)	Actuation Test	Spray nozzle hose heater
NISSAN	All Mode	2015 - 2018	BCM (Body Control Module)	Actuation Test	Inner right rear lamp unit
NISSAN	All Mode	2015 - 2018	BCM (Body Control Module)	Actuation Test	Daytime Running Light
NISSAN	All Mode	2015 - 2018	BCM (Body Control Module)	Actuation Test	Windscreen Wiper
NISSAN	All Mode	2015 - 2018	BCM (Body Control Module)	Actuation Test	Last data record
NISSAN	All Mode	2015 - 2018	BCM (Body Control Module)	Actuation Test	Second from last data record
NISSAN	All Mode	2015 - 2018	BCM (Body Control Module)	Actuation Test	Third from last data record
NISSAN	All Mode	2015 - 2018	BCM (Body Control Module)	Actuation Test	Fourth from last data record
NISSAN	All Mode	2015 - 2018	BCM (Body Control Module)	Actuation Test	Fifth from last data record
NISSAN	All Mode	2015 - 2018	BCM (Body Control Module)	Actuation Test	Sixth to last data record
NISSAN	All Mode	2015 - 2018	BCM (Body Control Module)	Actuation Test	Seventh to last data record
NISSAN	All Mode	2015 - 2018	BCM (Body Control Module)	Actuation Test	Eighth to last data record
NISSAN	All Mode	2015 - 2018	BCM (Body Control Module)	Actuation Test	Ninth to last data record
NISSAN	All Mode	2015 - 2018	BCM (Body Control Module)	Actuation Test	Tenth to last data record
NISSAN	All Mode	2015 - 2018	BCM (Body Control Module)	Actuation Test	Front fog lamp
NISSAN	All Mode	2015 - 2018	BCM (Body Control Module)	Actuation Test	Door handle illumination rear doors
NISSAN	All Mode	2015 - 2018	BCM (Body Control Module)	Actuation Test	Ambiance illumination of rear door
NISSAN	All Mode	2015 - 2018	BCM (Body Control Module)	Actuation Test	Interior lamp
NISSAN	All Mode	2015 - 2018	BCM (Body Control Module)	Actuation Test	Mirror lamps of sun visors
NISSAN	All Mode	2015 - 2018	BCM (Body Control Module)	Actuation Test	Reading lamp actuation
NISSAN	All Mode	2015 - 2018	BCM (Body Control Module)	Actuation Test	Rear lamp actuation
NISSAN	All Mode	2015 - 2018	BCM (Body Control Module)	Actuation Test	Check component M10 5 RL door power window motor
NISSAN	All Mode	2015 - 2018	BCM (Body Control Module)	Actuation Test	Check component M10 6 RR door power window motor
NISSAN	All Mode	2015 - 2018	BCM (Body Control Module)	Actuation Test	Left rear power window actual value

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
NISSAN	All Mode	2015 - 2018	BCM (Body Control Module)	Actuation Test	Right rear power window actual value
NISSAN	All Mode	2015 - 2018	BCM (Body Control Module)	Actuation Test	Confirmation of battery change
NISSAN	All Mode	2015 - 2018	BCM (Body Control Module)	Special Function	Replace decoupling relay
NISSAN	All Mode	2015 - 2018	BCM (Body Control Module)	Special Function	Replace eco start stop function add battery
NISSAN	All Mode	2015 - 2017	BCM (Body Control Module)	Read Fault Code	
NISSAN	All Mode	2015 - 2017	BCM (Body Control Module)	Clear Fault Code	
NISSAN	All Mode	2015 - 2017	BCM (Body Control Module)	Read Data Stream	
NISSAN	All Mode	2015 - 2017	BCM (Body Control Module)	Module Information	
NISSAN	All Mode	2015 - 2017	BCM (Body Control Module)	Actuation Test	Central Door Locking
NISSAN	All Mode	2015 - 2017	BCM (Body Control Module)	Actuation Test	UNLOCKING THE DOORS AND BOOT
NISSAN	All Mode	2015 - 2017	BCM (Body Control Module)	Actuation Test	Rear Screen Wiper
NISSAN	All Mode	2015 - 2017	BCM (Body Control Module)	Actuation Test	PCHR RELAY1
NISSAN	All Mode	2015 - 2017	BCM (Body Control Module)	Actuation Test	PCHR RELAY2
NISSAN	All Mode	2015 - 2017	BCM (Body Control Module)	Actuation Test	PCHR RELAY3
NISSAN	All Mode	2015 - 2017	BCM (Body Control Module)	Actuation Test	REAR DE-ICING Indic Lamp
NISSAN	All Mode	2015 - 2017	BCM (Body Control Module)	Actuation Test	CENTRAL LOCKING KEY LIGHT
NISSAN	All Mode	2015 - 2017	BCM (Body Control Module)	Actuation Test	LEFT INDICATOR
NISSAN	All Mode	2015 - 2017	BCM (Body Control Module)	Actuation Test	RIGHT-HAND INDICATOR
NISSAN	All Mode	2015 - 2017	BCM (Body Control Module)	Actuation Test	Deadlocking
NISSAN	All Mode	2015 - 2017	BCM (Body Control Module)	Actuation Test	HAZARD LIGHTS LED
NISSAN	All Mode	2015 - 2017	BCM (Body Control Module)	Actuation Test	Deadunlocking
NISSAN	All Mode	2015 - 2017	BCM (Body Control Module)	Actuation Test	WINDSCREEN WIPER:LOW SPEED
NISSAN	All Mode	2015 - 2017	BCM (Body Control Module)	Actuation Test	Hazard Warning Lights
NISSAN	All Mode	2015 - 2017	BCM (Body Control Module)	Actuation Test	HEATED RR SCREEN RELAY
NISSAN	All Mode	2015 - 2017	BCM (Body Control Module)	Actuation Test	INTERIOR LIGHTING
NISSAN	All Mode	2015 - 2017	BCM (Body Control Module)	Actuation Test	UCH --> TRANSPONDER RING CONNECTION TEST
NISSAN	All Mode	2015 - 2017	BCM (Body Control Module)	Actuation Test	REAR WINDOW LOCKING
NISSAN	All Mode	2015 - 2017	BCM (Body Control Module)	Special Function	Vin Registration
NISSAN	All Mode	2015 - 2017	BCM (Body Control Module)	Read Fault Code	
NISSAN	All Mode	2015 - 2017	BCM (Body Control Module)	Clear Fault Code	
NISSAN	All Mode	2015 - 2017	BCM (Body Control Module)	Read Data Stream	
NISSAN	All Mode	2015 - 2017	BCM (Body Control Module)	Module Information	
NISSAN	All Mode	2015 - 2017	BCM (Body Control Module)	Actuation Test	RIGHT-HAND INDICATOR
NISSAN	All Mode	2015 - 2017	BCM (Body Control Module)	Actuation Test	LEFT INDICATOR
NISSAN	All Mode	2015 - 2017	BCM (Body Control Module)	Actuation Test	HAZARD LIGHTS LED
NISSAN	All Mode	2015 - 2017	BCM (Body Control Module)	Actuation Test	INTERIOR LIGHTING
NISSAN	All Mode	2015 - 2017	BCM (Body Control Module)	Actuation Test	PCHR RELAY1
NISSAN	All Mode	2015 - 2017	BCM (Body Control Module)	Actuation Test	PCHR RELAY2
NISSAN	All Mode	2015 - 2017	BCM (Body Control Module)	Actuation Test	HEATED RR SCREEN RELAY
NISSAN	All Mode	2015 - 2017	BCM (Body Control Module)	Actuation Test	Rear Screen Wiper
NISSAN	All Mode	2015 - 2017	BCM (Body Control Module)	Actuation Test	WINDSCREEN WIPER:LOW SPEED
NISSAN	All Mode	2015 - 2017	BCM (Body Control Module)	Actuation Test	REAR WINDOW LOCKING
NISSAN	All Mode	2015 - 2017	BCM (Body Control Module)	Actuation Test	UNLOCKING THE DOORS AND BOOT
NISSAN	All Mode	2015 - 2017	BCM (Body Control Module)	Actuation Test	Central Door Locking
NISSAN	All Mode	2015 - 2017	BCM (Body Control Module)	Actuation Test	UCH --> TRANSPONDER RING CONNECTION TEST
NISSAN	All Mode	2015 - 2017	BCM (Body Control Module)	Actuation Test	CENTRAL LOCKING KEY LIGHT
NISSAN	All Mode	2015 - 2017	BCM (Body Control Module)	Actuation Test	Deadlocking
NISSAN	All Mode	2015 - 2017	BCM (Body Control Module)	Actuation Test	Deadunlocking
NISSAN	All Mode	2015 - 2017	BCM (Body Control Module)	Actuation Test	Left Hand Heated Windscreen
NISSAN	All Mode	2015 - 2017	BCM (Body Control Module)	Actuation Test	Right Hand Heated Windscreen
NISSAN	All Mode	2015 - 2017	BCM (Body Control Module)	Actuation Test	Hazard Warning Lights
NISSAN	All Mode	2015 - 2017	BCM (Body Control Module)	Special Function	High Pressure Pump Counter
NISSAN	All Mode	2015 - 2017	BCM (Body Control Module)	Special Function	Number Of Starting Cycles
NISSAN	All Mode	2015 - 2017	BCM (Body Control Module)	Special Function	Vin Registration
NISSAN	NV300	2016	BCM (Body Control Module)	Read Fault Code	
NISSAN	NV300	2016	BCM (Body Control Module)	Clear Fault Code	
NISSAN	NV300	2016	BCM (Body Control Module)	Read Data Stream	
NISSAN	NV300	2016	BCM (Body Control Module)	Module Information	
NISSAN	All Mode	2016 - 2017	BCM (Body Control Module)	Read Fault Code	
NISSAN	All Mode	2016 - 2017	BCM (Body Control Module)	Clear Fault Code	
NISSAN	All Mode	2016 - 2017	BCM (Body Control Module)	Read Data Stream	
NISSAN	All Mode	2016 - 2017	BCM (Body Control Module)	Module Information	
NISSAN	All Mode	2016 - 2017	BCM (Body Control Module)	Special Function	Reset Setting Value
NISSAN	All Mode	2016 - 2017	BCM (Body Control Module)	Special Function	Inside ANT Diagnosis
NISSAN	All Mode	2016 - 2017	BCM (Body Control Module)	Special Function	SIREN SET
NISSAN	All Mode	2016 - 2017	BCM (Body Control Module)	Special Function	Security Alarm SET
NISSAN	All Mode	2016 - 2017	BCM (Body Control Module)	Special Function	Confirm Dongle ID
NISSAN	All Mode	2016 - 2017	BCM (Body Control Module)	Special Function	Auto Acc Fnctn (Audio/Nav Set After Ign Off)
NISSAN	All Mode	2016 - 2017	BCM (Body Control Module)	Special Function	Wiper Speed Setting
NISSAN	All Mode	2016 - 2017	BCM (Body Control Module)	Special Function	Rain Sensor
NISSAN	All Mode	2016 - 2017	BCM (Body Control Module)	Special Function	FR RR DRIP

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
NISSAN	All Mode	2016 - 2017	BCM (Body Control Module)	Special Function	Rear Wiper Link With Reverse Setting
NISSAN	All Mode	2016 - 2017	BCM (Body Control Module)	Special Function	Remote Engine Starter
NISSAN	All Mode	2016 - 2017	BCM (Body Control Module)	Special Function	Touch Sensor Unlock Function Setting
NISSAN	All Mode	2016 - 2017	BCM (Body Control Module)	Special Function	Door Lock-Unlock Set
NISSAN	All Mode	2016 - 2017	BCM (Body Control Module)	Special Function	Auto Unlock Type
NISSAN	All Mode	2016 - 2017	BCM (Body Control Module)	Special Function	Auto Lock Function
NISSAN	All Mode	2016 - 2017	BCM (Body Control Module)	Special Function	Auto Unlock Function
NISSAN	All Mode	2016 - 2017	BCM (Body Control Module)	Special Function	Signature Light Setting
NISSAN	All Mode	2016 - 2017	BCM (Body Control Module)	Special Function	Custom A/Light Setting
NISSAN	All Mode	2016 - 2017	BCM (Body Control Module)	Special Function	ILL Delay Set
NISSAN	All Mode	2016 - 2017	BCM (Body Control Module)	Special Function	Twilight On
NISSAN	All Mode	2016 - 2017	BCM (Body Control Module)	Special Function	Autofold function
NISSAN	All Mode	2016 - 2017	BCM (Body Control Module)	Special Function	Set I/L D-Unlock Intcon
NISSAN	All Mode	2016 - 2017	BCM (Body Control Module)	Special Function	FOG Lamp Override
NISSAN	All Mode	2016 - 2017	BCM (Body Control Module)	Special Function	3-TIME Flasher Setting
NISSAN	All Mode	2016 - 2017	BCM (Body Control Module)	Special Function	Lock/Unlock By I-Key
NISSAN	All Mode	2016 - 2017	BCM (Body Control Module)	Special Function	Engine Start By I-Key
NISSAN	All Mode	2016 - 2017	BCM (Body Control Module)	Special Function	Trunk/Glass Hatch Open
NISSAN	All Mode	2016 - 2017	BCM (Body Control Module)	Special Function	Auto Lock Set
NISSAN	All Mode	2016 - 2017	BCM (Body Control Module)	Special Function	Short Cranking Output
NISSAN	All Mode	2016 - 2017	BCM (Body Control Module)	Special Function	IGN/ACC Battery Saver
NISSAN	All Mode	2016 - 2017	BCM (Body Control Module)	Special Function	Answer Back
NISSAN	All Mode	2016 - 2017	BCM (Body Control Module)	Special Function	Answer Back I-Key Lock Unlock
NISSAN	All Mode	2016 - 2017	BCM (Body Control Module)	Special Function	Answerback I-Key Lock Unlock
NISSAN	All Mode	2016 - 2017	BCM (Body Control Module)	Special Function	Answerback Keyless Lock Unlock
NISSAN	All Mode	2016 - 2017	BCM (Body Control Module)	Special Function	WELCOME LIGHT OP SET
NISSAN	All Mode	2016 - 2017	BCM (Body Control Module)	Special Function	Intelligent Key Link Set
NISSAN	All Mode	2016 - 2017	BCM (Body Control Module)	Special Function	Wiper Link
NISSAN	All Mode	2016 - 2017	BCM (Body Control Module)	Special Function	Daytime Running Light Setting
NISSAN	All Mode	2016 - 2017	BCM (Body Control Module)	Special Function	Set R-DEF Timer
NISSAN	All Mode	2016 - 2017	BCM (Body Control Module)	Special Function	Theft ALM TRG
NISSAN	redi GO	2016	BCM (Body Control Module)	Read Fault Code	
NISSAN	redi GO	2016	BCM (Body Control Module)	Clear Fault Code	
NISSAN	redi GO	2016	BCM (Body Control Module)	Read Data Stream	
NISSAN	redi GO	2016	BCM (Body Control Module)	Module Information	
NISSAN	redi GO	2016	BCM (Body Control Module)	Special Function	Vin Registration
NISSAN	All Mode	Up to 2011	BCM (Body Control Module)	Read Fault Code	
NISSAN	All Mode	Up to 2011	BCM (Body Control Module)	Clear Fault Code	
NISSAN	All Mode	Up to 2011	BCM (Body Control Module)	Read Data Stream	
NISSAN	All Mode	Up to 2011	BCM (Body Control Module)	Module Information	
NISSAN	All Mode	Up to 2011	BCM (Body Control Module)	Special Function	REMO CONT ID CONFIR
NISSAN	All Mode	Up to 2011	BCM (Body Control Module)	Special Function	REMO CONT ID REGIST
NISSAN	All Mode	Up to 2011	BCM (Body Control Module)	Special Function	REMO CONT ID ERASUR
NISSAN	All Mode	Up to 2011	BCM (Body Control Module)	Special Function	
NISSAN	NP200	2008	BCM (Body Control Module)	Read Fault Code	
NISSAN	NP200	2008	BCM (Body Control Module)	Clear Fault Code	
NISSAN	NP200	2008	BCM (Body Control Module)	Read Data Stream	
NISSAN	NP200	2008	BCM (Body Control Module)	Module Information	
NISSAN	NP200	2008	BCM (Body Control Module)	Special Function	Vin Registration
NISSAN	NP200	2008	BCM (Body Control Module)	Special Function	Erase Computer Memory
NISSAN	NP200	2008	BCM (Body Control Module)	Read Fault Code	
NISSAN	NP200	2008	BCM (Body Control Module)	Clear Fault Code	
NISSAN	NP200	2008	BCM (Body Control Module)	Read Data Stream	
NISSAN	NP200	2008	BCM (Body Control Module)	Module Information	
NISSAN	NP200	2008	BCM (Body Control Module)	Special Function	Vin Registration
NISSAN	All Mode	2006 - 2009	BCM (Body Control Module)	Read Fault Code	
NISSAN	All Mode	2006 - 2009	BCM (Body Control Module)	Clear Fault Code	
NISSAN	All Mode	2006 - 2009	BCM (Body Control Module)	Read Data Stream	
NISSAN	All Mode	2006 - 2009	BCM (Body Control Module)	Module Information	
NISSAN	All Mode	2006 - 2009	BCM (Body Control Module)	Special Function	Key Programming
NISSAN	All Mode	2006 - 2009	BCM (Body Control Module)	Special Function	Vin Registration
NISSAN	All Mode	2006 - 2009	BCM (Body Control Module)	Read Fault Code	
NISSAN	All Mode	2006 - 2009	BCM (Body Control Module)	Clear Fault Code	
NISSAN	All Mode	2006 - 2009	BCM (Body Control Module)	Read Data Stream	
NISSAN	All Mode	2006 - 2009	BCM (Body Control Module)	Module Information	
NISSAN	All Mode	2006 - 2009	BCM (Body Control Module)	Special Function	Key Programming
NISSAN	All Mode	2006 - 2009	BCM (Body Control Module)	Special Function	Vin Registration
NISSAN	All Mode	2006 - 2009	BCM (Body Control Module)	Special Function	Multiplexed Network Configuration
NISSAN	All Mode	2006 - 2009	BCM (Body Control Module)	Read Fault Code	
NISSAN	All Mode	2006 - 2009	BCM (Body Control Module)	Clear Fault Code	
NISSAN	All Mode	2006 - 2009	BCM (Body Control Module)	Read Data Stream	
NISSAN	All Mode	2006 - 2009	BCM (Body Control Module)	Module Information	
NISSAN	All Mode	2006 - 2009	BCM (Body Control Module)	Special Function	Vin Registration

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

<b>make</b>	<b>model</b>	<b>year</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
NISSAN	All Mode	2006 - 2009	BCM (Body Control Module)	Special Function	Key Programming
NISSAN	ALMERA	2012	BCM (Body Control Module)	Read Data Stream	
NISSAN	ALMERA	2012	BCM (Body Control Module)	Module Information	
NISSAN	NP200	2008	BCM (Body Control Module)	Read Data Stream	
NISSAN	NP200	2008	BCM (Body Control Module)	Module Information	
NISSAN	All Mode	Up to 2017	4WAS (MAIN) /RAS/HICAS	Read Fault Code	
NISSAN	All Mode	Up to 2017	4WAS (MAIN) /RAS/HICAS	Clear Fault Code	
NISSAN	All Mode	Up to 2017	4WAS (MAIN) /RAS/HICAS	Read Data Stream	
NISSAN	All Mode	Up to 2017	4WAS (MAIN) /RAS/HICAS	Module Information	
NISSAN	All Mode	Up to 2017	4WAS (MAIN) /RAS/HICAS	Actuation Test	SELF DIAGNOSTIC MODE
NISSAN	All Mode	2006 - 2017	4WAS (MAIN) /RAS/HICAS	Read Fault Code	
NISSAN	All Mode	2006 - 2017	4WAS (MAIN) /RAS/HICAS	Clear Fault Code	
NISSAN	All Mode	2006 - 2017	4WAS (MAIN) /RAS/HICAS	Read Data Stream	
NISSAN	All Mode	2006 - 2017	4WAS (MAIN) /RAS/HICAS	Module Information	
NISSAN	All Mode	2006 - 2017	4WAS (MAIN) /RAS/HICAS	Actuation Test	SELF DIAGNOSTIC MODE
NISSAN	All Mode	2009 - 2017	4WAS (MAIN) /RAS/HICAS	Read Fault Code	
NISSAN	All Mode	2009 - 2017	4WAS (MAIN) /RAS/HICAS	Clear Fault Code	
NISSAN	All Mode	2009 - 2017	4WAS (MAIN) /RAS/HICAS	Read Data Stream	
NISSAN	All Mode	2009 - 2017	4WAS (MAIN) /RAS/HICAS	Module Information	
NISSAN	All Mode	2009 - 2017	4WAS (MAIN) /RAS/HICAS	Actuation Test	SELF DIAGNOSTIC MODE
NISSAN	All Mode	Up to 2015	4WAS (MAIN) /RAS/HICAS	Read Fault Code	
NISSAN	All Mode	Up to 2015	4WAS (MAIN) /RAS/HICAS	Clear Fault Code	
NISSAN	All Mode	Up to 2015	4WAS (MAIN) /RAS/HICAS	Read Data Stream	
NISSAN	All Mode	Up to 2015	4WAS (MAIN) /RAS/HICAS	Module Information	
NISSAN	All Mode	Up to 2015	4WAS (MAIN) /RAS/HICAS	Actuation Test	
NISSAN	All Mode	Up to 2015	4WAS (MAIN) /RAS/HICAS	Read Fault Code	
NISSAN	All Mode	Up to 2015	4WAS (MAIN) /RAS/HICAS	Clear Fault Code	
NISSAN	All Mode	Up to 2015	4WAS (MAIN) /RAS/HICAS	Read Data Stream	
NISSAN	All Mode	Up to 2015	4WAS (MAIN) /RAS/HICAS	Module Information	
NISSAN	All Mode	Up to 2015	4WAS (MAIN) /RAS/HICAS	Actuation Test	
NISSAN	All Mode	Up to 2015	4WAS (MAIN) /RAS/HICAS	Read Fault Code	
NISSAN	All Mode	Up to 2015	4WAS (MAIN) /RAS/HICAS	Clear Fault Code	
NISSAN	All Mode	Up to 2015	4WAS (MAIN) /RAS/HICAS	Read Data Stream	
NISSAN	All Mode	Up to 2015	4WAS (MAIN) /RAS/HICAS	Module Information	
NISSAN	All Mode	Up to 2015	4WAS (MAIN) /RAS/HICAS	Actuation Test	
NISSAN	All Mode	Up to 2017	Sonar	Read Fault Code	
NISSAN	All Mode	Up to 2017	Sonar	Clear Fault Code	
NISSAN	All Mode	Up to 2017	Sonar	Read Data Stream	
NISSAN	All Mode	Up to 2017	Sonar	Read Freeze Frame	
NISSAN	All Mode	Up to 2017	Sonar	Module Information	
NISSAN	All Mode	Up to 2017	Sonar	Actuation Test	BUZZER
NISSAN	All Mode	Up to 2017	Sonar	Actuation Test	CANCEL SW IND
NISSAN	All Mode	Up to 2017	Sonar	Actuation Test	SONAR SENSOR
NISSAN	All Mode	Up to 2017	Sonar	Actuation Test	PSM SONAR SENSOR
NISSAN	All Mode	Up to 2017	Sonar	Actuation Test	DISPLAY CONTROL
NISSAN	All Mode	Up to 2017	Sonar	Special Function	Corner Sen Distance Set
NISSAN	All Mode	Up to 2017	Sonar	Special Function	Center Sen Distance Set
NISSAN	All Mode	Up to 2017	Sonar	Special Function	Volume Setting
NISSAN	All Mode	Up to 2017	Sonar	Special Function	Trailer Hitch Mode
NISSAN	All Mode	Up to 2017	Sonar	Special Function	Parking Width Level Setting
NISSAN	All Mode	Up to 2017	Sonar	Special Function	TIRE DIAMETER ADJUSTMENT
NISSAN	All Mode	Up to 2018	Sonar	Read Fault Code	
NISSAN	All Mode	Up to 2018	Sonar	Clear Fault Code	
NISSAN	All Mode	Up to 2018	Sonar	Read Data Stream	
NISSAN	All Mode	Up to 2018	Sonar	Module Information	
NISSAN	All Mode	Up to 2018	Sonar	Actuation Test	REAR BUZZER
NISSAN	All Mode	Up to 2018	Sonar	Actuation Test	FRONT BUZZER
NISSAN	All Mode	Up to 2018	Sonar	Actuation Test	LED
NISSAN	All Mode	Up to 2018	Sonar	Special Function	Volume Setting
NISSAN	All Mode	Up to 2018	Sonar	Special Function	Trailer hitch detection range adjustment
NISSAN	All Mode	Up to 2017	Sonar	Read Fault Code	
NISSAN	All Mode	Up to 2017	Sonar	Clear Fault Code	
NISSAN	All Mode	Up to 2017	Sonar	Read Data Stream	
NISSAN	All Mode	Up to 2017	Sonar	Module Information	
NISSAN	All Mode	Up to 2017	Sonar	Actuation Test	REAR BUZZER
NISSAN	All Mode	Up to 2017	Sonar	Actuation Test	LED
NISSAN	All Mode	Up to 2017	Sonar	Actuation Test	FRONT BUZZER
NISSAN	All Mode	Up to 2017	Sonar	Special Function	Volume Setting
NISSAN	All Mode	Up to 2017	Sonar	Special Function	Trailer hitch detection range adjustment
NISSAN	All Mode	Up to 2017	Sonar	Read Fault Code	
NISSAN	All Mode	Up to 2017	Sonar	Clear Fault Code	
NISSAN	All Mode	Up to 2017	Sonar	Read Data Stream	
NISSAN	All Mode	Up to 2017	Sonar	Module Information	
NISSAN	All Mode	Up to 2017	Sonar	Actuation Test	REAR BUZZER
NISSAN	All Mode	Up to 2017	Sonar	Actuation Test	LED
NISSAN	All Mode	Up to 2017	Sonar	Actuation Test	FRONT BUZZER
NISSAN	All Mode	Up to 2017	Sonar	Special Function	Volume Setting



**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

<b>make</b>	<b>model</b>	<b>year</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
NISSAN	All Mode	Up to 2017	Sonar	Special Function	Trailer hitch detection range adjustment
NISSAN	All Mode	Up to 2017	Sonar	Read Fault Code	
NISSAN	All Mode	Up to 2017	Sonar	Clear Fault Code	
NISSAN	All Mode	Up to 2017	Sonar	Read Data Stream	
NISSAN	All Mode	Up to 2017	Sonar	Module Information	
NISSAN	All Mode	Up to 2017	Sonar	Actuation Test	REAR BUZZER
NISSAN	All Mode	Up to 2017	Sonar	Actuation Test	LED
NISSAN	All Mode	Up to 2017	Sonar	Actuation Test	FRONT BUZZER
NISSAN	All Mode	Up to 2017	Sonar	Special Function	Volume Setting
NISSAN	All Mode	Up to 2017	Sonar	Special Function	Trailer hitch detection range adjustment
NISSAN	NV300	2016	Sonar	Read Fault Code	
NISSAN	NV300	2016	Sonar	Clear Fault Code	
NISSAN	NV300	2016	Sonar	Read Data Stream	
NISSAN	NV300	2016	Sonar	Module Information	
NISSAN	All Mode	2015 - 2017	Sonar	Read Fault Code	
NISSAN	All Mode	2015 - 2017	Sonar	Clear Fault Code	
NISSAN	All Mode	2015 - 2017	Sonar	Read Data Stream	
NISSAN	All Mode	2015 - 2017	Sonar	Module Information	
NISSAN	All Mode	2015 - 2017	Sonar	Special Function	Volume Setting
NISSAN	All Mode	Up to 2017	Sonar	Read Fault Code	
NISSAN	All Mode	Up to 2017	Sonar	Clear Fault Code	
NISSAN	All Mode	Up to 2017	Sonar	Read Data Stream	
NISSAN	All Mode	Up to 2017	Sonar	Module Information	
NISSAN	All Mode	Up to 2017	Sonar	Actuation Test	BUZZER
NISSAN	All Mode	Up to 2017	Sonar	Actuation Test	CANCEL SW IND
NISSAN	All Mode	Up to 2017	Sonar	Actuation Test	SONAR SENSOR
NISSAN	All Mode	Up to 2017	Sonar	Special Function	Corner Sen Distance Set
NISSAN	All Mode	Up to 2017	Sonar	Special Function	Volume Setting
NISSAN	All Mode	Up to 2017	Sonar	Special Function	Trailer Hitch Mode
NISSAN	All Mode	Up to 2017	Sonar	Read Fault Code	
NISSAN	All Mode	Up to 2017	Sonar	Clear Fault Code	
NISSAN	All Mode	Up to 2017	Sonar	Read Data Stream	
NISSAN	All Mode	Up to 2017	Sonar	Module Information	
NISSAN	All Mode	Up to 2017	Sonar	Actuation Test	BUZZER
NISSAN	All Mode	Up to 2017	Sonar	Actuation Test	CANCEL SW IND
NISSAN	All Mode	Up to 2017	Sonar	Actuation Test	SONAR SENSOR
NISSAN	All Mode	Up to 2017	Sonar	Special Function	Corner Sen Distance Set
NISSAN	All Mode	Up to 2017	Sonar	Special Function	Center Sen Distance Set
NISSAN	All Mode	Up to 2017	Sonar	Special Function	Volume Setting
NISSAN	All Mode	Up to 2017	Sonar	Special Function	Trailer Hitch Mode
NISSAN	All Mode	2007 - 2017	Sonar	Read Fault Code	
NISSAN	All Mode	2007 - 2017	Sonar	Clear Fault Code	
NISSAN	All Mode	2007 - 2017	Sonar	Read Data Stream	
NISSAN	All Mode	2007 - 2017	Sonar	Module Information	
NISSAN	All Mode	2007 - 2017	Sonar	Actuation Test	BUZZER
NISSAN	All Mode	2007 - 2017	Sonar	Actuation Test	CANCEL SW IND
NISSAN	All Mode	2007 - 2017	Sonar	Actuation Test	SONAR SENSOR
NISSAN	All Mode	2007 - 2017	Sonar	Special Function	Corner Sen Distance Set
NISSAN	All Mode	2007 - 2017	Sonar	Special Function	Center Sen Distance Set
NISSAN	All Mode	2007 - 2017	Sonar	Special Function	Volume Setting
NISSAN	All Mode	2007 - 2017	Sonar	Special Function	Trailer Hitch Mode
NISSAN	All Mode	2008 - 2017	Sonar	Read Fault Code	
NISSAN	All Mode	2008 - 2017	Sonar	Clear Fault Code	
NISSAN	All Mode	2008 - 2017	Sonar	Read Data Stream	
NISSAN	All Mode	2008 - 2017	Sonar	Module Information	
NISSAN	All Mode	2008 - 2017	Sonar	Actuation Test	BUZZER
NISSAN	All Mode	2008 - 2017	Sonar	Actuation Test	CANCEL SW IND
NISSAN	All Mode	2008 - 2017	Sonar	Actuation Test	SONAR SENSOR
NISSAN	All Mode	2008 - 2017	Sonar	Special Function	Corner Sen Distance Set
NISSAN	All Mode	2008 - 2017	Sonar	Special Function	Center Sen Distance Set
NISSAN	All Mode	2008 - 2017	Sonar	Special Function	Volume Setting
NISSAN	All Mode	2008 - 2017	Sonar	Special Function	Trailer Hitch Mode
NISSAN	NV400	2011	Sonar	Read Fault Code	
NISSAN	NV400	2011	Sonar	Clear Fault Code	
NISSAN	NV400	2011	Sonar	Read Data Stream	
NISSAN	NV400	2011	Sonar	Module Information	
NISSAN	NV400	2011	Sonar	Actuation Test	REAR PROXIMITY SENSOR TEST
NISSAN	NV400	2011	Sonar	Special Function	Vin Registration
NISSAN	NV400	2011	Sonar	Special Function	Caravan Towing Distance
NISSAN	All Mode	2006 - 2009	Sonar	Read Fault Code	
NISSAN	All Mode	2006 - 2009	Sonar	Clear Fault Code	
NISSAN	All Mode	2006 - 2009	Sonar	Read Data Stream	
NISSAN	All Mode	2006 - 2009	Sonar	Module Information	
NISSAN	All Mode	2006 - 2009	Sonar	Special Function	Vin Registration
NISSAN	All Mode	Up to 2017	Lane Camera	Read Fault Code	
NISSAN	All Mode	Up to 2017	Lane Camera	Clear Fault Code	
NISSAN	All Mode	Up to 2017	Lane Camera	Read Data Stream	
NISSAN	All Mode	Up to 2017	Lane Camera	Module Information	

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
NISSAN	All Mode	Up to 2017	Lane Camera	Actuation Test	BUZZER DRIVE
NISSAN	All Mode	Up to 2017	Lane Camera	Actuation Test	SYSTEM ON LAMP DRIVE
NISSAN	All Mode	Up to 2017	Lane Camera	Actuation Test	INDICATOR LAMP DRIVE
NISSAN	All Mode	Up to 2017	Lane Camera	Special Function	AUTO AIM
NISSAN	All Mode	2008 - 2017	Lane Camera	Read Fault Code	
NISSAN	All Mode	2008 - 2017	Lane Camera	Clear Fault Code	
NISSAN	All Mode	2008 - 2017	Lane Camera	Read Data Stream	
NISSAN	All Mode	2008 - 2017	Lane Camera	Module Information	
NISSAN	All Mode	2008 - 2017	Lane Camera	Actuation Test	BUZZER DRIVE
NISSAN	All Mode	2008 - 2017	Lane Camera	Actuation Test	LDW ON IND
NISSAN	All Mode	2008 - 2017	Lane Camera	Actuation Test	LANE DEPARTURE W/L
NISSAN	All Mode	2008 - 2017	Lane Camera	Actuation Test	LDP ON IND
NISSAN	All Mode	2008 - 2017	Lane Camera	Special Function	AUTO AIM
NISSAN	All Mode	2008 - 2017	Lane Camera	Special Function	Aim Check
NISSAN	All Mode	2008 - 2017	Lane Camera	Special Function	Cause Of Auto-Cancel
NISSAN	All Mode	2009 - 2017	Lane Camera	Read Fault Code	
NISSAN	All Mode	2009 - 2017	Lane Camera	Clear Fault Code	
NISSAN	All Mode	2009 - 2017	Lane Camera	Read Data Stream	
NISSAN	All Mode	2009 - 2017	Lane Camera	Module Information	
NISSAN	All Mode	2009 - 2017	Lane Camera	Actuation Test	LDP ON IND
NISSAN	All Mode	2009 - 2017	Lane Camera	Actuation Test	LANE DEPARTURE W/L
NISSAN	All Mode	2009 - 2017	Lane Camera	Actuation Test	LDW ON IND
NISSAN	All Mode	2009 - 2017	Lane Camera	Actuation Test	BUZZER DRIVE
NISSAN	All Mode	2009 - 2017	Lane Camera	Special Function	AUTO AIM
NISSAN	All Mode	2009 - 2017	Lane Camera	Special Function	Aim Check
NISSAN	All Mode	2009 - 2017	Lane Camera	Special Function	Cause Of Auto-Cancel
NISSAN	All Mode	2013 - 2018	Lane Camera	Read Fault Code	
NISSAN	All Mode	2013 - 2018	Lane Camera	Clear Fault Code	
NISSAN	All Mode	2013 - 2018	Lane Camera	Read Data Stream	
NISSAN	All Mode	2013 - 2018	Lane Camera	Module Information	
NISSAN	All Mode	2013 - 2018	Lane Camera	Special Function	AUTO AIM
NISSAN	SYLPHY	2009	Lane Camera	Read Fault Code	
NISSAN	SYLPHY	2009	Lane Camera	Clear Fault Code	
NISSAN	SYLPHY	2009	Lane Camera	Read Data Stream	
NISSAN	SYLPHY	2009	Lane Camera	Module Information	
NISSAN	NV400	2014	Lane Camera	Read Fault Code	
NISSAN	NV400	2014	Lane Camera	Clear Fault Code	
NISSAN	NV400	2014	Lane Camera	Read Data Stream	
NISSAN	NV400	2014	Lane Camera	Module Information	
NISSAN	NV400	2014	Lane Camera	Special Function	Vin Registration
NISSAN	NV400	2014	Lane Camera	Special Function	Ecu Memory
NISSAN	SYLPHY	2009	Lane Camera	Read Fault Code	
NISSAN	SYLPHY	2009	Lane Camera	Clear Fault Code	
NISSAN	SYLPHY	2009	Lane Camera	Read Data Stream	
NISSAN	SYLPHY	2009	Lane Camera	Module Information	
NISSAN	SYLPHY	2009	Lane Camera	Special Function	AUTO AIM
NISSAN	SYLPHY	2009	Lane Camera	Special Function	Aim Check
NISSAN	All Mode	Up to 2011	Lane Camera	Read Fault Code	
NISSAN	All Mode	Up to 2011	Lane Camera	Clear Fault Code	
NISSAN	All Mode	Up to 2011	Lane Camera	Read Data Stream	
NISSAN	All Mode	Up to 2011	Lane Camera	Module Information	
NISSAN	All Mode	2004 - 2018	AFS (Adaptive Front Lighting System)	Read Fault Code	
NISSAN	All Mode	2004 - 2018	AFS (Adaptive Front Lighting System)	Clear Fault Code	
NISSAN	All Mode	2004 - 2018	AFS (Adaptive Front Lighting System)	Read Data Stream	
NISSAN	All Mode	2004 - 2018	AFS (Adaptive Front Lighting System)	Module Information	
NISSAN	All Mode	2004 - 2018	AFS (Adaptive Front Lighting System)	Actuation Test	LOW BEAM TEST RIGHT
NISSAN	All Mode	2004 - 2018	AFS (Adaptive Front Lighting System)	Actuation Test	LOW BEAM TEST LEFT
NISSAN	All Mode	2004 - 2018	AFS (Adaptive Front Lighting System)	Actuation Test	LEVELIZER TEST
NISSAN	All Mode	2004 - 2018	AFS (Adaptive Front Lighting System)	Special Function	ST ANG Sen Adjustment
NISSAN	All Mode	2004 - 2018	AFS (Adaptive Front Lighting System)	Special Function	Levelizer Adjustment
NISSAN	All Mode	2002 - 2016	AFS (Adaptive Front Lighting System)	Read Fault Code	
NISSAN	All Mode	2002 - 2016	AFS (Adaptive Front Lighting System)	Clear Fault Code	
NISSAN	All Mode	2002 - 2016	AFS (Adaptive Front Lighting System)	Read Data Stream	
NISSAN	All Mode	2002 - 2016	AFS (Adaptive Front Lighting System)	Module Information	
NISSAN	All Mode	2002 - 2016	AFS (Adaptive Front Lighting System)	Actuation Test	Low Beam Test Right
NISSAN	All Mode	2002 - 2016	AFS (Adaptive Front Lighting System)	Actuation Test	LOW BEAM TEST LEFT
NISSAN	All Mode	2002 - 2016	AFS (Adaptive Front Lighting System)	Special Function	ST ANG Sen Adjustment
NISSAN	All Mode	2002 - 2018	AFS (Adaptive Front Lighting System)	Read Fault Code	
NISSAN	All Mode	2002 - 2018	AFS (Adaptive Front Lighting System)	Clear Fault Code	
NISSAN	All Mode	2002 - 2018	AFS (Adaptive Front Lighting System)	Read Data Stream	
NISSAN	All Mode	2002 - 2018	AFS (Adaptive Front Lighting System)	Module Information	
NISSAN	All Mode	2002 - 2018	AFS (Adaptive Front Lighting System)	Actuation Test	LOW BEAM TEST RIGHT
NISSAN	All Mode	2002 - 2018	AFS (Adaptive Front Lighting System)	Actuation Test	LOW BEAM TEST LEFT
NISSAN	All Mode	2002 - 2018	AFS (Adaptive Front Lighting System)	Actuation Test	LEVELIZER TEST
NISSAN	All Mode	2002 - 2018	AFS (Adaptive Front Lighting System)	Special Function	ST ANG Sen Adjustment
NISSAN	All Mode	2002 - 2018	AFS (Adaptive Front Lighting System)	Special Function	Levelizer Adjustment
NISSAN	All Mode	Up to 2011	AFS (Adaptive Front Lighting System)	Read Fault Code	
NISSAN	All Mode	Up to 2011	AFS (Adaptive Front Lighting System)	Clear Fault Code	
NISSAN	All Mode	Up to 2011	AFS (Adaptive Front Lighting System)	Read Data Stream	
NISSAN	All Mode	Up to 2011	AFS (Adaptive Front Lighting System)	Module Information	

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

<b>make</b>	<b>model</b>	<b>year</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
NISSAN	All Mode	Up to 2011	AFS (Adaptive Front Lighting System)	Special Function	ST ANG Sen Adjustment
NISSAN	All Mode	2013 - 2017	AFS (Adaptive Front Lighting System)	Read Fault Code	
NISSAN	All Mode	2013 - 2017	AFS (Adaptive Front Lighting System)	Clear Fault Code	
NISSAN	All Mode	2013 - 2017	AFS (Adaptive Front Lighting System)	Read Data Stream	
NISSAN	All Mode	2013 - 2017	AFS (Adaptive Front Lighting System)	Module Information	
NISSAN	All Mode	2005 - 2015	Auto Slide Door Right	Read Fault Code	
NISSAN	All Mode	2005 - 2015	Auto Slide Door Right	Clear Fault Code	
NISSAN	All Mode	2005 - 2015	Auto Slide Door Right	Read Data Stream	
NISSAN	All Mode	2005 - 2015	Auto Slide Door Right	Module Information	
NISSAN	All Mode	2010 - 2017	Auto Slide Door Right	Read Fault Code	
NISSAN	All Mode	2010 - 2017	Auto Slide Door Right	Clear Fault Code	
NISSAN	All Mode	2010 - 2017	Auto Slide Door Right	Read Data Stream	
NISSAN	All Mode	2010 - 2017	Auto Slide Door Right	Read Freeze Frame	
NISSAN	All Mode	2010 - 2017	Auto Slide Door Right	Module Information	
NISSAN	All Mode	2010 - 2017	Auto Slide Door Right	Actuation Test	CLUTCH
NISSAN	All Mode	2016 - 2017	Auto Slide Door Right	Read Fault Code	
NISSAN	All Mode	2016 - 2017	Auto Slide Door Right	Clear Fault Code	
NISSAN	All Mode	2016 - 2017	Auto Slide Door Right	Read Data Stream	
NISSAN	All Mode	2016 - 2017	Auto Slide Door Right	Module Information	
NISSAN	All Mode	2016 - 2017	Auto Slide Door Right	Special Function	Hands free sensor parts number
NISSAN	All Mode	2008 - 2017	CAN Gateway	Read Fault Code	
NISSAN	All Mode	2008 - 2017	CAN Gateway	Clear Fault Code	
NISSAN	All Mode	2008 - 2017	CAN Gateway	Read Freeze Frame	
NISSAN	All Mode	2008 - 2017	CAN Gateway	Module Information	
NISSAN	All Mode	2013 - 2017	CAN Gateway	Read Fault Code	
NISSAN	All Mode	2013 - 2017	CAN Gateway	Clear Fault Code	
NISSAN	All Mode	2013 - 2017	CAN Gateway	Read Data Stream	
NISSAN	All Mode	2013 - 2017	CAN Gateway	Module Information	
NISSAN	All Mode	2015 - 2018	CAN Gateway	Read Fault Code	
NISSAN	All Mode	2015 - 2018	CAN Gateway	Clear Fault Code	
NISSAN	All Mode	2015 - 2018	CAN Gateway	Read Data Stream	
NISSAN	All Mode	2015 - 2018	CAN Gateway	Module Information	
NISSAN	All Mode	2010 - 2017	Shift	Read Fault Code	
NISSAN	All Mode	2010 - 2017	Shift	Clear Fault Code	
NISSAN	All Mode	2010 - 2017	Shift	Read Data Stream	
NISSAN	All Mode	2010 - 2017	Shift	Read Freeze Frame	
NISSAN	All Mode	2010 - 2017	Shift	Module Information	
NISSAN	All Mode	2010 - 2017	Shift	Special Function	P Position Learning Value Clear
NISSAN	All Mode	2015 - 2018	Shift	Read Fault Code	
NISSAN	All Mode	2015 - 2018	Shift	Clear Fault Code	
NISSAN	All Mode	2015 - 2018	Shift	Read Data Stream	
NISSAN	All Mode	2015 - 2018	Shift	Module Information	
NISSAN	All Mode	2015 - 2016	Shift	Read Fault Code	
NISSAN	All Mode	2015 - 2016	Shift	Clear Fault Code	
NISSAN	All Mode	2015 - 2016	Shift	Read Data Stream	
NISSAN	All Mode	2015 - 2016	Shift	Module Information	
NISSAN	All Mode	2015 - 2016	Shift	Special Function	P Position Learning Value Clear
NISSAN	All Mode	As of 2012	Shift	Read Fault Code	
NISSAN	All Mode	As of 2012	Shift	Clear Fault Code	
NISSAN	All Mode	As of 2012	Shift	Read Data Stream	
NISSAN	All Mode	As of 2012	Shift	Module Information	
NISSAN	All Mode	As of 2012	Shift	Special Function	P Position Learning Value Clear
NISSAN	ALTIMA Hybrid	2007	EV/HEV	Read Fault Code	
NISSAN	ALTIMA Hybrid	2007	EV/HEV	Clear Fault Code	
NISSAN	ALTIMA Hybrid	2007	EV/HEV	Read Data Stream	
NISSAN	ALTIMA Hybrid	2007	EV/HEV	Module Information	
NISSAN	ALTIMA Hybrid	2007	EV/HEV	Actuation Test	Inspection Mode 1
NISSAN	ALTIMA Hybrid	2007	EV/HEV	Actuation Test	Inspection Mode 2
NISSAN	ALTIMA Hybrid	2007	EV/HEV	Actuation Test	Compression Test
NISSAN	ALTIMA Hybrid	2007	EV/HEV	Actuation Test	COOLING FAN SPD
NISSAN	ALTIMA Hybrid	2007	EV/HEV	Actuation Test	DC/DC CONVERTER
NISSAN	ALTIMA Hybrid	2007	EV/HEV	Actuation Test	INV WATER PUMP
NISSAN	All Mode	2010 - 2017	EV/HEV	Read Fault Code	
NISSAN	All Mode	2010 - 2017	EV/HEV	Clear Fault Code	
NISSAN	All Mode	2010 - 2017	EV/HEV	Read Data Stream	
NISSAN	All Mode	2010 - 2017	EV/HEV	Module Information	
NISSAN	All Mode	2010 - 2017	EV/HEV	Actuation Test	PLUG IN INDICATOR
NISSAN	All Mode	2010 - 2017	EV/HEV	Actuation Test	CHARGE STAT INDICATOR 1
NISSAN	All Mode	2010 - 2017	EV/HEV	Actuation Test	CHARGE STAT INDICATOR 2
NISSAN	All Mode	2010 - 2017	EV/HEV	Actuation Test	CHARGE STAT INDICATOR 3
NISSAN	All Mode	2010 - 2017	EV/HEV	Actuation Test	F/S CHG RLY
NISSAN	All Mode	2010 - 2017	EV/HEV	Actuation Test	REVERSE LAMP RLY
NISSAN	All Mode	2010 - 2017	EV/HEV	Actuation Test	VOLTAGE CONTROL
NISSAN	All Mode	2010 - 2017	EV/HEV	Actuation Test	READY INDICATOR
NISSAN	All Mode	2010 - 2017	EV/HEV	Actuation Test	POWER LIMITATION INDICATOR
NISSAN	All Mode	2010 - 2017	EV/HEV	Actuation Test	EV SYSTEM W/L

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
NISSAN	All Mode	2010 - 2017	EV/HEV	Actuation Test	12 Battery Charge W/L
NISSAN	All Mode	2010 - 2017	EV/HEV	Special Function	HV Batt J/B Data Clear
NISSAN	All Mode	2010 - 2017	EV/HEV	Special Function	Specific Dtc Clear
NISSAN	All Mode	2010 - 2017	EV/HEV	Special Function	Vin Registration
NISSAN	All Mode	2010 - 2017	EV/HEV	Special Function	Saving Data For Replc CPU
NISSAN	All Mode	2010 - 2017	EV/HEV	Special Function	Write Data After Replace CPU
NISSAN	All Mode	2010 - 2017	EV/HEV	Special Function	Battery Gradual Cap Loss Data Clear
NISSAN	All Mode	2013 - 2018	EV/HEV	Read Fault Code	
NISSAN	All Mode	2013 - 2018	EV/HEV	Clear Fault Code	
NISSAN	All Mode	2013 - 2018	EV/HEV	Read Data Stream	
NISSAN	All Mode	2013 - 2018	EV/HEV	Module Information	
NISSAN	All Mode	2013 - 2018	EV/HEV	Actuation Test	Inspection Mode 5
NISSAN	All Mode	2013 - 2018	EV/HEV	Actuation Test	Inspection Mode 2
NISSAN	All Mode	2013 - 2018	EV/HEV	Actuation Test	Engine Cranking
NISSAN	All Mode	2013 - 2018	EV/HEV	Actuation Test	WATER PUMP
NISSAN	All Mode	2013 - 2018	EV/HEV	Actuation Test	Inspection Mode 3
NISSAN	All Mode	2013 - 2018	EV/HEV	Actuation Test	VOLTAGE CONTROL
NISSAN	All Mode	2013 - 2018	EV/HEV	Actuation Test	Inspection Mode 1
NISSAN	All Mode	2013 - 2018	EV/HEV	Special Function	Clutch 1 Position Learning
NISSAN	Note e-POWER	2016	EV/HEV	Read Fault Code	
NISSAN	Note e-POWER	2016	EV/HEV	Clear Fault Code	
NISSAN	Note e-POWER	2016	EV/HEV	Read Data Stream	
NISSAN	Note e-POWER	2016	EV/HEV	Module Information	
NISSAN	Note e-POWER	2016	EV/HEV	Actuation Test	REVERSE LAMP RLY
NISSAN	Note e-POWER	2016	EV/HEV	Actuation Test	(TBD)STOP LAMP RLY
NISSAN	Note e-POWER	2016	EV/HEV	Actuation Test	DC/DC CONV DUTY
NISSAN	Note e-POWER	2016	EV/HEV	Actuation Test	VOLTAGE CONTROL
NISSAN	Note e-POWER	2016	EV/HEV	Actuation Test	READY INDICATOR
NISSAN	Note e-POWER	2016	EV/HEV	Actuation Test	POWER LIMITATION INDICATOR
NISSAN	Note e-POWER	2016	EV/HEV	Actuation Test	EV SYSTEM W/L
NISSAN	Note e-POWER	2016	EV/HEV	Actuation Test	12 Battery Charge W/L
NISSAN	Note e-POWER	2016	EV/HEV	Actuation Test	(TBD)External Charge Req
NISSAN	Note e-POWER	2016	EV/HEV	Actuation Test	(TBD)Emergency Cranking Req
NISSAN	Note e-POWER	2016	EV/HEV	Actuation Test	(TBD)Maintenance Mode request
NISSAN	Note e-POWER	2016	EV/HEV	Actuation Test	Water Pump 1
NISSAN	Note e-POWER	2016	EV/HEV	Special Function	Saving Data For Replc CPU
NISSAN	Note e-POWER	2016	EV/HEV	Special Function	Writing Data For Replc CPU
NISSAN	Note e-POWER	2016	EV/HEV	Special Function	HV Batt J/B Data Clear
NISSAN	Note e-POWER	2016	EV/HEV	Special Function	Vin Registration
NISSAN	Note e-POWER	2016	EV/HEV	Special Function	Specific Dtc Clear
NISSAN	Note e-POWER	2016	EV/HEV	Special Function	Cooling Fan Integrated Operation Time Clear
NISSAN	LEAF	2016	EV/HEV	Read Fault Code	
NISSAN	LEAF	2016	EV/HEV	Clear Fault Code	
NISSAN	LEAF	2016	EV/HEV	Read Data Stream	
NISSAN	LEAF	2016	EV/HEV	Module Information	
NISSAN	LEAF	2016	EV/HEV	Special Function	Battery Gradual Cap Loss Data Clear
NISSAN	LEAF	2016	EV/HEV	Special Function	HV Batt J/B Data Clear
NISSAN	LEAF	2016	EV/HEV	Special Function	Vin Registration
NISSAN	LEAF	2016	EV/HEV	Special Function	Specific Dtc Clear
NISSAN	LEAF	2016	EV/HEV	Special Function	Saving Data For Replc CPU
NISSAN	LEAF	2016	EV/HEV	Special Function	Writing Data For Replc CPU
NISSAN	All Mode	2013 - 2018	POP UP HOOD	Read Fault Code	
NISSAN	All Mode	2013 - 2018	POP UP HOOD	Clear Fault Code	
NISSAN	All Mode	2013 - 2018	POP UP HOOD	Read Data Stream	
NISSAN	All Mode	2013 - 2018	POP UP HOOD	Module Information	
NISSAN	All Mode	2013 - 2018	POP UP HOOD	Special Function	Cause of Warning Lamp
NISSAN	All Mode	2007 - 2018	POP UP HOOD	Read Fault Code	
NISSAN	All Mode	2007 - 2018	POP UP HOOD	Clear Fault Code	
NISSAN	All Mode	2007 - 2018	POP UP HOOD	Module Information	
NISSAN	All Mode	Up to 2018	SRS (Supplemental Inflatable Restraint System)	Read Fault Code	
NISSAN	All Mode	Up to 2018	SRS (Supplemental Inflatable Restraint System)	Clear Fault Code	
NISSAN	All Mode	Up to 2018	SRS (Supplemental Inflatable Restraint System)	Read Data Stream	
NISSAN	All Mode	Up to 2018	SRS (Supplemental Inflatable Restraint System)	Module Information	
NISSAN	All Mode	Up to 2018	SRS (Supplemental Inflatable Restraint System)	Function Test	
NISSAN	All Mode	Up to 2018	SRS (Supplemental Inflatable Restraint System)	Special Function	SELF-DIAG[ETC]
NISSAN	All Mode	Up to 2018	SRS (Supplemental Inflatable Restraint System)	Special Function	Trouble Diag Record
NISSAN	All Mode	Up to 2018	SRS (Supplemental Inflatable Restraint System)	Special Function	Cause Of Warning
NISSAN	All Mode	Up to 2018	SRS (Supplemental Inflatable Restraint System)	Special Function	SELF-DIAG[PAST]
NISSAN	NV400	2011	SRS (Supplemental Inflatable Restraint System)	Read Fault Code	
NISSAN	NV400	2011	SRS (Supplemental Inflatable Restraint System)	Clear Fault Code	
NISSAN	NV400	2011	SRS (Supplemental Inflatable Restraint System)	Read Data Stream	
NISSAN	NV400	2011	SRS (Supplemental Inflatable Restraint System)	Module Information	
NISSAN	NV400	2011	SRS (Supplemental Inflatable Restraint System)	Special Function	Vin Registration
NISSAN	NV400	2011	SRS (Supplemental Inflatable Restraint System)	Special Function	Lock Computer
NISSAN	NV400	2011	SRS (Supplemental Inflatable Restraint System)	Special Function	Unlock Computer

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

<b>make</b>	<b>model</b>	<b>year</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
NISSAN	NV400	2011	SRS (Supplemental Inflatable Restraint System)	Special Function	Reading Impact Contexts
NISSAN	NV400	2011	SRS (Supplemental Inflatable Restraint System)	Special Function	Configuration Of System Components
NISSAN	All Mode	2010 - 2018	SRS (Supplemental Inflatable Restraint System)	Read Fault Code	
NISSAN	All Mode	2010 - 2018	SRS (Supplemental Inflatable Restraint System)	Clear Fault Code	
NISSAN	All Mode	2010 - 2018	SRS (Supplemental Inflatable Restraint System)	Read Data Stream	
NISSAN	All Mode	2010 - 2018	SRS (Supplemental Inflatable Restraint System)	Module Information	
NISSAN	All Mode	2010 - 2018	SRS (Supplemental Inflatable Restraint System)	Special Function	Trouble Diag Record
NISSAN	All Mode	2010 - 2018	SRS (Supplemental Inflatable Restraint System)	Special Function	Cause Of Warning
NISSAN	All Mode	2010 - 2018	SRS (Supplemental Inflatable Restraint System)	Special Function	SELF-DIAG[PAST]
NISSAN	All Mode	2010 - 2018	SRS (Supplemental Inflatable Restraint System)	Read Fault Code	
NISSAN	All Mode	2010 - 2018	SRS (Supplemental Inflatable Restraint System)	Clear Fault Code	
NISSAN	All Mode	2010 - 2018	SRS (Supplemental Inflatable Restraint System)	Read Data Stream	
NISSAN	All Mode	2010 - 2018	SRS (Supplemental Inflatable Restraint System)	Module Information	
NISSAN	All Mode	2011 - 2017	SRS (Supplemental Inflatable Restraint System)	Read Fault Code	
NISSAN	All Mode	2011 - 2017	SRS (Supplemental Inflatable Restraint System)	Clear Fault Code	
NISSAN	All Mode	2011 - 2017	SRS (Supplemental Inflatable Restraint System)	Read Data Stream	
NISSAN	All Mode	2011 - 2017	SRS (Supplemental Inflatable Restraint System)	Module Information	
NISSAN	All Mode	2015 - 2017	SRS (Supplemental Inflatable Restraint System)	Read Fault Code	
NISSAN	All Mode	2015 - 2017	SRS (Supplemental Inflatable Restraint System)	Clear Fault Code	
NISSAN	All Mode	2015 - 2017	SRS (Supplemental Inflatable Restraint System)	Read Data Stream	
NISSAN	All Mode	2015 - 2017	SRS (Supplemental Inflatable Restraint System)	Module Information	
NISSAN	All Mode	2015 - 2017	SRS (Supplemental Inflatable Restraint System)	Actuation Test	Pass Air Bag Fault And Status Warning Lights
NISSAN	All Mode	2015 - 2017	SRS (Supplemental Inflatable Restraint System)	Special Function	Vin Registration
NISSAN	All Mode	2015 - 2017	SRS (Supplemental Inflatable Restraint System)	Special Function	Lock Computer
NISSAN	All Mode	2015 - 2017	SRS (Supplemental Inflatable Restraint System)	Special Function	Unlock Computer
NISSAN	All Mode	2015 - 2017	SRS (Supplemental Inflatable Restraint System)	Special Function	Reading Impact Contexts
NISSAN	All Mode	2015 - 2017	SRS (Supplemental Inflatable Restraint System)	Special Function	Sensor Configuration
NISSAN	All Mode	2015 - 2017	SRS (Supplemental Inflatable Restraint System)	Special Function	Configuration Of System Components
NISSAN	All Mode	2015 - 2017	SRS (Supplemental Inflatable Restraint System)	Special Function	Trigger Line Config
NISSAN	All Mode	2015 - 2018	SRS (Supplemental Inflatable Restraint System)	Read Fault Code	
NISSAN	All Mode	2015 - 2018	SRS (Supplemental Inflatable Restraint System)	Clear Fault Code	
NISSAN	All Mode	2015 - 2018	SRS (Supplemental Inflatable Restraint System)	Read Data Stream	
NISSAN	All Mode	2015 - 2018	SRS (Supplemental Inflatable Restraint System)	Module Information	
NISSAN	All Mode	2015 - 2018	SRS (Supplemental Inflatable Restraint System)	Special Function	LOCK ECU
NISSAN	All Mode	2016 - 2017	SRS (Supplemental Inflatable Restraint System)	Read Fault Code	
NISSAN	All Mode	2016 - 2017	SRS (Supplemental Inflatable Restraint System)	Clear Fault Code	
NISSAN	All Mode	2016 - 2017	SRS (Supplemental Inflatable Restraint System)	Read Data Stream	
NISSAN	All Mode	2016 - 2017	SRS (Supplemental Inflatable Restraint System)	Module Information	
NISSAN	DATSUN GO	2014	SRS (Supplemental Inflatable Restraint System)	Read Fault Code	
NISSAN	DATSUN GO	2014	SRS (Supplemental Inflatable Restraint System)	Clear Fault Code	
NISSAN	DATSUN GO	2014	SRS (Supplemental Inflatable Restraint System)	Module Information	
NISSAN	All Mode	2016 - 2017	SRS (Supplemental Inflatable Restraint System)	Read Fault Code	
NISSAN	All Mode	2016 - 2017	SRS (Supplemental Inflatable Restraint System)	Clear Fault Code	
NISSAN	All Mode	2016 - 2017	SRS (Supplemental Inflatable Restraint System)	Read Data Stream	
NISSAN	All Mode	2016 - 2017	SRS (Supplemental Inflatable Restraint System)	Module Information	
NISSAN	All Mode	2016 - 2017	SRS (Supplemental Inflatable Restraint System)	Special Function	(TBD)Lock/Unlock for firing
NISSAN	All Mode	As of 2012	SRS (Supplemental Inflatable Restraint System)	Read Fault Code	
NISSAN	All Mode	As of 2012	SRS (Supplemental Inflatable Restraint System)	Clear Fault Code	
NISSAN	All Mode	As of 2012	SRS (Supplemental Inflatable Restraint System)	Read Data Stream	
NISSAN	All Mode	As of 2012	SRS (Supplemental Inflatable Restraint System)	Module Information	
NISSAN	All Mode	2014 - 2017	SRS (Supplemental Inflatable Restraint System)	Read Fault Code	
NISSAN	All Mode	2014 - 2017	SRS (Supplemental Inflatable Restraint System)	Clear Fault Code	
NISSAN	All Mode	2014 - 2017	SRS (Supplemental Inflatable Restraint System)	Read Data Stream	
NISSAN	All Mode	2014 - 2017	SRS (Supplemental Inflatable Restraint System)	Module Information	
NISSAN	All Mode	Up to 2017	SRS (Supplemental Inflatable Restraint System)	Read Fault Code	
NISSAN	All Mode	Up to 2017	SRS (Supplemental Inflatable Restraint System)	Clear Fault Code	
NISSAN	All Mode	Up to 2017	SRS (Supplemental Inflatable Restraint System)	Read Data Stream	
NISSAN	All Mode	Up to 2017	SRS (Supplemental Inflatable Restraint System)	Module Information	
NISSAN	SUNNY	2006	SRS (Supplemental Inflatable Restraint System)	Read Fault Code	
NISSAN	SUNNY	2006	SRS (Supplemental Inflatable Restraint System)	Clear Fault Code	
NISSAN	SUNNY	2006	SRS (Supplemental Inflatable Restraint System)	Read Data Stream	
NISSAN	SUNNY	2006	SRS (Supplemental Inflatable Restraint System)	Module Information	
NISSAN	SUNNY	2006	SRS (Supplemental Inflatable Restraint System)	Special Function	Lock Computer
NISSAN	SUNNY	2006	SRS (Supplemental Inflatable Restraint System)	Special Function	Unlock Computer
NISSAN	All Mode	2006 - 2009	SRS (Supplemental Inflatable Restraint System)	Read Fault Code	
NISSAN	All Mode	2006 - 2009	SRS (Supplemental Inflatable Restraint System)	Clear Fault Code	
NISSAN	All Mode	2006 - 2009	SRS (Supplemental Inflatable Restraint System)	Read Data Stream	
NISSAN	All Mode	2006 - 2009	SRS (Supplemental Inflatable Restraint System)	Module Information	
NISSAN	All Mode	2006 - 2009	SRS (Supplemental Inflatable Restraint System)	Special Function	Lock Computer
NISSAN	All Mode	2006 - 2009	SRS (Supplemental Inflatable Restraint System)	Special Function	Unlock Computer
NISSAN	All Mode	2006 - 2009	SRS (Supplemental Inflatable Restraint System)	Special Function	Write date of last after sales OPE
NISSAN	All Mode	2006 - 2009	SRS (Supplemental Inflatable Restraint System)	Special Function	Vin Registration
NISSAN	All Mode	2006 - 2009	SRS (Supplemental Inflatable Restraint System)	Special Function	Reading Impact Contexts
NISSAN	All Mode	2006 - 2009	SRS (Supplemental Inflatable Restraint System)	Read Fault Code	
NISSAN	All Mode	2006 - 2009	SRS (Supplemental Inflatable Restraint System)	Clear Fault Code	
NISSAN	All Mode	2006 - 2009	SRS (Supplemental Inflatable Restraint System)	Read Data Stream	

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
NISSAN	All Mode	2006 - 2009	SRS (Supplemental Inflatable Restraint System)	Module Information	
NISSAN	All Mode	2006 - 2009	SRS (Supplemental Inflatable Restraint System)	Special Function	Lock Computer
NISSAN	All Mode	2006 - 2009	SRS (Supplemental Inflatable Restraint System)	Special Function	Unlock Computer
NISSAN	All Mode	2006 - 2009	SRS (Supplemental Inflatable Restraint System)	Special Function	Write date of last after sales OPE
NISSAN	All Mode	2006 - 2009	SRS (Supplemental Inflatable Restraint System)	Special Function	Vin Registration
NISSAN	All Mode	2006 - 2009	SRS (Supplemental Inflatable Restraint System)	Special Function	Reading Impact Contexts
NISSAN	All Mode	2008 - 2017	SRS (Supplemental Inflatable Restraint System)	Read Fault Code	
NISSAN	All Mode	2008 - 2017	SRS (Supplemental Inflatable Restraint System)	Clear Fault Code	
NISSAN	All Mode	2008 - 2017	SRS (Supplemental Inflatable Restraint System)	Read Data Stream	
NISSAN	All Mode	2008 - 2017	SRS (Supplemental Inflatable Restraint System)	Module Information	
NISSAN	All Mode	2008 - 2017	SRS (Supplemental Inflatable Restraint System)	Special Function	Lock Computer
NISSAN	All Mode	2008 - 2017	SRS (Supplemental Inflatable Restraint System)	Special Function	Unlock Computer
NISSAN	All Mode	2008 - 2017	SRS (Supplemental Inflatable Restraint System)	Special Function	Vin Registration
NISSAN	All Mode	2008 - 2017	SRS (Supplemental Inflatable Restraint System)	Special Function	Reading Impact Contexts
NISSAN	All Mode	Up to 2016	SRS (Supplemental Inflatable Restraint System)	Read Fault Code	
NISSAN	All Mode	Up to 2016	SRS (Supplemental Inflatable Restraint System)	Clear Fault Code	
NISSAN	All Mode	Up to 2016	SRS (Supplemental Inflatable Restraint System)	Read Data Stream	
NISSAN	All Mode	Up to 2016	SRS (Supplemental Inflatable Restraint System)	Module Information	
NISSAN	All Mode	Up to 2016	SRS (Supplemental Inflatable Restraint System)	Read Fault Code	
NISSAN	All Mode	Up to 2016	SRS (Supplemental Inflatable Restraint System)	Clear Fault Code	
NISSAN	All Mode	Up to 2016	SRS (Supplemental Inflatable Restraint System)	Read Data Stream	
NISSAN	All Mode	Up to 2016	SRS (Supplemental Inflatable Restraint System)	Module Information	
NISSAN	All Mode	Up to 2016	SRS (Supplemental Inflatable Restraint System)	Read Fault Code	
NISSAN	All Mode	Up to 2016	SRS (Supplemental Inflatable Restraint System)	Clear Fault Code	
NISSAN	All Mode	Up to 2016	SRS (Supplemental Inflatable Restraint System)	Read Data Stream	
NISSAN	All Mode	Up to 2016	SRS (Supplemental Inflatable Restraint System)	Module Information	
NISSAN	All Mode	Up to 2016	SRS (Supplemental Inflatable Restraint System)	Read Fault Code	
NISSAN	All Mode	Up to 2016	SRS (Supplemental Inflatable Restraint System)	Clear Fault Code	
NISSAN	All Mode	Up to 2016	SRS (Supplemental Inflatable Restraint System)	Read Data Stream	
NISSAN	All Mode	Up to 2016	SRS (Supplemental Inflatable Restraint System)	Module Information	
NISSAN	All Mode	2007 - 2017	Auto Back Door	Read Fault Code	
NISSAN	All Mode	2007 - 2017	Auto Back Door	Clear Fault Code	
NISSAN	All Mode	2007 - 2017	Auto Back Door	Read Data Stream	
NISSAN	All Mode	2007 - 2017	Auto Back Door	Module Information	
NISSAN	All Mode	2010 - 2017	Auto Back Door	Read Fault Code	
NISSAN	All Mode	2010 - 2017	Auto Back Door	Clear Fault Code	
NISSAN	All Mode	2010 - 2017	Auto Back Door	Read Data Stream	
NISSAN	All Mode	2010 - 2017	Auto Back Door	Module Information	
NISSAN	All Mode	2010 - 2017	Auto Back Door	Special Function	Reset Auto Back Door Status
NISSAN	All Mode	2014 - 2017	Auto Back Door	Read Fault Code	
NISSAN	All Mode	2014 - 2017	Auto Back Door	Clear Fault Code	
NISSAN	All Mode	2014 - 2017	Auto Back Door	Read Data Stream	
NISSAN	All Mode	2014 - 2017	Auto Back Door	Module Information	
NISSAN	All Mode	2014 - 2017	Auto Back Door	Special Function	Reset Auto Back Door Status
NISSAN	All Mode	2006 - 2017	4WAS(Front)	Read Fault Code	
NISSAN	All Mode	2006 - 2017	4WAS(Front)	Clear Fault Code	
NISSAN	All Mode	2006 - 2017	4WAS(Front)	Read Data Stream	
NISSAN	All Mode	2006 - 2017	4WAS(Front)	Read Freeze Frame	
NISSAN	All Mode	2006 - 2017	4WAS(Front)	Module Information	
NISSAN	All Mode	2006 - 2017	4WAS(Front)	Actuation Test	LOCK OPERATION
NISSAN	All Mode	2006 - 2017	4WAS(Front)	Actuation Test	SLOW MODE
NISSAN	All Mode	2006 - 2009	Cluster	Read Fault Code	
NISSAN	All Mode	2006 - 2009	Cluster	Clear Fault Code	
NISSAN	All Mode	2006 - 2009	Cluster	Read Data Stream	
NISSAN	All Mode	2006 - 2009	Cluster	Module Information	
NISSAN	All Mode	2006 - 2009	Cluster	Actuation Test	Instrument Panel Needles
NISSAN	All Mode	2006 - 2009	Cluster	Actuation Test	Instrument Panel Warning Lights
NISSAN	All Mode	2006 - 2009	Cluster	Actuation Test	DISPLAY
NISSAN	All Mode	2006 - 2009	Cluster	Actuation Test	BUZZER
NISSAN	All Mode	2006 - 2009	Cluster	Special Function	FUEL GAUGE CALIBRATION
NISSAN	All Mode	2006 - 2009	Cluster	Special Function	Vin Registration
NISSAN	All Mode	2006 - 2009	Cluster	Special Function	BACKUP OF INSTRUMENT PANEL DATA FOR INJECTION
NISSAN	All Mode	2006 - 2009	Cluster	Special Function	WRITING OF INSTRUMENT PANEL DATA FOR INJECTION
NISSAN	NV400	2011	Cluster	Read Fault Code	
NISSAN	NV400	2011	Cluster	Clear Fault Code	
NISSAN	NV400	2011	Cluster	Read Data Stream	
NISSAN	NV400	2011	Cluster	Module Information	
NISSAN	NV400	2011	Cluster	Actuation Test	LIGHTING
NISSAN	NV400	2011	Cluster	Actuation Test	Instrument Panel Warning Lights
NISSAN	NV400	2011	Cluster	Actuation Test	Instrument Panel Needles
NISSAN	NV400	2011	Cluster	Actuation Test	BUZZER
NISSAN	NV400	2011	Cluster	Special Function	Vin Registration
NISSAN	NV400	2011	Cluster	Special Function	Restart The Computer
NISSAN	NV400	2011	Cluster	Special Function	Update Odometer
NISSAN	NV400	2011	Cluster	Special Function	OIL CHG INT (km)

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

<b>make</b>	<b>model</b>	<b>year</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
NISSAN	NV400	2011	Cluster	Special Function	Oil Change Interval In Months
NISSAN	NV400	2011	Cluster	Special Function	OIL CHANGE RANGE:IN KM
NISSAN	NV400	2011	Cluster	Special Function	Oil Change Range:Current Value In Months
NISSAN	NV400	2011	Cluster	Read Fault Code	
NISSAN	NV400	2011	Cluster	Clear Fault Code	
NISSAN	NV400	2011	Cluster	Read Data Stream	
NISSAN	NV400	2011	Cluster	Module Information	
NISSAN	NV400	2011	Cluster	Actuation Test	LIGHTING
NISSAN	NV400	2011	Cluster	Actuation Test	Instrument Panel Warning Lights
NISSAN	NV400	2011	Cluster	Actuation Test	Instrument Panel Needles
NISSAN	NV400	2011	Cluster	Actuation Test	BUZZER
NISSAN	NV400	2011	Cluster	Special Function	Vin Registration
NISSAN	NV400	2011	Cluster	Special Function	Restart The Computer
NISSAN	NV400	2011	Cluster	Special Function	Update Odometer
NISSAN	NV400	2011	Cluster	Special Function	OIL CHG INT (km)
NISSAN	NV400	2011	Cluster	Special Function	Oil Change Interval In Months
NISSAN	NV400	2011	Cluster	Special Function	OIL CHANGE RANGE:IN KM
NISSAN	NV400	2011	Cluster	Special Function	Oil Change Range:Current Value In Months
NISSAN	NV400	2011	Cluster	Read Fault Code	
NISSAN	NV400	2011	Cluster	Clear Fault Code	
NISSAN	NV400	2011	Cluster	Read Data Stream	
NISSAN	NV400	2011	Cluster	Module Information	
NISSAN	NV400	2011	Cluster	Actuation Test	Instrument Panel Needles
NISSAN	NV400	2011	Cluster	Actuation Test	Instrument Panel Warning Lights
NISSAN	NV400	2011	Cluster	Actuation Test	LIGHTING
NISSAN	NV400	2011	Cluster	Actuation Test	BUZZER
NISSAN	NV400	2011	Cluster	Special Function	Vin Registration
NISSAN	NV400	2011	Cluster	Special Function	Restart The Computer
NISSAN	NV400	2011	Cluster	Special Function	Update Odometer
NISSAN	NV400	2011	Cluster	Special Function	OIL CHG INT (km)
NISSAN	NV400	2011	Cluster	Special Function	Oil Change Interval In Months
NISSAN	NV400	2011	Cluster	Special Function	OIL CHANGE RANGE:IN KM
NISSAN	NV400	2011	Cluster	Special Function	Oil Change Range:Current Value In Months
NISSAN	NV400	2011	Cluster	Special Function	Analogic Display Fuel Gauge Calibration
NISSAN	NV400	2011	Cluster	Special Function	LCD Display Fuel Gauge Calibration
NISSAN	All Mode	2015 - 2017	Cluster	Read Fault Code	
NISSAN	All Mode	2015 - 2017	Cluster	Clear Fault Code	
NISSAN	All Mode	2015 - 2017	Cluster	Read Data Stream	
NISSAN	All Mode	2015 - 2017	Cluster	Module Information	
NISSAN	All Mode	2015 - 2017	Cluster	Actuation Test	BUZZER
NISSAN	All Mode	2015 - 2017	Cluster	Actuation Test	Instrument Panel Warning Lights
NISSAN	All Mode	2015 - 2017	Cluster	Actuation Test	LIGHTING
NISSAN	All Mode	2015 - 2017	Cluster	Actuation Test	Instrument Panel Needles
NISSAN	All Mode	2015 - 2017	Cluster	Actuation Test	Matrix Display
NISSAN	All Mode	2015 - 2017	Cluster	Actuation Test	Computer Initialisation
NISSAN	All Mode	2015 - 2017	Cluster	Special Function	Vin Registration
NISSAN	All Mode	2015 - 2017	Cluster	Special Function	Update Odometer
NISSAN	redi GO	2016	Cluster	Read Fault Code	
NISSAN	redi GO	2016	Cluster	Clear Fault Code	
NISSAN	redi GO	2016	Cluster	Read Data Stream	
NISSAN	redi GO	2016	Cluster	Module Information	
NISSAN	redi GO	2016	Cluster	Actuation Test	BUZZER
NISSAN	redi GO	2016	Cluster	Actuation Test	Instrument Panel Warning Lights
NISSAN	redi GO	2016	Cluster	Actuation Test	LIGHTING
NISSAN	redi GO	2016	Cluster	Actuation Test	Instrument Panel Needles
NISSAN	redi GO	2016	Cluster	Actuation Test	Matrix Display
NISSAN	redi GO	2016	Cluster	Actuation Test	LEFT INDICATOR
NISSAN	redi GO	2016	Cluster	Actuation Test	RIGHT-HAND INDICATOR
NISSAN	redi GO	2016	Cluster	Actuation Test	STARTER RELAY
NISSAN	redi GO	2016	Cluster	Actuation Test	HAZARD LIGHTS LED
NISSAN	redi GO	2016	Cluster	Actuation Test	UCH --> TRANSPONDER RING CONNECTION TEST
NISSAN	redi GO	2016	Cluster	Actuation Test	Computer Initialisation
NISSAN	redi GO	2016	Cluster	Actuation Test	Immobilizer Registration
NISSAN	redi GO	2016	Cluster	Special Function	Vin Registration
NISSAN	redi GO	2016	Cluster	Special Function	Update Odometer
NISSAN	NV300	2016	Cluster	Read Fault Code	
NISSAN	NV300	2016	Cluster	Clear Fault Code	

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
NISSAN	NV300	2016	Cluster	Read Data Stream	
NISSAN	NV300	2016	Cluster	Module Information	
NISSAN	NV300	2016	Cluster	Special Function	Vin Registration
NISSAN	NV300	2016	Cluster	Special Function	OIL CHG INT(km)
NISSAN	NV300	2016	Cluster	Special Function	OIL CHANGE RANGE:IN KM
NISSAN	NV300	2016	Cluster	Special Function	Oil Change Frq Days
NISSAN	NV300	2016	Cluster	Special Function	Oil Service Interval In Days
NISSAN	NV300	2016	Cluster	Special Function	Maint Autonomy: Days
NISSAN	NV300	2016	Cluster	Special Function	Maint Autonomy Int In Km
NISSAN	NV300	2016	Cluster	Special Function	Maint Autonomy In Km
NISSAN	NV300	2016	Cluster	Special Function	Maint Autonomy Int In Days
NISSAN	NV300	2016	Cluster	Special Function	Update Odometer
NISSAN	NV300	2016	Cluster	Special Function	Computer Initialisation
NISSAN	All Mode	2015 - 2017	Cluster	Read Fault Code	
NISSAN	All Mode	2015 - 2017	Cluster	Clear Fault Code	
NISSAN	All Mode	2015 - 2017	Cluster	Read Data Stream	
NISSAN	All Mode	2015 - 2017	Cluster	Module Information	
NISSAN	All Mode	2015 - 2017	Cluster	Actuation Test	BUZZER
NISSAN	All Mode	2015 - 2017	Cluster	Actuation Test	Instrument Panel Warning Lights
NISSAN	All Mode	2015 - 2017	Cluster	Actuation Test	LIGHTING
NISSAN	All Mode	2015 - 2017	Cluster	Actuation Test	Instrument Panel Needles
NISSAN	All Mode	2015 - 2017	Cluster	Actuation Test	Matrix Display
NISSAN	All Mode	2015 - 2017	Cluster	Special Function	Vin Registration
NISSAN	All Mode	2015 - 2017	Cluster	Special Function	Update Odometer
NISSAN	All Mode	2015 - 2017	Cluster	Special Function	Computer Initialisation
NISSAN	All Mode	2008 - 2017	E-SUS (Electric Suspension)	Read Fault Code	
NISSAN	All Mode	2008 - 2017	E-SUS (Electric Suspension)	Clear Fault Code	
NISSAN	All Mode	2008 - 2017	E-SUS (Electric Suspension)	Read Data Stream	
NISSAN	All Mode	2008 - 2017	E-SUS (Electric Suspension)	Read Freeze Frame	
NISSAN	All Mode	2008 - 2017	E-SUS (Electric Suspension)	Module Information	
NISSAN	All Mode	2008 - 2017	E-SUS (Electric Suspension)	Actuation Test	FRONT RIGHT ACTUATOR
NISSAN	All Mode	2008 - 2017	E-SUS (Electric Suspension)	Actuation Test	FRONT LEFT ACTUATOR
NISSAN	All Mode	2008 - 2017	E-SUS (Electric Suspension)	Actuation Test	REAR RIGHT ACTUATOR
NISSAN	All Mode	2008 - 2017	E-SUS (Electric Suspension)	Actuation Test	REAR LEFT ACTUATOR
NISSAN	All Mode	2008 - 2017	E-SUS (Electric Suspension)	Actuation Test	Mode Lamp
NISSAN	All Mode	2010 - 2017	E-SUS (Electric Suspension)	Read Fault Code	
NISSAN	All Mode	2010 - 2017	E-SUS (Electric Suspension)	Clear Fault Code	
NISSAN	All Mode	2010 - 2017	E-SUS (Electric Suspension)	Read Data Stream	
NISSAN	All Mode	2010 - 2017	E-SUS (Electric Suspension)	Module Information	
NISSAN	All Mode	2010 - 2017	E-SUS (Electric Suspension)	Actuation Test	COMPRESSOR
NISSAN	All Mode	2010 - 2017	E-SUS (Electric Suspension)	Actuation Test	EXHAUST SOLENOID
NISSAN	All Mode	2010 - 2017	E-SUS (Electric Suspension)	Actuation Test	Warnnig Lamp
NISSAN	All Mode	2010 - 2017	E-SUS (Electric Suspension)	Special Function	Standard Height Level
NISSAN	All Mode	2010 - 2017	E-SUS (Electric Suspension)	Special Function	Adjust Height Ini
NISSAN	All Mode	2010 - 2017	E-SUS (Electric Suspension)	Special Function	Clear Height INI
NISSAN	All Mode	2007 - 2017	Accele Pedal Act	Read Fault Code	
NISSAN	All Mode	2007 - 2017	Accele Pedal Act	Clear Fault Code	
NISSAN	All Mode	2007 - 2017	Accele Pedal Act	Read Data Stream	
NISSAN	All Mode	2007 - 2017	Accele Pedal Act	Module Information	
NISSAN	All Mode	2007 - 2017	Accele Pedal Act	Actuation Test	ACCELERATOR PEDAL ACTUATOR TEST1
NISSAN	All Mode	2007 - 2017	Accele Pedal Act	Actuation Test	ACCELERATOR PEDAL ACTUATOR TEST2
NISSAN	All Mode	2009 - 2018	Accele Pedal Act	Read Fault Code	
NISSAN	All Mode	2009 - 2018	Accele Pedal Act	Clear Fault Code	
NISSAN	All Mode	2009 - 2018	Accele Pedal Act	Read Data Stream	
NISSAN	All Mode	2009 - 2018	Accele Pedal Act	Module Information	
NISSAN	All Mode	2009 - 2018	Accele Pedal Act	Actuation Test	ACCELERATOR PEDAL ACTUATOR TEST1
NISSAN	All Mode	2009 - 2018	Accele Pedal Act	Actuation Test	ACCELERATOR PEDAL ACTUATOR TEST2
NISSAN	All Mode	2010 - 2017	HV Battery	Read Fault Code	
NISSAN	All Mode	2010 - 2017	HV Battery	Clear Fault Code	
NISSAN	All Mode	2010 - 2017	HV Battery	Read Data Stream	
NISSAN	All Mode	2010 - 2017	HV Battery	Module Information	
NISSAN	All Mode	2010 - 2017	HV Battery	Actuation Test	HV Battery Cooling Fan
NISSAN	All Mode	2010 - 2017	HV Battery	Special Function	Save Battery Information Data
NISSAN	All Mode	2010 - 2017	HV Battery	Special Function	Write Battery Information Data
NISSAN	All Mode	2010 - 2017	HV Battery	Special Function	Clear Battery Info
NISSAN	All Mode	2010 - 2017	HV Battery	Special Function	LI-ION Battery Capacity Balancing
NISSAN	All Mode	2010 - 2017	HV Battery	Read Fault Code	
NISSAN	All Mode	2010 - 2017	HV Battery	Clear Fault Code	
NISSAN	All Mode	2010 - 2017	HV Battery	Read Data Stream	
NISSAN	All Mode	2010 - 2017	HV Battery	Read Freeze Frame	
NISSAN	All Mode	2010 - 2017	HV Battery	Module Information	



**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

<b>make</b>	<b>model</b>	<b>year</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
NISSAN	All Mode	2010 - 2017	HV Battery	Special Function	Clear Battery Gradual Capacity Loss Data
NISSAN	All Mode	2010 - 2017	HV Battery	Special Function	Clear Batt Charge/Discharge Information Data
NISSAN	All Mode	2010 - 2017	HV Battery	Special Function	Save Battery Information Data
NISSAN	All Mode	2010 - 2017	HV Battery	Special Function	Write Battery Information Data
NISSAN	All Mode	2010 - 2017	HV Battery	Special Function	Cell voltage loss inspection
NISSAN	All Mode	2010 - 2017	HV Battery	Read Fault Code	
NISSAN	All Mode	2010 - 2017	HV Battery	Clear Fault Code	
NISSAN	All Mode	2010 - 2017	HV Battery	Read Data Stream	
NISSAN	All Mode	2010 - 2017	HV Battery	Module Information	
NISSAN	All Mode	2010 - 2017	HV Battery	Special Function	Clear Battery Gradual Capacity Loss Data
NISSAN	All Mode	2010 - 2017	HV Battery	Special Function	Clear Batt Charge/Discharge Information Data
NISSAN	All Mode	2010 - 2017	HV Battery	Special Function	Save Battery Information Data
NISSAN	All Mode	2010 - 2017	HV Battery	Special Function	Write Battery Information Data
NISSAN	All Mode	2010 - 2017	HV Battery	Special Function	Cell voltage loss inspection
NISSAN	All Mode	2013 - 2018	HV Battery	Read Fault Code	
NISSAN	All Mode	2013 - 2018	HV Battery	Clear Fault Code	
NISSAN	All Mode	2013 - 2018	HV Battery	Read Data Stream	
NISSAN	All Mode	2013 - 2018	HV Battery	Module Information	
NISSAN	All Mode	2013 - 2018	HV Battery	Actuation Test	HV Battery Cooling Fan
NISSAN	All Mode	2013 - 2018	HV Battery	Special Function	Save Battery Information Data
NISSAN	All Mode	2013 - 2018	HV Battery	Special Function	Write Battery Information Data
NISSAN	All Mode	2013 - 2018	HV Battery	Special Function	Clear Battery Info
NISSAN	All Mode	2013 - 2017	HV Battery	Read Fault Code	
NISSAN	All Mode	2013 - 2017	HV Battery	Clear Fault Code	
NISSAN	All Mode	2013 - 2017	HV Battery	Read Data Stream	
NISSAN	All Mode	2013 - 2017	HV Battery	Module Information	
NISSAN	All Mode	2013 - 2017	HV Battery	Actuation Test	HV Battery Cooling Fan
NISSAN	All Mode	2013 - 2017	HV Battery	Special Function	Idm Information Clear
NISSAN	LEAF	2016	HV Battery	Read Fault Code	
NISSAN	LEAF	2016	HV Battery	Clear Fault Code	
NISSAN	LEAF	2016	HV Battery	Read Data Stream	
NISSAN	LEAF	2016	HV Battery	Module Information	
NISSAN	LEAF	2016	HV Battery	Special Function	Clear Battery Gradual Capacity Loss Data
NISSAN	LEAF	2016	HV Battery	Special Function	Clear Batt Charge/Discharge Information Data
NISSAN	Note e-POWER	2016	HV Battery	Read Fault Code	
NISSAN	Note e-POWER	2016	HV Battery	Clear Fault Code	
NISSAN	Note e-POWER	2016	HV Battery	Read Data Stream	
NISSAN	Note e-POWER	2016	HV Battery	Module Information	
NISSAN	All Mode	As of 2012	Total Illum C/U	Read Fault Code	
NISSAN	All Mode	As of 2012	Total Illum C/U	Clear Fault Code	
NISSAN	All Mode	As of 2012	Total Illum C/U	Read Data Stream	
NISSAN	All Mode	As of 2012	Total Illum C/U	Module Information	
NISSAN	All Mode	2008 - 2017	Total Illum C/U	Read Fault Code	
NISSAN	All Mode	2008 - 2017	Total Illum C/U	Clear Fault Code	
NISSAN	All Mode	2008 - 2017	Total Illum C/U	Read Data Stream	
NISSAN	All Mode	2008 - 2018	Occupant Detection	Read Data Stream	
NISSAN	All Mode	2008 - 2018	Occupant Detection	Special Function	Zero point reset function
NISSAN	All Mode	As of 2012	Smart FOB(SmFOB)	Read Fault Code	
NISSAN	All Mode	As of 2012	Smart FOB(SmFOB)	Clear Fault Code	
NISSAN	All Mode	As of 2012	Smart FOB(SmFOB)	Module Information	
NISSAN	All Mode	2010 - 2018	Brakes	Read Fault Code	
NISSAN	All Mode	2010 - 2018	Brakes	Clear Fault Code	
NISSAN	All Mode	2010 - 2018	Brakes	Read Data Stream	
NISSAN	All Mode	2010 - 2018	Brakes	Module Information	
NISSAN	All Mode	2010 - 2018	Brakes	Actuation Test	STOP LAMP OFF RELAY
NISSAN	All Mode	2010 - 2018	Brakes	Special Function	Storke Sensor 0 Point Learning
NISSAN	All Mode	2015 - 2017	Brakes	Read Fault Code	
NISSAN	All Mode	2015 - 2017	Brakes	Clear Fault Code	
NISSAN	All Mode	2015 - 2017	Brakes	Read Data Stream	
NISSAN	All Mode	2015 - 2017	Brakes	Module Information	
NISSAN	All Mode	2009 - 2018	Side Radar Left	Read Fault Code	
NISSAN	All Mode	2009 - 2018	Side Radar Left	Clear Fault Code	
NISSAN	All Mode	2009 - 2018	Side Radar Left	Read Data Stream	
NISSAN	All Mode	2009 - 2018	Side Radar Left	Module Information	
NISSAN	All Mode	2009 - 2018	Side Radar Left	Special Function	Activate Operation

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
NISSAN	All Mode	2009 - 2017	Side Radar Left	Read Fault Code	
NISSAN	All Mode	2009 - 2017	Side Radar Left	Clear Fault Code	
NISSAN	All Mode	2009 - 2017	Side Radar Left	Read Data Stream	
NISSAN	All Mode	2009 - 2017	Side Radar Left	Module Information	
NISSAN	All Mode	2009 - 2017	Side Radar Left	Special Function	Activate Operation
NISSAN	All Mode	2010 - 2018	VSP	Read Fault Code	
NISSAN	All Mode	2010 - 2018	VSP	Clear Fault Code	
NISSAN	All Mode	2010 - 2018	VSP	Read Data Stream	
NISSAN	All Mode	2010 - 2018	VSP	Module Information	
NISSAN	All Mode	2010 - 2018	VSP	Actuation Test	VSP SPEAKER
NISSAN	All Mode	2010 - 2018	VSP	Actuation Test	START UP SOUND SPEAKER
NISSAN	All Mode	2010 - 2018	VSP	Actuation Test	VSP OFF INDICATOR
NISSAN	All Mode	2010 - 2017	VSP	Read Fault Code	
NISSAN	All Mode	2010 - 2017	VSP	Clear Fault Code	
NISSAN	All Mode	2010 - 2017	VSP	Read Data Stream	
NISSAN	All Mode	2010 - 2017	VSP	Module Information	
NISSAN	All Mode	2013 - 2018	Active Noise Cancellation (ANC)	Read Fault Code	
NISSAN	All Mode	2013 - 2018	Active Noise Cancellation (ANC)	Clear Fault Code	
NISSAN	All Mode	2013 - 2018	Active Noise Cancellation (ANC)	Read Data Stream	
NISSAN	All Mode	2013 - 2018	Active Noise Cancellation (ANC)	Module Information	
NISSAN	All Mode	2013 - 2018	Active Noise Cancellation (ANC)	Actuation Test	ANC TEST TONE
NISSAN	All Mode	2013 - 2018	Active Noise Cancellation (ANC)	Special Function	ANC Setting
NISSAN	All Mode	2013 - 2018	Active Noise Cancellation (ANC)	Special Function	ASC Setting
NISSAN	All Mode	2014 - 2018	Active Noise Cancellation (ANC)	Read Fault Code	
NISSAN	All Mode	2014 - 2018	Active Noise Cancellation (ANC)	Clear Fault Code	
NISSAN	All Mode	2014 - 2018	Active Noise Cancellation (ANC)	Read Data Stream	
NISSAN	All Mode	2014 - 2018	Active Noise Cancellation (ANC)	Module Information	
NISSAN	All Mode	2014 - 2018	Active Noise Cancellation (ANC)	Actuation Test	ANC TEST TONE
NISSAN	All Mode	2014 - 2018	Active Noise Cancellation (ANC)	Special Function	ANC Setting
NISSAN	All Mode	2014 - 2018	Active Noise Cancellation (ANC)	Special Function	ASC Setting
NISSAN	All Mode	2015 - 2018	Active Noise Cancellation (ANC)	Read Fault Code	
NISSAN	All Mode	2015 - 2018	Active Noise Cancellation (ANC)	Clear Fault Code	
NISSAN	All Mode	2015 - 2018	Active Noise Cancellation (ANC)	Read Data Stream	
NISSAN	All Mode	2015 - 2018	Active Noise Cancellation (ANC)	Module Information	
NISSAN	All Mode	2015 - 2018	Active Noise Cancellation (ANC)	Actuation Test	ANC TEST TONE
NISSAN	All Mode	2015 - 2018	Active Noise Cancellation (ANC)	Special Function	ANC Setting
NISSAN	All Mode	2015 - 2018	Active Noise Cancellation (ANC)	Special Function	ASC Setting
NISSAN	All Mode	2013 - 2018	Active Noise Cancellation (ANC)	Read Fault Code	
NISSAN	All Mode	2013 - 2018	Active Noise Cancellation (ANC)	Clear Fault Code	
NISSAN	All Mode	2013 - 2018	Active Noise Cancellation (ANC)	Read Data Stream	
NISSAN	All Mode	2013 - 2018	Active Noise Cancellation (ANC)	Module Information	
NISSAN	All Mode	2013 - 2018	Active Noise Cancellation (ANC)	Actuation Test	ANC TEST TONE
NISSAN	All Mode	2013 - 2018	Active Noise Cancellation (ANC)	Special Function	ANC Setting
NISSAN	All Mode	2013 - 2018	Active Noise Cancellation (ANC)	Special Function	ASC Setting
NISSAN	All Mode	As of 2012	Active Noise Cancellation (ANC)	Read Fault Code	
NISSAN	All Mode	As of 2012	Active Noise Cancellation (ANC)	Clear Fault Code	
NISSAN	All Mode	As of 2012	Active Noise Cancellation (ANC)	Read Data Stream	
NISSAN	All Mode	As of 2012	Active Noise Cancellation (ANC)	Module Information	
NISSAN	All Mode	As of 2012	Active Noise Cancellation (ANC)	Read Fault Code	
NISSAN	All Mode	As of 2012	Active Noise Cancellation (ANC)	Clear Fault Code	
NISSAN	All Mode	As of 2012	Active Noise Cancellation (ANC)	Read Data Stream	
NISSAN	All Mode	As of 2012	Active Noise Cancellation (ANC)	Module Information	
NISSAN	All Mode	As of 2012	Active Noise Cancellation (ANC)	Special Function	ANC Setting
NISSAN	All Mode	2010 - 2017	Multi Display	Read Fault Code	
NISSAN	All Mode	2010 - 2017	Multi Display	Clear Fault Code	
NISSAN	All Mode	2010 - 2017	Multi Display	Read Data Stream	
NISSAN	All Mode	2010 - 2017	Multi Display	Actuation Test	STOP LAMP OFF RELAY
NISSAN	All Mode	2004 - 2010	CCS (Cruise Control System)	Read Fault Code	
NISSAN	All Mode	2004 - 2010	CCS (Cruise Control System)	Clear Fault Code	
NISSAN	All Mode	2004 - 2010	CCS (Cruise Control System)	Read Data Stream	
NISSAN	All Mode	2004 - 2010	CCS (Cruise Control System)	Module Information	
NISSAN	All Mode	2004 - 2010	CCS (Cruise Control System)	Actuation Test	ICC BUZZER
NISSAN	All Mode	2004 - 2010	CCS (Cruise Control System)	Actuation Test	Meter Lamp
NISSAN	All Mode	2004 - 2010	CCS (Cruise Control System)	Actuation Test	Stop Lamp
NISSAN	All Mode	2004 - 2010	CCS (Cruise Control System)	Actuation Test	BOOSTER SOL/V
NISSAN	All Mode	2004 - 2010	CCS (Cruise Control System)	Special Function	Cause Of Auto-Cancel
NISSAN	All Mode	2004 - 2010	CCS (Cruise Control System)	Special Function	Laser Beam Adjust
NISSAN	All Mode	Up to 2017	CCS (Cruise Control System)	Read Fault Code	
NISSAN	All Mode	Up to 2017	CCS (Cruise Control System)	Clear Fault Code	
NISSAN	All Mode	Up to 2017	CCS (Cruise Control System)	Read Data Stream	
NISSAN	All Mode	Up to 2017	CCS (Cruise Control System)	Module Information	
NISSAN	All Mode	Up to 2017	CCS (Cruise Control System)	Actuation Test	ICC BUZZER
NISSAN	All Mode	Up to 2017	CCS (Cruise Control System)	Actuation Test	Meter Lamp
NISSAN	All Mode	Up to 2017	CCS (Cruise Control System)	Actuation Test	Stop Lamp
NISSAN	All Mode	Up to 2017	CCS (Cruise Control System)	Special Function	Cause Of Auto-Cancel
NISSAN	All Mode	Up to 2017	CCS (Cruise Control System)	Special Function	Laser Beam Adjust
NISSAN	All Mode	Up to 2017	CCS (Cruise Control System)	Read Fault Code	
NISSAN	All Mode	Up to 2017	CCS (Cruise Control System)	Clear Fault Code	
NISSAN	All Mode	Up to 2017	CCS (Cruise Control System)	Read Data Stream	
NISSAN	All Mode	Up to 2017	CCS (Cruise Control System)	Read Freeze Frame	

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
NISSAN	All Mode	Up to 2017	CCS (Cruise Control System)	Module Information	
NISSAN	All Mode	Up to 2017	CCS (Cruise Control System)	Actuation Test	ICC BUZZER
NISSAN	All Mode	Up to 2017	CCS (Cruise Control System)	Actuation Test	Meter Lamp
NISSAN	All Mode	Up to 2017	CCS (Cruise Control System)	Actuation Test	Stop Lamp
NISSAN	All Mode	Up to 2017	CCS (Cruise Control System)	Actuation Test	BOOSTER SOL/V
NISSAN	All Mode	Up to 2017	CCS (Cruise Control System)	Actuation Test	Accelerator Pedal Actuator
NISSAN	All Mode	Up to 2017	CCS (Cruise Control System)	Actuation Test	DCA Indicator
NISSAN	All Mode	Up to 2017	CCS (Cruise Control System)	Special Function	Cause Of Auto-Cancel
NISSAN	All Mode	Up to 2017	CCS (Cruise Control System)	Special Function	Laser Beam Adjust
NISSAN	All Mode	2009 - 2018	CCS (Cruise Control System)	Read Fault Code	
NISSAN	All Mode	2009 - 2018	CCS (Cruise Control System)	Clear Fault Code	
NISSAN	All Mode	2009 - 2018	CCS (Cruise Control System)	Read Data Stream	
NISSAN	All Mode	2009 - 2018	CCS (Cruise Control System)	Read Freeze Frame	
NISSAN	All Mode	2009 - 2018	CCS (Cruise Control System)	Module Information	
NISSAN	All Mode	2009 - 2018	CCS (Cruise Control System)	Actuation Test	Brake Actuator
NISSAN	All Mode	2009 - 2018	CCS (Cruise Control System)	Actuation Test	ICC BUZZER
NISSAN	All Mode	2009 - 2018	CCS (Cruise Control System)	Actuation Test	Meter Lamp
NISSAN	All Mode	2009 - 2018	CCS (Cruise Control System)	Actuation Test	Stop Lamp
NISSAN	All Mode	2009 - 2018	CCS (Cruise Control System)	Actuation Test	Active Pedal
NISSAN	All Mode	2009 - 2018	CCS (Cruise Control System)	Actuation Test	DCA Indicator
NISSAN	All Mode	2009 - 2018	CCS (Cruise Control System)	Actuation Test	LDP Buzzer
NISSAN	All Mode	2009 - 2018	CCS (Cruise Control System)	Actuation Test	Warning System IND
NISSAN	All Mode	2009 - 2018	CCS (Cruise Control System)	Actuation Test	LDP ON IND
NISSAN	All Mode	2009 - 2018	CCS (Cruise Control System)	Actuation Test	LANE DEPARTURE W/L
NISSAN	All Mode	2009 - 2018	CCS (Cruise Control System)	Actuation Test	BSW/BSI Warning Lamp
NISSAN	All Mode	2009 - 2018	CCS (Cruise Control System)	Actuation Test	BSI On Indicator
NISSAN	All Mode	2009 - 2018	CCS (Cruise Control System)	Actuation Test	LDW On Indicator
NISSAN	All Mode	2009 - 2018	CCS (Cruise Control System)	Actuation Test	LDP Warning Indicator
NISSAN	All Mode	2009 - 2018	CCS (Cruise Control System)	Actuation Test	LDW Warning Indicator
NISSAN	All Mode	2009 - 2018	CCS (Cruise Control System)	Actuation Test	BSW ON INDICATOR
NISSAN	All Mode	2009 - 2018	CCS (Cruise Control System)	Actuation Test	BSI Warning Indicator
NISSAN	All Mode	2009 - 2018	CCS (Cruise Control System)	Special Function	Cause Of Auto-Cancel 1
NISSAN	All Mode	2009 - 2018	CCS (Cruise Control System)	Special Function	Cause Of Auto-Cancel 2
NISSAN	All Mode	2009 - 2018	CCS (Cruise Control System)	Special Function	Cause Of Auto-Cancel 3
NISSAN	All Mode	2009 - 2018	CCS (Cruise Control System)	Special Function	FEB Operation Mileage
NISSAN	All Mode	2009 - 2018	CCS (Cruise Control System)	Special Function	Cause Of Auto-Cancel 4
NISSAN	All Mode	2009 - 2018	CCS (Cruise Control System)	Special Function	FEB Default Setting
NISSAN	All Mode	2012 - 2017	CCS (Cruise Control System)	Read Fault Code	
NISSAN	All Mode	2012 - 2017	CCS (Cruise Control System)	Clear Fault Code	
NISSAN	All Mode	2012 - 2017	CCS (Cruise Control System)	Read Data Stream	
NISSAN	All Mode	2012 - 2017	CCS (Cruise Control System)	Module Information	
NISSAN	All Mode	2012 - 2017	CCS (Cruise Control System)	Actuation Test	ADAS BUZZER
NISSAN	All Mode	2012 - 2017	CCS (Cruise Control System)	Actuation Test	Stop Lamp
NISSAN	All Mode	2012 - 2017	CCS (Cruise Control System)	Actuation Test	Meter Lamp
NISSAN	All Mode	2012 - 2017	CCS (Cruise Control System)	Actuation Test	METER BUZZER
NISSAN	All Mode	2012 - 2017	CCS (Cruise Control System)	Actuation Test	EAP SW Lamp
NISSAN	All Mode	2012 - 2017	CCS (Cruise Control System)	Actuation Test	BRAKE ACTUATOR 1
NISSAN	All Mode	2012 - 2017	CCS (Cruise Control System)	Actuation Test	BRAKE ACTUATOR 2
NISSAN	All Mode	2012 - 2017	CCS (Cruise Control System)	Actuation Test	BRAKE ACTUATOR 3
NISSAN	All Mode	2012 - 2017	CCS (Cruise Control System)	Special Function	FEB Operation Mileage
NISSAN	All Mode	2012 - 2017	CCS (Cruise Control System)	Special Function	FEB Default Setting
NISSAN	All Mode	2012 - 2017	CCS (Cruise Control System)	Special Function	Cause Of Auto-Cancel 4
NISSAN	All Mode	2012 - 2017	CCS (Cruise Control System)	Special Function	Cause Of Auto-Cancel 5
NISSAN	All Mode	2012 - 2017	CCS (Cruise Control System)	Special Function	Cause Of Auto-Cancel 6
NISSAN	All Mode	2013 - 2017	CCS (Cruise Control System)	Read Fault Code	
NISSAN	All Mode	2013 - 2017	CCS (Cruise Control System)	Clear Fault Code	
NISSAN	All Mode	2013 - 2017	CCS (Cruise Control System)	Read Data Stream	
NISSAN	All Mode	2013 - 2017	CCS (Cruise Control System)	Module Information	
NISSAN	All Mode	2013 - 2017	CCS (Cruise Control System)	Special Function	FEB Operation Mileage
NISSAN	All Mode	2013 - 2017	CCS (Cruise Control System)	Special Function	Cause Of Auto-Cancel 6
NISSAN	All Mode	As of 2012	CCS (Cruise Control System)	Read Fault Code	
NISSAN	All Mode	As of 2012	CCS (Cruise Control System)	Clear Fault Code	
NISSAN	All Mode	As of 2012	CCS (Cruise Control System)	Read Data Stream	
NISSAN	All Mode	As of 2012	CCS (Cruise Control System)	Module Information	
NISSAN	All Mode	As of 2012	CCS (Cruise Control System)	Special Function	FEB Operation Mileage
NISSAN	All Mode	As of 2012	CCS (Cruise Control System)	Special Function	FEB Default Setting
NISSAN	All Mode	As of 2012	CCS (Cruise Control System)	Special Function	Cause Of Auto-Cancel 3
NISSAN	All Mode	As of 2012	CCS (Cruise Control System)	Special Function	Cause Of Auto-Cancel 4
NISSAN	All Mode	As of 2012	CCS (Cruise Control System)	Special Function	Cause Of Auto-Cancel 1
NISSAN	All Mode	As of 2012	CCS (Cruise Control System)	Special Function	Cause Of Auto-Cancel 2
NISSAN	All Mode	2009 - 2018	Side Radar Right	Read Fault Code	
NISSAN	All Mode	2009 - 2018	Side Radar Right	Clear Fault Code	
NISSAN	All Mode	2009 - 2018	Side Radar Right	Read Data Stream	
NISSAN	All Mode	2009 - 2018	Side Radar Right	Module Information	
NISSAN	All Mode	2009 - 2018	Side Radar Right	Special Function	Activate Operation
NISSAN	All Mode	2009 - 2017	Side Radar Right	Read Fault Code	
NISSAN	All Mode	2009 - 2017	Side Radar Right	Clear Fault Code	
NISSAN	All Mode	2009 - 2017	Side Radar Right	Read Data Stream	
NISSAN	All Mode	2009 - 2017	Side Radar Right	Module Information	
NISSAN	All Mode	2009 - 2017	Side Radar Right	Special Function	ACTIVATE OPERATION

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

<b>make</b>	<b>model</b>	<b>year</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
NISSAN	All Mode	2013 - 2016	ADCM	Read Fault Code	
NISSAN	All Mode	2013 - 2016	ADCM	Clear Fault Code	
NISSAN	All Mode	2013 - 2016	ADCM	Read Data Stream	
NISSAN	All Mode	2013 - 2016	ADCM	Module Information	
NISSAN	All Mode	2013 - 2016	ADCM	Special Function	Saving Data For Replc CPU
NISSAN	All Mode	2013 - 2016	ADCM	Special Function	Writing Data For Replc CPU
NISSAN	All Mode	2013 - 2016	ADCM	Special Function	SCR Catalyst Data Clear
NISSAN	All Mode	2013 - 2016	ADCM	Special Function	NOX Sensor 1 Data Clear
NISSAN	All Mode	2013 - 2016	ADCM	Special Function	NOX Sensor 2 Data Clear
NISSAN	All Mode	2013 - 2016	ADCM	Special Function	SCR Catalyst Temp Sensor 1 Data Clear
NISSAN	All Mode	2013 - 2016	ADCM	Special Function	Data Clear For Replacing CPU A
NISSAN	All Mode	2013 - 2016	ADCM	Special Function	Data Clear For Replacing CPU B
NISSAN	All Mode	2013 - 2016	ADCM	Special Function	Oxidation Catalyst Data Clear
NISSAN	All Mode	2013 - 2016	ADCM	Special Function	DPF Data Clear
NISSAN	All Mode	2013 - 2016	ADCM	Special Function	Urea Injector Data Clear
NISSAN	All Mode	2013 - 2016	ADCM	Special Function	SCR CAT Amount Of Urea Adsorpt Data Clear
NISSAN	All Mode	2015 - 2016	ADCM	Read Fault Code	
NISSAN	All Mode	2015 - 2016	ADCM	Clear Fault Code	
NISSAN	All Mode	2015 - 2016	ADCM	Read Data Stream	
NISSAN	All Mode	2015 - 2016	ADCM	Module Information	
NISSAN	All Mode	2014 - 2017	ADCM	Read Fault Code	
NISSAN	All Mode	2014 - 2017	ADCM	Clear Fault Code	
NISSAN	All Mode	2014 - 2017	ADCM	Read Data Stream	
NISSAN	All Mode	2014 - 2017	ADCM	Module Information	
NISSAN	All Mode	2014 - 2017	ADCM	Actuation Test	Adblue Injector
NISSAN	All Mode	2014 - 2017	ADCM	Actuation Test	Adblue Pump
NISSAN	All Mode	2014 - 2017	ADCM	Actuation Test	Adblue Backflow Pump
NISSAN	All Mode	2014 - 2017	ADCM	Actuation Test	Pressure Line Adblue Heater
NISSAN	All Mode	2014 - 2017	ADCM	Actuation Test	Adblue Tank Heater
NISSAN	All Mode	2014 - 2017	ADCM	Special Function	Vin Registration
NISSAN	All Mode	2014 - 2017	ADCM	Special Function	Adblue Injector Programming
NISSAN	All Mode	2014 - 2017	ADCM	Special Function	Adblue Pump Module Programming
NISSAN	All Mode	2014 - 2017	ADCM	Special Function	Adblue Tank Programming
NISSAN	All Mode	2014 - 2017	ADCM	Special Function	Write Saved Data
NISSAN	All Mode	2014 - 2017	ADCM	Special Function	Save Computer Data
NISSAN	All Mode	2014 - 2017	ADCM	Special Function	Adblue Dos Mod Catalyst
NISSAN	CABSTAR (EURO product)	2016	ADCM	Read Fault Code	
NISSAN	CABSTAR (EURO product)	2016	ADCM	Clear Fault Code	
NISSAN	CABSTAR (EURO product)	2016	ADCM	Read Data Stream	
NISSAN	CABSTAR (EURO product)	2016	ADCM	Module Information	
NISSAN	CABSTAR (EURO product)	2016	ADCM	Special Function	Save Data For Replacing CPU
NISSAN	CABSTAR (EURO product)	2016	ADCM	Special Function	Write Data After Replacing CPU
NISSAN	CABSTAR (EURO product)	2016	ADCM	Special Function	SCR Catalyst Data Clear
NISSAN	CABSTAR (EURO product)	2016	ADCM	Special Function	NOX Sensor 1 Data Clear
NISSAN	CABSTAR (EURO product)	2016	ADCM	Special Function	NOX Sensor 2 Data Clear
NISSAN	CABSTAR (EURO product)	2016	ADCM	Special Function	SCR Catalyst Temp Sensor 1 Data Clear
NISSAN	CABSTAR (EURO product)	2016	ADCM	Special Function	Data Clear For Replacing CPU A
NISSAN	CABSTAR (EURO product)	2016	ADCM	Special Function	Data Clear For Replacing CPU B
NISSAN	CABSTAR (EURO product)	2016	ADCM	Special Function	Oxidation Catalyst Data Clear
NISSAN	CABSTAR (EURO product)	2016	ADCM	Special Function	DPF Data Clear
NISSAN	CABSTAR (EURO product)	2016	ADCM	Special Function	Urea Injector Data Clear
NISSAN	CABSTAR (EURO product)	2016	ADCM	Special Function	SCR CAT Amount Of Urea Adsorpt Data Clear
NISSAN	All Mode	2009 - 2017	PTC Heater	Read Fault Code	
NISSAN	All Mode	2009 - 2017	PTC Heater	Clear Fault Code	
NISSAN	All Mode	2009 - 2017	PTC Heater	Read Data Stream	
NISSAN	All Mode	2009 - 2017	PTC Heater	Module Information	
NISSAN	All Mode	2010 - 2017	Charger/PD Module	Read Fault Code	
NISSAN	All Mode	2010 - 2017	Charger/PD Module	Clear Fault Code	
NISSAN	All Mode	2010 - 2017	Charger/PD Module	Read Data Stream	
NISSAN	All Mode	2010 - 2017	Charger/PD Module	Module Information	
NISSAN	All Mode	2010 - 2017	Charger/PD Module	Actuation Test	QUICK CHARGE RELAY+
NISSAN	All Mode	2010 - 2017	Charger/PD Module	Actuation Test	Quick Charge Relay-
NISSAN	All Mode	2010 - 2017	Charger/PD Module	Actuation Test	Normal Charge Relay+
NISSAN	All Mode	2010 - 2017	Charger/PD Module	Actuation Test	Normal Charge Relay-
NISSAN	All Mode	2010 - 2017	Charger/PD Module	Actuation Test	Quick Charge Permit SIG Circuit
NISSAN	All Mode	2010 - 2017	Charger/PD Module	Read Fault Code	
NISSAN	All Mode	2010 - 2017	Charger/PD Module	Clear Fault Code	

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
NISSAN	All Mode	2010 - 2017	Charger/PD Module	Read Data Stream	
NISSAN	All Mode	2010 - 2017	Charger/PD Module	Module Information	
NISSAN	All Mode	2010 - 2017	Charger/PD Module	Actuation Test	QUICK CHARGE RELAY+
NISSAN	All Mode	2010 - 2017	Charger/PD Module	Actuation Test	Quick Charge Relay-
NISSAN	All Mode	2010 - 2017	Charger/PD Module	Actuation Test	Normal Charge Relay-
NISSAN	All Mode	2010 - 2017	Charger/PD Module	Special Function	CHARGE CURRENT LIMITATION HISTORY
NISSAN	LEAF	2016	Charger/PD Module	Read Fault Code	
NISSAN	LEAF	2016	Charger/PD Module	Clear Fault Code	
NISSAN	LEAF	2016	Charger/PD Module	Read Data Stream	
NISSAN	LEAF	2016	Charger/PD Module	Module Information	
NISSAN	LEAF	2016	Charger/PD Module	Read Fault Code	
NISSAN	LEAF	2016	Charger/PD Module	Clear Fault Code	
NISSAN	LEAF	2016	Charger/PD Module	Read Data Stream	
NISSAN	LEAF	2016	Charger/PD Module	Module Information	
NISSAN	All Mode	2010 - 2018	Telematics	Read Fault Code	
NISSAN	All Mode	2010 - 2018	Telematics	Clear Fault Code	
NISSAN	All Mode	2010 - 2018	Telematics	Read Data Stream	
NISSAN	All Mode	2010 - 2018	Telematics	Module Information	
NISSAN	All Mode	2010 - 2018	Telematics	Special Function	Center Connection Setting
NISSAN	All Mode	2010 - 2018	Telematics	Special Function	TCU Activate Setting
NISSAN	All Mode	2010 - 2018	Telematics	Special Function	Save Vin Data
NISSAN	All Mode	2010 - 2018	Telematics	Special Function	Write Vin (Saved Data)
NISSAN	All Mode	2010 - 2018	Telematics	Special Function	Write Vin (Manual Input)
NISSAN	All Mode	2008 - 2016	Telematics	Read Fault Code	
NISSAN	All Mode	2008 - 2016	Telematics	Clear Fault Code	
NISSAN	All Mode	2008 - 2016	Telematics	Read Data Stream	
NISSAN	All Mode	2008 - 2016	Telematics	Module Information	
NISSAN	All Mode	2008 - 2016	Telematics	Special Function	Bluetooth Function
NISSAN	All Mode	2008 - 2016	Telematics	Special Function	GPS Data Logger Connection Setting
NISSAN	All Mode	2008 - 2016	Telematics	Special Function	Change Bluetooth Name
NISSAN	All Mode	2008 - 2016	Telematics	Special Function	Bluetooth Pairing Erase
NISSAN	All Mode	2008 - 2016	Telematics	Special Function	Vehicle Data Transmitter Setting Erase
NISSAN	All Mode	2008 - 2016	Telematics	Special Function	Save Vin Data
NISSAN	All Mode	2008 - 2016	Telematics	Special Function	Write Vin (Saved Data)
NISSAN	All Mode	2008 - 2016	Telematics	Special Function	Write Vin (Manual Input)
NISSAN	All Mode	2015 - 2018	Telematics	Read Fault Code	
NISSAN	All Mode	2015 - 2018	Telematics	Clear Fault Code	
NISSAN	All Mode	2015 - 2018	Telematics	Read Data Stream	
NISSAN	All Mode	2015 - 2018	Telematics	Module Information	
NISSAN	All Mode	2015 - 2016	Telematics	Read Fault Code	
NISSAN	All Mode	2015 - 2016	Telematics	Clear Fault Code	
NISSAN	All Mode	2015 - 2016	Telematics	Read Data Stream	
NISSAN	All Mode	2015 - 2016	Telematics	Module Information	
NISSAN	All Mode	2005 - 2017	Telematics	Read Fault Code	
NISSAN	All Mode	2005 - 2017	Telematics	Clear Fault Code	
NISSAN	All Mode	2005 - 2017	Telematics	Read Data Stream	
NISSAN	All Mode	2005 - 2017	Telematics	Module Information	
NISSAN	All Mode	2005 - 2017	Telematics	Special Function	Vin Registration
NISSAN	All Mode	2005 - 2017	Telematics	Special Function	TCU Activate Setting
NISSAN	e-NV200	2014	Hill-start Assist System (HAS)	Read Fault Code	
NISSAN	e-NV200	2014	Hill-start Assist System (HAS)	Clear Fault Code	
NISSAN	e-NV200	2014	Hill-start Assist System (HAS)	Read Data Stream	
NISSAN	e-NV200	2014	Hill-start Assist System (HAS)	Module Information	
NISSAN	e-NV200	2014	Hill-start Assist System (HAS)	Actuation Test	INITIAL CHECK
NISSAN	e-NV200	2014	Hill-start Assist System (HAS)	Actuation Test	BIVC 1
NISSAN	e-NV200	2014	Hill-start Assist System (HAS)	Actuation Test	BIVC 2
NISSAN	e-NV200	2014	Hill-start Assist System (HAS)	Actuation Test	BIVS
NISSAN	e-NV200	2014	Hill-start Assist System (HAS)	Actuation Test	BOVC 1
NISSAN	e-NV200	2014	Hill-start Assist System (HAS)	Actuation Test	BOVC 2
NISSAN	e-NV200	2014	Hill-start Assist System (HAS)	Actuation Test	BOVS
NISSAN	e-NV200	2014	Hill-start Assist System (HAS)	Actuation Test	BSV
NISSAN	e-NV200	2014	Hill-start Assist System (HAS)	Actuation Test	SSV 1
NISSAN	e-NV200	2014	Hill-start Assist System (HAS)	Actuation Test	SSV 2
NISSAN	e-NV200	2014	Hill-start Assist System (HAS)	Special Function	Pump Lock/Unlock
NISSAN	e-NV200	2014	Hill-start Assist System (HAS)	Special Function	Valve Check
NISSAN	e-NV200	2014	Hill-start Assist System (HAS)	Special Function	Accumulator Pressure Decreases
NISSAN	e-NV200	2014	Hill-start Assist System (HAS)	Special Function	STROKE SENSOR CALIBRATION
NISSAN	e-NV200	2014	Hill-start Assist System (HAS)	Special Function	PRESSURE SENSOR CALIBRATION
NISSAN	e-NV200	2014	Hill-start Assist System (HAS)	Special Function	Valve Calibration
NISSAN	All Mode	2010 - 2018	EMCM	Read Fault Code	
NISSAN	All Mode	2010 - 2018	EMCM	Clear Fault Code	
NISSAN	All Mode	2010 - 2018	EMCM	Read Data Stream	
NISSAN	All Mode	2010 - 2018	EMCM	Module Information	
NISSAN	All Mode	2010 - 2018	EMCM	Actuation Test	Auto Stop Start
NISSAN	All Mode	2010 - 2018	EMCM	Special Function	Saving Data For Replc CPU
NISSAN	All Mode	2010 - 2018	EMCM	Special Function	Writing Data For Replc CPU

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

<b>make</b>	<b>model</b>	<b>year</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
NISSAN	All Mode	2010 - 2018	EMCM	Special Function	STRT OPRIN CNTR CLEAR
NISSAN	All Mode	2010 - 2018	EMCM	Special Function	CML B/DCHRG CRNT CLEAR
NISSAN	All Mode	2010 - 2018	EMCM	Special Function	Cumulative Sub-Battry Dischg Current Clear
NISSAN	All Mode	2010 - 2018	EMCM	Special Function	Chassis Dynamometer Mode
NISSAN	All Mode	2006 - 2013	HVAC (Heating Ventilation Air-conditioning and Cooling)	Read Fault Code	
NISSAN	All Mode	2006 - 2013	HVAC (Heating Ventilation Air-conditioning and Cooling)	Clear Fault Code	
NISSAN	All Mode	2006 - 2013	HVAC (Heating Ventilation Air-conditioning and Cooling)	Read Data Stream	
NISSAN	All Mode	2006 - 2013	HVAC (Heating Ventilation Air-conditioning and Cooling)	Module Information	
NISSAN	All Mode	2006 - 2013	HVAC (Heating Ventilation Air-conditioning and Cooling)	Actuation Test	ALL SEG
NISSAN	All Mode	2006 - 2013	HVAC (Heating Ventilation Air-conditioning and Cooling)	Actuation Test	Hvac Test
NISSAN	All Mode	2006 - 2013	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	Temp Set Correct
NISSAN	All Mode	2006 - 2013	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	REC Memory Set
NISSAN	All Mode	2006 - 2013	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	FRE Memory Set
NISSAN	All Mode	2006 - 2013	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	Blow Set
NISSAN	All Mode	2008 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Read Fault Code	
NISSAN	All Mode	2008 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Clear Fault Code	
NISSAN	All Mode	2008 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Read Data Stream	
NISSAN	All Mode	2008 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Read Freeze Frame	
NISSAN	All Mode	2008 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Module Information	
NISSAN	All Mode	2008 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Actuation Test	ALL SEG
NISSAN	All Mode	2008 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Actuation Test	Hvac Test
NISSAN	All Mode	2008 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	Temp Set Correct
NISSAN	All Mode	2008 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	REC Memory Set
NISSAN	All Mode	2008 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	FRE Memory Set
NISSAN	All Mode	2008 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	Blow Set
NISSAN	All Mode	2008 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	DOOR Motor Starting Position Reset
NISSAN	All Mode	2008 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	Target Max RPM ADJ AT Pre-Climat
NISSAN	All Mode	2008 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	Target Max RPM ADJ AT IDL
NISSAN	All Mode	2008 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	COMP OPRT SET AT DEF MODE (TIM/RMT CLIMT CONT)
NISSAN	All Mode	2009 - 2018	HVAC (Heating Ventilation Air-conditioning and Cooling)	Read Fault Code	
NISSAN	All Mode	2009 - 2018	HVAC (Heating Ventilation Air-conditioning and Cooling)	Clear Fault Code	
NISSAN	All Mode	2009 - 2018	HVAC (Heating Ventilation Air-conditioning and Cooling)	Read Data Stream	
NISSAN	All Mode	2009 - 2018	HVAC (Heating Ventilation Air-conditioning and Cooling)	Read Freeze Frame	
NISSAN	All Mode	2009 - 2018	HVAC (Heating Ventilation Air-conditioning and Cooling)	Module Information	
NISSAN	All Mode	2009 - 2018	HVAC (Heating Ventilation Air-conditioning and Cooling)	Actuation Test	Hvac Test
NISSAN	All Mode	2009 - 2018	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	Blow Set
NISSAN	All Mode	2009 - 2018	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	REC Memory Set
NISSAN	All Mode	2009 - 2018	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	FRE Memory Set
NISSAN	All Mode	2009 - 2018	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	Temp Set Correct
NISSAN	All Mode	2009 - 2018	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	Aroma Setting
NISSAN	All Mode	2009 - 2018	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	Fragrance Setting

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

<b>make</b>	<b>model</b>	<b>year</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
NISSAN	All Mode	2009 - 2018	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	Blower Motor Setting
NISSAN	All Mode	2009 - 2018	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	(TBD)WDBLIDOA
NISSAN	All Mode	2009 - 2018	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	Aroma Diffuser Setting
NISSAN	All Mode	2009 - 2018	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	(TBD)WDBLIDOC
NISSAN	All Mode	2009 - 2018	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	Target Evaporator Temp Upper Limit Setting
NISSAN	All Mode	2009 - 2018	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	CLEAN SW SET
NISSAN	All Mode	2009 - 2018	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	Air Inlet Change Setting
NISSAN	All Mode	2009 - 2018	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	Air Flow Reduction Setting
NISSAN	All Mode	Up to 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Read Fault Code	
NISSAN	All Mode	Up to 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Clear Fault Code	
NISSAN	All Mode	Up to 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Read Data Stream	
NISSAN	All Mode	Up to 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Module Information	
NISSAN	All Mode	2007 - 2018	HVAC (Heating Ventilation Air-conditioning and Cooling)	Read Fault Code	
NISSAN	All Mode	2007 - 2018	HVAC (Heating Ventilation Air-conditioning and Cooling)	Clear Fault Code	
NISSAN	All Mode	2007 - 2018	HVAC (Heating Ventilation Air-conditioning and Cooling)	Read Data Stream	
NISSAN	All Mode	2007 - 2018	HVAC (Heating Ventilation Air-conditioning and Cooling)	Read Freeze Frame	
NISSAN	All Mode	2007 - 2018	HVAC (Heating Ventilation Air-conditioning and Cooling)	Module Information	
NISSAN	All Mode	2007 - 2018	HVAC (Heating Ventilation Air-conditioning and Cooling)	Actuation Test	ALL SEG
NISSAN	All Mode	2007 - 2018	HVAC (Heating Ventilation Air-conditioning and Cooling)	Actuation Test	Hvac Test
NISSAN	All Mode	2007 - 2018	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	Blow Set
NISSAN	All Mode	2007 - 2018	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	REC Memory Set
NISSAN	All Mode	2007 - 2018	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	FRE Memory Set
NISSAN	All Mode	2007 - 2018	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	Temp Set Correct
NISSAN	All Mode	2007 - 2018	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	GAS Sensor Adjustment
NISSAN	All Mode	2007 - 2018	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	CLEAN SW SET
NISSAN	All Mode	2007 - 2018	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	(TBD)ACTR RESET
NISSAN	All Mode	2007 - 2018	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	DOOR Motor Starting Position Reset
NISSAN	All Mode	2007 - 2018	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	Rear Temp Set Correct
NISSAN	All Mode	2007 - 2018	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	Target Evaporator Temp Upper Limit Setting
NISSAN	All Mode	2007 - 2018	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	STOP/START SYSTEM OPERATION COND SETTING
NISSAN	All Mode	2007 - 2018	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	Air Inlet Change Setting
NISSAN	All Mode	2007 - 2018	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	Air Flow Reduction Setting
NISSAN	INFINITI JX35	2012	HVAC (Heating Ventilation Air-conditioning and Cooling)	Read Fault Code	
NISSAN	INFINITI JX35	2012	HVAC (Heating Ventilation Air-conditioning and Cooling)	Clear Fault Code	
NISSAN	INFINITI JX35	2012	HVAC (Heating Ventilation Air-conditioning and Cooling)	Read Data Stream	
NISSAN	INFINITI JX35	2012	HVAC (Heating Ventilation Air-conditioning and Cooling)	Module Information	
NISSAN	INFINITI JX35	2012	HVAC (Heating Ventilation Air-conditioning and Cooling)	Actuation Test	ALL SEG
NISSAN	INFINITI JX35	2012	HVAC (Heating Ventilation Air-conditioning and Cooling)	Actuation Test	Hvac Test
NISSAN	INFINITI JX35	2012	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	Rear Temp Set Correct
NISSAN	INFINITI JX35	2012	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	Temp Set Correct

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

<b>make</b>	<b>model</b>	<b>year</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
NISSAN	INFINITI JX35	2012	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	REC Memory Set
NISSAN	INFINITI JX35	2012	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	FRE Memory Set
NISSAN	INFINITI JX35	2012	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	Blow Set
NISSAN	INFINITI JX35	2012	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	GAS Sensor Adjustment
NISSAN	INFINITI JX35	2012	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	CLEAN SW SET
NISSAN	INFINITI JX35	2012	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	Target Evaporator Temp Upper Limit Setting
NISSAN	INFINITI JX35	2012	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	Air Inlet Change Setting
NISSAN	INFINITI JX35	2012	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	Air Flow Reduction Setting
NISSAN	INFINITI JX35	2012	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	Target Max RPM ADJ AT IDL
NISSAN	All Mode	2013 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Read Fault Code	
NISSAN	All Mode	2013 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Clear Fault Code	
NISSAN	All Mode	2013 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Read Data Stream	
NISSAN	All Mode	2013 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Module Information	
NISSAN	All Mode	2013 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Actuation Test	Hvac Test
NISSAN	All Mode	2013 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	Temp Set Correct
NISSAN	All Mode	2013 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	REC Memory Set
NISSAN	All Mode	2013 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	FRE Memory Set
NISSAN	All Mode	2013 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	Blow Set
NISSAN	All Mode	2013 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	Target Evaporator Temp Upper Limit Setting
NISSAN	All Mode	2013 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	DOOR Motor Starting Position Reset
NISSAN	All Mode	2013 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Read Fault Code	
NISSAN	All Mode	2013 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Clear Fault Code	
NISSAN	All Mode	2013 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Read Data Stream	
NISSAN	All Mode	2013 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Module Information	
NISSAN	All Mode	2013 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Actuation Test	Hvac Test
NISSAN	All Mode	2013 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	DOOR Motor Starting Position Reset
NISSAN	All Mode	2013 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	Target Evaporator Temp Upper Limit Setting
NISSAN	All Mode	2015 - 2018	HVAC (Heating Ventilation Air-conditioning and Cooling)	Read Fault Code	
NISSAN	All Mode	2015 - 2018	HVAC (Heating Ventilation Air-conditioning and Cooling)	Clear Fault Code	
NISSAN	All Mode	2015 - 2018	HVAC (Heating Ventilation Air-conditioning and Cooling)	Read Data Stream	
NISSAN	All Mode	2015 - 2018	HVAC (Heating Ventilation Air-conditioning and Cooling)	Module Information	
NISSAN	All Mode	2015 - 2018	HVAC (Heating Ventilation Air-conditioning and Cooling)	Actuation Test	Check adjustment range of actuator motors
NISSAN	All Mode	2015 - 2018	HVAC (Heating Ventilation Air-conditioning and Cooling)	Actuation Test	Refrigerant compressor magnetic clutch
NISSAN	All Mode	2015 - 2018	HVAC (Heating Ventilation Air-conditioning and Cooling)	Actuation Test	LED of automatic air conditioning cont operating unit
NISSAN	All Mode	2015 - 2018	HVAC (Heating Ventilation Air-conditioning and Cooling)	Actuation Test	Coolant circulation pump
NISSAN	All Mode	2015 - 2018	HVAC (Heating Ventilation Air-conditioning and Cooling)	Actuation Test	Rear Windshield Heater
NISSAN	All Mode	2015 - 2018	HVAC (Heating Ventilation Air-conditioning and Cooling)	Actuation Test	SW and cont illumi of auto air cond cont and operat unit
NISSAN	All Mode	2015 - 2018	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	Teach in of actuator motors
NISSAN	All Mode	2015 - 2018	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	Normalization of actuator motors



**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

<b>make</b>	<b>model</b>	<b>year</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
NISSAN	All Mode	2015 - 2018	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	Breaking in of refrigerant compressor
NISSAN	All Mode	2015 - 2018	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	Re learning
NISSAN	All Mode	2016 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Read Fault Code	
NISSAN	All Mode	2016 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Clear Fault Code	
NISSAN	All Mode	2016 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Read Data Stream	
NISSAN	All Mode	2016 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Module Information	
NISSAN	All Mode	2016 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Actuation Test	Hvac Test
NISSAN	All Mode	2016 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	Air Inlet Change Setting
NISSAN	All Mode	2016 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	Air Flow Reduction Setting
NISSAN	All Mode	2016 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	STOP/START SYSTEM OPERATION COND SETTING
NISSAN	All Mode	2016 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	Temp Set Correct
NISSAN	All Mode	2016 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	REC Memory Set
NISSAN	All Mode	2016 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	FRE Memory Set
NISSAN	All Mode	2016 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	Blow Set
NISSAN	All Mode	2016 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	Target Evaporator Temp Upper Limit Setting
NISSAN	All Mode	2016 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Read Fault Code	
NISSAN	All Mode	2016 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Clear Fault Code	
NISSAN	All Mode	2016 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Read Data Stream	
NISSAN	All Mode	2016 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Module Information	
NISSAN	All Mode	2016 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Actuation Test	ALL SEG
NISSAN	All Mode	2016 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Actuation Test	Hvac Test
NISSAN	All Mode	2013 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Read Fault Code	
NISSAN	All Mode	2013 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Clear Fault Code	
NISSAN	All Mode	2013 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Read Data Stream	
NISSAN	All Mode	2013 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Module Information	
NISSAN	All Mode	2013 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Actuation Test	Hvac Test
NISSAN	All Mode	2013 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Actuation Test	ALL SEG
NISSAN	All Mode	2013 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	Temp Set Correct
NISSAN	All Mode	2013 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	REC Memory Set
NISSAN	All Mode	2013 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	FRE Memory Set
NISSAN	All Mode	2013 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	Blow Set
NISSAN	All Mode	2013 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	Target Evaporator Temp Upper Limit Setting
NISSAN	All Mode	2013 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	DOOR Motor Starting Position Reset
NISSAN	All Mode	2016 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Read Fault Code	
NISSAN	All Mode	2016 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Clear Fault Code	
NISSAN	All Mode	2016 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Read Data Stream	
NISSAN	All Mode	2016 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Module Information	
NISSAN	All Mode	2016 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Actuation Test	Hvac Test
NISSAN	All Mode	2016 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	Temp Set Correct
NISSAN	All Mode	2016 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	REC Memory Set

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

<b>make</b>	<b>model</b>	<b>year</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
NISSAN	All Mode	2016 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	FRE Memory Set
NISSAN	All Mode	2016 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	Blow Set
NISSAN	All Mode	2015 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Read Fault Code	
NISSAN	All Mode	2015 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Clear Fault Code	
NISSAN	All Mode	2015 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Read Data Stream	
NISSAN	All Mode	2015 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Module Information	
NISSAN	All Mode	2015 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Actuation Test	Pass. Compartment Fan Assy
NISSAN	All Mode	2015 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Actuation Test	Recycling Motor: External Air
NISSAN	All Mode	2015 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Actuation Test	Distribution Motor: Vent
NISSAN	All Mode	2015 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Actuation Test	Control panel warning lights
NISSAN	All Mode	2015 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Actuation Test	Right mixing motor : full cold
NISSAN	All Mode	2015 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Actuation Test	Mixing Motor: All Hot
NISSAN	All Mode	2015 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Actuation Test	Mixing Motor: All Cold
NISSAN	All Mode	2015 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Actuation Test	Recycling Motor: Recycling
NISSAN	All Mode	2015 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Actuation Test	Distribution Motor: Demisting
NISSAN	All Mode	2015 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	Computer Reinitialisation
NISSAN	All Mode	2015 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	Geographical Zone
NISSAN	All Mode	2015 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	Vin Registration
NISSAN	KICKS	2016	HVAC (Heating Ventilation Air-conditioning and Cooling)	Read Fault Code	
NISSAN	KICKS	2016	HVAC (Heating Ventilation Air-conditioning and Cooling)	Clear Fault Code	
NISSAN	KICKS	2016	HVAC (Heating Ventilation Air-conditioning and Cooling)	Read Data Stream	
NISSAN	KICKS	2016	HVAC (Heating Ventilation Air-conditioning and Cooling)	Module Information	
NISSAN	LEAF	2016	HVAC (Heating Ventilation Air-conditioning and Cooling)	Read Fault Code	
NISSAN	LEAF	2016	HVAC (Heating Ventilation Air-conditioning and Cooling)	Clear Fault Code	
NISSAN	LEAF	2016	HVAC (Heating Ventilation Air-conditioning and Cooling)	Read Data Stream	
NISSAN	LEAF	2016	HVAC (Heating Ventilation Air-conditioning and Cooling)	Module Information	
NISSAN	All Mode	As of 2012	HVAC (Heating Ventilation Air-conditioning and Cooling)	Read Fault Code	
NISSAN	All Mode	As of 2012	HVAC (Heating Ventilation Air-conditioning and Cooling)	Clear Fault Code	
NISSAN	All Mode	As of 2012	HVAC (Heating Ventilation Air-conditioning and Cooling)	Read Data Stream	
NISSAN	All Mode	As of 2012	HVAC (Heating Ventilation Air-conditioning and Cooling)	Module Information	
NISSAN	All Mode	As of 2012	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	Temp Set Correct
NISSAN	All Mode	As of 2012	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	REC Memory Set
NISSAN	All Mode	As of 2012	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	FRE Memory Set
NISSAN	All Mode	As of 2012	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	Blow Set
NISSAN	All Mode	As of 2012	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	Target Evaporator Temp Upper Limit Setting
NISSAN	All Mode	As of 2012	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	GAS Sensor Adjustment
NISSAN	All Mode	As of 2012	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	CLEAN SW SET
NISSAN	All Mode	As of 2012	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	Air Inlet Change Setting
NISSAN	All Mode	As of 2012	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	Air Flow Reduction Setting
NISSAN	All Mode	As of 2012	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	STOP/START SYSTEM OPERATION COND SETTING

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
NISSAN	All Mode	As of 2012	Head-Up Display (E-HUD)	Read Fault Code	
NISSAN	All Mode	As of 2012	Head-Up Display (E-HUD)	Clear Fault Code	
NISSAN	All Mode	As of 2012	Head-Up Display (E-HUD)	Read Data Stream	
NISSAN	All Mode	As of 2012	Head-Up Display (E-HUD)	Module Information	
NISSAN	All Mode	2005 - 2015	SVT	Read Fault Code	
NISSAN	All Mode	2005 - 2015	SVT	Clear Fault Code	
NISSAN	All Mode	2005 - 2015	SVT	Read Data Stream	
NISSAN	All Mode	2005 - 2015	SVT	Module Information	
NISSAN	All Mode	2011 - 2017	BSW (Warning Of Lane Change)	Read Fault Code	
NISSAN	All Mode	2011 - 2017	BSW (Warning Of Lane Change)	Clear Fault Code	
NISSAN	All Mode	2011 - 2017	BSW (Warning Of Lane Change)	Read Data Stream	
NISSAN	All Mode	2011 - 2017	BSW (Warning Of Lane Change)	Module Information	
NISSAN	All Mode	2011 - 2017	BSW (Warning Of Lane Change)	Actuation Test	ICC BUZZER
NISSAN	All Mode	2011 - 2017	BSW (Warning Of Lane Change)	Actuation Test	BSW/BSI Warning Lamp
NISSAN	All Mode	2013 - 2018	BSW (Warning Of Lane Change)	Read Fault Code	
NISSAN	All Mode	2013 - 2018	BSW (Warning Of Lane Change)	Clear Fault Code	
NISSAN	All Mode	2013 - 2018	BSW (Warning Of Lane Change)	Read Data Stream	
NISSAN	All Mode	2013 - 2018	BSW (Warning Of Lane Change)	Module Information	
NISSAN	All Mode	2013 - 2018	BSW (Warning Of Lane Change)	Actuation Test	BUZZER 1 (ADAS)
NISSAN	All Mode	2013 - 2018	BSW (Warning Of Lane Change)	Actuation Test	BUZZER 2 (ADAS)
NISSAN	All Mode	2013 - 2018	BSW (Warning Of Lane Change)	Actuation Test	BUZZER 3 (ADAS)
NISSAN	All Mode	2013 - 2018	BSW (Warning Of Lane Change)	Actuation Test	BUZZER 4 (ADAS)
NISSAN	All Mode	2013 - 2018	BSW (Warning Of Lane Change)	Actuation Test	BUZZER 1 (CCM)
NISSAN	All Mode	2013 - 2018	BSW (Warning Of Lane Change)	Actuation Test	BUZZER 2 (CCM)
NISSAN	All Mode	2013 - 2018	BSW (Warning Of Lane Change)	Actuation Test	BUZZER 3 (CCM)
NISSAN	All Mode	2013 - 2018	BSW (Warning Of Lane Change)	Actuation Test	BUZZER 4 (CCM)
NISSAN	Venucia T90	2016	BSW (Warning Of Lane Change)	Read Fault Code	
NISSAN	Venucia T90	2016	BSW (Warning Of Lane Change)	Clear Fault Code	
NISSAN	Venucia T90	2016	BSW (Warning Of Lane Change)	Read Data Stream	
NISSAN	Venucia T90	2016	BSW (Warning Of Lane Change)	Module Information	
NISSAN	All Mode	Up to 2018	AVM (Around View Monitor)	Read Fault Code	
NISSAN	All Mode	Up to 2018	AVM (Around View Monitor)	Clear Fault Code	
NISSAN	All Mode	Up to 2018	AVM (Around View Monitor)	Read Data Stream	
NISSAN	All Mode	Up to 2018	AVM (Around View Monitor)	Module Information	
NISSAN	All Mode	Up to 2018	AVM (Around View Monitor)	Actuation Test	LED RH INDICATOR
NISSAN	All Mode	Up to 2018	AVM (Around View Monitor)	Actuation Test	AVM BUZZER
NISSAN	All Mode	Up to 2018	AVM (Around View Monitor)	Actuation Test	LED LH INDICATOR
NISSAN	All Mode	Up to 2018	AVM (Around View Monitor)	Actuation Test	WASH ACTIVE
NISSAN	All Mode	Up to 2018	AVM (Around View Monitor)	Actuation Test	AIR ACTIVE
NISSAN	All Mode	Up to 2018	AVM (Around View Monitor)	Special Function	Calibrating Camera Image(Front Camera)
NISSAN	All Mode	Up to 2018	AVM (Around View Monitor)	Special Function	Calibrating Camera Image(Pass-Side Camera)
NISSAN	All Mode	Up to 2018	AVM (Around View Monitor)	Special Function	Calibrating Camera Image(DR-Side Camera)
NISSAN	All Mode	Up to 2018	AVM (Around View Monitor)	Special Function	Calibrating Camera Image(Rear Camera)
NISSAN	All Mode	Up to 2018	AVM (Around View Monitor)	Special Function	Fine Tuning Of Birds-Eye View
NISSAN	All Mode	Up to 2018	AVM (Around View Monitor)	Special Function	GAS Sensor Adjustment
NISSAN	All Mode	Up to 2018	AVM (Around View Monitor)	Special Function	CLEAN SW SET
NISSAN	All Mode	Up to 2018	AVM (Around View Monitor)	Special Function	Air Inlet Change Setting
NISSAN	All Mode	Up to 2018	AVM (Around View Monitor)	Special Function	Air Flow Reduction Setting
NISSAN	All Mode	Up to 2018	AVM (Around View Monitor)	Special Function	STOP/START SYSTEM OPERATION COND SETTING
NISSAN	All Mode	Up to 2018	AVM (Around View Monitor)	Special Function	Target Max RPM ADJ AT IDL
NISSAN	All Mode	Up to 2018	AVM (Around View Monitor)	Special Function	Non-Viewable Area Reminder
NISSAN	All Mode	Up to 2018	AVM (Around View Monitor)	Special Function	Select Language Of Warning Message
NISSAN	All Mode	Up to 2017	AVM (Around View Monitor)	Read Fault Code	
NISSAN	All Mode	Up to 2017	AVM (Around View Monitor)	Clear Fault Code	
NISSAN	All Mode	Up to 2017	AVM (Around View Monitor)	Read Data Stream	
NISSAN	All Mode	Up to 2017	AVM (Around View Monitor)	Module Information	
NISSAN	All Mode	Up to 2017	AVM (Around View Monitor)	Special Function	Cause Of LDW Cancel
NISSAN	All Mode	Up to 2017	AVM (Around View Monitor)	Special Function	Cause Of BSW Cancel
NISSAN	All Mode	Up to 2017	AVM (Around View Monitor)	Special Function	Cause Of IPA Cancel
NISSAN	All Mode	Up to 2017	AVM (Around View Monitor)	Special Function	Cause Of PSR Cancel
NISSAN	All Mode	Up to 2017	AVM (Around View Monitor)	Special Function	Calibrating Camera Image(Front Camera)
NISSAN	All Mode	Up to 2017	AVM (Around View Monitor)	Special Function	Calibrating Camera Image(Pass-Side Camera)
NISSAN	All Mode	Up to 2017	AVM (Around View Monitor)	Special Function	Calibrating Camera Image(DR-Side Camera)
NISSAN	All Mode	Up to 2017	AVM (Around View Monitor)	Special Function	Calibrating Camera Image(Rear Camera)
NISSAN	All Mode	Up to 2017	AVM (Around View Monitor)	Special Function	Fine Tuning Of Birds-Eye View(Front Camera)
NISSAN	All Mode	Up to 2017	AVM (Around View Monitor)	Special Function	Fine Tuning Of Birds-Eye View(Pass-Side Camera)

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
NISSAN	All Mode	Up to 2017	AVM (Around View Monitor)	Special Function	Fine Tuning Of Birds-Eye View(DR-Side Camera)
NISSAN	All Mode	Up to 2017	AVM (Around View Monitor)	Special Function	Fine Tuning Of Birds-Eye View(Rear Camera)
NISSAN	All Mode	Up to 2017	AVM (Around View Monitor)	Special Function	Rear Wide-View Fixed Guide Line Correction
NISSAN	All Mode	Up to 2017	AVM (Around View Monitor)	Special Function	Non-Viewable Area Reminder
NISSAN	All Mode	Up to 2017	AVM (Around View Monitor)	Special Function	Select Language Of Warning Message
NISSAN	All Mode	Up to 2017	AVM (Around View Monitor)	Special Function	Predictive Course Line Display
NISSAN	All Mode	Up to 2017	AVM (Around View Monitor)	Special Function	Initialize Camera Image Calibration
NISSAN	All Mode	Up to 2017	AVM (Around View Monitor)	Special Function	Steering Angle Sensor Adjustment
NISSAN	All Mode	Up to 2017	AVM (Around View Monitor)	Special Function	Cause Of Entry Cancel
NISSAN	All Mode	Up to 2017	AVM (Around View Monitor)	Special Function	Mod Function
NISSAN	All Mode	Up to 2017	AVM (Around View Monitor)	Special Function	Parts With Door Mirror Auto Fold Func
NISSAN	All Mode	Up to 2017	AVM (Around View Monitor)	Special Function	Sonar Off Pop-Up Display Setting Change
NISSAN	All Mode	Up to 2017	AVM (Around View Monitor)	Special Function	Rear Camera ITS
NISSAN	All Mode	Up to 2017	AVM (Around View Monitor)	Special Function	FOG Lamp Override
NISSAN	All Mode	Up to 2017	AVM (Around View Monitor)	Special Function	3-TIME Flasher Setting
NISSAN	All Mode	Up to 2017	AVM (Around View Monitor)	Special Function	Lock/Unlock By I-Key
NISSAN	All Mode	Up to 2017	AVM (Around View Monitor)	Special Function	Engine Start By I-Key
NISSAN	All Mode	Up to 2017	AVM (Around View Monitor)	Special Function	Trunk/Glass Hatch Open
NISSAN	All Mode	Up to 2017	AVM (Around View Monitor)	Special Function	Auto Lock Set
NISSAN	All Mode	Up to 2017	AVM (Around View Monitor)	Special Function	Short Cranking Output
NISSAN	All Mode	Up to 2017	AVM (Around View Monitor)	Special Function	IGN/ACC Battery Saver
NISSAN	All Mode	Up to 2017	AVM (Around View Monitor)	Special Function	Answer Back
NISSAN	All Mode	Up to 2017	AVM (Around View Monitor)	Special Function	Answer Back I-Key Lock Unlock
NISSAN	All Mode	Up to 2017	AVM (Around View Monitor)	Special Function	Answerback I-Key Lock Unlock
NISSAN	All Mode	Up to 2017	AVM (Around View Monitor)	Special Function	
NISSAN	All Mode	Up to 2017	AVM (Around View Monitor)	Special Function	Intelligent Key Link Set
NISSAN	All Mode	2015 - 2018	AVM (Around View Monitor)	Read Fault Code	
NISSAN	All Mode	2015 - 2018	AVM (Around View Monitor)	Clear Fault Code	
NISSAN	All Mode	2015 - 2018	AVM (Around View Monitor)	Read Data Stream	
NISSAN	All Mode	2015 - 2018	AVM (Around View Monitor)	Module Information	
NISSAN	LEAF	2016	AVM (Around View Monitor)	Read Fault Code	
NISSAN	LEAF	2016	AVM (Around View Monitor)	Clear Fault Code	
NISSAN	LEAF	2016	AVM (Around View Monitor)	Read Data Stream	
NISSAN	LEAF	2016	AVM (Around View Monitor)	Module Information	
NISSAN	LEAF	2016	AVM (Around View Monitor)	Special Function	Initialize Camera Image Calibration
NISSAN	LEAF	2016	AVM (Around View Monitor)	Special Function	Steering Angle Sensor Adjustment
NISSAN	LEAF	2016	AVM (Around View Monitor)	Special Function	Mod Function
NISSAN	LEAF	2016	AVM (Around View Monitor)	Special Function	Parts With Door Mirror Auto Fold Func
NISSAN	LEAF	2016	AVM (Around View Monitor)	Special Function	Predictive Course Line Display
NISSAN	LEAF	2016	AVM (Around View Monitor)	Special Function	Select Language Of Warning Message
NISSAN	LEAF	2016	AVM (Around View Monitor)	Special Function	CALIBRATING CAMERA IMAGE 2 (FRONT CAMERA)
NISSAN	LEAF	2016	AVM (Around View Monitor)	Special Function	CALIBRATING CAMERA IMAGE 2 (PASS-SIDE CAMERA)
NISSAN	LEAF	2016	AVM (Around View Monitor)	Special Function	CALIBRATING CAMERA IMAGE 2 (DR-SIDE CAMERA)
NISSAN	LEAF	2016	AVM (Around View Monitor)	Special Function	CALIBRATING CAMERA IMAGE 2 (REAR CAMERA)
NISSAN	LEAF	2016	AVM (Around View Monitor)	Special Function	TURNING RADIUS CORRECTION
NISSAN	LEAF	2016	AVM (Around View Monitor)	Special Function	FRONT WIDE-VIEW FIXED GUIDE LINE CORRECTION
NISSAN	LEAF	2016	AVM (Around View Monitor)	Special Function	REAR WIDE-VIEW FIXED GUIDE LINE CORRECTION
NISSAN	LEAF	2016	AVM (Around View Monitor)	Special Function	FINE TUNING OF BIRDS-EYE VIE
NISSAN	MURANO	2012	Chassis Control	Read Fault Code	
NISSAN	MURANO	2012	Chassis Control	Clear Fault Code	
NISSAN	MURANO	2012	Chassis Control	Read Data Stream	
NISSAN	MURANO	2012	Chassis Control	Module Information	
NISSAN	MURANO	2012	Chassis Control	Actuation Test	BRAKE ACTUATOR 1 MODE 1
NISSAN	MURANO	2012	Chassis Control	Actuation Test	BRAKE ACTUATOR 1 MODE 2
NISSAN	MURANO	2012	Chassis Control	Actuation Test	BRAKE ACTUATOR 1 MODE 3
NISSAN	MURANO	2012	Chassis Control	Actuation Test	BRAKE ACTUATOR 2 MODE 1
NISSAN	MURANO	2012	Chassis Control	Actuation Test	BRAKE ACTUATOR 2 MODE 2

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
NISSAN	MURANO	2012	Chassis Control	Actuation Test	BRAKE ACTUATOR 2 MODE 3
NISSAN	MURANO	2012	Chassis Control	Actuation Test	BRAKE ACTUATOR 3 MODE 1
NISSAN	MURANO	2012	Chassis Control	Actuation Test	BRAKE ACTUATOR 3 MODE 2
NISSAN	MURANO	2012	Chassis Control	Actuation Test	BRAKE ACTUATOR 3 MODE 3
NISSAN	MURANO	2012	Chassis Control	Actuation Test	ESS RELAY ACTIVE
NISSAN	MURANO	2012	Chassis Control	Actuation Test	ALC DISP
NISSAN	MURANO	2012	Chassis Control	Actuation Test	FR TIRE DISP
NISSAN	MURANO	2012	Chassis Control	Actuation Test	RR TIRE DISP
NISSAN	MURANO	2012	Chassis Control	Actuation Test	ESS ACTIVE
NISSAN	MURANO	2012	Chassis Control	Actuation Test	COMMAND STEERING ANGLE
NISSAN	MURANO	2012	Chassis Control	Actuation Test	COMMAND ST WHL FORCE
NISSAN	MURANO	2012	Chassis Control	Actuation Test	STOP LAMP OFF RELAY 1 ACTIVE
NISSAN	MURANO	2012	Chassis Control	Actuation Test	STOP LAMP OFF RELAY 2 ACTIVE
NISSAN	MURANO	2012	Chassis Control	Actuation Test	MASTER WARNING ACTIVE
NISSAN	MURANO	2012	Chassis Control	Actuation Test	HDC DISP
NISSAN	MURANO	2012	Chassis Control	Actuation Test	BRAKE HOLD DISP
NISSAN	MURANO	2012	Chassis Control	Actuation Test	AEB DISP
NISSAN	MURANO	2012	Chassis Control	Actuation Test	FL TIRE DISP
NISSAN	MURANO	2012	Chassis Control	Actuation Test	RL TIRE DISP
NISSAN	MURANO	2012	Chassis Control	Actuation Test	VEHICLE DISP
NISSAN	MURANO	2012	Chassis Control	Actuation Test	INTERRUPT DISP
NISSAN	MURANO	2012	Chassis Control	Actuation Test	TURN DISP
NISSAN	MURANO	2012	Chassis Control	Actuation Test	ALC LEVEL
NISSAN	MURANO	2012	Chassis Control	Actuation Test	ALC SETTING
NISSAN	MURANO	2012	Chassis Control	Actuation Test	ATC 1 DISP
NISSAN	MURANO	2012	Chassis Control	Actuation Test	ATC 2 DISP
NISSAN	MURANO	2012	Chassis Control	Actuation Test	ATC 3 DISP
NISSAN	MURANO	2012	Chassis Control	Actuation Test	ATC 4 DISP
NISSAN	MURANO	2012	Chassis Control	Actuation Test	ATC 5 DISP
NISSAN	MURANO	2012	Chassis Control	Actuation Test	ARC DISP
NISSAN	MURANO	2012	Chassis Control	Special Function	Erase Last Driver Information
NISSAN	MURANO	2012	Chassis Control	Special Function	Erase Key Allotement User
NISSAN	MURANO	2012	Chassis Control	Special Function	Erase Personal Setting
NISSAN	MURANO	2012	Chassis Control	Special Function	CAUSE OF AUTO-CANCEL 1
NISSAN	All Mode	2013 - 2017	Chassis Control	Read Fault Code	
NISSAN	All Mode	2013 - 2017	Chassis Control	Clear Fault Code	
NISSAN	All Mode	2013 - 2017	Chassis Control	Read Data Stream	
NISSAN	All Mode	2013 - 2017	Chassis Control	Module Information	
NISSAN	All Mode	2013 - 2017	Chassis Control	Special Function	Erase Last Driver Information
NISSAN	All Mode	2013 - 2017	Chassis Control	Special Function	Erase Key Allotement User
NISSAN	All Mode	2013 - 2017	Chassis Control	Special Function	Erase Personal Setting
NISSAN	All Mode	2013 - 2017	Chassis Control	Special Function	CAUSE OF AUTO-CANCEL 1
NISSAN	All Mode	2013 - 2017	Chassis Control	Read Fault Code	
NISSAN	All Mode	2013 - 2017	Chassis Control	Clear Fault Code	
NISSAN	All Mode	2013 - 2017	Chassis Control	Read Data Stream	
NISSAN	All Mode	2013 - 2017	Chassis Control	Module Information	
NISSAN	All Mode	2013 - 2017	Chassis Control	Special Function	Erase Last Driver Information
NISSAN	All Mode	2013 - 2017	Chassis Control	Special Function	Erase Key Allotement User
NISSAN	All Mode	2013 - 2017	Chassis Control	Special Function	Erase Personal Setting
NISSAN	All Mode	2013 - 2017	Chassis Control	Special Function	CAUSE OF AUTO-CANCEL 1
NISSAN	All Mode	2013 - 2018	Chassis Control	Read Fault Code	
NISSAN	All Mode	2013 - 2018	Chassis Control	Clear Fault Code	
NISSAN	All Mode	2013 - 2018	Chassis Control	Read Data Stream	
NISSAN	All Mode	2013 - 2018	Chassis Control	Module Information	
NISSAN	All Mode	2013 - 2018	Chassis Control	Special Function	Erase Last Driver Information
NISSAN	All Mode	2013 - 2018	Chassis Control	Special Function	Erase Key Allotement User
NISSAN	All Mode	2013 - 2018	Chassis Control	Special Function	Erase Personal Setting
NISSAN	All Mode	2013 - 2018	Chassis Control	Special Function	CAUSE OF AUTO-CANCEL 1
NISSAN	All Mode	2013 - 2017	Chassis Control	Read Fault Code	
NISSAN	All Mode	2013 - 2017	Chassis Control	Clear Fault Code	
NISSAN	All Mode	2013 - 2017	Chassis Control	Read Data Stream	
NISSAN	All Mode	2013 - 2017	Chassis Control	Module Information	
NISSAN	All Mode	2013 - 2017	Chassis Control	Special Function	Erase Last Driver Information
NISSAN	All Mode	2013 - 2017	Chassis Control	Special Function	Erase Key Allotement User
NISSAN	All Mode	2013 - 2017	Chassis Control	Special Function	Erase Personal Setting
NISSAN	All Mode	2013 - 2017	Chassis Control	Special Function	CAUSE OF AUTO-CANCEL 1
NISSAN	All Mode	2013 - 2018	Chassis Control	Read Fault Code	
NISSAN	All Mode	2013 - 2018	Chassis Control	Clear Fault Code	
NISSAN	All Mode	2013 - 2018	Chassis Control	Read Data Stream	
NISSAN	All Mode	2013 - 2018	Chassis Control	Module Information	
NISSAN	All Mode	2013 - 2018	Chassis Control	Special Function	Erase Last Driver Information
NISSAN	All Mode	2013 - 2018	Chassis Control	Special Function	Erase Key Allotement User

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
NISSAN	All Mode	2013 - 2018	Chassis Control	Special Function	Erase Personal Setting
NISSAN	All Mode	2013 - 2018	Chassis Control	Special Function	CAUSE OF AUTO-CANCEL 1
NISSAN	All Mode	2013 - 2017	Chassis Control	Read Fault Code	
NISSAN	All Mode	2013 - 2017	Chassis Control	Clear Fault Code	
NISSAN	All Mode	2013 - 2017	Chassis Control	Read Data Stream	
NISSAN	All Mode	2013 - 2017	Chassis Control	Module Information	
NISSAN	All Mode	2013 - 2017	Chassis Control	Special Function	Erase Last Driver Information
NISSAN	All Mode	2013 - 2017	Chassis Control	Special Function	Erase Key Allotement User
NISSAN	All Mode	2013 - 2017	Chassis Control	Special Function	Erase Personal Setting
NISSAN	All Mode	2013 - 2017	Chassis Control	Special Function	CAUSE OF AUTO-CANCEL 1
NISSAN	All Mode	2016 - 2017	Chassis Control	Read Fault Code	
NISSAN	All Mode	2016 - 2017	Chassis Control	Clear Fault Code	
NISSAN	All Mode	2016 - 2017	Chassis Control	Read Data Stream	
NISSAN	All Mode	2016 - 2017	Chassis Control	Module Information	
NISSAN	All Mode	2013 - 2018	DAST 1	Read Fault Code	
NISSAN	All Mode	2013 - 2018	DAST 1	Clear Fault Code	
NISSAN	All Mode	2013 - 2018	DAST 1	Read Data Stream	
NISSAN	All Mode	2013 - 2018	DAST 1	Module Information	
NISSAN	All Mode	As of 2012	DAST 1	Read Fault Code	
NISSAN	All Mode	As of 2012	DAST 1	Clear Fault Code	
NISSAN	All Mode	As of 2012	DAST 1	Read Data Stream	
NISSAN	All Mode	As of 2012	DAST 1	Module Information	
NISSAN	All Mode	2013 - 2018	DAST 2	Read Fault Code	
NISSAN	All Mode	2013 - 2018	DAST 2	Clear Fault Code	
NISSAN	All Mode	2013 - 2018	DAST 2	Read Data Stream	
NISSAN	All Mode	2013 - 2018	DAST 2	Module Information	
NISSAN	All Mode	As of 2012	DAST 2	Read Fault Code	
NISSAN	All Mode	As of 2012	DAST 2	Clear Fault Code	
NISSAN	All Mode	As of 2012	DAST 2	Read Data Stream	
NISSAN	All Mode	As of 2012	DAST 2	Module Information	
NISSAN	All Mode	2013 - 2018	High Beam Assist	Read Fault Code	
NISSAN	All Mode	2013 - 2018	High Beam Assist	Clear Fault Code	
NISSAN	All Mode	2013 - 2018	High Beam Assist	Read Data Stream	
NISSAN	All Mode	2013 - 2018	High Beam Assist	Module Information	
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Read Fault Code	
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Clear Fault Code	
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Read Data Stream	
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Module Information	
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Function Test	
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Special Function	Engine Brake ADJ
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Special Function	Conform CVTF Deteriortn
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Special Function	ECO Mode Reset Function
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Special Function	G Sensor Calibration
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Special Function	Electric O. P. Air Bleeding
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Special Function	Calib Data
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Read Fault Code	
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Clear Fault Code	
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Read Data Stream	
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Module Information	
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Function Test	
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Special Function	Engine Brake ADJ
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Special Function	Conform CVTF Deteriortn
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Special Function	ECO Mode Reset Function
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Special Function	Calib Data
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Read Fault Code	
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Clear Fault Code	
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Read Data Stream	
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Module Information	
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Function Test	
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Actuation Test	CLUTCH OPRATION TEST
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Actuation Test	GEAR ENGAGE TEST
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Special Function	MAX. CLTCH STRK MSRMNT
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Special Function	Cltch Touchpointn Adjst
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Special Function	TM ACTR SELF ADJST
NISSAN	All Mode	2006 - 2017	TCM (Transmission Control Module)	Read Fault Code	
NISSAN	All Mode	2006 - 2017	TCM (Transmission Control Module)	Clear Fault Code	
NISSAN	All Mode	2006 - 2017	TCM (Transmission Control Module)	Read Data Stream	
NISSAN	All Mode	2006 - 2017	TCM (Transmission Control Module)	Module Information	
NISSAN	All Mode	2006 - 2017	TCM (Transmission Control Module)	Function Test	
NISSAN	All Mode	2006 - 2017	TCM (Transmission Control Module)	Special Function	EEPROM CLEAR CONFIRM
NISSAN	All Mode	2006 - 2017	TCM (Transmission Control Module)	Special Function	G Sensor Calibration
NISSAN	All Mode	2005 - 2018	TCM (Transmission Control Module)	Read Fault Code	
NISSAN	All Mode	2005 - 2018	TCM (Transmission Control Module)	Clear Fault Code	
NISSAN	All Mode	2005 - 2018	TCM (Transmission Control Module)	Read Data Stream	
NISSAN	All Mode	2005 - 2018	TCM (Transmission Control Module)	Read Freeze Frame	
NISSAN	All Mode	2005 - 2018	TCM (Transmission Control Module)	Module Information	
NISSAN	All Mode	2005 - 2018	TCM (Transmission Control Module)	Function Test	
NISSAN	All Mode	2005 - 2018	TCM (Transmission Control Module)	Special Function	G Sensor Calibration
NISSAN	All Mode	2005 - 2018	TCM (Transmission Control Module)	Special Function	Calib Data

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Read Fault Code	
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Clear Fault Code	
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Read Data Stream	
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Read Freeze Frame	
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Module Information	
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Function Test	
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Special Function	Engine Brake ADJ
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Special Function	Conform CVTF Deteriortn
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Special Function	ECO Mode Reset Function
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Special Function	G Sensor Calibration
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Special Function	Erase Calibration Data
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Special Function	Erase Learning Value
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Special Function	Erase Memory Data
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Special Function	Clutch Point Learning
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Special Function	Electric O. P. Air Bleeding
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Special Function	Auxiliary gearbox clutch point learning
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Special Function	Calib Data
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Read Fault Code	
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Clear Fault Code	
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Read Data Stream	
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Module Information	
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Special Function	Erase Calibration Data
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Special Function	Erase Learning Value
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Special Function	Erase Memory Data
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Special Function	Calib Data
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Read Fault Code	
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Clear Fault Code	
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Read Data Stream	
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Module Information	
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Function Test	
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Special Function	Engine Brake ADJ
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Special Function	Conform CVTF Deteriortn
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Special Function	Calib Data
NISSAN	All Mode	Up to 2011	TCM (Transmission Control Module)	Read Fault Code	
NISSAN	All Mode	Up to 2011	TCM (Transmission Control Module)	Clear Fault Code	
NISSAN	All Mode	Up to 2011	TCM (Transmission Control Module)	Read Data Stream	
NISSAN	All Mode	Up to 2011	TCM (Transmission Control Module)	Read Freeze Frame	
NISSAN	All Mode	Up to 2011	TCM (Transmission Control Module)	Module Information	
NISSAN	All Mode	Up to 2011	TCM (Transmission Control Module)	Function Test	
NISSAN	All Mode	Up to 2011	TCM (Transmission Control Module)	Special Function	Initialization
NISSAN	NV400	2011	TCM (Transmission Control Module)	Read Fault Code	
NISSAN	NV400	2011	TCM (Transmission Control Module)	Clear Fault Code	
NISSAN	NV400	2011	TCM (Transmission Control Module)	Read Data Stream	
NISSAN	NV400	2011	TCM (Transmission Control Module)	Module Information	
NISSAN	NV400	2011	TCM (Transmission Control Module)	Actuation Test	Hydraulic Pump Relay
NISSAN	NV400	2011	TCM (Transmission Control Module)	Actuation Test	Clutch Solenoid Valve
NISSAN	NV400	2011	TCM (Transmission Control Module)	Actuation Test	Engaging SOL/V
NISSAN	NV400	2011	TCM (Transmission Control Module)	Actuation Test	Selection SOL/V
NISSAN	NV400	2011	TCM (Transmission Control Module)	Actuation Test	DISPLAY
NISSAN	NV400	2011	TCM (Transmission Control Module)	Actuation Test	HYD ASSY PUMP PROHIBIT
NISSAN	NV400	2011	TCM (Transmission Control Module)	Actuation Test	HYD ASSY PUMP RESTORED
NISSAN	NV400	2011	TCM (Transmission Control Module)	Actuation Test	BLD CLTCH CIRC PHASE 1
NISSAN	NV400	2011	TCM (Transmission Control Module)	Actuation Test	BLD CLTCH CIRC PHASE 2
NISSAN	NV400	2011	TCM (Transmission Control Module)	Actuation Test	BLD HYD PRESS ASSY
NISSAN	NV400	2011	TCM (Transmission Control Module)	Actuation Test	G/B RETURN TO NEUTRAL
NISSAN	NV400	2011	TCM (Transmission Control Module)	Actuation Test	ACT SEQUENTIAL CTRL
NISSAN	NV400	2011	TCM (Transmission Control Module)	Actuation Test	BLEED CLTH SLV CYL HYD
NISSAN	NV400	2011	TCM (Transmission Control Module)	Actuation Test	ENGAGE REVERSE GEAR
NISSAN	NV400	2011	TCM (Transmission Control Module)	Actuation Test	PRESS ACCUM DISCHARGE
NISSAN	NV400	2011	TCM (Transmission Control Module)	Special Function	Programmed Values
NISSAN	NV400	2011	TCM (Transmission Control Module)	Special Function	Clth INI Close Pos
NISSAN	NV400	2011	TCM (Transmission Control Module)	Special Function	Program Slip Point
NISSAN	NV400	2011	TCM (Transmission Control Module)	Special Function	Programming selection/engaging zones
NISSAN	NV400	2011	TCM (Transmission Control Module)	Special Function	Write date of last after sales OPE
NISSAN	NV400	2011	TCM (Transmission Control Module)	Special Function	Write Date New Clthfit
NISSAN	NV400	2011	TCM (Transmission Control Module)	Special Function	Write Clth INI Close Pos
NISSAN	NV400	2011	TCM (Transmission Control Module)	Special Function	PRG CLUTCH CLOSE POS
NISSAN	NV400	2011	TCM (Transmission Control Module)	Special Function	Vin Registration
NISSAN	NV400	2011	TCM (Transmission Control Module)	Read Fault Code	
NISSAN	NV400	2011	TCM (Transmission Control Module)	Clear Fault Code	
NISSAN	NV400	2011	TCM (Transmission Control Module)	Read Data Stream	
NISSAN	NV400	2011	TCM (Transmission Control Module)	Module Information	
NISSAN	NV400	2011	TCM (Transmission Control Module)	Actuation Test	PROG CLUTCH TOUCHP
NISSAN	NV400	2011	TCM (Transmission Control Module)	Actuation Test	ACT SEQUENTIAL CTRL
NISSAN	NV400	2011	TCM (Transmission Control Module)	Actuation Test	CLUTCH MOVING TEST
NISSAN	NV400	2011	TCM (Transmission Control Module)	Actuation Test	ENGAGE REVERSE GEAR
NISSAN	NV400	2011	TCM (Transmission Control Module)	Actuation Test	ENGAGEMENT 1ST

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
NISSAN	NV400	2011	TCM (Transmission Control Module)	Actuation Test	ENGAGEMENT 2ND
NISSAN	NV400	2011	TCM (Transmission Control Module)	Actuation Test	ENGAGEMENT 3RD
NISSAN	NV400	2011	TCM (Transmission Control Module)	Actuation Test	ENGAGEMENT 4TH
NISSAN	NV400	2011	TCM (Transmission Control Module)	Actuation Test	ENGAGEMENT 5TH
NISSAN	NV400	2011	TCM (Transmission Control Module)	Actuation Test	ENGAGEMENT 6TH
NISSAN	NV400	2011	TCM (Transmission Control Module)	Special Function	Memorisation Of Speeds
NISSAN	NV400	2011	TCM (Transmission Control Module)	Special Function	Vin Registration
NISSAN	All Mode	2010 - 2017	TCM (Transmission Control Module)	Read Fault Code	
NISSAN	All Mode	2010 - 2017	TCM (Transmission Control Module)	Clear Fault Code	
NISSAN	All Mode	2010 - 2017	TCM (Transmission Control Module)	Read Data Stream	
NISSAN	All Mode	2010 - 2017	TCM (Transmission Control Module)	Module Information	
NISSAN	All Mode	2010 - 2017	TCM (Transmission Control Module)	Actuation Test	CVT Oil Cooler Fan Circuit
NISSAN	All Mode	2010 - 2017	TCM (Transmission Control Module)	Special Function	Conform CVTF Deterioratn
NISSAN	All Mode	2010 - 2017	TCM (Transmission Control Module)	Special Function	G Sensor Calibration
NISSAN	All Mode	2010 - 2017	TCM (Transmission Control Module)	Special Function	Erase Learning Value
NISSAN	All Mode	2010 - 2017	TCM (Transmission Control Module)	Special Function	Engine Brake ADJ
NISSAN	All Mode	2010 - 2017	TCM (Transmission Control Module)	Special Function	FWD Clutch Point Learning
NISSAN	All Mode	2010 - 2017	TCM (Transmission Control Module)	Special Function	Clutch Point
NISSAN	All Mode	2010 - 2017	TCM (Transmission Control Module)	Special Function	Read IP Chara-Replacement TCM
NISSAN	All Mode	2010 - 2017	TCM (Transmission Control Module)	Special Function	Write IP Chara-Replacement TCM
NISSAN	All Mode	2010 - 2017	TCM (Transmission Control Module)	Special Function	Electric O. P. Air Bleeding
NISSAN	All Mode	2010 - 2017	TCM (Transmission Control Module)	Special Function	Erase Calibration Data
NISSAN	All Mode	2010 - 2017	TCM (Transmission Control Module)	Special Function	Erase Memory Data
NISSAN	All Mode	2010 - 2017	TCM (Transmission Control Module)	Special Function	CVT Inspection
NISSAN	All Mode	2010 - 2017	TCM (Transmission Control Module)	Special Function	Calib Data
NISSAN	All Mode	2006 - 2009	TCM (Transmission Control Module)	Read Fault Code	
NISSAN	All Mode	2006 - 2009	TCM (Transmission Control Module)	Clear Fault Code	
NISSAN	All Mode	2006 - 2009	TCM (Transmission Control Module)	Read Data Stream	
NISSAN	All Mode	2006 - 2009	TCM (Transmission Control Module)	Module Information	
NISSAN	All Mode	2006 - 2009	TCM (Transmission Control Module)	Actuation Test	ENGAGING SOLENOID VALVES
NISSAN	All Mode	2006 - 2009	TCM (Transmission Control Module)	Actuation Test	SOLENOID VALVE SELECTION
NISSAN	All Mode	2006 - 2009	TCM (Transmission Control Module)	Actuation Test	HYDRAULIC ASSEMBLY PUMP PROHIBITION
NISSAN	All Mode	2006 - 2009	TCM (Transmission Control Module)	Actuation Test	HYDRAULIC ASSEMBLY PUMP RESTORED
NISSAN	All Mode	2006 - 2009	TCM (Transmission Control Module)	Actuation Test	PRESSURE ACCUMULATOR DISCHARGE
NISSAN	All Mode	2006 - 2009	TCM (Transmission Control Module)	Actuation Test	ENGAGE REVERSE GEAR
NISSAN	All Mode	2006 - 2009	TCM (Transmission Control Module)	Actuation Test	SHIFT TRANSMISSION TO NEUTRAL
NISSAN	All Mode	2006 - 2009	TCM (Transmission Control Module)	Actuation Test	ACTUATORS SEQUENTIAL CONTROL
NISSAN	All Mode	2006 - 2009	TCM (Transmission Control Module)	Actuation Test	DISPLAY
NISSAN	All Mode	2006 - 2009	TCM (Transmission Control Module)	Actuation Test	BLEED CLUTCH CIRCUIT PHASE 1
NISSAN	All Mode	2006 - 2009	TCM (Transmission Control Module)	Actuation Test	BLEED CLUTCH CIRCUIT PHASE 2
NISSAN	All Mode	2006 - 2009	TCM (Transmission Control Module)	Actuation Test	BLEED HYDRAULIC PRESSURE ASSEMBLY
NISSAN	All Mode	2006 - 2009	TCM (Transmission Control Module)	Actuation Test	BLEEDING CLUTCH SLAVE CYL HYDRAULIC CIRC
NISSAN	All Mode	2006 - 2009	TCM (Transmission Control Module)	Actuation Test	HYDRAULIC PUMP RELAY
NISSAN	All Mode	2006 - 2009	TCM (Transmission Control Module)	Actuation Test	Clutch Solenoid Valve
NISSAN	All Mode	2006 - 2009	TCM (Transmission Control Module)	Special Function	Programming selection/engaging zones
NISSAN	All Mode	2006 - 2009	TCM (Transmission Control Module)	Special Function	Write date of last after sales OPE
NISSAN	All Mode	2006 - 2009	TCM (Transmission Control Module)	Special Function	Wrte CLTH INI Close Pos
NISSAN	All Mode	2006 - 2009	TCM (Transmission Control Module)	Special Function	Vin Registration
NISSAN	All Mode	2006 - 2009	TCM (Transmission Control Module)	Special Function	Programmed Values
NISSAN	All Mode	2006 - 2009	TCM (Transmission Control Module)	Special Function	Program Slip Point
NISSAN	All Mode	2006 - 2009	TCM (Transmission Control Module)	Special Function	Write Date New Clutch Fitted
NISSAN	All Mode	2006 - 2009	TCM (Transmission Control Module)	Special Function	Clth INI Close Pos
NISSAN	All Mode	2006 - 2009	TCM (Transmission Control Module)	Special Function	Program Clutch Open Position
NISSAN	All Mode	2013 - 2018	TCM (Transmission Control Module)	Read Fault Code	
NISSAN	All Mode	2013 - 2018	TCM (Transmission Control Module)	Clear Fault Code	
NISSAN	All Mode	2013 - 2018	TCM (Transmission Control Module)	Read Data Stream	
NISSAN	All Mode	2013 - 2018	TCM (Transmission Control Module)	Module Information	
NISSAN	All Mode	2013 - 2018	TCM (Transmission Control Module)	Special Function	Resetting Of Adaption Values
NISSAN	All Mode	2013 - 2018	TCM (Transmission Control Module)	Special Function	Reverse Gear Reset Of Adaption Values
NISSAN	All Mode	2013 - 2018	TCM (Transmission Control Module)	Special Function	TEACH IN OF SELECTION RANGE SENSOR
NISSAN	All Mode	2013 - 2018	TCM (Transmission Control Module)	Special Function	Adaption Values Of Shift Operations



**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
NISSAN	All Mode	2013 - 2018	TCM (Transmission Control Module)	Special Function	Acceleration Downshift
NISSAN	All Mode	2013 - 2018	TCM (Transmission Control Module)	Special Function	Upshift
NISSAN	All Mode	2013 - 2018	TCM (Transmission Control Module)	Special Function	DOWNSHIFT
NISSAN	All Mode	2013 - 2015	TCM (Transmission Control Module)	Read Fault Code	
NISSAN	All Mode	2013 - 2015	TCM (Transmission Control Module)	Clear Fault Code	
NISSAN	All Mode	2013 - 2015	TCM (Transmission Control Module)	Read Data Stream	
NISSAN	All Mode	2013 - 2015	TCM (Transmission Control Module)	Module Information	
NISSAN	All Mode	2013 - 2015	TCM (Transmission Control Module)	Actuation Test	Clutch Exhaust Service
NISSAN	All Mode	2013 - 2015	TCM (Transmission Control Module)	Actuation Test	Valve Activation Test
NISSAN	All Mode	2013 - 2015	TCM (Transmission Control Module)	Special Function	Exhaust Hydraulic Pump
NISSAN	All Mode	2013 - 2015	TCM (Transmission Control Module)	Special Function	Accelerated Clutch Adaption
NISSAN	All Mode	2013 - 2015	TCM (Transmission Control Module)	Special Function	Set Default Characteristic Line
NISSAN	All Mode	2013 - 2015	TCM (Transmission Control Module)	Special Function	EXHAUST TRANSMISSION
NISSAN	All Mode	2013 - 2015	TCM (Transmission Control Module)	Special Function	START TRANSMISSION SELF ADAPTION
NISSAN	All Mode	2013 - 2015	TCM (Transmission Control Module)	Special Function	GEAR SHIFTING
NISSAN	All Mode	2013 - 2015	TCM (Transmission Control Module)	Special Function	POSITION CLUTCH ACTUATOR
NISSAN	All Mode	2013 - 2015	TCM (Transmission Control Module)	Special Function	TEACH IN CLUTCH TOUCH POINT
NISSAN	All Mode	2013 - 2015	TCM (Transmission Control Module)	Special Function	RESET CLUTCH LOAD CONFIGURATION
NISSAN	All Mode	2013 - 2015	TCM (Transmission Control Module)	Special Function	RECALCULATE FACTOR RDN
NISSAN	All Mode	2013 - 2015	TCM (Transmission Control Module)	Special Function	EMPTY PRESSURE RESERVOIR
NISSAN	All Mode	2013 - 2015	TCM (Transmission Control Module)	Special Function	FILL PRESSURE RESERVOIR
NISSAN	All Mode	2013 - 2015	TCM (Transmission Control Module)	Special Function	EXHAUST CLUTCH FAST MODE
NISSAN	All Mode	2013 - 2015	TCM (Transmission Control Module)	Special Function	RESET INITIAL ABSOLUTE CLUTCH POSITION
NISSAN	All Mode	2013 - 2015	TCM (Transmission Control Module)	Special Function	FORCE INITIAL ABSOLUTE CLUTCH POSITION
NISSAN	All Mode	2013 - 2015	TCM (Transmission Control Module)	Special Function	NEW CLUTCH INSTALLED
NISSAN	All Mode	2015 - 2018	TCM (Transmission Control Module)	Read Fault Code	
NISSAN	All Mode	2015 - 2018	TCM (Transmission Control Module)	Clear Fault Code	
NISSAN	All Mode	2015 - 2018	TCM (Transmission Control Module)	Read Data Stream	
NISSAN	All Mode	2015 - 2018	TCM (Transmission Control Module)	Module Information	
NISSAN	All Mode	2015 - 2018	TCM (Transmission Control Module)	Special Function	Sensor actor calibration start
NISSAN	All Mode	2015 - 2018	TCM (Transmission Control Module)	Special Function	Saving Data For Replc CPU
NISSAN	All Mode	2015 - 2018	TCM (Transmission Control Module)	Special Function	Writing Data For Replc CPU
NISSAN	All Mode	2015 - 2018	TCM (Transmission Control Module)	Read Fault Code	
NISSAN	All Mode	2015 - 2018	TCM (Transmission Control Module)	Clear Fault Code	
NISSAN	All Mode	2015 - 2018	TCM (Transmission Control Module)	Read Data Stream	
NISSAN	All Mode	2015 - 2018	TCM (Transmission Control Module)	Module Information	
NISSAN	All Mode	2015 - 2018	TCM (Transmission Control Module)	Special Function	Reverse Gear Reset Of Adaption Values
NISSAN	All Mode	2015 - 2018	TCM (Transmission Control Module)	Special Function	REMOVE ADAPTATIONS VALUE OF SHIFT OPERATIONS
NISSAN	All Mode	2015 - 2018	TCM (Transmission Control Module)	Special Function	TEACH IN OF SELECTION RANGE SENSOR
NISSAN	All Mode	2012 - 2017	TCM (Transmission Control Module)	Read Fault Code	
NISSAN	All Mode	2012 - 2017	TCM (Transmission Control Module)	Clear Fault Code	
NISSAN	All Mode	2012 - 2017	TCM (Transmission Control Module)	Read Data Stream	
NISSAN	All Mode	2012 - 2017	TCM (Transmission Control Module)	Module Information	
NISSAN	All Mode	2012 - 2017	TCM (Transmission Control Module)	Special Function	G Sensor Calibration
NISSAN	All Mode	2012 - 2017	TCM (Transmission Control Module)	Special Function	Erase Calibration Data
NISSAN	All Mode	2012 - 2017	TCM (Transmission Control Module)	Special Function	Erase Learning Value
NISSAN	All Mode	2012 - 2017	TCM (Transmission Control Module)	Special Function	Erase Memory Data
NISSAN	All Mode	2012 - 2017	TCM (Transmission Control Module)	Special Function	FWD Clutch Point Learning
NISSAN	All Mode	2012 - 2017	TCM (Transmission Control Module)	Special Function	Electric O. P. Air Bleeding
NISSAN	All Mode	2012 - 2017	TCM (Transmission Control Module)	Special Function	Engine Brake ADJ
NISSAN	All Mode	2012 - 2017	TCM (Transmission Control Module)	Special Function	Conform CVTF Deteriortn
NISSAN	All Mode	2012 - 2017	TCM (Transmission Control Module)	Special Function	Calib Data
NISSAN	All Mode	2010 - 2018	TCM (Transmission Control Module)	Read Fault Code	
NISSAN	All Mode	2010 - 2018	TCM (Transmission Control Module)	Clear Fault Code	
NISSAN	All Mode	2010 - 2018	TCM (Transmission Control Module)	Read Data Stream	
NISSAN	All Mode	2010 - 2018	TCM (Transmission Control Module)	Module Information	
NISSAN	All Mode	2010 - 2018	TCM (Transmission Control Module)	Special Function	G Sensor Calibration
NISSAN	All Mode	2010 - 2018	TCM (Transmission Control Module)	Special Function	Calib Data
NISSAN	All Mode	2010 - 2018	TCM (Transmission Control Module)	Read Fault Code	
NISSAN	All Mode	2013 - 2017	TCM (Transmission Control Module)	Clear Fault Code	
NISSAN	All Mode	2013 - 2017	TCM (Transmission Control Module)	Read Data Stream	
NISSAN	All Mode	2013 - 2017	TCM (Transmission Control Module)	Module Information	
NISSAN	All Mode	2013 - 2017	TCM (Transmission Control Module)	Actuation Test	CVT Oil Cooler Fan Circuit
NISSAN	All Mode	2013 - 2017	TCM (Transmission Control Module)	Special Function	Conform CVTF Deteriortn
NISSAN	All Mode	2013 - 2017	TCM (Transmission Control Module)	Special Function	Erase Memory Data
NISSAN	All Mode	2013 - 2017	TCM (Transmission Control Module)	Special Function	Erase Learning Value
NISSAN	All Mode	2013 - 2017	TCM (Transmission Control Module)	Special Function	Read IP Chara-Replacement TCM
NISSAN	All Mode	2013 - 2017	TCM (Transmission Control Module)	Special Function	Write IP Chara-Replacement TCM
NISSAN	All Mode	2013 - 2017	TCM (Transmission Control Module)	Special Function	Calib Data

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
NISSAN	All Mode	2016 - 2017	TCM (Transmission Control Module)	Read Fault Code	
NISSAN	All Mode	2016 - 2017	TCM (Transmission Control Module)	Clear Fault Code	
NISSAN	All Mode	2016 - 2017	TCM (Transmission Control Module)	Read Data Stream	
NISSAN	All Mode	2016 - 2017	TCM (Transmission Control Module)	Module Information	
NISSAN	ALMERA	2012	TCM (Transmission Control Module)	Read Fault Code	
NISSAN	ALMERA	2012	TCM (Transmission Control Module)	Clear Fault Code	
NISSAN	ALMERA	2012	TCM (Transmission Control Module)	Read Data Stream	
NISSAN	ALMERA	2012	TCM (Transmission Control Module)	Module Information	
NISSAN	All Mode	2012 - 2017	TCM (Transmission Control Module)	Read Fault Code	
NISSAN	All Mode	2012 - 2017	TCM (Transmission Control Module)	Clear Fault Code	
NISSAN	All Mode	2012 - 2017	TCM (Transmission Control Module)	Read Data Stream	
NISSAN	All Mode	2012 - 2017	TCM (Transmission Control Module)	Module Information	
NISSAN	All Mode	2012 - 2017	TCM (Transmission Control Module)	Special Function	Auxiliary gearbox clutch point learning
NISSAN	All Mode	2012 - 2017	TCM (Transmission Control Module)	Special Function	Conform CVTF Deteriortrn
NISSAN	All Mode	2012 - 2017	TCM (Transmission Control Module)	Special Function	Engine Brake ADJ
NISSAN	All Mode	2012 - 2017	TCM (Transmission Control Module)	Special Function	G Sensor Calibration
NISSAN	All Mode	2012 - 2017	TCM (Transmission Control Module)	Special Function	Erase Calibration Data
NISSAN	All Mode	2012 - 2017	TCM (Transmission Control Module)	Special Function	Erase Learning Value
NISSAN	All Mode	2012 - 2017	TCM (Transmission Control Module)	Special Function	Erase Memory Data
NISSAN	All Mode	2012 - 2017	TCM (Transmission Control Module)	Special Function	FWD Clutch Point Learning
NISSAN	All Mode	2012 - 2017	TCM (Transmission Control Module)	Special Function	ELECTRIC O.P. AIR BLEEDING
NISSAN	All Mode	2012 - 2017	TCM (Transmission Control Module)	Special Function	Calib Data
NISSAN	All Mode	2015 - 2017	TCM (Transmission Control Module)	Read Fault Code	
NISSAN	All Mode	2015 - 2017	TCM (Transmission Control Module)	Clear Fault Code	
NISSAN	All Mode	2015 - 2017	TCM (Transmission Control Module)	Read Data Stream	
NISSAN	All Mode	2015 - 2017	TCM (Transmission Control Module)	Module Information	
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Read Fault Code	
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Clear Fault Code	
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Read Data Stream	
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Module Information	
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Special Function	
NISSAN	All Mode	2006 - 2016	TCM (Transmission Control Module)	Module Information	
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Read Fault Code	
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Clear Fault Code	
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Read Data Stream	
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Module Information	
NISSAN	All Mode	2006 - 2009	TCM (Transmission Control Module)	Read Data Stream	
NISSAN	All Mode	2006 - 2009	TCM (Transmission Control Module)	Module Information	
NISSAN	All Mode	2006 - 2009	TCM (Transmission Control Module)	Special Function	Programming selection/engaging zones
NISSAN	All Mode	2006 - 2009	TCM (Transmission Control Module)	Special Function	Program Clutch Open Position
NISSAN	All Mode	2006 - 2009	TCM (Transmission Control Module)	Special Function	Write date of last after sales OPE
NISSAN	All Mode	2006 - 2009	TCM (Transmission Control Module)	Special Function	Write Date New Clutch Fitted
NISSAN	All Mode	2006 - 2009	TCM (Transmission Control Module)	Special Function	Wrte CLTH INI Close Pos
NISSAN	All Mode	2006 - 2009	TCM (Transmission Control Module)	Special Function	Vin Registration
NISSAN	All Mode	2006 - 2009	TCM (Transmission Control Module)	Special Function	Clth INI Close Pos
NISSAN	All Mode	2006 - 2009	TCM (Transmission Control Module)	Special Function	Program Slip Point
NISSAN	All Mode	2006 - 2009	TCM (Transmission Control Module)	Special Function	Programmed Values
NISSAN	All Mode	2006 - 2009	TCM (Transmission Control Module)	Special Function	Reinit. extreme cold REV gear ENGAGE
NISSAN	All Mode	2008 - 2016	TCM (Transmission Control Module)	Read Fault Code	
NISSAN	All Mode	2008 - 2016	TCM (Transmission Control Module)	Clear Fault Code	
NISSAN	All Mode	2008 - 2016	TCM (Transmission Control Module)	Read Data Stream	
NISSAN	All Mode	2008 - 2016	TCM (Transmission Control Module)	Module Information	
NISSAN	All Mode	2008 - 2016	TCM (Transmission Control Module)	Special Function	Write date of last after sales OPE
NISSAN	All Mode	2008 - 2016	TCM (Transmission Control Module)	Special Function	Write Transmission Oil Change Date
NISSAN	All Mode	2008 - 2016	TCM (Transmission Control Module)	Special Function	Vin Registration
NISSAN	All Mode	2008 - 2016	TCM (Transmission Control Module)	Special Function	Note Oil Wear Counter
NISSAN	All Mode	2008 - 2016	TCM (Transmission Control Module)	Special Function	Auto-Adaptives
NISSAN	All Mode	Up to 2011	TCM (Transmission Control Module)	Read Fault Code	
NISSAN	All Mode	Up to 2011	TCM (Transmission Control Module)	Clear Fault Code	
NISSAN	All Mode	Up to 2011	TCM (Transmission Control Module)	Read Data Stream	
NISSAN	All Mode	Up to 2011	TCM (Transmission Control Module)	Module Information	
NISSAN	All Mode	Up to 2011	TCM (Transmission Control Module)	Special Function	ENGINE BRAKE ADJ.
NISSAN	All Mode	Up to 2011	TCM (Transmission Control Module)	Read Fault Code	
NISSAN	All Mode	Up to 2011	TCM (Transmission Control Module)	Clear Fault Code	
NISSAN	All Mode	Up to 2011	TCM (Transmission Control Module)	Read Data Stream	
NISSAN	All Mode	Up to 2011	TCM (Transmission Control Module)	Module Information	
NISSAN	All Mode	Up to 2011	TCM (Transmission Control Module)	Special Function	ENGINE BRAKE ADJ.
NISSAN	All Mode	Up to 2011	TCM (Transmission Control Module)	Read Fault Code	
NISSAN	All Mode	Up to 2011	TCM (Transmission Control Module)	Clear Fault Code	
NISSAN	All Mode	Up to 2011	TCM (Transmission Control Module)	Read Data Stream	
NISSAN	All Mode	Up to 2011	TCM (Transmission Control Module)	Module Information	
NISSAN	All Mode	Up to 2011	TCM (Transmission Control Module)	Special Function	

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
NISSAN	All Mode	Up to 2011	TCM (Transmission Control Module)	Read Fault Code	
NISSAN	All Mode	Up to 2011	TCM (Transmission Control Module)	Clear Fault Code	
NISSAN	All Mode	Up to 2011	TCM (Transmission Control Module)	Read Data Stream	
NISSAN	All Mode	Up to 2011	TCM (Transmission Control Module)	Module Information	
NISSAN	All Mode	Up to 2011	TCM (Transmission Control Module)	Special Function	ENGINE BRAKE ADJ.
NISSAN	All Mode	Up to 2011	TCM (Transmission Control Module)	Read Fault Code	
NISSAN	All Mode	Up to 2011	TCM (Transmission Control Module)	Clear Fault Code	
NISSAN	All Mode	Up to 2011	TCM (Transmission Control Module)	Read Data Stream	
NISSAN	All Mode	Up to 2011	TCM (Transmission Control Module)	Module Information	
NISSAN	All Mode	Up to 2011	TCM (Transmission Control Module)	Read Fault Code	
NISSAN	All Mode	Up to 2011	TCM (Transmission Control Module)	Clear Fault Code	
NISSAN	All Mode	Up to 2011	TCM (Transmission Control Module)	Read Data Stream	
NISSAN	All Mode	Up to 2011	TCM (Transmission Control Module)	Module Information	
NISSAN	All Mode	Up to 2011	TCM (Transmission Control Module)	Special Function	ENGINE BRAKE ADJ.
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Read Fault Code	
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Clear Fault Code	
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Read Data Stream	
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Module Information	
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Read Fault Code	
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Clear Fault Code	
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Read Data Stream	
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Module Information	
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Special Function	ENGINE BRAKE ADJ.
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Read Fault Code	
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Clear Fault Code	
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Read Data Stream	
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Module Information	
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Special Function	ENGINE BRAKE ADJ.
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Read Fault Code	
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Clear Fault Code	
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Read Data Stream	
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Module Information	
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Special Function	ENGINE BRAKE ADJ.
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Read Fault Code	
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Clear Fault Code	
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Read Data Stream	
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Module Information	
NISSAN	All Mode	2006 - 2009	Computer Interface Unit (CIU)	Read Fault Code	
NISSAN	All Mode	2006 - 2009	Computer Interface Unit (CIU)	Clear Fault Code	
NISSAN	All Mode	2006 - 2009	Computer Interface Unit (CIU)	Read Data Stream	
NISSAN	All Mode	2006 - 2009	Computer Interface Unit (CIU)	Module Information	
NISSAN	All Mode	2006 - 2009	Computer Interface Unit (CIU)	Actuation Test	On/off switch
NISSAN	All Mode	2006 - 2009	Computer Interface Unit (CIU)	Actuation Test	DISPLAY TEST
NISSAN	All Mode	2006 - 2009	Computer Interface Unit (CIU)	Special Function	Vin Registration
NISSAN	All Mode	2006 - 2009	Computer Interface Unit (CIU)	Special Function	Vehicle Identifier
NISSAN	NV400	2011	Computer Interface Unit (CIU)	Read Fault Code	
NISSAN	NV400	2011	Computer Interface Unit (CIU)	Clear Fault Code	
NISSAN	NV400	2011	Computer Interface Unit (CIU)	Read Data Stream	
NISSAN	NV400	2011	Computer Interface Unit (CIU)	Module Information	
NISSAN	NV400	2011	Computer Interface Unit (CIU)	Actuation Test	On/off switch
NISSAN	NV400	2011	Computer Interface Unit (CIU)	Actuation Test	DISPLAY TEST
NISSAN	NV400	2011	Computer Interface Unit (CIU)	Special Function	Vin Registration
NISSAN	NV400	2011	Computer Interface Unit (CIU)	Special Function	Hour Setting
NISSAN	NV400	2011	Computer Interface Unit (CIU)	Special Function	Ecu Memory
NISSAN	All Mode	2015 - 2017	Computer Interface Unit (CIU)	Read Fault Code	
NISSAN	All Mode	2015 - 2017	Computer Interface Unit (CIU)	Clear Fault Code	
NISSAN	All Mode	2015 - 2017	Computer Interface Unit (CIU)	Read Data Stream	
NISSAN	All Mode	2015 - 2017	Computer Interface Unit (CIU)	Module Information	
NISSAN	All Mode	2015 - 2017	Computer Interface Unit (CIU)	Special Function	Vin Registration
NISSAN	All Mode	2015 - 2017	Computer Interface Unit (CIU)	Special Function	Hour Setting
NISSAN	All Mode	2015 - 2017	Computer Interface Unit (CIU)	Special Function	Ecu Memory
NISSAN	NV400	2011	MM CONN	Read Fault Code	
NISSAN	NV400	2011	MM CONN	Clear Fault Code	
NISSAN	NV400	2011	MM CONN	Read Data Stream	
NISSAN	NV400	2011	MM CONN	Module Information	
NISSAN	NV400	2011	MM CONN	Special Function	Write date of last after sales OPE
NISSAN	NV400	2011	MM CONN	Special Function	Vin Registration
NISSAN	NV400	2011	MM CONN	Special Function	Ecu Memory
NISSAN	All Mode	2006 - 2009	MM CONN	Read Fault Code	
NISSAN	All Mode	2006 - 2009	MM CONN	Clear Fault Code	
NISSAN	All Mode	2006 - 2009	MM CONN	Read Data Stream	
NISSAN	All Mode	2006 - 2009	MM CONN	Module Information	
NISSAN	All Mode	2006 - 2009	MM CONN	Special Function	Write date of last after sales OPE
NISSAN	All Mode	2006 - 2009	MM CONN	Special Function	Vin Registration
NISSAN	All Mode	As of 2012	(TBD)ATR	Read Fault Code	

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
NISSAN	All Mode	As of 2012	(TBD)ATR	Clear Fault Code	
NISSAN	All Mode	As of 2012	(TBD)ATR	Read Data Stream	
NISSAN	All Mode	As of 2012	(TBD)ATR	Module Information	
NISSAN	All Mode	2013 - 2017	Intelligent Cruise Control (ICC)/Automatic Data Acquisition System (ADAS) 2	Read Fault Code	
NISSAN	All Mode	2013 - 2017	Intelligent Cruise Control (ICC)/Automatic Data Acquisition System (ADAS) 2	Clear Fault Code	
NISSAN	All Mode	2013 - 2017	Intelligent Cruise Control (ICC)/Automatic Data Acquisition System (ADAS) 2	Read Data Stream	
NISSAN	All Mode	2013 - 2017	Intelligent Cruise Control (ICC)/Automatic Data Acquisition System (ADAS) 2	Module Information	
NISSAN	All Mode	2013 - 2017	Intelligent Cruise Control (ICC)/Automatic Data Acquisition System (ADAS) 2	Special Function	CAUSE OF AUTO-CANCEL 2
NISSAN	All Mode	2013 - 2016	Intelligent Cruise Control (ICC)/Automatic Data Acquisition System (ADAS) 2	Read Fault Code	
NISSAN	All Mode	2013 - 2016	Intelligent Cruise Control (ICC)/Automatic Data Acquisition System (ADAS) 2	Clear Fault Code	
NISSAN	All Mode	2013 - 2016	Intelligent Cruise Control (ICC)/Automatic Data Acquisition System (ADAS) 2	Read Data Stream	
NISSAN	All Mode	2013 - 2016	Intelligent Cruise Control (ICC)/Automatic Data Acquisition System (ADAS) 2	Module Information	
NISSAN	All Mode	As of 2012	Intelligent Cruise Control (ICC)/Automatic Data Acquisition System (ADAS) 2	Read Fault Code	
NISSAN	All Mode	As of 2012	Intelligent Cruise Control (ICC)/Automatic Data Acquisition System (ADAS) 2	Clear Fault Code	
NISSAN	All Mode	As of 2012	Intelligent Cruise Control (ICC)/Automatic Data Acquisition System (ADAS) 2	Read Data Stream	
NISSAN	All Mode	As of 2012	Intelligent Cruise Control (ICC)/Automatic Data Acquisition System (ADAS) 2	Module Information	
NISSAN	All Mode	As of 2012	Intelligent Cruise Control (ICC)/Automatic Data Acquisition System (ADAS) 2	Special Function	FEB Operation Mileage
NISSAN	All Mode	As of 2012	Intelligent Cruise Control (ICC)/Automatic Data Acquisition System (ADAS) 2	Special Function	Cause Of Auto-Cancel 6
NISSAN	INFINITI Q60	2016	Lane camera 2	Read Fault Code	
NISSAN	INFINITI Q60	2016	Lane camera 2	Clear Fault Code	
NISSAN	INFINITI Q60	2016	Lane camera 2	Read Data Stream	
NISSAN	INFINITI Q60	2016	Lane camera 2	Module Information	
NISSAN	NV300	2016	ABS (Anti-lock Braking System)	Module Information	
NISSAN	NV400	2011	ABS (Anti-lock Braking System)	Module Information	
NISSAN	NV400	2014	ABS (Anti-lock Braking System)	Module Information	
NISSAN	All Mode	2015 - 2017	ABS (Anti-lock Braking System)	Module Information	
NISSAN	All Mode	2014 - 2016	ADCM	Module Information	
NISSAN	All Mode	2008 - 2009	SRS (Supplemental Inflatable Restraint System)	Read Fault Code	
NISSAN	All Mode	2008 - 2009	SRS (Supplemental Inflatable Restraint System)	Clear Fault Code	
NISSAN	All Mode	2008 - 2009	SRS (Supplemental Inflatable Restraint System)	Read Data Stream	
NISSAN	All Mode	2008 - 2009	SRS (Supplemental Inflatable Restraint System)	Module Information	
NISSAN	All Mode	2007 - 2017	Air Pressure Monitor	Read Fault Code	
NISSAN	All Mode	2007 - 2017	Air Pressure Monitor	Clear Fault Code	
NISSAN	All Mode	2007 - 2017	Air Pressure Monitor	Read Data Stream	
NISSAN	All Mode	2007 - 2017	Air Pressure Monitor	Module Information	
NISSAN	All Mode	2007 - 2017	Air Pressure Monitor	Actuation Test	BUZZER
NISSAN	All Mode	2007 - 2017	Air Pressure Monitor	Actuation Test	Warn Lamp
NISSAN	All Mode	2007 - 2017	Air Pressure Monitor	Actuation Test	Hazard Lamp
NISSAN	All Mode	2007 - 2017	Air Pressure Monitor	Special Function	ID READ(TIRE SET 1)
NISSAN	All Mode	2007 - 2017	Air Pressure Monitor	Special Function	ID READ(TIRE SET 2)
NISSAN	All Mode	2007 - 2017	Air Pressure Monitor	Special Function	ID REGIST(TIRE SET 1)
NISSAN	All Mode	2007 - 2017	Air Pressure Monitor	Special Function	ID REGIST(TIRE SET 2)
NISSAN	All Mode	2007 - 2017	Air Pressure Monitor	Special Function	Switch Tpm Between On/Off
NISSAN	All Mode	2007 - 2017	Air Pressure Monitor	Special Function	ID REGIST
NISSAN	All Mode	2007 - 2017	BCM (Body Control Module)	Read Fault Code	
NISSAN	All Mode	2007 - 2017	BCM (Body Control Module)	Clear Fault Code	
NISSAN	All Mode	2007 - 2017	BCM (Body Control Module)	Read Data Stream	
NISSAN	All Mode	2007 - 2017	BCM (Body Control Module)	Read Freeze Frame	
NISSAN	All Mode	2007 - 2017	BCM (Body Control Module)	Module Information	
NISSAN	All Mode	2007 - 2017	BCM (Body Control Module)	Actuation Test	Door Lock
NISSAN	All Mode	2007 - 2017	BCM (Body Control Module)	Actuation Test	Super Lock
NISSAN	All Mode	2007 - 2017	BCM (Body Control Module)	Actuation Test	REAR DOOR UNLOCK TEST
NISSAN	All Mode	2007 - 2017	BCM (Body Control Module)	Actuation Test	Door Lock Ind
NISSAN	All Mode	2007 - 2017	BCM (Body Control Module)	Actuation Test	Rear Defogger
NISSAN	All Mode	2007 - 2017	BCM (Body Control Module)	Actuation Test	IGN KEY WARN ALM
NISSAN	All Mode	2007 - 2017	BCM (Body Control Module)	Actuation Test	Seat Belt Warn Test
NISSAN	All Mode	2007 - 2017	BCM (Body Control Module)	Actuation Test	Key Reminder Warn
NISSAN	All Mode	2007 - 2017	BCM (Body Control Module)	Actuation Test	ID REGIST WARNING
NISSAN	All Mode	2007 - 2017	BCM (Body Control Module)	Actuation Test	Light Warn Alm
NISSAN	All Mode	2007 - 2017	BCM (Body Control Module)	Actuation Test	Reverse Warning
NISSAN	All Mode	2007 - 2017	BCM (Body Control Module)	Actuation Test	RUN FLAT/T WARN BUZZER
NISSAN	All Mode	2007 - 2017	BCM (Body Control Module)	Actuation Test	Step Lamp Test
NISSAN	All Mode	2007 - 2017	BCM (Body Control Module)	Actuation Test	Int Lamp
NISSAN	All Mode	2007 - 2017	BCM (Body Control Module)	Actuation Test	LUGGAGE LAMP TEST
NISSAN	All Mode	2007 - 2017	BCM (Body Control Module)	Actuation Test	Tail Lamp

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
NISSAN	All Mode	2007 - 2017	BCM (Body Control Module)	Actuation Test	Head Lamp
NISSAN	All Mode	2007 - 2017	BCM (Body Control Module)	Actuation Test	FR FOG Lamp
NISSAN	All Mode	2007 - 2017	BCM (Body Control Module)	Actuation Test	RR FOG Lamp
NISSAN	All Mode	2007 - 2017	BCM (Body Control Module)	Actuation Test	Daytime Running Light
NISSAN	All Mode	2007 - 2017	BCM (Body Control Module)	Actuation Test	Cornering Lamp
NISSAN	All Mode	2007 - 2017	BCM (Body Control Module)	Actuation Test	ILL DIM Signal
NISSAN	All Mode	2007 - 2017	BCM (Body Control Module)	Actuation Test	FR Wiper
NISSAN	All Mode	2007 - 2017	BCM (Body Control Module)	Actuation Test	Head Lamp Washer
NISSAN	All Mode	2007 - 2017	BCM (Body Control Module)	Actuation Test	RR Wiper
NISSAN	All Mode	2007 - 2017	BCM (Body Control Module)	Actuation Test	Flasher
NISSAN	All Mode	2007 - 2017	BCM (Body Control Module)	Actuation Test	SIREN
NISSAN	All Mode	2007 - 2017	BCM (Body Control Module)	Actuation Test	Theft IND
NISSAN	All Mode	2007 - 2017	BCM (Body Control Module)	Actuation Test	PW REMOTO DOWN SET
NISSAN	All Mode	2007 - 2017	BCM (Body Control Module)	Actuation Test	Battery Saver
NISSAN	All Mode	2007 - 2017	BCM (Body Control Module)	Actuation Test	Outside Buzzer
NISSAN	All Mode	2007 - 2017	BCM (Body Control Module)	Actuation Test	Inside Buzzer
NISSAN	All Mode	2007 - 2017	BCM (Body Control Module)	Actuation Test	Indicator
NISSAN	All Mode	2007 - 2017	BCM (Body Control Module)	Actuation Test	LCD
NISSAN	All Mode	2007 - 2017	BCM (Body Control Module)	Actuation Test	Horn
NISSAN	All Mode	2007 - 2017	BCM (Body Control Module)	Actuation Test	P Range
NISSAN	All Mode	2007 - 2017	BCM (Body Control Module)	Actuation Test	Engine SW Illumi
NISSAN	All Mode	2007 - 2017	BCM (Body Control Module)	Actuation Test	Lock Indicator
NISSAN	All Mode	2007 - 2017	BCM (Body Control Module)	Actuation Test	ACC Indicator
NISSAN	All Mode	2007 - 2017	BCM (Body Control Module)	Actuation Test	Ignition ON IND
NISSAN	All Mode	2007 - 2017	BCM (Body Control Module)	Actuation Test	Key Slot Illumi
NISSAN	All Mode	2007 - 2017	BCM (Body Control Module)	Actuation Test	Trunk/Back Door
NISSAN	All Mode	2007 - 2017	BCM (Body Control Module)	Actuation Test	KEYLESS PW UP/DOWN
NISSAN	All Mode	2007 - 2017	BCM (Body Control Module)	Actuation Test	Trunk/Glass Hatch
NISSAN	All Mode	2007 - 2017	BCM (Body Control Module)	Actuation Test	Vehicle Security Horn
NISSAN	All Mode	2007 - 2017	BCM (Body Control Module)	Actuation Test	Head Lamp(HI)
NISSAN	All Mode	2007 - 2017	BCM (Body Control Module)	Actuation Test	OIL Pressure SW
NISSAN	All Mode	2007 - 2017	BCM (Body Control Module)	Actuation Test	Warning Lamp
NISSAN	All Mode	2007 - 2017	BCM (Body Control Module)	Actuation Test	RUN FLAT TIER W/L
NISSAN	All Mode	2007 - 2017	BCM (Body Control Module)	Special Function	D/LOCK VHCL SPD AJT
NISSAN	All Mode	2007 - 2017	BCM (Body Control Module)	Special Function	Door Lock-Unlock Set
NISSAN	All Mode	2007 - 2017	BCM (Body Control Module)	Special Function	Set I/L D-Unlck Intcon
NISSAN	All Mode	2007 - 2017	BCM (Body Control Module)	Special Function	Room Lamp Timer Set
NISSAN	All Mode	2007 - 2017	BCM (Body Control Module)	Special Function	Room Lamp On Time Set
NISSAN	All Mode	2007 - 2017	BCM (Body Control Module)	Special Function	Room Lamp BAT SAV SET
NISSAN	All Mode	2007 - 2017	BCM (Body Control Module)	Special Function	Room Lamp Off Time Set
NISSAN	All Mode	2007 - 2017	BCM (Body Control Module)	Special Function	R Lamp Timer Logic Set
NISSAN	All Mode	2007 - 2017	BCM (Body Control Module)	Special Function	Room Lamp On At Lock
NISSAN	All Mode	2007 - 2017	BCM (Body Control Module)	Special Function	Battery Saver Set
NISSAN	All Mode	2007 - 2017	BCM (Body Control Module)	Special Function	Custom A/Light Setting
NISSAN	All Mode	2007 - 2017	BCM (Body Control Module)	Special Function	ILL Delay Set
NISSAN	All Mode	2007 - 2017	BCM (Body Control Module)	Special Function	Wiper Speed Setting
NISSAN	All Mode	2007 - 2017	BCM (Body Control Module)	Special Function	HAZARD LAMP SET
NISSAN	All Mode	2007 - 2017	BCM (Body Control Module)	Special Function	Hazard Answer Back
NISSAN	All Mode	2007 - 2017	BCM (Body Control Module)	Special Function	Reset Setting Value
NISSAN	All Mode	2007 - 2017	BCM (Body Control Module)	Special Function	Security Alarm SET
NISSAN	All Mode	2007 - 2017	BCM (Body Control Module)	Special Function	Theft ALM TRG
NISSAN	All Mode	2007 - 2017	BCM (Body Control Module)	Special Function	SIREN SET
NISSAN	All Mode	2007 - 2017	BCM (Body Control Module)	Special Function	Retained PWR Set
NISSAN	All Mode	2007 - 2017	BCM (Body Control Module)	Special Function	REMO CONT ID CONFIR
NISSAN	All Mode	2007 - 2017	BCM (Body Control Module)	Special Function	Welcome Light Op Set
NISSAN	All Mode	2007 - 2017	BCM (Body Control Module)	Special Function	Lock/Unlock By I-Key
NISSAN	All Mode	2007 - 2017	BCM (Body Control Module)	Special Function	Engine Start By I-Key
NISSAN	All Mode	2007 - 2017	BCM (Body Control Module)	Special Function	Trunk/Glass Hatch Open
NISSAN	All Mode	2007 - 2017	BCM (Body Control Module)	Special Function	Answer Back Function
NISSAN	All Mode	2007 - 2017	BCM (Body Control Module)	Special Function	Panic Alarm Set
NISSAN	All Mode	2007 - 2017	BCM (Body Control Module)	Special Function	Take Out From Win Warn
NISSAN	All Mode	2007 - 2017	BCM (Body Control Module)	Special Function	Pw Down Set
NISSAN	All Mode	2007 - 2017	BCM (Body Control Module)	Special Function	Trunk Open Delay
NISSAN	All Mode	2007 - 2017	BCM (Body Control Module)	Special Function	LO-BATT OF KEY FOB WARN
NISSAN	All Mode	2007 - 2017	BCM (Body Control Module)	Special Function	Keyless Function
NISSAN	All Mode	2007 - 2017	BCM (Body Control Module)	Special Function	Anti Key Lock In Function
NISSAN	All Mode	2007 - 2017	BCM (Body Control Module)	Special Function	Ans Back I-Key Lock
NISSAN	All Mode	2007 - 2017	BCM (Body Control Module)	Special Function	Ans Back I-Key Unlock
NISSAN	All Mode	2007 - 2017	BCM (Body Control Module)	Special Function	Short Cranking Output
NISSAN	All Mode	2007 - 2017	BCM (Body Control Module)	Special Function	Inside ANT Diagnosis
NISSAN	All Mode	2007 - 2017	BCM (Body Control Module)	Special Function	Horn With Keyless Lock
NISSAN	All Mode	2007 - 2017	BCM (Body Control Module)	Special Function	Welcome Light Select
NISSAN	All Mode	2007 - 2017	BCM (Body Control Module)	Special Function	Confirm Dongle ID
NISSAN	All Mode	2007 - 2017	BCM (Body Control Module)	Special Function	Automatic Door Lock Select
NISSAN	All Mode	2007 - 2017	BCM (Body Control Module)	Special Function	HORN CHIRP SET
NISSAN	All Mode	2007 - 2017	BCM (Body Control Module)	Special Function	Auto Lock Set
NISSAN	All Mode	2007 - 2017	BCM (Body Control Module)	Special Function	Automatic Door Unlock Select
NISSAN	All Mode	2007 - 2017	BCM (Body Control Module)	Special Function	Automatic Door Lock/Unlock Select

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
NISSAN	All Mode	2007 - 2017	BCM (Body Control Module)	Special Function	ID REGIST
NISSAN	All Mode	2007 - 2017	BCM (Body Control Module)	Special Function	ID READ
NISSAN	All Mode	2007 - 2017	BCM (Body Control Module)	Special Function	Confirm Key Fob ID
NISSAN	NV300	2016	Engine	Module Information	
NISSAN	All Mode	2010 - 2016	Engine	Read Fault Code	
NISSAN	All Mode	2010 - 2016	Engine	Clear Fault Code	
NISSAN	All Mode	2010 - 2016	Engine	Read Data Stream	
NISSAN	All Mode	2010 - 2016	Engine	Module Information	
NISSAN	All Mode	2010 - 2016	Engine	Special Function	INJ ADJ VAL REGIST
NISSAN	All Mode	2010 - 2016	Engine	Special Function	P062F EXCLUSIVE FUNCTION
NISSAN	All Mode	2010 - 2016	Engine	Special Function	LEARNING
NISSAN	All Mode	2010 - 2016	Engine	Special Function	EGR/V LEARN CLR
NISSAN	All Mode	2010 - 2016	Engine	Special Function	ZFC VALUE RESET
NISSAN	All Mode	2010 - 2016	Engine	Special Function	DPF Data Clear
NISSAN	All Mode	2010 - 2016	Engine	Special Function	Service Regeneration
NISSAN	All Mode	2007 - 2017	Engine	Read Fault Code	
NISSAN	All Mode	2007 - 2017	Engine	Clear Fault Code	
NISSAN	All Mode	2007 - 2017	Engine	Read Data Stream	
NISSAN	All Mode	2007 - 2017	Engine	Module Information	
NISSAN	All Mode	2007 - 2017	Engine	Actuation Test	VENT CONTROL/V
NISSAN	All Mode	2007 - 2017	Engine	Actuation Test	Fuel/T Temp SEN
NISSAN	All Mode	2007 - 2017	Engine	Actuation Test	Decontamination Flow Control Solenoid Valve
NISSAN	All Mode	2007 - 2017	Engine	Actuation Test	FAN DUTY CONTROL
NISSAN	All Mode	2007 - 2017	Engine	Actuation Test	IGNITION TIMING
NISSAN	All Mode	2007 - 2017	Engine	Actuation Test	Fuel Pump Control Module
NISSAN	All Mode	2007 - 2017	Engine	Actuation Test	Sub Fuel Pump Relay
NISSAN	All Mode	2007 - 2017	Engine	Actuation Test	Electric Control Silencer
NISSAN	All Mode	2007 - 2017	Engine	Special Function	Fuel Pressure Relief
NISSAN	All Mode	2007 - 2017	Engine	Special Function	Self-Learning Control
NISSAN	All Mode	2007 - 2017	Engine	Special Function	ECT History
NISSAN	All Mode	2007 - 2017	Engine	Special Function	Eng Oil Temp History
NISSAN	All Mode	2007 - 2017	Engine	Special Function	ECT History Clear
NISSAN	All Mode	2007 - 2017	Engine	Special Function	ENG OIL Temp History Clear
NISSAN	All Mode	2007 - 2017	Engine	Special Function	TARGET IGN TIM ADJ
NISSAN	All Mode	2007 - 2017	Engine	Special Function	TARGET IDLE RPM ADJ
NISSAN	All Mode	2008 - 2017	Engine	Module Information	
NISSAN	NV400	2011	Engine	Module Information	
NISSAN	ALMERA	2012	Engine	Module Information	
NISSAN	All Mode	2006 - 2009	Engine	Module Information	
NISSAN	NV400	2014	Engine	Module Information	
NISSAN	All Mode	2007 - 2017	E-SUS (Electric Suspension)	Read Fault Code	
NISSAN	All Mode	2007 - 2017	E-SUS (Electric Suspension)	Clear Fault Code	
NISSAN	All Mode	2007 - 2017	E-SUS (Electric Suspension)	Read Data Stream	
NISSAN	All Mode	2007 - 2017	E-SUS (Electric Suspension)	Module Information	
NISSAN	All Mode	2007 - 2017	E-SUS (Electric Suspension)	Actuation Test	FRONT RIGHT ACTUATOR
NISSAN	All Mode	2007 - 2017	E-SUS (Electric Suspension)	Actuation Test	FRONT LEFT ACTUATOR
NISSAN	All Mode	2007 - 2017	E-SUS (Electric Suspension)	Actuation Test	REAR RIGHT ACTUATOR
NISSAN	All Mode	2007 - 2017	E-SUS (Electric Suspension)	Actuation Test	REAR LEFT ACTUATOR
NISSAN	All Mode	2007 - 2017	E-SUS (Electric Suspension)	Actuation Test	Mode Lamp
NISSAN	All Mode	2008 - 2017	Multi AV	Read Fault Code	
NISSAN	All Mode	2008 - 2017	Multi AV	Clear Fault Code	
NISSAN	All Mode	2008 - 2017	Multi AV	Read Data Stream	
NISSAN	All Mode	2008 - 2017	Multi AV	Module Information	
NISSAN	All Mode	2008 - 2017	Multi AV	Special Function	SELF-DIAG[ETC]
NISSAN	All Mode	Up to 2016	TCM (Transmission Control Module)	Read Fault Code	
NISSAN	All Mode	Up to 2016	TCM (Transmission Control Module)	Clear Fault Code	
NISSAN	All Mode	Up to 2016	TCM (Transmission Control Module)	Read Data Stream	
NISSAN	All Mode	Up to 2016	TCM (Transmission Control Module)	Read Fault Code	
NISSAN	All Mode	Up to 2016	TCM (Transmission Control Module)	Clear Fault Code	
NISSAN	All Mode	Up to 2016	TCM (Transmission Control Module)	Read Data Stream	
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Read Fault Code	
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Clear Fault Code	
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Read Data Stream	
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Actuation Test	SHIFT S/V 1
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Actuation Test	SHIFT S/V 2
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Actuation Test	SHIFT S/V 3
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Actuation Test	SHIFT S/V 4
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Actuation Test	SEQUENCE S/V
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Actuation Test	LINE PRESS S/V
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Actuation Test	C/L B PRESS S/V
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Actuation Test	C/L A PRESS S/V
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Actuation Test	LUBRICATION FLOW-RATE S/V
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Actuation Test	A-AXIS SUPPLY PRESSURE S/V
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Actuation Test	B-AXIS SUPPLY PRESSURE S/V
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Actuation Test	STARTER RELAY
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Actuation Test	REVERSE LAMP RELAY
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Actuation Test	TCM RELAY
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Actuation Test	SHIFT LOCK SOL
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Special Function	Clutch Gear Learning

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Special Function	Disengaging The Gear
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Special Function	Gear Position Test
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Special Function	Read Clutch Gear Learning Data
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Special Function	Show Oil Temp History
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Special Function	High Oil Temp Warning History
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Special Function	Delete Gear Position Learning Value
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Special Function	Delete Clutch A Learning Value
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Special Function	Delete Clutch B Learning Value
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Special Function	Write Previous Clutch Learning Value
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Special Function	Erase Cltch Enggmt Prsr Crctn
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Special Function	OIL Temp History Reset
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Special Function	Adjust Clutch A Capacity
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Special Function	Adjust Clutch B Capacity
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Special Function	Clutch A Touch Point
NISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Special Function	Clutch B Touch Point
NISSAN	All Mode	2006 - 2017	TCM (Transmission Control Module)	Module Information	
NISSAN	All Mode	2006 - 2017	TCM (Transmission Control Module)	Module Information	
DFNISSAN	All Mode	Up to 2017	Engine	Read Fault Code	
DFNISSAN	All Mode	Up to 2017	Engine	Clear Fault Code	
DFNISSAN	All Mode	Up to 2017	Engine	Read Data Stream	
DFNISSAN	All Mode	Up to 2017	Engine	Read Freeze Frame	
DFNISSAN	All Mode	Up to 2017	Engine	Module Information	
DFNISSAN	All Mode	Up to 2017	Engine	Function Test	
DFNISSAN	All Mode	Up to 2017	Engine	Actuation Test	IACV-AAC/V OPENING
DFNISSAN	All Mode	Up to 2017	Engine	Actuation Test	EGR CONT (MODE 1)
DFNISSAN	All Mode	Up to 2017	Engine	Actuation Test	TARGET FAN RPM
DFNISSAN	All Mode	Up to 2017	Engine	Actuation Test	EGRC SOLENOID VALVE
DFNISSAN	All Mode	Up to 2017	Engine	Actuation Test	P/REG CONT SOL/V
DFNISSAN	All Mode	Up to 2017	Engine	Actuation Test	VALVE TIMING SOL
DFNISSAN	All Mode	Up to 2017	Engine	Actuation Test	SWIRL CONT SOL VALVE
DFNISSAN	All Mode	Up to 2017	Engine	Actuation Test	AIR COND RLY
DFNISSAN	All Mode	Up to 2017	Engine	Actuation Test	VVL S/V
DFNISSAN	All Mode	Up to 2017	Engine	Actuation Test	INTAKE DUCT S/V
DFNISSAN	All Mode	Up to 2017	Engine	Actuation Test	MAP/BARO SW/V
DFNISSAN	All Mode	Up to 2017	Engine	Actuation Test	VC/V BYPASS/V
DFNISSAN	All Mode	Up to 2017	Engine	Actuation Test	Power Balance
DFNISSAN	All Mode	Up to 2017	Engine	Actuation Test	VENT CONT/V
DFNISSAN	All Mode	Up to 2017	Engine	Actuation Test	ENG COOLANT TEMP
DFNISSAN	All Mode	Up to 2017	Engine	Actuation Test	FUEL INJECTION
DFNISSAN	All Mode	Up to 2017	Engine	Actuation Test	Fuel/T Temp SEN
DFNISSAN	All Mode	Up to 2017	Engine	Actuation Test	PURG VOL CONT/V
DFNISSAN	All Mode	Up to 2017	Engine	Actuation Test	Fuel Pump Relay
DFNISSAN	All Mode	Up to 2017	Engine	Actuation Test	IGNITION TIMING
DFNISSAN	All Mode	Up to 2017	Engine	Actuation Test	V/T ASSIGN ANGLE
DFNISSAN	All Mode	Up to 2017	Engine	Actuation Test	VIAS S/V-1
DFNISSAN	All Mode	Up to 2017	Engine	Actuation Test	ENGINE MOUNT
DFNISSAN	All Mode	Up to 2017	Engine	Actuation Test	TUMBLE CONTROL VALVE
DFNISSAN	All Mode	Up to 2017	Engine	Actuation Test	FAN DUTY CONTROL
DFNISSAN	All Mode	Up to 2017	Engine	Actuation Test	ALTERNATOR DUTY
DFNISSAN	All Mode	Up to 2017	Engine	Actuation Test	VIAS S/V-2
DFNISSAN	All Mode	Up to 2017	Engine	Actuation Test	INT V/T ASSIGN ANGLE
DFNISSAN	All Mode	Up to 2017	Engine	Actuation Test	EXH V/T ASSIGN ANGLE
DFNISSAN	All Mode	Up to 2017	Engine	Actuation Test	COOLING FAN
DFNISSAN	All Mode	Up to 2017	Engine	Actuation Test	FPCM
DFNISSAN	All Mode	Up to 2017	Engine	Actuation Test	SUB FUEL CONT SOL/V
DFNISSAN	All Mode	Up to 2017	Engine	Actuation Test	Sub Fuel Pump Relay
DFNISSAN	All Mode	Up to 2017	Engine	Actuation Test	FUEL RETURN VALVA
DFNISSAN	All Mode	Up to 2017	Engine	Actuation Test	ALTERNATOR VOLTAGE
DFNISSAN	All Mode	Up to 2017	Engine	Actuation Test	Auto Stop Start
DFNISSAN	All Mode	Up to 2017	Engine	Actuation Test	FUEL SHUTOFF VALVE 1
DFNISSAN	All Mode	Up to 2017	Engine	Actuation Test	FUEL SHUTOFF VALVE 2
DFNISSAN	All Mode	Up to 2017	Engine	Actuation Test	FUEL SHUTOFF VALVE 3
DFNISSAN	All Mode	Up to 2017	Engine	Actuation Test	FUEL SHUTOFF VALVE
DFNISSAN	All Mode	Up to 2017	Engine	Actuation Test	FP RELAY2
DFNISSAN	All Mode	Up to 2017	Engine	Actuation Test	FP RELAY3
DFNISSAN	All Mode	Up to 2017	Engine	Actuation Test	EGR VOL CONT/V
DFNISSAN	All Mode	Up to 2017	Engine	Actuation Test	Pres Regulator
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	Idle Air Vol Learn
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	EVAP System Close
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	Fuel Pressure Release
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	Self-Learning Cont
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	TARGET IGN TIM ADJ
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	EXH V/T CONTROL LEARN

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	TARGET IDLE RPM ADJ
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	CO ADJUSTMENT
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	ETHANOL M/R ADJ
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	Vin Registration
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	AP POS LEARN CLR
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	TARGET IGN TIM HLD
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	CLSD THL POS LEARN
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	VVEL POS SEN ADJ PREP
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	M/T NEUTRAL POS LEARN
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	IGNITION TIMING ADJ
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	CHECK FUEL LINES
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	V/T CONTROL LEARN
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	WRT FUEL LEARN VALUE
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	A/F Initial Learning
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	Saving Data For Replc CPU
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	Writing Data For Replc CPU
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	STRT OPRTN CNTR CLEAR
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	CML B/DCHRG CNTR CLEAR
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	G Sensor Calibration
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	Valve Timing Offset Data Writing
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	Valve Timing Offset Data Clear
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	SC MAGNETIC CLUTCH ENGAGE COUNT CLEAR
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	Cumulative Sub-Battry Dischg Current Clear
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	SUB-STARTER&GENERATOR OPER COUNT CLEAR
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	Active Control Engine Mounting A
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	Active Control Engine Mounting B
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	A/F Sensor Response Diagnosis Status B1
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	A/F Sensor Response Diagnosis Status B2
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	Engine Coolant Bypass Valve
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	Misfire count (real-time)
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	Misfire count (past)
DFNISSAN	All Mode	Up to 2017	Engine	Read Fault Code	
DFNISSAN	All Mode	Up to 2017	Engine	Clear Fault Code	
DFNISSAN	All Mode	Up to 2017	Engine	Read Data Stream	
DFNISSAN	All Mode	Up to 2017	Engine	Module Information	
DFNISSAN	All Mode	Up to 2017	Engine	Function Test	
DFNISSAN	All Mode	Up to 2017	Engine	Actuation Test	THRTL POSITION
DFNISSAN	All Mode	Up to 2017	Engine	Actuation Test	EGR/V ANGEL
DFNISSAN	All Mode	Up to 2017	Engine	Actuation Test	SWIRL CONT S/V1
DFNISSAN	All Mode	Up to 2017	Engine	Actuation Test	GLOW RLY
DFNISSAN	All Mode	Up to 2017	Engine	Actuation Test	COOLING FAN
DFNISSAN	All Mode	Up to 2017	Engine	Actuation Test	TC BOOST CONT/V
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	Enter Injctr Calib Data
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	EGR/V LEARN CLR
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	TP POS LEARN CLR
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	DIF EX PRE LRN CLR
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	Service Regeneration
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	DPF Data Clear
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	A/F SEN LEAN CLR
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	PTO REGISTRATION
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	Vin Registration
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	Injector Learning Value Clear
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	Mixture Ratio Learning Value Clear
DFNISSAN	All Mode	2010 - 2011	Engine	Read Fault Code	
DFNISSAN	All Mode	2010 - 2011	Engine	Clear Fault Code	
DFNISSAN	All Mode	2010 - 2011	Engine	Read Data Stream	
DFNISSAN	All Mode	2010 - 2011	Engine	Module Information	
DFNISSAN	All Mode	2010 - 2011	Engine	Actuation Test	INJECTOR CYLINDER 1
DFNISSAN	All Mode	2010 - 2011	Engine	Actuation Test	INJECTOR CYLINDER 2
DFNISSAN	All Mode	2010 - 2011	Engine	Actuation Test	INJECTOR CYLINDER 3
DFNISSAN	All Mode	2010 - 2011	Engine	Actuation Test	INJECTOR CYLINDER 4
DFNISSAN	All Mode	2010 - 2011	Engine	Actuation Test	PREHEATER RELAY
DFNISSAN	All Mode	2010 - 2011	Engine	Actuation Test	FUEL PRESSURE SOLENOID/V
DFNISSAN	All Mode	2010 - 2011	Engine	Actuation Test	AIR INLET FLAP
DFNISSAN	All Mode	2010 - 2011	Engine	Actuation Test	FUEL FLOW SOLENOID/V
DFNISSAN	All Mode	2010 - 2011	Engine	Actuation Test	TURBOCHARGER CNTRL SOL/V
DFNISSAN	All Mode	2010 - 2011	Engine	Actuation Test	PRE ELEC CONSUM
DFNISSAN	All Mode	2010 - 2011	Engine	Actuation Test	HIGH PRES CIRCUIT LEAK TEST
DFNISSAN	All Mode	2010 - 2011	Engine	Actuation Test	Idle Speed Set Increment



**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
DFNISSAN	All Mode	2010 - 2011	Engine	Actuation Test	STATIC TEST OF ACTUATOR
DFNISSAN	All Mode	2010 - 2011	Engine	Special Function	Vin Registration
DFNISSAN	All Mode	2010 - 2011	Engine	Special Function	EGR Adaptives
DFNISSAN	All Mode	2010 - 2011	Engine	Special Function	Programmed Values
DFNISSAN	All Mode	2010 - 2011	Engine	Special Function	Prgrm Reinitialize
DFNISSAN	All Mode	2010 - 2011	Engine	Special Function	Pres REG Adaptive
DFNISSAN	All Mode	2010 - 2011	Engine	Special Function	Saving Data For Replc CPU
DFNISSAN	All Mode	2010 - 2011	Engine	Special Function	Writing Data For Replc CPU
DFNISSAN	All Mode	2006 - 2014	Engine	Read Fault Code	
DFNISSAN	All Mode	2006 - 2014	Engine	Clear Fault Code	
DFNISSAN	All Mode	2006 - 2014	Engine	Read Data Stream	
DFNISSAN	All Mode	2006 - 2014	Engine	Actuation Test	TC BST CONT S/V
DFNISSAN	All Mode	2006 - 2014	Engine	Actuation Test	FRP CONTROL VALVE
DFNISSAN	All Mode	2006 - 2014	Engine	Actuation Test	GLOW CONTROL UNIT
DFNISSAN	All Mode	2006 - 2014	Engine	Actuation Test	EGR COOLER BYPASS CONT S/V
DFNISSAN	All Mode	2006 - 2014	Engine	Actuation Test	TROTTLER VALVE
DFNISSAN	All Mode	2006 - 2014	Engine	Actuation Test	Fuel Pump
DFNISSAN	All Mode	2006 - 2014	Engine	Actuation Test	TURBOCHARGER COOLING PUMP
DFNISSAN	All Mode	2006 - 2014	Engine	Special Function	Service Regeneration
DFNISSAN	All Mode	2006 - 2014	Engine	Special Function	LEARNING
DFNISSAN	All Mode	2006 - 2014	Engine	Special Function	INI ADJ VAL REGIST
DFNISSAN	All Mode	2006 - 2014	Engine	Special Function	ZPC VALUE RESET
DFNISSAN	All Mode	2006 - 2014	Engine	Special Function	P062F EXCLUSIVE FUNCTION
DFNISSAN	All Mode	2006 - 2014	Engine	Special Function	EGR/V LEARN CLR
DFNISSAN	All Mode	2006 - 2014	Engine	Special Function	DPF Data Clear
DFNISSAN	All Mode	2006 - 2014	Engine	Special Function	Saving Data For Replc CPU
DFNISSAN	All Mode	2006 - 2014	Engine	Special Function	Writing Data For Replc CPU
DFNISSAN	All Mode	2008 - 2015	Engine	Read Fault Code	
DFNISSAN	All Mode	2008 - 2015	Engine	Clear Fault Code	
DFNISSAN	All Mode	2008 - 2015	Engine	Read Data Stream	
DFNISSAN	All Mode	2008 - 2015	Engine	Module Information	
DFNISSAN	All Mode	2008 - 2015	Engine	Actuation Test	Fuel Pump RLY
DFNISSAN	All Mode	2008 - 2015	Engine	Actuation Test	DOWN/ST O2 HT
DFNISSAN	All Mode	2008 - 2015	Engine	Actuation Test	UP/ST O2 HTR
DFNISSAN	All Mode	2008 - 2015	Engine	Actuation Test	Canister Bleed Sol/V
DFNISSAN	All Mode	2008 - 2015	Engine	Actuation Test	Motorised Throttle
DFNISSAN	All Mode	2008 - 2015	Engine	Actuation Test	A/C compressor relay control
DFNISSAN	All Mode	2008 - 2015	Engine	Actuation Test	FAN UNIT LOW
DFNISSAN	All Mode	2008 - 2015	Engine	Actuation Test	FAN UT HI SPD
DFNISSAN	All Mode	2008 - 2015	Engine	Actuation Test	Flex-fuel additional solenoid valve
DFNISSAN	All Mode	2008 - 2015	Engine	Actuation Test	Flex-fuel additional pump
DFNISSAN	All Mode	2008 - 2015	Engine	Special Function	Programmed Values
DFNISSAN	All Mode	2008 - 2015	Engine	Special Function	WRITE V. I. N.
DFNISSAN	All Mode	2010 - 2011	Engine	Read Fault Code	
DFNISSAN	All Mode	2010 - 2011	Engine	Clear Fault Code	
DFNISSAN	All Mode	2010 - 2011	Engine	Read Data Stream	
DFNISSAN	All Mode	2010 - 2011	Engine	Module Information	
DFNISSAN	All Mode	2010 - 2011	Engine	Actuation Test	INJECTOR CYLINDER 1
DFNISSAN	All Mode	2010 - 2011	Engine	Actuation Test	INJECTOR CYLINDER 2
DFNISSAN	All Mode	2010 - 2011	Engine	Actuation Test	INJECTOR CYLINDER 3
DFNISSAN	All Mode	2010 - 2011	Engine	Actuation Test	INJECTOR CYLINDER 4
DFNISSAN	All Mode	2010 - 2011	Engine	Actuation Test	PREHEATER RELAY
DFNISSAN	All Mode	2010 - 2011	Engine	Actuation Test	FUEL PRESSURE SOLENOID/V
DFNISSAN	All Mode	2010 - 2011	Engine	Actuation Test	AIR INLET FLAP
DFNISSAN	All Mode	2010 - 2011	Engine	Actuation Test	FUEL FLOW SOLENOID/V
DFNISSAN	All Mode	2010 - 2011	Engine	Actuation Test	TURBOCHARGER CNTRL SOL/V
DFNISSAN	All Mode	2010 - 2011	Engine	Actuation Test	PRE ELEC CONSUM
DFNISSAN	All Mode	2010 - 2011	Engine	Actuation Test	HIGH PRES CIRCUIT LEAK TEST
DFNISSAN	All Mode	2010 - 2011	Engine	Actuation Test	STATIC TEST OF ACTUATOR
DFNISSAN	All Mode	2010 - 2011	Engine	Actuation Test	AC COMPRESSOR RELAY
DFNISSAN	All Mode	2010 - 2011	Engine	Actuation Test	HEATER PLUG3
DFNISSAN	All Mode	2010 - 2011	Engine	Actuation Test	HEATER PLUG1 AND 2
DFNISSAN	All Mode	2010 - 2011	Engine	Actuation Test	HEATER PLUG4
DFNISSAN	All Mode	2010 - 2011	Engine	Actuation Test	Fuel Pump Relay
DFNISSAN	All Mode	2010 - 2011	Engine	Actuation Test	EXHAUST FUEL INJECTOR
DFNISSAN	All Mode	2010 - 2011	Engine	Actuation Test	DIAG CAP TEMP DPF
DFNISSAN	All Mode	2010 - 2011	Engine	Special Function	Service Regeneration
DFNISSAN	All Mode	2010 - 2011	Engine	Special Function	Vin Registration
DFNISSAN	All Mode	2010 - 2011	Engine	Special Function	EGR Adaptives
DFNISSAN	All Mode	2010 - 2011	Engine	Special Function	Programmed Values
DFNISSAN	All Mode	2010 - 2011	Engine	Special Function	Prgrm Reinitialize
DFNISSAN	All Mode	2010 - 2011	Engine	Special Function	Pres REG Adaptive
DFNISSAN	All Mode	2010 - 2011	Engine	Special Function	DPF Data Clear
DFNISSAN	All Mode	2010 - 2011	Engine	Special Function	Saving Data For Replc CPU
DFNISSAN	All Mode	2010 - 2011	Engine	Special Function	Writing Data For Replc CPU
DFNISSAN	All Mode	2005 - 2014	Engine	Read Fault Code	
DFNISSAN	All Mode	2005 - 2014	Engine	Clear Fault Code	
DFNISSAN	All Mode	2005 - 2014	Engine	Read Data Stream	

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
DFNISSAN	All Mode	2005 - 2014	Engine	Module Information	
DFNISSAN	All Mode	2005 - 2014	Engine	Function Test	
DFNISSAN	All Mode	2005 - 2014	Engine	Actuation Test	INJECTOR CYLINDER 1
DFNISSAN	All Mode	2005 - 2014	Engine	Actuation Test	INJECTOR CYLINDER 2
DFNISSAN	All Mode	2005 - 2014	Engine	Actuation Test	INJECTOR CYLINDER 3
DFNISSAN	All Mode	2005 - 2014	Engine	Actuation Test	INJECTOR CYLINDER 4
DFNISSAN	All Mode	2005 - 2014	Engine	Actuation Test	PREHEATER RELAY
DFNISSAN	All Mode	2005 - 2014	Engine	Actuation Test	FUEL PRESSURE SOLENOID/V
DFNISSAN	All Mode	2005 - 2014	Engine	Actuation Test	AIR INLET FLAP
DFNISSAN	All Mode	2005 - 2014	Engine	Actuation Test	FUEL FLOW SOLENOID/V
DFNISSAN	All Mode	2005 - 2014	Engine	Actuation Test	TURBOCHARGER CNTRL SOL/V
DFNISSAN	All Mode	2005 - 2014	Engine	Actuation Test	PRE ELEC CONSUM
DFNISSAN	All Mode	2005 - 2014	Engine	Actuation Test	HIGH PRES CIRCUIT LEAK TEST
DFNISSAN	All Mode	2005 - 2014	Engine	Actuation Test	STATIC TEST OF ACTUATOR
DFNISSAN	All Mode	2005 - 2014	Engine	Actuation Test	AC COMPRESSOR RELAY
DFNISSAN	All Mode	2005 - 2014	Engine	Special Function	Vin Registration
DFNISSAN	All Mode	2005 - 2014	Engine	Special Function	EGR Adaptives
DFNISSAN	All Mode	2005 - 2014	Engine	Special Function	Programmed Values
DFNISSAN	All Mode	2005 - 2014	Engine	Special Function	Prgrm Reinitialize
DFNISSAN	All Mode	2005 - 2014	Engine	Special Function	Pres REG Adaptive
DFNISSAN	All Mode	2005 - 2014	Engine	Special Function	Saving Data For Replc CPU
DFNISSAN	All Mode	2005 - 2014	Engine	Special Function	Writing Data For Replc CPU
DFNISSAN	All Mode	2008 - 2012	Engine	Read Fault Code	
DFNISSAN	All Mode	2008 - 2012	Engine	Clear Fault Code	
DFNISSAN	All Mode	2008 - 2012	Engine	Read Data Stream	
DFNISSAN	All Mode	2008 - 2012	Engine	Actuation Test	TC BST CONT S/V
DFNISSAN	All Mode	2008 - 2012	Engine	Actuation Test	FRP CONTROL VALVE
DFNISSAN	All Mode	2008 - 2012	Engine	Actuation Test	GLOW CONTROL UNIT
DFNISSAN	All Mode	2008 - 2012	Engine	Actuation Test	EGR COOLER BYPASS CONT S/V
DFNISSAN	All Mode	2008 - 2012	Engine	Actuation Test	TROTTL VALVE
DFNISSAN	All Mode	2008 - 2012	Engine	Actuation Test	Fuel Pump
DFNISSAN	All Mode	2008 - 2012	Engine	Actuation Test	TURBOCHARGER COOLING PUMP
DFNISSAN	All Mode	2008 - 2012	Engine	Special Function	LEARNING
DFNISSAN	All Mode	2008 - 2012	Engine	Special Function	INTJ ADJ VAL REGIST
DFNISSAN	All Mode	2008 - 2012	Engine	Special Function	ZFC VALUE RESET
DFNISSAN	All Mode	2008 - 2012	Engine	Special Function	P062F EXCLUSIVE FUNCTION
DFNISSAN	All Mode	2008 - 2012	Engine	Special Function	EGR/V LEARN CLR
DFNISSAN	All Mode	2008 - 2012	Engine	Special Function	DPF Data Clear
DFNISSAN	All Mode	2008 - 2012	Engine	Special Function	OC DATA CLEAR
DFNISSAN	All Mode	2008 - 2012	Engine	Special Function	Service Regeneration
DFNISSAN	All Mode	2008 - 2012	Engine	Special Function	Saving Data For Replc CPU
DFNISSAN	All Mode	2008 - 2012	Engine	Special Function	Writing Data For Replc CPU
DFNISSAN	All Mode	2011 - 2016	Engine	Read Fault Code	
DFNISSAN	All Mode	2011 - 2016	Engine	Clear Fault Code	
DFNISSAN	All Mode	2011 - 2016	Engine	Read Data Stream	
DFNISSAN	All Mode	2011 - 2016	Engine	Actuation Test	TC BST CONT S/V
DFNISSAN	All Mode	2011 - 2016	Engine	Actuation Test	FRP CONTROL VALVE
DFNISSAN	All Mode	2011 - 2016	Engine	Actuation Test	GLOW CONTROL UNIT
DFNISSAN	All Mode	2011 - 2016	Engine	Actuation Test	EGR COOLER BYPASS CONT S/V
DFNISSAN	All Mode	2011 - 2016	Engine	Actuation Test	TROTTL VALVE
DFNISSAN	All Mode	2011 - 2016	Engine	Actuation Test	Fuel Pump
DFNISSAN	All Mode	2011 - 2016	Engine	Actuation Test	TURBOCHARGER COOLING PUMP
DFNISSAN	All Mode	2011 - 2016	Engine	Actuation Test	ENGINE MOUNTING
DFNISSAN	All Mode	2011 - 2016	Engine	Special Function	Service Regeneration
DFNISSAN	All Mode	2011 - 2016	Engine	Special Function	INTJ ADJ VAL REGIST
DFNISSAN	All Mode	2011 - 2016	Engine	Special Function	TP POS LEARN CLR
DFNISSAN	All Mode	2011 - 2016	Engine	Special Function	EGR/V LEARN CLR
DFNISSAN	All Mode	2011 - 2016	Engine	Special Function	DPF Data Clear
DFNISSAN	All Mode	2011 - 2016	Engine	Special Function	EXH Fuel Inj Data Clear
DFNISSAN	All Mode	2011 - 2016	Engine	Special Function	ZFC VALUE RESET
DFNISSAN	All Mode	Up to 2009	Engine	Read Fault Code	
DFNISSAN	All Mode	Up to 2009	Engine	Clear Fault Code	
DFNISSAN	All Mode	Up to 2009	Engine	Read Data Stream	
DFNISSAN	All Mode	Up to 2009	Engine	Module Information	
DFNISSAN	All Mode	Up to 2009	Engine	Actuation Test	EGR SOLENOID VALVE
DFNISSAN	All Mode	Up to 2009	Engine	Actuation Test	PREHEATER UNIT
DFNISSAN	All Mode	Up to 2009	Engine	Actuation Test	TURBO SOL VALVE
DFNISSAN	All Mode	Up to 2009	Engine	Actuation Test	RAIL PRESS REG
DFNISSAN	All Mode	Up to 2009	Engine	Actuation Test	DAMPER FLAP
DFNISSAN	All Mode	Up to 2009	Engine	Actuation Test	LOCK INJECTOR CTRL
DFNISSAN	All Mode	Up to 2009	Engine	Actuation Test	UNLK INJECTOR CTRL
DFNISSAN	All Mode	Up to 2009	Engine	Actuation Test	PRE ELEC CONSUM
DFNISSAN	All Mode	Up to 2009	Engine	Special Function	Saving Data For Replc CPU
DFNISSAN	All Mode	Up to 2009	Engine	Special Function	Writing Data For Replc CPU
DFNISSAN	All Mode	Up to 2009	Engine	Special Function	Programmed Values
DFNISSAN	All Mode	Up to 2009	Engine	Special Function	Enter Injctr Calib Data
DFNISSAN	All Mode	Up to 2009	Engine	Special Function	EGR Adaptives
DFNISSAN	All Mode	Up to 2014	Engine	Read Fault Code	
DFNISSAN	All Mode	Up to 2014	Engine	Clear Fault Code	
DFNISSAN	All Mode	Up to 2014	Engine	Read Data Stream	

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
DFNISSAN	All Mode	Up to 2014	Engine	Module Information	
DFNISSAN	All Mode	Up to 2014	Engine	Actuation Test	PREHEATER UNIT
DFNISSAN	All Mode	Up to 2014	Engine	Actuation Test	EGR SOLENOID VALVE
DFNISSAN	All Mode	Up to 2014	Engine	Actuation Test	INJECTOR CYLINDER 1
DFNISSAN	All Mode	Up to 2014	Engine	Actuation Test	INJECTOR CYLINDER 2
DFNISSAN	All Mode	Up to 2014	Engine	Actuation Test	INJECTOR CYLINDER 3
DFNISSAN	All Mode	Up to 2014	Engine	Actuation Test	INJECTOR CYLINDER 4
DFNISSAN	All Mode	Up to 2014	Engine	Actuation Test	HIGH PRESSURE PUMP
DFNISSAN	All Mode	Up to 2014	Engine	Actuation Test	STATIC TEST
DFNISSAN	All Mode	Up to 2014	Engine	Actuation Test	HIGH PRESS CIRC LEAK T
DFNISSAN	All Mode	Up to 2014	Engine	Special Function	Vin Registration
DFNISSAN	All Mode	Up to 2014	Engine	Special Function	Programmed Values
DFNISSAN	All Mode	Up to 2014	Engine	Special Function	EGR Adaptives
DFNISSAN	All Mode	Up to 2014	Engine	Special Function	Reset Pump Forcefeeding
DFNISSAN	All Mode	Up to 2014	Engine	Special Function	Reset Injctr Adaptive
DFNISSAN	All Mode	Up to 2014	Engine	Special Function	Saving Data For Replc CPU
DFNISSAN	All Mode	Up to 2014	Engine	Special Function	Writing Data For Replc CPU
DFNISSAN	All Mode	Up to 2014	Engine	Special Function	Enter Injctr Calib Data
DFNISSAN	All Mode	Up to 2014	Engine	Special Function	Speed Limiter
DFNISSAN	All Mode	Up to 2017	Engine	Read Fault Code	
DFNISSAN	All Mode	Up to 2017	Engine	Clear Fault Code	
DFNISSAN	All Mode	Up to 2017	Engine	Read Data Stream	
DFNISSAN	All Mode	Up to 2017	Engine	Actuation Test	COOLING FAN
DFNISSAN	All Mode	Up to 2017	Engine	Actuation Test	INJ TIMING
DFNISSAN	All Mode	Up to 2017	Engine	Actuation Test	ENG COOLANT TEMP
DFNISSAN	All Mode	Up to 2017	Engine	Actuation Test	Fuel/T Temp SEN
DFNISSAN	All Mode	Up to 2017	Engine	Actuation Test	ALTERNATOR DUTY
DFNISSAN	All Mode	Up to 2017	Engine	Actuation Test	Tc boost control actuator
DFNISSAN	All Mode	Up to 2017	Engine	Actuation Test	EGR COOLER BYPASS VALVE
DFNISSAN	All Mode	Up to 2017	Engine	Actuation Test	PRES REGULATOR
DFNISSAN	All Mode	Up to 2017	Engine	Actuation Test	TARGET ETC ANGLE
DFNISSAN	All Mode	Up to 2017	Engine	Actuation Test	Power Balance
DFNISSAN	All Mode	Up to 2017	Engine	Actuation Test	TRG EGR/V angel
DFNISSAN	All Mode	Up to 2017	Engine	Actuation Test	GLOW RLY
DFNISSAN	All Mode	Up to 2017	Engine	Actuation Test	ENGINE MOUNTING
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	Enter Injctr Calib Data
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	Service Regeneration
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	PTO REGISTRATION
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	Pump Leant Clear
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	A/F SEN 1 LEARN CLR
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	DF EXH PRES SEN LEARN CLR
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	E/R AIR TEMP SEN LEARN CLR
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	Fuel INJ quantity learning
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	DPF Data Clear
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	Config CLR
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	INJ ADJ VAL CLR
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	A/F SEN 2 LEARN CLR
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	EGR/V LEARN CLEAR
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	Exh Prsr Sen Learn Clear
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	OC DATA CLEAR
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	Saving Data For Replc CPU
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	Writing Data For Replc CPU
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	Desulfuration
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	TC BOOST CONTROL ACTUATOR POSITION LEARNING
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	Vin Registration
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	Service Regene
DFNISSAN	All Mode	2010 - 2016	Engine	Read Fault Code	
DFNISSAN	All Mode	2010 - 2016	Engine	Clear Fault Code	
DFNISSAN	All Mode	2010 - 2016	Engine	Read Data Stream	
DFNISSAN	All Mode	2010 - 2016	Engine	Actuation Test	TURBOCHARGING SOLENOID VALVE
DFNISSAN	All Mode	2010 - 2016	Engine	Actuation Test	AIR INLET FLAP
DFNISSAN	All Mode	2010 - 2016	Engine	Actuation Test	EGR BYPASS
DFNISSAN	All Mode	2010 - 2016	Engine	Actuation Test	THERMOPLNGR RLY N1
DFNISSAN	All Mode	2010 - 2016	Engine	Actuation Test	THERMOPLNGR RLY N2
DFNISSAN	All Mode	2010 - 2016	Engine	Actuation Test	THERMOPLNGR 3 RLY
DFNISSAN	All Mode	2010 - 2016	Engine	Actuation Test	PREHEATER RLY
DFNISSAN	All Mode	2010 - 2016	Engine	Actuation Test	DPF INJECTOR
DFNISSAN	All Mode	2010 - 2016	Engine	Actuation Test	DPF INJECTOR SOLENOID VALVE
DFNISSAN	All Mode	2010 - 2016	Engine	Actuation Test	EGR VALVE
DFNISSAN	All Mode	2010 - 2016	Engine	Actuation Test	INJECTION SOL/V OPENING PF
DFNISSAN	All Mode	2010 - 2016	Engine	Actuation Test	ENGINE ADAPTIVES
DFNISSAN	All Mode	2010 - 2016	Engine	Actuation Test	DPF RELATIVE PRESSURE SENSOR
DFNISSAN	All Mode	2010 - 2016	Engine	Actuation Test	EXHAUST FUEL INJECTOR CIRCUIT
DFNISSAN	All Mode	2010 - 2016	Engine	Actuation Test	CC/SL PRGRM
DFNISSAN	All Mode	2010 - 2016	Engine	Actuation Test	E/O CC/SL PRGRM
DFNISSAN	All Mode	2010 - 2016	Engine	Actuation Test	FUEL SPLY PREV

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
DFNISSAN	All Mode	2010 - 2016	Engine	Actuation Test	EGR VALVE PROGRAMMING
DFNISSAN	All Mode	2010 - 2016	Engine	Actuation Test	AIR DAMPER VALVE PROGRAMMING
DFNISSAN	All Mode	2010 - 2016	Engine	Actuation Test	PRESSURE REGULATION ADAPTIVES
DFNISSAN	All Mode	2010 - 2016	Engine	Special Function	Service Regeneration
DFNISSAN	All Mode	2010 - 2016	Engine	Special Function	Enter Injector Codes
DFNISSAN	All Mode	2010 - 2016	Engine	Special Function	After Dpf Regeneration
DFNISSAN	All Mode	2010 - 2016	Engine	Special Function	After Dpf Replacement
DFNISSAN	All Mode	2010 - 2016	Engine	Special Function	Saving Data For Replc CPU
DFNISSAN	All Mode	2010 - 2016	Engine	Special Function	Writing Data For Replc CPU
DFNISSAN	All Mode	2010 - 2016	Engine	Read Fault Code	
DFNISSAN	All Mode	2010 - 2016	Engine	Clear Fault Code	
DFNISSAN	All Mode	2010 - 2016	Engine	Read Data Stream	
DFNISSAN	All Mode	2010 - 2016	Engine	Actuation Test	HIGH PRESSURE CIRCUIT LEAK TEST
DFNISSAN	All Mode	2010 - 2016	Engine	Actuation Test	AIR INLET FLAP
DFNISSAN	All Mode	2010 - 2016	Engine	Actuation Test	TURBOCHARGING SOLENOID VALVE
DFNISSAN	All Mode	2010 - 2016	Engine	Actuation Test	EGR VALVE
DFNISSAN	All Mode	2010 - 2016	Engine	Actuation Test	THERMOPLNGR RLY N1
DFNISSAN	All Mode	2010 - 2016	Engine	Actuation Test	THERMOPLNGR RLY N2
DFNISSAN	All Mode	2010 - 2016	Engine	Actuation Test	THERMOPLNGR 3 RLY
DFNISSAN	All Mode	2010 - 2016	Engine	Actuation Test	PREHEATER RLY
DFNISSAN	All Mode	2010 - 2016	Engine	Actuation Test	EGR BYPASS
DFNISSAN	All Mode	2010 - 2016	Engine	Actuation Test	DPF INJECTOR
DFNISSAN	All Mode	2010 - 2016	Engine	Actuation Test	DPF INJECTOR SOLENOID VALVE
DFNISSAN	All Mode	2010 - 2016	Engine	Actuation Test	INJECTOR CYLINDER 1
DFNISSAN	All Mode	2010 - 2016	Engine	Actuation Test	INJECTOR CYLINDER 2
DFNISSAN	All Mode	2010 - 2016	Engine	Actuation Test	INJECTOR CYLINDER 3
DFNISSAN	All Mode	2010 - 2016	Engine	Actuation Test	INJECTOR CYLINDER 4
DFNISSAN	All Mode	2010 - 2016	Engine	Actuation Test	RAIL PRS SEN ADAPTIVES
DFNISSAN	All Mode	2010 - 2016	Engine	Actuation Test	PRESSURE REGULATION ADAPTIVES
DFNISSAN	All Mode	2010 - 2016	Engine	Actuation Test	EGR VALVE PROGRAMMING
DFNISSAN	All Mode	2010 - 2016	Engine	Actuation Test	AIR PATH PROGRAMMING
DFNISSAN	All Mode	2010 - 2016	Engine	Actuation Test	DPF RELATIVE PRESSURE SENSOR
DFNISSAN	All Mode	2010 - 2016	Engine	Actuation Test	FUEL FLOW REGULATOR
DFNISSAN	All Mode	2010 - 2016	Engine	Actuation Test	EXHAUST FUEL INJECTOR CIRCUIT
DFNISSAN	All Mode	2010 - 2016	Engine	Actuation Test	AIR DAMPER VALVE PROGRAMMING
DFNISSAN	All Mode	2010 - 2016	Engine	Actuation Test	ENGINE ADAPTIVES
DFNISSAN	All Mode	2010 - 2016	Engine	Actuation Test	After DPF Regeneration
DFNISSAN	All Mode	2010 - 2016	Engine	Actuation Test	FUEL SPLY PREV
DFNISSAN	All Mode	2010 - 2016	Engine	Actuation Test	STP FUEL SPLY PREV
DFNISSAN	All Mode	2010 - 2016	Engine	Actuation Test	SPEED LIMITER/CRUISE CONTROL ACTIVATION
DFNISSAN	All Mode	2010 - 2016	Engine	Special Function	Vin Registration
DFNISSAN	All Mode	2010 - 2016	Engine	Special Function	Service Regeneration
DFNISSAN	All Mode	2010 - 2016	Engine	Special Function	Commercial VHCL idle SPD MOD
DFNISSAN	All Mode	2010 - 2016	Engine	Special Function	Speed Limiter
DFNISSAN	All Mode	2010 - 2016	Engine	Special Function	Enter Injector Codes
DFNISSAN	All Mode	2010 - 2016	Engine	Special Function	Saving Data For Replc CPU
DFNISSAN	All Mode	2010 - 2016	Engine	Special Function	Writing Data For Replc CPU
DFNISSAN	All Mode	2012 - 2015	Engine	Read Fault Code	
DFNISSAN	All Mode	2012 - 2015	Engine	Clear Fault Code	
DFNISSAN	All Mode	2012 - 2015	Engine	Read Data Stream	
DFNISSAN	All Mode	2012 - 2015	Engine	Module Information	
DFNISSAN	All Mode	2012 - 2015	Engine	Actuation Test	INJECTOR CYLINDER 1
DFNISSAN	All Mode	2012 - 2015	Engine	Actuation Test	INJECTOR CYLINDER 2
DFNISSAN	All Mode	2012 - 2015	Engine	Actuation Test	INJECTOR CYLINDER 3
DFNISSAN	All Mode	2012 - 2015	Engine	Actuation Test	INJECTOR CYLINDER 4
DFNISSAN	All Mode	2012 - 2015	Engine	Actuation Test	Fan Unit Low Speed RLY
DFNISSAN	All Mode	2012 - 2015	Engine	Actuation Test	Fan Unit High Speed RLY
DFNISSAN	All Mode	2012 - 2015	Engine	Actuation Test	A/C compressor relay control
DFNISSAN	All Mode	2012 - 2015	Engine	Actuation Test	Fuel Pump RLY
DFNISSAN	All Mode	2012 - 2015	Engine	Actuation Test	Canister Bleed SOL/V
DFNISSAN	All Mode	2012 - 2015	Engine	Actuation Test	Motorised Throttle
DFNISSAN	All Mode	2012 - 2015	Engine	Actuation Test	FLYWHL TGT PG
DFNISSAN	All Mode	2012 - 2015	Engine	Actuation Test	Richness Regulation Programming
DFNISSAN	All Mode	2012 - 2015	Engine	Actuation Test	Programming Throttle Limits
DFNISSAN	All Mode	2012 - 2015	Engine	Actuation Test	ENGINE ADAPTIVES
DFNISSAN	All Mode	2012 - 2015	Engine	Special Function	Vin Registration
DFNISSAN	All Mode	2012 - 2015	Engine	Special Function	Start OBD test: Catalytic converter

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

<b>make</b>	<b>model</b>	<b>year</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
DFNISSAN	All Mode	2012 - 2015	Engine	Special Function	Start OBD test: O2 sensor
DFNISSAN	All Mode	2012 - 2015	Engine	Special Function	Write Saved Data
DFNISSAN	All Mode	2012 - 2015	Engine	Special Function	Save Computer Data
DFNISSAN	All Mode	2010 - 2011	Engine	Read Fault Code	
DFNISSAN	All Mode	2010 - 2011	Engine	Clear Fault Code	
DFNISSAN	All Mode	2010 - 2011	Engine	Read Data Stream	
DFNISSAN	All Mode	2010 - 2011	Engine	Module Information	
DFNISSAN	All Mode	2010 - 2011	Engine	Actuation Test	TURBOCHARGING SOLENOID VALVE
DFNISSAN	All Mode	2010 - 2011	Engine	Actuation Test	AIR INLET FLAP
DFNISSAN	All Mode	2010 - 2011	Engine	Actuation Test	THERMOPLNGR RLY N1
DFNISSAN	All Mode	2010 - 2011	Engine	Actuation Test	THERMOPLNGR RLY N2
DFNISSAN	All Mode	2010 - 2011	Engine	Actuation Test	THERMOPLNGR 3 RLY
DFNISSAN	All Mode	2010 - 2011	Engine	Actuation Test	PREHEATER RLY
DFNISSAN	All Mode	2010 - 2011	Engine	Actuation Test	EGR VALVE
DFNISSAN	All Mode	2010 - 2011	Engine	Actuation Test	PUMP PRESSURE REGULATOR
DFNISSAN	All Mode	2010 - 2011	Engine	Actuation Test	SWIRL FLAP VOLTAGE
DFNISSAN	All Mode	2010 - 2011	Engine	Actuation Test	CONTROLLED CL THERMOS
DFNISSAN	All Mode	2010 - 2011	Engine	Actuation Test	Fuel Pump
DFNISSAN	All Mode	2010 - 2011	Engine	Actuation Test	EXHAUST E/THROTTLE CONTROL ACTUATOR
DFNISSAN	All Mode	2010 - 2011	Engine	Actuation Test	LOW PRESSURE EGR VALVE
DFNISSAN	All Mode	2010 - 2011	Engine	Special Function	Enter Injector Codes
DFNISSAN	All Mode	2010 - 2011	Engine	Special Function	Particle Filter Regeneration
DFNISSAN	All Mode	2010 - 2011	Engine	Special Function	Vin Registration
DFNISSAN	All Mode	2010 - 2011	Engine	Special Function	Egr Valve Programming
DFNISSAN	All Mode	2010 - 2011	Engine	Special Function	Air Damper Valve Programming
DFNISSAN	All Mode	2010 - 2011	Engine	Special Function	CC/SL PRGRM
DFNISSAN	All Mode	2010 - 2011	Engine	Special Function	E/O CC/SL PRGRM
DFNISSAN	All Mode	2010 - 2011	Engine	Special Function	Flywhl TGT PG
DFNISSAN	All Mode	2010 - 2011	Engine	Special Function	Prpr Rich Sen Prog
DFNISSAN	All Mode	2010 - 2011	Engine	Special Function	Exhaust Throttle Valve Programming
DFNISSAN	All Mode	2010 - 2011	Engine	Special Function	Swirl Flap Programming
DFNISSAN	All Mode	2010 - 2011	Engine	Special Function	Turbocharger Programming
DFNISSAN	All Mode	2010 - 2011	Engine	Special Function	Adaptives On ETC Actuator Malfunction
DFNISSAN	All Mode	2010 - 2011	Engine	Special Function	Air Flow Meter Programming
DFNISSAN	All Mode	2010 - 2011	Engine	Special Function	Manifold Pressure Sensor Programming
DFNISSAN	All Mode	2010 - 2011	Engine	Special Function	Diff Exh PRES. SEN
DFNISSAN	All Mode	2010 - 2011	Engine	Special Function	Low Pressure EGR Valve Programming
DFNISSAN	All Mode	2010 - 2011	Engine	Special Function	Engine Adaptives
DFNISSAN	All Mode	2010 - 2011	Engine	Special Function	Swirl Flap
DFNISSAN	All Mode	2010 - 2011	Engine	Special Function	RAIL PRESSURE SENSOR ADAPTIVES
DFNISSAN	All Mode	2010 - 2011	Engine	Special Function	Number Of Starting Cycles
DFNISSAN	All Mode	2010 - 2011	Engine	Special Function	Injection Pump Adaptatives
DFNISSAN	All Mode	2010 - 2011	Engine	Special Function	Fuel Sply Prev
DFNISSAN	All Mode	2010 - 2011	Engine	Special Function	H/P Fuel Pump Initial Starts Counter Reset
DFNISSAN	All Mode	2010 - 2011	Engine	Special Function	H/P Fuel Pump Total Starts Counter Reset
DFNISSAN	All Mode	2010 - 2011	Engine	Special Function	Write Saved Data
DFNISSAN	All Mode	2010 - 2011	Engine	Special Function	Save Computer Data
DFNISSAN	All Mode	2010 - 2011	Engine	Special Function	After Dpf Replacement
DFNISSAN	All Mode	2010 - 2011	Engine	Special Function	After Dpf Regeneration
DFNISSAN	All Mode	2010 - 2011	Engine	Special Function	Engine OIL Oxidation Data Reset
DFNISSAN	All Mode	2010 - 2011	Engine	Special Function	Engine OIL Dilution Data Reset
DFNISSAN	All Mode	2014 - 2016	Engine	Read Fault Code	
DFNISSAN	All Mode	2014 - 2016	Engine	Clear Fault Code	
DFNISSAN	All Mode	2014 - 2016	Engine	Read Data Stream	
DFNISSAN	All Mode	2014 - 2016	Engine	Module Information	
DFNISSAN	All Mode	2014 - 2016	Engine	Actuation Test	Check Coolant Pump For Proper Operation
DFNISSAN	All Mode	2014 - 2016	Engine	Actuation Test	Check Engine Diagnosis Indicator Lamp
DFNISSAN	All Mode	2014 - 2016	Engine	Actuation Test	Check Engine Oil Pump Valve
DFNISSAN	All Mode	2014 - 2016	Engine	Actuation Test	Check EGR Actuator
DFNISSAN	All Mode	2014 - 2016	Engine	Actuation Test	Check EGR Cooler Bypss Sw Over Valve
DFNISSAN	All Mode	2014 - 2016	Engine	Actuation Test	Check Glow Plugs
DFNISSAN	All Mode	2014 - 2016	Engine	Actuation Test	Check Oil Spray Nozzles Shutoff Valve

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

<b>make</b>	<b>model</b>	<b>year</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
DFNISSAN	All Mode	2014 - 2016	Engine	Actuation Test	Check O2 Upstream Of Catalytic Converter
DFNISSAN	All Mode	2014 - 2016	Engine	Actuation Test	Check Rail Pressure Sensor
DFNISSAN	All Mode	2014 - 2016	Engine	Actuation Test	CK Temp Sen Upstream Of Dsl Prtcl Sen
DFNISSAN	All Mode	2014 - 2016	Engine	Actuation Test	Check Temp Sen Upstream Turbocharger
DFNISSAN	All Mode	2014 - 2016	Engine	Actuation Test	Check Tm Oil Cng Clnt Circulation Pump
DFNISSAN	All Mode	2014 - 2016	Engine	Actuation Test	Rail Pressure Sensor Offset Test
DFNISSAN	All Mode	2014 - 2016	Engine	Actuation Test	Check Boost Pressure Positioner
DFNISSAN	All Mode	2014 - 2016	Engine	Actuation Test	Check Fuel System High Pressure Pump
DFNISSAN	All Mode	2014 - 2016	Engine	Actuation Test	Check Cylinder 1 Glow Plug
DFNISSAN	All Mode	2014 - 2016	Engine	Actuation Test	Check Fuel HI Press Circ For Leaktightness
DFNISSAN	All Mode	2014 - 2016	Engine	Actuation Test	Exhaust Gas Regulation Dynamic Test
DFNISSAN	All Mode	2014 - 2016	Engine	Actuation Test	Check Pres Regulating Valve For Leaks
DFNISSAN	All Mode	2014 - 2016	Engine	Actuation Test	Check Preglow System
DFNISSAN	All Mode	2014 - 2016	Engine	Actuation Test	Automatic Leak Test Of Charge Air System
DFNISSAN	All Mode	2014 - 2016	Engine	Actuation Test	Compression Test
DFNISSAN	All Mode	2014 - 2016	Engine	Actuation Test	Ck Cont Response Of Press Reg Vlv At Idle
DFNISSAN	All Mode	2014 - 2016	Engine	Actuation Test	CK Cont Response Of Press Regulating VLV
DFNISSAN	All Mode	2014 - 2016	Engine	Actuation Test	Check Control Response Of Quantity Control Valve At Idle
DFNISSAN	All Mode	2014 - 2016	Engine	Actuation Test	Collation Of Diagnosis Performance Data
DFNISSAN	All Mode	2014 - 2016	Engine	Actuation Test	Check Fuel Filter Heater
DFNISSAN	All Mode	2014 - 2016	Engine	Actuation Test	Auto Stop Start
DFNISSAN	All Mode	2014 - 2016	Engine	Actuation Test	Check Intake Port Shutoff Actuator Motor
DFNISSAN	All Mode	2014 - 2016	Engine	Actuation Test	Ck Eng And Ac With Intgrted Cont Fan Motor
DFNISSAN	All Mode	2014 - 2016	Engine	Actuation Test	Alternator Diagnosis
DFNISSAN	All Mode	2014 - 2016	Engine	Special Function	Bleeding Of High Pressure Fuel Circuit
DFNISSAN	All Mode	2014 - 2016	Engine	Special Function	Diesel Particle Filter Regeneration
DFNISSAN	All Mode	2014 - 2016	Engine	Special Function	OPR Time Basic Diag Of TM Neutral Pos Sen
DFNISSAN	All Mode	2014 - 2016	Engine	Special Function	Teach In Boost Pressure Positioner
DFNISSAN	All Mode	2014 - 2016	Engine	Special Function	QK TCH IN OF ZERO QUNTY CALIB VAL AT IDL
DFNISSAN	All Mode	2014 - 2016	Engine	Special Function	Reset Of Contamination Level Of Air Filter
DFNISSAN	All Mode	2014 - 2016	Engine	Special Function	Reset Of Lambda Values
DFNISSAN	All Mode	2014 - 2016	Engine	Special Function	Replace Diesel Particulate Filter
DFNISSAN	All Mode	2014 - 2016	Engine	Special Function	Activation Of Fuel Pump
DFNISSAN	All Mode	2014 - 2016	Engine	Special Function	Reset Of Learned Values Of Cmsft Hall Sen
DFNISSAN	All Mode	2014 - 2016	Engine	Special Function	Teach In Of Intake Port Shutoff
DFNISSAN	All Mode	2014 - 2016	Engine	Special Function	QK TCH In Zero Qunty Calib Val While Driving
DFNISSAN	All Mode	2014 - 2016	Engine	Special Function	Teach In Of Throttle Valve Stop
DFNISSAN	All Mode	2014 - 2016	Engine	Special Function	Vin Registration
DFNISSAN	All Mode	2014 - 2016	Engine	Special Function	Injector Injection Quantity Adjustment
DFNISSAN	All Mode	2014 - 2016	Engine	Special Function	Control Deviation Charge Air System
DFNISSAN	All Mode	2014 - 2016	Engine	Special Function	STRT OPRIN CNTR CLEAR
DFNISSAN	All Mode	2014 - 2016	Engine	Special Function	H/P Fuel Pump Total Starts Counter Clear
DFNISSAN	All Mode	2014 - 2016	Engine	Special Function	Saving Data For Replc CPU
DFNISSAN	All Mode	2014 - 2016	Engine	Special Function	Writing Data For Replc CPU
DFNISSAN	All Mode	Up to 2017	Engine	Read Fault Code	
DFNISSAN	All Mode	Up to 2017	Engine	Clear Fault Code	
DFNISSAN	All Mode	Up to 2017	Engine	Read Data Stream	
DFNISSAN	All Mode	Up to 2017	Engine	Module Information	

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
DFNISSAN	All Mode	Up to 2017	Engine	Actuation Test	ENG COOLANT TEMP
DFNISSAN	All Mode	Up to 2017	Engine	Actuation Test	FUEL INJECTION
DFNISSAN	All Mode	Up to 2017	Engine	Actuation Test	PURG VOL CONT/V
DFNISSAN	All Mode	Up to 2017	Engine	Actuation Test	Fuel/T Temp SEN
DFNISSAN	All Mode	Up to 2017	Engine	Actuation Test	EGR VOL CONT/V
DFNISSAN	All Mode	Up to 2017	Engine	Actuation Test	Power Balance
DFNISSAN	All Mode	Up to 2017	Engine	Actuation Test	INT V/T ASSIGN ANGLE
DFNISSAN	All Mode	Up to 2017	Engine	Actuation Test	EXH V/T ASSIGN ANGLE
DFNISSAN	All Mode	Up to 2017	Engine	Actuation Test	Fuel Pump Relay
DFNISSAN	All Mode	Up to 2017	Engine	Actuation Test	VIAS S/V-1
DFNISSAN	All Mode	Up to 2017	Engine	Actuation Test	VENT CONTROL/V
DFNISSAN	All Mode	Up to 2017	Engine	Actuation Test	Supercharger Clutch Relay
DFNISSAN	All Mode	Up to 2017	Engine	Actuation Test	FAN DUTY CONTROL
DFNISSAN	All Mode	Up to 2017	Engine	Actuation Test	ALTERNATOR DUTY
DFNISSAN	All Mode	Up to 2017	Engine	Actuation Test	TUMBLE CONTROL VALVE
DFNISSAN	All Mode	Up to 2017	Engine	Actuation Test	VIAS S/V-2
DFNISSAN	All Mode	Up to 2017	Engine	Actuation Test	ALTERNATOR VOLTAGE
DFNISSAN	All Mode	Up to 2017	Engine	Actuation Test	Active Grille Shutter
DFNISSAN	All Mode	Up to 2017	Engine	Actuation Test	Auto Stop Start
DFNISSAN	All Mode	Up to 2017	Engine	Actuation Test	COOLING FAN
DFNISSAN	All Mode	Up to 2017	Engine	Actuation Test	FPCM
DFNISSAN	All Mode	Up to 2017	Engine	Actuation Test	IGNITION TIMING
DFNISSAN	All Mode	Up to 2017	Engine	Actuation Test	EGR CONTROL VALVE
DFNISSAN	All Mode	Up to 2017	Engine	Actuation Test	WASTEGATE ACTUATOR
DFNISSAN	All Mode	Up to 2017	Engine	Actuation Test	TC BYPASS VALVE
DFNISSAN	All Mode	Up to 2017	Engine	Actuation Test	ENGINE COOLANT ELECTIC WATER PUMP
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	Cumulative Sub-Battry Dischg Current Clear
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	Vin Registration
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	EVAP System Close
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	Idle Air Vol Learn
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	Self-Learning Cont
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	A/F Initial Learning
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	SUB-STARTER & GENERATOR OPER COUNT CLEAR
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	CML B/DCHRG CRNT CLEAR
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	SC MAGNETIC CLUTCH ENGAGE COUNT CLEAR
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	Fuel Pressure Release
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	CLSD THL POS LEARN
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	Active Control Engine Mounting A
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	Active Control Engine Mounting B
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	G Sensor Calibration
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	TARGET IGN TIM ADJ
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	TARGET IDLE RPM ADJ
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	Valve Timing Offset Data Writing
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	Valve Timing Offset Data Clear
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	STRT OPRTN CNTR CLEAR
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	VALVE TIMING ADJUSTMENT
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	WASTEGATE ACTUATOR POSI LEARN VALUE CLEAR
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	Engine Coolant Bypass Valve
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	Saving Data For Replc CPU
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	Writing Data For Replc CPU
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	Write Starter Operation Count
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	EGR control valve closed position learning
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	Electric intake valve timing control learning
DFNISSAN	All Mode	2013 - 2016	Engine	Read Fault Code	
DFNISSAN	All Mode	2013 - 2016	Engine	Clear Fault Code	
DFNISSAN	All Mode	2013 - 2016	Engine	Read Data Stream	
DFNISSAN	All Mode	2013 - 2016	Engine	Module Information	
DFNISSAN	All Mode	2013 - 2016	Engine	Actuation Test	Check Deceleration Air Switchover Valve
DFNISSAN	All Mode	2013 - 2016	Engine	Actuation Test	Check Engine Oil Pump Valve
DFNISSAN	All Mode	2013 - 2016	Engine	Actuation Test	Boost Pressure
DFNISSAN	All Mode	2013 - 2016	Engine	Actuation Test	Check Fuel Injectors
DFNISSAN	All Mode	2013 - 2016	Engine	Actuation Test	Check Fuel HI Press Circ For Leaktightness
DFNISSAN	All Mode	2013 - 2016	Engine	Actuation Test	Check Fuel High Pressure Circuit
DFNISSAN	All Mode	2013 - 2016	Engine	Actuation Test	Check Fuel Press And Temp Sensor

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

<b>make</b>	<b>model</b>	<b>year</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
DFNISSAN	All Mode	2013 - 2016	Engine	Actuation Test	Auto Stop Start
DFNISSAN	All Mode	2013 - 2016	Engine	Actuation Test	Ck Coolant Thermostat Heating Element(<100 Degree C)
DFNISSAN	All Mode	2013 - 2016	Engine	Actuation Test	Ck Coolant Thermostat Heating Element(<55 Degree C)
DFNISSAN	All Mode	2013 - 2016	Engine	Special Function	Resetting Of Adaption Values
DFNISSAN	All Mode	2013 - 2016	Engine	Special Function	Activation Of Fuel Pump
DFNISSAN	All Mode	2013 - 2016	Engine	Special Function	Teach In Of Throttle Valve Stop
DFNISSAN	All Mode	2013 - 2016	Engine	Special Function	Status Of Teach In Processes
DFNISSAN	All Mode	2013 - 2016	Engine	Special Function	Injector Injection Quantity Adjustment
DFNISSAN	All Mode	2013 - 2016	Engine	Special Function	Vin Registration
DFNISSAN	All Mode	2013 - 2016	Engine	Special Function	STRT OPRIN CNTR CLEAR
DFNISSAN	All Mode	2013 - 2016	Engine	Special Function	H/P Fuel Pump Total Starts Counter Clear
DFNISSAN	All Mode	2013 - 2016	Engine	Special Function	Saving Data For Replc CPU
DFNISSAN	All Mode	2013 - 2016	Engine	Special Function	Writing Data For Replc CPU
DFNISSAN	All Mode	2013 - 2016	Engine	Special Function	Camshaft Reference Adaptation
DFNISSAN	All Mode	2013 - 2016	Engine	Special Function	Teach In Of Camshaft Position
DFNISSAN	All Mode	2012 - 2016	Engine	Read Fault Code	
DFNISSAN	All Mode	2012 - 2016	Engine	Clear Fault Code	
DFNISSAN	All Mode	2012 - 2016	Engine	Read Data Stream	
DFNISSAN	All Mode	2012 - 2016	Engine	Module Information	
DFNISSAN	All Mode	2012 - 2016	Engine	Actuation Test	TURBOCHARGING SOLENOID VALVE
DFNISSAN	All Mode	2012 - 2016	Engine	Actuation Test	AIR INLET FLAP
DFNISSAN	All Mode	2012 - 2016	Engine	Actuation Test	HIGH PRESSURE CIRCUIT LEAK TEST
DFNISSAN	All Mode	2012 - 2016	Engine	Actuation Test	THERMO NO.3 RELAY
DFNISSAN	All Mode	2012 - 2016	Engine	Actuation Test	EGR VALVE
DFNISSAN	All Mode	2012 - 2016	Engine	Actuation Test	PREHEATER RELAY
DFNISSAN	All Mode	2012 - 2016	Engine	Actuation Test	THERMOPLUNGER RELAY No.1
DFNISSAN	All Mode	2012 - 2016	Engine	Actuation Test	THERMOPLUNGER RELAY No.2
DFNISSAN	All Mode	2012 - 2016	Engine	Actuation Test	LOW PRESSURE EGR VALVE PROGRAMMING
DFNISSAN	All Mode	2012 - 2016	Engine	Actuation Test	EXHAUST AIR FLAP PROGRAMMING
DFNISSAN	All Mode	2012 - 2016	Engine	Actuation Test	COOLANT CIRC SWITCHING S/V
DFNISSAN	All Mode	2012 - 2016	Engine	Actuation Test	Fuel Pump
DFNISSAN	All Mode	2012 - 2016	Engine	Actuation Test	Fuel Pump Relay
DFNISSAN	All Mode	2012 - 2016	Engine	Actuation Test	FUEL HEATER RELAY
DFNISSAN	All Mode	2012 - 2016	Engine	Special Function	SOx MASS OPERATION
DFNISSAN	All Mode	2012 - 2016	Engine	Special Function	Vin Registration
DFNISSAN	All Mode	2012 - 2016	Engine	Special Function	Fuel Sply Prev
DFNISSAN	All Mode	2012 - 2016	Engine	Special Function	Number Of Starting 1
DFNISSAN	All Mode	2012 - 2016	Engine	Special Function	Number Of Starting 2
DFNISSAN	All Mode	2012 - 2016	Engine	Special Function	Number Of Starting 3
DFNISSAN	All Mode	2012 - 2016	Engine	Special Function	Number Of Starting 4
DFNISSAN	All Mode	2012 - 2016	Engine	Special Function	Engine Adaptives
DFNISSAN	All Mode	2012 - 2016	Engine	Special Function	Egr Valve Programming
DFNISSAN	All Mode	2012 - 2016	Engine	Special Function	Air Damper Valve Programming
DFNISSAN	All Mode	2012 - 2016	Engine	Special Function	Exhaust Flap Low Setting
DFNISSAN	All Mode	2012 - 2016	Engine	Special Function	Turbocharger Programming
DFNISSAN	All Mode	2012 - 2016	Engine	Special Function	Low Pressure EGR Valve Programming
DFNISSAN	All Mode	2012 - 2016	Engine	Special Function	P/FLT DIFF PRS SEN
DFNISSAN	All Mode	2012 - 2016	Engine	Special Function	Pressure Regulation Adaptives
DFNISSAN	All Mode	2012 - 2016	Engine	Special Function	Fuel Pump Programming
DFNISSAN	All Mode	2012 - 2016	Engine	Special Function	Adaptives On Air Intake Flap Malfunction
DFNISSAN	All Mode	2012 - 2016	Engine	Special Function	CC/SL PRGRM
DFNISSAN	All Mode	2012 - 2016	Engine	Special Function	Prpr Rich Sen Prog
DFNISSAN	All Mode	2012 - 2016	Engine	Special Function	Enter Injector Codes
DFNISSAN	All Mode	2012 - 2016	Engine	Special Function	Service Regeneration
DFNISSAN	All Mode	2012 - 2016	Engine	Special Function	Speed Limiter
DFNISSAN	All Mode	2012 - 2016	Engine	Special Function	Interval Of Oil Change (OCS) Oxidation
DFNISSAN	All Mode	2012 - 2016	Engine	Special Function	OIL Change Interval (Ocs): Dilution
DFNISSAN	All Mode	2012 - 2016	Engine	Special Function	Volume Control Valve Learning Value Clear



**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
DFNISSAN	All Mode	2012 - 2016	Engine	Special Function	EGR Bypass Programming
DFNISSAN	All Mode	2012 - 2016	Engine	Special Function	Air Flow Meter Programming
DFNISSAN	All Mode	2012 - 2016	Engine	Special Function	DPF Relative Pressure Sensor
DFNISSAN	All Mode	2012 - 2016	Engine	Special Function	Adaptives After Regenerating PF
DFNISSAN	All Mode	2012 - 2016	Engine	Special Function	After Dpf Replacement
DFNISSAN	All Mode	2012 - 2016	Engine	Special Function	Clutch Pedal End Stroke
DFNISSAN	All Mode	2012 - 2016	Engine	Special Function	Save Computer Data
DFNISSAN	All Mode	2012 - 2016	Engine	Special Function	Write Saved Data
DFNISSAN	All Mode	2012 - 2016	Engine	Special Function	Air Damper Valve Programming(R044)
DFNISSAN	All Mode	2012 - 2016	Engine	Special Function	NOX TRAP
DFNISSAN	All Mode	2012 - 2016	Engine	Special Function	SAVE COMPUTER DATA
DFNISSAN	All Mode	2012 - 2016	Engine	Special Function	WRITE SAVED DATA
DFNISSAN	All Mode	2012 - 2016	Engine	Special Function	After Dpf Regeneration
DFNISSAN	All Mode	2016 - 2016	Engine	Read Fault Code	
DFNISSAN	All Mode	2016 - 2016	Engine	Clear Fault Code	
DFNISSAN	All Mode	2016 - 2016	Engine	Read Data Stream	
DFNISSAN	All Mode	2016 - 2016	Engine	Module Information	
DFNISSAN	All Mode	2016 - 2016	Engine	Actuation Test	THRTL POSITION
DFNISSAN	All Mode	2016 - 2016	Engine	Actuation Test	EGR/V ANGLE
DFNISSAN	All Mode	2016 - 2016	Engine	Actuation Test	GLOW RLY
DFNISSAN	All Mode	2016 - 2016	Engine	Actuation Test	High Pressure Tc Boost Cont S/V
DFNISSAN	All Mode	2016 - 2016	Engine	Actuation Test	Low Pressure Tc Boost Cont S/V
DFNISSAN	All Mode	2016 - 2016	Engine	Actuation Test	Exhaust Shutter Solenoid Valve
DFNISSAN	All Mode	2016 - 2016	Engine	Special Function	Vin Registration
DFNISSAN	All Mode	2016 - 2016	Engine	Special Function	EGR/V LEARN CLR
DFNISSAN	All Mode	2016 - 2016	Engine	Special Function	TP POS LEARN CLR
DFNISSAN	All Mode	2016 - 2016	Engine	Special Function	DPF Data Clear
DFNISSAN	All Mode	2016 - 2016	Engine	Special Function	A/F SEN LEAN CLR
DFNISSAN	All Mode	2016 - 2016	Engine	Special Function	Injector Learning Value Clear
DFNISSAN	All Mode	2016 - 2016	Engine	Special Function	Mixture Ratio Learning Value Clear
DFNISSAN	All Mode	2016 - 2016	Engine	Special Function	Enter Injctr Calib Data
DFNISSAN	All Mode	2016 - 2016	Engine	Special Function	Service Regeneration
DFNISSAN	All Mode	2016 - 2016	Engine	Special Function	Battery discharge current totalizing clear
DFNISSAN	All Mode	2016 - 2016	Engine	Special Function	Common rail switching clear
DFNISSAN	All Mode	2016 - 2016	Engine	Special Function	Saving Data For Replc CPU
DFNISSAN	All Mode	2016 - 2016	Engine	Special Function	Writing Data For Replc CPU
DFNISSAN	All Mode	2014 - 2014	Engine	Read Fault Code	
DFNISSAN	All Mode	2014 - 2014	Engine	Clear Fault Code	
DFNISSAN	All Mode	2014 - 2014	Engine	Read Data Stream	
DFNISSAN	All Mode	2014 - 2014	Engine	Module Information	
DFNISSAN	All Mode	2014 - 2014	Engine	Actuation Test	TURBOCHARGING SOLENOID VALVE
DFNISSAN	All Mode	2014 - 2014	Engine	Actuation Test	AIR INLET FLAP
DFNISSAN	All Mode	2014 - 2014	Engine	Actuation Test	THERMO NO.3 RELAY
DFNISSAN	All Mode	2014 - 2014	Engine	Actuation Test	EGR VALVE
DFNISSAN	All Mode	2014 - 2014	Engine	Actuation Test	PREHEATER RELAY
DFNISSAN	All Mode	2014 - 2014	Engine	Actuation Test	Fan Unit Low Speed RLY
DFNISSAN	All Mode	2014 - 2014	Engine	Actuation Test	Fan Unit High Speed RLY
DFNISSAN	All Mode	2014 - 2014	Engine	Actuation Test	THERMOPLUNGER RELAY No.1
DFNISSAN	All Mode	2014 - 2014	Engine	Actuation Test	THERMOPLUNGER RELAY No.2
DFNISSAN	All Mode	2014 - 2014	Engine	Actuation Test	EGR BYPASS
DFNISSAN	All Mode	2014 - 2014	Engine	Actuation Test	Air Conditioning Compressor Relay Control
DFNISSAN	All Mode	2014 - 2014	Engine	Actuation Test	Low Pressure Fuel Pump
DFNISSAN	All Mode	2014 - 2014	Engine	Actuation Test	PUMP PRESSURE REGULATOR
DFNISSAN	All Mode	2014 - 2014	Engine	Actuation Test	LOW PRESSURE EGR VALVE
DFNISSAN	All Mode	2014 - 2014	Engine	Actuation Test	Exhaust Air Flap
DFNISSAN	All Mode	2014 - 2014	Engine	Actuation Test	COOLANT CIRC SWITCHING S/V
DFNISSAN	All Mode	2014 - 2014	Engine	Actuation Test	Fuel Pump
DFNISSAN	All Mode	2014 - 2014	Engine	Actuation Test	Active Grille Air Shutter
DFNISSAN	All Mode	2014 - 2014	Engine	Actuation Test	Fuel Pump Relay
DFNISSAN	All Mode	2014 - 2014	Engine	Actuation Test	FUEL HEATER RELAY
DFNISSAN	All Mode	2014 - 2014	Engine	Special Function	Save Computer Data
DFNISSAN	All Mode	2014 - 2014	Engine	Special Function	Write Saved Data
DFNISSAN	All Mode	2014 - 2014	Engine	Special Function	Cylinder Function Fault Finding
DFNISSAN	All Mode	2014 - 2014	Engine	Special Function	High Pressure Fuel Circuit Fault Finding
DFNISSAN	All Mode	2014 - 2014	Engine	Special Function	Vin Registration
DFNISSAN	All Mode	2014 - 2014	Engine	Special Function	Fuel Sply Prev
DFNISSAN	All Mode	2014 - 2014	Engine	Special Function	Number Of Starting 1

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
DFNISSAN	All Mode	2014 - 2014	Engine	Special Function	Number Of Starting 2
DFNISSAN	All Mode	2014 - 2014	Engine	Special Function	Number Of Starting 3
DFNISSAN	All Mode	2014 - 2014	Engine	Special Function	Number Of Starting 4
DFNISSAN	All Mode	2014 - 2014	Engine	Special Function	Egr Valve Programming
DFNISSAN	All Mode	2014 - 2014	Engine	Special Function	Air Damper Valve Programming
DFNISSAN	All Mode	2014 - 2014	Engine	Special Function	CC/SL Prgrm
DFNISSAN	All Mode	2014 - 2014	Engine	Special Function	Flywhl TGT PG
DFNISSAN	All Mode	2014 - 2014	Engine	Special Function	Exhaust Air Flap Programming
DFNISSAN	All Mode	2014 - 2014	Engine	Special Function	Turbocharger Programming
DFNISSAN	All Mode	2014 - 2014	Engine	Special Function	Adaptives On Air Intake Flap Malfunction
DFNISSAN	All Mode	2014 - 2014	Engine	Special Function	Manifold Pressure Sensor Programming
DFNISSAN	All Mode	2014 - 2014	Engine	Special Function	P/FLT DIFF PRS SEN
DFNISSAN	All Mode	2014 - 2014	Engine	Special Function	Low Pressure EGR Valve Programming
DFNISSAN	All Mode	2014 - 2014	Engine	Special Function	Engine Adaptives
DFNISSAN	All Mode	2014 - 2014	Engine	Special Function	Number Of Starting Cycles
DFNISSAN	All Mode	2014 - 2014	Engine	Special Function	Injection Pump Adaptives
DFNISSAN	All Mode	2014 - 2014	Engine	Special Function	Fuel Pump Programming
DFNISSAN	All Mode	2014 - 2014	Engine	Special Function	Injector Adaptives
DFNISSAN	All Mode	2014 - 2014	Engine	Special Function	Air Path Programming
DFNISSAN	All Mode	2014 - 2014	Engine	Special Function	EGR Adaptives
DFNISSAN	All Mode	2014 - 2014	Engine	Special Function	DPF Relative Pressure Sensor
DFNISSAN	All Mode	2014 - 2014	Engine	Special Function	Rail Pressure Sensor Adaptives
DFNISSAN	All Mode	2014 - 2014	Engine	Special Function	EGR Programming
DFNISSAN	All Mode	2014 - 2014	Engine	Special Function	Prpr Rich Sen Prog
DFNISSAN	All Mode	2014 - 2014	Engine	Special Function	Programmed Values
DFNISSAN	All Mode	2014 - 2014	Engine	Special Function	Fuel Rail Press Limiting Injctn Countr Clear
DFNISSAN	All Mode	2014 - 2014	Engine	Special Function	Service Regeneration
DFNISSAN	All Mode	2014 - 2014	Engine	Special Function	Enter Injector Codes
DFNISSAN	All Mode	2014 - 2014	Engine	Special Function	Speed Limiter
DFNISSAN	All Mode	2014 - 2014	Engine	Special Function	Adaptives After Regenerating PF
DFNISSAN	All Mode	2014 - 2014	Engine	Special Function	Interval Of Oil Change (OCS) Oxidation
DFNISSAN	All Mode	2014 - 2014	Engine	Special Function	Oil Change Interval(Ocs):Dilution
DFNISSAN	All Mode	2014 - 2014	Engine	Special Function	After Dpf Regeneration
DFNISSAN	All Mode	2014 - 2014	Engine	Special Function	Alternator Setpoint Voltage
DFNISSAN	All Mode	2014 - 2014	Engine	Special Function	NOX TRAP
DFNISSAN	All Mode	2015 - 2016	Engine	Read Fault Code	
DFNISSAN	All Mode	2015 - 2016	Engine	Clear Fault Code	
DFNISSAN	All Mode	2015 - 2016	Engine	Read Data Stream	
DFNISSAN	All Mode	2015 - 2016	Engine	Module Information	
DFNISSAN	All Mode	2015 - 2016	Engine	Actuation Test	Auto Stop Start
DFNISSAN	All Mode	2015 - 2016	Engine	Actuation Test	Gas Pump Command State (Gasoline)
DFNISSAN	All Mode	2015 - 2016	Engine	Actuation Test	Intake Comshaft Phaser Pwm Command
DFNISSAN	All Mode	2015 - 2016	Engine	Actuation Test	Boost Pressure Pwm Command (Gasoline)
DFNISSAN	All Mode	2015 - 2016	Engine	Actuation Test	Catalyst Exhaust Gas Upstream Oxygen Resistance Heater Pwm Command
DFNISSAN	All Mode	2015 - 2016	Engine	Actuation Test	Catalyst Exhaust Gas Downstream Oxygen Resistance Heater Pwm Command
DFNISSAN	All Mode	2015 - 2016	Engine	Actuation Test	Oil Pressure Rco Command With Monitool
DFNISSAN	All Mode	2015 - 2016	Engine	Actuation Test	Controlled Thermostat
DFNISSAN	All Mode	2015 - 2016	Engine	Actuation Test	Throttle Valve Position Setpoint
DFNISSAN	All Mode	2015 - 2016	Engine	Actuation Test	Canister Drain Valve Command (Conti)
DFNISSAN	All Mode	2015 - 2016	Engine	Actuation Test	Vvt Control Solenoid (Exhaust)
DFNISSAN	All Mode	2015 - 2016	Engine	Special Function	After throttle valve replacement
DFNISSAN	All Mode	2015 - 2016	Engine	Special Function	After turbocharger component replacement
DFNISSAN	All Mode	2015 - 2016	Engine	Special Function	After rail pressure sensor replacement
DFNISSAN	All Mode	2015 - 2016	Engine	Special Function	After injector replacement

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
DFNISSAN	All Mode	2015 - 2016	Engine	Special Function	After TDC sensor replacement
DFNISSAN	All Mode	2015 - 2016	Engine	Special Function	After turbocharger solenoid valve replacement
DFNISSAN	All Mode	2015 - 2016	Engine	Special Function	After end stroke clutch contactor replacement
DFNISSAN	All Mode	2015 - 2016	Engine	Special Function	After camshaft sensor replacement
DFNISSAN	All Mode	2015 - 2016	Engine	Special Function	Starter Operation Counter Clear
DFNISSAN	All Mode	2015 - 2016	Engine	Special Function	Write Starter Operation Count
DFNISSAN	All Mode	2015 - 2016	Engine	Special Function	Vin Registration
DFNISSAN	All Mode	2015 - 2016	Engine	Special Function	H/P Fuel Pump Total Starts Counter Clear
DFNISSAN	All Mode	2015 - 2016	Engine	Special Function	Write H/P Fuel Pump Total Starts Count
DFNISSAN	All Mode	2015 - 2016	Engine	Special Function	Fuel Sply Prev
DFNISSAN	All Mode	2015 - 2016	Engine	Special Function	Engine Adaptives
DFNISSAN	All Mode	2015 - 2016	Engine	Special Function	Injection Pump Adaptatives
DFNISSAN	All Mode	2015 - 2016	Engine	Special Function	Interval Of Oil Change (OCS) Oxidation
DFNISSAN	All Mode	2015 - 2016	Engine	Special Function	After High Pressure Fuel Pump Replacement
DFNISSAN	All Mode	2015 - 2016	Engine	Special Function	Inhibit Evap System
DFNISSAN	All Mode	2015 - 2016	Engine	Special Function	Activate Evap System
DFNISSAN	All Mode	2015 - 2016	Engine	Special Function	Air Fuel Ratio Sensor
DFNISSAN	All Mode	2015 - 2016	Engine	Special Function	Clutch Pedal End Stroke
DFNISSAN	All Mode	2015 - 2016	Engine	Special Function	Vacuum Pump
DFNISSAN	All Mode	2015 - 2016	Engine	Special Function	High Pressure Fuel Circuit Fault Finding
DFNISSAN	All Mode	2015 - 2016	Engine	Special Function	Save Computer Data
DFNISSAN	All Mode	2015 - 2016	Engine	Special Function	Write Saved Data
DFNISSAN	All Mode	2015 - 2016	Engine	Special Function	Start OBD test: Catalytic converter
DFNISSAN	All Mode	2015 - 2016	Engine	Special Function	Start OBD test: O2 sensor
DFNISSAN	All Mode	2015 - 2016	Engine	Special Function	After Tc Solenoid Valve Replacement
DFNISSAN	All Mode	2015 - 2016	Engine	Special Function	AFTR ELECTRIC THRRTL CNTRL ACTUATOR RPLCMNT
DFNISSAN	All Mode	2015 - 2016	Engine	Special Function	After Crankshaft Pos Sensor Replacement
DFNISSAN	All Mode	2014 - 2015	Engine	Read Fault Code	
DFNISSAN	All Mode	2014 - 2015	Engine	Clear Fault Code	
DFNISSAN	All Mode	2014 - 2015	Engine	Read Data Stream	
DFNISSAN	All Mode	2014 - 2015	Engine	Module Information	
DFNISSAN	All Mode	2014 - 2015	Engine	Actuation Test	COOLING FAN 2
DFNISSAN	All Mode	2014 - 2015	Engine	Actuation Test	COOLING FAN 1
DFNISSAN	All Mode	2014 - 2015	Engine	Actuation Test	Exhaust Throttle
DFNISSAN	All Mode	2014 - 2015	Engine	Actuation Test	EGR VOLUME CONTROL VALVE
DFNISSAN	All Mode	2014 - 2015	Engine	Actuation Test	Throttle Valve
DFNISSAN	All Mode	2014 - 2015	Engine	Actuation Test	Turbocharger Boost Pressure
DFNISSAN	All Mode	2014 - 2015	Engine	Actuation Test	COOLANT FLOW VALVE
DFNISSAN	All Mode	2014 - 2015	Engine	Actuation Test	GLOW PLUG
DFNISSAN	All Mode	2014 - 2015	Engine	Actuation Test	A/C COMPRESSOR
DFNISSAN	All Mode	2014 - 2015	Engine	Actuation Test	THERMO PLUNGER
DFNISSAN	All Mode	2014 - 2015	Engine	Actuation Test	Fuel Pump
DFNISSAN	All Mode	2014 - 2015	Engine	Actuation Test	Fuel Pump Relay
DFNISSAN	All Mode	2014 - 2015	Engine	Actuation Test	EGR WATER PUMP 1
DFNISSAN	All Mode	2014 - 2015	Engine	Actuation Test	Auto Stop Start
DFNISSAN	All Mode	2014 - 2015	Engine	Special Function	Fuel Pump Programming
DFNISSAN	All Mode	2014 - 2015	Engine	Special Function	Air Flow Meter Programming
DFNISSAN	All Mode	2014 - 2015	Engine	Special Function	Adaptives On Air Intake Flap Malfunction
DFNISSAN	All Mode	2014 - 2015	Engine	Special Function	Air Damper Valve Programming (R088)
DFNISSAN	All Mode	2014 - 2015	Engine	Special Function	Exhaust Flap Low Setting
DFNISSAN	All Mode	2014 - 2015	Engine	Special Function	Turbocharger Programming
DFNISSAN	All Mode	2014 - 2015	Engine	Special Function	Manifold Pressure Sensor Programming
DFNISSAN	All Mode	2014 - 2015	Engine	Special Function	Egr Valve Programming
DFNISSAN	All Mode	2014 - 2015	Engine	Special Function	EGR Bypass Programming
DFNISSAN	All Mode	2014 - 2015	Engine	Special Function	Injection Pump Adaptatives
DFNISSAN	All Mode	2014 - 2015	Engine	Special Function	Rail Pressure Sensor Adaptives
DFNISSAN	All Mode	2014 - 2015	Engine	Special Function	DPF Relative Pressure Sensor
DFNISSAN	All Mode	2014 - 2015	Engine	Special Function	P/FLT DIFF PRS SEN
DFNISSAN	All Mode	2014 - 2015	Engine	Special Function	Prpr Rich Sen Prog

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

<b>make</b>	<b>model</b>	<b>year</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
DFNISSAN	All Mode	2014 - 2015	Engine	Special Function	Air Damper Valve Programming(R044)
DFNISSAN	All Mode	2014 - 2015	Engine	Special Function	Low Pressure EGR Valve Programming
DFNISSAN	All Mode	2014 - 2015	Engine	Special Function	Swirl Flap Programming
DFNISSAN	All Mode	2014 - 2015	Engine	Special Function	Swirl Flap
DFNISSAN	All Mode	2014 - 2015	Engine	Special Function	Enter Injector Codes
DFNISSAN	All Mode	2014 - 2015	Engine	Special Function	Service Regeneration
DFNISSAN	All Mode	2014 - 2015	Engine	Special Function	Vin Registration
DFNISSAN	All Mode	2014 - 2015	Engine	Special Function	UDS Implementation Validation
DFNISSAN	All Mode	2014 - 2015	Engine	Special Function	Variable Valve Timing
DFNISSAN	All Mode	2014 - 2015	Engine	Special Function	Target Idle Speed(Increase)
DFNISSAN	All Mode	2014 - 2015	Engine	Special Function	Target Idle Speed(Decrease)
DFNISSAN	All Mode	2014 - 2015	Engine	Special Function	DPF Regeneration
DFNISSAN	All Mode	2014 - 2015	Engine	Special Function	Exhaust Fuel Injector Leakage
DFNISSAN	All Mode	2014 - 2015	Engine	Special Function	A/F Sensor Upstream Catalyst
DFNISSAN	All Mode	2014 - 2015	Engine	Special Function	Fuel Rail Pressure Test
DFNISSAN	All Mode	2014 - 2015	Engine	Special Function	Fuel Injector Test
DFNISSAN	All Mode	2014 - 2015	Engine	Special Function	Static Test
DFNISSAN	All Mode	2014 - 2015	Engine	Special Function	Fuel Pump
DFNISSAN	All Mode	2014 - 2015	Engine	Special Function	Immobilizer System Check 2
DFNISSAN	All Mode	2014 - 2015	Engine	Special Function	Number Of Starting 1
DFNISSAN	All Mode	2014 - 2015	Engine	Special Function	Number Of Starting 2
DFNISSAN	All Mode	2014 - 2015	Engine	Special Function	Number Of Starting 3
DFNISSAN	All Mode	2014 - 2015	Engine	Special Function	Number Of Starting 4
DFNISSAN	All Mode	2014 - 2015	Engine	Special Function	Starter Operation Counter Clear
DFNISSAN	All Mode	2014 - 2015	Engine	Special Function	H/P Fuel Pump Total Starts Counter Clear
DFNISSAN	All Mode	2014 - 2015	Engine	Special Function	Write Starter Operation Count
DFNISSAN	All Mode	2014 - 2015	Engine	Special Function	Write H/P Fuel Pump Total Starts Count
DFNISSAN	All Mode	2014 - 2015	Engine	Special Function	Bypass Solenoid Valve For HP Turbine Componet
DFNISSAN	All Mode	2014 - 2015	Engine	Special Function	Adaptives After Regenerating PF
DFNISSAN	All Mode	2014 - 2015	Engine	Special Function	Interval Of Oil Change (OCS) Oxidation
DFNISSAN	All Mode	2014 - 2015	Engine	Special Function	Oil Change Interval(Ocs):Dilution
DFNISSAN	All Mode	2014 - 2015	Engine	Special Function	High Pressure Fuel Circuit Fault Finding
DFNISSAN	All Mode	2014 - 2015	Engine	Special Function	Cylinder Function Fault Finding
DFNISSAN	All Mode	2014 - 2015	Engine	Special Function	Speed Limiter
DFNISSAN	All Mode	2014 - 2015	Engine	Special Function	Fast Idle Speed Modification
DFNISSAN	All Mode	2014 - 2015	Engine	Special Function	Save Computer Data
DFNISSAN	All Mode	2014 - 2015	Engine	Special Function	Write Saved Data
DFNISSAN	All Mode	2014 - 2015	Engine	Special Function	Clutch Pedal End Stroke
DFNISSAN	All Mode	2014 - 2015	Engine	Special Function	Fuel Sply Prev
DFNISSAN	All Mode	2014 - 2015	Engine	Special Function	Programmed Values
DFNISSAN	All Mode	2014 - 2015	Engine	Special Function	Thermoplunger Programming
DFNISSAN	All Mode	2014 - 2015	Engine	Special Function	SAVE COMPUTER DATA
DFNISSAN	All Mode	2014 - 2015	Engine	Special Function	WRITE SAVED DATA
DFNISSAN	All Mode	2014 - 2015	Engine	Special Function	After Dpf Regeneration
DFNISSAN	All Mode	2014 - 2015	Engine	Special Function	High Pressure Turbine Bypass Solenoid Valve
DFNISSAN	All Mode	2014 - 2015	Engine	Special Function	Alternator Setpoint Voltage
DFNISSAN	All Mode	2014 - 2015	Engine	Special Function	NOX TRAP
DFNISSAN	All Mode	2015 - 2016	Engine	Read Fault Code	
DFNISSAN	All Mode	2015 - 2016	Engine	Clear Fault Code	
DFNISSAN	All Mode	2015 - 2016	Engine	Read Data Stream	
DFNISSAN	All Mode	2015 - 2016	Engine	Module Information	
DFNISSAN	All Mode	2015 - 2016	Engine	Actuation Test	A/F SENSOR HEATER
DFNISSAN	All Mode	2015 - 2016	Engine	Actuation Test	FUEL FLOW ACTUATOR
DFNISSAN	All Mode	2015 - 2016	Engine	Actuation Test	COOLING FAN 2
DFNISSAN	All Mode	2015 - 2016	Engine	Actuation Test	COOLING FAN 1
DFNISSAN	All Mode	2015 - 2016	Engine	Actuation Test	EXHAUST FUEL INJECTOR
DFNISSAN	All Mode	2015 - 2016	Engine	Actuation Test	FUEL RAIL PRESSURE
DFNISSAN	All Mode	2015 - 2016	Engine	Actuation Test	INTAKE MANIFOLD RUNNER VALVE
DFNISSAN	All Mode	2015 - 2016	Engine	Actuation Test	EGR COOLER BYPASS VALVE
DFNISSAN	All Mode	2015 - 2016	Engine	Actuation Test	Exhaust Throttle
DFNISSAN	All Mode	2015 - 2016	Engine	Actuation Test	TC COOLING WATER PUMP
DFNISSAN	All Mode	2015 - 2016	Engine	Actuation Test	EGR COOLER BYPASS PWM

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

<b>make</b>	<b>model</b>	<b>year</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
DFNISSAN	All Mode	2015 - 2016	Engine	Actuation Test	EGR VOLUME CONTROL VALVE
DFNISSAN	All Mode	2015 - 2016	Engine	Actuation Test	Throttle Valve
DFNISSAN	All Mode	2015 - 2016	Engine	Actuation Test	Turbocharger Boost Pressure
DFNISSAN	All Mode	2015 - 2016	Engine	Actuation Test	COOLANT FLOW VALVE
DFNISSAN	All Mode	2015 - 2016	Engine	Actuation Test	PTC 3
DFNISSAN	All Mode	2015 - 2016	Engine	Actuation Test	PTC 2
DFNISSAN	All Mode	2015 - 2016	Engine	Actuation Test	PTC 1
DFNISSAN	All Mode	2015 - 2016	Engine	Actuation Test	GLOW PLUG
DFNISSAN	All Mode	2015 - 2016	Engine	Actuation Test	IDLE SPEED
DFNISSAN	All Mode	2015 - 2016	Engine	Actuation Test	A/C COMPRESSOR
DFNISSAN	All Mode	2015 - 2016	Engine	Actuation Test	Auto Stop Start
DFNISSAN	All Mode	2015 - 2016	Engine	Special Function	Enter Injector Codes
DFNISSAN	All Mode	2015 - 2016	Engine	Special Function	Service Regeneration
DFNISSAN	All Mode	2015 - 2016	Engine	Special Function	Vin Registration
DFNISSAN	All Mode	2015 - 2016	Engine	Special Function	Number Of Starting 1
DFNISSAN	All Mode	2015 - 2016	Engine	Special Function	Number Of Starting 2
DFNISSAN	All Mode	2015 - 2016	Engine	Special Function	Number Of Starting 3
DFNISSAN	All Mode	2015 - 2016	Engine	Special Function	Number Of Starting 4
DFNISSAN	All Mode	2015 - 2016	Engine	Special Function	Fuel Pump Programming
DFNISSAN	All Mode	2015 - 2016	Engine	Special Function	Air Flow Meter Programming
DFNISSAN	All Mode	2015 - 2016	Engine	Special Function	Adaptives On Air Intake Flap Malfunction
DFNISSAN	All Mode	2015 - 2016	Engine	Special Function	Air Damper Valve Programming(R088)
DFNISSAN	All Mode	2015 - 2016	Engine	Special Function	Exhaust Flap Low Setting
DFNISSAN	All Mode	2015 - 2016	Engine	Special Function	Turbocharger Programming
DFNISSAN	All Mode	2015 - 2016	Engine	Special Function	Egr Valve Programming
DFNISSAN	All Mode	2015 - 2016	Engine	Special Function	EGR Bypass Programming
DFNISSAN	All Mode	2015 - 2016	Engine	Special Function	Flywhl TGT PG
DFNISSAN	All Mode	2015 - 2016	Engine	Special Function	Injection Pump Adaptatives
DFNISSAN	All Mode	2015 - 2016	Engine	Special Function	Rail Pressure Sensor Adaptives
DFNISSAN	All Mode	2015 - 2016	Engine	Special Function	DPF Relative Pressure Sensor
DFNISSAN	All Mode	2015 - 2016	Engine	Special Function	P/FLT DIFF PRS SEN
DFNISSAN	All Mode	2015 - 2016	Engine	Special Function	Prpr Rich Sen Prog
DFNISSAN	All Mode	2015 - 2016	Engine	Special Function	Low Pressure EGR Valve Programming
DFNISSAN	All Mode	2015 - 2016	Engine	Special Function	Swirl Flap
DFNISSAN	All Mode	2015 - 2016	Engine	Special Function	Swirl Flap Programming
DFNISSAN	All Mode	2015 - 2016	Engine	Special Function	UDS Implementation Validation
DFNISSAN	All Mode	2015 - 2016	Engine	Special Function	Variable Valve Timing
DFNISSAN	All Mode	2015 - 2016	Engine	Special Function	Target Idle Speed(Increase)
DFNISSAN	All Mode	2015 - 2016	Engine	Special Function	Target Idle Speed(Decrease)
DFNISSAN	All Mode	2015 - 2016	Engine	Special Function	Exhaust Fuel Injector Leakage
DFNISSAN	All Mode	2015 - 2016	Engine	Special Function	A/F Sensor Upstream Catalyst
DFNISSAN	All Mode	2015 - 2016	Engine	Special Function	Fuel Rail Pressure Test
DFNISSAN	All Mode	2015 - 2016	Engine	Special Function	Fuel Injector Test
DFNISSAN	All Mode	2015 - 2016	Engine	Special Function	Static Test
DFNISSAN	All Mode	2015 - 2016	Engine	Special Function	Fuel Pump
DFNISSAN	All Mode	2015 - 2016	Engine	Special Function	Immobilizer System Check 2
DFNISSAN	All Mode	2015 - 2016	Engine	Special Function	Air Damper Valve Programming(R044)
DFNISSAN	All Mode	2015 - 2016	Engine	Special Function	Starter Operation Counter Clear
DFNISSAN	All Mode	2015 - 2016	Engine	Special Function	H/P Fuel Pump Total Starts Counter Clear
DFNISSAN	All Mode	2015 - 2016	Engine	Special Function	Write Starter Operation Count
DFNISSAN	All Mode	2015 - 2016	Engine	Special Function	Write H/P Fuel Pump Total Starts Count
DFNISSAN	All Mode	2015 - 2016	Engine	Special Function	Adaptives After Regenerating PF
DFNISSAN	All Mode	2015 - 2016	Engine	Special Function	Interval Of Oil Change (OCS) Oxidation
DFNISSAN	All Mode	2015 - 2016	Engine	Special Function	Oil Change Interval(Ocs):Dilution
DFNISSAN	All Mode	2015 - 2016	Engine	Special Function	Speed Limiter
DFNISSAN	All Mode	2015 - 2016	Engine	Special Function	Save Computer Data
DFNISSAN	All Mode	2015 - 2016	Engine	Special Function	Write Saved Data
DFNISSAN	All Mode	2015 - 2016	Engine	Special Function	Clutch Pedal End Stroke
DFNISSAN	All Mode	2015 - 2016	Engine	Special Function	Fuel Sply Prev
DFNISSAN	All Mode	2015 - 2016	Engine	Special Function	SAVE COMPUTER DATA
DFNISSAN	All Mode	2015 - 2016	Engine	Special Function	WRITE SAVED DATA
DFNISSAN	All Mode	2015 - 2016	Engine	Special Function	After Dpf Regeneration
DFNISSAN	All Mode	2015 - 2016	Engine	Special Function	NOX TRAP
DFNISSAN	All Mode	2014 - 2016	Engine	Read Fault Code	

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
DFNISSAN	All Mode	2014 - 2016	Engine	Clear Fault Code	
DFNISSAN	All Mode	2014 - 2016	Engine	Read Data Stream	
DFNISSAN	All Mode	2014 - 2016	Engine	Module Information	
DFNISSAN	All Mode	2014 - 2016	Engine	Actuation Test	Fuel Pump Relay
DFNISSAN	All Mode	2014 - 2016	Engine	Actuation Test	Intake Valve Timing Control Solenoid Valve
DFNISSAN	All Mode	2014 - 2016	Engine	Actuation Test	TC Wastegate Control Solenoid Valve
DFNISSAN	All Mode	2014 - 2016	Engine	Actuation Test	Engine Oil Pressure Control Solenoid Valve
DFNISSAN	All Mode	2014 - 2016	Engine	Actuation Test	Exhaust Valve Timing Control Solenoid Valve
DFNISSAN	All Mode	2014 - 2016	Engine	Actuation Test	Thermostat Heater Control Solenoid Valve
DFNISSAN	All Mode	2014 - 2016	Engine	Actuation Test	Electric Throttle Control Actuator
DFNISSAN	All Mode	2014 - 2016	Engine	Actuation Test	EVAP Canister Purge Control Solenoid Valve
DFNISSAN	All Mode	2014 - 2016	Engine	Special Function	Vin Registration
DFNISSAN	All Mode	2014 - 2016	Engine	Special Function	After throttle valve replacement
DFNISSAN	All Mode	2014 - 2016	Engine	Special Function	After turbocharger componet replacement
DFNISSAN	All Mode	2014 - 2016	Engine	Special Function	After turbocharger solenoid valve replacement
DFNISSAN	All Mode	2014 - 2016	Engine	Special Function	After end stroke clutch contactor replacement
DFNISSAN	All Mode	2014 - 2016	Engine	Special Function	After camshaft sensor replacement
DFNISSAN	All Mode	2014 - 2016	Engine	Special Function	After TDC sensor replacement
DFNISSAN	All Mode	2014 - 2016	Engine	Special Function	After injection pump replacement
DFNISSAN	All Mode	2014 - 2016	Engine	Special Function	After rail pressure sensor replacement
DFNISSAN	All Mode	2014 - 2016	Engine	Special Function	After injector replacement
DFNISSAN	All Mode	2014 - 2016	Engine	Special Function	Fuel Sply Prev
DFNISSAN	All Mode	2014 - 2016	Engine	Special Function	Engine Adaptives
DFNISSAN	All Mode	2014 - 2016	Engine	Special Function	Injection Pump Adaptatives
DFNISSAN	All Mode	2014 - 2016	Engine	Special Function	Interval Of Oil Change (OCS) Oxidation
DFNISSAN	All Mode	2014 - 2016	Engine	Special Function	High Pressure Fuel Circuit Fault Finding
DFNISSAN	All Mode	2014 - 2016	Engine	Special Function	Air Fuel Ratio Sensor
DFNISSAN	All Mode	2014 - 2016	Engine	Special Function	After High Pressure Fuel Pump Replacement
DFNISSAN	All Mode	2014 - 2016	Engine	Special Function	After Tc Solenoid Valve Replacement
DFNISSAN	All Mode	2014 - 2016	Engine	Special Function	AFTR ELECTRIC THRRTL CNTRL ACTUATOR RPLCMNT
DFNISSAN	All Mode	2014 - 2014	Engine	Read Fault Code	
DFNISSAN	All Mode	2014 - 2014	Engine	Clear Fault Code	
DFNISSAN	All Mode	2014 - 2014	Engine	Read Data Stream	
DFNISSAN	All Mode	2014 - 2014	Engine	Module Information	
DFNISSAN	All Mode	2014 - 2014	Engine	Actuation Test	Fuel Pump
DFNISSAN	All Mode	2014 - 2014	Engine	Actuation Test	TURBOCHARGING SOLENOID VALVE
DFNISSAN	All Mode	2014 - 2014	Engine	Actuation Test	AIR INLET FLAP
DFNISSAN	All Mode	2014 - 2014	Engine	Actuation Test	PREHEATER RELAY
DFNISSAN	All Mode	2014 - 2014	Engine	Actuation Test	COOLANT CIRC SWITCHING S/V
DFNISSAN	All Mode	2014 - 2014	Engine	Actuation Test	EGR VALVE
DFNISSAN	All Mode	2014 - 2014	Engine	Actuation Test	HIGH PRESSURE CIRCUIT LEAK TEST
DFNISSAN	All Mode	2014 - 2014	Engine	Actuation Test	HIGH PRESSURE TURBINE
DFNISSAN	All Mode	2014 - 2014	Engine	Actuation Test	EGR BYPASS
DFNISSAN	All Mode	2014 - 2014	Engine	Actuation Test	SECOND EGR COOLING PUMP
DFNISSAN	All Mode	2014 - 2014	Engine	Actuation Test	FIRST EGR COOLING PUMP
DFNISSAN	All Mode	2014 - 2014	Engine	Actuation Test	HIGH PRESSURE COMPRESSOR
DFNISSAN	All Mode	2014 - 2014	Engine	Actuation Test	ELECTRIC WATER PUMP
DFNISSAN	All Mode	2014 - 2014	Engine	Special Function	Fuel Sply Prev
DFNISSAN	All Mode	2014 - 2014	Engine	Special Function	Vin Registration
DFNISSAN	All Mode	2014 - 2014	Engine	Special Function	Number Of Starting 1
DFNISSAN	All Mode	2014 - 2014	Engine	Special Function	Number Of Starting 2
DFNISSAN	All Mode	2014 - 2014	Engine	Special Function	Number Of Starting 3
DFNISSAN	All Mode	2014 - 2014	Engine	Special Function	Number Of Starting 4
DFNISSAN	All Mode	2014 - 2014	Engine	Special Function	Air Damper Valve Programming
DFNISSAN	All Mode	2014 - 2014	Engine	Special Function	Egr Valve Programming
DFNISSAN	All Mode	2014 - 2014	Engine	Special Function	Injection Pump Adaptatives
DFNISSAN	All Mode	2014 - 2014	Engine	Special Function	Engine Adaptives

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
DFNISSAN	All Mode	2014 - 2014	Engine	Special Function	Fuel Pump Programming
DFNISSAN	All Mode	2014 - 2014	Engine	Special Function	Turbocharger Programming
DFNISSAN	All Mode	2014 - 2014	Engine	Special Function	CC/SL PRGRM
DFNISSAN	All Mode	2014 - 2014	Engine	Special Function	Prpr Rich Sen Prog
DFNISSAN	All Mode	2014 - 2014	Engine	Special Function	P/FLT DIFF PRS SEN
DFNISSAN	All Mode	2014 - 2014	Engine	Special Function	Hp Turbine Bypass SOL VLV Programming
DFNISSAN	All Mode	2014 - 2014	Engine	Special Function	Enter Injector Codes
DFNISSAN	All Mode	2014 - 2014	Engine	Special Function	Interval Of Oil Change (OCS) Oxidation
DFNISSAN	All Mode	2014 - 2014	Engine	Special Function	OIL Change Interval (Ocs): Dilution
DFNISSAN	All Mode	Up to 2017	Engine	Read Fault Code	
DFNISSAN	All Mode	Up to 2017	Engine	Clear Fault Code	
DFNISSAN	All Mode	Up to 2017	Engine	Read Data Stream	
DFNISSAN	All Mode	Up to 2017	Engine	Module Information	
DFNISSAN	All Mode	Up to 2017	Engine	Actuation Test	TC BYPASS VALVE
DFNISSAN	All Mode	Up to 2017	Engine	Actuation Test	Auto Stop Start
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	EGR control valve closed position learning
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	(TBD)VCR base position learning
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	Self-Learning Cont
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	A/F Initial Learning
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	TARGET IGN TIM ADJ
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	TARGET IDLE RPM ADJ
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	VALVE TIMING ADJUSTMENT
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	Engine Coolant Bypass Valve
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	Idle Air Vol Learn
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	Saving Data For Replc CPU
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	Writing Data For Replc CPU
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	Electric intake valve timing control learning
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	Valve Timing Offset Data Writing
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	Valve Timing Offset Data Clear
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	STRT OPRTN CNTR CLEAR
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	CML B/DCHRG CRNT CLEAR
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	SC MAGNETIC CLUTCH ENGAGE COUNT CLEAR
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	Fuel Pressure Release
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	EVAP System Close
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	CLSD THL POS LEARN
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	Active Control Engine Mounting A
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	Active Control Engine Mounting B
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	G Sensor Calibration
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	Wastegate Actuator Posi Learn Value Clear
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	Vin Registration
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	SUB-STARTER & GENERATOR OPER COUNT CLEAR
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	Cumulative Sub-Battry Dischg Current Clear
DFNISSAN	All Mode	2016 - 2016	Engine	Read Fault Code	
DFNISSAN	All Mode	2016 - 2016	Engine	Clear Fault Code	
DFNISSAN	All Mode	2016 - 2016	Engine	Read Data Stream	
DFNISSAN	All Mode	2016 - 2016	Engine	Module Information	
DFNISSAN	All Mode	2016 - 2016	Engine	Actuation Test	Check Boost Pressure Positioner
DFNISSAN	All Mode	2016 - 2016	Engine	Actuation Test	Check Rail Pressure Sensor
DFNISSAN	All Mode	2016 - 2016	Engine	Actuation Test	Check Intake Port Shutoff Actuator Motor
DFNISSAN	All Mode	2016 - 2016	Engine	Actuation Test	EGR Valve Jams
DFNISSAN	All Mode	2016 - 2016	Engine	Actuation Test	Injector shutoff(CYL 1)
DFNISSAN	All Mode	2016 - 2016	Engine	Actuation Test	Injector shutoff(CYL 2)
DFNISSAN	All Mode	2016 - 2016	Engine	Actuation Test	Injector shutoff(CYL 3)
DFNISSAN	All Mode	2016 - 2016	Engine	Actuation Test	Injector shutoff(CYL 4)
DFNISSAN	All Mode	2016 - 2016	Engine	Actuation Test	Fuel Pump
DFNISSAN	All Mode	2016 - 2016	Engine	Actuation Test	Ck Eng And Ac With Intgrted Cont Fan Motor
DFNISSAN	All Mode	2016 - 2016	Engine	Actuation Test	Check Glow Plugs
DFNISSAN	All Mode	2016 - 2016	Engine	Actuation Test	Check Engine Oil Pump Valve
DFNISSAN	All Mode	2016 - 2016	Engine	Actuation Test	Check Oil Spray Nozzles Shutoff Valve
DFNISSAN	All Mode	2016 - 2016	Engine	Actuation Test	Check Coolant Pump Switchover Valve

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

<b>make</b>	<b>model</b>	<b>year</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
DFNISSAN	All Mode	2016 - 2016	Engine	Actuation Test	Check EGR Cooler Bypss Sw Over Valve
DFNISSAN	All Mode	2016 - 2016	Engine	Actuation Test	Check O2 Upstream Of Catalytic Converter
DFNISSAN	All Mode	2016 - 2016	Engine	Actuation Test	Check EGR Actuator
DFNISSAN	All Mode	2016 - 2016	Engine	Actuation Test	Coolant thermostat heating element
DFNISSAN	All Mode	2016 - 2016	Engine	Actuation Test	Check Fuel HI Press Circ For Leaktightness
DFNISSAN	All Mode	2016 - 2016	Engine	Actuation Test	EGR actuator (auto evaluation)
DFNISSAN	All Mode	2016 - 2016	Engine	Actuation Test	Causes of engine stop prevention
DFNISSAN	All Mode	2016 - 2016	Engine	Actuation Test	Causes of engine stop prevention combustion engine
DFNISSAN	All Mode	2016 - 2016	Engine	Actuation Test	Malfunction status of stop/start system
DFNISSAN	All Mode	2016 - 2016	Engine	Actuation Test	History of regeneration of DPF
DFNISSAN	All Mode	2016 - 2016	Engine	Actuation Test	Preconditions for automatic engine stop
DFNISSAN	All Mode	2016 - 2016	Engine	Actuation Test	Requirements for automatic engine start
DFNISSAN	All Mode	2016 - 2016	Engine	Actuation Test	High pressure fuel pump (pressure regulation)
DFNISSAN	All Mode	2016 - 2016	Engine	Actuation Test	Leak test of charge air system
DFNISSAN	All Mode	2016 - 2016	Engine	Special Function	Enabling of engine start after crash event
DFNISSAN	All Mode	2016 - 2016	Engine	Special Function	Bleeding Of High Pressure Fuel Circuit
DFNISSAN	All Mode	2016 - 2016	Engine	Special Function	Teach In Boost Pressure Positioner
DFNISSAN	All Mode	2016 - 2016	Engine	Special Function	Reset Of Learned Values Of Cmsft Hall Sen
DFNISSAN	All Mode	2016 - 2016	Engine	Special Function	Reset Of Contamination Level Of Air Filter
DFNISSAN	All Mode	2016 - 2016	Engine	Special Function	Teach In Of DPF After Replace Of CDI C/U
DFNISSAN	All Mode	2016 - 2016	Engine	Special Function	Replace Diesel Particulate Filter
DFNISSAN	All Mode	2016 - 2016	Engine	Special Function	Teach In Of Throttle Valve Stop
DFNISSAN	All Mode	2016 - 2016	Engine	Special Function	Fuel Injector
DFNISSAN	All Mode	2016 - 2016	Engine	Read Fault Code	
DFNISSAN	All Mode	2016 - 2016	Engine	Clear Fault Code	
DFNISSAN	All Mode	2016 - 2016	Engine	Read Data Stream	
DFNISSAN	All Mode	2016 - 2016	Engine	Module Information	
DFNISSAN	All Mode	2016 - 2016	Engine	Actuation Test	Check fuel tank pressure sensor
DFNISSAN	All Mode	2016 - 2016	Engine	Actuation Test	Purging Switchover Valve
DFNISSAN	All Mode	2016 - 2016	Engine	Actuation Test	Check Deceleration Air Switchover Valve
DFNISSAN	All Mode	2016 - 2016	Engine	Actuation Test	Check Engine Oil Pump Valve
DFNISSAN	All Mode	2016 - 2016	Engine	Actuation Test	Check cylinder fuel injectors
DFNISSAN	All Mode	2016 - 2016	Engine	Actuation Test	Check purging pressure control
DFNISSAN	All Mode	2016 - 2016	Engine	Actuation Test	Check EGR Actuator
DFNISSAN	All Mode	2016 - 2016	Engine	Actuation Test	Check EGR valve hall sensor
DFNISSAN	All Mode	2016 - 2016	Engine	Actuation Test	Check Intake Camshaft Solenoid
DFNISSAN	All Mode	2016 - 2016	Engine	Actuation Test	Check Exhaust Camshaft Solenoid
DFNISSAN	All Mode	2016 - 2016	Engine	Actuation Test	Engine Diagnosis Indicator Lamp
DFNISSAN	All Mode	2016 - 2016	Engine	Actuation Test	Rail pressure reduction
DFNISSAN	All Mode	2016 - 2016	Engine	Actuation Test	Boost pressure control pressure transducer
DFNISSAN	All Mode	2016 - 2016	Engine	Actuation Test	Partial load operation crankcase ventilation valve
DFNISSAN	All Mode	2016 - 2016	Engine	Actuation Test	Check activated charcoal canister shutoff valve
DFNISSAN	All Mode	2016 - 2016	Engine	Actuation Test	Check cylinder fuel injectors for leaks
DFNISSAN	All Mode	2016 - 2016	Engine	Actuation Test	Check radiator shutters actuator
DFNISSAN	All Mode	2016 - 2016	Engine	Actuation Test	Quantity control valve



**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

<b>make</b>	<b>model</b>	<b>year</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
DFNISSAN	All Mode	2016 - 2016	Engine	Actuation Test	Check Fuel HI Press Circ For Leaktightness
DFNISSAN	All Mode	2016 - 2016	Engine	Actuation Test	Fuel Pump
DFNISSAN	All Mode	2016 - 2016	Engine	Special Function	Enabling of engine start after crash event
DFNISSAN	All Mode	2016 - 2016	Engine	Special Function	Teach In Of Throttle Valve Stop
DFNISSAN	All Mode	2016 - 2016	Engine	Special Function	Camshaft Reference Adaptation
DFNISSAN	All Mode	2016 - 2016	Engine	Special Function	Teach In Of Sensor Rotor Adaptation
DFNISSAN	All Mode	2016 - 2016	Engine	Special Function	Status Of Teach In Processes
DFNISSAN	All Mode	2016 - 2016	Engine	Special Function	Resetting Of Adaption Values
DFNISSAN	All Mode	2016 - 2016	Engine	Special Function	Ethanol Reading Frequency Counter Reset
DFNISSAN	All Mode	2016 - 2016	Engine	Special Function	Teach In The Ethanol Proportion In The Fuel
DFNISSAN	All Mode	2016 - 2016	Engine	Special Function	Teach In Of Camshaft Position
DFNISSAN	All Mode	2016 - 2016	Engine	Read Fault Code	
DFNISSAN	All Mode	2016 - 2016	Engine	Clear Fault Code	
DFNISSAN	All Mode	2016 - 2016	Engine	Read Data Stream	
DFNISSAN	All Mode	2016 - 2016	Engine	Module Information	
DFNISSAN	All Mode	2016 - 2016	Engine	Actuation Test	Check boost pressure regulator
DFNISSAN	All Mode	2016 - 2016	Engine	Actuation Test	Check exhaust flap controller
DFNISSAN	All Mode	2016 - 2016	Engine	Actuation Test	Low pressure EGR temperature sensor
DFNISSAN	All Mode	2016 - 2016	Engine	Actuation Test	High pressure fuel circuit leak test
DFNISSAN	All Mode	2016 - 2016	Engine	Actuation Test	Check DPF regeneration heater booster control unit
DFNISSAN	All Mode	2016 - 2016	Engine	Actuation Test	Rail Pressure
DFNISSAN	All Mode	2016 - 2016	Engine	Actuation Test	Check Fuel Injectors
DFNISSAN	All Mode	2016 - 2016	Engine	Special Function	Learned values reset - differential pressure sensor
DFNISSAN	All Mode	2016 - 2016	Engine	Special Function	Learned values reset - O2 sensor upstream of CAT
DFNISSAN	All Mode	2016 - 2016	Engine	Special Function	Teach in high pressure EGR actuator
DFNISSAN	All Mode	2016 - 2016	Engine	Special Function	Learned values reset - rail pressure sensor
DFNISSAN	All Mode	2016 - 2016	Engine	Special Function	Learned values reset - turbocharger
DFNISSAN	All Mode	2016 - 2016	Engine	Special Function	Teach in low pressure EGR actuator
DFNISSAN	All Mode	2016 - 2016	Engine	Special Function	Teach in exhaust flap controller
DFNISSAN	All Mode	2016 - 2016	Engine	Special Function	Teach in throttle valve actuator
DFNISSAN	All Mode	2016 - 2016	Engine	Special Function	Learned values reset - fuel system high pressure pump
DFNISSAN	All Mode	2016 - 2016	Engine	Special Function	Learned values reset - diesel particulate filter
DFNISSAN	All Mode	2016 - 2016	Engine	Special Function	Check glow output stage
DFNISSAN	All Mode	2016 - 2016	Engine	Special Function	Activation Of Fuel Pump
DFNISSAN	All Mode	2016 - 2016	Engine	Special Function	Status Of Teach In Processes
DFNISSAN	All Mode	2016 - 2016	Engine	Special Function	Injector Learning Value Clear
DFNISSAN	All Mode	2016 - 2016	Engine	Read Data Stream	
DFNISSAN	All Mode	2016 - 2016	Engine	Module Information	
DFNISSAN	All Mode	2016 - 2016	Engine	Actuation Test	Check EGR Cooler Bypss Sw Over Valve
DFNISSAN	All Mode	2016 - 2016	Engine	Actuation Test	Check Oil Spray Nozzles Shutoff Valve
DFNISSAN	All Mode	2016 - 2016	Engine	Actuation Test	Check Rail Pressure Sensor
DFNISSAN	All Mode	2016 - 2016	Engine	Actuation Test	Check Boost Pressure Positioner
DFNISSAN	All Mode	2016 - 2016	Engine	Actuation Test	Auto Stop Start
DFNISSAN	All Mode	2016 - 2016	Engine	Special Function	Teach In Boost Pressure Positioner
DFNISSAN	All Mode	2016 - 2016	Engine	Special Function	Reset Of Contamination Level Of Air Filter
DFNISSAN	All Mode	2016 - 2016	Engine	Special Function	Activation Of Fuel Pump

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

<b>make</b>	<b>model</b>	<b>year</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
DFNISSAN	All Mode	2016 - 2016	Engine	Special Function	Reset Of Learned Values Of Cmsft Hall Sen
DFNISSAN	All Mode	2016 - 2016	Engine	Special Function	Teach In Of Intake Port Shutoff
DFNISSAN	All Mode	2016 - 2016	Engine	Special Function	Vin Registration
DFNISSAN	All Mode	2016 - 2016	Engine	Special Function	STRT OPRTN CNTR CLEAR
DFNISSAN	All Mode	2016 - 2016	Engine	Special Function	H/P Fuel Pump Total Starts Counter Clear
DFNISSAN	All Mode	2016 - 2016	Engine	Special Function	Teach In Of Throttle Valve Stop
DFNISSAN	All Mode	2016 - 2016	Engine	Special Function	Replace Diesel Particulate Filter
DFNISSAN	All Mode	2016 - 2016	Engine	Special Function	Injector Injection Quantity Adjustment
DFNISSAN	All Mode	2016 - 2016	Engine	Special Function	OXIDATION CATALYTIC CONVERTER
DFNISSAN	All Mode	2016 - 2016	Engine	Special Function	Teach In Of DPf After Replace Of CDI C/U
DFNISSAN	All Mode	2016 - 2016	Engine	Special Function	OPR TIME BASIC DIAG SCR CATALYTIC CONVRTR
DFNISSAN	All Mode	2016 - 2016	Engine	Special Function	OPE TIME BASIC DIAG TEMP SEN UPSTREAM SCR CAT
DFNISSAN	All Mode	2016 - 2016	Engine	Special Function	TEACH IN AFTER REPLAC ADBLUE METERING VALVE
DFNISSAN	All Mode	2014 - 2016	Engine	Read Fault Code	
DFNISSAN	All Mode	2014 - 2016	Engine	Clear Fault Code	
DFNISSAN	All Mode	2014 - 2016	Engine	Read Data Stream	
DFNISSAN	All Mode	2014 - 2016	Engine	Module Information	
DFNISSAN	All Mode	2014 - 2016	Engine	Actuation Test	Auto Stop Start
DFNISSAN	All Mode	2014 - 2016	Engine	Actuation Test	Check Deceleration Air Switchover Valve
DFNISSAN	All Mode	2014 - 2016	Engine	Actuation Test	Check Engine Oil Pump Valve
DFNISSAN	All Mode	2014 - 2016	Engine	Actuation Test	Check Intake Camshaft Solenoid
DFNISSAN	All Mode	2014 - 2016	Engine	Actuation Test	Check Exhaust Camshaft Solenoid
DFNISSAN	All Mode	2014 - 2016	Engine	Actuation Test	Purging Switchover Valve
DFNISSAN	All Mode	2014 - 2016	Engine	Actuation Test	Check activated charcoal canister shutoff valve
DFNISSAN	All Mode	2014 - 2016	Engine	Actuation Test	Partial load operation crankcase ventilation valve
DFNISSAN	All Mode	2014 - 2016	Engine	Actuation Test	Check fuel tank pressure sensor
DFNISSAN	All Mode	2014 - 2016	Engine	Actuation Test	Check purging pressure control
DFNISSAN	All Mode	2014 - 2016	Engine	Actuation Test	Check cylinder fuel injectors
DFNISSAN	All Mode	2014 - 2016	Engine	Actuation Test	Check cylinder fuel injectors for leaks
DFNISSAN	All Mode	2014 - 2016	Engine	Actuation Test	Check Fuel HI Press Circ For Leaktightness
DFNISSAN	All Mode	2014 - 2016	Engine	Special Function	Resetting Of Adaption Values
DFNISSAN	All Mode	2014 - 2016	Engine	Special Function	Camshaft Reference Adaptation
DFNISSAN	All Mode	2014 - 2016	Engine	Special Function	Teach In Of Throttle Valve Stop
DFNISSAN	All Mode	2014 - 2016	Engine	Special Function	Teach In Of Camshaft Position
DFNISSAN	All Mode	2014 - 2016	Engine	Special Function	Injector Injection Quantity Adjustment
DFNISSAN	All Mode	2014 - 2016	Engine	Special Function	Vin Registration
DFNISSAN	All Mode	2014 - 2016	Engine	Special Function	STRT OPRTN CNTR CLEAR
DFNISSAN	All Mode	2014 - 2016	Engine	Special Function	H/P Fuel Pump Total Starts Counter Clear
DFNISSAN	All Mode	2014 - 2016	Engine	Special Function	Teach In Of Sensor Rotor Adaptation
DFNISSAN	All Mode	2014 - 2016	Engine	Special Function	Status Of Teach In Processes
DFNISSAN	All Mode	2014 - 2014	Engine	Read Fault Code	
DFNISSAN	All Mode	2014 - 2014	Engine	Clear Fault Code	
DFNISSAN	All Mode	2014 - 2014	Engine	Read Data Stream	
DFNISSAN	All Mode	2014 - 2014	Engine	Module Information	
DFNISSAN	All Mode	2014 - 2014	Engine	Actuation Test	PREHEATER RELAY
DFNISSAN	All Mode	2014 - 2014	Engine	Actuation Test	EGR VALVE
DFNISSAN	All Mode	2014 - 2014	Engine	Actuation Test	AIR INLET FLAP
DFNISSAN	All Mode	2014 - 2014	Engine	Actuation Test	TURBOCHARGING SOLENOID VALVE
DFNISSAN	All Mode	2014 - 2014	Engine	Actuation Test	Fuel Pump
DFNISSAN	All Mode	2014 - 2014	Engine	Actuation Test	PUMP PRESSURE REGULATOR

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
DFNISSAN	All Mode	2014 - 2014	Engine	Actuation Test	HIGH PRESSURE CIRCUIT LEAK TEST
DFNISSAN	All Mode	2014 - 2014	Engine	Actuation Test	STARTER RELAY
DFNISSAN	All Mode	2014 - 2014	Engine	Actuation Test	Starter Relay Command
DFNISSAN	All Mode	2014 - 2014	Engine	Actuation Test	FUEL HEATER
DFNISSAN	All Mode	2014 - 2014	Engine	Actuation Test	ELECTRIC WATER PUMP
DFNISSAN	All Mode	2014 - 2014	Engine	Actuation Test	FIRST EGR COOLING PUMP
DFNISSAN	All Mode	2014 - 2014	Engine	Actuation Test	SECOND EGR COOLING PUMP
DFNISSAN	All Mode	2014 - 2014	Engine	Actuation Test	COOLANT CIRC SWITCHING S/V
DFNISSAN	All Mode	2014 - 2014	Engine	Actuation Test	Auto Stop Start
DFNISSAN	All Mode	2014 - 2014	Engine	Special Function	Number Of Starting Cycles (V343)
DFNISSAN	All Mode	2014 - 2014	Engine	Special Function	High Pressure Pump Counter (V344)
DFNISSAN	All Mode	2014 - 2014	Engine	Special Function	Fuel Sply Prev
DFNISSAN	All Mode	2014 - 2014	Engine	Special Function	Number Of Starting 1
DFNISSAN	All Mode	2014 - 2014	Engine	Special Function	Number Of Starting 2
DFNISSAN	All Mode	2014 - 2014	Engine	Special Function	Number Of Starting 3
DFNISSAN	All Mode	2014 - 2014	Engine	Special Function	Number Of Starting 4
DFNISSAN	All Mode	2014 - 2014	Engine	Special Function	Vin Registration
DFNISSAN	All Mode	2014 - 2014	Engine	Special Function	Air Flowmeter Programming
DFNISSAN	All Mode	2014 - 2014	Engine	Special Function	Injection Pump Adaptatives (R077)
DFNISSAN	All Mode	2014 - 2014	Engine	Special Function	Fuel Pump Programming
DFNISSAN	All Mode	2014 - 2014	Engine	Special Function	Egr Valve Programming
DFNISSAN	All Mode	2014 - 2014	Engine	Special Function	EGR Adaptives
DFNISSAN	All Mode	2014 - 2014	Engine	Special Function	Engine Adaptives
DFNISSAN	All Mode	2014 - 2014	Engine	Special Function	Adaptives On Air Intake Flap Malfunction
DFNISSAN	All Mode	2014 - 2014	Engine	Special Function	Stop And Start Function
DFNISSAN	All Mode	2014 - 2014	Engine	Special Function	P/FLT DIFF PRS SEN
DFNISSAN	All Mode	2014 - 2014	Engine	Special Function	Prpr Rich Sen Prog
DFNISSAN	All Mode	2014 - 2014	Engine	Special Function	Catalytic Converter
DFNISSAN	All Mode	2014 - 2014	Engine	Special Function	CC/SL Prgrm
DFNISSAN	All Mode	2014 - 2014	Engine	Special Function	Interval Of Oil Change (OCS) Oxidation
DFNISSAN	All Mode	2014 - 2014	Engine	Special Function	OIL Change Interval (Ocs): Dilution
DFNISSAN	All Mode	2014 - 2014	Engine	Special Function	Enter Injector Codes
DFNISSAN	All Mode	2014 - 2014	Engine	Special Function	Write Saved Data
DFNISSAN	All Mode	2014 - 2014	Engine	Special Function	Save Computer Data
DFNISSAN	All Mode	2014 - 2014	Engine	Special Function	Speed Limiter
DFNISSAN	All Mode	2014 - 2014	Engine	Special Function	Alternator Setpoint Voltage
DFNISSAN	All Mode	2016 - 2016	Engine	Read Fault Code	
DFNISSAN	All Mode	2016 - 2016	Engine	Clear Fault Code	
DFNISSAN	All Mode	2016 - 2016	Engine	Read Data Stream	
DFNISSAN	All Mode	2016 - 2016	Engine	Module Information	
DFNISSAN	All Mode	2013 - 2017	Engine	Read Fault Code	
DFNISSAN	All Mode	2013 - 2017	Engine	Clear Fault Code	
DFNISSAN	All Mode	2013 - 2017	Engine	Read Data Stream	
DFNISSAN	All Mode	2013 - 2017	Engine	Module Information	
DFNISSAN	All Mode	Up to 2017	Engine	Read Fault Code	
DFNISSAN	All Mode	Up to 2017	Engine	Clear Fault Code	
DFNISSAN	All Mode	Up to 2017	Engine	Read Data Stream	
DFNISSAN	All Mode	Up to 2017	Engine	Module Information	
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	TP SW/TP SEN IDLE POSI ADJ
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	TP SW/TP SEN IDLE POSI ADJ
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	IGNITION TIMING ADJ
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	FUEL PRESSURE RELEASE
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	CHECK FUEL LINES
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	IDLE AIR VOL LEARN
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	SELF-LEARNING CONT
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	
DFNISSAN	All Mode	Up to 2017	Engine	Read Fault Code	
DFNISSAN	All Mode	Up to 2017	Engine	Clear Fault Code	
DFNISSAN	All Mode	Up to 2017	Engine	Read Data Stream	
DFNISSAN	All Mode	Up to 2017	Engine	Module Information	
DFNISSAN	All Mode	Up to 2017	Engine	Special Function	
DFNISSAN	All Mode	Up to 2009	Engine	Read Fault Code	
DFNISSAN	All Mode	Up to 2009	Engine	Clear Fault Code	
DFNISSAN	All Mode	Up to 2009	Engine	Read Data Stream	
DFNISSAN	All Mode	Up to 2009	Engine	Module Information	
DFNISSAN	All Mode	Up to 2009	Engine	Actuation Test	THERMO NO.3 RELAY
DFNISSAN	All Mode	Up to 2009	Engine	Actuation Test	FAN UNIT S SPD RLY
DFNISSAN	All Mode	Up to 2009	Engine	Actuation Test	FAN UNIT H SPD RLY
DFNISSAN	All Mode	Up to 2009	Engine	Actuation Test	OBD LIGHT
DFNISSAN	All Mode	Up to 2009	Engine	Actuation Test	EGR SOLENOID VALVE
DFNISSAN	All Mode	Up to 2009	Engine	Actuation Test	PRHT RLY GROUP N-1
DFNISSAN	All Mode	Up to 2009	Engine	Actuation Test	PREHEATER LIGHT
DFNISSAN	All Mode	Up to 2009	Engine	Actuation Test	OVERHEATING W/L

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

<b>make</b>	<b>model</b>	<b>year</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
DFNISSAN	All Mode	Up to 2009	Engine	Actuation Test	THERMOPLUNGER RLY1
DFNISSAN	All Mode	Up to 2009	Engine	Actuation Test	THERMOPLUNGER RLY2
DFNISSAN	All Mode	Up to 2009	Engine	Actuation Test	HIGH PRESSURE PUMP
DFNISSAN	All Mode	Up to 2009	Engine	Actuation Test	A/C COMPRESSOR
DFNISSAN	All Mode	Up to 2009	Engine	Actuation Test	INJECTOR CYLINDER 1
DFNISSAN	All Mode	Up to 2009	Engine	Actuation Test	INJECTOR CYLINDER 2
DFNISSAN	All Mode	Up to 2009	Engine	Actuation Test	INJECTOR CYLINDER 3
DFNISSAN	All Mode	Up to 2009	Engine	Actuation Test	INJECTOR CYLINDER 4
DFNISSAN	All Mode	Up to 2009	Engine	Actuation Test	LOCK INJECTOR CTRL
DFNISSAN	All Mode	Up to 2009	Engine	Actuation Test	UNLK INJECTOR CTRL
DFNISSAN	All Mode	Up to 2009	Engine	Actuation Test	HIGH PRESS CIRC LEAK T
DFNISSAN	All Mode	Up to 2009	Engine	Special Function	Saving Data For Replc CPU
DFNISSAN	All Mode	Up to 2009	Engine	Special Function	Writing Data For Replc CPU
DFNISSAN	All Mode	Up to 2009	Engine	Special Function	Vehicle Func Prog
DFNISSAN	All Mode	Up to 2009	Engine	Special Function	Decrement Idle Speed
DFNISSAN	All Mode	Up to 2009	Engine	Special Function	Increment Idle Speed
DFNISSAN	All Mode	Up to 2009	Engine	Special Function	EGR Adaptives
DFNISSAN	All Mode	Up to 2009	Engine	Special Function	Reset Pump Forcefeeding
DFNISSAN	All Mode	Up to 2009	Engine	Special Function	Reset Injctr Adaptative
DFNISSAN	All Mode	Up to 2009	Engine	Special Function	Enter Injctr Calib Data
DFNISSAN	All Mode	Up to 2009	Engine	Read Fault Code	
DFNISSAN	All Mode	Up to 2009	Engine	Clear Fault Code	
DFNISSAN	All Mode	Up to 2009	Engine	Read Data Stream	
DFNISSAN	All Mode	Up to 2009	Engine	Module Information	
DFNISSAN	All Mode	Up to 2009	Engine	Special Function	IGNITION TIMING ADJ
DFNISSAN	All Mode	Up to 2009	Engine	Special Function	IGNITION TIMING ADJ
DFNISSAN	All Mode	Up to 2009	Engine	Special Function	CHECK FUEL LINES
DFNISSAN	All Mode	Up to 2009	Engine	Special Function	FUEL PRESSURE RELEASE
DFNISSAN	All Mode	Up to 2009	Engine	Special Function	TP SW/TP SEN IDLE POSI ADJ
DFNISSAN	All Mode	Up to 2009	Engine	Special Function	TP SW/TP SEN IDLE POSI ADJ
DFNISSAN	All Mode	Up to 2009	Engine	Special Function	SELF-LEARNING CONT
DFNISSAN	All Mode	Up to 2009	Engine	Special Function	SELF-LEARNING CONT
DFNISSAN	All Mode	Up to 2009	Engine	Special Function	CLOSED TH/SW ADJ
DFNISSAN	All Mode	Up to 2009	Engine	Special Function	CLOSED TH/SW ADJ
DFNISSAN	All Mode	Up to 2009	Engine	Special Function	CLOSED TH/SW ADJ
DFNISSAN	All Mode	Up to 2009	Engine	Special Function	CLOSED TH/SW ADJ
DFNISSAN	All Mode	Up to 2009	Engine	Special Function	IDLE RPM ADJ
DFNISSAN	All Mode	Up to 2009	Engine	Special Function	IACV-AAC/V ADJ
DFNISSAN	All Mode	Up to 2009	Engine	Special Function	SET IDLE SPEED
DFNISSAN	All Mode	Up to 2009	Engine	Special Function	
DFNISSAN	All Mode	Up to 2009	Engine	Read Fault Code	
DFNISSAN	All Mode	Up to 2009	Engine	Clear Fault Code	
DFNISSAN	All Mode	Up to 2009	Engine	Read Data Stream	
DFNISSAN	All Mode	Up to 2009	Engine	Module Information	
DFNISSAN	All Mode	Up to 2009	Engine	Special Function	IDLE AIR VOL LEARN
DFNISSAN	All Mode	Up to 2009	Engine	Special Function	SELF-LEARNING CONT
DFNISSAN	All Mode	Up to 2009	Engine	Special Function	SELF-LEARNING CONT
DFNISSAN	All Mode	Up to 2009	Engine	Special Function	SELF-LEARNING CONT
DFNISSAN	All Mode	Up to 2009	Engine	Special Function	IGNITION TIMING ADJ
DFNISSAN	All Mode	Up to 2009	Engine	Special Function	IGNITION TIMING ADJ
DFNISSAN	All Mode	Up to 2009	Engine	Special Function	CHECK FUEL LINES
DFNISSAN	All Mode	Up to 2009	Engine	Special Function	FUEL PRESSURE RELEASE
DFNISSAN	All Mode	Up to 2009	Engine	Special Function	TP SW/TP SEN IDLE POSI ADJ
DFNISSAN	All Mode	Up to 2009	Engine	Special Function	TP SW/TP SEN IDLE POSI ADJ
DFNISSAN	All Mode	Up to 2009	Engine	Special Function	CLOSED TH/SW ADJ
DFNISSAN	All Mode	Up to 2009	Engine	Special Function	CLOSED TH/SW ADJ
DFNISSAN	All Mode	Up to 2009	Engine	Special Function	CLOSED TH/SW ADJ
DFNISSAN	All Mode	Up to 2009	Engine	Special Function	CLOSED TH/SW ADJ
DFNISSAN	All Mode	Up to 2009	Engine	Special Function	IDLE RPM ADJ
DFNISSAN	All Mode	Up to 2009	Engine	Special Function	IACV-AAC/V ADJ
DFNISSAN	All Mode	Up to 2009	Engine	Special Function	SET IDLE SPEED
DFNISSAN	All Mode	Up to 2009	Engine	Read Fault Code	
DFNISSAN	All Mode	Up to 2009	Engine	Clear Fault Code	
DFNISSAN	All Mode	Up to 2009	Engine	Read Data Stream	
DFNISSAN	All Mode	Up to 2009	Engine	Module Information	
DFNISSAN	All Mode	Up to 2009	Engine	Actuation Test	
DFNISSAN	All Mode	Up to 2017	Multi AV	Read Fault Code	
DFNISSAN	All Mode	Up to 2017	Multi AV	Clear Fault Code	
DFNISSAN	All Mode	Up to 2017	Multi AV	Read Data Stream	
DFNISSAN	All Mode	Up to 2017	Multi AV	Module Information	
DFNISSAN	All Mode	Up to 2017	Multi AV	Special Function	SELF-DIAG[ETC]
DFNISSAN	All Mode	Up to 2017	Multi AV	Read Fault Code	
DFNISSAN	All Mode	Up to 2017	Multi AV	Clear Fault Code	
DFNISSAN	All Mode	Up to 2017	Multi AV	Read Data Stream	
DFNISSAN	All Mode	Up to 2017	Multi AV	Module Information	
DFNISSAN	All Mode	Up to 2017	Multi AV	Special Function	SELF-DIAG[ETC]
DFNISSAN	All Mode	Up to 2017	Multi AV	Read Fault Code	
DFNISSAN	All Mode	Up to 2017	Multi AV	Clear Fault Code	
DFNISSAN	All Mode	Up to 2017	Multi AV	Read Data Stream	
DFNISSAN	All Mode	Up to 2017	Multi AV	Read Freeze Frame	

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
DFNISSAN	All Mode	Up to 2017	Multi AV	Module Information	
DFNISSAN	All Mode	Up to 2017	Multi AV	Special Function	SELF-DIAG[ETC]
DFNISSAN	All Mode	Up to 2017	Multi AV	Read Fault Code	
DFNISSAN	All Mode	Up to 2017	Multi AV	Clear Fault Code	
DFNISSAN	All Mode	Up to 2017	Multi AV	Read Data Stream	
DFNISSAN	All Mode	Up to 2017	Multi AV	Read Freeze Frame	
DFNISSAN	All Mode	Up to 2017	Multi AV	Module Information	
DFNISSAN	All Mode	Up to 2017	Multi AV	Read Fault Code	
DFNISSAN	All Mode	Up to 2017	Multi AV	Clear Fault Code	
DFNISSAN	All Mode	Up to 2017	Multi AV	Read Data Stream	
DFNISSAN	All Mode	Up to 2017	Multi AV	Module Information	
DFNISSAN	All Mode	Up to 2017	Multi AV	Read Fault Code	
DFNISSAN	All Mode	Up to 2017	Multi AV	Clear Fault Code	
DFNISSAN	All Mode	Up to 2017	Multi AV	Read Data Stream	
DFNISSAN	All Mode	Up to 2017	Multi AV	Read Freeze Frame	
DFNISSAN	All Mode	Up to 2017	Multi AV	Module Information	
DFNISSAN	All Mode	Up to 2017	Multi AV	Read Fault Code	
DFNISSAN	All Mode	Up to 2017	Multi AV	Clear Fault Code	
DFNISSAN	All Mode	Up to 2017	Multi AV	Read Data Stream	
DFNISSAN	All Mode	Up to 2017	Multi AV	Module Information	
DFNISSAN	All Mode	Up to 2017	Multi AV	Special Function	ST ANG Sen Adjustment
DFNISSAN	All Mode	2016 - 2016	Multi AV	Read Fault Code	
DFNISSAN	All Mode	2016 - 2016	Multi AV	Clear Fault Code	
DFNISSAN	All Mode	2016 - 2016	Multi AV	Read Data Stream	
DFNISSAN	All Mode	2016 - 2016	Multi AV	Module Information	
DFNISSAN	All Mode	2016 - 2016	Multi AV	Special Function	ST ANG Sen Adjustment
DFNISSAN	All Mode	2016 - 2016	Multi AV	Read Fault Code	
DFNISSAN	All Mode	2016 - 2016	Multi AV	Clear Fault Code	
DFNISSAN	All Mode	2016 - 2016	Multi AV	Read Data Stream	
DFNISSAN	All Mode	2016 - 2016	Multi AV	Module Information	
DFNISSAN	All Mode	2016 - 2016	Multi AV	Special Function	ST ANG Sen Adjustment
DFNISSAN	All Mode	2013 - 2017	Multi AV	Read Fault Code	
DFNISSAN	All Mode	2013 - 2017	Multi AV	Clear Fault Code	
DFNISSAN	All Mode	2013 - 2017	Multi AV	Read Data Stream	
DFNISSAN	All Mode	2013 - 2017	Multi AV	Module Information	
DFNISSAN	All Mode	Up to 2009	Multi AV	Read Fault Code	
DFNISSAN	All Mode	Up to 2009	Multi AV	Clear Fault Code	
DFNISSAN	All Mode	Up to 2009	Multi AV	Read Data Stream	
DFNISSAN	All Mode	Up to 2009	Multi AV	Module Information	
DFNISSAN	All Mode	2014 - 2017	CAN GATEWAY3	Read Fault Code	
DFNISSAN	All Mode	2014 - 2017	CAN GATEWAY3	Clear Fault Code	
DFNISSAN	All Mode	2014 - 2017	CAN GATEWAY3	Read Data Stream	
DFNISSAN	All Mode	2014 - 2017	CAN GATEWAY3	Module Information	
DFNISSAN	All Mode	Up to 2009	NATS IMMU	Read Fault Code	
DFNISSAN	All Mode	Up to 2009	NATS IMMU	Clear Fault Code	
DFNISSAN	All Mode	Up to 2009	NATS IMMU	Module Information	
DFNISSAN	All Mode	Up to 2011	Smart Entrance	Read Fault Code	
DFNISSAN	All Mode	Up to 2011	Smart Entrance	Clear Fault Code	
DFNISSAN	All Mode	Up to 2011	Smart Entrance	Read Data Stream	
DFNISSAN	All Mode	Up to 2011	Smart Entrance	Module Information	
DFNISSAN	All Mode	Up to 2011	Smart Entrance	Special Function	
DFNISSAN	All Mode	Up to 2011	Smart Entrance	Read Data Stream	
DFNISSAN	All Mode	Up to 2011	Smart Entrance	Module Information	
DFNISSAN	All Mode	Up to 2011	Smart Entrance	Special Function	REMO CONT ID ERASUR
DFNISSAN	All Mode	Up to 2011	Smart Entrance	Special Function	THEFT ALM TRG
DFNISSAN	All Mode	Up to 2011	Smart Entrance	Special Function	REMO CONT ID REGIST
DFNISSAN	All Mode	Up to 2011	Smart Entrance	Special Function	HZRD REM SET
DFNISSAN	All Mode	Up to 2011	Smart Entrance	Special Function	
DFNISSAN	All Mode	Up to 2011	Smart Entrance	Read Data Stream	
DFNISSAN	All Mode	Up to 2011	Smart Entrance	Module Information	
DFNISSAN	All Mode	Up to 2011	Smart Entrance	Special Function	REMO CONT ID REGIST
DFNISSAN	All Mode	Up to 2011	Smart Entrance	Special Function	REMO CONT ID ERASUR
DFNISSAN	All Mode	Up to 2017	Air Levelizer	Read Fault Code	
DFNISSAN	All Mode	Up to 2017	Air Levelizer	Clear Fault Code	
DFNISSAN	All Mode	Up to 2017	Air Levelizer	Read Data Stream	
DFNISSAN	All Mode	Up to 2017	Air Levelizer	Module Information	
DFNISSAN	All Mode	Up to 2017	Air Levelizer	Special Function	
DFNISSAN	All Mode	Up to 2013	Rearview Camera	Read Data Stream	
DFNISSAN	All Mode	Up to 2013	Rearview Camera	Module Information	
DFNISSAN	All Mode	Up to 2013	Rearview Camera	Special Function	
DFNISSAN	All Mode	Up to 2013	S/Blind Camera	Read Data Stream	
DFNISSAN	All Mode	Up to 2013	S/Blind Camera	Module Information	
DFNISSAN	All Mode	Up to 2013	S/Blind Camera	Special Function	
DFNISSAN	All Mode	Up to 2009	Active Engine Mount	Read Fault Code	
DFNISSAN	All Mode	Up to 2009	Active Engine Mount	Clear Fault Code	
DFNISSAN	All Mode	Up to 2009	Active Engine Mount	Read Data Stream	
DFNISSAN	All Mode	Up to 2009	Active Engine Mount	Module Information	
DFNISSAN	All Mode	Up to 2009	Active Sus	Read Fault Code	
DFNISSAN	All Mode	Up to 2009	Active Sus	Clear Fault Code	
DFNISSAN	All Mode	Up to 2009	Active Sus	Read Data Stream	

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
DFNISSAN	All Mode	Up to 2009	Active Sus	Module Information	
DFNISSAN	All Mode	Up to 2009	Active Sus	Actuation Test	
DFNISSAN	All Mode	Up to 2009	Active Sus	Read Fault Code	
DFNISSAN	All Mode	Up to 2009	Active Sus	Clear Fault Code	
DFNISSAN	All Mode	Up to 2009	Active Sus	Read Data Stream	
DFNISSAN	All Mode	Up to 2009	Active Sus	Module Information	
DFNISSAN	All Mode	Up to 2009	Active Sus	Special Function	HYDRAULIC SYSTEM
DFNISSAN	All Mode	Up to 2009	Active Sus	Special Function	OPERATION CHECK
DFNISSAN	All Mode	Up to 2009	ASCD	Read Fault Code	
DFNISSAN	All Mode	Up to 2009	ASCD	Clear Fault Code	
DFNISSAN	All Mode	Up to 2009	ASCD	Read Data Stream	
DFNISSAN	All Mode	Up to 2009	ASCD	Module Information	
DFNISSAN	All Mode	Up to 2009	ASCD	Read Fault Code	
DFNISSAN	All Mode	Up to 2009	ASCD	Clear Fault Code	
DFNISSAN	All Mode	Up to 2009	ASCD	Read Data Stream	
DFNISSAN	All Mode	Up to 2009	ASCD	Module Information	
DFNISSAN	All Mode	Up to 2009	Distance Control	Read Fault Code	
DFNISSAN	All Mode	Up to 2009	Distance Control	Clear Fault Code	
DFNISSAN	All Mode	Up to 2009	Distance Control	Read Data Stream	
DFNISSAN	All Mode	Up to 2009	Motor Assist	Read Fault Code	
DFNISSAN	All Mode	Up to 2009	Motor Assist	Clear Fault Code	
DFNISSAN	All Mode	Up to 2009	Motor Assist	Read Data Stream	
DFNISSAN	All Mode	Up to 2009	Motor Assist	Special Function	
DFNISSAN	All Mode	Up to 2009	IVMS (In-Vehicle Multiplexing System)	Read Fault Code	
DFNISSAN	All Mode	Up to 2009	IVMS (In-Vehicle Multiplexing System)	Clear Fault Code	
DFNISSAN	All Mode	Up to 2009	IVMS (In-Vehicle Multiplexing System)	Read Data Stream	
DFNISSAN	All Mode	Up to 2009	IVMS (In-Vehicle Multiplexing System)	Module Information	
DFNISSAN	All Mode	Up to 2009	IVMS (In-Vehicle Multiplexing System)	Special Function	UNIVERSAL FUNCTION
DFNISSAN	All Mode	Up to 2009	IVMS (In-Vehicle Multiplexing System)	Special Function	
DFNISSAN	All Mode	2014 - 2015	CAN GATEWAY2	Read Fault Code	
DFNISSAN	All Mode	2014 - 2015	CAN GATEWAY2	Clear Fault Code	
DFNISSAN	All Mode	2014 - 2015	CAN GATEWAY2	Read Data Stream	
DFNISSAN	All Mode	2014 - 2015	CAN GATEWAY2	Module Information	
DFNISSAN	All Mode	Up to 2009	TCS (Traction Control System)	Read Fault Code	
DFNISSAN	All Mode	Up to 2009	TCS (Traction Control System)	Clear Fault Code	
DFNISSAN	All Mode	Up to 2009	TCS (Traction Control System)	Read Data Stream	
DFNISSAN	All Mode	Up to 2009	TCS (Traction Control System)	Module Information	
DFNISSAN	All Mode	Up to 2009	TCS (Traction Control System)	Special Function	THRTL POS SEN2 ADJ
DFNISSAN	All Mode	Up to 2009	TCS (Traction Control System)	Special Function	CLSD/TH-P LEARN CLR
DFNISSAN	All Mode	2013 - 2016	FSCM (Fuel System Control Modle)	Read Fault Code	
DFNISSAN	All Mode	2013 - 2016	FSCM (Fuel System Control Modle)	Clear Fault Code	
DFNISSAN	All Mode	2013 - 2016	FSCM (Fuel System Control Modle)	Read Data Stream	
DFNISSAN	All Mode	2013 - 2016	FSCM (Fuel System Control Modle)	Module Information	
DFNISSAN	All Mode	2013 - 2016	FSCM (Fuel System Control Modle)	Actuation Test	CK Fuel Prss & Intrnl Lktghtnss Of FL Sys
DFNISSAN	All Mode	2016 - 2016	FSCM (Fuel System Control Modle)	Read Fault Code	
DFNISSAN	All Mode	2016 - 2016	FSCM (Fuel System Control Modle)	Clear Fault Code	
DFNISSAN	All Mode	2016 - 2016	FSCM (Fuel System Control Modle)	Read Data Stream	
DFNISSAN	All Mode	2016 - 2016	FSCM (Fuel System Control Modle)	Module Information	
DFNISSAN	All Mode	2014 - 2016	FSCM (Fuel System Control Modle)	Read Fault Code	
DFNISSAN	All Mode	2014 - 2016	FSCM (Fuel System Control Modle)	Clear Fault Code	
DFNISSAN	All Mode	2014 - 2016	FSCM (Fuel System Control Modle)	Read Data Stream	
DFNISSAN	All Mode	2014 - 2016	FSCM (Fuel System Control Modle)	Module Information	
DFNISSAN	All Mode	2014 - 2015	PMAS	Read Fault Code	
DFNISSAN	All Mode	2014 - 2015	PMAS	Clear Fault Code	
DFNISSAN	All Mode	2014 - 2015	PMAS	Read Data Stream	
DFNISSAN	All Mode	2014 - 2015	PMAS	Module Information	
DFNISSAN	All Mode	2014 - 2015	PMAS	Special Function	G Sensor Horizon Status Learning
DFNISSAN	All Mode	2014 - 2015	PMAS	Special Function	Cause Of Auto-Cancel 4
DFNISSAN	All Mode	2016 - 2016	Left front door control unit	Read Fault Code	
DFNISSAN	All Mode	2016 - 2016	Left front door control unit	Clear Fault Code	
DFNISSAN	All Mode	2016 - 2016	Left front door control unit	Read Data Stream	
DFNISSAN	All Mode	2016 - 2016	Left front door control unit	Module Information	
DFNISSAN	All Mode	2016 - 2016	Left front door control unit	Actuation Test	Front door lock actuator left
DFNISSAN	All Mode	2016 - 2016	Left front door control unit	Actuation Test	Front door switch illumination left
DFNISSAN	All Mode	2016 - 2016	Left front door control unit	Actuation Test	Front super lock actuator left
DFNISSAN	All Mode	2016 - 2016	Left front door control unit	Actuation Test	Front door handle illumination left
DFNISSAN	All Mode	2016 - 2016	Left front door control unit	Actuation Test	Front door exit and warning lamp left
DFNISSAN	All Mode	2016 - 2016	Left front door control unit	Actuation Test	Front door ambience illuminatin left
DFNISSAN	All Mode	2016 - 2016	Left front door control unit	Actuation Test	Side turn signal lamp left
DFNISSAN	All Mode	2016 - 2016	Left front door control unit	Actuation Test	Front power window motor left

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
DFNISSAN	All Mode	2016 - 2016	Left front door control unit	Actuation Test	Outside mirror ambient lamp left
DFNISSAN	All Mode	2016 - 2016	Left front door control unit	Actuation Test	Left blind spot assist warning
DFNISSAN	All Mode	2016 - 2016	Left front door control unit	Actuation Test	Auto anti-dazzling mirror
DFNISSAN	All Mode	2016 - 2016	Left front door control unit	Actuation Test	Power folding unit
DFNISSAN	All Mode	2016 - 2016	Left front door control unit	Actuation Test	Door mirror defogger
DFNISSAN	All Mode	2016 - 2016	Left front door control unit	Actuation Test	Adjustment actuator motor via actuation
DFNISSAN	All Mode	2016 - 2016	Left front door control unit	Actuation Test	Vertical and horizontal inclination adjustment
DFNISSAN	All Mode	2016 - 2016	Left front door control unit	Actuation Test	Left memory function
DFNISSAN	All Mode	2016 - 2016	Left front door control unit	Actuation Test	Denormalization of left front power window
DFNISSAN	All Mode	2016 - 2016	Left front door control unit	Actuation Test	Left outside mirror adjust
DFNISSAN	All Mode	2016 - 2016	Left front door control unit	Actuation Test	LEDs
DFNISSAN	All Mode	2016 - 2016	Left front door control unit	Actuation Test	Control unit reset
DFNISSAN	All Mode	2016 - 2016	Right front door control unit	Read Fault Code	
DFNISSAN	All Mode	2016 - 2016	Right front door control unit	Clear Fault Code	
DFNISSAN	All Mode	2016 - 2016	Right front door control unit	Read Data Stream	
DFNISSAN	All Mode	2016 - 2016	Right front door control unit	Module Information	
DFNISSAN	All Mode	2016 - 2016	Right front door control unit	Actuation Test	Front door lock actuator right
DFNISSAN	All Mode	2016 - 2016	Right front door control unit	Actuation Test	Front door switch illumination right
DFNISSAN	All Mode	2016 - 2016	Right front door control unit	Actuation Test	Front super lock actuator right
DFNISSAN	All Mode	2016 - 2016	Right front door control unit	Actuation Test	Front door handle illumination right
DFNISSAN	All Mode	2016 - 2016	Right front door control unit	Actuation Test	Front door exit and warning lamp right
DFNISSAN	All Mode	2016 - 2016	Right front door control unit	Actuation Test	Front door ambience illuminatin right
DFNISSAN	All Mode	2016 - 2016	Right front door control unit	Actuation Test	Side turn signal lamp right
DFNISSAN	All Mode	2016 - 2016	Right front door control unit	Actuation Test	Front power window motor right
DFNISSAN	All Mode	2016 - 2016	Right front door control unit	Actuation Test	Outside mirror ambient lamp right
DFNISSAN	All Mode	2016 - 2016	Right front door control unit	Actuation Test	Right blind spot assist warning
DFNISSAN	All Mode	2016 - 2016	Right front door control unit	Actuation Test	Auto anti-dazzling mirror
DFNISSAN	All Mode	2016 - 2016	Right front door control unit	Actuation Test	Power folding unit
DFNISSAN	All Mode	2016 - 2016	Right front door control unit	Actuation Test	Door mirror defogger
DFNISSAN	All Mode	2016 - 2016	Right front door control unit	Actuation Test	Adjustment actuator motor via actuation
DFNISSAN	All Mode	2016 - 2016	Right front door control unit	Actuation Test	Vertical and horizontal inclination adjustment
DFNISSAN	All Mode	2016 - 2016	Right front door control unit	Actuation Test	Right memory function
DFNISSAN	All Mode	2016 - 2016	Right front door control unit	Actuation Test	Denormalization of right rear power window
DFNISSAN	All Mode	2016 - 2016	Right front door control unit	Actuation Test	Right outside mirror adjust
DFNISSAN	All Mode	2016 - 2016	Right front door control unit	Actuation Test	LEDs
DFNISSAN	All Mode	2016 - 2016	Right front door control unit	Actuation Test	Control unit reset
DFNISSAN	All Mode	2016 - 2016	Siren control unit	Read Fault Code	
DFNISSAN	All Mode	2016 - 2016	Siren control unit	Clear Fault Code	
DFNISSAN	All Mode	2016 - 2016	Siren control unit	Read Data Stream	
DFNISSAN	All Mode	2016 - 2016	Siren control unit	Module Information	
DFNISSAN	All Mode	2016 - 2016	Siren control unit	Actuation Test	Actuation of tow away prot buttn and interior prot buttn
DFNISSAN	All Mode	2016 - 2016	Siren control unit	Actuation Test	Eighth to last data record
DFNISSAN	All Mode	2016 - 2016	Siren control unit	Actuation Test	Fifth from last data record
DFNISSAN	All Mode	2016 - 2016	Siren control unit	Actuation Test	Fourth from last data record
DFNISSAN	All Mode	2016 - 2016	Siren control unit	Actuation Test	Last data record
DFNISSAN	All Mode	2016 - 2016	Siren control unit	Actuation Test	Ninth to last data record
DFNISSAN	All Mode	2016 - 2016	Siren control unit	Actuation Test	Second from last data record
DFNISSAN	All Mode	2016 - 2016	Siren control unit	Actuation Test	Seventh to last data record
DFNISSAN	All Mode	2016 - 2016	Siren control unit	Actuation Test	Sixth to last data record
DFNISSAN	All Mode	2016 - 2016	Siren control unit	Actuation Test	Tenth to last data record
DFNISSAN	All Mode	2016 - 2016	Siren control unit	Actuation Test	Third from last data record
DFNISSAN	All Mode	2016 - 2016	Siren control unit	Special Function	Clear alarm history
DFNISSAN	All Mode	2016 - 2016	Alarm siren	Read Data Stream	
DFNISSAN	All Mode	2016 - 2016	Alarm siren	Module Information	
DFNISSAN	All Mode	2016 - 2016	Passenger seat control unit	Read Fault Code	
DFNISSAN	All Mode	2016 - 2016	Passenger seat control unit	Clear Fault Code	
DFNISSAN	All Mode	2016 - 2016	Passenger seat control unit	Read Data Stream	
DFNISSAN	All Mode	2016 - 2016	Passenger seat control unit	Module Information	

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

<b>make</b>	<b>model</b>	<b>year</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
DFNISSAN	All Mode	2016 - 2016	Passenger seat control unit	Actuation Test	Front passenger seat sliding motor
DFNISSAN	All Mode	2016 - 2016	Passenger seat control unit	Actuation Test	Front passenger seat lifting motor (front)
DFNISSAN	All Mode	2016 - 2016	Passenger seat control unit	Actuation Test	Front passenger seat lifting motor (rear)
DFNISSAN	All Mode	2016 - 2016	Passenger seat control unit	Actuation Test	Front passenger seat headrest motor
DFNISSAN	All Mode	2016 - 2016	Passenger seat control unit	Actuation Test	Front passenger seat reclining motor
DFNISSAN	All Mode	2016 - 2016	Passenger seat control unit	Special Function	Normalization
DFNISSAN	All Mode	2016 - 2016	Intelligent battery sensor	Module Information	
DFNISSAN	All Mode	2016 - 2016	Upper control panel cont unit	Module Information	
DFNISSAN	All Mode	2016 - 2016	EC mirror compass	Module Information	
DFNISSAN	All Mode	2016 - 2016	Universal garage door opener	Module Information	
DFNISSAN	All Mode	2016 - 2016	Universal garage door opener	Special Function	Writing security byte
DFNISSAN	All Mode	2016 - 2016	Universal garage door opener	Special Function	Initial startup
DFNISSAN	All Mode	2016 - 2016	Light & rain sensor	Read Data Stream	
DFNISSAN	All Mode	2016 - 2016	Light & rain sensor	Module Information	
DFNISSAN	All Mode	2016 - 2016	Light & rain sensor	Special Function	Adaptation of component of rain sensor
DFNISSAN	All Mode	2016 - 2016	Overhead control panel unit	Module Information	
DFNISSAN	All Mode	2016 - 2016	Electronic ign switch cont unit	Read Fault Code	
DFNISSAN	All Mode	2016 - 2016	Electronic ign switch cont unit	Clear Fault Code	
DFNISSAN	All Mode	2016 - 2016	Electronic ign switch cont unit	Read Data Stream	
DFNISSAN	All Mode	2016 - 2016	Electronic ign switch cont unit	Module Information	
DFNISSAN	All Mode	2016 - 2016	Electronic ign switch cont unit	Actuation Test	Vehicle data
DFNISSAN	All Mode	2016 - 2016	Electronic ign switch cont unit	Special Function	Vin Registration
DFNISSAN	All Mode	2016 - 2016	Trailer recognition control unit	Read Fault Code	
DFNISSAN	All Mode	2016 - 2016	Trailer recognition control unit	Clear Fault Code	
DFNISSAN	All Mode	2016 - 2016	Trailer recognition control unit	Read Data Stream	
DFNISSAN	All Mode	2016 - 2016	Trailer recognition control unit	Module Information	
DFNISSAN	All Mode	2016 - 2016	Trailer recognition control unit	Actuation Test	Back-Up Lamp
DFNISSAN	All Mode	2016 - 2016	Trailer recognition control unit	Actuation Test	Stop Lamp
DFNISSAN	All Mode	2016 - 2016	Trailer recognition control unit	Actuation Test	Left Tail Lamp
DFNISSAN	All Mode	2016 - 2016	Trailer recognition control unit	Actuation Test	Right Tail Lamp
DFNISSAN	All Mode	2016 - 2016	Trailer recognition control unit	Actuation Test	Left Turn Signal
DFNISSAN	All Mode	2016 - 2016	Trailer recognition control unit	Actuation Test	Right Turn Signal
DFNISSAN	All Mode	2016 - 2016	Trailer recognition control unit	Actuation Test	Rear Fog Lamp Type
DFNISSAN	All Mode	2016 - 2016	Trailer recognition control unit	Actuation Test	Terminal 15g trailer socket
DFNISSAN	All Mode	2016 - 2016	Trailer recognition control unit	Actuation Test	Terminal 30g trailer socket
DFNISSAN	All Mode	2016 - 2016	Occupant classification unit	Read Data Stream	
DFNISSAN	All Mode	2016 - 2016	Occupant classification unit	Module Information	
DFNISSAN	All Mode	2016 - 2016	ICC sensor	Read Fault Code	
DFNISSAN	All Mode	2016 - 2016	ICC sensor	Clear Fault Code	
DFNISSAN	All Mode	2016 - 2016	ICC sensor	Read Data Stream	
DFNISSAN	All Mode	2016 - 2016	ICC sensor	Module Information	
DFNISSAN	All Mode	2016 - 2016	ICC sensor	Special Function	Calibration of long range radar sensor
DFNISSAN	All Mode	2016 - 2016	Parking assist	Read Fault Code	
DFNISSAN	All Mode	2016 - 2016	Parking assist	Clear Fault Code	
DFNISSAN	All Mode	2016 - 2016	Parking assist	Read Data Stream	
DFNISSAN	All Mode	2016 - 2016	Parking assist	Module Information	
DFNISSAN	All Mode	2016 - 2016	Parking assist	Special Function	Electrical contacting of sensor and functional test
DFNISSAN	All Mode	2016 - 2016	Steering column cont module	Read Fault Code	
DFNISSAN	All Mode	2016 - 2016	Steering column cont module	Clear Fault Code	
DFNISSAN	All Mode	2016 - 2016	Steering column cont module	Read Data Stream	
DFNISSAN	All Mode	2016 - 2016	Steering column cont module	Module Information	
DFNISSAN	All Mode	2016 - 2016	Steering column cont module	Actuation Test	Speedtronic light emitting diode
DFNISSAN	All Mode	2016 - 2016	Steering wheel switch pad	Read Data Stream	
DFNISSAN	All Mode	2016 - 2016	Steering wheel switch pad	Module Information	
DFNISSAN	All Mode	2016 - 2016	Radar sensor	Read Fault Code	
DFNISSAN	All Mode	2016 - 2016	Radar sensor	Clear Fault Code	
DFNISSAN	All Mode	2016 - 2016	Radar sensor	Read Data Stream	
DFNISSAN	All Mode	2016 - 2016	Radar sensor	Module Information	
DFNISSAN	All Mode	2016 - 2016	Radar sensor	Actuation Test	Check for invalid VIN
DFNISSAN	All Mode	2016 - 2016	Radar sensor	Actuation Test	CPA has received crash signal
DFNISSAN	All Mode	2016 - 2016	Radar sensor	Actuation Test	Collision prevention assist warning lamp
DFNISSAN	All Mode	2016 - 2016	Radar sensor	Special Function	Resetting of learned values of control unit
DFNISSAN	All Mode	2016 - 2016	Radar sensor	Special Function	Re learning
DFNISSAN	All Mode	2016 - 2016	LED H/L control module RH	Read Data Stream	
DFNISSAN	All Mode	2016 - 2016	LED H/L control module RH	Module Information	
DFNISSAN	All Mode	2016 - 2016	LED H/L control module RH	Special Function	Reset operating hours counter of FR lamp fan motor 2



**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
DFNISSAN	All Mode	2016 - 2016	LED H/L control module LH	Read Data Stream	
DFNISSAN	All Mode	2016 - 2016	LED H/L control module LH	Module Information	
DFNISSAN	All Mode	2016 - 2016	LED H/L control module LH	Special Function	Reset operating hours counter of FL lamp fan motor 2
DFNISSAN	All Mode	2016 - 2016	Side radar RH	Read Fault Code	
DFNISSAN	All Mode	2016 - 2016	Side radar RH	Clear Fault Code	
DFNISSAN	All Mode	2016 - 2016	Side radar RH	Read Data Stream	
DFNISSAN	All Mode	2016 - 2016	Side radar RH	Module Information	
DFNISSAN	All Mode	2016 - 2016	Side radar LH	Read Fault Code	
DFNISSAN	All Mode	2016 - 2016	Side radar LH	Clear Fault Code	
DFNISSAN	All Mode	2016 - 2016	Side radar LH	Read Data Stream	
DFNISSAN	All Mode	2016 - 2016	Side radar LH	Module Information	
DFNISSAN	All Mode	2016 - 2016	Front camera unit	Read Fault Code	
DFNISSAN	All Mode	2016 - 2016	Front camera unit	Clear Fault Code	
DFNISSAN	All Mode	2016 - 2016	Front camera unit	Read Data Stream	
DFNISSAN	All Mode	2016 - 2016	Front camera unit	Module Information	
DFNISSAN	All Mode	2016 - 2016	Front camera unit	Actuation Test	Check auxiliary heater heating element has a malfunction
DFNISSAN	All Mode	2016 - 2016	Front camera unit	Special Function	Retrofitting
DFNISSAN	All Mode	2016 - 2016	PCM (Powertrain Control Module)	Read Fault Code	
DFNISSAN	All Mode	2016 - 2016	PCM (Powertrain Control Module)	Clear Fault Code	
DFNISSAN	All Mode	2016 - 2016	PCM (Powertrain Control Module)	Read Data Stream	
DFNISSAN	All Mode	2016 - 2016	PCM (Powertrain Control Module)	Module Information	
DFNISSAN	All Mode	2016 - 2016	PCM (Powertrain Control Module)	Read Fault Code	
DFNISSAN	All Mode	2016 - 2016	PCM (Powertrain Control Module)	Clear Fault Code	
DFNISSAN	All Mode	2016 - 2016	PCM (Powertrain Control Module)	Read Data Stream	
DFNISSAN	All Mode	2016 - 2016	PCM (Powertrain Control Module)	Module Information	
DFNISSAN	All Mode	2016 - 2016	PCM (Powertrain Control Module)	Actuation Test	Check fuel filter module
DFNISSAN	All Mode	2016 - 2016	PCM (Powertrain Control Module)	Actuation Test	Check power supply of drivetrain control unit
DFNISSAN	All Mode	2016 - 2016	PCM (Powertrain Control Module)	Actuation Test	Check radiator shutter actuator
DFNISSAN	All Mode	2016 - 2016	PCM (Powertrain Control Module)	Actuation Test	Status Of Circuit
DFNISSAN	All Mode	2016 - 2016	PCM (Powertrain Control Module)	Actuation Test	Causes of engine stop prevention
DFNISSAN	All Mode	2016 - 2016	PCM (Powertrain Control Module)	Actuation Test	Engine start request by stop/start system
DFNISSAN	All Mode	2016 - 2016	PCM (Powertrain Control Module)	Actuation Test	Malfunction status of stop/start system
DFNISSAN	All Mode	2016 - 2016	PCM (Powertrain Control Module)	Actuation Test	Malfunction status of stop/start system stored
DFNISSAN	All Mode	2016 - 2016	PCM (Powertrain Control Module)	Actuation Test	Requirements for stop/start system
DFNISSAN	All Mode	2016 - 2016	PCM (Powertrain Control Module)	Special Function	Manual transmission main shifter shaft position sensor
DFNISSAN	All Mode	2016 - 2016	H/L control module RH	Read Fault Code	
DFNISSAN	All Mode	2016 - 2016	H/L control module RH	Clear Fault Code	
DFNISSAN	All Mode	2016 - 2016	H/L control module RH	Read Data Stream	
DFNISSAN	All Mode	2016 - 2016	H/L control module RH	Module Information	
DFNISSAN	All Mode	2016 - 2016	H/L control module RH	Actuation Test	Check right front lamp unit fan motor 1
DFNISSAN	All Mode	2016 - 2016	H/L control module RH	Actuation Test	Fan
DFNISSAN	All Mode	2016 - 2016	H/L control module RH	Special Function	Reset operating hours counter of FR lamp fan motor 1
DFNISSAN	All Mode	2016 - 2016	H/L control module RH	Special Function	Reset of operating hours counter of R pos DTRL turn sig
DFNISSAN	All Mode	2016 - 2016	H/L control module LH	Read Fault Code	
DFNISSAN	All Mode	2016 - 2016	H/L control module LH	Clear Fault Code	
DFNISSAN	All Mode	2016 - 2016	H/L control module LH	Read Data Stream	
DFNISSAN	All Mode	2016 - 2016	H/L control module LH	Module Information	
DFNISSAN	All Mode	2016 - 2016	H/L control module LH	Actuation Test	Check left front lamp unit fan motor 1
DFNISSAN	All Mode	2016 - 2016	H/L control module LH	Actuation Test	Light distribution position sensor
DFNISSAN	All Mode	2016 - 2016	H/L control module LH	Actuation Test	Light distribution actuator motor
DFNISSAN	All Mode	2016 - 2016	H/L control module LH	Actuation Test	Fan
DFNISSAN	All Mode	2016 - 2016	H/L control module LH	Actuation Test	Intelligent light spread
DFNISSAN	All Mode	2016 - 2016	H/L control module LH	Special Function	Adjustment of headlamps via diagnosis
DFNISSAN	All Mode	2016 - 2016	H/L control module LH	Special Function	Reset operating hours counter of FL lamp fan motor 1

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
DFNISSAN	All Mode	2016 - 2016	H/L control module LH	Special Function	Reset of operating hours counter of L pos DTRL turn sig
DFNISSAN	All Mode	2016 - 2016	H/L control module LH	Special Function	Zero position adjustment
DFNISSAN	All Mode	2009 - 2009	EHS/PKB	Read Fault Code	
DFNISSAN	All Mode	2009 - 2009	EHS/PKB	Clear Fault Code	
DFNISSAN	All Mode	2009 - 2009	EHS/PKB	Read Data Stream	
DFNISSAN	All Mode	2009 - 2009	EHS/PKB	Read Freeze Frame	
DFNISSAN	All Mode	2009 - 2009	EHS/PKB	Module Information	
DFNISSAN	All Mode	2009 - 2009	EHS/PKB	Actuation Test	EHS VALVE
DFNISSAN	All Mode	2009 - 2009	EHS/PKB	Actuation Test	EHS Indicator Lamp
DFNISSAN	All Mode	2009 - 2009	EHS/PKB	Actuation Test	EHS WARNING BUZZER
DFNISSAN	All Mode	2011 - 2011	EHS/PKB	Read Fault Code	
DFNISSAN	All Mode	2011 - 2011	EHS/PKB	Clear Fault Code	
DFNISSAN	All Mode	2011 - 2011	EHS/PKB	Read Data Stream	
DFNISSAN	All Mode	2011 - 2011	EHS/PKB	Read Freeze Frame	
DFNISSAN	All Mode	2011 - 2011	EHS/PKB	Module Information	
DFNISSAN	All Mode	2011 - 2011	EHS/PKB	Special Function	Actuator 0 Point Learning
DFNISSAN	All Mode	2011 - 2011	EHS/PKB	Special Function	Parking brake brake in (drag on)
DFNISSAN	All Mode	2016 - 2016	EHS/PKB	Read Fault Code	
DFNISSAN	All Mode	2016 - 2016	EHS/PKB	Clear Fault Code	
DFNISSAN	All Mode	2016 - 2016	EHS/PKB	Read Data Stream	
DFNISSAN	All Mode	2016 - 2016	EHS/PKB	Module Information	
DFNISSAN	All Mode	2016 - 2016	EHS/PKB	Special Function	Vin Registration
DFNISSAN	All Mode	2016 - 2016	EHS/PKB	Special Function	Electrical contact actuator/brake clearance setting
DFNISSAN	All Mode	2016 - 2016	EHS/PKB	Special Function	Calibration of electric parking brake control unit
DFNISSAN	All Mode	2012 - 2016	Motor Control	Read Fault Code	
DFNISSAN	All Mode	2012 - 2016	Motor Control	Clear Fault Code	
DFNISSAN	All Mode	2012 - 2016	Motor Control	Read Data Stream	
DFNISSAN	All Mode	2012 - 2016	Motor Control	Read Freeze Frame	
DFNISSAN	All Mode	2012 - 2016	Motor Control	Module Information	
DFNISSAN	All Mode	2011 - 2013	Motor Control	Read Fault Code	
DFNISSAN	All Mode	2011 - 2013	Motor Control	Clear Fault Code	
DFNISSAN	All Mode	2011 - 2013	Motor Control	Read Data Stream	
DFNISSAN	All Mode	2011 - 2013	Motor Control	Module Information	
DFNISSAN	All Mode	2013 - 2014	Motor Control	Read Fault Code	
DFNISSAN	All Mode	2013 - 2014	Motor Control	Clear Fault Code	
DFNISSAN	All Mode	2013 - 2014	Motor Control	Read Data Stream	
DFNISSAN	All Mode	2013 - 2014	Motor Control	Module Information	
DFNISSAN	All Mode	2013 - 2014	Motor Control	Special Function	Clear Output Limit Reason
DFNISSAN	All Mode	2013 - 2014	Motor Control	Special Function	Resolver Write
DFNISSAN	All Mode	2013 - 2016	Motor Control	Read Fault Code	
DFNISSAN	All Mode	2013 - 2016	Motor Control	Clear Fault Code	
DFNISSAN	All Mode	2013 - 2016	Motor Control	Read Data Stream	
DFNISSAN	All Mode	2013 - 2016	Motor Control	Module Information	
DFNISSAN	All Mode	2014 - 2016	Motor Control	Read Fault Code	
DFNISSAN	All Mode	2014 - 2016	Motor Control	Clear Fault Code	
DFNISSAN	All Mode	2014 - 2016	Motor Control	Read Data Stream	
DFNISSAN	All Mode	2014 - 2016	Motor Control	Module Information	
DFNISSAN	All Mode	2014 - 2016	Motor Control	Special Function	Resolver Offset
DFNISSAN	All Mode	Up to 2016	EPS (Electronic Power Steering)	Read Fault Code	
DFNISSAN	All Mode	Up to 2016	EPS (Electronic Power Steering)	Clear Fault Code	
DFNISSAN	All Mode	Up to 2016	EPS (Electronic Power Steering)	Read Data Stream	
DFNISSAN	All Mode	Up to 2016	EPS (Electronic Power Steering)	Read Freeze Frame	
DFNISSAN	All Mode	Up to 2016	EPS (Electronic Power Steering)	Module Information	
DFNISSAN	All Mode	Up to 2016	EPS (Electronic Power Steering)	Read Fault Code	
DFNISSAN	All Mode	Up to 2016	EPS (Electronic Power Steering)	Clear Fault Code	
DFNISSAN	All Mode	Up to 2016	EPS (Electronic Power Steering)	Read Data Stream	
DFNISSAN	All Mode	Up to 2016	EPS (Electronic Power Steering)	Read Freeze Frame	
DFNISSAN	All Mode	Up to 2016	EPS (Electronic Power Steering)	Module Information	
DFNISSAN	All Mode	Up to 2016	EPS (Electronic Power Steering)	Read Fault Code	
DFNISSAN	All Mode	Up to 2016	EPS (Electronic Power Steering)	Clear Fault Code	
DFNISSAN	All Mode	Up to 2016	EPS (Electronic Power Steering)	Read Data Stream	
DFNISSAN	All Mode	Up to 2016	EPS (Electronic Power Steering)	Read Freeze Frame	
DFNISSAN	All Mode	Up to 2016	EPS (Electronic Power Steering)	Module Information	
DFNISSAN	All Mode	Up to 2009	EPS (Electronic Power Steering)	Read Fault Code	
DFNISSAN	All Mode	Up to 2009	EPS (Electronic Power Steering)	Clear Fault Code	
DFNISSAN	All Mode	Up to 2009	EPS (Electronic Power Steering)	Read Data Stream	
DFNISSAN	All Mode	Up to 2009	EPS (Electronic Power Steering)	Module Information	
DFNISSAN	All Mode	Up to 2009	EPS (Electronic Power Steering)	Special Function	St/Angle Adjustment
DFNISSAN	All Mode	Up to 2016	EPS (Electronic Power Steering)	Read Fault Code	
DFNISSAN	All Mode	Up to 2016	EPS (Electronic Power Steering)	Clear Fault Code	
DFNISSAN	All Mode	Up to 2016	EPS (Electronic Power Steering)	Read Data Stream	
DFNISSAN	All Mode	Up to 2016	EPS (Electronic Power Steering)	Module Information	
DFNISSAN	All Mode	Up to 2016	EPS (Electronic Power Steering)	Read Fault Code	
DFNISSAN	All Mode	Up to 2016	EPS (Electronic Power Steering)	Clear Fault Code	

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
DFNISSAN	All Mode	Up to 2016	EPS (Electronic Power Steering)	Read Data Stream	
DFNISSAN	All Mode	Up to 2016	EPS (Electronic Power Steering)	Read Freeze Frame	
DFNISSAN	All Mode	Up to 2016	EPS (Electronic Power Steering)	Module Information	
DFNISSAN	All Mode	Up to 2016	EPS (Electronic Power Steering)	Read Fault Code	
DFNISSAN	All Mode	Up to 2016	EPS (Electronic Power Steering)	Clear Fault Code	
DFNISSAN	All Mode	Up to 2016	EPS (Electronic Power Steering)	Read Data Stream	
DFNISSAN	All Mode	Up to 2016	EPS (Electronic Power Steering)	Module Information	
DFNISSAN	All Mode	Up to 2016	EPS (Electronic Power Steering)	Special Function	Power Steering Fluid Air Bleeding
DFNISSAN	All Mode	Up to 2016	EPS (Electronic Power Steering)	Read Fault Code	
DFNISSAN	All Mode	Up to 2016	EPS (Electronic Power Steering)	Clear Fault Code	
DFNISSAN	All Mode	Up to 2016	EPS (Electronic Power Steering)	Read Data Stream	
DFNISSAN	All Mode	Up to 2016	EPS (Electronic Power Steering)	Module Information	
DFNISSAN	All Mode	Up to 2016	EPS (Electronic Power Steering)	Read Fault Code	
DFNISSAN	All Mode	Up to 2016	EPS (Electronic Power Steering)	Clear Fault Code	
DFNISSAN	All Mode	Up to 2016	EPS (Electronic Power Steering)	Read Data Stream	
DFNISSAN	All Mode	Up to 2016	EPS (Electronic Power Steering)	Module Information	
DFNISSAN	All Mode	2014 - 2016	EPS (Electronic Power Steering)	Read Fault Code	
DFNISSAN	All Mode	2014 - 2016	EPS (Electronic Power Steering)	Clear Fault Code	
DFNISSAN	All Mode	2014 - 2016	EPS (Electronic Power Steering)	Read Data Stream	
DFNISSAN	All Mode	2014 - 2016	EPS (Electronic Power Steering)	Module Information	
DFNISSAN	All Mode	Up to 2017	EPS (Electronic Power Steering)	Read Fault Code	
DFNISSAN	All Mode	Up to 2017	EPS (Electronic Power Steering)	Clear Fault Code	
DFNISSAN	All Mode	Up to 2017	EPS (Electronic Power Steering)	Read Data Stream	
DFNISSAN	All Mode	Up to 2017	EPS (Electronic Power Steering)	Module Information	
DFNISSAN	All Mode	Up to 2017	EPS (Electronic Power Steering)	Special Function	ST Angle Sensor Adjustment
DFNISSAN	All Mode	Up to 2016	EPS (Electronic Power Steering)	Read Fault Code	
DFNISSAN	All Mode	Up to 2016	EPS (Electronic Power Steering)	Clear Fault Code	
DFNISSAN	All Mode	Up to 2016	EPS (Electronic Power Steering)	Read Data Stream	
DFNISSAN	All Mode	Up to 2016	EPS (Electronic Power Steering)	Module Information	
DFNISSAN	All Mode	Up to 2016	EPS (Electronic Power Steering)	Read Fault Code	
DFNISSAN	All Mode	Up to 2016	EPS (Electronic Power Steering)	Clear Fault Code	
DFNISSAN	All Mode	Up to 2016	EPS (Electronic Power Steering)	Read Data Stream	
DFNISSAN	All Mode	Up to 2016	EPS (Electronic Power Steering)	Module Information	
DFNISSAN	All Mode	2016 - 2016	EPS (Electronic Power Steering)	Read Fault Code	
DFNISSAN	All Mode	2016 - 2016	EPS (Electronic Power Steering)	Clear Fault Code	
DFNISSAN	All Mode	2016 - 2016	EPS (Electronic Power Steering)	Read Data Stream	
DFNISSAN	All Mode	2016 - 2016	EPS (Electronic Power Steering)	Module Information	
DFNISSAN	All Mode	2016 - 2016	EPS (Electronic Power Steering)	Special Function	Calibration of EPS torque sensor
DFNISSAN	All Mode	2016 - 2016	EPS (Electronic Power Steering)	Special Function	Resetting center position of steering
DFNISSAN	All Mode	2016 - 2016	EPS (Electronic Power Steering)	Special Function	Re learning
DFNISSAN	All Mode	2009 - 2016	EPS (Electronic Power Steering)	Read Fault Code	
DFNISSAN	All Mode	2009 - 2016	EPS (Electronic Power Steering)	Clear Fault Code	
DFNISSAN	All Mode	2009 - 2016	EPS (Electronic Power Steering)	Read Data Stream	
DFNISSAN	All Mode	2009 - 2016	EPS (Electronic Power Steering)	Module Information	
DFNISSAN	All Mode	2009 - 2016	EPS (Electronic Power Steering)	Special Function	ST Angle Sensor Adjustment
DFNISSAN	All Mode	Up to 2016	EPS (Electronic Power Steering)	Read Fault Code	
DFNISSAN	All Mode	Up to 2016	EPS (Electronic Power Steering)	Clear Fault Code	
DFNISSAN	All Mode	Up to 2016	EPS (Electronic Power Steering)	Read Data Stream	
DFNISSAN	All Mode	Up to 2016	EPS (Electronic Power Steering)	Module Information	
DFNISSAN	All Mode	2016 - 2017	EPS (Electronic Power Steering)	Read Fault Code	
DFNISSAN	All Mode	2016 - 2017	EPS (Electronic Power Steering)	Clear Fault Code	
DFNISSAN	All Mode	2016 - 2017	EPS (Electronic Power Steering)	Read Data Stream	
DFNISSAN	All Mode	2016 - 2017	EPS (Electronic Power Steering)	Module Information	
DFNISSAN	All Mode	Up to 2009	EPS (Electronic Power Steering)	Read Fault Code	
DFNISSAN	All Mode	Up to 2009	EPS (Electronic Power Steering)	Clear Fault Code	
DFNISSAN	All Mode	Up to 2009	EPS (Electronic Power Steering)	Read Data Stream	
DFNISSAN	All Mode	Up to 2016	ABS (Anti-lock Braking System)	Read Fault Code	
DFNISSAN	All Mode	Up to 2016	ABS (Anti-lock Braking System)	Clear Fault Code	
DFNISSAN	All Mode	Up to 2016	ABS (Anti-lock Braking System)	Read Data Stream	
DFNISSAN	All Mode	Up to 2016	ABS (Anti-lock Braking System)	Read Freeze Frame	
DFNISSAN	All Mode	Up to 2016	ABS (Anti-lock Braking System)	Module Information	
DFNISSAN	All Mode	Up to 2016	ABS (Anti-lock Braking System)	Function Test	
DFNISSAN	All Mode	Up to 2016	ABS (Anti-lock Braking System)	Actuation Test	FR RH SOL
DFNISSAN	All Mode	Up to 2016	ABS (Anti-lock Braking System)	Actuation Test	FR LH SOL
DFNISSAN	All Mode	Up to 2016	ABS (Anti-lock Braking System)	Actuation Test	RR RH SOL
DFNISSAN	All Mode	Up to 2016	ABS (Anti-lock Braking System)	Actuation Test	RR LH SOL
DFNISSAN	All Mode	Up to 2016	ABS (Anti-lock Braking System)	Actuation Test	ABS MOTOR
DFNISSAN	All Mode	Up to 2016	ABS (Anti-lock Braking System)	Actuation Test	FR RH ABS SOLENOID(ACT)
DFNISSAN	All Mode	Up to 2016	ABS (Anti-lock Braking System)	Actuation Test	FR LH ABS SOLENOID(ACT)
DFNISSAN	All Mode	Up to 2016	ABS (Anti-lock Braking System)	Actuation Test	RR RH ABS SOLENOID(ACT)
DFNISSAN	All Mode	Up to 2016	ABS (Anti-lock Braking System)	Actuation Test	RR LH ABS SOLENOID(ACT)
DFNISSAN	All Mode	Up to 2016	ABS (Anti-lock Braking System)	Special Function	ST Angle Sensor Adjustment
DFNISSAN	All Mode	Up to 2016	ABS (Anti-lock Braking System)	Special Function	Decel G Sen Calibration
DFNISSAN	All Mode	Up to 2016	ABS (Anti-lock Braking System)	Special Function	Valve Calibration
DFNISSAN	All Mode	Up to 2016	ABS (Anti-lock Braking System)	Special Function	Act Or Deact Roller Bench Test Mode
DFNISSAN	All Mode	Up to 2016	ABS (Anti-lock Braking System)	Read Fault Code	



**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
DFNISSAN	All Mode	2012 - 2017	ABS (Anti-lock Braking System)	Actuation Test	RR RH SOL
DFNISSAN	All Mode	2012 - 2017	ABS (Anti-lock Braking System)	Actuation Test	RR LH SOL
DFNISSAN	All Mode	2012 - 2017	ABS (Anti-lock Braking System)	Actuation Test	ABS MOTOR
DFNISSAN	All Mode	2012 - 2017	ABS (Anti-lock Braking System)	Actuation Test	FR RH ABS SOLENOID(ACT)
DFNISSAN	All Mode	2012 - 2017	ABS (Anti-lock Braking System)	Actuation Test	FR LH ABS SOLENOID(ACT)
DFNISSAN	All Mode	2012 - 2017	ABS (Anti-lock Braking System)	Actuation Test	RR RH ABS SOLENOID(ACT)
DFNISSAN	All Mode	2012 - 2017	ABS (Anti-lock Braking System)	Actuation Test	RR LH ABS SOLENOID(ACT)
DFNISSAN	All Mode	2012 - 2017	ABS (Anti-lock Braking System)	Actuation Test	STOP LAMP ON RELAY
DFNISSAN	All Mode	2012 - 2017	ABS (Anti-lock Braking System)	Special Function	ST Angle Sensor Adjustment
DFNISSAN	All Mode	2012 - 2017	ABS (Anti-lock Braking System)	Special Function	Decel G Sen Calibration
DFNISSAN	All Mode	2012 - 2017	ABS (Anti-lock Braking System)	Special Function	STROKE SENSOR CALIBRATION
DFNISSAN	All Mode	2016 - 2016	ABS (Anti-lock Braking System)	Read Fault Code	
DFNISSAN	All Mode	2016 - 2016	ABS (Anti-lock Braking System)	Clear Fault Code	
DFNISSAN	All Mode	2016 - 2016	ABS (Anti-lock Braking System)	Read Data Stream	
DFNISSAN	All Mode	2016 - 2016	ABS (Anti-lock Braking System)	Module Information	
DFNISSAN	All Mode	2016 - 2016	ABS (Anti-lock Braking System)	Actuation Test	Check power supply of solenoid valves
DFNISSAN	All Mode	2016 - 2016	ABS (Anti-lock Braking System)	Actuation Test	Defragment memory
DFNISSAN	All Mode	2016 - 2016	ABS (Anti-lock Braking System)	Actuation Test	Check power supply of high press and return flow pump
DFNISSAN	All Mode	2016 - 2016	ABS (Anti-lock Braking System)	Actuation Test	Rear left pressure regulating valve pressure release
DFNISSAN	All Mode	2016 - 2016	ABS (Anti-lock Braking System)	Special Function	Vin Registration
DFNISSAN	All Mode	2016 - 2016	ABS (Anti-lock Braking System)	Special Function	Calibration of acceleration sensor
DFNISSAN	All Mode	2015 - 2015	ABS (Anti-lock Braking System)	Read Fault Code	
DFNISSAN	All Mode	2015 - 2015	ABS (Anti-lock Braking System)	Clear Fault Code	
DFNISSAN	All Mode	2015 - 2015	ABS (Anti-lock Braking System)	Read Data Stream	
DFNISSAN	All Mode	2015 - 2015	ABS (Anti-lock Braking System)	Module Information	
DFNISSAN	All Mode	2015 - 2015	ABS (Anti-lock Braking System)	Actuation Test	FR RH SOL
DFNISSAN	All Mode	2015 - 2015	ABS (Anti-lock Braking System)	Actuation Test	FR LH SOL
DFNISSAN	All Mode	2015 - 2015	ABS (Anti-lock Braking System)	Actuation Test	RR RH SOL
DFNISSAN	All Mode	2015 - 2015	ABS (Anti-lock Braking System)	Actuation Test	RR LH SOL
DFNISSAN	All Mode	2015 - 2015	ABS (Anti-lock Braking System)	Actuation Test	ABS MOTOR
DFNISSAN	All Mode	2015 - 2015	ABS (Anti-lock Braking System)	Actuation Test	FR RH ABS SOLENOID(ACT)
DFNISSAN	All Mode	2015 - 2015	ABS (Anti-lock Braking System)	Actuation Test	FR LH ABS SOLENOID(ACT)
DFNISSAN	All Mode	2015 - 2015	ABS (Anti-lock Braking System)	Actuation Test	RR RH ABS SOLENOID(ACT)
DFNISSAN	All Mode	2015 - 2015	ABS (Anti-lock Braking System)	Actuation Test	RR LH ABS SOLENOID(ACT)
DFNISSAN	All Mode	2015 - 2015	ABS (Anti-lock Braking System)	Special Function	ST Angle Sensor Adjustment
DFNISSAN	All Mode	2015 - 2015	ABS (Anti-lock Braking System)	Special Function	Decel G Sen Calibration
DFNISSAN	All Mode	Up to 2016	ABS (Anti-lock Braking System)	Read Fault Code	
DFNISSAN	All Mode	Up to 2016	ABS (Anti-lock Braking System)	Clear Fault Code	
DFNISSAN	All Mode	Up to 2016	ABS (Anti-lock Braking System)	Read Data Stream	
DFNISSAN	All Mode	Up to 2016	ABS (Anti-lock Braking System)	Module Information	
DFNISSAN	All Mode	Up to 2016	ABS (Anti-lock Braking System)	Special Function	
DFNISSAN	Venucia R50	2012	ABS (Anti-lock Braking System)	Read Fault Code	
DFNISSAN	Venucia R50	2012	ABS (Anti-lock Braking System)	Clear Fault Code	
DFNISSAN	Venucia R50	2012	ABS (Anti-lock Braking System)	Read Data Stream	
DFNISSAN	Venucia R50	2012	ABS (Anti-lock Braking System)	Module Information	
DFNISSAN	Venucia R50	2012	ABS (Anti-lock Braking System)	Special Function	
DFNISSAN	All Mode	Up to 2009	ABS (Anti-lock Braking System)	Read Fault Code	
DFNISSAN	All Mode	Up to 2009	ABS (Anti-lock Braking System)	Clear Fault Code	
DFNISSAN	All Mode	Up to 2009	ABS (Anti-lock Braking System)	Read Data Stream	
DFNISSAN	All Mode	Up to 2009	ABS (Anti-lock Braking System)	Module Information	
DFNISSAN	All Mode	Up to 2009	ABS (Anti-lock Braking System)	Special Function	ST ANG SEN ADJUSTMENT
DFNISSAN	All Mode	Up to 2009	ABS (Anti-lock Braking System)	Special Function	AIR BLEEDING
DFNISSAN	All Mode	Up to 2009	ABS (Anti-lock Braking System)	Special Function	
DFNISSAN	All Mode	Up to 2015	ABS (Anti-lock Braking System)	Read Fault Code	
DFNISSAN	All Mode	Up to 2015	ABS (Anti-lock Braking System)	Clear Fault Code	
DFNISSAN	All Mode	Up to 2015	ABS (Anti-lock Braking System)	Read Data Stream	
DFNISSAN	All Mode	Up to 2015	ABS (Anti-lock Braking System)	Module Information	
DFNISSAN	All Mode	Up to 2015	ABS (Anti-lock Braking System)	Actuation Test	
DFNISSAN	All Mode	Up to 2015	ABS (Anti-lock Braking System)	Read Fault Code	
DFNISSAN	All Mode	Up to 2015	ABS (Anti-lock Braking System)	Clear Fault Code	
DFNISSAN	All Mode	Up to 2015	ABS (Anti-lock Braking System)	Read Data Stream	
DFNISSAN	All Mode	Up to 2015	ABS (Anti-lock Braking System)	Module Information	
DFNISSAN	All Mode	Up to 2015	ABS (Anti-lock Braking System)	Actuation Test	
DFNISSAN	All Mode	Up to 2015	ABS (Anti-lock Braking System)	Read Fault Code	
DFNISSAN	All Mode	Up to 2015	ABS (Anti-lock Braking System)	Clear Fault Code	
DFNISSAN	All Mode	Up to 2015	ABS (Anti-lock Braking System)	Read Data Stream	
DFNISSAN	All Mode	Up to 2015	ABS (Anti-lock Braking System)	Module Information	
DFNISSAN	All Mode	Up to 2015	ABS (Anti-lock Braking System)	Special Function	ETS AIR BLEEDING
DFNISSAN	All Mode	Up to 2015	ABS (Anti-lock Braking System)	Special Function	LSD AIR BLEEDING
DFNISSAN	All Mode	Up to 2015	ABS (Anti-lock Braking System)	Special Function	ETS OIL PRESS CHECK
DFNISSAN	All Mode	Up to 2015	ABS (Anti-lock Braking System)	Special Function	ETS OIL PRESS CHECK
DFNISSAN	All Mode	Up to 2015	ABS (Anti-lock Braking System)	Special Function	LSD OIL PRESS CHECK
DFNISSAN	All Mode	Up to 2015	ABS (Anti-lock Braking System)	Special Function	LSD OIL PRESS CHECK
DFNISSAN	All Mode	Up to 2015	ABS (Anti-lock Braking System)	Special Function	ETS LOCK CHECK
DFNISSAN	All Mode	Up to 2015	ABS (Anti-lock Braking System)	Special Function	LSD LOCK CHECK

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

<b>make</b>	<b>model</b>	<b>year</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
DFNISSAN	All Mode	Up to 2015	ABS (Anti-lock Braking System)	Special Function	ETS/LSD LOCK CHECK
DFNISSAN	All Mode	Up to 2015	ABS (Anti-lock Braking System)	Special Function	ETS/LSD AIR BLEEDING
DFNISSAN	All Mode	Up to 2014	IPDM E/R	Read Fault Code	
DFNISSAN	All Mode	Up to 2014	IPDM E/R	Clear Fault Code	
DFNISSAN	All Mode	Up to 2014	IPDM E/R	Read Data Stream	
DFNISSAN	All Mode	Up to 2014	IPDM E/R	Actuation Test	Head Lamp
DFNISSAN	All Mode	Up to 2014	IPDM E/R	Actuation Test	Front Fog Lamp
DFNISSAN	All Mode	Up to 2014	IPDM E/R	Actuation Test	Tail Lamp
DFNISSAN	All Mode	Up to 2014	IPDM E/R	Actuation Test	Rear Defogger
DFNISSAN	All Mode	Up to 2014	IPDM E/R	Actuation Test	Front Wiper
DFNISSAN	All Mode	Up to 2014	IPDM E/R	Actuation Test	Motor Fan
DFNISSAN	All Mode	Up to 2014	IPDM E/R	Actuation Test	Head Lamp Washer
DFNISSAN	All Mode	Up to 2014	IPDM E/R	Actuation Test	Lamps
DFNISSAN	All Mode	Up to 2014	IPDM E/R	Actuation Test	External Lamps
DFNISSAN	All Mode	Up to 2014	IPDM E/R	Actuation Test	Cornering Lamp
DFNISSAN	All Mode	Up to 2014	IPDM E/R	Actuation Test	Horn
DFNISSAN	All Mode	2005 - 2008	IPDM E/R	Read Fault Code	
DFNISSAN	All Mode	2005 - 2008	IPDM E/R	Clear Fault Code	
DFNISSAN	All Mode	2005 - 2008	IPDM E/R	Read Data Stream	
DFNISSAN	All Mode	2005 - 2008	IPDM E/R	Actuation Test	Head Lamp
DFNISSAN	All Mode	2005 - 2008	IPDM E/R	Actuation Test	Front Fog Lamp
DFNISSAN	All Mode	2005 - 2008	IPDM E/R	Actuation Test	Tail Lamp
DFNISSAN	All Mode	2005 - 2008	IPDM E/R	Actuation Test	Rear Defogger
DFNISSAN	All Mode	2005 - 2008	IPDM E/R	Actuation Test	Front Wiper
DFNISSAN	All Mode	2005 - 2008	IPDM E/R	Actuation Test	Motor Fan
DFNISSAN	All Mode	2005 - 2008	IPDM E/R	Actuation Test	Head Lamp Washer
DFNISSAN	All Mode	2005 - 2008	IPDM E/R	Actuation Test	Lamps
DFNISSAN	All Mode	2005 - 2008	IPDM E/R	Actuation Test	External Lamps
DFNISSAN	All Mode	2005 - 2008	IPDM E/R	Actuation Test	Cornering Lamp
DFNISSAN	All Mode	2005 - 2008	IPDM E/R	Actuation Test	Horn
DFNISSAN	All Mode	Up to 2017	IPDM E/R	Read Fault Code	
DFNISSAN	All Mode	Up to 2017	IPDM E/R	Clear Fault Code	
DFNISSAN	All Mode	Up to 2017	IPDM E/R	Read Data Stream	
DFNISSAN	All Mode	Up to 2017	IPDM E/R	Read Freeze Frame	
DFNISSAN	All Mode	Up to 2017	IPDM E/R	Module Information	
DFNISSAN	All Mode	Up to 2017	IPDM E/R	Actuation Test	Cornering Lamp
DFNISSAN	All Mode	Up to 2017	IPDM E/R	Actuation Test	Tail Lamp
DFNISSAN	All Mode	Up to 2017	IPDM E/R	Actuation Test	Horn
DFNISSAN	All Mode	Up to 2017	IPDM E/R	Actuation Test	Rear Defogger
DFNISSAN	All Mode	Up to 2017	IPDM E/R	Actuation Test	Front Wiper
DFNISSAN	All Mode	Up to 2017	IPDM E/R	Actuation Test	Motor Fan
DFNISSAN	All Mode	Up to 2017	IPDM E/R	Actuation Test	Head Lamp Washer
DFNISSAN	All Mode	Up to 2017	IPDM E/R	Actuation Test	Lamps
DFNISSAN	All Mode	Up to 2017	IPDM E/R	Actuation Test	External Lamps
DFNISSAN	All Mode	Up to 2009	IPDM E/R	Read Fault Code	
DFNISSAN	All Mode	Up to 2009	IPDM E/R	Clear Fault Code	
DFNISSAN	All Mode	Up to 2009	IPDM E/R	Read Data Stream	
DFNISSAN	All Mode	Up to 2009	IPDM E/R	Module Information	
DFNISSAN	All Mode	Up to 2009	IPDM E/R	Actuation Test	Head Lamp
DFNISSAN	All Mode	Up to 2009	IPDM E/R	Actuation Test	Front Fog Lamp
DFNISSAN	All Mode	Up to 2009	IPDM E/R	Actuation Test	Tail Lamp
DFNISSAN	All Mode	Up to 2009	IPDM E/R	Actuation Test	Rear Defogger
DFNISSAN	All Mode	Up to 2009	IPDM E/R	Actuation Test	Front Wiper
DFNISSAN	All Mode	Up to 2009	IPDM E/R	Actuation Test	Motor Fan
DFNISSAN	All Mode	Up to 2009	IPDM E/R	Actuation Test	Head Lamp Washer
DFNISSAN	All Mode	Up to 2009	IPDM E/R	Actuation Test	Lamps
DFNISSAN	All Mode	Up to 2009	IPDM E/R	Actuation Test	External Lamps
DFNISSAN	All Mode	Up to 2009	IPDM E/R	Actuation Test	Cornering Lamp
DFNISSAN	All Mode	Up to 2009	IPDM E/R	Actuation Test	Horn
DFNISSAN	All Mode	2014 - 2017	IPDM E/R	Read Fault Code	
DFNISSAN	All Mode	2014 - 2017	IPDM E/R	Clear Fault Code	
DFNISSAN	All Mode	2014 - 2017	IPDM E/R	Read Data Stream	
DFNISSAN	All Mode	2014 - 2017	IPDM E/R	Module Information	
DFNISSAN	All Mode	2014 - 2017	IPDM E/R	Actuation Test	Horn
DFNISSAN	All Mode	2014 - 2017	IPDM E/R	Actuation Test	Head Lamp Washer
DFNISSAN	All Mode	2014 - 2017	IPDM E/R	Actuation Test	Front Wiper
DFNISSAN	All Mode	2014 - 2017	IPDM E/R	Actuation Test	COMPRESSOR
DFNISSAN	All Mode	2014 - 2017	IPDM E/R	Actuation Test	Cooling Fan (Pwm)
DFNISSAN	All Mode	2014 - 2017	IPDM E/R	Actuation Test	Cooling Fan (Mono)
DFNISSAN	All Mode	2014 - 2017	IPDM E/R	Actuation Test	Cooling Fan (Dual)
DFNISSAN	All Mode	2014 - 2017	IPDM E/R	Actuation Test	Headlamp (Hi)
DFNISSAN	All Mode	2014 - 2017	IPDM E/R	Actuation Test	HEADLAMP (Lo)
DFNISSAN	All Mode	2014 - 2017	IPDM E/R	Actuation Test	Front Fog Lamp
DFNISSAN	All Mode	2014 - 2017	IPDM E/R	Actuation Test	Daytime Running Light
DFNISSAN	All Mode	2014 - 2017	IPDM E/R	Actuation Test	Parking Lamp
DFNISSAN	All Mode	2014 - 2017	IPDM E/R	Actuation Test	Tail Lamp
DFNISSAN	All Mode	2014 - 2017	IPDM E/R	Actuation Test	Optic Axis Active Test
DFNISSAN	All Mode	2014 - 2017	IPDM E/R	Special Function	Sensor Initialize
DFNISSAN	All Mode	2014 - 2017	IPDM E/R	Special Function	CML B/DCHRG CRNT CLEAR
DFNISSAN	All Mode	Up to 2016	Air Pressure Monitor	Read Fault Code	

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
DFNISSAN	All Mode	Up to 2016	Air Pressure Monitor	Clear Fault Code	
DFNISSAN	All Mode	Up to 2016	Air Pressure Monitor	Read Data Stream	
DFNISSAN	All Mode	Up to 2016	Air Pressure Monitor	Module Information	
DFNISSAN	All Mode	Up to 2016	Air Pressure Monitor	Actuation Test	BUZZER
DFNISSAN	All Mode	Up to 2016	Air Pressure Monitor	Actuation Test	Warn Lamp
DFNISSAN	All Mode	Up to 2016	Air Pressure Monitor	Actuation Test	Hazard Lamp
DFNISSAN	All Mode	Up to 2016	Air Pressure Monitor	Special Function	ID READ(TIRE SET 1)
DFNISSAN	All Mode	Up to 2016	Air Pressure Monitor	Special Function	ID READ(TIRE SET 2)
DFNISSAN	All Mode	Up to 2016	Air Pressure Monitor	Special Function	ID REGIST(TIRE SET 1)
DFNISSAN	All Mode	Up to 2016	Air Pressure Monitor	Special Function	ID REGIST(TIRE SET 2)
DFNISSAN	All Mode	Up to 2016	Air Pressure Monitor	Special Function	Switch Tpm Between On/Off
DFNISSAN	All Mode	Up to 2016	Air Pressure Monitor	Special Function	ID REGIST
DFNISSAN	All Mode	Up to 2014	Air Pressure Monitor	Read Fault Code	
DFNISSAN	All Mode	Up to 2014	Air Pressure Monitor	Clear Fault Code	
DFNISSAN	All Mode	Up to 2014	Air Pressure Monitor	Read Data Stream	
DFNISSAN	All Mode	Up to 2014	Air Pressure Monitor	Module Information	
DFNISSAN	All Mode	Up to 2014	Air Pressure Monitor	Special Function	ID REGIST
DFNISSAN	All Mode	Up to 2017	Air Pressure Monitor	Read Fault Code	
DFNISSAN	All Mode	Up to 2017	Air Pressure Monitor	Clear Fault Code	
DFNISSAN	All Mode	Up to 2017	Air Pressure Monitor	Read Data Stream	
DFNISSAN	All Mode	Up to 2017	Air Pressure Monitor	Module Information	
DFNISSAN	All Mode	Up to 2017	Air Pressure Monitor	Actuation Test	ID REGIST WARNING
DFNISSAN	All Mode	Up to 2017	Air Pressure Monitor	Actuation Test	RUN FLAT/T WARN BUZZER
DFNISSAN	All Mode	Up to 2017	Air Pressure Monitor	Actuation Test	Warning Lamp
DFNISSAN	All Mode	Up to 2017	Air Pressure Monitor	Actuation Test	Flasher
DFNISSAN	All Mode	Up to 2017	Air Pressure Monitor	Actuation Test	Horn
DFNISSAN	All Mode	Up to 2017	Air Pressure Monitor	Actuation Test	Outside Buzzer
DFNISSAN	All Mode	Up to 2017	Air Pressure Monitor	Special Function	ID READ
DFNISSAN	All Mode	Up to 2017	Air Pressure Monitor	Special Function	ID REGIST
DFNISSAN	All Mode	Up to 2017	Air Pressure Monitor	Special Function	Switch Tpm Between On/Off
DFNISSAN	All Mode	2014 - 2014	Air Pressure Monitor	Read Fault Code	
DFNISSAN	All Mode	2014 - 2014	Air Pressure Monitor	Clear Fault Code	
DFNISSAN	All Mode	2014 - 2014	Air Pressure Monitor	Read Data Stream	
DFNISSAN	All Mode	2014 - 2014	Air Pressure Monitor	Module Information	
DFNISSAN	All Mode	2014 - 2014	Air Pressure Monitor	Special Function	Vin Registration
DFNISSAN	All Mode	2014 - 2017	Air Pressure Monitor	Read Fault Code	
DFNISSAN	All Mode	2014 - 2017	Air Pressure Monitor	Clear Fault Code	
DFNISSAN	All Mode	2014 - 2017	Air Pressure Monitor	Read Data Stream	
DFNISSAN	All Mode	2014 - 2017	Air Pressure Monitor	Module Information	
DFNISSAN	All Mode	2014 - 2017	Air Pressure Monitor	Actuation Test	ID REGIST WARNING
DFNISSAN	All Mode	2014 - 2017	Air Pressure Monitor	Actuation Test	Warning Lamp
DFNISSAN	All Mode	2014 - 2017	Air Pressure Monitor	Actuation Test	RUN FLAT/T WARN BUZZER
DFNISSAN	All Mode	2014 - 2017	Air Pressure Monitor	Actuation Test	Flasher
DFNISSAN	All Mode	2014 - 2017	Air Pressure Monitor	Actuation Test	Horn
DFNISSAN	All Mode	2014 - 2017	Air Pressure Monitor	Special Function	ID REGIST
DFNISSAN	All Mode	2014 - 2017	Air Pressure Monitor	Special Function	Switch Tpm Between On/Off
DFNISSAN	All Mode	2016 - 2016	Air Pressure Monitor	Read Fault Code	
DFNISSAN	All Mode	2016 - 2016	Air Pressure Monitor	Clear Fault Code	
DFNISSAN	All Mode	2016 - 2016	Air Pressure Monitor	Read Data Stream	
DFNISSAN	All Mode	2016 - 2016	Air Pressure Monitor	Module Information	
DFNISSAN	All Mode	2016 - 2016	Air Pressure Monitor	Actuation Test	Check left front tire pressure sensor
DFNISSAN	All Mode	2016 - 2016	Air Pressure Monitor	Actuation Test	Check right front tire pressure sensor
DFNISSAN	All Mode	2016 - 2016	Air Pressure Monitor	Actuation Test	Check left rear tire pressure sensor
DFNISSAN	All Mode	2016 - 2016	Air Pressure Monitor	Actuation Test	Check right rear tire pressure sensor
DFNISSAN	All Mode	2016 - 2016	Air Pressure Monitor	Actuation Test	Activation memory
DFNISSAN	All Mode	2016 - 2016	Air Pressure Monitor	Actuation Test	Message memory
DFNISSAN	All Mode	2016 - 2016	Air Pressure Monitor	Special Function	Set autolocation disable
DFNISSAN	All Mode	2016 - 2016	Air Pressure Monitor	Special Function	Front or rear sensor localization was unsuccessful
DFNISSAN	All Mode	2016 - 2016	Air Pressure Monitor	Special Function	Saving Data For Replc CPU
DFNISSAN	All Mode	2016 - 2016	Air Pressure Monitor	Special Function	Writing Data For Replc CPU
DFNISSAN	All Mode	Up to 2009	Air Pressure Monitor	Read Fault Code	
DFNISSAN	All Mode	Up to 2009	Air Pressure Monitor	Clear Fault Code	
DFNISSAN	All Mode	Up to 2009	Air Pressure Monitor	Read Data Stream	
DFNISSAN	All Mode	Up to 2009	Air Pressure Monitor	Module Information	
DFNISSAN	All Mode	Up to 2009	Air Pressure Monitor	Special Function	ID REGIST (SUMMER)
DFNISSAN	All Mode	Up to 2009	Air Pressure Monitor	Special Function	ID REGIST (WINTER)
DFNISSAN	All Mode	Up to 2009	Air Pressure Monitor	Special Function	Type Set Selection
DFNISSAN	All Mode	Up to 2009	Air Pressure Monitor	Special Function	Tpm Cancellation
DFNISSAN	All Mode	Up to 2009	Air Pressure Monitor	Special Function	RECOMMEND PRESS SETTING
DFNISSAN	All Mode	Up to 2009	Air Pressure Monitor	Read Fault Code	
DFNISSAN	All Mode	Up to 2009	Air Pressure Monitor	Clear Fault Code	
DFNISSAN	All Mode	Up to 2009	Air Pressure Monitor	Read Data Stream	
DFNISSAN	All Mode	Up to 2009	Air Pressure Monitor	Module Information	
DFNISSAN	All Mode	Up to 2009	Air Pressure Monitor	Special Function	

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
DFNISSAN	All Mode	2010 - 2010	Sub Meter	Read Fault Code	
DFNISSAN	All Mode	2010 - 2010	Sub Meter	Clear Fault Code	
DFNISSAN	All Mode	2009 - 2014	Convertible Roof	Read Fault Code	
DFNISSAN	All Mode	2009 - 2014	Convertible Roof	Clear Fault Code	
DFNISSAN	All Mode	2009 - 2014	Convertible Roof	Read Data Stream	
DFNISSAN	All Mode	2009 - 2014	Convertible Roof	Module Information	
DFNISSAN	All Mode	2009 - 2014	Convertible Roof	Actuation Test	ROOF SYSTEM
DFNISSAN	All Mode	2009 - 2014	Convertible Roof	Actuation Test	ROOF STATE OUTPUT(AUDIO)
DFNISSAN	All Mode	2009 - 2014	Convertible Roof	Actuation Test	FRONT POWER WINDOW(LH)/RH)
DFNISSAN	All Mode	2009 - 2014	Convertible Roof	Actuation Test	REAR POWER WINDOW(LH)
DFNISSAN	All Mode	2009 - 2014	Convertible Roof	Actuation Test	REAR POWER WINDOW(RH)
DFNISSAN	All Mode	2009 - 2014	Convertible Roof	Special Function	Trunk Opener
DFNISSAN	All Mode	2009 - 2014	Convertible Roof	Special Function	FLIPPER DOOR
DFNISSAN	All Mode	2009 - 2014	Convertible Roof	Special Function	ROOF LATCH
DFNISSAN	All Mode	2009 - 2014	Convertible Roof	Special Function	Roof State Reset
DFNISSAN	All Mode	2009 - 2014	Convertible Roof	Special Function	Roof State Learning
DFNISSAN	All Mode	2013 - 2016	Convertible Roof	Read Fault Code	
DFNISSAN	All Mode	2013 - 2016	Convertible Roof	Clear Fault Code	
DFNISSAN	All Mode	2013 - 2016	Convertible Roof	Read Data Stream	
DFNISSAN	All Mode	2013 - 2016	Convertible Roof	Module Information	
DFNISSAN	All Mode	2013 - 2016	Convertible Roof	Actuation Test	ROOF LATCHED LH/RH
DFNISSAN	All Mode	2013 - 2016	Convertible Roof	Actuation Test	STORAGE LID
DFNISSAN	All Mode	2013 - 2016	Convertible Roof	Actuation Test	SOFT TOP SYSTEM
DFNISSAN	All Mode	2013 - 2016	Convertible Roof	Actuation Test	ROOF SYSTEM
DFNISSAN	All Mode	2013 - 2016	Convertible Roof	Actuation Test	5TH BOW SYSTEM
DFNISSAN	All Mode	2013 - 2016	Convertible Roof	Actuation Test	HYDRAULIC PRESSURE RELEASE
DFNISSAN	All Mode	2013 - 2016	Convertible Roof	Actuation Test	TRUNK OPENER
DFNISSAN	All Mode	2013 - 2016	Convertible Roof	Actuation Test	ROOF STATE OUTPUT(AUDIO)
DFNISSAN	All Mode	2013 - 2016	Convertible Roof	Actuation Test	POWER WINDOW(LH/RH)
DFNISSAN	All Mode	2013 - 2016	Convertible Roof	Actuation Test	REAR WINDOW DEFOGGER
DFNISSAN	All Mode	Up to 2009	Head Lamp Levelizer	Read Fault Code	
DFNISSAN	All Mode	Up to 2009	Head Lamp Levelizer	Clear Fault Code	
DFNISSAN	All Mode	Up to 2009	Head Lamp Levelizer	Read Data Stream	
DFNISSAN	All Mode	Up to 2009	Head Lamp Levelizer	Module Information	
DFNISSAN	All Mode	Up to 2009	Head Lamp Levelizer	Special Function	
DFNISSAN	All Mode	Up to 2017	Head Lamp Levelizer	Read Fault Code	
DFNISSAN	All Mode	Up to 2017	Head Lamp Levelizer	Clear Fault Code	
DFNISSAN	All Mode	Up to 2017	Head Lamp Levelizer	Read Data Stream	
DFNISSAN	All Mode	Up to 2017	Head Lamp Levelizer	Module Information	
DFNISSAN	All Mode	Up to 2017	Head Lamp Levelizer	Special Function	
DFNISSAN	All Mode	Up to 2015	IC (Instrument cluster)	Read Fault Code	
DFNISSAN	All Mode	Up to 2015	IC (Instrument cluster)	Clear Fault Code	
DFNISSAN	All Mode	Up to 2015	IC (Instrument cluster)	Read Data Stream	
DFNISSAN	All Mode	Up to 2015	IC (Instrument cluster)	Special Function	TURN SIGNAL BUZZER DIAGNOSIS
DFNISSAN	All Mode	Up to 2015	IC (Instrument cluster)	Special Function	Fuel Meter Diagnosis(Analog Pointer)
DFNISSAN	All Mode	Up to 2015	IC (Instrument cluster)	Read Fault Code	
DFNISSAN	All Mode	Up to 2015	IC (Instrument cluster)	Clear Fault Code	
DFNISSAN	All Mode	Up to 2015	IC (Instrument cluster)	Read Data Stream	
DFNISSAN	All Mode	Up to 2015	IC (Instrument cluster)	Special Function	TURN SIGNAL BUZZER DIAGNOSIS
DFNISSAN	All Mode	Up to 2015	IC (Instrument cluster)	Special Function	Fuel Meter Diagnosis(Analog Pointer)
DFNISSAN	All Mode	2009 - 2016	IC (Instrument cluster)	Read Fault Code	
DFNISSAN	All Mode	2009 - 2016	IC (Instrument cluster)	Clear Fault Code	
DFNISSAN	All Mode	2009 - 2016	IC (Instrument cluster)	Read Data Stream	
DFNISSAN	All Mode	2009 - 2016	IC (Instrument cluster)	Special Function	TURN SIGNAL BUZZER DIAGNOSIS
DFNISSAN	All Mode	2009 - 2016	IC (Instrument cluster)	Special Function	Fuel Meter Diagnosis(Analog Pointer)
DFNISSAN	All Mode	2008 - 2014	IC (Instrument cluster)	Read Fault Code	
DFNISSAN	All Mode	2008 - 2014	IC (Instrument cluster)	Clear Fault Code	
DFNISSAN	All Mode	2008 - 2014	IC (Instrument cluster)	Read Data Stream	
DFNISSAN	All Mode	2008 - 2014	IC (Instrument cluster)	Read Freeze Frame	
DFNISSAN	All Mode	2008 - 2014	IC (Instrument cluster)	Special Function	TURN SIGNAL BUZZER DIAGNOSIS
DFNISSAN	All Mode	2008 - 2014	IC (Instrument cluster)	Special Function	Outside Air Temperature Diagnosis
DFNISSAN	All Mode	2008 - 2014	IC (Instrument cluster)	Special Function	Fuel Meter Diagnosis(Analog Pointer)
DFNISSAN	All Mode	2007 - 2016	IC (Instrument cluster)	Read Fault Code	
DFNISSAN	All Mode	2007 - 2016	IC (Instrument cluster)	Clear Fault Code	
DFNISSAN	All Mode	2007 - 2016	IC (Instrument cluster)	Read Data Stream	
DFNISSAN	All Mode	2007 - 2016	IC (Instrument cluster)	Read Freeze Frame	
DFNISSAN	All Mode	2007 - 2016	IC (Instrument cluster)	Module Information	
DFNISSAN	All Mode	2007 - 2016	IC (Instrument cluster)	Special Function	TURN SIGNAL BUZZER DIAGNOSIS
DFNISSAN	All Mode	2007 - 2016	IC (Instrument cluster)	Special Function	Outside Air Temperature Diagnosis



**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

<b>make</b>	<b>model</b>	<b>year</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
DFNISSAN	All Mode	2007 - 2016	IC (Instrument cluster)	Special Function	Fuel Meter Diagnosis(Analog Pointer)
DFNISSAN	All Mode	2008 - 2016	IC (Instrument cluster)	Read Fault Code	
DFNISSAN	All Mode	2008 - 2016	IC (Instrument cluster)	Clear Fault Code	
DFNISSAN	All Mode	2008 - 2016	IC (Instrument cluster)	Read Data Stream	
DFNISSAN	All Mode	2008 - 2016	IC (Instrument cluster)	Read Freeze Frame	
DFNISSAN	All Mode	2008 - 2016	IC (Instrument cluster)	Special Function	Outside Air Temperature Diagnosis
DFNISSAN	All Mode	2008 - 2016	IC (Instrument cluster)	Special Function	Fuel Meter Diagnosis(Analog Pointer)
DFNISSAN	All Mode	2008 - 2016	IC (Instrument cluster)	Special Function	Warning Lamp Diagnosis
DFNISSAN	All Mode	2009 - 2017	IC (Instrument cluster)	Read Fault Code	
DFNISSAN	All Mode	2009 - 2017	IC (Instrument cluster)	Clear Fault Code	
DFNISSAN	All Mode	2009 - 2017	IC (Instrument cluster)	Read Data Stream	
DFNISSAN	All Mode	2009 - 2017	IC (Instrument cluster)	Read Freeze Frame	
DFNISSAN	All Mode	2009 - 2017	IC (Instrument cluster)	Special Function	TURN SIGNAL BUZZER DIAGNOSIS
DFNISSAN	All Mode	2009 - 2017	IC (Instrument cluster)	Special Function	Outside Air Temperature Diagnosis
DFNISSAN	All Mode	2009 - 2017	IC (Instrument cluster)	Special Function	Fuel Meter Diagnosis(Analog Pointer)
DFNISSAN	All Mode	2008 - 2016	IC (Instrument cluster)	Read Fault Code	
DFNISSAN	All Mode	2008 - 2016	IC (Instrument cluster)	Clear Fault Code	
DFNISSAN	All Mode	2008 - 2016	IC (Instrument cluster)	Read Data Stream	
DFNISSAN	All Mode	2008 - 2016	IC (Instrument cluster)	Read Freeze Frame	
DFNISSAN	All Mode	2008 - 2016	IC (Instrument cluster)	Module Information	
DFNISSAN	All Mode	2008 - 2016	IC (Instrument cluster)	Special Function	TURN SIGNAL BUZZER DIAGNOSIS
DFNISSAN	All Mode	2008 - 2016	IC (Instrument cluster)	Special Function	Outside Air Temperature Diagnosis
DFNISSAN	All Mode	2008 - 2016	IC (Instrument cluster)	Special Function	Fuel Meter Diagnosis(Analog Pointer)
DFNISSAN	All Mode	2012 - 2017	IC (Instrument cluster)	Read Fault Code	
DFNISSAN	All Mode	2012 - 2017	IC (Instrument cluster)	Clear Fault Code	
DFNISSAN	All Mode	2012 - 2017	IC (Instrument cluster)	Read Data Stream	
DFNISSAN	All Mode	2012 - 2017	IC (Instrument cluster)	Module Information	
DFNISSAN	All Mode	2012 - 2017	IC (Instrument cluster)	Special Function	TURN SIGNAL BUZZER DIAGNOSIS
DFNISSAN	All Mode	2012 - 2017	IC (Instrument cluster)	Special Function	Outside Air Temperature Diagnosis
DFNISSAN	All Mode	2012 - 2017	IC (Instrument cluster)	Special Function	Fuel Meter Diagnosis(Analog Pointer)
DFNISSAN	All Mode	2011 - 2015	IC (Instrument cluster)	Read Fault Code	
DFNISSAN	All Mode	2011 - 2015	IC (Instrument cluster)	Clear Fault Code	
DFNISSAN	All Mode	2011 - 2015	IC (Instrument cluster)	Read Data Stream	
DFNISSAN	All Mode	2011 - 2015	IC (Instrument cluster)	Module Information	
DFNISSAN	All Mode	2011 - 2015	IC (Instrument cluster)	Special Function	Reset Guideline Position
DFNISSAN	All Mode	2011 - 2015	IC (Instrument cluster)	Special Function	Customize Reset Consult
DFNISSAN	All Mode	2011 - 2015	IC (Instrument cluster)	Special Function	TURN SIGNAL BUZZER DIAGNOSIS
DFNISSAN	All Mode	2011 - 2015	IC (Instrument cluster)	Special Function	Outside Air Temperature Diagnosis
DFNISSAN	All Mode	2011 - 2015	IC (Instrument cluster)	Special Function	Fuel Meter Diagnosis(Analog Pointer)
DFNISSAN	All Mode	2011 - 2015	IC (Instrument cluster)	Special Function	Warning Lamp Diagnosis
DFNISSAN	All Mode	2016 - 2016	IC (Instrument cluster)	Read Fault Code	
DFNISSAN	All Mode	2016 - 2016	IC (Instrument cluster)	Clear Fault Code	
DFNISSAN	All Mode	2016 - 2016	IC (Instrument cluster)	Read Data Stream	
DFNISSAN	All Mode	2016 - 2016	IC (Instrument cluster)	Module Information	
DFNISSAN	All Mode	2016 - 2016	IC (Instrument cluster)	Actuation Test	Instrument illumination
DFNISSAN	All Mode	2016 - 2016	IC (Instrument cluster)	Actuation Test	Warning buzzer
DFNISSAN	All Mode	2016 - 2016	IC (Instrument cluster)	Actuation Test	Indicator Lamp
DFNISSAN	All Mode	2016 - 2016	IC (Instrument cluster)	Actuation Test	Mechanical instrument pointers
DFNISSAN	All Mode	2016 - 2016	IC (Instrument cluster)	Actuation Test	Control unit reset
DFNISSAN	All Mode	2016 - 2016	IC (Instrument cluster)	Special Function	Teach In Combination Meter
DFNISSAN	All Mode	2016 - 2016	IC (Instrument cluster)	Special Function	Table Initialization Assyst
DFNISSAN	All Mode	2016 - 2016	IC (Instrument cluster)	Special Function	Transfer Of Manufacturer Default Settings
DFNISSAN	All Mode	2016 - 2016	IC (Instrument cluster)	Special Function	Oil grade factor
DFNISSAN	Venucia T90	2016	IC (Instrument cluster)	Read Fault Code	
DFNISSAN	Venucia T90	2016	IC (Instrument cluster)	Clear Fault Code	
DFNISSAN	Venucia T90	2016	IC (Instrument cluster)	Read Data Stream	
DFNISSAN	Venucia T90	2016	IC (Instrument cluster)	Module Information	
DFNISSAN	Venucia T90	2016	IC (Instrument cluster)	Read Fault Code	
DFNISSAN	Venucia T90	2016	IC (Instrument cluster)	Clear Fault Code	
DFNISSAN	Venucia T90	2016	IC (Instrument cluster)	Read Data Stream	
DFNISSAN	Venucia T90	2016	IC (Instrument cluster)	Module Information	
DFNISSAN	All Mode	2010 - 2010	E-4WD	Read Fault Code	
DFNISSAN	All Mode	2010 - 2010	E-4WD	Clear Fault Code	

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
DFNISSAN	All Mode	2010 - 2010	E-4WD	Read Data Stream	
DFNISSAN	All Mode	2010 - 2010	E-4WD	Read Freeze Frame	
DFNISSAN	All Mode	2010 - 2010	E-4WD	Module Information	
DFNISSAN	All Mode	2010 - 2010	E-4WD	Actuation Test	MOTOR 1 CHECK
DFNISSAN	All Mode	2010 - 2010	E-4WD	Actuation Test	CLUTCH CHECK
DFNISSAN	All Mode	2010 - 2010	E-4WD	Actuation Test	e-4WD RELAY CHECK
DFNISSAN	All Mode	2010 - 2010	E-4WD	Actuation Test	MOTOR 2 CHECK
DFNISSAN	All Mode	2010 - 2010	E-4WD	Actuation Test	GENERATOR CHECK
DFNISSAN	All Mode	2009 - 2016	Laser/Radar	Read Fault Code	
DFNISSAN	All Mode	2009 - 2016	Laser/Radar	Clear Fault Code	
DFNISSAN	All Mode	2009 - 2016	Laser/Radar	Read Data Stream	
DFNISSAN	All Mode	2009 - 2016	Laser/Radar	Module Information	
DFNISSAN	All Mode	2009 - 2016	Laser/Radar	Special Function	Laser Beam Adjust
DFNISSAN	All Mode	2009 - 2017	Laser/Radar	Read Fault Code	
DFNISSAN	All Mode	2009 - 2017	Laser/Radar	Clear Fault Code	
DFNISSAN	All Mode	2009 - 2017	Laser/Radar	Read Data Stream	
DFNISSAN	All Mode	2009 - 2017	Laser/Radar	Module Information	
DFNISSAN	All Mode	2009 - 2016	Laser/Radar	Read Fault Code	
DFNISSAN	All Mode	2009 - 2016	Laser/Radar	Clear Fault Code	
DFNISSAN	All Mode	2009 - 2016	Laser/Radar	Read Data Stream	
DFNISSAN	All Mode	2009 - 2016	Laser/Radar	Module Information	
DFNISSAN	All Mode	2009 - 2016	Laser/Radar	Special Function	Milliwave Radar Adjust
DFNISSAN	All Mode	2009 - 2016	Laser/Radar	Read Fault Code	
DFNISSAN	All Mode	2009 - 2016	Laser/Radar	Clear Fault Code	
DFNISSAN	All Mode	2009 - 2016	Laser/Radar	Read Data Stream	
DFNISSAN	All Mode	2009 - 2016	Laser/Radar	Module Information	
DFNISSAN	All Mode	2009 - 2016	Laser/Radar	Actuation Test	Brake Actuator
DFNISSAN	All Mode	2009 - 2016	Laser/Radar	Actuation Test	ICC BUZZER
DFNISSAN	All Mode	2009 - 2016	Laser/Radar	Actuation Test	Meter Lamp
DFNISSAN	All Mode	2009 - 2016	Laser/Radar	Special Function	FEB Default Setting
DFNISSAN	All Mode	2009 - 2017	Laser/Radar	Read Fault Code	
DFNISSAN	All Mode	2009 - 2017	Laser/Radar	Clear Fault Code	
DFNISSAN	All Mode	2009 - 2017	Laser/Radar	Read Data Stream	
DFNISSAN	All Mode	2009 - 2017	Laser/Radar	Module Information	
DFNISSAN	All Mode	2016 - 2016	Laser/Radar	Read Fault Code	
DFNISSAN	All Mode	2016 - 2016	Laser/Radar	Clear Fault Code	
DFNISSAN	All Mode	2016 - 2016	Laser/Radar	Read Data Stream	
DFNISSAN	All Mode	2016 - 2016	Laser/Radar	Module Information	
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Read Fault Code	
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Clear Fault Code	
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Read Data Stream	
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Module Information	
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Actuation Test	Outside Buzzer
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Actuation Test	Inside Buzzer
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Actuation Test	Indicator
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Actuation Test	Door Lock/Unlock
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Actuation Test	ANTENNA
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Special Function	Confirm Key Fob ID
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Special Function	Take Out From Window Warn
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Special Function	Low Batt Of Key Fob Warn
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Special Function	Keyless Function
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Special Function	Answer Back Function
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Special Function	Selective Unlock Function
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Special Function	Hazard Answer Back
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Special Function	Answer Back With I-Key Lock
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Special Function	Answer Back With I-Key Unlock
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Special Function	Trunk Open Delay
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Special Function	Auto Relock Timer
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Special Function	Trunk/Glass Hatch Open
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Special Function	Power Slide Door Delay
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Special Function	Engine Start By I-Key
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Special Function	Lock/Unlock By I-Key
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Read Fault Code	
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Clear Fault Code	
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Read Data Stream	
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Module Information	
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Actuation Test	Door Lock/Unlock
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Actuation Test	ANTENNA
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Actuation Test	Outside Buzzer
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Actuation Test	Inside Buzzer
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Actuation Test	Indicator
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Actuation Test	LCD
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Actuation Test	P Range
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Actuation Test	Engine SW Illumi
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Actuation Test	Lock Indicator
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Actuation Test	ACC Indicator
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Actuation Test	Ignition ON IND
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Actuation Test	Key Slot Illumi
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Special Function	Confirm Key Fob ID

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Special Function	Take Out From Window Warn
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Special Function	Low Batt Of Key Fob Warn
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Special Function	I-Key Function
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Special Function	Answer Back Function
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Special Function	Keyless Function
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Special Function	Selective Unlock Function
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Special Function	Anti Key Lock In Function
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Special Function	Hazard Answer Back
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Special Function	Answer Back With I-Key Lock
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Special Function	Answer Back With I-Key Unlock
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Special Function	Auto Relock Timer
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Special Function	Panic Alarm Delay
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Special Function	Trunk Open Delay
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Special Function	P/W Down Delay
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Special Function	Power Slide Door Delay
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Special Function	Engine Start By I-Key
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Special Function	Lock/Unlock By I-Key
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Special Function	LUG Room Engine Start
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Special Function	Horn With Keyless Lock
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Special Function	Trunk/Glass Hatch Open
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Special Function	Short Cranking Output
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Read Fault Code	
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Clear Fault Code	
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Read Data Stream	
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Module Information	
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Actuation Test	Door Lock/Unlock
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Actuation Test	ANTENNA
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Actuation Test	Outside Buzzer
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Actuation Test	INDICATOR
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Actuation Test	LCD
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Actuation Test	P Range
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Actuation Test	Engine SW Illumi
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Actuation Test	Lock Indicator
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Actuation Test	ACC Indicator
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Actuation Test	Ignition ON IND
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Actuation Test	Key Slot Illumi
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Special Function	Confirm Key Fob ID
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Special Function	Short Cranking Output
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Special Function	Take Out From Window Warn
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Special Function	Low Batt Of Key Fob Warn
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Special Function	Answer Back Function
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Special Function	Selective Unlock Function
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Special Function	Horn With Keyless Lock
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Special Function	Hazard Answer Back
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Special Function	Answer Back With I-Key Lock
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Special Function	Answer Back With I-Key Unlock
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Special Function	Auto Relock Timer
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Special Function	Panic Alarm Delay
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Special Function	Trunk/Glass Hatch Open
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Special Function	Trunk Open Delay
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Special Function	P/W Down Delay
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Special Function	Engine Start By I-Key
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Special Function	Lock/Unlock By I-Key
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Special Function	LUG Room Engine Start
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Read Fault Code	
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Clear Fault Code	
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Read Data Stream	
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Module Information	
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Actuation Test	Outside Buzzer
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Actuation Test	Inside Buzzer
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Actuation Test	Indicator
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Actuation Test	Door Lock/Unlock
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Actuation Test	ANTENNA
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Special Function	Take Out From Window Warn
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Special Function	Low Batt Of Key Fob Warn
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Special Function	Answer Back Function
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Special Function	Selective Unlock Function
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Special Function	Anti Key Lock In Function
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Special Function	Horn With Keyless Lock
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Special Function	Hazard Answer Back
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Special Function	Answer Back With I-Key Lock
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Special Function	Answer Back With I-Key Unlock
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Special Function	Auto Relock Timer
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Special Function	Panic Alarm Delay
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Special Function	Trunk/Glass Hatch Open
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Special Function	Trunk Open Delay
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Special Function	P/W Down Delay

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

<b>make</b>	<b>model</b>	<b>year</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Special Function	Power Slide Door Delay
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Special Function	Engine Start By I-Key
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Special Function	Lock/Unlock By I-Key
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Special Function	Confirm Key Fob ID
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Read Fault Code	
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Clear Fault Code	
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Read Data Stream	
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Module Information	
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Special Function	Confirm Key Fob ID
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Special Function	Take Out From Window Warn
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Special Function	Low Batt Of Key Fob Warn
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Special Function	I-Key Function
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Special Function	Answer Back Function
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Read Fault Code	
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Clear Fault Code	
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Read Data Stream	
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Module Information	
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Actuation Test	Door Lock/Unlock
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Actuation Test	ANTENNA
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Actuation Test	Outside Buzzer
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Actuation Test	Inside Buzzer
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Actuation Test	Indicator
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Actuation Test	KEY LOCK SOLENOID
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Actuation Test	P Range
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Actuation Test	Engine SW Illumi
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Actuation Test	Lock Indicator
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Actuation Test	ACC Indicator
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Actuation Test	Ignition ON IND
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Actuation Test	Key Slot Illumi
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Actuation Test	LCD
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Special Function	Confirm Key Fob ID
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Special Function	Take Out From Window Warn
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Special Function	Low Batt Of Key Fob Warn
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Special Function	Keyless Function
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Special Function	I-Key Function
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Special Function	Answer Back Function
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Special Function	Selective Unlock Function
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Special Function	Anti Key Lock In Function
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Special Function	Hazard Answer Back
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Special Function	Answer Back With I-Key Unlock
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Special Function	Auto Relock Timer
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Special Function	Panic Alarm Delay
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Special Function	Trunk Open Delay
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Special Function	P/W Down Delay
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Special Function	Power Slide Door Delay
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Special Function	Engine Start By I-Key
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Special Function	Lock/Unlock By I-Key
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Special Function	LUG Room Engine Start
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Special Function	Trunk/Glass Hatch Open
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Special Function	Short Cranking Output
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Special Function	Answer Back With I-Key Lock
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Read Fault Code	
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Clear Fault Code	
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Read Data Stream	
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Module Information	
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Special Function	Take Out From Window Warn
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Special Function	Low Batt Of Key Fob Warn
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Special Function	I-Key Function
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Special Function	Answer Back Function
DFNISSAN	All Mode	Up to 2014	Intelligent Key	Special Function	Confirm Key Fob ID
DFNISSAN	All Mode	2013 - 2013	Intelligent Key	Read Fault Code	
DFNISSAN	All Mode	2013 - 2013	Intelligent Key	Clear Fault Code	
DFNISSAN	All Mode	2013 - 2013	Intelligent Key	Read Data Stream	
DFNISSAN	All Mode	2013 - 2013	Intelligent Key	Module Information	
DFNISSAN	All Mode	2013 - 2013	Intelligent Key	Actuation Test	Door Lock
DFNISSAN	All Mode	2013 - 2013	Intelligent Key	Actuation Test	ANTENNA
DFNISSAN	All Mode	2013 - 2013	Intelligent Key	Actuation Test	INDICATOR
DFNISSAN	All Mode	2013 - 2013	Intelligent Key	Special Function	Hands-Free Card Reading
DFNISSAN	All Mode	2013 - 2013	Intelligent Key	Special Function	Programming The Hands-Free Card
DFNISSAN	All Mode	2016 - 2016	Intelligent Key	Read Fault Code	
DFNISSAN	All Mode	2016 - 2016	Intelligent Key	Clear Fault Code	
DFNISSAN	All Mode	2016 - 2016	Intelligent Key	Read Data Stream	
DFNISSAN	All Mode	2016 - 2016	Intelligent Key	Module Information	
DFNISSAN	All Mode	Up to 2009	DIU	Read Fault Code	
DFNISSAN	All Mode	Up to 2009	DIU	Clear Fault Code	
DFNISSAN	All Mode	Up to 2009	DIU	Read Data Stream	
DFNISSAN	All Mode	Up to 2009	Auto Slide Door	Read Fault Code	
DFNISSAN	All Mode	Up to 2009	Auto Slide Door	Clear Fault Code	

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
DFNISSAN	All Mode	Up to 2009	Auto Slide Door	Read Data Stream	
DFNISSAN	All Mode	Up to 2009	Auto Slide Door	Module Information	
DFNISSAN	All Mode	Up to 2009	Auto Slide Door	Actuation Test	CLUTCH
DFNISSAN	All Mode	2012 - 2016	Auto Slide Door	Read Fault Code	
DFNISSAN	All Mode	2012 - 2016	Auto Slide Door	Clear Fault Code	
DFNISSAN	All Mode	2012 - 2016	Auto Slide Door	Read Data Stream	
DFNISSAN	All Mode	2012 - 2016	Auto Slide Door	Read Freeze Frame	
DFNISSAN	All Mode	2012 - 2016	Auto Slide Door	Module Information	
DFNISSAN	All Mode	2012 - 2016	Auto Slide Door	Actuation Test	CLUTCH
DFNISSAN	All Mode	2012 - 2016	Auto Slide Door	Actuation Test	Slide Door
DFNISSAN	All Mode	2012 - 2016	Auto Slide Door	Actuation Test	BUZZER
DFNISSAN	All Mode	2012 - 2016	Auto Slide Door	Actuation Test	Lock Release
DFNISSAN	All Mode	2008 - 2014	Precrash Seatbelt	Read Fault Code	
DFNISSAN	All Mode	2008 - 2014	Precrash Seatbelt	Clear Fault Code	
DFNISSAN	All Mode	2008 - 2014	Precrash Seatbelt	Read Data Stream	
DFNISSAN	All Mode	2008 - 2014	Precrash Seatbelt	Module Information	
DFNISSAN	All Mode	2013 - 2014	Precrash Seatbelt	Read Fault Code	
DFNISSAN	All Mode	2013 - 2014	Precrash Seatbelt	Clear Fault Code	
DFNISSAN	All Mode	2013 - 2014	Precrash Seatbelt	Read Data Stream	
DFNISSAN	All Mode	2013 - 2014	Precrash Seatbelt	Module Information	
DFNISSAN	All Mode	2009 - 2017	Precrash Seatbelt	Read Fault Code	
DFNISSAN	All Mode	2009 - 2017	Precrash Seatbelt	Clear Fault Code	
DFNISSAN	All Mode	2009 - 2017	Precrash Seatbelt	Read Data Stream	
DFNISSAN	All Mode	2009 - 2017	Precrash Seatbelt	Read Freeze Frame	
DFNISSAN	All Mode	2009 - 2017	Precrash Seatbelt	Module Information	
DFNISSAN	All Mode	2009 - 2017	Precrash Seatbelt	Special Function	Door Opening Retract Retry
DFNISSAN	All Mode	Up to 2016	Auto Drive Position	Read Fault Code	
DFNISSAN	All Mode	Up to 2016	Auto Drive Position	Clear Fault Code	
DFNISSAN	All Mode	Up to 2016	Auto Drive Position	Read Data Stream	
DFNISSAN	All Mode	Up to 2016	Auto Drive Position	Module Information	
DFNISSAN	All Mode	Up to 2016	Auto Drive Position	Actuation Test	SEAT SLIDE
DFNISSAN	All Mode	Up to 2016	Auto Drive Position	Actuation Test	SEAT RECLINING
DFNISSAN	All Mode	Up to 2016	Auto Drive Position	Actuation Test	SEAT LIFTER FR
DFNISSAN	All Mode	Up to 2016	Auto Drive Position	Actuation Test	SEAT LIFTER RR
DFNISSAN	All Mode	Up to 2016	Auto Drive Position	Actuation Test	TILT MOTOR
DFNISSAN	All Mode	Up to 2016	Auto Drive Position	Actuation Test	TELESCO MOTOR
DFNISSAN	All Mode	Up to 2016	Auto Drive Position	Actuation Test	PEDAL MOTOR
DFNISSAN	All Mode	Up to 2016	Auto Drive Position	Actuation Test	Mirror Motor RH
DFNISSAN	All Mode	Up to 2016	Auto Drive Position	Actuation Test	Mirror Motor LH
DFNISSAN	All Mode	Up to 2016	Auto Drive Position	Actuation Test	MEMORY SW INDCTR
DFNISSAN	All Mode	Up to 2016	Auto Drive Position	Actuation Test	SEAT LIFT
DFNISSAN	All Mode	Up to 2016	Auto Drive Position	Special Function	Exit Seat Slide Setting
DFNISSAN	All Mode	Up to 2016	Auto Drive Position	Special Function	Exit Tilt Setting
DFNISSAN	All Mode	Up to 2016	Auto Drive Position	Special Function	Seat Slide Volume Set
DFNISSAN	All Mode	Up to 2016	Auto Drive Position	Read Fault Code	
DFNISSAN	All Mode	Up to 2016	Auto Drive Position	Clear Fault Code	
DFNISSAN	All Mode	Up to 2016	Auto Drive Position	Read Data Stream	
DFNISSAN	All Mode	Up to 2016	Auto Drive Position	Module Information	
DFNISSAN	All Mode	Up to 2016	Auto Drive Position	Actuation Test	SEAT SLIDE
DFNISSAN	All Mode	Up to 2016	Auto Drive Position	Actuation Test	SEAT RECLINING
DFNISSAN	All Mode	Up to 2016	Auto Drive Position	Actuation Test	SEAT LIFTER FR
DFNISSAN	All Mode	Up to 2016	Auto Drive Position	Actuation Test	SEAT LIFTER RR
DFNISSAN	All Mode	Up to 2016	Auto Drive Position	Actuation Test	TILT MOTOR
DFNISSAN	All Mode	Up to 2016	Auto Drive Position	Actuation Test	TELESCO MOTOR
DFNISSAN	All Mode	Up to 2016	Auto Drive Position	Actuation Test	PEDAL MOTOR
DFNISSAN	All Mode	Up to 2016	Auto Drive Position	Actuation Test	Mirror Motor RH
DFNISSAN	All Mode	Up to 2016	Auto Drive Position	Actuation Test	Mirror Motor LH
DFNISSAN	All Mode	Up to 2016	Auto Drive Position	Actuation Test	MEMORY SW INDCTR
DFNISSAN	All Mode	Up to 2016	Auto Drive Position	Actuation Test	SEAT LIFT
DFNISSAN	All Mode	Up to 2016	Auto Drive Position	Special Function	Exit Seat Slide Setting
DFNISSAN	All Mode	Up to 2016	Auto Drive Position	Special Function	Exit Tilt Setting
DFNISSAN	All Mode	Up to 2016	Auto Drive Position	Special Function	Seat Slide Volume Set
DFNISSAN	All Mode	Up to 2017	Auto Drive Position	Read Fault Code	
DFNISSAN	All Mode	Up to 2017	Auto Drive Position	Clear Fault Code	
DFNISSAN	All Mode	Up to 2017	Auto Drive Position	Read Data Stream	
DFNISSAN	All Mode	Up to 2017	Auto Drive Position	Read Freeze Frame	
DFNISSAN	All Mode	Up to 2017	Auto Drive Position	Module Information	
DFNISSAN	All Mode	Up to 2017	Auto Drive Position	Actuation Test	SEAT SLIDE
DFNISSAN	All Mode	Up to 2017	Auto Drive Position	Actuation Test	SEAT RECLINING
DFNISSAN	All Mode	Up to 2017	Auto Drive Position	Actuation Test	SEAT LIFTER FR
DFNISSAN	All Mode	Up to 2017	Auto Drive Position	Actuation Test	SEAT LIFTER RR
DFNISSAN	All Mode	Up to 2017	Auto Drive Position	Actuation Test	TILT MOTOR
DFNISSAN	All Mode	Up to 2017	Auto Drive Position	Actuation Test	TELESCO MOTOR
DFNISSAN	All Mode	Up to 2017	Auto Drive Position	Actuation Test	Mirror Motor RH
DFNISSAN	All Mode	Up to 2017	Auto Drive Position	Actuation Test	Mirror Motor LH
DFNISSAN	All Mode	Up to 2017	Auto Drive Position	Actuation Test	MEMORY SW INDCTR
DFNISSAN	All Mode	Up to 2017	Auto Drive Position	Special Function	Exit Seat Slide Setting
DFNISSAN	All Mode	Up to 2017	Auto Drive Position	Special Function	Exit Tilt Setting
DFNISSAN	All Mode	Up to 2017	Auto Drive Position	Special Function	Seat Slide Volume Set
DFNISSAN	All Mode	2016 - 2016	Auto Drive Position	Read Fault Code	

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

<b>make</b>	<b>model</b>	<b>year</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
DFNISSAN	All Mode	2016 - 2016	Auto Drive Position	Clear Fault Code	
DFNISSAN	All Mode	2016 - 2016	Auto Drive Position	Read Data Stream	
DFNISSAN	All Mode	2016 - 2016	Auto Drive Position	Module Information	
DFNISSAN	All Mode	2016 - 2016	Auto Drive Position	Special Function	Normalization
DFNISSAN	All Mode	2014 - 2017	Auto Drive Position	Read Fault Code	
DFNISSAN	All Mode	2014 - 2017	Auto Drive Position	Clear Fault Code	
DFNISSAN	All Mode	2014 - 2017	Auto Drive Position	Read Data Stream	
DFNISSAN	All Mode	2014 - 2017	Auto Drive Position	Module Information	
DFNISSAN	All Mode	2014 - 2017	Auto Drive Position	Special Function	Exit Seat Slide Setting
DFNISSAN	All Mode	2014 - 2017	Auto Drive Position	Special Function	Exit Tilt Setting
DFNISSAN	All Mode	2014 - 2017	Auto Drive Position	Special Function	Seat Slide Volume Set
DFNISSAN	All Mode	2016 - 2016	Auto Drive Position	Read Data Stream	
DFNISSAN	All Mode	2016 - 2016	Auto Drive Position	Module Information	
DFNISSAN	All Mode	2016 - 2016	Auto Drive Position	Special Function	Control unit unlock
DFNISSAN	All Mode	2016 - 2016	Auto Drive Position	Special Function	Initial startup sequence locking
DFNISSAN	All Mode	2008 - 2015	All Mode Awd/4wd	Read Fault Code	
DFNISSAN	All Mode	2008 - 2015	All Mode Awd/4wd	Clear Fault Code	
DFNISSAN	All Mode	2008 - 2015	All Mode Awd/4wd	Read Data Stream	
DFNISSAN	All Mode	2008 - 2015	All Mode Awd/4wd	Read Freeze Frame	
DFNISSAN	All Mode	2008 - 2015	All Mode Awd/4wd	Module Information	
DFNISSAN	All Mode	2008 - 2016	All Mode Awd/4wd	Read Fault Code	
DFNISSAN	All Mode	2008 - 2016	All Mode Awd/4wd	Clear Fault Code	
DFNISSAN	All Mode	2008 - 2016	All Mode Awd/4wd	Read Data Stream	
DFNISSAN	All Mode	2008 - 2016	All Mode Awd/4wd	Read Freeze Frame	
DFNISSAN	All Mode	2008 - 2016	All Mode Awd/4wd	Module Information	
DFNISSAN	All Mode	2008 - 2016	All Mode Awd/4wd	Special Function	Unit Characteristics Data
DFNISSAN	All Mode	2008 - 2016	All Mode Awd/4wd	Special Function	Unit Characteristics Write
DFNISSAN	All Mode	Up to 2015	All Mode Awd/4wd	Read Fault Code	
DFNISSAN	All Mode	Up to 2015	All Mode Awd/4wd	Clear Fault Code	
DFNISSAN	All Mode	Up to 2015	All Mode Awd/4wd	Read Data Stream	
DFNISSAN	All Mode	Up to 2015	All Mode Awd/4wd	Module Information	
DFNISSAN	All Mode	Up to 2015	All Mode Awd/4wd	Special Function	Clutch/F RLS LIM ADJ
DFNISSAN	All Mode	2009 - 2017	All Mode Awd/4wd	Read Fault Code	
DFNISSAN	All Mode	2009 - 2017	All Mode Awd/4wd	Clear Fault Code	
DFNISSAN	All Mode	2009 - 2017	All Mode Awd/4wd	Read Data Stream	
DFNISSAN	All Mode	2009 - 2017	All Mode Awd/4wd	Module Information	
DFNISSAN	All Mode	2009 - 2017	All Mode Awd/4wd	Special Function	Unit Characteristics Write
DFNISSAN	All Mode	2009 - 2017	All Mode Awd/4wd	Special Function	Start Calibration
DFNISSAN	All Mode	2009 - 2017	All Mode Awd/4wd	Special Function	Lock Sleeve Sensor Initialize
DFNISSAN	All Mode	2009 - 2017	All Mode Awd/4wd	Special Function	Lock Sleeve Sensor Learning
DFNISSAN	All Mode	2009 - 2017	All Mode Awd/4wd	Special Function	Oil Deterioration Info Reset
DFNISSAN	All Mode	2009 - 2016	All Mode Awd/4wd	Read Fault Code	
DFNISSAN	All Mode	2009 - 2016	All Mode Awd/4wd	Clear Fault Code	
DFNISSAN	All Mode	2009 - 2016	All Mode Awd/4wd	Read Data Stream	
DFNISSAN	All Mode	2009 - 2016	All Mode Awd/4wd	Module Information	
DFNISSAN	All Mode	2009 - 2016	All Mode Awd/4wd	Actuation Test	SOLENOID LEFT
DFNISSAN	All Mode	2009 - 2016	All Mode Awd/4wd	Actuation Test	SOLENOID RIGHT
DFNISSAN	All Mode	2009 - 2016	All Mode Awd/4wd	Special Function	Unit Characteristics Write
DFNISSAN	All Mode	2009 - 2016	All Mode Awd/4wd	Special Function	Unit Characteristics Data
DFNISSAN	All Mode	2009 - 2017	All Mode Awd/4wd	Read Fault Code	
DFNISSAN	All Mode	2009 - 2017	All Mode Awd/4wd	Clear Fault Code	
DFNISSAN	All Mode	2009 - 2017	All Mode Awd/4wd	Read Data Stream	
DFNISSAN	All Mode	2009 - 2017	All Mode Awd/4wd	Module Information	
DFNISSAN	All Mode	2009 - 2017	All Mode Awd/4wd	Actuation Test	Drive Pwr Dstrbt Torque
DFNISSAN	All Mode	2009 - 2017	All Mode Awd/4wd	Special Function	Unit Characteristics Write
DFNISSAN	All Mode	2009 - 2017	All Mode Awd/4wd	Special Function	Unit Characteristics Data
DFNISSAN	All Mode	2016 - 2016	All Mode Awd/4wd	Read Fault Code	
DFNISSAN	All Mode	2016 - 2016	All Mode Awd/4wd	Clear Fault Code	
DFNISSAN	All Mode	2016 - 2016	All Mode Awd/4wd	Read Data Stream	
DFNISSAN	All Mode	2016 - 2016	All Mode Awd/4wd	Module Information	
DFNISSAN	All Mode	2016 - 2016	All Mode Awd/4wd	Special Function	Function test of solenoid valve while driving
DFNISSAN	All Mode	Up to 2016	All Mode Awd/4wd	Read Fault Code	
DFNISSAN	All Mode	Up to 2016	All Mode Awd/4wd	Clear Fault Code	
DFNISSAN	All Mode	Up to 2016	All Mode Awd/4wd	Read Data Stream	
DFNISSAN	All Mode	Up to 2016	All Mode Awd/4wd	Module Information	
DFNISSAN	All Mode	Up to 2015	All Mode Awd/4wd	Read Fault Code	
DFNISSAN	All Mode	Up to 2015	All Mode Awd/4wd	Clear Fault Code	
DFNISSAN	All Mode	Up to 2015	All Mode Awd/4wd	Read Data Stream	
DFNISSAN	All Mode	Up to 2015	All Mode Awd/4wd	Module Information	
DFNISSAN	All Mode	Up to 2015	All Mode Awd/4wd	Special Function	
DFNISSAN	All Mode	Up to 2009	All Mode Awd/4wd	Read Fault Code	
DFNISSAN	All Mode	Up to 2009	All Mode Awd/4wd	Clear Fault Code	
DFNISSAN	All Mode	Up to 2009	All Mode Awd/4wd	Read Data Stream	
DFNISSAN	All Mode	Up to 2009	All Mode Awd/4wd	Module Information	
DFNISSAN	All Mode	Up to 2009	All Mode Awd/4wd	Actuation Test	
DFNISSAN	All Mode	Up to 2016	All Mode Awd/4wd	Read Fault Code	

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
DFNISSAN	All Mode	Up to 2016	All Mode Awd/4wd	Clear Fault Code	
DFNISSAN	All Mode	Up to 2016	All Mode Awd/4wd	Read Data Stream	
DFNISSAN	All Mode	Up to 2016	All Mode Awd/4wd	Module Information	
DFNISSAN	All Mode	Up to 2016	All Mode Awd/4wd	Special Function	START TORQ OFFSET ADJ
DFNISSAN	All Mode	Up to 2016	All Mode Awd/4wd	Special Function	CLUTCH/F RLS LIM ADJ
DFNISSAN	All Mode	Up to 2014	All Mode Awd/4wd	Read Fault Code	
DFNISSAN	All Mode	Up to 2014	All Mode Awd/4wd	Clear Fault Code	
DFNISSAN	All Mode	Up to 2014	All Mode Awd/4wd	Read Data Stream	
DFNISSAN	All Mode	Up to 2014	All Mode Awd/4wd	Module Information	
DFNISSAN	All Mode	Up to 2014	All Mode Awd/4wd	Special Function	START TORQ OFFSET ADJ
DFNISSAN	All Mode	Up to 2014	All Mode Awd/4wd	Special Function	CLUTCH/F RLS LIM ADJ
DFNISSAN	All Mode	Up to 2014	All Mode Awd/4wd	Read Fault Code	
DFNISSAN	All Mode	Up to 2014	All Mode Awd/4wd	Clear Fault Code	
DFNISSAN	All Mode	Up to 2014	All Mode Awd/4wd	Read Data Stream	
DFNISSAN	All Mode	Up to 2014	All Mode Awd/4wd	Module Information	
DFNISSAN	All Mode	Up to 2014	All Mode Awd/4wd	Special Function	CLUTCH/F RLS LIM ADJ
DFNISSAN	All Mode	2014 - 2014	Diff Lock	Read Fault Code	
DFNISSAN	All Mode	2014 - 2014	Diff Lock	Clear Fault Code	
DFNISSAN	All Mode	2014 - 2014	Diff Lock	Read Data Stream	
DFNISSAN	All Mode	2014 - 2014	Diff Lock	Module Information	
DFNISSAN	All Mode	Up to 2017	Diff Lock	Read Fault Code	
DFNISSAN	All Mode	Up to 2017	Diff Lock	Clear Fault Code	
DFNISSAN	All Mode	Up to 2017	Diff Lock	Read Data Stream	
DFNISSAN	All Mode	Up to 2017	Diff Lock	Module Information	
DFNISSAN	All Mode	Up to 2012	BCM (Body Control Module)	Read Fault Code	
DFNISSAN	All Mode	Up to 2012	BCM (Body Control Module)	Clear Fault Code	
DFNISSAN	All Mode	Up to 2012	BCM (Body Control Module)	Read Data Stream	
DFNISSAN	All Mode	Up to 2012	BCM (Body Control Module)	Module Information	
DFNISSAN	All Mode	Up to 2012	BCM (Body Control Module)	Actuation Test	Door Lock
DFNISSAN	All Mode	Up to 2012	BCM (Body Control Module)	Actuation Test	Step Lamp Test
DFNISSAN	All Mode	Up to 2012	BCM (Body Control Module)	Actuation Test	Int Lamp
DFNISSAN	All Mode	Up to 2012	BCM (Body Control Module)	Actuation Test	Tail Lamp
DFNISSAN	All Mode	Up to 2012	BCM (Body Control Module)	Actuation Test	Head Lamp
DFNISSAN	All Mode	Up to 2012	BCM (Body Control Module)	Actuation Test	FR FOG Lamp
DFNISSAN	All Mode	Up to 2012	BCM (Body Control Module)	Actuation Test	RR FOG Lamp
DFNISSAN	All Mode	Up to 2012	BCM (Body Control Module)	Actuation Test	Daytime Running Light
DFNISSAN	All Mode	Up to 2012	BCM (Body Control Module)	Actuation Test	ILL DIM Signal
DFNISSAN	All Mode	Up to 2012	BCM (Body Control Module)	Actuation Test	FR Wiper
DFNISSAN	All Mode	Up to 2012	BCM (Body Control Module)	Actuation Test	Head Lamp Washer
DFNISSAN	All Mode	Up to 2012	BCM (Body Control Module)	Actuation Test	Flasher
DFNISSAN	All Mode	Up to 2012	BCM (Body Control Module)	Actuation Test	Theft IND
DFNISSAN	All Mode	Up to 2012	BCM (Body Control Module)	Actuation Test	Battery Saver
DFNISSAN	All Mode	Up to 2012	BCM (Body Control Module)	Actuation Test	Trunk/Glass Hatch
DFNISSAN	All Mode	Up to 2012	BCM (Body Control Module)	Actuation Test	Vehicle Security Horn
DFNISSAN	All Mode	Up to 2012	BCM (Body Control Module)	Actuation Test	Head Lamp(HI)
DFNISSAN	All Mode	Up to 2012	BCM (Body Control Module)	Actuation Test	OIL Pressure SW
DFNISSAN	All Mode	Up to 2012	BCM (Body Control Module)	Actuation Test	Rear Defogger
DFNISSAN	All Mode	Up to 2012	BCM (Body Control Module)	Actuation Test	IGN KEY WARN ALM
DFNISSAN	All Mode	Up to 2012	BCM (Body Control Module)	Actuation Test	Light Warn Alm
DFNISSAN	All Mode	Up to 2012	BCM (Body Control Module)	Actuation Test	Reverse Warning
DFNISSAN	All Mode	Up to 2012	BCM (Body Control Module)	Actuation Test	Seat Belt Warn Test
DFNISSAN	All Mode	Up to 2012	BCM (Body Control Module)	Actuation Test	Horn
DFNISSAN	All Mode	Up to 2012	BCM (Body Control Module)	Actuation Test	POWER WINDOW DOWN
DFNISSAN	All Mode	Up to 2012	BCM (Body Control Module)	Actuation Test	Cornering Lamp
DFNISSAN	All Mode	Up to 2012	BCM (Body Control Module)	Actuation Test	RR Wiper
DFNISSAN	All Mode	Up to 2012	BCM (Body Control Module)	Actuation Test	PBD
DFNISSAN	All Mode	Up to 2012	BCM (Body Control Module)	Actuation Test	Power Slide Door
DFNISSAN	All Mode	Up to 2012	BCM (Body Control Module)	Actuation Test	A/C Indicator
DFNISSAN	All Mode	Up to 2012	BCM (Body Control Module)	Special Function	Set I/L D-Unlck Intcon
DFNISSAN	All Mode	Up to 2012	BCM (Body Control Module)	Special Function	Room Lamp Timer Set
DFNISSAN	All Mode	Up to 2012	BCM (Body Control Module)	Special Function	Room Lamp On Time Set
DFNISSAN	All Mode	Up to 2012	BCM (Body Control Module)	Special Function	Room Lamp Off Time Set
DFNISSAN	All Mode	Up to 2012	BCM (Body Control Module)	Special Function	R Lamp Timer Logic Set
DFNISSAN	All Mode	Up to 2012	BCM (Body Control Module)	Special Function	Room Lamp On At Lock
DFNISSAN	All Mode	Up to 2012	BCM (Body Control Module)	Special Function	Battery Saver Set
DFNISSAN	All Mode	Up to 2012	BCM (Body Control Module)	Special Function	Custom A/Light Setting
DFNISSAN	All Mode	Up to 2012	BCM (Body Control Module)	Special Function	ILL Delay Set
DFNISSAN	All Mode	Up to 2012	BCM (Body Control Module)	Special Function	Wiper Speed Setting
DFNISSAN	All Mode	Up to 2012	BCM (Body Control Module)	Special Function	Reset Setting Value
DFNISSAN	All Mode	Up to 2012	BCM (Body Control Module)	Special Function	Security Alarm SET
DFNISSAN	All Mode	Up to 2012	BCM (Body Control Module)	Special Function	Theft ALM TRG
DFNISSAN	All Mode	Up to 2012	BCM (Body Control Module)	Special Function	Retained PWR Set
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Read Fault Code	
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Clear Fault Code	
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Read Data Stream	
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Read Freeze Frame	
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Module Information	
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Door Lock
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Super Lock
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	REAR DOOR UNLOCK TEST

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

<b>make</b>	<b>model</b>	<b>year</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Door Lock Ind
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Rear Defogger
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	IGN KEY WARN ALM
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Seat Belt Warn Test
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Key Reminder Warn
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	ID REGIST WARNING
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Light Warn Alm
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Reverse Warning
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	RUN FLAT/T WARN BUZZER
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Step Lamp Test
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Int Lamp
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	LUGGAGE LAMP TEST
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Tail Lamp
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Head Lamp
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	FR FOG Lamp
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	RR FOG Lamp
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Daytime Running Light
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Cornering Lamp
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	ILL DIM Signal
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	FR Wiper
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Head Lamp Washer
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	RR Wiper
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Flasher
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	SIREN
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Theft IND
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	PW REMOTO DOWN SET
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Battery Saver
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Outside Buzzer
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Inside Buzzer
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Indicator
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	LCD
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Horn
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	P Range
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Engine SW Illumi
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Lock Indicator
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	ACC Indicator
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Ignition ON IND
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Key Slot Illumi
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Trunk/Back Door
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	KEYLESS PW UP/DOWN
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Trunk/Glass Hatch
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Vehicle Security Horn
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Head Lamp(HT)
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	OIL Pressure SW
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Warning Lamp
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	RUN FLAT TIER W/L
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Door Lock-Unlock Set
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	HORN CHIRP SET
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Set I/L D-Unlock Intcon
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Room Lamp Timer Set
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Room Lamp On Time Set
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Room Lamp BAT SAV SET
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Room Lamp Off Time Set
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	R Lamp Timer Logic Set
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Battery Saver Set
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Custom A/Light Setting
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	ILL Delay Set
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Wiper Speed Setting
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	HAZARD LAMP SET
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Hazard Answer Back
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Reset Setting Value
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Security Alarm SET
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Theft ALM TRG
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	SIREN SET
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Auto Lock Set
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Lock/Unlock By I-Key
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Engine Start By I-Key
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Trunk/Glass Hatch Open
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Panic Alarm Set
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Take Out From Win Warn
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Pw Down Set
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Trunk Open Delay
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	LO-BATT OF KEY FOB WARN
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Keyless Function
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Anti Key Lock In Function
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Ans Back I-Key Lock
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Ans Back I-Key Unlock
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Short Cranking Output
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Inside ANT Diagnosis
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Horn With Keyless Lock



**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Automatic Door Lock Select
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Automatic Door Unlock Select
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Automatic Door Lock/Unlock Select
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Confirm Key Fob ID
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	ID REGIST
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	ID READ
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	D/LOCK VHCL SPD AJT
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Room Lamp On At Lock
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Retained PWR Set
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	REMO CONT ID CONFIR
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Welcome Light Op Set
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Answer Back Function
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Welcome Light Select
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Read Fault Code	
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Clear Fault Code	
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Read Data Stream	
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Read Freeze Frame	
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Module Information	
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Door Lock
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Super Lock
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Door Lock Ind
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Rear Defogger
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Seat Belt Warn Test
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Key Reminder Warn
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Light Warn Alm
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Reverse Warning
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Step Lamp Test
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Int Lamp
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Tail Lamp
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Head Lamp
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	FR FOG Lamp
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Daytime Running Light
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	ILL DIM Signal
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	FR Wiper
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Head Lamp Washer
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	RR Wiper
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Flasher
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	SIREN
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Theft IND
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Battery Saver
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Outside Buzzer
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Inside Buzzer
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Indicator
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	LCD
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Horn
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	P Range
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Engine SW Illumi
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Lock Indicator
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	ACC Indicator
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Ignition ON IND
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Trunk/Back Door
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Vehicle Security Horn
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Head Lamp(HI)
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Push Switch Indicator
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	RUN FLAT TIRE W/L
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Warning Lamp
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	ID REGIST WARNING
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	A/C Indication
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Intelligent Key Link
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Intelligent Key Link(CAN)
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Power Slide Door
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	OIL Pressure SW
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Retractable Mirror
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Heated Steering Wheel
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Confirm TCU ID
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Door Lock-Unlock Set
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Set I/L D-Unlck Intcon
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Room Lamp Timer Set
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Room Lamp On Time Set
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Room Lamp BAT SAV SET
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Room Lamp Off Time Set
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	R Lamp Timer Logic Set
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Battery Saver Set
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Custom A/Light Setting
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	ILL Delay Set
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Wiper Speed Setting
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Rain Sen Wip Func Set
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Drop Wipe Func Set

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Hazard Answer Back
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Reset Setting Value
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Security Alarm SET
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Theft ALM TRG
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	SIREN SET
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Lock/Unlock By I-Key
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Engine Start By I-Key
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Trunk/Glass Hatch Open
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Answer Back Function
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Panic Alarm Set
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Pw Down Set
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Trunk Open Delay
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	LO-BATT OF KEY FOB WARN
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Anti Key Lock In Function
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Ans Back I-Key Lock
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Ans Back I-Key Unlock
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Short Cranking Output
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Inside ANT Diagnosis
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Horn With Keyless Lock
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Automatic Door Lock Select
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Confirm Key Fob ID
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	ID REGIST
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Switch Tpm Between On/Off
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	ID READ
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Retractable Mirror Set
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Confirm Dongle ID
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Welcome Light Op Set
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Welcome Light Select
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Intelligent Key Link Set
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Security Alarm Set(Siren)
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Signature Light Setting
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	FOG Lamp Override
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Daytime Running Light Setting
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Remote Climate Cont Answer Back Function
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	RR WIP RVRS SET
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Auto Light Logic Set
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Auto Lock Set
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Ign Battery Saver Set
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Acc Battery Saver Set
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Head Light Timer
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Automatic Door Unlock Select
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Automatic Lock/Unlock Set
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Read Fault Code	
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Clear Fault Code	
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Read Data Stream	
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Module Information	
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Door Lock
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Super Lock
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Door Lock Ind
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Rear Defogger
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Seat Belt Warn Test
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Light Warn Alm
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	IGN KEY WARN ALM
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Reverse Warning
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Int Lamp
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Power Slide Door
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Tail Lamp
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Head Lamp
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	FR FOG Lamp
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	RR FOG Lamp
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Daytime Running Light
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	ILL DIM Signal
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	FR Wiper
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Head Lamp Washer
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	RR Wiper
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Flasher
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	SIREN
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Theft IND
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Battery Saver
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Horn
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Trunk/Back Door
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Trunk/Glass Hatch
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Vehicle Security Horn
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Head Lamp(HI)
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	RUN FLAT TIRE W/L
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Warning Lamp
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	ID REGIST WARNING

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	OIL Pressure SW
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	A/C Indicator
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Set R-DEF Timer
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Door Lock-Unlock Set
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Set I/L D-Unlock Intcon
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Room Lamp Timer Set
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Room Lamp On Time Set
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Room Lamp BAT SAV SET
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Room Lamp Off Time Set
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	R Lamp Timer Logic Set
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Battery Saver Set
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Custom A/Light Setting
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	ILL Delay Set
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Auto Light Logic Set
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Wiper Speed Setting
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Rain Sen Wip Func Set
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Drop Wipe Func Set
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Reset Setting Value
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Security Alarm SET
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Theft ALM TRG
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	SIREN SET
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Panic Alarm Set
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Automatic Door Lock Select
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	ID REGIST
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	ID READ
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Confirm Dongle ID
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	REMO CONT ID ERASUR
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	REMO CONT ID REGIST
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	REMO CONT ID CONFIR
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	HORN CHIRP SET
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	MULTI ANSWER BACK SET
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	HAZARD LAMP SET
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	TRUNK OPEN SET
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Retained PWR Set
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Security Alarm Set(Siren)
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Automatic Door Unlock Select
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Automatic Lock/Unlock Set
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Read Fault Code	
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Clear Fault Code	
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Read Data Stream	
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Read Freeze Frame	
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Module Information	
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Door Lock
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Super Lock
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	REAR DOOR UNLOCK TEST
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Door Lock Ind
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Rear Defogger
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	IGN KEY WARN ALM
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Seat Belt Warn Test
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Key Reminder Warn
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	ID REGIST WARNING
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Light Warn Alm
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Reverse Warning
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	RUN FLAT/T WARN BUZZER
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Step Lamp Test
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Int Lamp
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	LUGGAGE LAMP TEST
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Tail Lamp
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Head Lamp
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	FR FOG Lamp
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	RR FOG Lamp
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Daytime Running Light
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Cornering Lamp
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	ILL DIM Signal
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	FR Wiper
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Head Lamp Washer
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	RR Wiper
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Flasher
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	SIREN
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Theft IND
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	PW REMOTO DOWN SET
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Battery Saver
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Outside Buzzer
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Inside Buzzer
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Indicator
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	LCD
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Horn
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	P Range
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Engine SW Illumi

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Lock Indicator
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	ACC Indicator
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Ignition ON IND
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Key Slot Illumi
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Trunk/Back Door
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	KEYLESS PW UP/DOWN
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Trunk/Glass Hatch
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Vehicle Security Horn
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Head Lamp(HI)
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	OIL Pressure SW
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Warning Lamp
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	RUN FLAT TIER W/L
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	D/LOCK VHCL SPD AJT
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Door Lock-Unlock Set
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Set I/L D-Unlock Intcon
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Room Lamp Timer Set
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Room Lamp On Time Set
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Room Lamp BAT SAV SET
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Room Lamp Off Time Set
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	R Lamp Timer Logic Set
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Room Lamp On At Lock
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Battery Saver Set
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Custom A/Light Setting
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	ILL Delay Set
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Wiper Speed Setting
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	HAZARD LAMP SET
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Hazard Answer Back
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Reset Setting Value
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Security Alarm SET
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Theft ALM TRG
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	SIREN SET
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Retained PWR Set
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	REMO CONT ID CONFIR
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Welcome Light Op Set
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Lock/Unlock By I-Key
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Engine Start By I-Key
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Trunk/Glass Hatch Open
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Answer Back Function
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Panic Alarm Set
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Take Out From Win Warn
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Pw Down Set
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Trunk Open Delay
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	LO-BATT OF KEY FOB WARN
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Keyless Function
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Anti Key Lock In Function
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Ans Back I-Key Lock
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Ans Back I-Key Unlock
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Short Cranking Output
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Inside ANT Diagnosis
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Horn With Keyless Lock
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Welcome Light Select
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Confirm Dongle ID
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Automatic Door Lock Select
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	HORN CHIRP SET
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Auto Lock Set
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Automatic Door Unlock Select
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Automatic Door Lock/Unlock Select
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	ID REGIST
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	ID READ
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Confirm Key Fob ID
DFNISSAN	All Mode	Up to 2010	BCM (Body Control Module)	Read Fault Code	
DFNISSAN	All Mode	Up to 2010	BCM (Body Control Module)	Clear Fault Code	
DFNISSAN	All Mode	Up to 2010	BCM (Body Control Module)	Read Data Stream	
DFNISSAN	All Mode	Up to 2010	BCM (Body Control Module)	Module Information	
DFNISSAN	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	Rear Defogger
DFNISSAN	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	IGN KEY WARN ALM
DFNISSAN	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	Light Warn Alm
DFNISSAN	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	Seat Belt Warn Test
DFNISSAN	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	Tail Lamp
DFNISSAN	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	Head Lamp
DFNISSAN	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	FR FOG Lamp
DFNISSAN	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	Daytime Running Light
DFNISSAN	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	CARGO Lamp
DFNISSAN	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	Cornering Lamp
DFNISSAN	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	RR Wiper
DFNISSAN	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	FR Wiper
DFNISSAN	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	Head Lamp Washer
DFNISSAN	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	Flasher

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

<b>make</b>	<b>model</b>	<b>year</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
DFNISSAN	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	Trunk/Back Door
DFNISSAN	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	A/C Indicator
DFNISSAN	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	Theft IND
DFNISSAN	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	OIL Pressure SW
DFNISSAN	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	FUEL LID OPEN
DFNISSAN	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	Warning Lamp
DFNISSAN	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	ID REGIST WARNING
DFNISSAN	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	FLAT TIRE WARNING
DFNISSAN	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	Horn
DFNISSAN	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	RUN FLAT TIRE W/L
DFNISSAN	All Mode	Up to 2010	BCM (Body Control Module)	Special Function	Automatic Door Lock Select
DFNISSAN	All Mode	Up to 2010	BCM (Body Control Module)	Special Function	Automatic Door Unlock Select
DFNISSAN	All Mode	Up to 2010	BCM (Body Control Module)	Special Function	Automatic Door Lock/Unlock Select
DFNISSAN	All Mode	Up to 2010	BCM (Body Control Module)	Special Function	Battery Saver Set
DFNISSAN	All Mode	Up to 2010	BCM (Body Control Module)	Special Function	Custom A/Light Setting
DFNISSAN	All Mode	Up to 2010	BCM (Body Control Module)	Special Function	ILL Delay Set
DFNISSAN	All Mode	Up to 2010	BCM (Body Control Module)	Special Function	Wiper Speed Setting
DFNISSAN	All Mode	Up to 2010	BCM (Body Control Module)	Special Function	Reset Setting Value
DFNISSAN	All Mode	Up to 2010	BCM (Body Control Module)	Special Function	ID REGIST
DFNISSAN	All Mode	Up to 2010	BCM (Body Control Module)	Special Function	ID READ
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Read Fault Code	
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Clear Fault Code	
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Read Data Stream	
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Module Information	
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Actuation Test	Door Lock
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Actuation Test	Step Lamp Test
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Actuation Test	Int Lamp
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Actuation Test	Tail Lamp
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Actuation Test	Head Lamp
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Actuation Test	FR FOG Lamp
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Actuation Test	RR FOG Lamp
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Actuation Test	Daytime Running Light
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Actuation Test	ILL DIM Signal
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Actuation Test	FR Wiper
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Actuation Test	Head Lamp Washer
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Actuation Test	Flasher
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Actuation Test	Theft IND
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Actuation Test	Battery Saver
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Actuation Test	Trunk/Glass Hatch
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Actuation Test	Vehicle Security Horn
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Actuation Test	Head Lamp(HT)
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Actuation Test	OIL Pressure SW
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Actuation Test	Rear Defogger
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Actuation Test	IGN KEY WARN ALM
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Actuation Test	Light Warn ALM
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Actuation Test	Reverse Warning
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Actuation Test	Seat Belt Warn Test
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Actuation Test	Horn
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Actuation Test	POWER WINDOW DOWN
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Actuation Test	Cornering Lamp
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Actuation Test	RR Wiper
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Actuation Test	PBD
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Actuation Test	Power Slide Door
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Actuation Test	A/C Indicator
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Special Function	Set I/L D-Unlck Intcon
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Special Function	Room Lamp Timer Set
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Special Function	Room Lamp On Time Set
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Special Function	Room Lamp Off Time Set
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Special Function	R Lamp Timer Logic Set
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Special Function	Room Lamp On At Lock
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Special Function	Battery Saver Set
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Special Function	Custom A/Light Setting
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Special Function	ILL Delay Set
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Special Function	Wiper Speed Setting
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Special Function	Reset Setting Value
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Special Function	Security Alarm SET
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Special Function	Theft ALM TRG
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Special Function	Room Lamp BAT SAV SET
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Special Function	REMO CONT ID ERASUR
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Special Function	REMO CONT ID REGIST
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Special Function	REMO CONT ID CONFIR
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Special Function	HAZARD LAMP SET
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Special Function	Auto Lock Set
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Special Function	TRUNK OPEN SET
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Special Function	Panic Alarm Set
DFNISSAN	All Mode	Up to 2012	BCM (Body Control Module)	Read Fault Code	
DFNISSAN	All Mode	Up to 2012	BCM (Body Control Module)	Clear Fault Code	
DFNISSAN	All Mode	Up to 2012	BCM (Body Control Module)	Read Data Stream	

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
DFNISSAN	All Mode	Up to 2012	BCM (Body Control Module)	Module Information	
DFNISSAN	All Mode	Up to 2012	BCM (Body Control Module)	Actuation Test	Door Lock
DFNISSAN	All Mode	Up to 2012	BCM (Body Control Module)	Actuation Test	Int Lamp
DFNISSAN	All Mode	Up to 2012	BCM (Body Control Module)	Actuation Test	Super Lock
DFNISSAN	All Mode	Up to 2012	BCM (Body Control Module)	Actuation Test	Door Lock Ind
DFNISSAN	All Mode	Up to 2012	BCM (Body Control Module)	Actuation Test	Step Lamp Test
DFNISSAN	All Mode	Up to 2012	BCM (Body Control Module)	Actuation Test	Tail Lamp
DFNISSAN	All Mode	Up to 2012	BCM (Body Control Module)	Actuation Test	Head Lamp
DFNISSAN	All Mode	Up to 2012	BCM (Body Control Module)	Actuation Test	FR FOG Lamp
DFNISSAN	All Mode	Up to 2012	BCM (Body Control Module)	Actuation Test	RR FOG Lamp
DFNISSAN	All Mode	Up to 2012	BCM (Body Control Module)	Actuation Test	Daytime Running Light
DFNISSAN	All Mode	Up to 2012	BCM (Body Control Module)	Actuation Test	ILL DIM Signal
DFNISSAN	All Mode	Up to 2012	BCM (Body Control Module)	Actuation Test	FR Wiper
DFNISSAN	All Mode	Up to 2012	BCM (Body Control Module)	Actuation Test	RR Wiper
DFNISSAN	All Mode	Up to 2012	BCM (Body Control Module)	Actuation Test	Head Lamp Washer
DFNISSAN	All Mode	Up to 2012	BCM (Body Control Module)	Actuation Test	Flasher
DFNISSAN	All Mode	Up to 2012	BCM (Body Control Module)	Actuation Test	Theft IND
DFNISSAN	All Mode	Up to 2012	BCM (Body Control Module)	Actuation Test	Trunk/Glass Hatch
DFNISSAN	All Mode	Up to 2012	BCM (Body Control Module)	Actuation Test	Vehicle Security Horn
DFNISSAN	All Mode	Up to 2012	BCM (Body Control Module)	Actuation Test	OIL Pressure SW
DFNISSAN	All Mode	Up to 2012	BCM (Body Control Module)	Actuation Test	Rear Defogger
DFNISSAN	All Mode	Up to 2012	BCM (Body Control Module)	Actuation Test	IGN KEY WARN ALM
DFNISSAN	All Mode	Up to 2012	BCM (Body Control Module)	Actuation Test	Light Warn Alm
DFNISSAN	All Mode	Up to 2012	BCM (Body Control Module)	Actuation Test	Reverse Warning
DFNISSAN	All Mode	Up to 2012	BCM (Body Control Module)	Actuation Test	Seat Belt Warn Test
DFNISSAN	All Mode	Up to 2012	BCM (Body Control Module)	Actuation Test	Key Reminder Warn
DFNISSAN	All Mode	Up to 2012	BCM (Body Control Module)	Actuation Test	A/C Indicator
DFNISSAN	All Mode	Up to 2012	BCM (Body Control Module)	Actuation Test	Battery Saver
DFNISSAN	All Mode	Up to 2012	BCM (Body Control Module)	Actuation Test	PTC HEATER
DFNISSAN	All Mode	Up to 2012	BCM (Body Control Module)	Actuation Test	Head Lamp(HI)
DFNISSAN	All Mode	Up to 2012	BCM (Body Control Module)	Special Function	Security Door Lock Set
DFNISSAN	All Mode	Up to 2012	BCM (Body Control Module)	Special Function	Set R-DEF Timer
DFNISSAN	All Mode	Up to 2012	BCM (Body Control Module)	Special Function	Set I/L D-Unlck Intcon
DFNISSAN	All Mode	Up to 2012	BCM (Body Control Module)	Special Function	Room Lamp Timer Set
DFNISSAN	All Mode	Up to 2012	BCM (Body Control Module)	Special Function	Room Lamp On Time Set
DFNISSAN	All Mode	Up to 2012	BCM (Body Control Module)	Special Function	Room Lamp Off Time Set
DFNISSAN	All Mode	Up to 2012	BCM (Body Control Module)	Special Function	R Lamp Timer Logic Set
DFNISSAN	All Mode	Up to 2012	BCM (Body Control Module)	Special Function	Room Lamp On At Lock
DFNISSAN	All Mode	Up to 2012	BCM (Body Control Module)	Special Function	Custom A/Light Setting
DFNISSAN	All Mode	Up to 2012	BCM (Body Control Module)	Special Function	ILL Delay Set
DFNISSAN	All Mode	Up to 2012	BCM (Body Control Module)	Special Function	Head Light Timer
DFNISSAN	All Mode	Up to 2012	BCM (Body Control Module)	Special Function	Wiper Speed Setting
DFNISSAN	All Mode	Up to 2012	BCM (Body Control Module)	Special Function	Headlamp Washer Auto Set
DFNISSAN	All Mode	Up to 2012	BCM (Body Control Module)	Special Function	Reset Setting Value
DFNISSAN	All Mode	Up to 2012	BCM (Body Control Module)	Special Function	Security Alarm SET
DFNISSAN	All Mode	Up to 2012	BCM (Body Control Module)	Special Function	Theft ALM TRG
DFNISSAN	All Mode	Up to 2012	BCM (Body Control Module)	Special Function	REMO CONT ID CONFIR
DFNISSAN	All Mode	Up to 2012	BCM (Body Control Module)	Special Function	HAZARD LAMP SET
DFNISSAN	All Mode	Up to 2012	BCM (Body Control Module)	Special Function	Auto Lock Set
DFNISSAN	All Mode	Up to 2012	BCM (Body Control Module)	Special Function	TRUNK OPEN SET
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Read Fault Code	
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Clear Fault Code	
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Read Data Stream	
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Module Information	
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Actuation Test	Door Lock
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Actuation Test	Int Lamp
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Actuation Test	Step Lamp Test
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Actuation Test	Tail Lamp
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Actuation Test	Head Lamp
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Actuation Test	FR FOG Lamp
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Actuation Test	RR FOG Lamp
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Actuation Test	ILL DIM Signal
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Actuation Test	Cornering Lamp
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Actuation Test	FR Wiper
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Actuation Test	Head Lamp Washer
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Actuation Test	RR Wiper
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Actuation Test	Flasher
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Actuation Test	Theft IND
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Actuation Test	Trunk/Glass Hatch
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Actuation Test	Vehicle Security Horn
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Actuation Test	OIL Pressure SW
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Actuation Test	Rear Defogger
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Actuation Test	IGN KEY WARN ALM
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Actuation Test	Light Warn Alm
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Actuation Test	A/C Indicator
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Actuation Test	Battery Saver
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Special Function	Set I/L D-Unlck Intcon
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Special Function	Room Lamp Timer Set
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Special Function	Room Lamp On Time Set
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Special Function	Room Lamp Off Time Set

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Special Function	R Lamp Timer Logic Set
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Special Function	Battery Saver Set
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Special Function	Custom A/Light Setting
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Special Function	Wiper Speed Setting
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Special Function	Reset Setting Value
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Special Function	Room Lamp BAT SAV SET
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Special Function	REMO CONT ID ERASUR
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Special Function	REMO CONT ID REGIST
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Special Function	REMO CONT ID CONFIR
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Special Function	TRUNK OPEN SET
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Special Function	Panic Alarm Set
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Special Function	Security Alarm SET
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Special Function	Theft ALM TRG
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Read Fault Code	
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Clear Fault Code	
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Read Data Stream	
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Read Freeze Frame	
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Module Information	
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Actuation Test	Door Lock
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Actuation Test	Int Lamp
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Actuation Test	Tail Lamp
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Actuation Test	Head Lamp
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Actuation Test	FR FOG Lamp
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Actuation Test	RR FOG Lamp
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Actuation Test	ILL DIM Signal
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Actuation Test	FR Wiper
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Actuation Test	RR Wiper
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Actuation Test	Flasher
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Actuation Test	Theft IND
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Actuation Test	Trunk/Glass Hatch
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Actuation Test	PBD
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Actuation Test	Power Slide Door
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Actuation Test	Vehicle Security Horn
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Actuation Test	OIL Pressure SW
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Actuation Test	Rear Defogger
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Actuation Test	IGN KEY WARN ALM
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Actuation Test	Light Warn Alm
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Actuation Test	Reverse Warning
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Actuation Test	Seat Belt Warn Test
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Actuation Test	A/C Indicator
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Special Function	Set I/L D-Unlck Intcon
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Special Function	Room Lamp Timer Set
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Special Function	Room Lamp On Time Set
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Special Function	Room Lamp Off Time Set
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Special Function	R Lamp Timer Logic Set
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Special Function	Room Lamp On At Lock
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Special Function	Battery Saver Set
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Special Function	Custom A/Light Setting
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Special Function	ILL Delay Set
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Special Function	Wiper Speed Setting
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Special Function	Reset Setting Value
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Special Function	Security Alarm SET
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Special Function	Theft ALM TRG
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Special Function	Retained PWR Set
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Special Function	Room Lamp BAT SAV SET
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Special Function	REMO CONT ID ERASUR
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Special Function	REMO CONT ID REGIST
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Special Function	REMO CONT ID CONFIR
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Special Function	HAZARD LAMP SET
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Special Function	TRUNK OPEN SET
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Special Function	Panic Alarm Set
DFNISSAN	All Mode	Up to 2010	BCM (Body Control Module)	Read Fault Code	
DFNISSAN	All Mode	Up to 2010	BCM (Body Control Module)	Clear Fault Code	
DFNISSAN	All Mode	Up to 2010	BCM (Body Control Module)	Read Data Stream	
DFNISSAN	All Mode	Up to 2010	BCM (Body Control Module)	Module Information	
DFNISSAN	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	Door Lock
DFNISSAN	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	Door Lock Ind
DFNISSAN	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	Super Lock
DFNISSAN	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	Rear Defogger
DFNISSAN	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	IGN KEY WARN ALM
DFNISSAN	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	Light Warn Alm
DFNISSAN	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	Key Reminder Warn
DFNISSAN	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	Int Lamp
DFNISSAN	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	Tail Lamp
DFNISSAN	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	Head Lamp
DFNISSAN	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	FR FOG Lamp
DFNISSAN	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	RR FOG Lamp
DFNISSAN	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	FR Wiper
DFNISSAN	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	RR Wiper
DFNISSAN	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	Head Lamp Washer

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
DFNISSAN	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	Flasher
DFNISSAN	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	A/C Indicator
DFNISSAN	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	Theft IND
DFNISSAN	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	OIL Pressure SW
DFNISSAN	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	Battery Saver
DFNISSAN	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	Vehicle Security Horn
DFNISSAN	All Mode	Up to 2010	BCM (Body Control Module)	Special Function	Custom A/Light Setting
DFNISSAN	All Mode	Up to 2010	BCM (Body Control Module)	Special Function	Head Light Timer
DFNISSAN	All Mode	Up to 2010	BCM (Body Control Module)	Special Function	Wiper Speed Setting
DFNISSAN	All Mode	Up to 2010	BCM (Body Control Module)	Special Function	Reset Setting Value
DFNISSAN	All Mode	Up to 2010	BCM (Body Control Module)	Special Function	Security Door Lock Set
DFNISSAN	All Mode	Up to 2010	BCM (Body Control Module)	Special Function	Set I/L D-Unlck Intcon
DFNISSAN	All Mode	Up to 2010	BCM (Body Control Module)	Special Function	Room Lamp On Time Set
DFNISSAN	All Mode	Up to 2010	BCM (Body Control Module)	Special Function	Room Lamp Off Time Set
DFNISSAN	All Mode	Up to 2010	BCM (Body Control Module)	Special Function	Room Lamp Timer Set
DFNISSAN	All Mode	Up to 2010	BCM (Body Control Module)	Special Function	HAZARD LAMP SET
DFNISSAN	All Mode	Up to 2010	BCM (Body Control Module)	Special Function	REMO CONT ID ERASUR
DFNISSAN	All Mode	Up to 2010	BCM (Body Control Module)	Special Function	REMO CONT ID REGIST
DFNISSAN	All Mode	Up to 2010	BCM (Body Control Module)	Special Function	Security Alarm SET
DFNISSAN	All Mode	Up to 2010	BCM (Body Control Module)	Special Function	Theft ALM TRG
DFNISSAN	All Mode	Up to 2010	BCM (Body Control Module)	Special Function	Auto Lock Set
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Read Fault Code	
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Clear Fault Code	
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Read Data Stream	
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Module Information	
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Actuation Test	Light Warn Alm
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Actuation Test	IGN KEY WARN ALM
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Actuation Test	Key Reminder Warn
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Actuation Test	Theft IND
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Special Function	Reset Setting Value
DFNISSAN	All Mode	Up to 2011	BCM (Body Control Module)	Read Fault Code	
DFNISSAN	All Mode	Up to 2011	BCM (Body Control Module)	Clear Fault Code	
DFNISSAN	All Mode	Up to 2011	BCM (Body Control Module)	Read Data Stream	
DFNISSAN	All Mode	Up to 2011	BCM (Body Control Module)	Module Information	
DFNISSAN	All Mode	Up to 2011	BCM (Body Control Module)	Actuation Test	Door Lock
DFNISSAN	All Mode	Up to 2011	BCM (Body Control Module)	Actuation Test	Rear Defogger
DFNISSAN	All Mode	Up to 2011	BCM (Body Control Module)	Actuation Test	Seat Belt Warn Test
DFNISSAN	All Mode	Up to 2011	BCM (Body Control Module)	Actuation Test	Light Warn Alm
DFNISSAN	All Mode	Up to 2011	BCM (Body Control Module)	Actuation Test	IGN KEY WARN ALM
DFNISSAN	All Mode	Up to 2011	BCM (Body Control Module)	Actuation Test	IGN Illum
DFNISSAN	All Mode	Up to 2011	BCM (Body Control Module)	Actuation Test	Int Lamp
DFNISSAN	All Mode	Up to 2011	BCM (Body Control Module)	Actuation Test	Step Lamp Test
DFNISSAN	All Mode	Up to 2011	BCM (Body Control Module)	Actuation Test	LUGGAGE LAMP TEST
DFNISSAN	All Mode	Up to 2011	BCM (Body Control Module)	Actuation Test	Tail Lamp
DFNISSAN	All Mode	Up to 2011	BCM (Body Control Module)	Actuation Test	Head Lamp
DFNISSAN	All Mode	Up to 2011	BCM (Body Control Module)	Actuation Test	FR FOG Lamp
DFNISSAN	All Mode	Up to 2011	BCM (Body Control Module)	Actuation Test	RR FOG Lamp
DFNISSAN	All Mode	Up to 2011	BCM (Body Control Module)	Actuation Test	Daytime Running Light
DFNISSAN	All Mode	Up to 2011	BCM (Body Control Module)	Actuation Test	CARGO Lamp
DFNISSAN	All Mode	Up to 2011	BCM (Body Control Module)	Actuation Test	Cornering Lamp
DFNISSAN	All Mode	Up to 2011	BCM (Body Control Module)	Actuation Test	FR Wiper
DFNISSAN	All Mode	Up to 2011	BCM (Body Control Module)	Actuation Test	RR Wiper
DFNISSAN	All Mode	Up to 2011	BCM (Body Control Module)	Actuation Test	Head Lamp Washer
DFNISSAN	All Mode	Up to 2011	BCM (Body Control Module)	Actuation Test	RISE UP WIPER TEST
DFNISSAN	All Mode	Up to 2011	BCM (Body Control Module)	Actuation Test	Flasher
DFNISSAN	All Mode	Up to 2011	BCM (Body Control Module)	Actuation Test	A/C Indicator
DFNISSAN	All Mode	Up to 2011	BCM (Body Control Module)	Actuation Test	Theft IND
DFNISSAN	All Mode	Up to 2011	BCM (Body Control Module)	Actuation Test	Battery Saver
DFNISSAN	All Mode	Up to 2011	BCM (Body Control Module)	Actuation Test	Trunk/Back Door
DFNISSAN	All Mode	Up to 2011	BCM (Body Control Module)	Actuation Test	Vehicle Security Horn
DFNISSAN	All Mode	Up to 2011	BCM (Body Control Module)	Actuation Test	Head Lamp(HI)
DFNISSAN	All Mode	Up to 2011	BCM (Body Control Module)	Actuation Test	Retained PWR
DFNISSAN	All Mode	Up to 2011	BCM (Body Control Module)	Actuation Test	OIL Pressure SW
DFNISSAN	All Mode	Up to 2011	BCM (Body Control Module)	Actuation Test	BRAKE SW
DFNISSAN	All Mode	Up to 2011	BCM (Body Control Module)	Actuation Test	PW REMOTO DOWN SET
DFNISSAN	All Mode	Up to 2011	BCM (Body Control Module)	Actuation Test	Horn
DFNISSAN	All Mode	Up to 2011	BCM (Body Control Module)	Actuation Test	PSD PBD OPEN TEST
DFNISSAN	All Mode	Up to 2011	BCM (Body Control Module)	Actuation Test	FUEL LID OPEN
DFNISSAN	All Mode	Up to 2011	BCM (Body Control Module)	Actuation Test	Warning Lamp
DFNISSAN	All Mode	Up to 2011	BCM (Body Control Module)	Actuation Test	ID REGIST WARNING
DFNISSAN	All Mode	Up to 2011	BCM (Body Control Module)	Actuation Test	FLAT TIRE WARNING
DFNISSAN	All Mode	Up to 2011	BCM (Body Control Module)	Actuation Test	RUN FLAT TIRE W/L
DFNISSAN	All Mode	Up to 2011	BCM (Body Control Module)	Actuation Test	PANIC ALARM
DFNISSAN	All Mode	Up to 2011	BCM (Body Control Module)	Special Function	Door Lock-Unlock Set
DFNISSAN	All Mode	Up to 2011	BCM (Body Control Module)	Special Function	ANTI-LOCK OUT SET
DFNISSAN	All Mode	Up to 2011	BCM (Body Control Module)	Special Function	Automatic Door Lock Select
DFNISSAN	All Mode	Up to 2011	BCM (Body Control Module)	Special Function	Automatic Door Unlock Select
DFNISSAN	All Mode	Up to 2011	BCM (Body Control Module)	Special Function	Automatic Door Lock/Unlock Select



**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
DFNISSAN	All Mode	Up to 2011	BCM (Body Control Module)	Special Function	Battery Saver Set
DFNISSAN	All Mode	Up to 2011	BCM (Body Control Module)	Special Function	Custom A/Light Setting
DFNISSAN	All Mode	Up to 2011	BCM (Body Control Module)	Special Function	ILL Delay Set
DFNISSAN	All Mode	Up to 2011	BCM (Body Control Module)	Special Function	Wiper Speed Setting
DFNISSAN	All Mode	Up to 2011	BCM (Body Control Module)	Special Function	Reset Setting Value
DFNISSAN	All Mode	Up to 2011	BCM (Body Control Module)	Special Function	ID READ
DFNISSAN	All Mode	Up to 2011	BCM (Body Control Module)	Special Function	ID REGIST
DFNISSAN	All Mode	Up to 2011	BCM (Body Control Module)	Special Function	Set I/L D-Unlck Intcon
DFNISSAN	All Mode	Up to 2011	BCM (Body Control Module)	Special Function	Room Lamp On Time Set
DFNISSAN	All Mode	Up to 2011	BCM (Body Control Module)	Special Function	Room Lamp Off Time Set
DFNISSAN	All Mode	Up to 2011	BCM (Body Control Module)	Special Function	Room Lamp Timer Set
DFNISSAN	All Mode	Up to 2011	BCM (Body Control Module)	Special Function	Retained PWR Set
DFNISSAN	All Mode	Up to 2011	BCM (Body Control Module)	Special Function	HORN CHIRP SET
DFNISSAN	All Mode	Up to 2011	BCM (Body Control Module)	Special Function	HAZARD LAMP SET
DFNISSAN	All Mode	Up to 2011	BCM (Body Control Module)	Special Function	MULTI ANSWER BACK SET
DFNISSAN	All Mode	Up to 2011	BCM (Body Control Module)	Special Function	Auto Lock Set
DFNISSAN	All Mode	Up to 2011	BCM (Body Control Module)	Special Function	Panic Alarm Set
DFNISSAN	All Mode	Up to 2011	BCM (Body Control Module)	Special Function	TRUNK OPEN SET
DFNISSAN	All Mode	Up to 2011	BCM (Body Control Module)	Special Function	Pw Down Set
DFNISSAN	All Mode	Up to 2011	BCM (Body Control Module)	Special Function	REMO CONT ID REGIST
DFNISSAN	All Mode	Up to 2011	BCM (Body Control Module)	Special Function	REMO CONT ID ERASUR
DFNISSAN	All Mode	Up to 2011	BCM (Body Control Module)	Special Function	REMO CONT ID CONFIR
DFNISSAN	All Mode	Up to 2011	BCM (Body Control Module)	Special Function	Security Alarm SET
DFNISSAN	All Mode	Up to 2011	BCM (Body Control Module)	Special Function	Theft ALM TRG
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Read Fault Code	
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Clear Fault Code	
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Read Data Stream	
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Module Information	
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Actuation Test	Door Lock
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Actuation Test	Rear Defogger
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Actuation Test	Seat Belt Warn Test
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Actuation Test	Light Warn Alm
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Actuation Test	IGN KEY WARN ALM
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Actuation Test	IGN Illum
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Actuation Test	Int Lamp
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Actuation Test	Step Lamp Test
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Actuation Test	LUGGAGE LAMP TEST
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Actuation Test	Tail Lamp
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Actuation Test	Head Lamp
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Actuation Test	FR FOG Lamp
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Actuation Test	RR FOG Lamp
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Actuation Test	Daytime Running Light
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Actuation Test	Cornering Lamp
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Actuation Test	FR Wiper
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Actuation Test	RR Wiper
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Actuation Test	Head Lamp Washer
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Actuation Test	RISE UP WIPER TEST
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Actuation Test	Flasher
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Actuation Test	A/C Indicator
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Actuation Test	Theft IND
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Actuation Test	Battery Saver
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Actuation Test	Trunk/Back Door
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Actuation Test	Vehicle Security Horn
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Actuation Test	Head Lamp(HI)
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Actuation Test	Retained PWR
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Actuation Test	OIL Pressure SW
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Actuation Test	PW REMOTO DOWN SET
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Actuation Test	Horn
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Actuation Test	PSD PBD OPEN TEST
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Actuation Test	FUEL LID OPEN
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Actuation Test	PANIC ALARM
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Special Function	Door Lock-Unlock Set
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Special Function	ANTI-LOCK OUT SET
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Special Function	Set I/L D-Unlck Intcon
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Special Function	Room Lamp On Time Set
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Special Function	Room Lamp Off Time Set
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Special Function	Battery Saver Set
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Special Function	Custom A/Light Setting
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Special Function	ILL Delay Set
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Special Function	Wiper Speed Setting
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Special Function	Room Lamp Timer Set
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Special Function	Security Alarm SET
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Special Function	Retained PWR Set
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Special Function	HORN CHIRP SET
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Special Function	HAZARD LAMP SET
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Special Function	MULTI ANSWER BACK SET
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Special Function	Auto Lock Set
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Special Function	Panic Alarm Set
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Special Function	TRUNK OPEN SET
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Special Function	Pw Down Set

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

<b>make</b>	<b>model</b>	<b>year</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Special Function	REMO CONT ID REGIST
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Special Function	REMO CONT ID ERASUR
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Special Function	REMO CONT ID CONFIR
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Special Function	Reset Setting Value
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Read Fault Code	
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Clear Fault Code	
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Read Data Stream	
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Module Information	
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Actuation Test	Door Lock
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Actuation Test	Flasher
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Actuation Test	Power Slide Door
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Actuation Test	Inside Buzzer
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Actuation Test	starter cut relay
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Actuation Test	Indicator
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Actuation Test	Theft IND
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Special Function	Reset Setting Value
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Read Fault Code	
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Clear Fault Code	
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Read Data Stream	
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Module Information	
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Actuation Test	Door Lock (Door Lock)
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Actuation Test	Door Lock (Multi Remote Enter)
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Actuation Test	Door Lock (Intelligent Key)
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Actuation Test	Rear Defogger
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Actuation Test	IGN KEY WARN ALM
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Actuation Test	Light Warn Alm
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Actuation Test	Reverse Warning
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Actuation Test	INT LAMP (INT LAMP)
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Actuation Test	INT LAMP (MULTI REMOTE ENTER)
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Actuation Test	INT LAMP (INTELLIGENT KEY)
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Actuation Test	Tail Lamp
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Actuation Test	Head Lamp
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Actuation Test	FR FOG Lamp
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Actuation Test	FR Wiper
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Actuation Test	Head Lamp Washer
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Actuation Test	RR Wiper
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Actuation Test	Flasher (Multi Remote Enter,Flasher)
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Actuation Test	Flasher (Intelligent Key)
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Actuation Test	Trunk/Back Door
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Special Function	Battery Saver Set
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Special Function	Custom A/Light Setting
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Special Function	REMO CONT ID ERASUR
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Read Fault Code	
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Clear Fault Code	
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Read Data Stream	
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Module Information	
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Special Function	SET R/DEF -ENG INTCON
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Special Function	Set I/L D-Unlck Intcon
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Special Function	Room Lamp Timer Set
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Special Function	Custom A/Light Setting
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Special Function	Wiper Speed Setting
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Special Function	Switch Monitor
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Special Function	ST ANG Sen Adjustment
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Read Fault Code	
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Clear Fault Code	
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Read Data Stream	
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Module Information	
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Special Function	Auto RE-Lock
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Special Function	Selective Unlock
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Special Function	Trunk Open Delay
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Special Function	Audible Trailer Warning
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Special Function	Keyless Registration
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Special Function	Keyless Check
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Special Function	Keyless DI Flash
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Special Function	THEFT WARNING
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Special Function	Lastest Alarm Trigger
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Special Function	PRE-ARM Fast Flash
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Special Function	Siren Fitted
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Special Function	Previous Alarm Trigger
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Special Function	Oldest Alarm Trigger
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Read Fault Code	
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Clear Fault Code	
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Read Data Stream	
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Module Information	
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Actuation Test	Door Lock (Door Lock)
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Actuation Test	Door Lock Ind
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Actuation Test	Super Lock

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Actuation Test	BACK/TRNK LCK RLY
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Actuation Test	BACK/TRNK UNLOCK
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Actuation Test	Rear Defogger
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Actuation Test	Light Warn Alm
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Actuation Test	Key Reminder Warn
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Actuation Test	BACK DR OPEN WARN
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Actuation Test	DOOR WARNING IND
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Actuation Test	Int Lamp
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Actuation Test	Tail Lamp
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Actuation Test	Head Lamp
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Actuation Test	FR FOG Lamp
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Actuation Test	RR FOG Lamp
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Actuation Test	FR Wiper
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Actuation Test	Head Lamp Washer
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Actuation Test	RR Wiper
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Actuation Test	Flasher
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Actuation Test	Theft IND
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Actuation Test	PTC HEATER
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Actuation Test	DR FR WINDOW
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Actuation Test	AS FR WINDOW
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Actuation Test	DR RR WINDOW
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Actuation Test	AS RR WINDOW
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Actuation Test	TRUNK
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Actuation Test	Parcel Shelf
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Actuation Test	VALVE
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Actuation Test	HYDRAULIC MOTOR
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Actuation Test	Roof
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Special Function	Battery Saver Set
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Special Function	Security Door Lock Set
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Special Function	Auto Lock Set
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Special Function	Custom A/Light Setting
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Special Function	RR WIP RVRS SET
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Special Function	HAZARD LAMP SET
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Special Function	Security Alarm SET
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Special Function	Headlamp Washer Auto Set
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Read Fault Code	
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Clear Fault Code	
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Read Data Stream	
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Module Information	
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Actuation Test	Door Lock
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Actuation Test	Rear Defogger
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Actuation Test	IGN KEY WARN ALM
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Actuation Test	Light Warn Alm
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Actuation Test	Reverse Warning
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Actuation Test	Seat Belt Warn Test
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Actuation Test	Int Lamp
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Actuation Test	Tail Lamp
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Actuation Test	Head Lamp
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Actuation Test	Head Lamp(HI)
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Actuation Test	PANIC ALARM
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Actuation Test	FR FOG Lamp
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Actuation Test	RR FOG Lamp
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Actuation Test	Cornering Lamp
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Actuation Test	ILL DIM Signal
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Actuation Test	FR Wiper
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Actuation Test	RR Wiper
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Actuation Test	Head Lamp Washer
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Actuation Test	Flasher
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Actuation Test	Trunk/Glass Hatch
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Actuation Test	Theft IND
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Actuation Test	OIL Pressure SW
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Actuation Test	GLASS HATCH
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Actuation Test	Trunk/Back Door
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Actuation Test	Power Slide Door
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Actuation Test	A/C Indicator
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Actuation Test	Inside Buzzer
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Actuation Test	starter cut relay
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Actuation Test	Indicator
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Special Function	Battery Saver Set
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Special Function	Custom A/Light Setting
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Special Function	Set I/L D-Unlock Intcon
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Special Function	Room Lamp On Time Set
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Special Function	Room Lamp Off Time Set
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Special Function	Room Lamp BAT SAV SET
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Special Function	Room Lamp Timer Set
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Special Function	Wiper Speed Setting
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Special Function	Reset Setting Value
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Special Function	REMO CONT ID REGIST
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Special Function	REMO CONT ID ERASUR
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Special Function	REMO CONT ID CONFIR

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Special Function	HAZARD LAMP SET
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Special Function	Auto Lock Set
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Special Function	Panic Alarm Set
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Special Function	TRUNK OPEN SET
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Read Fault Code	
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Clear Fault Code	
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Read Data Stream	
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Module Information	
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Door Lock
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Door Lock Ind
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Super Lock
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Rear Defogger
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Seat Belt Warn Test
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Light Warn Alm
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Reverse Warning
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Key Reminder Warn
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	ID REGIST WARNING
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	RUN FLAT/T WARN BUZZER
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Int Lamp
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Step Lamp Test
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Battery Saver
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	FR Wiper
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	RR Wiper
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Head Lamp Washer
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Flasher
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Theft IND
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	FR FOG Lamp
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	RR FOG Lamp
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Daytime Running Light
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	ILL DIM Signal
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	OIL Pressure SW
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	BRAKE SW
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Vehicle Security Horn
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Head Lamp(HI)
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	SIREN
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Horn
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Warning Lamp
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	RUN FLAT TIRE W/L
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Intelligent Key Link(CAN)
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Retractable Mirror
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Trunk/Back Door
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Outside Buzzer
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Inside Buzzer
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Indicator
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	IGN CONT2
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	MIRROR+5
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Engine SW Illumi
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Push Switch Indicator
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	ACC CONT
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	IGN CONT1
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	ST CONT LOW
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	SL 12V CPU
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	IGNITION RELAY
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	REVERSE LAMP TEST
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	DOOR HANDLE LAMP TEST
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	DR SEAT LAMP TEST
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	AS SEAT LAMP TEST
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	SHIFT SPOT LAMP TEST
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Trunk/Luggage Lamp Test
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	KEYFOB P/W TEST
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	SHIFTLCK SOLENOID TEST
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Signature Light Setting
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Door Lock-Unlock Set
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Auto Unlock Type
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Auto Lock Function
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Auto Unlock Function
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Set R-DEF Timer
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Scenario Lighting Setting
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Set I/L D-Unlck Intcon
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	FOG Lamp Override
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Rear Wiper Link With Reverse Setting
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Rain Sensor
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	FR RR DRIP
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Wiper Speed Setting
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	3-TIME Flasher Setting
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Confirm Dongle ID
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Daytime Running Light Setting
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Twilight On

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Wiper Link
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Custom A/Light Setting
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	ILL Delay Set
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Security Alarm SET
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	SIREN SET
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	ID READ
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	ID REGIST
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Touch Sensor Unlock Function Setting
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	IGN/ACC Battery Saver
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Remote Engine Starter
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Answer Back I-Key Lock Unlock
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Answerback I-Key Lock Unlock
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Answerback Keyless Lock Unlock
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Welcome Light Op Set
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Answer Back
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Retractable Mirror Set
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Confirm Key Fob ID
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Lock/Unlock By I-Key
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Engine Start By I-Key
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Trunk/Glass Hatch Open
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Intelligent Key Link Set
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Short Cranking Output
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Auto Lock Set
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Inside ANT Diagnosis
DFNISSAN	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Reset Setting Value
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Read Fault Code	
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Clear Fault Code	
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Read Data Stream	
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Module Information	
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Actuation Test	Rear Defogger
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Actuation Test	Int Lamp
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Actuation Test	Battery Saver
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Actuation Test	Vehicle Security Horn
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Actuation Test	Tail Lamp
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Actuation Test	FR FOG Lamp
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Actuation Test	ILL DIM Signal
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Actuation Test	Head Lamp
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Actuation Test	Cornering Lamp
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Actuation Test	Head Lamp Washer
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Actuation Test	FR Wiper
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Actuation Test	Door Lock
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Actuation Test	Flasher
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Actuation Test	Theft IND
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Actuation Test	BRAKE SW
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Actuation Test	OIL Pressure SW
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Actuation Test	Trunk/Glass Hatch
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Actuation Test	IGN KEY WARN ALM
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Actuation Test	Light Warn Alm
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Actuation Test	PANIC ALARM
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Special Function	Set R-DEF Timer
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Special Function	Set I/L D-Unlock Intcon
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Special Function	Room Lamp On Time Set
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Special Function	Room Lamp Off Time Set
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Special Function	Room Lamp Timer Set
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Special Function	Room Lamp BAT SAV SET
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Special Function	Security Alarm Set(Siren)
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Special Function	Battery Saver Set
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Special Function	Custom A/Light Setting
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Special Function	Wiper Speed Setting
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Special Function	REMO CONT ID REGIST
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Special Function	REMO CONT ID ERASUR
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Special Function	Auto Lock Set
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Special Function	Panic Alarm Set
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Special Function	TRUNK OPEN SET
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Special Function	Reset Setting Value
DFNISSAN	All Mode	Up to 2014	BCM (Body Control Module)	Special Function	Automatic Door Unlock Select
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Read Fault Code	
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Clear Fault Code	
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Read Data Stream	
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Module Information	
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Door Lock
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Super Lock
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Door Lock Ind
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Rear Defogger
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	IGN KEY WARN ALM

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

<b>make</b>	<b>model</b>	<b>year</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Seat Belt Warn Test
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	ID REGIST WARNING
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Light Warn Alm
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Reverse Warning
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	RUN FLAT/T WARN BUZZER
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Key Reminder Warn
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	FR FOG Lamp
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	RR FOG Lamp
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	STOP LAMP 1
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	STOP LAMP 2
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	STOP LAMP 3
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Daytime Running Light
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	ILL DIM Signal
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Int Lamp
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	FR Wiper
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	RR Wiper
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Head Lamp Washer
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	PTC RELAY-1
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	PTC RELAY-2
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	PTC RELAY-3
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	A/C Indicator
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Outside Buzzer
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Inside Buzzer
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	INDICATOR
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Flasher
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Horn
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	IGN CONT-2
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	MIRROR+5
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Engine SW Illumi
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Push Switch Indicator
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	ENGINE START REQUEST
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	IGNITION RELAY
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	starter cut relay
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	ENGINE START
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Trunk/Back Door
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Retractable Mirror
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	REVERSE LAMP TEST
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	AS SEAT LAMP TEST
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	KEYFOB P/W TEST
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	AUTO ACC 2
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	AUTOMATIC BACK DOOR
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	AUTO ACC 1
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Trunk/Luggage Lamp Test
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Theft IND
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Battery Saver
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	SIREN
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Vehicle Security Horn
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Head Lamp
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	OIL Pressure SW
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	BRAKE SW
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Warning Lamp
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Door Lock-Unlock Set
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Auto Lock Type
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Auto Lock Function
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Auto Unlock Function
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Signature Light Setting
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Set R-DEF Timer
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Custom A/Light Setting
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	ILL Delay Set
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Twilight On
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Wiper Link
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Daytime Running Light Setting
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Set I/L D-Unlock Intcon
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	FOG Lamp Override
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Spicy Brightness Setting
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Wiper Speed Setting
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Rain Sensor
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	FR RR DRIP
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Rear Wiper Link With Reverse Setting
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	3-TIME Flasher Setting
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Inside ANT Diagnosis
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Lock/Unlock By I-Key
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Engine Start By I-Key
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Trunk/Glass Hatch Open
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Auto Lock Set
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	IGN/ACC Battery Saver
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Short Cranking Output
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Answer Back

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

<b>make</b>	<b>model</b>	<b>year</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Answer Back I-Key Lock Unlock
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Answerback I-Key Lock Unlock
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Answerback Keyless Lock Unlock
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Welcome Light Op Set
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Reset Setting Value
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Confirm Dongle ID
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	SIREN SET
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Security Alarm SET
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Auto Acc Fnctn (Audio/Nav Set After Ign Off)
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Autofold function
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Theft ALM TRG
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Confirm TCU ID
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Remote Engine Starter
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Touch Sensor Unlock Function Setting
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Intelligent Key Link Set
DFNISSAN	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	(TBD)ShBW_ID_REGISTRATION FINISHED
DFNISSAN	All Mode	2016 - 2016	BCM (Body Control Module)	Read Fault Code	
DFNISSAN	All Mode	2016 - 2016	BCM (Body Control Module)	Clear Fault Code	
DFNISSAN	All Mode	2016 - 2016	BCM (Body Control Module)	Read Data Stream	
DFNISSAN	All Mode	2016 - 2016	BCM (Body Control Module)	Module Information	
DFNISSAN	All Mode	2016 - 2016	BCM (Body Control Module)	Actuation Test	Check left front turn signal lamp
DFNISSAN	All Mode	2016 - 2016	BCM (Body Control Module)	Actuation Test	Check eco start stop function additional battery relay
DFNISSAN	All Mode	2016 - 2016	BCM (Body Control Module)	Actuation Test	Check right front turn signal lamp
DFNISSAN	All Mode	2016 - 2016	BCM (Body Control Module)	Actuation Test	Check right rear turn signal lamp
DFNISSAN	All Mode	2016 - 2016	BCM (Body Control Module)	Actuation Test	Check left rear turn signal lamp
DFNISSAN	All Mode	2016 - 2016	BCM (Body Control Module)	Actuation Test	Check Right Daytime Running Light Headlamp
DFNISSAN	All Mode	2016 - 2016	BCM (Body Control Module)	Actuation Test	Check Left Daytime Running Light Headlamp
DFNISSAN	All Mode	2016 - 2016	BCM (Body Control Module)	Actuation Test	Left front lamp unit
DFNISSAN	All Mode	2016 - 2016	BCM (Body Control Module)	Actuation Test	Centre brake lamp
DFNISSAN	All Mode	2016 - 2016	BCM (Body Control Module)	Actuation Test	License Plate Lamp
DFNISSAN	All Mode	2016 - 2016	BCM (Body Control Module)	Actuation Test	Left rear fog lamp
DFNISSAN	All Mode	2016 - 2016	BCM (Body Control Module)	Actuation Test	Windshield washer system pump
DFNISSAN	All Mode	2016 - 2016	BCM (Body Control Module)	Actuation Test	Headlamp clean system pump
DFNISSAN	All Mode	2016 - 2016	BCM (Body Control Module)	Actuation Test	Tank cap central locking actuator
DFNISSAN	All Mode	2016 - 2016	BCM (Body Control Module)	Actuation Test	Side marker lamp
DFNISSAN	All Mode	2016 - 2016	BCM (Body Control Module)	Actuation Test	Inner left rear lamp unit
DFNISSAN	All Mode	2016 - 2016	BCM (Body Control Module)	Actuation Test	Left rear power window
DFNISSAN	All Mode	2016 - 2016	BCM (Body Control Module)	Actuation Test	Right rear lamp unit
DFNISSAN	All Mode	2016 - 2016	BCM (Body Control Module)	Actuation Test	Front turn signal lamp
DFNISSAN	All Mode	2016 - 2016	BCM (Body Control Module)	Actuation Test	Erase alarm sources
DFNISSAN	All Mode	2016 - 2016	BCM (Body Control Module)	Actuation Test	Circuit 30G Relay
DFNISSAN	All Mode	2016 - 2016	BCM (Body Control Module)	Actuation Test	Rear fuse box
DFNISSAN	All Mode	2016 - 2016	BCM (Body Control Module)	Actuation Test	Engine compartment fuse and relay module
DFNISSAN	All Mode	2016 - 2016	BCM (Body Control Module)	Actuation Test	Symbol illumination
DFNISSAN	All Mode	2016 - 2016	BCM (Body Control Module)	Actuation Test	Activate demo mode of exterior lamp
DFNISSAN	All Mode	2016 - 2016	BCM (Body Control Module)	Actuation Test	Rear Doors
DFNISSAN	All Mode	2016 - 2016	BCM (Body Control Module)	Actuation Test	Liftgate central locking motor
DFNISSAN	All Mode	2016 - 2016	BCM (Body Control Module)	Actuation Test	Right rear power window
DFNISSAN	All Mode	2016 - 2016	BCM (Body Control Module)	Actuation Test	Running board courtesy light
DFNISSAN	All Mode	2016 - 2016	BCM (Body Control Module)	Actuation Test	Illuminated door sill moldings
DFNISSAN	All Mode	2016 - 2016	BCM (Body Control Module)	Actuation Test	Right front lamp unit
DFNISSAN	All Mode	2016 - 2016	BCM (Body Control Module)	Actuation Test	Left rear lamp unit
DFNISSAN	All Mode	2016 - 2016	BCM (Body Control Module)	Actuation Test	Footwell lamp
DFNISSAN	All Mode	2016 - 2016	BCM (Body Control Module)	Actuation Test	Back-Up Lamp
DFNISSAN	All Mode	2016 - 2016	BCM (Body Control Module)	Actuation Test	Trunk Lamp
DFNISSAN	All Mode	2016 - 2016	BCM (Body Control Module)	Actuation Test	Spray nozzle hose heater
DFNISSAN	All Mode	2016 - 2016	BCM (Body Control Module)	Actuation Test	Inner right rear lamp unit
DFNISSAN	All Mode	2016 - 2016	BCM (Body Control Module)	Actuation Test	Daytime Running Light
DFNISSAN	All Mode	2016 - 2016	BCM (Body Control Module)	Actuation Test	Windscreen Wiper

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

<b>make</b>	<b>model</b>	<b>year</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
DFNISSAN	All Mode	2016 - 2016	BCM (Body Control Module)	Actuation Test	Last data record
DFNISSAN	All Mode	2016 - 2016	BCM (Body Control Module)	Actuation Test	Second from last data record
DFNISSAN	All Mode	2016 - 2016	BCM (Body Control Module)	Actuation Test	Third from last data record
DFNISSAN	All Mode	2016 - 2016	BCM (Body Control Module)	Actuation Test	Fourth from last data record
DFNISSAN	All Mode	2016 - 2016	BCM (Body Control Module)	Actuation Test	Fifth from last data record
DFNISSAN	All Mode	2016 - 2016	BCM (Body Control Module)	Actuation Test	Sixth to last data record
DFNISSAN	All Mode	2016 - 2016	BCM (Body Control Module)	Actuation Test	Seventh to last data record
DFNISSAN	All Mode	2016 - 2016	BCM (Body Control Module)	Actuation Test	Eighth to last data record
DFNISSAN	All Mode	2016 - 2016	BCM (Body Control Module)	Actuation Test	Ninth to last data record
DFNISSAN	All Mode	2016 - 2016	BCM (Body Control Module)	Actuation Test	Tenth to last data record
DFNISSAN	All Mode	2016 - 2016	BCM (Body Control Module)	Actuation Test	Front fog lamp
DFNISSAN	All Mode	2016 - 2016	BCM (Body Control Module)	Actuation Test	Door handle illumination rear doors
DFNISSAN	All Mode	2016 - 2016	BCM (Body Control Module)	Actuation Test	Ambiance illumination of rear door
DFNISSAN	All Mode	2016 - 2016	BCM (Body Control Module)	Actuation Test	Interior lamp
DFNISSAN	All Mode	2016 - 2016	BCM (Body Control Module)	Actuation Test	Mirror lamps of sun visors
DFNISSAN	All Mode	2016 - 2016	BCM (Body Control Module)	Actuation Test	Reading lamp actuation
DFNISSAN	All Mode	2016 - 2016	BCM (Body Control Module)	Actuation Test	Rear lamp actuation
DFNISSAN	All Mode	2016 - 2016	BCM (Body Control Module)	Actuation Test	Check component M10 5 RL door power window motor
DFNISSAN	All Mode	2016 - 2016	BCM (Body Control Module)	Actuation Test	Check component M10 6 RR door power window motor
DFNISSAN	All Mode	2016 - 2016	BCM (Body Control Module)	Actuation Test	Left rear power window actual value
DFNISSAN	All Mode	2016 - 2016	BCM (Body Control Module)	Actuation Test	Right rear power window actual value
DFNISSAN	All Mode	2016 - 2016	BCM (Body Control Module)	Actuation Test	Confirmation of battery change
DFNISSAN	All Mode	2016 - 2016	BCM (Body Control Module)	Special Function	Replace decoupling relay
DFNISSAN	All Mode	2016 - 2016	BCM (Body Control Module)	Special Function	Replace eco start stop function add battery
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Read Fault Code	
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Clear Fault Code	
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Read Data Stream	
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Module Information	
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Special Function	REMO CONT ID CONFIR
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Special Function	REMO CONT ID REGIST
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Special Function	REMO CONT ID ERASUR
DFNISSAN	All Mode	Up to 2009	BCM (Body Control Module)	Special Function	
DFNISSAN	All Mode	Up to 2016	4WAS (MAIN) /RAS/HICAS	Read Fault Code	
DFNISSAN	All Mode	Up to 2016	4WAS (MAIN) /RAS/HICAS	Clear Fault Code	
DFNISSAN	All Mode	Up to 2016	4WAS (MAIN) /RAS/HICAS	Read Data Stream	
DFNISSAN	All Mode	Up to 2016	4WAS (MAIN) /RAS/HICAS	Module Information	
DFNISSAN	All Mode	Up to 2016	4WAS (MAIN) /RAS/HICAS	Actuation Test	SELF DIAGNOSTIC MODE
DFNISSAN	All Mode	2008 - 2016	4WAS (MAIN) /RAS/HICAS	Read Fault Code	
DFNISSAN	All Mode	2008 - 2016	4WAS (MAIN) /RAS/HICAS	Clear Fault Code	
DFNISSAN	All Mode	2008 - 2016	4WAS (MAIN) /RAS/HICAS	Read Data Stream	
DFNISSAN	All Mode	2008 - 2016	4WAS (MAIN) /RAS/HICAS	Module Information	
DFNISSAN	All Mode	2008 - 2016	4WAS (MAIN) /RAS/HICAS	Actuation Test	SELF DIAGNOSTIC MODE
DFNISSAN	All Mode	2009 - 2016	4WAS (MAIN) /RAS/HICAS	Read Fault Code	
DFNISSAN	All Mode	2009 - 2016	4WAS (MAIN) /RAS/HICAS	Clear Fault Code	
DFNISSAN	All Mode	2009 - 2016	4WAS (MAIN) /RAS/HICAS	Read Data Stream	
DFNISSAN	All Mode	2009 - 2016	4WAS (MAIN) /RAS/HICAS	Module Information	
DFNISSAN	All Mode	2009 - 2016	4WAS (MAIN) /RAS/HICAS	Actuation Test	SELF DIAGNOSTIC MODE
DFNISSAN	All Mode	Up to 2014	4WAS (MAIN) /RAS/HICAS	Read Fault Code	
DFNISSAN	All Mode	Up to 2014	4WAS (MAIN) /RAS/HICAS	Clear Fault Code	
DFNISSAN	All Mode	Up to 2014	4WAS (MAIN) /RAS/HICAS	Read Data Stream	
DFNISSAN	All Mode	Up to 2014	4WAS (MAIN) /RAS/HICAS	Module Information	
DFNISSAN	All Mode	Up to 2014	4WAS (MAIN) /RAS/HICAS	Actuation Test	
DFNISSAN	All Mode	Up to 2014	4WAS (MAIN) /RAS/HICAS	Read Fault Code	
DFNISSAN	All Mode	Up to 2014	4WAS (MAIN) /RAS/HICAS	Clear Fault Code	
DFNISSAN	All Mode	Up to 2014	4WAS (MAIN) /RAS/HICAS	Read Data Stream	
DFNISSAN	All Mode	Up to 2014	4WAS (MAIN) /RAS/HICAS	Module Information	
DFNISSAN	All Mode	Up to 2014	4WAS (MAIN) /RAS/HICAS	Actuation Test	
DFNISSAN	All Mode	Up to 2014	4WAS (MAIN) /RAS/HICAS	Read Fault Code	
DFNISSAN	All Mode	Up to 2014	4WAS (MAIN) /RAS/HICAS	Clear Fault Code	
DFNISSAN	All Mode	Up to 2014	4WAS (MAIN) /RAS/HICAS	Read Data Stream	
DFNISSAN	All Mode	Up to 2014	4WAS (MAIN) /RAS/HICAS	Module Information	
DFNISSAN	All Mode	Up to 2014	4WAS (MAIN) /RAS/HICAS	Actuation Test	
DFNISSAN	All Mode	Up to 2016	Sonar	Read Fault Code	
DFNISSAN	All Mode	Up to 2016	Sonar	Clear Fault Code	
DFNISSAN	All Mode	Up to 2016	Sonar	Read Data Stream	
DFNISSAN	All Mode	Up to 2016	Sonar	Read Freeze Frame	
DFNISSAN	All Mode	Up to 2016	Sonar	Module Information	
DFNISSAN	All Mode	Up to 2016	Sonar	Actuation Test	BUZZER
DFNISSAN	All Mode	Up to 2016	Sonar	Actuation Test	CANCEL SW IND
DFNISSAN	All Mode	Up to 2016	Sonar	Actuation Test	SONAR SENSOR



**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

<b>make</b>	<b>model</b>	<b>year</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
DFNISSAN	All Mode	Up to 2016	Sonar	Actuation Test	PSM SONAR SENSOR
DFNISSAN	All Mode	Up to 2016	Sonar	Actuation Test	DISPLAY CONTROL
DFNISSAN	All Mode	Up to 2016	Sonar	Special Function	Corner Sen Distance Set
DFNISSAN	All Mode	Up to 2016	Sonar	Special Function	Center Sen Distance Set
DFNISSAN	All Mode	Up to 2016	Sonar	Special Function	Volume Setting
DFNISSAN	All Mode	Up to 2016	Sonar	Special Function	Trailer Hitch Mode
DFNISSAN	All Mode	Up to 2016	Sonar	Special Function	Parking Width Level Setting
DFNISSAN	All Mode	Up to 2016	Sonar	Special Function	TIRE DIAMETER ADJUSTMENT
DFNISSAN	All Mode	Up to 2017	Sonar	Read Fault Code	
DFNISSAN	All Mode	Up to 2017	Sonar	Clear Fault Code	
DFNISSAN	All Mode	Up to 2017	Sonar	Read Data Stream	
DFNISSAN	All Mode	Up to 2017	Sonar	Module Information	
DFNISSAN	All Mode	Up to 2017	Sonar	Actuation Test	REAR BUZZER
DFNISSAN	All Mode	Up to 2017	Sonar	Actuation Test	FRONT BUZZER
DFNISSAN	All Mode	Up to 2017	Sonar	Actuation Test	LED
DFNISSAN	All Mode	Up to 2017	Sonar	Special Function	Volume Setting
DFNISSAN	All Mode	Up to 2017	Sonar	Special Function	Trailer hitch detection range adjustment
DFNISSAN	All Mode	Up to 2017	Sonar	Read Fault Code	
DFNISSAN	All Mode	Up to 2017	Sonar	Clear Fault Code	
DFNISSAN	All Mode	Up to 2017	Sonar	Read Data Stream	
DFNISSAN	All Mode	Up to 2017	Sonar	Module Information	
DFNISSAN	All Mode	Up to 2017	Sonar	Actuation Test	REAR BUZZER
DFNISSAN	All Mode	Up to 2017	Sonar	Actuation Test	LED
DFNISSAN	All Mode	Up to 2017	Sonar	Actuation Test	FRONT BUZZER
DFNISSAN	All Mode	Up to 2017	Sonar	Special Function	Volume Setting
DFNISSAN	All Mode	Up to 2017	Sonar	Special Function	Trailer hitch detection range adjustment
DFNISSAN	All Mode	Up to 2016	Sonar	Read Fault Code	
DFNISSAN	All Mode	Up to 2016	Sonar	Clear Fault Code	
DFNISSAN	All Mode	Up to 2016	Sonar	Read Data Stream	
DFNISSAN	All Mode	Up to 2016	Sonar	Module Information	
DFNISSAN	All Mode	Up to 2016	Sonar	Actuation Test	REAR BUZZER
DFNISSAN	All Mode	Up to 2016	Sonar	Actuation Test	LED
DFNISSAN	All Mode	Up to 2016	Sonar	Actuation Test	FRONT BUZZER
DFNISSAN	All Mode	Up to 2016	Sonar	Special Function	Volume Setting
DFNISSAN	All Mode	Up to 2016	Sonar	Special Function	Trailer hitch detection range adjustment
DFNISSAN	All Mode	Up to 2016	Sonar	Read Fault Code	
DFNISSAN	All Mode	Up to 2016	Sonar	Clear Fault Code	
DFNISSAN	All Mode	Up to 2016	Sonar	Read Data Stream	
DFNISSAN	All Mode	Up to 2016	Sonar	Module Information	
DFNISSAN	All Mode	Up to 2016	Sonar	Actuation Test	REAR BUZZER
DFNISSAN	All Mode	Up to 2016	Sonar	Actuation Test	LED
DFNISSAN	All Mode	Up to 2016	Sonar	Actuation Test	FRONT BUZZER
DFNISSAN	All Mode	Up to 2016	Sonar	Special Function	Volume Setting
DFNISSAN	All Mode	Up to 2016	Sonar	Special Function	Trailer hitch detection range adjustment
DFNISSAN	All Mode	2015 - 2015	Sonar	Read Fault Code	
DFNISSAN	All Mode	2015 - 2015	Sonar	Clear Fault Code	
DFNISSAN	All Mode	2015 - 2015	Sonar	Read Data Stream	
DFNISSAN	All Mode	2015 - 2015	Sonar	Module Information	
DFNISSAN	All Mode	2015 - 2015	Sonar	Special Function	Volume Setting
DFNISSAN	All Mode	Up to 2016	Sonar	Read Fault Code	
DFNISSAN	All Mode	Up to 2016	Sonar	Clear Fault Code	
DFNISSAN	All Mode	Up to 2016	Sonar	Read Data Stream	
DFNISSAN	All Mode	Up to 2016	Sonar	Module Information	
DFNISSAN	All Mode	Up to 2016	Sonar	Actuation Test	BUZZER
DFNISSAN	All Mode	Up to 2016	Sonar	Actuation Test	CANCEL SW IND
DFNISSAN	All Mode	Up to 2016	Sonar	Actuation Test	SONAR SENSOR
DFNISSAN	All Mode	Up to 2016	Sonar	Special Function	Corner Sen Distance Set
DFNISSAN	All Mode	Up to 2016	Sonar	Special Function	Volume Setting
DFNISSAN	All Mode	Up to 2016	Sonar	Special Function	Trailer Hitch Mode
DFNISSAN	All Mode	Up to 2015	Sonar	Read Fault Code	
DFNISSAN	All Mode	Up to 2015	Sonar	Clear Fault Code	
DFNISSAN	All Mode	Up to 2015	Sonar	Read Data Stream	
DFNISSAN	All Mode	Up to 2015	Sonar	Module Information	
DFNISSAN	All Mode	Up to 2015	Sonar	Actuation Test	BUZZER
DFNISSAN	All Mode	Up to 2015	Sonar	Actuation Test	CANCEL SW IND
DFNISSAN	All Mode	Up to 2015	Sonar	Actuation Test	SONAR SENSOR
DFNISSAN	All Mode	Up to 2015	Sonar	Special Function	Corner Sen Distance Set
DFNISSAN	All Mode	Up to 2015	Sonar	Special Function	Center Sen Distance Set
DFNISSAN	All Mode	Up to 2015	Sonar	Special Function	Volume Setting
DFNISSAN	All Mode	Up to 2015	Sonar	Special Function	Trailer Hitch Mode
DFNISSAN	All Mode	2008 - 2016	Sonar	Read Fault Code	
DFNISSAN	All Mode	2008 - 2016	Sonar	Clear Fault Code	
DFNISSAN	All Mode	2008 - 2016	Sonar	Read Data Stream	
DFNISSAN	All Mode	2008 - 2016	Sonar	Module Information	
DFNISSAN	All Mode	2008 - 2016	Sonar	Actuation Test	BUZZER
DFNISSAN	All Mode	2008 - 2016	Sonar	Actuation Test	CANCEL SW IND

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
DFNISSAN	All Mode	2008 - 2016	Sonar	Actuation Test	SONAR SENSOR
DFNISSAN	All Mode	2008 - 2016	Sonar	Special Function	Corner Sen Distance Set
DFNISSAN	All Mode	2008 - 2016	Sonar	Special Function	Center Sen Distance Set
DFNISSAN	All Mode	2008 - 2016	Sonar	Special Function	Volume Setting
DFNISSAN	All Mode	2008 - 2016	Sonar	Special Function	Trailer Hitch Mode
DFNISSAN	All Mode	2008 - 2016	Sonar	Read Fault Code	
DFNISSAN	All Mode	2008 - 2016	Sonar	Clear Fault Code	
DFNISSAN	All Mode	2008 - 2016	Sonar	Read Data Stream	
DFNISSAN	All Mode	2008 - 2016	Sonar	Module Information	
DFNISSAN	All Mode	2008 - 2016	Sonar	Actuation Test	BUZZER
DFNISSAN	All Mode	2008 - 2016	Sonar	Actuation Test	CANCEL SW IND
DFNISSAN	All Mode	2008 - 2016	Sonar	Actuation Test	SONAR SENSOR
DFNISSAN	All Mode	2008 - 2016	Sonar	Special Function	Corner Sen Distance Set
DFNISSAN	All Mode	2008 - 2016	Sonar	Special Function	Center Sen Distance Set
DFNISSAN	All Mode	2008 - 2016	Sonar	Special Function	Volume Setting
DFNISSAN	All Mode	2008 - 2016	Sonar	Special Function	Trailer Hitch Mode
DFNISSAN	All Mode	Up to 2016	Lane Camera	Read Fault Code	
DFNISSAN	All Mode	Up to 2016	Lane Camera	Clear Fault Code	
DFNISSAN	All Mode	Up to 2016	Lane Camera	Read Data Stream	
DFNISSAN	All Mode	Up to 2016	Lane Camera	Module Information	
DFNISSAN	All Mode	Up to 2016	Lane Camera	Actuation Test	BUZZER DRIVE
DFNISSAN	All Mode	Up to 2016	Lane Camera	Actuation Test	SYSTEM ON LAMP DRIVE
DFNISSAN	All Mode	Up to 2016	Lane Camera	Actuation Test	INDICATOR LAMP DRIVE
DFNISSAN	All Mode	Up to 2016	Lane Camera	Special Function	AUTO AIM
DFNISSAN	All Mode	2009 - 2016	Lane Camera	Read Fault Code	
DFNISSAN	All Mode	2009 - 2016	Lane Camera	Clear Fault Code	
DFNISSAN	All Mode	2009 - 2016	Lane Camera	Read Data Stream	
DFNISSAN	All Mode	2009 - 2016	Lane Camera	Module Information	
DFNISSAN	All Mode	2009 - 2016	Lane Camera	Actuation Test	BUZZER DRIVE
DFNISSAN	All Mode	2009 - 2016	Lane Camera	Actuation Test	LDW ON IND
DFNISSAN	All Mode	2009 - 2016	Lane Camera	Actuation Test	LANE DEPARTURE W/L
DFNISSAN	All Mode	2009 - 2016	Lane Camera	Actuation Test	LDP ON IND
DFNISSAN	All Mode	2009 - 2016	Lane Camera	Special Function	AUTO AIM
DFNISSAN	All Mode	2009 - 2016	Lane Camera	Special Function	Aim Check
DFNISSAN	All Mode	2009 - 2016	Lane Camera	Special Function	Cause Of Auto-Cancel
DFNISSAN	All Mode	2009 - 2017	Lane Camera	Read Fault Code	
DFNISSAN	All Mode	2009 - 2017	Lane Camera	Clear Fault Code	
DFNISSAN	All Mode	2009 - 2017	Lane Camera	Read Data Stream	
DFNISSAN	All Mode	2009 - 2017	Lane Camera	Module Information	
DFNISSAN	All Mode	2009 - 2017	Lane Camera	Actuation Test	LDP ON IND
DFNISSAN	All Mode	2009 - 2017	Lane Camera	Actuation Test	LANE DEPARTURE W/L
DFNISSAN	All Mode	2009 - 2017	Lane Camera	Actuation Test	LDW ON IND
DFNISSAN	All Mode	2009 - 2017	Lane Camera	Actuation Test	BUZZER DRIVE
DFNISSAN	All Mode	2009 - 2017	Lane Camera	Special Function	AUTO AIM
DFNISSAN	All Mode	2009 - 2017	Lane Camera	Special Function	Aim Check
DFNISSAN	All Mode	2009 - 2017	Lane Camera	Special Function	Cause Of Auto-Cancel
DFNISSAN	All Mode	2014 - 2015	Lane Camera	Read Fault Code	
DFNISSAN	All Mode	2014 - 2015	Lane Camera	Clear Fault Code	
DFNISSAN	All Mode	2014 - 2015	Lane Camera	Read Data Stream	
DFNISSAN	All Mode	2014 - 2015	Lane Camera	Module Information	
DFNISSAN	All Mode	2014 - 2015	Lane Camera	Special Function	AUTO AIM
DFNISSAN	SYLPHY	2009	Lane Camera	Read Fault Code	
DFNISSAN	SYLPHY	2009	Lane Camera	Clear Fault Code	
DFNISSAN	SYLPHY	2009	Lane Camera	Read Data Stream	
DFNISSAN	SYLPHY	2009	Lane Camera	Module Information	
DFNISSAN	SYLPHY	2009	Lane Camera	Read Fault Code	
DFNISSAN	SYLPHY	2009	Lane Camera	Clear Fault Code	
DFNISSAN	SYLPHY	2009	Lane Camera	Read Data Stream	
DFNISSAN	SYLPHY	2009	Lane Camera	Module Information	
DFNISSAN	SYLPHY	2009	Lane Camera	Special Function	AUTO AIM
DFNISSAN	SYLPHY	2009	Lane Camera	Special Function	Aim Check
DFNISSAN	All Mode	Up to 2009	Lane Camera	Read Fault Code	
DFNISSAN	All Mode	Up to 2009	Lane Camera	Clear Fault Code	
DFNISSAN	All Mode	Up to 2009	Lane Camera	Read Data Stream	
DFNISSAN	All Mode	Up to 2009	Lane Camera	Module Information	
DFNISSAN	All Mode	2007 - 2017	AFS (Adaptive Front Lighting System)	Read Fault Code	
DFNISSAN	All Mode	2007 - 2017	AFS (Adaptive Front Lighting System)	Clear Fault Code	
DFNISSAN	All Mode	2007 - 2017	AFS (Adaptive Front Lighting System)	Read Data Stream	
DFNISSAN	All Mode	2007 - 2017	AFS (Adaptive Front Lighting System)	Module Information	
DFNISSAN	All Mode	2007 - 2017	AFS (Adaptive Front Lighting System)	Actuation Test	LOW BEAM TEST RIGHT
DFNISSAN	All Mode	2007 - 2017	AFS (Adaptive Front Lighting System)	Actuation Test	LOW BEAM TEST LEFT
DFNISSAN	All Mode	2007 - 2017	AFS (Adaptive Front Lighting System)	Actuation Test	LEVELIZER TEST
DFNISSAN	All Mode	2007 - 2017	AFS (Adaptive Front Lighting System)	Special Function	ST ANG Sen Adjustment
DFNISSAN	All Mode	2007 - 2017	AFS (Adaptive Front Lighting System)	Special Function	Levelizer Adjustment
DFNISSAN	All Mode	2006 - 2010	AFS (Adaptive Front Lighting System)	Read Fault Code	
DFNISSAN	All Mode	2006 - 2010	AFS (Adaptive Front Lighting System)	Clear Fault Code	
DFNISSAN	All Mode	2006 - 2010	AFS (Adaptive Front Lighting System)	Read Data Stream	
DFNISSAN	All Mode	2006 - 2010	AFS (Adaptive Front Lighting System)	Module Information	
DFNISSAN	All Mode	2006 - 2010	AFS (Adaptive Front Lighting System)	Actuation Test	Low Beam Test Right
DFNISSAN	All Mode	2006 - 2010	AFS (Adaptive Front Lighting System)	Actuation Test	LOW BEAM TEST LEFT

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

<b>make</b>	<b>model</b>	<b>year</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
DFNISSAN	All Mode	2006 - 2010	AFS (Adaptive Front Lighting System)	Special Function	ST ANG Sen Adjustment
DFNISSAN	All Mode	2008 - 2017	AFS (Adaptive Front Lighting System)	Read Fault Code	
DFNISSAN	All Mode	2008 - 2017	AFS (Adaptive Front Lighting System)	Clear Fault Code	
DFNISSAN	All Mode	2008 - 2017	AFS (Adaptive Front Lighting System)	Read Data Stream	
DFNISSAN	All Mode	2008 - 2017	AFS (Adaptive Front Lighting System)	Module Information	
DFNISSAN	All Mode	2008 - 2017	AFS (Adaptive Front Lighting System)	Actuation Test	LOW BEAM TEST RIGHT
DFNISSAN	All Mode	2008 - 2017	AFS (Adaptive Front Lighting System)	Actuation Test	LOW BEAM TEST LEFT
DFNISSAN	All Mode	2008 - 2017	AFS (Adaptive Front Lighting System)	Actuation Test	LEVELIZER TEST
DFNISSAN	All Mode	2008 - 2017	AFS (Adaptive Front Lighting System)	Special Function	ST ANG Sen Adjustment
DFNISSAN	All Mode	2008 - 2017	AFS (Adaptive Front Lighting System)	Special Function	Levelizer Adjustment
DFNISSAN	All Mode	Up to 2009	AFS (Adaptive Front Lighting System)	Read Fault Code	
DFNISSAN	All Mode	Up to 2009	AFS (Adaptive Front Lighting System)	Clear Fault Code	
DFNISSAN	All Mode	Up to 2009	AFS (Adaptive Front Lighting System)	Read Data Stream	
DFNISSAN	All Mode	Up to 2009	AFS (Adaptive Front Lighting System)	Module Information	
DFNISSAN	All Mode	Up to 2009	AFS (Adaptive Front Lighting System)	Special Function	ST ANG Sen Adjustment
DFNISSAN	All Mode	2014 - 2017	AFS (Adaptive Front Lighting System)	Read Fault Code	
DFNISSAN	All Mode	2014 - 2017	AFS (Adaptive Front Lighting System)	Clear Fault Code	
DFNISSAN	All Mode	2014 - 2017	AFS (Adaptive Front Lighting System)	Read Data Stream	
DFNISSAN	All Mode	2014 - 2017	AFS (Adaptive Front Lighting System)	Module Information	
DFNISSAN	All Mode	2012 - 2016	Auto Slide Door Right	Read Fault Code	
DFNISSAN	All Mode	2012 - 2016	Auto Slide Door Right	Clear Fault Code	
DFNISSAN	All Mode	2012 - 2016	Auto Slide Door Right	Read Data Stream	
DFNISSAN	All Mode	2012 - 2016	Auto Slide Door Right	Read Freeze Frame	
DFNISSAN	All Mode	2012 - 2016	Auto Slide Door Right	Module Information	
DFNISSAN	All Mode	2012 - 2016	Auto Slide Door Right	Actuation Test	CLUTCH
DFNISSAN	All Mode	2008 - 2017	CAN Gateway	Read Fault Code	
DFNISSAN	All Mode	2008 - 2017	CAN Gateway	Clear Fault Code	
DFNISSAN	All Mode	2008 - 2017	CAN Gateway	Read Freeze Frame	
DFNISSAN	All Mode	2008 - 2017	CAN Gateway	Module Information	
DFNISSAN	All Mode	2013 - 2017	CAN Gateway	Read Fault Code	
DFNISSAN	All Mode	2013 - 2017	CAN Gateway	Clear Fault Code	
DFNISSAN	All Mode	2013 - 2017	CAN Gateway	Read Data Stream	
DFNISSAN	All Mode	2013 - 2017	CAN Gateway	Module Information	
DFNISSAN	All Mode	2016 - 2016	CAN Gateway	Read Fault Code	
DFNISSAN	All Mode	2016 - 2016	CAN Gateway	Clear Fault Code	
DFNISSAN	All Mode	2016 - 2016	CAN Gateway	Read Data Stream	
DFNISSAN	All Mode	2016 - 2016	CAN Gateway	Module Information	
DFNISSAN	All Mode	2011 - 2016	Shift	Read Fault Code	
DFNISSAN	All Mode	2011 - 2016	Shift	Clear Fault Code	
DFNISSAN	All Mode	2011 - 2016	Shift	Read Data Stream	
DFNISSAN	All Mode	2011 - 2016	Shift	Read Freeze Frame	
DFNISSAN	All Mode	2011 - 2016	Shift	Module Information	
DFNISSAN	All Mode	2011 - 2016	Shift	Special Function	P Position Learning Value Clear
DFNISSAN	All Mode	2016 - 2016	Shift	Read Fault Code	
DFNISSAN	All Mode	2016 - 2016	Shift	Clear Fault Code	
DFNISSAN	All Mode	2016 - 2016	Shift	Read Data Stream	
DFNISSAN	All Mode	2016 - 2016	Shift	Module Information	
DFNISSAN	All Mode	2011 - 2013	EV/HEV	Read Fault Code	
DFNISSAN	All Mode	2011 - 2013	EV/HEV	Clear Fault Code	
DFNISSAN	All Mode	2011 - 2013	EV/HEV	Read Data Stream	
DFNISSAN	All Mode	2011 - 2013	EV/HEV	Module Information	
DFNISSAN	All Mode	2011 - 2013	EV/HEV	Actuation Test	PLUG IN INDICATOR
DFNISSAN	All Mode	2011 - 2013	EV/HEV	Actuation Test	CHARGE STAT INDICATOR 1
DFNISSAN	All Mode	2011 - 2013	EV/HEV	Actuation Test	CHARGE STAT INDICATOR 2
DFNISSAN	All Mode	2011 - 2013	EV/HEV	Actuation Test	CHARGE STAT INDICATOR 3
DFNISSAN	All Mode	2011 - 2013	EV/HEV	Actuation Test	F/S CHG RLY
DFNISSAN	All Mode	2011 - 2013	EV/HEV	Actuation Test	REVERSE LAMP RLY
DFNISSAN	All Mode	2011 - 2013	EV/HEV	Actuation Test	VOLTAGE CONTROL
DFNISSAN	All Mode	2011 - 2013	EV/HEV	Actuation Test	READY INDICATOR
DFNISSAN	All Mode	2011 - 2013	EV/HEV	Actuation Test	POWER LIMITATION INDICATOR
DFNISSAN	All Mode	2011 - 2013	EV/HEV	Actuation Test	EV SYSTEM W/L
DFNISSAN	All Mode	2011 - 2013	EV/HEV	Actuation Test	12 Battery Charge W/L
DFNISSAN	All Mode	2011 - 2013	EV/HEV	Special Function	HV Batt J/B Data Clear
DFNISSAN	All Mode	2011 - 2013	EV/HEV	Special Function	Specific Dtc Clear
DFNISSAN	All Mode	2011 - 2013	EV/HEV	Special Function	Vin Registration
DFNISSAN	All Mode	2011 - 2013	EV/HEV	Special Function	Saving Data For Replc CPU
DFNISSAN	All Mode	2011 - 2013	EV/HEV	Special Function	Write Data After Replace CPU
DFNISSAN	All Mode	2011 - 2013	EV/HEV	Special Function	Battery Gradual Cap Loss Data Clear
DFNISSAN	All Mode	2013 - 2016	EV/HEV	Read Fault Code	
DFNISSAN	All Mode	2013 - 2016	EV/HEV	Clear Fault Code	
DFNISSAN	All Mode	2013 - 2016	EV/HEV	Read Data Stream	
DFNISSAN	All Mode	2013 - 2016	EV/HEV	Module Information	
DFNISSAN	All Mode	2013 - 2016	EV/HEV	Actuation Test	Inspection Mode 5
DFNISSAN	All Mode	2013 - 2016	EV/HEV	Actuation Test	Inspection Mode 2
DFNISSAN	All Mode	2013 - 2016	EV/HEV	Actuation Test	Engine Cranking
DFNISSAN	All Mode	2013 - 2016	EV/HEV	Actuation Test	WATER PUMP
DFNISSAN	All Mode	2013 - 2016	EV/HEV	Actuation Test	Inspection Mode 3



**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
DFNISSAN	All Mode	2015 - 2015	Auto Back Door	Module Information	
DFNISSAN	All Mode	2015 - 2015	Auto Back Door	Special Function	Reset Auto Back Door Status
DFNISSAN	All Mode	2008 - 2016	4WAS (Front)	Read Fault Code	
DFNISSAN	All Mode	2008 - 2016	4WAS (Front)	Clear Fault Code	
DFNISSAN	All Mode	2008 - 2016	4WAS (Front)	Read Data Stream	
DFNISSAN	All Mode	2008 - 2016	4WAS (Front)	Read Freeze Frame	
DFNISSAN	All Mode	2008 - 2016	4WAS (Front)	Module Information	
DFNISSAN	All Mode	2008 - 2016	4WAS (Front)	Actuation Test	LOCK OPERATION
DFNISSAN	All Mode	2008 - 2016	4WAS (Front)	Actuation Test	SLOW MODE
DFNISSAN	All Mode	2008 - 2016	E-SUS (Electric Suspension)	Read Fault Code	
DFNISSAN	All Mode	2008 - 2016	E-SUS (Electric Suspension)	Clear Fault Code	
DFNISSAN	All Mode	2008 - 2016	E-SUS (Electric Suspension)	Read Data Stream	
DFNISSAN	All Mode	2008 - 2016	E-SUS (Electric Suspension)	Read Freeze Frame	
DFNISSAN	All Mode	2008 - 2016	E-SUS (Electric Suspension)	Module Information	
DFNISSAN	All Mode	2008 - 2016	E-SUS (Electric Suspension)	Actuation Test	FRONT RIGHT ACTUATOR
DFNISSAN	All Mode	2008 - 2016	E-SUS (Electric Suspension)	Actuation Test	FRONT LEFT ACTUATOR
DFNISSAN	All Mode	2008 - 2016	E-SUS (Electric Suspension)	Actuation Test	REAR RIGHT ACTUATOR
DFNISSAN	All Mode	2008 - 2016	E-SUS (Electric Suspension)	Actuation Test	REAR LEFT ACTUATOR
DFNISSAN	All Mode	2008 - 2016	E-SUS (Electric Suspension)	Actuation Test	Mode Lamp
DFNISSAN	All Mode	2010 - 2017	E-SUS (Electric Suspension)	Read Fault Code	
DFNISSAN	All Mode	2010 - 2017	E-SUS (Electric Suspension)	Clear Fault Code	
DFNISSAN	All Mode	2010 - 2017	E-SUS (Electric Suspension)	Read Data Stream	
DFNISSAN	All Mode	2010 - 2017	E-SUS (Electric Suspension)	Module Information	
DFNISSAN	All Mode	2010 - 2017	E-SUS (Electric Suspension)	Actuation Test	COMPRESSOR
DFNISSAN	All Mode	2010 - 2017	E-SUS (Electric Suspension)	Actuation Test	EXHAUST SOLENOID
DFNISSAN	All Mode	2010 - 2017	E-SUS (Electric Suspension)	Actuation Test	Warnmig Lamp
DFNISSAN	All Mode	2010 - 2017	E-SUS (Electric Suspension)	Special Function	Standard Height Level
DFNISSAN	All Mode	2010 - 2017	E-SUS (Electric Suspension)	Special Function	Adjust Height Ini
DFNISSAN	All Mode	2010 - 2017	E-SUS (Electric Suspension)	Special Function	Clear Height INI
DFNISSAN	All Mode	2009 - 2017	Accele Pedal Act	Read Fault Code	
DFNISSAN	All Mode	2009 - 2017	Accele Pedal Act	Clear Fault Code	
DFNISSAN	All Mode	2009 - 2017	Accele Pedal Act	Read Data Stream	
DFNISSAN	All Mode	2009 - 2017	Accele Pedal Act	Module Information	
DFNISSAN	All Mode	2009 - 2017	Accele Pedal Act	Actuation Test	ACCELERATOR PEDAL ACTUATOR TEST1
DFNISSAN	All Mode	2009 - 2017	Accele Pedal Act	Actuation Test	ACCELERATOR PEDAL ACTUATOR TEST2
DFNISSAN	All Mode	2009 - 2017	Accele Pedal Act	Read Fault Code	
DFNISSAN	All Mode	2009 - 2017	Accele Pedal Act	Clear Fault Code	
DFNISSAN	All Mode	2009 - 2017	Accele Pedal Act	Read Data Stream	
DFNISSAN	All Mode	2009 - 2017	Accele Pedal Act	Module Information	
DFNISSAN	All Mode	2009 - 2017	Accele Pedal Act	Actuation Test	ACCELERATOR PEDAL ACTUATOR TEST1
DFNISSAN	All Mode	2009 - 2017	Accele Pedal Act	Actuation Test	ACCELERATOR PEDAL ACTUATOR TEST2
DFNISSAN	All Mode	2012 - 2016	HV Battery	Read Fault Code	
DFNISSAN	All Mode	2012 - 2016	HV Battery	Clear Fault Code	
DFNISSAN	All Mode	2012 - 2016	HV Battery	Read Data Stream	
DFNISSAN	All Mode	2012 - 2016	HV Battery	Module Information	
DFNISSAN	All Mode	2012 - 2016	HV Battery	Actuation Test	HV Battery Cooling Fan
DFNISSAN	All Mode	2012 - 2016	HV Battery	Special Function	Save Battery Information Data
DFNISSAN	All Mode	2012 - 2016	HV Battery	Special Function	Write Battery Information Data
DFNISSAN	All Mode	2012 - 2016	HV Battery	Special Function	Clear Battery Info
DFNISSAN	All Mode	2012 - 2016	HV Battery	Special Function	LI-ION Battery Capacity Balancing
DFNISSAN	All Mode	2011 - 2013	HV Battery	Read Fault Code	
DFNISSAN	All Mode	2011 - 2013	HV Battery	Clear Fault Code	
DFNISSAN	All Mode	2011 - 2013	HV Battery	Read Data Stream	
DFNISSAN	All Mode	2011 - 2013	HV Battery	Read Freeze Frame	
DFNISSAN	All Mode	2011 - 2013	HV Battery	Module Information	
DFNISSAN	All Mode	2011 - 2013	HV Battery	Special Function	Clear Battery Gradual Capacity Loss Data
DFNISSAN	All Mode	2011 - 2013	HV Battery	Special Function	Clear Batt Charge/Discharge Information Data
DFNISSAN	All Mode	2011 - 2013	HV Battery	Special Function	Save Battery Information Data
DFNISSAN	All Mode	2011 - 2013	HV Battery	Special Function	Write Battery Information Data
DFNISSAN	All Mode	2011 - 2013	HV Battery	Special Function	Cell voltage loss inspection
DFNISSAN	All Mode	2013 - 2014	HV Battery	Read Fault Code	
DFNISSAN	All Mode	2013 - 2014	HV Battery	Clear Fault Code	
DFNISSAN	All Mode	2013 - 2014	HV Battery	Read Data Stream	
DFNISSAN	All Mode	2013 - 2014	HV Battery	Module Information	
DFNISSAN	All Mode	2013 - 2014	HV Battery	Special Function	Clear Battery Gradual Capacity Loss Data
DFNISSAN	All Mode	2013 - 2014	HV Battery	Special Function	Clear Batt Charge/Discharge Information Data

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
DFNISSAN	All Mode	2013 - 2014	HV Battery	Special Function	Save Battery Information Data
DFNISSAN	All Mode	2013 - 2014	HV Battery	Special Function	Write Battery Information Data
DFNISSAN	All Mode	2013 - 2014	HV Battery	Special Function	Cell voltage loss inspection
DFNISSAN	All Mode	2013 - 2016	HV Battery	Read Fault Code	
DFNISSAN	All Mode	2013 - 2016	HV Battery	Clear Fault Code	
DFNISSAN	All Mode	2013 - 2016	HV Battery	Read Data Stream	
DFNISSAN	All Mode	2013 - 2016	HV Battery	Module Information	
DFNISSAN	All Mode	2013 - 2016	HV Battery	Actuation Test	HV Battery Cooling Fan
DFNISSAN	All Mode	2013 - 2016	HV Battery	Special Function	Save Battery Information Data
DFNISSAN	All Mode	2013 - 2016	HV Battery	Special Function	Write Battery Information Data
DFNISSAN	All Mode	2013 - 2016	HV Battery	Special Function	Clear Battery Info
DFNISSAN	All Mode	2014 - 2016	HV Battery	Read Fault Code	
DFNISSAN	All Mode	2014 - 2016	HV Battery	Clear Fault Code	
DFNISSAN	All Mode	2014 - 2016	HV Battery	Read Data Stream	
DFNISSAN	All Mode	2014 - 2016	HV Battery	Module Information	
DFNISSAN	All Mode	2014 - 2016	HV Battery	Actuation Test	HV Battery Cooling Fan
DFNISSAN	All Mode	2014 - 2016	HV Battery	Special Function	Idm Information Clear
DFNISSAN	All Mode	2008 - 2016	Total Illum C/U	Read Fault Code	
DFNISSAN	All Mode	2008 - 2016	Total Illum C/U	Clear Fault Code	
DFNISSAN	All Mode	2008 - 2016	Total Illum C/U	Read Data Stream	
DFNISSAN	All Mode	2008 - 2017	Occupant Detection	Read Data Stream	
DFNISSAN	All Mode	2008 - 2017	Occupant Detection	Special Function	Zero point reset function
DFNISSAN	All Mode	2011 - 2016	Brakes	Read Fault Code	
DFNISSAN	All Mode	2011 - 2016	Brakes	Clear Fault Code	
DFNISSAN	All Mode	2011 - 2016	Brakes	Read Data Stream	
DFNISSAN	All Mode	2011 - 2016	Brakes	Module Information	
DFNISSAN	All Mode	2011 - 2016	Brakes	Actuation Test	STOP LAMP OFF RELAY
DFNISSAN	All Mode	2011 - 2016	Brakes	Special Function	Storke Sensor 0 Point Learning
DFNISSAN	All Mode	2009 - 2017	Side Radar Left	Read Fault Code	
DFNISSAN	All Mode	2009 - 2017	Side Radar Left	Clear Fault Code	
DFNISSAN	All Mode	2009 - 2017	Side Radar Left	Read Data Stream	
DFNISSAN	All Mode	2009 - 2017	Side Radar Left	Module Information	
DFNISSAN	All Mode	2009 - 2017	Side Radar Left	Special Function	Activate Operation
DFNISSAN	All Mode	2009 - 2017	Side Radar Left	Read Fault Code	
DFNISSAN	All Mode	2009 - 2017	Side Radar Left	Read Data Stream	
DFNISSAN	All Mode	2009 - 2017	Side Radar Left	Module Information	
DFNISSAN	All Mode	2009 - 2017	Side Radar Left	Special Function	Activate Operation
DFNISSAN	All Mode	2013 - 2016	VSP	Read Fault Code	
DFNISSAN	All Mode	2013 - 2016	VSP	Clear Fault Code	
DFNISSAN	All Mode	2013 - 2016	VSP	Read Data Stream	
DFNISSAN	All Mode	2013 - 2016	VSP	Module Information	
DFNISSAN	All Mode	2013 - 2016	VSP	Actuation Test	VSP SPEAKER
DFNISSAN	All Mode	2013 - 2016	VSP	Actuation Test	START UP SOUND SPEAKER
DFNISSAN	All Mode	2013 - 2016	VSP	Actuation Test	VSP OFF INDICATOR
DFNISSAN	All Mode	2011 - 2015	VSP	Read Fault Code	
DFNISSAN	All Mode	2011 - 2015	VSP	Clear Fault Code	
DFNISSAN	All Mode	2011 - 2015	VSP	Read Data Stream	
DFNISSAN	All Mode	2011 - 2015	VSP	Module Information	
DFNISSAN	All Mode	2013 - 2016	Active Noise Cancellation (ANC)	Read Fault Code	
DFNISSAN	All Mode	2013 - 2016	Active Noise Cancellation (ANC)	Clear Fault Code	
DFNISSAN	All Mode	2013 - 2016	Active Noise Cancellation (ANC)	Read Data Stream	
DFNISSAN	All Mode	2013 - 2016	Active Noise Cancellation (ANC)	Module Information	
DFNISSAN	All Mode	2013 - 2016	Active Noise Cancellation (ANC)	Actuation Test	ANC TEST TONE
DFNISSAN	All Mode	2013 - 2016	Active Noise Cancellation (ANC)	Special Function	ANC Setting
DFNISSAN	All Mode	2013 - 2016	Active Noise Cancellation (ANC)	Special Function	ASC Setting
DFNISSAN	All Mode	2014 - 2016	Active Noise Cancellation (ANC)	Read Fault Code	
DFNISSAN	All Mode	2014 - 2016	Active Noise Cancellation (ANC)	Clear Fault Code	
DFNISSAN	All Mode	2014 - 2016	Active Noise Cancellation (ANC)	Read Data Stream	
DFNISSAN	All Mode	2014 - 2016	Active Noise Cancellation (ANC)	Module Information	
DFNISSAN	All Mode	2014 - 2016	Active Noise Cancellation (ANC)	Actuation Test	ANC TEST TONE
DFNISSAN	All Mode	2014 - 2016	Active Noise Cancellation (ANC)	Special Function	ANC Setting
DFNISSAN	All Mode	2014 - 2016	Active Noise Cancellation (ANC)	Special Function	ASC Setting
DFNISSAN	All Mode	2016 - 2016	Active Noise Cancellation (ANC)	Read Fault Code	
DFNISSAN	All Mode	2016 - 2016	Active Noise Cancellation (ANC)	Clear Fault Code	
DFNISSAN	All Mode	2016 - 2016	Active Noise Cancellation (ANC)	Read Data Stream	
DFNISSAN	All Mode	2016 - 2016	Active Noise Cancellation (ANC)	Module Information	
DFNISSAN	All Mode	2016 - 2016	Active Noise Cancellation (ANC)	Actuation Test	ANC TEST TONE
DFNISSAN	All Mode	2016 - 2016	Active Noise Cancellation (ANC)	Special Function	ANC Setting
DFNISSAN	All Mode	2016 - 2016	Active Noise Cancellation (ANC)	Special Function	ASC Setting
DFNISSAN	All Mode	2013 - 2016	Active Noise Cancellation (ANC)	Read Fault Code	
DFNISSAN	All Mode	2013 - 2016	Active Noise Cancellation (ANC)	Clear Fault Code	
DFNISSAN	All Mode	2013 - 2016	Active Noise Cancellation (ANC)	Read Data Stream	
DFNISSAN	All Mode	2013 - 2016	Active Noise Cancellation (ANC)	Module Information	

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
DFNISSAN	All Mode	2013 - 2016	Active Noise Cancellation (ANC)	Actuation Test	ANC TEST TONE
DFNISSAN	All Mode	2013 - 2016	Active Noise Cancellation (ANC)	Special Function	ANC Setting
DFNISSAN	All Mode	2013 - 2016	Active Noise Cancellation (ANC)	Special Function	ASC Setting
DFNISSAN	All Mode	2012 - 2016	Multi Display	Read Fault Code	
DFNISSAN	All Mode	2012 - 2016	Multi Display	Clear Fault Code	
DFNISSAN	All Mode	2012 - 2016	Multi Display	Read Data Stream	
DFNISSAN	All Mode	2012 - 2016	Multi Display	Actuation Test	STOP LAMP OFF RELAY
DFNISSAN	All Mode	Up to 2017	CCS (Cruise Control System)	Read Fault Code	
DFNISSAN	All Mode	Up to 2017	CCS (Cruise Control System)	Clear Fault Code	
DFNISSAN	All Mode	Up to 2017	CCS (Cruise Control System)	Read Data Stream	
DFNISSAN	All Mode	Up to 2017	CCS (Cruise Control System)	Module Information	
DFNISSAN	All Mode	Up to 2017	CCS (Cruise Control System)	Actuation Test	ICC BUZZER
DFNISSAN	All Mode	Up to 2017	CCS (Cruise Control System)	Actuation Test	Meter Lamp
DFNISSAN	All Mode	Up to 2017	CCS (Cruise Control System)	Actuation Test	Stop Lamp
DFNISSAN	All Mode	Up to 2017	CCS (Cruise Control System)	Special Function	Cause Of Auto-Cancel
DFNISSAN	All Mode	Up to 2017	CCS (Cruise Control System)	Special Function	Laser Beam Adjust
DFNISSAN	All Mode	Up to 2017	CCS (Cruise Control System)	Read Fault Code	
DFNISSAN	All Mode	Up to 2017	CCS (Cruise Control System)	Clear Fault Code	
DFNISSAN	All Mode	Up to 2017	CCS (Cruise Control System)	Read Data Stream	
DFNISSAN	All Mode	Up to 2017	CCS (Cruise Control System)	Read Freeze Frame	
DFNISSAN	All Mode	Up to 2017	CCS (Cruise Control System)	Module Information	
DFNISSAN	All Mode	Up to 2017	CCS (Cruise Control System)	Actuation Test	ICC BUZZER
DFNISSAN	All Mode	Up to 2017	CCS (Cruise Control System)	Actuation Test	Meter Lamp
DFNISSAN	All Mode	Up to 2017	CCS (Cruise Control System)	Actuation Test	Stop Lamp
DFNISSAN	All Mode	Up to 2017	CCS (Cruise Control System)	Actuation Test	BOOSTER SOL/V
DFNISSAN	All Mode	Up to 2017	CCS (Cruise Control System)	Actuation Test	Accelerator Pedal Actuator
DFNISSAN	All Mode	Up to 2017	CCS (Cruise Control System)	Actuation Test	DCA Indicator
DFNISSAN	All Mode	Up to 2017	CCS (Cruise Control System)	Special Function	Cause Of Auto-Cancel
DFNISSAN	All Mode	Up to 2017	CCS (Cruise Control System)	Special Function	Laser Beam Adjust
DFNISSAN	All Mode	2010 - 2017	CCS (Cruise Control System)	Read Fault Code	
DFNISSAN	All Mode	2010 - 2017	CCS (Cruise Control System)	Clear Fault Code	
DFNISSAN	All Mode	2010 - 2017	CCS (Cruise Control System)	Read Data Stream	
DFNISSAN	All Mode	2010 - 2017	CCS (Cruise Control System)	Read Freeze Frame	
DFNISSAN	All Mode	2010 - 2017	CCS (Cruise Control System)	Module Information	
DFNISSAN	All Mode	2010 - 2017	CCS (Cruise Control System)	Actuation Test	Brake Actuator
DFNISSAN	All Mode	2010 - 2017	CCS (Cruise Control System)	Actuation Test	ICC BUZZER
DFNISSAN	All Mode	2010 - 2017	CCS (Cruise Control System)	Actuation Test	Meter Lamp
DFNISSAN	All Mode	2010 - 2017	CCS (Cruise Control System)	Actuation Test	Stop Lamp
DFNISSAN	All Mode	2010 - 2017	CCS (Cruise Control System)	Actuation Test	DCA Indicator
DFNISSAN	All Mode	2010 - 2017	CCS (Cruise Control System)	Actuation Test	LDP Buzzer
DFNISSAN	All Mode	2010 - 2017	CCS (Cruise Control System)	Actuation Test	Warning System IND
DFNISSAN	All Mode	2010 - 2017	CCS (Cruise Control System)	Actuation Test	LDP ON IND
DFNISSAN	All Mode	2010 - 2017	CCS (Cruise Control System)	Actuation Test	LANE DEPARTURE W/L
DFNISSAN	All Mode	2010 - 2017	CCS (Cruise Control System)	Actuation Test	BSW/BSI Warning Lamp
DFNISSAN	All Mode	2010 - 2017	CCS (Cruise Control System)	Actuation Test	BSI On Indicator
DFNISSAN	All Mode	2010 - 2017	CCS (Cruise Control System)	Actuation Test	LDW On Indicator
DFNISSAN	All Mode	2010 - 2017	CCS (Cruise Control System)	Actuation Test	LDP Warning Indicator
DFNISSAN	All Mode	2010 - 2017	CCS (Cruise Control System)	Actuation Test	LDW Warning Indicator
DFNISSAN	All Mode	2010 - 2017	CCS (Cruise Control System)	Actuation Test	BSW ON INDICATOR
DFNISSAN	All Mode	2010 - 2017	CCS (Cruise Control System)	Actuation Test	BSI Warning Indicator
DFNISSAN	All Mode	2010 - 2017	CCS (Cruise Control System)	Special Function	Cause Of Auto-Cancel 1
DFNISSAN	All Mode	2010 - 2017	CCS (Cruise Control System)	Special Function	Cause Of Auto-Cancel 2
DFNISSAN	All Mode	2010 - 2017	CCS (Cruise Control System)	Special Function	Cause Of Auto-Cancel 3
DFNISSAN	All Mode	2010 - 2017	CCS (Cruise Control System)	Special Function	FEB Operation Mileage
DFNISSAN	All Mode	2010 - 2017	CCS (Cruise Control System)	Special Function	Cause Of Auto-Cancel 4
DFNISSAN	All Mode	2010 - 2017	CCS (Cruise Control System)	Special Function	FEB Default Setting
DFNISSAN	All Mode	2012 - 2016	CCS (Cruise Control System)	Read Fault Code	
DFNISSAN	All Mode	2012 - 2016	CCS (Cruise Control System)	Clear Fault Code	
DFNISSAN	All Mode	2012 - 2016	CCS (Cruise Control System)	Read Data Stream	
DFNISSAN	All Mode	2012 - 2016	CCS (Cruise Control System)	Module Information	
DFNISSAN	All Mode	2012 - 2016	CCS (Cruise Control System)	Actuation Test	ADAS BUZZER
DFNISSAN	All Mode	2012 - 2016	CCS (Cruise Control System)	Actuation Test	Stop Lamp
DFNISSAN	All Mode	2012 - 2016	CCS (Cruise Control System)	Actuation Test	Meter Lamp
DFNISSAN	All Mode	2012 - 2016	CCS (Cruise Control System)	Actuation Test	METER BUZZER
DFNISSAN	All Mode	2012 - 2016	CCS (Cruise Control System)	Actuation Test	EAP SW Lamp
DFNISSAN	All Mode	2012 - 2016	CCS (Cruise Control System)	Actuation Test	BRAKE ACTUATOR 1
DFNISSAN	All Mode	2012 - 2016	CCS (Cruise Control System)	Actuation Test	BRAKE ACTUATOR 2
DFNISSAN	All Mode	2012 - 2016	CCS (Cruise Control System)	Actuation Test	BRAKE ACTUATOR 3
DFNISSAN	All Mode	2012 - 2016	CCS (Cruise Control System)	Special Function	FEB Operation Mileage
DFNISSAN	All Mode	2012 - 2016	CCS (Cruise Control System)	Special Function	FEB Default Setting
DFNISSAN	All Mode	2012 - 2016	CCS (Cruise Control System)	Special Function	Cause Of Auto-Cancel 4
DFNISSAN	All Mode	2012 - 2016	CCS (Cruise Control System)	Special Function	Cause Of Auto-Cancel 5
DFNISSAN	All Mode	2012 - 2016	CCS (Cruise Control System)	Special Function	Cause Of Auto-Cancel 6
DFNISSAN	All Mode	2013 - 2016	CCS (Cruise Control System)	Read Fault Code	
DFNISSAN	All Mode	2013 - 2016	CCS (Cruise Control System)	Clear Fault Code	
DFNISSAN	All Mode	2013 - 2016	CCS (Cruise Control System)	Read Data Stream	
DFNISSAN	All Mode	2013 - 2016	CCS (Cruise Control System)	Module Information	
DFNISSAN	All Mode	2013 - 2016	CCS (Cruise Control System)	Special Function	FEB Operation Mileage
DFNISSAN	All Mode	2013 - 2016	CCS (Cruise Control System)	Special Function	Cause Of Auto-Cancel 6

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
DFNISSAN	All Mode	2009 - 2017	Side Radar Right	Read Fault Code	
DFNISSAN	All Mode	2009 - 2017	Side Radar Right	Clear Fault Code	
DFNISSAN	All Mode	2009 - 2017	Side Radar Right	Read Data Stream	
DFNISSAN	All Mode	2009 - 2017	Side Radar Right	Module Information	
DFNISSAN	All Mode	2009 - 2017	Side Radar Right	Special Function	Activate Operation
DFNISSAN	All Mode	2009 - 2017	Side Radar Right	Read Fault Code	
DFNISSAN	All Mode	2009 - 2017	Side Radar Right	Clear Fault Code	
DFNISSAN	All Mode	2009 - 2017	Side Radar Right	Read Data Stream	
DFNISSAN	All Mode	2009 - 2017	Side Radar Right	Module Information	
DFNISSAN	All Mode	2009 - 2017	Side Radar Right	Special Function	ACTIVATE OPERATION
DFNISSAN	All Mode	2016 - 2016	ADCM	Read Fault Code	
DFNISSAN	All Mode	2016 - 2016	ADCM	Clear Fault Code	
DFNISSAN	All Mode	2016 - 2016	ADCM	Read Data Stream	
DFNISSAN	All Mode	2016 - 2016	ADCM	Module Information	
DFNISSAN	All Mode	2016 - 2016	ADCM	Special Function	Saving Data For Replc CPU
DFNISSAN	All Mode	2016 - 2016	ADCM	Special Function	Writing Data For Replc CPU
DFNISSAN	All Mode	2016 - 2016	ADCM	Special Function	SCR Catalyst Data Clear
DFNISSAN	All Mode	2016 - 2016	ADCM	Special Function	NOX Sensor 1 Data Clear
DFNISSAN	All Mode	2016 - 2016	ADCM	Special Function	NOX Sensor 2 Data Clear
DFNISSAN	All Mode	2016 - 2016	ADCM	Special Function	SCR Catalyst Temp Sensor 1 Data Clear
DFNISSAN	All Mode	2016 - 2016	ADCM	Special Function	Data Clear For Replacing CPU A
DFNISSAN	All Mode	2016 - 2016	ADCM	Special Function	Data Clear For Replacing CPU B
DFNISSAN	All Mode	2016 - 2016	ADCM	Special Function	Oxidation Catalyst Data Clear
DFNISSAN	All Mode	2016 - 2016	ADCM	Special Function	DPF Data Clear
DFNISSAN	All Mode	2016 - 2016	ADCM	Special Function	Urea Injector Data Clear
DFNISSAN	All Mode	2016 - 2016	ADCM	Special Function	SCR CAT Amount Of Urea Adsorpt Data Clear
DFNISSAN	All Mode	2015 - 2015	ADCM	Read Fault Code	
DFNISSAN	All Mode	2015 - 2015	ADCM	Clear Fault Code	
DFNISSAN	All Mode	2015 - 2015	ADCM	Read Data Stream	
DFNISSAN	All Mode	2015 - 2015	ADCM	Module Information	
DFNISSAN	All Mode	2014 - 2014	ADCM	Read Fault Code	
DFNISSAN	All Mode	2014 - 2014	ADCM	Clear Fault Code	
DFNISSAN	All Mode	2014 - 2014	ADCM	Read Data Stream	
DFNISSAN	All Mode	2014 - 2014	ADCM	Module Information	
DFNISSAN	All Mode	2014 - 2014	ADCM	Actuation Test	Adblue Injector
DFNISSAN	All Mode	2014 - 2014	ADCM	Actuation Test	Adblue Pump
DFNISSAN	All Mode	2014 - 2014	ADCM	Actuation Test	Adblue Backflow Pump
DFNISSAN	All Mode	2014 - 2014	ADCM	Actuation Test	Pressure Line Adblue Heater
DFNISSAN	All Mode	2014 - 2014	ADCM	Actuation Test	Adblue Tank Heater
DFNISSAN	All Mode	2014 - 2014	ADCM	Special Function	Vin Registration
DFNISSAN	All Mode	2014 - 2014	ADCM	Special Function	Adblue Injector Programming
DFNISSAN	All Mode	2014 - 2014	ADCM	Special Function	Adblue Pump Module Programming
DFNISSAN	All Mode	2014 - 2014	ADCM	Special Function	Adblue Tank Programming
DFNISSAN	All Mode	2014 - 2014	ADCM	Special Function	Write Saved Data
DFNISSAN	All Mode	2014 - 2014	ADCM	Special Function	Save Computer Data
DFNISSAN	All Mode	2014 - 2014	ADCM	Special Function	Adblue Dos Mod Catalyst
DFNISSAN	All Mode	2016 - 2016	ADCM	Read Fault Code	
DFNISSAN	All Mode	2016 - 2016	ADCM	Clear Fault Code	
DFNISSAN	All Mode	2016 - 2016	ADCM	Read Data Stream	
DFNISSAN	All Mode	2016 - 2016	ADCM	Module Information	
DFNISSAN	All Mode	2016 - 2016	ADCM	Special Function	Save Data For Replacing CPU
DFNISSAN	All Mode	2016 - 2016	ADCM	Special Function	Write Data After Replacing CPU
DFNISSAN	All Mode	2016 - 2016	ADCM	Special Function	SCR Catalyst Data Clear
DFNISSAN	All Mode	2016 - 2016	ADCM	Special Function	NOX Sensor 1 Data Clear
DFNISSAN	All Mode	2016 - 2016	ADCM	Special Function	NOX Sensor 2 Data Clear
DFNISSAN	All Mode	2016 - 2016	ADCM	Special Function	SCR Catalyst Temp Sensor 1 Data Clear
DFNISSAN	All Mode	2016 - 2016	ADCM	Special Function	Data Clear For Replacing CPU A
DFNISSAN	All Mode	2016 - 2016	ADCM	Special Function	Data Clear For Replacing CPU B
DFNISSAN	All Mode	2016 - 2016	ADCM	Special Function	Oxidation Catalyst Data Clear
DFNISSAN	All Mode	2016 - 2016	ADCM	Special Function	DPF Data Clear
DFNISSAN	All Mode	2016 - 2016	ADCM	Special Function	Urea Injector Data Clear
DFNISSAN	All Mode	2016 - 2016	ADCM	Special Function	SCR CAT Amount Of Urea Adsorpt Data Clear
DFNISSAN	All Mode	2012 - 2016	PTC Heater	Read Fault Code	
DFNISSAN	All Mode	2012 - 2016	PTC Heater	Clear Fault Code	
DFNISSAN	All Mode	2012 - 2016	PTC Heater	Read Data Stream	
DFNISSAN	All Mode	2012 - 2016	PTC Heater	Module Information	
DFNISSAN	All Mode	2011 - 2013	Charger/PD Module	Read Fault Code	
DFNISSAN	All Mode	2011 - 2013	Charger/PD Module	Clear Fault Code	



**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

<b>make</b>	<b>model</b>	<b>year</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
DFNISSAN	All Mode	2011 - 2013	Charger/PD Module	Read Data Stream	
DFNISSAN	All Mode	2011 - 2013	Charger/PD Module	Module Information	
DFNISSAN	All Mode	2011 - 2013	Charger/PD Module	Actuation Test	QUICK CHARGE RELAY+
DFNISSAN	All Mode	2011 - 2013	Charger/PD Module	Actuation Test	Quick Charge Relay-
DFNISSAN	All Mode	2011 - 2013	Charger/PD Module	Actuation Test	Normal Charge Relay+
DFNISSAN	All Mode	2011 - 2013	Charger/PD Module	Actuation Test	Normal Charge Relay-
DFNISSAN	All Mode	2011 - 2013	Charger/PD Module	Actuation Test	Quick Charge Permit SIG Circuit
DFNISSAN	All Mode	2013 - 2014	Charger/PD Module	Read Fault Code	
DFNISSAN	All Mode	2013 - 2014	Charger/PD Module	Clear Fault Code	
DFNISSAN	All Mode	2013 - 2014	Charger/PD Module	Read Data Stream	
DFNISSAN	All Mode	2013 - 2014	Charger/PD Module	Module Information	
DFNISSAN	All Mode	2013 - 2014	Charger/PD Module	Actuation Test	QUICK CHARGE RELAY+
DFNISSAN	All Mode	2013 - 2014	Charger/PD Module	Actuation Test	Quick Charge Relay-
DFNISSAN	All Mode	2013 - 2014	Charger/PD Module	Actuation Test	Normal Charge Relay-
DFNISSAN	All Mode	2013 - 2014	Charger/PD Module	Special Function	CHARGE CURRENT LIMITATION HISTORY
DFNISSAN	All Mode	2010 - 2017	Telematics	Read Fault Code	
DFNISSAN	All Mode	2010 - 2017	Telematics	Clear Fault Code	
DFNISSAN	All Mode	2010 - 2017	Telematics	Read Data Stream	
DFNISSAN	All Mode	2010 - 2017	Telematics	Module Information	
DFNISSAN	All Mode	2010 - 2017	Telematics	Special Function	Center Connection Setting
DFNISSAN	All Mode	2010 - 2017	Telematics	Special Function	TCU Activate Setting
DFNISSAN	All Mode	2010 - 2017	Telematics	Special Function	Save Vin Data
DFNISSAN	All Mode	2010 - 2017	Telematics	Special Function	Write Vin (Saved Data)
DFNISSAN	All Mode	2010 - 2017	Telematics	Special Function	Write Vin (Manual Input)
DFNISSAN	All Mode	2016 - 2016	Telematics	Read Fault Code	
DFNISSAN	All Mode	2016 - 2016	Telematics	Clear Fault Code	
DFNISSAN	All Mode	2016 - 2016	Telematics	Read Data Stream	
DFNISSAN	All Mode	2016 - 2016	Telematics	Module Information	
DFNISSAN	All Mode	2011 - 2016	EMCM	Read Fault Code	
DFNISSAN	All Mode	2011 - 2016	EMCM	Clear Fault Code	
DFNISSAN	All Mode	2011 - 2016	EMCM	Read Data Stream	
DFNISSAN	All Mode	2011 - 2016	EMCM	Module Information	
DFNISSAN	All Mode	2011 - 2016	EMCM	Actuation Test	Auto Stop Start
DFNISSAN	All Mode	2011 - 2016	EMCM	Special Function	Saving Data For Replc CPU
DFNISSAN	All Mode	2011 - 2016	EMCM	Special Function	Writing Data For Replc CPU
DFNISSAN	All Mode	2011 - 2016	EMCM	Special Function	STRT OPRTN CNTR CLEAR
DFNISSAN	All Mode	2011 - 2016	EMCM	Special Function	CML B/DCHRG CRNT CLEAR
DFNISSAN	All Mode	2011 - 2016	EMCM	Special Function	Cumulative Sub-Battery Dischg Current Clear
DFNISSAN	All Mode	2011 - 2016	EMCM	Special Function	Chassis Dynamometer Mode
DFNISSAN	All Mode	2010 - 2014	HVAC (Heating Ventilation Air-conditioning and Cooling)	Read Fault Code	
DFNISSAN	All Mode	2010 - 2014	HVAC (Heating Ventilation Air-conditioning and Cooling)	Clear Fault Code	
DFNISSAN	All Mode	2010 - 2014	HVAC (Heating Ventilation Air-conditioning and Cooling)	Read Data Stream	
DFNISSAN	All Mode	2010 - 2014	HVAC (Heating Ventilation Air-conditioning and Cooling)	Read Freeze Frame	
DFNISSAN	All Mode	2010 - 2014	HVAC (Heating Ventilation Air-conditioning and Cooling)	Module Information	
DFNISSAN	All Mode	2010 - 2014	HVAC (Heating Ventilation Air-conditioning and Cooling)	Actuation Test	ALL SEG
DFNISSAN	All Mode	2010 - 2014	HVAC (Heating Ventilation Air-conditioning and Cooling)	Actuation Test	Hvac Test
DFNISSAN	All Mode	2010 - 2014	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	Temp Set Correct
DFNISSAN	All Mode	2010 - 2014	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	REC Memory Set
DFNISSAN	All Mode	2010 - 2014	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	FRE Memory Set
DFNISSAN	All Mode	2010 - 2014	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	Blow Set
DFNISSAN	All Mode	2010 - 2014	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	DOOR Motor Starting Position Reset
DFNISSAN	All Mode	2010 - 2014	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	Target Max RPM ADJ AT Pre-Climate
DFNISSAN	All Mode	2010 - 2014	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	Target Max RPM ADJ AT IDL
DFNISSAN	All Mode	2010 - 2014	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	COMP OPRT SET AT DEF MODE (TIM/RMT CLIMT CONT)
DFNISSAN	All Mode	2010 - 2016	HVAC (Heating Ventilation Air-conditioning and Cooling)	Read Fault Code	
DFNISSAN	All Mode	2010 - 2016	HVAC (Heating Ventilation Air-conditioning and Cooling)	Clear Fault Code	
DFNISSAN	All Mode	2010 - 2016	HVAC (Heating Ventilation Air-conditioning and Cooling)	Read Data Stream	
DFNISSAN	All Mode	2010 - 2016	HVAC (Heating Ventilation Air-conditioning and Cooling)	Read Freeze Frame	

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

<b>make</b>	<b>model</b>	<b>year</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
DFNISSAN	All Mode	2010 - 2016	HVAC (Heating Ventilation Air-conditioning and Cooling)	Module Information	
DFNISSAN	All Mode	2010 - 2016	HVAC (Heating Ventilation Air-conditioning and Cooling)	Actuation Test	Hvac Test
DFNISSAN	All Mode	2010 - 2016	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	Blow Set
DFNISSAN	All Mode	2010 - 2016	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	REC Memory Set
DFNISSAN	All Mode	2010 - 2016	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	FRE Memory Set
DFNISSAN	All Mode	2010 - 2016	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	Temp Set Correct
DFNISSAN	All Mode	2010 - 2016	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	Aroma Setting
DFNISSAN	All Mode	2010 - 2016	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	Fragrance Setting
DFNISSAN	All Mode	2010 - 2016	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	Blower Motor Setting
DFNISSAN	All Mode	2010 - 2016	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	(TBD)WDBLIDOA
DFNISSAN	All Mode	2010 - 2016	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	Aroma Diffuser Setting
DFNISSAN	All Mode	2010 - 2016	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	(TBD)WDBLIDOC
DFNISSAN	All Mode	2010 - 2016	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	Target Evaporator Temp Upper Limit Setting
DFNISSAN	All Mode	2010 - 2016	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	CLEAN SW SET
DFNISSAN	All Mode	2010 - 2016	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	Air Inlet Change Setting
DFNISSAN	All Mode	2010 - 2016	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	Air Flow Reduction Setting
DFNISSAN	All Mode	Up to 2012	HVAC (Heating Ventilation Air-conditioning and Cooling)	Read Fault Code	
DFNISSAN	All Mode	Up to 2012	HVAC (Heating Ventilation Air-conditioning and Cooling)	Clear Fault Code	
DFNISSAN	All Mode	Up to 2012	HVAC (Heating Ventilation Air-conditioning and Cooling)	Read Data Stream	
DFNISSAN	All Mode	Up to 2012	HVAC (Heating Ventilation Air-conditioning and Cooling)	Module Information	
DFNISSAN	All Mode	2008 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Read Fault Code	
DFNISSAN	All Mode	2008 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Clear Fault Code	
DFNISSAN	All Mode	2008 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Read Data Stream	
DFNISSAN	All Mode	2008 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Read Freeze Frame	
DFNISSAN	All Mode	2008 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Module Information	
DFNISSAN	All Mode	2008 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Actuation Test	ALL SEG
DFNISSAN	All Mode	2008 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Actuation Test	Hvac Test
DFNISSAN	All Mode	2008 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	Blow Set
DFNISSAN	All Mode	2008 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	REC Memory Set
DFNISSAN	All Mode	2008 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	FRE Memory Set
DFNISSAN	All Mode	2008 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	Temp Set Correct
DFNISSAN	All Mode	2008 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	GAS Sensor Adjustment
DFNISSAN	All Mode	2008 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	CLEAN SW SET
DFNISSAN	All Mode	2008 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	(TBD)ACTR RESET
DFNISSAN	All Mode	2008 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	DOOR Motor Starting Position Reset
DFNISSAN	All Mode	2008 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	Rear Temp Set Correct
DFNISSAN	All Mode	2008 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	Target Evaporator Temp Upper Limit Setting
DFNISSAN	All Mode	2008 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	STOP/START SYSTEM OPERATION COND SETTING
DFNISSAN	All Mode	2008 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	Air Inlet Change Setting
DFNISSAN	All Mode	2008 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	Air Flow Reduction Setting

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

<b>make</b>	<b>model</b>	<b>year</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
DFNISSAN	All Mode	2012 - 2016	HVAC (Heating Ventilation Air-conditioning and Cooling)	Read Fault Code	
DFNISSAN	All Mode	2012 - 2016	HVAC (Heating Ventilation Air-conditioning and Cooling)	Clear Fault Code	
DFNISSAN	All Mode	2012 - 2016	HVAC (Heating Ventilation Air-conditioning and Cooling)	Read Data Stream	
DFNISSAN	All Mode	2012 - 2016	HVAC (Heating Ventilation Air-conditioning and Cooling)	Module Information	
DFNISSAN	All Mode	2012 - 2016	HVAC (Heating Ventilation Air-conditioning and Cooling)	Actuation Test	ALL SEG
DFNISSAN	All Mode	2012 - 2016	HVAC (Heating Ventilation Air-conditioning and Cooling)	Actuation Test	Hvac Test
DFNISSAN	All Mode	2012 - 2016	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	Rear Temp Set Correct
DFNISSAN	All Mode	2012 - 2016	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	Temp Set Correct
DFNISSAN	All Mode	2012 - 2016	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	REC Memory Set
DFNISSAN	All Mode	2012 - 2016	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	FRE Memory Set
DFNISSAN	All Mode	2012 - 2016	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	Blow Set
DFNISSAN	All Mode	2012 - 2016	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	GAS Sensor Adjustment
DFNISSAN	All Mode	2012 - 2016	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	CLEAN SW SET
DFNISSAN	All Mode	2012 - 2016	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	Target Evaporator Temp Upper Limit Setting
DFNISSAN	All Mode	2012 - 2016	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	Air Inlet Change Setting
DFNISSAN	All Mode	2012 - 2016	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	Air Flow Reduction Setting
DFNISSAN	All Mode	2012 - 2016	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	Target Max RPM ADJ AT IDL
DFNISSAN	All Mode	2014 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Read Fault Code	
DFNISSAN	All Mode	2014 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Clear Fault Code	
DFNISSAN	All Mode	2014 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Read Data Stream	
DFNISSAN	All Mode	2014 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Module Information	
DFNISSAN	All Mode	2014 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Actuation Test	Hvac Test
DFNISSAN	All Mode	2014 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	Temp Set Correct
DFNISSAN	All Mode	2014 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	REC Memory Set
DFNISSAN	All Mode	2014 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	FRE Memory Set
DFNISSAN	All Mode	2014 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	Blow Set
DFNISSAN	All Mode	2014 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	Target Evaporator Temp Upper Limit Setting
DFNISSAN	All Mode	2014 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	DOOR Motor Starting Position Reset
DFNISSAN	All Mode	2014 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Read Fault Code	
DFNISSAN	All Mode	2014 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Clear Fault Code	
DFNISSAN	All Mode	2014 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Read Data Stream	
DFNISSAN	All Mode	2014 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Module Information	
DFNISSAN	All Mode	2014 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Actuation Test	Hvac Test
DFNISSAN	All Mode	2014 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	DOOR Motor Starting Position Reset
DFNISSAN	All Mode	2014 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	Target Evaporator Temp Upper Limit Setting
DFNISSAN	All Mode	2016 - 2016	HVAC (Heating Ventilation Air-conditioning and Cooling)	Read Fault Code	
DFNISSAN	All Mode	2016 - 2016	HVAC (Heating Ventilation Air-conditioning and Cooling)	Clear Fault Code	
DFNISSAN	All Mode	2016 - 2016	HVAC (Heating Ventilation Air-conditioning and Cooling)	Read Data Stream	
DFNISSAN	All Mode	2016 - 2016	HVAC (Heating Ventilation Air-conditioning and Cooling)	Module Information	
DFNISSAN	All Mode	2016 - 2016	HVAC (Heating Ventilation Air-conditioning and Cooling)	Actuation Test	Check adjustment range of actuator motors

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

<b>make</b>	<b>model</b>	<b>year</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
DFNISSAN	All Mode	2016 - 2016	HVAC (Heating Ventilation Air-conditioning and Cooling)	Actuation Test	Refrigerant compressor magnetic clutch
DFNISSAN	All Mode	2016 - 2016	HVAC (Heating Ventilation Air-conditioning and Cooling)	Actuation Test	LED of automatic air conditioning cont operating unit
DFNISSAN	All Mode	2016 - 2016	HVAC (Heating Ventilation Air-conditioning and Cooling)	Actuation Test	Coolant circulation pump
DFNISSAN	All Mode	2016 - 2016	HVAC (Heating Ventilation Air-conditioning and Cooling)	Actuation Test	Rear Windshield Heater
DFNISSAN	All Mode	2016 - 2016	HVAC (Heating Ventilation Air-conditioning and Cooling)	Actuation Test	SW and cont illumi of auto air cond cont and operat unit
DFNISSAN	All Mode	2016 - 2016	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	Teach in of actuator motors
DFNISSAN	All Mode	2016 - 2016	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	Normalization of actuator motors
DFNISSAN	All Mode	2016 - 2016	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	Breaking in of refrigerant compressor
DFNISSAN	All Mode	2016 - 2016	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	Re learning
DFNISSAN	All Mode	2014 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Read Fault Code	
DFNISSAN	All Mode	2014 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Clear Fault Code	
DFNISSAN	All Mode	2014 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Read Data Stream	
DFNISSAN	All Mode	2014 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Module Information	
DFNISSAN	All Mode	2014 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Actuation Test	Hvac Test
DFNISSAN	All Mode	2014 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Actuation Test	ALL SEG
DFNISSAN	All Mode	2014 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	Temp Set Correct
DFNISSAN	All Mode	2014 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	REC Memory Set
DFNISSAN	All Mode	2014 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	FRE Memory Set
DFNISSAN	All Mode	2014 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	Blow Set
DFNISSAN	All Mode	2014 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	Target Evaporator Temp Upper Limit Setting
DFNISSAN	All Mode	2014 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	DOOR Motor Starting Position Reset
DFNISSAN	All Mode	2010 - 2015	SVT	Read Fault Code	
DFNISSAN	All Mode	2010 - 2015	SVT	Clear Fault Code	
DFNISSAN	All Mode	2010 - 2015	SVT	Read Data Stream	
DFNISSAN	All Mode	2010 - 2015	SVT	Module Information	
DFNISSAN	All Mode	2014 - 2016	BSW (Warning Of Lane Change)	Read Fault Code	
DFNISSAN	All Mode	2014 - 2016	BSW (Warning Of Lane Change)	Clear Fault Code	
DFNISSAN	All Mode	2014 - 2016	BSW (Warning Of Lane Change)	Read Data Stream	
DFNISSAN	All Mode	2014 - 2016	BSW (Warning Of Lane Change)	Module Information	
DFNISSAN	All Mode	2014 - 2016	BSW (Warning Of Lane Change)	Actuation Test	ICC BUZZER
DFNISSAN	All Mode	2014 - 2016	BSW (Warning Of Lane Change)	Actuation Test	BSW/BSI Warning Lamp
DFNISSAN	All Mode	2013 - 2016	BSW (Warning Of Lane Change)	Read Fault Code	
DFNISSAN	All Mode	2013 - 2016	BSW (Warning Of Lane Change)	Clear Fault Code	
DFNISSAN	All Mode	2013 - 2016	BSW (Warning Of Lane Change)	Read Data Stream	
DFNISSAN	All Mode	2013 - 2016	BSW (Warning Of Lane Change)	Module Information	
DFNISSAN	All Mode	2013 - 2016	BSW (Warning Of Lane Change)	Actuation Test	BUZZER 1 (ADAS)
DFNISSAN	All Mode	2013 - 2016	BSW (Warning Of Lane Change)	Actuation Test	BUZZER 2 (ADAS)
DFNISSAN	All Mode	2013 - 2016	BSW (Warning Of Lane Change)	Actuation Test	BUZZER 3 (ADAS)
DFNISSAN	All Mode	2013 - 2016	BSW (Warning Of Lane Change)	Actuation Test	BUZZER 4 (ADAS)
DFNISSAN	All Mode	2013 - 2016	BSW (Warning Of Lane Change)	Actuation Test	BUZZER 1 (CCM)
DFNISSAN	All Mode	2013 - 2016	BSW (Warning Of Lane Change)	Actuation Test	BUZZER 2 (CCM)
DFNISSAN	All Mode	2013 - 2016	BSW (Warning Of Lane Change)	Actuation Test	BUZZER 3 (CCM)
DFNISSAN	All Mode	2013 - 2016	BSW (Warning Of Lane Change)	Actuation Test	BUZZER 4 (CCM)
DFNISSAN	Venucia T90	2016	BSW (Warning Of Lane Change)	Read Fault Code	
DFNISSAN	Venucia T90	2016	BSW (Warning Of Lane Change)	Clear Fault Code	
DFNISSAN	Venucia T90	2016	BSW (Warning Of Lane Change)	Read Data Stream	
DFNISSAN	Venucia T90	2016	BSW (Warning Of Lane Change)	Module Information	
DFNISSAN	All Mode	Up to 2017	AVM (Around View Monitor)	Read Fault Code	
DFNISSAN	All Mode	Up to 2017	AVM (Around View Monitor)	Clear Fault Code	
DFNISSAN	All Mode	Up to 2017	AVM (Around View Monitor)	Read Data Stream	
DFNISSAN	All Mode	Up to 2017	AVM (Around View Monitor)	Module Information	
DFNISSAN	All Mode	Up to 2017	AVM (Around View Monitor)	Actuation Test	LED RH INDICATOR
DFNISSAN	All Mode	Up to 2017	AVM (Around View Monitor)	Actuation Test	AVM BUZZER
DFNISSAN	All Mode	Up to 2017	AVM (Around View Monitor)	Actuation Test	LED LH INDICATOR
DFNISSAN	All Mode	Up to 2017	AVM (Around View Monitor)	Actuation Test	WASH ACTIVE
DFNISSAN	All Mode	Up to 2017	AVM (Around View Monitor)	Actuation Test	AIR ACTIVE

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

<b>make</b>	<b>model</b>	<b>year</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
DFNISSAN	All Mode	Up to 2017	AVM (Around View Monitor)	Special Function	Calibrating Camera Image(Front Camera)
DFNISSAN	All Mode	Up to 2017	AVM (Around View Monitor)	Special Function	Calibrating Camera Image(Pass-Side Camera)
DFNISSAN	All Mode	Up to 2017	AVM (Around View Monitor)	Special Function	Calibrating Camera Image(DR-Side Camera)
DFNISSAN	All Mode	Up to 2017	AVM (Around View Monitor)	Special Function	Calibrating Camera Image(Rear Camera)
DFNISSAN	All Mode	Up to 2017	AVM (Around View Monitor)	Special Function	Fine Tuning Of Birds-Eye View
DFNISSAN	All Mode	Up to 2017	AVM (Around View Monitor)	Special Function	DOOR Motor Starting Position Reset
DFNISSAN	All Mode	Up to 2017	AVM (Around View Monitor)	Special Function	GAS Sensor Adjustment
DFNISSAN	All Mode	Up to 2017	AVM (Around View Monitor)	Special Function	CLEAN SW SET
DFNISSAN	All Mode	Up to 2017	AVM (Around View Monitor)	Special Function	Target Evaporator Temp Upper Limit Setting
DFNISSAN	All Mode	Up to 2017	AVM (Around View Monitor)	Special Function	Air Flow Reduction Setting
DFNISSAN	All Mode	Up to 2017	AVM (Around View Monitor)	Special Function	Target Max RPM ADJ AT IDL
DFNISSAN	All Mode	Up to 2017	AVM (Around View Monitor)	Special Function	Non-Viewable Area Reminder
DFNISSAN	All Mode	Up to 2017	AVM (Around View Monitor)	Special Function	Select Language Of Warning Message
DFNISSAN	All Mode	Up to 2017	AVM (Around View Monitor)	Read Fault Code	
DFNISSAN	All Mode	Up to 2017	AVM (Around View Monitor)	Clear Fault Code	
DFNISSAN	All Mode	Up to 2017	AVM (Around View Monitor)	Read Data Stream	
DFNISSAN	All Mode	Up to 2017	AVM (Around View Monitor)	Module Information	
DFNISSAN	All Mode	Up to 2017	AVM (Around View Monitor)	Special Function	Cause Of LDW Cancel
DFNISSAN	All Mode	Up to 2017	AVM (Around View Monitor)	Special Function	Cause Of BSW Cancel
DFNISSAN	All Mode	Up to 2017	AVM (Around View Monitor)	Special Function	Cause Of IPA Cancel
DFNISSAN	All Mode	Up to 2017	AVM (Around View Monitor)	Special Function	Cause Of PSR Cancel
DFNISSAN	All Mode	Up to 2017	AVM (Around View Monitor)	Special Function	Calibrating Camera Image(Front Camera)
DFNISSAN	All Mode	Up to 2017	AVM (Around View Monitor)	Special Function	Calibrating Camera Image(Pass-Side Camera)
DFNISSAN	All Mode	Up to 2017	AVM (Around View Monitor)	Special Function	Calibrating Camera Image(DR-Side Camera)
DFNISSAN	All Mode	Up to 2017	AVM (Around View Monitor)	Special Function	Calibrating Camera Image(Rear Camera)
DFNISSAN	All Mode	Up to 2017	AVM (Around View Monitor)	Special Function	Fine Tuning Of Birds-Eye View(Front Camera)
DFNISSAN	All Mode	Up to 2017	AVM (Around View Monitor)	Special Function	Fine Tuning Of Birds-Eye View(Pass-Side Camera)
DFNISSAN	All Mode	Up to 2017	AVM (Around View Monitor)	Special Function	Fine Tuning Of Birds-Eye View(DR-Side Camera)
DFNISSAN	All Mode	Up to 2017	AVM (Around View Monitor)	Special Function	Fine Tuning Of Birds-Eye View(Rear Camera)
DFNISSAN	All Mode	Up to 2017	AVM (Around View Monitor)	Special Function	Rear Wide-View Fixed Guide Line Correction
DFNISSAN	All Mode	Up to 2017	AVM (Around View Monitor)	Special Function	Non-Viewable Area Reminder
DFNISSAN	All Mode	Up to 2017	AVM (Around View Monitor)	Special Function	Select Language Of Warning Message
DFNISSAN	All Mode	Up to 2017	AVM (Around View Monitor)	Special Function	Predictive Course Line Display
DFNISSAN	All Mode	Up to 2017	AVM (Around View Monitor)	Special Function	Initialize Camera Image Calibration
DFNISSAN	All Mode	Up to 2017	AVM (Around View Monitor)	Special Function	Steering Angle Sensor Adjustment
DFNISSAN	All Mode	Up to 2017	AVM (Around View Monitor)	Special Function	Cause Of Entry Cancel
DFNISSAN	All Mode	Up to 2017	AVM (Around View Monitor)	Special Function	Mod Function
DFNISSAN	All Mode	Up to 2017	AVM (Around View Monitor)	Special Function	Parts With Door Mirror Auto Fold Func
DFNISSAN	All Mode	Up to 2017	AVM (Around View Monitor)	Special Function	Sonar Off Pop-Up Display Setting Change
DFNISSAN	All Mode	Up to 2017	AVM (Around View Monitor)	Special Function	Rear Camera ITS
DFNISSAN	All Mode	Up to 2017	AVM (Around View Monitor)	Special Function	Auto Lock Set
DFNISSAN	All Mode	Up to 2017	AVM (Around View Monitor)	Special Function	IGN/ACC Battery Saver
DFNISSAN	All Mode	Up to 2017	AVM (Around View Monitor)	Special Function	Short Cranking Output
DFNISSAN	All Mode	Up to 2017	AVM (Around View Monitor)	Special Function	Answer Back
DFNISSAN	All Mode	Up to 2017	AVM (Around View Monitor)	Special Function	Answer Back I-Key Lock Unlock
DFNISSAN	All Mode	Up to 2017	AVM (Around View Monitor)	Special Function	Answerback I-Key Lock Unlock
DFNISSAN	All Mode	Up to 2017	AVM (Around View Monitor)	Special Function	Answerback Keyless Lock Unlock
DFNISSAN	All Mode	Up to 2017	AVM (Around View Monitor)	Special Function	Welcome Light Op Set
DFNISSAN	All Mode	Up to 2017	AVM (Around View Monitor)	Special Function	Reset Setting Value
DFNISSAN	All Mode	Up to 2017	AVM (Around View Monitor)	Special Function	Confirm Dongle ID
DFNISSAN	All Mode	Up to 2017	AVM (Around View Monitor)	Special Function	
DFNISSAN	All Mode	Up to 2017	AVM (Around View Monitor)	Special Function	Auto Acc Fnctn (Audio/Nav) Set After Ign Off)

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
DFNISSAN	All Mode	2015 - 2016	AVM (Around View Monitor)	Read Fault Code	
DFNISSAN	All Mode	2015 - 2016	AVM (Around View Monitor)	Clear Fault Code	
DFNISSAN	All Mode	2015 - 2016	AVM (Around View Monitor)	Read Data Stream	
DFNISSAN	All Mode	2015 - 2016	AVM (Around View Monitor)	Module Information	
DFNISSAN	MURANO	2012	Chassis Control	Read Fault Code	
DFNISSAN	MURANO	2012	Chassis Control	Clear Fault Code	
DFNISSAN	MURANO	2012	Chassis Control	Read Data Stream	
DFNISSAN	MURANO	2012	Chassis Control	Module Information	
DFNISSAN	MURANO	2012	Chassis Control	Actuation Test	BRAKE ACTUATOR 1 MODE 1
DFNISSAN	MURANO	2012	Chassis Control	Actuation Test	BRAKE ACTUATOR 1 MODE 2
DFNISSAN	MURANO	2012	Chassis Control	Actuation Test	BRAKE ACTUATOR 1 MODE 3
DFNISSAN	MURANO	2012	Chassis Control	Actuation Test	BRAKE ACTUATOR 2 MODE 1
DFNISSAN	MURANO	2012	Chassis Control	Actuation Test	BRAKE ACTUATOR 2 MODE 2
DFNISSAN	MURANO	2012	Chassis Control	Actuation Test	BRAKE ACTUATOR 2 MODE 3
DFNISSAN	MURANO	2012	Chassis Control	Actuation Test	BRAKE ACTUATOR 3 MODE 1
DFNISSAN	MURANO	2012	Chassis Control	Actuation Test	BRAKE ACTUATOR 3 MODE 2
DFNISSAN	MURANO	2012	Chassis Control	Actuation Test	BRAKE ACTUATOR 3 MODE 3
DFNISSAN	MURANO	2012	Chassis Control	Actuation Test	ESS RELAY ACTIVE
DFNISSAN	MURANO	2012	Chassis Control	Actuation Test	ALC DISP
DFNISSAN	MURANO	2012	Chassis Control	Actuation Test	FR TIRE DISP
DFNISSAN	MURANO	2012	Chassis Control	Actuation Test	RR TIRE DISP
DFNISSAN	MURANO	2012	Chassis Control	Actuation Test	ESS ACTIVE
DFNISSAN	MURANO	2012	Chassis Control	Actuation Test	COMMAND STEERING ANGLE
DFNISSAN	MURANO	2012	Chassis Control	Actuation Test	COMMAND ST WHL FORCE
DFNISSAN	MURANO	2012	Chassis Control	Actuation Test	STOP LAMP OFF RELAY 1 ACTIVE
DFNISSAN	MURANO	2012	Chassis Control	Actuation Test	STOP LAMP OFF RELAY 2 ACTIVE
DFNISSAN	MURANO	2012	Chassis Control	Actuation Test	MASTER WARNING ACTIVE
DFNISSAN	MURANO	2012	Chassis Control	Actuation Test	HDC DISP
DFNISSAN	MURANO	2012	Chassis Control	Actuation Test	BRAKE HOLD DISP
DFNISSAN	MURANO	2012	Chassis Control	Actuation Test	AEB DISP
DFNISSAN	MURANO	2012	Chassis Control	Actuation Test	FL TIRE DISP
DFNISSAN	MURANO	2012	Chassis Control	Actuation Test	RL TIRE DISP
DFNISSAN	MURANO	2012	Chassis Control	Actuation Test	VEHICLE DISP
DFNISSAN	MURANO	2012	Chassis Control	Actuation Test	INTERRUPT DISP
DFNISSAN	MURANO	2012	Chassis Control	Actuation Test	TURN DISP
DFNISSAN	MURANO	2012	Chassis Control	Actuation Test	ALC LEVEL
DFNISSAN	MURANO	2012	Chassis Control	Actuation Test	ALC SETTING
DFNISSAN	MURANO	2012	Chassis Control	Actuation Test	ATC 1 DISP
DFNISSAN	MURANO	2012	Chassis Control	Actuation Test	ATC 2 DISP
DFNISSAN	MURANO	2012	Chassis Control	Actuation Test	ATC 3 DISP
DFNISSAN	MURANO	2012	Chassis Control	Actuation Test	ATC 4 DISP
DFNISSAN	MURANO	2012	Chassis Control	Actuation Test	ATC 5 DISP
DFNISSAN	MURANO	2012	Chassis Control	Actuation Test	ARC DISP
DFNISSAN	MURANO	2012	Chassis Control	Special Function	Erase Last Driver Information
DFNISSAN	MURANO	2012	Chassis Control	Special Function	Erase Key Allotement User
DFNISSAN	MURANO	2012	Chassis Control	Special Function	Erase Personal Setting
DFNISSAN	MURANO	2012	Chassis Control	Special Function	CAUSE OF AUTO-CANCEL 1
DFNISSAN	All Mode	2015 - 2015	Chassis Control	Read Fault Code	
DFNISSAN	All Mode	2015 - 2015	Chassis Control	Clear Fault Code	
DFNISSAN	All Mode	2015 - 2015	Chassis Control	Read Data Stream	
DFNISSAN	All Mode	2015 - 2015	Chassis Control	Module Information	
DFNISSAN	All Mode	2015 - 2015	Chassis Control	Special Function	Erase Last Driver Information
DFNISSAN	All Mode	2015 - 2015	Chassis Control	Special Function	Erase Key Allotement User
DFNISSAN	All Mode	2015 - 2015	Chassis Control	Special Function	Erase Personal Setting
DFNISSAN	All Mode	2015 - 2015	Chassis Control	Special Function	CAUSE OF AUTO-CANCEL 1
DFNISSAN	All Mode	2014 - 2017	Chassis Control	Read Fault Code	
DFNISSAN	All Mode	2014 - 2017	Chassis Control	Clear Fault Code	
DFNISSAN	All Mode	2014 - 2017	Chassis Control	Read Data Stream	
DFNISSAN	All Mode	2014 - 2017	Chassis Control	Module Information	
DFNISSAN	All Mode	2014 - 2017	Chassis Control	Special Function	Erase Last Driver Information
DFNISSAN	All Mode	2014 - 2017	Chassis Control	Special Function	Erase Key Allotement User
DFNISSAN	All Mode	2014 - 2017	Chassis Control	Special Function	Erase Personal Setting
DFNISSAN	All Mode	2014 - 2017	Chassis Control	Special Function	CAUSE OF AUTO-CANCEL 1
DFNISSAN	All Mode	2014 - 2015	Chassis Control	Read Fault Code	
DFNISSAN	All Mode	2014 - 2015	Chassis Control	Clear Fault Code	
DFNISSAN	All Mode	2014 - 2015	Chassis Control	Read Data Stream	
DFNISSAN	All Mode	2014 - 2015	Chassis Control	Module Information	
DFNISSAN	All Mode	2014 - 2015	Chassis Control	Special Function	Erase Last Driver Information
DFNISSAN	All Mode	2014 - 2015	Chassis Control	Special Function	Erase Key Allotement User
DFNISSAN	All Mode	2014 - 2015	Chassis Control	Special Function	Erase Personal Setting
DFNISSAN	All Mode	2014 - 2015	Chassis Control	Special Function	CAUSE OF AUTO-CANCEL 1
DFNISSAN	All Mode	2014 - 2016	Chassis Control	Read Fault Code	
DFNISSAN	All Mode	2014 - 2016	Chassis Control	Clear Fault Code	
DFNISSAN	All Mode	2014 - 2016	Chassis Control	Read Data Stream	

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
DFNISSAN	All Mode	2014 - 2016	Chassis Control	Module Information	
DFNISSAN	All Mode	2014 - 2016	Chassis Control	Special Function	Erase Last Driver Information
DFNISSAN	All Mode	2014 - 2016	Chassis Control	Special Function	Erase Key Allotement User
DFNISSAN	All Mode	2014 - 2016	Chassis Control	Special Function	Erase Personal Setting
DFNISSAN	All Mode	2014 - 2016	Chassis Control	Special Function	CAUSE OF AUTO-CANCEL 1
DFNISSAN	All Mode	2015 - 2015	Chassis Control	Read Fault Code	
DFNISSAN	All Mode	2015 - 2015	Chassis Control	Clear Fault Code	
DFNISSAN	All Mode	2015 - 2015	Chassis Control	Read Data Stream	
DFNISSAN	All Mode	2015 - 2015	Chassis Control	Module Information	
DFNISSAN	All Mode	2015 - 2015	Chassis Control	Special Function	Erase Last Driver Information
DFNISSAN	All Mode	2015 - 2015	Chassis Control	Special Function	Erase Key Allotement User
DFNISSAN	All Mode	2015 - 2015	Chassis Control	Special Function	Erase Personal Setting
DFNISSAN	All Mode	2015 - 2015	Chassis Control	Special Function	CAUSE OF AUTO-CANCEL 1
DFNISSAN	All Mode	2015 - 2016	Chassis Control	Read Fault Code	
DFNISSAN	All Mode	2015 - 2016	Chassis Control	Clear Fault Code	
DFNISSAN	All Mode	2015 - 2016	Chassis Control	Read Data Stream	
DFNISSAN	All Mode	2015 - 2016	Chassis Control	Module Information	
DFNISSAN	All Mode	2015 - 2016	Chassis Control	Special Function	Erase Last Driver Information
DFNISSAN	All Mode	2015 - 2016	Chassis Control	Special Function	Erase Key Allotement User
DFNISSAN	All Mode	2015 - 2016	Chassis Control	Special Function	Erase Personal Setting
DFNISSAN	All Mode	2015 - 2016	Chassis Control	Special Function	CAUSE OF AUTO-CANCEL 1
DFNISSAN	All Mode	2014 - 2016	DAST 1	Read Fault Code	
DFNISSAN	All Mode	2014 - 2016	DAST 1	Clear Fault Code	
DFNISSAN	All Mode	2014 - 2016	DAST 1	Read Data Stream	
DFNISSAN	All Mode	2014 - 2016	DAST 1	Module Information	
DFNISSAN	All Mode	2014 - 2016	DAST 2	Read Fault Code	
DFNISSAN	All Mode	2014 - 2016	DAST 2	Clear Fault Code	
DFNISSAN	All Mode	2014 - 2016	DAST 2	Read Data Stream	
DFNISSAN	All Mode	2014 - 2016	DAST 2	Module Information	
DFNISSAN	All Mode	2014 - 2016	High Beam Assist	Read Fault Code	
DFNISSAN	All Mode	2014 - 2016	High Beam Assist	Clear Fault Code	
DFNISSAN	All Mode	2014 - 2016	High Beam Assist	Read Data Stream	
DFNISSAN	All Mode	2014 - 2016	High Beam Assist	Module Information	
DFNISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Read Fault Code	
DFNISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Clear Fault Code	
DFNISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Read Data Stream	
DFNISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Module Information	
DFNISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Function Test	
DFNISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Special Function	Engine Brake ADJ
DFNISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Special Function	Conform CVTF Deteriortrn
DFNISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Special Function	ECO Mode Reset Function
DFNISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Special Function	G Sensor Calibration
DFNISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Special Function	Electric O. P. Air Bleeding
DFNISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Special Function	Calib Data
DFNISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Read Fault Code	
DFNISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Clear Fault Code	
DFNISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Read Data Stream	
DFNISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Module Information	
DFNISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Function Test	
DFNISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Special Function	Engine Brake ADJ
DFNISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Special Function	Conform CVTF Deteriortrn
DFNISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Special Function	ECO Mode Reset Function
DFNISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Special Function	Calib Data
DFNISSAN	All Mode	Up to 2016	TCM (Transmission Control Module)	Read Fault Code	
DFNISSAN	All Mode	Up to 2016	TCM (Transmission Control Module)	Clear Fault Code	
DFNISSAN	All Mode	Up to 2016	TCM (Transmission Control Module)	Read Data Stream	
DFNISSAN	All Mode	Up to 2016	TCM (Transmission Control Module)	Module Information	
DFNISSAN	All Mode	Up to 2016	TCM (Transmission Control Module)	Function Test	
DFNISSAN	All Mode	Up to 2016	TCM (Transmission Control Module)	Actuation Test	CLUTCH OPERATION TEST
DFNISSAN	All Mode	Up to 2016	TCM (Transmission Control Module)	Actuation Test	GEAR ENGAGE TEST
DFNISSAN	All Mode	Up to 2016	TCM (Transmission Control Module)	Special Function	MAX. CLTCH STRK MSRMNT
DFNISSAN	All Mode	Up to 2016	TCM (Transmission Control Module)	Special Function	Cltch Touchpoint Adjst
DFNISSAN	All Mode	Up to 2016	TCM (Transmission Control Module)	Special Function	TM ACTR SELF ADJST
DFNISSAN	All Mode	2008 - 2015	TCM (Transmission Control Module)	Read Fault Code	
DFNISSAN	All Mode	2008 - 2015	TCM (Transmission Control Module)	Clear Fault Code	
DFNISSAN	All Mode	2008 - 2015	TCM (Transmission Control Module)	Read Data Stream	
DFNISSAN	All Mode	2008 - 2015	TCM (Transmission Control Module)	Module Information	
DFNISSAN	All Mode	2008 - 2015	TCM (Transmission Control Module)	Function Test	
DFNISSAN	All Mode	2008 - 2015	TCM (Transmission Control Module)	Special Function	EEPROM CLEAR CONFIRM
DFNISSAN	All Mode	2008 - 2015	TCM (Transmission Control Module)	Special Function	G Sensor Calibration
DFNISSAN	All Mode	2008 - 2017	TCM (Transmission Control Module)	Read Fault Code	
DFNISSAN	All Mode	2008 - 2017	TCM (Transmission Control Module)	Clear Fault Code	
DFNISSAN	All Mode	2008 - 2017	TCM (Transmission Control Module)	Read Data Stream	
DFNISSAN	All Mode	2008 - 2017	TCM (Transmission Control Module)	Read Freeze Frame	
DFNISSAN	All Mode	2008 - 2017	TCM (Transmission Control Module)	Module Information	
DFNISSAN	All Mode	2008 - 2017	TCM (Transmission Control Module)	Function Test	
DFNISSAN	All Mode	2008 - 2017	TCM (Transmission Control Module)	Special Function	G Sensor Calibration

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
DFNISSAN	All Mode	2008 - 2017	TCM (Transmission Control Module)	Special Function	Calib Data
DFNISSAN	All Mode	2009 - 2017	TCM (Transmission Control Module)	Read Fault Code	
DFNISSAN	All Mode	2009 - 2017	TCM (Transmission Control Module)	Clear Fault Code	
DFNISSAN	All Mode	2009 - 2017	TCM (Transmission Control Module)	Read Data Stream	
DFNISSAN	All Mode	2009 - 2017	TCM (Transmission Control Module)	Read Freeze Frame	
DFNISSAN	All Mode	2009 - 2017	TCM (Transmission Control Module)	Module Information	
DFNISSAN	All Mode	2009 - 2017	TCM (Transmission Control Module)	Function Test	
DFNISSAN	All Mode	2009 - 2017	TCM (Transmission Control Module)	Special Function	Engine Brake ADJ
DFNISSAN	All Mode	2009 - 2017	TCM (Transmission Control Module)	Special Function	Conform CVTF Deteriortn
DFNISSAN	All Mode	2009 - 2017	TCM (Transmission Control Module)	Special Function	ECO Mode Reset Function
DFNISSAN	All Mode	2009 - 2017	TCM (Transmission Control Module)	Special Function	G Sensor Calibration
DFNISSAN	All Mode	2009 - 2017	TCM (Transmission Control Module)	Special Function	Erase Calibration Data
DFNISSAN	All Mode	2009 - 2017	TCM (Transmission Control Module)	Special Function	Erase Learning Value
DFNISSAN	All Mode	2009 - 2017	TCM (Transmission Control Module)	Special Function	Erase Memory Data
DFNISSAN	All Mode	2009 - 2017	TCM (Transmission Control Module)	Special Function	Clutch Point Learning
DFNISSAN	All Mode	2009 - 2017	TCM (Transmission Control Module)	Special Function	Electric O. P. Air Bleeding
DFNISSAN	All Mode	2009 - 2017	TCM (Transmission Control Module)	Special Function	Auxiliary gearbox clutch point learning
DFNISSAN	All Mode	2009 - 2017	TCM (Transmission Control Module)	Special Function	Calib Data
DFNISSAN	All Mode	2009 - 2014	TCM (Transmission Control Module)	Read Fault Code	
DFNISSAN	All Mode	2009 - 2014	TCM (Transmission Control Module)	Clear Fault Code	
DFNISSAN	All Mode	2009 - 2014	TCM (Transmission Control Module)	Read Data Stream	
DFNISSAN	All Mode	2009 - 2014	TCM (Transmission Control Module)	Module Information	
DFNISSAN	All Mode	2009 - 2014	TCM (Transmission Control Module)	Special Function	Erase Calibration Data
DFNISSAN	All Mode	2009 - 2014	TCM (Transmission Control Module)	Special Function	Erase Learning Value
DFNISSAN	All Mode	2009 - 2014	TCM (Transmission Control Module)	Special Function	Erase Memory Data
DFNISSAN	All Mode	2009 - 2014	TCM (Transmission Control Module)	Special Function	Calib Data
DFNISSAN	All Mode	Up to 2014	TCM (Transmission Control Module)	Read Fault Code	
DFNISSAN	All Mode	Up to 2014	TCM (Transmission Control Module)	Clear Fault Code	
DFNISSAN	All Mode	Up to 2014	TCM (Transmission Control Module)	Read Data Stream	
DFNISSAN	All Mode	Up to 2014	TCM (Transmission Control Module)	Module Information	
DFNISSAN	All Mode	Up to 2014	TCM (Transmission Control Module)	Function Test	
DFNISSAN	All Mode	Up to 2014	TCM (Transmission Control Module)	Special Function	Engine Brake ADJ
DFNISSAN	All Mode	Up to 2014	TCM (Transmission Control Module)	Special Function	Conform CVTF Deteriortn
DFNISSAN	All Mode	Up to 2014	TCM (Transmission Control Module)	Special Function	Calib Data
DFNISSAN	All Mode	Up to 2009	TCM (Transmission Control Module)	Read Fault Code	
DFNISSAN	All Mode	Up to 2009	TCM (Transmission Control Module)	Clear Fault Code	
DFNISSAN	All Mode	Up to 2009	TCM (Transmission Control Module)	Read Data Stream	
DFNISSAN	All Mode	Up to 2009	TCM (Transmission Control Module)	Read Freeze Frame	
DFNISSAN	All Mode	Up to 2009	TCM (Transmission Control Module)	Module Information	
DFNISSAN	All Mode	Up to 2009	TCM (Transmission Control Module)	Function Test	
DFNISSAN	All Mode	Up to 2009	TCM (Transmission Control Module)	Special Function	Initialization
DFNISSAN	All Mode	2012 - 2017	TCM (Transmission Control Module)	Read Fault Code	
DFNISSAN	All Mode	2012 - 2017	TCM (Transmission Control Module)	Clear Fault Code	
DFNISSAN	All Mode	2012 - 2017	TCM (Transmission Control Module)	Read Data Stream	
DFNISSAN	All Mode	2012 - 2017	TCM (Transmission Control Module)	Module Information	
DFNISSAN	All Mode	2012 - 2017	TCM (Transmission Control Module)	Actuation Test	CVT Oil Cooler Fan Circuit
DFNISSAN	All Mode	2012 - 2017	TCM (Transmission Control Module)	Special Function	Conform CVTF Deteriortn
DFNISSAN	All Mode	2012 - 2017	TCM (Transmission Control Module)	Special Function	G Sensor Calibration
DFNISSAN	All Mode	2012 - 2017	TCM (Transmission Control Module)	Special Function	Erase Learning Value
DFNISSAN	All Mode	2012 - 2017	TCM (Transmission Control Module)	Special Function	Engine Brake ADJ
DFNISSAN	All Mode	2012 - 2017	TCM (Transmission Control Module)	Special Function	FWD Clutch Point Learning
DFNISSAN	All Mode	2012 - 2017	TCM (Transmission Control Module)	Special Function	Clutch Point
DFNISSAN	All Mode	2012 - 2017	TCM (Transmission Control Module)	Special Function	Read IP Chara-Replacement TCM
DFNISSAN	All Mode	2012 - 2017	TCM (Transmission Control Module)	Special Function	Write IP Chara-Replacement TCM
DFNISSAN	All Mode	2012 - 2017	TCM (Transmission Control Module)	Special Function	Electric O. P. Air Bleeding
DFNISSAN	All Mode	2012 - 2017	TCM (Transmission Control Module)	Special Function	Erase Calibration Data
DFNISSAN	All Mode	2012 - 2017	TCM (Transmission Control Module)	Special Function	Erase Memory Data
DFNISSAN	All Mode	2012 - 2017	TCM (Transmission Control Module)	Special Function	CVT Inspection
DFNISSAN	All Mode	2012 - 2017	TCM (Transmission Control Module)	Special Function	Calib Data
DFNISSAN	All Mode	2014 - 2016	TCM (Transmission Control Module)	Read Fault Code	
DFNISSAN	All Mode	2014 - 2016	TCM (Transmission Control Module)	Clear Fault Code	
DFNISSAN	All Mode	2014 - 2016	TCM (Transmission Control Module)	Read Data Stream	
DFNISSAN	All Mode	2014 - 2016	TCM (Transmission Control Module)	Module Information	
DFNISSAN	All Mode	2014 - 2016	TCM (Transmission Control Module)	Special Function	Resetting Of Adaption Values
DFNISSAN	All Mode	2014 - 2016	TCM (Transmission Control Module)	Special Function	Reverse Gear Reset Of Adaption Values
DFNISSAN	All Mode	2014 - 2016	TCM (Transmission Control Module)	Special Function	TEACH IN OF SELECTION RANGE SENSOR
DFNISSAN	All Mode	2014 - 2016	TCM (Transmission Control Module)	Special Function	Adaption Values Of Shift Operations
DFNISSAN	All Mode	2014 - 2016	TCM (Transmission Control Module)	Special Function	Acceleration Downshift
DFNISSAN	All Mode	2014 - 2016	TCM (Transmission Control Module)	Special Function	Upshift
DFNISSAN	All Mode	2014 - 2016	TCM (Transmission Control Module)	Special Function	DOWNSHIFT
DFNISSAN	All Mode	2016 - 2016	TCM (Transmission Control Module)	Read Fault Code	
DFNISSAN	All Mode	2016 - 2016	TCM (Transmission Control Module)	Clear Fault Code	
DFNISSAN	All Mode	2016 - 2016	TCM (Transmission Control Module)	Read Data Stream	



**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
DFNISSAN	All Mode	2016 - 2016	TCM (Transmission Control Module)	Module Information	
DFNISSAN	All Mode	2016 - 2016	TCM (Transmission Control Module)	Special Function	Sensor actor calibration start
DFNISSAN	All Mode	2016 - 2016	TCM (Transmission Control Module)	Special Function	Saving Data For Replc CPU
DFNISSAN	All Mode	2016 - 2016	TCM (Transmission Control Module)	Special Function	Writing Data For Replc CPU
DFNISSAN	All Mode	2016 - 2016	TCM (Transmission Control Module)	Read Fault Code	
DFNISSAN	All Mode	2016 - 2016	TCM (Transmission Control Module)	Clear Fault Code	
DFNISSAN	All Mode	2016 - 2016	TCM (Transmission Control Module)	Read Data Stream	
DFNISSAN	All Mode	2016 - 2016	TCM (Transmission Control Module)	Module Information	
DFNISSAN	All Mode	2016 - 2016	TCM (Transmission Control Module)	Special Function	Reverse Gear Reset Of Adaption Values
DFNISSAN	All Mode	2016 - 2016	TCM (Transmission Control Module)	Special Function	REMOVE ADAPTATIONS VALUE OF SHIFT OPERATIONS
DFNISSAN	All Mode	2016 - 2016	TCM (Transmission Control Module)	Special Function	TEACH IN OF SELECTION RANGE SENSOR
DFNISSAN	All Mode	2012 - 2017	TCM (Transmission Control Module)	Read Fault Code	
DFNISSAN	All Mode	2012 - 2017	TCM (Transmission Control Module)	Clear Fault Code	
DFNISSAN	All Mode	2012 - 2017	TCM (Transmission Control Module)	Read Data Stream	
DFNISSAN	All Mode	2012 - 2017	TCM (Transmission Control Module)	Module Information	
DFNISSAN	All Mode	2012 - 2017	TCM (Transmission Control Module)	Special Function	G Sensor Calibration
DFNISSAN	All Mode	2012 - 2017	TCM (Transmission Control Module)	Special Function	Erase Calibration Data
DFNISSAN	All Mode	2012 - 2017	TCM (Transmission Control Module)	Special Function	Erase Learning Value
DFNISSAN	All Mode	2012 - 2017	TCM (Transmission Control Module)	Special Function	Erase Memory Data
DFNISSAN	All Mode	2012 - 2017	TCM (Transmission Control Module)	Special Function	FWD Clutch Point Learning
DFNISSAN	All Mode	2012 - 2017	TCM (Transmission Control Module)	Special Function	Electric O. P. Air Bleeding
DFNISSAN	All Mode	2012 - 2017	TCM (Transmission Control Module)	Special Function	Engine Brake ADJ
DFNISSAN	All Mode	2012 - 2017	TCM (Transmission Control Module)	Special Function	Conform CVTF Deteriortn
DFNISSAN	All Mode	2012 - 2017	TCM (Transmission Control Module)	Special Function	Calib Data
DFNISSAN	All Mode	2012 - 2016	TCM (Transmission Control Module)	Read Fault Code	
DFNISSAN	All Mode	2012 - 2016	TCM (Transmission Control Module)	Clear Fault Code	
DFNISSAN	All Mode	2012 - 2016	TCM (Transmission Control Module)	Read Data Stream	
DFNISSAN	All Mode	2012 - 2016	TCM (Transmission Control Module)	Module Information	
DFNISSAN	All Mode	2012 - 2016	TCM (Transmission Control Module)	Special Function	G Sensor Calibration
DFNISSAN	All Mode	2012 - 2016	TCM (Transmission Control Module)	Special Function	Calib Data
DFNISSAN	All Mode	2014 - 2016	TCM (Transmission Control Module)	Read Fault Code	
DFNISSAN	All Mode	2014 - 2016	TCM (Transmission Control Module)	Clear Fault Code	
DFNISSAN	All Mode	2014 - 2016	TCM (Transmission Control Module)	Read Data Stream	
DFNISSAN	All Mode	2014 - 2016	TCM (Transmission Control Module)	Module Information	
DFNISSAN	All Mode	2014 - 2016	TCM (Transmission Control Module)	Actuation Test	CVT Oil Cooler Fan Circuit
DFNISSAN	All Mode	2014 - 2016	TCM (Transmission Control Module)	Special Function	Conform CVTF Deteriortn
DFNISSAN	All Mode	2014 - 2016	TCM (Transmission Control Module)	Special Function	Erase Memory Data
DFNISSAN	All Mode	2014 - 2016	TCM (Transmission Control Module)	Special Function	Erase Learning Value
DFNISSAN	All Mode	2014 - 2016	TCM (Transmission Control Module)	Special Function	Read IP Chara-Replacement TCM
DFNISSAN	All Mode	2014 - 2016	TCM (Transmission Control Module)	Special Function	Write IP Chara-Replacement TCM
DFNISSAN	All Mode	2014 - 2016	TCM (Transmission Control Module)	Special Function	Calib Data
DFNISSAN	All Mode	2013 - 2017	TCM (Transmission Control Module)	Read Fault Code	
DFNISSAN	All Mode	2013 - 2017	TCM (Transmission Control Module)	Clear Fault Code	
DFNISSAN	All Mode	2013 - 2017	TCM (Transmission Control Module)	Read Data Stream	
DFNISSAN	All Mode	2013 - 2017	TCM (Transmission Control Module)	Module Information	
DFNISSAN	All Mode	2013 - 2017	TCM (Transmission Control Module)	Special Function	Auxiliary gearbox clutch point learning
DFNISSAN	All Mode	2013 - 2017	TCM (Transmission Control Module)	Special Function	Conform CVTF Deteriortn
DFNISSAN	All Mode	2013 - 2017	TCM (Transmission Control Module)	Special Function	Engine Brake ADJ
DFNISSAN	All Mode	2013 - 2017	TCM (Transmission Control Module)	Special Function	G Sensor Calibration
DFNISSAN	All Mode	2013 - 2017	TCM (Transmission Control Module)	Special Function	Erase Calibration Data
DFNISSAN	All Mode	2013 - 2017	TCM (Transmission Control Module)	Special Function	Erase Learning Value
DFNISSAN	All Mode	2013 - 2017	TCM (Transmission Control Module)	Special Function	Erase Memory Data
DFNISSAN	All Mode	2013 - 2017	TCM (Transmission Control Module)	Special Function	FWD Clutch Point Learning
DFNISSAN	All Mode	2013 - 2017	TCM (Transmission Control Module)	Special Function	ELECTRIC O. P. AIR BLEEDING
DFNISSAN	All Mode	2013 - 2017	TCM (Transmission Control Module)	Special Function	Calib Data
DFNISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Read Fault Code	
DFNISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Clear Fault Code	
DFNISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Read Data Stream	
DFNISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Module Information	
DFNISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Special Function	
DFNISSAN	All Mode	2009 - 2016	TCM (Transmission Control Module)	Module Information	
DFNISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Read Fault Code	
DFNISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Clear Fault Code	
DFNISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Read Data Stream	
DFNISSAN	All Mode	Up to 2017	TCM (Transmission Control Module)	Module Information	
DFNISSAN	All Mode	Up to 2009	TCM (Transmission Control Module)	Read Fault Code	
DFNISSAN	All Mode	Up to 2009	TCM (Transmission Control Module)	Clear Fault Code	
DFNISSAN	All Mode	Up to 2009	TCM (Transmission Control Module)	Read Data Stream	
DFNISSAN	All Mode	Up to 2009	TCM (Transmission Control Module)	Module Information	
DFNISSAN	All Mode	Up to 2009	TCM (Transmission Control Module)	Special Function	ENGINE BRAKE ADJ.
DFNISSAN	All Mode	Up to 2009	TCM (Transmission Control Module)	Read Fault Code	
DFNISSAN	All Mode	Up to 2009	TCM (Transmission Control Module)	Clear Fault Code	
DFNISSAN	All Mode	Up to 2009	TCM (Transmission Control Module)	Read Data Stream	



**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
DFNISSAN	All Mode	2009 - 2016	BCM (Body Control Module)	Read Data Stream	
DFNISSAN	All Mode	2009 - 2016	BCM (Body Control Module)	Read Freeze Frame	
DFNISSAN	All Mode	2009 - 2016	BCM (Body Control Module)	Module Information	
DFNISSAN	All Mode	2009 - 2016	BCM (Body Control Module)	Actuation Test	Door Lock
DFNISSAN	All Mode	2009 - 2016	BCM (Body Control Module)	Actuation Test	Super Lock
DFNISSAN	All Mode	2009 - 2016	BCM (Body Control Module)	Actuation Test	REAR DOOR UNLOCK TEST
DFNISSAN	All Mode	2009 - 2016	BCM (Body Control Module)	Actuation Test	Door Lock Ind
DFNISSAN	All Mode	2009 - 2016	BCM (Body Control Module)	Actuation Test	Rear Defogger
DFNISSAN	All Mode	2009 - 2016	BCM (Body Control Module)	Actuation Test	IGN KEY WARN ALM
DFNISSAN	All Mode	2009 - 2016	BCM (Body Control Module)	Actuation Test	Seat Belt Warn Test
DFNISSAN	All Mode	2009 - 2016	BCM (Body Control Module)	Actuation Test	Key Reminder Warn
DFNISSAN	All Mode	2009 - 2016	BCM (Body Control Module)	Actuation Test	ID REGIST WARNING
DFNISSAN	All Mode	2009 - 2016	BCM (Body Control Module)	Actuation Test	Light Warn Alm
DFNISSAN	All Mode	2009 - 2016	BCM (Body Control Module)	Actuation Test	Reverse Warning
DFNISSAN	All Mode	2009 - 2016	BCM (Body Control Module)	Actuation Test	RUN FLAT/T WARN BUZZER
DFNISSAN	All Mode	2009 - 2016	BCM (Body Control Module)	Actuation Test	Step Lamp Test
DFNISSAN	All Mode	2009 - 2016	BCM (Body Control Module)	Actuation Test	Int Lamp
DFNISSAN	All Mode	2009 - 2016	BCM (Body Control Module)	Actuation Test	LUGGAGE LAMP TEST
DFNISSAN	All Mode	2009 - 2016	BCM (Body Control Module)	Actuation Test	Tail Lamp
DFNISSAN	All Mode	2009 - 2016	BCM (Body Control Module)	Actuation Test	Head Lamp
DFNISSAN	All Mode	2009 - 2016	BCM (Body Control Module)	Actuation Test	FR FOG Lamp
DFNISSAN	All Mode	2009 - 2016	BCM (Body Control Module)	Actuation Test	RR FOG Lamp
DFNISSAN	All Mode	2009 - 2016	BCM (Body Control Module)	Actuation Test	Daytime Running Light
DFNISSAN	All Mode	2009 - 2016	BCM (Body Control Module)	Actuation Test	Cornering Lamp
DFNISSAN	All Mode	2009 - 2016	BCM (Body Control Module)	Actuation Test	ILL DIM Signal
DFNISSAN	All Mode	2009 - 2016	BCM (Body Control Module)	Actuation Test	FR Wiper
DFNISSAN	All Mode	2009 - 2016	BCM (Body Control Module)	Actuation Test	Head Lamp Washer
DFNISSAN	All Mode	2009 - 2016	BCM (Body Control Module)	Actuation Test	RR Wiper
DFNISSAN	All Mode	2009 - 2016	BCM (Body Control Module)	Actuation Test	Flasher
DFNISSAN	All Mode	2009 - 2016	BCM (Body Control Module)	Actuation Test	SIREN
DFNISSAN	All Mode	2009 - 2016	BCM (Body Control Module)	Actuation Test	Theft IND
DFNISSAN	All Mode	2009 - 2016	BCM (Body Control Module)	Actuation Test	PW REMOTO DOWN SET
DFNISSAN	All Mode	2009 - 2016	BCM (Body Control Module)	Actuation Test	Battery Saver
DFNISSAN	All Mode	2009 - 2016	BCM (Body Control Module)	Actuation Test	Outside Buzzer
DFNISSAN	All Mode	2009 - 2016	BCM (Body Control Module)	Actuation Test	Inside Buzzer
DFNISSAN	All Mode	2009 - 2016	BCM (Body Control Module)	Actuation Test	Indicator
DFNISSAN	All Mode	2009 - 2016	BCM (Body Control Module)	Actuation Test	LCD
DFNISSAN	All Mode	2009 - 2016	BCM (Body Control Module)	Actuation Test	Horn
DFNISSAN	All Mode	2009 - 2016	BCM (Body Control Module)	Actuation Test	P Range
DFNISSAN	All Mode	2009 - 2016	BCM (Body Control Module)	Actuation Test	Engine SW Illumi
DFNISSAN	All Mode	2009 - 2016	BCM (Body Control Module)	Actuation Test	Lock Indicator
DFNISSAN	All Mode	2009 - 2016	BCM (Body Control Module)	Actuation Test	ACC Indicator
DFNISSAN	All Mode	2009 - 2016	BCM (Body Control Module)	Actuation Test	Ignition ON IND
DFNISSAN	All Mode	2009 - 2016	BCM (Body Control Module)	Actuation Test	Key Slot Illumi
DFNISSAN	All Mode	2009 - 2016	BCM (Body Control Module)	Actuation Test	Trunk/Back Door
DFNISSAN	All Mode	2009 - 2016	BCM (Body Control Module)	Actuation Test	KEYLESS PW UP/DOWN
DFNISSAN	All Mode	2009 - 2016	BCM (Body Control Module)	Actuation Test	Trunk/Glass Hatch
DFNISSAN	All Mode	2009 - 2016	BCM (Body Control Module)	Actuation Test	Vehicle Security Horn
DFNISSAN	All Mode	2009 - 2016	BCM (Body Control Module)	Actuation Test	Head Lamp(HI)
DFNISSAN	All Mode	2009 - 2016	BCM (Body Control Module)	Actuation Test	OIL Pressure SW
DFNISSAN	All Mode	2009 - 2016	BCM (Body Control Module)	Actuation Test	Warning Lamp
DFNISSAN	All Mode	2009 - 2016	BCM (Body Control Module)	Actuation Test	RUN FLAT TIER W/L
DFNISSAN	All Mode	2009 - 2016	BCM (Body Control Module)	Special Function	D/LOCK VHCL SPD AJT
DFNISSAN	All Mode	2009 - 2016	BCM (Body Control Module)	Special Function	Door Lock-Unlock Set
DFNISSAN	All Mode	2009 - 2016	BCM (Body Control Module)	Special Function	Set I/L D-Unlock Intcon
DFNISSAN	All Mode	2009 - 2016	BCM (Body Control Module)	Special Function	Room Lamp Timer Set
DFNISSAN	All Mode	2009 - 2016	BCM (Body Control Module)	Special Function	Room Lamp On Time Set
DFNISSAN	All Mode	2009 - 2016	BCM (Body Control Module)	Special Function	Room Lamp BAT SAV SET
DFNISSAN	All Mode	2009 - 2016	BCM (Body Control Module)	Special Function	Room Lamp Off Time Set
DFNISSAN	All Mode	2009 - 2016	BCM (Body Control Module)	Special Function	R Lamp Timer Logic Set
DFNISSAN	All Mode	2009 - 2016	BCM (Body Control Module)	Special Function	Room Lamp On At Lock
DFNISSAN	All Mode	2009 - 2016	BCM (Body Control Module)	Special Function	Battery Saver Set
DFNISSAN	All Mode	2009 - 2016	BCM (Body Control Module)	Special Function	Custom A/Light Setting
DFNISSAN	All Mode	2009 - 2016	BCM (Body Control Module)	Special Function	ILL Delay Set
DFNISSAN	All Mode	2009 - 2016	BCM (Body Control Module)	Special Function	Wiper Speed Setting
DFNISSAN	All Mode	2009 - 2016	BCM (Body Control Module)	Special Function	HAZARD LAMP SET
DFNISSAN	All Mode	2009 - 2016	BCM (Body Control Module)	Special Function	Hazard Answer Back
DFNISSAN	All Mode	2009 - 2016	BCM (Body Control Module)	Special Function	Reset Setting Value
DFNISSAN	All Mode	2009 - 2016	BCM (Body Control Module)	Special Function	Security Alarm SET
DFNISSAN	All Mode	2009 - 2016	BCM (Body Control Module)	Special Function	Theft ALM TRG
DFNISSAN	All Mode	2009 - 2016	BCM (Body Control Module)	Special Function	SIREN SET
DFNISSAN	All Mode	2009 - 2016	BCM (Body Control Module)	Special Function	Retained PWR Set
DFNISSAN	All Mode	2009 - 2016	BCM (Body Control Module)	Special Function	REMO CONT ID CONFIR
DFNISSAN	All Mode	2009 - 2016	BCM (Body Control Module)	Special Function	Welcome Light Op Set
DFNISSAN	All Mode	2009 - 2016	BCM (Body Control Module)	Special Function	Lock/Unlock By I-Key
DFNISSAN	All Mode	2009 - 2016	BCM (Body Control Module)	Special Function	Engine Start By I-Key
DFNISSAN	All Mode	2009 - 2016	BCM (Body Control Module)	Special Function	Trunk/Glass Hatch Open
DFNISSAN	All Mode	2009 - 2016	BCM (Body Control Module)	Special Function	Answer Back Function
DFNISSAN	All Mode	2009 - 2016	BCM (Body Control Module)	Special Function	Panic Alarm Set
DFNISSAN	All Mode	2009 - 2016	BCM (Body Control Module)	Special Function	Take Out From Win Warn

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
DFNISSAN	All Mode	2009 - 2016	BCM (Body Control Module)	Special Function	Pw Down Set
DFNISSAN	All Mode	2009 - 2016	BCM (Body Control Module)	Special Function	Trunk Open Delay
DFNISSAN	All Mode	2009 - 2016	BCM (Body Control Module)	Special Function	LO-BATT OF KEY FOB WARN
DFNISSAN	All Mode	2009 - 2016	BCM (Body Control Module)	Special Function	Keyless Function
DFNISSAN	All Mode	2009 - 2016	BCM (Body Control Module)	Special Function	Anti Key Lock In Function
DFNISSAN	All Mode	2009 - 2016	BCM (Body Control Module)	Special Function	Ans Back I-Key Lock
DFNISSAN	All Mode	2009 - 2016	BCM (Body Control Module)	Special Function	Ans Back I-Key Unlock
DFNISSAN	All Mode	2009 - 2016	BCM (Body Control Module)	Special Function	Short Cranking Output
DFNISSAN	All Mode	2009 - 2016	BCM (Body Control Module)	Special Function	Inside ANT Diagnosis
DFNISSAN	All Mode	2009 - 2016	BCM (Body Control Module)	Special Function	Horn With Keyless Lock
DFNISSAN	All Mode	2009 - 2016	BCM (Body Control Module)	Special Function	Welcome Light Select
DFNISSAN	All Mode	2009 - 2016	BCM (Body Control Module)	Special Function	Confirm Dongle ID
DFNISSAN	All Mode	2009 - 2016	BCM (Body Control Module)	Special Function	Automatic Door Lock Select
DFNISSAN	All Mode	2009 - 2016	BCM (Body Control Module)	Special Function	HORN CHIRP SET
DFNISSAN	All Mode	2009 - 2016	BCM (Body Control Module)	Special Function	Auto Lock Set
DFNISSAN	All Mode	2009 - 2016	BCM (Body Control Module)	Special Function	Automatic Door Unlock Select
DFNISSAN	All Mode	2009 - 2016	BCM (Body Control Module)	Special Function	Automatic Door Lock/Unlock Select
DFNISSAN	All Mode	2009 - 2016	BCM (Body Control Module)	Special Function	ID REGIST
DFNISSAN	All Mode	2009 - 2016	BCM (Body Control Module)	Special Function	ID READ
DFNISSAN	All Mode	2009 - 2016	BCM (Body Control Module)	Special Function	Confirm Key Fob ID
DFNISSAN	All Mode	2011 - 2016	Engine	Read Fault Code	
DFNISSAN	All Mode	2011 - 2016	Engine	Clear Fault Code	
DFNISSAN	All Mode	2011 - 2016	Engine	Read Data Stream	
DFNISSAN	All Mode	2011 - 2016	Engine	Module Information	
DFNISSAN	All Mode	2011 - 2016	Engine	Special Function	INJ ADJ VAL REGIST
DFNISSAN	All Mode	2011 - 2016	Engine	Special Function	P062F EXCLUSIVE FUNCTION
DFNISSAN	All Mode	2011 - 2016	Engine	Special Function	LEARNING
DFNISSAN	All Mode	2011 - 2016	Engine	Special Function	EGR/V LEARN CLR
DFNISSAN	All Mode	2011 - 2016	Engine	Special Function	ZFC VALUE RESET
DFNISSAN	All Mode	2011 - 2016	Engine	Special Function	DPF Data Clear
DFNISSAN	All Mode	2011 - 2016	Engine	Special Function	Service Regeneration
DFNISSAN	All Mode	2009 - 2016	Engine	Read Fault Code	
DFNISSAN	All Mode	2009 - 2016	Engine	Clear Fault Code	
DFNISSAN	All Mode	2009 - 2016	Engine	Read Data Stream	
DFNISSAN	All Mode	2009 - 2016	Engine	Module Information	
DFNISSAN	All Mode	2009 - 2016	Engine	Actuation Test	VENT CONTROL/V
DFNISSAN	All Mode	2009 - 2016	Engine	Actuation Test	Fuel/T Temp SEN
DFNISSAN	All Mode	2009 - 2016	Engine	Actuation Test	Decontamination Flow Control Solenoid Valve
DFNISSAN	All Mode	2009 - 2016	Engine	Actuation Test	FAN DUTY CONTROL
DFNISSAN	All Mode	2009 - 2016	Engine	Actuation Test	IGNITION TIMING
DFNISSAN	All Mode	2009 - 2016	Engine	Actuation Test	Fuel Pump Control Module
DFNISSAN	All Mode	2009 - 2016	Engine	Actuation Test	Sub Fuel Pump Relay
DFNISSAN	All Mode	2009 - 2016	Engine	Actuation Test	Electric Control Silencer
DFNISSAN	All Mode	2009 - 2016	Engine	Special Function	Fuel Pressure Relief
DFNISSAN	All Mode	2009 - 2016	Engine	Special Function	Self-Learning Control
DFNISSAN	All Mode	2009 - 2016	Engine	Special Function	ECT History
DFNISSAN	All Mode	2009 - 2016	Engine	Special Function	Eng Oil Temp History
DFNISSAN	All Mode	2009 - 2016	Engine	Special Function	ECT History Clear
DFNISSAN	All Mode	2009 - 2016	Engine	Special Function	ENG OIL Temp History Clear
DFNISSAN	All Mode	2009 - 2016	Engine	Special Function	TARGET IGN TIM ADJ
DFNISSAN	All Mode	2009 - 2016	Engine	Special Function	TARGET IDLE RPM ADJ
DFNISSAN	All Mode	2009 - 2016	E-SUS (Electric Suspension)	Read Fault Code	
DFNISSAN	All Mode	2009 - 2016	E-SUS (Electric Suspension)	Clear Fault Code	
DFNISSAN	All Mode	2009 - 2016	E-SUS (Electric Suspension)	Read Data Stream	
DFNISSAN	All Mode	2009 - 2016	E-SUS (Electric Suspension)	Module Information	
DFNISSAN	All Mode	2009 - 2016	E-SUS (Electric Suspension)	Actuation Test	FRONT RIGHT ACTUATOR
DFNISSAN	All Mode	2009 - 2016	E-SUS (Electric Suspension)	Actuation Test	FRONT LEFT ACTUATOR
DFNISSAN	All Mode	2009 - 2016	E-SUS (Electric Suspension)	Actuation Test	REAR RIGHT ACTUATOR
DFNISSAN	All Mode	2009 - 2016	E-SUS (Electric Suspension)	Actuation Test	REAR LEFT ACTUATOR
DFNISSAN	All Mode	2009 - 2016	E-SUS (Electric Suspension)	Actuation Test	Mode Lamp
DFNISSAN	All Mode	2009 - 2017	Multi AV	Read Fault Code	
DFNISSAN	All Mode	2009 - 2017	Multi AV	Clear Fault Code	
DFNISSAN	All Mode	2009 - 2017	Multi AV	Read Data Stream	
DFNISSAN	All Mode	2009 - 2017	Multi AV	Module Information	
DFNISSAN	All Mode	2009 - 2017	Multi AV	Special Function	SELF-DIAG[ETC]
DFNISSAN	All Mode	Up to 2011	TCM (Transmission Control Module)	Read Fault Code	
DFNISSAN	All Mode	Up to 2011	TCM (Transmission Control Module)	Clear Fault Code	
DFNISSAN	All Mode	Up to 2011	TCM (Transmission Control Module)	Read Data Stream	
DFNISSAN	All Mode	Up to 2011	TCM (Transmission Control Module)	Read Fault Code	
DFNISSAN	All Mode	Up to 2011	TCM (Transmission Control Module)	Clear Fault Code	
DFNISSAN	All Mode	Up to 2011	TCM (Transmission Control Module)	Read Data Stream	
DFNISSAN	All Mode	Up to 2016	TCM (Transmission Control Module)	Read Fault Code	
DFNISSAN	All Mode	Up to 2016	TCM (Transmission Control Module)	Clear Fault Code	
DFNISSAN	All Mode	Up to 2016	TCM (Transmission Control Module)	Read Data Stream	
DFNISSAN	All Mode	Up to 2016	TCM (Transmission Control Module)	Actuation Test	SHIFT S/V 1
DFNISSAN	All Mode	Up to 2016	TCM (Transmission Control Module)	Actuation Test	SHIFT S/V 2
DFNISSAN	All Mode	Up to 2016	TCM (Transmission Control Module)	Actuation Test	SHIFT S/V 3

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
DFNISSAN	All Mode	Up to 2016	TCM (Transmission Control Module)	Actuation Test	SHIFT S/V 4
DFNISSAN	All Mode	Up to 2016	TCM (Transmission Control Module)	Actuation Test	SEQUENCE S/V
DFNISSAN	All Mode	Up to 2016	TCM (Transmission Control Module)	Actuation Test	LINE PRESS S/V
DFNISSAN	All Mode	Up to 2016	TCM (Transmission Control Module)	Actuation Test	C/L B PRESS S/V
DFNISSAN	All Mode	Up to 2016	TCM (Transmission Control Module)	Actuation Test	C/L A PRESS S/V
DFNISSAN	All Mode	Up to 2016	TCM (Transmission Control Module)	Actuation Test	LUBRICATION FLOW-RATE S/V
DFNISSAN	All Mode	Up to 2016	TCM (Transmission Control Module)	Actuation Test	A-AXIS SUPPLY PRESSURE S/V
DFNISSAN	All Mode	Up to 2016	TCM (Transmission Control Module)	Actuation Test	B-AXIS SUPPLY PRESSURE S/V
DFNISSAN	All Mode	Up to 2016	TCM (Transmission Control Module)	Actuation Test	STARTER RELAY
DFNISSAN	All Mode	Up to 2016	TCM (Transmission Control Module)	Actuation Test	REVERSE LAMP RELAY
DFNISSAN	All Mode	Up to 2016	TCM (Transmission Control Module)	Actuation Test	TCM RELAY
DFNISSAN	All Mode	Up to 2016	TCM (Transmission Control Module)	Actuation Test	SHIFT LOCK SOL
DFNISSAN	All Mode	Up to 2016	TCM (Transmission Control Module)	Special Function	Clutch Gear Learning
DFNISSAN	All Mode	Up to 2016	TCM (Transmission Control Module)	Special Function	Disengaging The Gear
DFNISSAN	All Mode	Up to 2016	TCM (Transmission Control Module)	Special Function	Gear Position Test
DFNISSAN	All Mode	Up to 2016	TCM (Transmission Control Module)	Special Function	Read Clutch Gear Learning Data
DFNISSAN	All Mode	Up to 2016	TCM (Transmission Control Module)	Special Function	Show Oil Temp History
DFNISSAN	All Mode	Up to 2016	TCM (Transmission Control Module)	Special Function	High Oil Temp Warning History
DFNISSAN	All Mode	Up to 2016	TCM (Transmission Control Module)	Special Function	Delete Gear Position Learning Value
DFNISSAN	All Mode	Up to 2016	TCM (Transmission Control Module)	Special Function	Delete Clutch A Learning Value
DFNISSAN	All Mode	Up to 2016	TCM (Transmission Control Module)	Special Function	Delete Clutch B Learning Value
DFNISSAN	All Mode	Up to 2016	TCM (Transmission Control Module)	Special Function	Write Previous Clutch Learning Value
DFNISSAN	All Mode	Up to 2016	TCM (Transmission Control Module)	Special Function	Erase Cltch Enggmt Prsr Crctn
DFNISSAN	All Mode	Up to 2016	TCM (Transmission Control Module)	Special Function	OIL Temp History Reset
DFNISSAN	All Mode	Up to 2016	TCM (Transmission Control Module)	Special Function	Adjust Clutch A Capacity
DFNISSAN	All Mode	Up to 2016	TCM (Transmission Control Module)	Special Function	Adjust Clutch B Capacity
DFNISSAN	All Mode	Up to 2016	TCM (Transmission Control Module)	Special Function	Clutch A Touch Point
DFNISSAN	All Mode	Up to 2016	TCM (Transmission Control Module)	Special Function	Clutch B Touch Point
INFINITI	All Mode	Up to 2018	Engine	Read Fault Code	
INFINITI	All Mode	Up to 2018	Engine	Clear Fault Code	
INFINITI	All Mode	Up to 2018	Engine	Read Data Stream	
INFINITI	All Mode	Up to 2018	Engine	Read Freeze Frame	
INFINITI	All Mode	Up to 2018	Engine	Module Information	
INFINITI	All Mode	Up to 2018	Engine	Function Test	
INFINITI	All Mode	Up to 2018	Engine	Actuation Test	IACV-AAC/V OPENING
INFINITI	All Mode	Up to 2018	Engine	Actuation Test	EGR CONT(MODE 1)
INFINITI	All Mode	Up to 2018	Engine	Actuation Test	TARGET FAN RPM
INFINITI	All Mode	Up to 2018	Engine	Actuation Test	EGRC SOLENOID VALVE
INFINITI	All Mode	Up to 2018	Engine	Actuation Test	P/REG CONT SOL/V
INFINITI	All Mode	Up to 2018	Engine	Actuation Test	VALVE TIMING SOL
INFINITI	All Mode	Up to 2018	Engine	Actuation Test	SWIRL CONT SOL VALVE
INFINITI	All Mode	Up to 2018	Engine	Actuation Test	AIR COND RLY
INFINITI	All Mode	Up to 2018	Engine	Actuation Test	VVL S/V
INFINITI	All Mode	Up to 2018	Engine	Actuation Test	INTAKE DUCT S/V
INFINITI	All Mode	Up to 2018	Engine	Actuation Test	MAP/BARO SW/V
INFINITI	All Mode	Up to 2018	Engine	Actuation Test	VC/V BYPASS/V
INFINITI	All Mode	Up to 2018	Engine	Actuation Test	Power Balance
INFINITI	All Mode	Up to 2018	Engine	Actuation Test	VENT CONT/V
INFINITI	All Mode	Up to 2018	Engine	Actuation Test	ENG COOLANT TEMP
INFINITI	All Mode	Up to 2018	Engine	Actuation Test	FUEL INJECTION
INFINITI	All Mode	Up to 2018	Engine	Actuation Test	Fuel/T Temp SEN
INFINITI	All Mode	Up to 2018	Engine	Actuation Test	PURG VOL CONT/V
INFINITI	All Mode	Up to 2018	Engine	Actuation Test	Fuel Pump Relay
INFINITI	All Mode	Up to 2018	Engine	Actuation Test	IGNITION TIMING
INFINITI	All Mode	Up to 2018	Engine	Actuation Test	V/T ASSIGN ANGLE
INFINITI	All Mode	Up to 2018	Engine	Actuation Test	VIAS S/V-1
INFINITI	All Mode	Up to 2018	Engine	Actuation Test	ENGINE MOUNT
INFINITI	All Mode	Up to 2018	Engine	Actuation Test	TUMBLE CONTROL VALVE
INFINITI	All Mode	Up to 2018	Engine	Actuation Test	FAN DUTY CONTROL
INFINITI	All Mode	Up to 2018	Engine	Actuation Test	ALTERNATOR DUTY
INFINITI	All Mode	Up to 2018	Engine	Actuation Test	VIAS S/V-2
INFINITI	All Mode	Up to 2018	Engine	Actuation Test	INT V/T ASSIGN ANGLE
INFINITI	All Mode	Up to 2018	Engine	Actuation Test	EXH V/T ASSIGN ANGLE
INFINITI	All Mode	Up to 2018	Engine	Actuation Test	COOLING FAN
INFINITI	All Mode	Up to 2018	Engine	Actuation Test	FPCM
INFINITI	All Mode	Up to 2018	Engine	Actuation Test	SUB FUEL CONT SOL/V
INFINITI	All Mode	Up to 2018	Engine	Actuation Test	Sub Fuel Pump Relay
INFINITI	All Mode	Up to 2018	Engine	Actuation Test	FUEL RETURN VALVA
INFINITI	All Mode	Up to 2018	Engine	Actuation Test	ALTERNATOR VOLTAGE
INFINITI	All Mode	Up to 2018	Engine	Actuation Test	Auto Stop Start
INFINITI	All Mode	Up to 2018	Engine	Actuation Test	FUEL SHUTOFF VALVE 1
INFINITI	All Mode	Up to 2018	Engine	Actuation Test	FUEL SHUTOFF VALVE 2
INFINITI	All Mode	Up to 2018	Engine	Actuation Test	FUEL SHUTOFF VALVE 3

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
INFINITI	All Mode	Up to 2018	Engine	Actuation Test	FUEL SHUTOFF VALVE
INFINITI	All Mode	Up to 2018	Engine	Actuation Test	FP RELAY2
INFINITI	All Mode	Up to 2018	Engine	Actuation Test	FP RELAY3
INFINITI	All Mode	Up to 2018	Engine	Actuation Test	EGR VOL CONT/V
INFINITI	All Mode	Up to 2018	Engine	Actuation Test	Pres Regulator
INFINITI	All Mode	Up to 2018	Engine	Special Function	Idle Air Vol Learn
INFINITI	All Mode	Up to 2018	Engine	Special Function	EVAP System Close
INFINITI	All Mode	Up to 2018	Engine	Special Function	Fuel Pressure Release
INFINITI	All Mode	Up to 2018	Engine	Special Function	Self-Learning Cont
INFINITI	All Mode	Up to 2018	Engine	Special Function	TARGET IGN TIM ADJ
INFINITI	All Mode	Up to 2018	Engine	Special Function	EXH V/T CONTROL LEARN
INFINITI	All Mode	Up to 2018	Engine	Special Function	TARGET IDLE RPM ADJ
INFINITI	All Mode	Up to 2018	Engine	Special Function	CO ADJUSTMENT
INFINITI	All Mode	Up to 2018	Engine	Special Function	ETHANOL M/R ADJ
INFINITI	All Mode	Up to 2018	Engine	Special Function	Vin Registration
INFINITI	All Mode	Up to 2018	Engine	Special Function	AP POS LEARN CLR
INFINITI	All Mode	Up to 2018	Engine	Special Function	TARGET IGN TIM HLD
INFINITI	All Mode	Up to 2018	Engine	Special Function	CLSD THL POS LEARN
INFINITI	All Mode	Up to 2018	Engine	Special Function	VVEL POS SEN ADJ PREP
INFINITI	All Mode	Up to 2018	Engine	Special Function	M/T NEUTRAL POS LEARN
INFINITI	All Mode	Up to 2018	Engine	Special Function	IGNITION TIMING ADJ
INFINITI	All Mode	Up to 2018	Engine	Special Function	CHECK FUEL LINES
INFINITI	All Mode	Up to 2018	Engine	Special Function	V/T CONTROL LEARN
INFINITI	All Mode	Up to 2018	Engine	Special Function	WRT FUEL LEARN VALUE
INFINITI	All Mode	Up to 2018	Engine	Special Function	A/F Initial Learning
INFINITI	All Mode	Up to 2018	Engine	Special Function	Saving Data For Replc CPU
INFINITI	All Mode	Up to 2018	Engine	Special Function	Writing Data For Replc CPU
INFINITI	All Mode	Up to 2018	Engine	Special Function	STRT OPRTN CNTR CLEAR
INFINITI	All Mode	Up to 2018	Engine	Special Function	CML B/DCHRG CRNT CLEAR
INFINITI	All Mode	Up to 2018	Engine	Special Function	G Sensor Calibration
INFINITI	All Mode	Up to 2018	Engine	Special Function	Valve Timing Offset Data Writing
INFINITI	All Mode	Up to 2018	Engine	Special Function	Valve Timing Offset Data Clear
INFINITI	All Mode	Up to 2018	Engine	Special Function	SC MAGNETIC CLUTCH ENGAGE COUNT CLEAR
INFINITI	All Mode	Up to 2018	Engine	Special Function	Cumulative Sub-Battry Dischg Current Clear
INFINITI	All Mode	Up to 2018	Engine	Special Function	SUB-STARTER&GENERATOR OPER COUNT CLEAR
INFINITI	All Mode	Up to 2018	Engine	Special Function	Active Control Engine Mounting A
INFINITI	All Mode	Up to 2018	Engine	Special Function	Active Control Engine Mounting B
INFINITI	All Mode	Up to 2018	Engine	Special Function	A/F Sensor Response Diagnosis Status B1
INFINITI	All Mode	Up to 2018	Engine	Special Function	A/F Sensor Response Diagnosis Status B2
INFINITI	All Mode	Up to 2018	Engine	Special Function	Engine Coolant Bypass Valve
INFINITI	All Mode	Up to 2018	Engine	Special Function	Misfire count (real-time)
INFINITI	All Mode	Up to 2018	Engine	Special Function	Misfire count (past)
INFINITI	All Mode	Up to 2017	Engine	Read Fault Code	
INFINITI	All Mode	Up to 2017	Engine	Clear Fault Code	
INFINITI	All Mode	Up to 2017	Engine	Read Data Stream	
INFINITI	All Mode	Up to 2017	Engine	Module Information	
INFINITI	All Mode	Up to 2017	Engine	Function Test	
INFINITI	All Mode	Up to 2017	Engine	Actuation Test	THRTL POSITION
INFINITI	All Mode	Up to 2017	Engine	Actuation Test	EGR/V ANGEL
INFINITI	All Mode	Up to 2017	Engine	Actuation Test	SWIRL CONT S/V1
INFINITI	All Mode	Up to 2017	Engine	Actuation Test	GLOW RLY
INFINITI	All Mode	Up to 2017	Engine	Actuation Test	COOLING FAN
INFINITI	All Mode	Up to 2017	Engine	Actuation Test	TC BOOST CONT/V
INFINITI	All Mode	Up to 2017	Engine	Special Function	Enter Injctr Calib Data
INFINITI	All Mode	Up to 2017	Engine	Special Function	EGR/V LEARN CLR
INFINITI	All Mode	Up to 2017	Engine	Special Function	TP POS LEARN CLR
INFINITI	All Mode	Up to 2017	Engine	Special Function	DIF EX PRE LRN CLR
INFINITI	All Mode	Up to 2017	Engine	Special Function	Service Regeneration
INFINITI	All Mode	Up to 2017	Engine	Special Function	DPF Data Clear
INFINITI	All Mode	Up to 2017	Engine	Special Function	A/F SEN LEAN CLR
INFINITI	All Mode	Up to 2017	Engine	Special Function	PTO REGISTRATION
INFINITI	All Mode	Up to 2017	Engine	Special Function	Vin Registration
INFINITI	All Mode	Up to 2017	Engine	Special Function	Injector Learning Value Clear
INFINITI	All Mode	Up to 2017	Engine	Special Function	Mixture Ratio Learning Value Clear
INFINITI	All Mode	2009 - 2012	Engine	Read Fault Code	
INFINITI	All Mode	2009 - 2012	Engine	Clear Fault Code	
INFINITI	All Mode	2009 - 2012	Engine	Read Data Stream	
INFINITI	All Mode	2009 - 2012	Engine	Actuation Test	TC BST CONT S/V
INFINITI	All Mode	2009 - 2012	Engine	Actuation Test	FRP CONTROL VALVE

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
INFINITI	All Mode	2009 - 2012	Engine	Actuation Test	GLOW CONTROL UNIT
INFINITI	All Mode	2009 - 2012	Engine	Actuation Test	EGR COOLER BYPASS CONT S/V
INFINITI	All Mode	2009 - 2012	Engine	Actuation Test	TROTTL VALVE
INFINITI	All Mode	2009 - 2012	Engine	Actuation Test	Fuel Pump
INFINITI	All Mode	2009 - 2012	Engine	Actuation Test	TURBOCHARGER COOLING PUMP
INFINITI	All Mode	2009 - 2012	Engine	Special Function	Service Regeneration
INFINITI	All Mode	2009 - 2012	Engine	Special Function	LEARNING
INFINITI	All Mode	2009 - 2012	Engine	Special Function	INJ ADJ VAL REGIST
INFINITI	All Mode	2009 - 2012	Engine	Special Function	ZFC VALUE RESET
INFINITI	All Mode	2009 - 2012	Engine	Special Function	P062F EXCLUSIVE FUNCTION
INFINITI	All Mode	2009 - 2012	Engine	Special Function	EGR/V LEARN CLR
INFINITI	All Mode	2009 - 2012	Engine	Special Function	DPF Data Clear
INFINITI	All Mode	2009 - 2012	Engine	Special Function	Saving Data For Replc CPU
INFINITI	All Mode	2009 - 2012	Engine	Special Function	Writing Data For Replc CPU
INFINITI	All Mode	2009 - 2012	Engine	Read Fault Code	
INFINITI	All Mode	2009 - 2012	Engine	Clear Fault Code	
INFINITI	All Mode	2009 - 2012	Engine	Read Data Stream	
INFINITI	All Mode	2009 - 2012	Engine	Actuation Test	TC BST CONT S/V
INFINITI	All Mode	2009 - 2012	Engine	Actuation Test	FRP CONTROL VALVE
INFINITI	All Mode	2009 - 2012	Engine	Actuation Test	GLOW CONTROL UNIT
INFINITI	All Mode	2009 - 2012	Engine	Actuation Test	EGR COOLER BYPASS CONT S/V
INFINITI	All Mode	2009 - 2012	Engine	Actuation Test	TROTTL VALVE
INFINITI	All Mode	2009 - 2012	Engine	Actuation Test	Fuel Pump
INFINITI	All Mode	2009 - 2012	Engine	Actuation Test	TURBOCHARGER COOLING PUMP
INFINITI	All Mode	2009 - 2012	Engine	Special Function	LEARNING
INFINITI	All Mode	2009 - 2012	Engine	Special Function	INJ ADJ VAL REGIST
INFINITI	All Mode	2009 - 2012	Engine	Special Function	ZFC VALUE RESET
INFINITI	All Mode	2009 - 2012	Engine	Special Function	P062F EXCLUSIVE FUNCTION
INFINITI	All Mode	2009 - 2012	Engine	Special Function	EGR/V LEARN CLR
INFINITI	All Mode	2009 - 2012	Engine	Special Function	DPF Data Clear
INFINITI	All Mode	2009 - 2012	Engine	Special Function	OC DATA CLEAR
INFINITI	All Mode	2009 - 2012	Engine	Special Function	Service Regeneration
INFINITI	All Mode	2009 - 2012	Engine	Special Function	Saving Data For Replc CPU
INFINITI	All Mode	2009 - 2012	Engine	Special Function	Writing Data For Replc CPU
INFINITI	All Mode	2009 - 2017	Engine	Read Fault Code	
INFINITI	All Mode	2009 - 2017	Engine	Clear Fault Code	
INFINITI	All Mode	2009 - 2017	Engine	Read Data Stream	
INFINITI	All Mode	2009 - 2017	Engine	Actuation Test	TC BST CONT S/V
INFINITI	All Mode	2009 - 2017	Engine	Actuation Test	FRP CONTROL VALVE
INFINITI	All Mode	2009 - 2017	Engine	Actuation Test	GLOW CONTROL UNIT
INFINITI	All Mode	2009 - 2017	Engine	Actuation Test	EGR COOLER BYPASS CONT S/V
INFINITI	All Mode	2009 - 2017	Engine	Actuation Test	TROTTL VALVE
INFINITI	All Mode	2009 - 2017	Engine	Actuation Test	Fuel Pump
INFINITI	All Mode	2009 - 2017	Engine	Actuation Test	TURBOCHARGER COOLING PUMP
INFINITI	All Mode	2009 - 2017	Engine	Actuation Test	ENGINE MOUNTING
INFINITI	All Mode	2009 - 2017	Engine	Special Function	Service Regeneration
INFINITI	All Mode	2009 - 2017	Engine	Special Function	INJ ADJ VAL REGIST
INFINITI	All Mode	2009 - 2017	Engine	Special Function	TP POS LEARN CLR
INFINITI	All Mode	2009 - 2017	Engine	Special Function	EGR/V LEARN CLR
INFINITI	All Mode	2009 - 2017	Engine	Special Function	DPF Data Clear
INFINITI	All Mode	2009 - 2017	Engine	Special Function	EXH Fuel Inj Data Clear
INFINITI	All Mode	2009 - 2017	Engine	Special Function	ZFC VALUE RESET
INFINITI	All Mode	Up to 2008	Engine	Read Fault Code	
INFINITI	All Mode	Up to 2008	Engine	Clear Fault Code	
INFINITI	All Mode	Up to 2008	Engine	Read Data Stream	
INFINITI	All Mode	Up to 2008	Engine	Module Information	
INFINITI	All Mode	Up to 2008	Engine	Actuation Test	EGR SOLENOID VALVE
INFINITI	All Mode	Up to 2008	Engine	Actuation Test	PREHEATER UNIT
INFINITI	All Mode	Up to 2008	Engine	Actuation Test	TURBO SOL VALVE
INFINITI	All Mode	Up to 2008	Engine	Actuation Test	RAIL PRESS REG
INFINITI	All Mode	Up to 2008	Engine	Actuation Test	DAMPER FLAP
INFINITI	All Mode	Up to 2008	Engine	Actuation Test	LOCK INJECTOR CTRL
INFINITI	All Mode	Up to 2008	Engine	Actuation Test	UNLK INJECTOR CTRL
INFINITI	All Mode	Up to 2008	Engine	Actuation Test	PRE ELEC CONSUM
INFINITI	All Mode	Up to 2008	Engine	Special Function	Saving Data For Replc CPU
INFINITI	All Mode	Up to 2008	Engine	Special Function	Writing Data For Replc CPU
INFINITI	All Mode	Up to 2008	Engine	Special Function	Programmed Values
INFINITI	All Mode	Up to 2008	Engine	Special Function	Enter Injctr Calib Data
INFINITI	All Mode	Up to 2008	Engine	Special Function	EGR Adaptives
INFINITI	All Mode	Up to 2008	Engine	Read Fault Code	
INFINITI	All Mode	Up to 2008	Engine	Clear Fault Code	
INFINITI	All Mode	Up to 2008	Engine	Read Data Stream	
INFINITI	All Mode	Up to 2008	Engine	Module Information	
INFINITI	All Mode	Up to 2008	Engine	Actuation Test	PREHEATER UNIT
INFINITI	All Mode	Up to 2008	Engine	Actuation Test	EGR SOLENOID VALVE
INFINITI	All Mode	Up to 2008	Engine	Actuation Test	INJECTOR CYLINDER 1
INFINITI	All Mode	Up to 2008	Engine	Actuation Test	INJECTOR CYLINDER 2
INFINITI	All Mode	Up to 2008	Engine	Actuation Test	INJECTOR CYLINDER 3
INFINITI	All Mode	Up to 2008	Engine	Actuation Test	INJECTOR CYLINDER 4
INFINITI	All Mode	Up to 2008	Engine	Actuation Test	HIGH PRESSURE PUMP

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
INFINITI	All Mode	Up to 2008	Engine	Actuation Test	STATIC TEST
INFINITI	All Mode	Up to 2008	Engine	Actuation Test	HIGH PRESS CIRC LEAK T
INFINITI	All Mode	Up to 2008	Engine	Special Function	Vin Registration
INFINITI	All Mode	Up to 2008	Engine	Special Function	Programmed Values
INFINITI	All Mode	Up to 2008	Engine	Special Function	EGR Adaptives
INFINITI	All Mode	Up to 2008	Engine	Special Function	Reset Pump Forcefeeding
INFINITI	All Mode	Up to 2008	Engine	Special Function	Reset Injctr Adaptative
INFINITI	All Mode	Up to 2008	Engine	Special Function	Saving Data For Replc CPU
INFINITI	All Mode	Up to 2008	Engine	Special Function	Writing Data For Replc CPU
INFINITI	All Mode	Up to 2008	Engine	Special Function	Enter Injctr Calib Data
INFINITI	All Mode	Up to 2008	Engine	Special Function	Speed Limiter
INFINITI	All Mode	Up to 2017	Engine	Read Fault Code	
INFINITI	All Mode	Up to 2017	Engine	Clear Fault Code	
INFINITI	All Mode	Up to 2017	Engine	Read Data Stream	
INFINITI	All Mode	Up to 2017	Engine	Actuation Test	COOLING FAN
INFINITI	All Mode	Up to 2017	Engine	Actuation Test	INJ TIMING
INFINITI	All Mode	Up to 2017	Engine	Actuation Test	ENG COOLANT TEMP
INFINITI	All Mode	Up to 2017	Engine	Actuation Test	Fuel/T Temp SEN
INFINITI	All Mode	Up to 2017	Engine	Actuation Test	ALTERNATOR DUTY
INFINITI	All Mode	Up to 2017	Engine	Actuation Test	Tc boost control actuator
INFINITI	All Mode	Up to 2017	Engine	Actuation Test	EGR COOLER BYPASS VALVE
INFINITI	All Mode	Up to 2017	Engine	Actuation Test	PRES REGULATOR
INFINITI	All Mode	Up to 2017	Engine	Actuation Test	TARGET ETC ANGLE
INFINITI	All Mode	Up to 2017	Engine	Actuation Test	Power Balance
INFINITI	All Mode	Up to 2017	Engine	Actuation Test	TRG EGR/V angel
INFINITI	All Mode	Up to 2017	Engine	Actuation Test	GLOW RLY
INFINITI	All Mode	Up to 2017	Engine	Actuation Test	ENGINE MOUNTING
INFINITI	All Mode	Up to 2017	Engine	Special Function	Enter Injctr Calib Data
INFINITI	All Mode	Up to 2017	Engine	Special Function	Service Regeneration
INFINITI	All Mode	Up to 2017	Engine	Special Function	PTO REGISTRATION
INFINITI	All Mode	Up to 2017	Engine	Special Function	Pump Leant Clear
INFINITI	All Mode	Up to 2017	Engine	Special Function	A/F SEN 1 LEARN CLR
INFINITI	All Mode	Up to 2017	Engine	Special Function	DF EXH PRES SEN LEARN CLR
INFINITI	All Mode	Up to 2017	Engine	Special Function	E/R AIR TEMP SEN LEARN CLR
INFINITI	All Mode	Up to 2017	Engine	Special Function	Fuel INJ quantity learning
INFINITI	All Mode	Up to 2017	Engine	Special Function	DPF Data Clear
INFINITI	All Mode	Up to 2017	Engine	Special Function	Config CLR
INFINITI	All Mode	Up to 2017	Engine	Special Function	INJ ADJ VAL CLR
INFINITI	All Mode	Up to 2017	Engine	Special Function	A/F SEN 2 LEARN CLR
INFINITI	All Mode	Up to 2017	Engine	Special Function	EGR/V LEARN CLEAR
INFINITI	All Mode	Up to 2017	Engine	Special Function	Exh Prsr Sen Learn Clear
INFINITI	All Mode	Up to 2017	Engine	Special Function	OC DATA CLEAR
INFINITI	All Mode	Up to 2017	Engine	Special Function	Saving Data For Replc CPU
INFINITI	All Mode	Up to 2017	Engine	Special Function	Writing Data For Replc CPU
INFINITI	All Mode	Up to 2017	Engine	Special Function	Desulfuration
INFINITI	All Mode	Up to 2017	Engine	Special Function	TC BOOST CONTROL ACTUATOR POSITION LEARNING
INFINITI	All Mode	Up to 2017	Engine	Special Function	Vin Registration
INFINITI	All Mode	Up to 2017	Engine	Special Function	Service Regene
INFINITI	All Mode	2014 - 2016	Engine	Read Fault Code	
INFINITI	All Mode	2014 - 2016	Engine	Clear Fault Code	
INFINITI	All Mode	2014 - 2016	Engine	Read Data Stream	
INFINITI	All Mode	2014 - 2016	Engine	Actuation Test	TURBOCHARGING SOLENOID VALVE
INFINITI	All Mode	2014 - 2016	Engine	Actuation Test	AIR INLET FLAP
INFINITI	All Mode	2014 - 2016	Engine	Actuation Test	EGR BYPASS
INFINITI	All Mode	2014 - 2016	Engine	Actuation Test	THERMOPLNGR RLY N1
INFINITI	All Mode	2014 - 2016	Engine	Actuation Test	THERMOPLNGR RLY N2
INFINITI	All Mode	2014 - 2016	Engine	Actuation Test	THERMOPLNGR 3 RLY
INFINITI	All Mode	2014 - 2016	Engine	Actuation Test	PREHEATER RLY
INFINITI	All Mode	2014 - 2016	Engine	Actuation Test	DPF INJECTOR
INFINITI	All Mode	2014 - 2016	Engine	Actuation Test	DPF INJECTOR SOLENOID VALVE
INFINITI	All Mode	2014 - 2016	Engine	Actuation Test	EGR VALVE
INFINITI	All Mode	2014 - 2016	Engine	Actuation Test	INJECTION SOL/V OPENING PF
INFINITI	All Mode	2014 - 2016	Engine	Actuation Test	ENGINE ADAPTIVES
INFINITI	All Mode	2014 - 2016	Engine	Actuation Test	DPF RELATIVE PRESSURE SENSOR
INFINITI	All Mode	2014 - 2016	Engine	Actuation Test	EXHAUST FUEL INJECTOR CIRCUIT
INFINITI	All Mode	2014 - 2016	Engine	Actuation Test	CC/SL PRGRM
INFINITI	All Mode	2014 - 2016	Engine	Actuation Test	E/O CC/SL PRGRM
INFINITI	All Mode	2014 - 2016	Engine	Actuation Test	FUEL SPLY PREV
INFINITI	All Mode	2014 - 2016	Engine	Actuation Test	EGR VALVE PROGRAMMING
INFINITI	All Mode	2014 - 2016	Engine	Actuation Test	AIR DAMPER VALVE PROGRAMMING
INFINITI	All Mode	2014 - 2016	Engine	Actuation Test	PRESSURE REGULATION ADAPTIVES
INFINITI	All Mode	2014 - 2016	Engine	Special Function	Service Regeneration
INFINITI	All Mode	2014 - 2016	Engine	Special Function	Enter Injector Codes
INFINITI	All Mode	2014 - 2016	Engine	Special Function	After Dpf Regeneration



**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
INFINITI	All Mode	2014 - 2016	Engine	Special Function	After Dpf Replacement
INFINITI	All Mode	2014 - 2016	Engine	Special Function	Saving Data For Replc CPU
INFINITI	All Mode	2014 - 2016	Engine	Special Function	Writing Data For Replc CPU
INFINITI	All Mode	2014 - 2016	Engine	Read Fault Code	
INFINITI	All Mode	2014 - 2016	Engine	Clear Fault Code	
INFINITI	All Mode	2014 - 2016	Engine	Read Data Stream	
INFINITI	All Mode	2014 - 2016	Engine	Actuation Test	HIGH PRESSURE CIRCUIT LEAK TEST
INFINITI	All Mode	2014 - 2016	Engine	Actuation Test	AIR INLET FLAP
INFINITI	All Mode	2014 - 2016	Engine	Actuation Test	TURBOCHARGING SOLENOID VALVE
INFINITI	All Mode	2014 - 2016	Engine	Actuation Test	EGR VALVE
INFINITI	All Mode	2014 - 2016	Engine	Actuation Test	THERMOPLNGR RLY N1
INFINITI	All Mode	2014 - 2016	Engine	Actuation Test	THERMOPLNGR RLY N2
INFINITI	All Mode	2014 - 2016	Engine	Actuation Test	THERMOPLNGR 3 RLY
INFINITI	All Mode	2014 - 2016	Engine	Actuation Test	PREHEATER RLY
INFINITI	All Mode	2014 - 2016	Engine	Actuation Test	EGR BYPASS
INFINITI	All Mode	2014 - 2016	Engine	Actuation Test	DPF INJECTOR
INFINITI	All Mode	2014 - 2016	Engine	Actuation Test	DPF INJECTOR SOLENOID VALVE
INFINITI	All Mode	2014 - 2016	Engine	Actuation Test	INJECTOR CYLINDER 1
INFINITI	All Mode	2014 - 2016	Engine	Actuation Test	INJECTOR CYLINDER 2
INFINITI	All Mode	2014 - 2016	Engine	Actuation Test	INJECTOR CYLINDER 3
INFINITI	All Mode	2014 - 2016	Engine	Actuation Test	INJECTOR CYLINDER 4
INFINITI	All Mode	2014 - 2016	Engine	Actuation Test	RAIL PRS SEN ADAPTIVES
INFINITI	All Mode	2014 - 2016	Engine	Actuation Test	PRESSURE REGULATION ADAPTIVES
INFINITI	All Mode	2014 - 2016	Engine	Actuation Test	EGR VALVE PROGRAMMING
INFINITI	All Mode	2014 - 2016	Engine	Actuation Test	AIR PATH PROGRAMMING
INFINITI	All Mode	2014 - 2016	Engine	Actuation Test	DPF RELATIVE PRESSURE SENSOR
INFINITI	All Mode	2014 - 2016	Engine	Actuation Test	FUEL FLOW REGULATOR
INFINITI	All Mode	2014 - 2016	Engine	Actuation Test	EXHAUST FUEL INJECTOR CIRCUIT
INFINITI	All Mode	2014 - 2016	Engine	Actuation Test	AIR DAMPER VALVE PROGRAMMING
INFINITI	All Mode	2014 - 2016	Engine	Actuation Test	ENGINE ADAPTIVES
INFINITI	All Mode	2014 - 2016	Engine	Actuation Test	After DPF Regeneration
INFINITI	All Mode	2014 - 2016	Engine	Actuation Test	FUEL SPLY PREV
INFINITI	All Mode	2014 - 2016	Engine	Actuation Test	STP FUEL SPLY PREV
INFINITI	All Mode	2014 - 2016	Engine	Actuation Test	SPEED LIMITER/CRUISE CONTROL ACTIVATION
INFINITI	All Mode	2014 - 2016	Engine	Special Function	Vin Registration
INFINITI	All Mode	2014 - 2016	Engine	Special Function	Service Regeneration
INFINITI	All Mode	2014 - 2016	Engine	Special Function	Commercial VHCL idle SPD MOD
INFINITI	All Mode	2014 - 2016	Engine	Special Function	Speed Limiter
INFINITI	All Mode	2014 - 2016	Engine	Special Function	Enter Injector Codes
INFINITI	All Mode	2014 - 2016	Engine	Special Function	Saving Data For Replc CPU
INFINITI	All Mode	2014 - 2016	Engine	Special Function	Writing Data For Replc CPU
INFINITI	All Mode	2013 - 2018	Engine	Read Fault Code	
INFINITI	All Mode	2013 - 2018	Engine	Clear Fault Code	
INFINITI	All Mode	2013 - 2018	Engine	Read Data Stream	
INFINITI	All Mode	2013 - 2018	Engine	Module Information	
INFINITI	All Mode	2013 - 2018	Engine	Actuation Test	Check Coolant Pump For Proper Operation
INFINITI	All Mode	2013 - 2018	Engine	Actuation Test	Check Engine Diagnosis Indicator Lamp
INFINITI	All Mode	2013 - 2018	Engine	Actuation Test	Check Engine Oil Pump Valve
INFINITI	All Mode	2013 - 2018	Engine	Actuation Test	Check EGR Actuator
INFINITI	All Mode	2013 - 2018	Engine	Actuation Test	Check EGR Cooler Bypss Sw Over Valve
INFINITI	All Mode	2013 - 2018	Engine	Actuation Test	Check Glow Plugs
INFINITI	All Mode	2013 - 2018	Engine	Actuation Test	Check Oil Spray Nozzles Shutoff Valve
INFINITI	All Mode	2013 - 2018	Engine	Actuation Test	Check O2 Upstream Of Catalytic Converter
INFINITI	All Mode	2013 - 2018	Engine	Actuation Test	Check Rail Pressure Sensor
INFINITI	All Mode	2013 - 2018	Engine	Actuation Test	CK Temp Sen Upstream Of Dsl Prtel Sen
INFINITI	All Mode	2013 - 2018	Engine	Actuation Test	Check Temp Sen Upstream Turbocharger
INFINITI	All Mode	2013 - 2018	Engine	Actuation Test	Check Tm Oil Clng Clnt Circulation Pump
INFINITI	All Mode	2013 - 2018	Engine	Actuation Test	Rail Pressure Sensor Offset Test
INFINITI	All Mode	2013 - 2018	Engine	Actuation Test	Check Boost Pressure Positioner
INFINITI	All Mode	2013 - 2018	Engine	Actuation Test	Check Fuel System High Pressure Pump
INFINITI	All Mode	2013 - 2018	Engine	Actuation Test	Check Cylinder 1 Glow Plug

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
INFINITI	All Mode	2013 - 2018	Engine	Actuation Test	Check Fuel HI Press Circ For Leaktightness
INFINITI	All Mode	2013 - 2018	Engine	Actuation Test	Exhaust Gas Regulation Dynamic Test
INFINITI	All Mode	2013 - 2018	Engine	Actuation Test	Check Pres Regulating Valve For Leaks
INFINITI	All Mode	2013 - 2018	Engine	Actuation Test	Check Preglow System
INFINITI	All Mode	2013 - 2018	Engine	Actuation Test	Automatic Leak Test Of Charge Air System
INFINITI	All Mode	2013 - 2018	Engine	Actuation Test	Compression Test
INFINITI	All Mode	2013 - 2018	Engine	Actuation Test	Ck Cont Response Of Press Reg Vlv At Idle
INFINITI	All Mode	2013 - 2018	Engine	Actuation Test	CK Cont Response Of Press Regulating VLV
INFINITI	All Mode	2013 - 2018	Engine	Actuation Test	Check Control Response Of Quantity Control Valve At Idle
INFINITI	All Mode	2013 - 2018	Engine	Actuation Test	Collation Of Diagnosis Performance Data
INFINITI	All Mode	2013 - 2018	Engine	Actuation Test	Check Fuel Filter Heater
INFINITI	All Mode	2013 - 2018	Engine	Actuation Test	Auto Stop Start
INFINITI	All Mode	2013 - 2018	Engine	Actuation Test	Check Intake Port Shutoff Actuator Motor
INFINITI	All Mode	2013 - 2018	Engine	Actuation Test	Ck Eng And Ac With Intgrted Cont Fan Motor
INFINITI	All Mode	2013 - 2018	Engine	Actuation Test	Alternator Diagnosis
INFINITI	All Mode	2013 - 2018	Engine	Special Function	Bleeding Of High Pressure Fuel Circuit
INFINITI	All Mode	2013 - 2018	Engine	Special Function	Diesel Particle Filter Regeneration
INFINITI	All Mode	2013 - 2018	Engine	Special Function	OPR Time Basic Diag Of TM Neutral Pos Sen
INFINITI	All Mode	2013 - 2018	Engine	Special Function	Teach In Boost Pressure Positioner
INFINITI	All Mode	2013 - 2018	Engine	Special Function	QK TCH IN OF ZERO QUNTY CALIB VAL AT IDL
INFINITI	All Mode	2013 - 2018	Engine	Special Function	Reset Of Contamination Level Of Air Filter
INFINITI	All Mode	2013 - 2018	Engine	Special Function	Reset Of Lambda Values
INFINITI	All Mode	2013 - 2018	Engine	Special Function	Replace Diesel Particulate Filter
INFINITI	All Mode	2013 - 2018	Engine	Special Function	Activation Of Fuel Pump
INFINITI	All Mode	2013 - 2018	Engine	Special Function	Reset Of Learned Values Of Cmsft Hall Sen
INFINITI	All Mode	2013 - 2018	Engine	Special Function	Teach In Of Intake Port Shutoff
INFINITI	All Mode	2013 - 2018	Engine	Special Function	QK TCH In Zero Qunty Calib Val While Driving
INFINITI	All Mode	2013 - 2018	Engine	Special Function	Teach In Of Throttle Valve Stop
INFINITI	All Mode	2013 - 2018	Engine	Special Function	Vin Registration
INFINITI	All Mode	2013 - 2018	Engine	Special Function	Injector Injection Quantity Adjustment
INFINITI	All Mode	2013 - 2018	Engine	Special Function	Control Deviation Charge Air System
INFINITI	All Mode	2013 - 2018	Engine	Special Function	STRT OPRIN CNTR CLEAR
INFINITI	All Mode	2013 - 2018	Engine	Special Function	H/P Fuel Pump Total Starts Counter Clear
INFINITI	All Mode	2013 - 2018	Engine	Special Function	Saving Data For Replc CPU
INFINITI	All Mode	2013 - 2018	Engine	Special Function	Writing Data For Replc CPU
INFINITI	All Mode	Up to 2018	Engine	Read Fault Code	
INFINITI	All Mode	Up to 2018	Engine	Clear Fault Code	
INFINITI	All Mode	Up to 2018	Engine	Read Data Stream	
INFINITI	All Mode	Up to 2018	Engine	Module Information	
INFINITI	All Mode	Up to 2018	Engine	Actuation Test	ENG COOLANT TEMP
INFINITI	All Mode	Up to 2018	Engine	Actuation Test	FUEL INJECTION
INFINITI	All Mode	Up to 2018	Engine	Actuation Test	PURG VOL CONT/V
INFINITI	All Mode	Up to 2018	Engine	Actuation Test	Fuel/T Temp SEN
INFINITI	All Mode	Up to 2018	Engine	Actuation Test	EGR VOL CONT/V
INFINITI	All Mode	Up to 2018	Engine	Actuation Test	Power Balance
INFINITI	All Mode	Up to 2018	Engine	Actuation Test	INT V/T ASSIGN ANGLE
INFINITI	All Mode	Up to 2018	Engine	Actuation Test	EXH V/T ASSIGN ANGLE
INFINITI	All Mode	Up to 2018	Engine	Actuation Test	Fuel Pump Relay
INFINITI	All Mode	Up to 2018	Engine	Actuation Test	VIAS S/V-1
INFINITI	All Mode	Up to 2018	Engine	Actuation Test	VENT CONTROL/V
INFINITI	All Mode	Up to 2018	Engine	Actuation Test	Supercharger Clutch Relay
INFINITI	All Mode	Up to 2018	Engine	Actuation Test	FAN DUTY CONTROL
INFINITI	All Mode	Up to 2018	Engine	Actuation Test	ALTERNATOR DUTY
INFINITI	All Mode	Up to 2018	Engine	Actuation Test	TUMBLE CONTROL VALVE
INFINITI	All Mode	Up to 2018	Engine	Actuation Test	VIAS S/V-2

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
INFINITI	All Mode	Up to 2018	Engine	Actuation Test	ALTERNATOR VOLTAGE
INFINITI	All Mode	Up to 2018	Engine	Actuation Test	Active Grille Shutter
INFINITI	All Mode	Up to 2018	Engine	Actuation Test	Auto Stop Start
INFINITI	All Mode	Up to 2018	Engine	Actuation Test	COOLING FAN
INFINITI	All Mode	Up to 2018	Engine	Actuation Test	FPCM
INFINITI	All Mode	Up to 2018	Engine	Actuation Test	IGNITION TIMING
INFINITI	All Mode	Up to 2018	Engine	Actuation Test	EGR CONTROL VALVE
INFINITI	All Mode	Up to 2018	Engine	Actuation Test	WASTEGATE ACTUATOR
INFINITI	All Mode	Up to 2018	Engine	Actuation Test	TC BYPASS VALVE
INFINITI	All Mode	Up to 2018	Engine	Actuation Test	ENGINE COOLANT ELECTIC WATER PUMP
INFINITI	All Mode	Up to 2018	Engine	Special Function	Cumulative Sub-Battry Dischg Current Clear
INFINITI	All Mode	Up to 2018	Engine	Special Function	Vin Registration
INFINITI	All Mode	Up to 2018	Engine	Special Function	EVAP System Close
INFINITI	All Mode	Up to 2018	Engine	Special Function	Idle Air Vol Learn
INFINITI	All Mode	Up to 2018	Engine	Special Function	Self-Learning Cont
INFINITI	All Mode	Up to 2018	Engine	Special Function	A/F Initial Learning
INFINITI	All Mode	Up to 2018	Engine	Special Function	SUB-STARTER & GENERATOR OPER COUNT CLEAR
INFINITI	All Mode	Up to 2018	Engine	Special Function	CML B/DCHRG CRNT CLEAR
INFINITI	All Mode	Up to 2018	Engine	Special Function	SC MAGNETIC CLUTCH ENGAGE COUNT CLEAR
INFINITI	All Mode	Up to 2018	Engine	Special Function	Fuel Pressure Release
INFINITI	All Mode	Up to 2018	Engine	Special Function	CLSD THL POS LEARN
INFINITI	All Mode	Up to 2018	Engine	Special Function	Active Control Engine Mounting A
INFINITI	All Mode	Up to 2018	Engine	Special Function	Active Control Engine Mounting B
INFINITI	All Mode	Up to 2018	Engine	Special Function	G Sensor Calibration
INFINITI	All Mode	Up to 2018	Engine	Special Function	TARGET IGN TIM ADJ
INFINITI	All Mode	Up to 2018	Engine	Special Function	TARGET IDLE RPM ADJ
INFINITI	All Mode	Up to 2018	Engine	Special Function	Valve Timing Offset Data Writing
INFINITI	All Mode	Up to 2018	Engine	Special Function	Valve Timing Offset Data Clear
INFINITI	All Mode	Up to 2018	Engine	Special Function	STRT OPRTN CNTR CLEAR
INFINITI	All Mode	Up to 2018	Engine	Special Function	VALVE TIMING ADJUSTMENT
INFINITI	All Mode	Up to 2018	Engine	Special Function	WASTEGATE ACTUATOR POST LEARN VALUE CLEAR
INFINITI	All Mode	Up to 2018	Engine	Special Function	Engine Coolant Bypass Valve
INFINITI	All Mode	Up to 2018	Engine	Special Function	Saving Data For Replc CPU
INFINITI	All Mode	Up to 2018	Engine	Special Function	Writing Data For Replc CPU
INFINITI	All Mode	Up to 2018	Engine	Special Function	Write Starter Operation Count
INFINITI	All Mode	Up to 2018	Engine	Special Function	EGR control valve closed position learning
INFINITI	All Mode	Up to 2018	Engine	Special Function	Electric intake valve timing control learning
INFINITI	All Mode	2013 - 2018	Engine	Read Fault Code	
INFINITI	All Mode	2013 - 2018	Engine	Clear Fault Code	
INFINITI	All Mode	2013 - 2018	Engine	Read Data Stream	
INFINITI	All Mode	2013 - 2018	Engine	Module Information	
INFINITI	All Mode	2013 - 2018	Engine	Actuation Test	Check Deceleration Air Switchover Valve
INFINITI	All Mode	2013 - 2018	Engine	Actuation Test	Check Engine Oil Pump Valve
INFINITI	All Mode	2013 - 2018	Engine	Actuation Test	Boost Pressure
INFINITI	All Mode	2013 - 2018	Engine	Actuation Test	Check Fuel Injectors
INFINITI	All Mode	2013 - 2018	Engine	Actuation Test	Check Fuel HI Press Circ For Leaktightness
INFINITI	All Mode	2013 - 2018	Engine	Actuation Test	Check Fuel High Pressure Circuit
INFINITI	All Mode	2013 - 2018	Engine	Actuation Test	Check Fuel Press And Temp Sensor
INFINITI	All Mode	2013 - 2018	Engine	Actuation Test	Auto Stop Start
INFINITI	All Mode	2013 - 2018	Engine	Actuation Test	Ck Coolant Thermostat Heating Element(<100 Degree C)
INFINITI	All Mode	2013 - 2018	Engine	Actuation Test	Ck Coolant Thermostat Heating Element(<55 Degree C)
INFINITI	All Mode	2013 - 2018	Engine	Special Function	Resetting Of Adaption Values
INFINITI	All Mode	2013 - 2018	Engine	Special Function	Activation Of Fuel Pump
INFINITI	All Mode	2013 - 2018	Engine	Special Function	Teach In Of Throttle Valve Stop
INFINITI	All Mode	2013 - 2018	Engine	Special Function	Status Of Teach In Processes
INFINITI	All Mode	2013 - 2018	Engine	Special Function	Injector Injection Quantity Adjustment

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
INFINITI	All Mode	2013 - 2018	Engine	Special Function	Vin Registration
INFINITI	All Mode	2013 - 2018	Engine	Special Function	STRT OPRTN CNTR CLEAR
INFINITI	All Mode	2013 - 2018	Engine	Special Function	H/P Fuel Pump Total Starts Counter Clear
INFINITI	All Mode	2013 - 2018	Engine	Special Function	Saving Data For Replc CPU
INFINITI	All Mode	2013 - 2018	Engine	Special Function	Writing Data For Replc CPU
INFINITI	All Mode	2013 - 2018	Engine	Special Function	Camshaft Reference Adaptation
INFINITI	All Mode	2013 - 2018	Engine	Special Function	Teach In Of Camshaft Position
INFINITI	All Mode	2014 - 2016	Engine	Read Fault Code	
INFINITI	All Mode	2014 - 2016	Engine	Clear Fault Code	
INFINITI	All Mode	2014 - 2016	Engine	Read Data Stream	
INFINITI	All Mode	2014 - 2016	Engine	Module Information	
INFINITI	All Mode	2014 - 2016	Engine	Actuation Test	TURBOCHARGING SOLENOID VALVE
INFINITI	All Mode	2014 - 2016	Engine	Actuation Test	AIR INLET FLAP
INFINITI	All Mode	2014 - 2016	Engine	Actuation Test	HIGH PRESSURE CIRCUIT LEAK TEST
INFINITI	All Mode	2014 - 2016	Engine	Actuation Test	THERMO NO.3 RELAY
INFINITI	All Mode	2014 - 2016	Engine	Actuation Test	EGR VALVE
INFINITI	All Mode	2014 - 2016	Engine	Actuation Test	PREHEATER RELAY
INFINITI	All Mode	2014 - 2016	Engine	Actuation Test	THERMOPLUNGER RELAY No.1
INFINITI	All Mode	2014 - 2016	Engine	Actuation Test	THERMOPLUNGER RELAY No.2
INFINITI	All Mode	2014 - 2016	Engine	Actuation Test	LOW PRESSURE EGR VALVE PROGRAMMING
INFINITI	All Mode	2014 - 2016	Engine	Actuation Test	EXHAUST AIR FLAP PROGRAMMING
INFINITI	All Mode	2014 - 2016	Engine	Actuation Test	COOLANT CIRC SWITCHING S/V
INFINITI	All Mode	2014 - 2016	Engine	Actuation Test	Fuel Pump
INFINITI	All Mode	2014 - 2016	Engine	Actuation Test	Fuel Pump Relay
INFINITI	All Mode	2014 - 2016	Engine	Actuation Test	FUEL HEATER RELAY
INFINITI	All Mode	2014 - 2016	Engine	Special Function	SOx MASS OPERATION
INFINITI	All Mode	2014 - 2016	Engine	Special Function	Vin Registration
INFINITI	All Mode	2014 - 2016	Engine	Special Function	Fuel Sply Prev
INFINITI	All Mode	2014 - 2016	Engine	Special Function	Number Of Starting 1
INFINITI	All Mode	2014 - 2016	Engine	Special Function	Number Of Starting 2
INFINITI	All Mode	2014 - 2016	Engine	Special Function	Number Of Starting 3
INFINITI	All Mode	2014 - 2016	Engine	Special Function	Number Of Starting 4
INFINITI	All Mode	2014 - 2016	Engine	Special Function	Engine Adaptives
INFINITI	All Mode	2014 - 2016	Engine	Special Function	Egr Valve Programming
INFINITI	All Mode	2014 - 2016	Engine	Special Function	Air Damper Valve Programming
INFINITI	All Mode	2014 - 2016	Engine	Special Function	Exhaust Flap Low Setting
INFINITI	All Mode	2014 - 2016	Engine	Special Function	Turbocharger Programming
INFINITI	All Mode	2014 - 2016	Engine	Special Function	Low Pressure EGR Valve Programming
INFINITI	All Mode	2014 - 2016	Engine	Special Function	P/FLT DIFP PRS SEN
INFINITI	All Mode	2014 - 2016	Engine	Special Function	Pressure Regulation Adaptives
INFINITI	All Mode	2014 - 2016	Engine	Special Function	Fuel Pump Programming
INFINITI	All Mode	2014 - 2016	Engine	Special Function	Adaptives On Air Intake Flap Malfunction
INFINITI	All Mode	2014 - 2016	Engine	Special Function	CC/SL PRGRM
INFINITI	All Mode	2014 - 2016	Engine	Special Function	Prpr Rich Sen Prog
INFINITI	All Mode	2014 - 2016	Engine	Special Function	Enter Injector Codes
INFINITI	All Mode	2014 - 2016	Engine	Special Function	Service Regeneration
INFINITI	All Mode	2014 - 2016	Engine	Special Function	Speed Limiter
INFINITI	All Mode	2014 - 2016	Engine	Special Function	Interval Of Oil Change (OCS) Oxidation
INFINITI	All Mode	2014 - 2016	Engine	Special Function	OIL Change Interval (Ocs): Dilution
INFINITI	All Mode	2014 - 2016	Engine	Special Function	Volume Control Valve Learning Value Clear
INFINITI	All Mode	2014 - 2016	Engine	Special Function	EGR Bypass Programming
INFINITI	All Mode	2014 - 2016	Engine	Special Function	Air Flow Meter Programming
INFINITI	All Mode	2014 - 2016	Engine	Special Function	DPF Relative Pressure Sensor
INFINITI	All Mode	2014 - 2016	Engine	Special Function	Adaptives After Regenerating PF
INFINITI	All Mode	2014 - 2016	Engine	Special Function	After Dpf Replacement
INFINITI	All Mode	2014 - 2016	Engine	Special Function	Clutch Pedal End Stroke
INFINITI	All Mode	2014 - 2016	Engine	Special Function	Save Computer Data
INFINITI	All Mode	2014 - 2016	Engine	Special Function	Write Saved Data
INFINITI	All Mode	2014 - 2016	Engine	Special Function	Air Damper Valve Programming(R044)
INFINITI	All Mode	2014 - 2016	Engine	Special Function	NOX TRAP
INFINITI	All Mode	2014 - 2016	Engine	Special Function	SAVE COMPUTER DATA
INFINITI	All Mode	2014 - 2016	Engine	Special Function	WRITE SAVED DATA
INFINITI	All Mode	2014 - 2016	Engine	Special Function	After Dpf Regeneration

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
INFINITI	All Mode	2014 - 2016	Engine	Read Fault Code	
INFINITI	All Mode	2014 - 2016	Engine	Clear Fault Code	
INFINITI	All Mode	2014 - 2016	Engine	Read Data Stream	
INFINITI	All Mode	2014 - 2016	Engine	Module Information	
INFINITI	All Mode	2014 - 2016	Engine	Actuation Test	Fuel Pump Relay
INFINITI	All Mode	2014 - 2016	Engine	Actuation Test	Intake Valve Timing Control Solenoid Valve
INFINITI	All Mode	2014 - 2016	Engine	Actuation Test	TC Wastegate Control Solenoid Valve
INFINITI	All Mode	2014 - 2016	Engine	Actuation Test	Engine Oil Pressure Control Solenoid Valve
INFINITI	All Mode	2014 - 2016	Engine	Actuation Test	Exhaust Valve Timing Control Solenoid Valve
INFINITI	All Mode	2014 - 2016	Engine	Actuation Test	Thermostat Heater Control Solenoid Valve
INFINITI	All Mode	2014 - 2016	Engine	Actuation Test	Electric Throttle Control Actuator
INFINITI	All Mode	2014 - 2016	Engine	Actuation Test	EVAP Canister Purge Control Solenoid Valve
INFINITI	All Mode	2014 - 2016	Engine	Special Function	Vin Registration
INFINITI	All Mode	2014 - 2016	Engine	Special Function	After throttle valve replacement
INFINITI	All Mode	2014 - 2016	Engine	Special Function	After turbocharger componet replacement
INFINITI	All Mode	2014 - 2016	Engine	Special Function	After turbocharger solenoid valve replacement
INFINITI	All Mode	2014 - 2016	Engine	Special Function	After end stroke clutche contactor replacement
INFINITI	All Mode	2014 - 2016	Engine	Special Function	After camshaft sensor replacement
INFINITI	All Mode	2014 - 2016	Engine	Special Function	After TDC sensor replacement
INFINITI	All Mode	2014 - 2016	Engine	Special Function	After injection pump replacement
INFINITI	All Mode	2014 - 2016	Engine	Special Function	After rail pressure sensor replacement
INFINITI	All Mode	2014 - 2016	Engine	Special Function	After injector replacement
INFINITI	All Mode	2014 - 2016	Engine	Special Function	Fuel Sply Prev
INFINITI	All Mode	2014 - 2016	Engine	Special Function	Engine Adaptives
INFINITI	All Mode	2014 - 2016	Engine	Special Function	Injection Pump Adaptatives
INFINITI	All Mode	2014 - 2016	Engine	Special Function	Interval Of Oil Change (OCS) Oxidation
INFINITI	All Mode	2014 - 2016	Engine	Special Function	High Pressure Fuel Circuit Fault Finding
INFINITI	All Mode	2014 - 2016	Engine	Special Function	Air Fuel Ratio Sensor
INFINITI	All Mode	2014 - 2016	Engine	Special Function	After High Pressure Fuel Pump Replacement
INFINITI	All Mode	2014 - 2016	Engine	Special Function	After Tc Solenoid Valve Replacement
INFINITI	All Mode	2014 - 2016	Engine	Special Function	AFTR ELECTRIC THRRTL CNTRL ACTUATOR RPLCMNT
INFINITI	All Mode	Up to 2018	Engine	Read Fault Code	
INFINITI	All Mode	Up to 2018	Engine	Clear Fault Code	
INFINITI	All Mode	Up to 2018	Engine	Read Data Stream	
INFINITI	All Mode	Up to 2018	Engine	Module Information	
INFINITI	All Mode	Up to 2018	Engine	Actuation Test	TC BYPASS VALVE
INFINITI	All Mode	Up to 2018	Engine	Actuation Test	Auto Stop Start
INFINITI	All Mode	Up to 2018	Engine	Special Function	EGR control valve closed position learning
INFINITI	All Mode	Up to 2018	Engine	Special Function	(TBD)VCR base position learning
INFINITI	All Mode	Up to 2018	Engine	Special Function	Self-Learning Cont
INFINITI	All Mode	Up to 2018	Engine	Special Function	A/F Initial Learning
INFINITI	All Mode	Up to 2018	Engine	Special Function	TARGET IGN TIM ADJ
INFINITI	All Mode	Up to 2018	Engine	Special Function	TARGET IDLE RPM ADJ
INFINITI	All Mode	Up to 2018	Engine	Special Function	VALVE TIMING ADJUSTMENT
INFINITI	All Mode	Up to 2018	Engine	Special Function	Engine Coolant Bypass Valve
INFINITI	All Mode	Up to 2018	Engine	Special Function	Idle Air Vol Learn
INFINITI	All Mode	Up to 2018	Engine	Special Function	Saving Data For Replc CPU
INFINITI	All Mode	Up to 2018	Engine	Special Function	Writing Data For Replc CPU
INFINITI	All Mode	Up to 2018	Engine	Special Function	Electric intake valve timing control learning
INFINITI	All Mode	Up to 2018	Engine	Special Function	Valve Timing Offset Data Writing
INFINITI	All Mode	Up to 2018	Engine	Special Function	Valve Timing Offset Data Clear
INFINITI	All Mode	Up to 2018	Engine	Special Function	STRT OPRTN CNTR CLEAR
INFINITI	All Mode	Up to 2018	Engine	Special Function	CML B/DCHRG CRNT CLEAR
INFINITI	All Mode	Up to 2018	Engine	Special Function	SC MAGNETIC CLUTCH ENGAGE COUNT CLEAR

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
INFINITI	All Mode	Up to 2018	Engine	Special Function	Fuel Pressure Release
INFINITI	All Mode	Up to 2018	Engine	Special Function	EVAP System Close
INFINITI	All Mode	Up to 2018	Engine	Special Function	CLSD THL POS LEARN
INFINITI	All Mode	Up to 2018	Engine	Special Function	Active Control Engine Mounting A
INFINITI	All Mode	Up to 2018	Engine	Special Function	Active Control Engine Mounting B
INFINITI	All Mode	Up to 2018	Engine	Special Function	G Sensor Calibration
INFINITI	All Mode	Up to 2018	Engine	Special Function	Wastegate Actuator Posi Learn Value Clear
INFINITI	All Mode	Up to 2018	Engine	Special Function	Vin Registration
INFINITI	All Mode	Up to 2018	Engine	Special Function	SUB-STARTER & GENERATOR OPER COUNT CLEAR
INFINITI	All Mode	Up to 2018	Engine	Special Function	Cumulative Sub-Battry Dischg Current Clear
INFINITI	All Mode	2015 - 2018	Engine	Read Fault Code	
INFINITI	All Mode	2015 - 2018	Engine	Clear Fault Code	
INFINITI	All Mode	2015 - 2018	Engine	Read Data Stream	
INFINITI	All Mode	2015 - 2018	Engine	Module Information	
INFINITI	All Mode	2015 - 2018	Engine	Actuation Test	Check Boost Pressure Positioner
INFINITI	All Mode	2015 - 2018	Engine	Actuation Test	Check Rail Pressure Sensor
INFINITI	All Mode	2015 - 2018	Engine	Actuation Test	Check Intake Port Shutoff Actuator Motor
INFINITI	All Mode	2015 - 2018	Engine	Actuation Test	EGR Valve Jams
INFINITI	All Mode	2015 - 2018	Engine	Actuation Test	Injector shutoff(CYL 1)
INFINITI	All Mode	2015 - 2018	Engine	Actuation Test	Injector shutoff(CYL 2)
INFINITI	All Mode	2015 - 2018	Engine	Actuation Test	Injector shutoff(CYL 3)
INFINITI	All Mode	2015 - 2018	Engine	Actuation Test	Injector shutoff(CYL 4)
INFINITI	All Mode	2015 - 2018	Engine	Actuation Test	Fuel Pump
INFINITI	All Mode	2015 - 2018	Engine	Actuation Test	Ck Eng And Ac With Intgrted Cont Fan Motor
INFINITI	All Mode	2015 - 2018	Engine	Actuation Test	Check Glow Plugs
INFINITI	All Mode	2015 - 2018	Engine	Actuation Test	Check Engine Oil Pump Valve
INFINITI	All Mode	2015 - 2018	Engine	Actuation Test	Check Oil Spray Nozzles Shutoff Valve
INFINITI	All Mode	2015 - 2018	Engine	Actuation Test	Check Coolant Pump Switchover Valve
INFINITI	All Mode	2015 - 2018	Engine	Actuation Test	Check EGR Cooler Bypss Sw Over Valve
INFINITI	All Mode	2015 - 2018	Engine	Actuation Test	Check O2 Upstream Of Catalytic Converter
INFINITI	All Mode	2015 - 2018	Engine	Actuation Test	Check EGR Actuator
INFINITI	All Mode	2015 - 2018	Engine	Actuation Test	Coolant thermostat heating element
INFINITI	All Mode	2015 - 2018	Engine	Actuation Test	Check Fuel HI Press Circ For Leaktightness
INFINITI	All Mode	2015 - 2018	Engine	Actuation Test	EGR actuator (auto evaluation)
INFINITI	All Mode	2015 - 2018	Engine	Actuation Test	Causes of engine stop prevention
INFINITI	All Mode	2015 - 2018	Engine	Actuation Test	Causes of engine stop prevention combustion engine
INFINITI	All Mode	2015 - 2018	Engine	Actuation Test	Malfunction status of stop/start system
INFINITI	All Mode	2015 - 2018	Engine	Actuation Test	History of regeneration of DPF
INFINITI	All Mode	2015 - 2018	Engine	Actuation Test	Preconditions for automatic engine stop
INFINITI	All Mode	2015 - 2018	Engine	Actuation Test	Requirements for automatic engine start
INFINITI	All Mode	2015 - 2018	Engine	Actuation Test	High pressure fuel pump (pressure regulation)
INFINITI	All Mode	2015 - 2018	Engine	Actuation Test	Leak test of charge air system
INFINITI	All Mode	2015 - 2018	Engine	Special Function	Enabling of engine start after crash event
INFINITI	All Mode	2015 - 2018	Engine	Special Function	Bleeding Of High Pressure Fuel Circuit
INFINITI	All Mode	2015 - 2018	Engine	Special Function	Teach In Boost Pressure Positioner
INFINITI	All Mode	2015 - 2018	Engine	Special Function	Reset Of Learned Values Of Cmsft Hall Sen
INFINITI	All Mode	2015 - 2018	Engine	Special Function	Reset Of Contamination Level Of Air Filter
INFINITI	All Mode	2015 - 2018	Engine	Special Function	Teach In Of DPF After Replace Of CDI C/U
INFINITI	All Mode	2015 - 2018	Engine	Special Function	Replace Diesel Particulate Filter

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

<b>make</b>	<b>model</b>	<b>year</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
INFINITI	All Mode	2015 - 2018	Engine	Special Function	Teach In Of Throttle Valve Stop
INFINITI	All Mode	2015 - 2018	Engine	Special Function	Fuel Injector
INFINITI	All Mode	2015 - 2018	Engine	Read Fault Code	
INFINITI	All Mode	2015 - 2018	Engine	Clear Fault Code	
INFINITI	All Mode	2015 - 2018	Engine	Read Data Stream	
INFINITI	All Mode	2015 - 2018	Engine	Module Information	
INFINITI	All Mode	2015 - 2018	Engine	Actuation Test	Check fuel tank pressure sensor
INFINITI	All Mode	2015 - 2018	Engine	Actuation Test	Purging Switchover Valve
INFINITI	All Mode	2015 - 2018	Engine	Actuation Test	Check Deceleration Air Switchover Valve
INFINITI	All Mode	2015 - 2018	Engine	Actuation Test	Check Engine Oil Pump Valve
INFINITI	All Mode	2015 - 2018	Engine	Actuation Test	Check cylinder fuel injectors
INFINITI	All Mode	2015 - 2018	Engine	Actuation Test	Check purging pressure control
INFINITI	All Mode	2015 - 2018	Engine	Actuation Test	Check EGR Actuator
INFINITI	All Mode	2015 - 2018	Engine	Actuation Test	Check EGR valve hall sensor
INFINITI	All Mode	2015 - 2018	Engine	Actuation Test	Check Intake Camshaft Solenoid
INFINITI	All Mode	2015 - 2018	Engine	Actuation Test	Check Exhaust Camshaft Solenoid
INFINITI	All Mode	2015 - 2018	Engine	Actuation Test	Engine Diagnosis Indicator Lamp
INFINITI	All Mode	2015 - 2018	Engine	Actuation Test	Rail pressure reduction
INFINITI	All Mode	2015 - 2018	Engine	Actuation Test	Boost pressure control pressure transducer
INFINITI	All Mode	2015 - 2018	Engine	Actuation Test	Partial load operation crankcase ventilation valve
INFINITI	All Mode	2015 - 2018	Engine	Actuation Test	Check activated charcoal canister shutoff valve
INFINITI	All Mode	2015 - 2018	Engine	Actuation Test	Check cylinder fuel injectors for leaks
INFINITI	All Mode	2015 - 2018	Engine	Actuation Test	Check radiator shutters actuator
INFINITI	All Mode	2015 - 2018	Engine	Actuation Test	Quantity control valve
INFINITI	All Mode	2015 - 2018	Engine	Actuation Test	Check Fuel HI Press Circ For Leaktightness
INFINITI	All Mode	2015 - 2018	Engine	Actuation Test	Fuel Pump
INFINITI	All Mode	2015 - 2018	Engine	Special Function	Enabling of engine start after crash event
INFINITI	All Mode	2015 - 2018	Engine	Special Function	Teach In Of Throttle Valve Stop
INFINITI	All Mode	2015 - 2018	Engine	Special Function	Camshaft Reference Adaptation
INFINITI	All Mode	2015 - 2018	Engine	Special Function	Teach In Of Sensor Rotor Adaptation
INFINITI	All Mode	2015 - 2018	Engine	Special Function	Status Of Teach In Processes
INFINITI	All Mode	2015 - 2018	Engine	Special Function	Resetting Of Adaption Values
INFINITI	All Mode	2015 - 2018	Engine	Special Function	Ethanol Reading Frequency Counter Reset
INFINITI	All Mode	2015 - 2018	Engine	Special Function	Teach In The Ethanol Proportion In The Fuel
INFINITI	All Mode	2015 - 2018	Engine	Special Function	Teach In Of Camshaft Position
INFINITI	All Mode	2015 - 2018	Engine	Read Fault Code	
INFINITI	All Mode	2015 - 2018	Engine	Clear Fault Code	
INFINITI	All Mode	2015 - 2018	Engine	Read Data Stream	
INFINITI	All Mode	2015 - 2018	Engine	Module Information	
INFINITI	All Mode	2015 - 2018	Engine	Actuation Test	Check boost pressure regulator
INFINITI	All Mode	2015 - 2018	Engine	Actuation Test	Check exhaust flap controller
INFINITI	All Mode	2015 - 2018	Engine	Actuation Test	Low pressure EGR temperature sensor
INFINITI	All Mode	2015 - 2018	Engine	Actuation Test	High pressure fuel circuit leak test
INFINITI	All Mode	2015 - 2018	Engine	Actuation Test	Check DPF regeneration heater booster control unit
INFINITI	All Mode	2015 - 2018	Engine	Actuation Test	Rail Pressure
INFINITI	All Mode	2015 - 2018	Engine	Actuation Test	Check Fuel Injectors
INFINITI	All Mode	2015 - 2018	Engine	Special Function	Learned values reset - differential pressure sensor
INFINITI	All Mode	2015 - 2018	Engine	Special Function	Learned values reset - O2 sensor upstream of CAT

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

<b>make</b>	<b>model</b>	<b>year</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
INFINITI	All Mode	2015 - 2018	Engine	Special Function	Teach in high pressure EGR actuator
INFINITI	All Mode	2015 - 2018	Engine	Special Function	Learned values reset - rail pressure sensor
INFINITI	All Mode	2015 - 2018	Engine	Special Function	Learned values reset - turbocharger
INFINITI	All Mode	2015 - 2018	Engine	Special Function	Teach in low pressure EGR actuator
INFINITI	All Mode	2015 - 2018	Engine	Special Function	Teach in exhaust flap controller
INFINITI	All Mode	2015 - 2018	Engine	Special Function	Teach in throttle valve actuator
INFINITI	All Mode	2015 - 2018	Engine	Special Function	Learned values reset - fuel system high pressure pump
INFINITI	All Mode	2015 - 2018	Engine	Special Function	Learned values reset - diesel particulate filter
INFINITI	All Mode	2015 - 2018	Engine	Special Function	Check glow output stage
INFINITI	All Mode	2015 - 2018	Engine	Special Function	Activation Of Fuel Pump
INFINITI	All Mode	2015 - 2018	Engine	Special Function	Status Of Teach In Processes
INFINITI	All Mode	2015 - 2018	Engine	Special Function	Injector Learning Value Clear
INFINITI	All Mode	2015 - 2018	Engine	Read Data Stream	
INFINITI	All Mode	2015 - 2018	Engine	Module Information	
INFINITI	All Mode	2015 - 2018	Engine	Actuation Test	Check EGR Cooler Bypss Sw Over Valve
INFINITI	All Mode	2015 - 2018	Engine	Actuation Test	Check Oil Spray Nozzles Shutoff Valve
INFINITI	All Mode	2015 - 2018	Engine	Actuation Test	Check Rail Pressure Sensor
INFINITI	All Mode	2015 - 2018	Engine	Actuation Test	Check Boost Pressure Positioner
INFINITI	All Mode	2015 - 2018	Engine	Actuation Test	Auto Stop Start
INFINITI	All Mode	2015 - 2018	Engine	Special Function	Teach In Boost Pressure Positioner
INFINITI	All Mode	2015 - 2018	Engine	Special Function	Reset Of Contamination Level Of Air Filter
INFINITI	All Mode	2015 - 2018	Engine	Special Function	Activation Of Fuel Pump
INFINITI	All Mode	2015 - 2018	Engine	Special Function	Reset Of Learned Values Of Cmsft Hall Sen
INFINITI	All Mode	2015 - 2018	Engine	Special Function	Teach In Of Intake Port Shutoff
INFINITI	All Mode	2015 - 2018	Engine	Special Function	Vin Registration
INFINITI	All Mode	2015 - 2018	Engine	Special Function	STRT OPRTN CNTR CLEAR
INFINITI	All Mode	2015 - 2018	Engine	Special Function	H/P Fuel Pump Total Starts Counter Clear
INFINITI	All Mode	2015 - 2018	Engine	Special Function	Teach In Of Throttle Valve Stop
INFINITI	All Mode	2015 - 2018	Engine	Special Function	Replace Diesel Particulate Filter
INFINITI	All Mode	2015 - 2018	Engine	Special Function	Injector Injection Quantity Adjustment
INFINITI	All Mode	2015 - 2018	Engine	Special Function	OXIDATION CATALYTIC CONVERTER
INFINITI	All Mode	2015 - 2018	Engine	Special Function	Teach In Of DPF After Replace Of CDI C/U
INFINITI	All Mode	2015 - 2018	Engine	Special Function	OPR TIME BASIC DIAG SCR CATALYSTIC CONVRTR
INFINITI	All Mode	2015 - 2018	Engine	Special Function	OPE TIME BASIC DIAG TEMP SEN UPSTREAM SCR CAT
INFINITI	All Mode	2015 - 2018	Engine	Special Function	TEACH IN AFTER REPLAC ADBLUE METERING VALVE
INFINITI	All Mode	2013 - 2018	Engine	Read Fault Code	
INFINITI	All Mode	2013 - 2018	Engine	Clear Fault Code	
INFINITI	All Mode	2013 - 2018	Engine	Read Data Stream	
INFINITI	All Mode	2013 - 2018	Engine	Module Information	
INFINITI	All Mode	2013 - 2018	Engine	Actuation Test	Auto Stop Start
INFINITI	All Mode	2013 - 2018	Engine	Actuation Test	Check Deceleration Air Switchover Valve
INFINITI	All Mode	2013 - 2018	Engine	Actuation Test	Check Engine Oil Pump Valve
INFINITI	All Mode	2013 - 2018	Engine	Actuation Test	Check Intake Camshaft Solenoid
INFINITI	All Mode	2013 - 2018	Engine	Actuation Test	Check Exhaust Camshaft Solenoid
INFINITI	All Mode	2013 - 2018	Engine	Actuation Test	Purging Switchover Valve
INFINITI	All Mode	2013 - 2018	Engine	Actuation Test	Check activated charcoal canister shutoff valve
INFINITI	All Mode	2013 - 2018	Engine	Actuation Test	Partial load operation crankcase ventilation valve
INFINITI	All Mode	2013 - 2018	Engine	Actuation Test	Check fuel tank pressure sensor



**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

<b>make</b>	<b>model</b>	<b>year</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
INFINITI	All Mode	2013 - 2018	Engine	Actuation Test	Check purging pressure control
INFINITI	All Mode	2013 - 2018	Engine	Actuation Test	Check cylinder fuel injectors
INFINITI	All Mode	2013 - 2018	Engine	Actuation Test	Check cylinder fuel injectors for leaks
INFINITI	All Mode	2013 - 2018	Engine	Actuation Test	Check Fuel HI Press Circ For Leaktightness
INFINITI	All Mode	2013 - 2018	Engine	Special Function	Resetting Of Adaption Values
INFINITI	All Mode	2013 - 2018	Engine	Special Function	Camshaft Reference Adaptation
INFINITI	All Mode	2013 - 2018	Engine	Special Function	Teach In Of Throttle Valve Stop
INFINITI	All Mode	2013 - 2018	Engine	Special Function	Teach In Of Camshaft Position
INFINITI	All Mode	2013 - 2018	Engine	Special Function	Injector Injection Quantity Adjustment
INFINITI	All Mode	2013 - 2018	Engine	Special Function	Vin Registration
INFINITI	All Mode	2013 - 2018	Engine	Special Function	STRT OPRTN CNTR CLEAR
INFINITI	All Mode	2013 - 2018	Engine	Special Function	H/P Fuel Pump Total Starts Counter Clear
INFINITI	All Mode	2013 - 2018	Engine	Special Function	Teach In Of Sensor Rotor Adaptation
INFINITI	All Mode	2013 - 2018	Engine	Special Function	Status Of Teach In Processes
INFINITI	All Mode	2016 - 2018	Engine	Read Fault Code	
INFINITI	All Mode	2016 - 2018	Engine	Clear Fault Code	
INFINITI	All Mode	2016 - 2018	Engine	Read Data Stream	
INFINITI	All Mode	2016 - 2018	Engine	Module Information	
INFINITI	All Mode	Up to 2017	Engine	Read Fault Code	
INFINITI	All Mode	Up to 2017	Engine	Clear Fault Code	
INFINITI	All Mode	Up to 2017	Engine	Read Data Stream	
INFINITI	All Mode	Up to 2017	Engine	Module Information	
INFINITI	All Mode	Up to 2017	Engine	Special Function	TP SW/TP SEN IDLE POSI ADJ
INFINITI	All Mode	Up to 2017	Engine	Special Function	TP SW/TP SEN IDLE POSI ADJ
INFINITI	All Mode	Up to 2017	Engine	Special Function	IGNITION TIMING ADJ
INFINITI	All Mode	Up to 2017	Engine	Special Function	FUEL PRESSURE RELEASE
INFINITI	All Mode	Up to 2017	Engine	Special Function	CHECK FUEL LINES
INFINITI	All Mode	Up to 2017	Engine	Special Function	IDLE AIR VOL LEARN
INFINITI	All Mode	Up to 2017	Engine	Special Function	SELF-LEARNING CONT
INFINITI	All Mode	Up to 2017	Engine	Special Function	
INFINITI	All Mode	Up to 2017	Engine	Read Fault Code	
INFINITI	All Mode	Up to 2017	Engine	Clear Fault Code	
INFINITI	All Mode	Up to 2017	Engine	Read Data Stream	
INFINITI	All Mode	Up to 2017	Engine	Module Information	
INFINITI	All Mode	Up to 2017	Engine	Special Function	
INFINITI	All Mode	Up to 2017	Engine	Special Function	
INFINITI	All Mode	Up to 2008	Engine	Read Fault Code	
INFINITI	All Mode	Up to 2008	Engine	Clear Fault Code	
INFINITI	All Mode	Up to 2008	Engine	Read Data Stream	
INFINITI	All Mode	Up to 2008	Engine	Module Information	
INFINITI	All Mode	Up to 2008	Engine	Actuation Test	THERMO NO. 3 RELAY
INFINITI	All Mode	Up to 2008	Engine	Actuation Test	FAN UNIT S SPD RLY
INFINITI	All Mode	Up to 2008	Engine	Actuation Test	FAN UNIT H SPD RLY
INFINITI	All Mode	Up to 2008	Engine	Actuation Test	OBD LIGHT
INFINITI	All Mode	Up to 2008	Engine	Actuation Test	EGR SOLENOID VALVE
INFINITI	All Mode	Up to 2008	Engine	Actuation Test	PRHT RLY GROUP N-1
INFINITI	All Mode	Up to 2008	Engine	Actuation Test	PREHEATER LIGHT
INFINITI	All Mode	Up to 2008	Engine	Actuation Test	OVERHEATING W/L
INFINITI	All Mode	Up to 2008	Engine	Actuation Test	THERMOPLUNGER RLY1
INFINITI	All Mode	Up to 2008	Engine	Actuation Test	THERMOPLUNGER RLY2
INFINITI	All Mode	Up to 2008	Engine	Actuation Test	HIGH PRESSURE PUMP
INFINITI	All Mode	Up to 2008	Engine	Actuation Test	A/C COMPRESSOR
INFINITI	All Mode	Up to 2008	Engine	Actuation Test	INJECTOR CYLINDER 1
INFINITI	All Mode	Up to 2008	Engine	Actuation Test	INJECTOR CYLINDER 2
INFINITI	All Mode	Up to 2008	Engine	Actuation Test	INJECTOR CYLINDER 3
INFINITI	All Mode	Up to 2008	Engine	Actuation Test	INJECTOR CYLINDER 4
INFINITI	All Mode	Up to 2008	Engine	Actuation Test	LOCK INJECTOR CTRL
INFINITI	All Mode	Up to 2008	Engine	Actuation Test	UNLK INJECTOR CTRL
INFINITI	All Mode	Up to 2008	Engine	Actuation Test	HIGH PRESS CIRC LEAK T
INFINITI	All Mode	Up to 2008	Engine	Special Function	Saving Data For Replc CPU
INFINITI	All Mode	Up to 2008	Engine	Special Function	Writing Data For Replc CPU
INFINITI	All Mode	Up to 2008	Engine	Special Function	Vehicle Func Prog
INFINITI	All Mode	Up to 2008	Engine	Special Function	Decrement Idle Speed
INFINITI	All Mode	Up to 2008	Engine	Special Function	Increment Idle Speed
INFINITI	All Mode	Up to 2008	Engine	Special Function	EGR Adaptives
INFINITI	All Mode	Up to 2008	Engine	Special Function	Reset Pump Forcefeeding
INFINITI	All Mode	Up to 2008	Engine	Special Function	Reset Injctr Adaptative
INFINITI	All Mode	Up to 2008	Engine	Special Function	Enter Injctr Calib Data
INFINITI	All Mode	Up to 2008	Engine	Read Fault Code	

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
INFINITI	All Mode	Up to 2008	Engine	Clear Fault Code	
INFINITI	All Mode	Up to 2008	Engine	Read Data Stream	
INFINITI	All Mode	Up to 2008	Engine	Module Information	
INFINITI	All Mode	Up to 2008	Engine	Special Function	IGNITION TIMING ADJ
INFINITI	All Mode	Up to 2008	Engine	Special Function	IGNITION TIMING ADJ
INFINITI	All Mode	Up to 2008	Engine	Special Function	CHECK FUEL LINES
INFINITI	All Mode	Up to 2008	Engine	Special Function	FUEL PRESSURE RELEASE
INFINITI	All Mode	Up to 2008	Engine	Special Function	TP SW/TP SEN IDLE POSI ADJ
INFINITI	All Mode	Up to 2008	Engine	Special Function	TP SW/TP SEN IDLE POSI ADJ
INFINITI	All Mode	Up to 2008	Engine	Special Function	SELF-LEARNING CONT
INFINITI	All Mode	Up to 2008	Engine	Special Function	SELF-LEARNING CONT
INFINITI	All Mode	Up to 2008	Engine	Special Function	SELF-LEARNING CONT
INFINITI	All Mode	Up to 2008	Engine	Special Function	CLOSED TH/SW ADJ
INFINITI	All Mode	Up to 2008	Engine	Special Function	CLOSED TH/SW ADJ
INFINITI	All Mode	Up to 2008	Engine	Special Function	CLOSED TH/SW ADJ
INFINITI	All Mode	Up to 2008	Engine	Special Function	IDLE RPM ADJ
INFINITI	All Mode	Up to 2008	Engine	Special Function	IACV-AAC/V ADJ
INFINITI	All Mode	Up to 2008	Engine	Special Function	SET IDLE SPEED
INFINITI	All Mode	Up to 2008	Engine	Read Fault Code	
INFINITI	All Mode	Up to 2008	Engine	Clear Fault Code	
INFINITI	All Mode	Up to 2008	Engine	Read Data Stream	
INFINITI	All Mode	Up to 2008	Engine	Module Information	
INFINITI	All Mode	Up to 2008	Engine	Special Function	IDLE AIR VOL LEARN
INFINITI	All Mode	Up to 2008	Engine	Special Function	SELF-LEARNING CONT
INFINITI	All Mode	Up to 2008	Engine	Special Function	SELF-LEARNING CONT
INFINITI	All Mode	Up to 2008	Engine	Special Function	SELF-LEARNING CONT
INFINITI	All Mode	Up to 2008	Engine	Special Function	IGNITION TIMING ADJ
INFINITI	All Mode	Up to 2008	Engine	Special Function	IGNITION TIMING ADJ
INFINITI	All Mode	Up to 2008	Engine	Special Function	CHECK FUEL LINES
INFINITI	All Mode	Up to 2008	Engine	Special Function	FUEL PRESSURE RELEASE
INFINITI	All Mode	Up to 2008	Engine	Special Function	TP SW/TP SEN IDLE POSI ADJ
INFINITI	All Mode	Up to 2008	Engine	Special Function	TP SW/TP SEN IDLE POSI ADJ
INFINITI	All Mode	Up to 2008	Engine	Special Function	CLOSED TH/SW ADJ
INFINITI	All Mode	Up to 2008	Engine	Special Function	CLOSED TH/SW ADJ
INFINITI	All Mode	Up to 2008	Engine	Special Function	CLOSED TH/SW ADJ
INFINITI	All Mode	Up to 2008	Engine	Special Function	IDLE RPM ADJ
INFINITI	All Mode	Up to 2008	Engine	Special Function	IACV-AAC/V ADJ
INFINITI	All Mode	Up to 2008	Engine	Special Function	SET IDLE SPEED
INFINITI	All Mode	Up to 2008	Engine	Read Fault Code	
INFINITI	All Mode	Up to 2008	Engine	Clear Fault Code	
INFINITI	All Mode	Up to 2008	Engine	Read Data Stream	
INFINITI	All Mode	Up to 2008	Engine	Module Information	
INFINITI	All Mode	Up to 2008	Engine	Actuation Test	
INFINITI	All Mode	Up to 2017	Multi AV	Read Fault Code	
INFINITI	All Mode	Up to 2017	Multi AV	Clear Fault Code	
INFINITI	All Mode	Up to 2017	Multi AV	Read Data Stream	
INFINITI	All Mode	Up to 2017	Multi AV	Module Information	
INFINITI	All Mode	Up to 2017	Multi AV	Special Function	SELF-DIAG[ETC]
INFINITI	All Mode	Up to 2017	Multi AV	Read Fault Code	
INFINITI	All Mode	Up to 2017	Multi AV	Clear Fault Code	
INFINITI	All Mode	Up to 2017	Multi AV	Read Data Stream	
INFINITI	All Mode	Up to 2017	Multi AV	Read Freeze Frame	
INFINITI	All Mode	Up to 2017	Multi AV	Module Information	
INFINITI	All Mode	Up to 2017	Multi AV	Special Function	SELF-DIAG[ETC]
INFINITI	All Mode	Up to 2017	Multi AV	Read Fault Code	
INFINITI	All Mode	Up to 2017	Multi AV	Clear Fault Code	
INFINITI	All Mode	Up to 2017	Multi AV	Read Data Stream	
INFINITI	All Mode	Up to 2017	Multi AV	Read Freeze Frame	
INFINITI	All Mode	Up to 2017	Multi AV	Module Information	
INFINITI	All Mode	Up to 2017	Multi AV	Read Fault Code	
INFINITI	All Mode	Up to 2017	Multi AV	Clear Fault Code	
INFINITI	All Mode	Up to 2017	Multi AV	Read Data Stream	
INFINITI	All Mode	Up to 2017	Multi AV	Module Information	
INFINITI	All Mode	Up to 2017	Multi AV	Read Fault Code	
INFINITI	All Mode	Up to 2017	Multi AV	Clear Fault Code	
INFINITI	All Mode	Up to 2017	Multi AV	Read Data Stream	
INFINITI	All Mode	Up to 2017	Multi AV	Read Freeze Frame	
INFINITI	All Mode	Up to 2017	Multi AV	Module Information	
INFINITI	All Mode	Up to 2018	Multi AV	Read Fault Code	
INFINITI	All Mode	Up to 2018	Multi AV	Clear Fault Code	
INFINITI	All Mode	Up to 2018	Multi AV	Read Data Stream	
INFINITI	All Mode	Up to 2018	Multi AV	Module Information	
INFINITI	All Mode	Up to 2018	Multi AV	Special Function	ST ANG Sen Adjustment

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
INFINITI	All Mode	2015 - 2018	Multi AV	Read Fault Code	
INFINITI	All Mode	2015 - 2018	Multi AV	Clear Fault Code	
INFINITI	All Mode	2015 - 2018	Multi AV	Read Data Stream	
INFINITI	All Mode	2015 - 2018	Multi AV	Module Information	
INFINITI	All Mode	2015 - 2018	Multi AV	Special Function	ST ANG Sen Adjustment
INFINITI	All Mode	2015 - 2018	Multi AV	Read Fault Code	
INFINITI	All Mode	2015 - 2018	Multi AV	Clear Fault Code	
INFINITI	All Mode	2015 - 2018	Multi AV	Read Data Stream	
INFINITI	All Mode	2015 - 2018	Multi AV	Module Information	
INFINITI	All Mode	2015 - 2018	Multi AV	Special Function	ST ANG Sen Adjustment
INFINITI	All Mode	Up to 2008	Multi AV	Read Fault Code	
INFINITI	All Mode	Up to 2008	Multi AV	Clear Fault Code	
INFINITI	All Mode	Up to 2008	Multi AV	Read Data Stream	
INFINITI	All Mode	Up to 2008	Multi AV	Module Information	
INFINITI	All Mode	2016 - 2018	CAN GATEWAY3	Read Fault Code	
INFINITI	All Mode	2016 - 2018	CAN GATEWAY3	Clear Fault Code	
INFINITI	All Mode	2016 - 2018	CAN GATEWAY3	Read Data Stream	
INFINITI	All Mode	2016 - 2018	CAN GATEWAY3	Module Information	
INFINITI	All Mode	Up to 2008	NATS IMMU	Read Fault Code	
INFINITI	All Mode	Up to 2008	NATS IMMU	Clear Fault Code	
INFINITI	All Mode	Up to 2008	NATS IMMU	Module Information	
INFINITI	All Mode	Up to 2008	Smart Entrance	Read Fault Code	
INFINITI	All Mode	Up to 2008	Smart Entrance	Clear Fault Code	
INFINITI	All Mode	Up to 2008	Smart Entrance	Read Data Stream	
INFINITI	All Mode	Up to 2008	Smart Entrance	Module Information	
INFINITI	All Mode	Up to 2008	Smart Entrance	Special Function	
INFINITI	All Mode	Up to 2008	Smart Entrance	Read Data Stream	
INFINITI	All Mode	Up to 2008	Smart Entrance	Module Information	
INFINITI	All Mode	Up to 2008	Smart Entrance	Special Function	REMO CONT ID ERASUR
INFINITI	All Mode	Up to 2008	Smart Entrance	Special Function	THEFT ALM TRG
INFINITI	All Mode	Up to 2008	Smart Entrance	Special Function	REMO CONT ID REGIST
INFINITI	All Mode	Up to 2008	Smart Entrance	Special Function	HZRD REM SET
INFINITI	All Mode	Up to 2008	Smart Entrance	Special Function	
INFINITI	All Mode	Up to 2008	Smart Entrance	Read Data Stream	
INFINITI	All Mode	Up to 2008	Smart Entrance	Module Information	
INFINITI	All Mode	Up to 2008	Smart Entrance	Special Function	REMO CONT ID REGIST
INFINITI	All Mode	Up to 2008	Smart Entrance	Special Function	REMO CONT ID ERASUR
INFINITI	All Mode	Up to 2017	Air Levelizer	Read Fault Code	
INFINITI	All Mode	Up to 2017	Air Levelizer	Clear Fault Code	
INFINITI	All Mode	Up to 2017	Air Levelizer	Read Data Stream	
INFINITI	All Mode	Up to 2017	Air Levelizer	Module Information	
INFINITI	All Mode	Up to 2017	Air Levelizer	Special Function	
INFINITI	All Mode	Up to 2011	Rearview Camera	Read Data Stream	
INFINITI	All Mode	Up to 2011	Rearview Camera	Module Information	
INFINITI	All Mode	Up to 2011	Rearview Camera	Special Function	
INFINITI	All Mode	Up to 2010	S/Blind Camera	Read Data Stream	
INFINITI	All Mode	Up to 2010	S/Blind Camera	Module Information	
INFINITI	All Mode	Up to 2010	S/Blind Camera	Special Function	
INFINITI	All Mode	Up to 2008	Active Engine Mount	Read Fault Code	
INFINITI	All Mode	Up to 2008	Active Engine Mount	Clear Fault Code	
INFINITI	All Mode	Up to 2008	Active Engine Mount	Read Data Stream	
INFINITI	All Mode	Up to 2008	Active Engine Mount	Module Information	
INFINITI	All Mode	Up to 2008	Active Sus	Read Fault Code	
INFINITI	All Mode	Up to 2008	Active Sus	Clear Fault Code	
INFINITI	All Mode	Up to 2008	Active Sus	Read Data Stream	
INFINITI	All Mode	Up to 2008	Active Sus	Module Information	
INFINITI	All Mode	Up to 2008	Active Sus	Actuation Test	
INFINITI	All Mode	Up to 2008	Active Sus	Read Fault Code	
INFINITI	All Mode	Up to 2008	Active Sus	Clear Fault Code	
INFINITI	All Mode	Up to 2008	Active Sus	Read Data Stream	
INFINITI	All Mode	Up to 2008	Active Sus	Module Information	
INFINITI	All Mode	Up to 2008	Active Sus	Special Function	HYDRAULIC SYSTEM
INFINITI	All Mode	Up to 2008	Active Sus	Special Function	OPERATION CHECK
INFINITI	All Mode	Up to 2008	ASCD	Read Fault Code	
INFINITI	All Mode	Up to 2008	ASCD	Clear Fault Code	
INFINITI	All Mode	Up to 2008	ASCD	Read Data Stream	
INFINITI	All Mode	Up to 2008	ASCD	Module Information	
INFINITI	All Mode	Up to 2008	ASCD	Read Fault Code	
INFINITI	All Mode	Up to 2008	ASCD	Clear Fault Code	
INFINITI	All Mode	Up to 2008	ASCD	Read Data Stream	
INFINITI	All Mode	Up to 2008	ASCD	Module Information	
INFINITI	All Mode	Up to 2008	Distance Control	Read Fault Code	
INFINITI	All Mode	Up to 2008	Distance Control	Clear Fault Code	
INFINITI	All Mode	Up to 2008	Distance Control	Read Data Stream	
INFINITI	All Mode	Up to 2008	Motor Assist	Read Fault Code	
INFINITI	All Mode	Up to 2008	Motor Assist	Clear Fault Code	
INFINITI	All Mode	Up to 2008	Motor Assist	Read Data Stream	
INFINITI	All Mode	Up to 2008	Motor Assist	Special Function	
INFINITI	All Mode	Up to 2008	IVMS (In-Vehicle Multiplexing System)	Read Fault Code	
INFINITI	All Mode	Up to 2008	IVMS (In-Vehicle Multiplexing System)	Clear Fault Code	

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
INFINITI	All Mode	Up to 2008	IVMS (In-Vehicle Multiplexing System)	Read Data Stream	
INFINITI	All Mode	Up to 2008	IVMS (In-Vehicle Multiplexing System)	Module Information	
INFINITI	All Mode	Up to 2008	IVMS (In-Vehicle Multiplexing System)	Special Function	UNIVERSAL FUNCTION
INFINITI	All Mode	Up to 2008	IVMS (In-Vehicle Multiplexing System)	Special Function	
INFINITI	All Mode	2016 - 2018	CAN GATEWAY2	Read Fault Code	
INFINITI	All Mode	2016 - 2018	CAN GATEWAY2	Clear Fault Code	
INFINITI	All Mode	2016 - 2018	CAN GATEWAY2	Read Data Stream	
INFINITI	All Mode	2016 - 2018	CAN GATEWAY2	Module Information	
INFINITI	All Mode	Up to 2008	TCS (Traction Control System)	Read Fault Code	
INFINITI	All Mode	Up to 2008	TCS (Traction Control System)	Clear Fault Code	
INFINITI	All Mode	Up to 2008	TCS (Traction Control System)	Read Data Stream	
INFINITI	All Mode	Up to 2008	TCS (Traction Control System)	Module Information	
INFINITI	All Mode	Up to 2008	TCS (Traction Control System)	Special Function	THRTL POS SEN2 ADJ
INFINITI	All Mode	Up to 2008	TCS (Traction Control System)	Special Function	CLSD/TH-P LEARN CLR
INFINITI	All Mode	2013 - 2018	FSCM (Fuel System Control Modle)	Read Fault Code	
INFINITI	All Mode	2013 - 2018	FSCM (Fuel System Control Modle)	Clear Fault Code	
INFINITI	All Mode	2013 - 2018	FSCM (Fuel System Control Modle)	Read Data Stream	
INFINITI	All Mode	2013 - 2018	FSCM (Fuel System Control Modle)	Module Information	
INFINITI	All Mode	2013 - 2018	FSCM (Fuel System Control Modle)	Actuation Test	CK Fuel Prss & Intrnl Lkghtnss Of FL Sys
INFINITI	All Mode	2015 - 2018	FSCM (Fuel System Control Modle)	Read Fault Code	
INFINITI	All Mode	2015 - 2018	FSCM (Fuel System Control Modle)	Clear Fault Code	
INFINITI	All Mode	2015 - 2018	FSCM (Fuel System Control Modle)	Read Data Stream	
INFINITI	All Mode	2015 - 2018	FSCM (Fuel System Control Modle)	Module Information	
INFINITI	All Mode	2015 - 2018	FSCM (Fuel System Control Modle)	Read Fault Code	
INFINITI	All Mode	2015 - 2018	FSCM (Fuel System Control Modle)	Clear Fault Code	
INFINITI	All Mode	2015 - 2018	FSCM (Fuel System Control Modle)	Read Data Stream	
INFINITI	All Mode	2015 - 2018	FSCM (Fuel System Control Modle)	Module Information	
INFINITI	INFINITI QX80	2016	Vehicle Data Transmitter	Read Fault Code	
INFINITI	INFINITI QX80	2016	Vehicle Data Transmitter	Clear Fault Code	
INFINITI	INFINITI QX80	2016	Vehicle Data Transmitter	Read Data Stream	
INFINITI	INFINITI QX80	2016	Vehicle Data Transmitter	Module Information	
INFINITI	INFINITI QX80	2016	Vehicle Data Transmitter	Special Function	Bluetooth Function
INFINITI	INFINITI QX80	2016	Vehicle Data Transmitter	Special Function	GPS Data Logger Connection Setting
INFINITI	INFINITI QX80	2016	Vehicle Data Transmitter	Special Function	Bluetooth Pairing Erase
INFINITI	INFINITI QX80	2016	Vehicle Data Transmitter	Special Function	Vehicle Data Transmitter Setting Erase
INFINITI	INFINITI QX80	2016	Vehicle Data Transmitter	Special Function	Save Vin Data
INFINITI	INFINITI QX80	2016	Vehicle Data Transmitter	Special Function	Write Vin (Saved Data)
INFINITI	INFINITI QX80	2016	Vehicle Data Transmitter	Special Function	Write Vin (Manual Input)
INFINITI	All Mode	2013 - 2014	PMAS	Read Fault Code	
INFINITI	All Mode	2013 - 2014	PMAS	Clear Fault Code	
INFINITI	All Mode	2013 - 2014	PMAS	Read Data Stream	
INFINITI	All Mode	2013 - 2014	PMAS	Module Information	
INFINITI	All Mode	2013 - 2014	PMAS	Special Function	G Sensor Horizon Status Learning
INFINITI	All Mode	2013 - 2014	PMAS	Special Function	Cause Of Auto-Cancel 4
INFINITI	All Mode	2015 - 2018	Left front door control unit	Read Fault Code	
INFINITI	All Mode	2015 - 2018	Left front door control unit	Clear Fault Code	
INFINITI	All Mode	2015 - 2018	Left front door control unit	Read Data Stream	
INFINITI	All Mode	2015 - 2018	Left front door control unit	Module Information	
INFINITI	All Mode	2015 - 2018	Left front door control unit	Actuation Test	Front door lock actuator left
INFINITI	All Mode	2015 - 2018	Left front door control unit	Actuation Test	Front door switch illumination left
INFINITI	All Mode	2015 - 2018	Left front door control unit	Actuation Test	Front super lock actuator left
INFINITI	All Mode	2015 - 2018	Left front door control unit	Actuation Test	Front door handle illumination left
INFINITI	All Mode	2015 - 2018	Left front door control unit	Actuation Test	Front door exit and warning lamp left
INFINITI	All Mode	2015 - 2018	Left front door control unit	Actuation Test	Front door ambience illuminatin left
INFINITI	All Mode	2015 - 2018	Left front door control unit	Actuation Test	Side turn signal lamp left
INFINITI	All Mode	2015 - 2018	Left front door control unit	Actuation Test	Front power window motor left
INFINITI	All Mode	2015 - 2018	Left front door control unit	Actuation Test	Outside mirror ambient lamp left
INFINITI	All Mode	2015 - 2018	Left front door control unit	Actuation Test	Left blind spot assist warning
INFINITI	All Mode	2015 - 2018	Left front door control unit	Actuation Test	Auto anti-dazzling mirror
INFINITI	All Mode	2015 - 2018	Left front door control unit	Actuation Test	Power folding unit
INFINITI	All Mode	2015 - 2018	Left front door control unit	Actuation Test	Door mirror defogger
INFINITI	All Mode	2015 - 2018	Left front door control unit	Actuation Test	Adjustment actuator motor via actuation
INFINITI	All Mode	2015 - 2018	Left front door control unit	Actuation Test	Vertical and horizontal inclination adjustment
INFINITI	All Mode	2015 - 2018	Left front door control unit	Actuation Test	Left memory function

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
INFINITI	All Mode	2015 - 2018	Left front door control unit	Actuation Test	Denormalization of left front power window
INFINITI	All Mode	2015 - 2018	Left front door control unit	Actuation Test	Left outside mirror adjust
INFINITI	All Mode	2015 - 2018	Left front door control unit	Actuation Test	LEDs
INFINITI	All Mode	2015 - 2018	Left front door control unit	Actuation Test	Control unit reset
INFINITI	All Mode	2015 - 2018	Right front door control unit	Read Fault Code	
INFINITI	All Mode	2015 - 2018	Right front door control unit	Clear Fault Code	
INFINITI	All Mode	2015 - 2018	Right front door control unit	Read Data Stream	
INFINITI	All Mode	2015 - 2018	Right front door control unit	Module Information	
INFINITI	All Mode	2015 - 2018	Right front door control unit	Actuation Test	Front door lock actuator right
INFINITI	All Mode	2015 - 2018	Right front door control unit	Actuation Test	Front door switch illumination right
INFINITI	All Mode	2015 - 2018	Right front door control unit	Actuation Test	Front super lock actuator right
INFINITI	All Mode	2015 - 2018	Right front door control unit	Actuation Test	Front door handle illumination right
INFINITI	All Mode	2015 - 2018	Right front door control unit	Actuation Test	Front door exit and warning lamp right
INFINITI	All Mode	2015 - 2018	Right front door control unit	Actuation Test	Front door ambience illumination right
INFINITI	All Mode	2015 - 2018	Right front door control unit	Actuation Test	Side turn signal lamp right
INFINITI	All Mode	2015 - 2018	Right front door control unit	Actuation Test	Front power window motor right
INFINITI	All Mode	2015 - 2018	Right front door control unit	Actuation Test	Outside mirror ambient lamp right
INFINITI	All Mode	2015 - 2018	Right front door control unit	Actuation Test	Right blind spot assist warning
INFINITI	All Mode	2015 - 2018	Right front door control unit	Actuation Test	Auto anti-dazzling mirror
INFINITI	All Mode	2015 - 2018	Right front door control unit	Actuation Test	Power folding unit
INFINITI	All Mode	2015 - 2018	Right front door control unit	Actuation Test	Door mirror defogger
INFINITI	All Mode	2015 - 2018	Right front door control unit	Actuation Test	Adjustment actuator motor via actuation
INFINITI	All Mode	2015 - 2018	Right front door control unit	Actuation Test	Vertical and horizontal inclination adjustment
INFINITI	All Mode	2015 - 2018	Right front door control unit	Actuation Test	Right memory function
INFINITI	All Mode	2015 - 2018	Right front door control unit	Actuation Test	Denormalization of right rear power window
INFINITI	All Mode	2015 - 2018	Right front door control unit	Actuation Test	Right outside mirror adjust
INFINITI	All Mode	2015 - 2018	Right front door control unit	Actuation Test	LEDs
INFINITI	All Mode	2015 - 2018	Right front door control unit	Actuation Test	Control unit reset
INFINITI	All Mode	2015 - 2018	Siren control unit	Read Fault Code	
INFINITI	All Mode	2015 - 2018	Siren control unit	Clear Fault Code	
INFINITI	All Mode	2015 - 2018	Siren control unit	Read Data Stream	
INFINITI	All Mode	2015 - 2018	Siren control unit	Module Information	
INFINITI	All Mode	2015 - 2018	Siren control unit	Actuation Test	Actuation of tow away prot buttn and interior prot buttn
INFINITI	All Mode	2015 - 2018	Siren control unit	Actuation Test	Eighth to last data record
INFINITI	All Mode	2015 - 2018	Siren control unit	Actuation Test	Fifth from last data record
INFINITI	All Mode	2015 - 2018	Siren control unit	Actuation Test	Fourth from last data record
INFINITI	All Mode	2015 - 2018	Siren control unit	Actuation Test	Last data record
INFINITI	All Mode	2015 - 2018	Siren control unit	Actuation Test	Ninth to last data record
INFINITI	All Mode	2015 - 2018	Siren control unit	Actuation Test	Second from last data record
INFINITI	All Mode	2015 - 2018	Siren control unit	Actuation Test	Seventh to last data record
INFINITI	All Mode	2015 - 2018	Siren control unit	Actuation Test	Sixth to last data record
INFINITI	All Mode	2015 - 2018	Siren control unit	Actuation Test	Tenth to last data record
INFINITI	All Mode	2015 - 2018	Siren control unit	Actuation Test	Third from last data record
INFINITI	All Mode	2015 - 2018	Siren control unit	Special Function	Clear alarm history
INFINITI	All Mode	2015 - 2018	Alarm siren	Read Data Stream	
INFINITI	All Mode	2015 - 2018	Alarm siren	Module Information	
INFINITI	All Mode	2015 - 2018	Passenger seat control unit	Read Fault Code	
INFINITI	All Mode	2015 - 2018	Passenger seat control unit	Clear Fault Code	
INFINITI	All Mode	2015 - 2018	Passenger seat control unit	Read Data Stream	
INFINITI	All Mode	2015 - 2018	Passenger seat control unit	Module Information	
INFINITI	All Mode	2015 - 2018	Passenger seat control unit	Actuation Test	Front passenger seat sliding motor
INFINITI	All Mode	2015 - 2018	Passenger seat control unit	Actuation Test	Front passenger seat lifting motor (front)
INFINITI	All Mode	2015 - 2018	Passenger seat control unit	Actuation Test	Front passenger seat lifting motor (rear)
INFINITI	All Mode	2015 - 2018	Passenger seat control unit	Actuation Test	Front passenger seat headrest motor
INFINITI	All Mode	2015 - 2018	Passenger seat control unit	Actuation Test	Front passenger seat reclining motor
INFINITI	All Mode	2015 - 2018	Passenger seat control unit	Special Function	Normalization
INFINITI	All Mode	2015 - 2018	Intelligent battery sensor	Module Information	
INFINITI	All Mode	2015 - 2018	Upper control panel cont unit	Module Information	

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
INFINITI	All Mode	2015 - 2018	EC mirror compass	Module Information	
INFINITI	All Mode	2015 - 2018	Universal garage door opener	Module Information	
INFINITI	All Mode	2015 - 2018	Universal garage door opener	Special Function	Writing security byte
INFINITI	All Mode	2015 - 2018	Universal garage door opener	Special Function	Initial startup
INFINITI	All Mode	2015 - 2018	Light & rain sensor	Read Data Stream	
INFINITI	All Mode	2015 - 2018	Light & rain sensor	Module Information	
INFINITI	All Mode	2015 - 2018	Light & rain sensor	Special Function	Adaptation of component of rain sensor
INFINITI	All Mode	2015 - 2018	Overhead control panel unit	Module Information	
INFINITI	All Mode	2015 - 2018	Electronic ign switch cont unit	Read Fault Code	
INFINITI	All Mode	2015 - 2018	Electronic ign switch cont unit	Clear Fault Code	
INFINITI	All Mode	2015 - 2018	Electronic ign switch cont unit	Read Data Stream	
INFINITI	All Mode	2015 - 2018	Electronic ign switch cont unit	Module Information	
INFINITI	All Mode	2015 - 2018	Electronic ign switch cont unit	Actuation Test	Vehicle data
INFINITI	All Mode	2015 - 2018	Electronic ign switch cont unit	Special Function	Vin Registration
INFINITI	All Mode	2015 - 2018	Trailer recognition control unit	Read Fault Code	
INFINITI	All Mode	2015 - 2018	Trailer recognition control unit	Clear Fault Code	
INFINITI	All Mode	2015 - 2018	Trailer recognition control unit	Read Data Stream	
INFINITI	All Mode	2015 - 2018	Trailer recognition control unit	Module Information	
INFINITI	All Mode	2015 - 2018	Trailer recognition control unit	Actuation Test	Back-Up Lamp
INFINITI	All Mode	2015 - 2018	Trailer recognition control unit	Actuation Test	Stop Lamp
INFINITI	All Mode	2015 - 2018	Trailer recognition control unit	Actuation Test	Left Tail Lamp
INFINITI	All Mode	2015 - 2018	Trailer recognition control unit	Actuation Test	Right Tail Lamp
INFINITI	All Mode	2015 - 2018	Trailer recognition control unit	Actuation Test	Left Turn Signal
INFINITI	All Mode	2015 - 2018	Trailer recognition control unit	Actuation Test	Right Turn Signal
INFINITI	All Mode	2015 - 2018	Trailer recognition control unit	Actuation Test	Rear Fog Lamp Type
INFINITI	All Mode	2015 - 2018	Trailer recognition control unit	Actuation Test	Terminal 15g trailer socket
INFINITI	All Mode	2015 - 2018	Trailer recognition control unit	Actuation Test	Terminal 30g trailer socket
INFINITI	All Mode	2015 - 2018	Occupant classification unit	Read Data Stream	
INFINITI	All Mode	2015 - 2018	Occupant classification unit	Module Information	
INFINITI	All Mode	2015 - 2018	ICC sensor	Read Fault Code	
INFINITI	All Mode	2015 - 2018	ICC sensor	Clear Fault Code	
INFINITI	All Mode	2015 - 2018	ICC sensor	Read Data Stream	
INFINITI	All Mode	2015 - 2018	ICC sensor	Module Information	
INFINITI	All Mode	2015 - 2018	ICC sensor	Special Function	Calibration of long range radar sensor
INFINITI	All Mode	2015 - 2018	Parking assist	Read Fault Code	
INFINITI	All Mode	2015 - 2018	Parking assist	Clear Fault Code	
INFINITI	All Mode	2015 - 2018	Parking assist	Read Data Stream	
INFINITI	All Mode	2015 - 2018	Parking assist	Module Information	
INFINITI	All Mode	2015 - 2018	Parking assist	Special Function	Electrical contacting of sensor and functional test
INFINITI	All Mode	2015 - 2018	Steering column cont module	Read Fault Code	
INFINITI	All Mode	2015 - 2018	Steering column cont module	Clear Fault Code	
INFINITI	All Mode	2015 - 2018	Steering column cont module	Read Data Stream	
INFINITI	All Mode	2015 - 2018	Steering column cont module	Module Information	
INFINITI	All Mode	2015 - 2018	Steering column cont module	Actuation Test	Speedtronic light emitting diode
INFINITI	All Mode	2015 - 2018	Steering wheel switch pad	Read Data Stream	
INFINITI	All Mode	2015 - 2018	Steering wheel switch pad	Module Information	
INFINITI	All Mode	2015 - 2018	Radar sensor	Read Fault Code	
INFINITI	All Mode	2015 - 2018	Radar sensor	Clear Fault Code	
INFINITI	All Mode	2015 - 2018	Radar sensor	Read Data Stream	
INFINITI	All Mode	2015 - 2018	Radar sensor	Module Information	
INFINITI	All Mode	2015 - 2018	Radar sensor	Actuation Test	Check for invalid VIN
INFINITI	All Mode	2015 - 2018	Radar sensor	Actuation Test	CPA has received crash signal
INFINITI	All Mode	2015 - 2018	Radar sensor	Actuation Test	Collision prevention assist warning lamp
INFINITI	All Mode	2015 - 2018	Radar sensor	Special Function	Resetting of learned values of control unit
INFINITI	All Mode	2015 - 2018	Radar sensor	Special Function	Re learning
INFINITI	All Mode	2015 - 2018	LED H/L control module RH	Read Data Stream	
INFINITI	All Mode	2015 - 2018	LED H/L control module RH	Module Information	
INFINITI	All Mode	2015 - 2018	LED H/L control module RH	Special Function	Reset operating hours counter of FR lamp fan motor 2
INFINITI	All Mode	2015 - 2018	LED H/L control module LH	Read Data Stream	
INFINITI	All Mode	2015 - 2018	LED H/L control module LH	Module Information	
INFINITI	All Mode	2015 - 2018	LED H/L control module LH	Special Function	Reset operating hours counter of FL lamp fan motor 2
INFINITI	All Mode	2015 - 2018	Side radar RH	Read Fault Code	
INFINITI	All Mode	2015 - 2018	Side radar RH	Clear Fault Code	
INFINITI	All Mode	2015 - 2018	Side radar RH	Read Data Stream	
INFINITI	All Mode	2015 - 2018	Side radar RH	Module Information	
INFINITI	All Mode	2015 - 2018	Side radar LH	Read Fault Code	
INFINITI	All Mode	2015 - 2018	Side radar LH	Clear Fault Code	
INFINITI	All Mode	2015 - 2018	Side radar LH	Read Data Stream	
INFINITI	All Mode	2015 - 2018	Side radar LH	Module Information	

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
INFINITI	All Mode	2015 - 2018	Front camera unit	Read Fault Code	
INFINITI	All Mode	2015 - 2018	Front camera unit	Clear Fault Code	
INFINITI	All Mode	2015 - 2018	Front camera unit	Read Data Stream	
INFINITI	All Mode	2015 - 2018	Front camera unit	Module Information	
INFINITI	All Mode	2015 - 2018	Front camera unit	Actuation Test	Check auxiliary heater heating element has a malfunction
INFINITI	All Mode	2015 - 2018	Front camera unit	Special Function	Retrofitting
INFINITI	All Mode	2015 - 2018	PCM (Powertrain Control Module)	Read Fault Code	
INFINITI	All Mode	2015 - 2018	PCM (Powertrain Control Module)	Clear Fault Code	
INFINITI	All Mode	2015 - 2018	PCM (Powertrain Control Module)	Read Data Stream	
INFINITI	All Mode	2015 - 2018	PCM (Powertrain Control Module)	Module Information	
INFINITI	All Mode	2015 - 2018	PCM (Powertrain Control Module)	Read Fault Code	
INFINITI	All Mode	2015 - 2018	PCM (Powertrain Control Module)	Clear Fault Code	
INFINITI	All Mode	2015 - 2018	PCM (Powertrain Control Module)	Read Data Stream	
INFINITI	All Mode	2015 - 2018	PCM (Powertrain Control Module)	Module Information	
INFINITI	All Mode	2015 - 2018	PCM (Powertrain Control Module)	Actuation Test	Check fuel filter module
INFINITI	All Mode	2015 - 2018	PCM (Powertrain Control Module)	Actuation Test	Check power supply of drivetrain control unit
INFINITI	All Mode	2015 - 2018	PCM (Powertrain Control Module)	Actuation Test	Check radiator shutter actuator
INFINITI	All Mode	2015 - 2018	PCM (Powertrain Control Module)	Actuation Test	Status Of Circuit
INFINITI	All Mode	2015 - 2018	PCM (Powertrain Control Module)	Actuation Test	Causes of engine stop prevention
INFINITI	All Mode	2015 - 2018	PCM (Powertrain Control Module)	Actuation Test	Engine start request by stop/start system
INFINITI	All Mode	2015 - 2018	PCM (Powertrain Control Module)	Actuation Test	Malfunction status of stop/start system
INFINITI	All Mode	2015 - 2018	PCM (Powertrain Control Module)	Actuation Test	Malfunction status of stop/start system stored
INFINITI	All Mode	2015 - 2018	PCM (Powertrain Control Module)	Actuation Test	Requirements for stop/start system
INFINITI	All Mode	2015 - 2018	PCM (Powertrain Control Module)	Special Function	Manual transmission main shifter shaft position sensor
INFINITI	All Mode	2015 - 2018	H/L control module RH	Read Fault Code	
INFINITI	All Mode	2015 - 2018	H/L control module RH	Clear Fault Code	
INFINITI	All Mode	2015 - 2018	H/L control module RH	Read Data Stream	
INFINITI	All Mode	2015 - 2018	H/L control module RH	Module Information	
INFINITI	All Mode	2015 - 2018	H/L control module RH	Actuation Test	Check right front lamp unit fan motor 1
INFINITI	All Mode	2015 - 2018	H/L control module RH	Actuation Test	Fan
INFINITI	All Mode	2015 - 2018	H/L control module RH	Special Function	Reset operating hours counter of FR lamp fan motor 1
INFINITI	All Mode	2015 - 2018	H/L control module RH	Special Function	Reset of operating hours counter of R pos DTRL turn sig
INFINITI	All Mode	2015 - 2018	H/L control module LH	Read Fault Code	
INFINITI	All Mode	2015 - 2018	H/L control module LH	Clear Fault Code	
INFINITI	All Mode	2015 - 2018	H/L control module LH	Read Data Stream	
INFINITI	All Mode	2015 - 2018	H/L control module LH	Module Information	
INFINITI	All Mode	2015 - 2018	H/L control module LH	Actuation Test	Check left front lamp unit fan motor 1
INFINITI	All Mode	2015 - 2018	H/L control module LH	Actuation Test	Light distribution position sensor
INFINITI	All Mode	2015 - 2018	H/L control module LH	Actuation Test	Light distribution actuator motor
INFINITI	All Mode	2015 - 2018	H/L control module LH	Actuation Test	Fan
INFINITI	All Mode	2015 - 2018	H/L control module LH	Actuation Test	Intelligent light spread
INFINITI	All Mode	2015 - 2018	H/L control module LH	Special Function	Adjustment of headlamps via diagnosis
INFINITI	All Mode	2015 - 2018	H/L control module LH	Special Function	Reset operating hours counter of FL lamp fan motor 1
INFINITI	All Mode	2015 - 2018	H/L control module LH	Special Function	Reset of operating hours counter of L pos DTRL turn sig
INFINITI	All Mode	2015 - 2018	H/L control module LH	Special Function	Zero position adjustment
INFINITI	All Mode	2015 - 2018	EHS/PKB	Read Fault Code	
INFINITI	All Mode	2015 - 2018	EHS/PKB	Clear Fault Code	
INFINITI	All Mode	2015 - 2018	EHS/PKB	Read Data Stream	
INFINITI	All Mode	2015 - 2018	EHS/PKB	Module Information	
INFINITI	All Mode	2015 - 2018	EHS/PKB	Special Function	Vin Registration
INFINITI	All Mode	2015 - 2018	EHS/PKB	Special Function	Electrical contact actuator/brake clearance setting
INFINITI	All Mode	2015 - 2018	EHS/PKB	Special Function	Calibration of electric parking brake control unit
INFINITI	All Mode	2010 - 2017	Motor Control	Read Fault Code	







**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
INFINITI	All Mode	Up to 2018	ABS (Anti-lock Braking System)	Read Data Stream	
INFINITI	All Mode	Up to 2018	ABS (Anti-lock Braking System)	Read Freeze Frame	
INFINITI	All Mode	Up to 2018	ABS (Anti-lock Braking System)	Module Information	
INFINITI	All Mode	Up to 2018	ABS (Anti-lock Braking System)	Function Test	
INFINITI	All Mode	Up to 2018	ABS (Anti-lock Braking System)	Actuation Test	FR RH SOL
INFINITI	All Mode	Up to 2018	ABS (Anti-lock Braking System)	Actuation Test	FR LH SOL
INFINITI	All Mode	Up to 2018	ABS (Anti-lock Braking System)	Actuation Test	RR RH SOL
INFINITI	All Mode	Up to 2018	ABS (Anti-lock Braking System)	Actuation Test	RR LH SOL
INFINITI	All Mode	Up to 2018	ABS (Anti-lock Braking System)	Actuation Test	ABS MOTOR
INFINITI	All Mode	Up to 2018	ABS (Anti-lock Braking System)	Actuation Test	FR RH ABS SOLENOID (ACT)
INFINITI	All Mode	Up to 2018	ABS (Anti-lock Braking System)	Actuation Test	FR LH ABS SOLENOID (ACT)
INFINITI	All Mode	Up to 2018	ABS (Anti-lock Braking System)	Actuation Test	RR RH ABS SOLENOID (ACT)
INFINITI	All Mode	Up to 2018	ABS (Anti-lock Braking System)	Actuation Test	RR LH ABS SOLENOID (ACT)
INFINITI	All Mode	Up to 2018	ABS (Anti-lock Braking System)	Special Function	ST Angle Sensor Adjustment
INFINITI	All Mode	Up to 2018	ABS (Anti-lock Braking System)	Special Function	Decel G Sen Calibration
INFINITI	All Mode	Up to 2018	ABS (Anti-lock Braking System)	Special Function	STROKE SENSOR CALIBRATION
INFINITI	All Mode	Up to 2017	ABS (Anti-lock Braking System)	Read Fault Code	
INFINITI	All Mode	Up to 2017	ABS (Anti-lock Braking System)	Clear Fault Code	
INFINITI	All Mode	Up to 2017	ABS (Anti-lock Braking System)	Read Data Stream	
INFINITI	All Mode	Up to 2017	ABS (Anti-lock Braking System)	Read Freeze Frame	
INFINITI	All Mode	Up to 2017	ABS (Anti-lock Braking System)	Module Information	
INFINITI	All Mode	Up to 2017	ABS (Anti-lock Braking System)	Function Test	
INFINITI	All Mode	Up to 2017	ABS (Anti-lock Braking System)	Actuation Test	FR RH SOL
INFINITI	All Mode	Up to 2017	ABS (Anti-lock Braking System)	Actuation Test	FR LH SOL
INFINITI	All Mode	Up to 2017	ABS (Anti-lock Braking System)	Actuation Test	RR RH SOL
INFINITI	All Mode	Up to 2017	ABS (Anti-lock Braking System)	Actuation Test	RR LH SOL
INFINITI	All Mode	Up to 2017	ABS (Anti-lock Braking System)	Actuation Test	ABS MOTOR
INFINITI	All Mode	Up to 2017	ABS (Anti-lock Braking System)	Actuation Test	FR RH ABS SOLENOID (ACT)
INFINITI	All Mode	Up to 2017	ABS (Anti-lock Braking System)	Actuation Test	FR LH ABS SOLENOID (ACT)
INFINITI	All Mode	Up to 2017	ABS (Anti-lock Braking System)	Actuation Test	RR RH ABS SOLENOID (ACT)
INFINITI	All Mode	Up to 2017	ABS (Anti-lock Braking System)	Actuation Test	RR LH ABS SOLENOID (ACT)
INFINITI	All Mode	Up to 2017	ABS (Anti-lock Braking System)	Actuation Test	STOP LAMP ON RELAY
INFINITI	All Mode	Up to 2017	ABS (Anti-lock Braking System)	Special Function	ST Angle Sensor Adjustment
INFINITI	All Mode	Up to 2017	ABS (Anti-lock Braking System)	Special Function	Decel G Sen Calibration
INFINITI	All Mode	2013 - 2018	ABS (Anti-lock Braking System)	Read Fault Code	
INFINITI	All Mode	2013 - 2018	ABS (Anti-lock Braking System)	Clear Fault Code	
INFINITI	All Mode	2013 - 2018	ABS (Anti-lock Braking System)	Read Data Stream	
INFINITI	All Mode	2013 - 2018	ABS (Anti-lock Braking System)	Module Information	
INFINITI	All Mode	2013 - 2018	ABS (Anti-lock Braking System)	Actuation Test	FR RH SOL
INFINITI	All Mode	2013 - 2018	ABS (Anti-lock Braking System)	Actuation Test	FR LH SOL
INFINITI	All Mode	2013 - 2018	ABS (Anti-lock Braking System)	Actuation Test	RR RH SOL
INFINITI	All Mode	2013 - 2018	ABS (Anti-lock Braking System)	Actuation Test	RR LH SOL
INFINITI	All Mode	2013 - 2018	ABS (Anti-lock Braking System)	Actuation Test	ABS MOTOR
INFINITI	All Mode	2013 - 2018	ABS (Anti-lock Braking System)	Actuation Test	FR RH ABS SOLENOID (ACT)
INFINITI	All Mode	2013 - 2018	ABS (Anti-lock Braking System)	Actuation Test	FR LH ABS SOLENOID (ACT)
INFINITI	All Mode	2013 - 2018	ABS (Anti-lock Braking System)	Actuation Test	RR RH ABS SOLENOID (ACT)
INFINITI	All Mode	2013 - 2018	ABS (Anti-lock Braking System)	Actuation Test	RR LH ABS SOLENOID (ACT)
INFINITI	All Mode	2013 - 2018	ABS (Anti-lock Braking System)	Actuation Test	STOP LAMP ON RELAY
INFINITI	All Mode	2013 - 2018	ABS (Anti-lock Braking System)	Special Function	ST Angle Sensor Adjustment
INFINITI	All Mode	2013 - 2018	ABS (Anti-lock Braking System)	Special Function	Decel G Sen Calibration
INFINITI	All Mode	2013 - 2018	ABS (Anti-lock Braking System)	Special Function	STROKE SENSOR CALIBRATION
INFINITI	All Mode	2015 - 2018	ABS (Anti-lock Braking System)	Read Fault Code	
INFINITI	All Mode	2015 - 2018	ABS (Anti-lock Braking System)	Clear Fault Code	
INFINITI	All Mode	2015 - 2018	ABS (Anti-lock Braking System)	Read Data Stream	
INFINITI	All Mode	2015 - 2018	ABS (Anti-lock Braking System)	Module Information	
INFINITI	All Mode	2015 - 2018	ABS (Anti-lock Braking System)	Actuation Test	Check power supply of solenoid valves
INFINITI	All Mode	2015 - 2018	ABS (Anti-lock Braking System)	Actuation Test	Defragment memory
INFINITI	All Mode	2015 - 2018	ABS (Anti-lock Braking System)	Actuation Test	Check power supply of high press and return flow pump
INFINITI	All Mode	2015 - 2018	ABS (Anti-lock Braking System)	Actuation Test	Rear left pressure regulating valve pressure release
INFINITI	All Mode	2015 - 2018	ABS (Anti-lock Braking System)	Special Function	Vin Registration
INFINITI	All Mode	2015 - 2018	ABS (Anti-lock Braking System)	Special Function	Calibration of acceleration sensor
INFINITI	All Mode	Up to 2017	ABS (Anti-lock Braking System)	Read Fault Code	
INFINITI	All Mode	Up to 2017	ABS (Anti-lock Braking System)	Clear Fault Code	
INFINITI	All Mode	Up to 2017	ABS (Anti-lock Braking System)	Read Data Stream	
INFINITI	All Mode	Up to 2017	ABS (Anti-lock Braking System)	Module Information	
INFINITI	All Mode	Up to 2017	ABS (Anti-lock Braking System)	Special Function	
INFINITI	All Mode	Up to 2008	ABS (Anti-lock Braking System)	Read Fault Code	
INFINITI	All Mode	Up to 2008	ABS (Anti-lock Braking System)	Clear Fault Code	
INFINITI	All Mode	Up to 2008	ABS (Anti-lock Braking System)	Read Data Stream	
INFINITI	All Mode	Up to 2008	ABS (Anti-lock Braking System)	Module Information	
INFINITI	All Mode	Up to 2008	ABS (Anti-lock Braking System)	Special Function	ST ANG SEN ADJUSTMENT
INFINITI	All Mode	Up to 2008	ABS (Anti-lock Braking System)	Special Function	AIR BLEEDING
INFINITI	All Mode	Up to 2008	ABS (Anti-lock Braking System)	Special Function	
INFINITI	All Mode	Up to 2008	ABS (Anti-lock Braking System)	Read Fault Code	
INFINITI	All Mode	Up to 2008	ABS (Anti-lock Braking System)	Clear Fault Code	

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
INFINITI	All Mode	Up to 2008	ABS (Anti-lock Braking System)	Read Data Stream	
INFINITI	All Mode	Up to 2008	ABS (Anti-lock Braking System)	Module Information	
INFINITI	All Mode	Up to 2008	ABS (Anti-lock Braking System)	Actuation Test	
INFINITI	All Mode	Up to 2008	ABS (Anti-lock Braking System)	Read Fault Code	
INFINITI	All Mode	Up to 2008	ABS (Anti-lock Braking System)	Clear Fault Code	
INFINITI	All Mode	Up to 2008	ABS (Anti-lock Braking System)	Read Data Stream	
INFINITI	All Mode	Up to 2008	ABS (Anti-lock Braking System)	Module Information	
INFINITI	All Mode	Up to 2008	ABS (Anti-lock Braking System)	Actuation Test	
INFINITI	All Mode	Up to 2008	ABS (Anti-lock Braking System)	Read Fault Code	
INFINITI	All Mode	Up to 2008	ABS (Anti-lock Braking System)	Clear Fault Code	
INFINITI	All Mode	Up to 2008	ABS (Anti-lock Braking System)	Read Data Stream	
INFINITI	All Mode	Up to 2008	ABS (Anti-lock Braking System)	Module Information	
INFINITI	All Mode	Up to 2008	ABS (Anti-lock Braking System)	Special Function	ETS AIR BLEEDING
INFINITI	All Mode	Up to 2008	ABS (Anti-lock Braking System)	Special Function	LSD AIR BLEEDING
INFINITI	All Mode	Up to 2008	ABS (Anti-lock Braking System)	Special Function	ETS OIL PRESS CHECK
INFINITI	All Mode	Up to 2008	ABS (Anti-lock Braking System)	Special Function	ETS OIL PRESS CHECK
INFINITI	All Mode	Up to 2008	ABS (Anti-lock Braking System)	Special Function	LSD OIL PRESS CHECK
INFINITI	All Mode	Up to 2008	ABS (Anti-lock Braking System)	Special Function	LSD OIL PRESS CHECK
INFINITI	All Mode	Up to 2008	ABS (Anti-lock Braking System)	Special Function	ETS LOCK CHECK
INFINITI	All Mode	Up to 2008	ABS (Anti-lock Braking System)	Special Function	LSD LOCK CHECK
INFINITI	All Mode	Up to 2008	ABS (Anti-lock Braking System)	Special Function	ETS/LSD LOCK CHECK
INFINITI	All Mode	Up to 2008	ABS (Anti-lock Braking System)	Special Function	ETS/LSD AIR BLEEDING
INFINITI	All Mode	Up to 2012	IPDM E/R	Read Fault Code	
INFINITI	All Mode	Up to 2012	IPDM E/R	Clear Fault Code	
INFINITI	All Mode	Up to 2012	IPDM E/R	Read Data Stream	
INFINITI	All Mode	Up to 2012	IPDM E/R	Actuation Test	Head Lamp
INFINITI	All Mode	Up to 2012	IPDM E/R	Actuation Test	Front Fog Lamp
INFINITI	All Mode	Up to 2012	IPDM E/R	Actuation Test	Tail Lamp
INFINITI	All Mode	Up to 2012	IPDM E/R	Actuation Test	Rear Defogger
INFINITI	All Mode	Up to 2012	IPDM E/R	Actuation Test	Front Wiper
INFINITI	All Mode	Up to 2012	IPDM E/R	Actuation Test	Motor Fan
INFINITI	All Mode	Up to 2012	IPDM E/R	Actuation Test	Head Lamp Washer
INFINITI	All Mode	Up to 2012	IPDM E/R	Actuation Test	Lamps
INFINITI	All Mode	Up to 2012	IPDM E/R	Actuation Test	External Lamps
INFINITI	All Mode	Up to 2012	IPDM E/R	Actuation Test	Cornering Lamp
INFINITI	All Mode	Up to 2012	IPDM E/R	Actuation Test	Horn
INFINITI	All Mode	2005 - 2010	IPDM E/R	Read Fault Code	
INFINITI	All Mode	2005 - 2010	IPDM E/R	Clear Fault Code	
INFINITI	All Mode	2005 - 2010	IPDM E/R	Read Data Stream	
INFINITI	All Mode	2005 - 2010	IPDM E/R	Actuation Test	Head Lamp
INFINITI	All Mode	2005 - 2010	IPDM E/R	Actuation Test	Front Fog Lamp
INFINITI	All Mode	2005 - 2010	IPDM E/R	Actuation Test	Tail Lamp
INFINITI	All Mode	2005 - 2010	IPDM E/R	Actuation Test	Rear Defogger
INFINITI	All Mode	2005 - 2010	IPDM E/R	Actuation Test	Front Wiper
INFINITI	All Mode	2005 - 2010	IPDM E/R	Actuation Test	Motor Fan
INFINITI	All Mode	2005 - 2010	IPDM E/R	Actuation Test	Head Lamp Washer
INFINITI	All Mode	2005 - 2010	IPDM E/R	Actuation Test	Lamps
INFINITI	All Mode	2005 - 2010	IPDM E/R	Actuation Test	External Lamps
INFINITI	All Mode	2005 - 2010	IPDM E/R	Actuation Test	Cornering Lamp
INFINITI	All Mode	2005 - 2010	IPDM E/R	Actuation Test	Horn
INFINITI	All Mode	Up to 2018	IPDM E/R	Read Fault Code	
INFINITI	All Mode	Up to 2018	IPDM E/R	Clear Fault Code	
INFINITI	All Mode	Up to 2018	IPDM E/R	Read Data Stream	
INFINITI	All Mode	Up to 2018	IPDM E/R	Read Freeze Frame	
INFINITI	All Mode	Up to 2018	IPDM E/R	Module Information	
INFINITI	All Mode	Up to 2018	IPDM E/R	Actuation Test	Cornering Lamp
INFINITI	All Mode	Up to 2018	IPDM E/R	Actuation Test	Tail Lamp
INFINITI	All Mode	Up to 2018	IPDM E/R	Actuation Test	Horn
INFINITI	All Mode	Up to 2018	IPDM E/R	Actuation Test	Rear Defogger
INFINITI	All Mode	Up to 2018	IPDM E/R	Actuation Test	Front Wiper
INFINITI	All Mode	Up to 2018	IPDM E/R	Actuation Test	Motor Fan
INFINITI	All Mode	Up to 2018	IPDM E/R	Actuation Test	Head Lamp Washer
INFINITI	All Mode	Up to 2018	IPDM E/R	Actuation Test	Lamps
INFINITI	All Mode	Up to 2018	IPDM E/R	Actuation Test	External Lamps
INFINITI	All Mode	Up to 2008	IPDM E/R	Read Fault Code	
INFINITI	All Mode	Up to 2008	IPDM E/R	Clear Fault Code	
INFINITI	All Mode	Up to 2008	IPDM E/R	Read Data Stream	
INFINITI	All Mode	Up to 2008	IPDM E/R	Module Information	
INFINITI	All Mode	Up to 2008	IPDM E/R	Actuation Test	Head Lamp
INFINITI	All Mode	Up to 2008	IPDM E/R	Actuation Test	Front Fog Lamp
INFINITI	All Mode	Up to 2008	IPDM E/R	Actuation Test	Tail Lamp
INFINITI	All Mode	Up to 2008	IPDM E/R	Actuation Test	Rear Defogger
INFINITI	All Mode	Up to 2008	IPDM E/R	Actuation Test	Front Wiper
INFINITI	All Mode	Up to 2008	IPDM E/R	Actuation Test	Motor Fan
INFINITI	All Mode	Up to 2008	IPDM E/R	Actuation Test	Head Lamp Washer
INFINITI	All Mode	Up to 2008	IPDM E/R	Actuation Test	Lamps
INFINITI	All Mode	Up to 2008	IPDM E/R	Actuation Test	External Lamps
INFINITI	All Mode	Up to 2008	IPDM E/R	Actuation Test	Cornering Lamp
INFINITI	All Mode	Up to 2008	IPDM E/R	Actuation Test	Horn
INFINITI	All Mode	Up to 2017	Air Pressure Monitor	Read Fault Code	

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
INFINITI	All Mode	Up to 2017	Air Pressure Monitor	Clear Fault Code	
INFINITI	All Mode	Up to 2017	Air Pressure Monitor	Read Data Stream	
INFINITI	All Mode	Up to 2017	Air Pressure Monitor	Module Information	
INFINITI	All Mode	Up to 2017	Air Pressure Monitor	Actuation Test	BUZZER
INFINITI	All Mode	Up to 2017	Air Pressure Monitor	Actuation Test	Warn Lamp
INFINITI	All Mode	Up to 2017	Air Pressure Monitor	Actuation Test	Hazard Lamp
INFINITI	All Mode	Up to 2017	Air Pressure Monitor	Special Function	ID READ(TIRE SET 1)
INFINITI	All Mode	Up to 2017	Air Pressure Monitor	Special Function	ID READ(TIRE SET 2)
INFINITI	All Mode	Up to 2017	Air Pressure Monitor	Special Function	ID REGIST(TIRE SET 1)
INFINITI	All Mode	Up to 2017	Air Pressure Monitor	Special Function	ID REGIST(TIRE SET 2)
INFINITI	All Mode	Up to 2017	Air Pressure Monitor	Special Function	Switch Tpsms Between On/Off
INFINITI	All Mode	Up to 2017	Air Pressure Monitor	Special Function	ID REGIST
INFINITI	All Mode	Up to 2015	Air Pressure Monitor	Read Fault Code	
INFINITI	All Mode	Up to 2015	Air Pressure Monitor	Clear Fault Code	
INFINITI	All Mode	Up to 2015	Air Pressure Monitor	Read Data Stream	
INFINITI	All Mode	Up to 2015	Air Pressure Monitor	Module Information	
INFINITI	All Mode	Up to 2015	Air Pressure Monitor	Special Function	ID REGIST
INFINITI	All Mode	Up to 2018	Air Pressure Monitor	Read Fault Code	
INFINITI	All Mode	Up to 2018	Air Pressure Monitor	Clear Fault Code	
INFINITI	All Mode	Up to 2018	Air Pressure Monitor	Read Data Stream	
INFINITI	All Mode	Up to 2018	Air Pressure Monitor	Module Information	
INFINITI	All Mode	Up to 2018	Air Pressure Monitor	Actuation Test	ID REGIST WARNING
INFINITI	All Mode	Up to 2018	Air Pressure Monitor	Actuation Test	RUN FLAT/T WARN BUZZER
INFINITI	All Mode	Up to 2018	Air Pressure Monitor	Actuation Test	Warning Lamp
INFINITI	All Mode	Up to 2018	Air Pressure Monitor	Actuation Test	Flasher
INFINITI	All Mode	Up to 2018	Air Pressure Monitor	Actuation Test	Horn
INFINITI	All Mode	Up to 2018	Air Pressure Monitor	Actuation Test	Outside Buzzer
INFINITI	All Mode	Up to 2018	Air Pressure Monitor	Special Function	ID READ
INFINITI	All Mode	Up to 2018	Air Pressure Monitor	Special Function	ID REGIST
INFINITI	All Mode	Up to 2018	Air Pressure Monitor	Special Function	Switch Tpsms Between On/Off
INFINITI	INFINITI QX80	2014	Air Pressure Monitor	Read Fault Code	
INFINITI	INFINITI QX80	2014	Air Pressure Monitor	Clear Fault Code	
INFINITI	INFINITI QX80	2014	Air Pressure Monitor	Read Data Stream	
INFINITI	INFINITI QX80	2014	Air Pressure Monitor	Module Information	
INFINITI	INFINITI QX80	2014	Air Pressure Monitor	Special Function	Vin Registration
INFINITI	All Mode	2014 - 2015	Air Pressure Monitor	Read Fault Code	
INFINITI	All Mode	2014 - 2015	Air Pressure Monitor	Clear Fault Code	
INFINITI	All Mode	2014 - 2015	Air Pressure Monitor	Read Data Stream	
INFINITI	All Mode	2014 - 2015	Air Pressure Monitor	Module Information	
INFINITI	All Mode	2014 - 2015	Air Pressure Monitor	Actuation Test	ID REGIST WARNING
INFINITI	All Mode	2014 - 2015	Air Pressure Monitor	Actuation Test	Warning Lamp
INFINITI	All Mode	2014 - 2015	Air Pressure Monitor	Actuation Test	RUN FLAT/T WARN BUZZER
INFINITI	All Mode	2014 - 2015	Air Pressure Monitor	Actuation Test	Flasher
INFINITI	All Mode	2014 - 2015	Air Pressure Monitor	Actuation Test	Horn
INFINITI	All Mode	2014 - 2015	Air Pressure Monitor	Special Function	ID REGIST
INFINITI	All Mode	2014 - 2015	Air Pressure Monitor	Special Function	Switch Tpsms Between On/Off
INFINITI	All Mode	2015 - 2018	Air Pressure Monitor	Read Fault Code	
INFINITI	All Mode	2015 - 2018	Air Pressure Monitor	Clear Fault Code	
INFINITI	All Mode	2015 - 2018	Air Pressure Monitor	Read Data Stream	
INFINITI	All Mode	2015 - 2018	Air Pressure Monitor	Module Information	
INFINITI	All Mode	2015 - 2018	Air Pressure Monitor	Actuation Test	Check left front tire pressure sensor
INFINITI	All Mode	2015 - 2018	Air Pressure Monitor	Actuation Test	Check right front tire pressure sensor
INFINITI	All Mode	2015 - 2018	Air Pressure Monitor	Actuation Test	Check left rear tire pressure sensor
INFINITI	All Mode	2015 - 2018	Air Pressure Monitor	Actuation Test	Check right rear tire pressure sensor
INFINITI	All Mode	2015 - 2018	Air Pressure Monitor	Actuation Test	Activation memory
INFINITI	All Mode	2015 - 2018	Air Pressure Monitor	Actuation Test	Message memory
INFINITI	All Mode	2015 - 2018	Air Pressure Monitor	Special Function	Set autolocation disable
INFINITI	All Mode	2015 - 2018	Air Pressure Monitor	Special Function	Front or rear sensor localization was unsuccessful
INFINITI	All Mode	2015 - 2018	Air Pressure Monitor	Special Function	Saving Data For Replc CPU
INFINITI	All Mode	2015 - 2018	Air Pressure Monitor	Special Function	Writing Data For Replc CPU
INFINITI	All Mode	Up to 2008	Air Pressure Monitor	Read Fault Code	
INFINITI	All Mode	Up to 2008	Air Pressure Monitor	Clear Fault Code	
INFINITI	All Mode	Up to 2008	Air Pressure Monitor	Read Data Stream	
INFINITI	All Mode	Up to 2008	Air Pressure Monitor	Module Information	
INFINITI	All Mode	Up to 2008	Air Pressure Monitor	Special Function	ID REGIST (SUMMER)
INFINITI	All Mode	Up to 2008	Air Pressure Monitor	Special Function	ID REGIST (WINTER)
INFINITI	All Mode	Up to 2008	Air Pressure Monitor	Special Function	Type Set Selection
INFINITI	All Mode	Up to 2008	Air Pressure Monitor	Special Function	Tpsms Cancellation
INFINITI	All Mode	Up to 2008	Air Pressure Monitor	Special Function	RECOMMEND PRESS SETTING
INFINITI	All Mode	Up to 2008	Air Pressure Monitor	Read Fault Code	
INFINITI	All Mode	Up to 2008	Air Pressure Monitor	Clear Fault Code	
INFINITI	All Mode	Up to 2008	Air Pressure Monitor	Read Data Stream	
INFINITI	All Mode	Up to 2008	Air Pressure Monitor	Module Information	
INFINITI	All Mode	Up to 2008	Air Pressure Monitor	Special Function	

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
INFINITI	All Mode	2009 - 2015	Convertible Roof	Read Fault Code	
INFINITI	All Mode	2009 - 2015	Convertible Roof	Clear Fault Code	
INFINITI	All Mode	2009 - 2015	Convertible Roof	Read Data Stream	
INFINITI	All Mode	2009 - 2015	Convertible Roof	Module Information	
INFINITI	All Mode	2009 - 2015	Convertible Roof	Actuation Test	ROOF SYSTEM
INFINITI	All Mode	2009 - 2015	Convertible Roof	Actuation Test	ROOF STATE OUTPUT(AUDIO)
INFINITI	All Mode	2009 - 2015	Convertible Roof	Actuation Test	FRONT POWER WINDOW(LH)/RH)
INFINITI	All Mode	2009 - 2015	Convertible Roof	Actuation Test	REAR POWER WINDOW(LH)
INFINITI	All Mode	2009 - 2015	Convertible Roof	Actuation Test	REAR POWER WINDOW(RH)
INFINITI	All Mode	2009 - 2015	Convertible Roof	Special Function	Trunk Opener
INFINITI	All Mode	2009 - 2015	Convertible Roof	Special Function	FLIPPER DOOR
INFINITI	All Mode	2009 - 2015	Convertible Roof	Special Function	ROOF LATCH
INFINITI	All Mode	2009 - 2015	Convertible Roof	Special Function	Roof State Reset
INFINITI	All Mode	2009 - 2015	Convertible Roof	Special Function	Roof State Learning
INFINITI	All Mode	Up to 2008	Head Lamp Levelizer	Read Fault Code	
INFINITI	All Mode	Up to 2008	Head Lamp Levelizer	Clear Fault Code	
INFINITI	All Mode	Up to 2008	Head Lamp Levelizer	Read Data Stream	
INFINITI	All Mode	Up to 2008	Head Lamp Levelizer	Module Information	
INFINITI	All Mode	Up to 2008	Head Lamp Levelizer	Special Function	
INFINITI	All Mode	Up to 2017	Head Lamp Levelizer	Read Fault Code	
INFINITI	All Mode	Up to 2017	Head Lamp Levelizer	Clear Fault Code	
INFINITI	All Mode	Up to 2017	Head Lamp Levelizer	Read Data Stream	
INFINITI	All Mode	Up to 2017	Head Lamp Levelizer	Module Information	
INFINITI	All Mode	Up to 2017	Head Lamp Levelizer	Special Function	
INFINITI	All Mode	Up to 2016	IC (Instrument cluster)	Read Fault Code	
INFINITI	All Mode	Up to 2016	IC (Instrument cluster)	Clear Fault Code	
INFINITI	All Mode	Up to 2016	IC (Instrument cluster)	Read Data Stream	
INFINITI	All Mode	Up to 2016	IC (Instrument cluster)	Special Function	TURN SIGNAL BUZZER DIAGNOSIS
INFINITI	All Mode	Up to 2016	IC (Instrument cluster)	Special Function	Fuel Meter Diagnosis(Analog Pointer)
INFINITI	All Mode	Up to 2010	IC (Instrument cluster)	Read Fault Code	
INFINITI	All Mode	Up to 2010	IC (Instrument cluster)	Clear Fault Code	
INFINITI	All Mode	Up to 2010	IC (Instrument cluster)	Read Data Stream	
INFINITI	All Mode	Up to 2010	IC (Instrument cluster)	Special Function	TURN SIGNAL BUZZER DIAGNOSIS
INFINITI	All Mode	Up to 2010	IC (Instrument cluster)	Special Function	Fuel Meter Diagnosis(Analog Pointer)
INFINITI	All Mode	2006 - 2017	IC (Instrument cluster)	Read Fault Code	
INFINITI	All Mode	2006 - 2017	IC (Instrument cluster)	Clear Fault Code	
INFINITI	All Mode	2006 - 2017	IC (Instrument cluster)	Read Data Stream	
INFINITI	All Mode	2006 - 2017	IC (Instrument cluster)	Read Freeze Frame	
INFINITI	All Mode	2006 - 2017	IC (Instrument cluster)	Module Information	
INFINITI	All Mode	2006 - 2017	IC (Instrument cluster)	Special Function	TURN SIGNAL BUZZER DIAGNOSIS
INFINITI	All Mode	2006 - 2017	IC (Instrument cluster)	Special Function	Outside Air Temperature Diagnosis
INFINITI	All Mode	2006 - 2017	IC (Instrument cluster)	Special Function	Fuel Meter Diagnosis(Analog Pointer)
INFINITI	All Mode	2010 - 2017	IC (Instrument cluster)	Read Fault Code	
INFINITI	All Mode	2010 - 2017	IC (Instrument cluster)	Clear Fault Code	
INFINITI	All Mode	2010 - 2017	IC (Instrument cluster)	Read Data Stream	
INFINITI	All Mode	2010 - 2017	IC (Instrument cluster)	Read Freeze Frame	
INFINITI	All Mode	2010 - 2017	IC (Instrument cluster)	Special Function	Outside Air Temperature Diagnosis
INFINITI	All Mode	2010 - 2017	IC (Instrument cluster)	Special Function	Fuel Meter Diagnosis(Analog Pointer)
INFINITI	All Mode	2010 - 2017	IC (Instrument cluster)	Special Function	Warning Lamp Diagnosis
INFINITI	All Mode	2010 - 2017	IC (Instrument cluster)	Read Fault Code	
INFINITI	All Mode	2010 - 2017	IC (Instrument cluster)	Clear Fault Code	
INFINITI	All Mode	2010 - 2017	IC (Instrument cluster)	Read Data Stream	
INFINITI	All Mode	2010 - 2017	IC (Instrument cluster)	Read Freeze Frame	
INFINITI	All Mode	2010 - 2017	IC (Instrument cluster)	Special Function	TURN SIGNAL BUZZER DIAGNOSIS
INFINITI	All Mode	2010 - 2017	IC (Instrument cluster)	Special Function	Outside Air Temperature Diagnosis
INFINITI	All Mode	2010 - 2017	IC (Instrument cluster)	Special Function	Fuel Meter Diagnosis(Analog Pointer)
INFINITI	All Mode	2007 - 2017	IC (Instrument cluster)	Read Fault Code	
INFINITI	All Mode	2007 - 2017	IC (Instrument cluster)	Clear Fault Code	
INFINITI	All Mode	2007 - 2017	IC (Instrument cluster)	Read Data Stream	
INFINITI	All Mode	2007 - 2017	IC (Instrument cluster)	Read Freeze Frame	
INFINITI	All Mode	2007 - 2017	IC (Instrument cluster)	Module Information	
INFINITI	All Mode	2007 - 2017	IC (Instrument cluster)	Special Function	TURN SIGNAL BUZZER DIAGNOSIS
INFINITI	All Mode	2007 - 2017	IC (Instrument cluster)	Special Function	Outside Air Temperature Diagnosis
INFINITI	All Mode	2007 - 2017	IC (Instrument cluster)	Special Function	Fuel Meter Diagnosis(Analog Pointer)
INFINITI	All Mode	2013 - 2018	IC (Instrument cluster)	Read Fault Code	

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
INFINITI	All Mode	2013 - 2018	IC (Instrument cluster)	Clear Fault Code	
INFINITI	All Mode	2013 - 2018	IC (Instrument cluster)	Read Data Stream	
INFINITI	All Mode	2013 - 2018	IC (Instrument cluster)	Module Information	
INFINITI	All Mode	2013 - 2018	IC (Instrument cluster)	Special Function	TURN SIGNAL BUZZER DIAGNOSIS
INFINITI	All Mode	2013 - 2018	IC (Instrument cluster)	Special Function	Outside Air Temperature Diagnosis
INFINITI	All Mode	2013 - 2018	IC (Instrument cluster)	Special Function	Fuel Meter Diagnosis(Analog Pointer)
INFINITI	All Mode	2015 - 2018	IC (Instrument cluster)	Read Fault Code	
INFINITI	All Mode	2015 - 2018	IC (Instrument cluster)	Clear Fault Code	
INFINITI	All Mode	2015 - 2018	IC (Instrument cluster)	Read Data Stream	
INFINITI	All Mode	2015 - 2018	IC (Instrument cluster)	Module Information	
INFINITI	All Mode	2015 - 2018	IC (Instrument cluster)	Actuation Test	Instrument illumination
INFINITI	All Mode	2015 - 2018	IC (Instrument cluster)	Actuation Test	Warning buzzer
INFINITI	All Mode	2015 - 2018	IC (Instrument cluster)	Actuation Test	Indicator Lamp
INFINITI	All Mode	2015 - 2018	IC (Instrument cluster)	Actuation Test	Mechanical instrument pointers
INFINITI	All Mode	2015 - 2018	IC (Instrument cluster)	Actuation Test	Control unit reset
INFINITI	All Mode	2015 - 2018	IC (Instrument cluster)	Special Function	Teach In Combination Meter
INFINITI	All Mode	2015 - 2018	IC (Instrument cluster)	Special Function	Table Initialization Assyst
INFINITI	All Mode	2015 - 2018	IC (Instrument cluster)	Special Function	Transfer Of Manufacturer Default Settings
INFINITI	All Mode	2015 - 2018	IC (Instrument cluster)	Special Function	Oil grade factor
INFINITI	All Mode	2010 - 2017	Laser/Radar	Read Fault Code	
INFINITI	All Mode	2010 - 2017	Laser/Radar	Clear Fault Code	
INFINITI	All Mode	2010 - 2017	Laser/Radar	Read Data Stream	
INFINITI	All Mode	2010 - 2017	Laser/Radar	Module Information	
INFINITI	All Mode	2010 - 2017	Laser/Radar	Special Function	Laser Beam Adjust
INFINITI	All Mode	2011 - 2017	Laser/Radar	Read Fault Code	
INFINITI	All Mode	2011 - 2017	Laser/Radar	Clear Fault Code	
INFINITI	All Mode	2011 - 2017	Laser/Radar	Read Data Stream	
INFINITI	All Mode	2011 - 2017	Laser/Radar	Module Information	
INFINITI	All Mode	2013 - 2018	Laser/Radar	Read Fault Code	
INFINITI	All Mode	2013 - 2018	Laser/Radar	Clear Fault Code	
INFINITI	All Mode	2013 - 2018	Laser/Radar	Read Data Stream	
INFINITI	All Mode	2013 - 2018	Laser/Radar	Module Information	
INFINITI	All Mode	2013 - 2018	Laser/Radar	Special Function	Milliwave Radar Adjust
INFINITI	All Mode	2013 - 2017	Laser/Radar	Read Fault Code	
INFINITI	All Mode	2013 - 2017	Laser/Radar	Clear Fault Code	
INFINITI	All Mode	2013 - 2017	Laser/Radar	Read Data Stream	
INFINITI	All Mode	2013 - 2017	Laser/Radar	Module Information	
INFINITI	All Mode	2013 - 2017	Laser/Radar	Actuation Test	Brake Actuator
INFINITI	All Mode	2013 - 2017	Laser/Radar	Actuation Test	ICC BUZZER
INFINITI	All Mode	2013 - 2017	Laser/Radar	Actuation Test	Meter Lamp
INFINITI	All Mode	2013 - 2017	Laser/Radar	Special Function	FEB Default Setting
INFINITI	All Mode	2016 - 2017	Laser/Radar	Read Fault Code	
INFINITI	All Mode	2016 - 2017	Laser/Radar	Clear Fault Code	
INFINITI	All Mode	2016 - 2017	Laser/Radar	Read Data Stream	
INFINITI	All Mode	2016 - 2017	Laser/Radar	Module Information	
INFINITI	All Mode	Up to 2010	Intelligent Key	Read Fault Code	
INFINITI	All Mode	Up to 2010	Intelligent Key	Clear Fault Code	
INFINITI	All Mode	Up to 2010	Intelligent Key	Read Data Stream	
INFINITI	All Mode	Up to 2010	Intelligent Key	Module Information	
INFINITI	All Mode	Up to 2010	Intelligent Key	Actuation Test	Outside Buzzer
INFINITI	All Mode	Up to 2010	Intelligent Key	Actuation Test	Inside Buzzer
INFINITI	All Mode	Up to 2010	Intelligent Key	Actuation Test	Indicator
INFINITI	All Mode	Up to 2010	Intelligent Key	Actuation Test	Door Lock/Unlock
INFINITI	All Mode	Up to 2010	Intelligent Key	Actuation Test	ANTENNA
INFINITI	All Mode	Up to 2010	Intelligent Key	Special Function	Confirm Key Fob ID
INFINITI	All Mode	Up to 2010	Intelligent Key	Special Function	Take Out From Window Warn
INFINITI	All Mode	Up to 2010	Intelligent Key	Special Function	Low Batt Of Key Fob Warn
INFINITI	All Mode	Up to 2010	Intelligent Key	Special Function	Keyless Function
INFINITI	All Mode	Up to 2010	Intelligent Key	Special Function	Answer Back Function
INFINITI	All Mode	Up to 2010	Intelligent Key	Special Function	Selective Unlock Function
INFINITI	All Mode	Up to 2010	Intelligent Key	Special Function	Hazard Answer Back
INFINITI	All Mode	Up to 2010	Intelligent Key	Special Function	Answer Back With I-Key Lock
INFINITI	All Mode	Up to 2010	Intelligent Key	Special Function	Answer Back With I-Key Unlock
INFINITI	All Mode	Up to 2010	Intelligent Key	Special Function	Trunk Open Delay
INFINITI	All Mode	Up to 2010	Intelligent Key	Special Function	Auto Relock Timer
INFINITI	All Mode	Up to 2010	Intelligent Key	Special Function	Trunk/Glass Hatch Open
INFINITI	All Mode	Up to 2010	Intelligent Key	Special Function	Power Slide Door Delay
INFINITI	All Mode	Up to 2010	Intelligent Key	Special Function	Engine Start By I-Key
INFINITI	All Mode	Up to 2010	Intelligent Key	Special Function	Lock/Unlock By I-Key
INFINITI	All Mode	Up to 2010	Intelligent Key	Read Fault Code	
INFINITI	All Mode	Up to 2010	Intelligent Key	Clear Fault Code	
INFINITI	All Mode	Up to 2010	Intelligent Key	Read Data Stream	
INFINITI	All Mode	Up to 2010	Intelligent Key	Module Information	
INFINITI	All Mode	Up to 2010	Intelligent Key	Actuation Test	Door Lock/Unlock

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
INFINITI	All Mode	Up to 2010	Intelligent Key	Actuation Test	ANTENNA
INFINITI	All Mode	Up to 2010	Intelligent Key	Actuation Test	Outside Buzzer
INFINITI	All Mode	Up to 2010	Intelligent Key	Actuation Test	Inside Buzzer
INFINITI	All Mode	Up to 2010	Intelligent Key	Actuation Test	Indicator
INFINITI	All Mode	Up to 2010	Intelligent Key	Actuation Test	LCD
INFINITI	All Mode	Up to 2010	Intelligent Key	Actuation Test	P Range
INFINITI	All Mode	Up to 2010	Intelligent Key	Actuation Test	Engine SW Illumi
INFINITI	All Mode	Up to 2010	Intelligent Key	Actuation Test	Lock Indicator
INFINITI	All Mode	Up to 2010	Intelligent Key	Actuation Test	ACC Indicator
INFINITI	All Mode	Up to 2010	Intelligent Key	Actuation Test	Ignition ON IND
INFINITI	All Mode	Up to 2010	Intelligent Key	Actuation Test	Key Slot Illumi
INFINITI	All Mode	Up to 2010	Intelligent Key	Special Function	Confirm Key Fob ID
INFINITI	All Mode	Up to 2010	Intelligent Key	Special Function	Take Out From Window Warn
INFINITI	All Mode	Up to 2010	Intelligent Key	Special Function	Low Batt Of Key Fob Warn
INFINITI	All Mode	Up to 2010	Intelligent Key	Special Function	I-Key Function
INFINITI	All Mode	Up to 2010	Intelligent Key	Special Function	Answer Back Function
INFINITI	All Mode	Up to 2010	Intelligent Key	Special Function	Keyless Function
INFINITI	All Mode	Up to 2010	Intelligent Key	Special Function	Selective Unlock Function
INFINITI	All Mode	Up to 2010	Intelligent Key	Special Function	Anti Key Lock In Function
INFINITI	All Mode	Up to 2010	Intelligent Key	Special Function	Hazard Answer Back
INFINITI	All Mode	Up to 2010	Intelligent Key	Special Function	Answer Back With I-Key Lock
INFINITI	All Mode	Up to 2010	Intelligent Key	Special Function	Answer Back With I-Key Unlock
INFINITI	All Mode	Up to 2010	Intelligent Key	Special Function	Auto Relock Timer
INFINITI	All Mode	Up to 2010	Intelligent Key	Special Function	Panic Alarm Delay
INFINITI	All Mode	Up to 2010	Intelligent Key	Special Function	Trunk Open Delay
INFINITI	All Mode	Up to 2010	Intelligent Key	Special Function	P/W Down Delay
INFINITI	All Mode	Up to 2010	Intelligent Key	Special Function	Power Slide Door Delay
INFINITI	All Mode	Up to 2010	Intelligent Key	Special Function	Engine Start By I-Key
INFINITI	All Mode	Up to 2010	Intelligent Key	Special Function	Lock/Unlock By I-Key
INFINITI	All Mode	Up to 2010	Intelligent Key	Special Function	LUG Room Engine Start
INFINITI	All Mode	Up to 2010	Intelligent Key	Special Function	Horn With Keyless Lock
INFINITI	All Mode	Up to 2010	Intelligent Key	Special Function	Trunk/Glass Hatch Open
INFINITI	All Mode	Up to 2010	Intelligent Key	Special Function	Short Cranking Output
INFINITI	All Mode	Up to 2010	Intelligent Key	Read Fault Code	
INFINITI	All Mode	Up to 2010	Intelligent Key	Clear Fault Code	
INFINITI	All Mode	Up to 2010	Intelligent Key	Read Data Stream	
INFINITI	All Mode	Up to 2010	Intelligent Key	Module Information	
INFINITI	All Mode	Up to 2010	Intelligent Key	Actuation Test	Door Lock/Unlock
INFINITI	All Mode	Up to 2010	Intelligent Key	Actuation Test	ANTENNA
INFINITI	All Mode	Up to 2010	Intelligent Key	Actuation Test	Outside Buzzer
INFINITI	All Mode	Up to 2010	Intelligent Key	Actuation Test	INDICATOR
INFINITI	All Mode	Up to 2010	Intelligent Key	Actuation Test	LCD
INFINITI	All Mode	Up to 2010	Intelligent Key	Actuation Test	P Range
INFINITI	All Mode	Up to 2010	Intelligent Key	Actuation Test	Engine SW Illumi
INFINITI	All Mode	Up to 2010	Intelligent Key	Actuation Test	Lock Indicator
INFINITI	All Mode	Up to 2010	Intelligent Key	Actuation Test	ACC Indicator
INFINITI	All Mode	Up to 2010	Intelligent Key	Actuation Test	Ignition ON IND
INFINITI	All Mode	Up to 2010	Intelligent Key	Actuation Test	Key Slot Illumi
INFINITI	All Mode	Up to 2010	Intelligent Key	Special Function	Confirm Key Fob ID
INFINITI	All Mode	Up to 2010	Intelligent Key	Special Function	Short Cranking Output
INFINITI	All Mode	Up to 2010	Intelligent Key	Special Function	Take Out From Window Warn
INFINITI	All Mode	Up to 2010	Intelligent Key	Special Function	Low Batt Of Key Fob Warn
INFINITI	All Mode	Up to 2010	Intelligent Key	Special Function	Answer Back Function
INFINITI	All Mode	Up to 2010	Intelligent Key	Special Function	Selective Unlock Function
INFINITI	All Mode	Up to 2010	Intelligent Key	Special Function	Horn With Keyless Lock
INFINITI	All Mode	Up to 2010	Intelligent Key	Special Function	Hazard Answer Back
INFINITI	All Mode	Up to 2010	Intelligent Key	Special Function	Answer Back With I-Key Lock
INFINITI	All Mode	Up to 2010	Intelligent Key	Special Function	Answer Back With I-Key Unlock
INFINITI	All Mode	Up to 2010	Intelligent Key	Special Function	Auto Relock Timer
INFINITI	All Mode	Up to 2010	Intelligent Key	Special Function	Panic Alarm Delay
INFINITI	All Mode	Up to 2010	Intelligent Key	Special Function	Trunk/Glass Hatch Open
INFINITI	All Mode	Up to 2010	Intelligent Key	Special Function	Trunk Open Delay
INFINITI	All Mode	Up to 2010	Intelligent Key	Special Function	P/W Down Delay
INFINITI	All Mode	Up to 2010	Intelligent Key	Special Function	Engine Start By I-Key
INFINITI	All Mode	Up to 2010	Intelligent Key	Special Function	Lock/Unlock By I-Key
INFINITI	All Mode	Up to 2010	Intelligent Key	Special Function	LUG Room Engine Start
INFINITI	All Mode	Up to 2010	Intelligent Key	Read Fault Code	
INFINITI	All Mode	Up to 2010	Intelligent Key	Clear Fault Code	
INFINITI	All Mode	Up to 2010	Intelligent Key	Read Data Stream	
INFINITI	All Mode	Up to 2010	Intelligent Key	Module Information	
INFINITI	All Mode	Up to 2010	Intelligent Key	Actuation Test	Outside Buzzer
INFINITI	All Mode	Up to 2010	Intelligent Key	Actuation Test	Inside Buzzer
INFINITI	All Mode	Up to 2010	Intelligent Key	Actuation Test	Indicator
INFINITI	All Mode	Up to 2010	Intelligent Key	Actuation Test	Door Lock/Unlock
INFINITI	All Mode	Up to 2010	Intelligent Key	Actuation Test	ANTENNA
INFINITI	All Mode	Up to 2010	Intelligent Key	Special Function	Take Out From Window Warn
INFINITI	All Mode	Up to 2010	Intelligent Key	Special Function	Low Batt Of Key Fob Warn
INFINITI	All Mode	Up to 2010	Intelligent Key	Special Function	Answer Back Function

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
INFINITI	All Mode	Up to 2010	Intelligent Key	Special Function	Selective Unlock Function
INFINITI	All Mode	Up to 2010	Intelligent Key	Special Function	Anti Key Lock In Function
INFINITI	All Mode	Up to 2010	Intelligent Key	Special Function	Horn With Keyless Lock
INFINITI	All Mode	Up to 2010	Intelligent Key	Special Function	Hazard Answer Back
INFINITI	All Mode	Up to 2010	Intelligent Key	Special Function	Answer Back With I-Key Lock
INFINITI	All Mode	Up to 2010	Intelligent Key	Special Function	Answer Back With I-Key Unlock
INFINITI	All Mode	Up to 2010	Intelligent Key	Special Function	Auto Relock Timer
INFINITI	All Mode	Up to 2010	Intelligent Key	Special Function	Panic Alarm Delay
INFINITI	All Mode	Up to 2010	Intelligent Key	Special Function	Trunk/Glass Hatch Open
INFINITI	All Mode	Up to 2010	Intelligent Key	Special Function	Trunk Open Delay
INFINITI	All Mode	Up to 2010	Intelligent Key	Special Function	P/W Down Delay
INFINITI	All Mode	Up to 2010	Intelligent Key	Special Function	Power Slide Door Delay
INFINITI	All Mode	Up to 2010	Intelligent Key	Special Function	Engine Start By I-Key
INFINITI	All Mode	Up to 2010	Intelligent Key	Special Function	Lock/Unlock By I-Key
INFINITI	All Mode	Up to 2010	Intelligent Key	Special Function	Confirm Key Fob ID
INFINITI	All Mode	Up to 2010	Intelligent Key	Read Fault Code	
INFINITI	All Mode	Up to 2010	Intelligent Key	Clear Fault Code	
INFINITI	All Mode	Up to 2010	Intelligent Key	Read Data Stream	
INFINITI	All Mode	Up to 2010	Intelligent Key	Module Information	
INFINITI	All Mode	Up to 2010	Intelligent Key	Special Function	Confirm Key Fob ID
INFINITI	All Mode	Up to 2010	Intelligent Key	Special Function	Take Out From Window Warn
INFINITI	All Mode	Up to 2010	Intelligent Key	Special Function	Low Batt Of Key Fob Warn
INFINITI	All Mode	Up to 2010	Intelligent Key	Special Function	I-Key Function
INFINITI	All Mode	Up to 2010	Intelligent Key	Special Function	Answer Back Function
INFINITI	All Mode	Up to 2010	Intelligent Key	Read Fault Code	
INFINITI	All Mode	Up to 2010	Intelligent Key	Clear Fault Code	
INFINITI	All Mode	Up to 2010	Intelligent Key	Read Data Stream	
INFINITI	All Mode	Up to 2010	Intelligent Key	Module Information	
INFINITI	All Mode	Up to 2010	Intelligent Key	Actuation Test	Door Lock/Unlock
INFINITI	All Mode	Up to 2010	Intelligent Key	Actuation Test	ANTENNA
INFINITI	All Mode	Up to 2010	Intelligent Key	Actuation Test	Outside Buzzer
INFINITI	All Mode	Up to 2010	Intelligent Key	Actuation Test	Inside Buzzer
INFINITI	All Mode	Up to 2010	Intelligent Key	Actuation Test	Indicator
INFINITI	All Mode	Up to 2010	Intelligent Key	Actuation Test	KEY LOCK SOLENOID
INFINITI	All Mode	Up to 2010	Intelligent Key	Actuation Test	P Range
INFINITI	All Mode	Up to 2010	Intelligent Key	Actuation Test	Engine SW Illumi
INFINITI	All Mode	Up to 2010	Intelligent Key	Actuation Test	Lock Indicator
INFINITI	All Mode	Up to 2010	Intelligent Key	Actuation Test	ACC Indicator
INFINITI	All Mode	Up to 2010	Intelligent Key	Actuation Test	Ignition ON IND
INFINITI	All Mode	Up to 2010	Intelligent Key	Actuation Test	Key Slot Illumi
INFINITI	All Mode	Up to 2010	Intelligent Key	Actuation Test	LCD
INFINITI	All Mode	Up to 2010	Intelligent Key	Special Function	Confirm Key Fob ID
INFINITI	All Mode	Up to 2010	Intelligent Key	Special Function	Take Out From Window Warn
INFINITI	All Mode	Up to 2010	Intelligent Key	Special Function	Low Batt Of Key Fob Warn
INFINITI	All Mode	Up to 2010	Intelligent Key	Special Function	Keyless Function
INFINITI	All Mode	Up to 2010	Intelligent Key	Special Function	I-Key Function
INFINITI	All Mode	Up to 2010	Intelligent Key	Special Function	Answer Back Function
INFINITI	All Mode	Up to 2010	Intelligent Key	Special Function	Selective Unlock Function
INFINITI	All Mode	Up to 2010	Intelligent Key	Special Function	Anti Key Lock In Function
INFINITI	All Mode	Up to 2010	Intelligent Key	Special Function	Hazard Answer Back
INFINITI	All Mode	Up to 2010	Intelligent Key	Special Function	Answer Back With I-Key Unlock
INFINITI	All Mode	Up to 2010	Intelligent Key	Special Function	Auto Relock Timer
INFINITI	All Mode	Up to 2010	Intelligent Key	Special Function	Panic Alarm Delay
INFINITI	All Mode	Up to 2010	Intelligent Key	Special Function	Trunk Open Delay
INFINITI	All Mode	Up to 2010	Intelligent Key	Special Function	P/W Down Delay
INFINITI	All Mode	Up to 2010	Intelligent Key	Special Function	Power Slide Door Delay
INFINITI	All Mode	Up to 2010	Intelligent Key	Special Function	Engine Start By I-Key
INFINITI	All Mode	Up to 2010	Intelligent Key	Special Function	Lock/Unlock By I-Key
INFINITI	All Mode	Up to 2010	Intelligent Key	Special Function	LUG Room Engine Start
INFINITI	All Mode	Up to 2010	Intelligent Key	Special Function	Trunk/Glass Hatch Open
INFINITI	All Mode	Up to 2010	Intelligent Key	Special Function	Short Cranking Output
INFINITI	All Mode	Up to 2010	Intelligent Key	Special Function	Answer Back With I-Key Lock
INFINITI	All Mode	Up to 2010	Intelligent Key	Read Fault Code	
INFINITI	All Mode	Up to 2010	Intelligent Key	Clear Fault Code	
INFINITI	All Mode	Up to 2010	Intelligent Key	Read Data Stream	
INFINITI	All Mode	Up to 2010	Intelligent Key	Module Information	
INFINITI	All Mode	Up to 2010	Intelligent Key	Special Function	Take Out From Window Warn
INFINITI	All Mode	Up to 2010	Intelligent Key	Special Function	Low Batt Of Key Fob Warn
INFINITI	All Mode	Up to 2010	Intelligent Key	Special Function	I-Key Function
INFINITI	All Mode	Up to 2010	Intelligent Key	Special Function	Answer Back Function
INFINITI	All Mode	Up to 2010	Intelligent Key	Special Function	Confirm Key Fob ID
INFINITI	All Mode	2015 - 2018	Intelligent Key	Read Fault Code	
INFINITI	All Mode	2015 - 2018	Intelligent Key	Clear Fault Code	
INFINITI	All Mode	2015 - 2018	Intelligent Key	Read Data Stream	
INFINITI	All Mode	2015 - 2018	Intelligent Key	Module Information	
INFINITI	All Mode	Up to 2008	DIU	Read Fault Code	
INFINITI	All Mode	Up to 2008	DIU	Clear Fault Code	
INFINITI	All Mode	Up to 2008	DIU	Read Data Stream	



**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
INFINITI	All Mode	Up to 2008	Auto Slide Door	Read Fault Code	
INFINITI	All Mode	Up to 2008	Auto Slide Door	Clear Fault Code	
INFINITI	All Mode	Up to 2008	Auto Slide Door	Read Data Stream	
INFINITI	All Mode	Up to 2008	Auto Slide Door	Module Information	
INFINITI	All Mode	Up to 2008	Auto Slide Door	Actuation Test	CLUTCH
INFINITI	All Mode	2005 - 2015	Precrash Seatbelt	Read Fault Code	
INFINITI	All Mode	2005 - 2015	Precrash Seatbelt	Clear Fault Code	
INFINITI	All Mode	2005 - 2015	Precrash Seatbelt	Read Data Stream	
INFINITI	All Mode	2005 - 2015	Precrash Seatbelt	Module Information	
INFINITI	All Mode	2008 - 2015	Precrash Seatbelt	Read Fault Code	
INFINITI	All Mode	2008 - 2015	Precrash Seatbelt	Clear Fault Code	
INFINITI	All Mode	2008 - 2015	Precrash Seatbelt	Read Data Stream	
INFINITI	All Mode	2008 - 2015	Precrash Seatbelt	Module Information	
INFINITI	All Mode	2009 - 2018	Precrash Seatbelt	Read Fault Code	
INFINITI	All Mode	2009 - 2018	Precrash Seatbelt	Clear Fault Code	
INFINITI	All Mode	2009 - 2018	Precrash Seatbelt	Read Data Stream	
INFINITI	All Mode	2009 - 2018	Precrash Seatbelt	Read Freeze Frame	
INFINITI	All Mode	2009 - 2018	Precrash Seatbelt	Module Information	
INFINITI	All Mode	2009 - 2018	Precrash Seatbelt	Special Function	Door Opening Retract Retry
INFINITI	All Mode	Up to 2017	Auto Drive Position	Read Fault Code	
INFINITI	All Mode	Up to 2017	Auto Drive Position	Clear Fault Code	
INFINITI	All Mode	Up to 2017	Auto Drive Position	Read Data Stream	
INFINITI	All Mode	Up to 2017	Auto Drive Position	Module Information	
INFINITI	All Mode	Up to 2017	Auto Drive Position	Actuation Test	SEAT SLIDE
INFINITI	All Mode	Up to 2017	Auto Drive Position	Actuation Test	SEAT RECLINING
INFINITI	All Mode	Up to 2017	Auto Drive Position	Actuation Test	SEAT LIFTER FR
INFINITI	All Mode	Up to 2017	Auto Drive Position	Actuation Test	SEAT LIFTER RR
INFINITI	All Mode	Up to 2017	Auto Drive Position	Actuation Test	TILT MOTOR
INFINITI	All Mode	Up to 2017	Auto Drive Position	Actuation Test	TELESCO MOTOR
INFINITI	All Mode	Up to 2017	Auto Drive Position	Actuation Test	PEDAL MOTOR
INFINITI	All Mode	Up to 2017	Auto Drive Position	Actuation Test	Mirror Motor RH
INFINITI	All Mode	Up to 2017	Auto Drive Position	Actuation Test	Mirror Motor LH
INFINITI	All Mode	Up to 2017	Auto Drive Position	Actuation Test	MEMORY SW INDCTR
INFINITI	All Mode	Up to 2017	Auto Drive Position	Actuation Test	SEAT LIFT
INFINITI	All Mode	Up to 2017	Auto Drive Position	Special Function	Exit Seat Slide Setting
INFINITI	All Mode	Up to 2017	Auto Drive Position	Special Function	Exit Tilt Setting
INFINITI	All Mode	Up to 2017	Auto Drive Position	Special Function	Seat Slide Volume Set
INFINITI	All Mode	Up to 2018	Auto Drive Position	Read Fault Code	
INFINITI	All Mode	Up to 2018	Auto Drive Position	Clear Fault Code	
INFINITI	All Mode	Up to 2018	Auto Drive Position	Read Data Stream	
INFINITI	All Mode	Up to 2018	Auto Drive Position	Module Information	
INFINITI	All Mode	Up to 2018	Auto Drive Position	Actuation Test	SEAT SLIDE
INFINITI	All Mode	Up to 2018	Auto Drive Position	Actuation Test	SEAT RECLINING
INFINITI	All Mode	Up to 2018	Auto Drive Position	Actuation Test	SEAT LIFTER FR
INFINITI	All Mode	Up to 2018	Auto Drive Position	Actuation Test	SEAT LIFTER RR
INFINITI	All Mode	Up to 2018	Auto Drive Position	Actuation Test	TILT MOTOR
INFINITI	All Mode	Up to 2018	Auto Drive Position	Actuation Test	TELESCO MOTOR
INFINITI	All Mode	Up to 2018	Auto Drive Position	Actuation Test	PEDAL MOTOR
INFINITI	All Mode	Up to 2018	Auto Drive Position	Actuation Test	Mirror Motor RH
INFINITI	All Mode	Up to 2018	Auto Drive Position	Actuation Test	Mirror Motor LH
INFINITI	All Mode	Up to 2018	Auto Drive Position	Actuation Test	MEMORY SW INDCTR
INFINITI	All Mode	Up to 2018	Auto Drive Position	Actuation Test	SEAT LIFT
INFINITI	All Mode	Up to 2018	Auto Drive Position	Special Function	Exit Seat Slide Setting
INFINITI	All Mode	Up to 2018	Auto Drive Position	Special Function	Exit Tilt Setting
INFINITI	All Mode	Up to 2018	Auto Drive Position	Special Function	Seat Slide Volume Set
INFINITI	All Mode	Up to 2018	Auto Drive Position	Read Fault Code	
INFINITI	All Mode	Up to 2018	Auto Drive Position	Clear Fault Code	
INFINITI	All Mode	Up to 2018	Auto Drive Position	Read Data Stream	
INFINITI	All Mode	Up to 2018	Auto Drive Position	Read Freeze Frame	
INFINITI	All Mode	Up to 2018	Auto Drive Position	Module Information	
INFINITI	All Mode	Up to 2018	Auto Drive Position	Actuation Test	SEAT SLIDE
INFINITI	All Mode	Up to 2018	Auto Drive Position	Actuation Test	SEAT RECLINING
INFINITI	All Mode	Up to 2018	Auto Drive Position	Actuation Test	SEAT LIFTER FR
INFINITI	All Mode	Up to 2018	Auto Drive Position	Actuation Test	SEAT LIFTER RR
INFINITI	All Mode	Up to 2018	Auto Drive Position	Actuation Test	TILT MOTOR
INFINITI	All Mode	Up to 2018	Auto Drive Position	Actuation Test	TELESCO MOTOR
INFINITI	All Mode	Up to 2018	Auto Drive Position	Actuation Test	Mirror Motor RH
INFINITI	All Mode	Up to 2018	Auto Drive Position	Actuation Test	Mirror Motor LH
INFINITI	All Mode	Up to 2018	Auto Drive Position	Actuation Test	MEMORY SW INDCTR
INFINITI	All Mode	Up to 2018	Auto Drive Position	Special Function	Exit Seat Slide Setting
INFINITI	All Mode	Up to 2018	Auto Drive Position	Special Function	Exit Tilt Setting
INFINITI	All Mode	Up to 2018	Auto Drive Position	Special Function	Seat Slide Volume Set
INFINITI	All Mode	2015 - 2018	Auto Drive Position	Read Fault Code	
INFINITI	All Mode	2015 - 2018	Auto Drive Position	Clear Fault Code	
INFINITI	All Mode	2015 - 2018	Auto Drive Position	Read Data Stream	
INFINITI	All Mode	2015 - 2018	Auto Drive Position	Module Information	
INFINITI	All Mode	2015 - 2018	Auto Drive Position	Special Function	Normalization
INFINITI	All Mode	2015 - 2018	Auto Drive Position	Read Data Stream	
INFINITI	All Mode	2015 - 2018	Auto Drive Position	Module Information	
INFINITI	All Mode	2015 - 2018	Auto Drive Position	Special Function	Control unit unlock

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
INFINITI	All Mode	2015 - 2018	Auto Drive Position	Special Function	Initial startup sequence locking
INFINITI	All Mode	2007 - 2015	All Mode Awd/Awd	Read Fault Code	
INFINITI	All Mode	2007 - 2015	All Mode Awd/Awd	Clear Fault Code	
INFINITI	All Mode	2007 - 2015	All Mode Awd/Awd	Read Data Stream	
INFINITI	All Mode	2007 - 2015	All Mode Awd/Awd	Read Freeze Frame	
INFINITI	All Mode	2007 - 2015	All Mode Awd/Awd	Module Information	
INFINITI	All Mode	2007 - 2018	All Mode Awd/Awd	Read Fault Code	
INFINITI	All Mode	2007 - 2018	All Mode Awd/Awd	Clear Fault Code	
INFINITI	All Mode	2007 - 2018	All Mode Awd/Awd	Read Data Stream	
INFINITI	All Mode	2007 - 2018	All Mode Awd/Awd	Read Freeze Frame	
INFINITI	All Mode	2007 - 2018	All Mode Awd/Awd	Module Information	
INFINITI	All Mode	2007 - 2018	All Mode Awd/Awd	Special Function	Unit Characteristics Data
INFINITI	All Mode	2007 - 2018	All Mode Awd/Awd	Special Function	Unit Characteristics Write
INFINITI	All Mode	Up to 2015	All Mode Awd/Awd	Read Fault Code	
INFINITI	All Mode	Up to 2015	All Mode Awd/Awd	Clear Fault Code	
INFINITI	All Mode	Up to 2015	All Mode Awd/Awd	Read Data Stream	
INFINITI	All Mode	Up to 2015	All Mode Awd/Awd	Module Information	
INFINITI	All Mode	Up to 2015	All Mode Awd/Awd	Special Function	Clutch/F RLS LIM ADJ
INFINITI	All Mode	2010 - 2017	All Mode Awd/Awd	Read Fault Code	
INFINITI	All Mode	2010 - 2017	All Mode Awd/Awd	Clear Fault Code	
INFINITI	All Mode	2010 - 2017	All Mode Awd/Awd	Read Data Stream	
INFINITI	All Mode	2010 - 2017	All Mode Awd/Awd	Module Information	
INFINITI	All Mode	2010 - 2017	All Mode Awd/Awd	Special Function	Unit Characteristics Write
INFINITI	All Mode	2010 - 2017	All Mode Awd/Awd	Special Function	Start Calibration
INFINITI	All Mode	2010 - 2017	All Mode Awd/Awd	Special Function	Lock Sleeve Sensor Initialize
INFINITI	All Mode	2010 - 2017	All Mode Awd/Awd	Special Function	Lock Sleeve Sensor Learning
INFINITI	All Mode	2010 - 2017	All Mode Awd/Awd	Special Function	Oil Deterioration Info Reset
INFINITI	All Mode	2013 - 2016	All Mode Awd/Awd	Read Fault Code	
INFINITI	All Mode	2013 - 2016	All Mode Awd/Awd	Clear Fault Code	
INFINITI	All Mode	2013 - 2016	All Mode Awd/Awd	Read Data Stream	
INFINITI	All Mode	2013 - 2016	All Mode Awd/Awd	Module Information	
INFINITI	All Mode	2013 - 2016	All Mode Awd/Awd	Actuation Test	SOLENOID LEFT
INFINITI	All Mode	2013 - 2016	All Mode Awd/Awd	Actuation Test	SOLENOID RIGHT
INFINITI	All Mode	2013 - 2016	All Mode Awd/Awd	Special Function	Unit Characteristics Write
INFINITI	All Mode	2013 - 2016	All Mode Awd/Awd	Special Function	Unit Characteristics Data
INFINITI	All Mode	2013 - 2015	All Mode Awd/Awd	Read Fault Code	
INFINITI	All Mode	2013 - 2015	All Mode Awd/Awd	Clear Fault Code	
INFINITI	All Mode	2013 - 2015	All Mode Awd/Awd	Read Data Stream	
INFINITI	All Mode	2013 - 2015	All Mode Awd/Awd	Module Information	
INFINITI	All Mode	2013 - 2015	All Mode Awd/Awd	Actuation Test	Drive Pwr Dstrbt Torque
INFINITI	All Mode	2013 - 2015	All Mode Awd/Awd	Special Function	Unit Characteristics Write
INFINITI	All Mode	2013 - 2015	All Mode Awd/Awd	Special Function	Unit Characteristics Data
INFINITI	All Mode	2015 - 2018	All Mode Awd/Awd	Read Fault Code	
INFINITI	All Mode	2015 - 2018	All Mode Awd/Awd	Clear Fault Code	
INFINITI	All Mode	2015 - 2018	All Mode Awd/Awd	Read Data Stream	
INFINITI	All Mode	2015 - 2018	All Mode Awd/Awd	Module Information	
INFINITI	All Mode	2015 - 2018	All Mode Awd/Awd	Special Function	Function test of solenoid valve while driving
INFINITI	All Mode	Up to 2015	All Mode Awd/Awd	Read Fault Code	
INFINITI	All Mode	Up to 2015	All Mode Awd/Awd	Clear Fault Code	
INFINITI	All Mode	Up to 2015	All Mode Awd/Awd	Read Data Stream	
INFINITI	All Mode	Up to 2015	All Mode Awd/Awd	Module Information	
INFINITI	All Mode	Up to 2015	All Mode Awd/Awd	Read Fault Code	
INFINITI	All Mode	Up to 2015	All Mode Awd/Awd	Clear Fault Code	
INFINITI	All Mode	Up to 2015	All Mode Awd/Awd	Read Data Stream	
INFINITI	All Mode	Up to 2015	All Mode Awd/Awd	Module Information	
INFINITI	All Mode	Up to 2015	All Mode Awd/Awd	Special Function	
INFINITI	All Mode	Up to 2008	All Mode Awd/Awd	Read Fault Code	
INFINITI	All Mode	Up to 2008	All Mode Awd/Awd	Clear Fault Code	
INFINITI	All Mode	Up to 2008	All Mode Awd/Awd	Read Data Stream	
INFINITI	All Mode	Up to 2008	All Mode Awd/Awd	Module Information	
INFINITI	All Mode	Up to 2008	All Mode Awd/Awd	Actuation Test	
INFINITI	All Mode	Up to 2014	All Mode Awd/Awd	Read Fault Code	
INFINITI	All Mode	Up to 2014	All Mode Awd/Awd	Clear Fault Code	
INFINITI	All Mode	Up to 2014	All Mode Awd/Awd	Read Data Stream	
INFINITI	All Mode	Up to 2014	All Mode Awd/Awd	Module Information	
INFINITI	All Mode	Up to 2014	All Mode Awd/Awd	Special Function	START TORQ OFFSET ADJ
INFINITI	All Mode	Up to 2014	All Mode Awd/Awd	Special Function	CLUTCH/F RLS LIM ADJ
INFINITI	All Mode	Up to 2014	All Mode Awd/Awd	Read Fault Code	
INFINITI	All Mode	Up to 2014	All Mode Awd/Awd	Clear Fault Code	
INFINITI	All Mode	Up to 2014	All Mode Awd/Awd	Read Data Stream	
INFINITI	All Mode	Up to 2014	All Mode Awd/Awd	Module Information	
INFINITI	All Mode	Up to 2014	All Mode Awd/Awd	Special Function	START TORQ OFFSET ADJ
INFINITI	All Mode	Up to 2014	All Mode Awd/Awd	Special Function	CLUTCH/F RLS LIM ADJ
INFINITI	All Mode	Up to 2014	All Mode Awd/Awd	Read Fault Code	
INFINITI	All Mode	Up to 2014	All Mode Awd/Awd	Clear Fault Code	
INFINITI	All Mode	Up to 2014	All Mode Awd/Awd	Read Data Stream	

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
INFINITI	All Mode	Up to 2014	All Mode Awd/4wd	Module Information	
INFINITI	All Mode	Up to 2014	All Mode Awd/4wd	Special Function	CLUTCH/F RLS LIM ADJ
INFINITI	All Mode	Up to 2017	Diff Lock	Read Fault Code	
INFINITI	All Mode	Up to 2017	Diff Lock	Clear Fault Code	
INFINITI	All Mode	Up to 2017	Diff Lock	Read Data Stream	
INFINITI	All Mode	Up to 2017	Diff Lock	Module Information	
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Read Fault Code	
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Clear Fault Code	
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Read Data Stream	
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Module Information	
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	Door Lock
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	Step Lamp Test
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	Int Lamp
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	Tail Lamp
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	Head Lamp
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	FR FOG Lamp
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	RR FOG Lamp
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	Daytime Running Light
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	ILL DIM Signal
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	FR Wiper
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	Head Lamp Washer
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	Flasher
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	Theft IND
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	Battery Saver
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	Trunk/Glass Hatch
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	Vehicle Security Horn
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	Head Lamp(HI)
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	OIL Pressure SW
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	Rear Defogger
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	IGN KEY WARN ALM
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	Light Warn Alm
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	Reverse Warning
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	Seat Belt Warn Test
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	Horn
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	POWER WINDOW DOWN
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	Cornering Lamp
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	RR Wiper
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	PBD
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	Power Slide Door
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	A/C Indicator
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Special Function	Set I/L D-Unlck Intcon
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Special Function	Room Lamp Timer Set
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Special Function	Room Lamp On Time Set
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Special Function	Room Lamp Off Time Set
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Special Function	R Lamp Timer Logic Set
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Special Function	Room Lamp On At Lock
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Special Function	Battery Saver Set
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Special Function	Custom A/Light Setting
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Special Function	ILL Delay Set
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Special Function	Wiper Speed Setting
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Special Function	Reset Setting Value
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Special Function	Security Alarm SET
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Special Function	Theft ALM TRG
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Special Function	Retained PWR Set
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Read Fault Code	
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Clear Fault Code	
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Read Data Stream	
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Read Freeze Frame	
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Module Information	
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Door Lock
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Super Lock
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	REAR DOOR UNLOCK TEST
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Door Lock Ind
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Rear Defogger
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	IGN KEY WARN ALM
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Seat Belt Warn Test
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Key Reminder Warn
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	ID REGIST WARNING
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Light Warn Alm
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Reverse Warning
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	RUN FLAT/T WARN BUZZER
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Step Lamp Test
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Int Lamp
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	LUGGAGE LAMP TEST
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Tail Lamp
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Head Lamp
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	FR FOG Lamp
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	RR FOG Lamp
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Daytime Running Light
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Cornering Lamp

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

<b>make</b>	<b>model</b>	<b>year</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	ILL DIM Signal
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	FR Wiper
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Head Lamp Washer
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	RR Wiper
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Flasher
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	SIREN
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Theft IND
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	PW REMOTO DOWN SET
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Battery Saver
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Outside Buzzer
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Inside Buzzer
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Indicator
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	LCD
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Horn
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	P Range
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Engine SW Illumi
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Lock Indicator
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	ACC Indicator
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Ignition ON IND
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Key Slot Illumi
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Trunk/Back Door
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	KEYLESS PW UP/DOWN
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Trunk/Glass Hatch
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Vehicle Security Horn
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Head Lamp(HI)
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	OIL Pressure SW
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Warning Lamp
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	RUN FLAT TIER W/L
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Door Lock-Unlock Set
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	HORN CHIRP SET
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Set I/L D-Unlock Intcon
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Room Lamp Timer Set
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Room Lamp On Time Set
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Room Lamp BAT SAV SET
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Room Lamp Off Time Set
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	R Lamp Timer Logic Set
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Battery Saver Set
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Custom A/Light Setting
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	ILL Delay Set
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Wiper Speed Setting
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	HAZARD LAMP SET
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Hazard Answer Back
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Reset Setting Value
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Security Alarm SET
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Theft ALM TRG
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	SIREN SET
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Auto Lock Set
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Lock/Unlock By I-Key
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Engine Start By I-Key
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Trunk/Glass Hatch Open
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Panic Alarm Set
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Take Out From Win Warn
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Pw Down Set
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Trunk Open Delay
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	LO-BATT OP KEY FOB WARN
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Keyless Function
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Anti Key Lock In Function
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Ans Back I-Key Lock
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Ans Back I-Key Unlock
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Short Cranking Output
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Inside ANT Diagnosis
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Horn With Keyless Lock
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Automatic Door Lock Select
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Automatic Door Unlock Select
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Automatic Door Lock/Unlock Select
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Confirm Key Fob ID
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	ID REGIST
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	ID READ
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	D/LOCK VHCL SPD AJT
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Room Lamp On At Lock
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Retained PWR Set
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	REMO CONT ID CONFIR
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Welcome Light Op Set
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Answer Back Function
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Welcome Light Select
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Read Fault Code	
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Clear Fault Code	
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Read Data Stream	

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Read Freeze Frame	
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Module Information	
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Door Lock
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Super Lock
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Door Lock Ind
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Rear Defogger
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Seat Belt Warn Test
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Key Reminder Warn
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Light Warn Alm
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Reverse Warning
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Step Lamp Test
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Int Lamp
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Tail Lamp
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Head Lamp
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	FR FOG Lamp
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Daytime Running Light
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	ILL DIM Signal
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	FR Wiper
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Head Lamp Washer
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	RR Wiper
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Flasher
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	SIREN
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Theft IND
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Battery Saver
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Outside Buzzer
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Inside Buzzer
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Indicator
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	LCD
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Horn
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	P Range
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Engine SW Illumi
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Lock Indicator
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	ACC Indicator
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Ignition ON IND
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Trunk/Back Door
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Vehicle Security Horn
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Head Lamp(HI)
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Push Switch Indicator
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	RUN FLAT TIRE W/L
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Warning Lamp
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	ID REGIST WARNING
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	A/C Indication
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Intelligent Key Link
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Intelligent Key Link(CAN)
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Power Slide Door
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	OIL Pressure SW
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Retractable Mirror
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Heated Steering Wheel
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Confirm TCU ID
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Door Lock-Unlock Set
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Set I/L D-Unlock Intcon
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Room Lamp Timer Set
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Room Lamp On Time Set
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Room Lamp BAT SAV SET
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Room Lamp Off Time Set
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	R Lamp Timer Logic Set
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Battery Saver Set
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Custom A/Light Setting
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	ILL Delay Set
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Wiper Speed Setting
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Rain Sen Wip Func Set
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Drop Wipe Func Set
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Hazard Answer Back
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Reset Setting Value
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Security Alarm SET
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Theft ALM TRG
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	SIREN SET
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Lock/Unlock By I-Key
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Engine Start By I-Key
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Trunk/Glass Hatch Open
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Answer Back Function
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Panic Alarm Set
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Pw Down Set
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Trunk Open Delay
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	LO-BATT OF KEY FOB WARN
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Anti Key Lock In Function
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Ans Back I-Key Lock
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Ans Back I-Key Unlock
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Short Cranking Output
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Inside ANT Diagnosis

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Horn With Keyless Lock
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Automatic Door Lock Select
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Confirm Key Fob ID
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	ID REGIST
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Switch Tpmns Between On/Off
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	ID READ
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Retractable Mirror Set
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Confirm Dongle ID
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Welcome Light Op Set
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Welcome Light Select
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Intelligent Key Link Set
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Security Alarm Set(Siren)
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Signature Light Setting
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	FOG Lamp Override
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Daytime Running Light Setting
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Remote Climate Cont Answer Back Function
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	RR WIP RVRS SET
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Auto Light Logic Set
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Auto Lock Set
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Ign Battery Saver Set
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Acc Battery Saver Set
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Head Light Timer
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Automatic Door Unlock Select
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Automatic Lock/Unlock Set
INFINITI	All Mode	Up to 2016	BCM (Body Control Module)	Read Fault Code	
INFINITI	All Mode	Up to 2016	BCM (Body Control Module)	Clear Fault Code	
INFINITI	All Mode	Up to 2016	BCM (Body Control Module)	Read Data Stream	
INFINITI	All Mode	Up to 2016	BCM (Body Control Module)	Module Information	
INFINITI	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Door Lock
INFINITI	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Super Lock
INFINITI	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Door Lock Ind
INFINITI	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Rear Defogger
INFINITI	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Seat Belt Warn Test
INFINITI	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Light Warn Alm
INFINITI	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	IGN KEY WARN ALM
INFINITI	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Reverse Warning
INFINITI	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Int Lamp
INFINITI	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Power Slide Door
INFINITI	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Tail Lamp
INFINITI	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Head Lamp
INFINITI	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	FR FOG Lamp
INFINITI	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	RR FOG Lamp
INFINITI	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Daytime Running Light
INFINITI	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	ILL DIM Signal
INFINITI	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	FR Wiper
INFINITI	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Head Lamp Washer
INFINITI	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	RR Wiper
INFINITI	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Flasher
INFINITI	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	SIREN
INFINITI	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Theft IND
INFINITI	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Battery Saver
INFINITI	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Horn
INFINITI	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Trunk/Back Door
INFINITI	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Trunk/Glass Hatch
INFINITI	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Vehicle Security Horn
INFINITI	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Head Lamp(HI)
INFINITI	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	RUN FLAT TIRE W/L
INFINITI	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	Warning Lamp
INFINITI	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	ID REGIST WARNING
INFINITI	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	OIL Pressure SW
INFINITI	All Mode	Up to 2016	BCM (Body Control Module)	Actuation Test	A/C Indicator
INFINITI	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Set R-DEF Timer
INFINITI	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Door Lock-Unlock Set
INFINITI	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Set I/L D-Unlck Intcon
INFINITI	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Room Lamp Timer Set
INFINITI	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Room Lamp On Time Set
INFINITI	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Room Lamp BAT SAV SET
INFINITI	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Room Lamp Off Time Set
INFINITI	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	R Lamp Timer Logic Set
INFINITI	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Battery Saver Set
INFINITI	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Custom A/Light Setting
INFINITI	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	ILL Delay Set
INFINITI	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Auto Light Logic Set
INFINITI	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Wiper Speed Setting
INFINITI	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Rain Sen Wip Func Set
INFINITI	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Drop Wipe Func Set
INFINITI	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Reset Setting Value

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
INFINITI	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Security Alarm SET
INFINITI	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Theft ALM TRG
INFINITI	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	SIREN SET
INFINITI	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Panic Alarm Set
INFINITI	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Automatic Door Lock Select
INFINITI	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	ID REGIST
INFINITI	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	ID READ
INFINITI	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Confirm Dongle ID
INFINITI	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	REMO CONT ID ERASUR
INFINITI	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	REMO CONT ID REGIST
INFINITI	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	REMO CONT ID CONFIR
INFINITI	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	HORN CHIRP SET
INFINITI	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	MULTI ANSWER BACK SET
INFINITI	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	HAZARD LAMP SET
INFINITI	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	TRUNK OPEN SET
INFINITI	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Retained PWR Set
INFINITI	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Security Alarm Set(Siren)
INFINITI	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Automatic Door Unlock Select
INFINITI	All Mode	Up to 2016	BCM (Body Control Module)	Special Function	Automatic Lock/Unlock Set
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Read Fault Code	
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Clear Fault Code	
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Read Data Stream	
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Read Freeze Frame	
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Module Information	
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Door Lock
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Super Lock
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	REAR DOOR UNLOCK TEST
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Door Lock Ind
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Rear Defogger
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	IGN KEY WARN ALM
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Seat Belt Warn Test
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Key Reminder Warn
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	ID REGIST WARNING
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Light Warn Alm
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Reverse Warning
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	RUN FLAT/T WARN BUZZER
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Step Lamp Test
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Int Lamp
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	LUGGAGE LAMP TEST
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Tail Lamp
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Head Lamp
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	FR FOG Lamp
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	RR FOG Lamp
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Daytime Running Light
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Cornering Lamp
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	ILL DIM Signal
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	FR Wiper
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Head Lamp Washer
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	RR Wiper
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Flasher
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	SIREN
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Theft IND
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	PW REMOTO DOWN SET
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Battery Saver
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Outside Buzzer
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Inside Buzzer
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Indicator
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	LCD
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Horn
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	P Range
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Engine SW Illumi
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Lock Indicator
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	ACC Indicator
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Ignition ON IND
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Key Slot Illumi
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Trunk/Back Door
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	KEYLESS PW UP/DOWN
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Trunk/Glass Hatch
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Vehicle Security Horn
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Head Lamp(HI)
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	OIL Pressure SW
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	Warning Lamp
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Actuation Test	RUN FLAT TIER W/L
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	D/LOCK VHCL SPD AJT
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Door Lock-Unlock Set
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Set I/L D-Unlock Intcon
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Room Lamp Timer Set
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Room Lamp On Time Set
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Room Lamp BAT SAV SET

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Room Lamp Off Time Set
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	R Lamp Timer Logic Set
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Room Lamp On At Lock
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Battery Saver Set
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Custom A/Light Setting
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	ILL Delay Set
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Wiper Speed Setting
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	HAZARD LAMP SET
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Hazard Answer Back
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Reset Setting Value
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Security Alarm SET
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Theft ALM TRG
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	SIREN SET
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Retained PWR Set
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	REMO CONT ID CONFIR
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Welcome Light Op Set
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Lock/Unlock By I-Key
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Engine Start By I-Key
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Trunk/Glass Hatch Open
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Answer Back Function
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Panic Alarm Set
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Take Out From Win Warn
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Pw Down Set
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Trunk Open Delay
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	LO-BATT OF KEY FOB WARN
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Keyless Function
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Anti Key Lock In Function
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Ans Back I-Key Lock
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Ans Back I-Key Unlock
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Short Cranking Output
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Inside ANT Diagnosis
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Horn With Keyless Lock
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Welcome Light Select
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Confirm Dongle ID
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Automatic Door Lock Select
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	HORN CHIRP SET
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Auto Lock Set
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Automatic Door Unlock Select
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Automatic Door Lock/Unlock Select
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	ID REGIST
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	ID READ
INFINITI	All Mode	Up to 2017	BCM (Body Control Module)	Special Function	Confirm Key Fob ID
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Read Fault Code	
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Clear Fault Code	
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Read Data Stream	
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Module Information	
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	Rear Defogger
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	IGN KEY WARN ALM
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	Light Warn Alm
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	Seat Belt Warn Test
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	Tail Lamp
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	Head Lamp
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	FR FOG Lamp
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	Daytime Running Light
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	CARGO Lamp
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	Cornering Lamp
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	RR Wiper
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	FR Wiper
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	Head Lamp Washer
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	Flasher
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	Trunk/Back Door
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	A/C Indicator
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	Theft IND
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	OIL Pressure SW
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	FUEL LID OPEN
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	Warning Lamp
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	ID REGIST WARNING
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	FLAT TIRE WARNING
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	Horn
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	RUN FLAT TIRE W/L
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Special Function	Automatic Door Lock Select
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Special Function	Automatic Door Unlock Select
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Special Function	Automatic Door Lock/Unlock Select
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Special Function	Battery Saver Set
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Special Function	Custom A/Light Setting
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Special Function	ILL Delay Set



**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

<b>make</b>	<b>model</b>	<b>year</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Special Function	Wiper Speed Setting
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Special Function	Reset Setting Value
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Special Function	ID REGIST
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Special Function	ID READ
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Read Fault Code	
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Clear Fault Code	
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Read Data Stream	
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Module Information	
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Door Lock
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Step Lamp Test
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Int Lamp
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Tail Lamp
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Head Lamp
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	FR FOG Lamp
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	RR FOG Lamp
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Daytime Running Light
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	ILL DIM Signal
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	FR Wiper
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Head Lamp Washer
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Flasher
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Theft IND
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Battery Saver
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Trunk/Glass Hatch
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Vehicle Security Horn
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Head Lamp(HI)
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	OIL Pressure SW
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Rear Defogger
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	IGN KEY WARN ALM
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Light Warn Alm
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Reverse Warning
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Seat Belt Warn Test
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Horn
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	POWER WINDOW DOWN
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Cornering Lamp
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	RR Wiper
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	PBD
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Power Slide Door
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	A/C Indicator
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Set 1/L D-Unlck Intcon
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Room Lamp Timer Set
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Room Lamp On Time Set
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Room Lamp Off Time Set
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	R Lamp Timer Logic Set
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Room Lamp On At Lock
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Battery Saver Set
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Custom A/Light Setting
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	ILL Delay Set
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Wiper Speed Setting
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Reset Setting Value
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Security Alarm SET
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Theft ALM TRG
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Room Lamp BAT SAV SET
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	REMO CONT ID ERASUR
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	REMO CONT ID REGIST
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	REMO CONT ID CONFIR
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	HAZARD LAMP SET
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Auto Lock Set
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	TRUNK OPEN SET
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Panic Alarm Set
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Read Fault Code	
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Clear Fault Code	
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Read Data Stream	
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Module Information	
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Door Lock
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Int Lamp
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Super Lock
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Door Lock Ind
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Step Lamp Test
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Tail Lamp
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Head Lamp
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	FR FOG Lamp
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	RR FOG Lamp
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Daytime Running Light
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	ILL DIM Signal
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	FR Wiper
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	RR Wiper
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Head Lamp Washer
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Flasher
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Theft IND
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Trunk/Glass Hatch

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Vehicle Security Horn
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	OIL Pressure SW
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Rear Defogger
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	IGN KEY WARN ALM
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Light Warn Alm
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Reverse Warning
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Seat Belt Warn Test
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Key Reminder Warn
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	A/C Indicator
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Battery Saver
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	PTC HEATER
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Head Lamp(HI)
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Security Door Lock Set
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Set R-DEF Timer
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Set I/L D-Unlock Intcon
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Room Lamp Timer Set
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Room Lamp On Time Set
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Room Lamp Off Time Set
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	R Lamp Timer Logic Set
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Room Lamp On At Lock
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Custom A/Light Setting
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	ILL Delay Set
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Head Light Timer
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Wiper Speed Setting
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Headlamp Washer Auto Set
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Reset Setting Value
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Security Alarm SET
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Theft ALM TRG
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	REMO CONT ID CONFIR
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	HAZARD LAMP SET
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Auto Lock Set
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	TRUNK OPEN SET
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Read Fault Code	
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Clear Fault Code	
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Read Data Stream	
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Module Information	
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Door Lock
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Int Lamp
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Step Lamp Test
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Tail Lamp
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Head Lamp
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	FR FOG Lamp
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	RR FOG Lamp
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	ILL DIM Signal
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Cornering Lamp
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	FR Wiper
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Head Lamp Washer
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	RR Wiper
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Flasher
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Theft IND
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Trunk/Glass Hatch
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Vehicle Security Horn
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	OIL Pressure SW
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Rear Defogger
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	IGN KEY WARN ALM
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Light Warn Alm
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	A/C Indicator
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Battery Saver
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Set I/L D-Unlock Intcon
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Room Lamp Timer Set
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Room Lamp On Time Set
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Room Lamp Off Time Set
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	R Lamp Timer Logic Set
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Battery Saver Set
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Custom A/Light Setting
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Wiper Speed Setting
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Reset Setting Value
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Room Lamp BAT SAV SET
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	REMO CONT ID ERASUR
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	REMO CONT ID REGIST
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	REMO CONT ID CONFIR
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	TRUNK OPEN SET
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Panic Alarm Set
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Security Alarm SET
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Theft ALM TRG
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Read Fault Code	
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Clear Fault Code	
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Read Data Stream	
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Read Freeze Frame	
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Module Information	

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Door Lock
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Int Lamp
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Tail Lamp
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Head Lamp
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	FR FOG Lamp
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	RR FOG Lamp
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	ILL DIM Signal
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	FR Wiper
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	RR Wiper
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Flasher
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Theft IND
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Trunk/Glass Hatch
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	PBD
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Power Slide Door
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Vehicle Security Horn
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	OIL Pressure SW
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Rear Defogger
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	IGN KEY WARN ALM
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Light Warn Alm
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Reverse Warning
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Seat Belt Warn Test
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	A/C Indicator
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Set I/L D-Unlck Intcon
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Room Lamp Timer Set
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Room Lamp On Time Set
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Room Lamp Off Time Set
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	R Lamp Timer Logic Set
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Room Lamp On At Lock
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Battery Saver Set
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Custom A/Light Setting
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	ILL Delay Set
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Wiper Speed Setting
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Reset Setting Value
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Security Alarm SET
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Theft ALM TRG
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Retained PWR Set
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Room Lamp BAT SAV SET
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	REMO CONT ID ERASUR
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	REMO CONT ID REGIST
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	REMO CONT ID CONFIR
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	HAZARD LAMP SET
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	TRUNK OPEN SET
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Panic Alarm Set
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Read Fault Code	
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Clear Fault Code	
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Read Data Stream	
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Module Information	
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Door Lock
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Door Lock Ind
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Super Lock
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Rear Defogger
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	IGN KEY WARN ALM
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Light Warn Alm
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Key Reminder Warn
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Int Lamp
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Tail Lamp
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Head Lamp
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	FR FOG Lamp
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	RR FOG Lamp
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	FR Wiper
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	RR Wiper
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Head Lamp Washer
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Flasher
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	A/C Indicator
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Theft IND
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	OIL Pressure SW
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Battery Saver
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Vehicle Security Horn
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Custom A/Light Setting
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Head Light Timer
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Wiper Speed Setting
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Reset Setting Value
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Security Door Lock Set
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Set I/L D-Unlck Intcon
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Room Lamp On Time Set
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Room Lamp Off Time Set
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Room Lamp Timer Set
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	HAZARD LAMP SET
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	REMO CONT ID ERASUR
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	REMO CONT ID REGIST

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Security Alarm SET
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Theft ALM TRG
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Auto Lock Set
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Read Fault Code	
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Clear Fault Code	
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Read Data Stream	
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Module Information	
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Light Warn Alm
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	IGN KEY WARN ALM
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Key Reminder Warn
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Theft IND
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Reset Setting Value
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Read Fault Code	
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Clear Fault Code	
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Read Data Stream	
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Module Information	
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	Door Lock
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	Rear Defogger
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	Seat Belt Warn Test
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	Light Warn Alm
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	IGN KEY WARN ALM
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	IGN Illum
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	Int Lamp
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	Step Lamp Test
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	LUGGAGE LAMP TEST
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	Tail Lamp
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	Head Lamp
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	FR FOG Lamp
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	RR FOG Lamp
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	Daytime Running Light
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	CARGO Lamp
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	Cornering Lamp
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	FR Wiper
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	RR Wiper
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	Head Lamp Washer
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	RISE UP WIPER TEST
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	Flasher
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	A/C Indicator
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	Theft IND
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	Battery Saver
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	Trunk/Back Door
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	Vehicle Security Horn
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	Head Lamp(HI)
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	Retained PWR
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	OIL Pressure SW
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	BRAKE SW
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	PW REMOTO DOWN SET
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	Horn
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	PSD PBD OPEN TEST
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	FUEL LID OPEN
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	Warning Lamp
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	ID REGIST WARNING
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	FLAT TIRE WARNING
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	RUN FLAT TIRE W/L
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Actuation Test	PANIC ALARM
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Special Function	Door Lock-Unlock Set
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Special Function	ANTI-LOCK OUT SET
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Special Function	Automatic Door Lock Select
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Special Function	Automatic Door Unlock Select
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Special Function	Automatic Door Lock/Unlock Select
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Special Function	Battery Saver Set
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Special Function	Custom A/Light Setting
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Special Function	ILL Delay Set
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Special Function	Wiper Speed Setting
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Special Function	Reset Setting Value
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Special Function	ID READ
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Special Function	ID REGIST
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Special Function	Set I/L D-Unlock Intcon
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Special Function	Room Lamp On Time Set
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Special Function	Room Lamp Off Time Set
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Special Function	Room Lamp Timer Set
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Special Function	Retained PWR Set
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Special Function	HORN CHIRP SET
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Special Function	HAZARD LAMP SET
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Special Function	MULTI ANSWER BACK SET
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Special Function	Auto Lock Set
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Special Function	Panic Alarm Set
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Special Function	TRUNK OPEN SET

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Special Function	Pw Down Set
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Special Function	REMO CONT ID REGIST
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Special Function	REMO CONT ID ERASUR
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Special Function	REMO CONT ID CONFIR
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Special Function	Security Alarm SET
INFINITI	All Mode	Up to 2010	BCM (Body Control Module)	Special Function	Theft ALM TRG
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Read Fault Code	
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Clear Fault Code	
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Read Data Stream	
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Module Information	
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Door Lock
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Rear Defogger
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Seat Belt Warn Test
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Light Warn Alm
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	IGN KEY WARN ALM
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	IGN Illum
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Int Lamp
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Step Lamp Test
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	LUGGAGE LAMP TEST
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Tail Lamp
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Head Lamp
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	FR FOG Lamp
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	RR FOG Lamp
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Daytime Running Light
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Cornering Lamp
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	FR Wiper
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	RR Wiper
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Head Lamp Washer
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	RISE UP WIPER TEST
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Flasher
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	A/C Indicator
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Theft IND
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Battery Saver
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Trunk/Back Door
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Vehicle Security Horn
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Head Lamp(HI)
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Retained PWR
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	OIL Pressure SW
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	PW REMOTO DOWN SET
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Horn
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	PSD PBD OPEN TEST
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	FUEL LID OPEN
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	PANIC ALARM
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Door Lock-Unlock Set
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	ANTI-LOCK OUT SET
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Set I/L D-Unlock Intcon
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Room Lamp On Time Set
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Room Lamp Off Time Set
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Battery Saver Set
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Custom A/Light Setting
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	ILL Delay Set
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Wiper Speed Setting
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Room Lamp Timer Set
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Security Alarm SET
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Retained PWR Set
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	HORN CHIRP SET
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	HAZARD LAMP SET
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	MULTI ANSWER BACK SET
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Auto Lock Set
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Panic Alarm Set
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	TRUNK OPEN SET
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Pw Down Set
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	REMO CONT ID REGIST
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	REMO CONT ID ERASUR
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	REMO CONT ID CONFIR
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Reset Setting Value
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Read Fault Code	
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Clear Fault Code	
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Read Data Stream	
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Module Information	
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Door Lock
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Flasher
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Power Slide Door
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Inside Buzzer
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	starter cut relay
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Indicator
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Theft IND
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Reset Setting Value
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Read Fault Code	
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Clear Fault Code	

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Read Data Stream	
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Module Information	
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Door Lock (Door Lock)
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Door Lock (Multi Remote Enter)
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Door Lock (Intelligent Key)
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Rear Defogger
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	IGN KEY WARN ALM
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Light Warn Alm
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Reverse Warning
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	INT LAMP (INT LAMP)
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	INT LAMP (MULTI REMOTE ENTER)
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	INT LAMP (INTELLIGENT KEY)
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Tail Lamp
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Head Lamp
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	FR FOG Lamp
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	FR Wiper
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Head Lamp Washer
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	RR Wiper
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Flasher (Multi Remote Enter, Flasher)
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Flasher (Intelligent Key)
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Trunk/Back Door
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Battery Saver Set
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Custom A/Light Setting
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	REMO CONT ID ERASUR
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Read Fault Code	
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Clear Fault Code	
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Read Data Stream	
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Module Information	
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	SET R/DEF -ENG INTCON
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Set I/L D-Unlck Intcon
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Room Lamp Timer Set
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Custom A/Light Setting
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Wiper Speed Setting
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Switch Monitor
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	ST ANG Sen Adjustment
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Read Fault Code	
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Clear Fault Code	
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Read Data Stream	
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Module Information	
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Auto RE-Lock
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Selective Unlock
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Trunk Open Delay
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Audible Trailer Warning
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Keyless Registration
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Keyless Check
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Keyless DI Flash
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	THEFT WARNING
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Lastest Alarm Trigger
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	PRE-ARM Fast Flash
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Siren Fitted
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Previous Alarm Trigger
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Oldest Alarm Trigger
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Read Fault Code	
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Clear Fault Code	
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Read Data Stream	
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Module Information	
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Door Lock (Door Lock)
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Door Lock Ind
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Super Lock
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	BACK/TRNK LCK RLY
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	BACK/TRNK UNLOCK
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Rear Defogger
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Light Warn Alm
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Key Reminder Warn
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	BACK DR OPEN WARN
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	DOOR WARNING IND
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Int Lamp
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Tail Lamp
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Head Lamp
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	FR FOG Lamp
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	RR FOG Lamp
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	FR Wiper
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Head Lamp Washer
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	RR Wiper
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Flasher
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Theft IND
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	PTC HEATER

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	DR FR WINDOW
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	AS FR WINDOW
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	DR RR WINDOW
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	AS RR WINDOW
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	TRUNK
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Parcel Shelf
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	VALVE
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	HYDRAULIC MOTOR
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Roof
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Battery Saver Set
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Security Door Lock Set
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Auto Lock Set
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Custom A/Light Setting
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	RR WIP RVRS SET
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	HAZARD LAMP SET
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Security Alarm SET
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Headlamp Washer Auto Set
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Read Fault Code	
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Clear Fault Code	
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Read Data Stream	
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Module Information	
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Door Lock
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Rear Defogger
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	IGN KEY WARN ALM
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Light Warn Alm
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Reverse Warning
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Seat Belt Warn Test
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Int Lamp
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Tail Lamp
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Head Lamp
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Head Lamp(HT)
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	PANIC ALARM
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	FR FOG Lamp
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	RR FOG Lamp
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Cornering Lamp
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	ILL DIM Signal
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	FR Wiper
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	RR Wiper
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Head Lamp Washer
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Flasher
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Trunk/Glass Hatch
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Theft IND
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	OIL Pressure SW
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	GLASS HATCH
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Trunk/Back Door
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Power Slide Door
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	A/C Indicator
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Inside Buzzer
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	starter cut relay
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Indicator
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Battery Saver Set
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Custom A/Light Setting
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Set I/L D-Unlck Intcon
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Room Lamp On Time Set
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Room Lamp Off Time Set
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Room Lamp BAT SAV SET
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Room Lamp Timer Set
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Wiper Speed Setting
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Reset Setting Value
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	REMO CONT ID REGIST
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	REMO CONT ID ERASUR
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	REMO CONT ID CONFIR
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	HAZARD LAMP SET
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Auto Lock Set
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Panic Alarm Set
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	TRUNK OPEN SET
INFINITI	All Mode	Up to 2018	BCM (Body Control Module)	Read Fault Code	
INFINITI	All Mode	Up to 2018	BCM (Body Control Module)	Clear Fault Code	
INFINITI	All Mode	Up to 2018	BCM (Body Control Module)	Read Data Stream	
INFINITI	All Mode	Up to 2018	BCM (Body Control Module)	Module Information	
INFINITI	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	Door Lock
INFINITI	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	Door Lock Ind
INFINITI	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	Super Lock
INFINITI	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	Rear Defogger
INFINITI	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	Seat Belt Warn Test
INFINITI	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	Light Warn Alm
INFINITI	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	Reverse Warning
INFINITI	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	Key Reminder Warn
INFINITI	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	ID REGIST WARNING
INFINITI	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	RUN FLAT/T WARN BUZZER

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
INFINITI	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	Int Lamp
INFINITI	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	Step Lamp Test
INFINITI	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	Battery Saver
INFINITI	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	FR Wiper
INFINITI	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	RR Wiper
INFINITI	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	Head Lamp Washer
INFINITI	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	Flasher
INFINITI	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	Theft IND
INFINITI	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	FR FOG Lamp
INFINITI	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	RR FOG Lamp
INFINITI	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	Daytime Running Light
INFINITI	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	ILL DIM Signal
INFINITI	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	OIL Pressure SW
INFINITI	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	BRAKE SW
INFINITI	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	Vehicle Security Horn
INFINITI	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	Head Lamp(HI)
INFINITI	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	SIREN
INFINITI	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	Horn
INFINITI	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	Warning Lamp
INFINITI	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	RUN FLAT TIRE W/L
INFINITI	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	Intelligent Key Link(CAN)
INFINITI	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	Retractable Mirror
INFINITI	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	Trunk/Back Door
INFINITI	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	Outside Buzzer
INFINITI	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	Inside Buzzer
INFINITI	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	Indicator
INFINITI	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	IGN CONT2
INFINITI	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	MIRROR+5
INFINITI	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	Engine SW Illumi
INFINITI	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	Push Switch Indicator
INFINITI	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	ACC CONT
INFINITI	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	ING CONT1
INFINITI	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	ST CONT LOW
INFINITI	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	SL 12V CPU
INFINITI	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	IGNITION RELAY
INFINITI	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	REVERSE LAMP TEST
INFINITI	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	DOOR HANDLE LAMP TEST
INFINITI	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	DR SEAT LAMP TEST
INFINITI	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	AS SEAT LAMP TEST
INFINITI	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	SHIFT SPOT LAMP TEST
INFINITI	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	Trunk/Luggage Lamp Test
INFINITI	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	KEYFOB P/W TEST
INFINITI	All Mode	Up to 2018	BCM (Body Control Module)	Actuation Test	SHIFTLOCK SORENOID TEST
INFINITI	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Signature Light Setting
INFINITI	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Door Lock-Unlock Set
INFINITI	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Auto Unlock Type
INFINITI	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Auto Lock Function
INFINITI	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Auto Unlock Function
INFINITI	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Set R-DEF Timer
INFINITI	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Scenario Lighting Setting
INFINITI	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Set I/L D-Unlock Intcon
INFINITI	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	FOG Lamp Override
INFINITI	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Rear Wiper Link With Reverse Setting
INFINITI	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Rain Sensor
INFINITI	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	FR RR DRIP
INFINITI	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Wiper Speed Setting
INFINITI	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	3-TIME Flasher Setting
INFINITI	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Confirm Dongle ID
INFINITI	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Daytime Running Light Setting
INFINITI	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Twilight On
INFINITI	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Wiper Link
INFINITI	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Custom A/Light Setting
INFINITI	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	ILL Delay Set
INFINITI	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Security Alarm SET
INFINITI	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	SIREN SET
INFINITI	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	ID READ
INFINITI	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	ID REGIST
INFINITI	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Touch Sensor Unlock Function Setting
INFINITI	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	IGN/ACC Battery Saver
INFINITI	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Remote Engine Starter
INFINITI	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Answer Back I-Key Lock Unlock
INFINITI	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Answerback I-Key Lock Unlock
INFINITI	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Answerback Keyless Lock Unlock
INFINITI	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Welcome Light Op Set



**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
INFINITI	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Answer Back
INFINITI	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Retractable Mirror Set
INFINITI	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Confirm Key Fob ID
INFINITI	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Lock/Unlock By I-Key
INFINITI	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Engine Start By I-Key
INFINITI	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Trunk/Glass Hatch Open
INFINITI	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Intelligent Key Link Set
INFINITI	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Short Cranking Output
INFINITI	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Auto Lock Set
INFINITI	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Inside ANT Diagnosis
INFINITI	All Mode	Up to 2018	BCM (Body Control Module)	Special Function	Reset Setting Value
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Read Fault Code	
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Clear Fault Code	
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Read Data Stream	
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Module Information	
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Rear Defogger
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Int Lamp
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Battery Saver
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Vehicle Security Horn
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Tail Lamp
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	FR FOG Lamp
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	ILL DIM Signal
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Head Lamp
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Cornering Lamp
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Head Lamp Washer
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	FR Wiper
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Door Lock
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Flasher
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Theft IND
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	BRAKE SW
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	OIL Pressure SW
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Trunk/Glass Hatch
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	IGN KEY WARN ALM
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Light Warn Alm
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	PANIC ALARM
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Set R-DEF Timer
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Set I/L D-Unlock Intcon
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Room Lamp On Time Set
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Room Lamp Off Time Set
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Room Lamp Timer Set
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Room Lamp BAT SAV SET
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Security Alarm Set(Siren)
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Battery Saver Set
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Custom A/Light Setting
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Wiper Speed Setting
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	REMO CONT ID REGIST
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	REMO CONT ID ERASUR
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Auto Lock Set
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Panic Alarm Set
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	TRUNK OPEN SET
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Reset Setting Value
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Automatic Door Unlock Select
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Read Fault Code	
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Clear Fault Code	
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Read Data Stream	
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Module Information	
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Door Lock
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Super Lock
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Door Lock Ind
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Rear Defogger
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	IGN KEY WARN ALM
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Seat Belt Warn Test
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	ID REGIST WARNING
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Light Warn Alm
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Reverse Warning
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	RUN FLAT/T WARN BUZZER
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Key Reminder Warn
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	FR FOG Lamp
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	RR FOG Lamp
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	STOP LAMP 1
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	STOP LAMP 2
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	STOP LAMP 3
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Daytime Running Light
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	ILL DIM Signal
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Int Lamp
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	FR Wiper
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	RR Wiper
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Head Lamp Washer
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	PTC RELAY-1

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	PTC RELAY-2
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	PTC RELAY-3
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	A/C Indicator
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Outside Buzzer
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Inside Buzzer
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	INDICATOR
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Flasher
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Horn
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	IGN CONT-2
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	MIRROR+5
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Engine SW Illumi
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Push Switch Indicator
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	ENGINE START REQUEST
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	IGNITION RELAY
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	starter cut relay
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	ENGINE START
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Trunk/Back Door
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Retractable Mirror
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	REVERSE LAMP TEST
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	AS SEAT LAMP TEST
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	KEYFOB P/W TEST
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	AUTO ACC 2
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	AUTOMATIC BACK DOOR
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	AUTO ACC 1
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Trunk/Luggage Lamp Test
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Theft IND
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Battery Saver
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	SIREN
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Vehicle Security Horn
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Head Lamp
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	OIL Pressure SW
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	BRAKE SW
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Actuation Test	Warning Lamp
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Door Lock-Unlock Set
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Auto Unlock Type
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Auto Lock Function
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Auto Unlock Function
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Signature Light Setting
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Set R-DEF Timer
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Custom A/Light Setting
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	ILL Delay Set
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Twilight On
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Wiper Link
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Daytime Running Light Setting
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Set I/L D-Unlck Intcon
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	FOG Lamp Override
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Spicy Brightness Setting
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Wiper Speed Setting
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Rain Sensor
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	FR RR DRIP
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Rear Wiper Link With Reverse Setting
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	3-TIME Flasher Setting
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Inside ANT Diagnosis
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Lock/Unlock By I-Key
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Engine Start By I-Key
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Trunk/Glass Hatch Open
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Auto Lock Set
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	IGN/ACC Battery Saver
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Short Cranking Output
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Answer Back
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Answer Back I-Key Lock Unlock
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Answerback I-Key Lock Unlock
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Answerback Keyless Lock Unlock
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Welcome Light Op Set
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Reset Setting Value
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Confirm Dongle ID
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	SIREN SET
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Security Alarm SET
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Auto Acc Fnctn (Audio/Navt Set After Ign Off)
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Autofold function
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Theft ALM TRG
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Confirm TCU ID
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Remote Engine Starter

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

<b>make</b>	<b>model</b>	<b>year</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Touch Sensor Unlock Function Setting
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	Intelligent Key Link Set
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	(TBD)ShBW_ID_REGISTRATION FINISHED
INFINITI	All Mode	2015 - 2018	BCM (Body Control Module)	Read Fault Code	
INFINITI	All Mode	2015 - 2018	BCM (Body Control Module)	Clear Fault Code	
INFINITI	All Mode	2015 - 2018	BCM (Body Control Module)	Read Data Stream	
INFINITI	All Mode	2015 - 2018	BCM (Body Control Module)	Module Information	
INFINITI	All Mode	2015 - 2018	BCM (Body Control Module)	Actuation Test	Check left front turn signal lamp
INFINITI	All Mode	2015 - 2018	BCM (Body Control Module)	Actuation Test	Check eco start stop function additional battery relay
INFINITI	All Mode	2015 - 2018	BCM (Body Control Module)	Actuation Test	Check right front turn signal lamp
INFINITI	All Mode	2015 - 2018	BCM (Body Control Module)	Actuation Test	Check right rear turn signal lamp
INFINITI	All Mode	2015 - 2018	BCM (Body Control Module)	Actuation Test	Check left rear turn signal lamp
INFINITI	All Mode	2015 - 2018	BCM (Body Control Module)	Actuation Test	Check Right Daytime Running Light Headlamp
INFINITI	All Mode	2015 - 2018	BCM (Body Control Module)	Actuation Test	Check Left Daytime Running Light Headlamp
INFINITI	All Mode	2015 - 2018	BCM (Body Control Module)	Actuation Test	Left front lamp unit
INFINITI	All Mode	2015 - 2018	BCM (Body Control Module)	Actuation Test	Centre brake lamp
INFINITI	All Mode	2015 - 2018	BCM (Body Control Module)	Actuation Test	License Plate Lamp
INFINITI	All Mode	2015 - 2018	BCM (Body Control Module)	Actuation Test	Left rear fog lamp
INFINITI	All Mode	2015 - 2018	BCM (Body Control Module)	Actuation Test	Windshield washer system pump
INFINITI	All Mode	2015 - 2018	BCM (Body Control Module)	Actuation Test	Headlamp clean system pump
INFINITI	All Mode	2015 - 2018	BCM (Body Control Module)	Actuation Test	Tank cap central locking actuator
INFINITI	All Mode	2015 - 2018	BCM (Body Control Module)	Actuation Test	Side marker lamp
INFINITI	All Mode	2015 - 2018	BCM (Body Control Module)	Actuation Test	Inner left rear lamp unit
INFINITI	All Mode	2015 - 2018	BCM (Body Control Module)	Actuation Test	Left rear power window
INFINITI	All Mode	2015 - 2018	BCM (Body Control Module)	Actuation Test	Right rear lamp unit
INFINITI	All Mode	2015 - 2018	BCM (Body Control Module)	Actuation Test	Front turn signal lamp
INFINITI	All Mode	2015 - 2018	BCM (Body Control Module)	Actuation Test	Erase alarm sources
INFINITI	All Mode	2015 - 2018	BCM (Body Control Module)	Actuation Test	Circuit 30G Relay
INFINITI	All Mode	2015 - 2018	BCM (Body Control Module)	Actuation Test	Rear fuse box
INFINITI	All Mode	2015 - 2018	BCM (Body Control Module)	Actuation Test	Engine compartment fuse and relay module
INFINITI	All Mode	2015 - 2018	BCM (Body Control Module)	Actuation Test	Symbol illumination
INFINITI	All Mode	2015 - 2018	BCM (Body Control Module)	Actuation Test	Activate demo mode of exterior lamp
INFINITI	All Mode	2015 - 2018	BCM (Body Control Module)	Actuation Test	Rear Doors
INFINITI	All Mode	2015 - 2018	BCM (Body Control Module)	Actuation Test	Liftgate central locking motor
INFINITI	All Mode	2015 - 2018	BCM (Body Control Module)	Actuation Test	Right rear power window
INFINITI	All Mode	2015 - 2018	BCM (Body Control Module)	Actuation Test	Running board courtesy light
INFINITI	All Mode	2015 - 2018	BCM (Body Control Module)	Actuation Test	Illuminated door sill moldings
INFINITI	All Mode	2015 - 2018	BCM (Body Control Module)	Actuation Test	Right front lamp unit
INFINITI	All Mode	2015 - 2018	BCM (Body Control Module)	Actuation Test	Left rear lamp unit
INFINITI	All Mode	2015 - 2018	BCM (Body Control Module)	Actuation Test	Footwell lamp
INFINITI	All Mode	2015 - 2018	BCM (Body Control Module)	Actuation Test	Back-Up Lamp
INFINITI	All Mode	2015 - 2018	BCM (Body Control Module)	Actuation Test	Trunk Lamp
INFINITI	All Mode	2015 - 2018	BCM (Body Control Module)	Actuation Test	Spray nozzle hose heater
INFINITI	All Mode	2015 - 2018	BCM (Body Control Module)	Actuation Test	Inner right rear lamp unit
INFINITI	All Mode	2015 - 2018	BCM (Body Control Module)	Actuation Test	Daytime Running Light
INFINITI	All Mode	2015 - 2018	BCM (Body Control Module)	Actuation Test	Windscreen Wiper
INFINITI	All Mode	2015 - 2018	BCM (Body Control Module)	Actuation Test	Last data record
INFINITI	All Mode	2015 - 2018	BCM (Body Control Module)	Actuation Test	Second from last data record
INFINITI	All Mode	2015 - 2018	BCM (Body Control Module)	Actuation Test	Third from last data record
INFINITI	All Mode	2015 - 2018	BCM (Body Control Module)	Actuation Test	Fourth from last data record
INFINITI	All Mode	2015 - 2018	BCM (Body Control Module)	Actuation Test	Fifth from last data record
INFINITI	All Mode	2015 - 2018	BCM (Body Control Module)	Actuation Test	Sixth to last data record
INFINITI	All Mode	2015 - 2018	BCM (Body Control Module)	Actuation Test	Seventh to last data record
INFINITI	All Mode	2015 - 2018	BCM (Body Control Module)	Actuation Test	Eighth to last data record
INFINITI	All Mode	2015 - 2018	BCM (Body Control Module)	Actuation Test	Ninth to last data record
INFINITI	All Mode	2015 - 2018	BCM (Body Control Module)	Actuation Test	Tenth to last data record
INFINITI	All Mode	2015 - 2018	BCM (Body Control Module)	Actuation Test	Front fog lamp
INFINITI	All Mode	2015 - 2018	BCM (Body Control Module)	Actuation Test	Door handle illumination rear doors
INFINITI	All Mode	2015 - 2018	BCM (Body Control Module)	Actuation Test	Ambiance illumination of rear door

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
INFINITI	All Mode	2015 - 2018	BCM (Body Control Module)	Actuation Test	Interior lamp
INFINITI	All Mode	2015 - 2018	BCM (Body Control Module)	Actuation Test	Mirror lamps of sun visors
INFINITI	All Mode	2015 - 2018	BCM (Body Control Module)	Actuation Test	Reading lamp actuation
INFINITI	All Mode	2015 - 2018	BCM (Body Control Module)	Actuation Test	Rear lamp actuation
INFINITI	All Mode	2015 - 2018	BCM (Body Control Module)	Actuation Test	Check component M10 5 RL door power window motor
INFINITI	All Mode	2015 - 2018	BCM (Body Control Module)	Actuation Test	Check component M10 6 RR door power window motor
INFINITI	All Mode	2015 - 2018	BCM (Body Control Module)	Actuation Test	Left rear power window actual value
INFINITI	All Mode	2015 - 2018	BCM (Body Control Module)	Actuation Test	Right rear power window actual value
INFINITI	All Mode	2015 - 2018	BCM (Body Control Module)	Actuation Test	Confirmation of battery change
INFINITI	All Mode	2015 - 2018	BCM (Body Control Module)	Special Function	Replace decoupling relay
INFINITI	All Mode	2015 - 2018	BCM (Body Control Module)	Special Function	Replace eco start stop function add battery
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Read Fault Code	
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Clear Fault Code	
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Read Data Stream	
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Module Information	
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	REMO CONT ID CONFIR
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	REMO CONT ID REGIST
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	REMO CONT ID ERASUR
INFINITI	All Mode	Up to 2008	BCM (Body Control Module)	Special Function	
INFINITI	All Mode	Up to 2017	4WAS(MAIN)/RAS/HICAS	Read Fault Code	
INFINITI	All Mode	Up to 2017	4WAS(MAIN)/RAS/HICAS	Clear Fault Code	
INFINITI	All Mode	Up to 2017	4WAS(MAIN)/RAS/HICAS	Read Data Stream	
INFINITI	All Mode	Up to 2017	4WAS(MAIN)/RAS/HICAS	Module Information	
INFINITI	All Mode	Up to 2017	4WAS(MAIN)/RAS/HICAS	Actuation Test	SELF DIAGNOSTIC MODE
INFINITI	All Mode	2007 - 2017	4WAS(MAIN)/RAS/HICAS	Read Fault Code	
INFINITI	All Mode	2007 - 2017	4WAS(MAIN)/RAS/HICAS	Clear Fault Code	
INFINITI	All Mode	2007 - 2017	4WAS(MAIN)/RAS/HICAS	Read Data Stream	
INFINITI	All Mode	2007 - 2017	4WAS(MAIN)/RAS/HICAS	Module Information	
INFINITI	All Mode	2007 - 2017	4WAS(MAIN)/RAS/HICAS	Actuation Test	SELF DIAGNOSTIC MODE
INFINITI	All Mode	2009 - 2017	4WAS(MAIN)/RAS/HICAS	Read Fault Code	
INFINITI	All Mode	2009 - 2017	4WAS(MAIN)/RAS/HICAS	Clear Fault Code	
INFINITI	All Mode	2009 - 2017	4WAS(MAIN)/RAS/HICAS	Read Data Stream	
INFINITI	All Mode	2009 - 2017	4WAS(MAIN)/RAS/HICAS	Module Information	
INFINITI	All Mode	2009 - 2017	4WAS(MAIN)/RAS/HICAS	Actuation Test	SELF DIAGNOSTIC MODE
INFINITI	All Mode	Up to 2015	4WAS(MAIN)/RAS/HICAS	Read Fault Code	
INFINITI	All Mode	Up to 2015	4WAS(MAIN)/RAS/HICAS	Clear Fault Code	
INFINITI	All Mode	Up to 2015	4WAS(MAIN)/RAS/HICAS	Read Data Stream	
INFINITI	All Mode	Up to 2015	4WAS(MAIN)/RAS/HICAS	Module Information	
INFINITI	All Mode	Up to 2015	4WAS(MAIN)/RAS/HICAS	Actuation Test	
INFINITI	All Mode	Up to 2015	4WAS(MAIN)/RAS/HICAS	Read Fault Code	
INFINITI	All Mode	Up to 2015	4WAS(MAIN)/RAS/HICAS	Clear Fault Code	
INFINITI	All Mode	Up to 2015	4WAS(MAIN)/RAS/HICAS	Read Data Stream	
INFINITI	All Mode	Up to 2015	4WAS(MAIN)/RAS/HICAS	Module Information	
INFINITI	All Mode	Up to 2015	4WAS(MAIN)/RAS/HICAS	Actuation Test	
INFINITI	All Mode	Up to 2017	Sonar	Read Fault Code	
INFINITI	All Mode	Up to 2017	Sonar	Clear Fault Code	
INFINITI	All Mode	Up to 2017	Sonar	Read Data Stream	
INFINITI	All Mode	Up to 2017	Sonar	Read Freeze Frame	
INFINITI	All Mode	Up to 2017	Sonar	Module Information	
INFINITI	All Mode	Up to 2017	Sonar	Actuation Test	BUZZER
INFINITI	All Mode	Up to 2017	Sonar	Actuation Test	CANCEL SW IND
INFINITI	All Mode	Up to 2017	Sonar	Actuation Test	SONAR SENSOR
INFINITI	All Mode	Up to 2017	Sonar	Actuation Test	PSM SONAR SENSOR
INFINITI	All Mode	Up to 2017	Sonar	Actuation Test	DISPLAY CONTROL
INFINITI	All Mode	Up to 2017	Sonar	Special Function	Corner Sen Distance Set
INFINITI	All Mode	Up to 2017	Sonar	Special Function	Center Sen Distance Set
INFINITI	All Mode	Up to 2017	Sonar	Special Function	Volume Setting
INFINITI	All Mode	Up to 2017	Sonar	Special Function	Trailer Hitch Mode
INFINITI	All Mode	Up to 2017	Sonar	Special Function	Parking Width Level Setting
INFINITI	All Mode	Up to 2017	Sonar	Special Function	TIRE DIAMETER ADJUSTMENT
INFINITI	All Mode	Up to 2018	Sonar	Read Fault Code	
INFINITI	All Mode	Up to 2018	Sonar	Clear Fault Code	
INFINITI	All Mode	Up to 2018	Sonar	Read Data Stream	
INFINITI	All Mode	Up to 2018	Sonar	Module Information	
INFINITI	All Mode	Up to 2018	Sonar	Actuation Test	REAR BUZZER
INFINITI	All Mode	Up to 2018	Sonar	Actuation Test	FRONT BUZZER
INFINITI	All Mode	Up to 2018	Sonar	Actuation Test	LED
INFINITI	All Mode	Up to 2018	Sonar	Special Function	Volume Setting

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

<b>make</b>	<b>model</b>	<b>year</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
INFINITI	All Mode	Up to 2018	Sonar	Special Function	Trailer hitch detection range adjustment
INFINITI	All Mode	Up to 2017	Sonar	Read Fault Code	
INFINITI	All Mode	Up to 2017	Sonar	Clear Fault Code	
INFINITI	All Mode	Up to 2017	Sonar	Read Data Stream	
INFINITI	All Mode	Up to 2017	Sonar	Module Information	
INFINITI	All Mode	Up to 2017	Sonar	Actuation Test	REAR BUZZER
INFINITI	All Mode	Up to 2017	Sonar	Actuation Test	LED
INFINITI	All Mode	Up to 2017	Sonar	Actuation Test	FRONT BUZZER
INFINITI	All Mode	Up to 2017	Sonar	Special Function	Volume Setting
INFINITI	All Mode	Up to 2017	Sonar	Special Function	Trailer hitch detection range adjustment
INFINITI	All Mode	Up to 2017	Sonar	Read Fault Code	
INFINITI	All Mode	Up to 2017	Sonar	Clear Fault Code	
INFINITI	All Mode	Up to 2017	Sonar	Read Data Stream	
INFINITI	All Mode	Up to 2017	Sonar	Module Information	
INFINITI	All Mode	Up to 2017	Sonar	Actuation Test	REAR BUZZER
INFINITI	All Mode	Up to 2017	Sonar	Actuation Test	LED
INFINITI	All Mode	Up to 2017	Sonar	Actuation Test	FRONT BUZZER
INFINITI	All Mode	Up to 2017	Sonar	Special Function	Volume Setting
INFINITI	All Mode	Up to 2017	Sonar	Special Function	Trailer hitch detection range adjustment
INFINITI	All Mode	Up to 2017	Sonar	Read Fault Code	
INFINITI	All Mode	Up to 2017	Sonar	Clear Fault Code	
INFINITI	All Mode	Up to 2017	Sonar	Read Data Stream	
INFINITI	All Mode	Up to 2017	Sonar	Module Information	
INFINITI	All Mode	Up to 2017	Sonar	Actuation Test	REAR BUZZER
INFINITI	All Mode	Up to 2017	Sonar	Actuation Test	LED
INFINITI	All Mode	Up to 2017	Sonar	Actuation Test	FRONT BUZZER
INFINITI	All Mode	Up to 2017	Sonar	Special Function	Volume Setting
INFINITI	All Mode	Up to 2017	Sonar	Special Function	Trailer hitch detection range adjustment
INFINITI	All Mode	2017 - 2017	Sonar	Read Fault Code	
INFINITI	All Mode	2017 - 2017	Sonar	Clear Fault Code	
INFINITI	All Mode	2017 - 2017	Sonar	Read Data Stream	
INFINITI	All Mode	2017 - 2017	Sonar	Module Information	
INFINITI	All Mode	2017 - 2017	Sonar	Special Function	Volume Setting
INFINITI	All Mode	Up to 2017	Sonar	Read Fault Code	
INFINITI	All Mode	Up to 2017	Sonar	Clear Fault Code	
INFINITI	All Mode	Up to 2017	Sonar	Read Data Stream	
INFINITI	All Mode	Up to 2017	Sonar	Module Information	
INFINITI	All Mode	Up to 2017	Sonar	Actuation Test	BUZZER
INFINITI	All Mode	Up to 2017	Sonar	Actuation Test	CANCEL SW IND
INFINITI	All Mode	Up to 2017	Sonar	Actuation Test	SONAR SENSOR
INFINITI	All Mode	Up to 2017	Sonar	Special Function	Corner Sen Distance Set
INFINITI	All Mode	Up to 2017	Sonar	Special Function	Volume Setting
INFINITI	All Mode	Up to 2017	Sonar	Special Function	Trailer Hitch Mode
INFINITI	All Mode	Up to 2017	Sonar	Read Fault Code	
INFINITI	All Mode	Up to 2017	Sonar	Clear Fault Code	
INFINITI	All Mode	Up to 2017	Sonar	Read Data Stream	
INFINITI	All Mode	Up to 2017	Sonar	Module Information	
INFINITI	All Mode	Up to 2017	Sonar	Actuation Test	BUZZER
INFINITI	All Mode	Up to 2017	Sonar	Actuation Test	CANCEL SW IND
INFINITI	All Mode	Up to 2017	Sonar	Actuation Test	SONAR SENSOR
INFINITI	All Mode	Up to 2017	Sonar	Special Function	Corner Sen Distance Set
INFINITI	All Mode	Up to 2017	Sonar	Special Function	Center Sen Distance Set
INFINITI	All Mode	Up to 2017	Sonar	Special Function	Volume Setting
INFINITI	All Mode	Up to 2017	Sonar	Special Function	Trailer Hitch Mode
INFINITI	All Mode	2012 - 2017	Sonar	Read Fault Code	
INFINITI	All Mode	2012 - 2017	Sonar	Clear Fault Code	
INFINITI	All Mode	2012 - 2017	Sonar	Read Data Stream	
INFINITI	All Mode	2012 - 2017	Sonar	Module Information	
INFINITI	All Mode	2012 - 2017	Sonar	Actuation Test	BUZZER
INFINITI	All Mode	2012 - 2017	Sonar	Actuation Test	CANCEL SW IND
INFINITI	All Mode	2012 - 2017	Sonar	Actuation Test	SONAR SENSOR
INFINITI	All Mode	2012 - 2017	Sonar	Special Function	Corner Sen Distance Set
INFINITI	All Mode	2012 - 2017	Sonar	Special Function	Center Sen Distance Set
INFINITI	All Mode	2012 - 2017	Sonar	Special Function	Volume Setting
INFINITI	All Mode	2012 - 2017	Sonar	Special Function	Trailer Hitch Mode
INFINITI	All Mode	2008 - 2017	Sonar	Read Fault Code	
INFINITI	All Mode	2008 - 2017	Sonar	Clear Fault Code	
INFINITI	All Mode	2008 - 2017	Sonar	Read Data Stream	
INFINITI	All Mode	2008 - 2017	Sonar	Module Information	
INFINITI	All Mode	2008 - 2017	Sonar	Actuation Test	BUZZER
INFINITI	All Mode	2008 - 2017	Sonar	Actuation Test	CANCEL SW IND
INFINITI	All Mode	2008 - 2017	Sonar	Actuation Test	SONAR SENSOR
INFINITI	All Mode	2008 - 2017	Sonar	Special Function	Corner Sen Distance Set
INFINITI	All Mode	2008 - 2017	Sonar	Special Function	Center Sen Distance Set
INFINITI	All Mode	2008 - 2017	Sonar	Special Function	Volume Setting
INFINITI	All Mode	2008 - 2017	Sonar	Special Function	Trailer Hitch Mode

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
INFINITI	All Mode	Up to 2017	Lane Camera	Read Fault Code	
INFINITI	All Mode	Up to 2017	Lane Camera	Clear Fault Code	
INFINITI	All Mode	Up to 2017	Lane Camera	Read Data Stream	
INFINITI	All Mode	Up to 2017	Lane Camera	Module Information	
INFINITI	All Mode	Up to 2017	Lane Camera	Actuation Test	BUZZER DRIVE
INFINITI	All Mode	Up to 2017	Lane Camera	Actuation Test	SYSTEM ON LAMP DRIVE
INFINITI	All Mode	Up to 2017	Lane Camera	Actuation Test	INDICATOR LAMP DRIVE
INFINITI	All Mode	Up to 2017	Lane Camera	Special Function	AUTO AIM
INFINITI	All Mode	2008 - 2017	Lane Camera	Read Fault Code	
INFINITI	All Mode	2008 - 2017	Lane Camera	Clear Fault Code	
INFINITI	All Mode	2008 - 2017	Lane Camera	Read Data Stream	
INFINITI	All Mode	2008 - 2017	Lane Camera	Module Information	
INFINITI	All Mode	2008 - 2017	Lane Camera	Actuation Test	BUZZER DRIVE
INFINITI	All Mode	2008 - 2017	Lane Camera	Actuation Test	LDW ON IND
INFINITI	All Mode	2008 - 2017	Lane Camera	Actuation Test	LANE DEPARTURE W/L
INFINITI	All Mode	2008 - 2017	Lane Camera	Actuation Test	LDP ON IND
INFINITI	All Mode	2008 - 2017	Lane Camera	Special Function	AUTO AIM
INFINITI	All Mode	2008 - 2017	Lane Camera	Special Function	Aim Check
INFINITI	All Mode	2008 - 2017	Lane Camera	Special Function	Cause Of Auto-Cancel
INFINITI	All Mode	2010 - 2017	Lane Camera	Read Fault Code	
INFINITI	All Mode	2010 - 2017	Lane Camera	Clear Fault Code	
INFINITI	All Mode	2010 - 2017	Lane Camera	Read Data Stream	
INFINITI	All Mode	2010 - 2017	Lane Camera	Module Information	
INFINITI	All Mode	2010 - 2017	Lane Camera	Actuation Test	LDP ON IND
INFINITI	All Mode	2010 - 2017	Lane Camera	Actuation Test	LANE DEPARTURE W/L
INFINITI	All Mode	2010 - 2017	Lane Camera	Actuation Test	LDW ON IND
INFINITI	All Mode	2010 - 2017	Lane Camera	Actuation Test	BUZZER DRIVE
INFINITI	All Mode	2010 - 2017	Lane Camera	Special Function	AUTO AIM
INFINITI	All Mode	2010 - 2017	Lane Camera	Special Function	Aim Check
INFINITI	All Mode	2010 - 2017	Lane Camera	Special Function	Cause Of Auto-Cancel
INFINITI	All Mode	2013 - 2018	Lane Camera	Read Fault Code	
INFINITI	All Mode	2013 - 2018	Lane Camera	Clear Fault Code	
INFINITI	All Mode	2013 - 2018	Lane Camera	Read Data Stream	
INFINITI	All Mode	2013 - 2018	Lane Camera	Module Information	
INFINITI	All Mode	2013 - 2018	Lane Camera	Special Function	AUTO AIM
INFINITI	All Mode	2016 - 2017	Lane Camera	Read Fault Code	
INFINITI	All Mode	2016 - 2017	Lane Camera	Clear Fault Code	
INFINITI	All Mode	2016 - 2017	Lane Camera	Read Data Stream	
INFINITI	All Mode	2016 - 2017	Lane Camera	Module Information	
INFINITI	All Mode	2016 - 2017	Lane Camera	Read Fault Code	
INFINITI	All Mode	2016 - 2017	Lane Camera	Clear Fault Code	
INFINITI	All Mode	2016 - 2017	Lane Camera	Read Data Stream	
INFINITI	All Mode	2016 - 2017	Lane Camera	Module Information	
INFINITI	All Mode	2016 - 2017	Lane Camera	Special Function	AUTO AIM
INFINITI	All Mode	2016 - 2017	Lane Camera	Special Function	Aim Check
INFINITI	All Mode	Up to 2008	Lane Camera	Read Fault Code	
INFINITI	All Mode	Up to 2008	Lane Camera	Clear Fault Code	
INFINITI	All Mode	Up to 2008	Lane Camera	Read Data Stream	
INFINITI	All Mode	Up to 2008	Lane Camera	Module Information	
INFINITI	All Mode	2005 - 2018	AFS (Adaptive Front Lighting System)	Read Fault Code	
INFINITI	All Mode	2005 - 2018	AFS (Adaptive Front Lighting System)	Clear Fault Code	
INFINITI	All Mode	2005 - 2018	AFS (Adaptive Front Lighting System)	Read Data Stream	
INFINITI	All Mode	2005 - 2018	AFS (Adaptive Front Lighting System)	Module Information	
INFINITI	All Mode	2005 - 2018	AFS (Adaptive Front Lighting System)	Actuation Test	LOW BEAM TEST RIGHT
INFINITI	All Mode	2005 - 2018	AFS (Adaptive Front Lighting System)	Actuation Test	LOW BEAM TEST LEFT
INFINITI	All Mode	2005 - 2018	AFS (Adaptive Front Lighting System)	Actuation Test	LEVELIZER TEST
INFINITI	All Mode	2005 - 2018	AFS (Adaptive Front Lighting System)	Special Function	ST ANG Sen Adjustment
INFINITI	All Mode	2005 - 2018	AFS (Adaptive Front Lighting System)	Special Function	Levelizer Adjustment
INFINITI	All Mode	2007 - 2018	AFS (Adaptive Front Lighting System)	Read Fault Code	
INFINITI	All Mode	2007 - 2018	AFS (Adaptive Front Lighting System)	Clear Fault Code	
INFINITI	All Mode	2007 - 2018	AFS (Adaptive Front Lighting System)	Read Data Stream	
INFINITI	All Mode	2007 - 2018	AFS (Adaptive Front Lighting System)	Module Information	
INFINITI	All Mode	2007 - 2018	AFS (Adaptive Front Lighting System)	Actuation Test	LOW BEAM TEST RIGHT
INFINITI	All Mode	2007 - 2018	AFS (Adaptive Front Lighting System)	Actuation Test	LOW BEAM TEST LEFT
INFINITI	All Mode	2007 - 2018	AFS (Adaptive Front Lighting System)	Actuation Test	LEVELIZER TEST
INFINITI	All Mode	2007 - 2018	AFS (Adaptive Front Lighting System)	Special Function	ST ANG Sen Adjustment
INFINITI	All Mode	2007 - 2018	AFS (Adaptive Front Lighting System)	Special Function	Levelizer Adjustment
INFINITI	All Mode	Up to 2008	AFS (Adaptive Front Lighting System)	Read Fault Code	
INFINITI	All Mode	Up to 2008	AFS (Adaptive Front Lighting System)	Clear Fault Code	
INFINITI	All Mode	Up to 2008	AFS (Adaptive Front Lighting System)	Read Data Stream	
INFINITI	All Mode	Up to 2008	AFS (Adaptive Front Lighting System)	Module Information	
INFINITI	All Mode	Up to 2008	AFS (Adaptive Front Lighting System)	Special Function	ST ANG Sen Adjustment
INFINITI	All Mode	2008 - 2017	CAN Gateway	Read Fault Code	
INFINITI	All Mode	2008 - 2017	CAN Gateway	Clear Fault Code	
INFINITI	All Mode	2008 - 2017	CAN Gateway	Read Freeze Frame	
INFINITI	All Mode	2008 - 2017	CAN Gateway	Module Information	
INFINITI	All Mode	2013 - 2016	CAN Gateway	Read Fault Code	
INFINITI	All Mode	2013 - 2016	CAN Gateway	Clear Fault Code	
INFINITI	All Mode	2013 - 2016	CAN Gateway	Read Data Stream	
INFINITI	All Mode	2013 - 2016	CAN Gateway	Module Information	

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
INFINITI	All Mode	2015 - 2018	CAN Gateway	Read Fault Code	
INFINITI	All Mode	2015 - 2018	CAN Gateway	Clear Fault Code	
INFINITI	All Mode	2015 - 2018	CAN Gateway	Read Data Stream	
INFINITI	All Mode	2015 - 2018	CAN Gateway	Module Information	
INFINITI	All Mode	2015 - 2015	Shift	Read Fault Code	
INFINITI	All Mode	2015 - 2015	Shift	Clear Fault Code	
INFINITI	All Mode	2015 - 2015	Shift	Read Data Stream	
INFINITI	All Mode	2015 - 2015	Shift	Read Freeze Frame	
INFINITI	All Mode	2015 - 2015	Shift	Module Information	
INFINITI	All Mode	2015 - 2015	Shift	Special Function	P Position Learning Value Clear
INFINITI	All Mode	2015 - 2018	Shift	Read Fault Code	
INFINITI	All Mode	2015 - 2018	Shift	Clear Fault Code	
INFINITI	All Mode	2015 - 2018	Shift	Read Data Stream	
INFINITI	All Mode	2015 - 2018	Shift	Module Information	
INFINITI	All Mode	2013 - 2018	EV/HEV	Read Fault Code	
INFINITI	All Mode	2013 - 2018	EV/HEV	Clear Fault Code	
INFINITI	All Mode	2013 - 2018	EV/HEV	Read Data Stream	
INFINITI	All Mode	2013 - 2018	EV/HEV	Module Information	
INFINITI	All Mode	2013 - 2018	EV/HEV	Actuation Test	Inspection Mode 5
INFINITI	All Mode	2013 - 2018	EV/HEV	Actuation Test	Inspection Mode 2
INFINITI	All Mode	2013 - 2018	EV/HEV	Actuation Test	Engine Cranking
INFINITI	All Mode	2013 - 2018	EV/HEV	Actuation Test	WATER PUMP
INFINITI	All Mode	2013 - 2018	EV/HEV	Actuation Test	Inspection Mode 3
INFINITI	All Mode	2013 - 2018	EV/HEV	Actuation Test	VOLTAGE CONTROL
INFINITI	All Mode	2013 - 2018	EV/HEV	Actuation Test	Inspection Mode 1
INFINITI	All Mode	2013 - 2018	EV/HEV	Special Function	Clutch 1 Position Learning
INFINITI	All Mode	2013 - 2018	POP UP HOOD	Read Fault Code	
INFINITI	All Mode	2013 - 2018	POP UP HOOD	Clear Fault Code	
INFINITI	All Mode	2013 - 2018	POP UP HOOD	Read Data Stream	
INFINITI	All Mode	2013 - 2018	POP UP HOOD	Module Information	
INFINITI	All Mode	2013 - 2018	POP UP HOOD	Special Function	Cause of Warning Lamp
INFINITI	All Mode	2008 - 2017	POP UP HOOD	Read Fault Code	
INFINITI	All Mode	2008 - 2017	POP UP HOOD	Clear Fault Code	
INFINITI	All Mode	2008 - 2017	POP UP HOOD	Module Information	
INFINITI	All Mode	Up to 2017	SRS (Supplemental Inflatable Restraint System)	Read Fault Code	
INFINITI	All Mode	Up to 2017	SRS (Supplemental Inflatable Restraint System)	Clear Fault Code	
INFINITI	All Mode	Up to 2017	SRS (Supplemental Inflatable Restraint System)	Read Data Stream	
INFINITI	All Mode	Up to 2017	SRS (Supplemental Inflatable Restraint System)	Module Information	
INFINITI	All Mode	Up to 2017	SRS (Supplemental Inflatable Restraint System)	Function Test	
INFINITI	All Mode	Up to 2017	SRS (Supplemental Inflatable Restraint System)	Special Function	SELF-DIAG[ETC]
INFINITI	All Mode	Up to 2017	SRS (Supplemental Inflatable Restraint System)	Special Function	Trouble Diag Record
INFINITI	All Mode	Up to 2017	SRS (Supplemental Inflatable Restraint System)	Special Function	Cause Of Warning
INFINITI	All Mode	Up to 2017	SRS (Supplemental Inflatable Restraint System)	Special Function	SELF-DIAG[PAST]
INFINITI	All Mode	2011 - 2017	SRS (Supplemental Inflatable Restraint System)	Read Fault Code	
INFINITI	All Mode	2011 - 2017	SRS (Supplemental Inflatable Restraint System)	Clear Fault Code	
INFINITI	All Mode	2011 - 2017	SRS (Supplemental Inflatable Restraint System)	Read Data Stream	
INFINITI	All Mode	2011 - 2017	SRS (Supplemental Inflatable Restraint System)	Module Information	
INFINITI	All Mode	2011 - 2017	SRS (Supplemental Inflatable Restraint System)	Special Function	Trouble Diag Record
INFINITI	All Mode	2011 - 2017	SRS (Supplemental Inflatable Restraint System)	Special Function	Cause Of Warning
INFINITI	All Mode	2011 - 2017	SRS (Supplemental Inflatable Restraint System)	Special Function	SELF-DIAG[PAST]
INFINITI	All Mode	2012 - 2018	SRS (Supplemental Inflatable Restraint System)	Read Fault Code	
INFINITI	All Mode	2012 - 2018	SRS (Supplemental Inflatable Restraint System)	Clear Fault Code	
INFINITI	All Mode	2012 - 2018	SRS (Supplemental Inflatable Restraint System)	Read Data Stream	
INFINITI	All Mode	2012 - 2018	SRS (Supplemental Inflatable Restraint System)	Module Information	
INFINITI	All Mode	2014 - 2017	SRS (Supplemental Inflatable Restraint System)	Read Fault Code	
INFINITI	All Mode	2014 - 2017	SRS (Supplemental Inflatable Restraint System)	Clear Fault Code	
INFINITI	All Mode	2014 - 2017	SRS (Supplemental Inflatable Restraint System)	Read Data Stream	
INFINITI	All Mode	2014 - 2017	SRS (Supplemental Inflatable Restraint System)	Module Information	
INFINITI	All Mode	2015 - 2018	SRS (Supplemental Inflatable Restraint System)	Read Fault Code	
INFINITI	All Mode	2015 - 2018	SRS (Supplemental Inflatable Restraint System)	Clear Fault Code	
INFINITI	All Mode	2015 - 2018	SRS (Supplemental Inflatable Restraint System)	Read Data Stream	
INFINITI	All Mode	2015 - 2018	SRS (Supplemental Inflatable Restraint System)	Module Information	
INFINITI	All Mode	2015 - 2018	SRS (Supplemental Inflatable Restraint System)	Special Function	LOCK ECU
INFINITI	All Mode	Up to 2017	SRS (Supplemental Inflatable Restraint System)	Read Fault Code	
INFINITI	All Mode	Up to 2017	SRS (Supplemental Inflatable Restraint System)	Clear Fault Code	
INFINITI	All Mode	Up to 2017	SRS (Supplemental Inflatable Restraint System)	Read Data Stream	
INFINITI	All Mode	Up to 2017	SRS (Supplemental Inflatable Restraint System)	Module Information	
INFINITI	All Mode	Up to 2008	SRS (Supplemental Inflatable Restraint System)	Read Fault Code	
INFINITI	All Mode	Up to 2008	SRS (Supplemental Inflatable Restraint System)	Clear Fault Code	
INFINITI	All Mode	Up to 2008	SRS (Supplemental Inflatable Restraint System)	Read Data Stream	
INFINITI	All Mode	Up to 2008	SRS (Supplemental Inflatable Restraint System)	Module Information	
INFINITI	All Mode	Up to 2008	SRS (Supplemental Inflatable Restraint System)	Read Fault Code	
INFINITI	All Mode	Up to 2008	SRS (Supplemental Inflatable Restraint System)	Clear Fault Code	
INFINITI	All Mode	Up to 2008	SRS (Supplemental Inflatable Restraint System)	Read Data Stream	
INFINITI	All Mode	Up to 2008	SRS (Supplemental Inflatable Restraint System)	Module Information	
INFINITI	All Mode	Up to 2008	SRS (Supplemental Inflatable Restraint System)	Read Fault Code	
INFINITI	All Mode	Up to 2008	SRS (Supplemental Inflatable Restraint System)	Clear Fault Code	
INFINITI	All Mode	Up to 2008	SRS (Supplemental Inflatable Restraint System)	Read Data Stream	
INFINITI	All Mode	Up to 2008	SRS (Supplemental Inflatable Restraint System)	Module Information	

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
INFINITI	All Mode	Up to 2008	SRS (Supplemental Inflatable Restraint System)	Read Fault Code	
INFINITI	All Mode	Up to 2008	SRS (Supplemental Inflatable Restraint System)	Clear Fault Code	
INFINITI	All Mode	Up to 2008	SRS (Supplemental Inflatable Restraint System)	Read Data Stream	
INFINITI	All Mode	Up to 2008	SRS (Supplemental Inflatable Restraint System)	Module Information	
INFINITI	All Mode	2010 - 2017	Auto Back Door	Read Fault Code	
INFINITI	All Mode	2010 - 2017	Auto Back Door	Clear Fault Code	
INFINITI	All Mode	2010 - 2017	Auto Back Door	Read Data Stream	
INFINITI	All Mode	2010 - 2017	Auto Back Door	Module Information	
INFINITI	All Mode	2010 - 2017	Auto Back Door	Read Fault Code	
INFINITI	All Mode	2010 - 2017	Auto Back Door	Clear Fault Code	
INFINITI	All Mode	2010 - 2017	Auto Back Door	Read Data Stream	
INFINITI	All Mode	2010 - 2017	Auto Back Door	Module Information	
INFINITI	All Mode	2010 - 2017	Auto Back Door	Special Function	Reset Auto Back Door Status
INFINITI	All Mode	2014 - 2014	Auto Back Door	Read Fault Code	
INFINITI	All Mode	2014 - 2014	Auto Back Door	Clear Fault Code	
INFINITI	All Mode	2014 - 2014	Auto Back Door	Read Data Stream	
INFINITI	All Mode	2014 - 2014	Auto Back Door	Module Information	
INFINITI	All Mode	2014 - 2014	Auto Back Door	Special Function	Reset Auto Back Door Status
INFINITI	All Mode	2007 - 2017	4WAS(Front)	Read Fault Code	
INFINITI	All Mode	2007 - 2017	4WAS(Front)	Clear Fault Code	
INFINITI	All Mode	2007 - 2017	4WAS(Front)	Read Data Stream	
INFINITI	All Mode	2007 - 2017	4WAS(Front)	Read Freeze Frame	
INFINITI	All Mode	2007 - 2017	4WAS(Front)	Module Information	
INFINITI	All Mode	2007 - 2017	4WAS(Front)	Actuation Test	LOCK OPERATION
INFINITI	All Mode	2007 - 2017	4WAS(Front)	Actuation Test	SLOW MODE
INFINITI	All Mode	2008 - 2017	E-SUS (Electric Suspension)	Read Fault Code	
INFINITI	All Mode	2008 - 2017	E-SUS (Electric Suspension)	Clear Fault Code	
INFINITI	All Mode	2008 - 2017	E-SUS (Electric Suspension)	Read Data Stream	
INFINITI	All Mode	2008 - 2017	E-SUS (Electric Suspension)	Read Freeze Frame	
INFINITI	All Mode	2008 - 2017	E-SUS (Electric Suspension)	Module Information	
INFINITI	All Mode	2008 - 2017	E-SUS (Electric Suspension)	Actuation Test	FRONT RIGHT ACTUATOR
INFINITI	All Mode	2008 - 2017	E-SUS (Electric Suspension)	Actuation Test	FRONT LEFT ACTUATOR
INFINITI	All Mode	2008 - 2017	E-SUS (Electric Suspension)	Actuation Test	REAR RIGHT ACTUATOR
INFINITI	All Mode	2008 - 2017	E-SUS (Electric Suspension)	Actuation Test	REAR LEFT ACTUATOR
INFINITI	All Mode	2008 - 2017	E-SUS (Electric Suspension)	Actuation Test	Mode Lamp
INFINITI	All Mode	2010 - 2017	E-SUS (Electric Suspension)	Read Fault Code	
INFINITI	All Mode	2010 - 2017	E-SUS (Electric Suspension)	Clear Fault Code	
INFINITI	All Mode	2010 - 2017	E-SUS (Electric Suspension)	Read Data Stream	
INFINITI	All Mode	2010 - 2017	E-SUS (Electric Suspension)	Module Information	
INFINITI	All Mode	2010 - 2017	E-SUS (Electric Suspension)	Actuation Test	COMPRESSOR
INFINITI	All Mode	2010 - 2017	E-SUS (Electric Suspension)	Actuation Test	EXHAUST SOLENOID
INFINITI	All Mode	2010 - 2017	E-SUS (Electric Suspension)	Actuation Test	Warnnig Lamp
INFINITI	All Mode	2010 - 2017	E-SUS (Electric Suspension)	Special Function	Standard Height Level
INFINITI	All Mode	2010 - 2017	E-SUS (Electric Suspension)	Special Function	Adjust Height Ini
INFINITI	All Mode	2010 - 2017	E-SUS (Electric Suspension)	Special Function	Clear Height INI
INFINITI	All Mode	2008 - 2017	Accele Pedal Act	Read Fault Code	
INFINITI	All Mode	2008 - 2017	Accele Pedal Act	Clear Fault Code	
INFINITI	All Mode	2008 - 2017	Accele Pedal Act	Read Data Stream	
INFINITI	All Mode	2008 - 2017	Accele Pedal Act	Module Information	
INFINITI	All Mode	2008 - 2017	Accele Pedal Act	Actuation Test	ACCELERATOR PEDAL ACTUATOR TEST1
INFINITI	All Mode	2008 - 2017	Accele Pedal Act	Actuation Test	ACCELERATOR PEDAL ACTUATOR TEST2
INFINITI	All Mode	2010 - 2018	Accele Pedal Act	Read Fault Code	
INFINITI	All Mode	2010 - 2018	Accele Pedal Act	Clear Fault Code	
INFINITI	All Mode	2010 - 2018	Accele Pedal Act	Read Data Stream	
INFINITI	All Mode	2010 - 2018	Accele Pedal Act	Module Information	
INFINITI	All Mode	2010 - 2018	Accele Pedal Act	Actuation Test	ACCELERATOR PEDAL ACTUATOR TEST1
INFINITI	All Mode	2010 - 2018	Accele Pedal Act	Actuation Test	ACCELERATOR PEDAL ACTUATOR TEST2
INFINITI	All Mode	2010 - 2017	HV Battery	Read Fault Code	
INFINITI	All Mode	2010 - 2017	HV Battery	Clear Fault Code	
INFINITI	All Mode	2010 - 2017	HV Battery	Read Data Stream	
INFINITI	All Mode	2010 - 2017	HV Battery	Module Information	
INFINITI	All Mode	2010 - 2017	HV Battery	Actuation Test	HV Battery Cooling Fan
INFINITI	All Mode	2010 - 2017	HV Battery	Special Function	Save Battery Information Data
INFINITI	All Mode	2010 - 2017	HV Battery	Special Function	Write Battery Information Data
INFINITI	All Mode	2010 - 2017	HV Battery	Special Function	Clear Battery Info
INFINITI	All Mode	2010 - 2017	HV Battery	Special Function	LI-ION Battery Capacity Balancing
INFINITI	All Mode	2013 - 2018	HV Battery	Read Fault Code	
INFINITI	All Mode	2013 - 2018	HV Battery	Clear Fault Code	
INFINITI	All Mode	2013 - 2018	HV Battery	Read Data Stream	
INFINITI	All Mode	2013 - 2018	HV Battery	Module Information	
INFINITI	All Mode	2013 - 2018	HV Battery	Actuation Test	HV Battery Cooling Fan
INFINITI	All Mode	2013 - 2018	HV Battery	Special Function	Save Battery Information Data



**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
INFINITI	All Mode	2013 - 2018	HV Battery	Special Function	Write Battery Information Data
INFINITI	All Mode	2013 - 2018	HV Battery	Special Function	Clear Battery Info
INFINITI	All Mode	2013 - 2017	HV Battery	Read Fault Code	
INFINITI	All Mode	2013 - 2017	HV Battery	Clear Fault Code	
INFINITI	All Mode	2013 - 2017	HV Battery	Read Data Stream	
INFINITI	All Mode	2013 - 2017	HV Battery	Module Information	
INFINITI	All Mode	2013 - 2017	HV Battery	Actuation Test	HV Battery Cooling Fan
INFINITI	All Mode	2013 - 2017	HV Battery	Special Function	Idm Information Clear
INFINITI	All Mode	2008 - 2017	Total Illum C/U	Read Fault Code	
INFINITI	All Mode	2008 - 2017	Total Illum C/U	Clear Fault Code	
INFINITI	All Mode	2008 - 2017	Total Illum C/U	Read Data Stream	
INFINITI	All Mode	2008 - 2018	Occupant Detection	Read Data Stream	
INFINITI	All Mode	2008 - 2018	Occupant Detection	Special Function	Zero point reset function
INFINITI	All Mode	2010 - 2018	Brakes	Read Fault Code	
INFINITI	All Mode	2010 - 2018	Brakes	Clear Fault Code	
INFINITI	All Mode	2010 - 2018	Brakes	Read Data Stream	
INFINITI	All Mode	2010 - 2018	Brakes	Module Information	
INFINITI	All Mode	2010 - 2018	Brakes	Actuation Test	STOP LAMP OFF RELAY
INFINITI	All Mode	2010 - 2018	Brakes	Special Function	Storke Sensor 0 Point Learning
INFINITI	All Mode	2010 - 2018	Side Radar Left	Read Fault Code	
INFINITI	All Mode	2010 - 2018	Side Radar Left	Clear Fault Code	
INFINITI	All Mode	2010 - 2018	Side Radar Left	Read Data Stream	
INFINITI	All Mode	2010 - 2018	Side Radar Left	Module Information	
INFINITI	All Mode	2010 - 2018	Side Radar Left	Special Function	Activate Operation
INFINITI	All Mode	2016 - 2017	Side Radar Left	Read Fault Code	
INFINITI	All Mode	2016 - 2017	Side Radar Left	Clear Fault Code	
INFINITI	All Mode	2016 - 2017	Side Radar Left	Read Data Stream	
INFINITI	All Mode	2016 - 2017	Side Radar Left	Module Information	
INFINITI	All Mode	2016 - 2017	Side Radar Left	Special Function	Activate Operation
INFINITI	All Mode	2013 - 2018	VSP	Read Fault Code	
INFINITI	All Mode	2013 - 2018	VSP	Clear Fault Code	
INFINITI	All Mode	2013 - 2018	VSP	Read Data Stream	
INFINITI	All Mode	2013 - 2018	VSP	Module Information	
INFINITI	All Mode	2013 - 2018	VSP	Actuation Test	VSP SPEAKER
INFINITI	All Mode	2013 - 2018	VSP	Actuation Test	START UP SOUND SPEAKER
INFINITI	All Mode	2013 - 2018	VSP	Actuation Test	VSP OFF INDICATOR
INFINITI	All Mode	2010 - 2016	VSP	Read Fault Code	
INFINITI	All Mode	2010 - 2016	VSP	Clear Fault Code	
INFINITI	All Mode	2010 - 2016	VSP	Read Data Stream	
INFINITI	All Mode	2010 - 2016	VSP	Module Information	
INFINITI	All Mode	2013 - 2018	Active Noise Cancellation (ANC)	Read Fault Code	
INFINITI	All Mode	2013 - 2018	Active Noise Cancellation (ANC)	Clear Fault Code	
INFINITI	All Mode	2013 - 2018	Active Noise Cancellation (ANC)	Read Data Stream	
INFINITI	All Mode	2013 - 2018	Active Noise Cancellation (ANC)	Module Information	
INFINITI	All Mode	2013 - 2018	Active Noise Cancellation (ANC)	Actuation Test	ANC TEST TONE
INFINITI	All Mode	2013 - 2018	Active Noise Cancellation (ANC)	Special Function	ANC Setting
INFINITI	All Mode	2013 - 2018	Active Noise Cancellation (ANC)	Special Function	ASC Setting
INFINITI	All Mode	2014 - 2018	Active Noise Cancellation (ANC)	Read Fault Code	
INFINITI	All Mode	2014 - 2018	Active Noise Cancellation (ANC)	Clear Fault Code	
INFINITI	All Mode	2014 - 2018	Active Noise Cancellation (ANC)	Read Data Stream	
INFINITI	All Mode	2014 - 2018	Active Noise Cancellation (ANC)	Module Information	
INFINITI	All Mode	2014 - 2018	Active Noise Cancellation (ANC)	Actuation Test	ANC TEST TONE
INFINITI	All Mode	2014 - 2018	Active Noise Cancellation (ANC)	Special Function	ANC Setting
INFINITI	All Mode	2014 - 2018	Active Noise Cancellation (ANC)	Special Function	ASC Setting
INFINITI	All Mode	2015 - 2018	Active Noise Cancellation (ANC)	Read Fault Code	
INFINITI	All Mode	2015 - 2018	Active Noise Cancellation (ANC)	Clear Fault Code	
INFINITI	All Mode	2015 - 2018	Active Noise Cancellation (ANC)	Read Data Stream	
INFINITI	All Mode	2015 - 2018	Active Noise Cancellation (ANC)	Module Information	
INFINITI	All Mode	2015 - 2018	Active Noise Cancellation (ANC)	Actuation Test	ANC TEST TONE
INFINITI	All Mode	2015 - 2018	Active Noise Cancellation (ANC)	Special Function	ANC Setting
INFINITI	All Mode	2015 - 2018	Active Noise Cancellation (ANC)	Special Function	ASC Setting
INFINITI	All Mode	2014 - 2016	Multi Display	Read Fault Code	
INFINITI	All Mode	2014 - 2016	Multi Display	Clear Fault Code	
INFINITI	All Mode	2014 - 2016	Multi Display	Read Data Stream	
INFINITI	All Mode	2014 - 2016	Multi Display	Actuation Test	STOP LAMP OFF RELAY
INFINITI	All Mode	Up to 2017	CCS (Cruise Control System)	Read Fault Code	
INFINITI	All Mode	Up to 2017	CCS (Cruise Control System)	Clear Fault Code	
INFINITI	All Mode	Up to 2017	CCS (Cruise Control System)	Read Data Stream	
INFINITI	All Mode	Up to 2017	CCS (Cruise Control System)	Module Information	
INFINITI	All Mode	Up to 2017	CCS (Cruise Control System)	Actuation Test	ICC BUZZER
INFINITI	All Mode	Up to 2017	CCS (Cruise Control System)	Actuation Test	Meter Lamp
INFINITI	All Mode	Up to 2017	CCS (Cruise Control System)	Actuation Test	Stop Lamp
INFINITI	All Mode	Up to 2017	CCS (Cruise Control System)	Special Function	Cause Of Auto-Cancel
INFINITI	All Mode	Up to 2017	CCS (Cruise Control System)	Special Function	Laser Beam Adjust
INFINITI	All Mode	Up to 2017	CCS (Cruise Control System)	Read Fault Code	
INFINITI	All Mode	Up to 2017	CCS (Cruise Control System)	Clear Fault Code	
INFINITI	All Mode	Up to 2017	CCS (Cruise Control System)	Read Data Stream	
INFINITI	All Mode	Up to 2017	CCS (Cruise Control System)	Read Freeze Frame	

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
INFINITI	All Mode	Up to 2017	CCS (Cruise Control System)	Module Information	
INFINITI	All Mode	Up to 2017	CCS (Cruise Control System)	Actuation Test	ICC BUZZER
INFINITI	All Mode	Up to 2017	CCS (Cruise Control System)	Actuation Test	Meter Lamp
INFINITI	All Mode	Up to 2017	CCS (Cruise Control System)	Actuation Test	Stop Lamp
INFINITI	All Mode	Up to 2017	CCS (Cruise Control System)	Actuation Test	BOOSTER SOL/V
INFINITI	All Mode	Up to 2017	CCS (Cruise Control System)	Actuation Test	Accelerator Pedal Actuator
INFINITI	All Mode	Up to 2017	CCS (Cruise Control System)	Actuation Test	DCA Indicator
INFINITI	All Mode	Up to 2017	CCS (Cruise Control System)	Special Function	Cause Of Auto-Cancel
INFINITI	All Mode	Up to 2017	CCS (Cruise Control System)	Special Function	Laser Beam Adjust
INFINITI	All Mode	2010 - 2018	CCS (Cruise Control System)	Read Fault Code	
INFINITI	All Mode	2010 - 2018	CCS (Cruise Control System)	Clear Fault Code	
INFINITI	All Mode	2010 - 2018	CCS (Cruise Control System)	Read Data Stream	
INFINITI	All Mode	2010 - 2018	CCS (Cruise Control System)	Read Freeze Frame	
INFINITI	All Mode	2010 - 2018	CCS (Cruise Control System)	Module Information	
INFINITI	All Mode	2010 - 2018	CCS (Cruise Control System)	Actuation Test	Brake Actuator
INFINITI	All Mode	2010 - 2018	CCS (Cruise Control System)	Actuation Test	ICC BUZZER
INFINITI	All Mode	2010 - 2018	CCS (Cruise Control System)	Actuation Test	Meter Lamp
INFINITI	All Mode	2010 - 2018	CCS (Cruise Control System)	Actuation Test	Stop Lamp
INFINITI	All Mode	2010 - 2018	CCS (Cruise Control System)	Actuation Test	Active Pedal
INFINITI	All Mode	2010 - 2018	CCS (Cruise Control System)	Actuation Test	DCA Indicator
INFINITI	All Mode	2010 - 2018	CCS (Cruise Control System)	Actuation Test	LDP Buzzer
INFINITI	All Mode	2010 - 2018	CCS (Cruise Control System)	Actuation Test	Warning System IND
INFINITI	All Mode	2010 - 2018	CCS (Cruise Control System)	Actuation Test	LDP ON IND
INFINITI	All Mode	2010 - 2018	CCS (Cruise Control System)	Actuation Test	LANE DEPARTURE W/L
INFINITI	All Mode	2010 - 2018	CCS (Cruise Control System)	Actuation Test	BSW/BSI Warning Lamp
INFINITI	All Mode	2010 - 2018	CCS (Cruise Control System)	Actuation Test	BSI On Indicator
INFINITI	All Mode	2010 - 2018	CCS (Cruise Control System)	Actuation Test	LDW On Indicator
INFINITI	All Mode	2010 - 2018	CCS (Cruise Control System)	Actuation Test	LDP Warning Indicator
INFINITI	All Mode	2010 - 2018	CCS (Cruise Control System)	Actuation Test	LDW Warning Indicator
INFINITI	All Mode	2010 - 2018	CCS (Cruise Control System)	Actuation Test	BSW ON INDICATOR
INFINITI	All Mode	2010 - 2018	CCS (Cruise Control System)	Actuation Test	BSI Warning Indicator
INFINITI	All Mode	2010 - 2018	CCS (Cruise Control System)	Special Function	Cause Of Auto-Cancel 1
INFINITI	All Mode	2010 - 2018	CCS (Cruise Control System)	Special Function	Cause Of Auto-Cancel 2
INFINITI	All Mode	2010 - 2018	CCS (Cruise Control System)	Special Function	Cause Of Auto-Cancel 3
INFINITI	All Mode	2010 - 2018	CCS (Cruise Control System)	Special Function	FEB Operation Mileage
INFINITI	All Mode	2010 - 2018	CCS (Cruise Control System)	Special Function	Cause Of Auto-Cancel 4
INFINITI	All Mode	2010 - 2018	CCS (Cruise Control System)	Special Function	FEB Default Setting
INFINITI	All Mode	2014 - 2017	CCS (Cruise Control System)	Read Fault Code	
INFINITI	All Mode	2014 - 2017	CCS (Cruise Control System)	Clear Fault Code	
INFINITI	All Mode	2014 - 2017	CCS (Cruise Control System)	Read Data Stream	
INFINITI	All Mode	2014 - 2017	CCS (Cruise Control System)	Module Information	
INFINITI	All Mode	2014 - 2017	CCS (Cruise Control System)	Actuation Test	ADAS BUZZER
INFINITI	All Mode	2014 - 2017	CCS (Cruise Control System)	Actuation Test	Stop Lamp
INFINITI	All Mode	2014 - 2017	CCS (Cruise Control System)	Actuation Test	Meter Lamp
INFINITI	All Mode	2014 - 2017	CCS (Cruise Control System)	Actuation Test	METER BUZZER
INFINITI	All Mode	2014 - 2017	CCS (Cruise Control System)	Actuation Test	EAP SW Lamp
INFINITI	All Mode	2014 - 2017	CCS (Cruise Control System)	Actuation Test	BRAKE ACTUATOR 1
INFINITI	All Mode	2014 - 2017	CCS (Cruise Control System)	Actuation Test	BRAKE ACTUATOR 2
INFINITI	All Mode	2014 - 2017	CCS (Cruise Control System)	Actuation Test	BRAKE ACTUATOR 3
INFINITI	All Mode	2014 - 2017	CCS (Cruise Control System)	Special Function	FEB Operation Mileage
INFINITI	All Mode	2014 - 2017	CCS (Cruise Control System)	Special Function	FEB Default Setting
INFINITI	All Mode	2014 - 2017	CCS (Cruise Control System)	Special Function	Cause Of Auto-Cancel 4
INFINITI	All Mode	2014 - 2017	CCS (Cruise Control System)	Special Function	Cause Of Auto-Cancel 5
INFINITI	All Mode	2014 - 2017	CCS (Cruise Control System)	Special Function	Cause Of Auto-Cancel 6
INFINITI	All Mode	2016 - 2017	CCS (Cruise Control System)	Read Fault Code	
INFINITI	All Mode	2016 - 2017	CCS (Cruise Control System)	Clear Fault Code	
INFINITI	All Mode	2016 - 2017	CCS (Cruise Control System)	Read Data Stream	
INFINITI	All Mode	2016 - 2017	CCS (Cruise Control System)	Module Information	
INFINITI	All Mode	2016 - 2017	CCS (Cruise Control System)	Special Function	FEB Operation Mileage
INFINITI	All Mode	2016 - 2017	CCS (Cruise Control System)	Special Function	Cause Of Auto-Cancel 6
INFINITI	All Mode	2010 - 2018	Side Radar Right	Read Fault Code	
INFINITI	All Mode	2010 - 2018	Side Radar Right	Clear Fault Code	
INFINITI	All Mode	2010 - 2018	Side Radar Right	Read Data Stream	
INFINITI	All Mode	2010 - 2018	Side Radar Right	Module Information	
INFINITI	All Mode	2010 - 2018	Side Radar Right	Special Function	Activate Operation
INFINITI	All Mode	2016 - 2017	Side Radar Right	Read Fault Code	
INFINITI	All Mode	2016 - 2017	Side Radar Right	Clear Fault Code	
INFINITI	All Mode	2016 - 2017	Side Radar Right	Read Data Stream	
INFINITI	All Mode	2016 - 2017	Side Radar Right	Module Information	
INFINITI	All Mode	2016 - 2017	Side Radar Right	Special Function	ACTIVATE OPERATION
INFINITI	All Mode	2015 - 2016	ADCM	Read Fault Code	
INFINITI	All Mode	2015 - 2016	ADCM	Clear Fault Code	
INFINITI	All Mode	2015 - 2016	ADCM	Read Data Stream	
INFINITI	All Mode	2015 - 2016	ADCM	Module Information	
INFINITI	All Mode	2014 - 2016	PTC Heater	Read Fault Code	
INFINITI	All Mode	2014 - 2016	PTC Heater	Clear Fault Code	
INFINITI	All Mode	2014 - 2016	PTC Heater	Read Data Stream	
INFINITI	All Mode	2014 - 2016	PTC Heater	Module Information	
INFINITI	All Mode	2013 - 2014	Charger/PD Module	Read Fault Code	
INFINITI	All Mode	2013 - 2014	Charger/PD Module	Clear Fault Code	

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
INFINITI	All Mode	2013 - 2014	Charger/PD Module	Read Data Stream	
INFINITI	All Mode	2013 - 2014	Charger/PD Module	Module Information	
INFINITI	All Mode	2013 - 2014	Charger/PD Module	Actuation Test	QUICK CHARGE RELAY+
INFINITI	All Mode	2013 - 2014	Charger/PD Module	Actuation Test	Quick Charge Relay-
INFINITI	All Mode	2013 - 2014	Charger/PD Module	Actuation Test	Normal Charge Relay-
INFINITI	All Mode	2013 - 2014	Charger/PD Module	Special Function	CHARGE CURRENT LIMITATION HISTORY
INFINITI	All Mode	2011 - 2018	Telematics	Read Fault Code	
INFINITI	All Mode	2011 - 2018	Telematics	Clear Fault Code	
INFINITI	All Mode	2011 - 2018	Telematics	Read Data Stream	
INFINITI	All Mode	2011 - 2018	Telematics	Module Information	
INFINITI	All Mode	2011 - 2018	Telematics	Special Function	Center Connection Setting
INFINITI	All Mode	2011 - 2018	Telematics	Special Function	TCU Activate Setting
INFINITI	All Mode	2011 - 2018	Telematics	Special Function	Save Vin Data
INFINITI	All Mode	2011 - 2018	Telematics	Special Function	Write Vin (Saved Data)
INFINITI	All Mode	2011 - 2018	Telematics	Special Function	Write Vin (Manual Input)
INFINITI	All Mode	2015 - 2018	Telematics	Read Fault Code	
INFINITI	All Mode	2015 - 2018	Telematics	Clear Fault Code	
INFINITI	All Mode	2015 - 2018	Telematics	Read Data Stream	
INFINITI	All Mode	2015 - 2018	Telematics	Module Information	
INFINITI	All Mode	2010 - 2016	Telematics	Read Fault Code	
INFINITI	All Mode	2010 - 2016	Telematics	Clear Fault Code	
INFINITI	All Mode	2010 - 2016	Telematics	Read Data Stream	
INFINITI	All Mode	2010 - 2016	Telematics	Module Information	
INFINITI	All Mode	2010 - 2016	Telematics	Special Function	Vin Registration
INFINITI	All Mode	2010 - 2016	Telematics	Special Function	TCU Activate Setting
INFINITI	INFINITI M25/M37/M56	2012	EMCM	Read Fault Code	
INFINITI	INFINITI M25/M37/M56	2012	EMCM	Clear Fault Code	
INFINITI	INFINITI M25/M37/M56	2012	EMCM	Read Data Stream	
INFINITI	INFINITI M25/M37/M56	2012	EMCM	Module Information	
INFINITI	INFINITI M25/M37/M56	2012	EMCM	Actuation Test	Auto Stop Start
INFINITI	INFINITI M25/M37/M56	2012	EMCM	Special Function	Saving Data For Replc CPU
INFINITI	INFINITI M25/M37/M56	2012	EMCM	Special Function	Writing Data For Replc CPU
INFINITI	INFINITI M25/M37/M56	2012	EMCM	Special Function	STRT OPRTN CNTR CLEAR
INFINITI	INFINITI M25/M37/M56	2012	EMCM	Special Function	CML B/DCHRG CRNT CLEAR
INFINITI	INFINITI M25/M37/M56	2012	EMCM	Special Function	Cumulative Sub-Battry Dischg Current Clear
INFINITI	INFINITI M25/M37/M56	2012	EMCM	Special Function	Chassis Dynamometer Mode
INFINITI	All Mode	2010 - 2011	HVAC (Heating Ventilation Air-conditioning and Cooling)	Read Fault Code	
INFINITI	All Mode	2010 - 2011	HVAC (Heating Ventilation Air-conditioning and Cooling)	Clear Fault Code	
INFINITI	All Mode	2010 - 2011	HVAC (Heating Ventilation Air-conditioning and Cooling)	Read Data Stream	
INFINITI	All Mode	2010 - 2011	HVAC (Heating Ventilation Air-conditioning and Cooling)	Read Freeze Frame	
INFINITI	All Mode	2010 - 2011	HVAC (Heating Ventilation Air-conditioning and Cooling)	Module Information	
INFINITI	All Mode	2010 - 2011	HVAC (Heating Ventilation Air-conditioning and Cooling)	Actuation Test	ALL SEG
INFINITI	All Mode	2010 - 2011	HVAC (Heating Ventilation Air-conditioning and Cooling)	Actuation Test	Hvac Test
INFINITI	All Mode	2010 - 2011	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	Temp Set Correct
INFINITI	All Mode	2010 - 2011	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	REC Memory Set
INFINITI	All Mode	2010 - 2011	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	FRE Memory Set
INFINITI	All Mode	2010 - 2011	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	Blow Set
INFINITI	All Mode	2010 - 2011	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	DOOR Motor Starting Position Reset
INFINITI	All Mode	2010 - 2011	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	Target Max RPM ADJ AT Pre-Climate
INFINITI	All Mode	2010 - 2011	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	Target Max RPM ADJ AT IDL
INFINITI	All Mode	2010 - 2011	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	COMP OPRT SET AT DEF MODE (TIM/RMT CLIMT CONT)
INFINITI	All Mode	2010 - 2018	HVAC (Heating Ventilation Air-conditioning and Cooling)	Read Fault Code	
INFINITI	All Mode	2010 - 2018	HVAC (Heating Ventilation Air-conditioning and Cooling)	Clear Fault Code	
INFINITI	All Mode	2010 - 2018	HVAC (Heating Ventilation Air-conditioning and Cooling)	Read Data Stream	
INFINITI	All Mode	2010 - 2018	HVAC (Heating Ventilation Air-conditioning and Cooling)	Read Freeze Frame	
INFINITI	All Mode	2010 - 2018	HVAC (Heating Ventilation Air-conditioning and Cooling)	Module Information	
INFINITI	All Mode	2010 - 2018	HVAC (Heating Ventilation Air-conditioning and Cooling)	Actuation Test	Hvac Test

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

<b>make</b>	<b>model</b>	<b>year</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
INFINITI	All Mode	2010 - 2018	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	Blow Set
INFINITI	All Mode	2010 - 2018	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	REC Memory Set
INFINITI	All Mode	2010 - 2018	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	FRE Memory Set
INFINITI	All Mode	2010 - 2018	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	Temp Set Correct
INFINITI	All Mode	2010 - 2018	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	Aroma Setting
INFINITI	All Mode	2010 - 2018	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	Fragrance Setting
INFINITI	All Mode	2010 - 2018	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	Blower Motor Setting
INFINITI	All Mode	2010 - 2018	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	(TBD)WDBLIDOA
INFINITI	All Mode	2010 - 2018	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	Aroma Diffuser Setting
INFINITI	All Mode	2010 - 2018	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	(TBD)WDBLIDOC
INFINITI	All Mode	2010 - 2018	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	Target Evaporator Temp Upper Limit Setting
INFINITI	All Mode	2010 - 2018	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	CLEAN SW SET
INFINITI	All Mode	2010 - 2018	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	Air Inlet Change Setting
INFINITI	All Mode	2010 - 2018	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	Air Flow Reduction Setting
INFINITI	All Mode	Up to 2016	HVAC (Heating Ventilation Air-conditioning and Cooling)	Read Fault Code	
INFINITI	All Mode	Up to 2016	HVAC (Heating Ventilation Air-conditioning and Cooling)	Clear Fault Code	
INFINITI	All Mode	Up to 2016	HVAC (Heating Ventilation Air-conditioning and Cooling)	Read Data Stream	
INFINITI	All Mode	Up to 2016	HVAC (Heating Ventilation Air-conditioning and Cooling)	Module Information	
INFINITI	All Mode	2010 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Read Fault Code	
INFINITI	All Mode	2010 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Clear Fault Code	
INFINITI	All Mode	2010 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Read Data Stream	
INFINITI	All Mode	2010 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Read Freeze Frame	
INFINITI	All Mode	2010 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Module Information	
INFINITI	All Mode	2010 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Actuation Test	ALL SEG
INFINITI	All Mode	2010 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Actuation Test	Hvac Test
INFINITI	All Mode	2010 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	Blow Set
INFINITI	All Mode	2010 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	REC Memory Set
INFINITI	All Mode	2010 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	FRE Memory Set
INFINITI	All Mode	2010 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	Temp Set Correct
INFINITI	All Mode	2010 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	GAS Sensor Adjustment
INFINITI	All Mode	2010 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	CLEAN SW SET
INFINITI	All Mode	2010 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	(TBD)ACTR RESET
INFINITI	All Mode	2010 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	DOOR Motor Starting Position Reset
INFINITI	All Mode	2010 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	Rear Temp Set Correct
INFINITI	All Mode	2010 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	Target Evaporator Temp Upper Limit Setting
INFINITI	All Mode	2010 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	STOP/START SYSTEM OPERATION COND SETTING
INFINITI	All Mode	2010 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	Air Inlet Change Setting
INFINITI	All Mode	2010 - 2017	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	Air Flow Reduction Setting
INFINITI	INFINITI JX35	2012	HVAC (Heating Ventilation Air-conditioning and Cooling)	Read Fault Code	
INFINITI	INFINITI JX35	2012	HVAC (Heating Ventilation Air-conditioning and Cooling)	Clear Fault Code	

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

<b>make</b>	<b>model</b>	<b>year</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
INFINITI	INFINITI JX35	2012	HVAC (Heating Ventilation Air-conditioning and Cooling)	Read Data Stream	
INFINITI	INFINITI JX35	2012	HVAC (Heating Ventilation Air-conditioning and Cooling)	Module Information	
INFINITI	INFINITI JX35	2012	HVAC (Heating Ventilation Air-conditioning and Cooling)	Actuation Test	ALL SEG
INFINITI	INFINITI JX35	2012	HVAC (Heating Ventilation Air-conditioning and Cooling)	Actuation Test	Hvac Test
INFINITI	INFINITI JX35	2012	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	Rear Temp Set Correct
INFINITI	INFINITI JX35	2012	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	Temp Set Correct
INFINITI	INFINITI JX35	2012	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	REC Memory Set
INFINITI	INFINITI JX35	2012	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	FRE Memory Set
INFINITI	INFINITI JX35	2012	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	Blow Set
INFINITI	INFINITI JX35	2012	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	GAS Sensor Adjustment
INFINITI	INFINITI JX35	2012	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	CLEAN SW SET
INFINITI	INFINITI JX35	2012	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	Target Evaporator Temp Upper Limit Setting
INFINITI	INFINITI JX35	2012	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	Air Inlet Change Setting
INFINITI	INFINITI JX35	2012	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	Air Flow Reduction Setting
INFINITI	INFINITI JX35	2012	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	Target Max RPM ADJ AT IDL
INFINITI	All Mode	2015 - 2018	HVAC (Heating Ventilation Air-conditioning and Cooling)	Read Fault Code	
INFINITI	All Mode	2015 - 2018	HVAC (Heating Ventilation Air-conditioning and Cooling)	Clear Fault Code	
INFINITI	All Mode	2015 - 2018	HVAC (Heating Ventilation Air-conditioning and Cooling)	Read Data Stream	
INFINITI	All Mode	2015 - 2018	HVAC (Heating Ventilation Air-conditioning and Cooling)	Module Information	
INFINITI	All Mode	2015 - 2018	HVAC (Heating Ventilation Air-conditioning and Cooling)	Actuation Test	Check adjustment range of actuator motors
INFINITI	All Mode	2015 - 2018	HVAC (Heating Ventilation Air-conditioning and Cooling)	Actuation Test	Refrigerant compressor magnetic clutch
INFINITI	All Mode	2015 - 2018	HVAC (Heating Ventilation Air-conditioning and Cooling)	Actuation Test	LED of automatic air conditioning cont operating unit
INFINITI	All Mode	2015 - 2018	HVAC (Heating Ventilation Air-conditioning and Cooling)	Actuation Test	Coolant circulation pump
INFINITI	All Mode	2015 - 2018	HVAC (Heating Ventilation Air-conditioning and Cooling)	Actuation Test	Rear Windshield Heater
INFINITI	All Mode	2015 - 2018	HVAC (Heating Ventilation Air-conditioning and Cooling)	Actuation Test	SW and cont illumi of auto air cond cont and operat unit
INFINITI	All Mode	2015 - 2018	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	Teach in of actuator motors
INFINITI	All Mode	2015 - 2018	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	Normalization of actuator motors
INFINITI	All Mode	2015 - 2018	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	Breaking in of refrigerant compressor
INFINITI	All Mode	2015 - 2018	HVAC (Heating Ventilation Air-conditioning and Cooling)	Special Function	Re learning
INFINITI	All Mode	2013 - 2013	SVT	Read Fault Code	
INFINITI	All Mode	2013 - 2013	SVT	Clear Fault Code	
INFINITI	All Mode	2013 - 2013	SVT	Read Data Stream	
INFINITI	All Mode	2013 - 2013	SVT	Module Information	
INFINITI	All Mode	2011 - 2017	BSW (Warning Of Lane Change)	Read Fault Code	
INFINITI	All Mode	2011 - 2017	BSW (Warning Of Lane Change)	Clear Fault Code	
INFINITI	All Mode	2011 - 2017	BSW (Warning Of Lane Change)	Read Data Stream	
INFINITI	All Mode	2011 - 2017	BSW (Warning Of Lane Change)	Module Information	
INFINITI	All Mode	2011 - 2017	BSW (Warning Of Lane Change)	Actuation Test	ICC BUZZER
INFINITI	All Mode	2011 - 2017	BSW (Warning Of Lane Change)	Actuation Test	BSW/BSI Warning Lamp
INFINITI	All Mode	2013 - 2018	BSW (Warning Of Lane Change)	Read Fault Code	
INFINITI	All Mode	2013 - 2018	BSW (Warning Of Lane Change)	Clear Fault Code	
INFINITI	All Mode	2013 - 2018	BSW (Warning Of Lane Change)	Read Data Stream	
INFINITI	All Mode	2013 - 2018	BSW (Warning Of Lane Change)	Module Information	
INFINITI	All Mode	2013 - 2018	BSW (Warning Of Lane Change)	Actuation Test	BUZZER 1 (ADAS)
INFINITI	All Mode	2013 - 2018	BSW (Warning Of Lane Change)	Actuation Test	BUZZER 2 (ADAS)
INFINITI	All Mode	2013 - 2018	BSW (Warning Of Lane Change)	Actuation Test	BUZZER 3 (ADAS)
INFINITI	All Mode	2013 - 2018	BSW (Warning Of Lane Change)	Actuation Test	BUZZER 4 (ADAS)
INFINITI	All Mode	2013 - 2018	BSW (Warning Of Lane Change)	Actuation Test	BUZZER 1 (CCM)
INFINITI	All Mode	2013 - 2018	BSW (Warning Of Lane Change)	Actuation Test	BUZZER 2 (CCM)

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

<b>make</b>	<b>model</b>	<b>year</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
INFINITI	All Mode	2013 - 2018	BSW (Warning Of Lane Change)	Actuation Test	BUZZER 3 (CCM)
INFINITI	All Mode	2013 - 2018	BSW (Warning Of Lane Change)	Actuation Test	BUZZER 4 (CCM)
INFINITI	All Mode	Up to 2018	AVM (Around View Monitor)	Read Fault Code	
INFINITI	All Mode	Up to 2018	AVM (Around View Monitor)	Clear Fault Code	
INFINITI	All Mode	Up to 2018	AVM (Around View Monitor)	Read Data Stream	
INFINITI	All Mode	Up to 2018	AVM (Around View Monitor)	Module Information	
INFINITI	All Mode	Up to 2018	AVM (Around View Monitor)	Actuation Test	LED RH INDICATOR
INFINITI	All Mode	Up to 2018	AVM (Around View Monitor)	Actuation Test	AVM BUZZER
INFINITI	All Mode	Up to 2018	AVM (Around View Monitor)	Actuation Test	LED LH INDICATOR
INFINITI	All Mode	Up to 2018	AVM (Around View Monitor)	Actuation Test	WASH ACTIVE
INFINITI	All Mode	Up to 2018	AVM (Around View Monitor)	Actuation Test	AIR ACTIVE
INFINITI	All Mode	Up to 2018	AVM (Around View Monitor)	Special Function	Calibrating Camera Image(Front Camera)
INFINITI	All Mode	Up to 2018	AVM (Around View Monitor)	Special Function	Calibrating Camera Image(Pass-Side Camera)
INFINITI	All Mode	Up to 2018	AVM (Around View Monitor)	Special Function	Calibrating Camera Image(DR-Side Camera)
INFINITI	All Mode	Up to 2018	AVM (Around View Monitor)	Special Function	Calibrating Camera Image(Rear Camera)
INFINITI	All Mode	Up to 2018	AVM (Around View Monitor)	Special Function	Fine Tuning Of Birds-Eye View
INFINITI	All Mode	Up to 2018	AVM (Around View Monitor)	Special Function	Blow Set
INFINITI	All Mode	Up to 2018	AVM (Around View Monitor)	Special Function	GAS Sensor Adjustment
INFINITI	All Mode	Up to 2018	AVM (Around View Monitor)	Special Function	CLEAN SW SET
INFINITI	All Mode	Up to 2018	AVM (Around View Monitor)	Special Function	Target Evaporator Temp Upper Limit Setting
INFINITI	All Mode	Up to 2018	AVM (Around View Monitor)	Special Function	Air Flow Reduction Setting
INFINITI	All Mode	Up to 2018	AVM (Around View Monitor)	Special Function	Target Max RPM ADJ AT IDL
INFINITI	All Mode	Up to 2018	AVM (Around View Monitor)	Special Function	Non-Viewable Area Reminder
INFINITI	All Mode	Up to 2018	AVM (Around View Monitor)	Special Function	Select Language Of Warning Message
INFINITI	All Mode	Up to 2017	AVM (Around View Monitor)	Read Fault Code	
INFINITI	All Mode	Up to 2017	AVM (Around View Monitor)	Clear Fault Code	
INFINITI	All Mode	Up to 2017	AVM (Around View Monitor)	Read Data Stream	
INFINITI	All Mode	Up to 2017	AVM (Around View Monitor)	Module Information	
INFINITI	All Mode	Up to 2017	AVM (Around View Monitor)	Special Function	Cause Of LDW Cancel
INFINITI	All Mode	Up to 2017	AVM (Around View Monitor)	Special Function	Cause Of BSW Cancel
INFINITI	All Mode	Up to 2017	AVM (Around View Monitor)	Special Function	Cause Of IPA Cancel
INFINITI	All Mode	Up to 2017	AVM (Around View Monitor)	Special Function	Cause Of PSR Cancel
INFINITI	All Mode	Up to 2017	AVM (Around View Monitor)	Special Function	Calibrating Camera Image(Front Camera)
INFINITI	All Mode	Up to 2017	AVM (Around View Monitor)	Special Function	Calibrating Camera Image(Pass-Side Camera)
INFINITI	All Mode	Up to 2017	AVM (Around View Monitor)	Special Function	Calibrating Camera Image(DR-Side Camera)
INFINITI	All Mode	Up to 2017	AVM (Around View Monitor)	Special Function	Calibrating Camera Image(Rear Camera)
INFINITI	All Mode	Up to 2017	AVM (Around View Monitor)	Special Function	Fine Tuning Of Birds-Eye View(Front Camera)
INFINITI	All Mode	Up to 2017	AVM (Around View Monitor)	Special Function	Fine Tuning Of Birds-Eye View(Pass-Side Camera)
INFINITI	All Mode	Up to 2017	AVM (Around View Monitor)	Special Function	Fine Tuning Of Birds-Eye View(DR-Side Camera)
INFINITI	All Mode	Up to 2017	AVM (Around View Monitor)	Special Function	Fine Tuning Of Birds-Eye View(Rear Camera)
INFINITI	All Mode	Up to 2017	AVM (Around View Monitor)	Special Function	Rear Wide-View Fixed Guide Line Correction
INFINITI	All Mode	Up to 2017	AVM (Around View Monitor)	Special Function	Non-Viewable Area Reminder
INFINITI	All Mode	Up to 2017	AVM (Around View Monitor)	Special Function	Select Language Of Warning Message
INFINITI	All Mode	Up to 2017	AVM (Around View Monitor)	Special Function	Predictive Course Line Display
INFINITI	All Mode	Up to 2017	AVM (Around View Monitor)	Special Function	Initialize Camera Image Calibration
INFINITI	All Mode	Up to 2017	AVM (Around View Monitor)	Special Function	Steering Angle Sensor Adjustment
INFINITI	All Mode	Up to 2017	AVM (Around View Monitor)	Special Function	Cause Of Entry Cancel
INFINITI	All Mode	Up to 2017	AVM (Around View Monitor)	Special Function	Mod Function
INFINITI	All Mode	Up to 2017	AVM (Around View Monitor)	Special Function	Parts With Door Mirror Auto Fold Func
INFINITI	All Mode	Up to 2017	AVM (Around View Monitor)	Special Function	Sonar Off Pop-Up Display Setting Change
INFINITI	All Mode	Up to 2017	AVM (Around View Monitor)	Special Function	Rear Camera ITS
INFINITI	All Mode	Up to 2017	AVM (Around View Monitor)	Special Function	Auto Lock Set
INFINITI	All Mode	Up to 2017	AVM (Around View Monitor)	Special Function	IGN/ACC Battery Saver
INFINITI	All Mode	Up to 2017	AVM (Around View Monitor)	Special Function	Short Cranking Output
INFINITI	All Mode	Up to 2017	AVM (Around View Monitor)	Special Function	Answer Back
INFINITI	All Mode	Up to 2017	AVM (Around View Monitor)	Special Function	Answer Back I-Key Lock Unlock

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
INFINITI	All Mode	Up to 2017	AVM (Around View Monitor)	Special Function	Answerback I-Key Lock Unlock
INFINITI	All Mode	Up to 2017	AVM (Around View Monitor)	Special Function	Answerback Keyless Lock Unlock
INFINITI	All Mode	Up to 2017	AVM (Around View Monitor)	Special Function	Welcome Light Op Set
INFINITI	All Mode	Up to 2017	AVM (Around View Monitor)	Special Function	Reset Setting Value
INFINITI	All Mode	Up to 2017	AVM (Around View Monitor)	Special Function	Confirm Dongle ID
INFINITI	All Mode	Up to 2017	AVM (Around View Monitor)	Special Function	Auto Acc Fcnct (Audio/Nav Set After Ign Off)
INFINITI	All Mode	2015 - 2018	AVM (Around View Monitor)	Read Fault Code	
INFINITI	All Mode	2015 - 2018	AVM (Around View Monitor)	Clear Fault Code	
INFINITI	All Mode	2015 - 2018	AVM (Around View Monitor)	Read Data Stream	
INFINITI	All Mode	2015 - 2018	AVM (Around View Monitor)	Module Information	
INFINITI	All Mode	2013 - 2018	Chassis Control	Read Fault Code	
INFINITI	All Mode	2013 - 2018	Chassis Control	Clear Fault Code	
INFINITI	All Mode	2013 - 2018	Chassis Control	Read Data Stream	
INFINITI	All Mode	2013 - 2018	Chassis Control	Module Information	
INFINITI	All Mode	2013 - 2018	Chassis Control	Actuation Test	BRAKE ACTUATOR 1 MODE 1
INFINITI	All Mode	2013 - 2018	Chassis Control	Actuation Test	BRAKE ACTUATOR 1 MODE 2
INFINITI	All Mode	2013 - 2018	Chassis Control	Actuation Test	BRAKE ACTUATOR 1 MODE 3
INFINITI	All Mode	2013 - 2018	Chassis Control	Actuation Test	BRAKE ACTUATOR 2 MODE 1
INFINITI	All Mode	2013 - 2018	Chassis Control	Actuation Test	BRAKE ACTUATOR 2 MODE 2
INFINITI	All Mode	2013 - 2018	Chassis Control	Actuation Test	BRAKE ACTUATOR 2 MODE 3
INFINITI	All Mode	2013 - 2018	Chassis Control	Actuation Test	BRAKE ACTUATOR 3 MODE 1
INFINITI	All Mode	2013 - 2018	Chassis Control	Actuation Test	BRAKE ACTUATOR 3 MODE 2
INFINITI	All Mode	2013 - 2018	Chassis Control	Actuation Test	BRAKE ACTUATOR 3 MODE 3
INFINITI	All Mode	2013 - 2018	Chassis Control	Actuation Test	ESS RELAY ACTIVE
INFINITI	All Mode	2013 - 2018	Chassis Control	Actuation Test	ALC DISP
INFINITI	All Mode	2013 - 2018	Chassis Control	Actuation Test	FR TIRE DISP
INFINITI	All Mode	2013 - 2018	Chassis Control	Actuation Test	RR TIRE DISP
INFINITI	All Mode	2013 - 2018	Chassis Control	Actuation Test	ESS ACTIVE
INFINITI	All Mode	2013 - 2018	Chassis Control	Actuation Test	COMMAND STEERING ANGLE
INFINITI	All Mode	2013 - 2018	Chassis Control	Actuation Test	COMMAND ST WHL FORCE
INFINITI	All Mode	2013 - 2018	Chassis Control	Actuation Test	STOP LAMP OFF RELAY 1 ACTIVE
INFINITI	All Mode	2013 - 2018	Chassis Control	Actuation Test	STOP LAMP OFF RELAY 2 ACTIVE
INFINITI	All Mode	2013 - 2018	Chassis Control	Actuation Test	MASTER WARNING ACTIVE
INFINITI	All Mode	2013 - 2018	Chassis Control	Actuation Test	HDC DISP
INFINITI	All Mode	2013 - 2018	Chassis Control	Actuation Test	BRAKE HOLD DISP
INFINITI	All Mode	2013 - 2018	Chassis Control	Actuation Test	AEB DISP
INFINITI	All Mode	2013 - 2018	Chassis Control	Actuation Test	FL TIRE DISP
INFINITI	All Mode	2013 - 2018	Chassis Control	Actuation Test	RL TIRE DISP
INFINITI	All Mode	2013 - 2018	Chassis Control	Actuation Test	VEHICLE DISP
INFINITI	All Mode	2013 - 2018	Chassis Control	Actuation Test	INTERRUPT DISP
INFINITI	All Mode	2013 - 2018	Chassis Control	Actuation Test	TURN DISP
INFINITI	All Mode	2013 - 2018	Chassis Control	Actuation Test	ALC LEVEL
INFINITI	All Mode	2013 - 2018	Chassis Control	Actuation Test	ALC SETTING
INFINITI	All Mode	2013 - 2018	Chassis Control	Actuation Test	ATC 1 DISP
INFINITI	All Mode	2013 - 2018	Chassis Control	Actuation Test	ATC 2 DISP
INFINITI	All Mode	2013 - 2018	Chassis Control	Actuation Test	ATC 3 DISP
INFINITI	All Mode	2013 - 2018	Chassis Control	Actuation Test	ATC 4 DISP
INFINITI	All Mode	2013 - 2018	Chassis Control	Actuation Test	ATC 5 DISP
INFINITI	All Mode	2013 - 2018	Chassis Control	Actuation Test	ARC DISP
INFINITI	All Mode	2013 - 2018	Chassis Control	Special Function	Erase Last Driver Information
INFINITI	All Mode	2013 - 2018	Chassis Control	Special Function	Erase Key Allotement User
INFINITI	All Mode	2013 - 2018	Chassis Control	Special Function	Erase Personal Setting
INFINITI	All Mode	2013 - 2018	Chassis Control	Special Function	CAUSE OF AUTO-CANCEL 1
INFINITI	All Mode	2015 - 2017	Chassis Control	Read Fault Code	
INFINITI	All Mode	2015 - 2017	Chassis Control	Clear Fault Code	
INFINITI	All Mode	2015 - 2017	Chassis Control	Read Data Stream	
INFINITI	All Mode	2015 - 2017	Chassis Control	Module Information	
INFINITI	All Mode	2015 - 2017	Chassis Control	Special Function	Erase Last Driver Information
INFINITI	All Mode	2015 - 2017	Chassis Control	Special Function	Erase Key Allotement User
INFINITI	All Mode	2015 - 2017	Chassis Control	Special Function	Erase Personal Setting
INFINITI	All Mode	2015 - 2017	Chassis Control	Special Function	CAUSE OF AUTO-CANCEL 1
INFINITI	All Mode	2015 - 2017	Chassis Control	Read Fault Code	
INFINITI	All Mode	2015 - 2017	Chassis Control	Clear Fault Code	
INFINITI	All Mode	2015 - 2017	Chassis Control	Read Data Stream	
INFINITI	All Mode	2015 - 2017	Chassis Control	Module Information	
INFINITI	All Mode	2015 - 2017	Chassis Control	Special Function	Erase Last Driver Information
INFINITI	All Mode	2015 - 2017	Chassis Control	Special Function	Erase Key Allotement User
INFINITI	All Mode	2015 - 2017	Chassis Control	Special Function	Erase Personal Setting
INFINITI	All Mode	2015 - 2017	Chassis Control	Special Function	CAUSE OF AUTO-CANCEL 1
INFINITI	All Mode	2014 - 2018	Chassis Control	Read Fault Code	
INFINITI	All Mode	2014 - 2018	Chassis Control	Clear Fault Code	

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
INFINITI	All Mode	2014 - 2018	Chassis Control	Read Data Stream	
INFINITI	All Mode	2014 - 2018	Chassis Control	Module Information	
INFINITI	All Mode	2014 - 2018	Chassis Control	Special Function	Erase Last Driver Information
INFINITI	All Mode	2014 - 2018	Chassis Control	Special Function	Erase Key Allotement User
INFINITI	All Mode	2014 - 2018	Chassis Control	Special Function	Erase Personal Setting
INFINITI	All Mode	2014 - 2018	Chassis Control	Special Function	CAUSE OF AUTO-CANCEL 1
INFINITI	All Mode	2015 - 2017	Chassis Control	Read Fault Code	
INFINITI	All Mode	2015 - 2017	Chassis Control	Clear Fault Code	
INFINITI	All Mode	2015 - 2017	Chassis Control	Read Data Stream	
INFINITI	All Mode	2015 - 2017	Chassis Control	Module Information	
INFINITI	All Mode	2015 - 2017	Chassis Control	Special Function	Erase Last Driver Information
INFINITI	All Mode	2015 - 2017	Chassis Control	Special Function	Erase Key Allotement User
INFINITI	All Mode	2015 - 2017	Chassis Control	Special Function	Erase Personal Setting
INFINITI	All Mode	2015 - 2017	Chassis Control	Special Function	CAUSE OF AUTO-CANCEL 1
INFINITI	All Mode	2015 - 2018	Chassis Control	Read Fault Code	
INFINITI	All Mode	2015 - 2018	Chassis Control	Clear Fault Code	
INFINITI	All Mode	2015 - 2018	Chassis Control	Read Data Stream	
INFINITI	All Mode	2015 - 2018	Chassis Control	Module Information	
INFINITI	All Mode	2015 - 2018	Chassis Control	Special Function	Erase Last Driver Information
INFINITI	All Mode	2015 - 2018	Chassis Control	Special Function	Erase Key Allotement User
INFINITI	All Mode	2015 - 2018	Chassis Control	Special Function	Erase Personal Setting
INFINITI	All Mode	2015 - 2018	Chassis Control	Special Function	CAUSE OF AUTO-CANCEL 1
INFINITI	All Mode	2015 - 2017	Chassis Control	Read Fault Code	
INFINITI	All Mode	2015 - 2017	Chassis Control	Clear Fault Code	
INFINITI	All Mode	2015 - 2017	Chassis Control	Read Data Stream	
INFINITI	All Mode	2015 - 2017	Chassis Control	Module Information	
INFINITI	All Mode	2015 - 2017	Chassis Control	Special Function	Erase Last Driver Information
INFINITI	All Mode	2015 - 2017	Chassis Control	Special Function	Erase Key Allotement User
INFINITI	All Mode	2015 - 2017	Chassis Control	Special Function	Erase Personal Setting
INFINITI	All Mode	2015 - 2017	Chassis Control	Special Function	CAUSE OF AUTO-CANCEL 1
INFINITI	All Mode	2013 - 2018	DAST 1	Read Fault Code	
INFINITI	All Mode	2013 - 2018	DAST 1	Clear Fault Code	
INFINITI	All Mode	2013 - 2018	DAST 1	Read Data Stream	
INFINITI	All Mode	2013 - 2018	DAST 1	Module Information	
INFINITI	All Mode	2013 - 2018	DAST 2	Read Fault Code	
INFINITI	All Mode	2013 - 2018	DAST 2	Clear Fault Code	
INFINITI	All Mode	2013 - 2018	DAST 2	Read Data Stream	
INFINITI	All Mode	2013 - 2018	DAST 2	Module Information	
INFINITI	All Mode	2013 - 2018	High Beam Assist	Read Fault Code	
INFINITI	All Mode	2013 - 2018	High Beam Assist	Clear Fault Code	
INFINITI	All Mode	2013 - 2018	High Beam Assist	Read Data Stream	
INFINITI	All Mode	2013 - 2018	High Beam Assist	Module Information	
INFINITI	All Mode	Up to 2016	TCM (Transmission Control Module)	Read Fault Code	
INFINITI	All Mode	Up to 2016	TCM (Transmission Control Module)	Clear Fault Code	
INFINITI	All Mode	Up to 2016	TCM (Transmission Control Module)	Read Data Stream	
INFINITI	All Mode	Up to 2016	TCM (Transmission Control Module)	Module Information	
INFINITI	All Mode	Up to 2016	TCM (Transmission Control Module)	Function Test	
INFINITI	All Mode	Up to 2016	TCM (Transmission Control Module)	Special Function	Engine Brake ADJ
INFINITI	All Mode	Up to 2016	TCM (Transmission Control Module)	Special Function	Conform CVTF Deteriortn
INFINITI	All Mode	Up to 2016	TCM (Transmission Control Module)	Special Function	ECO Mode Reset Function
INFINITI	All Mode	Up to 2016	TCM (Transmission Control Module)	Special Function	G Sensor Calibration
INFINITI	All Mode	Up to 2016	TCM (Transmission Control Module)	Special Function	Electric O. P. Air Bleeding
INFINITI	All Mode	Up to 2016	TCM (Transmission Control Module)	Special Function	Calib Data
INFINITI	All Mode	Up to 2016	TCM (Transmission Control Module)	Read Fault Code	
INFINITI	All Mode	Up to 2016	TCM (Transmission Control Module)	Clear Fault Code	
INFINITI	All Mode	Up to 2016	TCM (Transmission Control Module)	Read Data Stream	
INFINITI	All Mode	Up to 2016	TCM (Transmission Control Module)	Module Information	
INFINITI	All Mode	Up to 2016	TCM (Transmission Control Module)	Function Test	
INFINITI	All Mode	Up to 2016	TCM (Transmission Control Module)	Special Function	Engine Brake ADJ
INFINITI	All Mode	Up to 2016	TCM (Transmission Control Module)	Special Function	Conform CVTF Deteriortn
INFINITI	All Mode	Up to 2016	TCM (Transmission Control Module)	Special Function	ECO Mode Reset Function
INFINITI	All Mode	Up to 2016	TCM (Transmission Control Module)	Special Function	Calib Data
INFINITI	All Mode	Up to 2008	TCM (Transmission Control Module)	Read Fault Code	
INFINITI	All Mode	Up to 2008	TCM (Transmission Control Module)	Clear Fault Code	
INFINITI	All Mode	Up to 2008	TCM (Transmission Control Module)	Read Data Stream	
INFINITI	All Mode	Up to 2008	TCM (Transmission Control Module)	Module Information	
INFINITI	All Mode	Up to 2008	TCM (Transmission Control Module)	Function Test	
INFINITI	All Mode	Up to 2008	TCM (Transmission Control Module)	Actuation Test	CLUTCH OPERATION TEST
INFINITI	All Mode	Up to 2008	TCM (Transmission Control Module)	Actuation Test	GEAR ENGAGE TEST
INFINITI	All Mode	Up to 2008	TCM (Transmission Control Module)	Special Function	MAX. CLTCH STRK MSRMNT
INFINITI	All Mode	Up to 2008	TCM (Transmission Control Module)	Special Function	Cltch Touchpoint Adjst
INFINITI	All Mode	Up to 2008	TCM (Transmission Control Module)	Special Function	TM ACTR SELF ADJST
INFINITI	All Mode	2008 - 2018	TCM (Transmission Control Module)	Read Fault Code	
INFINITI	All Mode	2008 - 2018	TCM (Transmission Control Module)	Clear Fault Code	
INFINITI	All Mode	2008 - 2018	TCM (Transmission Control Module)	Read Data Stream	
INFINITI	All Mode	2008 - 2018	TCM (Transmission Control Module)	Read Freeze Frame	



**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
INFINITI	All Mode	2008 - 2018	TCM (Transmission Control Module)	Module Information	
INFINITI	All Mode	2008 - 2018	TCM (Transmission Control Module)	Function Test	
INFINITI	All Mode	2008 - 2018	TCM (Transmission Control Module)	Special Function	G Sensor Calibration
INFINITI	All Mode	2008 - 2018	TCM (Transmission Control Module)	Special Function	Calib Data
INFINITI	All Mode	2014 - 2016	TCM (Transmission Control Module)	Read Fault Code	
INFINITI	All Mode	2014 - 2016	TCM (Transmission Control Module)	Clear Fault Code	
INFINITI	All Mode	2014 - 2016	TCM (Transmission Control Module)	Read Data Stream	
INFINITI	All Mode	2014 - 2016	TCM (Transmission Control Module)	Read Freeze Frame	
INFINITI	All Mode	2014 - 2016	TCM (Transmission Control Module)	Module Information	
INFINITI	All Mode	2014 - 2016	TCM (Transmission Control Module)	Function Test	
INFINITI	All Mode	2014 - 2016	TCM (Transmission Control Module)	Special Function	Engine Brake ADJ
INFINITI	All Mode	2014 - 2016	TCM (Transmission Control Module)	Special Function	Conform CVTF Deteriortrtn
INFINITI	All Mode	2014 - 2016	TCM (Transmission Control Module)	Special Function	ECO Mode Reset Function
INFINITI	All Mode	2014 - 2016	TCM (Transmission Control Module)	Special Function	G Sensor Calibration
INFINITI	All Mode	2014 - 2016	TCM (Transmission Control Module)	Special Function	Erase Calibration Data
INFINITI	All Mode	2014 - 2016	TCM (Transmission Control Module)	Special Function	Erase Learning Value
INFINITI	All Mode	2014 - 2016	TCM (Transmission Control Module)	Special Function	Erase Memory Data
INFINITI	All Mode	2014 - 2016	TCM (Transmission Control Module)	Special Function	Clutch Point Learning
INFINITI	All Mode	2014 - 2016	TCM (Transmission Control Module)	Special Function	Electric O. P. Air Bleeding
INFINITI	All Mode	2014 - 2016	TCM (Transmission Control Module)	Special Function	Auxiliary gearbox clutch point learning
INFINITI	All Mode	2014 - 2016	TCM (Transmission Control Module)	Special Function	Calib Data
INFINITI	INFINITI JX35	2012	TCM (Transmission Control Module)	Read Fault Code	
INFINITI	INFINITI JX35	2012	TCM (Transmission Control Module)	Clear Fault Code	
INFINITI	INFINITI JX35	2012	TCM (Transmission Control Module)	Read Data Stream	
INFINITI	INFINITI JX35	2012	TCM (Transmission Control Module)	Module Information	
INFINITI	INFINITI JX35	2012	TCM (Transmission Control Module)	Special Function	Erase Calibration Data
INFINITI	INFINITI JX35	2012	TCM (Transmission Control Module)	Special Function	Erase Learning Value
INFINITI	INFINITI JX35	2012	TCM (Transmission Control Module)	Special Function	Erase Memory Data
INFINITI	INFINITI JX35	2012	TCM (Transmission Control Module)	Special Function	Calib Data
INFINITI	All Mode	Up to 2008	TCM (Transmission Control Module)	Read Fault Code	
INFINITI	All Mode	Up to 2008	TCM (Transmission Control Module)	Clear Fault Code	
INFINITI	All Mode	Up to 2008	TCM (Transmission Control Module)	Read Data Stream	
INFINITI	All Mode	Up to 2008	TCM (Transmission Control Module)	Module Information	
INFINITI	All Mode	Up to 2008	TCM (Transmission Control Module)	Function Test	
INFINITI	All Mode	Up to 2008	TCM (Transmission Control Module)	Special Function	Engine Brake ADJ
INFINITI	All Mode	Up to 2008	TCM (Transmission Control Module)	Special Function	Conform CVTF Deteriortrtn
INFINITI	All Mode	Up to 2008	TCM (Transmission Control Module)	Special Function	Calib Data
INFINITI	All Mode	Up to 2008	TCM (Transmission Control Module)	Read Fault Code	
INFINITI	All Mode	Up to 2008	TCM (Transmission Control Module)	Clear Fault Code	
INFINITI	All Mode	Up to 2008	TCM (Transmission Control Module)	Read Data Stream	
INFINITI	All Mode	Up to 2008	TCM (Transmission Control Module)	Read Freeze Frame	
INFINITI	All Mode	Up to 2008	TCM (Transmission Control Module)	Module Information	
INFINITI	All Mode	Up to 2008	TCM (Transmission Control Module)	Function Test	
INFINITI	All Mode	Up to 2008	TCM (Transmission Control Module)	Special Function	Initialization
INFINITI	All Mode	2012 - 2017	TCM (Transmission Control Module)	Read Fault Code	
INFINITI	All Mode	2012 - 2017	TCM (Transmission Control Module)	Clear Fault Code	
INFINITI	All Mode	2012 - 2017	TCM (Transmission Control Module)	Read Data Stream	
INFINITI	All Mode	2012 - 2017	TCM (Transmission Control Module)	Module Information	
INFINITI	All Mode	2012 - 2017	TCM (Transmission Control Module)	Actuation Test	CVT Oil Cooler Fan Circuit
INFINITI	All Mode	2012 - 2017	TCM (Transmission Control Module)	Special Function	Conform CVTF Deteriortrtn
INFINITI	All Mode	2012 - 2017	TCM (Transmission Control Module)	Special Function	G Sensor Calibration
INFINITI	All Mode	2012 - 2017	TCM (Transmission Control Module)	Special Function	Erase Learning Value
INFINITI	All Mode	2012 - 2017	TCM (Transmission Control Module)	Special Function	Engine Brake ADJ
INFINITI	All Mode	2012 - 2017	TCM (Transmission Control Module)	Special Function	FWD Clutch Point Learning
INFINITI	All Mode	2012 - 2017	TCM (Transmission Control Module)	Special Function	Clutch Point
INFINITI	All Mode	2012 - 2017	TCM (Transmission Control Module)	Special Function	Read IP Chara-Replacement TCM
INFINITI	All Mode	2012 - 2017	TCM (Transmission Control Module)	Special Function	Write IP Chara-Replacement TCM
INFINITI	All Mode	2012 - 2017	TCM (Transmission Control Module)	Special Function	Electric O. P. Air Bleeding
INFINITI	All Mode	2012 - 2017	TCM (Transmission Control Module)	Special Function	Erase Calibration Data
INFINITI	All Mode	2012 - 2017	TCM (Transmission Control Module)	Special Function	Erase Memory Data
INFINITI	All Mode	2012 - 2017	TCM (Transmission Control Module)	Special Function	CVT Inspection
INFINITI	All Mode	2012 - 2017	TCM (Transmission Control Module)	Special Function	Calib Data
INFINITI	All Mode	2013 - 2018	TCM (Transmission Control Module)	Read Fault Code	
INFINITI	All Mode	2013 - 2018	TCM (Transmission Control Module)	Clear Fault Code	
INFINITI	All Mode	2013 - 2018	TCM (Transmission Control Module)	Read Data Stream	
INFINITI	All Mode	2013 - 2018	TCM (Transmission Control Module)	Module Information	
INFINITI	All Mode	2013 - 2018	TCM (Transmission Control Module)	Special Function	Resetting Of Adaption Values
INFINITI	All Mode	2013 - 2018	TCM (Transmission Control Module)	Special Function	Reverse Gear Reset Of Adaption Values
INFINITI	All Mode	2013 - 2018	TCM (Transmission Control Module)	Special Function	TEACH IN OF SELECTION RANGE SENSOR
INFINITI	All Mode	2013 - 2018	TCM (Transmission Control Module)	Special Function	Adaption Values Of Shift Operations
INFINITI	All Mode	2013 - 2018	TCM (Transmission Control Module)	Special Function	Acceleration Downshift
INFINITI	All Mode	2013 - 2018	TCM (Transmission Control Module)	Special Function	Upshift
INFINITI	All Mode	2013 - 2018	TCM (Transmission Control Module)	Special Function	DOWNSHIFT



**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

make	model	year	system	function	subfunction
INFINITI	All Mode	Up to 2008	TCM (Transmission Control Module)	Clear Fault Code	
INFINITI	All Mode	Up to 2008	TCM (Transmission Control Module)	Read Data Stream	
INFINITI	All Mode	Up to 2008	TCM (Transmission Control Module)	Module Information	
INFINITI	All Mode	Up to 2008	TCM (Transmission Control Module)	Read Fault Code	
INFINITI	All Mode	Up to 2008	TCM (Transmission Control Module)	Clear Fault Code	
INFINITI	All Mode	Up to 2008	TCM (Transmission Control Module)	Read Data Stream	
INFINITI	All Mode	Up to 2008	TCM (Transmission Control Module)	Module Information	
INFINITI	All Mode	Up to 2008	TCM (Transmission Control Module)	Special Function	ENGINE BRAKE ADJ.
INFINITI	All Mode	Up to 2008	TCM (Transmission Control Module)	Read Fault Code	
INFINITI	All Mode	Up to 2008	TCM (Transmission Control Module)	Clear Fault Code	
INFINITI	All Mode	Up to 2008	TCM (Transmission Control Module)	Read Data Stream	
INFINITI	All Mode	Up to 2008	TCM (Transmission Control Module)	Module Information	
INFINITI	All Mode	Up to 2008	TCM (Transmission Control Module)	Read Fault Code	
INFINITI	All Mode	Up to 2008	TCM (Transmission Control Module)	Clear Fault Code	
INFINITI	All Mode	Up to 2008	TCM (Transmission Control Module)	Read Data Stream	
INFINITI	All Mode	Up to 2008	TCM (Transmission Control Module)	Module Information	
INFINITI	All Mode	Up to 2008	TCM (Transmission Control Module)	Special Function	ENGINE BRAKE ADJ.
INFINITI	All Mode	Up to 2008	TCM (Transmission Control Module)	Read Fault Code	
INFINITI	All Mode	Up to 2008	TCM (Transmission Control Module)	Clear Fault Code	
INFINITI	All Mode	Up to 2008	TCM (Transmission Control Module)	Read Data Stream	
INFINITI	All Mode	Up to 2008	TCM (Transmission Control Module)	Module Information	
INFINITI	All Mode	2016 - 2017	Intelligent Cruise Control (ICC)/Automatic Data Acquisition System (ADAS) 2	Read Fault Code	
INFINITI	All Mode	2016 - 2017	Intelligent Cruise Control (ICC)/Automatic Data Acquisition System (ADAS) 2	Clear Fault Code	
INFINITI	All Mode	2016 - 2017	Intelligent Cruise Control (ICC)/Automatic Data Acquisition System (ADAS) 2	Read Data Stream	
INFINITI	All Mode	2016 - 2017	Intelligent Cruise Control (ICC)/Automatic Data Acquisition System (ADAS) 2	Module Information	
INFINITI	All Mode	2016 - 2017	Intelligent Cruise Control (ICC)/Automatic Data Acquisition System (ADAS) 2	Special Function	CAUSE OF AUTO-CANCEL 2
INFINITI	INFINITI Q60	2016	Lane camera 2	Read Fault Code	
INFINITI	INFINITI Q60	2016	Lane camera 2	Clear Fault Code	
INFINITI	INFINITI Q60	2016	Lane camera 2	Read Data Stream	
INFINITI	INFINITI Q60	2016	Lane camera 2	Module Information	
INFINITI	*INFINITI EX35 Camp:P8202	2008	SRS (Supplemental Inflatable Restraint System)	Read Fault Code	
INFINITI	*INFINITI EX35 Camp:P8202	2008	SRS (Supplemental Inflatable Restraint System)	Clear Fault Code	
INFINITI	*INFINITI EX35 Camp:P8202	2008	SRS (Supplemental Inflatable Restraint System)	Read Data Stream	
INFINITI	*INFINITI EX35 Camp:P8202	2008	SRS (Supplemental Inflatable Restraint System)	Module Information	
INFINITI	All Mode	2014 - 2016	Engine	Read Fault Code	
INFINITI	All Mode	2014 - 2016	Engine	Clear Fault Code	
INFINITI	All Mode	2014 - 2016	Engine	Read Data Stream	
INFINITI	All Mode	2014 - 2016	Engine	Module Information	
INFINITI	All Mode	2014 - 2016	Engine	Special Function	INJ ADJ VAL REGIST
INFINITI	All Mode	2014 - 2016	Engine	Special Function	P062F EXCLUSIVE FUNCTION
INFINITI	All Mode	2014 - 2016	Engine	Special Function	LEARNING
INFINITI	All Mode	2014 - 2016	Engine	Special Function	EGR/V LEARN CLR
INFINITI	All Mode	2014 - 2016	Engine	Special Function	ZFC VALUE RESET
INFINITI	All Mode	2014 - 2016	Engine	Special Function	DPF Data Clear
INFINITI	All Mode	2014 - 2016	Engine	Special Function	Service Regeneration
INFINITI	All Mode	2013 - 2016	Multi AV	Read Fault Code	
INFINITI	All Mode	2013 - 2016	Multi AV	Clear Fault Code	
INFINITI	All Mode	2013 - 2016	Multi AV	Read Data Stream	
INFINITI	All Mode	2013 - 2016	Multi AV	Module Information	
INFINITI	All Mode	2013 - 2016	Multi AV	Special Function	SELF-DIAG[ETC]
INFINITI	All Mode	Up to 2012	TCM (Transmission Control Module)	Read Fault Code	
INFINITI	All Mode	Up to 2012	TCM (Transmission Control Module)	Clear Fault Code	
INFINITI	All Mode	Up to 2012	TCM (Transmission Control Module)	Read Data Stream	
INFINITI	All Mode	Up to 2012	TCM (Transmission Control Module)	Read Fault Code	
INFINITI	All Mode	Up to 2012	TCM (Transmission Control Module)	Clear Fault Code	
INFINITI	All Mode	Up to 2012	TCM (Transmission Control Module)	Read Data Stream	
INFINITI	All Mode	Up to 2017	TCM (Transmission Control Module)	Read Fault Code	
INFINITI	All Mode	Up to 2017	TCM (Transmission Control Module)	Clear Fault Code	
INFINITI	All Mode	Up to 2017	TCM (Transmission Control Module)	Read Data Stream	
INFINITI	All Mode	Up to 2017	TCM (Transmission Control Module)	Actuation Test	SHIFT S/V 1
INFINITI	All Mode	Up to 2017	TCM (Transmission Control Module)	Actuation Test	SHIFT S/V 2
INFINITI	All Mode	Up to 2017	TCM (Transmission Control Module)	Actuation Test	SHIFT S/V 3
INFINITI	All Mode	Up to 2017	TCM (Transmission Control Module)	Actuation Test	SHIFT S/V 4
INFINITI	All Mode	Up to 2017	TCM (Transmission Control Module)	Actuation Test	SEQUENCE S/V
INFINITI	All Mode	Up to 2017	TCM (Transmission Control Module)	Actuation Test	LINE PRESS S/V
INFINITI	All Mode	Up to 2017	TCM (Transmission Control Module)	Actuation Test	C/L B PRESS S/V
INFINITI	All Mode	Up to 2017	TCM (Transmission Control Module)	Actuation Test	C/L A PRESS S/V
INFINITI	All Mode	Up to 2017	TCM (Transmission Control Module)	Actuation Test	LUBRICATION FLOW-RATE S/V
INFINITI	All Mode	Up to 2017	TCM (Transmission Control Module)	Actuation Test	A-AXIS SUPPLY PRESSURE S/V
INFINITI	All Mode	Up to 2017	TCM (Transmission Control Module)	Actuation Test	B-AXIS SUPPLY PRESSURE S/V
INFINITI	All Mode	Up to 2017	TCM (Transmission Control Module)	Actuation Test	STARTER RELAY
INFINITI	All Mode	Up to 2017	TCM (Transmission Control Module)	Actuation Test	REVERSE LAMP RELAY
INFINITI	All Mode	Up to 2017	TCM (Transmission Control Module)	Actuation Test	TCM RELAY
INFINITI	All Mode	Up to 2017	TCM (Transmission Control Module)	Actuation Test	SHIFT LOCK SOL
INFINITI	All Mode	Up to 2017	TCM (Transmission Control Module)	Special Function	Clutch Gear Learning

**NISSAN/DFNISSAN/INFINITI Diagnostics List**  
(Note:For reference only)

<b>make</b>	<b>model</b>	<b>year</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
INFINITI	All Mode	Up to 2017	TCM (Transmission Control Module)	Special Function	Disengaging The Gear
INFINITI	All Mode	Up to 2017	TCM (Transmission Control Module)	Special Function	Gear Position Test
INFINITI	All Mode	Up to 2017	TCM (Transmission Control Module)	Special Function	Read Clutch Gear Learning Data
INFINITI	All Mode	Up to 2017	TCM (Transmission Control Module)	Special Function	Show Oil Temp History
INFINITI	All Mode	Up to 2017	TCM (Transmission Control Module)	Special Function	High Oil Temp Warning History
INFINITI	All Mode	Up to 2017	TCM (Transmission Control Module)	Special Function	Delete Gear Position Learning Value
INFINITI	All Mode	Up to 2017	TCM (Transmission Control Module)	Special Function	Delete Clutch A Learning Value
INFINITI	All Mode	Up to 2017	TCM (Transmission Control Module)	Special Function	Delete Clutch B Learning Value
INFINITI	All Mode	Up to 2017	TCM (Transmission Control Module)	Special Function	Write Previous Clutch Learning Value
INFINITI	All Mode	Up to 2017	TCM (Transmission Control Module)	Special Function	Erase Cltch Enggmt Prsr Crctn
INFINITI	All Mode	Up to 2017	TCM (Transmission Control Module)	Special Function	OIL Temp History Reset
INFINITI	All Mode	Up to 2017	TCM (Transmission Control Module)	Special Function	Adjust Clutch A Capacity
INFINITI	All Mode	Up to 2017	TCM (Transmission Control Module)	Special Function	Adjust Clutch B Capacity
INFINITI	All Mode	Up to 2017	TCM (Transmission Control Module)	Special Function	Clutch A Touch Point
INFINITI	All Mode	Up to 2017	TCM (Transmission Control Module)	Special Function	Clutch B Touch Point