


Fiat 500 (2010 – 2014) fuse box diagram


Fuse box in dashboard



Fiat 500 – fuse box – dashboard

Fuse	Fuse	Ampere rating [A]
Supply of right low beam	F12	7,5
Supply of left low beam and headlamp direction adjustment control unit	F13	7,5
Lights of front and rear ceiling lights, trunk and door courtesy lights	F32	7,5
Diagnostic socket, car radio, climate control system, EOBD	F36	10
Stop lights switch, instrument panel node	F37	5
Door central locking	F38	20
Windshield/Rear windshield washer pump	F43	15
Driver side power window	F47	20
Passenger side power window	F48	20
Parking sensor, backlighting switches, electric mirrors	F49	5
Car radio switch, convergence, climate control system, stop lights, clutch	F51	7,5
Instrument panel node	F53	5

Fuse box in engine compartment



Fiat 500 – bezpieczniki – komora silnika

Description	Fuse	Ampere rating [A]
Climate control system fan	F08	30
Trailer	F09	15
Buzzers	F10	15
Engine control system (secondary loads)	F11	10
Main headlights	F14	15
Sunroof motor	F15	20
Heated rear window, mirror demisters	F20	30
Fog headlights	F30	15
Front socket (with or without cigar lighter plug)	F85	15

Article about Fiat 500 (2007 – 2010) include description every fuses and relays from diagram. If you looking it, you can check it here.